



MODULAR REFERENCE DESIGN PLATFORM



January 2008

SONET Aggregation and T/E Carrier Applications Group

© 2007 Exar Corporation

XRUM00001

TABLE OF CONTENTS

1.0 INTRODUCTION TO ORION..... 4

1.1 ORION MODULAR REFERENCE DESIGN PLATFORM FEATURES 5

2.0 THE ORION PLATFORM 6

2.1 THE MODULAR HIGH DENSITY BACKPLANE..... 6

2.2 FPGA BASED USB 2.0 GUI ENABLED SOFTWARE COMMON CONTROL CARD 7

2.3 MODULAR LINE CARD ACCESS SLOT 7

3.0 THE XRT86SH328/221 TRIPLE VOYAGER REFERENCE DESIGN PLATFORM 8

3.1 MASTER VS SLAVE MODE..... 8

3.2 THE XRT86SH328/221 TRIPLE VOYAGER LINE CARD..... 9

3.3 THE XRT86SH328/221 TRIPLE VOYAGER T1/E1/J1 MAGNETICS LINE CARD..... 9

3.4 EXAR POWERBLOXTM POWER MANAGEMENT SOLUTION REFERENCE DESIGN..... 10

4.0 THE XRT86SH221 TRIPLE VOYAGER LITE GRAPHICAL USER INTERFACE 11

4.1 XRT86SH221 TRIPLE VOYAGER LITE GUI SETUP AND INSTALLATION 11

 4.1.1 MANUALLY LOADING EXAR DRIVERS (IF INSTALLATION IS NOT SUCCESSFUL)..... 14

4.2 STARTING THE XRT86SH221 TRIPLE VOYAGER LITE GUI..... 16

4.3 USING THE EVALUATION SOFTWARE 20

4.3.1 OPERATION CONTROL BLOCK..... 21

 4.3.1.1 SDH OPERATIONS..... 21

 4.3.1.2 TELECOM BUS CONTROL 23

4.3.2 RECEIVE SDH OVERHEAD 24

 4.3.2.1 RECEIVE REGENERATOR AND MULTIPLEX SECTION OVERHEAD (RECEIVE TOH) 24

 4.3.2.2 RECEIVE HIGH-ORDER PATH OVERHEAD (RECEIVE POH) 25

4.3.3 RECEIVE REGENERATOR AND MULTIPLEX SECTION PERFORMANCE MONITORS..... 25

4.3.4 RECEIVE HIGH-ORDER PATH PERFORMANCE MONITORS..... 26

4.3.5 E1 FRAMER GENERAL CONFIGURATION 26

 4.3.5.1 E1 FRAMER CONTROL..... 26

 4.3.5.2 E1 INTERRUPT ENABLE..... 27

4.3.6 TRANSMIT SDH OVERHEAD 28

 4.3.6.1 TRANSMIT REGENERATOR AND MULTIPLEX SECTION OVERHEAD 28

 4.3.6.2 TRANSMIT HIGH-ORDER PATH OVERHEAD..... 29

4.3.7 VT MAPPER 30

 4.3.7.1 GLOBAL VT MAPPER CONTROL 30

 4.3.7.2 CHANNELIZED VT MAPPER CONTROL..... 30

 4.3.7.3 VT MAPPER PERFORMANCE MONITORS 31

4.3.8 E1 LINE INTERFACE UNIT CONFIGURATION AND CONTROL 31

4.3.9 REGISTER READ/WRITE ACCESS..... 32

5.0 THE XRT86SH328 TRIPLE VOYAGER GRAPHICAL USER INTERFACE..... 33

5.1 XRT86SH328 TRIPLE VOYAGER GUI SETUP AND INSTALLATION 33

 5.1.1 MANUALLY LOADING EXAR DRIVERS (IF INSTALLATION IS NOT SUCCESSFUL)..... 37

6.0 STARTING THE XRT86SH328 TRIPLE VOYAGER GUI 39

6.0.1 MAIN EVALUATION MENU..... 40

6.0.2 RECEIVE SONET TRANSPORT OVERHEAD /SDH REGENERATOR AND MULTIPLEX SECTION CONFIGURATION 41

6.0.2.1 RECEIVE SONET TRANSPORT OVERHEAD /SDH REGENERATOR AND MULTIPLEX SECTION PERFORMANCE MONITORING ALARMS..... 41

6.0.3 RECEIVE SONET PATH OVERHEAD /SDH HIGH-ORDER PATH CONFIGURATION..... 42

 6.0.3.1 RECEIVE SONET PATH OVERHEAD /SDH HIGH-ORDER PATH PERFORMANCE MONITORING ALARMS 42

6.0.4 RECEIVE VALIDATED SONET (J0) SECTION AND (J1) PATH AND (J2) VT-PATH TRACE BUFFER /SDH (J0) REGENERATOR SECTION AND (J1) HIGH-ORDER PATH AND (J2) LOW-ORDER PATH TRACE MESSAGE BUFFER .. 43

6.0.5 RECEIVE EXPECTED SONET (J0) SECTION AND (J1) PATH AND (J2) VT-PATH TRACE BUFFER /SDH (J0) REGENERATOR SECTION AND (J1) HIGH-ORDER PATH AND (J2) LOW-ORDER PATH TRACE MESSAGE BUFFER .. 43

6.0.6 VT MAPPER CONFIGURATION..... 44

 6.0.6.1 VT MAPPER ALARMS..... 44

6.0.7 T1 EGRESS CONFIGURATION 45

 6.0.7.1 T1 EGRESS ALARMS 45

6.0.8 LINE INTERFACE UNIT CONFIGURATION 46

 6.0.8.1 LINE INTERFACE UNIT PERFORMANCE MONITORING ALARMS..... 46

6.0.9 TRANSMIT SONET TRANSPORT OVERHEAD CONFIGURATION..... 47

6.0.10 TRANSMIT SONET PATH OVERHEAD CONFIGURATION 47

6.0.11 TRANSMIT SONET (J0) SECTION AND (J1) PATH AND (J2) VT-PATH TRACE BUFFER /SDH (J0) REGENERATOR SECTION AND (J1) HIGH-ORDER PATH AND (J2) LOW-ORDER PATH TRACE MESSAGE BUFFER 48



| | |
|--|----|
| 6.0.12 T1 INGRESS CONFIGURATION | 48 |
| 6.0.12.1 T1 INGRESS ALARMS..... | 49 |
| 7.0 PYTHON SCRIPT INTERFACE..... | 50 |
| 8.0 XRT86SH221 E1 TEST HEADERS H3 AND H4 | 52 |
| 9.0 XRT86SH328 T1/J1 TEST HEADERS H3 AND H4 | 55 |
| 10.0 EXAR POWERBLOX™ POWER SUPPLY REFERENCE DESIGN SCHEMATIC DIAGRAM | 61 |
| 11.0 TRIPLE VOYAGER LITE XRT86SH221 REFERENCE DESIGN 1 SCHEMATIC DIAGRAM | 62 |
| 12.0 TRIPLE VOYAGER XRT86SH328 REFERENCE DESIGN 2 SCHEMATIC DIAGRAM | 67 |

1.0 INTRODUCTION TO ORION



The Orion Modular Reference Design Platform serves to demonstrate Exar's broadband product portfolio solutions and capabilities in Metropolitan Access Networks. The Orion MRDP can showcase viable solutions within the capabilities of Exar's product devices in a multitude of network service applications.



Orion Platform Target Deployment Applications:

- Add Drop Multiplexer (ADM) Devices
- Digital Loop Carriers (DLC)
- Digital Subscriber Line Access Multiplexer (DSLAM)
- SONET/SDH based transmission systems
- SONET/SDH based modules
- Plesiochronous/PDH Networks
- Broadband Cross Connect Systems
- Dense Wave Division Multiplexer Termination Equipment
- Multi-Service Switches and Routers
- Multi-Service Provisioning Platforms
- Wireless Broadband Network Base Stations



1.1 ORION Modular Reference Design Platform Features

The following features are supported on the Orion MRD Platform.

- **Self-Contained Stand Alone Unit**
- **USB 2.0 Compliant GUI Enabled Software Programmable Control**
- **Service Oriented Modular Line Card Flexibility**

This self-contained module may be used as an evaluation and demonstration tool. The GUI Application through the USB interface on a Host Personal Computer can be used to provision and control the use of Exar's product device to showcase its application's scalability, flexibility, and unique capabilities.

2.0 THE ORION PLATFORM

The Orion Modular Reference Design Platform is a stand alone unit consisting of:

- A Multi-Layer High Density Backplane
- An FPGA based USB 2.0 GUI Enabled Software Common Control Card
- Three Modular Line Card Access Slot
- A Display Polymer Cube Chassis
- A 240V/120V 30W Integrated Power Supply Unit


FIGURE 1. ORION REFERENCE DESIGN PLATFORM



2.1 *The Modular High Density Backplane*


This Modular High Density Backplane has the main function for interconnecting and integrating the reference design line cards and delivering line card access for functionality control. It is the key backbone of the Orion platform providing the necessary cross-connects for operability.

FIGURE 2. THE MODULAR HIGH DENSITY BACKPLANE




2.2 *FPGA Based USB 2.0 GUI Enabled Software Common Control Card*

The Common Control Card has the specific function of provisioning the populated reference design cards. The FPGA provides direct access to the microprocessor bus thus enabling a GUI supplied software running on a PC with a USB interface to configure and provision all the elements within the Reference Design Line Cards for demonstrating Exar device's key operability and unique capabilities and performance.



2.3 *Modular Line Card Access Slot*


There are three Modular Line Card Access Slot for populating reference design platforms. These slots provide the user scalability and flexibility in choosing design platforms for their specific target applications. Customers can quickly evaluate and validate Exar devices in proven solutions with their intended applications before they ever begin to allocate and develop significant resources in their project. Having the reference design solution before development greatly reduces risk on the customer part in developing new applications for Exar devices while quickly gaining confidence in the product performance and viability. With today's increasingly competitive global market and emerging economical challenges, the platform also serves customers seeking a cost reduction alternative to their existing solutions by having the ability to evaluate Exar devices in exceptional and proven solutions without functional and performance compromise.



3.0 THE XRT86SH328/221 TRIPLE VOYAGER REFERENCE DESIGN PLATFORM

The XRT86SH328/221 Triple Voyager Reference Design Platform offers an unmatched high density unique solution packing 84 T1 or 63 E1 channels into VT1.5 tributaries and directly mapping them into SONET/SDH STS3/STM1 data rate. The main elements in the design consists of three XRT86SH328/221 Voyager devices using a common telecom bus operating at 19.44MHz. For optical transmission, the STS3/STM1 telecom bus interface is coupled with the XRT91L30 transceiver and an optical module. Each XRT86SH328/221 devices can map 28 T1 or 21 E1 channels for a total of 84 T1 or 63 E1 channels. The Triple Voyager Design trully demonstrates the XRT86SH328/221 device extraordinary capabilities and delivers high density T1/E1 applications in the market today.

FIGURE 3. XRT86SH328 TRIPLE VOYAGER BLOCK DIAGRAM




3.1 Master vs Slave Mode

For STM-1 applications, all three devices should be programmed to Slave. The "Master" device will occupy time slot 0 as a slave so that the system provides 2kHz to all three devices. This allows the V1 bytes to be aligned. In this mode, B1 is NOT calculated (see errata).


3.2 *The XRT86SH328/221 Triple Voyager Line Card*

The XRT86SH328/221 Triple Voyager Line Card Reference Design Platform exemplifies Exar's lead in telecommunications silicon industry, providing a highly integrated unique STS3/STM1 SONET/SDH solution in high density VT Mapper T1, E1, and J1 applications. Customers implementing Exar's innovative solution can deliver cutting edge products while significantly reducing their cost with the simplification of their Bill of Materials and Board System Design.



3.3 *The XRT86SH328/221 Triple Voyager T1/E1/J1 Magnetics Line Card*

The XRT86SH328/221 Triple Voyager T1/E1/J1 Magnetics Line Card provide access to a density total of 84 T1 or 63 E1 channels. Each of the three XRT86SH328 Voyager device maps 28 T1 or 21 E1 channels.




3.4 Exar PowerBlox™ Power Management Solution Reference Design


Powering the XRT86SH328/221 Triple Voyager Line Card Reference Design is the Exar's proven PowerBlox™ Power Management Solution. The PowerBlox™ Power Management Solution is comprised of Exar's leading edge SP7662 and SP7663 Buck Regulators. The SP7662 is capable of supplying 12 Amps at 3.3V and the SP7663 can drive up to 6 Amps at 1.8V. The SP7662/SP7663 are synchronous step-down switching regulators optimized for high efficiency. These devices is designed for use with a single 5V(SP7662)/4.75V(SP7663) to 22V single supply or 3V to 22V input if an external Vcc is provided.

The SP7662/SP7663 provides a fully integrated buck regulator solution using a fixed 300/600(respectively) kHz frequency, PWM voltage mode architecture. Protection features include UVLO, thermal shutdown, output current limit and short circuit protection. The SP7662 and the SP7663 are available in the space saving DFN package.

PowerBlox™ Power Management Solution



SP7762 Schematic Reference Design




4.0 THE XRT86SH221 TRIPLE VOYAGER LITE GRAPHICAL USER INTERFACE

The GUI is intended to allow easy access to configure basic registers in the 3 Voyager Lite devices on the reference design platform.


4.1 XRT86SH221 Triple Voyager Lite GUI Setup and Installation

Included in every Orion Modular Reference Design Platform is an Installation file. Located within the contents of the CDROM, the installation filename for the XRT86SH221 Triple Voyager Reference Design Platform is called "**XRT86SH221_Orion EvaluationUSB08022007.exe**". This file will automatically load the Exar USB drivers and install the XRT86SH221 Triple Voyager Reference Design Platform GUI software. However, if the following steps are performed and the board is NOT recognized by the PC, **SEE "MANUALLY LOADING EXAR DRIVERS (IF INSTALLATION IS NOT SUCCESSFUL)" ON PAGE 14.** that describes how to manually load the drivers.


Step 1 Double Click the "**XRT86SH221_Orion_EvaluationUSB_08022007.exe**" file to bring up the following screen. Click on the **Next>** button.




Step 2 If there are no changes to the installation directory, Click on the **Next >** button to proceed. Otherwise, make the necessary changes and Click on the **Next >** button to proceed.




Step 3 Click the **Next>** button to continue.



Step 4 Click on the **Install** button to continue installation.




Step 5 Click on the **Finish** button to complete installation. The Exar USB drivers should be properly installed and ready to go. If so, continue to the next section that describes the Graphical User Interface. If not, see the last step below to manually load the Exar USB Drivers.




4.1.1 Manually Loading Exar Drivers (If Installation is NOT Successful)

If the Evaluation Board is NOT recognized and/or the installation process was NOT successful, most likely there is a driver contention or the driver was not installed in the proper directory from the software. This section describes how to manually load the drivers.

Note: Each Windows operating system may access the System Hardware differently. Therefore, it is not practical to describe this procedure for each OS. However, the key component is usually the Control Panel of the PC. From the Control Panel, you can access the System Properties dialog box. From there, choose the Hardware menu item and go to the Device Manager...



The device Manager will bring up the following dialog box. Choose the USB I/O Controlled Devices, select Exar Device, right click, select properties, select Update Driver, and then follow the directions to choose the driver from the CD or the /Driver directory in the Exar working directory ("C:\Program Files\Exar\3VoyagerLites Evaluation Software" by default).



4.2 STARTING THE XRT86SH221 TRIPLE VOYAGER LITE GUI

The evaluation software allows the user to do the following:

- Configure the XRT86SH221 for proper operation
- Poll current and historical performance status
- Download the FPGA file
- Enable/Disable XRT86SH221 features with the click of a button

Initialization of the GUI

Once the USB Installer program is completed, all files are installed under the directory: "**C:\Program Files\Exar\XRT86SH221_Orion Evaluation Software**" (If the user did not change the default directory for installation).

There are two ways to initialize the GUI:

- 1. Double Click the file "3VoyagerLitesGui.exe" under the installed directory.
- 2. Click on the **Start** button then choose **Programs > Exar > XRT86SH221_Orion Evaluation Software > XRT86SH221_Orion Evaluation GUI**. Once the GUI is initiated, the software will download a .hex file from the installed directory automatically. If the downloading fails, the following dialog box will appear.




If there is an error loading the FPGA file, refer to the section that describes "Manually Loading Exar Drivers".

After executing the program, the following dialog box will appear to notify the user that the FPGA file is being downloaded to the on board FPGA.



If the FPGA has been successfully loaded, the following main dialog box will appear.




The Main Dialog Box

There are two main selection items on the tool bar.

1. Configuration
2. Special Operations


Under the Configuration menu, the following items will appear. You'll have the option to program in each of the three Voyager Lite devices:

- SDH Operation and Control
- E1 Framer
- Receive TOH/POH Blocks
- Transmit TOH/POH Blocks
- VT Mapper
- E1 LIU Registers.



Under the Special Operations menu, the following items will appear. You'll have the option to do one of the following:


1. Run Python Script (Script Files are Automatically Loaded)
2. Read/Write Registers (Allows Access to a Manual Read or Write)
3. Download FPGA
4. Debug Window (Interactive Tool to Monitor Register Activity)



4.3 Using the Evaluation Software

It is possible to achieve full device functionality through the GUI. The XRT86SH221 and other device features are also accessed and can be enabled or disabled through the main GUI window. Upon each selection, the control pin assertion or software register operation occurs immediately and is displayed in the main GUI window.

Once the FPGA has been successfully programmed, you should see a similar window below. To begin the Triple Voyager Lite Evaluation, Select "Configuration" on the Menu.



4.3.1 Operation Control Block


There are two pages in the Operation Control block dialog:

- **SDH Operations**
- **Telecom Bus Control.**


Click on the labeled tabs to switch to the wanted page.

4.3.1.1 SDH Operations

Selecting "SDH Operation Control" on the drop list, the following window will appear. Each of the three XRT86SH221 are independently accessed and controlled by an "Operation Control" window. All dialog boxes have a pull down menu for specifying which device, Slave 0, Slave 1 or Slave 2, is being controlled by the dialog box. Slave 0 device can also be converted to Master device by clicking the checkbox on the left of the pull down menu. The default "Operation Control" window will automatically select the "Master" device of the three XRT86SH221.




To select and provision the Slave 1 and Slave 2 Voyager Lite device, the user can open multiple windows (a second and a third "Operation Control" window) by Clicking-On "Configuration" on the Menu followed and selecting "SDH Operation Control" on the drop list. Slave 1 or Slave 2 is selected on the Drop Down List near the bottom of the application window.



Status indicators will begin polling upon selecting the Start Poll button and will continue to poll until it is stopped.

4.3.1.2 Telecom Bus Control


Selecting "Telecom Bus Control" on the drop list, the following window will appear. Again, each of the three XRT86SH221 are independently accessed and controlled by an "Operation Control" window. All dialog boxes have a pull down menu for specifying which device, Slave 0, Slave 1 or Slave 2, is being controlled by the dialog box. Slave 0 device can also be converted to Master device by clicking the checkbox on the left of the pull down menu. The default "Operation Control" window will automatically select the "Master" device of the three XRT86SH221.




4.3.2 Receive SDH Overhead

On the Receive SDH Overhead dialog, the two pages are for Regenerator and Multiplex Section OH (TOH) and High-Order Path Overhead (POH). There are two buttons, TOH Monitors and POH Monitors, on the bottom of the dialog for displaying status indicators. Click on the two buttons will evoke two separate dialog boxes, which contain all the status indicators.


4.3.2.1 Receive Regenerator and Multiplex Section Overhead (Receive TOH)




4.3.2.2 Receive High-Order Path Overhead (Receive POH)



4.3.3 Receive Regenerator and Multiplex Section Performance Monitors




4.3.4 Receive High-Order Path Performance Monitors




4.3.5 E1 Framer General Configuration

The dialog box for framer block also has two pages, E1 Framer Control and E1 Interrupt Enable. The All Channel Modify button is used to modify all channels on the specified board with the same settings on the current dialog box.

4.3.5.1 E1 Framer control




4.3.5.2 E1 Interrupt Enable



4.3.6 Transmit SDH Overhead

The following shows the two pages on the Transmit Overhead dialog

4.3.6.1 Transmit Regenerator and Multiplex Section Overhead



4.3.6.2 Transmit High-Order Path Overhead

Transmit Overhead
✕

Transmit TOH
Transmit POH

PATH CONTROL

Select Input Hardware Pin

Z5 Z3 F2 C2 Auto Insertion
 Z4 H4 C2 AU-AIS

HP-REI Insertion Type

From receiver

HP-RDI Insertion Type

From receiver

J11 Insertion Type

Insert the value 0x00

Pointer Control

Force Pointer
 Check Stuff
 Continuous NDF
 Single NDF

RDI-P CONTROL

HP-PLM Insert Enable
 HP-PLM value for PLM Alarm-----> 0

HP-TIM Insert Enable
 RDI value for HP-TIM Alarm-----> 0

HP-UNEQ Insert Enable
 RDI value for HP-UNEQ Alarm--> 0

AU-LOP Insert Enable
 RDI value for AU-LOP Alarm-----> 0

AU-AIS Insert Enable
 RDI value for AU-AIS Alarm-----> 0

TRANSMIT VALUE

| | | | | | |
|---------|---|---------|---|---------|---|
| J1 Byte | 0 | H4 Byte | 0 | Z3 Byte | 0 |
| B3 Mask | 0 | G1 Byte | 0 | Z4 Byte | 0 |
| C2 Byte | 0 | F2 Byte | 0 | Z5 Byte | 0 |


Master (Slave if unchecked)

Slave 0


4.3.7 VT Mapper

The following are the two pages in VT Mapper block control. Click Display Monitors to display status indicators.


4.3.7.1 Global VT Mapper Control



4.3.7.2 Channelized VT Mapper Control




4.3.7.3 VT Mapper Performance Monitors




4.3.8 E1 Line Interface Unit Configuration and Control

Use this dialog to control the LIU block. Indicators on the right show alarm signals.



4.3.9 Register Read/Write Access

Use this dialog to access, read or write, values in specified registers.




5.0 THE XRT86SH328 TRIPLE VOYAGER GRAPHICAL USER INTERFACE

The GUI is intended to allow easy access to configure basic registers in the 3 Voyager devices on the reference design platform.


5.1 XRT86SH328 Triple Voyager GUI Setup and Installation

Included in every Orion Modular Reference Design Platform is an Installation file. Located within the contents of the CDROM, the installation filename for the XRT86SH328 Triple Voyager Reference Design Platform is called "**XR86SH328 setup.exe**". This file will automatically load the Exar USB drivers and install the XRT86SH328 Triple Voyager Reference Design Platform GUI software. However, if the following steps are performed and the board is NOT recognized by the PC, **SEE "MANUALLY LOADING EXAR DRIVERS (IF INSTALLATION IS NOT SUCCESSFUL)" ON PAGE 37.** that describes how to manually load the drivers.


Step 1 Double Click the "**XR86SH328 setup.exe**" file to bring up the following screen. Click on the **Next>** button.




Step 2 If there are no changes to the installation directory, Click on the **Next>** button to proceed. Otherwise, make the necessary changes and Click on the **Next>** button to proceed.




Step 3 Click the **Next>** button to continue.




Step 4 Select or De-select **Create a Desktop Icon**. Click the **Next>** button to continue.



Step 5 Click on the **Install** button to continue installation.




Step 6 Click on the **Finish** button to complete installation. The Exar USB drivers should be properly installed and ready to go. If so, continue to the next section that describes the Graphical User Interface. If not, see **SEE "MANUALLY LOADING EXAR DRIVERS (IF INSTALLATION IS NOT SUCCESSFUL)" ON PAGE 37.** to manually load the Exar USB Drivers.




5.1.1 Manually Loading Exar Drivers (If Installation is NOT Successful)

If the Evaluation Board is NOT recognized and/or the installation process was NOT successful, most likely there is a driver contention or the driver was not installed in the proper directory from the software. This section describes how to manually load the drivers.

Note: Each Windows operating system may access the System Hardware differently. Therefore, it is not practical to describe this procedure for each OS. However, the key component is usually the Control Panel of the PC. From the Control Panel, you can access the System Properties dialog box. From there, choose the Hardware menu item and go to the Device Manager...



The device Manager will bring up the following dialog box. Choose the USB I/O Controlled Devices, select Exar Device, right click, select properties, select Update Driver, and then follow the directions to choose the driver from the CD or the /Driver directory in the Exar working directory ("C:\Program Files\Exar\3VoyagerLites Evaluation Software" by default).




6.0 STARTING THE XRT86SH328 TRIPLE VOYAGER GUI

The evaluation software allows the user to do the following:

- Configure the XRT86SH328 for proper operation
- Poll current and historical performance status
- Download the FPGA code
- Enable/Disable XRT86SH328 features with the click of a button


After launching the executable, select the option corresponding to the hardware evaluation system you have.




FPGA download was successful.




Select the fields that the application will use and the board can support.




6.0.1 Main Evaluation Menu.



6.0.2 Receive SONET Transport Overhead /SDH Regenerator and Multiplex Section Configuration




6.0.2.1 Receive SONET Transport Overhead /SDH Regenerator and Multiplex Section Performance Monitoring Alarms




6.0.3 Receive SONET Path Overhead /SDH High-Order Path Configuration



6.0.3.1 Receive SONET Path Overhead /SDH High-Order Path Performance Monitoring Alarms



6.0.4 Receive Validated SONET (J0) Section and (J1) Path and (J2) VT-Path Trace Buffer /SDH (J0) Regenerator Section and (J1) High-Order Path and (J2) Low-Order Path Trace Message Buffer



Rx Trace Buffer 0

Registers


| | | | | | | | | | | | | | | | | |
|-------|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| 0-15 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 16-31 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 32-47 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 48-63 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |

Control

Read from Expected Buffer Message Length: Line Feed

Read Actual Buffer Type:
 Expected Buffer

6.0.5 Receive Expected SONET (J0) Section and (J1) Path and (J2) VT-Path Trace Buffer /SDH (J0) Regenerator Section and (J1) High-Order Path and (J2) Low-Order Path Trace Message Buffer



Trace Message Expected Buffer

Registers


| | | | | | | | | | | | | | | | | |
|-------|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| 0-15 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 16-31 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 32-47 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 48-63 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |

Fill Pattern


Byte Increment Byte Decrement Pseudo Random
 Default Fill with:

Buffer Type:


6.0.6 VT Mapper Configuration




6.0.6.1 VT Mapper Alarms




6.0.7 T1 Egress Configuration



6.0.7.1 T1 Egress Alarms



6.0.8 Line Interface Unit Configuration



6.0.8.1 Line Interface Unit Performance Monitoring Alarms



6.0.9 Transmit SONET Transport Overhead Configuration

Tx SONET TOH 0

Control

- STS-N Overhead Insert
- E2 Software
- E1 Software
- F1 Software
- S1 Hardware
- K1K2 Hardware

MDM1 Type: from receiver

- Default TOH Values (00/FF)
- Force RDI-L insert
- Force AIS-L insert
- LOS insert
- Scramble
- B2 Error Insert
- A1A2 Error Insert

RDI-L Insertion Control

- Enable External
- AIS-L detection
- LOF detection
- LOS detection

Byte Values

A1 Mask: 0

A2 Mask: 0

B1 Mask: 0

B2 Mask: 0

B2 Bit Mask: 0

K2 Value: 0

K1 Value: 0

M1M0 Value: 0

S1 Value: 0

F1 Value: 0

E1 Value: 0

E2 Value: 0

Apply

OK

6.0.10 Transmit SONET Path Overhead Configuration

Tx SONET POH 0

Control

- Insert SS bit
- Z5 hardware input
- Z4 hardware input
- Z3 hardware input
- H4 hardware input
- F2 hardware input

REI-P: from receiver

RDI-P: from receiver

- C2 hardware input
- C2 Insertion
- AIS-P Insertion

B3 Pass Through

- POH pass through
- B3 pass through

Path Control

- Force Pointer
- Check Stuff
- NDF Continuous Flags

Negative Stuff

Positive Stuff

NDF Single

OK

Apply Values

Transmit Values

J1 Byte: 0

B3 Mask: 0

C2 Byte: 2

G1 Byte: 2

F2 Byte: 0

H4 Byte: 0

Z3 Byte: 0

Z4 Byte: 0

Z5 Byte: 0

RDI-P Control

- LCD-P Insert Enable
RDI value for LCD Alarm: 2
- PLM-P Insert Enable
RDI value for PLM Alarm: 2
- TIM-P Insert Enable
RDI value for TIM Alarm: 6
- UNEQ-P Insert Enable
RDI value for UNEQ Alarm: 6
- LOP-P Insert Enable
RDI value for LOP Alarm: 5
- AIS-P Insert Enable
RDI value for AIS Alarm: 5

6.0.11 Transmit SONET (J0) Section and (J1) Path and (J2) VT-Path Trace Buffer /SDH (J0) Regenerator Section and (J1) High-Order Path and (J2) Low-Order Path Trace Message Buffer

Transmit Trace Buffer 0

Registers (values in hex)

| | | | | | | | | | | | | | | | | |
|-------|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| 0-15 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 16-31 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 32-47 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 48-63 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |

Fill Pattern: Byte Increment Byte Decrement Pseudo Random Default Fill with 0

Buffer Type: J0

Control: Message Length: 16

6.0.12 T1 Ingress Configuration

T1 Ingress Framer 0

Clock Register Select

8 kHz Sync Enable

Clock Source Select: OSCCLK divided Clock

Line Interface Control

Force LOS

Loopbacks: No local loopback

Synchronize Mux

Multiframe Alignment

Tx Superframe sync

Sync Invert

CRC-6 Source

Framing bit Source

Frame Selection

Signal Frame

Force CRC Error

CRC calculation in J1

One Sync

Fast Sync

Framing: ESF

Alarm Enable

Defect detect

Enable LOS alarm 1

Enable LOS alarm 2

Enable OOF alarm 1

Enable OOF alarm 2

Enable AIS alarm 1

Enable AIS alarm 2

Alarm Generation

One Sec Alarm

Enable Alarm

Yellow Alarm: Disable

AISG: No AIS alarm


AISD: AIS alarm detection

Rx Framing Control

Sync with CRC

Channel: 0

6.0.12.1 T1 Ingress Alarms




| PMDN | |
|------------------------|-------|
| LCV | 65535 |
| Frame Alignment | 0 |
| Severely Errored Frame | 0 |
| Synchronize Bit Error | 0 |
| FEBE | 0 |
| Receive Slip | 0 |
| LOPC | 255 |
| Change of Fr Alignment | 0 |
| LAPD FCS | 0 |
| PRBS Bit Err | 0 |
| Transmit Slip | 0 |

7.0 PYTHON SCRIPT INTERFACE

Running a Python Script From the GUI


From the main GUI, select the Special Operations menu shown below and click on the "Run Python Script" to continue.



Once you select the "Run Python Script" option from the Special Operations menu from the GUI, the "xrScripting Interface" will pop-up as shown below. At this point, the xrScripting Interface is independent of the GUI and any script files that are run will automatically overwrite the GUI settings if there is an overlap with the registers. Therefore, caution must be used to keep track of the register configurations if one wants to toggle back and forth from the

GUI to the xrScripting Interface. The next step is to use the "Special" menu on the tool bar to run the actual test script file.

Note: If you would like to view a particular test script in a plain text editor mode, use the "File" menu on the tool bar and select "Open".



8.0 XRT86SH221 E1 TEST HEADERS H3 AND H4

There are two test headers H3 and H4 on Front Panel of the XRT86SH221 Triple Voyager Lite device platform. These permit access to all 63 possible E1 channels. Below is a magnified view of the XRT86SH221 Triple Voyager test header diagram. The following table has the complete tip and ring transmission and reception lines in reference to channel assignment location on the H3 and H4 test headers.




TABLE 1: TRIPLE VOYAGER LITE CHANNEL TO PIN LOCATION CROSS REFERENCE GUIDE

| E1 CHANNEL | XRT86SH221 | DEVICE CHANNEL | HEADER | PIN LOCATION | | | |
|------------|-------------|----------------|--------|--------------|-------|------|-------|
| | | | | TTIP | TRING | RTIP | RRING |
| 0 | U2 - Master | 0 | H3 | A1 | A2 | A3 | A4 |
| 1 | U2 - Master | 1 | H3 | A5 | A6 | A7 | A8 |
| 2 | U2 - Master | 2 | H3 | A9 | A10 | A11 | A12 |
| 3 | U2 - Master | 3 | H3 | A13 | A14 | A15 | A16 |
| 4 | U2 - Master | 4 | H3 | A17 | A18 | A19 | A20 |
| 5 | U2 - Master | 5 | H3 | A21 | A22 | A23 | A24 |
| 6 | U2 - Master | 6 | H3 | A25 | A26 | A27 | A28 |
| 7 | U2 - Master | 7 | H3 | A29 | A30 | A31 | A32 |
| 8 | U2 - Master | 8 | H3 | A33 | A34 | A35 | A36 |
| 9 | U2 - Master | 9 | H3 | A37 | A38 | A39 | A40 |

TABLE 1: TRIPLE VOYAGER LITE CHANNEL TO PIN LOCATION CROSS REFERENCE GUIDE

| E1 CHANNEL | XRT86SH221 | DEVICE CHANNEL | HEADER | PIN LOCATION | | | |
|------------|--------------|----------------|--------|--------------|-------|------|-------|
| | | | | TTIP | TRING | RTIP | RRING |
| 10 | U2 - Master | 10 | H3 | A41 | A42 | A43 | A44 |
| 11 | U2 - Master | 11 | H3 | A45 | A46 | A47 | A48 |
| 12 | U2 - Master | 12 | H4 | A1 | A2 | A3 | A4 |
| 13 | U2 - Master | 13 | H4 | A5 | A6 | A7 | A8 |
| 14 | U2 - Master | 14 | H4 | A9 | A10 | A11 | A12 |
| 15 | U2 - Master | 15 | H4 | A13 | A14 | A15 | A16 |
| 16 | U2 - Master | 16 | H4 | A17 | A18 | A19 | A20 |
| 17 | U2 - Master | 17 | H4 | A21 | A22 | A23 | A24 |
| 18 | U2 - Master | 18 | H4 | A25 | A26 | A27 | A28 |
| 19 | U2 - Master | 19 | H4 | A29 | A30 | A31 | A32 |
| 20 | U2 - Master | 20 | H4 | A33 | A34 | A35 | A36 |
| 21 | U3 - Slave 1 | 0 | H3 | B1 | B2 | B3 | B4 |
| 22 | U3 - Slave 1 | 1 | H3 | B5 | B6 | B7 | B8 |
| 23 | U3 - Slave 1 | 2 | H3 | B9 | B10 | B11 | B12 |
| 24 | U3 - Slave 1 | 3 | H3 | B13 | B14 | B15 | B16 |
| 25 | U3 - Slave 1 | 4 | H3 | B17 | B18 | B19 | B20 |
| 26 | U3 - Slave 1 | 5 | H3 | B21 | B22 | B23 | B24 |
| 27 | U3 - Slave 1 | 6 | H3 | B25 | B26 | B27 | B28 |
| 28 | U3 - Slave 1 | 7 | H3 | B29 | B30 | B31 | B32 |
| 29 | U3 - Slave 1 | 8 | H3 | B33 | B34 | B35 | B36 |
| 30 | U3 - Slave 1 | 9 | H3 | B37 | B38 | B39 | B40 |
| 31 | U3 - Slave 1 | 10 | H3 | B41 | B42 | B43 | B44 |
| 32 | U3 - Slave 1 | 11 | H3 | B45 | B46 | B47 | B48 |
| 33 | U3 - Slave 1 | 12 | H4 | B1 | B2 | B3 | B4 |
| 34 | U3 - Slave 1 | 13 | H4 | B5 | B6 | B7 | B8 |
| 35 | U3 - Slave 1 | 14 | H4 | B9 | B10 | B11 | B12 |
| 36 | U3 - Slave 1 | 15 | H4 | B13 | B14 | B15 | B16 |
| 37 | U3 - Slave 1 | 16 | H4 | B17 | B18 | B19 | B20 |
| 38 | U3 - Slave 1 | 17 | H4 | B21 | B22 | B23 | B24 |
| 39 | U3 - Slave 1 | 18 | H4 | B25 | B26 | B27 | B28 |
| 40 | U3 - Slave 1 | 19 | H4 | B29 | B30 | B31 | B32 |

TABLE 1: TRIPLE VOYAGER LITE CHANNEL TO PIN LOCATION CROSS REFERENCE GUIDE

| E1 CHANNEL | XRT86SH221 | DEVICE CHANNEL | HEADER | PIN LOCATION | | | |
|------------|--------------|----------------|--------|--------------|-------|------|-------|
| | | | | TTIP | TRING | RTIP | RRING |
| 41 | U3 - Slave 1 | 20 | H4 | B33 | B34 | B35 | B36 |
| 42 | U4 - Slave 2 | 0 | H3 | C1 | C2 | C3 | C4 |
| 43 | U4 - Slave 2 | 1 | H3 | C5 | C6 | C7 | C8 |
| 44 | U4 - Slave 2 | 2 | H3 | C9 | C10 | C11 | C12 |
| 45 | U4 - Slave 2 | 3 | H3 | C13 | C14 | C15 | C16 |
| 46 | U4 - Slave 2 | 4 | H3 | C17 | C18 | C19 | C20 |
| 47 | U4 - Slave 2 | 5 | H3 | C21 | C22 | C23 | C24 |
| 48 | U4 - Slave 2 | 6 | H3 | C25 | C26 | C27 | C28 |
| 49 | U4 - Slave 2 | 7 | H3 | C29 | C30 | C31 | C32 |
| 50 | U4 - Slave 2 | 8 | H3 | C33 | C34 | C35 | C36 |
| 51 | U4 - Slave 2 | 9 | H3 | C37 | C38 | C39 | C40 |
| 52 | U4 - Slave 2 | 10 | H3 | C41 | C42 | C43 | C44 |
| 53 | U4 - Slave 2 | 11 | H3 | C45 | C46 | C47 | C48 |
| 54 | U4 - Slave 2 | 12 | H4 | C1 | C2 | C3 | C4 |
| 55 | U4 - Slave 2 | 13 | H4 | C5 | C6 | C7 | C8 |
| 56 | U4 - Slave 2 | 14 | H4 | C9 | C10 | C11 | C12 |
| 57 | U4 - Slave 2 | 15 | H4 | C13 | C14 | C15 | C16 |
| 58 | U4 - Slave 2 | 16 | H4 | C17 | C18 | C19 | C20 |
| 59 | U4 - Slave 2 | 17 | H4 | C21 | C22 | C23 | C24 |
| 60 | U4 - Slave 2 | 18 | H4 | C25 | C26 | C27 | C28 |
| 61 | U4 - Slave 2 | 19 | H4 | C29 | C30 | C31 | C32 |
| 62 | U4 - Slave 2 | 20 | H4 | C33 | C34 | C35 | C36 |

9.0 XRT86SH328 T1/J1 TEST HEADERS H3 AND H4

There are two test headers H3 and H4 on Front Panel of the XRT86SH328 Triple Voyager device platform. These permit access to all 84 possible T1 or J1 channels. Below is a magnified view of the XRT86SH328 Triple Voyager test header diagram. The following table has the complete tip and ring transmission and reception lines in reference to channel assignment location on the H3 and H4 test headers.




TABLE 2: TRIPLE VOYAGER CHANNEL TO PIN LOCATION CROSS REFERENCE GUIDE

| T1/J1 CHANNEL | XRT86SH328 | DEVICE CHANNEL | HEADER | PIN LOCATION | | | |
|---------------|-------------|----------------|--------|--------------|-------|------|-------|
| | | | | TTIP | TRING | RTIP | RRING |
| 0 | U2 - Master | 0 | H3 | A1 | A2 | A3 | A4 |
| 1 | U2 - Master | 1 | H3 | A5 | A6 | A7 | A8 |
| 2 | U2 - Master | 2 | H3 | A9 | A10 | A11 | A12 |
| 3 | U2 - Master | 3 | H3 | A13 | A14 | A15 | A16 |
| 4 | U2 - Master | 4 | H3 | A17 | A18 | A19 | A20 |
| 5 | U2 - Master | 5 | H3 | A21 | A22 | A23 | A24 |
| 6 | U2 - Master | 6 | H3 | A25 | A26 | A27 | A28 |
| 7 | U2 - Master | 7 | H3 | A29 | A30 | A31 | A32 |
| 8 | U2 - Master | 8 | H3 | A33 | A34 | A35 | A36 |
| 9 | U2 - Master | 9 | H3 | A37 | A38 | A39 | A40 |

TABLE 2: TRIPLE VOYAGER CHANNEL TO PIN LOCATION CROSS REFERENCE GUIDE

| T1/J1 CHANNEL | XRT86SH328 | DEVICE CHANNEL | HEADER | PIN LOCATION | | | |
|---------------|--------------|----------------|--------|--------------|-------|------|-------|
| | | | | TTIP | TRING | RTIP | RRING |
| 10 | U2 - Master | 10 | H3 | A41 | A42 | A43 | A44 |
| 11 | U2 - Master | 11 | H3 | A45 | A46 | A47 | A48 |
| 12 | U2 - Master | 12 | H4 | A1 | A2 | A3 | A4 |
| 13 | U2 - Master | 13 | H4 | A5 | A6 | A7 | A8 |
| 14 | U2 - Master | 14 | H4 | A9 | A10 | A11 | A12 |
| 15 | U2 - Master | 15 | H4 | A13 | A14 | A15 | A16 |
| 16 | U2 - Master | 16 | H4 | A17 | A18 | A19 | A20 |
| 17 | U2 - Master | 17 | H4 | A21 | A22 | A23 | A24 |
| 18 | U2 - Master | 18 | H4 | A25 | A26 | A27 | A28 |
| 19 | U2 - Master | 19 | H4 | A29 | A30 | A31 | A32 |
| 20 | U2 - Master | 20 | H4 | A33 | A34 | A35 | A36 |
| 21 | U2 - Master | 21 | H4 | A37 | A38 | A39 | A40 |
| 22 | U2 - Master | 22 | H4 | A41 | A42 | A43 | A44 |
| 23 | U2 - Master | 23 | H4 | A45 | A46 | A47 | A48 |
| 24 | U2 - Master | 24 | H3 | D1 | D2 | D3 | D4 |
| 25 | U2 - Master | 25 | H3 | D5 | D6 | D7 | D8 |
| 26 | U2 - Master | 26 | H3 | D9 | D10 | D11 | D12 |
| 27 | U2 - Master | 27 | H3 | D13 | D14 | D15 | D16 |
| 28 | U3 - Slave 1 | 0 | H3 | B1 | B2 | B3 | B4 |
| 29 | U3 - Slave 1 | 1 | H3 | B5 | B6 | B7 | B8 |
| 30 | U3 - Slave 1 | 2 | H3 | B9 | B10 | B11 | B12 |
| 31 | U3 - Slave 1 | 3 | H3 | B13 | B14 | B15 | B16 |
| 32 | U3 - Slave 1 | 4 | H3 | B17 | B18 | B19 | B20 |
| 33 | U3 - Slave 1 | 5 | H3 | B21 | B22 | B23 | B24 |
| 34 | U3 - Slave 1 | 6 | H3 | B25 | B26 | B27 | B28 |
| 35 | U3 - Slave 1 | 7 | H3 | B29 | B30 | B31 | B32 |
| 36 | U3 - Slave 1 | 8 | H3 | B33 | B34 | B35 | B36 |
| 37 | U3 - Slave 1 | 9 | H3 | B37 | B38 | B39 | B40 |
| 38 | U3 - Slave 1 | 10 | H3 | B41 | B42 | B43 | B44 |
| 39 | U3 - Slave 1 | 11 | H3 | B45 | B46 | B47 | B48 |
| 40 | U3 - Slave 1 | 12 | H4 | B1 | B2 | B3 | B4 |

TABLE 2: TRIPLE VOYAGER CHANNEL TO PIN LOCATION CROSS REFERENCE GUIDE

| T1/J1 CHANNEL | XRT86SH328 | DEVICE CHANNEL | HEADER | PIN LOCATION | | | |
|---------------|--------------|----------------|--------|--------------|-------|------|-------|
| | | | | TTIP | TRING | RTIP | RRING |
| 41 | U3 - Slave 1 | 13 | H4 | B5 | B6 | B7 | B8 |
| 42 | U3 - Slave 1 | 14 | H4 | B9 | B10 | B11 | B12 |
| 43 | U3 - Slave 1 | 15 | H4 | B13 | B14 | B15 | B16 |
| 44 | U3 - Slave 1 | 16 | H4 | B17 | B18 | B19 | B20 |
| 45 | U3 - Slave 1 | 17 | H4 | B21 | B22 | B23 | B24 |
| 46 | U3 - Slave 1 | 18 | H4 | B25 | B26 | B27 | B28 |
| 47 | U3 - Slave 1 | 19 | H4 | B29 | B30 | B31 | B32 |
| 48 | U3 - Slave 1 | 20 | H4 | B33 | B34 | B35 | B36 |
| 49 | U3 - Slave 1 | 21 | H4 | B37 | B38 | B39 | B40 |
| 50 | U3 - Slave 1 | 22 | H4 | B41 | B42 | B43 | B44 |
| 51 | U3 - Slave 1 | 23 | H4 | B45 | B46 | B47 | B48 |
| 52 | U3 - Slave 1 | 24 | H3 | D17 | D18 | D19 | D20 |
| 53 | U3 - Slave 1 | 25 | H3 | D21 | D22 | D23 | D24 |
| 54 | U3 - Slave 1 | 26 | H3 | D25 | D26 | D27 | D28 |
| 55 | U3 - Slave 1 | 27 | H3 | D29 | D30 | D31 | D32 |
| 56 | U4 - Slave 2 | 0 | H3 | C1 | C2 | C3 | C4 |
| 57 | U4 - Slave 2 | 1 | H3 | C5 | C6 | C7 | C8 |
| 58 | U4 - Slave 2 | 2 | H3 | C9 | C10 | C11 | C12 |
| 59 | U4 - Slave 2 | 3 | H3 | C13 | C14 | C15 | C16 |
| 60 | U4 - Slave 2 | 4 | H3 | C17 | C18 | C19 | C20 |
| 61 | U4 - Slave 2 | 5 | H3 | C21 | C22 | C23 | C24 |
| 62 | U4 - Slave 2 | 6 | H3 | C25 | C26 | C27 | C28 |
| 63 | U4 - Slave 2 | 7 | H3 | C29 | C30 | C31 | C32 |
| 64 | U4 - Slave 2 | 8 | H3 | C33 | C34 | C35 | C36 |
| 65 | U4 - Slave 2 | 9 | H3 | C37 | C38 | C39 | C40 |
| 66 | U4 - Slave 2 | 10 | H3 | C41 | C42 | C43 | C44 |
| 67 | U4 - Slave 2 | 11 | H3 | C45 | C46 | C47 | C48 |
| 68 | U4 - Slave 2 | 12 | H4 | C1 | C2 | C3 | C4 |
| 69 | U4 - Slave 2 | 13 | H4 | C5 | C6 | C7 | C8 |
| 70 | U4 - Slave 2 | 14 | H4 | C9 | C10 | C11 | C12 |
| 71 | U4 - Slave 2 | 15 | H4 | C13 | C14 | C15 | C16 |

TABLE 2: TRIPLE VOYAGER CHANNEL TO PIN LOCATION CROSS REFERENCE GUIDE

| T1/J1 CHANNEL | XRT86SH328 | DEVICE CHANNEL | HEADER | PIN LOCATION | | | |
|---------------|--------------|----------------|--------|--------------|-------|------|-------|
| | | | | TTIP | TRING | RTIP | RRING |
| 72 | U4 - Slave 2 | 16 | H4 | C17 | C18 | C19 | C20 |
| 73 | U4 - Slave 2 | 17 | H4 | C21 | C22 | C23 | C24 |
| 74 | U4 - Slave 2 | 18 | H4 | C25 | C26 | C27 | C28 |
| 75 | U4 - Slave 2 | 19 | H4 | C29 | C30 | C31 | C32 |
| 76 | U4 - Slave 2 | 20 | H4 | C33 | C34 | C35 | C36 |
| 77 | U4 - Slave 2 | 21 | H4 | C37 | C38 | C39 | C40 |
| 78 | U4 - Slave 2 | 22 | H4 | C41 | C42 | C43 | C44 |
| 79 | U4 - Slave 2 | 23 | H4 | C45 | C46 | C47 | C48 |
| 80 | U4 - Slave 2 | 24 | H3 | D33 | D34 | D35 | D36 |
| 81 | U4 - Slave 2 | 25 | H3 | D37 | D38 | D39 | D40 |
| 82 | U4 - Slave 2 | 26 | H3 | D41 | D42 | D43 | D44 |
| 83 | U4 - Slave 2 | 27 | H3 | D45 | D46 | D47 | D48 |



Line Card E1 Test Interface

Header Pin Def.

| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|---|
| 48 | 47 | 46 | 45 | 44 | 43 | 42 | 41 | 40 | 39 | 38 | 37 | 36 | 35 | 34 | 33 | 32 | 31 | 30 | 29 | 28 | 27 | 26 | 25 | 24 | 23 | 22 | 21 | 20 | 19 | 18 | 17 | 16 | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | | | | | |
| G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | E |
| RR | RT | TR | TT | D |
| RR | RT | TR | TT | C |
| RR | RT | TR | TT | B |
| RR | RT | TR | TT | A |

H3

H3

| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|---|
| 48 | 47 | 46 | 45 | 44 | 43 | 42 | 41 | 40 | 39 | 38 | 37 | 36 | 35 | 34 | 33 | 32 | 31 | 30 | 29 | 28 | 27 | 26 | 25 | 24 | 23 | 22 | 21 | 20 | 19 | 18 | 17 | 16 | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | | | | | | | | | | | | | | | | | | | |
| gnd | E | | | | | | | | | | | | | | | | |
| Ch53 | Ch52 | Ch51 | Ch50 | Ch49 | Ch48 | Ch47 | Ch46 | Ch45 | Ch44 | Ch43 | Ch42 | Ch41 | Ch40 | Ch39 | Ch38 | Ch37 | Ch36 | Ch35 | Ch34 | Ch33 | Ch32 | Ch31 | Ch30 | Ch29 | Ch28 | Ch27 | Ch26 | Ch25 | Ch24 | Ch23 | Ch22 | Ch21 | Ch20 | Ch19 | Ch18 | Ch17 | Ch16 | Ch15 | Ch14 | Ch13 | Ch12 | Ch11 | Ch10 | Ch9 | Ch8 | Ch7 | Ch6 | Ch5 | Ch4 | Ch3 | Ch2 | Ch1 | Ch0 | D | | | | | | | | | | | | |
| Ch32 | Ch31 | Ch30 | Ch29 | Ch28 | Ch27 | Ch26 | Ch25 | Ch24 | Ch23 | Ch22 | Ch21 | Ch20 | Ch19 | Ch18 | Ch17 | Ch16 | Ch15 | Ch14 | Ch13 | Ch12 | Ch11 | Ch10 | Ch9 | Ch8 | Ch7 | Ch6 | Ch5 | Ch4 | Ch3 | Ch2 | Ch1 | Ch0 | Ch53 | Ch52 | Ch51 | Ch50 | Ch49 | Ch48 | Ch47 | Ch46 | Ch45 | Ch44 | Ch43 | Ch42 | Ch41 | Ch40 | Ch39 | Ch38 | Ch37 | Ch36 | Ch35 | Ch34 | Ch33 | Ch32 | C | | | | | | | | | | | |
| Ch11 | Ch10 | Ch9 | Ch8 | Ch7 | Ch6 | Ch5 | Ch4 | Ch3 | Ch2 | Ch1 | Ch0 | Ch53 | Ch52 | Ch51 | Ch50 | Ch49 | Ch48 | Ch47 | Ch46 | Ch45 | Ch44 | Ch43 | Ch42 | Ch41 | Ch40 | Ch39 | Ch38 | Ch37 | Ch36 | Ch35 | Ch34 | Ch33 | Ch32 | Ch31 | Ch30 | Ch29 | Ch28 | Ch27 | Ch26 | Ch25 | Ch24 | Ch23 | Ch22 | Ch21 | Ch20 | Ch19 | Ch18 | Ch17 | Ch16 | Ch15 | Ch14 | Ch13 | Ch12 | Ch11 | Ch10 | Ch9 | Ch8 | Ch7 | Ch6 | Ch5 | Ch4 | Ch3 | Ch2 | Ch1 | Ch0 | B |
| Ch11 | Ch10 | Ch9 | Ch8 | Ch7 | Ch6 | Ch5 | Ch4 | Ch3 | Ch2 | Ch1 | Ch0 | Ch53 | Ch52 | Ch51 | Ch50 | Ch49 | Ch48 | Ch47 | Ch46 | Ch45 | Ch44 | Ch43 | Ch42 | Ch41 | Ch40 | Ch39 | Ch38 | Ch37 | Ch36 | Ch35 | Ch34 | Ch33 | Ch32 | Ch31 | Ch30 | Ch29 | Ch28 | Ch27 | Ch26 | Ch25 | Ch24 | Ch23 | Ch22 | Ch21 | Ch20 | Ch19 | Ch18 | Ch17 | Ch16 | Ch15 | Ch14 | Ch13 | Ch12 | Ch11 | Ch10 | Ch9 | Ch8 | Ch7 | Ch6 | Ch5 | Ch4 | Ch3 | Ch2 | Ch1 | Ch0 | A |

| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|---|---|
| 48 | 47 | 46 | 45 | 44 | 43 | 42 | 41 | 40 | 39 | 38 | 37 | 36 | 35 | 34 | 33 | 32 | 31 | 30 | 29 | 28 | 27 | 26 | 25 | 24 | 23 | 22 | 21 | 20 | 19 | 18 | 17 | 16 | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | | | | | | |
| G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | G | E |
| RR | RT | TR | TT | D | |
| RR | RT | TR | TT | C | |
| RR | RT | TR | TT | B | |
| RR | RT | TR | TT | A | |

H4

H4

| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|---|---|---|---|---|
| 48 | 47 | 46 | 45 | 44 | 43 | 42 | 41 | 40 | 39 | 38 | 37 | 36 | 35 | 34 | 33 | 32 | 31 | 30 | 29 | 28 | 27 | 26 | 25 | 24 | 23 | 22 | 21 | 20 | 19 | 18 | 17 | 16 | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | | | | | | | | | | |
| gnd | E | | | | |
| - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | D | | | | |
| - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | C | | | |
| - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | B | | |
| - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | A |


VOYAGER LITE Channel Groupings

| E1 CH # | Device [CH #] | Main Board Device # | Master/Slave |
|---------|---------------|---------------------|--------------|
| 0 - 20 | A[0:20] | U2 | Master |
| 21 - 41 | B[0:20] | U3 | Slave #1 |
| 42 - 62 | C[0:20] | U4 | Slave #2 |



Line Card T1/J1 Test Interface

Header Pin Def.




H3

H3

H4

H4




VOYAGER
Channel Groupings


| T1/J1 CH # | Device [CH #] | Main Board Device # | Master/Slave |
|---------------|------------------|------------------------|--------------|
| 0 - 27 | A[0:27] | U2 | Master |
| 28 - 55 | B[0:27] | U3 | Slave #1 |
| 56 - 83 | C[0:27] | U4 | Slave #2 |

Exar PowerBlox™ Power Supply Reference Design Daughter Card


INPUT VOLTAGE 5V




- M11
- M9
- M8
- M1
- M2





| | | |
|------------------------------------|-----------------------------|----------|
| EXAR Power Management Solution | | |
| Title ORION Daughter Power Card | | |
| Size C | Document Number SP766xOR | Rev A |
| Date Friday, January 11, 2008 | Sheet 1 | of 1 |



System power provided by EXAR PowerBlox™
 Power Supply Reference Design Daughter Card, SP766xOR











Transmitt



Receive





System power provided by EXAR PowerBlox™
 Power Supply Reference Design Daughter Card, SP766xOR






EXAR Experience our Connectivity

Title: XRT86SH328 "Slave 1"

Size: C **Document Number:** ORION Reference Design 2b **Rev:** B.1

Date: Thursday, January 10, 2008 **Sheet:** 3 of 6



Transmit

Receive

