

UM10069

Installation guide for the ISP1761 peripheral controller on Linux 2.6.9

Rev. 01 — 15 October 2007

User manual

Document information

Info	Content
Keywords	isp1761, peripheral controller, universal serial bus, usb, linux
Abstract	This document explains the installation of Linux version 2.6.9, with the kernel directory for the ISP1761 peripheral controller.

Revision history

Rev	Date	Description
01	20071015	First release.

Contact information

For additional information, please visit: <http://www.nxp.com>

For sales office addresses, please send an email to: salesaddresses@nxp.com

1. Introduction

This document explains the installation of Linux version 2.6.9, with the kernel directory **/usr/src/linux-2.6.9** for the ISP1761 Peripheral Controller.

2. Installation environment

This document is based on the installation of the ISP1761 PCI card on a newly formatted hard disk, and using Fedora core 2 with kernel version 2.6.5-1.358 as the initial install. Kernel version 2.6.5-1.358 must be changed to kernel version 2.6.9. Linux-2.6.9 kernel source can be downloaded from the kernel.org site. Make sure that you have the required files to run the ISP1761 Peripheral controller **ISP1761_Linux269_DCD_Ver2.0.0.0.tar.gz** and the optional **.config** file.

3. Extracting source files

Place the downloaded kernel source (**Linux-2.6.9.tar.bz2** or **gz**) in the **/usr/src** directory and extract the kernel source files to the directory.

Steps to extract gz files:

```
#cd /usr/src
#tar -zxvf linux-2.6.9.tar.gz
```

Steps to extract bz/bz2 files:

```
#cd /usr/src
#tar -jxvf linux-2.6.9.tar.bz
```

Or,

```
#cd /usr/src
#tar -jxvf linux-2.6.9.tar.bz2
```

4. Extracting pehcd modules

Copy **ISP1761_Linux269_DCD_Ver2.0.0.0.tar.gz** to **/usr/src/linux-2.6.9/drivers/usb/**.

Go to **/usr/src/linux-2.6.9/drivers/usb/** and run:

```
#tar -xvzf ISP1761_Linux269_DCD_Ver2.0.0.0.tar.gz
```

Go back to **/usr/src/linux-2.6.9**.

5. Compiling and installing Linux-2.6.9

Compile and install **Linux kernel version 2.6.9** with module support enabled.

Go to **/usr/src/linux-2.6.9/**, and run:

```
#make menuconfig
```

Save and exit the configuration.

Or,

Copy the given **.config** file to the root directory of your kernel source.

```
#make menuconfig
```

Save and exit the configuration.

After exiting **menuconfig**, a new **.config** is created.

Run the following commands:

```
#make
#make modules
#make modules_install
#make install
```

If you are using **grub bootloader**, the kernel image is already added to the **grub.conf**.

If you are using **lilo bootloader**, run **lilo** every time modification is made to **lilo.conf**.

Then reboot your computer and run the newly compiled kernel.

6. Creating and inserting binaries for the peripheral controller

After installing the new kernel (Linux-2.6.9).

Go to **/usr/src/linux-2.6.9/drivers/usb/pehcd** and run:

```
#make clean
#make all
```

This will create binaries required for the NXP Peripheral controller in the **/usr/src/linux-2.6.9/drivers/usb/pehcd/objs** directory.

Go to **/usr/src/linux-2.6.9/drivers/usb/pehcd/** and run:

Remark: Perform this set of four commands only when installing a fresh driver:

```
#mkdir /dev/usb/otg
#mknod /dev/usb/otg/otgdev0 c 18 0
#mknod /dev/usb/otg/otgfs0 c 244 0
#dd if=/dev/zero of=/dev/usb/otg/otgdisk count=16388 bs=512
```

Every time you want to unload the driver, run:

```
#!/stop
```

Every time you want to load the driver, run:

```
#!/start
```

7. Enabling messages

All debug levels are defined in **/hal/isp1761.h**.

You can enable required debug messages by defining the related macros.

Example: To enable entry or exit of functions:

```
#undef HCD_DEBUG_LEVEL1 change to #define HCD_DEBUG_LEVEL1
```

8. Enabling MTP support

If you have a Media Transfer Protocol (MTP) client driver, you can enable the MTP support by defining the **MTP_ENABLE** macro in **/hal/isp1761.h**.

9. Legal information

9.1 Definitions

Draft — The document is a draft version only. The content is still under internal review and subject to formal approval, which may result in modifications or additions. NXP Semiconductors does not give any representations or warranties as to the accuracy or completeness of information included herein and shall have no liability for the consequences of use of such information.

9.2 Disclaimers

General — Information in this document is believed to be accurate and reliable. However, NXP Semiconductors does not give any representations or warranties, expressed or implied, as to the accuracy or completeness of such information and shall have no liability for the consequences of use of such information.

Right to make changes — NXP Semiconductors reserves the right to make changes to information published in this document, including without limitation specifications and product descriptions, at any time and without notice. This document supersedes and replaces all information supplied prior to the publication hereof.

Suitability for use — NXP Semiconductors products are not designed, authorized or warranted to be suitable for use in medical, military, aircraft, space or life support equipment, nor in applications where failure or malfunction of a NXP Semiconductors product can reasonably be expected to result in personal injury, death or severe property or environmental damage. NXP Semiconductors accepts no liability for inclusion and/or use of NXP Semiconductors products in such equipment or applications and therefore such inclusion and/or use is for the customer's own risk.

Applications — Applications that are described herein for any of these products are for illustrative purposes only. NXP Semiconductors makes no representation or warranty that such applications will be suitable for the specified use without further testing or modification.

9.3 Trademarks

Notice: All referenced brands, product names, service names and trademarks are property of their respective owners.

10. Contents

1.	Introduction	3
2.	Installation environment	3
3.	Extracting source files	3
4.	Extracting pehcd modules.....	3
5.	Compiling and installing Linux-2.6.9	3
6.	Creating and inserting binaries for the peripheral controller	4
7.	Enabling messages	4
8.	Enabling MTP support	4
9.	Legal information	5
9.1	Definitions	5
9.2	Disclaimers.....	5
9.3	Trademarks	5
10.	Contents.....	6

Please be aware that important notices concerning this document and the product(s) described herein, have been included in the section 'Legal information'.

© NXP B.V. 2007. All rights reserved.

For more information, please visit: <http://www.nxp.com>.
 For sales office addresses, email to: salesaddresses@nxp.com.

