

Acer

**Aspire 4920
Service Guide**

Service guide files and updates are available on the ACER/CSD web; for more information, please refer to <http://csd.acer.com.tw>

PRINTED IN TAIWAN

Revision History

Please refer to the table below for the updates made on Aspire 4920 service guide.

Date	Chapter	Updates

Copyright

Copyright © 2007 by Acer Incorporated. All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written permission of Acer Incorporated.

Disclaimer

The information in this guide is subject to change without notice.

Acer Incorporated makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims any warranties of merchantability or fitness for any particular purpose. Any Acer Incorporated software described in this manual is sold or licensed "as is". Should the programs prove defective following their purchase, the buyer (and not Acer Incorporated, its distributor, or its dealer) assumes the entire cost of all necessary servicing, repair, and any incidental or consequential damages resulting from any defect in the software.

Acer is a registered trademark of Acer Corporation.

Intel is a registered trademark of Intel Corporation.

Core Duo and Core 2 Duo are trademarks of Intel Corporation.

Other brand and product names are trademarks and/or registered trademarks of their respective holders.

Conventions

The following conventions are used in this manual:

SCREEN MESSAGES	Denotes actual messages that appear on screen.
NOTE	Gives bits and pieces of additional information related to the current topic.
WARNING	Alerts you to any damage that might result from doing or not doing specific actions.
CAUTION	Gives precautionary measures to avoid possible hardware or software problems.
IMPORTANT	Reminds you to do specific actions relevant to the accomplishment of procedures.

Preface

Before using this information and the product it supports, please read the following general information.

1. This Service Guide provides you with all technical information relating to the BASIC CONFIGURATION decided for Acer's "global" product offering. To better fit local market requirements and enhance product competitiveness, your regional office MAY have decided to extend the functionality of a machine (e.g. add-on card, modem, or extra memory capability). These LOCALIZED FEATURES will NOT be covered in this generic service guide. In such cases, please contact your regional offices or the responsible personnel/channel to provide you with further technical details.
2. Please note WHEN ORDERING FRU PARTS, that you should check the most up-to-date information available on your regional web or channel. If, for whatever reason, a part number change is made, it will not be noted in the printed Service Guide. For ACER-AUTHORIZED SERVICE PROVIDERS, your Acer office may have a DIFFERENT part number code to those given in the FRU list of this printed Service Guide. You MUST use the list provided by your regional Acer office to order FRU parts for repair and service of customer machines.

Table of Contents

System Specification	1
Features	1
Your Acer Notebook Tour	4
Front View	4
Closed Front View	5
Left View	6
Right View	7
Rear Panel	7
Bottom Panel	8
Indicators	9
Easy-launch Buttons	10
MediaTouch Keys	11
Touchpad	12
Touchpad Basics	12
Using the Keyboard	14
Lock Keys and Embedded Numeric Keypad	14
Windows Keys	15
Hotkeys	16
Special Keys	17
Acer Empowering Technology	18
Empowering Technology Password	18
Acer eNet Management	19
Acer ePower Management	21
Acer eAudio Management	23
Acer ePresentation Management	24
Acer eDataSecurity Management	25
Acer eLock Management	26
Acer eRecovery Management	27
Acer eSettings Management	28
Windows Mobility Center	29
Using the System Utilities	30
Acer GridVista (dual-display compatible)	30
Launch Manager	31
Norton Internet Security	32
Hardware Specifications and Configurations	33
System Utilities	41
BIOS Setup Utility	41
Entering BIOS Setup	41
BIOS Setup Primary Menus	41
BIOS Setup Navigation Keys	41
Information Menu	42
Main Menu	43
Security Menu	44
Boot Menu	46
Exit Menu	47
Machine Disassembly and Replacement	49
Disassembly Requirements	49
General Information	50
Pre-disassembly Instructions	50
Disassembly Process	51

External Module Disassembly Process	52
External Modules Disassembly Flowchart	52
Removing the Battery Pack	53
Removing the SD Dummy Card	54
Removing the Express Dummy Card	54
Removing the Lower Cover	55
Removing the DIMM	56
Removing the WLAN Board Module	57
Removing the Hard Disk Drive Module	58
Removing the Optical Drive Module	59
Main Unit Disassembly Process	61
Main Unit Disassembly Flowchart	61
Removing the CPU Heatsink Module	62
Removing the CPU	63
Removing the Keyboard	64
Removing the Middle Cover	65
Removing the Power Board	66
Removing the Media Board	67
Removing the LCD Module	68
Separating the Upper Case from the Lower Case	70
Removing the Speaker Modules	73
Removing the Launch Board	74
Removing the Touchpad Board Module	75
Removing the Bluetooth Board	77
Removing the USB board	78
Removing the Mainboard	79
Removing the Modem Board	81
Removing the RTC Battery	83
LCD Module Disassembly Process	85
LCD Module Disassembly Flowchart	85
Removing the LCD Bezel	86
Removing the Camera Board	87
Removing the Inverter Board	88
Removing the LCD with Brackets	89
Removing the LCD Brackets	91
Removing the LCD Module Hinges	92
Removing the Antennas	93
Removing the Microphones	94
Troubleshooting	97
System Check Procedures	98
External CD/DVD-ROM Drive Check	98
Keyboard or Auxiliary Input Device Check	98
Memory Check	98
Power System Check	99
Touchpad Check	100
Power-On Self-Test (POST) Error Message	101
Index of Error Messages	102
Phoenix BIOS Beep Codes	104
Index of Symptom-to-FRU Error Message	108
Intermittent Problems	111
Undetermined Problems	112
System Block Diagram and Connector Locations	113
System Block Diagram	113

Board Layout	114
Top View	114
Bottom View	115
FRU (Field Replaceable Unit) List	119
Aspire 4920 Exploded Diagram	120
Aspire 4920 FRU List	121
Model Definition and Configuration	130
Aspire 4920	130
Test Compatible Components	133
Microsoft® Windows® Vista™ Compatibility Test	134
Online Support Information	139

System Specification

Features

Below is a brief summary of the computer's many feature:

Platform

- ❑ Intel® Core™ 2 Duo Mobile Processor T7300/T7500/T7700 (4 MB L2 cache, 2/2.2/2.4 GHz, 800 MHz FSB) and T7100 (2 MB L2 cache, 1.8 GHz, 800 MHz FSB) supporting Intel 64 architecture
- ❑ Mobile Intel GM965/PM965 Express chipset
- ❑ Intel PRO/Wireless 3945ABG (dual-band tri-mode 802.11a/b/g) or 3945BG (dual-mode 802.11b/g) Wi-Fi CERTIFIED® network connection, supporting Acer SignalUp™ wireless technology

Display and Graphics

- ❑ 14.1" WXGA high brightness (200-nits) Acer CrystalBrite™ TFT LCD, 1280 x 800 pixel resolution, supporting simultaneous multi-window viewing via Acer GridVista™
- ❑ 16 ms response time
- ❑ ATI Mobility™ Radeon® X2500 (256 MB of dedicated GDDR2 VRAM) with HyperMemory™ supporting Microsoft® DirectX® 9 and PCI Express® (for selected models)
or
Mobile Intel GM965 Express Chipset with integrated 3D graphics, featuring Intel Graphics Media Accelerator (GMA) X3100 with up to 358 MB of Intel Dynamic Video Memory Technology 4.0 (8 MB of dedicated DDR2 VRAM, up to 350 MB of dynamic system memory), supporting Microsoft® DirectX 9 and DirectX 10 (for selected models)
- ❑ Dual independent display support
- ❑ 16.7 million colors
- ❑ MPEG-2/DVD hardware-assisted capability (acceleration)
- ❑ S-video/TV-out (NTSC/PAL) support
- ❑ Acer Arcade™ featuring Acer CinemaVision™ and Acer ClearVision™ technologies

Storage Subsystem

- ❑ 80/120/160 GB or larger hard disk drive
- ❑ DVD-Super Multi double-layer drive
- ❑ 5-in-1 card reader supporting Secure Digital (SD), MultiMediaCard (MMC), Memory Stick® (MS), Memory Stick PRO™ (MS PRO), xD-Picture Card™ (xD)

Audio

- ❑ Dolby®-certified surround sound system with two built-in stereo speakers
- ❑ Dolby Home Theater audio enhancement featuring Dolby Digital, Dolby Digital Live, Dolby PRO LOGIC® II, Dolby Digital Stereo Creator, Dolby Headphone and Dolby Virtual Speaker technologies
- ❑ Intel High Definition Audio support
- ❑ S/PDIF (Sony/Philips Digital Interface) support for digital speakers
- ❑ MS-Sound compatible

-
- ❑ Acer PureZone technology with two built-in stereo microphones featuring beam forming, echo cancellation, and noise suppression technologies

Input Devices

- ❑ 88-/89-/93-key keyboard, with inverted "T" cursor layout; 2.5 mm (minimum) key travel
- ❑ Seamless touchpad with 4-way scroll button
- ❑ 12 function keys, four cursor keys, two Windows® keys, hotkey controls, embedded numeric keypad, international language support, independent US and Euro dollar sign keys
- ❑ Empowering Key
- ❑ Easy-launch buttons: WLAN, Internet, email, Bluetooth, Acer Arcade™
- ❑ Acer MediaTouch keys: play/pause, stop, previous, next and record keys
- ❑ Acer Media Center remote control (optional)

Communication

- ❑ Acer Video Conference featuring:
 - ✦ Integrated Acer CrystalEye webcam supporting enhanced Acer PrimaLite™ technology
 - ✦ Acer PureZone technology
 - ✦ Optional Acer Xpress VoIP phone
- ❑ WLAN: Intel PRO/Wireless 3945ABG (dual-band tri-mode 802.11a/b/g), or 3945BG (dual-mode 802.11b/g) Wi-Fi CERTIFIED® network connection, supporting Acer SignalUp™ wireless technology
- ❑ WPAN: Bluetooth® 2.0+EDR (Enhanced Data Rate) (for selected models)
- ❑ LAN: Gigabit Ethernet; Wake-on-LAN ready
- ❑ Modem: 56K ITU V.92 with PTT approval; Wake-on-Ring ready

I/O Interface

- ❑ ExpressCard™/54 slot
- ❑ 5-in-1 card reader (SD™/MMC/MS/MS PRO/xD)
- ❑ Four USB 2.0 ports
- ❑ IEEE 1394 port
- ❑ Consumer infrared (CIR) port
- ❑ External display (VGA) port
- ❑ S-video/TV-out (NTSC/PAL) port
- ❑ Headphones/speaker/line-out port with S/PDIF support
- ❑ Microphone-in jack
- ❑ Line-in jack
- ❑ Ethernet (RJ-45) port
- ❑ Modem (RJ-11) port
- ❑ DC-in jack for AC adapter

Power Subsystem

- ❑ ACPI 3.0 CPU power management standard: supports Standby and Hibernation power-saving modes
- ❑ 53.3 W 4800 mAh Li-ion battery pack (6-cell) (for selected models) / 44.4 W 4000 mAh Li-ion battery pack (6-cell) (for selected models)
- ❑ 3-pin 65 W AC adapter (for selected models)

-
- ✦ 2.5-hour rapid charge system-off
 - ✦ 3.5-hour charge-in-use
 - ❑ 3-pin 90 W AC adapter supporting Acer QuicCharge™ technology (for selected models):
 - ✦ 80% charge in 1 hour
 - ✦ 2-hour rapid charge system-off
 - ✦ 3-hour charge-in-use

Dimensions and weight

- ❑ Width: 344 mm (13.5 inches)
- ❑ Depth: 246 mm (9.7 inches)
- ❑ Height: 37/42 mm (1.45/1.65 inches)
- ❑ Weight (approximately, with 6-cell battery): 2.65 kg (5.84 lbs.) (configuration may vary by models)

Environment

- ❑ Temperature:
 - ✦ Operating: 5° C to 35° C
 - ✦ Non-operating: -20° C to 65° C
- ❑ Humidity (non-condensing):
 - ✦ operating: 20% to 80%
 - ✦ Non-operating: 20% to 80%

Your Acer Notebook Tour

After knowing your computer features, let us show you around your new Aspire computer.

Front View



#	Item	Description
1	Acer PureZone	Internal microphone for sound recording.
2	Acer Crystal Eye	Web camera for video communication.
3	Display screen	Also called Liquid-Crystal Display (LCD), displays computer output.
4	Power button	Turns the computer on and off.
5	Status indicators	Light-Emitting Diodes (LEDs) that light up to show the status of the computer's functions and components.
6	Empowering key	Launch Acer Empowering Technology.
7	Easy-launch buttons	Buttons for launching frequently used programs.
8	Palmrest	Comfortable support area for your hands when you use the computer.
9	Status indicators	Light-Emitting Diodes (LEDs) that light up to show the status of the computer's functions and components.
10	Click buttons (left, center and right)	The left and right buttons function like the left and right mouse buttons; the center button serves as a 4-way scroll button.
11	Touchpad	Touch-sensitive pointing device which functions like a computer mouse.
12	Keyboard	For entering data into your computer.
13	Speakers	Left and right speakers deliver stereo audio output.
14	MediaTouch keys	Touch-sensitive keys which function as play/pause, stop, previous, next and record.
15	Acer Arcade	For use with Acer Arcade media playing program.










Closed Front View



#	Icon	Item	Description
1		Unlimited volume control wheel	Adjust the volume of the audio-out.
2		Latch	Locks and releases the lid.
3		CIR receiver	Receives signals from a remote control.
4		Line-in jack	Accepts audio line-in devices (e.g., audio CD player, stereo walkman, mp3 player)
5		Microphone jack	Accepts inputs from external microphones.
6		Headphones/speaker/line-out jack with S/PDIF support	Connects to audio line-out devices (e.g., speakers, headphones).





Left View



#	Icon	Item	Description
1		Kensington lock slot	Connects to a Kensington-compatible computer security lock.
2		External display (VGA) port	Connects to a display device (e.g., external monitor, LCD projector).
3		Modem (RJ-11) port	Connects to a phone line.
4		Ethernet (RJ-45) port	Connects to an Ethernet 10/100/1000-based network.
5		S-video/TV-out (NTSC/PAL) port	Connects to a television or display device with S-video input.
6		USB 2.0 ports	Connect to USB 2.0 devices (e.g., USB mouse, USB camera).
7		4-pin IEEE 1394 port	Connects to IEEE 1394 devices.
8		ExpressCard/54 slot	Accepts one ExpressCard/54 module.
9		5-in-1 card reader	Accepts Secure Digital (SD), MultiMediaCard (MMC), Memory Stick (MS), Memory Stick Pro (MS PRO), and xD-Picture Card. Note: Only one card can operate at any given time.

Right View



#	Icon	Item	Description
1		Optical drive	Internal optical drive; accepts CDs or DVDs.
2		Optical disk access indicator	Lights up when the optical drive is active.
3		Optical drive eject button	Ejects the optical disk from the drive.
4		Emergency eject hole	Ejects the optical drive tray when the computer is turned off.
5		USB 2.0 ports	Connect to USB 2.0 devices (e.g., USB mouse, USB camera).
6		DC-in jack	Connects to an AC adapter.






Rear Panel



#	Item	Description
1	Ventilation slots	Enable the computer to stay cool, even after prolonged use.

Bottom Panel








#	Icon	Item	Description
1		Battery bay	Houses the computer's battery pack.
2		Battery release latch	Releases the battery for removal.
3		Battery lock	Locks the battery in position.
4		Memory compartment	Houses the computer's main memory.
5		Hard disk bay	Houses the computer's hard disk (secured with screws)
6		Ventilation slots and cooling fan	Enable the computer to stay cool, even after prolonged use. Note: Do not cover or obstruct the opening of the fan.

Indicators

The computer has four easy-to-read status indicators:



The front panel indicators are visible even when the computer cover is closed up.

Icon	Function	Description
	HDD	Indicates when the hard disk drive is active.
	Num lock	Lights up when Num Lock is activated.
	Caps lock	Lights up when Caps Lock is activated.
	Power	Indicates the computer's power status.
	Battery	Indicates the computer's battery status.

NOTE: Battery LED status during charging:







- **Amber:** Charging.
- **Green:** Charging complete.

Easy-launch Buttons

There are several conveniently located easy-launch buttons. They are: mail, Web browser, Empowering Key <e> and one user-programmable button.

Press <e> to run the Acer Empowering Technology. The mail and Web browser buttons are pre-set to email and Internet programs, but can be reset by users. To set the Web browser, mail and programmable buttons, run the Acer Launch Manager.



Icon	Function	Description
	Wireless communication button/indicator	Enables/disables the wireless function. Indicates the status of wireless LAN communication.
	Web browser	Internet browser (user-Programmable)
	Mail	Email application (user-Programmable)
	Bluetooth communication button/indicator	Enables/disables the Bluetooth function. Indicates the status of Bluetooth communication.
	Empowering Technology	Launch Acer Empowering Technology. (user-programmable)
	Acer Arcade	Launch Acer Arcade utility

MediaTouch Keys

The touch-sensitive media keys make easy and quick media control with great touch feedback.



Media-Touch keys	Description
▶/	Play or Pause
■	Stop
◀◀	Move backward within the current track or go to the next title or chapter.
▶▶	Move forward within the current track or go to next track, title, or chapter.
●	Record


Touchpad

The built-in touchpad is a pointing device that senses movement on its surface. This means the cursor responds as you move your finger across the surface of the touchpad. The central location on the palmrest provides optimum comfort and support.



Touchpad Basics

The following teaches you how to use the touchpad:



- ☐ Move your finger across the touchpad **(2)** to move the cursor.
- ☐ Press the left **(1)** and right **(4)** buttons located beneath the touchpad to perform selection and execution functions. These two buttons are similar to the left and right buttons on a mouse. Tapping on the touchpad is the same as clicking the left button.
- ☐ Use the 4-way scroll **(3)** button (for selected models) or Acer BioProtect fingerprint reader **(3)** supporting Acer FingerNav 4-way control function (for selected models) to scroll up or down and move left or right a page. This button or fingerprint reader mimics your cursor pressing on the right scroll bar of Windows applications.

Function	Left Button (1)	Right Button (4)	Main touchpad (2)	Center button (3)
Execute	Click twice quickly.		Tap twice (at the same speed as double-clicking the mouse button).	
Select	Click once.		Tap once.	
Drag	Click and hold, then use finger to drag the cursor on the touchpad		Tap twice (at the same speed as double-clicking a mouse button) then hold finger to the touchpad on the second tap to drag the cursor.	
Access context menu		Click once		
Scroll				Click and hold to move up/down/left/right.

NOTE: When using the touchpad, keep it - and your fingers - dry and clean. The touchpad is sensitive to finger movement; hence, the lighter the touch, the better the response. Tapping too hard will not increase the touchpad's responsiveness.

NOTE: By default, vertical and horizontal scrolling is enabled on your touchpad. It can be disabled under Mouse settings in Windows Control Panel.

Using the Keyboard

The keyboard has full-sized keys and an embedded keypad, separate cursor keys, two Windows keys and twelve function keys, and two special keys.

Lock Keys and Embedded Numeric Keypad

The keyboard has three lock keys which you can toggle on and off.






















Lock Key	Description
Caps Lock	When Caps Lock is on, all alphabetic characters typed are in uppercase.
Num Lock <Fn> + <F11>	When Num Lock is on, the embedded keypad is in numeric mode. The keys function as a calculator (complete with the arithmetic operators +, -, *, and /). Use this mode when you need to do a lot of numeric data entry. A better solution would be to connect an external keypad.
Scroll Lock <Fn> + <F12>	When Scroll Lock is on, the screen moves one line up or down when you press the up or down arrow keys respectively. Scroll Lock does not work with some applications.

The embedded numeric keypad functions like a desktop numeric keypad. It is indicated by small characters located on the upper right corner of the keycaps. To simplify the keyboard legend, cursor-control key symbols are not printed on the keys.

Desired Access	Num Lock On	Num Lock Off
Number keys on embedded keypad.	Type numbers in a normal manner.	N/A
Cursor-control keys on embedded keypad	Hold <Shift> while using cursor-control keys.	Hold <Fn> while using cursor-control keys.
Main keyboard keys	Hold <Fn> while typing letters on embedded keypad.	Type the letters in a normal manner.

Windows Keys

The keyboard has two keys that perform Windows-specific functions.

Key	Icon	Description
Windows key		<p>Pressed alone, this key has the same effect as clicking on the Windows Start button; it launches the Start menu.</p> <p>It can also be used with other keys to provide a variety of functions:</p> <ul style="list-style-type: none"><  > : Open or close the Start menu<  > + <D>: Display the desktop<  > + <E>: Open Windows Explore<  > + <F>: Search for a file or folder<  > + <G>: Cycle through Sidebar gadgets<  > + <L>: Lock your computer (if you are connected to a network domain), or switch users (if you're not connected to a network domain)<  > + <M>: Minimizes all windows<  > + <R>: Open the Run dialog box<  > + <T>: Cycle through programs on the taskbar<  > + <U>: Open Ease of Access Center<  > + <X>: Open Windows Mobility Center<  > + <BREAK>: Display the System Properties dialog box<  > + <SHIFT+M>: Restore minimized windows to the desktop<  > + <TAB>: Cycle through programs on the taskbar by using Windows Flip 3-D<  > + <SPACEBAR>: Bring all gadgets to the front and select Windows Sidebar<CTRL> + <  > + <F>: Search for computers (if you are on a network)<CTRL> + <  > + <TAB>: Use the arrow keys to cycle through programs on the taskbar by using Windows Flip 3-D <p>Note: Depending on your edition of Windows Vista, some shortcuts may not function as described.</p>
Application key		<p>This key has the same effect as clicking the right mouse button; it opens the application's context menu.</p>

Hotkeys

The computer employs hotkeys or key combinations to access most of the computer's controls like screen brightness, volume output and the BIOS utility.

To activate hotkeys, press and hold the **<Fn>** key before pressing the other key in the hotkey combination.



Hot Key	Icon	Function	Description
Fn-F1	?	Hot key help	Displays help on hot keys.
Fn-F2		Acer eSettings	Launches the Acer eSettings in Acer eManager.
Fn-F3		Acer ePower Management	Launches the Acer ePowerManagement in Acer eManager.
Fn-F4		Sleep	Puts the computer in Sleep mode.
Fn-F5		Display toggle	Switches display output between the display screen, external monitor (if connected) and both.
Fn-F6		Screen blank	Turns the display screen backlight off to save power. Press any key to return.
Fn-F7		Touchpad toggle	Turns the internal touchpad on and off.
Fn-F8		Speaker toggle	Turns the speakers on and off.
Fn-w		Volume up	Increases the speaker volume.
Fn-y		Volume down	Decreases the speaker volume.
Fn-x		Brightness up	Increases the screen brightness.
Fn-z		Brightness down	Decreases the screen brightness

Special Keys

You can locate the Euro symbol and the US dollar sign at the upper-center and/or bottom-right of your keyboard.



The Euro symbol

1. Open a text editor or word processor.
2. Either press <€> at the bottom-right of the keyboard, or hold <Alt Gr> and then press the <5> key at the upper-center of the keyboard.

NOTE: Some fonts and software do not support the Euro symbol. Please refer to www.microsoft.com/typography/faq/faq12.htm for more information.

The US dollar sign

1. Open a text editor or word processor.
2. Either press <\$> at the bottom-right of the keyboard, or hold <Shift> and then press the <4> key at the upper-center of the keyboard.

NOTE: This function varies according to the language settings.

Acer Empowering Technology

The Empowering Technology toolbar makes it easy for you to access frequently used functions and manage your new Acer system. Displayed by default in the upper half of your screen, it provides access to the following utilities:

- ☐ **Acer eNet Management** hooks up to location-based networks intelligently.
- ☐ **Acer ePower Management** optimizes battery usage via customizable power plans.
- ☐ **Acer ePresentation Management** connects to a projector and adjusts display settings.
- ☐ **Acer eDataSecurity Management** protects data with passwords and encryption.
- ☐ **Acer eLock Management** limits access to external storage media.
- ☐ **Acer eRecovery Management** backs up and recovers data flexibly, reliably and completely.
- ☐ **Acer eSettings Management** accesses system information and adjusts settings easily.



For more information, right click on the Empowering Technology toolbar, then select the **"Help"** or **"Tutorial"** function.

Empowering Technology Password

Before using Acer eLock Management and Acer eRecovery Management, you must initialize the Empowering Technology password. Right-click on the Empowering Technology toolbar and select **"Password Setup"** to do so. If you have not initialized the Empowering Technology password and run Acer eLock Management or Acer eRecovery Management, you will be asked to create it.

NOTE: If you lose the Empowering Technology password, there is no way to reset it except by reformatting your system. Make sure to remember or write down your password!


Acer eNet Management

Acer eNet Management helps you quickly connect to both wired and wireless networks in a variety of locations. To access this utility, select "**Acer eNet Management**" from the Empowering Technology toolbar or run the program from the Acer Empowering Technology program group in Start menu. You can also set Acer eNet Management to start automatically when you boot up your PC.

Acer eNet Management automatically detects the best settings for a new location, while offering you the option to manually adjust the settings to match your needs.



Acer eNet Management can save network settings for a location to a profile, and automatically switch to the appropriate profile when you move from one location to another. Settings stored include network connection settings (IP and DNS settings, wireless AP details, etc.), as well as default printer settings. Security and safety concerns mean that Acer eNet Management does not store username and password information.



Acer ePower Management

Acer ePower Management features a straightforward user interface for configuring your power management options. To access this utility, select "**Acer ePower Management**" from the Empowering Technology toolbar, run the program from the Acer Empowering Technology program group in Start menu, or right-click the Windows power icon in the system tray and select "**Acer ePower Management**".

Using Power Plans


Acer ePower Management comes with three predefined power plans: Balanced, High performance and Power saver. You can also create customized power plans. You can create, switch between, edit, delete and restore power plans, as described below.

View and adjust settings for On Battery and Plugged In modes by clicking the appropriate tabs. You can open Windows power options by clicking "**More Power Options**".

NOTE: You cannot delete the predefined power plans.

To create a new power plan:

Creating customized power plans allows you to save and quickly switch to a personalized set of power options.

1. Click the Create Power Plan icon. 
2. Enter a name for your new power plan.
3. Choose a predefined power plan to base your customized plan on.
4. If necessary, change the display and sleep settings you want your computer to use.
5. Click "**OK**" to save your new power plan.

To switch between power plans:

1. Select the power plan you wish to switch to from the drop-down list.
2. Click "**Apply**".


To edit a power plan:

Editing a power plan allows you to adjust system settings like LCD brightness and CPU speed. You can also turn on/off system components to extend battery life.

1. Switch to the power plan you wish to edit
2. Adjust settings as required.
3. Click "**Apply**" to save your new settings.

To delete a power plan:

You cannot delete the power plan you are currently using. If you want to delete the active power plan, switch to another one first.

1. Select the power plan you wish to delete from the drop-down list.
2. Click the Delete Power Plan icon. 

Battery status

For real-time battery life estimates based on current usage, refer to the panel in the upper half of the window. Click the ⓘ to view estimated battery life in sleep and hibernate modes.




Acer eAudio Management

Acer eAudio Management allows you to easily control the enhanced sound effects of Dolby® Home Theater™ on your system. Select "**Movie**" or "**Game**" mode to experience the awesome realism of 5.1-channel surround sound from just 2 speakers, via Dolby Virtual Speaker technology. "**Music**" mode lets you enjoy your favorite tunes, in vivid detail..



Acer ePresentation Management

Acer ePresentation Management lets you project your computer's display to an external display device or projector using the hotkey: **<Fn> + <F5>**. If auto-detection hardware is implemented in the system and the external display supports it, your system display will be automatically switched out when an external display is connected to the system. For projectors and external devices that are not auto-detected, launch Acer ePresentation Management to choose an appropriate display setting.



NOTE: If the restored resolution is not correct after disconnecting a projector, or you need to use an external resolution that is not supported by Acer ePresentation Management, adjust your display settings using Display Properties or the utility provided by the graphics vendor.

Acer eDataSecurity Management

Acer eDataSecurity Management is an encryption utility that protects your files from being accessed by unauthorized persons. It is conveniently integrated with Windows Explorer as a shell extension for quick data encryption/decryption and also supports on-the-fly file encryption for Lotus Notes and Microsoft Outlook.

The Acer eDataSecurity Management setup wizard will prompt you for a supervisor password and default encryption password. This password will be used to encrypt files by default, or you can choose to enter your own password when encrypting a file.



NOTE: The password used to encrypt a file is the unique key that the system needs to decrypt it. If you lose the password, the supervisor password is the only other key capable of decrypting the file. If you lose both passwords, there will be no way to decrypt your encrypted file! **Be sure to safeguard all related passwords!**




Acer eLock Management

Acer eLock Management is simple yet effective utility that allows you to lock removable storage, optical and floppy drive devices to ensure that data can't be stolen while your system is unattended.

- ☐ Removable Storage Devices — includes USB disk drives, USB pen drives, USB flash drives, USB MP3 drives, USB memory card readers, IEEE 1394 disk drives, and any other removable storage devices that can be mounted as a file system when plugged into the system.
- ☐ Optical Drive Devices — includes any kind of CD-ROM, DVD-ROM, HD-DVD or Blu-ray drive devices.
- ☐ Floppy Drive Devices — 3.5-inch floppy drives only.

To use Acer eLock Management, the Empowering Technology password must be set first. Once set, you can apply locks to any of the devices types. Lock(s) will immediately be set without any reboot necessary, and will remain after rebooting, until removed.

NOTE: If you lose the Empowering Technology password, there is no method to reset it except by reformatting your system. Make sure to remember or write down your password.




Acer eRecovery Management

Acer eRecovery Management is a versatile backup utility. It allows you to create full or incremental backups, burn the factory default image to optical disc, and restore from previously created backups or reinstall applications and drivers. By default, user-created backups are stored to the D:\ drive.

Acer eRecovery Management provides you with:

- ☐ Password protection (Empowering Technology password)
- ☐ Full and incremental backups to hard disk or optical disc
- ☐ Creation of backups:
 - Factory default image
 - User backup image
 - Current system configuration
 - Application backup
- ☐ Restore and recovery:
 - Factory default image
 - User backup image
 - From previously-created CD/DVD
 - Reinstall applications/drivers



NOTE: If your computer did not come with a Recovery CD or System CD, please use Acer eRecovery Management's "System backup to optical disc" feature to burn a backup image to CD or DVD. To ensure the best results when recovering your system using a CD or Acer eRecovery Management, detach all peripherals (except the external Acer ODD, if your computer has one), including your Acer ezDock.

Acer eSettings Management

Acer eSettings Management allows you to inspect hardware specifications, set BIOS passwords and modify boot options.

Acer eSettings Management also:

- ☐ Provides a simple graphical user interface for navigation.
- ☐ Prints and saves hardware specifications.
- ☐ Lets you set an asset tag for your system.



Windows Mobility Center



The Windows Mobility Center collects key mobile-related system settings in one easy-to-find place, so you can quickly configure your Acer system to fit the situation as you change locations, networks or activities. Settings include display brightness, power plan, volume, wireless networking on/off, external display settings, display orientation and synchronization status.

Windows Mobility Center also includes Acer-specific settings like Bluetooth Add Device (if applicable), sharing folders overview/sharing service on or off, and a shortcut to the Acer user guide, drivers and utilities.

To launch Windows Mobility Center:

- ☐ Use the shortcut key <Windows> + <X>
- ☐ Start Windows Mobility Center from the Control panel
- ☐ Start Windows Mobility Center from the Accessories program group in the Start menu


Using the System Utilities

Acer GridVista (dual-display compatible)

To enable the dual display feature of your notebook, first ensure that a second display is connected, then, open the **Display Settings** properties box using the Control Panel or by right-clicking the Windows desktop and selecting **Personalize**. Select the secondary monitor **(2)** icon in the display box and then click the check box **Extend the desktop onto this monitor**. Finally, click **Apply** to confirm the new settings and click **OK** to complete the process.



Acer GridVista is a handy utility that offers four pre-defined display settings so you can view multiple windows on the same screen. To access this function, please go to **Start, All Programs** and click on **Acer GridVista**. You may choose any one of the four display settings indicated below:




Double (vertical), Triple (primary at left), Triple (primary at right), or Quad

Acer GridVista is dual-display compatible, allowing two displays to be partitioned independently.


Acer GridVista is simple to set up:

1. Run Acer GridVista and select your preferred screen configuration for each display from the taskbar.
2. Drag and drop each window into the appropriate grid.
3. Enjoy the convenience of a well-organized desktop.



NOTE: Please ensure that the resolution setting of your second monitor is set to the manufacturer's recommended value.

Launch Manager



Launch Manager allows you to set the four easy-launch buttons located above the keyboard.

You can access the Launch Manager by clicking on **Start, All Programs**, and then **Launch Manager** to start the application.

Norton Internet Security

Norton Internet Security is an anti-virus utility that can protect against viruses, keeping your data safe and secure.

How do I check for viruses?

1. Double-click the **Norton Internet Security** icon on the Windows desktop.
2. Select **Tasks & Scans**.
3. Select **Run Scan** to scan your system.



4. When the scan is complete, review the results of the scan.

NOTE: For optimal security, run a Full System Scan when scanning your computer for the first time.

You can schedule customized virus scans that run unattended on specific dates and times or at periodic intervals. If you are using the computer when the scheduled scan begins, it runs in the background so that you do not have to stop working.

For more information refer to the Norton Internet Security help files.

Hardware Specifications and Configurations

Processor

Item	Specification			
CPU type	Intel® Core™2 Duo T7100 Mobile Processor	Intel Core™2 Duo T7300 Mobile Processor	Intel® Core™2 Duo T7500 Mobile Processor	Intel® Core™2 Duo T7700 Mobile Processor
Clock Speeds	1.8 GHz	2.0 GHz	2.2 GHz	2.4 GHz
L2 Cache	2 MB	4 MB	4 MB	4 MB
Front Side Bus	800 MHz			
Socket Interface	Socket P (PGA/BGA)			

System Board Major Chips

Item	Specification
System core logic	Intel GM965 Express + Intel ICH8M chipsets
HDD controller	Intel ICH8M chipset
Memory controller	Intel GM965 Express chipset
Video controller	Intel GM965 Express chipset
Audio controller	Codec ALC268
PCMCIA controller	OZ129
LAN controller	Intel ICH8M + Broadcom 5787MKMLG chipsets
Modem controller	Intel ICH8M chipset
Bluetooth controller	Intel ICH8M chipset
Keyboard controller	Winbond WPC8768L

Hard Disk Drive Interface

Item	Specification											
Product	Hitachi Travelstar 5K160			Toshiba			Western Digital			Seagate		
Model Name	HTS 5416 80J9 SA00	HTS 5416 12J9 SA00	HTS 5416 16J9 SA00	MK8 037 GSX	MK1 237 GSX	MK1 637 GSX	WD8 00B EVS	WD1 200B EVS	WD1 600B EVS	ST9 8081 1AS	ST9 1208 22A S	ST9 1608 21A S
Capacity (GB)	80	120	160	80	120	160	80	120	160	80	120	160
Form factor and Interface type	2.5 inch Serial ATA											
Bytes per sector	512			512			N/A			512		
Data heads	4			4			N/A			3		
Data disks	2			2			N/A			2		
Spindle speed (RPM)	5400			5400			5400			5400		
Buffer size (MB)	8			8.192			8			8		
Media transfer rate (Mbytes/s, max)	540			300			600			N/A		

Hard Disk Drive Interface

Item	Specification			
Interface transfer rate (Mbytes/s, max)	150 MB/s	N/A	150 MB/s	150 MB/s
Voltage tolerance	5V(DC) +/- 5%	5V(DC) +/- 5%	5V(DC) +/- 5%	5V(DC) +/- 5%

BIOS

Item	Specification
BIOS vendor	Phoenix
BIOS Version	v0.25
Supported protocols	ACPI 1.0b/2.0/3.0 compliance, PCI 2.2, System/HDD Password Security Control, INT 13h Extensions, PnP BIOS 1.0a, SMBIOS 2.4, BIOS Boot Specification, Simple Boot Flag 1.0, Boot Block, PCI Bus Power Management Interface Specification, USB Specification 1.1/2.0, IEEE 1394 1.0, USB/1394 CD-ROM Boot Up support, PC Card Standard 1995 (PCMCIA 3.0 Compliant Device), IrDA 1.0, HD audio, WfM 2.0, Preboot Execution Environment 2.1, Boot Integrity Service Application Program Interface (BIS) 1.0, PC2002/2005 compliant, Intel Enhanced SpeedStep Technology, Intel DPST support, ASF 2.0, TPM v1.2, AHCI support, iAMT 2.5

System Memory

Item	Specification				
Memory controller	Intel GM965 Express chipset				
DIMM socket number	2 sockets				
Supports maximum memory size	2 GB for 32 bit OS, 4 GB for 64bit OS				
Vendor	Samsung	Hynix	Nanya	Powerchip	Promos
Model name	M470T2953 EZ3-CE6	HYMP512S 64CP8-Y5	NT512T64U H8B0FN-3C	AS6E8E63B-6E1A	V916764B24 QBFW-F5
DIMM type	DDR2 Synchronous DRAM				
DIMM speed (MHz)	667				
DIMM size	1GB	1GB	512 MB	512 MB	512 MB

Video

Item	Specification	
VGA controller	Intel GM965 Express chipset with integrated 3D graphics	
Features	Intel Graphic Media Accelerator (GMA) X3100 with up to 358 MB of Intel Dynamic Video Memory Technology 4.0 (8 MB of dedicated DDR2 VRAM, up to 350 MB of dynamic system memory), supporting Microsoft DirectX 9 and DirectX 10	ATI Mobility Radeon X2500 (with up to 256 MB of dedicated GDDR2 VRAM) with HyperMemory supporting Microsoft DirectX 9 and PCI Express

Audio

Item	Specification
Audio controller	Realtek ALC268 Codec
Features	Two built-in Acer 3DSonic stereo speakers, Supports high definition audio, Built-in microphone, MS-sound compatible

PCMCIA Port

Item	Specification
PCMCIA controller	T17412
Card type support	Type-II
Number of slot	One

LAN

Item	Specification
LAN controller	Intel ICH8M + Broadcom 5785KMLG chipsets
LAN connector type	RJ45
Features	Onboard Gigabit Ethernet, PCI-E interface, support ASF 2.0

Wireless LAN module

Item	Specification		
Vendor	Intel		
Model name	Wireless WiFi Link 4965AGN	PRO/Wireless 3945ABG	PRO/Wireless 3945BG
Data throughput	54 Mbps		
Protocol	802.11a/b/g	802.11 a/b/g	802.11 b/g
Interface	PCI bus (mini PCI socket for wireless module)		

Modem

Item	Specification		
Modem controller	Intel ICH8M chipset		
Vendor	Liteon	Foxconn	CastleNet
Model name	MDC-003#A8B	MDC 1.5 T60M955.00	MA820
Baud rate	56 K		
Modem connector type	RJ11		

Bluetooth Module

Item	Specification
Bluetooth controller	Intel ICH8M chipset
Vendor	Foxconn BCM2045
Model name	T60H928.01
Protocol	Bluetooth 2.0
Connector type	Mini USB

Keyboard and Input Devices

Item	Specification
Keyboard controller	Winbond WPC8768L
Model name	Acer FineTouch keyboard
Features	5-degree curve, 88-/89- key, inverted "T" cursor layout, 2.5 mm (minimum) key travel, touchpad pointing device with 4-way scroll button or Acer BioProtect fingerprint reader supporting Acer Finger Nav 4-way control function, hotkey controls, embedded numeric keypad, multi-language support, three easy-launch buttons, three productivity keys, and two front-access communication switches

Combo Drive Interface

Item	Specification	
Vendor	Sony	Philips BenQ
Model name	Slim Combo CRX880A	DS-24CZP
Drive type	Internal Slim CD-RW/DVD combo drive	
Data transfer rate	Write: <ul style="list-style-type: none">• CD-R: 24X• CD-RW: 24X	Read: <ul style="list-style-type: none">• DVD-ROM: 8X• CD-ROM: 24X
Buffer Memory	2 MB	N/A
Interface	IDE	
Applicable disc format	CD-R, CD-RW (Multi speed, High speed, Ultra-speed and Ultra-speed plus) CD-DA, CD-ROM (mode 1), CD-ROM XA (Mode 2, Form 1, Form 2), CD-I, CD-i Bridge, Video-CD, Karaoke CD, Photo CD, Enhanced CD, CD Plus, CD Extra, i-trax CD, CD-Text DVD-ROM, DVD-Video, DVD-Audio, SACD (Hybrid), UDF DVD, DVD-R/RW, DVD+R/RW, DVD+/-R DL, DVD-RAM V1.0/V2.1	
Power supply	5 V DC	

DVD Drive Interface

Item	Specification			
Vendor	Sony	Pioneer	Philips BenQ	Panasonic
Model name	AD-7560A	DVR-K17RS	DS-8A1P	UJ-850
Drive type	Internal Slim DVD/CD writer			
Data transfer rate	Write: <ul style="list-style-type: none"> CD-R: 24X CAV CD-RW: 24X CAV DVD+RW/-RW (single layer): 8X, 6X ZCLV DVD-R/+R (single layer): 8X CAV DVD-R/+R (double layer): 4X ZCLV DVD-RAM: 5X ZCLV Read: <ul style="list-style-type: none"> CD-R/RW/ROM: 24X Max DVD-ROM (single layer): 8X CAV DVD-ROM (double layer): 6X CAV DVD-RAM: 5X ZCLV DVD-R/+R/+RW/-RW (single layer): 8X CAV DVD-R/+R (double layer): 6X CAV 	Write: <ul style="list-style-type: none"> CD-R: 24X CD-RW: 24X DVD-RW: 6X DVD-R/+R/+RW: 8X Read: <ul style="list-style-type: none"> DVD-RAM: 5X 	N/A	Write: <ul style="list-style-type: none"> CD-R: 24X CD-RW: 16X DVD-R: 8X DVD-RW: 4X DVD-RAM: 5X DVD+R(DL): 2.4X DVD+R: 8X DVD+RW: 4X Read: <ul style="list-style-type: none"> CD-R/RW/ROM: 24X DVD-R/RW/ROM: 8X
Buffer Memory	2 MB			
Interface	Enhanced IDE(ATAPI) compatible			
Applicable disc format	DVD-RAM, DVD-R/RW, DVD+R (SL, DL)/RW, CD-R/RW, DVD-ROM, DVD-RAM, DVD-R, DVD-RW, DVD+R (SL, DL), DVD+RW; CD-R, CD-RW, CD-ROM, CD-ROM XA, CD-DA, CD-I, CD-Extra, CD-Text, Photo CD, Video CD			
Power supply	5V DC			

Battery

Item	Specification							
Vendor	Panasonic		Sanyo		Sony		Simplo	
Battery Type	Li-ion		Li-ion		Li-ion		Li-ion	
Pack capacity	6 cell: 2.0 mAh	6 cell: 2.4 mAh	6 cell: 2.0 mAh	6 cell: 2.4 mAh	6 cell: 2.0 mAh	6 cell: 2.4 mAh	6 cell: 2.0 mAh	6 cell: 2.4 mAh

LCD

Item	Specification				
Vendor	AUO	CMO	LG		Samsung
Model name	B141EW04-V4 (Glare)	N141I3-L02 (Glare)	LP141WX1-TLA2 (Glare)	LP141WX3-TLB1(Glare)	LTN141W3-L01-G (Glare)
Screen diagonal (mm)	14.1" WXGA				
Display resolution (pixels)	1280 x 800	1280 x 800	1280 x 768	N/A	1280 x 800
Aspect ratio	16:10	N/A	15:9	N/A	N/A
Active area (mm)	303.36 x 189.6	N/A	305.8 x 183.2	N/A	303.4 x 189.6
Pixel pitch (mm)	0.237	N/A	0.2385 (107)	N/A	0.237
Mode	TN	N/A	N/A	N/A	N/A
Number of colors	262 K	262 K	262,144 (6 bit)	N/A	262 K
Color saturation (NTSC%)	45	N/A	45%	N/A	N/A
Typical white luminance (cd/m ²) also called brightness	200	220	185 (typ.5p)	200	200
Contrast ratio	400:1	300:1	500:1	N/A	500:1
Response time (optical rise time + fall time) (msec)	16	16	25	16	16
Power consumption (watt)	5.1	5.3	N/A	N/A	N/A
Supply voltage (v)	3.3	N/A	N/A	N/A	N/A
Backlight	1 CCFL	N/A	N/A	N/A	N/A
Outline dimensions (mm)	319.5 x 205.5 x 5.2	319.5 x 205.5 x 5.2	320.0 x 199.0 x 5.5	N/A	319.5 x 205.5 x 5.5
Weight (g)	400	400	400	N/A	390

LCD Inverter Board

Item	Specification		
Vendor	YEC	Foxconn	RoHS
Model name	YNV-W06S	T621240.02	VK.21189.406

AC Adapter

Item	Specification	
Vendor	Delta	Lite-On
Model Name	ADP-90SB BBDAF	PA-1900-24 AR
	ADP-90SB BBEA LF	PA-1900-04 WR
Output rating	19 V/4.74 A, 90 W	19 V , 90 W
Input (Vac)	90 ~ 270	100 ~ 240

System Power Management

ACPI mode	Power Management
Off	<ul style="list-style-type: none">• Mech. Off (G3): All devices in the system are turned off completely.• Soft Off (G2/S5): OS initiated shutdown. All devices in the system are turned off completely.
On	<ul style="list-style-type: none">• Working (G0/S0): Individual devices such as the CPU and hard disk may be power managed in this state.• Suspend to RAM (S3): CPU set power down, VGA Suspend, PCMCIA Suspend, Audio Power Down, Hard Disk Power Down, CD-ROM Power Down, and Super I/O Low Power mode.• Save to Disk (S4): Also called Hibernation Mode. System saves all system states and data onto the disc prior to system shutdown.

System Utilities

BIOS Setup Utility

The BIOS Setup Utility is a hardware configuration program built into your system's BIOS (Basic Input/Output System). Since most systems are already properly configured and optimized, there is no need to run this utility. The BIOS setup utility stores basic settings for your system. You will need to run this utility if you encounter configuration problems. Refer to Chapter 4 Troubleshooting when problem arises.

Entering BIOS Setup

Power on the system to start the system POST process. During bootup, press **F2** to enter the BIOS setup screen.

NOTE: You must press **F2** while the system is booting. This key does not work during any other time.

BIOS Setup Primary Menus

There are several tabs on the setup screen corresponding to the six primary BIOS menus.

- ☐ Information
- ☐ Main
- ☐ Security
- ☐ Boot
- ☐ Exit

In the descriptive table following each of the screen illustrations, settings in **boldface** are the default and suggested parameter settings.

BIOS Setup Navigation Keys

Note the following reminders when moving around the Setup utility.

- ☐ Use the **Left** and **Right** arrow keys to move to the next page or to return to the previous screen.
- ☐ Use the **Up** and **Down** arrow keys to select an item.
- ☐ Use the **+** and **-** keys to select an option.

NOTE: You can configure a parameter that is enclosed in square brackets. Grayed-out items have fixed settings and are not user-configurable.


- ☐ Use the **Enter** key to display a submenu screen.

NOTE: When a parameter is preceded by an **arrow** or (**>**), it means that a submenu screen is available.

- ☐ Press **F1** for General Help using the BIOS setup.
- ☐ Press **F9** to load the default configuration.
- ☐ Press **F10** to save changes and close the BIOS setup.
- ☐ Press **Esc** to close the BIOS setup.

NOTE: The parameters on the screens shown in this Guide display default system values. These values may not be the same as those in the system. System information is subject to different models.


Information Menu



Parameter	Description
CPU Type	Type of processor currently installed in the system.
CPU Speed	Speed of the processor currently installed in the system.
IDE0 Model Name	Model name of HDD installed on the primary IDE channel.
IDE0 Serial Number	Serial number of HDD installed on the primary IDE channel.
ATAPI Model Name	Model name of the ATAPI CD/DVD-ROM drive installed in the system.
System BIOS Version	Version number of the BIOS setup utility.
VGA BIOS Version	Version number of the VGA firmware.
KBC Version	Version number of the keyboard controller.
Serial Number	Serial number of the system.
Asset Tag Number	Asset tag number of the system.
Product Name	Product name of the system.
Manufacturer Name	Name of the manufacturer of this system.
UUID	Visible only when an internal LAN device is present. UUID=32bytes


NOTE: The system configuration information varies in different models.

Main Menu



Parameter	Description	Format/Option
System Time	Set the system time following the hour-minute-second format.	Format: HH:MM:SS (hour:minute:second)
System Date	Set the date following the weekday-month-day-year format.	Format MM/DD/YYYY (month/day/year)
System Memory	Total size of system memory detected during POST.	
Extended Memory	Total size of extended memory during POST.	
Video Memory	Total size of VGA memory.	
Quiet Boot	When Enabled, the BIOS splash screen is displayed during startup.	Enabled Disabled
Network Boot	When Enabled, the system can be booted from another PC on your LAN, such as a remote server.	Enabled Disabled
F12 Boot Menu	When Enabled, pressing the F12 key during POST brings up a menu of devices that you can select to boot.	Disabled Enabled
D2D Recovery	Enables or disables disk-to-disk recovery. D2D recovery is a method of restoring the system to factory configurations without using recovery CDs.	Enabled Disabled

Security Menu



Parameter	Description	Option
Supervisor Password Is	Indicates whether a supervisor password has been assigned.	Clear or Set
User Password Is	Indicates whether a user password has been assigned.	Clear or Set
HDD Password Is	Indicates whether a hard disk drive password has been assigned.	Clear or HDD Password Set
Set Supervisor Password	Press Enter to configure the supervisor password.	
Set User Password	Press Enter to configure the user password.	
Set HDD Password	Press Enter to configure the hard disk drive password.	
Password on Boot	Enables or disables security check during POST.	Disabled or Enabled

NOTE: Refer to the “Removing a System Password” section for more information on how to remove a password.

Setting a System Password

1. Use the **up/down** keys to select a password parameter (Set Supervisor Password, Set User Password, or Set Secondary MAS.Disk Password), then press **Enter**. A Password box will appear.
2. Type a password then press **Enter**.
The password may consist of up to six alphanumeric characters (A-Z, a-z, 0-9).
3. Retype the password to verify the first entry then press **Enter** again.
4. Press **F10**.
5. Select **Yes** to save the new password and close the Setup Utility.

Changing a System Password


1. Use the **up/down** keys to select a password parameter (Set Supervisor Password, Set User Password, or Set Secondary MAS.Disk Password), then press **Enter**.
2. Type the original password then press **Enter**.
3. Type a new password then press **Enter**.
4. Retype the password to verify the first entry then press **Enter** again.
5. Press **F10**.
6. Select **Yes** to save the new password and close the Setup Utility.

Removing a System Password


1. Use the **up/down** keys to select a password parameter (Set Supervisor Password, Set User Password, or Set Secondary MAS.Disk Password), then press **Enter**.
2. Enter the current password then press **Enter**.
3. Press **Enter** twice without entering anything in the new and confirm password fields.
4. After doing this, the system automatically sets the related password parameter to **Clear**.

Boot Menu

This menu allows you to set the drive priority during system boot-up. The system will attempt to boot from the first device on the list. If the first device is not available, it will continue down the list until it reaches an available device. BIOS setup will display an error message if the drive(s) specified is not bootable.



Exit Menu



Parameter	Description
Exit Saving Changes	Save changes made and close the BIOS setup.
Exit Discarding Changes	Discards changes made and close the BIOS setup.
Load Setup Defaults	Loads the default settings for all BIOS setup parameters. Setup Defaults are quite demanding in terms of resources consumption. If you are using low-speed memory chips or other kinds of low-performance components and you choose to load these settings, the system might not function properly.
Discard Changes	Discards all changes made in the BIOS setup.
Save Changes	Saves changes made in the BIOS setup.

Machine Disassembly and Replacement

This chapter contains step-by-step procedures on how to disassemble the notebook computer for maintenance and troubleshooting.

Disassembly Requirements

To disassemble the computer, you need the following tools:

- ☐ Wrist grounding strap and conductive mat for preventing electrostatic discharge
- ☐ Flat screwdriver
- ☐ Philips screwdriver
- ☐ Hex screwdriver
- ☐ Plastic flat-blade screwdriver
- ☐ Plastic tweezers

NOTE: The screws for the different components vary in size. During the disassembly process, group the screws with the corresponding components to avoid mismatch when putting back the components.

General Information

Pre-disassembly Instructions

Before proceeding with the disassembly procedure, make sure that you do the following:

1. Turn off the power to the system and all peripherals.
2. Unplug the AC adapter and all power and signal cables from the system.



3. Place the system on a flat, stable surface.
4. Remove the battery pack. See "Removing the Battery Pack" on page 53.

Disassembly Process

The disassembly process is divided into the following stages:

- ☐ External module disassembly
- ☐ Main unit disassembly
- ☐ LCD module disassembly

The flowcharts provided in the succeeding disassembly sections illustrate the entire disassembly sequence. Observe the order of the sequence to avoid damage to any of the hardware components. For example, if you want to remove the mainboard, you must first remove the keyboard, then disassemble the inside assembly frame in that order.

Main Screw List


Item	Screw	Color	Part No.
A	M2 x L4 (torque 1.6)	Black	86.00F24.724
	M2 x L4 (torque 3.0)		
B	M3 x L4	Silver	86.9A554.4R0
C	M2 x L6	Black	86.00F58.726
D	M2 x L2.5	Silver	86.00F22.722
E	M2 x L4		86.9A552.3R0
F	M2.5 x L8	Black	86.00E34.738
G	M2.5 x L6		86.00E33.736
H	M2 x L3	Silver	86.00C07.220
I	M2 x L2.5	Silver	86.9A552.6R0

External Module Disassembly Process

External Modules Disassembly Flowchart

The flowchart below gives you a graphic representation on the entire disassembly sequence and instructs you on the components that need to be removed during servicing. For example, if you want to remove the mainboard, you must first remove the keyboard, then disassemble the inside assembly frame in that order.

EXTERNAL MODULE DISASSEMBLY



Screw List

Item	Screw	Part No.
A	M2 x L4	86.00F24.724
B	M3 x L4	86.9A554.4R0
C	M2 x L6	86.00F58.726
D	M2 x L2.5	86.00F22.722

Removing the Battery Pack

1. Turn base unit over.
2. Slide the battery lock/unlock latch to the unlock position (1).



3. Slide and hold the battery release latch to the release position (2).



4. Remove the battery from the main unit (3).



Removing the SD Dummy Card

1. See “Removing the Battery Pack” on page 53.
2. Push against the card, as if you were pushing it further into the slot, letting the card spring out.



3. Remove the card from the slot.



Removing the Express Dummy Card

1. See “Removing the Battery Pack” on page 53.
2. Push against the card, as if you were pushing it further into the slot, letting the card spring out.



3. Remove the card from the slot.



Removing the Lower Cover

1. See “Removing the Battery Pack” on page 53.
2. Turn the base unit over, then loosen the eight screws (A) on the lower cover.



Step	Size (Quantity)	Color	Torque
1~8	M2 x L4	Black	1.6 kgf-cm

3. Use a plastic flat-blade screwdriver to pry open the lower cover.



4. Remove the lower cover from the lower case.



Removing the DIMM

1. See "Removing the Battery Pack" on page 53.
2. See "Removing the Lower Cover" on page 55.
3. Push out the latches on both sides of the DIMM socket to release the DIMM.



4. Remove the DIMM module.



Removing the WLAN Board Module

- 1. See “Removing the Battery Pack” on page 53.
- 2. See “Removing the Lower Cover” on page 55.
- 3. Detach the wireless board barcode label from the WLAN board.



- 4. Disconnect the two antenna cables from the WLAN board, then move the antennas away from the board.



- 5. Remove the two screws (A) on the WLAN board to release the WLAN board.



Step	Size (Quantity)	Color	Torque
1~2	M2 x L4 (2)	Black	1.6 kgf-cm

6. Detach the WLAN board from the WLAN socket.



NOTE: When attaching the antennas back to the WLAN board, make sure the cable are routed properly.

Removing the Hard Disk Drive Module

1. See “Removing the Battery Pack” on page 53.
2. See “Removing the SD Dummy Card” on page 54.
3. See “Removing the Express Dummy Card” on page 54.
4. See “Removing the Lower Cover” on page 55.
5. Remove the screw (A) securing the HDD assembly to the unit.



Step	Size (Quantity)	Color	Torque
1	M2 x L4 (1)	Black	3 kgf-cm

6. Pull the HDD module out by pulling on the mylar attached to it, gently slide-out the HDD module from its bay.



NOTE: To prevent damage to device, avoid pressing down on it or placing heavy objects on top of it.

7. Remove the two screws (A) on the HDD bracket.



Step	Size (Quantity)	Color	Torque
1~2	M2 x L4 (2)	Silver	3.0 kgf-cm

8. Remove the hard disk drive.



Removing the Optical Drive Module

1. See “Removing the Battery Pack” on page 53.
2. See “Removing the Lower Cover” on page 55.
3. Remove the screw (C) on the bottom side of the unit, as shown.



Step	Size (Quantity)	Color	Torque
1	M2 x L6 (1)	Black	3 kgf-cm

4. Using the flat-blade screwdriver, press the end of the module forward, then slide out the optical drive module from the main unit.




5. Remove the two screws (D) securing the optical bracket and remove the locker bracket from the optical disk drive module.



Step	Size (Quantity)	Color	Torque
1-2	M2 x L2.5 (2)	Silver	1.6 kgf-cm

Main Unit Disassembly Process

Main Unit Disassembly Flowchart



Screw List

	Screw	Part No.
A	M2 x L4	86.00F24.724
C	M2 x L6	86.00F58.726
F	M2.5 X L8	86.00E34.738

Removing the CPU Heatsink Module

1. See “Removing the Battery Pack” on page 53.
2. See “Removing the Lower Cover” on page 55.
3. Detach the heatsink cable from the mainboard.



4. Loosen the four spring-loaded screws on the heatsink in the order shown.



5. Remove the heatsink module.



Removing the CPU

1. See “Removing the Battery Pack” on page 53.
2. See “Removing the Lower Cover” on page 55.
3. See “Removing the CPU Heatsink Module” on page 62.
4. Using a flat screwdriver, turn the CPU socket latch to the unlock position by aligning the latch to the unlock symbol, then remove the CPU.



NOTE: When installing the CPU, make sure to install the CPU with PIN 1 at the corner as shown.



Removing the Keyboard

1. See “Removing the Battery Pack” on page 53.
2. Press the plastic flat-blade screwdriver to the notches, shown below, to disengage the keyboard from the main unit.



3. Carefully pry up and out the keyboard and turn it over.



4. Disconnect the keyboard cable from the mainboard to remove the keyboard.



Removing the Middle Cover

1. See “Removing the Battery Pack” on page 53.
2. See “Removing the Keyboard” on page 64.
3. Open the LCD screen all the way to facilitate the easy removal of the middle cover.
4. Carefully insert the flat screwdriver between the middle cover and lower case and gently pry up the middle cover.





5. Continue prying the middle cover until the full length of the cover releases from the main unit, then turn it over.



6. Using a plastic flat-blade screwdriver, pry open the connector plate then detach the media board cable from the media board.



7. Detach the power board cable from the power board, then remove the middle cover.



Removing the Power Board

1. See “Removing the Battery Pack” on page 53.
2. See “Removing the Keyboard” on page 64.
3. See “Removing the Middle Cover” on page 65.
4. Detach the mylar tape from the launch board.




5. Remove the three screws (A) from the power board.



Step	Size (Quantity)	Color	Torque
1~3	M2 x L4 (3)	Black	1.6 kgf-cm

-
6. Remove the power board.



Removing the Media Board

1. See “Removing the Battery Pack” on page 53.
2. See “Removing the Keyboard” on page 64.
3. See “Removing the Middle Cover” on page 65.
4. See “Removing the Power Board” on page 66.
5. Insert a flat-blade screwdriver between the media board cover and middle cover and pry up the gently.



6. Remove the media board cover from the middle cover.



7. Detach the mylar tape from the media board.



8. Carefully insert the flat-blade screwdriver under the side of the media board cover and gently pry up the board until it releases from the cover.
9. Remove the media board.



Removing the LCD Module

1. See “Removing the Battery Pack” on page 53.
2. See “Removing the Lower Cover” on page 55.
3. See “Removing the Keyboard” on page 64.
4. See “Removing the Middle Cover” on page 65.
5. Disconnect the microphone cable from the mainboard.



6. Disconnect the LCD coaxial cable from the mainboard.



7. Pull out the antenna cables as shown.



8. Turn the system over and remove the two screws (F) from the base of the unit.



Step	Size (Quantity)	Color	Torque
1~2	M2.5 x L8 (2)	Black	4.0 kgf-cm

9. Remove the two screws (F) from the left and right hinge of the LCD module.



Step	Size (Quantity)	Color	Torque
1~2	M2.5 x L8 (2)	Black	4.0 kgf-cm

10. Carefully remove the LCD module from the base unit.



NOTE: Make sure the cables are routed well before connecting the cables back to the unit.

Separating the Upper Case from the Lower Case

1. See "Removing the Battery Pack" on page 53.
2. See "Removing the SD Dummy Card" on page 54.
3. See "Removing the Express Dummy Card" on page 54.
4. See "Removing the Lower Cover" on page 55.
5. See "Removing the DIMM" on page 56.
6. See "Removing the WLAN Board Module" on page 57.
7. See "Removing the Hard Disk Drive Module" on page 58.
8. See "Removing the Optical Drive Module" on page 59.
9. See "Removing the CPU Heatsink Module" on page 62.
10. See "Removing the CPU" on page 63.
11. See "Removing the Keyboard" on page 64.
12. See "Removing the Middle Cover" on page 65.
13. See "Removing the LCD Module" on page 68.

14. Disconnect the speaker cable from the mainboard.



15. Detach the launch board cable from the mainboard.



16. Detach the touchpad cable from the mainboard.



17. Remove the three screws (A) on the upper case.



Step	Size (Quantity)	Color	Torque
1~3	M2 x L4 (3)	Black	1.6 kgf-cm

18. Turn the system over and remove the eleven screws (C) on the lower case.




Step	Size (Quantity)	Color	Torque
1~11	M2 x L6 (11)	Black	3.0 kgf-cm

19. Gently detach the upper case from the lower case.



Removing the Speaker Modules

- 1. See “Removing the Battery Pack” on page 53.
- 2. See “Removing the SD Dummy Card” on page 54.
- 3. See “Removing the Express Dummy Card” on page 54.
- 4. See “Removing the Lower Cover” on page 55.
- 5. See “Removing the DIMM” on page 56.
- 6. See “Removing the WLAN Board Module” on page 57.
- 7. See “Removing the Hard Disk Drive Module” on page 58.
- 8. See “Removing the Optical Drive Module” on page 59.
- 9. See “Removing the CPU Heatsink Module” on page 62.
- 10. See “Removing the CPU” on page 63.
- 11. See “Removing the Keyboard” on page 64.
- 12. See “Removing the Middle Cover” on page 65.
- 13. See “Removing the LCD Module” on page 68.
- 14. See “Separating the Upper Case from the Lower Case” on page 70.
- 15. Remove the four screws on the speaker modules.



Step	Size (Quantity)	Color	Torque
1~4	N/A	Silver	1.6 kgf-cm

- 16. Remove the speakers.



Removing the Launch Board

- 1. See “Removing the Battery Pack” on page 53.
- 2. See “Removing the SD Dummy Card” on page 54.
- 3. See “Removing the Express Dummy Card” on page 54.
- 4. See “Removing the Lower Cover” on page 55.
- 5. See “Removing the DIMM” on page 56.
- 6. See “Removing the WLAN Board Module” on page 57.
- 7. See “Removing the Hard Disk Drive Module” on page 58.
- 8. See “Removing the Optical Drive Module” on page 59.
- 9. See “Removing the CPU Heatsink Module” on page 62.
- 10. See “Removing the CPU” on page 63.
- 11. See “Removing the Keyboard” on page 64.
- 12. See “Removing the Middle Cover” on page 65.
- 13. See “Removing the LCD Module” on page 68.
- 14. See “Separating the Upper Case from the Lower Case” on page 70.
- 15. Remove the two screws (A) from the launch board bracket.



Step	Size (Quantity)	Color	Torque
1~2	M2 x L4 (2)	Black	1.6 kgf-cm

- 16. Remove the bracket.



17. Remove the three screws (A) from the launch board.



Step	Size (Quantity)	Color	Torque
1~3	M2 x L4 (3)	Black	1.6 kgf-cm


18. Remove the launch board.



Removing the Touchpad Board Module

1. See "Removing the Battery Pack" on page 53.
2. See "Removing the SD Dummy Card" on page 54.
3. See "Removing the Express Dummy Card" on page 54.
4. See "Removing the Lower Cover" on page 55.
5. See "Removing the DIMM" on page 56.
6. See "Removing the WLAN Board Module" on page 57.
7. See "Removing the Hard Disk Drive Module" on page 58.
8. See "Removing the Optical Drive Module" on page 59.
9. See "Removing the CPU Heatsink Module" on page 62.
10. See "Removing the CPU" on page 63.
11. See "Removing the Keyboard" on page 64.
12. See "Removing the Middle Cover" on page 65.
13. See "Removing the LCD Module" on page 68.
14. See "Separating the Upper Case from the Lower Case" on page 70.

15. Remove the two screws (A) on the touchpad bracket.



Step	Size (Quantity)	Color	Torque
1~2	M2 x L4 (2)	Black	1.6 kgf-cm

16. Remove the touchpad bracket from the upper case.



17. Carefully insert the flat screwdriver under the side of the touchpad board and gently pry up the board.



-
18. Continue prying the board until it releases from the upper case, then remove the board.



Removing the Bluetooth Board

1. See "Removing the Battery Pack" on page 53.
2. See "Removing the SD Dummy Card" on page 54.
3. See "Removing the Express Dummy Card" on page 54.
4. See "Removing the Lower Cover" on page 55.
5. See "Removing the DIMM" on page 56.
6. See "Removing the WLAN Board Module" on page 57.
7. See "Removing the Hard Disk Drive Module" on page 58.
8. See "Removing the Optical Drive Module" on page 59.
9. See "Removing the CPU Heatsink Module" on page 62.
10. See "Removing the CPU" on page 63.
11. See "Removing the Keyboard" on page 64.
12. See "Removing the Middle Cover" on page 65.
13. See "Removing the LCD Module" on page 68.
14. See "Separating the Upper Case from the Lower Case" on page 70.
15. Disconnect the Bluetooth cable from the mainboard.



-
16. Carefully detach the Bluetooth board from the lower case.



Removing the USB board

1. See "Removing the Battery Pack" on page 53.
2. See "Removing the SD Dummy Card" on page 54.
3. See "Removing the Express Dummy Card" on page 54.
4. See "Removing the Lower Cover" on page 55.
5. See "Removing the DIMM" on page 56.
6. See "Removing the WLAN Board Module" on page 57.
7. See "Removing the Hard Disk Drive Module" on page 58.
8. See "Removing the Optical Drive Module" on page 59.
9. See "Removing the CPU Heatsink Module" on page 62.
10. See "Removing the CPU" on page 63.
11. See "Removing the Keyboard" on page 64.
12. See "Removing the Middle Cover" on page 65.
13. See "Removing the LCD Module" on page 68.
14. See "Separating the Upper Case from the Lower Case" on page 70.
15. Disconnect the USB FFC (flat flexible cable) from the mainboard.



16. Pull out the AC input cable and move away from the USB board.



17. Remove the screw (A) on the USB board.



Step	Size (Quantity)	Color	Torque
1~2	M2 x L4 (2)	Black	1.6 kgf-cm

18. Remove the USB board.



Removing the Mainboard

1. See “Removing the Battery Pack” on page 53.
2. See “Removing the SD Dummy Card” on page 54.
3. See “Removing the Express Dummy Card” on page 54.
4. See “Removing the Lower Cover” on page 55.
5. See “Removing the DIMM” on page 56.
6. See “Removing the WLAN Board Module” on page 57.

-
7. See "Removing the Hard Disk Drive Module" on page 58.
 8. See "Removing the Optical Drive Module" on page 59.
 9. See "Removing the CPU Heatsink Module" on page 62.
 10. See "Removing the CPU" on page 63.
 11. See "Removing the Keyboard" on page 64.
 12. See "Removing the Middle Cover" on page 65.
 13. See "Removing the LCD Module" on page 68.
 14. See "Separating the Upper Case from the Lower Case" on page 70.
 15. See "Removing the Bluetooth Board" on page 77.
 16. See "Removing the USB board" on page 78.
 17. Detach the media board cable from the lower case.



18. Detach the power board cable from the lower case.



19. Remove the two screws (A) holding the mainboard to the lower case.



Step	Size (Quantity)	Color	Torque
1~2	M2 x L4 (2)	Black	1.6 kgf-cm

20. Carefully detach the mainboard from the lower case.



Removing the Modem Board

1. See “Removing the Battery Pack” on page 53.
2. See “Removing the SD Dummy Card” on page 54.
3. See “Removing the Express Dummy Card” on page 54.
4. See “Removing the Lower Cover” on page 55.
5. See “Removing the DIMM” on page 56.
6. See “Removing the WLAN Board Module” on page 57.
7. See “Removing the Hard Disk Drive Module” on page 58.
8. See “Removing the Optical Drive Module” on page 59.
9. See “Removing the CPU Heatsink Module” on page 62.
10. See “Removing the CPU” on page 63.
11. See “Removing the Keyboard” on page 64.
12. See “Removing the Middle Cover” on page 65.
13. See “Removing the LCD Module” on page 68.
14. See “Separating the Upper Case from the Lower Case” on page 70.
15. See “Removing the Bluetooth Board” on page 77.
16. See “Removing the USB board” on page 78.

17. See “Removing the Mainboard” on page 79.
18. Disconnect the modem cable from the mainboard.



19. Detach the masking tape from the mainboard.



20. Remove the two screws (A) on the modem board.



Step	Size (Quantity)	Color	Torque
1~2	M2 x L4 (2)	Silver	1.6 kgf-cm

-
21. Detach the modem board from the mainboard.



Removing the RTC Battery

1. See "Removing the Battery Pack" on page 53.
2. See "Removing the SD Dummy Card" on page 54.
3. See "Removing the Express Dummy Card" on page 54.
4. See "Removing the Lower Cover" on page 55.
5. See "Removing the DIMM" on page 56.
6. See "Removing the WLAN Board Module" on page 57.
7. See "Removing the Hard Disk Drive Module" on page 58.
8. See "Removing the Optical Drive Module" on page 59.
9. See "Removing the CPU Heatsink Module" on page 62.
10. See "Removing the CPU" on page 63.
11. See "Removing the Keyboard" on page 64.
12. See "Removing the Middle Cover" on page 65.
13. See "Removing the LCD Module" on page 68.
14. See "Separating the Upper Case from the Lower Case" on page 70.
15. See "Removing the Bluetooth Board" on page 77.
16. See "Removing the USB board" on page 78.
17. See "Removing the Mainboard" on page 79.
18. Detach the battery cable from the mainboard.




19. Carefully detach the RTC battery from the SD card slot.



LCD Module Disassembly Process

LCD Module Disassembly Flowchart

LCD MODULE DISASSEMBLY



Main Screw List

Item	Screw	Part No.
G	M2.5 x L6	86.00E33.736
H	M2 x L3	86.00C07.220

Removing the LCD Bezel

- 1. See “Removing the Battery Pack” on page 53.
- 2. See “Removing the Lower Cover” on page 55.
- 3. See “Removing the DIMM” on page 56.
- 4. See “Removing the WLAN Board Module” on page 57.
- 5. See “Removing the Hard Disk Drive Module” on page 58.
- 6. See “Removing the Optical Drive Module” on page 59.
- 7. See “Removing the CPU Heatsink Module” on page 62.
- 8. See “Removing the CPU” on page 63.
- 9. See “Removing the Keyboard” on page 64.
- 10. See “Removing the Middle Cover” on page 65.
- 11. See “Removing the LCD Module” on page 68.
- 12. Remove the six rounded screw caps as shown.



- 13. Remove the six screws (G) on the LCD module.



Step	Size (Quantity)	Color	Torque
1~4	M2.5 x L6 (6)	Black	3.0 kgf-cm

-
14. Carefully pry open the LCD bezel and remove the bezel from the LCD module.



Removing the Camera Board

1. See “Removing the Battery Pack” on page 53.
2. See “Removing the Lower Cover” on page 55.
3. See “Removing the DIMM” on page 56.
4. See “Removing the WLAN Board Module” on page 57.
5. See “Removing the Hard Disk Drive Module” on page 58.
6. See “Removing the Optical Drive Module” on page 59.
7. See “Removing the CPU Heatsink Module” on page 62.
8. See “Removing the CPU” on page 63.
9. See “Removing the Keyboard” on page 64.
10. See “Removing the Middle Cover” on page 65.
11. See “Removing the LCD Module” on page 68.
12. See “Removing the LCD Bezel” on page 86.
13. Disconnect the camera cable from the camera board.



-
14. Remove the camera board.




Removing the Inverter Board

1. See "Removing the Battery Pack" on page 53.
2. See "Removing the Lower Cover" on page 55.
3. See "Removing the DIMM" on page 56.
4. See "Removing the WLAN Board Module" on page 57.
5. See "Removing the Hard Disk Drive Module" on page 58.
6. See "Removing the Optical Drive Module" on page 59.
7. See "Removing the CPU Heatsink Module" on page 62.
8. See "Removing the CPU" on page 63.
9. See "Removing the Keyboard" on page 64.
10. See "Removing the Middle Cover" on page 65.
11. See "Removing the LCD Module" on page 68.
12. See "Removing the LCD Bezel" on page 86.
13. Carefully detach the aluminum foil tape from the inverter board.



14. Remove the screw (G) that holds the board to the panel.



Step	Size (Quantity)	Color	Torque
1~2	M2.5 x L6 (2)	Black	3 kgf-cm

15. Turn the inverter board over.
16. Disconnect the 2P cable from the inverter board, then disconnect the inverter board cable from its connector.



17. Remove the inverter board.

Removing the LCD with Brackets

1. See “Removing the Battery Pack” on page 53.
2. See “Removing the Lower Cover” on page 55.
3. See “Removing the DIMM” on page 56.
4. See “Removing the WLAN Board Module” on page 57.
5. See “Removing the Hard Disk Drive Module” on page 58.
6. See “Removing the Optical Drive Module” on page 59.
7. See “Removing the CPU Heatsink Module” on page 62.
8. See “Removing the CPU” on page 63.
9. See “Removing the Keyboard” on page 64.
10. See “Removing the Middle Cover” on page 65.
11. See “Removing the LCD Module” on page 68.
12. See “Removing the LCD Bezel” on page 86.
13. See “Removing the Inverter Board” on page 88.

14. Remove the two screws (G) securing the left and right LCD brackets to the LCD back cover.



Step	Size (Quantity)	Color	Torque
1~2	M2.5 x L6 (2)	Silver	2.5 kgf-cm

15. Detach the LCD with the brackets from the back cover, then turn it over.



16. Detach the acetic tapes holding the cables to the back panel.



-
17. Detach the acetic tapes holding the FPC cable to the edge of the LCD panel.



18. Detach the acetic tape securing the FPC connector.
19. Disconnect the FPC cable from the LCD panel.



Removing the LCD Brackets

1. See "Removing the Battery Pack" on page 53.
2. See "Removing the Lower Cover" on page 55.
3. See "Removing the DIMM" on page 56.
4. See "Removing the WLAN Board Module" on page 57.
5. See "Removing the Hard Disk Drive Module" on page 58.
6. See "Removing the Optical Drive Module" on page 59.
7. See "Removing the CPU Heatsink Module" on page 62.
8. See "Removing the CPU" on page 63.
9. See "Removing the Keyboard" on page 64.
10. See "Removing the Middle Cover" on page 65.
11. See "Removing the LCD Module" on page 68.
12. See "Removing the LCD Bezel" on page 86.
13. See "Removing the Inverter Board" on page 88.
14. See "Removing the LCD with Brackets" on page 89.

15. Remove the four screws (H) securing the left and right LCD brackets to remove the brackets.



Step	Size (Quantity)	Color	Torque
1~4	M2 x L3 (4)	Silver	1.6 kgf-cm

Removing the LCD Module Hinges

1. See “Removing the Battery Pack” on page 53.
2. See “Removing the Lower Cover” on page 55.
3. See “Removing the DIMM” on page 56.
4. See “Removing the WLAN Board Module” on page 57.
5. See “Removing the Hard Disk Drive Module” on page 58.
6. See “Removing the Optical Drive Module” on page 59.
7. See “Removing the CPU Heatsink Module” on page 62.
8. See “Removing the CPU” on page 63.
9. See “Removing the Keyboard” on page 64.
10. See “Removing the Middle Cover” on page 65.
11. See “Removing the LCD Module” on page 68.
12. See “Removing the LCD Bezel” on page 86.
13. See “Removing the Inverter Board” on page 88.
14. See “Removing the LCD with Brackets” on page 89.
15. See “Removing the LCD Brackets” on page 91.
16. Remove the two screws (G) securing the left and right LCD module hinges.



Step	Size (Quantity)	Color	Torque
1~2	M2.5 x L6 (2)	Black	3.0 kgf-cm

-
17. Remove the left and right hinges from the LCD back cover.



Removing the Antennas

1. See "Removing the Battery Pack" on page 53.
2. See "Removing the Lower Cover" on page 55.
3. See "Removing the DIMM" on page 56.
4. See "Removing the WLAN Board Module" on page 57.
5. See "Removing the Hard Disk Drive Module" on page 58.
6. See "Removing the Optical Drive Module" on page 59.
7. See "Removing the CPU Heatsink Module" on page 62.
8. See "Removing the CPU" on page 63.
9. See "Removing the Keyboard" on page 64.
10. See "Removing the Middle Cover" on page 65.
11. See "Removing the LCD Module" on page 68.
12. See "Removing the LCD Bezel" on page 86.
13. See "Removing the Inverter Board" on page 88.
14. See "Removing the LCD with Brackets" on page 89.
15. Detach the gasket tape holding the right antenna in place, remove the antenna bracket, then carefully remove the antenna.



16. Detach the gasket tape holding the left antenna in place, remove the antenna bracket, then carefully remove the antenna.



Removing the Microphones

1. See "Removing the Battery Pack" on page 53.
2. See "Removing the Lower Cover" on page 55.
3. See "Removing the DIMM" on page 56.
4. See "Removing the WLAN Board Module" on page 57.
5. See "Removing the Hard Disk Drive Module" on page 58.
6. See "Removing the Optical Drive Module" on page 59.
7. See "Removing the CPU Heatsink Module" on page 62.
8. See "Removing the CPU" on page 63.
9. See "Removing the Keyboard" on page 64.
10. See "Removing the Middle Cover" on page 65.
11. See "Removing the LCD Module" on page 68.
12. See "Removing the LCD Bezel" on page 86.
13. See "Removing the Inverter Board" on page 88.
14. See "Removing the LCD with Brackets" on page 89.
15. See "Removing the Antennas" on page 93.
16. Carefully remove the microphone cables from underneath the adhesive aluminum foil.



17. Remove the microphones .



Troubleshooting

Use the following procedure as a guide for computer problems.

NOTE: The diagnostic tests are intended to test only Acer products. Non-Acer products, prototype cards, or modified options can give false errors and invalid system responses.

1. Obtain the failing symptoms in as much detail as possible.
2. Verify the symptoms by attempting to recreate the failure by running the diagnostic tests or repeating the same operation.
3. Do not use any power sources when performing an assembly or disassembly procedures.
4. If any problems occur, you can perform the following visual inspection before you continue.
 - ☐ Power cords are properly connected and secured.
 - ☐ There are no obvious shorts or opens.
 - ☐ There are no burned or heated components.
 - ☐ All components appear normal.

System Check Procedures

External CD/DVD-ROM Drive Check

Perform the following procedures to isolate the possible problem a controller, drive, or CD-ROM.

NOTE: Make sure that the CD-ROM does not have any label attached to it. The label may damage the drive or cause drive failure.

1. Boot from the diagnostic disc and start the diagnostic programs.
2. See if CD-ROM Test is passed when the program runs the CD-ROM Test.
3. Follow onscreen instructions.

If an error occurs, reconnect the drive to the connector on the mainboard. If the error persists, do the following:

1. Reconnect the CD/DVD-ROM drive.
2. Replace the CD/DVD-ROM drive.
3. Replace the mainboard.

Keyboard or Auxiliary Input Device Check

Remove the external keyboard if the internal keyboard is to be tested.

If the internal keyboard does not work or an unexpected error occurs, make sure that the flexible cable extending from the internal keyboard is correctly connected to the mainboard. If the keyboard cable connection is correct, run the Keyboard Test.

If the tests detect a keyboard problem, do the following procedures in sequence to correct the problems. Do not replace a non-defective FRU:

1. Reconnect the keyboard cable.
2. Replace the keyboard.
3. Replace the mainboard.

The following auxiliary input devices are supported by this computer:

- ☐ Numeric keypad
- ☐ External keyboard

If any of these devices do not function, reconnect the cable and repeat above procedures.

Memory Check

NOTE: Make sure that the DIMM is properly installed into the connector. A loose connection can cause an error.

Do the following:

1. Boot from the diagnostic diskette and start the diagnostic program.
2. Go to the diagnostic memory in the test items.
3. Press **F2** in the test items.
4. Follow onscreen instructions.

Power System Check

Do the following:

1. Remove the battery pack.
2. Connect the power adapter and check the power supply.
3. Disconnect the power adapter and install the battery pack; then check that power supply.

If you suspect a power problem, see the appropriate power supply check in the following list:

- ☐ “Check the Power Adapter” on page 99
- ☐ “Check the Battery Pack” on page 99

Check the Power Adapter

Unplug the power adapter cable from the system and measure the output voltage at the plug of the power adapter cable.

1. If the voltage is not correct, replace the power adapter.
2. If the voltage is within range, do the following:
 - a. Replace the System board.
 - b. If the problem is not resolved, see “Undetermined Problems” on page 112.
 - c. If the voltage is not correct, go to the next step.

NOTE: An audible noise from the power adapter does not always indicate a defect.

3. If the power-on indicator does not light up, check if the adapter’s power cord is properly connected to the system.
4. If the operational charge does not work, see “Check the Battery Pack” on page 99.

Check the Battery Pack

Do the following:

Using the software to identify whether a problem occurs while the battery pack during recharge or discharge:

1. Open Power Management in the Control Panel.
2. In Power Meter, confirm if the parameters for Current Power Source and Total Battery Power Remaining are correct.
3. Repeat the steps 1 and 2 for both battery and adapter.

Using the hardware to identify whether you should replace the battery pack or not:

1. Power off the system.
2. Remove the battery pack and measure the voltage between terminals one (+) and seven (-). There are seven terminals totally.
3. If the voltage is still less than 7.5 Vdc after recharging, replace the battery.

If the battery status indicator does not light up, remove the battery pack . If the charge indicator still does not light up, replace the AC/DC charger board.

Touchpad Check

If the touchpad doesn't work, do the following procedures in sequence to correct the problem. Do not replace a non-defective FRU:

1. After rebooting, run Tracking Pad PS2 Mode Driver. For example Syn touch driver.
2. Run utility with the PS/2 mouse function and check if the mouse is working.
3. If the PS/2 mouse does not work, then check if the main board to switch board FPC is connected properly.
4. If the main board to switch board FPC is connected correctly, then check if the FFC on the touch pad PCB is connected properly.
5. If the FFC on the touch pad PCB is connected correctly, check if LS851 JP1 Pin6 = 5V are pules. If yes, then replace switch board. If not, then go to the next step.
6. Replace the touch pad PCB.
7. If the touch pad still does not work, then replace the FPC on Track Pad PCB.

After you use the touchpad, the pointer drifts on the screen for a short time. This self-acting pointer movement will occur when a slight, steady pressure is applied to the touchpad pointer. This symptom is not a hardware problem. No actions are necessary to be taken if the pointer movement stops in a short period of time.

Power-On Self-Test (POST) Error Message

The POST error message index lists the error message and their possible causes.

NOTE: Perform the FRU replacement or actions in the sequence shown in FRU/Action column, if the FRU replacement does not solve the problem, put the original part back in the computer. Do not replace a non-defective FRU.

The error messages are listed in the coming pages to indicate the BIOS signals on the screen and the error symptoms classified by functions. If the symptom is not included on the list, please refer to “Undetermined Problems”.

NOTE: Most of the error messages occur during POST. Some of them display information about a hardware device, e.g., the amount of memory installed. Others may indicate a problem with a device, such as the way it has been configured.

NOTE: If the system fails after you make changes in the BIOS Setup Utility menus, reset the computer, enter Setup and install Setup defaults or correct the error.

Index of Error Messages

Error Message List

Error Messages	Check or do the following in sequence:
Stuck Key	See "Keyboard or Auxiliary Input Device Check" on page 98.
System CMOS checksum bad - Default configuration used	<input type="checkbox"/> RTC battery. <input type="checkbox"/> Run the BIOS Setup Utility to reconfigure the system time, then reboot system.
Real time clock error	<input type="checkbox"/> RTC battery <input type="checkbox"/> Run the BIOS Setup Utility to reconfigure system time, then reboot system. <input type="checkbox"/> Mainboard
Previous boot incomplete - Default configuration used	<input type="checkbox"/> Run "Load Setup Defaults" in BIOS Setup Utility. <input type="checkbox"/> RTC battery <input type="checkbox"/> Mainboard
Invalid System Configuration Data	<input type="checkbox"/> Run "Load Setup Defaults" in BIOS Setup Utility. <input type="checkbox"/> Mainboard
Operating system not found	<input type="checkbox"/> Run the BIOS Setup Utility to check if the fixed disk and drive A are properly identified. <input type="checkbox"/> CD/DVD-ROM drive <input type="checkbox"/> Hard disk drive <input type="checkbox"/> Mainboard
Power-on indicator turns off and LCD is blank.	<input type="checkbox"/> Power source (battery pack and power adapter.) See "Power System Check" on page 99. <input type="checkbox"/> Ensure every connector is connected tightly and correctly. <input type="checkbox"/> Reconnect the DIMM <input type="checkbox"/> Mainboard
Power-on indicator turns on and LCD is blank.	<input type="checkbox"/> Power source (battery pack and power adapter.) See "Power System Check" on page 99. <input type="checkbox"/> Reconnect the LCD connector <input type="checkbox"/> Hard disk drive <input type="checkbox"/> LCD cable <input type="checkbox"/> LCD inverter board <input type="checkbox"/> LCD <input type="checkbox"/> Mainboard
Power-on indicator turns on and LCD is blank. But you can see POST on an external CRT.	<input type="checkbox"/> Reconnect the LCD connectors. <input type="checkbox"/> LCD cable <input type="checkbox"/> LCD inverter board <input type="checkbox"/> LCD <input type="checkbox"/> Mainboard
Power-on indicator turns on and a blinking cursor shown on LCD during POST.	<input type="checkbox"/> Ensure every connector is connected tightly and correctly. <input type="checkbox"/> Mainboard
Failure Fixed Disk	<input type="checkbox"/> Reconnect the hard disk drive connector. <input type="checkbox"/> Run "Load Setup Defaults" in BIOS Setup Utility. <input type="checkbox"/> Hard disk drive <input type="checkbox"/> Mainboard

Error Message List

Error Messages	Check or do the following in sequence:
No beep, power-on indicator turns off and LCD is blank.	<input type="checkbox"/> Power source (battery pack and power adapter). See "Power System Check" on page 99. <input type="checkbox"/> Ensure every connector is connected tightly and correctly. <input type="checkbox"/> Reconnect the DIMM. <input type="checkbox"/> LED board <input type="checkbox"/> Mainboard
No beep, power-on indicator turns on and LCD is blank.	<input type="checkbox"/> Power source (battery pack and power adapter). See "Power System Check" on page 99. <input type="checkbox"/> Reconnect the LCD connector <input type="checkbox"/> Hard disk drive <input type="checkbox"/> LCD inverter ID <input type="checkbox"/> LCD cable <input type="checkbox"/> LCD Inverter board <input type="checkbox"/> LCD <input type="checkbox"/> Mainboard
No beep, power-on indicator turns on and LCD is blank. But you can see POST on an external CRT.	<input type="checkbox"/> Reconnect the LCD connectors. <input type="checkbox"/> LCD inverter ID <input type="checkbox"/> LCD cable <input type="checkbox"/> LCD inverter board <input type="checkbox"/> LCD <input type="checkbox"/> Mainboard
No beep, power-on indicator turns on and a blinking cursor shown on LCD during POST.	<input type="checkbox"/> Ensure every connector is connected tightly and correctly. <input type="checkbox"/> Mainboard
No beep during POST but system runs correctly.	<input type="checkbox"/> Speaker <input type="checkbox"/> Mainboard

Phoenix BIOS Beep Codes

Code	Beeps	POST Routine Description
02h		Verify Real Mode
03h		Disable Non-Maskable Interrupt (NMI)
04h		Get CPU type
06h		Initialize system hardware
08h		Initialize chipset with initial POST values
09h		Set IN POST flag
0Ah		Initialize CPU registers
0Bh		Enable CPU cache
0Ch		Initialize caches to initial POST values
0Eh		Initialize I/O component
0Fh		Initialize the local bus IDE
10h		Initialize Power Management
11h		Load alternate registers with initial POST values
12h		Restore CPU control word during warm boot
13h		Initialize PCI Bus Mastering devices
14h		Initialize keyboard controller
16h	1-2-2-3	BIOS ROM checksum
17h		Initialize cache before memory autosize
18h		8254 timer initialization
1Ah		8237 DMA controller initialization
1Ch		Reset Programmable Interrupt Controller
20h	1-3-1-1	Test DRAM refresh
22h	1-3-1-3	Test 8742 Keyboard Controller
24h		Set ES segment register to 4 GB
26h		Enable A20 line
28h		Autosize DRAM
29h		Initialize POST Memory Manager
2Ah		Clear 215 KB base RAM
2Ch	1-3-4-1	RAM failure on address line xxxx*
2Eh	1-3-4-3	RAM failure on data bits xxxx* of low byte of memory bus
2Fh		Enable cache before system BIOS shadow
30h	1-4-1-1	RAM failure on data bits xxxx* of high byte of memory bus
32h		Test CPU bus-clock frequency
33h		Initialize Phoenix Dispatch Manager
36h		Warm start shut down
38h		Shadow system BIOS ROM
3Ah		Autosize cache
3Ch		Advanced configuration of chipset registers
3Dh		Load alternate registers with CMOS values
42h		Initialize interrupt vectors
45h		POST device initialization

Code	Beeps	POST Routine Description
46h	2-1-2-3	Check ROM copyright notice
48h		Check video configuration against CMOS
49h		Initialize PCI bus and devices
4Ah		Initialize all video adapters in system
4Bh		QuietBoot start (optional)
4Ch		Shadow video BIOS ROM
4Eh		Display BIOS copyright notice
50h		Display CPU type and speed
51h		Initialize EISA board
52h		Test keyboard
54h		Set key click if enabled
58h		Test for unexpected interrupts
59h	2-2-3-1	Initialize POST display service
5Ah		Display prompt "Press F2 to enter SETUP"
5Bh		Disable CPU cache
5Ch		Test RAM between 512 and 640 KB
60h		Test extended memory
62h		Test extended memory address lines
64h		Jump to User Patch1
66h		Configure advanced cache registers
67h		Initialize Multi Processor APIC
68h		Enable external and CPU caches
69h		Setup System Management Mode (SMM) area
6Ah		Display external L2 cache size
6Bh		Load custom defaults (optional)
6Ch		Display shadow-area message
6Eh		Display possible high address for UMB recovery
70h		Display error messages
72h		Check for configuration errors
76h		Check for keyboard errors
7Ch		Set up hardware interrupt vectors
7Eh		Initialize coprocessor if present
80h		Disable onboard Super I/O ports and IRQs
81h		Late POST device initialization
82h		Detect and install external RS232 ports
83h		Configure non-MCD IDE controllers
84h		Detect and install external parallel ports
85h		Initialize PC-compatible PnP ISA devices
86h		Re-initialize onboard I/O ports
87h		Configure Motherboard Configurable Devices (optional)
88h		Initialize BIOS Data Area
89h		Enable Non-Maskable Interrupts (NMIs)

Code	Beeps	POST Routine Description
8Ah		Initialize Extended BIOS Data Area
8Bh		Test and initialize PS/2 mouse
8Ch		Initialize floppy controller
8Fh		Determine number of ATA drives (optional)
90h		Initialize hard-disk controllers
91h		Initialize local-bus hard-disk controllers
92h		Jump to UserPatch2
93h		Build MPTABLE for multi-processor boards
95h		Install CD-ROM for boot
96h		Clear huge ES segment register
97h		Fixup Multiprocessor table
98h	1-2	Search for option ROMs. One long, two short beeps on checksum failure.
99h		Check for SMART drive (optional)
9Ah		Shadow option ROMs
9Ch		Set up Power Management
9Dh		Initialize security engine (optional)
9Eh		Enable hardware interrupts
9Fh		Determine number of ATA and SCSI drives
A0h		Set time of day
A2h		Check key lock
A4h		Initialize Typematic rate
A8h		Erase F2 prompt
AAh		Scan for F2 key stroke
ACh		Enter SETUP
A Eh		Clear Boot flag
B0h		Check for errors
B2h		POST done- prepare to boot operating system
B4h	1	One short beep before boot
B5h		Terminate QuietBoot (optional)
B6h		Check password (optional)
B9h		Prepare Boot
BAh		Initialize DMI parameters
BBh		Initialize PnP Option ROMs
BCh		Clear parity checkers
BDh		Display MultiBoot menu
BEh		Clear screen (optional)
BFh		Check virus and backup reminders
C0h		Try to boot with INT 19
C1h		Initialize POST Error Manager (PEM)
C2h		Initialize error logging
C3h		Initialize error display function

Code	Beeps	POST Routine Description
C4h		Initialize system error handler
C5h		PnPnd dual CMOS (optional)
C6h		Initialize notebook docking (optional)
C7h		Initialize notebook docking late
C8h		Force check (optional)
C9h		Extended checksum (optional)
D2h		Unknown interrupt

* If the BIOS detects error 2C, 2E, or 30 (base 512K RAM error), it displays an additional word-bitmap (xxxx) indicating the address line or bits that failed. For example, "2C 0002" means address line 1 (bit one set) has failed. "2E 1020" means data bits 12 and 5 (bits 12 and 5 set) have failed in the lower 16 bits. Note that error 30 cannot occur on 386SX systems because they have a 16 rather than 32-bit bus. The BIOS also sends the bitmap to the port-80 LED display. It first displays the check point code, followed by a delay, the high-order byte, another delay, and then the low-order byte of the error. It repeats this sequence continuously.

BIOS Beep Codes for Boot Block in Flash ROM

Code	Beeps	For Boot Block in Flash ROM
E0h		Initialize the chipset
E1h		Initialize the bridge
E2h		Initialize the CPU
E3h		Initialize the system timer
E4h		Initialize system I/O
E5h		Check force recovery boot
E6h		Checksum BIOS ROM
E7h		Go to BIOS
E8h		Set Huge Segment
E9h		Initialize Multiprocessor
EAh		Initialize OEM special code
EBh		Initialize PIC and DMA
ECh		Initialize Memory type
EDh		Initialize Memory size
EEh		Shadow Boot Block
EFh		System memory test
F0h		Initialize interrupt vectors
F1h		Initialize Run Time Clock
F2h		Initialize video
F3h		Initialize System Management Mode
F4h	1	Output one beep before boot
F5h		Boot to Mini DOS
F6h		Clear Huge Segment
F7h		Boot to Full DOS

Index of Symptom-to-FRU Error Message

LCD-Related Symptoms

Symptom / Error	Check or do the following in sequence
LCD backlight doesn't work LCD is too dark LCD brightness cannot be adjusted LCD contrast cannot be adjusted	<input type="checkbox"/> Run "Load Setup Defaults" in BIOS Setup Utility, then reboot system. <input type="checkbox"/> Reconnect the LCD connectors. <input type="checkbox"/> Keyboard (if contrast and brightness function key doesn't work). <input type="checkbox"/> LCD inverter ID <input type="checkbox"/> LCD cable <input type="checkbox"/> LCD inverter board <input type="checkbox"/> LCD <input type="checkbox"/> Mainboard
Unreadable LCD screen Missing pels in characters Abnormal screen Wrong color displayed	<input type="checkbox"/> Reconnect the LCD connector <input type="checkbox"/> LCD inverter ID <input type="checkbox"/> LCD cable <input type="checkbox"/> LCD inverter board <input type="checkbox"/> LCD <input type="checkbox"/> Mainboard
LCD has extra horizontal or vertical lines displayed.	<input type="checkbox"/> LCD inverter ID <input type="checkbox"/> LCD inverter board <input type="checkbox"/> LCD cable <input type="checkbox"/> LCD <input type="checkbox"/> Mainboard

Indicator-Related Symptoms

Symptom / Error	Check or do the following in sequence
Indicator incorrectly remains off or on, but system runs correctly	<input type="checkbox"/> Reconnect the inverter board. <input type="checkbox"/> Mainboard

Power-Related Symptoms

Symptom / Error	Check or do the following in sequence
Power shuts down during operation	<input type="checkbox"/> Power source (battery pack and power adapter). See "Power System Check" on page 99. <input type="checkbox"/> Battery pack <input type="checkbox"/> Power adapter <input type="checkbox"/> Hard disk drive & battery connection board <input type="checkbox"/> Mainboard
The system doesn't power-on.	<input type="checkbox"/> Power source (battery pack and power adapter). See "Power System Check" on page 99. <input type="checkbox"/> Battery pack <input type="checkbox"/> Power adapter <input type="checkbox"/> Hard disk drive & battery connection board <input type="checkbox"/> Mainboard

Power-Related Symptoms

Symptom / Error	Check or do the following in sequence
The system doesn't power-off.	<input type="checkbox"/> Power source (battery pack and power adapter). See "Power System Check" on page 99. <input type="checkbox"/> Hold and press the power switch for more than 4 seconds. <input type="checkbox"/> Mainboard
Battery can't be charged	<input type="checkbox"/> See "Check the Battery Pack" on page 99. <input type="checkbox"/> Battery pack <input type="checkbox"/> Mainboard

PCMCIA-Related Symptoms

Symptom / Error	Check or do the following in sequence
System cannot detect the PC Card (PCMCIA)	<input type="checkbox"/> PCMCIA slot assembly <input type="checkbox"/> Mainboard
PCMCIA slot pin is damaged.	PCMCIA slot assembly

Memory-Related Symptoms

Symptom / Error	Check or do the following in sequence
Memory count (size) appears different from actual size.	<input type="checkbox"/> Run "Load Setup Defaults" in BIOS Setup Utility, then reboot system. <input type="checkbox"/> DIMM <input type="checkbox"/> Mainboard

Speaker-Related Symptoms

Symptom / Error	Check or do the following in sequence
In Windows, multimedia programs, no sound comes from the computer.	<input type="checkbox"/> Audio driver <input type="checkbox"/> Speaker <input type="checkbox"/> Mainboard
Internal speakers make noise or emit no sound.	<input type="checkbox"/> Speaker <input type="checkbox"/> Mainboard

Power Management-Related Symptoms

Symptom / Error	Check or do the following in sequence
The system will not enter hibernation	<input type="checkbox"/> See "Save to Disk (S4)" on page 44. <input type="checkbox"/> Keyboard (if control is from the keyboard) <input type="checkbox"/> Hard disk drive <input type="checkbox"/> Mainboard
The system doesn't enter hibernation mode and four short beeps every minute.	<input type="checkbox"/> Press Fn+0 and see if the computer enters hibernation mode. <input type="checkbox"/> Touchpad <input type="checkbox"/> Keyboard <input type="checkbox"/> Hard disk connection board <input type="checkbox"/> Hard disk drive <input type="checkbox"/> Mainboard
The system doesn't enter standby mode after closing the LCD	<input type="checkbox"/> See "Save to Disk (S4)" on page 44. <input type="checkbox"/> Mainboard

Power Management-Related Symptoms

Symptom / Error	Check or do the following in sequence
The system doesn't resume from hibernation mode.	<input type="checkbox"/> See "Save to Disk (S4)" on page 44. <input type="checkbox"/> Hard disk connection board <input type="checkbox"/> Hard disk drive <input type="checkbox"/> Mainboard
The system doesn't resume from standby mode after opening the LCD.	<input type="checkbox"/> See "Save to Disk (S4)" on page 44. <input type="checkbox"/> Mainboard
Battery fuel gauge in Windows doesn't go higher than 90%.	<input type="checkbox"/> Remove battery pack and let it cool for 2 hours. <input type="checkbox"/> Refresh battery (continue use battery until power off, then charge battery). <input type="checkbox"/> Battery pack <input type="checkbox"/> Mainboard
System hangs intermittently.	<input type="checkbox"/> Reconnect hard disk/CD-ROM drives. <input type="checkbox"/> Hard disk connection board <input type="checkbox"/> Mainboard

Peripheral-Related Symptoms

Symptom / Error	Check or do the following in sequence
System configuration does not match the installed devices.	<input type="checkbox"/> Run "Load Setup Defaults" in BIOS Setup Utility, then reboot system. <input type="checkbox"/> Reconnect hard disk/CD-ROM/diskette drives.
External display does not work correctly.	<input type="checkbox"/> Press Fn+F5 to switch to LCD or CRT <input type="checkbox"/> Mainboard
USB does not work correctly	<input type="checkbox"/> Mainboard
Print problems.	<input type="checkbox"/> Run printer self-test. <input type="checkbox"/> Printer driver <input type="checkbox"/> Printer cable <input type="checkbox"/> Printer <input type="checkbox"/> Mainboard

Keyboard/Touchpad-Related Symptoms

Symptom / Error	Check or do the following in sequence
Keyboard (one or more keys) does not work.	<input type="checkbox"/> Reconnect the keyboard cable. <input type="checkbox"/> Keyboard <input type="checkbox"/> Mainboard
Touchpad does not work.	<input type="checkbox"/> Reconnect touchpad cable. <input type="checkbox"/> Touchpad board <input type="checkbox"/> Mainboard

Modem-Related Symptoms

Symptom / Error	Check or do the following in sequence
Internal modem does not work correctly.	<input type="checkbox"/> Modem phone port <input type="checkbox"/> Modem combo board <input type="checkbox"/> Mainboard

NOTE: If you cannot find a symptom or an error in this list and the problem remains, see "Undetermined Problems" on page 112.

Intermittent Problems

Intermittent system hang problems can be caused by a variety of reasons that have nothing to do with a hardware defect, such as: cosmic radiation, electrostatic discharge, or software errors. FRU replacement should be considered only when a recurring problem exists.

When analyzing an intermittent problem, do the following:

1. Run the advanced diagnostic test for the mainboard in loop mode at least 10 times.
2. If no error is detected, do not replace any FRU.
3. If any error is detected, replace the FRU. Rerun the test to verify that there are no more errors.

Undetermined Problems

The diagnostic problems does not identify which adapter or device failed, which installed devices are incorrect, whether a short circuit is suspected, or whether the system is inoperative.


NOTE: Verify that all attached devices are supported by the computer.

NOTE: Verify that the power supply being used at the time of the failure is operating correctly. (See “Power System Check” on page 99.)

Follow procedures below to isolate the failing FRU. Do not isolate non-defective FRU.


1. Power off the computer.
2. Visually check them for damage. If any problems are found, replace the FRU.
3. Remove or disconnect all of the following devices:
 - ☐ Non-Acer devices
 - ☐ Printer, mouse, and other external devices
 - ☐ Battery pack
 - ☐ Hard disk drive
 - ☐ DIMM
 - ☐ CD/DVD-ROM drive
 - ☐ PC cards
4. Power on the computer.
5. Determine if the problem has been resolved.
6. If the problem does not recur, reconnect the removed devices one at a time until you find the failed FRU.
7. If the problem persists, replace the following FRU one at a time. Do not replace a non-defective FRU.
 - ☐ System board
 - ☐ LCD assembly

System Block Diagram




Board Layout

Top View



#	Item	#	Item
1	LCD connector	7	Power board cable connector
2	Internal microphone cable connector	8	USB board cable connector
3	Speaker cable connector	9	ExpressCard/54 slot
4	Keyboard cable connector	10	ICH8-M chipset (south bridge)
5	Touchpad cable connector	11	Launch board cable connector
6	Media board cable connector		

Bottom View



#	Item	#	Item
1	AC-in jack	11	5-in-1 card reader
2	Mini-card connector	12	RTC battery cable connector
3	Battery cable connector	13	Modem board
4	CPU	14	Volume control wheel
5	Intel PM965 Express chipset (north bridge)	15	Line-in jack
6	CRT port	16	Microphone jack
7	RJ11+RJ45 port	17	Line-out jack
8	S-video port	18	ODD connector
9	USB ports	19	HDD connector
10	1394 port	20	DIMM slot

Switch Setting

Short R525 to clear password.

Standard Operation Procedures of Password Bypassing and BIOS Recovery

For RD and CSD to debug easily, the system provide one hardware DIP switch for Bypassing Password Check, and one Hotkey to enable BIOS Recovery.

1. DIP Switches:

DIP	Default Setting	Description
SW1	Disabled (High)	Bypassing Password Check


2. Hotkey to enable BIOS Recovery: press the combination **Fn+ESC**, then press the **Power Button**. To use this function, it is strongly recommended that the AC adapter is connected to the system and plug-in to a wall outlet and the Battery is also in the system

Bypassing Password Check (SW1): If the user has set Password (power-on or setup password) for security reason, BIOS will check password during POST or when entering the BIOS setup menu. However, if it is necessary to ignore the password check, the user may enable DIP SW1 to bypass password check.

BIOS Recovery: Boot Block is a special block of BIOS. It is used to boot up the system with minimum BIOS initialization. The user can enable this feature to restore the BIOS to a successful one if previous BIOS flashing process fails.

1. DIP Switch Location:

RD/CSD can enable or disable this function by switching the DIP. The DIP switch is located as shown in the figure below:



2. Clear Password

DIP SW1: Bypassing Password Check is disabled by default. Switching it to ON then powering on the system will force the BIOS to clear Supervisor and User passwords. The power-on, setup password, and the HDD password are all cleared.

3. Restore BIOS by the Crisis Disk

Enable this function by pressing the combination: **Fn+ESC**, and pressing the **Power Button**. To use this function, it is strongly recommended that the AC adapter is connected to the system and plug-in to a wall outlet and the Battery is also in the system. If this function is enabled, the system will force the BIOS to enter a special BIOS block, called BootBlock. RD/CSD can use this special BIOS code to recover the BIOS to a successful one if previous BIOS flashing process fails. However, before doing this, one Crisis Disk should be prepared in WinXP. Detailed steps are as the followings:

- a. Prepare the Crisis Disk in WinXP.
- b. Insert the Crisis Disk to a USB floppy drive which is attached to the failed machine.
- c. While the system is turned off, press and hold **Fn+ESC**, then press **Power Button**. The system should be powered on with Crisis Recovery process.
- d. BootBlock BIOS starts to restore the failed BIOS code. Short beeps should be heard when flashing.
- e. If the flashing process is finished, a long beep should be heard.
- f. Power down the system after you hear the long beep.

If the crisis recovery process is finished, the system should be powered on with the successful BIOS. RD/CSD can then update the BIOS to a workable one by regular BIOS flashing process.


FRU (Field Replaceable Unit) List

This chapter offers the FRU (Field Replaceable Unit) list in global configuration of Aspire 4920. Refer to this chapter whenever ordering the parts to repair or for RMA (Return Merchandise Authorization).

NOTE: When ordering FRU parts, check the most up-to-date information available on your regional web or channel. For whatever reasons a part number is changed, it will NOT be noted on the printed Service Guide. For Acer authorized service providers, your Acer office may have a different part number code from those given in the FRU list of this printed Service Guide. You **MUST** use the local FRU list provided by your regional Acer office to order FRU parts for service.

NOTE: To scrap or to return the defective parts, follow the local government ordinance or regulations on how to dispose it properly, or follow the rules set by your regional Acer office on how to return it.





Aspire 4920 Exploded Diagram









NO.	PART NO.	DESCRIPTION	QTY	REV.
1	31.41701.001	Top Cover Panel	1	0A
2	42.41702.001	LCD bezel	2	0A
3	34.41704.001	Top Cover	1	0A
4	40.41701.001	Combo LCD Panel Mylar	1	0A
5	41.41704.001	LCD bezel	1	0A
6	86.00817.795	SCREW	2	0A
7	40.41702.001	MYLAR LCD TAPE	1	0A
8	47.41702.001	RUB BAR TAPE	2	0A
9	34.41703.001	Top Cover L	1	0A
10	34.41703.001	Top Cover R	1	0A
11	34.41703.001	M-COVER TAPE	1	0A
12	42.41702.001	TAPE FUNCTION LENS	1	0A
13	42.41702.001	LENS POWER RING TAPE	1	0A
14	42.41702.001	RIGHT PWR TAPE	1	0A
15	42.41702.001	POWER KEY TAPE	1	0A
16	42.41702.001	A KEY TAPE	1	0A
17	5.4001.714	TR	1	0A
18	33.41703.001	SUPPORT BRKT R TAPE	1	0A
19	34.41704.001	LATCH SPRING	1	0A
20	34.41704.001	U-CASE SHIELDING TAPE	1	0A
21	34.41704.001	U-CASE TAPE	1	0A
22	40.41703.001	SPEAKER MESH TAPE	1	0A
23	40.41703.001	U-CASE MYLAR TAPE	1	0A
24	42.41702.001	TP MYLAR TAPE	1	0A
25	42.41704.001	FRONT LENS TAPE	1	0A
26	42.41704.001	FUNCTION KEY TAPE	1	0A
27	42.41704.001	TP KEY TAPE	1	0A
28	42.41702.001	SCROLL KEY TAPE	1	0A
29	42.41702.001	NAMEPLATE TAPE	1	0A
30	42.41704.001	KE HOOK TAPE	4	0A
31	42.41702.001	KEY ASST TAPE	1	0A
32	42.41702.001	LCD LATCH ASST TAPE	1	0A
33	33.41703.001	BRKT L-CASE SUPPORT R TAPE	1	0A
34	33.41703.001	BRKT L-CASE SUPPORT L TAPE	1	0A
35	34.41703.001	EMI L-CASE SHIELDING TAPE	1	0A
36	34.41704.001	SPRING BT TAPE	1	0A
37	39.41702.001	CAS L-CASE TAPE	1	0A
38	40.41703.001	MYLAR L-CASE BT TAPE	1	0A
39	42.41702.001	KNIB BT LOCK TAPE	1	0A
40	42.41703.001	KNIB L-CASE BT RELEASE TAPE	1	0A
41	42.41703.001	LATCH L-CASE BT RELEASE TAPE	1	0A
42	42.41702.001	LENS L-CASE IR TAPE	1	0A
43	42.41702.001	BT TAPE	1	0A
44	47.41702.001	SPONGE B/T TAPE	1	0A
45	47.41702.001	RUB L-CASE FOOT FRONT TAPE	2	0A
46	47.41702.001	RUB L-CASE FOOT BACK TAPE	2	0A
47	34.41703.001	EMI BIG DOOR SHIELDING TAPE	1	0A
48	40.41703.001	MYLAR SCREW M2X2.5 ENVA	8	0A
49	42.41702.001	DOOR BIG-DOOR TAPE	1	0A
50	47.41702.001	RUB BIG-DOOR FOOT TAPE	1	0A
51	86.00817.795	SCREW	8	0A

Aspire 4920 FRU List

Category	Part Name	Description	Acer Part No.
Adapter			
	Adapter 90W Delta ADP-90SB BBDAF	ADT 90W Delta ADP-90SB BBDAF	AP.09001.010
	Adapter 90W Delta ADP-90SB BBEA LF	ADP 90W Delta ADP-90SB BBEA LF	AP.09001.013
	Adapter 90W Liteon PA-1900-24AR	ADT 90W Liteon PA-1900-24AR	AP.09003.011
	Adapter 90W Liteon PA-1900-04WR	ADT 90W Liteon PA-1900-04WR	AP.09003.005
Battery			
	Battery Pack Li+6 cell 2.0mAh Sanyo	BTY Pack Li+6C 2.0Ah Sanyo	BT.00603.036
	Battery Pack Li+6 cell 2.4mAh Sanyo	BTY Pack LI+6C 2.4Ah Sanyo	BT.00603.037
	Battery Pack Li-ion 6 cell 2.0mAh Sony	BTY Pack Li+6C 2.0Ah Sony	BT.00604.022
	Battery Pack Li-ion 6 cell 2.4mAh Sony	BTY Pack Li+6C 2.4Ah Sony	BT.00604.023
	Battery Pack Li-Mn 6 cell 2.0mAh Panasonic	BTY Pack Li+6C 2.0Ah PANA	BT.00605.018
	Battery Pack Li-Mn 6 cell 2.4mAh Panasonic	BTY Pack Li+6C 2.4Ah PANA	BT.00605.019
	Battery Pack Li-Mn 6 cell 2.0 Simplo	BTY Pack Li+6C 2.0Ah SMP	BT.00607.013
	Battery Pack Li-ion 6 cell 2.4mAh Simplo	BTY Pack PANA Li 6C 2.4 SMP	BT.00607.014
Boards			
	Bluetooth board Foxconn BCM2045 V01	BT Module Foxconn BCM2045 V01	56.25020.003
	VGA board MXM-1N M66M	MXM-1N M66M VGA BD (D)	55.4U002.051G
	VGA board MXM-1N M66M	MXM-1N Infineon M66M VGA BD (D)	55.4U002.061G
	Modem board	Modem MDC003 A8B B85244300G	54.09027.091
	Modem board Foxconn MDC1.5 T60M955.00 3.3V	Modem MDC1.5 T60M955.00 3.3V	54.09018.051
	Modem board Castlene	Modem MDC1.5 Moto MA820	54.09018.001
	Touchpad board Synaptics TM00450-000	Touchpad Synaptics TM00450-000	56.17024.001
	Capacitive button board	Capacitive button TM-00542-00	56.41004.031



Category	Part Name	Description	Acer Part No.
	Launch board	Tahoe LAU-BD 06626-1 PD (D)	55.4T902.001G
	USB board	Tahoe USB-BD 06628-1 PD (D)	55.4T904.001G
	Power board	Tahoe PWR-BD 06627-2 PD (D)	55.4T903.001G
Wireless LAN board			
	Wireless LAN 802.11ABGN Kedron MOW1	WLAN 802.11ABGN Kedron MOW1	KI.KDN01.001
	Wireless LAN 802.11ABGN Kedron MOW2	WLAN 802.11ABGN Kedron MOW2	KI.KDN01.002
	Wireless LAN 802.11ABGN Kedron ROW	WLAN 802.11ABGN Kedron ROW	KI.KDN01.003
	Wireless LAN 802.11ABGN Kedron	WLAN 802.11ABGN Kedron	KI.KDN01.005
	Wireless LAN Board 802.11ABG Intel 3945 MW1	WLAN 802.11ABG Intel 3945 MW1	KI.GLN01.001
	Wireless LAN Board 802.11ABG Intel 3945 MW2	WLAN 802.11ABG Intel 3945 MW2	KI.GLN01.002
	Wireless LAN Board 802.11ABG Intel 3945 RW	WLAN 802.11ABG Intel 3945 RW	KI.GLN01.003
	Wireless LAN Board 802.11BG Intel 3945BG	WLAN PRO/Wireless 3945BG	KI.GLN01.005
Cables			
	Bluetooth cable HL	C.A. B.T HL	50.4T910.001
	Bluetooth cable MEC	C.A. B.T MEC	50.4T910.011
	Power board cable	C.A. power board FFC	50.4T905.001
	Media board cable	C.A. media board FFC	50.4T902.001
	USB cable HL	C.A. USB HL	50.4T906.001
	USB cable MEC	C.A. USB MEC	50.4T906.011
	Touchpad cable	C.A. T/P FFC	50.4T903.001
	Launch board cable	C.A. launch board FFC	50.4T904.001
	DC-in cable HL	C.A. DC-in HL	50.4T907.001
	DC-in cable MEC	C.A. DC-in MEC	50.4T907.011
	Power cord 10A 125V US	Code US 10A 125V BK	27.01518.521
	Power cord 10A 125V 3-pin US BK	Code 10A 125V 3P US BK	27.01518.641
	Power cord 2.5A 125V USA	Code USA/W CNS 2.5A 125V 8121	27.01518.781
	Power cord 3A 250V 3-pin UK	Code UK 3A 250V 3P BK	27.01518.541
	Power cord 5A 250V 3-pin UK BK	Code 5A 250V 3P UK BK	27.03118.001


Category	Part Name	Description	Acer Part No.
	Power cord 10A 3-pin BK Denmark	Code Denmark 10A 3P BK	27.01518.561
	Power cord 10A 250V 3-pin Denmark BK	Code 10A 250V 3P Denmark BK	27.01518.671
	Power cord 10A 250V 3-pin South Africa	Code South Africa 10A 250V BK	27.01518.571
	Power cord 16A 250V South Africa BK	Code 16A 250V South Africa BK	27.01518.681
	Power cord 10A 250V Swiss	Code Swiss Power 10A 250V BK	27.01518.581
	Power cord 10A 250V 3-pin Swiss BK	Code 10A 250V 3P Swiss BK	27.01518.691
	Power cord 10A 250V 3-pin China	Cord China 10A 250V 3P	27.01518.591
	Power cord 10A 250V 3-pin China BK	Cord 10A 250V 3P China BK	27.01518.701
	Power cord 220V 3-pin EUR	Cord EUR 220V 3P BK	27.01518.601
	Power cable 16A 250V 3-pin EUR BK	Cord 16A 250V 3P EUR BK	27.01518.731
	Power cord 10A 250V 3-pin Italy	Cord Italy 10A 250V 3P BK	27.01518.611
	Power cord 10A 250V 3-pin Italy BK	Cord 10A 250V 3P Italy BK	27.01518.711
	Power cord 2.5A 250V South Africa BK (India)	Cord 2.5A 250V South Africa Bk	27.01518.631
	Power cord 10A 250V South Africa BK (India)	Cord 10A 250V South Africa BK	27.01518.721
	Power cord 250V 10A 3-pin Israel	Cord 250V 10~16A 3P Israel	27.01518.761
	Power cord ACA/ACNZ	Power cord ACA/ACNZ Annie	27.03218.021
System case/cover/bracket/assembly			
	LCD latch bracket	LCD latch ASSY	60.4T906.001
	SD dummy card	SD dummy card	42.TKJ01.001
	New card dummy card	Dummy new card	42.4T924.001
	Lowercase	ASSY L-Case	60.4T907.001
	Unitload cover	ASSY big door	60.4T908.001
	E-key cover	E-key ASSY	60.4T903.001
	Support bracket left	Support L ASSY	60.4T905.001

Category	Part Name	Description	Acer Part No.
	Touchpad bracket	TP bracket ASSY	60.4T904.001
	Middle cover	M-cover ASSY	60.4T902.001
	VGA bracket	ASSY MXM BRT	60.4T933.002
	Upper case w/ speaker	ASSY U-Case	60.4T901.001
Memory			
	SDIMM 1GB Hynix HYMP512S64CP8-Y5 AB	SODIMM 1G HYMP512S64CP8-Y5 AB	KN.1GB0G.006
	SDIMM 1GB Nanya NT1GT64U8HB0BN-3C	SODIMM 1G NT1GT64U8HB0BN-3C	KN.1GB03.014
	SDIMM 1GB Samsung M470T2953EZ3-CE6	SODIMM 1GB M470T2953EZ3-CE6	KN.1GB0B.011
	SDIMM 512MB Hynix HYMP564S64CP6-Y5 AB	SODIMM 512M HYMP564S64CP6-Y5 AB	KN.5120G.019
	SDIMM 512MB Nanya NT512T64UH8B0FN-3C	SODIMM 512M NT512T64UH8B0FN-3C	KN.51203.032
	SDIMM 512MB Samsung M470T6554EZ3-CE6 LF	SODIMM 512M M470T6554EZ3-CE6	KN.5120B.023
	SDIMM 512MB PSC AS6E8E63B-6E1A	SODIMM 512M AS6E8E63B- 6E1A	KN.5120E.004
	SDIMM 512MB DDRII667 Promos V916764B24QBFW-F5 LF	SODIMM 512M V916764B24QBFW-F5	KN.5120M.004
Combo module			
	Combo module 24X	ODD NCB24X combo	G2.OPAHP.001
	Optical bracket	BRKT ODD	33.4T910.001
	Combo bezel	ASSY ODD bezel combo	60.4T914.001
	Combo module 24X PDBS DS- 24CZP w/o bezel	Combo 24X PDBS DS-24CZP	KO.02409.029
	Combo module 24X Sony CRX880A LF w/o bezel	Combo 24X Sony/CRX880A Myall2	KO.0240E.005
DVD module			
	DVD-RW Super Multi module 8X	ODD NSM8X Super-multi drive TA	G2.OPAHP.002
	Optical bracket	BRKT ODD	33.4T910.001
	Super Multi bezel	ASSY ODD bezel S-Multi	60.4T915.001
	DVD-RW drive 8X Super Mult Pioneer DVR-K17RS LF w/o bezel	S-Mult 8X PIO/DVR-K17RS	KU.00805.038
	DVD-RW drive 8X Super Mult Panasonic UJ-850UAA1-A w/o bezel	S-Mult PAN/UJ-850UAA1-A	KU.00807.055
	DVD-RW drive 8X Super Multi PDBS DS-8A1P	8X S-Multi PDBS DS-8A1P	KU.00809.010
DVD module (cont.)	DVD-RW drive 8X Super Mult Sony AD-7530A	8X S-Mult Sony/AD-7530A	KU.0080E.005

Category	Part Name	Description	Acer Part No.
HDD/Hard Disk Drive			
	HDD bracket	ASSY HDD bracket	60.4T918.001
	HDD module 80G 5400RPM SATA	HDD N80GB5.4KS	G2.HDAHP.001
	HDD 80GB SATA Hitachi HTS541680J9SA00	HDD 80GB SATA HTS541680J9SA00	KH.08007.021
	HDD 80GB Seagate ST980811AS	HDD 80GB SGT ST980811AS	KH.08001.030
	HDD 80GB 5400RPM SATA Toshiba MK8037GSX Gemini BS LF F/W:DL230	HDD 80GB Toshiba MK8037GSX	KH.08004.010
	HDD 80GB 5400RPM SATA WD WD800BEVS-22RST0 ML80 LF F/W:04.01G04	HDD 80GB WD WD800BEVS-22RST0	KH.08008.033
	HDD module 120G 5400RPM SATA	HDD N120GB5.4KS	G2.HDAHP.002
	HDD 120GB SATA Hitachi HTS541612J9SA00	HDD 120GB SATA HTS541612J9SA00	KH.12007.010
	HDD 120GB Seagate ST9120822AS	HDD 120GB SGT ST9120822AS	KH.12001.031
	HDD 120GB 5400RPM SATA Toshiba MK1237GSX Gemini BS LF F/W:DL130J	HDD 120GB Toshiba MK1237GSX	KH.12004.006
	HDD 120GB WD WD1200BEVS-22RST0	HDD 120GB WD WD1200BEVS-22RST0	KH.12008.018
	HDD module 160G 5400RPM SATA	HDD N160GB5.4KS	G2.HDAHP.003
	HDD 160GB SATA Hitachi HTS541616J9SA00	HDD 160GB SATA HTS541616J9SA00	KH.16007.011
	HDD 160GB Seagate ST9160821AS	HDD 160GB SGT ST9160821AS	KH.16001.026
	HDD 160GB 5400RPM SATA Toshiba MK1637GSX Gemini BS LF F/W:DL030J	HDD 160GB Toshiba MK1637GSX	KH.16004.001
	HDD 160GB WD WD1600BEVS-22RST0	HDD 160GB WD WD1600BEVS-22RST0	KH.16008.019
CPU Heatsink			
	CPU heatsink w/ fan	ASSY Thermal DIS Foxconn	60.4T928.001
	CPU heatsink w/ fan	ASSY Thermal DIS Robin	60.4T926.001
	CPU heatsink w/ fan	ASSY Thermal DIS Forcecon	60.4T930.001

CPU/Processor

Category	Part Name	Description	Acer Part No.
	CPU Merom Core 2 Dual T7100 1.8G 2M 800 Intel	IC CPU Merom T7100 1.8G PGA	KC.71001.DTP
	CPU Intel Merom Core 2 Dual T7300 2.0G 4M 800L Intel	IC CPU Merom T7300 2.0G PGA	KC.73001.DTP
	CPU Intel Merom Core 2 Dual T7500 2.2G 4M 800 Intel	IC CPU Merom T7500 2.2G PGA	KC.75001.DTP
	CPU Intel Merom Core 2 Dual T7700 2.4G 4M 800 Intel	IC CPU Merom T7700 2.4G PGA	KC.77001.DTP
Keyboard			
	Keyboard 88 key Darfon NSK-H3V1D UI US-IN	KB Darfon NSK-H3V1D UI US-IN88	9J.N5982.V1D
	Keyboard 88 key Darfon NSK-H3V02 TW Taiwan	KB Darfon NSK-H3V02 TW Taiwa88	9J.N5982.V02
	Keyboard 88 key Darfon NSK-H3V03 TI Thailand	KB Darfon NSK-H3V03 TI Thai88	9J.N5982.V03
	Keyboard 88 key Darfon NSK-H3V0A Ar Arabic	KB Darfon NSK-H3V0A AR Arabi88	9J.N5982.V0A
	Keyboard 88 key Darfon NSK-H3V0H HB Hebrew	KB Darfon NSK-H3V0H HB Hebre88	9J.N5982.V0H
	Keyboard 88 key Darfon NSK-H3V0K KO Korean	KB Darfon NSK-H3V0K KO Korea88	9J.N5982.V0K
	Keyboard 88 key Darfon NSK-H3V0L GK Greek	KB Darfon NSK-H3V0L GK Greek88	9J.N5982.V0L
	Keyboard 88 key Darfon NSK-H3V0R RU Russian	KB Darfon NSK-H3V0R RU Russi88	9J.N5982.V0R
	Keyboard 88 key Darfon NSK-H3V0X Blank US	KB Darfon NSK-H3V0X BL-84K(88)	9J.N5982.V0X
	Keyboard 89 key Darfon NSK-H3V06 PO Portuguese	KB Darfon NSK-H3V06 PO Portu89	9J.N5982.V06
	Keyboard 89 key Darfon NSK-H3V0C CZ Czech	KB Darfon NSK-H3V0C Czech89	9J.N5982.V0C
	Keyboard 89 key Darfon NSK-H3V0D DM Danish	KB Darfon NSK-H3V0D DM Danis89	9J.N5982.V0D
	Keyboard 89 key Darfon NSK-H3V0E IT Italian	KB Darfon NSK-H3V0E IT Itali89	9J.N5982.V0E
	Keyboard 89 key Darfon NSK-H3V0FFR French	KB Darfon NSK-H3V0F FR Rehcn89	9J.N5982.V0F
	Keyboard 89 key Darfon NSK-H3V0G GR German	KB Darfon NSK-H3V0G GR Germa89	9J.N5982.V0G
	Keyboard 89 key Darfon NSK-H3V00 SW Swiss	KB Darfon NSK-H3V00 SW Swiss89	9J.N5982.V00
	Keyboard 89 key Darfon NSK-H3V0M Canadian	KB Darfon NSK-H3V0M CF FR.CA89	9J.N5982.V0M
	Keyboard 89 key Darfon NSK-H3V0N NW Norwegian	KB Darfon NSK-H3V0N NW Norwe89	9J.N5982.V0N
	Keyboard 89 key Darfon NSK-H3V0Q HG Hungarian	KB Darfon NSK-H3V0Q HG Huga89	9J.N5982.V0Q

Category	Part Name	Description	Acer Part No.
Keyboard (cont.)	Keyboard 89 key Darfon NSK-H3V0S SP Spanish	KB Darfon NSK-H3V0S SP Spani89	9J.N5982.V0S
	Keyboard 89 key Darfon NSK-H3V0T TR Turkish	KB Darfon NSK-H3V0T TR Turki89	9J.N5982.V0T
	Keyboard 89 key Darfon NSK-H3V0U UK UK	KB Darfon NSK-H3V0U UK UK89	9J.N5982.V0U
	Keyboard 89 key Darfon NSK-H3V0W SD Swedish	KB Darfon NSK-H3V0W SD Swedi89	9J.N5982.V0W
	Keyboard 89 key Darfon NSK-H3V1A BE Belgian	KB Darfon NSK-H3V1A BE Belgian	9J.N5982.V1A
	Keyboard 89 key Darfon NSK-H3V01B BP Brazilian	KB Darfon NSK-H3V1B BP BR-PO89	9J.N5982.V1B
	Keyboard 89 key Darfon NSK-H3V1F SK Slovenian	KB Darfon NSK-H3V1F SK Slove89	9J.N5982.V1F
	Keyboard 89 key Darfon NSK-H3V0Y BL-85K	KB Darfon NSK-H3V0Y BL-85K(89)	9J.N5982.V0Y
	Keyboard 92 key Darfon NSK-H3V0J JA Japanese	KB Darfon NSK-H3V0J JA Japan92	9J.N5982.V0J
LCD module			
	LCD module 14.1" WXGA glare w/ antenna and camera	LCD N14.1WXGAG W/0.3M DV	G2.LDAHP.002
	Inverter board 17" FOXCONN T62I240.02 V.00	Inverter 17" T62I240.02 V.00	19.TK501.001
	Inverter board 17" YEC YNV-W06S	Inverter 17" YNV-W06S	19.TK501.002
	Inverter board 17" ROHS VK.21189.406	Inverter 17" ROHS VK.21189.406	19.TCBV1.001
	LCD cable 14.1: WXGA HL	C.A. LCD WXGA HL	50.4T901.001
	LCD cable 14.1: WXGA MEC	C.A. LCD WXGA MEC	50.4T901.011
	Camera CMOS 0.3M Suyin CN0314-OV03 U	Camera CMOS 0.3M CN0314-OV03 U	57.TK901.001
	Camera CMOS 0.3M Bison BN30V40717300	Camera CMOS 0.3M BN30V40717300	57.TK501.001
	LCD bracket right	Bracket LCD R	33.4T904.001
	LCD bracket left	Bracket LCD L	33.4T905.001
	LCD bezel 14.1"	ASSY LCD bezel	60.4T912.001
	LCD panel 14.1"	ASSY LCD panel	60.4T913.001
	Wireless antenna left/right	Antenna	25.90480.001
	LCD 14.1" WXGA AU B141EW04-V4 LF Glare 200 nits 16ms	LCD 14.1" WXGA AU B141EW04-V4 G	LK.14105.018
	LCD 14.1" WXGA LG LP141WX3-TLB1 glare	LCD 14.1" WXGA LG LP141WX3-TLB1	LK.14108.010
	LCD 14.1" WXGA LG LP141WX1-TLA2 LF Glare 200 nits 16ms	LCD 14.1" WXGA LG LP141EWX1-TLA2	LK.14108.007
	LCD 14.1" WXGA LG LP141WX3-TLA1 Glare	LCD 14.1" WXGA LG LP141WX3-TLA1	LK.14108.012

Category	Part Name	Description	Acer Part No.
LCD module (cont.)	LCD 14.1" WXGA Samsung LTN141W3-L01-G LF Glare 200 nits 16ms	LCD 14.1" WXGA Samsung LTN141W3	LK.14106.011
	LCD 14.1" WXGA CMO N141I3-L02 LF Glare 200 nits 16ms	LCD 14.1" WXGA CMO N141I3-L02 G	LK.1410D.016
	Microphone SAB	Microphone cable SAB	23.42120.001
	Microphone FORG	Microphone cable FORG	23.42123.001
	Microphone SHAN	Microphone cable SHAN	23.42124.001
Speaker			
	Speaker pack left/left	Speaker	23.40297.001
Mainboard			
	Mainboard Aspire4920 w/ RTC battery and PCMCIA slot w/o CPU and DIMM	Tahoe MB-DIS 06252-1 w/o modem	55.4T901.051G
RTC Battery			
	RTC battery	BTY RTC Mitsubishi ROHS	23.TDMV1.001
	RTC battery	BTY RTC Panasonic ROHS (UP)	23.22059.001
PCMCIA slot/PC card slot			
	PCMCIA slot	CONN Cardbus 4P 10057913-	21.H0153.001
Miscellaneous			
	LCD screw rubber	Rub cirle LCD	47.4T901.001
	Name plate	Name plate U-case Tahoe	42.4T913.001
	Media key	Media key Tahoe	42.4T907.001
Screws			
	Screw	Screw M2xL3 (white)	86.00C07.220
	Screw	Screw M2.5xL6 nylok CR3+	86.00E33.736
	Screw	Screw M2.5xL8 nylok CR3+	86.00E34.738
	Screw	Screw WAF M2x4 BZnylok CR3+	86.00E92.724
	Screw	Screw M2x2.5 nylok	86.00F22.722
	Screw	Screw M2x4 nylok H0.3	86.00F24.724
	Screw	Screw 2x6 nylok	86.00F58.726
	Screw	Screw Ni M2x6L	86.9A552.6R0
	Screw	Screw Mach Wafer M3xL4 Ni	86.9A554.4R0
	Screw	Screw wafer nylok Ni M2xL3	86.9A552.3R0

Model Definition and Configuration

Aspire 4920

[illegible]

Test Compatible Components

This computer's compatibility is tested and verified by Acer's internal testing department. All of its system functions are tested under Windows® Vista™ Business, Vista Home Premium, and Vista Home Basic environment.

Refer to the following lists for components, adapter cards, and peripherals which have passed these tests. Regarding configuration, combination and test procedures, please refer to the Aspire 4920 Vista Compatibility Test Report released by the Acer Mobile System Testing Department.

Microsoft® Windows® Vista™ Compatibility Test

I/O Peripheral Compatibility Test

Vendor	Device Description	Result
External CRT		
Acer	211c21"	P
ViewSonic	G220F	P
	PF790 19"	P
External LCD		
Acer	FP751 17" TFT LCD	P
	15" LCD Monitor (DVI) Model: AL1521 ¹	P
	17" LCD Monitor (DVI) Model: AL1721 ¹	P
ViewSonic	20" LCD VD201b(DVI-I), (DVI-D), (D-sub) ¹	P
Westinghouse	W37G (HDMI)	P
HP	LP2065 20" TFT Monitor (DVI)	P
	S9500 19" Monitor (DVI)	P
Projector		
DELL	3300MP projector	P
USB keyboard or mouse		
Microsoft	Natural keyboard Pro	P
Logicoool	USB mouse (OWCM-USB)	P
Logitech	USB wheel mouse	P
	First wheel mouse	P
DELL	USB keyboard	P
	Dell by Logitech	P
	Internet navigator keyboard	P
	Smart card keyboard	P
HP	USB optical Austin mouse	P
	HP USB optical mouse (RB129AA)	P
Belkin	Miniglow optical USB mouse	P
USB printer/scanner		
Canon	Canon Scanner D1250 (USB 2.0) (JP OS only)	N/A
HP	450wbt deskjet printer (USB/Bluetooth)	P
	2400 Scanjet (USB 1.1)	N/A
USB speaker/joystick		
Aiwa	Multimedia digital speaker (SC-UC78)	P
Logitech	WingMan RumblePad (G-UA3)	N/A
Peripheral	Dolby Headphone 5.1 channel	N/A
Panasonic	USB speaker EAB-MPC57USB	P
JS	iFun USB speaker	N/A
USB camera		
Intel	Easy PC Camera (A20953-001)	P
Orange	Micro USB 2.0 Web Cam	P
USB storage device		
lomega	USB zip 250MB	P
Fujitsu	MO-1300 1.3G USB 2.0	N/A

I/O Peripheral Compatibility Test

Vendor	Device Description	Result
Transcend	80GB HDD USB 2.0+IEEE 1394	P
PQI	6-in-1 Flash card reader/writer ²	P
Plextor	DVD+R/RW USB 2.0	P
Galileo	Mass storage 2.5 travel kit with 1394	N/A
LG	DVD+R/RW 16X USB 2.0+IEEE 1394	P
Sony	DVD+R/RW 16X USB 2.0+IEEE 1394	P
USB flash drive		
Sony	Memory key 128MB	P
	Micro Bault Pro USD-5G 5GB USB flash	P
Apacer	Handy drive the USB flash drive	P
IBM	128MB USB 2.0 memory key	P
	512MB USB 2.0 memory key	P
USB hub and others		
A TEN	4 port hub USB 2.0 UH-204	P
IOGEAR	4 port hub USB 2.0	P
Corega	Wireless LAN USB stick 11 USB 1.1 CG-WLUSBST11	P
USB ODD		
Logitech	CD-RW + DVD-ROM combo USB interface	P
LG	DVD+R/RW 16X USB 2.0+IEEE 1394	P
Sony	DVD+R/RW 16X USB 2.0+IEEE 1394	P
USB HDD		
Transcend	2.5" portable 80GB hard disk	P
1394 storage drive		
LG	DVD+R/RW 16X USB 2.0+IEEE 1394	N/A
Sony	DVD+R/RW 16X USB 2.0+IEEE 1394	P
Transcend	2.5" portable 80GB hard disk	P
1394 camera		
Sony	DV	P
Access point 802.11b		
Cisco	Aironet 350	N/A
	Aironet 1230	N/A
Access point 802.11a		
Intel	Pro/Wireless 5000	P
NetGear	54Mbps 802.11a Access point model: HE 102	P
Access point 802.11g		
D-Link	Building networks people WiFi certified a/b/g wireless 108AG	P
Access point 802.11n		
D-Link	Rangebooster N 650 Router Wireless-802.11n	N/A
Buffalo	Air Station Wireless IEEE 802.11n/g/b WZR-G144N	N/A
MIMO	Belkin N1MIMO Wireless router high performance Wireless 802.11n	P
Bluetooth access point		
X Bridge	Bluetooth access point BT300	P
Bluetooth device		
Sony Ericsson	Wireless headset	P
	T610	P

I/O Peripheral Compatibility Test

Vendor	Device Description	Result
X Bridge	Bluetooth access point BT300	P
Epson	Bluetooth print adapter	N/A
HP	Deskjet 450wbt	N/A
AmbiCom	Bluetooth wireless compact Flash card with PC card adapter	N/A
SDIO card		
Toshiba	Bluetooth SD card	N/A
Express card		
Abcom	5-in-1 adapter express card reader	P
	GigaLAN express card	P
Sunix	ECF2400 2 ports 1394A express card	P
	Serial ATA External SATAII express card	N/A
IK Kouwell	IK Kouwell IEEE1394+USB2.0 express card	N/A
SIIG	SIIG express card 11-in R/W easily add a memory card reader/writer to express card equipped systems	N/A

- 1 If system support s DVI, a D-sub interface supplemental test is required.
- 2 PQI 6-in-1 flash card reader/writer is not compatible with USB 2.0 systems.

Memory Card Compatibility Test

Vendor	Device Description	Result
Multimedia card		
Sandisk	Multimedia card 32MB	P
	RS-MMC 128MB memory card	P
Transcend	Multimedia card 64/128MB	P
	Multimedia card 128MB	P
	Multimedia card 256MB	P
	Multimedia card 512MB	P
Apacer	Multimedia card 128MB	N/A
PQI	RS-MMC mobile 256MB memory card	P
A-Data	Turbo 200x 2GB MMC card	P
SD card		
Apacer	SD card 128/256MB	P
	SD card 2GB (150X Hi-Speed)	P
Transcend	SD card 256MB	N/A
SanDisk	SD card 256MB	P
	SD card 1GB	P
KINGMAX	SD card 1GB (66X Hi-Speed)	P
RiData	SD 4GB SD Pro memory card	P
Memory stick		
I-O data	Memory stick 64MB	N/A
Apacer	Memory stick 128MB	N/A
Lexar	High speed 512MB memory stick Pro Duo	P
	High speed 1GB memory stick Pro Duo	P
SanDisk	MS Pro 1GB memory card	N/A

Memory Card Compatibility Test

Vendor	Device Description	Result
Sony	Memory stick Pro 512MB	P
	MS Pro Duo 2GB high speed	P
	MS Pro 2GB memory card	P
Compact Flash		
Apacer	Compact Flash card 256/512MB	P
SanDisk	Compact Flash card 2GB	P
XD card		
Apacer	Compact Flash card 256/512MB	P
SanDisk	Compact Flash card 2GB	P
Olympus	XD-Picture card 512MB	P

Game Test

Vendor	Item Description	Result
Blizzard	WarCraft III- Frozen Throne	P
Activision	Doom3	P
EA	Battlefield 2 Patch 1.01 (DX9)	P
	FIFA World Cup 2006	P
	FIFA Soccer 06	P
EA games	Under Ground II	P
Sierra	Half-Life 2	P
Online game	Lineage II: Chronicle 3	P
	World of WarCraft	P
	RF Online	P

SW Utility and Application Test

Item Description	Result
PowerDVD	P
Windows DVD Maker	P
NTI-CD Maker	P
NIS	P
Launch Manager	P
Wireless AP	N/A
Bluetooth AP	P
Acrobat Reader	P
Office	P

Online Support Information

This section describes online technical support services available to help you repair your Acer Systems.

If you are a distributor, dealer, ASP or TPM, please refer your technical queries to your local Acer branch office. Acer Branch Offices and Regional Business Units may access our website. However some information sources will require a user i.d. and password. These can be obtained directly from Acer CSD Taiwan.

Acer's Website offers you convenient and valuable support resources whenever you need them.

In the Technical Information section you can download information on all of Acer's Notebook, Desktop and Server models including:

- ☐ Service guides for all models
- ☐ User's manuals
- ☐ Training materials
- ☐ BIOS updates
- ☐ Software utilities
- ☐ Spare parts lists
- ☐ TABs (Technical Announcement Bulletin)

For these purposes, we have included an Acrobat File to facilitate the problem-free downloading of our technical material.

Also contained on this website are:

- ☐ Detailed information on Acer's International Traveler's Warranty (ITW)
- ☐ Returned material authorization procedures
- ☐ An overview of all the support services we offer, accompanied by a list of telephone, fax and email contacts for all your technical queries.

We are always looking for ways to optimize and improve our services, so if you have any suggestions or comments, please do not hesitate to communicate these to us.

www.s-manuals.com