
ADVANTEST[®]

ADVANTEST CORPORATION

***R3267 Series OPT64
PDC/PHS/IS-136
Measurement Option
Operation Manual***

MANUAL NUMBER FOE-8335220G00

Applicable models

R3264

R3267

R3273

Safety Summary

To ensure thorough understanding of all functions and to ensure efficient use of this instrument, please read the manual carefully before using. Note that Advantest bears absolutely no responsibility for the result of operations caused due to incorrect or inappropriate use of this instrument.

If the equipment is used in a manner not specified by Advantest, the protection provided by the equipment may be impaired.

- **Warning Labels**

Warning labels are applied to Advantest products in locations where specific dangers exist. Pay careful attention to these labels during handling. Do not remove or tear these labels. If you have any questions regarding warning labels, please ask your nearest Advantest dealer. Our address and phone number are listed at the end of this manual.

Symbols of those warning labels are shown below together with their meaning.

DANGER: Indicates an imminently hazardous situation which will result in death or serious personal injury.

WARNING: Indicates a potentially hazardous situation which will result in death or serious personal injury.

CAUTION: Indicates a potentially hazardous situation which will result in personal injury or a damage to property including the product.

- **Basic Precautions**

Please observe the following precautions to prevent fire, burn, electric shock, and personal injury.

- Use a power cable rated for the voltage in question. Be sure however to use a power cable conforming to safety standards of your nation when using a product overseas.
- When inserting the plug into the electrical outlet, first turn the power switch OFF and then insert the plug as far as it will go.
- When removing the plug from the electrical outlet, first turn the power switch OFF and then pull it out by gripping the plug. Do not pull on the power cable itself. Make sure your hands are dry at this time.
- Before turning on the power, be sure to check that the supply voltage matches the voltage requirements of the instrument.
- Connect the power cable to a power outlet that is connected to a protected ground terminal. Grounding will be defeated if you use an extension cord which does not include a protected ground terminal.
- Be sure to use fuses rated for the voltage in question.
- Do not use this instrument with the case open.
- Do not place anything on the product and do not apply excessive pressure to the product. Also, do not place flower pots or other containers containing liquid such as chemicals near this

product.

- When the product has ventilation outlets, do not stick or drop metal or easily flammable objects into the ventilation outlets.
- When using the product on a cart, fix it with belts to avoid its drop.
- When connecting the product to peripheral equipment, turn the power off.

- **Caution Symbols Used Within this Manual**

Symbols indicating items requiring caution which are used in this manual are shown below together with their meaning.

DANGER: Indicates an item where there is a danger of serious personal injury (death or serious injury).

WARNING: Indicates an item relating to personal safety or health.

CAUTION: Indicates an item relating to possible damage to the product or instrument or relating to a restriction on operation.

- **Safety Marks on the Product**

The following safety marks can be found on Advantest products.



: ATTENTION - Refer to manual.



: Protective ground (earth) terminal.



: DANGER - High voltage.



: CAUTION - Risk of electric shock.

- **Replacing Parts with Limited Life**

The following parts used in the instrument are main parts with limited life.

Replace the parts listed below before their expected lifespan has expired to maintain the performance and function of the instrument.

Note that the estimated lifespan for the parts listed below may be shortened by factors such as the environment where the instrument is stored or used, and how often the instrument is used. The parts inside are not user-replaceable. For a part replacement, please contact the Advantest sales office for servicing.

Each product may use parts with limited life.

For more information, refer to the section in this document where the parts with limited life are described.

Main Parts with Limited Life

Part name	Life
Unit power supply	5 years
Fan motor	5 years
Electrolytic capacitor	5 years
LCD display	6 years
LCD backlight	2.5 years
Floppy disk drive	5 years
Memory backup battery	5 years

- **Hard Disk Mounted Products**

The operational warnings are listed below.

- Do not move, shock and vibrate the product while the power is turned on.
Reading or writing data in the hard disk unit is performed with the memory disk turning at a high speed. It is a very delicate process.
- Store and operate the products under the following environmental conditions.
An area with no sudden temperature changes.
An area away from shock or vibrations.
An area free from moisture, dirt, or dust.
An area away from magnets or an instrument which generates a magnetic field.
- Make back-ups of important data.
The data stored in the disk may become damaged if the product is mishandled. The hard disc has a limited life span which depends on the operational conditions. Note that there is no guarantee for any loss of data.

- **Precautions when Disposing of this Instrument**

When disposing of harmful substances, be sure dispose of them properly with abiding by the state-provided law.

Harmful substances: (1) PCB (polycarbon biphenyl)
(2) Mercury
(3) Ni-Cd (nickel cadmium)
(4) Other
Items possessing cyan, organic phosphorous and hexadic chromium and items which may leak cadmium or arsenic (excluding lead in solder).

Example: fluorescent tubes, batteries

Environmental Conditions

This instrument should be only be used in an area which satisfies the following conditions:

- An area free from corrosive gas
- An area away from direct sunlight
- A dust-free area
- An area free from vibrations
- Altitude of up to 2000 m




Figure-1 Environmental Conditions

- Operating position




Figure-2 Operating Position

- Storage position




Figure-3 Storage Position








- The classification of the transient over-voltage, which exists typically in the main power supply, and the pollution degree is defined by IEC61010-1 and described below.

Impulse withstand voltage (over-voltage) category II defined by IEC60364-4-443

Pollution Degree 2

Types of Power Cable

Replace any references to the power cable type, according to the following table, with the appropriate power cable type for your country.

Plug configuration	Standards	Rating, color and length	Model number (Option number)
	PSE: Japan Electrical Appliance and Material Safety Law	125 V at 7 A Black 2 m (6 ft)	Straight: A01402 Angled: A01412
	UL: United States of America CSA: Canada	125 V at 7 A Black 2 m (6 ft)	Straight: A01403 (Option 95) Angled: A01413
	CEE: Europe DEMKO: Denmark NEMKO: Norway VDE: Germany KEMA: The Netherlands CEBEC: Belgium OVE: Austria FIMKO: Finland SEMKO: Sweden	250 V at 6 A Gray 2 m (6 ft)	Straight: A01404 (Option 96) Angled: A01414
	SEV: Switzerland	250 V at 6 A Gray 2 m (6 ft)	Straight: A01405 (Option 97) Angled: A01415
	SAA: Australia, New Zealand	250 V at 6 A Gray 2 m (6 ft)	Straight: A01406 (Option 98) Angled: -----
	BS: United Kingdom	250 V at 6 A Black 2 m (6 ft)	Straight: A01407 (Option 99) Angled: A01417
	CCC: China	250 V at 10 A Black 2 m (6 ft)	Straight: A114009 (Option 94) Angled: A114109

PREFACE

This manual provides the information necessary to check functionality, operate and program the R3267 Series Option 64, PDC/PHS/IS-136 measurement.

(1) Organization of this manual

This manual consists of the following chapters:

Safety Summary	To use the analyzer safely, be sure to read this manual first.
1. Introduction <ul style="list-style-type: none"> • Product Description (Option) • Standard Accessories • Self Test Error • Connectors on the rear panel 	Includes a description of the option and its' parts and a self test error.
2. Operation	You can learn the basic operations of the option through the examples shown in this chapter.
3. Reference <ul style="list-style-type: none"> • Menu Index • Menu Map • Functional Description 	Shows a list of operation keys, and describes the function of each key.
4. Remote Control <ul style="list-style-type: none"> • GPIB 	Included are a list of commands necessary for programming.
5. Technical Notes <ul style="list-style-type: none"> • PDC/PHS/IS-136 Burst measurement 	Describes the principle of operation necessary for taking measurements more accurately.
6. Performance Verification Test	Describes how to test performance.
7. Specifications	Shows the specifications of the option.
APPENDIX <ul style="list-style-type: none"> • Messages 	If an error occurs during operation, an error number and its corresponding error message are displayed. The meaning of each error is explained in this section.

(2) Typeface conventions used in this manual

- Panel keys and soft keys are printed in a contrasting typeface to make them stand out from the text as follows:

Panel keys: Boldface type

Example: **FREQ, TRANSIENT**

Soft keys: Boldface and italic type

Example: ***Center, Detector***

- When a series of key operations are described using a comma between two keys.
- There are various soft menus used to switch between two states such as ON/OFF and AUTO/MNL. For example, when turning off the ***Average Times ON/OFF*** function, the annotation "***Average Times ON/OFF(OFF)***" is used. When switching the ***RBW AUTO/MNL*** function to MNL, the annotation "***RBW AUTO/MNL(MNL)***" is used.

TABLE OF CONTENTS

1	INTRODUCTION	1-1
1.1	Product Overview	1-1
1.2	Accessories	1-1
1.3	Self Test Function	1-1
1.4	About Calibration	1-1
1.5	Explanation of the Connectors	1-1
2	OPERATION	2-1
2.1	Measuring the Base Station PDC System Signal	2-1
2.2	Measuring the Mobile Station PDC System Signal	2-7
3	REFERENCE	3-1
3.1	Menu Index	3-1
3.2	Menu Map	3-6
3.3	Functional Description	3-22
3.3.1	Switching between Communication Systems	3-23
3.3.2	T-Domain	3-24
3.3.2.1	Power (T-Domain)	3-24
3.3.2.2	ON/OFF Ratio	3-27
3.3.2.3	Spurious (T-Domain)	3-29
3.3.3	F-Domain	3-32
3.3.3.1	Power (F-Domain)	3-32
3.3.3.2	OBW	3-35
3.3.3.3	Due to Transient	3-36
3.3.3.4	Due to Modulation	3-39
3.3.3.5	Inband Spurious	3-43
3.3.3.6	Outband Spurious	3-45
3.3.4	Modulation	3-47
3.3.4.1	Power	3-47
3.3.4.2	OBW	3-52
3.3.4.3	Modulation Accuracy	3-53
3.3.4.4	Bit Rate Error	3-56
3.3.4.5	ALL Measurement	3-57
3.3.4.6	Wave Check	3-59
3.3.5	STD	3-62
3.3.5.1	DC CAL	3-62
3.3.5.2	Channel Setting	3-62
3.3.5.3	STD Setup	3-63
4	REMOTE CONTROL	4-1
4.1	GPIB Command Index	4-1

Table of Contents

4.2	GPIB Command Codes	4-8
5	TECHNICAL NOTES	5-1
5.1	Measuring Signals Including Multiple Bursts in the Frame in the PDC or IS-136 System	5-1
5.2	Measuring the Signals Including Both Up Link and Down Link Bursts in the Frame in the PHS System	5-2
5.3	Averaging the First 10 Symbols of Error Vector Magnitude in the IS-136 System	5-3
5.4	How to Measure the ACP using the Modulation Menu	5-4
5.5	Template Edit function	5-6
5.5.1	Template Setting in the T-Domain Measuring Mode	5-6
5.5.2	Template Setting in the F-Domain Measuring Mode	5-8
5.6	Measurement Parameter Settings in Due to Transient, Due to Modulation and Inband Spurious	5-10
5.6.1	Marker Edit Function	5-10
5.6.2	Measurement results Using Due to Modulation, Due to Transient and Inband Spurious Modes	5-12
5.6.3	Measurement Result of Inband Spurious	5-13
5.7	Mag Error (Magnitude Error)	5-14
5.8	Phase Error	5-14
5.9	E.V.M. (Error Vector Magnitude)	5-15
5.10	Block Diagram	5-16
6	PERFORMANCE VERIFICATION TEST	6-1
6.1	General	6-1
6.1.1	Introduction	6-1
6.1.2	Test Equipment	6-1
6.1.3	Calibration Cycle	6-2
6.1.4	Performance Verification Test Record Sheet	6-2
6.1.5	Performance Verification Procedures	6-2
6.2	Performance Verification Test Procedure	6-3
6.2.1	Modulation Accuracy Measurement for PDC	6-3
6.2.2	Modulation Accuracy Measurement for PHS	6-4
6.2.3	Modulation Accuracy Measurement for IS-136	6-5
6.3	Performance Verification Test Record Sheet	6-7
7	SPECIFICATIONS	7-1
	APPENDIX	A-1
A.1	Messages	A-1
	ALPHABETICAL INDEX	I-1

LIST OF ILLUSTRATIONS

No.	Title	Page
2-1	Connection for the PDC Measurement	2-1
2-2	PDC Spectrum	2-2
2-3	Communication System Dialog box	2-2
2-4	STD Measurement Parameter Set Dialog Box	2-3
2-5	Parameter Setup Dialog Box	2-4
2-6	Measurement Results of the PDC Signal	2-5
2-7	Connection for the PDC Measurement	2-7
2-8	STD Measurement Parameter Set Dialog Box	2-8
2-9	Parameter Setup Dialog Box	2-9
2-10	Measurement Results of the PDC Signal	2-9
3-1	Dialog Box Used for the Communication Systems	3-23
3-2	Trigger Setup Dialog Box	3-24
3-3	Parameter Setup Dialog Box	3-26
3-4	Trigger Setup Dialog Box	3-27
3-5	Parameter Setup Dialog Box	3-28
3-6	Trigger Setup Dialog Box	3-29
3-7	Parameter Setup Dialog Box	3-30
3-8	Trigger Setup Dialog Box	3-32
3-9	Detector Dialog Box	3-33
3-10	Parameter Setup Dialog Box	3-34
3-11	Parameter Setup Dialog Box	3-35
3-12	Parameter Setup Dialog Box	3-37
3-13	Trigger Setup Dialog Box	3-39
3-14	Detector Dialog Box	3-40
3-15	Parameter Setup Dialog Box	3-41
3-16	Parameter Setup Dialog Box	3-44
3-17	Parameter Setup Dialog Box	3-46
3-18	Parameter Setup Dialog Box	3-47
3-19	Template settings	3-48
3-20	Parameter Setup Dialog Box	3-49
3-21	Parameter Setup Dialog Box	3-50
3-22	Parameter Setup Dialog Box	3-52
3-23	Graph Menu	3-54
3-24	Parameter Setup Dialog Box	3-55
3-25	Parameter Setup Dialog Box	3-56
3-26	Parameter Setup Dialog Box	3-57
3-27	Select Type Dialog Box	3-59
3-28	Parameter Setup Dialog Box	3-60
3-29	Parameter Setup Dialog Box	3-61
3-30	STD Measurement Parameter Set Dialog Box	3-63
3-31	STD Measurement Parameter Set Dialog Box	3-66
3-32	STD Measurement Parameter Set Dialog Box	3-69
5-1	Signal with Multiple Bursts in the Frame	5-1
5-2	Burst Wave Including Both Up Link and Down Link Signals In the Frame	5-2

List of Illustrations

No.	Title	Page
5-3	Principle of the Partial Sweeps	5-4
5-4	Template to Be Set	5-6
5-5	Template settings	5-7
5-6	Template Shifted Using the Shift Y Function	5-7
5-7	Template with the Set Values	5-8
5-8	Template with Margin Delta X.	5-8
5-9	Example of Marker Edit Setting	5-10
5-10	Marker Edit Setting	5-11
5-11	Example of Peak Marker Y Delta	5-11
5-12	Mag Error, Phase Error, E.V.M.	5-15
5-13	Block Diagram	5-16
6-1	Setup of Modulation Accuracy Measurement for PDC, PHS and IS-136	6-3
6-2	Setup of Parameter for Phase Accuracy Measurement (PDC)	6-4
6-3	Setup of Measurement Parameter for Modulation Accuracy (PHS)	6-5
6-4	Setup of Measurement Parameter for Modulation Accuracy (IS-136)	6-6

LIST OF TABLES

No.	Title	Page
4-1	Operating Mode	4-8
4-2	ATT Key (Attenuator)	4-8
4-3	COPY Key (Hand copy)	4-8
4-4	COUPLE Key (Couple function)	4-9
4-5	FREQ Key (Frequency)	4-9
4-6	LEVEL Key (Reference Level)	4-9
4-7	MKR Key (Marker)	4-10
4-8	PRESET Key (Initialization)	4-10
4-9	RCL Key (Recall)	4-10
4-10	SAVE Key (Save)	4-11
4-11	SPAN Key (Frequency span)	4-11
4-12	TRASIENT Key	4-12
4-13	Numeric Keys/Step Keys/Data Knob/Unit Keys (Entering Data)	4-50
4-14	Miscellaneous	4-51
5-1	Spectrum Analyzer's ACP Measurement Settings in the Modulation Menu	5-4
6-1	Performance Verification Items	6-1
6-2	Equipment List	6-1

1 INTRODUCTION

1.1 Product Overview

This PDC/PHS/IS-136 analysis option software (Option 64) allows you to measure the modulation accuracy and transfer rate error and evaluate them.

This option is a factory option which is incorporated into the R3267 Series Spectrum Analyzer prior to shipment.

This option includes the following features:

- PDC, PHS and IS-136 system can be measured by simply switching the measurement system.
- Used to measure the transmission characteristics of the base station (BTS) signals and mobile station (MS) signals.
- Used to measure the Tx Power, Power vs Time, OBW, ACP, modulation accuracy and transfer rate error specified by the communication standard using a simple key operation.

1.2 Accessories

Name of accessories	Type of name	Quantity	Remarks
R3267 Series OPT64 Operation manual	ER3267/73 OPT64	1	English

1.3 Self Test Function

The self test also checks the Option 64 for correct operation when the spectrum analyzer power is turned on. The message shown below will be displayed when an error related to Option 64 occurs. Contact ADVANTEST Corp. for repair.

Error Message
Handshake error occurred to DSP

1.4 About Calibration

When you want to calibrate the R3267 Series, please contact a sales representative.

Desirable Period	One year

1.5 Explanation of the Connectors

Connectors used for this option are described as follows:

1. EXT TRIG terminal Connector for inputting the external trigger signal.
2. I channel terminal Connector for inputting the I channel signal (Baseband).
3. Q channel terminal Connector for inputting the Q channel signal (Baseband).

2 OPERATION

This chapter describes how to use this option using practical measurement examples.

2.1 Measuring the Base Station PDC System Signal

Measurement conditions:

The measurement target is PDC system equipment under test, which transmits a signal with a frequency of 810 MHz and a level of -10 dBm.

Measurement specifications:

Physical channels for down-link communication

Synchronization word: 87A4B [HEX]

Full rate

Connection of the Instrument

1. Connect the instrument to the base station equipment as shown in Figure 2-1.




Figure 2-1 Connection for the PDC Measurement

Setting Measurement Conditions

Set measurement conditions so the input signal can be observed clearly.

2. Press **FREQ, 8, 1, 0** and **MHz**.
3. Press **SPAN, 1, 0, 0** and **kHz**.
4. Press **LEVEL, 0** and **GHz (+dBm)**.
5. Press **COUPLE, RBW AUTO/MNL (MNL), 3, 0, 0** and **Hz**.
6. Press **VBW AUTO/MNL (MNL), 3, 0, 0** and **Hz**.
7. Press **Sweep Time AUTO/MNL (MNL), 2, 0** and **MHz (sec)**.

2.1 Measuring the Base Station PDC System Signal

8. Press **FORMAT**, *Trace Detector* and *Positive*.




Figure 2-2 PDC Spectrum

9. Press **CONFIG**, *more 1/2* and *Comm. System*.
10. Move the cursor to *PDC* in the Communication System menu using the data knob and press **Hz(ENTR)**.




Figure 2-3 Communication System Dialog box

11. Press **TRANSIENT**, *STD* and *STD Setup*.
12. Set *Type* to *PDC 800 M-1* using the data knob, and then press **Hz(ENTR)**.
13. Set *Link* to *DOWNLINK* using the data knob, and then press **Hz(ENTR)**.

2.1 Measuring the Base Station PDC System Signal

14. Press **∇**.
15. Set *Slot Format* to **TRAFFIC** using the data knob, and then press **Hz(ENTR)**.
16. Set *Rate* to **FULL RATE** using data knob, and then press **Hz(ENTR)**.
17. Set *Sync Type* to **SYNC WORD** using the data knob, and then press **Hz(ENTR)**.
18. Set *Sync Word* to **S1/S7** using the data knob, and then press **Hz(ENTR)**.
19. Set *Root Nyquist Filter* to **ON** using the data knob, and then press **Hz(ENTR)**.
20. Set *Freq Meas Range* to **NORMAL** using the data knob, and then press **Hz(ENTR)**.
21. Set *Filter Mode* to **WIDE** using the data knob, and then press **Hz(ENTR)**.
22. ENTR **0, ,, 0** and **GHz(dB)** to *Offset Level* using the numeric keys.
23. Set *Frequency Input* to **FREQUENCY** using the data knob, and then press **Hz(ENTR)**.
24. Set *Input* to **RF** using the data knob, and then press **Hz(ENTR)**.
25. Set *IQ Inverse* to **NORMAL** using the data knob, and then press **Hz(ENTR)**.
26. Set *Cont Auto Level Set* to **OFF** using the data knob, and then press **Hz(ENTR)**.

STD Measurement Parameter Set					
Type	PDC 800M-1	PDC 800M-2	PDC 800M-3	PDC 1.5G	STD
Link	UPLINK	DOWNLINK			1
Meas Mode	BURST	MULTI-BURST	CONTINUOUS		DC CAL
Slot Format	CONTROL	TRAFFIC	VOX		
Rate	FULL RATE	HALF RATE			
Sync Type	SYNC WORD	NO SYNC WORD			
Sync Word	S1/S7	S2/S8	S3/S9		
	S4/S10	S5/S11	S6/S12	87A4B/31BAF	
Root Nyquist Filter	ON	OFF			
Freq Meas Range	NORMAL	EXPAND			
Filter Mode	WIDE	NARROW			
Offset Level	0.0 dB				
Frequency Input	FREQUENCY	CHANNEL			
Input	RF	BASEBAND(I&Q)			6
Baseband Input	AC	DC			Channel Setting
IQ Inverse	NORMAL	INVERSE			
Cont Auto Level Set	ON	OFF			7
					STD Setup

Figure 2-4 STD Measurement Parameter Set Dialog Box

2.1 Measuring the Base Station PDC System Signal

27. Press **RETURN**.
28. Press **Modulation**.
29. Press **Modulation Accuracy**.
30. Press **Parameter Setup**.
31. Set **Trigger Source** to **FREE RUN** using the data knob, and then press **Hz(ENTR)**.




Figure 2-5 Parameter Setup Dialog Box

32. Press **Parameter Setup**.
33. Press **Auto Level Set**.

34. Press **SINGLE**.




Figure 2-6 Measurement Results of the PDC Signal

Burst Amplitude Droop	Droop factor (dB/Symbol)
Carrier Frequency Error	Carrier frequency error (Hz)
I/Q Origin Offset	I/Q origin offset (dBc)
Magnitude Error	Magnitude error (% rms) used when the symbol specified by the standard is evaluated
Phase Error	Phase error (deg rms) used when the symbol specified by the standard is evaluated
Error Vector Magnitude	Modulation accuracy (% rms) used when the symbol specified by the standard is evaluated
First 10 Symbols Mag Err	Magnitude error (% rms) used when the first 10 symbols are evaluated
First 10 Symbols Phase Err	Phase error (deg rms) used when the first 10 symbols are evaluated
First 10 Symbols E.V.M.	Modulation accuracy (% rms) used when the first 10 symbols are evaluated

2.1 Measuring the Base Station PDC System Signal

Peak Mag Error	Peak value (%) of a magnitude error and its symbol number within the evaluation symbols specified by the standard
Peak Phase Error	Peak value (deg) of a phase error and its symbol number of within the evaluation symbols specified by the standard
Peak E.V.M.	Peak value (%) of modulation accuracy and its symbol number within the evaluation symbols specified by the standard

2.2 Measuring the Mobile Station PDC System Signal

Measurement conditions:

The measurement target is PDC system equipment under test, which transmits a signal with a frequency of 940 MHz and a level of -10 dBm.

Measurement specifications:

Physical channels for up-link communication

Synchronization word: 785B4 [HEX]

Full rate

Connection of the Instrument

1. Connect the instrument to the mobile station equipment as shown in Figure 2-7.




Figure 2-7 Connection for the PDC Measurement

Setting Measurement Conditions

Set the center frequency of the spectrum analyzer for the frequency of a signal to be measured.

2. Press **FREQ, 9, 4, 0** and **MHz**.
3. Press **TRANSIENT, STD** and **STD Setup**.
4. Set **Type** to **PDC 800 M-1** using the data knob, and then press **Hz(ENTR)**.
5. Set **Link** to **UPLINK** using the data knob, and then press **Hz(ENTR)**.
6. Set **Meas Mode** to **BURST** using the data knob, and then press **Hz(ENTR)**.
7. Set **Slot Format** to **TRAFFIC** using data knob, and then press **Hz(ENTR)**.
8. Set **Rate** to **FULL RATE** using the data knob, and then press **Hz(ENTR)**.
9. Set **Sync Type** to **SYNC WORD** using the data knob, and then press **Hz (ENTR)**.

2.2 Measuring the Mobile Station PDC System Signal

10. Set *Sync Word* to *S1/S7* using the data knob, and then press **Hz(ENTR)**.
11. Set *Root Nyquist Filter* to *ON* using data knob, and then press **Hz(ENTR)**.
12. Set *Freq Meas Range* to *NORMAL* using the data knob, and then press **Hz(ENTR)**.
13. Set *Filter Mode* to *WIDE* using the data knob, and then press **Hz(ENTR)**.
14. Enter **0**, **,**, **0** and **GHz(dB)** to *Offset Level* using the numeric keys.
15. Set *Frequency Input* to *FREQUENCY* using the data knob, and then press **Hz(ENTR)**.
16. Set *Input* to *RF* using the data knob, and then press **Hz(ENTR)**.
17. Set *IQ Inverse* to *NORMAL* using the data knob, and then press **Hz(ENTR)**.
18. Set *Cont Auto Level Set* to *OFF* using the data knob, and then press **Hz(ENTR)**.




Figure 2-8 STD Measurement Parameter Set Dialog Box

19. Press **RETURN**.
20. Press *Modulation*.
21. Press *Modulation Accuracy*.
22. Press *Parameter Setup*.

23. Set *Trigger Source* to *FREE RUN* using the data knob, and then press **Hz(ENTR)**.
24. Press **∇**.
25. Enter **-, 2, 5** and **GHz(dB)** to *Search Level* using the numeric keys.




Figure 2-9 Parameter Setup Dialog Box

26. Press *Parameter Setup*.
27. Press *Auto Level Set*.
28. Press **SINGLE**.




Figure 2-10 Measurement Results of the PDC Signal

2.2 Measuring the Mobile Station PDC System Signal

Burst Amplitude Droop	Droop factor (dB/Symbol)
Carrier Frequency Error	Carrier frequency error (Hz)
I/Q Origin Offset	I/Q origin offset (dBc)
Magnitude Error	Magnitude error (% rms) used when the symbol specified by the standard is evaluated
Phase Error	Phase error (deg rms) used when the symbol specified by the standard is evaluated
Error Vector Magnitude	Modulation accuracy (% rms) used when the symbol specified by the standard is evaluated
First 10 Symbols Mag Err	Magnitude error (% rms) used when the first 10 symbols are evaluated
First 10 Symbols Phase Err	Phase error (deg rms) used when the first 10 symbols are evaluated
First 10 Symbols E.V.M.	Modulation accuracy (% rms) used when the first 10 symbols are evaluated
Peak Mag Error	Peak value (%) of a magnitude error and its symbol number within the evaluation symbols specified by the standard
Peak Phase Error	Peak value (deg) of a phase error and its symbol number of within the evaluation symbols specified by the standard
Peak E.V.M.	Peak value (%) of modulation accuracy and its symbol number within the evaluation symbols specified by the standard

3 REFERENCE

This chapter describes the functions of the panel and soft keys for option 64 software.

3.1 Menu Index

This menu index is used to easily find the keys described in Chapter 3.

Operation Key	Pages	Operation Key	Pages
22.5deg Turn	3-18, 3-54		3-68, 3-72
ACP.....	3-16, 3-50	Bit Rate Error.....	3-6, 3-59
ACP ON/OFF	3-19, 3-57	Bit Rate Error ON/OFF.....	3-19, 3-57
ACP Unit.....	3-51, 3-58	Burst Search.....	3-16, 3-17,
ALL Measurement.....	3-6, 3-19		3-18, 3-19,
Auto Level Set	3-7, 3-8,		3-20, 3-48,
	3-9, 3-10,		3-49, 3-51,
	3-11, 3-12,		3-53, 3-55,
	3-13, 3-14,		3-56, 3-58,
	3-15, 3-16,		3-61
	3-17, 3-18,	Channel Setting.....	3-6, 3-20
	3-19, 3-20,	Config	3-7, 3-8,
	3-24, 3-27,		3-9, 3-10,
	3-29, 3-32,		3-11, 3-12,
	3-35, 3-36,		3-13, 3-14,
	3-39, 3-43,		3-15, 3-26,
	3-45, 3-47,		3-28, 3-30,
	3-48, 3-50,		3-34, 3-35,
	3-52, 3-53,		3-37, 3-41,
	3-56, 3-57,		3-44, 3-46
	3-59, 3-61	Constellation	3-18, 3-54
Average Times.....	3-52	Constellation (Dot)	3-18, 3-54
Average Times ON/OFF.....	3-7, 3-8,	Constellation (Line & Dot).....	3-18, 3-54
	3-9, 3-10,	Constellation (Line).....	3-18, 3-54
	3-11, 3-12,	Cont Auto Level.....	3-9, 3-31
	3-13, 3-14,	Cont Auto Level Set	3-21, 3-66,
	3-15, 3-16,		3-69, 3-72
	3-17, 3-18,	Copy from STD	3-7, 3-12,
	3-19, 3-20,		3-13, 3-14,
	3-26, 3-28,		3-20, 3-25,
	3-30, 3-34,		3-36, 3-41,
	3-35, 3-37,		3-43, 3-62
	3-41, 3-44,	DC CAL.....	3-6, 3-20
	3-46, 3-48,	Delay Time	3-7, 3-8,
	3-50, 3-53,		3-9, 3-10,
	3-55, 3-57,		3-13, 3-25,
	3-59, 3-60		3-27, 3-29,
Baseband Input	3-21, 3-65,		3-33, 3-39

3.1 Menu Index

Delete Line.....	3-7, 3-9, 3-12, 3-13, 3-14, 3-15, 3-25, 3-30, 3-36, 3-41, 3-43, 3-45	3-33, 3-40
Demodulated Data	3-18, 3-54	Graphics
Detector.....	3-7, 3-8, 3-9, 3-10, 3-11, 3-12, 3-13, 3-14, 3-15, 3-26, 3-28, 3-30, 3-33, 3-34, 3-35, 3-37, 3-40, 3-41, 3-44, 3-46	3-18, 3-54
Display Unit.....	3-7, 3-8, 3-9, 3-10, 3-12, 3-13, 3-14, 3-15, 3-26, 3-28, 3-30, 3-34, 3-37, 3-42, 3-45, 3-46	I EYE Diagram
Due to Modulation	3-6	I/Q EYE Diagram
Due to Transient.....	3-6	Ich & Qch Time
E.V.M. vs Symbol.....	3-18, 3-54	Ich Time & FFT
EXT Gate	3-10, 3-13, 3-33, 3-40	Inband Spurious
F-Domain	3-6	Input.....
Filter Mode	3-21, 3-65, 3-68, 3-71	3-21, 3-65, 3-68, 3-71
Freq Meas Range	3-21, 3-64, 3-67, 3-71	Insert Line
Freq. Setting.....	3-12, 3-13, 3-14, 3-37, 3-41, 3-44	3-7, 3-9, 3-12, 3-13, 3-14, 3-15, 3-25, 3-30, 3-36, 3-41, 3-43, 3-45
Frequency Input	3-21, 3-65, 3-68, 3-71	IQ Complex FFT.....
Gate Position.....	3-10, 3-13, 3-33, 3-40	IQ Inverse
Gate Setup.....	3-10, 3-13, 3-32, 3-33, 3-39, 3-40	3-21, 3-65, 3-68, 3-72
Gate Source.....	3-10, 3-13, 3-33, 3-40	Judgment.....
Gate Width.....	3-10, 3-13, 3-33, 3-40	3-7, 3-8, 3-9, 3-10, 3-11, 3-12, 3-13, 3-14, 3-15, 3-26, 3-28, 3-30, 3-34, 3-35, 3-38, 3-42, 3-45, 3-46
Gated Sweep	3-10, 3-34	Link
Gated Sweep ON/OFF.....	3-10, 3-13,	3-21, 3-63, 3-66, 3-70
		Load Table
		3-9, 3-15, 3-29, 3-30, 3-45
		Lower Limit
		3-7, 3-10, 3-11, 3-26, 3-34, 3-35
		Mag Error vs Symbol.....
		3-18, 3-54
		Margin ΔX ON/OFF
		3-12, 3-13, 3-14, 3-36, 3-40, 3-43
		Marker Edit
		3-12, 3-13, 3-14, 3-36, 3-41, 3-43
		Meas Mode
		3-21, 3-63, 3-67, 3-70
		Meas Mode NORM/HIGH
		3-16, 3-49
		Modulation.....
		3-6, 3-18
		Modulation Accuracy
		3-6
		Multiplier
		3-9, 3-30
		OBW
		3-6
		OBW%.....
		3-11, 3-35
		OFF Position.....
		3-8, 3-28

OFF Width	3-8, 3-28	3-18, 3-20,
OffLevUnit dBm/dB	3-16, 3-49	3-48, 3-50,
Offset Level	3-21, 3-65,	3-51, 3-53,
	3-68, 3-71	3-55, 3-56,
ON Position.....	3-8, 3-28	3-58, 3-61
ON Width.....	3-8, 3-28	Select Type
ON/OFF Ratio.....	3-6	3-18, 3-20,
Outband Spurious	3-6	3-54, 3-59
Parameter Setup	3-7, 3-8,	Set to Default
	3-9, 3-10,	3-9, 3-15,
	3-11, 3-12,	3-31, 3-46
	3-13, 3-14,	Set to STD.....
	3-15, 3-16,	3-7, 3-8,
	3-17, 3-18,	3-10, 3-11,
	3-19, 3-20,	3-12, 3-13,
	3-26, 3-28,	3-14, 3-25,
	3-30, 3-34,	3-26, 3-28,
	3-35, 3-37,	3-33, 3-34,
	3-41, 3-44,	3-35, 3-38,
	3-46, 3-47,	3-40, 3-42,
	3-49, 3-50,	3-45
	3-52, 3-55,	Shift X.....
	3-56, 3-57,	3-7, 3-12,
	3-60, 3-61	3-13, 3-14,
Peak MKR Y Delta.....	3-9, 3-14,	3-25, 3-36,
	3-15, 3-30,	3-40, 3-43
	3-44, 3-46	Shift Y.....
Phase Error vs Symbol.....	3-18, 3-54	3-7, 3-12,
Power	3-6	3-13, 3-14,
Power vs Time	3-16, 3-48	3-25, 3-36,
Preselector.....	3-9, 3-15,	3-40, 3-43
	3-30, 3-46	Slope
Q EYE Diagram.....	3-18, 3-54	3-7, 3-8,
Qch Time & FFT	3-20	3-9, 3-10,
Rate	3-21, 3-64,	3-13, 3-25,
	3-70	3-27, 3-29,
Ref Power	3-12, 3-13,	3-33, 3-39
	3-14, 3-37,	Slot Format
	3-42, 3-44	3-21, 3-64,
Ref. Level Adjust.....	3-51	3-67
Result	3-9, 3-12,	Slot Number
	3-13, 3-14,	3-16, 3-17,
	3-30, 3-37,	3-18, 3-19,
	3-42, 3-44	3-20, 3-48,
Rolloff Factor.....	3-12, 3-13,	3-50, 3-51,
	3-38, 3-42	3-53, 3-55,
Root Nyquist Filter	3-21, 3-64,	3-57, 3-58,
	3-67, 3-70	3-60, 3-62
Save Table.....	3-9, 3-15,	Sort.....
	3-30, 3-45	3-7, 3-12,
Search Level	3-16, 3-17,	3-13, 3-14,
		3-25, 3-36,
		3-41, 3-43
		Spurious
		3-6
		STD.....
		3-6
		STD Setup.....
		3-6, 3-20
		STD Template.....
		3-16, 3-49
		Sweep Time
		3-16, 3-19,
		3-20, 3-52,
		3-59, 3-61

3.1 Menu Index


Symbol Rate 1/T	3-12, 3-13, 3-38, 3-42	Trigger Level	3-7, 3-8, 3-9, 3-10, 3-13, 3-16, 3-17, 3-18, 3-19, 3-20, 3-25, 3-27, 3-29, 3-33, 3-39, 3-48, 3-50, 3-51, 3-53, 3-55, 3-57, 3-58, 3-60, 3-62
Sync Type	3-21, 3-64, 3-67, 3-70	Trigger Position	3-7, 3-8, 3-9, 3-10, 3-13, 3-16, 3-20, 3-25, 3-27, 3-29, 3-33, 3-39, 3-62
Sync Word	3-21, 3-64, 3-70	Trigger Setup	3-7, 3-8, 3-9, 3-10, 3-13, 3-24, 3-27, 3-29, 3-32, 3-39
Table Edit.....	3-9, 3-15, 3-30, 3-45	Trigger Slop	3-55, 3-58, 3-60, 3-62
Table Init.....	3-7, 3-9, 3-12, 3-13, 3-14, 3-15, 3-25, 3-30, 3-36, 3-41, 3-43, 3-45	Trigger Slope	3-16, 3-17, 3-18, 3-19, 3-20, 3-48, 3-50, 3-51, 3-53, 3-56
Table No. 1/2/3	3-9, 3-15, 3-29, 3-30, 3-45	Trigger Source	3-7, 3-8, 3-9, 3-10, 3-13, 3-16, 3-17, 3-18, 3-19, 3-20, 3-24, 3-27, 3-29, 3-32, 3-39, 3-47, 3-49, 3-51, 3-53, 3-55, 3-56, 3-58, 3-60, 3-61
T-Domain.....	3-6, 3-24	Tx Power.....	3-16, 3-47
Template	3-7, 3-12, 3-13, 3-14, 3-25, 3-36, 3-40, 3-43	Tx Power Average	3-51
Template Couple to Power	3-7, 3-12, 3-13, 3-14, 3-26, 3-38, 3-42, 3-45	Tx Power Type.....	3-58
Template Edit.....	3-7, 3-12, 3-13, 3-14, 3-25, 3-36, 3-41, 3-43	Tx Power Unit.....	3-58
Template Entry	3-16, 3-48	Type	3-21, 3-63, 3-66, 3-70
Template Limit	3-7, 3-12, 3-13, 3-14, 3-26, 3-38, 3-42, 3-45	Unique Word.....	3-21, 3-67
Template ON/OFF	3-7, 3-13, 3-14, 3-25, 3-36, 3-40, 3-43	Unit	3-52
Template UP/LOW	3-25		
Time	3-20, 3-61		
Time & FFT	3-20, 3-59		
Trigger	3-10, 3-13, 3-33, 3-40		
Trigger Delay.....	3-16, 3-17, 3-18, 3-19, 3-20, 3-48, 3-50, 3-51, 3-53, 3-55, 3-57, 3-58, 3-60, 3-62		


Upper Limit.....	3-7, 3-8, 3-10, 3-11, 3-26, 3-28, 3-34, 3-35
User Define	3-16, 3-19, 3-52, 3-59
User Template1	3-16, 3-49
User Template2.....	3-16, 3-49
User Template3.....	3-16, 3-49
Wave Check.....	3-6, 3-20
Window ON/OFF	3-7, 3-8, 3-10, 3-25, 3-28, 3-34
Window Position.....	3-7, 3-10, 3-25, 3-34
Window Setup.....	3-7, 3-8, 3-10, 3-25, 3-28, 3-34
Window Width.....	3-7, 3-10, 3-25, 3-34
Y [dB/div] 20/10/5	3-16, 3-49
Y Scale [dB/div] 10/5/2	3-7, 3-8, 3-10, 3-26, 3-28, 3-34

3.2 Menu Map


3.2 Menu Map


This section shows the hierarchical menu configuration for each panel key.







3.2 Menu Map







3.2 Menu Map







3.2 Menu Map







3.2 Menu Map








3.2 Menu Map







3.2 Menu Map






3.2 Menu Map



3.3 Functional Description

3.3 Functional Description

When modulation analysis hardware and software are installed, the following menus are assigned to the **TRANSIENT** key.



3.3.1 Switching between Communication Systems

This section describes how to switch the communication systems. The analyzer must be set to the SPA mode to switch between the communication systems.

1. Press the **POWER** key to enter the SPA mode.
2. Press **CONFIG**.
3. Press *more 1/2*.
If there are other communication systems installed, with which this instrument can analyze, "Comm.System" is displayed in the soft menu. Press **Comm.System**. Select the communication system you wish using the data knob, and press the knob (or **ENTR**).




Figure 3-1 Dialog Box Used for the Communication Systems

4. When the data knob (or **ENTR**) is pressed, the message "LOADING" is displayed. After the message disappears, the switchover to another system is complete.
5. Press the **TRANSIENT** key to confirm that the menu has been changed.

NOTE: *After the communication system has been switched, the parameters previously set for the former communication system will be cleared.*

If necessary, save the old parameters, before switching the communication system to another.

1. To save the parameters, press **SHIFT** and **RCL**.
2. Set the **SAVE FILE** number and press **Save**.

3.3 Functional Description

3.3.2 T-Domain

This function carries out a measurement according to the standard using the zero span of the spectrum analyzer. Measurement items include power, ON/OFF ratio of a burst signal, and spurious measurements in the time domain with a specified frequency.

In the T-Domain measurement, the setting for the RBW, VBW, Sweep Time, or Detector is saved when exiting from each measurement and recalled when entering each measurement again. To return the setting to the value specified by the standard, press *Config* and *Set to STD*.

3.3.2.1 Power (T-Domain)

This is a function to measure power in the time domain (zero span).

There are two Pass/Fail judgment functions: a judgment function for the template and a judgment function for power.

NOTE: The RBW must be set wider than the modulation band.

Auto Level Set

Adjusts the internal reference level to an optimum value in accordance with the measurement signal. Level adjustment is carried out only when this key is pressed.

NOTE: The signal level must remain constant while Auto Level Set is being carried out.

Trigger Setup

Sets a trigger.




Figure 3-2 Trigger Setup Dialog Box

Trigger Source

Selects a trigger.

FREERUN:

Captures the signal using internal timing.

VIDEO: Triggers the signal using the video signal.

IF: Triggers the signal using the IF signal (approximately 6 MHz band).

EXT: Triggers the signal using the external signal, which is input from the EXT TRIG terminal on the rear panel.

<i>Slope</i>	Selects the edge when triggering. +: Triggers at the leading edge. -: Triggers at the trailing edge.
<i>Trigger Level</i>	Sets the level to trigger.
<i>Trigger Position</i>	Sets the trigger position where it is displayed on the screen.
<i>Delay Time</i>	Sets a delay time from the time a trigger signal is detected to the time the signal is captured.
<hr/> <i>NOTE: When Delay Time is a negative value, signals before the trigger can be captured.</i> <hr/>	
<i>Window Setup</i>	Sets the window used for power measurement.
<i>Window ON/OFF</i>	Displays a window showing the range for power measurement. When OFF is set, the power measurement range covers all points on the display screen.
<i>Set to STD</i>	Sets the window specified by the communication standard.
<i>Window Position</i>	Sets the position of the window.
<i>Window Width</i>	Sets the width of the window.
<i>Template</i>	Sets the template.
<i>Template ON/OFF</i>	Sets to display the template and to toggles the Pass/Fail judgment function on or off.
<i>Shift X</i>	Sets the amount of template movement in the X-axis direction.
<i>Shift Y</i>	Sets the amount of template movement in the Y-axis direction.
<i>Template Edit</i>	Edits the template.
<i>Template UP/LOW</i>	Selects the upper template or the lower template.
<i>Copy from STD</i>	Copies the template specified by the communication standard.
<i>Insert Line</i>	Inserts a line.
<i>Delete Line</i>	Deletes a line.
<i>Sort</i>	Sorts template data in ascending order.
<i>Table Init</i>	Initializes the table.

3.3 Functional Description

Y Scale [dB/div] 10/5/2

Switches the display screen scale to 10, 5 or 2 dB/div.

Average Times ON/OFF

Sets the averaging count.
 Performs averaging of both display screen and power at the same time.
 (This is because a large error results when calculating power from the averaged display screen, since the display screen is logarithmically compressed.)

Config

Parameter Setup

Sets the method of measurement, edits the template, and so forth.




Figure 3-3 Parameter Setup Dialog Box

Detector

NORMAL/POSI/NEGA/SAMPLE Sets the detector.

Display Unit

dBm/W/dBµV Sets the display unit of power.

Template Couple to Power

Displays the template that is connected to the measured power.

ON: Displays the template that is connected to the measured power.
 On the template edit screen, set the template level to the portion linked with the power value set to 0 dB.

OFF: Displays the template regarding the Y-axis value edited by the template as an absolute value.

Template Limit

If the absolute value of the template is smaller than this value when Template Couple to Power is set to ON, clip the template at this value.

Judgment

Sets ON/OFF for Pass/Fail judgments.

Upper Limit

Enters the upper limit value of power.

Lower Limit

Enters the lower limit value of power.

Set to STD

Returns measurement parameters to the values specified by the communication standard.

3.3.2.2 ON/OFF Ratio

Measures the power during the burst-on period and the one during the burst-off period, and calculate the ratio of the powers.

Auto Level Set

Adjusts the internal reference level to an optimum value in accordance with the measurement signal. Level adjustment is carried out only when this key is pressed.

NOTE: *The signal level must remain constant while Auto Level Set is being carried out.*

Trigger Setup

Sets a trigger.

Trigger Setup	
Trigger Source :	<input type="radio"/> FREE RUN <input type="radio"/> VIDEO <input checked="" type="radio"/> IF <input type="radio"/> EXT
Slope :	<input checked="" type="radio"/> + <input type="radio"/> -
Trigger Level :	<input type="text" value="30 %"/>
Trigger Position :	<input type="text" value="8 %"/>
Delay Time :	<input type="text" value="0.000 ns"/>

Figure 3-4 Trigger Setup Dialog Box

Trigger Source

Selects a trigger.

FREERUN:

Captures the signal using internal timing.

VIDEO: Triggers the signal using the video signal.

IF: Triggers the signal using the IF signal (approximately 6 MHz band).

EXT: Triggers the signal using the external signal, which is input from the EXT TRIG terminal on the rear panel.

Slope

Selects the edge when triggering.

+: Triggers at the leading edge.

-: Triggers at the trailing edge.

Trigger Level

Sets the level to trigger.

Trigger Position

Sets where the trigger position is displayed on the screen.

Delay Time

Sets a delay time from the time a trigger signal is detected to the time the signal is captured.

NOTE: *When Delay Time is a negative value, signals before the trigger can be captured.*

3.3 Functional Description

Window Setup	Sets the burst ON and OFF periods.
Window ON/OFF	Displays a window showing the range for power measurement.
Set to STD	Sets the value that is specified by or complies with the communication standard.
ON Position	Sets the desired position during the burst-on period.
ON Width	Sets the desired width during the burst-on period.
OFF Position	Sets the position during the burst-off period.
OFF Width	Sets the width during the burst-off period.
Y Scale [dB/div] 10/5/2	Switches the display screen scale to 10, 5 or 2 dB/div.
Average Times ON/OFF	Sets the averaging count.
Config	
Parameter Setup	Sets the measurement parameters.




Figure 3-5 Parameter Setup Dialog Box

Detector	NORMAL/POSI/NEGA/SAMPLE Selects the detector.
Display Unit	dBm/W/dBµV Sets the display unit of power.

NOTE: The ON/OFF ratio is displayed in units of dB (fixed).

Judgment	Sets ON/OFF of the Pass/Fail judgment for the ON/OFF ratio.
Upper Limit	Enters the upper limit value.

Set to STD Sets measurement parameters to the values specified by the communication standard.

3.3.2.3 Spurious (T-Domain)

This function measures power (or peak power) according to the frequency specified in the table by sweeping in the zero span mode.

Auto Level Set

Adjusts the internal reference level to an optimum value in accordance with the measurement signal. Level adjustment is carried out only when this key is pressed.

NOTE: The signal level must remain constant while Auto Level Set is being carried out.

Trigger Setup

Sets a trigger.




Figure 3-6 Trigger Setup Dialog Box

Trigger Source

Selects a trigger.

FREERUN:

Captures the signal using internal timing.

IF: Triggers the signal using the IF signal (approximately 6 MHz band).

EXT: Triggers the signal using the external signal, which is input from the EXT TRIG terminal on the rear panel.

Slope

Selects the edge when triggering.

+: Triggers at the leading edge.

-: Triggers at the trailing edge.

Trigger Level

Sets the level to trigger.

Trigger Position

Sets where the trigger position is displayed on the screen.

Delay Time

Sets a delay time from the time a trigger signal is detected to the time the signal is captured.

NOTE: When Delay Time is a negative value, signals before the trigger can be captured.

Table No. 1/2/3

Selects the measurement table.

Load Table

Loads the measurement table.

3.3 Functional Description

Table Edit	Edits the measurement table.
Table No. 1/2/3	Selects the table to be edited.
Load Table	Loads the measurement table.
Save Table	Saves the measurement table.
Insert Line	Inserts additional frequency data before the selected frequency number.
Delete Line	Deletes the selected line.
Table Init	Initializes the table.
Average Times ON/OFF	Sets the averaging count. Max Hold is set when the detector is set to POSI.
Config	
Parameter Setup	Sets measurement conditions.




Figure 3-7 Parameter Setup Dialog Box

Detector	NORMAL/POSI/NEGA/SAMPLE Sets the detector.
Result	PEAK/RMS Sets whether to display the result using average power or peak power.
Peak MKR Y Delta	Sets the Y delta of the peak marker.
Multiplier	Multiplies the measurement result by the set value, then displays the resultant value.
Display Unit	dBm/W/dBµV Sets the display units.
Judgment	Sets ON/OFF of the Pass/Fail judgment for the limit value.
Preselector	Sets the preselector.

NOTE: This selection is displayed on R3267 only.

1.6G: Used to measure harmonics of more than 1.6 GHz or spurious signals when the carrier frequency is lower than 1.6 GHz.

3.6G: Used to set this parameter for cases other than that above.

Cont Auto Level The auto ranging operation can be performed only within the frequency range where the preselector of the spectrum analyzer attenuates signals.

The dynamic range varies depending on the instrument and preselector settings.

This function runs only when ABS is selected in Freq. Type.

ON: Measures spurious signals after the auto ranging operation.

OFF: Measures spurious signals without the auto ranging operation.

Set to Default

Returns the set value to the default.

3.3 Functional Description

3.3.3 F-Domain

This function performs measurements according to the communication standard using the spectrum analyzer's sweep measurement method. Measurement items include power, occupied bandwidth, ACP Due To Switching, ACP Due to Modulation, Inband Spurious, and Outband Spurious measurements in the frequency domain.

In F-Domain measurement, the setting for the RBW, VBW, Sweep Time, or Detector is saved when exiting each measurement and recalled when entering each measurement again. To return the setting to the value specified by the standard, press *Config* and *Set to STD*.

3.3.3.1 Power (F-Domain)

This function measures power in the frequency domain using the spectrum analyzer.

Auto Level Set

Adjusts the internal reference level to an optimum value in accordance with the measurement signal. Level adjustment is carried out only when this key is pressed.

NOTE: The signal level must remain constant while Auto Level Set is being carried out.

Gate Setup

Sets the gated sweep. This setting is required when the input signal is a bursted signal and Sample Detector is used.

Trigger Setup

Sets a trigger.




Figure 3-8 Trigger Setup Dialog Box

Trigger Source

Selects a trigger

FREERUN:

Captures the signal using internal timing.

VIDEO: Triggers the signal using the video signal (displayed signal).

IF: Triggers the signal using the IF signal (approximately 6 MHz band).

EXT: Triggers the signal using the external signal, which is input from the EXT TRIG terminal on the rear panel.

<i>Slope</i>	Selects the edge when triggering. +: Triggers at the leading edge. -: Triggers at the trailing edge.
<i>Trigger Level</i>	Sets the level to trigger.
<i>Trigger Position</i>	Sets where the trigger position is displayed on the screen.
<i>Delay Time</i>	Sets a delay time from the time a trigger signal is detected to the time the signal is captured.

NOTE: When Delay Time is a negative value, signals before the trigger can be captured.

Gate Source

Trigger Sets Trigger Source specified by Trigger Setup as Gate Source.

NOTE: When Trigger Source is set to IF and SPAN is set to a frequency higher than 6 MHz, the sweeping seems to be stopped, because the IF trigger bandwidth is approximately 6 MHz and the gate trigger is failing.

EXT Gate Performs the gated sweep using the gate signal input from the EXT GATE terminal on the rear panel.

Gate Setup Sets the gated sweep range when Trigger is selected for Gate Source.

Set to STD Sets the gate position and width to the values specified by the communication standard.

Gate Position Sets the gate position.

Gate Width Sets the gate width.

Gated Sweep ON/OFF Starts the gated sweep.

Detector NORMAL/POSI/NEGA/SAMPLE Selects the detector.




Figure 3-9 Detector Dialog Box

3.3 Functional Description

Window Setup	Sets the frequency range used for power measurement.
Window ON/OFF	Sets the window to ON or OFF. When the window is set to OFF, the power measurement range becomes a sweep band.
Set to STD	Sets the value determined by the communication standard.
Window Position	Sets the position of the window.
Window Width	Sets the width of the window.
Y Scale [dB/div] 10/5/2	Sets the display scale.
Average Times ON/OFF	Sets the averaging count.
Config	
Parameter Setup	Sets measurement conditions.




Figure 3-10 Parameter Setup Dialog Box

Detector	NORMAL/POSI/NEGA/SAMPLE Selects the detector.
Gated Sweep	Sets the gated sweep to ON or OFF.
Display Unit	dBm/W/dBμV Selects the display unit.
Judgment	Sets ON/OFF of the Pass/Fail judgment for measured power.
Upper Limit	Sets the upper limit for Pass/Fail judgment.
Lower Limit	Sets the lower limit for Pass/Fail judgment.
Set to STD	Sets the measurement parameters to the values specified by the communication standard.

3.3.3.2 OBW

This function measures an occupied bandwidth.

Auto Level Set

Adjusts the internal reference level to an optimum value in accordance with the measurement signal. Level adjustment is carried out only when this key is pressed.

NOTE: The signal level must remain constant while Auto Level Set is being carried out.

OBW%

Sets the frequency, including the percentage of the total power as an occupied bandwidth, when calculating the occupied bandwidth.

Average Times ON/OFF

Sets the averaging count.

Config

Parameter Setup

Sets measurement conditions and so on.




Figure 3-11 Parameter Setup Dialog Box

Detector

NORMAL/POSI/NEGA/SAMPLE Selects the detector.

Judgment

Sets ON/OFF of the Pass/Fail judgment for the occupied bandwidth.

Upper Limit

Sets the upper limit for Pass/Fail judgment.

Lower Limit

Sets the lower limit for Pass/Fail judgment.

Set to STD

Sets the measurement parameters to the values specified by the communication standard.

3.3 Functional Description

3.3.3.3 Due to Transient

This function measures the spectrum, including the rise and fall times of the burst.

Auto Level Set Adjusts the internal reference level to an optimum value in accordance with the measurement signal. Level adjustment is carried out only when this key is pressed.

NOTE: The signal level must remain constant while Auto Level Set is being carried out.

Template Sets and edits the template.

Template ON/OFF Sets ON/OFF of the template display. When Template is set to ON, the Pass/Fail judgment for the template is displayed under the sweep screen.

Shift X Shifts the set template in the frequency direction (X-axis).

Shift Y Shifts the set template in the level direction (Y-axis).

Margin ΔX ON/OFF Magnifies the template in the X-axis direction with a set template frequency 0 as the center.

Template Edit Opens the template edit menu.

Copy from STD Copies the template of the communication standard.

Insert Line Inserts a line before the selected line.

Delete Line Deletes the selected line.

Sort Sorts the tables in order of frequency.

Table Init Initializes the table.

Marker Edit Sets the measurement frequency (frequency offset) and measurement band.

Copy from STD Sets to the parameters specified by the communication standard.

Insert Line Inserts a line before the selected line.

Delete Line Deletes the selected line.

Sort Sorts data in order of frequency.

Table Init Initializes the table.

Average Times ON/OFF Sets the averaging count.

Config

Parameter Setup

Parameter Setup	
Freq. Setting :	START&STOP SPAN
Detector :	NORMAL POSI NEGA SAMPLE
Result :	MARKER RELATIVE ABS POWER
Ref Power :	REF MARKER MODULATION
Display Unit :	dBm W dBμV
Template Couple to Power :	ON OFF
Template Limit :	-60.00 dBm
Judgment :	ON OFF
Symbol Rate 1/T :	21.000 kHz
Rolloff Factor :	0.50

Figure 3-12 Parameter Setup Dialog Box

Freq. Setting

START&STOP/SPAN

Selects the measurement mode.

Detector

NORMAL/POSI/NEGA/SAMPLE

Selects the detector.

Result

MARKER:

Displays the marker read value. The position of the marker is set by Marker Edit.

RELATIVE:

Displays the marker read value using a relative value.

ABS POWER:

Converts the value displayed by RELATIVE into the absolute value using carrier power and displays it.

Ref Power

When RELATIVE is selected for Result, this selects which relative value to use to display the marker read value.

REF MARKER:

Displays a relative value to Ref Marker set by Marker Edit.

MODULATION:

Display a relative value to the measurement result of Tx power in Modulation.

Display Unit

dBm/W/dBμV Specifies the unit of the result displayed.

NOTE: When RELATIVE is selected for Result, the unit is dB.

3.3 Functional Description

Template Couple to Power

Sets whether to raise or lower the template with the power set by Ref Power.

Template Limit

If the absolute value of the template is smaller than this value when Template Couple to Power is set to ON, clip the template at this value.

Judgment

Makes the Pass/fail judgment for the limit value set by Marker edit. The Pass/Fail judgment result is displayed under the display screen together with the marker list.

Symbol Rate 1/T

Sets the symbol rate for the Root Nyquist filter.

Rolloff Factor

Sets the rolloff factor for the Root Nyquist filter.

Set to STD

Returns the measurement parameters to the values specified by the standard.

3.3.3.4 Due to Modulation

Measure the modulation spectrum excluding the rise and fall of the burst.

Auto Level Set

Adjusts the internal reference level to an optimum value in accordance with the measurement signal. Level adjustment is carried out only when this key is pressed.

NOTE: The signal level must remain constant while Auto Level Set is being carried out.

Gate Setup

Sets the gated sweep.

Trigger Setup

Sets a trigger.




Figure 3-13 Trigger Setup Dialog Box

Trigger Source

Selects a trigger.

FREERUN:

Captures the signal using internal timing.

VIDEO: Triggers the signal using the video signal.

IF: Triggers the signal using the IF signal (approximately 6 MHz band).

EXT: Triggers the signal using the external signal, which is input from the EXT TRIG terminal on the rear panel.

Slope

Selects the edge when triggering.

+: Triggers at the leading edge.

-: Triggers at the trailing edge.

Trigger Level

Sets the level to trigger.

Trigger Position

Sets where the trigger position is displayed on the screen.

Delay Time

Sets a delay time from the time a trigger signal is detected to the time the signal is captured.

NOTE: When Delay Time is a negative value, signals before the trigger can be captured.

3.3 Functional Description

Gate Source

Trigger Sets Trigger Source specified by Trigger Setup as Gate Source.

NOTE: When Trigger Source is set to IF and SPAN is set to a frequency higher than 6 MHz, the sweeping seems to be stopped, because the IF trigger bandwidth is approximately 6 MHz and the gate trigger is failing.

EXT Gate Performs the gated sweep using the gate signal input from the EXT Gate terminal on the rear panel.

Gate Setup Sets the gated sweep range when Trigger is selected for Gate Source.

Set to STD Sets the gate position and width to the values specified by the communication standard.

Gate Position Sets the gate position.

Gate Width Sets the gate width.

Gated Sweep ON/OFF Starts the gated sweep.

Detector NORMAL/POSI/NEGA/SAMPLE Selects the detector.




Figure 3-14 Detector Dialog Box

Template Sets and edits the template.

Template ON/OFF Sets the template display to ON or OFF. When Template is set to ON, the Pass/Fail judgment for the template is displayed under the sweep screen.

Shift X Shifts the set template in the frequency direction (X-axis).

Shift Y Shifts the set template in the level direction (Y-axis).

Margin ΔX ON/OFF Magnifies the template in the X-axis direction with a set template frequency 0 as the center.

Template Edit

Copy from STD	Copies the template specified by the communication standard.
Insert Line	Inserts a line before the selected line.
Delete Line	Deletes the selected line.
Sort	Sorts the tables in frequency order.
Table Init	Initializes the table.

Marker Edit

Copy from STD	Sets to the parameters specified by the communication standard.
Insert Line	Inserts a line before the selected line.
Delete Line	Deletes the selected line.
Sort	Sorts data in order of frequency.
Table Init	Initializes the table.

Average Times ON/OFF Sets the averaging count.

Config**Parameter Setup**

Parameter Setup	
Freq. Setting :	<input type="radio"/> START&STOP <input checked="" type="radio"/> SPAN
Detector :	<input type="radio"/> NORMAL <input type="radio"/> POSI <input type="radio"/> NEGA <input checked="" type="radio"/> SAMPLE
Result :	<input type="radio"/> MARKER <input type="radio"/> RELATIVE <input checked="" type="radio"/> ABS POWER
Ref Power :	<input type="radio"/> REF MARKER <input checked="" type="radio"/> MODULATION
Display Unit :	<input type="radio"/> dBm <input type="radio"/> V <input checked="" type="radio"/> dBμV
Template	
Couple to Power :	<input type="radio"/> ON <input checked="" type="radio"/> OFF
Template Limit :	<input type="text" value="-200.00 dBm"/>
Judgment :	<input type="radio"/> ON <input checked="" type="radio"/> OFF
Symbol Rate 1/T :	<input type="text" value="21.000 kHz"/>
RollOff Factor :	<input type="text" value="0.50"/>

Figure 3-15 Parameter Setup Dialog Box

Freq. Setting	START&STOP/SPAN Selects the measurement mode.
Detector	NORMAL/POSI/NEGA/SAMPLE Selects the detector.

3.3 Functional Description

Result	<p>Specifies how to display the results.</p> <p>MARKER: Displays the marker read value. The position of the marker is set by Marker Edit.</p> <p>RELATIVE: Displays the marker read value using a relative value.</p> <p>ABS POWER: Converts the value displayed by RELATIVE into the absolute value using carrier power and displays it.</p>
Ref Power	<p>When RELATIVE is selected for Result, this selects which relative value to use to display the marker read value.</p> <p>REF MARKER: Displays a relative value to Ref Marker set by Marker Edit.</p> <p>MODULATION: Displays a relative value to the measurement result of Tx power in Modulation.</p>
Display Unit	<p>dBm/W/dBμV Selects the display unit.</p>

NOTE: When RELATIVE is selected for Result, the unit is dB.

Template Couple to Power	<p>Sets whether or not to raise or lower the template with the power set by Ref Power.</p>
Template Limit	<p>If the absolute value of the template is smaller than this value when Template Couple to Power is set to ON, clip the template at this value.</p>
Judgment	<p>Makes the Pass/Fail judgment for the limit value set by Marker edit. The Pass/Fail judgment result is displayed under the display screen together with the marker list.</p>
Symbol Rate 1/T	<p>Sets the symbol rate for the Root Nyquist filter.</p>
Rolloff Factor	<p>Sets the rolloff factor for the Root Nyquist filter.</p>
Set to STD	<p>Returns the measurement parameters to the values specified by the standard.</p>

3.3.3.5 Inband Spurious

This function searches for a peak by sweeping the set frequency.

Auto Level Set

Adjusts the internal reference level to an optimum value in accordance with the measurement signal. Level adjustment is carried out only when this key is pressed.

NOTE: The signal level must remain constant while Auto Level Set is being carried out.

Template

Template ON/OFF

Sets the template display to ON or OFF. When Template is set to ON, the Pass/Fail judgment for the template is displayed under the sweep screen.

Shift X

Shifts the set template in the frequency direction (X-axis).

Shift Y

Shifts the set template in the level direction (Y-axis).

Margin ΔX ON/OFF

Magnifies the template in the X-axis direction with a set template frequency 0 as the center.

Template Edit

Copy from STD

Copies the template specified by the communication standard.

Insert Line

Inserts a line before the selected line.

Delete Line

Deletes the selected line.

Sort

Sorts the tables in frequency order.

Table Init

Initializes the table.

Marker Edit

Copy from STD

Sets the measurement parameters specified by the communication standard.

Insert Line

Inserts a line before the selected line.

Delete Line

Deletes the selected line.

Sort

Sorts data in order of frequency.

Table Init

Initializes the table.

3.3 Functional Description

Average Times ON/OFF

Sets the averaging count.

Config

Parameter Setup




Figure 3-16 Parameter Setup Dialog Box

Freq. Setting

START&STOP/SPAN Selects the measurement mode.

Detector

NORMAL/POSTI/NEGA/SAMPLE Selects the detector.

Peak MKR Y Delta

Sets the Y delta of the peak marker.

Result

Specifies how to display the results.

MARKER:

Displays the marker read value. The position of the marker is set by Marker Edit.

RELATIVE:

Displays the marker read value using a relative value.

ABS POWER:

Converts the value displayed by RELATIVE into the absolute value using carrier power and displays it.

Ref Power

When RELATIVE is selected for Result, this selects which relative value is used to display the marker read value.

REF MARKER:

Displays a relative value to Ref Marker set by Marker Edit.

MODULATION:

Displays a relative value to the measurement result of Tx power in Modulation.

Display Unit dBm/W/dB μ V Selects the display unit.

NOTE: When RELATIVE is selected for Result, the unit is dB.

Template Couple to Power

Sets whether or not to raise or lower the template with the power set by Ref Power.

Template Limit

If the absolute value of the template is smaller than this value when Template Couple to Power is set to ON, clip the template at this value.

Judgment

Makes the Pass/Fail judgment for the limit value set by Marker edit. The Pass/Fail judgment result is displayed under the display screen together with the marker list.

Set to STD

Returns the measurement parameters to the values specified by the standard.

3.3.3.6 Outband Spurious

This function searches for a peak by sweeping the frequency according to the table.

Auto Level Set

Adjusts the internal reference level to an optimum value in accordance with the measurement signal. Level adjustment is carried out only when this key is pressed.

NOTE: The signal level must remain constant while Auto Level Set is being carried out.

Table No. 1/2/3

Selects the table number.

Load Table

Loads the table.

Table Edit

Edits the table.

Table No. 1/2/3

Selects the table number.

Load Table

Loads the table.

Save Table

Saves the table.

Insert Line

Inserts a line before the selected line.

Delete Line

Deletes the selected line.

Table Init

Initializes the table.

3.3 Functional Description

Average Times ON/OFF Sets the averaging count.

Config

Parameter Setup Sets measurement parameters.

Parameter Setup				
Detector :	NORMAL	POSI	NEGA	SAMPLE
Peak MKR Y Delta :	1.0 div			
Display Unit :	dBm	W	dBμV	
Judgment :	ON	OFF		
Preselector :	1.6G	3.6G		

Figure 3-17 Parameter Setup Dialog Box

Detector NORMAL/POSI/NEGA/SAMPLE Sets the detector.

Peak MKR Y Delta Sets the Y delta of a peak marker.

Display Unit dBm/W/dBμV Sets the display unit.

Judgment Makes the Pass/Fail judgment using the limit values set by Table Edit.

Preselector Sets the preselector.

NOTE: This selection is displayed on R3267 only.

1.6G: Used to measure harmonics of more than 1.6 GHz or spurious signals when the carrier frequency is lower than 1.6 GHz.

3.6G: Used to set this parameter for cases other than that above.

Set to Default Returns the set value to the default.

3.3.4 Modulation

This function performs a modulation analysis with DSP.

3.3.4.1 Power

This function is used when making power measurements (Tx power, Power vs Time and ACP).

Tx Power

Measures an average power within a burst (Burst Power) and an average power within a frame (Frame Power).

When Meas mode in STD Setup is set to BURST, Frame Power indicates an average power measured on condition that there is only one burst in a frame.

NOTE: When Meas mode in STD Setup is set to BURST, the average power measured by Frame Power is incorrect if two or more bursts exist in a frame.

Auto Level Set

Adjusts the internal reference level to an optimum value in accordance with the measurement signal. Level adjustment is carried out only when this key is pressed.

NOTE: The signal level must remain constant while Auto Level Set is being carried out.

Parameter Setup

Sets parameters used for measuring.

Figure 3-18 Parameter Setup Dialog Box

Trigger Source

Selects a mode of controlling the measurement timing of the burst signal and others.

FREERUN:

Measures the signal using the internal measurement timing.

IF: Captures data in sync with the internal IF signal.

EXT: Captures data in sync with the signal input from the EXT TRIG terminal on the rear panel.

3.3 Functional Description

<i>Burst Search</i>	Searches for the rising position of the captured signal and measure the signal using that position as a trigger.
<i>Search Level</i>	Sets the level at which the rising position of a burst is searched.
<i>Trigger Slope</i>	Sets the edge of the trigger. + : Triggers at the leading edge. - : Triggers at the trailing edge.
<i>Trigger Level</i>	Sets the level at which synchronization is taken using the IF trigger.
<i>Slot Number</i>	Sets the slot number. This set value automatically set Trigger Delay to the times of an integral multiple of one slot.
<i>Trigger Delay</i>	Sets the delay time from the trigger.
<i>Average Times ON/OFF</i>	Sets the averaging count.
<i>Power vs Time</i>	Performs a time domain waveform analysis. The rise and fall times of the burst signal can be measured with the template.
<i>Auto Level Set</i>	Adjusts the internal reference level to an optimum value in accordance with the measurement signal. Level adjustment is carried out only when this key is pressed.

NOTE: The signal level must remain constant while Auto Level Set is being carried out.

Template Entry Registers the template.




Figure 3-19 Template settings

- User Template1** Registers template 1.
- User Template2** Registers template 2.
- User Template3** Registers template 3.
- STD Template** Registers the template specified by the communication standard.

OffLevUnit dBm/dB

Sets the unit of the carrier offset level in the template.

dBm: Set the unit to Absolute.

dB: Sets the unit to relative to the average power during the burst ON period.

Meas Mode NORM/HIGH

Selects the measurement mode.

NORM: Usually measurement is performed in this mode.

HIGH: Performs measurement with high dynamic ranges.

NOTE: If the signal have the multiple bursts in a frame, the measurement cannot be taken in the HIGH mode.

Y [dB/div] 20/10/5

Sets the vertical axis scale.

Parameter Setup

Sets parameters used for measurement.




Figure 3-20 Parameter Setup Dialog Box

Trigger Source

Selects a mode of controlling the measurement timing of the burst signal and others.

FREERUN:

Measures the signal using internal measurement timing.

IF: Captures data in sync with the internal IF signal.

EXT: Captures data in sync with the signal input from the EXT TRIG terminal on the rear panel.

Burst Search

Searches for the rising position of the captured signal and measure the signal using that position as a trigger.

3.3 Functional Description

<i>Search Level</i>	Sets the level at which the rising position of a burst is searched.
<i>Trigger Slope</i>	Sets the edge of the trigger. +: Triggers at the leading edge. -: Triggers at the trailing edge.
<i>Trigger Level</i>	Sets the level at which synchronization is taken using the IF trigger.
<i>Slot Number</i>	Sets the slot number. This set value automatically set Trigger Delay to the multiples of one slot.
<i>Trigger Delay</i>	Sets the delay time from the trigger.
<i>Average Times ON/OFF</i>	Sets the averaging count.
<i>ACP</i>	This function measures the adjacent channel leakage power including the leading and trailing edges using the spectrum analyzer's sweep measurement.
<i>Auto Level Set</i>	Adjusts the internal reference level to an optimum value in accordance with the measurement signal. Level adjustment is carried out only when this key is pressed.

NOTE: The signal level must remain constant while Auto Level Set is being carried out.

Parameter Setup Sets the parameter to be used for the measurement.

Parameter Setup	
Trigger Source :	<input checked="" type="radio"/> FREE RUN <input type="radio"/> IF <input type="radio"/> EXT
Burst Search :	<input checked="" type="radio"/> ON <input type="radio"/> OFF
Search Level :	<input type="text" value="-25.0 dB"/>
Trigger Slope :	<input checked="" type="radio"/> + <input type="radio"/> -
Trigger Level :	<input type="text" value="30 %"/>
Slot Number :	<input type="text" value="0"/>
Trigger Delay :	<input type="text" value="0.00 ms"/>
ACP Unit :	<input checked="" type="radio"/> dB <input type="radio"/> dBm <input type="radio"/> W
Ref. Level Adjust :	<input checked="" type="radio"/> ON <input type="radio"/> OFF
Tx Power Average :	<input checked="" type="radio"/> ON <input type="radio"/> OFF
Average Times :	<input type="text" value="2"/>
Unit :	<input checked="" type="radio"/> dBm <input type="radio"/> W
Sweep Time :	<input checked="" type="radio"/> DEFAULT <input type="radio"/> USER DEF
User Define :	<input type="text" value="20 ms"/>

Figure 3-21 Parameter Setup Dialog Box

Trigger Source	Selects a mode of synchronization where timing signals such as burst signal are measured. FREERUN: Measures the signal using internal measurement timing. IF: Captures data in sync with the internal IF signal. EXT: Captures data in sync with the signal input from the EXT TRIG terminal on the rear panel.
Burst Search	Searches for the rising position of the captured signal and measures the signal using the position as the trigger.
Search Level	Sets the level at which the rising position of a burst is searched.
Trigger Slope	Sets the edge of the trigger. +: Triggers at the leading edge. -: Triggers at the trailing edge.
Trigger Level	Sets the level at which the signal is brought into sync with the IF trigger.
Slot Number	Sets the number of slots. This value automatically set Trigger Delay to an integral multiple of slot interval.
Trigger Delay	Sets the delay time from the trigger.
ACP Unit	Sets the unit of the ACP. dB: Displays a value relative to the carrier power. dBm: Displays a value in dBm. W: Displays a value in W.
Ref. Level Adjust	Measures Tx Power and sets the reference level to an optimum value. When set to ON, ACP and Tx Power are measured at the same time. ON: Sets the reference level to an optimum value. OFF: The reference level stays unchanged.

NOTE: To take measurements in other menus after you have taken measurements in the current menu with Ref. Level Adjust set to OFF, perform AUTO Level Set in advance.

Tx Power Average	Toggles the Tx Power Averaging function on or off. ON: Performs the Tx Power averaging. OFF: Does not perform the Tx Power averaging.
-------------------------	---

3.3 Functional Description

<i>Average Times</i>	Sets the Tx Power averaging count.
<i>Unit</i>	Sets the unit of Tx Power. dBm: Displays the power in dBm. W: Displays the power in W.
<i>Sweep Time</i>	Sets the sweep time for the ACP measurement. DEFAULT: Sets the sweep time to the default. USER DEF: Sets the sweep time to the desired value.
<i>User Define</i>	When the USER DEF is selected in the Sweep Time setting, enter the desired sweep time.

3.3.4.2 OBW

This function measures the occupied bandwidth (OBW).

CAUTION: *In the STD Setup menu, the analyzer does not make a measurement in sync with SYNC WORD or UNIQUE WORD, even if Sync type for the PDC/IS-136 is set to SYNC WORD or Sync type for the PHS is set to UNIQUE WORD.*

Auto Level Set Adjusts the internal reference level to an optimum value in accordance with the measurement signal. Level adjustment is carried out only when this key is pressed.

NOTE: *The signal level must remain constant while Auto Level Set is being carried out.*

Parameter Setup Sets parameters used for measurement.

Parameter Setup		
Trigger Source :	<input type="radio"/> FREE RUN	<input checked="" type="radio"/> IF
	<input type="radio"/> EXT	
Burst Search :	<input checked="" type="radio"/> ON	<input type="radio"/> OFF
Search Level :	<input type="text" value="-25.0 dB"/>	
Trigger Slope :	<input checked="" type="radio"/> +	<input type="radio"/> -
Trigger Level :	<input type="text" value="30 %"/>	
Slot Number :	<input type="text" value="0"/>	
Trigger Delay :	<input type="text" value="0.00 ms"/>	

Figure 3-22 Parameter Setup Dialog Box

Trigger Source	Selects a mode of controlling the measurement timing of the burst signal and others. FREERUN: Measures the signal using the internal measurement timing. IF: Captures data in sync with the internal IF signal. EXT: Captures data in sync with the signal input from the EXT TRIG terminal on the rear panel.
Burst Search	Searches for the rising position of the captured signal and measure the signal using that position as a trigger.
Search Level	Sets the level at which the rising position of a burst is searched.
Trigger Slope	Sets the edge of the trigger. +: Triggers at the leading edge. -: Triggers at the trailing edge.
Trigger Level	Sets the level at which synchronization is taken using the IF trigger.
Slot Number	Sets the slot number. This set value automatically set Trigger Delay to the times of an integral multiple of one slot.
Trigger Delay	Sets the delay time from the trigger.
Average Times ON/OFF	Sets the averaging count.

3.3.4.3 Modulation Accuracy

This function measures the modulation accuracy (Frequency Error, Magnitude Error, Phase Error, Modulation Accuracy, etc.).

Auto Level Set Adjusts the internal reference level to an optimum value in accordance with the measurement signal. Level adjustment is carried out only when this key is pressed.

NOTE: The signal level must remain constant while Auto Level Set is being carried out.

3.3 Functional Description

Graphics

Displays the menu to show graphs.




Figure 3-23 Graph Menu

Select Type

Opens the graphics selection window.

Constellation

Constellation (interpolation)

Constellation (Line)

Constellation (straight-line interpolation)

Constellation (Dot)

Constellation (symbol)

Constellation (Line & Dot)

Constellation (interpolation and symbol)

I EYE Diagram

Eye pattern (in-phase components)

Q EYE Diagram

Eye pattern (quadrature phase components)

I/Q EYE Diagram

Eye pattern (in-phase/quadrature phase components)

Demodulated Data

Demodulated bit data

E.V.M. vs Symbol

The relationship between error vector magnitude and a symbol.

Mag Error vs Symbol

The relationship between a magnitude error and a symbol.

Phase Error vs Symbol

The relationship between a phase error and a symbol.

22.5deg Turn

Turns the graphic data of the EYE Diagram and the constellation by 22.5°.

Parameter Setup

Sets parameters used for measurement.

Figure 3-24 Parameter Setup Dialog Box

Trigger Source

Selects a mode of controlling the measurement timing for the burst signal and others.

FREERUN:

Measures the signal using internal measurement timing.

IF: Captures data in sync with the internal IF signal.

EXT: Captures data in sync with the signal input from the EXT TRIG terminal on the rear panel.

Burst Search

Searches for the rising position of the captured signal and measure the signal using that position as a trigger.

Search Level

Sets the level at which the rising position of a burst is searched.

Trigger Slope

Sets the edge of the trigger.

+: Triggers at the leading edge.

-: Triggers at the trailing edge.

Trigger Level

Sets the level at which synchronization is taken using the IF trigger.

Slot Number

Sets the slot number. This set value automatically set Trigger Delay to the times of an integral multiple of one slot.

Trigger Delay

Sets the delay time from the trigger.

Average Times ON/OFF

Sets the averaging count.

3.3 Functional Description

3.3.4.4 Bit Rate Error

This function measures the transmission rate error. Displays the transmission rate error in units of ppm and bps (Hz).

Auto Level Set

Adjusts the internal reference level to an optimum value in accordance with the measurement signal. Level adjustment is carried out only when this key is pressed.

NOTE: The signal level must remain constant while Auto Level Set is being carried out.

Parameter Setup

Sets parameters used for measurement.




Figure 3-25 Parameter Setup Dialog Box

Trigger Source

Selects a mode of controlling the measurement timing of the burst signal and others.

FREE RUN:

Measures the signal using internal measurement timing.

IF: Captures data in sync with the internal IF signal.

EXT: Captures in sync with the signal input from the EXT TRIG terminal on the rear panel.

Burst Search

Searches for the rising position of the captured signal and measure the signal using that position as a trigger.

Search Level

Sets the level at which the rising position of a burst is searched.

Trigger Slope

Sets the edge of the trigger.

+: Triggers at the leading edge.

-: Triggers at the trailing edge.

<i>Trigger Level</i>	Sets the level at which synchronization is taken using the IF trigger.
<i>Slot Number</i>	Sets the slot number. This set value automatically set Trigger Delay to the times of an integral multiple of one slot.
<i>Trigger Delay</i>	Sets the delay time from the trigger source.
<i>Average Times ON/OFF</i>	Sets the averaging count.

3.3.4.5 ALL Measurement

This function is used to measure the Tx Power, ACP, OBW, Modulation Accuracy and Bit Rate Error in a single operation.

Auto Level Set Sets the reference level to an optimum value according to the signal to be measured. The level is adjusted when this key is pressed.

NOTE: The signal level must remain constant while Auto Level Set is being carried out.

ACP ON/OFF Sets whether or not the ACP is measured.

ON: Measures the ACP.

OFF: Does not measure the ACP.

Bit Rate Error ON/OFF Sets whether or not the Bit Rate Error is measured.

ON: Measures the Bit Rate Error.

OFF: Does not measure the Bit Rate Error.

Parameter Setup Sets parameters used for measurement.




Figure 3-26 Parameter Setup Dialog Box

3.3 Functional Description

<i>Trigger Source</i>	<p>Selects a mode of controlling the measurement timing for the burst signal and others.</p> <p>FREERUN: Measures the signal using internal measurement timing.</p> <p>IF: Captures data in sync with the internal IF signal.</p> <p>EXT: Captures data in sync with the signal input from the EXT TRIG terminal on the rear panel.</p>
<i>Burst Search</i>	<p>Searches for the rising position of the captured signal and measure the signal using that position as a trigger.</p>
<i>Search Level</i>	<p>Sets the level at which the rising position of a burst is searched.</p>
<i>Trigger Slope</i>	<p>Sets the edge of the trigger.</p> <p>+: Triggers at the leading edge.</p> <p>-: Triggers at the trailing edge.</p>
<i>Trigger Level</i>	<p>Sets the level at which synchronization is taken using the IF trigger.</p>
<i>Slot Number</i>	<p>Sets the slot number. This set value automatically set Trigger Delay to the times of an integral multiple of one slot.</p>
<i>Trigger Delay</i>	<p>Sets the delay time from the trigger.</p>
<i>Tx Power Type</i>	<p>Sets the display type of Tx Power.</p> <p>BURST POWER: Displays an average power during the burst ON period.</p> <p>FRAME POWER: Displays an average power during the frame period.</p> <hr/> <p><i>NOTE: The Frame Power is converted from the Burst Power assuming that there is only one burst in the frame period when Meas mode in STD Setup is set to BURST.</i></p> <hr/>
<i>Tx Power Unit</i>	<p>Sets the unit of Tx Power.</p> <p>dBm: Displays a value in dBm.</p> <p>W: Displays a value in W.</p>
<i>ACP Unit</i>	<p>Sets the unit used with the ACP</p> <p>dB: Displays a value relative to the carrier power.</p> <p>dBm: Displays a value in dBm.</p> <p>W: Displays a value in W.</p>

<i>Sweep Time</i>	Sets the sweep time for the ACP measurement. DEFAULT: Sets the sweep time to the default. USER DEF: Sets the sweep time to the desired value.
<i>User Define</i>	When the USER DEF is selected in the Sweep Time setting, enter the desired sweep time.
<i>Bit Rate Error</i>	Sets the unit of the Bit Rate Error. ppm: Displays a value in ppm. bps (Hz): Displays a value in bps (Hz).
<i>Average Times ON/OFF</i>	Sets the averaging count.

NOTE: The averaging is not performed for the ACP measurement.

3.3.4.6 Wave Check

This function is used to display IF or baseband waveforms in the time domain or FFT traces.

Time & FFT This function is used to display IF or baseband waveforms in the time domain or FFT traces. This key is used for verification of input signal.

Auto Level Set Sets the reference level to an optimum value according to the signal to be measured. The level is adjusted when this key is pressed.

NOTE: The signal level must remain constant while Auto Level Set is being carried out.

Select Type Selects the type of graphic display.




Figure 3-27 Select Type Dialog Box

3.3 Functional Description

Parameter Setup

Sets parameters used for measurement.




Figure 3-28 Parameter Setup Dialog Box

Trigger Source Selects a mode of controlling the measurement timing for the burst signal and others.

FREERUN:

Measures the signal using internal measurement timing.

IF: Captures data in sync with the internal IF signal.

EXT: Captures data in sync with the signal input from the EXT TRIG terminal on the rear panel.

Trigger Slope Sets the edge of the trigger.

+: Triggers at the leading edge.

-: Triggers at the trailing edge.

Trigger Level Sets the level at which synchronization is taken using the IF trigger.

Slot Number Sets the slot number. This set value automatically set Trigger Delay to the times of an integral multiple of one slot.

Trigger Delay Sets the delay time from the trigger.

Average Times ON/OFF Sets the averaging count.

Time Displays IF or baseband waveforms in the time domain using the slot length and frame length. This function is used to check the settings used with Trigger Level and Trigger Delay or the input signals used.

Auto Level Set Sets the reference level to an optimum value according to the signal to be measured. The level is adjusted when this key is pressed.

NOTE: The signal level must remain constant while Auto Level Set is being carried out.

Parameter Setup Sets the parameter to be used for the measurement.




Figure 3-29 Parameter Setup Dialog Box

Sweep Time Sets the sweep time when displaying a waveform in the time domain.

SLOT: Displays a waveform within one slot.

FRAME: Displays a waveform within a frame.

Trigger Source Selects a mode of controlling the measurement timing for the burst signal and others.

FREERUN:

Measures the signal using internal measurement timing.

IF: Captures data in sync with the internal IF signal.

EXT: Captures data in sync with the signal input from the EXT TRIG terminal on the rear panel.

Burst Search Searches for the rising position of the captured signal and measure the signal using that position as a trigger.

Search Level Sets the level at which the rising position of a burst is searched.

3.3 Functional Description

<i>Trigger Slope</i>	Sets the edge of the trigger. +: Triggers at the leading edge. -: Triggers at the trailing edge.
<i>Trigger Level</i>	Sets the level at which synchronization is taken using the IF trigger.
<i>Trigger Position</i>	Sets the trigger position where it is displayed on the screen.
<i>Slot Number</i>	Sets the number of slots. This set value automatically set Trigger Delay to an integral multiple of slot interval.
<i>Trigger Delay</i>	Sets the delay time from the trigger.

3.3.5 STD

This function sets parameters used for measurement and the relationship between the channel number and frequency.

3.3.5.1 DC CAL

Compensates for direct current components inside the circuit.

3.3.5.2 Channel Setting

Sets the relationship between the channel number and frequency.

<i>Copy from STD</i>	Sets the relationship between the channel number and frequency specified by the communication standard.
-----------------------------	---

3.3.5.3 STD Setup

Setting the PDC system

STD Measurement Parameter Set	
Type	PDC 800M-1 PDC 800M-2 PDC 800M-3 PDC 1.5G
Link	UPLINK DOWNLINK
Meas Mode	BURST MULTI-BURST CONTINUOUS
Slot Format	CONTROL TRAFFIC VOX
Rate	FULL RATE HALF RATE
Sync Type	SYNC WORD NO SYNC WORD
Sync Word	S1/S7 S2/S8 S3/S9 S4/S10 S5/S11 S6/S12 785B4/CE450
Root Nyquist Filter	ON OFF
Freq Meas Range	NORMAL EXPAND
Filter Mode	WIDE NARROW
Offset Level	0.0 dB
Frequency Input	FREQUENCY CHANNEL
Input	RF BASEBAND (I&Q)
Baseband Input	AC DC
IQ Inverse	NORMAL INVERSE
Cont Auto Level Set	ON OFF

Figure 3-30 STD Measurement Parameter Set Dialog Box

Type

Sets the frequency band.

PDC 800M-1: 800 MHz band 1

PDC 800M-2: 800 MHz band 2

PDC 800M-3: 800 MHz band 3

PDC 1.5G: 1500 MHz band

The above frequency bands are required to calculate the frequency from the channel number.

Link

Sets the direction of the channel.

UPLINK:

Up-link channel

DOWNLINK:

Down-link channel

Meas Mode

Sets the measurement mode.

BURST: Measures one burst in the frame.

MULTI-BURST:

Searches for the desired burst, which contains the target sync word, from the multiple bursts in the frame to make the measurement.

CONTINUOUS:

Measures continuous waves.

3.3 Functional Description

Slot Format	<p>Sets physical channels.</p> <p>CONTROL: Control Physical channel and Packet traffic physical channel</p> <p>TRAFFIC: Traffic physical channel</p> <p>VOX: Transmission signal format during VOX control (traffic channel up-link burst)</p>
Rate	<p>Sets the signal rate.</p> <p>FULL RATE: Sets the signal rate to the full rate.</p> <p>HALF RATE: Sets the signal rate to the half rate.</p>
Sync Type	<p>Sets the sync word synchronization.</p> <p>SYNC WORD: Sets the sync word to obtain synchronization.</p> <p>NO SYNC WORD: Performs measurement without using the sync word.</p>
Sync Word	<p>Selects a Sync Word type.</p>
<hr/> <p>NOTE: In FULL RATE, S1/S7 through S3/S9 can be set. In HALF RATE, S1/S7 through S6/S12 can be set. Synchronization is obtained using either of the two Sync Words. It is possible to measure a signal from the supper frame structure for this reason.</p> <hr/>	
Root Nyquist Filter	<p>Specifies whether or not to apply the Root Nyquist filter.</p> <p>ON: Sets the Root Nyquist filter for measurement.</p> <p>OFF: Performs measurements without using the Root Nyquist filter.</p>
Freq Meas Range	<p>Sets the estimated range of frequency error.</p> <p>NORMAL: Sets this mode when signals exist in the adjacent channels.</p> <p>EXPAND: Expands the estimated range of frequency error.</p>
<hr/> <p>NOTE: When Freq Meas Range is set to EXPAND, signals other than the standard coding test signal or signals including a large number of noise components may sometimes not be measured.</p> <hr/>	

<i>Filter Mode</i>	<p>Sets the band of the internal filter.</p> <p>WIDE: Sets the internal filter to the wide band. This mode is set when measuring Power vs Time and OBW based on the standard.</p> <p>NARROW: Sets the internal filter to the narrow band. This mode is set when signals exist in the adjacent channels.</p> <hr/> <p>NOTE: <i>Filter Mode cannot be set to NARROW when Freq Meas Range is set to EXPAND.</i></p> <hr/>
<i>Offset Level</i>	<p>Sets the offset value of the reference level within the range of ± 100 dB.</p> <hr/> <p>NOTE: <i>In a high-power signal measurement, this function allows you to read the signal directly when a fixed attenuator is connected to the input signal.</i></p> <hr/>
<i>Frequency Input</i>	<p>Sets whether or not a frequency or a channel number is used to input the center frequency of the instrument.</p> <p>FREQUENCY: Frequency input</p> <p>CHANNEL: Channel number input</p>
<i>Input</i>	<p>Sets the input signal.</p> <p>RF: Sets Input to RF.</p> <p>BASEBAND(I&Q): Sets Input to BASEBAND(I&Q).</p>
<i>Baseband Input</i>	<p>Selects the coupling of signals. Effective for BASEBAND(I & Q) only</p> <p>AC: Sets an alternate current coupling. (A cutoff frequency is approx. 15 Hz)</p> <p>DC: Sets a direct current coupling.</p>
<i>IQ Inverse</i>	<p>Sets the phases I and Q.</p> <p>NORMAL: The phases I and Q do not change.</p> <p>INVERSE: The phases I and Q are swapped.</p>

3.3 Functional Description

Cont Auto Level Set

Selects ON or OFF from the mode which automatically sets the internal reference level (REF LEVEL) to an optimum value in accordance with the measurement signal.

ON: Sets automatically the reference level to an optimum value. Always check the level before starting measurement and set an optimum value.

OFF: Fixes the reference level at the set level. Set the level manually or using "Auto Level Set" soft key.

NOTE: The signal level must be constant while Auto Level Set is being performed.

This key is enabled for the following measurements: Tx Power, Power vs Time, ACP (Modulation), OBW (Modulation), Modulation Accuracy, Bit Rate Error measurements and ALL measurement.

However, ACP (Modulation) is enabled when Ref. Level Adjust is turned on.

Setting the PHS system

STD Measurement Parameter Set	
Type :	PHS
Link :	UPLINK DOWNLINK
Meas Mode :	BURST CONTINUOUS
Slot Format :	CONTROL TRAFFIC
Sync Type :	UNIQUE WORD NO UNIQUE WORD
Unique Word :	E149
Root Nyquist Filter :	ON OFF
Freq Meas Range :	NORMAL EXPAND
Filter Mode :	WIDE NARROW
Offset Level :	0.0 dB
Frequency Input :	FREQUENCY CHANNEL
Input :	RF BASEBAND(I&Q)
Baseband Input :	AC DC
IQ Inverse :	NORMAL INVERSE
Cont Auto Level Set :	ON OFF

Figure 3-31 STD Measurement Parameter Set Dialog Box

Type

PHS

Link

Sets the direction of the slot.

UPLINK:

Up-link slot

DOWNLINK:

Down-link slot

<i>Meas Mode</i>	Sets the measurement mode. BURST: Measures one burst in the frame. CONTINUOUS: Measures continuous waves. Normally the PHS signals are burst waves, but this mode is set when continuous waves are transmitted for testing.
<i>Slot Format</i>	Sets physical slots. CONTROL: Physical slots for control TRAFFIC: Physical slots for communication
<i>Sync Type</i>	Sets the unique word synchronization. UNIQUE WORD: Sets the unique word to get synchronization. NO UNIQUEWORD: Performs measurement without using the unique word.
<i>Unique Word</i>	Displays the Unique Word that is determined by the combination of Link and Slot Format.
<i>Root Nyquist Filter</i>	Specifies whether or not to apply the Root Nyquist filter. ON: Sets the Root Nyquist filter for measurement. OFF: Performs measurements without using the Root Nyquist filter.
<i>Freq Meas Range</i>	Sets the estimated range of frequency error. NORMAL: This mode is set when signals exist in the adjacent channels. EXPAND: Expands the estimated range of frequency error.

NOTE: When Freq Meas Range is set to EXPAND, signals other than the standard coding test signal or signals including a large number noise components may sometimes not be measured.

3.3 Functional Description

<i>Filter Mode</i>	<p>Sets the band of the internal filter.</p> <p>WIDE: Sets the internal filter to the wide band. This mode is set when measuring Power vs Time and OBW based on the standard.</p> <p>NARROW: Sets the internal filter to the narrow band. This mode is set when signals exist in the adjacent channels.</p> <hr/> <p><i>NOTE: Filter Mode cannot be set to NARROW when Freq Meas Range is set to EXPAND.</i></p> <hr/>
<i>Offset Level</i>	<p>Adjusts the offset value of the reference level within the range of ± 100 dB.</p> <hr/> <p><i>NOTE: In a high-power signal measurement, this function allows you to read the signal directly when a fixed attenuator is connected to the input signal.</i></p> <hr/>
<i>Frequency Input</i>	<p>Sets whether a frequency or a channel number is used to input the center frequency of the instrument.</p> <p>FREQUENCY: Frequency input</p> <p>CHANNEL: Channel number input</p>
<i>Input</i>	<p>Sets the input signal.</p> <p>RF: Sets Input to RF.</p> <p>BASEBAND(I&Q): Sets Input to BASEBAND(I & Q).</p>
<i>Baseband Input</i>	<p>Selects the coupling of signals. Effective for BASEBAND(I & Q) only</p> <p>AC: Sets an alternate current coupling. (A cutoff frequency is approx. 15 Hz)</p> <p>DC: Sets a direct current coupling.</p>
<i>IQ Inverse</i>	<p>Sets the phases of I and Q.</p> <p>NORMAL: The phases I and Q do not change.</p> <p>INVERSE: The phases I and Q are swapped.</p>

Cont Auto Level Set

Selects ON or OFF of the mode which automatically adjusts the internal reference level (REF LEVEL) to an optimum value in accordance with the measurement signal.

ON: Sets automatically the reference level to an optimum value. Always checks the level before starting measurement and sets an optimum value. The signal level must be constant while Auto Level is being performed.

OFF: Fixes the reference level at the set level. Set the level manually or using "Auto Level Set" soft key.

NOTE: The signal level must be constant while Auto Level Set is being performed.

This key is enabled for the following measurements: Tx Power, Power vs Time, ACP (Modulation), OBW (Modulation), Modulation Accuracy, Bit Rate Error measurements and ALL measurement.

However, ACP (Modulation) is enabled when Ref. Level Adjust is turned on.

Setting the IS-136 system

STD Measurement Parameter Set	
Type :	IS-136 800M IS-136 1.9G
Link :	UPLINK DOWNLINK
Meas Mode :	BURST MULTI-BURST CONTINUOUS
Rate :	FULL RATE HALF RATE
Sync Type :	SYNC WORD NO SYNC WORD
Sync Word :	S1 S2 S3 S4 S5 S6
Root Nyquist Filter :	ON OFF
Freq Meas Range :	NORMAL EXPAND
Filter Mode :	WIDE NARROW
Offset Level :	0.0 dB
Frequency Input :	FREQUENCY CHANNEL
Input :	RF BASEBAND(I&Q)
Baseband Input :	AC DC
IQ Inverse :	NORMAL INVERSE
Cont Auto Level Set :	ON OFF

Figure 3-32 STD Measurement Parameter Set Dialog Box

3.3 Functional Description

Type	<p>Sets the frequency band.</p> <p>IS-136 800M: 800 MHz band</p> <p>IS-136 1.9G: 1900 MHz band</p> <p>The above bands are required to calculate the frequency from the channel number.</p>
Link	<p>Sets the direction of the channel.</p> <p>UPLINK: Up-link channel</p> <p>DOWNLINK: Down-link channel</p>
Meas Mode	<p>Sets the measurement mode.</p> <p>BURST: Measures one burst in the frame.</p> <p>MULTI-BURST: Searches for the desired burst from the multiple bursts in the frame to perform measurement.</p> <p>CONTINUOUS: Measures continuous waves.</p>
Rate	<p>Sets the signal rate.</p> <p>FULL RATE: Sets the signal rate to the full rate.</p> <p>HALF RATE: Sets the signal rate to the half rate.</p>
Sync Type	<p>Sets the sync word synchronization.</p> <p>SYNC WORD: Sets the sync word to obtain synchronization.</p> <p>NO SYNC WORD: Performs measurement without using the sync word.</p>
Sync Word	<p>Selects a Sync Word type.</p> <p>In FULL RATE: S1 to S3 can be set.</p> <p>In HALF RATE: S1 to S6 can be set.</p>
Root Nyquist Filter	<p>Sets whether or not to apply the Root Nyquist filter.</p> <p>ON: Sets the Root Nyquist filter for measurement.</p> <p>OFF: Performs measurement without using the Root Nyquist filter.</p>

Freq Meas Range

Sets the estimated range of frequency error.

NORMAL:

This mode is set when signals exist in the adjacent channels.

EXPAND:

Expands the estimated range of frequency error.

NOTE: When Freq Meas Range is set to EXPAND, signals other than the standard coding test signal or signals including a large number of noise components may sometimes not be measured.

Filter Mode

Sets the band of the internal filter.

WIDE: Sets the internal filter to the wide band. This mode is set when measuring the Power vs Time and OBW based on the standard.

NARROW:

Sets the internal filter to the narrow band. This mode is set when signals exist in the adjacent channels.

NOTE: Filter Mode cannot be set NARROW when Freq Meas Range is set to EXPAND.

Offset Level

Sets the offset value of the reference level to the range within ± 100 dB.

NOTE: In a high-power signal measurement, this function allows you to read the signal directly when a fixed attenuator is connected to the input signal.

Frequency Input

Sets whether a frequency or a channel number is used to input the center frequency of the instrument.

FREQUENCY:

Frequency input

CHANNEL:

Channel number input

Input

Sets the input signal.

RF: Sets Input to RF.

BASEBAND(I&Q):

Sets Input to BASEBAND(I & Q).

3.3 Functional Description

<i>Baseband Input</i>	Selects the coupling of signals. Effective for BASEBAND(I & Q) only AC: Sets an alternate current coupling. (A cutoff frequency is approx. 15 Hz) DC: Sets a direct current coupling.
<i>IQ Inverse</i>	Sets the phases of I and Q. NORMAL: The phases I and Q do not change. INVERSE: The phases I and Q are swapped.
<i>Cont Auto Level Set</i>	Selects ON or OFF of the mode which automatically sets the internal reference level (REF LEVEL) to an optimum value in accordance with the measurement signal. ON: Sets automatically the reference level to an optimum value. Always checks the level before starting measurement and sets an optimum value. OFF: Fixes the reference level at the set level. Set the level manually or using "Auto Level Set" soft key.

***NOTE: The signal level must be constant while Auto Level Set is being performed.
This key is enabled for the following measurements: Tx Power, Power vs Time, ACP (Modulation), OBW (Modulation), Modulation Accuracy, Bit Rate Error measurements and ALL measurement.
However, ACP (Modulation) is enabled when Ref. Level Adjust is turned on.***

4 REMOTE CONTROL

4.1 GPIB Command Index

This GPIB command index can be used as the index for Chapter 4.

GPIB Command	Pages	GPIB Command	Pages
*CLS	4-51		4-17
.	4-50	CHEDUP2	4-13, 4-15, 4-17
0 to 9	4-50	CHEDUP3	4-13, 4-15, 4-17
AA.....	4-8	CHSETSTD	4-13, 4-15, 4-17
AD.....	4-51	CHTBL1 DSBL.....	4-13, 4-15, 4-17
ALS OFF.....	4-14, 4-15, 4-17	CHTBL1 ENBL.....	4-13, 4-15, 4-17
ALS ON	4-14, 4-15, 4-17	CHTBL2 DSBL.....	4-13, 4-15, 4-17
AS	4-9	CHTBL2 ENBL.....	4-13, 4-15, 4-17
AT	4-8	CHTBL3 DSBL.....	4-13, 4-15, 4-17
ATMIN	4-8	CHTBL3 ENBL.....	4-13, 4-15, 4-17
ATMIN OFF.....	4-8	CLDC.....	4-14, 4-15, 4-17
ATMIN ON.....	4-8	CODEC FULL.....	4-12, 4-16
AUTOLVL.....	4-36, 4-37, 4-39, 4-40, 4-41, 4-46	CODEC HALF	4-12, 4-16
AUTOWFL	4-18	COMMSYS IS-136.....	4-8
BA.....	4-9	COMMSYS IS95.....	4-8
BBINPUT AC.....	4-13, 4-15, 4-17	COMMSYS PDC.....	4-8
BBINPUT DC.....	4-13, 4-15, 4-17	COMMSYS PHS	4-8
BITRERR.....	4-39, 4-49	DB.....	4-50
BTR.....	4-39	DC0.....	4-10
BTRAVG	4-39	DC1	4-10
BTRST OFF.....	4-47	DC2.....	4-10
BTRST ON	4-47	DEL.....	4-11
CF.....	4-9	DEL REG_mn.....	4-11
CH.....	4-13, 4-14, 4-16	DELSTBL.....	4-22
CHEDDN1.....	4-13, 4-15, 4-17	DEMOD.....	4-43
CHEDDN2.....	4-13, 4-15, 4-17	DL0	4-51
CHEDDN3.....	4-13, 4-15, 4-17	DL1	4-51
CHEDUP1	4-13, 4-15,	DL2	4-51

4.1 GPIB Command Index

DL3	4-51	DTSMKRCP	4-27
DL4	4-51	DTSMKRED	4-27
DTMAUTOLVL	4-29, 4-32	DTSREF MKR	4-28
DTMAVG	4-30	DTSREF MOD	4-28
DTMDET NEG	4-30	DTSREFPWR	4-28
DTMDET NRM	4-30	DTSRES ABS	4-28
DTMDET POS	4-30	DTSRES MKR	4-28
DTMDET SMP	4-30	DTSRES REL	4-28
DTMFRMD CFSP	4-31	DTSRFACT	4-28
DTMFRMD STSP	4-31	DTSSETSTD	4-28
DTMJDG OFF	4-31	DTSSYMRT	4-28
DTMJDG ON	4-31	DTSTMPL OFF	4-27
DTMMEAS	4-31	DTSTMPL ON	4-27
DTMMKRCLR	4-30	DTSTMPLBTM	4-28
DTMMKRCP	4-30	DTSTMPLCLR	4-27
DTMMKRED	4-30	DTSTMPLCP	4-27
DTMREF MKR	4-31	DTSTMPLDX	4-27
DTMREF MOD	4-31	DTSTMPLD	4-27
DTMREFPWR	4-31	DTSTMPLPW OFF	4-28
DTMRES ABS	4-31	DTSTMPLPW ON	4-28
DTMRES MKR	4-31	DTSTMPLSX	4-27
DTMRES REL	4-31	DTSTMPLSY	4-27
DTMRFACT	4-31	DTSUNIT DBM	4-28
DTMSETSTD	4-31	DTSUNIT DBUV	4-28
DTMSYMRT	4-31	DTSUNIT W	4-28
DTMTMPL OFF	4-29	ENT	4-50
DTMTMPL ON	4-29	ERRNO	4-51
DTMTMPLBTM	4-30	ESE	4-51
DTMTMPLCLR	4-30	ESR	4-51
DTMTMPLCP	4-30	EUTEMP d1,d2,d3,d4	4-38
DTMTMPLDX	4-29	FA	4-9
DTMTMPLED	4-30	FB	4-9
DTMTMPLPW OFF	4-30	FDPAUTOLVL	4-24
DTMTMPLPW ON	4-30	FDPAVG	4-25
DTMTMPLSX	4-29	FDPDET NEG	4-25
DTMTMPLSY	4-29	FDPDET NRM	4-25
DTMUNIT DBM	4-30	FDPDET POS	4-25
DTMUNIT DBUV	4-30	FDPDET SMP	4-25
DTMUNIT W	4-30	FDPDIV P10DB	4-25
DTSAUTOLVL	4-27	FDPDIV P2DB	4-25
DTSAVG	4-27	FDPDIV P5DB	4-25
DTSDET NEG	4-27	FDPJDG OFF	4-25
DTSDET NRM	4-27	FDPJDG ON	4-25
DTSDET POS	4-27	FDPJDGLOW	4-25
DTSDET SMP	4-27	FDPJDGUP	4-25
DTSFRMD CFSP	4-28	FDPMEAS	4-26
DTSFRMD STSP	4-28	FDPSETSTD	4-25
DTSJDG OFF	4-28	FDPUNIT DBM	4-25
DTSJDG ON	4-28	FDPUNIT DBUV	4-25
DTSMEAS	4-28	FDPUNIT W	4-25
DTSMKRCLR	4-27	FDPWDO OFF	4-25

FDPWDO ON	4-25	INPUT IQ	4-13, 4-15, 4-17
FDPWPOS	4-25	INPUT RF	4-13, 4-15, 4-17
FDPWWID	4-25	IP	4-10
FDSAUTOLVL	4-34	IQMD INV	4-13, 4-15, 4-17
FDSAVG	4-34	IQMD NORM	4-13, 4-15, 4-17
FDSCLR	4-34	KZ	4-50
FDSDET NEG	4-35	LC	4-51
FDSDET NRM	4-35	LINK DOWN	4-12, 4-14, 4-16
FDSDET POS	4-35	LINK UP	4-12, 4-14, 4-16
FDSDET SMP	4-35	MA	4-50
FDSJDG OFF	4-35	MEASMD BURST	4-12, 4-14, 4-16
FDSJDG ON	4-35	MEASMD CONT	4-12, 4-14, 4-16
FDSLID	4-34	MEASMD MBURST	4-12, 4-16
FDSMEAS	4-35	MF	4-10
FDSPKMKY	4-35	MFL	4-10
FDSPRE 16G	4-35	MFLTMD NARW	4-12, 4-14, 4-16
FDSPRE 36G	4-35	MFLTMD WIDE	4-12, 4-14, 4-16
FDSSETSTD	4-35	MK	4-10
FDSSV	4-34	MKBW	4-10
FDSTBL	4-34	MKD	4-10
FDSTBLED	4-34	MKN	4-10
FDSUNIT DBM	4-35	MKOFF	4-10
FDSUNIT DBUV	4-35	ML	4-10
FDSUNIT W	4-35	MO	4-10
FINPMD CHL	4-13, 4-14, 4-16	MODACC	4-40, 4-49
FINPMD FREQ	4-13, 4-14, 4-16	MODACC10	4-41, 4-49
FRRNG EXP	4-12, 4-14, 4-16	MODACCPK	4-41, 4-49
FRRNG NORM	4-12, 4-14, 4-16	MODBRSTLVL	4-44, 4-46
GPHI	4-42	MODTRG EXT	4-36, 4-37, 4-39, 4-40, 4-41, 4-44, 4-46
GPHQ	4-43	MODTRG FREE	4-36, 4-37, 4-39, 4-40, 4-41, 4-44, 4-46
GPHTYP CON	4-42	MODTRG IF	4-36, 4-37, 4-39, 4-40, 4-41, 4-44, 4-46
GPHTYP DEMOD	4-42	MODTRGBRST OFF	4-36, 4-37,
GPHTYP DOT	4-42		
GPHTYP EVM	4-42		
GPHTYP IEYE	4-42		
GPHTYP INP	4-42		
GPHTYP IQEYE	4-42		
GPHTYP LIN	4-42		
GPHTYP ME	4-42		
GPHTYP PFE	4-42		
GPHTYP QEYE	4-42		
GPHX	4-43		
GPHY	4-43		
GZ	4-50		
HCOPY	4-8		
HZ	4-50		
IDN	4-51		

4.1 GPIB Command Index

	4-39, 4-40,	OORAVG	4-21
	4-42, 4-44,	OORDET NEG	4-21
	4-46	OORDET NRM	4-21
MODTRGBRST ON	4-36, 4-37,	OORDET POS	4-21
	4-39, 4-40,	OORDET SMP	4-21
	4-42, 4-44,	OORDIV P10DB	4-21
	4-46	OORDIV P2DB	4-21
MODTRGDLY	4-36, 4-37,	OORDIV P5DB	4-21
	4-39, 4-40,	OORJDG OFF	4-21
	4-41, 4-44,	OORJDG ON	4-21
	4-46	OORJDGUP	4-21
MODTRGLVL	4-36, 4-37,	OORMEAS	4-21
	4-39, 4-40,	OORSETSTD	4-21
	4-41, 4-44,	OORTRGDT	4-20
	4-46	OORTRGLV L	4-20
MODTRGSLP FALL	4-36, 4-37,	OORTRGPOS	4-20
	4-39, 4-40,	OORTRGSLP FALL	4-20
	4-41, 4-44,	OORTRGSLP RISE	4-20
	4-46	OORTRGSLP RISE	4-20
MODTRGSLP RISE	4-36, 4-37,	OORTRGSRG EXT	4-20
	4-39, 4-40,	OORTRGSRG FREE	4-20
	4-41, 4-44,	OORTRGSRG IF	4-20
	4-46	OORTRGSRG VIDEO	4-20
MODTRGSLT	4-36, 4-37,	OORUNIT DBM	4-21
	4-39, 4-40,	OORUNIT DBUV	4-21
	4-41, 4-44,	OORUNIT W	4-21
	4-46	OORWDO OFF	4-20
MODTYP IS1900M	4-16	OORWDO ON	4-20
MODTYP IS800M	4-16	OORWOFPOS	4-20
MODTYP PDC1500M	4-12	OORWOFWID	4-20
MODTYP PDC800M1	4-12	OORWONPOS	4-20
MODTYP PDC800M2	4-12	OORWONWID	4-20
MODTYP PDC800M3	4-12	OPR	4-52
MS	4-50	OPREVT	4-52
MV	4-50	PS	4-10
MW	4-50	PTAVG	4-37, 4-38
MZ	4-50	PTDIV P10DB	4-37
OBWAUTOLVL	4-26	PTDIV P20DB	4-37
OBWAVG	4-26	PTDIV P5DB	4-37
OBWDET NEG	4-26	PTJDG	4-38
OBWDET NRM	4-26	PTMOD HIGH	4-37
OBWDET POS	4-26	PTMOD NORM	4-37
OBWDET SMP	4-26	PTTENT	4-38
OBWJDG OFF	4-26	PTTUNIT DB	4-38
OBWJDG ON	4-26	PTTUNIT DBM	4-38
OBWJDGLOW	4-26	PTTYP	4-38
OBWJDGUP	4-26	PWRM	4-38
OBWMEAS	4-26	RATE FULL	4-12
OBWPER	4-26	RATE HALF	4-12
OBWSETSTD	4-26	RB	4-9
OORAUTOLVL	4-20	RC	4-10
		RC REG_n	4-10

RCLTBL	4-22	SPRTMPL OFF	4-32
RL	4-9	SPRTMPL ON	4-32
RNYQ OFF	4-12, 4-14, 4-16	SPRTMPLBTM	4-33
RNYQ ON	4-12, 4-14, 4-16	SPRTMPLCLR	4-32
RO	4-12, 4-14, 4-16	SPRTMPLCP	4-32
RQS	4-51	SPRTMPLDX	4-32
RST	4-51	SPRTMPLED	4-32
RUDJDG	4-38	SPRTMPLPW OFF	4-33
RUDPWR	4-38	SPRTMPLPW ON	4-33
RUPDN	4-38	SPRTMPLSX	4-32
RUTEMP	4-38	SPRTMPLSY	4-32
S0	4-51	SPRUNIT DBM	4-33
S1	4-51	SPRUNIT DBUV	4-33
S2	4-51	SPRUNIT W	4-33
SC	4-50	SPULVL	4-24
SETFUNC CW	4-8	SPUR	4-23
SETFUNC TRAN	4-8	SRE	4-51
SI	4-20, 4-21, 4-23, 4-26, 4-28, 4-31, 4-34, 4-35, 4-36, 4-38, 4-39, 4-40, 4-42, 4-45, 4-47	ST	4-9
SLTTYP CONT	4-14	STB	4-51
SLTTYP TRAF	4-14	SV	4-11
SP	4-11	SV REG_nm	4-11
SPRAVG	4-32	SVSTBL	4-22
SPRDET NEG	4-32	SW	4-9
SPRDET NRM	4-32	SYNC NO	4-12, 4-16
SPRDET POS	4-32	SYNC S	4-12, 4-16
SPRDET SMP	4-32	TACP	4-45, 4-48
SPRFRMD CFSP	4-33	TACPAUTOLVL	4-44
SPRFRMD STSP	4-33	TACPLVLADJ OFF	4-44
SPRJDG OFF	4-33	TACPLVLADJ ON	4-44
SPRJDG ON	4-33	TACPPWRAVG	4-44
SPRMEAS	4-34	TACPPWRRES DBM	4-44
SPRMRCLR	4-32	TACPPWRRES W	4-44
SPRMRCP	4-32	TACPRES DB	4-44
SPRMRKRED	4-32	TACPRES DBM	4-44
SPRPMKY	4-33	TACPRES W	4-44
SPRREF MKR	4-33	TACPST OFF	4-47
SPRREF MOD	4-33	TACPST ON	4-47
SPRREFPWR	4-34	TACPSTDEF	4-45
SPRRES ABS	4-33	TACPSTIME	4-45
SPRRES REL	4-33	TACPX	4-45, 4-48
SPRSETSTD	4-33	TAVGAP	4-36
		TAVGMOD	4-40
		TAVGOW	4-42
		TAVGTX	4-36
		TDPAUTOLVL	4-18
		TDPAVG	4-18
		TDPDET NEG	4-19
		TDPDET NRM	4-19
		TDPDET POS	4-19
		TDPDET SMP	4-19
		TDPDIV P10DB	4-18

4.1 GPIB Command Index

TDPDIV P2DB	4-18	TDSPRE 16G.....	4-23
TDPDIV P5DB	4-18	TDSPRE 36G.....	4-23
TDPJDG OFF	4-19	TDSRES PK	4-23
TDPJDG ON.....	4-19	TDSRES RMS	4-23
TDPJDGLOW	4-20	TDSSETSTD	4-23
TDPJDGUP	4-20	TDSSV	4-22
TDPMEAS.....	4-20	TDSTBL	4-22
TDPSETSTD	4-20	TDSTBLED.....	4-22
TDPTMPL OFF.....	4-19	TDSTBLF ABS	4-22
TDPTMPL ON	4-19	TDSTBLF REL.....	4-22
TDPTMPLBTM.....	4-19	TDSTRGDT.....	4-22
TDPTMPLCLR	4-19	TDSTRGLVL.....	4-22
TDPTMPLCP	4-19	TDSTRGPOS.....	4-22
TDPTMPLED.....	4-19	TDSTRGSLP FALL	4-22
TDPTMPLPW OFF.....	4-19	TDSTRGSLP RISE	4-22
TDPTMPLPW ON	4-19	TDSTRGSRC EXT.....	4-22
TDPTMPLSEL LOW.....	4-19	TDSTRGSRC FREE.....	4-22
TDPTMPLSEL UP.....	4-19	TDSTRGSRC IF.....	4-22
TDPTMPLSX.....	4-19	TDSUNIT DBM.....	4-23
TDPTMPLSY	4-19	TDSUNIT DBUV	4-23
TDPTRGDT.....	4-18	TDSUNIT W.....	4-23
TDPTRGLVL	4-18	TGTDET NEG.....	4-25, 4-29
TDPTRGPOS.....	4-18	TGTDET NRM.....	4-25, 4-29
TDPTRGSLP FALL	4-18	TGTDET POS.....	4-25, 4-29
TDPTRGSLP RISE	4-18	TGTDET SMP	4-25, 4-29
TDPTRGSRC EXT.....	4-18	TGTPOS	4-24, 4-29
TDPTRGSRC FREE.....	4-18	TGTSETUP OFF.....	4-24, 4-29
TDPTRGSRC IF.....	4-18	TGTSETUP ON.....	4-24, 4-29
TDPTRGSRC VIDEO.....	4-18	TGTSRC EXT	4-24, 4-29
TDPUNIT DBM	4-19	TGTSRC TRG	4-24, 4-29
TDPUNIT DBUV	4-19	TGTSWP OFF	4-25, 4-29
TDPUNIT W.....	4-19	TGTSWP ON.....	4-25, 4-29
TDPWDO OFF.....	4-18	TGTTRG EXT	4-24, 4-29
TDPWDO ON.....	4-18	TGTTRG FREE.....	4-24, 4-29
TDPWPOS.....	4-18	TGTTRG IF	4-24, 4-29
TDPWWID	4-18	TGTTRG VIDEO	4-24, 4-29
TDSAUTOLVL	4-22	TGTTRGDT	4-24, 4-29
TDSAVG	4-22	TGTTRGLVL.....	4-24, 4-29
TDSCLR	4-22	TGTTRGPOS	4-24, 4-29
TDSCONTALS OFF	4-23	TGTTRGSLP FALL.....	4-24, 4-29
TDSCONTALS ON.....	4-23	TGTTRGSLP RISE	4-24, 4-29
TDSDET NEG.....	4-23	TGTWID.....	4-24, 4-29
TDSDET NRM.....	4-23	TOBW.....	4-42, 4-47
TDSDET POS.....	4-23	TOBW1.....	4-42
TDSDET SMP	4-23	TRGDT	4-18
TDSJDG OFF	4-23	TRGLVL.....	4-18
TDSJDG ON.....	4-23	TRGMODE EXT.....	4-36, 4-37,
TDSL.....	4-22		4-39, 4-40,
TDSMEAS.....	4-23, 4-24		4-41, 4-44,
TDSMULTI	4-23		4-46
TDSPKMKY	4-23	TRGMODE FREE.....	4-36, 4-37,

	4-39, 4-40, 4-41, 4-44, 4-46
TRGMODE IF	4-36, 4-37, 4-39, 4-40, 4-41, 4-44, 4-46
TRGMSLP FALL	4-44, 4-46
TRGMSLP RISE	4-44, 4-46
TRGPOS	4-18
TRGSLP FALL.....	4-18
TRGSLP RISE.....	4-18
TRGSRC EXT	4-18
TRGSRC FREE	4-18
TRGSRC IF	4-18
TRGSRC VIDEO	4-18
TRSPMD FREE.....	4-22
TRSPMD IF.....	4-22
TRSPSLP FALL.....	4-22
TRSPSLP RISE	4-22
TXAVG	4-36
TXMACPRES DB	4-47
TXMACPRES DBM	4-47
TXMACPRES W.....	4-47
TXMAVG	4-47
TXMBTRRES BPS	4-47
TXMBTRRES PPM	4-47
TXMEAS	4-47
TXMPWRRES DBM	4-47
TXMPWRRES W.....	4-47
TXMPWRTYP BURST	4-46
TXMPWRTYP FRAME.....	4-46
TXMST	4-47
TXMSTDEF	4-47
TXPWR	4-36, 4-46, 4-47
UNIQ B32.....	4-14
UNIQ NO.....	4-14
US	4-50
VA.....	4-9
VB	4-9
WAVEFM.....	4-20
XDB	4-10
XDL	4-10
XDR.....	4-10

4.2 GPIB Command Codes

4.2 GPIB Command Codes

The following table list the GPIB commands by function.

Table 4-1 Operating Mode

Function		Listener Code	Talker Request		Remarks
			Code	Output Format	
Operating mode	Spectrum analyzer mode	SETFUNC CW	SETFUNC?	0: Spectrum analyzer	
	TRANSIENT mode	SETFUNC TRAN		1: TRANSIENT	
Communication system	IS-95 mode	COMMSYS IS95		2: IS-95	*1
	PDC mode	COMMSYS PDC		3: PDC	
	PHS mode	COMMSYS PHS		4: PHS	
	IS-136 mode	COMMSYS IS136		5: IS-136	

*1: Listener code is available only when the analyzer is set to the CW mode. The codes within the talker request are available for both the CW and TRANSIENT modes.

Table 4-2 ATT Key (Attenuator)

Function		Listener Code	Talker Request		Remarks
			Code	Output Format	
Attenuator	AT	AT *	AT?	Level	
	ATT AUTO	AA	AA?	0: Manual 1: AUTO	
	Min. ATT	ATMIN *	ATMIN?	Level	
	Min. ATT ON OFF	ATMIN ON [*] ATMIN OFF	ATMINON?	0: OFF 1: ON	

Table 4-3 COPY Key (Hand copy)

Function		Listener Code	Talker Request		Remarks
			Code	Output Format	
Printer output					
File output		HCOPY	-	-	

Table 4-4 COUPLE Key (Couple function)

Function		Listener Code	Talker Request		Remarks
			Code	Output Format	
Couple function	RBW	RB *	RB?	Frequency	
	RBW AUTO	BA	BA?	0: Manual 1: AUTO	
	VBW	VB *	VB?	Frequency	
	VBW AUTO	VA	VA?	0: Manual 1: AUTO	
	Sweep Time	SW * ST *	SW? ST?	Time	
	Sweep Time Auto	AS	AS?	0: Manual 1: AUTO	

Table 4-5 FREQ Key (Frequency)

Function		Listener Code	Talker Request		Remarks
			Code	Output Format	
Frequency	Center frequency	CF *	CF?	Frequency	
	Start frequency	FA *	FA?	Frequency	
	Stop frequency	FB *	FB?	Frequency	

Table 4-6 LEVEL Key (Reference Level)

Function		Listener Code	Talker Request		Remarks
			Code	Output Format	
Reference level		RL *	RL?	Level	

4.2 GPIB Command Codes

Table 4-7 MKR Key (Marker)

Function		Listener Code	Talker Request		Remarks
			Code	Output Format	
Marker	ΔMarker ON	MKD [*]	-	Frequency(Time)	
	OFF	MKOFF MO	- -	- -	
	Reading marker frequency (time)	-	MF?	Frequency(Time)	
	Reading marker level	-	ML?	Level	
	Reading marker frequency (time) and marker level	-	MFL?	Frequency(Time), Level	
	Normal marker	MK [*] MKN [*]	- -	Frequency(Time)	
	Peak search	PS			
	X-dB Down				
	X-dB Down width	MKBW *	MKBW?	Level	
	X-dB Down	XDB	-		
X-dB Down Left	XDL	-			
Right	XDR	-			
Display mode REL.	DC0	DC?	0: Relative mode		
ABS.L.	DC1		1: Absolute mode (Left side)		
ABS.R.	DC2		2: Absolute mode (Right side)		

Table 4-8 PRESET Key (Initialization)

Function		Listener Code	Talker Request		Remarks
			Code	Output Format	
Preset	Instrument preset	IP	-	-	

Table 4-9 RCL Key (Recall)

Function		Listener Code	Talker Request		Remarks
			Code	Output Format	
Recall		RC REG_nn	-	nn: 01 to 10	
		RC file name	-	File name: Max.8 character	

Table 4-10 SAVE Key (Save)

Function		Listener Code	Talker Request		Remarks
			Code	Output Format	
Save	Save	SV REG_nn SV file name	- -	nn: 01 to 10 File name: Max.8 character	
	Deletion	DEL REG_nn DEL file name	- -	nn: 01 to 10 File name: Max.8 character	

Table 4-11 SPAN Key (Frequency span)

Function		Listener Code	Talker Request		Remarks
			Code	Output Format	
Frequency span		SP *	SP?	Frequency	

4.2 GPIB Command Codes

Table 4-12 TRASIENT Key

Function	Listener Code	Talker Request		Remarks
		Code	Output Format	
STD Setup (PDC)	Communication System			
	PDC 800M - 1	MODTYP PDC800M1	MODTYP?	0: 800M-1
	PDC 800M - 2	MODTYP PDC800M2		1: 800M-2
	PDC 800M - 3	MODTYP PDC800M3		2: 800M-3
	PDC 1.5G	MODTYP PDC1500M		3: 1.5G
	Link			
	UPLINK	LINK UP	LINK?	0: UPLINK
	DOWNLINK	LINK DOWN		1: DOWNLINK
	Signal Type			
	BURST	MEASMD BURST	MEASMD?	0: BURST
MULTI-BURST	MEASMD MBURST		1: MULTI-BURST	
CONTINUOUS	MEASMD CONT		2: CONTINUOUS	
Transfer Rate				
FULL	CODEC FULL RATE FULL	CODEC? RATE?	0: FULL 1: HALF	
HALF	CODEC HALF RATE HALF			
Sync.Type&Sync.Word				
SYNC WORD Using	SYNC S *	SYNC?	1: S1/S7 2: S2/S8 3: S3/S9 4: S4/S10 5: S5/S11 6: S6/S12	
SYNC WORD Not using	SYNC NO		0: NO SYNC WORD	
Root Nyquist Filter				
Filter OFF	RNYQ OFF	RNYQ?	0: OFF	
Filter ON	RNYQ ON		1: ON	
Freq.Range				
NORMAL	FRRNG NORM	FRRNG?	0: NORMAL	
EXPAND	FRRNG EXP		1: EXPAND	
Meas.Filter mode				
WIDE	MFLTMD WIDE	MFLTMD?	0: WIDE	
NARROW	MFLTMD NARW		1: NARROW	
Offset Level	RO *	RO?	Level	

Table 4-12 TRASIENT Key

Function	Listener Code	Talker Request		Remarks
		Code	Output Format	
STD Setup (PDC)	Freq.Setting mode			
	Freq.Input mode	FINPMD FREQ	FINPMD?	0: Frequency Input
	Channel Input mode	FINPMD CHL		1: Channel Input
	Channel Setting	CH *	CH?	Integer (Channel No.)
	Channel Edit			
	Input #1(UPLINK)	CHEDUP1 *,*,*,*	CHEDUP1?	ch1,ch2,f1,f2,chof
	Input #2(UPLINK)	CHEDUP2 *,*,*,*	CHEDUP2?	ch1,ch2,f1,f2,chof
	Input #3(UPLINK)	CHEDUP3 *,*,*,*	CHEDUP3?	ch1,ch2,f1,f2,chof
	Input #1(DOWNLINK)	CHEDDN1 *,*,*,*	CHEDDN1?	ch1,ch2,f1,f2,chof
	Input #2(DOWNLINK)	CHEDDN2 *,*,*,*	CHEDDN2?	ch1,ch2,f1,f2,chof
Input #3(DOWNLINK)	CHEDDN3 *,*,*,*	CHEDDN3?	ch1,ch2,f1,f2,chof	
			ch1: Start channel no. ch2: Stop channel no. f1: Base frequency(Hz) f2: Channel space(Hz) chof: Channel offset	Units of frequency are necessary for f1 and f2.
Selection of ENABLE or DISABLE for channel table				
#1 ENABLE	CHTBL1 ENBL	CHTBL1?	0: Disable	
DISABLE	CHTBL1 DSBL		1: Enable	
#2 ENABLE	CHTBL2 ENBL	CHTBL2?	0: Disable	
DISABLE	CHTBL2 DSBL		1: Enable	
#3 ENABLE	CHTBL3 ENBL	CHTBL3?	0: Disable	
DISABLE	CHTBL3 DSBL		1: Enable	
Channel				
Copy from STD	CHSETSTD			
Input				
RF	INPUT RF	INPUT?	0: RF	
Baseband(I&Q)	INPUT IQ		1: Baseband(I&Q)	
BaseBand Input				
AC	BBINPUT AC	BBINPUT?	0: AC	
DC	BBINPUT DC		1: DC	
IQ Inverse				
NORMAL	IQMD NORM	IQMD?	0: NORMAL	
INVERSE	IQMD INV		1: INVERSE	

4.2 GPIB Command Codes

Table 4-12 TRASIENT Key

Function	Listener Code	Talker Request		Remarks
		Code	Output Format	
STD Setup (PDC)	Auto Level Setting			
	Auto Level OFF	ALS OFF	ALS?	0: OFF
	Auto Level ON	ALS ON		1: ON
	DC CAL	CLDC		
STD Setup (PHS)	Link			
	UPLINK	LINK UP	LINK?	0: UPLINK
	DOWNLINK	LINK DOWN		1: DOWNLINK
	Signal type			
	BURST	MEASMD BURST	MEASMD?	0: BURST
	CONTINUOUS	MEASMD CONT		2: CONTINUOUS
	SLOT format			
	CONTROL	SLTTYP CONT	SLTTYP?	0: CONTROL
	TRAFFIC	SLTTYP TRAF		1: TRAFFIC
	Sync. type			
UNIQUE WORD sync.	UNIQ B32	UNIQ?	1: UNIQUE WORD Using	
UNIQUE WORD no sync.	UNIQ NO		0: NO UNIQUE WORD	
Root Nyquist Filter				
Filter OFF	RNYQ OFF	RNYQ?	0: OFF	
Filter ON	RNYQ ON		1: ON	
Freq. Range				
NORMAL	FRRNG NORM	FRRNG?	0: NORMAL	
EXPAND	FRRNG EXP		1: EXPAND	
Meas. Filter mode				
WIDE	MFLTMD WIDE	MFLTMD?	0: WIDE	
NARROW	MFLTMD NARW		1: NARROW	
Offset Level	RO *	RO?	Level	
Frequency Setting Mode				
Frequency Input Mode	FINPMD FREQ	FINPMD?	0: Frequency Input	
Channel Input Mode	FINPMD CHL		1: Channel Input	
Channel Setting	CH *	CH?	Integer (Channel No.)	

Table 4-12 TRASIENT Key

Function	Listener Code	Talker Request		Remarks
		Code	Output Format	
STD Setup (PHS)	Channel Edit			
	Input#1(UPLINK)	CHEDUP1 *,*,*,*	CHEDUP1?	ch1,ch2,f1,f2,chof
	Input#2(UPLINK)	CHEDUP2 *,*,*,*	CHEDUP2?	ch1,ch2,f1,f2,chof
	Input#3(UPLINK)	CHEDUP3 *,*,*,*	CHEDUP3?	ch1,ch2,f1,f2,chof
	Input#1(DOWNLINK)	CHEDDN1 *,*,*,*	CHEDDN1?	ch1,ch2,f1,f2,chof
	Input#2(DOWNLINK)	CHEDDN2 *,*,*,*	CHEDDN2?	ch1,ch2,f1,f2,chof
	Input#3(DOWNLINK)	CHEDDN3 *,*,*,*	CHEDDN3?	ch1,ch2,f1,f2,chof ch1: Start channel no. ch2: Stop channel no. f1: Base frequency(Hz) f2: Channel space(Hz) chof: Channel offset
Channel Table Enable/Disable				
#1 ENABLE	CHTBL1 ENBL	CHTBL1?	0: Disable	Units of frequency are necessary for f1 and f2.
DISABLE	CHTBL1 DSBL		1: Enable	
#2 ENABLE	CHTBL2 ENBL	CHTBL2?	0: Disable	
DISABLE	CHTBL2 DSBL		1: Enable	
#3 ENABLE	CHTBL3 ENBL	CHTBL3?	0: Disable	
DISABLE	CHTBL3 DSBL		1: Enable	
Channel Copy from STD	CHSETSTD			
Input				
RF	INPUT RF	INPUT?	0: RF	
Baseband(I&Q)	INPUT IQ		1: Baseband(I&Q)	
BaseBand Input				
AC	BBINPUT AC	BBINPUT?	0: AC	
DC	BBINPUT DC		1: DC	
IQ Inverse				
NORMAL	IQMD NORM	IQMD?	0: NORMAL	
INVERSE	IQMD INV		1: INVERSE	
Auto Level Setting				
Auto Level OFF	ALS OFF	ALS?	0: OFF	
Auto Level ON	ALS ON		1: ON	
DC CAL	CLDC			

4.2 GPIB Command Codes

Table 4-12 TRASIENT Key

Function	Listener Code	Talker Request		Remarks	
		Code	Output Format		
STD Setup (IS-136)	Communication system IS-136 800M IS-136 1.9G	MODTYP IS800M MODTYP IS1900M	MODTYP?	0: 800M 1: 1.9G	
	Link UPLINK DOWNLINK	LINK UP LINK DOWN	LINK?	0: UPLINK 1: DOWNLINK	
	Signal Type BURST MULTI-BURST CONTINUOUS	MEASMD BURST MEASMD MBURST MEASMD CONT	MEASMD?	0: BURST 1: MULTI-BURST 2: CONTINUOUS	
	Transfer Rate FULL HALF	CODEC FULL CODEC HALF	CODEC?	0: FULL 1: HALF	
	Sync. Type & Sync. Word SYNC WORD using SYNC WORD not using	SYNC S * SYNC NO	SYNC?	1: S1 2: S2 3: S3 4: S4 5: S5 6: S6 0: NO SYNC WORD	
	Root Nyquist Filter Filter OFF Filter ON	RNYQ OFF RNYQ ON	RNYQ?	0: OFF 1: ON	
	Freq. Range NORMAL EXPAND	FRRNG NORM FRRNG EXP	FRRNG?	0: NORMAL 1: EXPAND	
	Meas. Filter Mode WIDE NARROW	MFLTMD WIDE MFLTMD NARW	MFLTMD?	0: WIDE 1: NARROW	
	Offset Level	RO *	RO?	Level	
	Frequency Setting Mode Frequency Input Mode Channel Input Mode Channel Setting	FINPMD FREQ FINPMD CHL CH *	FINPMD? CH?	0: Frequency Input 1: Channel Input Integer (Channel No.)	

Table 4-12 TRASIENT Key

Function	Listener Code	Talker Request		Remarks	
		Code	Output Format		
STD Setup (IS-136)	Channel Edit				
	Input #1(UPLINK)	CHEDUP1 *,*,*,*,*	CHEDUP1?	ch1,ch2,f1,f2,chof	
	Input #2(UPLINK)	CHEDUP2 *,*,*,*,*	CHEDUP2?	ch1,ch2,f1,f2,chof	
	Input #3(UPLINK)	CHEDUP3 *,*,*,*,*	CHEDUP3?	ch1,ch2,f1,f2,chof	
	Input #1(DOWNLINK)	CHEDDN1 *,*,*,*,*	CHEDDN1?	ch1,ch2,f1,f2,chof	
	Input #2(DOWNLINK)	CHEDDN2 *,*,*,*,*	CHEDDN2?	ch1,ch2,f1,f2,chof	
	Input #3(DOWNLINK)	CHEDDN3 *,*,*,*,*	CHEDDN3?	ch1,ch2,f1,f2,chof	
				ch1: Start channel no. ch2: Stop channel no. f1: Base frequency(Hz) f2: Channel space(Hz) chof: Channel offset	Units of frequency are necessary for f1 and f2.
Selection of ENABLE or DISABLE for channel table					
#1 ENABLE	CHTBL1 ENBL	CHTBL1?	0: Disable		
DISABLE	CHTBL1 DSBL		1: Enable		
#2 ENABLE	CHTBL2 ENBL	CHTBL2?	0: Disable		
DISABLE	CHTBL2 DSBL		1: Enable		
#3 ENABLE	CHTBL3 ENBL	CHTBL3?	0: Disable		
DISABLE	CHTBL3 DSBL		1: Enable		
Channel					
Copy from STD	CHSETSTD				
Input					
RF	INPUT RF	INPUT?	0: RF		
Baseband(I&Q)	INPUT IQ		1: Baseband(I&Q)		
BaseBand Input					
AC	BBINPUT AC	BBINPUT?	0: AC		
DC	BBINPUT DC		1: DC		
IQ Inverse					
NORMAL	IQMD NORM	IQMD?	0: NORMAL		
INVERSE	IQMD INV		1: INVERSE		
Auto Level Setting					
Auto Level OFF	ALS OFF	ALS?	0: OFF		
Auto Level ON	ALS ON		1: ON		
DC CAL	CLDC				

4.2 GPIB Command Codes

Table 4-12 TRASIENT Key

Function	Listener Code	Talker Request		Remarks	
		Code	Output Format		
T-Domain Power	Auto Level Set	AUTOWFL TDPAUTOLVL			
	Trigger Setup				
	Trigger Source				
	FREERUN	TRGSRC FREE TDPTRGSRC FREE	TRGSRC? TDPTRGSRC?	0: FREERUN 1: VIDEO	
	VIDEO	TRGSRC VIDEO TDPTRGSRC VIDEO		2: IF 3: EXT	
	IF	TRGSRC IF TDPTRGSRC IF			
	EXT	TRGSRC EXT TDPTRGSRC EXT			
	Trigger Slope				
	+	TRGSLP RISE TDPTRGSLP RISE	TRGSLP? TDPTRGSLP?	0: - 1: +	
	-	TRGSLP FALL TDPTRGSLP FALL			
	Trigger Level	TRGLVL * TDPTRGLVL *	TRGLVL? TDPTRGLVL?	Integer (0 to 100)	
	Trigger Position	TRGPOS * TDPTRGPOS *	TRGPOS? TDPTRGPOS?	Integer (0 to 100)	
	Trigger Delay	TRGDT * TDPTRGDT *	TRGDT? TDPTRGDT?	Time	
	Window Setup				
	Window				
ON	TDPWDO ON	TDPWDO?	0: OFF		
OFF	TDPWDO OFF		1: ON		
Window Position	TDPWPOS *	TDPWPOS?	Time		
Window Width	TDPWWID *	TDPWWID?	Time		
Y Scale					
10dB/div	TDPDIV P10DB	TDPDIV?	0: 10dB/div		
5dB/div	TDPDIV P5DB		1: 5dB/div		
2dB/div	TDPDIV P2DB		2: 2dB/div		
Average Times	TDPAVG *	TDPAVG?	Integer (1: OFF, 2 to 999)		

Table 4-12 TRASIENT Key

Function	Listener Code	Talker Request		Remarks
		Code	Output Format	
T-Domain Power	Template			
	Template			
	ON	TDPTMPL ON	TDPTMPL?	0: OFF
	OFF	TDPTMPL OFF		1: ON
	Template Shift			
	Shift X	TDPTMPLSX *	TDPTMPLSX?	Time
	Shift Y	TDPTMPLSY *	TDPTMPLSY?	Level
	Template Edit			
	Template UP/LOW Selection	TDPTMPLSEL UP TDPTMPLSEL LOW	TDPTMPLSEL?	0: UP 1: LOW
	Copy from STD Template	TDPTMPLCP		
Data Input	TDPTMPLED *,*		t1,l1 t1: Time l1: Level (dBm/W/dBμV)	
Init Table	TDPTMPLCLR			
Parameter Setup				
Detector				
Normal	TDPDET NRM	TDPDET?	0: Normal	
Posi	TDPDET POS		1: Posi	
Nega	TDPDET NEG		2: Nega	
Sample	TDPDET SMP		3: Sample	
Display Unit				
dBm	TDPUNIT DBM	TDPUNIT?	0: dBm	
W	TDPUNIT W		1: W	
dBμV	TDPUNIT DBUV		2: dBμV	
Template Couple to Power				
ON	TDPTMPLPW ON	TDPTMPLPW?	0: OFF	
OFF	TDPTMPLPW OFF		1: ON	
Template Limit	TDPTMPLBTM *	TDPTMPLBTM?	Level (dBm/W/dBμV)	
Judgement				
ON	TDPJDG ON	TDPJDG?	0: OFF	
OFF	TDPJDG OFF		1: ON	

4.2 GPIB Command Codes

Table 4-12 TRASIENT Key

Function	Listener Code	Talker Request		Remarks	
		Code	Output Format		
T-Domain Power	Upper Limit	TDPJDGUP *	TDPJDGUP?	Level	
	Lower Limit	TDPJDGLOW *	TDPJDGLOW?	Level	
	Set to STD	TDPSETSTD			
	Starts measurement T-Domain Power	WAVEFM TDPMEAS			
	Starts measurement in the same mode	SI			
Measurement results T-Domain Power		TDPMEAS?	11, j1 11: Level (dBm/W/dBµV) j1: Integer (0: FAIL, 1: PASS, -1: Judgement OFF)		
ON/OFF Ratio	Auto Level Set	OORAUTOLVL			
	Trigger Setup				
	Trigger Source				
	FREERUN	OORTRGSRC FREE	OORTRGSRC?	0: FREERUN	
	VIDEO	OORTRGSRC VIDEO		1: VIDEO	
	IF	OORTRGSRC IF		2: IF	
	EXT	OORTRGSRC EXT		3: EXT	
	Trigger Slope				
	+	OORTRGSLP RISE	OORTRGSLP?	0: -	
	-	OORTRGSLP FALL		1: +	
	Trigger Level	OORTRGLVL*	OORTRGLVL?	Integer (0 to 100)	
	Trigger Position	OORTRGPOS *	OORTRGPOS?	Integer (0 to 100)	
	Trigger Delay	OORTRGDT *	OORTRGDT?	Time	
	Window Setup				
Window					
ON	OORWDO ON	OORWDO?	0: OFF		
OFF	OORWDO OFF		1: ON		
ON Position	OORWONPOS *	OORWONPOS?	Time		
ON Width	OORWONWID *	OORWONWID?	Time		
OFF Position	OORWOFPOS *	OORWOFPOS?	Time		
OFF Width	OORWOFWID *	OORWOFWID?	Time		

Table 4-12 TRASIENT Key

Function	Listener Code	Talker Request		Remarks
		Code	Output Format	
ON/OFF Ratio	Y Scale			
	10dB/div	OORDIV P10DB	OORDIV?	0: 10dB/div
	5dB/div	OORDIV P5DB		1: 5dB/div
	2dB/div	OORDIV P2DB		2: 2dB/div
	Average Times	OORAVG *	OORAVG?	Integer (1: OFF, 2 to 999)
	Parameter Setup			
	Detector			
	Normal	OORDET NRM	OORDET?	0: Normal
	Posi	OORDET POS		1: Posi
	Nega	OORDET NEG		2: Nega
	Sample	OORDET SMP		3: Sample
	Display Unit			
dBm	OORUNIT DBM	OORUNIT?	0: dBm	
W	OORUNIT W		1: W	
dBµV	OORUNIT DBUV		2: dBµV	
Judgement				
ON	OORJDG ON	OORJDG?	0: OFF	
OFF	OORJDG OFF		1: ON	
Upper Limit	OORJDGUP *	OORJDGUP?	Level	
Set to STD	OORSETSTD			
Starts measurement				
ON/OFF Ratio	OORMEAS			
Starts measurement in the same mode	SI			
Measurement results				
ON/OFF Ratio		OORMEAS?	11,12,d1,j1 11: ON Level (dBm/W/dBµV) 12: OFF Level (dBm/W/dBµV) d1: ON/OFF Ratio(dB) j1: Integer (0: FAIL, 1: PASS, -1: Judgement OFF)	

4.2 GPIB Command Codes

Table 4-12 TRASIENT Key

Function	Listener Code	Talker Request		Remarks	
		Code	Output Format		
T-Domain Spurious	Auto Level Set	TDSAUTOLVL			
	Trigger Setup				
	Trigger Source				
	FREERUN	TDSTRGSRC FREE TRSPMD FREE	TDSTRGSRC? TRSPMD?	0: FREERUN 2: IF 3: EXT	
	IF	TDSTRGSRC IF TRSPMD IF			
	EXT	TDSTRGSRC EXT TDSTRGSRC EXT			
	Trigger Slope				
	+	TDSTRGSLP RISE TRSPSLP RISE	TDSTRGSLP? TRSPSLP?	0: - 1: +	
	-	TDSTRGSLP FALL TRSPSLP FALL			
	Trigger Level	TDSTRGLVL *	TDSTRGLVL?	Integer (0 to 100)	
	Trigger Position	TDSTRGPOS *	TDSTRGPOS?	Integer (0 to 100)	
	Trigger Delay	TDSTRGDT *	TDSTRGDT?	Time	
	Table				
	Table No. 1/2/3	TDSTBL *	TDSTBL?	Integer (1 to 3)	
Table Edit	TDSTBLED *,*		f1,l1 f1:Frequency l1:Limit Level		
Load Table	TDSL RCLTBL *		Integer (1 to 3)		
Save Table	TDSSV SVSTBL *		Integer (1 to 3)		
Init Table	TDSCLR DELSTBL				
Table Freq. Input					
ABS	TDSTBLF ABS	TDSTBLF?	0: ABS		
REL	TDSTBLF REL		1: REL		
Average Times	TDSAVG *	TDSAVG?	Integer (1: OFF, 2 to 999)		

Table 4-12 TRASIEN Key

Function	Listener Code	Talker Request		Remarks
		Code	Output Format	
T-Domain Spurious	Parameter Setup			
	Detector			
	Normal	TDSDET NRM	TDSDET?	0: Normal
	Posi	TDSDET POS		1: Posi
	Nega	TDSDET NEG		2: Nega
	Sample	TDSDET SMP		3: Sample
	Display Unit			
	dBm	TDSUNIT DBM	TDSUNIT?	0: dBm
	W	TDSUNIT W		1: W
	dBµV	TDSUNIT DBUV		2: dBµV
	Judgement			
	ON	TDSJDG ON	TDSJDG?	0: OFF
	OFF	TDSJDG OFF		1: ON
	Result			
Peak	TDSRES PK	TDSRES?	0: Peak	
RMS	TDSRES RMS		1: RMS	
Multiplier	TDSMULTI *	TDSMULTI?	Real Number	
Peak Marker Y-Delta	TDSPKMKY *	TDSPKMKY?	Real Number	
Preselector 1.6G	TDSPRE 16G	TDSPRE?	0: 1.6G	
3.6G	TDSPRE 36G		1: 3.6G	
Cont Auto Level				
ON	TDSCONTALS ON	TDSCONTALS?	0: OFF	
OFF	TDSCONTALS OFF		1: ON	
Set to Default	TDSSETSTD			
Starts measurement				
Spurious	TDSMEAS SPUR			
Starts measurement in the same mode	SI			

4.2 GPIB Command Codes

Table 4-12 TRASIENT Key

Function		Listener Code	Talker Request		Remarks
			Code	Output Format	
T-Domain Spurious	Measurement results Spurious		TDSMEAS?	n<CR+LF>+f1,l1,j1<CR+LF> +fn,ln,jn<CR+LF> n: Amount (Integer) fn: Frequency ln: Level (dBm/W/dBµV) jn: Integer (0: FAIL, 1: PASS, -1: Judgement OFF)	
			SPULVL?	n<CR+LF>+f1,l1<CR+LF> +fn,ln<CR+LF> n: Amount (Integer) fn: Frequency ln: Level (dBm)	
F-Domain Power	Auto Level Set	FDPAUTOLVL			
	Gate Setup				
	ON	TGTSETUP ON	TGTSETUP?	0: OFF	
	OFF	TGTSETUP OFF		1: ON	
	Trigger Source				
	FREERUN	TGTTRG FREE	TGTTRG?	0: FREERUN	
	VIDEO	TGTTRG VIDEO		1: VIDEO	
	IF	TGTTRG IF		2: IF	
	EXT	TGTTRG EXT		3: EXT	
	Trigger Slope				
	-	TGTTRGSLP FALL	TGTTRGSLP?	0: -	
	+	TGTTRGSLP RISE		1: +	
	Trigger Level	TGTTRGLVL *	TGTTRGLVL?	Integer (0 to 100)	
Trigger Position	TGTTRGPOS *	TGTTRGPOS?	Integer (0 to 100)		
Trigger Delay	TGTTRGDT *	TGTTRGDT?	Time		
Gate Source					
Trigger	TGTSRC TRG	TGTSRC?	0: Trigger		
Ext Gate	TGTSRC EXT		1: EXT		
Gate Position	TGTPOS *	TGTPOS?	Time		
Gate Width	TGTWID *	TGTWID?	Time		

Table 4-12 TRASIENT Key

Function	Listener Code	Talker Request		Remarks
		Code	Output Format	
F-Domain Power	Detector			
	Normal	TGTDET NRM	TGTDET?	0: Normal
	Posi	TGTDET POS		1: Posi
	Nega	TGTDET NEG		2: Nega
	Sample	TGTDET SMP		3: Sample
	Gated Sweep ON/OFF			
	ON	TGTSWP ON	TGTSWP?	0: OFF
	OFF	TGTSWP OFF		1: ON
	Window Setup			
	Window			
	ON	FDPWDO ON	FDPWDO?	0: OFF
	OFF	FDPWDO OFF		1: ON
	Window Position	FDPWPOS *	FDPWPOS?	Frequency
	Window Width	FDPWWID *	FDPWWID?	Frequency
	Y Scale			
	10dB/div	FDPDIV P10DB	FDPDIV?	0: 10dB/div
	5dB/div	FDPDIV P5DB		1: 5dB/div
	2dB/div	FDPDIV P2DB		2: 2dB/div
	Average Times	FDPAVG *	FDPAVG?	Integer (1: OFF, 2 to 999)
Parameter Setup				
Detector				
Normal	FDPDET NRM	FDPDET?	0: Normal	
Posi	FDPDET POS		1: Posi	
Nega	FDPDET NEG		2: Nega	
Sample	FDPDET SMP		3: Sample	
Display Unit				
dBm	FDPUNIT DBM	FDPUNIT?	0: dBm	
W	FDPUNIT W		1: W	
dB μ V	FDPUNIT DBUV		2: dB μ V	
Judgement				
ON	FDPJDG ON	FDPJDG?	0: OFF	
OFF	FDPJDG OFF		1: ON	
Upper Limit	FDPJDGUP *	FDPJDGUP?	Level (dBm/W/dB μ V)	
Lower Limit	FDPJDGLOW *	FDPJDGLOW?	Level (dBm/W/dB μ V)	
Set to STD	FDPSETSTD			

4.2 GPIB Command Codes

Table 4-12 TRASIENT Key

Function		Listener Code	Talker Request		Remarks
			Code	Output Format	
F-Domain Power	Starts measurement F-Domain Power	FDPMEAS			
	Starts measurement in the same mode	SI			
	Measurement results F-Domain Power		FDPMEAS?	l1, j1 l1: Level (dBm/W/dBµV) j1: Integer (0: FAIL, 1: PASS, -1: Judgement OFF)	
OBW	Auto Level Set	OBWAUTOLVL			
	OBW%	OBWPER *	OBWPER?	Real Number (0.5 to 99.5)	
	Average Times	OBWAVG *	OBWAVG?	Integer (1: OFF, 2 to 999)	
	Parameter Setup				
	Detector				
	Normal	OBWDET NRM	OBWDET?	0: Normal	
	Posi	OBWDET POS		1: Pos	
	Nega	OBWDET NEG		2: Nega	
	Sample	OBWDET SMP		3: Sample	
	Judgement				
ON	OBWJDG ON	OBWJDG?	0: OFF		
OFF	OBWJDG OFF		1: ON		
Upper Limit	OBWJDGUP *	OBWJDGUP?	Frequency		
Lower Limit	OBWJDGLOW *	OBWJDGLOW?	Frequency		
Set to STD	OBWSETSTD				
Starts measurement OBW	OBWMEAS				
Starts measurement in the same mode	SI				
Measurement results OBW		OBWMEAS?	f1,f2,f3,j1 f1: OBW frequency f2: Lower side frequency f3: Higher side frequency j1: Integer (0: FAIL, 1: PASS, -1: Judgement OFF)		

Table 4-12 TRASIENT Key

Function	Listener Code	Talker Request		Remarks	
		Code	Output Format		
Due to Transient	Auto Level Set	DTSAUTOLVL			
	Template				
	Template				
	ON	DTSTMPL ON	DTSTMPL?	0: OFF	
	OFF	DTSTMPL OFF		1: ON	
	Template Shift				
	Shift X	DTSTMPLSX *	DTSTMPLSX?	Frequency	
	Shift Y	DTSTMPLSY *	DTSTMPLSY?	Level	
	Margin delta X	DTSTMPLDX *	DTSTMPLDX?	Frequency (0: OFF)	
	Copy from STD	DTSTMPLCP			
	Data Input	DTSTMPLD *,*		f1,l1 f1: Frequency l1: Level (dBm/W/dBμV)	
	Init Table	DTSTMPLCLR			
	Marker Edit				
	Copy from STD	DTSMKRCP			
	Data Input	DTSMKRED *,*,*,*		d1,f1,f2,l1 d1: (0: Normal 1: Integral 2: √Nyquist) f1: Offset frequency f2: Bandwidth l1: Limit Level	(*1)
Init Table	DTSMKRCLR				
Average Times	DTSAVG *	DTSAVG?	Integer (1: OFF, 2 to 999)		
Parameter Setup					
Detector					
Normal	DTSEDET NRM	DTSEDET?	0: Normal		
Posi	DTSEDET POS		1: Posi		
Nega	DTSEDET NEG		2: Nega		
Sample	DTSEDET SMP		3: Sample		

(*1) After the table has been initialized using an appropriate listener code, the parameters d1 and f2 defined in the first command correspond to the reference MKR type and reference band width setting, respectively (the values assigned to f1 and l1 are ignored).

The parameter d1 of the second command corresponds to the offset MKR type. Even if the setting of the command parameter d1 is changed from the third command onwards, the new settings are ignored.

4.2 GPIB Command Codes

Table 4-12 TRASIENT Key

Function	Listener Code	Talker Request		Remarks
		Code	Output Format	
Due to Transient	Display Unit			
	dBm	DTSUNIT DBM	DTSUNIT?	0: dBm
	W	DTSUNIT W		1: W
	dBµV	DTSUNIT DBUV		2: dBµV
	Template Couple to Power			
	ON	DTSTMPLPW ON	DTSTMPLPW?	0: OFF
	OFF	DTSTMPLPW OFF		1: ON
	Template Limit	DTSTMPLBTM *	DTSTMPLBTM?	Level (dBm/W/dBµV)
	Judgement			
	ON	DTSJDG ON	DTSJDG?	0: OFF
	OFF	DTSJDG OFF		1: ON
	Freq. Setting			
	CFSP	DTSFRMD CFSP	DTSFRMD?	0: Center/Span Mode
	STSP	DTSFRMD STSP		1: Start/Stop Mode
	Result Type			
ABS	DTSRES ABS	DTSRES?	0: Absolute	
REL	DTSRES REL		1: Relative	
MKR	DTSRES MKR		2: Marker	
Reference Power				
MKR	DTSREF MKR	DTSREF?	0: Reference Marker	
MOD	DTSREF MOD		1: Modulation	
Symbol Rate 1/T	DTSSYMRT *	DTSSYMRT?	Frequency	
Rolloff Factor	DTSRFACT *	DTSRFACT?	Real Number	
Set to STD	DTSSSETSTD			
Starts measurement				
Due to Transient	DTSMEAS			
Starts measurement in the same mode	SI			
Measurement results				
Due to Transient		DTSMEAS?	n<CR+LF>+d1,j1<CR+LF>" +dn,jn<CR+LF> n: Amount(Integer) dn: Power jn: Integer (0: FAIL, 1: PASS, -1: Judgement OFF)	
Ref. Power	-	DTSREFPWR?	Level	

Table 4-12 TRASIENT Key

Function	Listener Code	Talker Request		Remarks	
		Code	Output Format		
Due to Modulation	Auto Level Sct	DTMAUTOLVL			
	Gate Setup				
	ON	TGTSETUP ON	TGTSETUP?	0: OFF	
	OFF	TGTSETUP OFF		1: ON	
	Trigger Source				
	FREERUN	TGTTRG FREE	TGTTRG?	0: FREERUN	
	VIDEO	TGTTRG VIDEO		1: VIDEO	
	IF	TGTTRG IF		2: IF	
	EXT	TGTTRG EXT		3: EXT	
	Trigger Slope				
	-	TGTTRGSLP FALL	TGTTRGSLP?	0: -	
	+	TGTTRGSLP RISE		1: +	
	Trigger Level	TGTTRGLVL *	TGTTRGLVL?	Integer (0 to 100)	
	Trigger Position	TGTTRGPOS *	TGTTRGPOS?	Integer (0 to 100)	
	Trigger Delay	TGTTRGDT *	TGTTRGDT?	Time	
	Gate Source				
	Trigger	TGTSRC TRG	TGTSRC?	0: Trigger	
	Ext Gate	TGTSRC EXT		1: EXT	
	Gate Position	TGTPOS *	TGTPOS?	Time	
	Gate Width	TGTWID *	TGTWID?	Time	
	Detector				
Normal	TGTDET NRM	TGTDET?	0: Normal		
Posi	TGTDET POS		1: Posi		
Nega	TGTDET NEG		2: Nega		
Sample	TGTDET SMP		3: Sample		
Gated Sweep ON/OFF					
ON	TGTSWP ON	TGTSWP?	0: OFF		
OFF	TGTSWP OFF		1: ON		
Template					
Template					
ON	DTMTMPL ON	DTMTMPL?	0: OFF		
OFF	DTMTMPL OFF		1: ON		
Template Shift					
Shift X	DTMTMPLSX *	DTMTMPLSX?	Frequency		
Shift Y	DTMTMPLSY *	DTMTMPLSY?	Level		
Margin delta X	DTMTMPLDX *	DTMTMPLDX?	Frequency (0: OFF)		

4.2 GPIB Command Codes

Table 4-12 TRASIENT Key

Function	Listener Code	Talker Request		Remarks	
		Code	Output Format		
Due to Modulation	Copy from STD	DTMTMPLCP			
	Data Input	DTMTMPLED *,*		f1,l1 f1: frequency l1: Level (dBm/W/dBμV)	
	Init Table	DTMTMPLCLR			
	Marker Edit				
	Copy from STD	DTMMKRCP			
	Data Input	DTMMKRED *,*,*,*		d1,f1,f2,l1 d1: (0: Normal 1: Integral 2: √Nyquist)) f1: Offset frequency f2: Bandwidth l1: Limit Level	(*1)
	Init Table	DTMMKRCLR			
	Average Times	DTMAVG *	DTMAVG?	Integer (1: OFF, 2 to 999)	
	Parameter Setup				
	Detector		DTMDET?		
	Normal	DTMDET NRM		0: Normal	
	Posi	DTMDET POS		1: Posi	
	Nega	DTMDET NEG		2: Nega	
	Sample	DTMDET SMP		3: Sample	
Display Unit		DTMUNIT?			
dBm	DTMUNIT DBM		0: dBm		
W	DTMUNIT W		1: W		
dBμV	DTMUNIT DBUV		2: dBμV		
Template Couple to Power					
ON	DTMTMPLPW ON	DTMTMPLPW?	0: OFF		
OFF	DTMTMPLPW OFF		1: ON		
Template Limit	DTMTMPLBTM *	DTMTMPLBTM?	Level (dBm/W/dBμV)		

(*1) After the table has been initialized using an appropriate listener code, the parameters d1 and f2 defined in the first command correspond to the reference MKR type and reference band width setting, respectively (the values assigned to f1 and l1 are ignored).

The parameter d1 of the second command corresponds to the offset MKR type. Even if the setting of the command parameter d1 is changed from the third command onwards, the new settings are ignored.

Table 4-12 TRASIENT Key

Function	Listener Code	Talker Request		Remarks	
		Code	Output Format		
Due to Modulation	Judgement ON OFF	DTMJDG ON DTMJDG OFF	DTMJDG?	0: OFF 1: ON	
	Freq. Setting CFSP STSP	DTMFRMD CFSP DTMFRMD STSP	DTMFRMD?	0: Center/Span Mode 1: Start/Stop Mode	
	Result Type ABS REL MKR	DTMRES ABS DTMRES REL DTMRES MKR	DTMRES?	0: Absolute 1: Relative 2: Marker	
	Reference Power MKR MOD	DTMREF MKR DTMREF MOD	DTMREF?	0: Reference Marker 1: Modulation	
	Symbol Rate 1/T	DTMSYMRT *	DTMSYMRT?	Frequency	
	Rolloff Factor	DTMRFAC *	DTMRFAC?	Real Number	
	Set to STD	DTMSETSTD			
	Start measurement Due to Modulation Starts measurement in the same mode	DTMMEAS SI			
	Measurement results Due to Modulation		DTMMEAS?	n<CR+LF>+d1, j1<CR+LF>+dn,jn<CR+LF> n: Amount (Integer) dn: Power jn: Integer (0: FAIL, 1: PASS, -1: Judgement OFF)	
	Ref. Power	-	DTMREFPWR?	Level	

4.2 GPIB Command Codes

Table 4-12 TRASIENT Key

Function	Listener Code	Talker Request		Remarks	
		Code	Output Format		
Inband Spurious	Auto Level Set	DTMAUTOLVL			
	Template				
	Template				
	ON	SPRTMPL ON	SPRTMPL?	0: OFF	
	OFF	SPRTMPL OFF		1: ON	
	Template Shift				
	Shift X	SPRTMPLSX *	SPRTMPLSX?	Frequency	
	Shift Y	SPRTMPLSY *	SPRTMPLSY?	Level	
	Margin delta X	SPRTMPLDX *	SPRTMPLDX?	Frequency (0: OFF)	
	Copy from STD	SPRTMPLCP			
	Data Input	SPRTMPLED *,*		f1,l1 f1: Frequency l1: Level (dBm/W/dBµV)	
	Init Table	SPRTMPLCLR			
	Marker Edit				
	Copy from STD	SPRMKRCP			
	Data Input	SPRMKRED *,*,*,*		d1, f1,f2,l1 d1: (0: Peak, 1: Integral) f1: Start Frequency f2: Stop Frequency l1: Limit Level	(*1)
Init Table	SPRMKRCLR				
Average Times	SPRAVG *	SPRAVG?	Integer (1: OFF, 2 to 999)		
Parameter Setup					
Detector					
Normal	SPRDET NRM	SPRDET?	0: Normal		
Posi	SPRDET POS		1: Posi		
Nega	SPRDET NEG		2: Nega		
Sample	SPRDET SMP		3: Sample		

(*1) After the table has been initialized using an appropriate listener code, the parameters d1 and f2 defined in the first command correspond to the reference MKR type and reference band width setting, respectively. Even if the setting of the command parameter d1 is changed from the next command onwards, the new settings are ignored.

Table 4-12 TRASIENT Key

Function	Listener Code	Talker Request		Remarks
		Code	Output Format	
Inband Spurious	Display Unit			
	dBm	SPRUNIT DBM	SPRUNIT?	0: dBm
	W	SPRUNIT W		1: W
	dB μ V	SPRUNIT DBUV		2: dB μ V
	Template Couple to Power			
	ON	SPRTMPLPW ON	SPRTMPLPW?	0: OFF
	OFF	SPRTMPLPW OFF		1: ON
	Template Limit	SPRTMPLBTM *	SPRTMPLBTM?	Level (dBm/W/dB μ V)
	Judgement			
	ON	SPRJDG ON	SPRJDG?	0: OFF
	OFF	SPRJDG OFF		1: ON
	Freq. Setting			
CFSP	SPRFRMD CFSP	SPRFRMD?	0: Center/Span Mode	
STSP	SPRFRMD STSP		1: Start/Stop Mode	
Result Type				
ABS	SPRRES ABS	SPRRES?	0: Absolute	
REL	SPRRES REL		1: Relative	
MKR	SPRRES MKR		2: Marker	
Reference Power				
MKR	SPRREF MKR	SPRREF?	0: Reference Marker	
MOD	SPRREF MOD		1: Modulation	
Peak Marker Y-Delta	SPRPMKY *	SPRPMKY?	Real Number	
Set to STD	SPRSETSTD			

4.2 GPIB Command Codes

Table 4-12 TRASIENT Key

Function		Listener Code	Talker Request		Remarks
			Code	Output Format	
Inband Spurious	Starts measurement				
	Inband Spurious	SPRMEAS			
	Starts measurement in the same mode	SI			
	Measurement results Inband spurious		SPRMEAS?	n<CR+LF>+f1,l1,j1<CR+LF> +fn,ln,jn<CR+LF> n: Amount (Integer) fn: Frequency ln: Level (dBm/W/dBuV) jn: Integer (0: FAIL, 1: PASS, -1: Judgement OFF)	
Ref. Power	-	SPRREFPWR?	Level		
Outband Spurious	Auto Level Sct	FDSAUTOLVL			
	Table				
	Table No.1/2/3	FDSTBL *	FDSTBL?	Integer (1 to 3)	
	Table Edit	FDSTBLED *,*,*,*,*		f1,f2,f3,f4,d1,l1 f1: Start Frequency f2: Stop Frequency f3: RBW f4: VBW d1: Sweep Time l1: Limit Level	
	Load Table	FDSLDD			
	Save Table	FDSSV			
	Init Table	FDSCLR			
Average Times	FDSAVG *	FDSAVG?	Integer (1: OFF, 2 to 999)		

Table 4-12 TRASIENT Key

Function	Listener Code	Talker Request		Remarks
		Code	Output Format	
Outband Spurious	Parameter Setup			
	Detector			
	Normal	FDSDET NRM	FDSDET?	0: Normal
	Posi	FDSDET POS		1: Posi
	Nega	FDSDET NEG		2: Nega
	Sample	FDSDET SMP		3: Sample
	Display Unit			
	dBm	FDSUNIT DBM	FDSUNIT?	0: dBm
	W	FDSUNIT W		1: W
	dB μ V	FDSUNIT DBUV		2: dB μ V
Judgement				
ON	FDSJDG ON	FDSJDG?	0: OFF	
OFF	FDSJDG OFF		1: ON	
Peak Marker Y-Delta	FDSPKMKY *	FDSPKMKY?	Real Number	
Preselector 1.6G	FDSPRE 16G	FDSPRE?	0: 1.6G	
3.6G	FDSPRE 36G		1: 3.6G	
Set to Default	FDSSETSTD			
Starts measurement				
Outband Spurious	FDSMEAS			
Starts measurement in the same mode	SI			
Measurement results				
Outband Spurious		FDSMEAS?	n<CR+LF>+f1,l1,j1<CR+LF> +fn,ln,jn<CR+LF> n: Amount (Integer) fn: Frequency ln: Level (dBm/W/dB μ V) jn: Integer (0: FAIL, 1: PASS, -1: Judgement OFF)	

4.2 GPIB Command Codes

Table 4-12 TRASIENT Key

Function	Listener Code	Talker Request		Remarks	
		Code	Output Format		
Tx Power	Auto Level Set	AUTOLVL			
	Trigger Setup				
	Trigger Mode	MODTRG FREE	MODTRG?	0: FREERUN	
	FREERUN	TRGMODE FREE	TRGMODE?		
	IF	MODTRG IF		1: IF	
	EXT	TRGMODE IF			
		MODTRG EXT		2: EXT	
		TRGMODE EXT			
	EXT Trigger Slope				
	+	MODTRGSLP RISE	MODTRGSLP?	0: -	
	-	MODTRGSLP FALL		1: +	
	EXT Trigger Delay				
Time Setting	MODTRGDLY *	MODTRGDLY?	Time		
Slot Setting	MODTRGSLT *	MODTRGSLT?	0 to 2 (FULL RATE)		
IF Trigger Level	MODTRGLVL *	MODTRGLVL?	Integer (0 to 100)		
Burst Search					
Burst Search OFF	MODTRGBRST OFF	MODTRGBRST?	0: OFF		
Burst Search ON	MODTRGBRST ON		1: ON		
Average Times	TXAVG *	TXAVG?	Integer (1: OFF, 2 to 32)		
	TAVGTX *	TAVGTX?			
	TAVGAP *	TAVGAP?			
Starts measurement					
Tx Power	TXPWR				
Starts measurement in the same mode	SI				
Measurement results					
Tx Power		TXPWR?	d1,d2, d3, d4 d1: Burst Power(dBm) d2: Burst Power(W) d3: Frame Power(dBm) d4: Frame Power(W)		

Table 4-12 TRASIENT Key

Function	Listener Code	Talker Request		Remarks	
		Code	Output Format		
Power vs Time	Auto Level Set	AUTOLVL			
	Trigger Setup				
	Trigger Mode				
	FREERUN	MODTRG FREE TRGMODE FREE	MODTRG? TRGMODE?	0: FREERUN	
	IF	MODTRG IF TRGMODE IF		1: IF	
	EXT	MODTRG EXT TRGMODE EXT		2: EXT	
	EXT Trigger Slope				
	+	MODTRGSLP RISE	MODTRGSLP?	0: -	
	-	MODTRGSLP FALL		1: +	
	EXT Trigger Delay				
	Time Setting	MODTRGDLY *	MODTRGDLY?	Time	
	Slot Setting	MODTRGSLT *	MODTRGSLT?	0 to 2 (FULL RATE)	
	IF Trigger Level	MODTRGLVL *	MODTRGLVL?	Integer (%)	
Burst Search					
Burst Search OFF	MODTRGBRST OFF	MODTRGBRST?	0: OFF		
Burst Search ON	MODTRGBRST ON		1: ON		
Average Times	PTAVG *	PTAVG?	Integer (1: OFF, 2 to 32)		
Measurement Mode					
Normal	PTMOD NORM	PTMOD?	0: NORM		
High dynamic range	PTMOD HIGH		1: HIGH		
Y Scale					
20dB/div	PTDIV P20DB	PTDIV?	0: 20dB/div		
10dB/div	PTDIV P10DB		1: 10dB/div		
5dB/div	PTDIV P5DB		2: 5dB/div		

4.2 GPIB Command Codes

Table 4-12 TRASIENT Key

Function		Listener Code	Talker Request		Remarks
			Code	Output Format	
Power vs Time	Template selection	RUTEMP * PTTYP *	RUTEMP? PTTYP?	Integer (Template No.: 1,2,3,4) (#4: STD Template)	
	Template Edit	EUTEMP PDC: d1, d2, d3, d4, d5, d6 PHS, IS-136: d1, d2, d3, d4 PTTENT PDC: d1, d2, d3, d4, d5, d6 PHS, IS-136: d1, d2, d3, d4		PDC: d1 to d6 PHS, IS-136: d1 to d4 level(dB)	Unit of level, dB, is necessary
	Off Level Unit				
	dBm	PTTUNIT DBM	PTTUNIT?	0: dBm	
	dB	PTTUNIT DB		1: dB	
	Average Times	PTAVG *	PTAVG?	Integer (1: OFF, 2 to 32)	
	Starts measurement				
	Power vs Time	RUPDN PWRTM			
Starts measurement in the same mode	SI				
Measurement results					
Burst Power		RUDPWR? PWRTM?	Level(dBm)		
PASS/FAIL		RUDJDG? PTJDG?	0: FAIL 1: PASS		

Table 4-12 TRASIENT Key

Function	Listener Code	Talker Request		Remarks	
		Code	Output Format		
Bit Rate Error	Auto Level Set	AUTOLVL			
	Trigger Setup				
	Trigger Mode				
	FREERUN	MODTRG FREE TRGMODE FREE	MODTRG? TRGMODE?	0: FREERUN	
	IF	MODTRG IF TRGMODE IF		1: IF	
	EXT	MODTRG EXT TRGMODE EXT		2: EXT	
	EXT Trigger Slope				
	+	MODTRGSLP RISE	MODTRGSLP?	0: -	
	-	MODTRGSLP FALL		1: +	
	EXT Trigger Delay				
	Time Setting	MODTRGDLY *	MODTRGDLY?	Time	
	Slot Setting	MODTRGSLT *	MODTRGSLT?	0 to 2 (FULL RATE)	
IF Trigger Level	MODTRGLVL *	MODTRGLVL?	Integer(%)		
Burst Search					
Burst Search OFF	MODTRGBRST OFF	MODTRGBRST?	0: OFF		
Burst Search ON	MODTRGBRST ON		1: ON		
Average Times	BTRAVG *	BTRAVG?	Integer (1: OFF, 2 to 32)		
Starts measurement					
Bit Rate Error	BTR				
Starts measurement in the same mode	SI				
Measurement results					
Bit Rate Error		BITRERR?	d1,d2 d1: Bit Rate Error(ppm) d2: Bit Rate Error(Hz)		

4.2 GPIB Command Codes

Table 4-12 TRASIENT Key

Function	Listener Code	Talker Request		Remarks	
		Code	Output Format		
Modulation Accuracy	Auto Level Set	AUTOLVL			
	Trigger Setup				
	Trigger Mode				
	FREERUN	MODTRG FREE TRGMODE FREE	MODTRG? TRGMODE?	0: FREERUN	
	IF	MODTRG IF TRGMODE IF		1: IF	
	EXT	MODTRG EXT TRGMODE EXT		2: EXT	
	EXT Trigger Slope				
	+	MODTRGSLP RISE	MODTRGSLP?	0: -	
	-	MODTRGSLP FALL		1: +	
	EXT Trigger Delay				
	Time Setting	MODTRGDLY *	MODTRGDLY?	Time	
	Slot Setting	MODTRGSLT *	MODTRGSLT?	0 to 2 (FULL RATE)	
IF Trigger Level	MODTRGLVL *	MODTRGLVL?	Integer(%)		
Burst Search					
Burst Search OFF	MODTRGBRST OFF	MODTRGBRST?	0: OFF		
Burst Search ON	MODTRGBRST ON		1: ON		
Average Times	TAVGMOD *	TAVGMOD?	Integer (1: OFF, 2 to 32)		
Starts measurement					
Modulation Accuracy	MODACC				
Starts measurement in the same mode	SI				
Measurement results					
Modulation Accuracy		MODACC?	d1,d2,d3,d4,d5,d6 d1: Burst Amplitude Droop(dB/symbol) d2: Frequency Error(Hz) d3: I/Q origin off-set(dBc) d4: Magnitude Error d5: Phase Error (deg. rms) d6: Error Vector Magnitude(% rms)		

Table 4-12 TRASIENT Key

Function	Listener Code	Talker Request		Remarks	
		Code	Output Format		
Modulation Accuracy	Modulation Accuracy (10 symbols)		MODACC10?	d1,d2,d3 d1: 10 symbol Magnitude Error(%rms) d2: 10 symbol Phase Error(deg,rms) d3: 10 symbol E.V.M(%rms)	
	Modulation Accuracy (Peak)		MODACCPK?	d1,s1,d2,s2,d3,s3 d1: Peak Magnitude Error(%rms) s1: Position of Peak Mag. Error d2: Peak Phase Error(deg,rms) s2: Position of Peak Phase Error d3: Peak E.V.M(%rms) s3: Position of Peak E.V.M	
OBW (Modulation)	Auto Level Set	AUTOLVL			
	Trigger Setup				
	Trigger Mode				
	FREERUN	MODTRG FREE TRGMODE FREE	MODTRG? TRGMODE?	0: FREERUN	
	IF	MODTRG IF TRGMODE IF		1: IF	
	EXT	MODTRG EXT TRGMODE EXT		2: EXT	
	Trigger Slope				
+	MODTRGSLP RISE	MODTRGSLP?	0: -		
-	MODTRGSLP FALL		1: +		
Trigger Delay					
Time Setting	MODTRGDLY *	MODTRGDLY?	Time		
Slot Setting	MODTRGSLT *	MODTRGSLT?	0 to 2 (FULL RATE)		
IF Trigger Level	MODTRGLVL *	MODTRGLVL?	Integer(%)		

4.2 GPIB Command Codes

Table 4-12 TRASIENT Key

Function		Listener Code	Talker Request		Remarks
			Code	Output Format	
OBW (Modulation)	Burst Search				
	Burst Search OFF	MODTRGBRST OFF	MODTRGBRST?	0: OFF	
	Burst Search ON	MODTRGBRST ON		1: ON	
	Average Times	TAVGOBW?	TOBWAVG?	Integer (1: OFF, 2 to 32)	
Starts measurement					
OBW	TOBW				
Starts measurement in the same mode	SI				
Measurement results					
OBW			TOBW? TOBW1?	OBW OBW, fc OBW: OBW frequency fc: Inband Center frequency(Hz)	
Graphics Selection	Constellation	GPHTYP INP	GPHTYP?	0: Constellation	
	Constellation(Line)	GPHTYP LIN		1: Constellation(Line)	
	Constellation(Dot)	GPHTYP DOT		2: Constellation(Dot)	
	Constellation(Line&Dot)	GPHTYP CON		3: Constellation (Line&Dot)	
	I EYE Diagram	GPHTYP IEYE		4: I EYE Diagram	
	Q EYE Diagram	GPHTYP QEYE		5: Q EYE Diagram	
	I/Q EYE Diagram	GPHTYP IQEYE		6: I/Q EYE Diagram	
	Demodulated Data	GPHTYP DEMOD		7: Demodulated Data	
	E.V.M. vs Symbol	GPHTYP EVM		8: E.V.M. vs Symbol	
	Mag. Error vs Symbol	GPHTYP ME		9: Mag. Error vs Symbol	
Phase Error vs Symbol	GPHTYP PFE		10: Phase Error vs Symbol		
Output data					
Constellation	I-channel data output		GPHI?	n<CR+LF>+d1<CR+LF>++dn<CR+LF>	
Constellation (Line)				n: Number of output	
Constellation (Dot)				dn: Data (Real Number)	

Table 4-12 TRASIENT Key

Function		Listener Code	Talker Request		Remarks
			Code	Output Format	
Constellation (Line & Dot)					
I EYE Diagram	Q-channel data output		GPHQ?	n<CR+LF>+d1<CR+LF>+ F>++dn<CR+LF>	
Q EYE Diagram				n: Number of output	
I&Q EYE Diagram				dn: Data (Real Number)	
Demodulated Data	Demodulated data output		DEM0D?	n<CR+LF>+d1<CR+LF>+ F>++dn<CR+LF>	
				n: Number of output	
				dn: Character string data (1 Data: 10 bit)	
E.V.M. vs Symbol	X data (Symbol number)		GPHX?	n<CR+LF>+d1<CR+LF>+ F>++dn<CR+LF>	
Mag. Error vs Symbol				n: Number of output	
Phase Error vs Symbol	Y data		GPHY?	dn: Data (Integer)	
				n<CR+LF>+d1<CR+LF>+ F>++dn<CR+LF>	
				n: Number of output	
				dn: Data (Real Number)	

4.2 GPIB Command Codes

Table 4-12 TRASIENT Key

Function	Listener Code	Talker Request		Remarks
		Code	Output Format	
ACP	Auto Level Set	TACPAUTOLVL		
	Parameter Setup			
	Trigger Mode			
	FREERUN	MODTRG FREE TRGMODE FREE	MODTRG? TRGMODE?	0: FREERUN
	IF	MODTRG IF TRGMODE IF		1: IF
	EXT	MODTRG EXT TRGMODE EXT		2: EXT
	EXT Trigger Slope			
	+	MODTRGSLP RISE TRGMSLP RISE	MODTRGSLP? TRGMSLP?	0: - 1: +
	-	MODTRGSLP FALL TRGMSLP FALL		
	EXT Trigger Delay			
	Time specification	MODTRGDLY *	MODTRGDLY?	Time
	Slot specification	MODTRGSLT *	MODTRGSLT?	0 to 2 (FULL RATE)
	IF Trigger Level	MODTRGLVL *	MODTRGLVL?	Integer(%)
	Burst Search			
	Burst Search OFF	MODTRGBRST OFF	MODTRGBRST?	0: OFF
	Burst Search ON	MODTRGBRST ON		1: ON
	Search Level	MODBRSTLVL *	MODBRSTLVL?	Level
	ACP Unit			
	dB	TACPRES DB	TACPRES?	0: dB
	dBm	TACPRES DBM		1: dBm
	W	TACPRES W		2: W
	Ref. Level Adjust			
	OFF	TACPLVLADJ OFF	TACPLVLADJ?	0: OFF
	ON	TACPLVLADJ ON		1: ON
	Tx Power			
	Average Times	TACPPWRAVG *	TACPPWRAVG?	Integer (1: OFF, 2 to 32)
	Unit			
	dBm	TACPPWRRES DBM	TACPPWRRES?	0: dBm
	W	TACPPWRRES W		1: W

Table 4-12 TRASIENT Key

Function	Listener Code	Talker Request		Remarks	
		Code	Output Format		
ACP	Sweep Time	TACPSTIME *	TACPSTIME?	Time	
	Sweep Time Default		TACPSTDEF?	0: User Define 1: Default	
	Starts measurement	TACP SI			
	ACP Starts measurement in the same mode				
	Measurement results		TACP? TACPX?	bpwr,p11,p12,pu1,pu2, 0,0,0,0 bpwr,p11,p12,pu1,pu2 bpwr: Burst Power p11: -50kHz p12: -100kHz pu1: 50kHz pu2: 100kHz	
ACP(PHS)		TACP? TACPX?	bpwr,p11,p12,pu1,pu2, 0,0,0,0 bpwr,p11,p12,pu1,pu2 bpwr: Burst Power p11: -600kHz p12: -900kHz pu1: 600kHz pu2: 900kHz		
ACP(IS-136)		TACP? TACPX?	bpwr,p11,p12,p13,pu1, pu2,pu3, 0,0,0,0,0,0 bpwr,p11,p12,p13,pu1, pu2,pu3 bpwr: Burst Power p11: -30kHz p12: -60kHz p13: -90kHz pu1: 30kHz pu2: 60kHz pu3: 90kHz		

4.2 GPIB Command Codes

Table 4-12 TRASIENT Key

Function	Listener Code	Talker Request		Remarks
		Code	Output Format	
ACP	Tx Power		TXPWR?	d1,d2,d3,d4 d1: Burst Power(dBm) d2: Burst Power(W) d3: Frame Power(dBm) d4: Frame Power(W)
ALL Measure- ment	Auto Level Set	AUTOLVL		
	Parameter Setup			
	Trigger Mode			
	FREERUN	MODTRG FREE TRGMODE FREE	MODTRG? TRGMODE?	0: FREERUN
	IF	MODTRG IF TRGMODE IF		1: IF
	EXT	MODTRG EXT TRGMODE EXT		2: EXT
	EXT Trigger Slope			
	+	MODTRGSLP RISE TRGMSLP RISE	MODTRGSLP? TRGMSLP?	0: - 1: +
	-	MODTRGSLP FALL TRGMSLP FALL		
	EXT Trigger Delay			
Time specification	MODTRGDLY *	MODTRGDLY?	Time	
Slot specification	MODTRGSLT *	MODTRGSLT?	0 to 2 (FULL RATE)	
IF Trigger Level	MODTRGLVL *	MODTRGLVL?	Integer(%)	
Burst Search				
Burst Search OFF	MODTRGBRST OFF	MODTRGBRST?	0: OFF	
Burst Search ON	MODTRGBRST ON		1: ON	
Search Level	MODBRSTLVL *	MODBRSTLVL?	Level	
Tx Power Type				
BURST POWER	TXMPWRTYP BURST	TXMPWRTYP?	0: BURST	
FRAME POWER	TXMPWRTYP FRAME		1: FRAME	

Table 4-12 TRASIENT Key

Function	Listener Code	Talker Request		Remarks	
		Code	Output Format		
ALL Measurement	Tx Power Unit dBm W	TXMPWRRES DBM TXMPWRRES W	TXMPWRRES?	0: dBm 1: W	
	ACP Unit dB dBm W	TXMACPRES DB TXMACPRES DBM TXMACPRES W	TXMACPRES?	0: dB 1: dBm 2: W	
	Sweep Time Sweep Time Sweep Time Default	TXMST * TXMSTDEF	TXMST? TXMSTDEF?	Time 0: User Define 1: Default	
	Bit Rate Error Unit ppm bps(Hz)	TXMBTRRES PPM TXMBTRRES BPS	TXMBTRRES?	0: ppm 1: bps(Hz)	
	ACP measurement OFF ON	TACPST OFF TACPST ON	TACPST?	0: OFF 1: ON	
	Bit Rate Error Measurement OFF ON	BTRST OFF BTRST ON	BTRST?	0: OFF 1: ON	
	Average Times	TXMAVG *	TXMAVG?	Integer (1: OFF, 2 to 32)	
	Start measurement ALL Measurement Start measurement in the same mode	TXMEAS SI			
	Measurement results Tx Power		TXPWR?	d1,d2,d3,d4 d1: Burst Power(dBm) d2: Burst Power(W) d3: Frame Power(dBm) d4: Frame Power(W)	
	OBW		TOBW?	OBW	

4.2 GPIB Command Codes

Table 4-12 TRASIENT Key

Function	Listener Code	Talker Request		Remarks
		Code	Output Format	
ALL Measure- ment	ACP(PDC)	TACP?	bpwr,pl1,pl2,pu1,pu2, 0,0,0,0	
		TACPX?	bpwr,pl1,pl2,pu1,pu2 bpwr: Burst Power pl1: -50kHz pl2: -100kHz pu1: 50kHz pu2: 100kHz	
	ACP(PHS)	TACP?	bpwr,pl1,pl2,pu1,pu2, 0,0,0,0	
		TACPX?	bpwr,pl1,pl2,pu1,pu2 bpwr: Burst Power pl1: -600kHz pl2: -900kHz pu1: 600kHz pu2: 900kHz	
	ACP(IS-136)	TACP?	bpwr,pl1,pl2,pl3,pu1, pu2,pu3, 0,0,0,0,0,0	
		TACPX?	bpwr,pl1,pl2,pl3,pu1, pu2,pu3 bpwr: Burst Power pl1: -30kHz pl2: -60kHz pl3: -90kHz pu1: 30kHz pu2: 60kHz pu3: 90kHz	

Table 4-12 TRASIENT Key

Function	Listener Code	Talker Request		Remarks
		Code	Output Format	
ALL Measurement	Modulation Accuracy		MODACC?	d1,d2,d3,d4,d5,d6 d1: Burst Amplitude Droop(dB/symbol) d2: Frequency Error(Hz) d3: I/Q origin offset(dBc) d4: Magnitude Error d5: Phase Error (deg. rms) d6: Error Vector Magnitude(% rms)
	Modulation Accuracy (10 symbols)		MODACC10?	d1,d2,d3 d1: 10 symbol Magnitude Error(%rms) d2: 10 symbol Phase Error(deg.rms) d3: 10 symbol E.V.M(%rms)
	Modulation Accuracy (Peak)		MODACCPK?	d1,s1,d2,s2,d3,s3 d1: Peak Magnitude Error(%rms) s1: Position of Peak Mag. Error d2: Peak Phase Error(deg.rms) s2: Position of Peak Phase Error d3: Peak E.V.M(%rms) s3: Position of Peak E.V.M
	Bit Rate Error		BITRERR?	d1,d2 d1: Bit Rate Error(ppm) d2: Bit Rate Error(Hz)

4.2 GPIB Command Codes

Table 4-13 Numeric Keys/Step Keys/Data Knob/Unit Keys (Entering Data)

Function	Listener Code	Talker Request		Remarks	
		Code	Output Format		
Entering data	0 to 9	0 to 9	-	-	
	. (Decimal point)	.	-	-	
	GHz	GZ	-	-	
	MHz	MZ	-	-	
	kHz	KZ	-	-	
	Hz	HZ	-	-	
	mV	MV	-	-	
	mW	MW	-	-	
	dB	DB	-	-	
	mA	MA	-	-	
	sec	SC	-	-	
	ms	MS	-	-	
	µs	US	-	-	
	ENTER	ENT	-	-	

Table 4-14 Miscellaneous

Function	Listener Code	Talker Request		Remarks
		Code	Output Format	
Miscellaneous	Outputting error number	-	ERRNO?	Integer
	Local	LC	-	-
	Reading GPIB address	-	AD?	Integer (0 to 30)
	Specification of the delimiter			
	CR LF <EOI>	DL0	-	-
	LF	DL1	-	-
	<EOI>	DL2	-	-
	CR LF	DL3	-	-
	LF <EOI>	DL4	-	-
	Service request interruption			
	ON	S0	-	-
	OFF	S1	-	-
	Status clear	S2	-	-
	Service request mask	RQS *	RQS?	Decimal number corresponding to the SRQ bit
Outputting ID of the instrument	-	*IDN?	Manufacturer name (character string), instrument type (character string), 0 and revision (character string)	
Initializing the instrument	*RST	-	-	
Clearing the queues related to the status byte	*CLS	-	-	
Accessing the standard event enable register	*ESE *	*ESE?	Decimal number corresponding to the register bits	
Reading or clearing the standard event enable register	-	*ESR?	Decimal number corresponding to the register bits	
Accessing the service request enable register	*SRE *	*SRE?	Decimal number corresponding to the register bits	
Reading the status byte and MSS bit	-	*STB?	Decimal number corresponding to the status byte	

4.2 GPIB Command Codes

Table 4-14 Miscellaneous

Function		Listener Code	Talker Request		Remarks
			Code	Output Format	
Miscellaneous	Accessing the operation status enable register	OPR *	OPR?	Decimal number corresponding to the register bits	
	Reading or clearing the operation status register	-	OPREVT?	Decimal number corresponding to the register bits	

5 TECHNICAL NOTES

5.1 Measuring Signals Including Multiple Bursts in the Frame in the PDC or IS-136 System




Figure 5-1 Signal with Multiple Bursts in the Frame

For the PDC or IS-136 system, a target slot can be measured by setting Meas Mode of STD Setup to MULTI-BURST even if the signal includes multiple bursts in the frame as shown in Figure 5-1.

When the analyzer measures the slot with the sync word S1, set the parameters in STD Setup as shown below.

[STD Setup]

Meas Mode: MULTI-BURST

Sync Type: SYNC WORD

Sync Word: S1

- (1) When Meas Mode is set to BURST, measurement is possible when a trigger is activated at the position ①. However, the measurement is not possible when a trigger is activated at the position ②.
- (2) However, measurement is always possible by means of setting Meas Mode to MULTI-BURST even if a trigger is activated at the trailing edge of any burst.

In this mode, adjacent slot data is captured and measurement is repeated even though the sync word of the first burst does not match with S1. For this reason, no matter which burst is the first one, measurement is possible by means of using the slot with the sync word of S1 in the frame so long as the trailing edge of the burst is correctly detected.

5.2 Measuring the Signals Including Both Up Link and Down Link Bursts in the Frame in the PHS System




Figure 5-2 Burst Wave Including Both Up Link and Down Link Signals In the Frame

For the PHS system, signals including both up and down-link signals in the frame can be measured as shown in Figure 5-2.

Set STD Setup as shown below.

[STD Setup]

Link: UPLINK

Meas Mode: BURST

Sync Type: UNIQUE WORD

- (1) The signal can be measured using the up-link slot when a trigger position is at ①.
- (2) When a trigger position is at ②, measurement is not possible because the direction of this slot is down-link. When the measurement is not possible, this up-link slot is measured by means of capturing data located on the position automatically shifted by four slots inside the instrument.

As the result, the set signal can be measured even if both up and down-link signals are transmitted.

NOTE: *Even if Link is set to DOWNLINK, the down-link slot can be measured in the same way.*

5.3 Averaging the First 10 Symbols of Error Vector Magnitude in the IS-136 System

5.3 Averaging the First 10 Symbols of Error Vector Magnitude in the IS-136 System

Modulation Accuracy measurement includes First 10 Symbols Mag Err, First 10 Symbols Phase Err and First 10 Symbols E.V.M. measurement parameters. The functions of these parameters are to calculate Magnitude Error, Phase Error and Error Vector Magnitude as average values (rms) of the first 10 symbols out of evaluation symbols in one slot.

For the IS-136 system, there is a measurement item for the average of 10 bursts of Error Vector Magnitude (modulation accuracy). (For more information, refer to Page 31 of TIA/EIA/IS-136.2-A.)

This measurement method calculates the RMS value of 10 bursts using 10 symbols after the rising of the burst for evaluation symbols.

In the Modulation Accuracy measurement, the average of 10 bursts can be measured for First 10 Symbols Mag Err, First 10 Symbols Phase Err and First 10 Symbols E.V.M. with the average times set to 10.

5.4 How to Measure the ACP using the Modulation Menu

5.4 How to Measure the ACP using the Modulation Menu

The ACP measurement in the Modulation menu uses spectrum analyzer’s sweep measurement to comply with the communication standards. (See Table 5-1 for information on how to set the spectrum analyzer.)

As an example of the PDC system, the standard (STD-27) stipulates that at least one burst must be included in one sampling. Therefore, a minimum sweep time of 10 sec is required if there are 501 trace points in the full rate mode (500 points × 20 msec = 10 sec). The definitions necessary to measure the ACP measurement in the PDC system are: the specified bandwidth of the main carrier, the specified bandwidth of the adjacent channel with an offset of 50 kHz, and the alternate channel with an offset of 100 kHz. As a result, it is intended that the measurement time required for the ACP measurement in the Modulation menu be reduced by sweeping only the adjacent and alternate channels.




Figure 5-3 Principle of the Partial Sweeps

The PHS and IS-136 systems use measurement modes similar to the one used in the PDC system. However, the IS-136 system uses Root Nyquist filters that are specified by the standard for each band.

Table 5-1 Spectrum Analyzer’s ACP Measurement Settings in the Modulation Menu

Comm. System	Link or Meas Mode	DEFAULT Sweep Time	Span	RBW	VBW	Trace Detector	Trace point
PDC	UPLINK	10 sec (FULL RATE) 20 sec (HALF RATE)	500 kHz	1 kHz	3 kHz	Positive	501
	DOWNLINK	1.0 sec	500 kHz	1 kHz	3 kHz	Positive	501
PHS	BURST	2.5 sec	2 MHz	3 kHz	10 kHz	Positive	501
	CONTINUOUS	450 msec	2 MHz	3 kHz	10 kHz	Positive	501

Comm. System	Link or Meas Mode	DEFAULT Sweep Time	Span	RBW	VBW	Trace Detector	Trace point
IS-136	UPLINK	10 sec (FULL RATE) 20 sec (HALF RATE)	250 kHz	1 kHz	10 kHz	Positive	501
	DOWNLINK	2.5 sec	250 kHz	1 kHz	10 kHz	Positive	501

5.5 Template Edit function

5.5 Template Edit function

In TRANSIENT mode, the user can change template. It is necessary to pay attention when entering template, because the data can be interpreted as a relative or absolute value, depending on the setting of Template Couple to Power ON/OFF in the Config menu.

The PASS/FAIL judgment is performed and then the result is displayed on the screen, when Template ON/OFF in the Template menu is set to ON.

5.5.1 Template Setting in the T-Domain Measuring Mode

When Template Couple to Power is set to OFF, template (Y axis data) is interpreted as an absolute value. As a result, the template consists of the data you entered.

Use the Shift X/Y keys to adjust the template position over the measured value.

When Template Couple to Power is set to ON, template (Y axis data) is interpreted as a relative value to the average power.




Figure 5-4 Template to Be Set

For example, the above template gives +3 dB and -40 dB of the power during the burst period of the signal. To prepare this template, follow the procedure shown below.

Set the template using the relative value to the average power.




Figure 5-5 Template settings

When you shift the template to the direction of Y axis using Shift X/Y function while the Template Couple to Power is set to ON, the relative value to the average power is: Relative value (set on the template) + Shifted data on Y axis.




Figure 5-6 Template Shifted Using the Shift Y Function

5.5 Template Edit function

5.5.2 Template Setting in the F-Domain Measuring Mode

In F-Domain measurement mode, the carrier frequencies depend on the channel numbers. As a result, use the offset frequency from the carrier frequency for template's X axis data.

Set the carrier frequency on the template to 0 Hz so that you can use plus or minus values for the offset frequencies.

The analyzer sets the template by adding the center frequency currently used to X value in the Shift X menu.




Figure 5-7 Template with the Set Values

Soft menu Margin delta X expands the template frequency by (X/2 to both sides toward plus and minus frequency directions) from the 0 Hz on the template.




Figure 5-8 Template with Margin Delta X.

When Template Couple to Power is set to OFF, template (Y axis data) is interpreted as an absolute value. As a result, the template is made up of the data you entered.

Use the Shift X/Y keys to adjust the template position over the measured value.

When Template Couple to Power is set to ON, template (Y axis data) is interpreted as a relative value to the average power.

When the template is shifted on Y axis using the Shift X/Y function, the relative value to the average power is: Relative value (set on the template) + Shifted data on Y axis.

5.6 Measurement Parameter Settings in Due to Transient, Due to Modulation and Inband Spurious

5.6 Measurement Parameter Settings in Due to Transient, Due to Modulation and Inband Spurious

In TRANSIENT mode, any parameters are compliant with the communication standard when you specify the communication standard. You can also change the measuring frequency and the secondary processing of the measured results.

For the method of changing these, refer to the following.

5.6.1 Marker Edit Function

Measurement frequency can be set using Marker Edit in Due to Transient, Due to Modulation or Inband Spurious function (these three functions are found within the Transient mode). In addition, each limit level can be set using Marker Edit.

(1) Marker Edit used in the Due to Transient and Due to Modulation

The measuring frequency is set using the offset frequency from a carrier frequency. If you set the offset frequency to 200 kHz, the offset frequencies (+200 kHz and -200 kHz) can be measured. The Normal marker, Integral marker and Root Nyquist marker are available.

Normal marker is used to read the level of the frequency previously set, and the Integral marker is used to calculate the power of the bandwidth whose center frequency is specified by Marker Edit.

When Root Nyquist is selected, calculates the power of the bandwidth to which the Root Nyquist filter is applied. Set the Root Nyquist filter at Config in Parameter Setup.




Figure 5-9 Example of Marker Edit Setting

(2) Marker Edit used in the Inband Spurious

Measuring frequency range is set using the offset frequency from the carrier frequency. If you set 3 MHz and 10 MHz, the peak search is performed for two ranges: one of the two offset frequency range is between -3 MHz and -10 MHz; another range is between +3 MHz and +10 MHz.

5.6 Measurement Parameter Settings in Due to Transient, Due to Modulation and Inband Spurious




Figure 5-10 Marker Edit Setting

Peak marker is set using the Peak Marker Y Delta soft key in the Config menu.




Figure 5-11 Example of Peak Marker Y Delta

5.6.2 Measurement results Using Due to Modulation, Due to Transient and Inband Spurious Modes

In spectrum measurements, there are three methods for displaying results of adjacent or alternate adjacent channel leakage power measurements.

- (1) The measured value displays the absolute level of the marker, which is located at an offset frequency from the carrier frequency.
- (2) The ratio of the absolute level of the marker to the absolute level of the carrier is displayed. The marker point is located at an offset frequency from the carrier frequency.
- (3) The value obtained in (2) is multiplied by the level by the power meter. The calculated value is then displayed.

This method is used when the absolute value of the adjacent channel power cannot be measured. The ratio of the adjacent channel power to the carrier power can be measured only when Detector is set to Posi. However, the absolute level cannot be measured.

NOTE: *As for the absolute level of adjacent channel power and the absolute level of carrier frequency, each of these can be defined in two modes:*

- *Level at a specific frequency where the marker is located (the marker level is read in such a case)*
 - *Level calculated from integration to the specified frequency band*
-

To display a measured value in (1), select MARKER on the Result : MARKER/RELATIVE/ABS POWER menu in the Parameter Setup dialog box.

To display the measured value in (2), select RELATIVE.

To display a measured value in (3), select ABS POWER. In addition, use the Marker Edit menu to set up measurement conditions for the carrier power. Set the MKR Type to NORMAL or INTEGRAL in the Reference Marker in order to measure the carrier power.

To measure the power of the bandwidth by integration, Reference MKR Type must be set to INTEGRAL.

To measure a point level (marker reading), Reference MKR Type must set to NORMAL.

To measure adjacent channel power, set Offset MKR Type to NORMAL or INTEGRAL. To measure the carrier power in (2) or (3), there are two methods: one is by setting the Marker Edit to the Reference MKR type (set the Ref Power to REF MARKER. Ref Power is in the Parameter Setup dialog box on the config menu); another is to measure power using the DSP (set the Ref Power to MODULATION. Ref Power is in the Parameter Setup dialog box on the config menu).

When REF MARKER is selected, the carrier power is measured by setting Reference MKR Type in the Marker Edit menu.

When MODULATION is selected, the carrier power is measured by Tx Power (Modulation, Tx Power).

When ABS POWER of the Result is selected from the Parameter Setup dialog box in the Config Menu, the ratio of Offset MKR to Reference MKR is calculated, the measurement value from Tx Power is multiplied by this ratio. Then, the result will be displayed.

5.6.3 Measurement Result of Inband Spurious

In Spurious measurements, there are two methods:

- (1) After searching for the peak on the trace, the frequency and level at the marker are displayed.
- (2) After searching for the peak on the trace, the ratio of the marker level to the carrier level is displayed.
- (3) The calculated level, which is calculated using the result obtained in (2) and the level on the power meter is displayed.

To display the measured value in (1), select **MARKER** on the **Result : MARKER/RELATIVE/ABS POWER** menu in the **Parameter Setup** dialog box. And also, to display the measured value in (2), select **RELATIVE**; for the (3), select **ABS POWER**. The measurement conditions for the carrier power is set up using the **Marker Edit** menu. To measure the carrier power, set **Reference MKR Type** to **PEAK** or **NORMAL**.

To measure the carrier power at the specified frequency, **NORMAL** is set; and to measure the carrier power at the peak on the trace, **PEAK** is set.

To measure the carrier power in (2) or (3), there are two methods: one is by setting the instrument to the **Reference MKR** type in the **Marker Edit** menu; another is by the **DSP**.

When **Ref Power** is set to **REF MARKER**, the carrier power is measured by **Reference MKR Type** in the **Marker Edit** menu.

When **Ref Power** is set to **MODULATION**, the carrier power is measured by the **Tx Power (Modulation, Tx Power)**.

5.7 Mag Error (Magnitude Error)

5.7 Mag Error (Magnitude Error)

Mag Error is defined as shown in Figure 5-12, and the value is calculated using the following formula.

$$\text{Magnitude Error}(i) = \left(\sqrt{I_m(i)^2 + Q_m(i)^2} - \sqrt{I_r(i)^2 + Q_r(i)^2} \right) \times 100$$

$I_m(i), Q_m(i)$: measured value
 $I_r(i), Q_r(i)$: Reference value
 i : Symbol number

5.8 Phase Error

Phase Error is defined as shown in Figure 5-12, and the value is calculated using the following formula.

$$\text{Phase Error}(i) = \tan^{-1}(Q_m(i)/I_m(i)) - \tan^{-1}(Q_r(i)/I_r(i))$$

$I_m(i), Q_m(i)$: measured value
 $I_r(i), Q_r(i)$: Reference value
 i : Symbol number

5.9 E.V.M. (Error Vector Magnitude)

E.V.M. is defined as shown in Figure 5-12, and the value is calculated using the following formula.

$$\text{Error Vector Magnitude (i)} = \sqrt{(\text{Im}(i) - \text{Ir}(i))^2 + (\text{Qm}(i) - \text{Qr}(i))^2} \times 100$$

Im(i), Qm(i) : measured value
 Ir(i), Qr(i) : Reference value
 i : Symbol number




Figure 5-12 Mag Error, Phase Error, E.V.M.

5.10 Block Diagram

5.10 Block Diagram

This section shows the block diagram for the modulation analysis hardware.

The Figure 5-13 shows the modulation analysis part. Therefore the spectrum analyzer part is simplified. The area inside the double lines is the block diagram for the spectrum analyzer, and the part outside that area represents the modulation analysis hardware.




Figure 5-13 Block Diagram

6 PERFORMANCE VERIFICATION TEST

6.1 General

6.1.1 Introduction

This chapter provides R3267 Series performance verification test procedures, item by item as listed in Table 6-1.

Performance verification test will be carried out under following condition.

Temperature range: 20°C to 30°C

Relative Humidity: 85% or less

Table 6-1 Performance Verification Items

No.	Test Items
6.2.1	Modulation Accuracy Measurement for PDC
6.2.2	Modulation Accuracy Measurement for PHS
6.2.3	Modulation Accuracy Measurement for IS-136

6.1.2 Test Equipment

The Table 6-2 lists recommended test equipment.

The equipment needed to perform all of the performance test.

Equipment lists for individual tests are provided in each performance verification test.

In the table, PV is abbreviation of performance verification.

-
- NOTE:**
1. *The R3267 Series with OPT64 to be tested should be warm up for at least 30 minutes before starting test.*
 2. *Make sure that the test equipment used meets its own published specifications.*
 3. *Any equipment that meets the critical specifications given in the table can be substituted for recommended models.*
-

Table 6-2 Equipment List

No.	Description	Specification required	Recommended Model	Manufacturer	Usage
1	RF Cable	BNC(m)-BNC(m), 50 Ω	MI-09	Advantest	PV
2	Adapter	Type N(m)-BNC(f), 50 Ω	JUG-201A-U	Advantest	PV

6.1 General

6.1.3 Calibration Cycle

The performance verifications test should be used to check the spectrum analyzer against its specifications once a year recommended.

6.1.4 Performance Verification Test Record Sheet

The performance verification test record sheets are provided at the end of this chapter.

The test record lists test specification and acceptable limits.

Recommend that make a copy of this table, record the complete test results on the copy, and keep the copy for calibration test record.

This record could prove invaluable in tracking gradual changes in test result over long periods of the time.

6.1.5 Performance Verification Procedures

Typeface conventions used in this manual.

- Panel keys and soft keys are printed in a contrasting typestyle to make them stand out from the text as follows:

Panel keys: Boldface type

Example: **FREQ, FORMAT**

Soft keys: Boldface and Italic

Example: ***Center, Trace Detector***

- When a series of key operations are described using a comma between two keys.
- There are various soft menus used to switch between two states such as ON/OFF and AUTO/MNL.

For example, when turning off the ***Display ON/OFF*** function, the annotation "***Display ON/OFF (OFF)***" is used.

When switching the ***RBW AUTO/MNL*** function to MNL, the annotation "***RBW AUTO/MNL (MNL)***" is used.

6.2 Performance Verification Test Procedure

This section provides performance verification test procedure for R3267 Series OPT 63.

Built-in calibration signal is used for performance verification.

6.2.1 Modulation Accuracy Measurement for PDC

(1) Description

Test carrier frequency accuracy and modulation accuracy for PDC.

(2) Specification

Carrier Frequency Accuracy: $< \pm 5$ Hz

Modulation Accuracy: $< 1\%$

(3) Equipment used

RF Cable: BNC (m)-BNC (m)

Adapter: N (m)-BNC (f)

(4) Setup




Figure 6-1 Setup of Modulation Accuracy Measurement for PDC, PHS and IS-136

(5) Procedure

1. Connect equipment as shown in Figure 6-1.
2. On the R3267 Series, after preset, set control as follow:

Center Frequency: 29.997375 MHz

6.2 Performance Verification Test Procedure

- On the R3267 Series, set the STD parameter as shown Figure 6-2.




Figure 6-2 Setup of Parameter for Phase Accuracy Measurement (PDC)

- On the R3267 Series, press **DC CAL**, **Modulation Accuracy** and **AUTO LEVEL**.
- On the R3267 Series, press **SINGLE** for single sweep.
- After single sweep has completed, record the measurement result in the performance verification record sheet.

6.2.2 Modulation Accuracy Measurement for PHS

- Description

Test carrier frequency accuracy and modulation accuracy for PHS.

- Specification

Carrier Frequency Accuracy: < ±20 Hz

Modulation Accuracy: < 1%

- Equipment used

RF Cable: BNC (m)-BNC (m)

Adapter: N (m)-BNC (f)

(4) Procedure

1. Connect equipment as shown in Figure 6-1.
2. On the R3267 Series, after preset, set control as follow:
Center Frequency: 29.976 MHz
3. On the R3267 Series, set the measurement parameter as shown in Figure 6-3.




Figure 6-3 Setup of Measurement Parameter for Modulation Accuracy (PHS)

4. On the R3267 Series, press **DC CAL**, **Freq Deviation** and **AUTO LEVEL**.
5. On the R3267 Series, press **SINGLE** for single sweep.
6. After single sweep has completed, record the measurement result in the performance verification record sheet.

6.2.3 Modulation Accuracy Measurement for IS-136

(1) Description

Test carrier frequency accuracy and modulation accuracy for IS-136.

(2) Specification

Carrier Frequency Accuracy: < ± 5 Hz

Modulation Accuracy: < 1%

(3) Equipment used

RF Cable: BNC (m)-BNC (m)

Adapter: N (m)-BNC (f)

6.2 Performance Verification Test Procedure

(4) Procedure

1. Connect equipment as shown in Figure 6-1.
2. On the R3267 Series, after preset, set control as follow:
Center Frequency: 29.996963 MHz
3. On the R3267 Series, set the measurement parameter as shown in Figure 6-4.

STD Measurement Parameter Set	
Type :	IS-136 800M IS-136 1.9G
Link :	UPLINK DOWNLINK
Meas Mode :	BURST MULTI-BURST CONTINUOUS
Rate :	FULL RATE HALF RATE
Sync Type :	SYNC WORD NO SYNC WORD
Sync Word :	S1 S2 S3 S4 S5 S6
Root Nyquist Filter :	ON OFF
Freq Meas Range :	NORMAL EXPAND
Filter Mode :	WIDE NARROW
Offset Level :	0.0 dB
Frequency Input :	FREQUENCY CHANNEL
Input :	RF BASEBAND(I&Q)
Baseband Input :	AC DC
IQ Inverse :	NORMAL INVERSE
Cont Auto Level Set :	ON OFF

1 STD

DC CAL

6 Channel Setting

7 STD Setup

Figure 6-4 Setup of Measurement Parameter for Modulation Accuracy (IS-136)

4. On the R3267 Series, press *DC CAL*, *Freq Deviation* and *AUTO LEVEL*.
5. On the R3267 Series, press *SINGLE* for single sweep.
6. After single sweep has completed, record the measurement result in the performance verification test record sheet.

6.3 Performance Verification Test Record Sheet

Model: OPT3264/67/73+64

S/N:

(1) Modulation Accuracy Measurement for PDC

Items	Specification			Result
	Min.	Measured Value	Max.	Pass/Fail
Carrier Frequency Accuracy	-5 Hz		+5 Hz	
Modulation Accuracy	N/A		1%	

(2) Modulation Accuracy Measurement for PHS

Test Items	Specification			Result
	Min.	Measured Value	Max.	Pass/Fail
Carrier Frequency Accuracy	-20 Hz		+20 Hz	
Modulation Accuracy	N/A		1%	

(3) Modulation Accuracy Measurement for IS-136

Test Items	Specification			Result
	Min.	Measured Value	Max.	Pass/Fail
Carrier Frequency Accuracy	-5 Hz		+5 Hz	
Modulation Accuracy	N/A		1%	

7 SPECIFICATIONS

RF input

PDC/IS136 measurement

Characteristics	Description
Measurement frequency range	30 MHz to 3.0 GHz
Input level range	-30dBm to +30 dBm
Frequency error accuracy	$< \pm(\text{Reference frequency accuracy} \times \text{Carrier frequency} + 5 \text{ Hz})$
Frequency error measurement range	
Normal	$< \pm 1.4 \text{ kHz}$
Expand	$< \pm 5 \text{ kHz}$
Modulation accuracy	
Measurement accuracy	$< \pm 1\% \pm(\text{measured value}) \times \pm 2\%$
Transfer rate	$< 1 \text{ ppm}$

PHS measurement

Characteristics	Description
Measurement frequency range	30 MHz to 3.0 GHz
Input level range	-30dBm to +30 dBm
Frequency error accuracy	$< \pm(\text{Reference frequency accuracy} \times \text{Carrier frequency} + 20 \text{ Hz})$
Frequency error measurement range	
Normal	$< \pm 13 \text{ kHz}$
Expand	$< \pm 50 \text{ kHz}$
Modulation accuracy	
Measurement accuracy	$< \pm 1\% \pm(\text{measured value}) \times \pm 2\%$

APPENDIX

A.1 Messages

In this section, the messages that are displayed while the analyzer is being used are described.

Code	Messages	Description
700	System Error. Cannot allocate the required memory.	Fatal Error occurred. Data area for the calculation is insufficient on the memory. Contact a sales representative.
701	System Error. Clock is not operational.	Fatal Error occurred. System clock is not in operation. Contact a sales representative.
702	Modulation Gain CAL error. Check 30 MHz CAL signal for connection.	
703	Modulation DC CAL error. Remove input signals and try again.	
704	Time Out! No Trigger Detected	Time out error on the trigger signal occurred. Check the trigger settings.
705	Input Level is out of Range. Check the Ref. level.	
706	No graph data. Execute measurement.	
708	System Error. Contact qualified engineer.	
710	Auto Level completed !	
711	Auto Level Set can not be succeed. Signal level is not stable.	
715	Frequency Error is out of Meas. Range.	
716	Cannot execute measurement in the selected Meas Mode. Change Meas Mode.	
717	Cannot execute measurement. Set Sync Type SYNC WORD (UNIQUE WORD).	

A.1 Messages

Code	Messages	Description
718	Sync Word (Unique Word) is not detected. Check Sync Word (Unique Word).	
719	Burst signal is not detected. Check Burst length or Ref. level.	
720	Data detection error. Check the input signal.	
721	Modulation Gain CAL error!(#100) Check 30 MHz CAL signal for connection.	
722	Modulation Gain CAL error!(#200) Check 30 MHz CAL signal for connection.	
723	Modulation Gain CAL error!(#300) Check 30 MHz CAL signal for connection.	
724	Modulation Gain CAL error!(#110) Check 30 MHz CAL signal for connection.	
725	Modulation Gain CAL error!(#120) Check 30 MHz CAL signal for connection.	
726	Modulation Gain CAL error!(#210) Check 30 MHz CAL signal for connection.	
727	Modulation Gain CAL error!(#220) Check 30 MHz CAL signal for connection.	
728	Modulation Gain CAL error!(#310) Check 30 MHz CAL signal for connection.	

Code	Messages	Description
729	Modulation Gain CAL error!(#320) Check 30 MHz CAL signal for connection.	
735	Cannot measure Baseband signal.Set Input to RF.	The baseband signal cannot be measured. Set the Input to RF.
750	Handshake error occurred to DSP. Contact qualified engineer.	
751	Cannot Detect Mod. DSP board. Contact qualified engineer.	
795	System Error. Memory test failed. (#0)	A memory error was detected. Contact a sales representative.
796	System Error. Memory test failed. (#1)	A memory error was detected. Contact a sales representative.
797	System Error. Memory test failed. (#2)	A memory error was detected. Contact a sales representative.
798	System Error. Memory test failed. (#3)	A memory error was detected. Contact a sales representative.

Alphabetical Index

	3-12, 3-13, 3-14, 3-15, 3-25, 3-30, 3-36, 3-41, 3-43, 3-45
Demodulated Data	3-18, 3-54
Detector	3-7, 3-8, 3-9, 3-10, 3-11, 3-12, 3-13, 3-14, 3-15, 3-26, 3-28, 3-30, 3-33, 3-34, 3-35, 3-37, 3-40, 3-41, 3-44, 3-46
Display Unit	3-7, 3-8, 3-9, 3-10, 3-12, 3-13, 3-14, 3-15, 3-26, 3-28, 3-30, 3-34, 3-37, 3-42, 3-45, 3-46
Due to Modulation	3-6, 3-39, 5-12
Due to Transient	3-6, 3-36, 5-12

[E]

E.V.M. vs Symbol	3-18, 3-54
EXT Gate	3-10, 3-13, 3-33, 3-40

[F]

F-Domain	3-6, 3-32
Filter Mode	3-21, 3-65, 3-68, 3-71
Freq Meas Range	3-21, 3-64, 3-67, 3-71
Freq. Setting	3-12, 3-13, 3-14, 3-37, 3-41, 3-44
Frequency Input	3-21, 3-65, 3-68, 3-71
Functional Description	3-22

[G]

Gate Position	3-10, 3-13, 3-33, 3-40
---------------------	---------------------------

Gate Setup	3-10, 3-13, 3-32, 3-33, 3-39, 3-40
Gate Source	3-10, 3-13, 3-33, 3-40
Gate Width	3-10, 3-13, 3-33, 3-40
Gated Sweep	3-10, 3-34
Gated Sweep ON/OFF	3-10, 3-13, 3-33, 3-40
GPIO Command Codes	4-8
GPIO Command Index	4-1
Graphics	3-18, 3-54

[I]

I EYE Diagram	3-18, 3-54
I/Q EYE Diagram	3-18, 3-54
Ich & Qch Time	3-20
Ich Time & FFT	3-20
Inband Spurious	3-6, 3-43, 5-13
Inband Spurious Modes	5-12
Input	3-21, 3-65, 3-68, 3-71
Insert Line	3-7, 3-9, 3-12, 3-13, 3-14, 3-15, 3-25, 3-30, 3-36, 3-41, 3-43, 3-45
INTRODUCTION	1-1
IQ Complex FFT	3-20
IQ Inverse	3-21, 3-65, 3-68, 3-72

[J]

Judgment	3-7, 3-8, 3-9, 3-10, 3-11, 3-12, 3-13, 3-14, 3-15, 3-26, 3-28, 3-30, 3-34, 3-35, 3-38, 3-42, 3-45, 3-46
----------------	---

[L]

Link	3-21, 3-63, 3-66, 3-70
Load Table	3-9, 3-15,

	3-29, 3-30, 3-45		3-15, 3-16, 3-17, 3-18, 3-19, 3-20, 3-26, 3-28, 3-30, 3-34, 3-35, 3-37, 3-41, 3-44, 3-46, 3-47, 3-49, 3-50, 3-52, 3-55, 3-56, 3-57, 3-60, 3-61
Lower Limit	3-7, 3-10, 3-11, 3-26, 3-34, 3-35		
[M]			
Mag Error vs Symbol	3-18, 3-54		
Margin ΔX ON/OFF	3-12, 3-13, 3-14, 3-36, 3-40, 3-43		
Marker Edit	3-12, 3-13, 3-14, 3-36, 3-41, 3-43	PDC System Signal	2-1, 2-7
Marker Edit Function	5-10	Peak MKR Y Delta	3-9, 3-14, 3-15, 3-30, 3-44, 3-46
Meas Mode	3-21, 3-63, 3-67, 3-70	PERFORMANCE VERIFICATION	
Meas Mode NORM/HIGH	3-16, 3-49	TEST	6-1
Menu Index	3-1	Phase Error vs Symbol	3-18, 3-54
Menu Map	3-6	Power	3-6, 3-47
Messages	A-1	Power (F-Domain)	3-32
Modulation	3-6, 3-18, 3-47	Power (T-Domain)	3-24
Modulation Accuracy	3-6, 3-53	Power vs Time	3-16, 3-48
Modulation Accuracy Measurement for PDC	6-3	Preselector	3-9, 3-15, 3-30, 3-46
Modulation Accuracy Measurement for PHS	6-4	Product Overview	1-1
Multiplier	3-9, 3-30	[Q]	
[O]			
OBW	3-6, 3-35, 3-52	Q EYE Diagram	3-18, 3-54
OBW%	3-11, 3-35	Qch Time & FFT	3-20
OFF Position	3-8, 3-28	[R]	
OFF Width	3-8, 3-28	Rate	3-21, 3-64, 3-70
OffLevUnit dBm/dB	3-16, 3-49	Record Sheet	6-7
Offset Level	3-21, 3-65, 3-68, 3-71	Ref Power	3-12, 3-13, 3-14, 3-37, 3-42, 3-44
ON Position	3-8, 3-28	Ref. Level Adjust	3-51
ON Width	3-8, 3-28	REFERENCE	3-1
ON/OFF Ratio	3-6, 3-27	REMOTE CONTROL	4-1
OPERATION	2-1	Result	3-9, 3-12, 3-13, 3-14, 3-30, 3-37, 3-42, 3-44
Outband Spurious	3-6, 3-45	Rolloff Factor	3-12, 3-13, 3-38, 3-42
[P]			
Parameter Setup	3-7, 3-8, 3-9, 3-10, 3-11, 3-12, 3-13, 3-14,	Root Nyquist Filter	3-21, 3-64, 3-67, 3-70

Alphabetical Index

[S]

Save Table 3-9, 3-15,
3-30, 3-45

Search Level 3-16, 3-17,
3-18, 3-20,
3-48, 3-50,
3-51, 3-53,
3-55, 3-56,
3-58, 3-61

Select Type 3-18, 3-20,
3-54, 3-59

Self Test Function 1-1

Set to Default 3-9, 3-15,
3-31, 3-46

Set to STD 3-7, 3-8,
3-10, 3-11,
3-12, 3-13,
3-14, 3-25,
3-26, 3-28,
3-33, 3-34,
3-35, 3-38,
3-40, 3-42,
3-45

Shift X 3-7, 3-12,
3-13, 3-14,
3-25, 3-36,
3-40, 3-43

Shift Y 3-7, 3-12,
3-13, 3-14,
3-25, 3-36,
3-40, 3-43

Slope 3-7, 3-8,
3-9, 3-10,
3-13, 3-25,
3-27, 3-29,
3-33, 3-39

Slot Format 3-21, 3-64,
3-67

Slot Number 3-16, 3-17,
3-18, 3-19,
3-20, 3-48,
3-50, 3-51,
3-53, 3-55,
3-57, 3-58,
3-60, 3-62

Sort 3-7, 3-12,
3-13, 3-14,
3-25, 3-36,
3-41, 3-43

SPECIFICATIONS 7-1

Spurious 3-6

Spurious (T-Domain) 3-29

STD 3-6, 3-62

STD Setup 3-6, 3-20,
3-63

STD Template 3-16, 3-49

Sweep Time 3-16, 3-19,
3-20, 3-52,
3-59, 3-61

Symbol Rate 1/T 3-12, 3-13,
3-38, 3-42

Sync Type 3-21, 3-64,
3-67, 3-70

Sync Word 3-21, 3-64,
3-70

[T]

Table Edit 3-9, 3-15,
3-30, 3-45

Table Init 3-7, 3-9,
3-12, 3-13,
3-14, 3-15,
3-25, 3-30,
3-36, 3-41,
3-43, 3-45

Table No. 1/2/3 3-9, 3-15,
3-29, 3-30,
3-45

T-Domain 3-6, 3-24

TECHNICAL NOTES 5-1

Template 3-7, 3-12,
3-13, 3-14,
3-25, 3-36,
3-40, 3-43

Template Couple to Power 3-7, 3-12,
3-13, 3-14,
3-26, 3-38,
3-42, 3-45

Template Edit 3-7, 3-12,
3-13, 3-14,
3-25, 3-36,
3-41, 3-43

Template Entry 3-16, 3-48

Template Limit 3-7, 3-12,
3-13, 3-14,
3-26, 3-38,
3-42, 3-45

Template ON/OFF 3-7, 3-13,
3-14, 3-25,
3-36, 3-40,
3-43

Template UP/LOW 3-25

IMPORTANT INFORMATION FOR ADVANTEST SOFTWARE

PLEASE READ CAREFULLY: This is an important notice for the software defined herein. Computer programs including any additions, modifications and updates thereof, operation manuals, and related materials provided by Advantest (hereafter referred to as "SOFTWARE"), included in or used with hardware produced by Advantest (hereafter referred to as "PRODUCTS").

SOFTWARE License

All rights in and to the SOFTWARE (including, but not limited to, copyright) shall be and remain vested in Advantest. Advantest hereby grants you a license to use the SOFTWARE only on or with Advantest PRODUCTS.

Restrictions

- (1) You may not use the SOFTWARE for any purpose other than for the use of the PRODUCTS.
- (2) You may not copy, modify, or change, all or any part of, the SOFTWARE without permission from Advantest.
- (3) You may not reverse engineer, de-compile, or disassemble, all or any part of, the SOFTWARE.

Liability

Advantest shall have no liability (1) for any PRODUCT failures, which may arise out of any misuse (misuse is deemed to be use of the SOFTWARE for purposes other than its intended use) of the SOFTWARE. (2) For any dispute between you and any third party for any reason whatsoever including, but not limited to, infringement of intellectual property rights.

LIMITED WARRANTY

1. Unless otherwise specifically agreed by Seller and Purchaser in writing, Advantest will warrant to the Purchaser that during the Warranty Period this Product (other than consumables included in the Product) will be free from defects in material and workmanship and shall conform to the specifications set forth in this Operation Manual.
2. The warranty period for the Product (the "Warranty Period") will be a period of one year commencing on the delivery date of the Product.
3. If the Product is found to be defective during the Warranty Period, Advantest will, at its option and in its sole and absolute discretion, either (a) repair the defective Product or part or component thereof or (b) replace the defective Product or part or component thereof, in either case at Advantest's sole cost and expense.
4. This limited warranty will not apply to defects or damage to the Product or any part or component thereof resulting from any of the following:
 - (a) any modifications, maintenance or repairs other than modifications, maintenance or repairs (i) performed by Advantest or (ii) specifically recommended or authorized by Advantest and performed in accordance with Advantest's instructions;
 - (b) any improper or inadequate handling, carriage or storage of the Product by the Purchaser or any third party (other than Advantest or its agents);
 - (c) use of the Product under operating conditions or environments different than those specified in the Operation Manual or recommended by Advantest, including, without limitation, (i) instances where the Product has been subjected to physical stress or electrical voltage exceeding the permissible range and (ii) instances where the corrosion of electrical circuits or other deterioration was accelerated by exposure to corrosive gases or dusty environments;
 - (d) use of the Product in connection with software, interfaces, products or parts other than software, interfaces, products or parts supplied or recommended by Advantest;
 - (e) incorporation in the Product of any parts or components (i) provided by Purchaser or (ii) provided by a third party at the request or direction of Purchaser or due to specifications or designs supplied by Purchaser (including, without limitation, any degradation in performance of such parts or components);
 - (f) Advantest's incorporation or use of any specifications or designs supplied by Purchaser;
 - (g) the occurrence of an event of force majeure, including, without limitation, fire, explosion, geological change, storm, flood, earthquake, tidal wave, lightning or act of war; or
 - (h) any negligent act or omission of the Purchaser or any third party other than Advantest.
5. **EXCEPT TO THE EXTENT EXPRESSLY PROVIDED HEREIN, ADVANTEST HEREBY EXPRESSLY DISCLAIMS, AND THE PURCHASER HEREBY WAIVES, ALL WARRANTIES, WHETHER EXPRESS OR IMPLIED, STATUTORY OR OTHERWISE, INCLUDING, WITHOUT LIMITATION, (A) ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE AND (B) ANY WARRANTY OR REPRESENTATION AS TO THE VALIDITY, SCOPE, EFFECTIVENESS OR USEFULNESS OF ANY TECHNOLOGY OR ANY INVENTION.**
6. **THE REMEDY SET FORTH HEREIN SHALL BE THE SOLE AND EXCLUSIVE REMEDY OF THE PURCHASER FOR BREACH OF WARRANTY WITH RESPECT TO THE PRODUCT.**
7. **ADVANTEST WILL NOT HAVE ANY LIABILITY TO THE PURCHASER FOR ANY INDIRECT, INCIDENTAL, SPECIAL, CONSEQUENTIAL OR PUNITIVE DAMAGES, INCLUDING, WITHOUT LIMITATION, LOSS OF ANTICIPATED PROFITS OR REVENUES, IN ANY AND ALL CIRCUMSTANCES, EVEN IF ADVANTEST HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES AND WHETHER ARISING OUT OF BREACH OF CONTRACT, WARRANTY, TORT (INCLUDING, WITHOUT LIMITATION, NEGLIGENCE), STRICT LIABILITY, INDEMNITY, CONTRIBUTION OR OTHERWISE. TORT (INCLUDING, WITHOUT LIMITATION, NEGLIGENCE), STRICT LIABILITY, INDEMNITY, CONTRIBUTION OR OTHERWISE.**
8. **OTHER THAN THE REMEDY FOR THE BREACH OF WARRANTY SET FORTH HEREIN, ADVANTEST SHALL NOT BE LIABLE FOR, AND HEREBY DISCLAIMS TO THE FULLEST EXTENT PERMITTED BY LAW ANY LIABILITY FOR, DAMAGES FOR PRODUCT FAILURE OR DEFECT, WHETHER ARISING OUT OF BREACH OF CONTRACT, TORT (INCLUDING, WITHOUT LIMITATION, NEGLIGENCE), STRICT LIABILITY, INDEMNITY, CONTRIBUTION OR OTHERWISE.**

CUSTOMER SERVICE DESCRIPTION

In order to maintain safe and trouble-free operation of the Product and to prevent the incurrence of unnecessary costs and expenses, Advantest recommends a regular preventive maintenance program under its maintenance agreement.

Advantest's maintenance agreement provides the Purchaser on-site and off-site maintenance, parts, maintenance machinery, regular inspections, and telephone support and will last a maximum of ten years from the date the delivery of the Product. For specific details of the services provided under the maintenance agreement, please contact the nearest Advantest office listed at the end of this Operation Manual or Advantest's sales representatives.

Some of the components and parts of this Product have a limited operating life (such as, electrical and mechanical parts, fan motors, unit power supply, etc.). Accordingly, these components and parts will have to be replaced on a periodic basis. If the operating life of a component or part has expired and such component or part has not been replaced, there is a possibility that the Product will not perform properly. Additionally, if the operating life of a component or part has expired and continued use of such component or part damages the Product, the Product may not be repairable. Please contact the nearest Advantest office listed at the end of this Operation Manual or Advantest's sales representatives to determine the operating life of a specific component or part, as the operating life may vary depending on various factors such as operating condition and usage environment.

SALES & SUPPORT OFFICES

Advantest Korea Co., Ltd.

22BF, Kyobo KangNam Tower,
1303-22, Seocho-Dong, Seocho-Ku, Seoul #137-070, Korea
Phone: +82-2-532-7071
Fax: +82-2-532-7132

Advantest (Suzhou) Co., Ltd.

Shanghai Branch Office:
Bldg. 6D, NO.1188 Gumei Road, Shanghai, China 201102 P.R.C.
Phone: +86-21-6485-2725
Fax: +86-21-6485-2726

Shanghai Branch Office:
406/F, Ying Building, Quantum Plaza, No. 23 Zhi Chun Road,
Hai Dian District, Beijing,
China 100083
Phone: +86-10-8235-3377
Fax: +86-10-8235-6717

Advantest (Singapore) Pte. Ltd.

438A Alexandra Road, #08-03/06
Alexandra Technopark Singapore 119967
Phone: +65-6274-3100
Fax: +65-6274-4055

Advantest America, Inc.

3201 Scott Boulevard, Suite, Santa Clara, CA 95054, U.S.A
Phone: +1-408-988-7700
Fax: +1-408-987-0691

ROHDE & SCHWARZ Europe GmbH

Mühldorfstraße 15 D-81671 München, Germany
(P.O.B. 80 14 60 D-81614 München, Germany)
Phone: +49-89-4129-13711
Fax: +49-89-4129-13723

ADVANTEST®

<http://www.advantest.co.jp>