

**AS-7074  
INSTRUCTION MANUAL  
FOR  
AG-4311B LCR METER**

**ANDO ELECTRIC CO., LTD.  
Tokyo, Japan**

All rights reserved.

## AG-4311B OPERATING PRECAUTIONS

- Before connecting a capacitor with the apparatus, be sure to discharge the capacitor.

This AG-4311B is provided with a protective circuit which blocks the flow of excessive discharge current from a capacitor connected with the apparatus. However, if a capacitor charged at high voltage (35 V or more) is connected with the apparatus, it may cause damage to the apparatus. To avoid this, be sure to discharge the capacitor to be measured, before connecting it with the apparatus.

## NOTE

Even if once discharged, a capacitor may return to a slightly charged state with the lapse of time, because of the charge absorption effect.

If a charged capacitor is connected with the apparatus, it will be discharged through a direct current resistance (about 153  $\Omega$ ). Since this discharge current may affect the measurement, the measurement should be started after the lapse of time at least ten times longer than the time constant (C·R). This precaution should be observed especially when a large-capacity capacitor is to be measured.

- Before operating the apparatus, please read this manual thoroughly to obtain optimum performance from the apparatus.

## NOTE

Be sure to observe the instructions given in the WARNING, CAUTION, NOTE, and REMARKS in this manual which cover items particularly important to ensure proper and safe operation of the apparatus.

## CONTENTS

|  | PAGE   |
|--|--------|
| <b>SECTION 1 GENERAL INFORMATION</b>                   |        |
| 1.1 INTRODUCTION .....                                 | 1 - 1  |
| 1.2 GENERAL .....                                      | 1 - 1  |
| 1.3 SPECIFICATIONS .....                               | 1 - 3  |
| 1.4 COMPOSITION .....                                  | 1 - 3  |
| <b>SECTION 2 PREPARATION FOR USE</b>                   |        |
| 2.1 INTRODUCTION .....                                 | 2 - 1  |
| 2.2 UNPACKING AND ACCEPTANCE INSPECTION .....          | 2 - 1  |
| 2.3 POWER .....  | 2 - 1  |
| 2.4 POWER CORD .....                                   | 2 - 3  |
| 2.5 REPACKING .....                                    | 2 - 4  |
| <b>SECTION 3 OPERATION</b>                             |        |
| 3.1 INTRODUCTION .....                                 | 3 - 1  |
| 3.2 DESCRIPTION OF THE CONTROLS .....                  | 3 - 1  |
| 3.3 OPERATING PRECAUTIONS .....                        | 3 - 1  |
| 3.4 BASIC OPERATING PROCEDURES .....                   | 3 - 10 |
| 3.5 CONNECTING THE SAMPLE .....                        | 3 - 13 |
| 3.6 MEASURING GROUNDED SAMPLE .....                    | 3 - 15 |
| 3.7 ZERO OFFSET ADJUSTMENT .....                       | 3 - 16 |
| 3.8 MEASUREMENT PARAMETERS .....                       | 3 - 17 |
| 3.9 EQUIVALENT CIRCUITS .....                          | 3 - 22 |
| 3.10 SETTING AND MONITORING OF MEASURING SIGNAL .....  | 3 - 25 |
| 3.11 MEASURING RANGE .....                             | 3 - 26 |
| 3.12 STARTING MEASUREMENT .....                        | 3 - 26 |
| 3.13 MEASUREMENT SPEED MODES .....                     | 3 - 27 |
| 3.14 DEVIATION MEASUREMENT .....                       | 3 - 28 |
| 3.15 COMPARATOR FUNCTION .....                         | 3 - 30 |
| 3.16 EXTERNAL DC BIAS .....                            | 3 - 33 |
| 3.17 MEASUREMENT BY USE OF EXTERNAL FREQUENCY .....    | 3 - 37 |
| 3.18 EXTERNAL CONTROL INTERFACE .....                  | 3 - 44 |
| 3.19 GP-IB INTERFACE .....                             | 3 - 48 |
| 3.20 ERROR INDICATION .....                            | 3 - 81 |
| 3.21 BASIC INSPECTION AND MAINTENANCE PROCEDURES ..... | 3 - 83 |

## LIST OF FIGURES AND TABLES

|  | PAGE   |
|--|--------|
| Fig. 2-1. Line Voltage Setting Procedure .....                       | 2 - 2  |
| Fig. 2-2. Power Fuse Replacement Procedure .....                     | 2 - 3  |
| Fig. 3-1. 4-terminal Pair Connection .....                           | 3 - 13 |
| Fig. 3-2. Connection of Special Measuring Jigs .....                 | 3 - 15 |
| Fig. 3-3. Vector Representation of Impedance .....                   | 3 - 17 |
| Fig. 3-4. Equivalent Circuit Expressions .....                       | 3 - 22 |
| Fig. 3-5. Maximum Bias Current .....                                 | 3 - 33 |
| Fig. 3-6. Application of External DC Bias .....                      | 3 - 35 |
| Fig. 3-7. Setups for Measurement by Use of External Frequency .....  | 3 - 38 |
|  |        |
| Table 1-1. Specifications .....                                      | 1 - 4  |
| Table 1-2. Reference Data .....                                      | 1 - 23 |
| Table 2-1. Power Fuse .....  | 2 - 2  |
| Table 3-1. Front Panel .....   | 3 - 3  |
| Table 3-2. Rear Panel .....  | 3 - 8  |
| Table 3-3. Basic Operating Procedures .....                          | 3 - 10 |
| Table 3-4. Accessories .....   | 3 - 14 |
| Table 3-5. Residual Parameter Value Ranges and Measuring Frequencies |        |
| Allowable for Offset Adjustment .....                                | 3 - 16 |
| Table 3-6. $ Z $ and $\theta$ of Ideal L, C, and R .....             | 3 - 17 |
| Table 3-7. Parameter Calculation Formulas .....                      | 3 - 21 |
| Table 3-8. Equivalent Circuits .....                                 | 3 - 24 |
| Table 3-9. Reference Value Range .....                               | 3 - 28 |
| Table 3-10. Allowable Limit Value Ranges .....                       | 3 - 30 |
| Table 3-11. Comparator Judgment Condition .....                      | 3 - 32 |
| Table 3-12. Functions of External Frequency Interface .....          | 3 - 39 |
| Table 3-13. Functions of External Control Interface .....            | 3 - 45 |
| Table 3-14. Functions of GP-IB Interface .....                       | 3 - 49 |
| Table 3-15. Error Indications .....                                  | 3 - 82 |
| Table 3-16. Memory Back-up and Initial Settings .....                | 3 - 83 |
| Table 3-17. Self Test Error Indications .....                        | 3 - 85 |
| Table 3-18. Basic Periodic Inspections .....                         | 3 - 86 |
| Table 3-19. Troubleshooting .....                                    | 3 - 88 |

## APPENDICES

|  | PAGE      |
|--|-----------|
| Appendix A. Top Cover Removing Procedure .....           | A-1 - A-2 |
| Appendix B. Battery Replacement Procedure .....          | B-1 - B-2 |
| Appendix C. Functions of the Internal DIP Switches ..... | C-1 - C-5 |

## LIST OF ATTACHED DRAWINGS

Table 1. List of Standard Accessories

|  |              |
|--|--------------|
| Fig. 1. Front Panel View of AG-4311B LCR METER ..... | ASD-7074-1/3 |
| Fig. 2. Rear Panel View of AG-4311B LCR METER .....  | ASD-7074-2/3 |
| Fig. 3. Outside View of AG-4311B LCR METER .....     | ASD-7074-3/3 |

## SECTION 1 GENERAL INFORMATION

### 1.1 INTRODUCTION

This manual contains a general description of the AG-4311B LCR Meter, its preparation for use, and its operating procedures. (The AG-4311B LCR Meter will be referred to simply as the apparatus or the AG-4311B throughout this manual.)

Section 1 describes the outline of the apparatus, its specifications, and other general information on it.

### 1.2 GENERAL

The AG-4311B LCR Meter is designed to analyze the AC impedances of ordinary LCR parts, semiconductors, composite parts, electronic materials, and other samples as vectors, and fully automatically measure their parameters (inductance, capacitance, loss factor, resistance, absolute impedance value, and phase angle, etc.).

This apparatus covers a measuring frequency range of 100 Hz to 100 kHz and a measuring signal level range of 1 mV to 5 V, and it can also make deviation and high resolution measurements, and that with high accuracy. These features make this apparatus usable for a wide variety of applications ranging from research and development to manufacturing tests and product quality inspection.

Further, this apparatus is supplied as standard with a comparator function and a GP-IB interface, so it can be applied to automatic measuring systems for automatic evaluation or sorting of parts or processing of parts characteristics data.

#### (1) Varieties of measurable parameters and deviation measurement function

Any of eleven different parameters can be measured for optimum evaluation of the sample; they are inductance (L), resistance (R), capacitance (C), dissipation factor (D), Q factor, equivalent series resistance (ESR), conductance (G), reactance (X), susceptance (B), absolute impedance value ( $|Z|$ ), and phase angle ( $\theta$ ).

In addition, for L, C, R, and  $|Z|$ , their deviations from the reference ( $\Delta$ ) or their percent deviations ( $\Delta\%$ ) can be displayed to facilitate evaluation of the temperature characteristics or quality of parts. For deviation measurement, a measured value can be stored as the reference, or a desired value can be set as the reference.

#### (2) Wide measurement ranges

This apparatus can measure parameters over wide ranges; L ranges from 0.00001  $\mu\text{H}$  to 1.999 kH, C from 0.0001 pF to 1990 mF, and R and  $|Z|$  from 0.00001  $\Omega$  to 19.99 M $\Omega$ . Its measurement accuracy is between 0.1% and 10%. (The measurement ranges and accuracy depend on the measuring frequency, signal level range, and measured value.) D, Q, ESR, or G can be displayed

together with L or C in L or C measurement, X or B together with R in R measurement, and  $\theta$  together with |Z| in |Z| measurement.

(3) Up to 5 1/2-digit display

Three measurement speed modes, FAST, NORMAL, and SLOW, are available. The optimum measurement speed and resolution can be selected according to the application.

**FAST:** Up to 4-digit measured data (4999 counts maximum) can be obtained during a measurement period of about 150 to 250 ms. This mode is ideally suited for parts inspection and evaluation in the manufacturing process.

**NORMAL:** Up to 4 1/2-digit measured data (19999 counts maximum) can be obtained during a measurement period of about 250 to 350 ms.

**SLOW:** Ten measured values are averaged and the average data is displayed up to 5 1/2 digits (199999 counts maximum). This mode is effective in measuring slight changes as in the temperature characteristics of parts at high resolution.

(4) Internal measuring frequency and external frequency interface

The internal measuring frequency can be selected from among a total of 31 values, including frequently used 120 Hz, 1 kHz, and 10 kHz, in the range of 100 Hz to 100 kHz; they are almost equally spaced in terms of logarithm.

The apparatus is equipped with an external frequency interface. Measurement can be made at any frequency between 100 Hz and 100 kHz by entering a signal whose frequency is 16 times higher than the measuring frequency and, at the same time, specifying frequency data. Frequency data can be specified through use of either the external frequency data interface or the GP-IB interface.

(5) Level monitor function

In addition to the two digital displays that indicate measurement parameters, this apparatus is provided with a digital display that shows the measuring frequency, signal level, and other data. This display can be used to monitor the measurement condition, for example, the value of signal voltage or current applied to the sample, while carrying out a parameter measurement. With this function, the inductance of a coil or transformer with a signal current characteristic can be measured while monitoring the signal current.

(6) Automatic zero adjustment function

This offset adjustment function is used to measure the stray capacitance, residual inductance, and resistance of the measuring tools (test fixture and leads) in advance, and correct the measurements of parameters by subtracting their parasitic impedance so as to obtain the accurate parameter values of the sample. The offset values (the stray capacitance being 20 pF or less, the residual inductance 2  $\mu$ H or less, the resistance 0.5  $\Omega$  or less, and the conductance 5  $\mu$ S or less) are automatically applied to the measurements, and the corrected measurements are displayed.

(7) Comparator function

Measured data can be compared with preset limits (upper and lower limits) for quality evaluation or sorting of parts. The result of the judgment is indicated by the PASS, HIGH, or LOW LED. The loudspeaker can be made to sound at the same time. The result of the judgment is also output to the EXT CONTROL connector as an external control signal.

(8) GP-IB interface

This apparatus is supplied as standard with a GP-IB remote control interface. This interface allows the apparatus to be remotely controlled or built into an automatic measuring system. Setting of a measurement condition or delivery of measured data can be made via this GP-IB interface.

(9) Memory back-up function

The front panel key settings, deviation measurement reference, and judgment limits are retained even after power is turned off. When power is turned on again, the previous operating conditions (except the EXT DC BIAS key setting and offset adjustment data) are reproduced and need not be set again.

### 1.3 SPECIFICATIONS

The specifications and general performance characteristics of the apparatus are listed in Table 1-1. General properties other than the specifications are shown in Table 1-2; they are just reference data which seems to be necessary for operating the apparatus. The apparatus has been factory adjusted to meet the specifications listed in Table 1-1.

### 1.4 COMPOSITION

The apparatus is supplied with the standard accessories listed in Table 1 at the end of this manual.





Table 1-1. Specifications



## 1. Measurement Items

## (1) Parameters:

C (capacitance)    D (dissipation factor)                      X (reactance)  
 L (inductance)    Q (Q factor = 1/D)                                      B (susceptance)  
 R (resistance)    ESR (equivalent series resistance)                      G (conductance)  
 |Z| (absolute impedance value)                                       $\theta$  (phase angle)

(2) Measuring circuit modes:  (series equivalent circuit),  
 (parallel equivalent circuit), AUTO (automatic selection)

## (3) Parameter combinations

|  (Series equivalent circuit) |  (Parallel equivalent circuit) |
|---|---|
| C-D, Q, or ESR<br>L-D, Q, or ESR<br>R-X or L<br> Z  - $\theta$  | C-D, Q, or G<br>L-D, Q, or G<br>R-B or C<br> Z  - $\theta$  |

(4) Measurement speed modes: FAST, NORMAL, and SLOW

(5) Display: The display depends on the measurement speed mode.

| Measurement Speed Mode | Number of Digits Displayed | Maximum Count |
|------------------------|----------------------------|---------------|
| FAST                   | Up to 4 digits             | 4999          |
| NORMAL                 | Up to 4 1/2 digits         | 19999         |
| SLOW                   | Up to 5 1/2 digits         | 199999        |

The number of significant digits varies with the measurement range, measuring frequency, and signal level range.

## 2. Deviation Measurement (L, C, R, and |Z| only)

(1) Reference value setting: As the reference value, measured data can be stored or a desired value can be keyed in.

(2) Display: The deviation from the reference value ( $\Delta$  = measured value - reference value) or its percentage ( $\Delta\%$ ). The display is within the measurement limits determined by the range. In the  $\Delta\%$  display mode, the display range varies with the measurement speed mode.

| Measurement Speed Mode | Display Range in the $\Delta\%$ Mode |
|------------------------|--------------------------------------|
| FAST                   | - 199.9    -    + 199.9    %         |
| NORMAL                 | - 199.99    -    + 199.99    %       |
| SLOW                   | - 199.999    -    + 199.999    %     |

Table 1-1. Specifications (Continued)

3. Range Selection: Auto or manual (UP or DOWN)
4. Start of Measurement: Auto (repetitive operation), manual, or external control
5. Measurement Terminals: Four terminal pairs
6. Measurement Signals
- (1) Measuring frequency: 100 Hz to 100 kHz Internal frequency: 31 frequencies  
 100, 120, 150, 200, 250, 300, 401, 500, 601, 801 Hz  
 1.00, 1.20, 1.50, 2.00, 2.50, 3.00, 4.01, 5.00, 6.01, 8.01 kHz  
 10.0, 12.0, 15.1, 20.2, 25.0, 30.5, 40.3, 50.0, 62.5, 78.1, 100 kHz  
 (The above frequency values are nominal ones.)
- (2) Measuring signal level: 1 mV to 5 Vrms, continuously variable over four ranges  
 (10 mV, 100 mV, 1 V, 5 V)
- (3) Level monitor: The signal voltage or current across the sample can be monitored.
7. Automatic Zero Adjustment Function:  
 The residues caused by the measuring jigs can be removed within the following ranges.  
 C: 20 pF or less, G: 5  $\mu$ S or less, L: 2  $\mu$ H or less, R: 0.5  $\Omega$  or less
8. Comparator Function:  
 Measured data is compared with preset upper and lower limits, and the result of the judgment is displayed.
- | Display | Criterion  |
|---------|--|
| PASS    | Lower limit $\leq$ Measured value $\leq$ Upper limit |
| HIGH    | Measured value $>$ Upper limit                       |
| LOW     | Measured value $<$ Lower limit                       |
9. Memory Back-up Function:  
 The front panel key settings, deviation measurement reference, and judgment limits are stored and reproduced when power is turned on again. (The EXT DC BIAS key setting and offset adjustment data are excluded.)
10. DC Bias: An external DC power source is used.  
 Maximum applied voltage:  $\pm 35$  V, maximum current: 100 mA  
 (The maximum current may be limited, depending on the signal level range and measuring frequency.)

Table 1-1. Specifications (Continued)

**11. Measurement Ranges and Accuracies**

The measurement ranges, the number of significant display digits, and the measurement accuracies are shown below.

**11.1 Measurement limits and measurement ranges****(1) Measurement limits**

| Measurement Parameter                | Measurement Limits                 |
|--------------------------------------|------------------------------------|
| C                                    | 0.0001pF - 1990mF                  |
| L                                    | 0.00001 $\mu$ H - 1.999kH          |
| R,  Z , ESR, X                       | 0.00001 $\Omega$ - 19.99M $\Omega$ |
| D                                    | 0.0001 - 9.99                      |
| Q (1/D is calculated and displayed.) | 0.1 - 9000                         |
| G, B                                 | 0.0001 $\mu$ S - 199.9S            |
| $\theta$                             | - 180.00deg - + 180.00deg          |

The measurement limits vary with the measuring frequency, signal level range, and measurement speed mode. (The measurement limits shown at left indicate the maximum ranges in the NORMAL measurement speed mode.)

**(2) Measurement ranges**

For measured data (main parameters L, C, R, and |Z|) shown on the main display, the display range varies with the measurement range. In the accuracy table given in 11.3, measurement range representatives are shown as the range representatives. (The range codes corresponding to the range representatives are also shown in the table.)

The measurement limits in each measurement range are expressed in terms of  $\alpha_0$  in the table below.

$$\alpha_0 = \frac{\text{Main parameter measured value}}{\text{Main parameter range value}}$$

| Measurement Limits                     | Measurement Range | $\alpha_0$                 |
|--|-------------------|----------------------------|
| Range representative $\times \alpha_0$ | Maximum range     | About 0.17 to 1.99 or more |
|  | Normal range      | About 0.17 to about 1.8    |
|  | Minimum range     | 0 to about 1.8             |

**REMARKS:**

- 1) The maximum value of  $\alpha_0$  as the maximum range varies with the signal level range, in regard to the number of significant display digits.
- 2) The above values of  $\alpha_0$  are the values in the AUTO range. In the fixed range, the maximum value of  $\alpha_0$  as the normal or minimum range is about 2, and the minimum value of  $\alpha_0$  as the maximum or normal range is about 0.1 or less.
- 3) In the 1 k $\Omega$  range for |Z| measurement, for example, the value of  $\alpha_0$  as the normal range is applied. The measurement limits are about 170  $\Omega$  and about 1.8 k $\Omega$  (in the AUTO range).

Table 1-1. Specifications (Continued)

(3) Range control

If the impedance of the sample is within the impedance range determined from the upper and lower limits in each measurement range, the range is judged appropriate and a measurement is started. If the impedance of the sample is close to a range boundary value, the measured value may not correspond to the range.


**REMARKS:**

The judgment limits (upper and lower limits) for each measurement range are calculated from reactance  $X_L = \omega L$  at  $D = 0$  in L measurement, reactance  $X_C = 1/\omega C$  at  $D = 0$  in C measurement, and the value of R at  $Q = 0$  in R measurement.

11.2 Number of significant display digits

(1) The number of display digits in the NORMAL measurement speed mode is shown in the accuracy table given in 11.3.

How to read the number of display digits

- The number of display digits in each signal level range is shown in the parenthesis.  
 Example: (4, 4, 3, 2)  

  - Number of display digits in the 10 mV range
  - Number of display digits in the 100 mV range
  - Number of display digits in the 1 V range
  - Number of display digits in the 5 V range
- In the display of the number of digits, the highest order digits 1 of the range value display is not included. (4 represents a 4 1/2-digit display.)  
 Example:  
 When the range value is 100 and the number of display digits is 4: ..... 100.00  
 When the range value is 100 and the number of display digits is 1: ..... 10<sub>0</sub>.  

↑

A small zero indicating the insignificant digit is displayed.
- The - mark indicates a 1/2-digit display. When the range value is displayed, 1 is displayed.
- In  $|Z| - \theta$  measurement, the minimum digit (deg) of  $\theta$  is shown in  $\langle \rangle$ ,
- The number of digits preceded by  $\Delta$  in the table varies with the measured value.

(2) When the measurement speed mode is SLOW

The number of digits increases by one as long as it does not exceed 5 1/2 digits.

(3) When the measurement speed mode is FAST

The number of digits not preceded by  $\Delta$  decreases by one.

Table 1-1. Specifications (Continued)

**11.3 Measurement accuracy**

- (1) The measurement accuracy for each parameter in the NORMAL measurement speed mode is shown in 11.3.1 to 11.3.4.

The measurement accuracy is specified at the front panel measuring terminal under the following conditions.

**Accuracy prescribing conditions**

1. Warm-up period: 30 min or more
  2. Measuring signal level: The LEVEL FINE adjuster is set at the MAX (rightmost) position in each of the 5 V, 1 V, and 100 mV level ranges.
  3. Measurement speed mode: NORMAL
  4. Auto offset adjustment (open/short) has been made.
  5. Ambient temperature:  $(23 \pm 5)^{\circ}\text{C}$
  6. DC bias: OFF
  7. Significant measured data count: 20 or more
- The accuracy count is specified at the number of significant display digits in the table. Small zeros indicating the insignificant digits are not included.

- (2) Accuracy in the SLOW measurement speed mode

The value in the accuracy table is used. However, the count is specified at the number of significant digits in the NORMAL mode, except the display digits added in the SLOW mode.

- (3) Accuracy in the FAST measurement speed mode

Double the error shown in the accuracy table

- (4) The error limit is doubled at an ambient temperature of 5 to 18°C or 28 to 35°C. (No error is specified at an ambient temperature of 0 to 5°C or 35 to 40°C.)

Table 1-1. Specifications (Continued)

11.3.1 |Z| -  $\theta$  measurement

For the accuracy of |Z| or  $\theta$  in |Z| -  $\theta$  measurement, refer to table A-1.

- How to read the accuracy table

Upper column: Accuracy of |Z|:  $\pm$  (reading % + count)  
 Lower column: Accuracy of  $\theta$ :  $\pm$  (angle (°) + count)

- Accuracy factor

$$\alpha_0 = \frac{\text{Measured value of } |Z|}{\text{Range value of } |Z|}$$

Table A-1. Accuracy of |Z| or  $\theta$

| Z  range |                |  |  |
|----------|----------------|--|--|
| Code     | Value          |  |  |
| R19      | 10 M $\Omega$  | $\Delta$ ( 3, 2, 1, - )<br><0.01, 0.1, 1, 10>      | 5%+1<br>$0.1^\circ + (0.1 \alpha_0)^\circ + 1$                           |
| R18      | 1 M $\Omega$   | $\Delta$ ( 3, 3, 2, 1 )<br><0.01, 0.01, 0.1, 1>    | 3%+1<br>$0.05^\circ + (0.1 \alpha_0)^\circ + 1$                          |
| R17      | 100 k $\Omega$ | $\Delta$ ( 3, 3, 3, 2 )<br><0.01, 0.01, 0.01, 0.1> | $(0.1 + 0.2 \alpha_0)\% + 1$<br>$0.05^\circ + (0.05 \alpha_0)^\circ + 1$ |
| R16      | 10 k $\Omega$  |  |  |
| R15      | 1 k $\Omega$   |  |  |
| R14      | 100 $\Omega$   | ( 4, 4, 4, 3 )                                     | 0.1%+3   |
| R13      | 10 $\Omega$    | <0.01, 0.01, 0.01, 0.1>                            | $0.05^\circ + (0.05 / \alpha_0)^\circ + 1$                               |
| R12      | 1 $\Omega$     | ( 4, 4, 3, 2 )<br><0.01, 0.01, 0.1, 1>             | 0.3%+5<br>$0.05^\circ + (0.05 / \alpha_0)^\circ + 1$                     |
| R11      | 0.1 $\Omega$   | ( 4, 3, 2, 1 )<br><0.01, 0.1, 1, 10>               | 0.8%+2<br>$0.3^\circ + (0.3 / \alpha_0)^\circ + 1$                       |

100 20k 100k

Measuring frequency (Hz)

REMARKS:

- 1) Number of significant display digits

- The number of display digits of |Z| in the NORMAL measurement speed mode (with the range value displayed) is shown in the parenthesis ( ). The number of digits marked with  $\Delta$  varies with the measured value.
- The minimum digit (deg) of  $\theta$  in the NORMAL measurement speed mode is shown in the bracket < >.

- 2) Measurement range in the 1 V range in the NORMAL mode

|Z|: 0.0001  $\Omega$  to 19.9 M $\Omega$

$\theta$ : -180.00 to +180.00°

Table 1-1. Specifications (Continued)

11.3.2 R-X/B, L/C measurement

(1) For the accuracy of R in R-X/B or L/C measurement, refer to table B-1.

- How to read the accuracy table


|  |
|--|
| Accuracy of R: $\pm$ (reading % + count) |
|--|

- The accuracy of R is valid when  $Q \leq 0.1$  ( $D \geq 10$ ).
- The accuracy of R is not specified when the display of subparameter X, B, L, or C is OF, CF.
- Accuracy factor

$$\alpha_0 = \frac{\text{Measured value of R}}{\text{Range value of R}}$$

Table B-1. Accuracy of R

| R range |        |                |                             |
|---------|--------|----------------|-----------------------------|
| Code    | Value  |                |                             |
| R19     | 10 MΩ  | Δ( 3, 2, 1, -) | 5%+1                        |
| R18     | 1 MΩ   | Δ( 3, 3, 2, 1) | 3%+1                        |
| R17     | 100 kΩ | Δ( 3, 3, 3, 2) | (0.1+0.2α <sub>0</sub> )%+1 |
| R16     | 10 kΩ  |                |                             |
| R15     | .1 kΩ  |                |                             |
| R14     | 100 Ω  | ( 4, 4, 4, 3)  | 0.1%+3                      |
| R13     | 10 Ω   |                |                             |
| R12     | 1 Ω    | ( 4, 4, 3, 2)  | 0.3%+5                      |
| R11     | 0.1 Ω  | ( 4, 3, 2, 1)  | 0.8%+2                      |
|         |        |                | 1.2%+2                      |



REMARKS:

1) Number of significant display digits



The number of display digits of R in the NORMAL measurement speed mode (with the range value displayed) is shown in the parenthesis ( ). The number of digits marked with Δ varies with the measured value.

2) Measurement range in the 1 V range in the NORMAL mode

R: 0.0001 Ω to 19.9 MΩ

Table 1-1. Specifications (Continued)

(2) For the accuracy of X or B in R-X/B measurement, refer to table B-3.

- The subparameter is X in the  measuring circuit mode and B in the  measuring circuit mode.

- The measurement range for X or B is automatically selected by the R range. Refer to Table B-2.

- How to read the accuracy table.

Upper column: Accuracy of X  
Lower column: Accuracy of B

Accuracy:  $\pm$  (reading % + count + residue)

- Accuracy factor


$$\alpha_0 = \frac{\text{Measured value of R}}{\text{Range value of R}}$$

$$\gamma = \frac{\text{Measured value of X}}{\text{Range value of X}}$$

Table B-2. X, B Range Selection

| R range |                | Range value    |              |
|---------|----------------|----------------|--------------|
| Code    | Value          | X              | B            |
| R19     | 10 M $\Omega$  | 10 M $\Omega$  | 1 $\mu$ S    |
| R18     | 1 M $\Omega$   | 1 M $\Omega$   | 10 $\mu$ S   |
| R17     | 100 k $\Omega$ | 100 k $\Omega$ | 100 $\mu$ S  |
| R16     | 10 k $\Omega$  | 10 k $\Omega$  | 1000 $\mu$ S |
| R15     | 1 k $\Omega$   | 1 k $\Omega$   | 10 mS        |
| R14     | 100 $\Omega$   | 100 $\Omega$   | 100 mS       |
| R13     | 10 $\Omega$    | 10 $\Omega$    | 1000 mS      |
| R12     | 1 $\Omega$     | 1 $\Omega$     | 10 S         |
| R11     | 0.1 $\Omega$   | 0.1 $\Omega$   | 100 S        |

| Range value    |              | Table B-3. Accuracy of X or B in R-X/B Measurement |  |
|----------------|--------------|--|--|
| X              | B            |  |  |
| 10 M $\Omega$  | 1 $\mu$ S    | $\Delta(3, 2, 1, -)$<br>(4, 3, 2, 1)               | 5%+1+(0.05 $\alpha_0$ +0.2 $\alpha_0^2$ )M $\Omega$<br>3%+5+(0.0002/ $\alpha_0$ ) $\mu$ S  |
| 1 M $\Omega$   | 10 $\mu$ S   | $\Delta(3, 3, 2, 1)$<br>(4, 4, 3, 2)               | 3%+1+(0.005 $\alpha_0$ +0.02 $\alpha_0^2$ )M $\Omega$<br>1%+3+(0.002/ $\alpha_0$ ) $\mu$ S   |
| 100 k $\Omega$ | 100 $\mu$ S  | $\Delta(3, 3, 3, 2)$<br>(4, 4, 4, 3)               | (0.1+0.2 $\gamma$ )%+1+(0.3 $\alpha_0$ +2 $\alpha_0^2$ )k $\Omega$<br>0.1%+3+(0.02/ $\alpha_0$ ) $\mu$ S   |
| 10 k $\Omega$  | 1000 $\mu$ S | $\Delta(3, 3, 3, 2)$<br>(4, 4, 4, 3)               | (0.1+0.2 $\gamma$ )%+1+(0.03 $\alpha_0$ +0.2 $\alpha_0^2$ )k $\Omega$<br>0.1%+3+(0.2/ $\alpha_0$ ) $\mu$ S   |
| 1 k $\Omega$   | 10 mS        | $\Delta(3, 3, 3, 2)$<br>(4, 4, 4, 3)               | (0.1+0.2 $\gamma$ )%+1+(0.003 $\alpha_0$ +0.02 $\alpha_0^2$ )k $\Omega$<br>0.1%+3+(0.002/ $\alpha_0$ )mS   |
| 100 $\Omega$   | 100 mS       | (4, 4, 4, 3)<br>$\Delta(3, 3, 3, 2)$               | 0.1%+3+(0.1 $\alpha_0$ ) $\Omega$<br>0.1%+1+(0.2/ $\alpha_0$ +0.2/ $\alpha_0^2$ )mS  |
| 10 $\Omega$    | 1000 mS      | (4, 4, 4, 3)<br>$\Delta(3, 3, 3, 2)$               | 0.1%+3+(0.01 $\alpha_0$ ) $\Omega$<br>0.1%+1+(2/ $\alpha_0$ +2/ $\alpha_0^2$ )mS   |
| 1 $\Omega$     | 10 S         | (4, 4, 3, 2)<br>$\Delta(3, 3, 2, 1)$               | 0.3%+5+(0.001 $\alpha_0$ ) $\Omega$<br>0.3%+1+(0.02/ $\alpha_0$ +0.02/ $\alpha_0^2$ )S   |
| 0.1 $\Omega$   | 100 S        | (4, 3, 2, 1)<br>$\Delta(3, 2, 1, -)$               | 0.8%+2+(0.0002 $\alpha_0$ ) $\Omega$   1.2%+2+(0.0002 $\alpha_0$ ) $\Omega$<br>1%+1+(0.3/ $\alpha_0$ +0.5/ $\alpha_0^2$ )S   1%+1+(0.3/ $\alpha_0$ +0.5/ $\alpha_0^2$ )S |



REMARKS:

- 1) Number of significant display digits

Upper column( ): Number of display digits of X  
Lower column( ): Number of display digits of B

The number of display digits shown is one in the case where the measurement speed mode is NORMAL and the range value is displayed. The number of digits marked with  $\Delta$  varies with the measured value.

- 2) Measurement range in the 1 V range in the NORMAL mode

X: 0.0001  $\Omega$  to 19.9 M $\Omega$

B: 0.001  $\mu$ S to 199 S



Table 1-1. Specifications (Continued)

(3) In R-L/C measurement, L and C are calculated based on the following formulas.

$$L = \frac{X}{2\pi f} \quad C = \frac{B}{2\pi f}$$

The measurement range for L or C in R-L/C measurement is automatically selected according to the R range and measuring frequency. Refer to Tables B-4 and B-5.

**REMARKS:**

The number of significant display digits and the display range for L or C are the same as those for L in L-D, Q, or ESR/G measurement or C in C-D, Q, or ESR/G measurement. (The measurement accuracy of L or C in R-L/C measurement is not specified.)

Table B-4. L Range Selection in R-L Measurement

| R range |        | Range value of L (R-L measurement) |        |        |        |
|---------|--------|------------------------------------|--------|--------|--------|
| Code    | Value  |                                    |        |        |        |
| R19     | 10 MΩ  | 10 kH                              | 1 kH   | 100 H  | 10 H   |
| R18     | 1 MΩ   | 1 kH                               | 100 H  | 10 H   | 1 H    |
| R17     | 100 kΩ | 100 H                              | 10 H   | 1 H    | 100 mH |
| R16     | 10 kΩ  | 10 H                               | 1 H    | 100 mH | 10 mH  |
| R15     | 1 kΩ   | 1 H                                | 100 mH | 10 mH  | 1 mH   |
| R14     | 100 Ω  | 100 mH                             | 10 mH  | 1 mH   | 100 μH |
| R13     | 10 Ω   | 10 mH                              | 1 mH   | 100 μH | 10 μH  |
| R12     | 1 Ω    | 1 mH                               | 100 μH | 10 μH  | 1 μH   |
| R11     | 0.1 Ω  | 100 μH                             | 10 μH  | 1 μH   | 0.1 μH |

100                      1k                      10k                      100k  
 Measuring frequency (Hz)

Table B-5. C Range Selection in R-C Measurement

| R range |        | Range value of C (R-C measurement) |        |        |        |
|---------|--------|------------------------------------|--------|--------|--------|
| Code    | Value  |                                    |        |        |        |
| R19     | 10 MΩ  | 1 nF                               | 100 pF | 10 pF  | 1 pF   |
| R18     | 1 MΩ   | 10 nF                              | 1 nF   | 100 pF | 10 pF  |
| R17     | 100 kΩ | 100 nF                             | 10 nF  | 1 nF   | 100 pF |
| R16     | 10 kΩ  | 1 μF                               | 100 nF | 10 nF  | 1 nF   |
| R15     | 1 kΩ   | 10 μF                              | 1 μF   | 100 nF | 10 nF  |
| R14     | 100 Ω  | 100 μF                             | 10 μF  | 1 μF   | 100 nF |
| R13     | 10 Ω   | 1 mF                               | 100 μF | 10 μF  | 1 μF   |
| R12     | 1 Ω    | 10 mF                              | 1 mF   | 100 μF | 10 μF  |
| R11     | 0.1 Ω  | 100 mF                             | 10 mF  | 1 mF   | 100 μF |

100      250                      2.5k                      25k                      100k  
 Measuring frequency (Hz)

Table 1-1. Specifications (Continued)

## 11.3.3 C-D, Q, or ESR/G measurement

(1) For the accuracy of C in C-D, Q, or ESR/G measurement, refer to Table C-1.

- How to read the accuracy table

Accuracy of C:  $\pm$  (reading % + count) or  $\pm$  (reading % + count + residue)

- The accuracy of C is valid when  $D \leq 0.1$ .
- The accuracy of C is not specified when the display of subparameter D, Q, ESR, or G is OF, CF.
- The accuracy for --- in the table is not specified.
- Accuracy factor

$$\alpha = k_0 \cdot \frac{\text{Measured value of C}}{\text{Range value of C}} \quad (\text{For } k_0, \text{ refer to graph (b) on page 1-21.})$$

For  $\beta$ , refer to graph (a) on page 1-21.

Table C-1. Accuracy of C

| C range |             |  |  |                                      |                                      |  |  |
|---------|-------------|--|--|--------------------------------------|--------------------------------------|--|--|
| Code    | Value       |  |  |                                      |                                      |  |  |
| R23     | 1000 mF     | $\Delta(2, 1, -, -)\%$<br>10%+1                |  |                                      |                                      |  |  |
| R22     | 100 mF      | $\Delta(3, 2, 1, -)$<br>3%+1                   | $\Delta(2, 1, -, -)\%$<br>5%+1                 | ← 10%+1                              |                                      |  |  |
| R21     | 10 mF       | $\Delta(3, 3, 2, 1)$<br>1%+1                   | $\Delta(3, 2, 1, -)$<br>3%+1                   | $\Delta(2, 1, -, -)\%$<br>---        | 3%+1                                 |  |  |
| R20     | 1 mF        | $\Delta(3, 3, 3, 2)$<br>(0.1+0.1 $\alpha$ )%+1 | $\Delta(3, 3, 2, 1)$<br>1%+1                   | $\Delta(3, 2, 1, -)$<br>3%+1         | $\Delta(2, 1, -, -)\%$<br>---        |  |  |
| R19     | 100 $\mu$ F |  | $\Delta(3, 3, 3, 2)$<br>(0.1+0.1 $\alpha$ )%+1 | $\Delta(3, 3, 2, 1)$<br>1%+1         | $\Delta(3, 2, 1, -)$<br>---          | $\Delta(3, 2, 1, -)$<br>---                    |  |
| R18     | 10 $\mu$ F  | $\Delta(3, 3, 3, 2)$<br>(0.1+0.1 $\alpha$ )%+1 |  | $\Delta(3, 3, 2, 1)$<br>3%+1         | $\Delta(3, 3, 2, 1)$<br>3%+1         | $\Delta(3, 3, 3, 2)$<br>(0.1+0.1 $\alpha$ )%+1 |  |
| R17     | 1 $\mu$ F   |  |  |                                      |                                      |  | $(4, 4, 4, 3)$<br>0.1%+(1+ $\beta$ )         |
| R16     | 100 nF      | $(4, 4, 4, 3)$<br>0.1%+(1+ $\beta$ )           | $(4, 4, 4, 3)$<br>0.1%+(1+ $\beta$ )           | $(4, 4, 4, 3)$<br>0.1%+(1+ $\beta$ ) |                                      |  |  |
| R15     | 10 nF       |  |  |                                      | $(4, 4, 3, 2)$<br>0.1%+(1+ $\beta$ ) | $(4, 4, 3, 2)$<br>0.1%+(1+ $\beta$ )           |  |
| R14     | 1 nF        | $(4, 3, 2, 1)$<br>0.1%+(1+ $\beta$ )           | $(4, 3, 2, 1)$<br>0.1%+(1+ $\beta$ )           | $(4, 3, 2, 1)$<br>0.1%+(1+ $\beta$ ) |                                      |  |  |
| R13     | 100 pF      |  |  |                                      | $(4, 3, 2, 1)$<br>0.1%+(1+ $\beta$ ) | $(4, 3, 2, 1)$<br>0.1%+(1+ $\beta$ )           | $(4, 3, 2, 1)$<br>0.1%+(1+ $\beta$ )         |
| R12     | 10 pF       | $(4, 3, 2, 1)$<br>0.1%+(1+ $\beta$ )           | $(4, 3, 2, 1)$<br>0.1%+(1+ $\beta$ )           | $(4, 3, 2, 1)$<br>0.1%+(1+ $\beta$ ) |                                      |  |  |
| R11     | 1 pF        |  |  |                                      |                                      |  | $(4, 3, 2, 1)$<br>0.3%+(1+ $\beta$ )+0.001pF |

100      250      1k      2.5k      20k      25k      100k  
Measuring frequency (Hz)

- REMARKS: 1) The number of display digits of C in the NORMAL measurement speed mode with  $D \leq 0.1$  (with the range value displayed) is shown in the parenthesis ( ). The number of digits marked with  $\Delta$  varies with the measured value.
- 2) In the highest range (indicated by  $\%$ ), ten measurements are made and their average is determined.
- 3) Measurement range in the 1 V range in the NORMAL mode  
C: 0.001 pF to 1900 mF (depending on the measuring frequency)

Table 1-1. Specifications (Continued)

(2) For the accuracy of D in C-D measurement, refer to Table C-2.

- How to read the accuracy table

Accuracy of D:  $\pm$  (reading % + count + residue)

- The accuracy for --- in the table is not specified.
- Accuracy factor

$$\alpha = k_0 \cdot \frac{\text{Measured value of C}}{\text{Range value of C}} \quad (\text{For } k_0, \text{ refer to graph (b) on page 1-21.})$$

(3) The result of calculation 1/D is displayed as Q in C-Q measurement.

(The measurement accuracy of Q is not specified.)

Table C-2. Accuracy of D in C-D Measurement

| C range |         |                                       |                                       |                                       |                                       |
|---------|---------|---------------------------------------|---------------------------------------|---------------------------------------|---------------------------------------|
| Code    | Value   |                                       |                                       |                                       |                                       |
| R23     | 1000 mF | 10%+1<br>+(0.01+0.03 α)               |                                       |                                       |                                       |
| R22     | 100 mF  | 3%+1<br>+(0.002+0.01 α)               | 5%+1<br>+(0.01+0.03 α)                | ← 10%+1+(0.01+0.03 α)                 |                                       |
| R21     | 10 mF   | 1%+1<br>+(0.001+0.002 α)              | 3%+1<br>+(0.002+0.01 α)               | 3%+1+(0.001+0.002 α)                  |                                       |
| R20     | 1 mF    | (0.3+0.1 α)%+1<br>+(0.0005+0.002 α)   | 1%+1<br>+(0.001+0.002 α)              | 3%+1<br>+(0.002+0.01 α)               | ----                                  |
| R19     | 100 μF  |                                       | (0.3+0.1 α)%+1<br>+(0.0005+0.002 α)   | 1%+1<br>+(0.001+0.002 α)              | ----                                  |
| R18     | 10 μF   | (0.3+0.03/α)%+1<br>+(0.0005+0.0003/α) | (0.3+0.03/α)%+1<br>+(0.0005+0.0003/α) | (0.3+0.1 α)%+1<br>+(0.0005+0.002 α)   | 3%+1<br>+(0.001+0.002 α)              |
| R17     | 1 μF    |                                       |                                       | (0.3+0.1 α)%+1<br>+(0.0005+0.002 α)   | (0.3+0.1 α)%+1<br>+(0.0005+0.002 α)   |
| R16     | 100 nF  |                                       |                                       | (0.3+0.03/α)%+1<br>+(0.0005+0.0003/α) | (0.3+0.03/α)%+1<br>+(0.0005+0.0003/α) |
| R15     | 10 nF   |                                       |                                       | (0.3+0.03/α)%+1<br>+(0.0005+0.0003/α) | (0.3+0.03/α)%+1<br>+(0.0005+0.0003/α) |
| R14     | 1 nF    | (0.3+0.03/α)%+1<br>+(0.0005+0.0003/α) | (0.3+0.03/α)%+1<br>+(0.0005+0.0003/α) | (0.3+0.03/α)%+1<br>+(0.0005+0.0003/α) | (0.3+0.03/α)%+1<br>+(0.0005+0.0003/α) |
| R13     | 100 pF  |                                       |                                       | (0.3+0.03/α)%+1<br>+(0.0005+0.0003/α) | (0.3+0.03/α)%+1<br>+(0.0005+0.0003/α) |
| R12     | 10 pF   |                                       |                                       | (0.3+0.03/α)%+1<br>+(0.0005+0.0003/α) | (0.3+0.03/α)%+1<br>+(0.0005+0.0003/α) |
| R11     | 1 pF    |                                       |                                       | (0.5+0.06/α)%+1<br>+(0.001+0.0006/α)  |                                       |

Measuring frequency (Hz)

REMARKS:

1) In the highest range for C, ten measurements are made and their average is determined.

2) Measurement range in the 1 V range in the NORMAL mode



D: 0.0001 to 9.99

Q: 0.1 to 9000 (The result of calculation 1/D is displayed.)

The number of display digits of D or Q varies with the measurement range for C, signal level range, and measured value.

Table 1-1. Specifications (Continued)

(4) For the accuracy of ESR or G in C-ESR/G measurement, refer to Table C-3.

- The subparameter is ESR in the  measuring circuit mode and G in the  measuring circuit mode.
- The measurement range for ESR or G is automatically selected according to the range for C and the measuring frequency. Refer to Table C-4.
- How to read the accuracy table.

Upper column: Accuracy of ESR  
Lower column: Accuracy of G


Accuracy:  $\pm$  (reading % + count + residue)

- Accuracy factor

$$\alpha = k_0 \cdot \frac{\text{Measured value of C}}{\text{Range value of C}} \quad (\text{For } k_0, \text{ refer to graph (b) on page 1-21.})$$

Table C-3. Accuracy of ESR or G in C-ESR/G Measurement

| Range value |         |                                      |   |
|-------------|---------|--------------------------------------|---|
| ESR         | G       |                                      |   |
| 10 MΩ       | 1 μS    | $\Delta(3, 2, 1, -)$<br>(4, 3, 2, 1) | $3\%+2+(0.01/\alpha+0.05/\alpha^2)\text{M}\Omega$<br>$3\%+5+(0.0005\alpha)\mu\text{S}$    |
| 1 MΩ        | 10 μS   | $\Delta(3, 3, 2, 1)$<br>(4, 4, 3, 2) | $1\%+2+(0.001/\alpha+0.005/\alpha^2)\text{M}\Omega$<br>$1\%+3+(0.003\alpha)\mu\text{S}$   |
| 100 kΩ      | 100 μS  | $\Delta(3, 3, 3, 2)$<br>(4, 4, 4, 3) | $0.2\%+2+(0.1/\alpha+0.5/\alpha^2)\text{k}\Omega$<br>$0.1\%+3+(0.03\alpha)\mu\text{S}$    |
| 10 kΩ       | 1000 μS | $\Delta(3, 3, 3, 2)$<br>(4, 4, 4, 3) | $0.2\%+2+(0.01/\alpha+0.05/\alpha^2)\text{k}\Omega$<br>$0.1\%+3+(0.3\alpha)\mu\text{S}$   |
| 1 kΩ        | 10 mS   | $\Delta(3, 3, 3, 2)$<br>(4, 4, 4, 3) | $0.2\%+2+(0.001/\alpha+0.005/\alpha^2)\text{k}\Omega$<br>$0.1\%+3+(0.003\alpha)\text{mS}$ |
| 100 Ω       | 100 mS  | (4, 4, 4, 3)<br>$\Delta(3, 3, 3, 2)$ | $0.1\%+2+(0.01/\alpha)\Omega$<br>$0.1\%+1+(0.5\alpha+0.5\alpha^2)\text{mS}$               |
| 10 Ω        | 1000 mS | (4, 4, 4, 3)<br>$\Delta(3, 3, 3, 2)$ | $0.1\%+2+(0.001/\alpha)\Omega$<br>$0.1\%+1+(5\alpha+5\alpha^2)\text{mS}$                  |
| 1 Ω         | 10 S    | (4, 4, 3, 2)<br>$\Delta(3, 3, 2, 1)$ | $0.3\%+3+(0.0001/\alpha)\Omega$<br>$0.3\%+1+(0.05\alpha+0.1\alpha^2)\text{S}$             |
| 0.1 Ω       | 100 S   | (4, 3, 2, 1)<br>$\Delta(3, 2, 1, -)$ | $0.8\%+2+(0.00002/\alpha)\Omega$<br>$1\%+1+(\alpha+6\alpha^2)\text{S}$                    |
|             |         |                                      | $1.2\%+2+(0.00002/\alpha)\Omega$<br>$1\%+1+(\alpha+6\alpha^2)\text{S}$                    |



REMARKS:

1) Number of significant display digits

Upper column ( ): Number of display digits of ESR  
Lower column ( ): Number of display digits of G

The number of display digits is one in the case where the measurement speed mode is NORMAL and the range representative is displayed. The number of digits marked with  $\Delta$  varies with the measured value.

2) Measurement range in the 1 V range in the NORMAL mode

ESR: 0.0001 Ω to 19.9 MΩ

G : 0.001 μS to 199 S

Table 1-1. Specifications (Continued)

Table C-4. Range Selection for ESR or G in C-ESR/G Measurement

| C range |             |                              |                              |                              |                              |                      |
|---------|-------------|------------------------------|------------------------------|------------------------------|------------------------------|----------------------|
| Code    | Value       |                              |                              |                              |                              |                      |
| R23     | 1000 mF     | 0.1 $\Omega$ / 100 S         |                              |                              |                              |                      |
| R22     | 100 mF      |                              | 0.1 $\Omega$ / 100 S         |                              |                              |                      |
| R21     | 10 mF       | 1 $\Omega$ / 10 S            | 0.1 $\Omega$ / 100 S         |                              |                              |                      |
| R20     | 1 mF        | 10 $\Omega$ /1000 mS         | 1 $\Omega$ / 10 S            | 0.1 $\Omega$ / 100 S         |                              | 0.1 $\Omega$ / 100 S |
| R19     | 100 $\mu$ F | 100 $\Omega$ / 100 mS        | 10 $\Omega$ /1000 mS         | 1 $\Omega$ / 10 S            |                              |                      |
| R18     | 10 $\mu$ F  | 1 k $\Omega$ / 10 mS         | 100 $\Omega$ / 100 mS        | 10 $\Omega$ /1000 mS         | 1 $\Omega$ / 10 S            |                      |
| R17     | 1 $\mu$ F   | 10 k $\Omega$ /1000 $\mu$ S  | 1 k $\Omega$ / 10 mS         | 100 $\Omega$ / 100 mS        | 10 $\Omega$ /1000 mS         |                      |
| R16     | 100 nF      | 100 k $\Omega$ / 100 $\mu$ S | 10 k $\Omega$ /1000 $\mu$ S  | 1 k $\Omega$ / 10 mS         | 100 $\Omega$ / 100 mS        |                      |
| R15     | 10 nF       | 1 M $\Omega$ / 10 $\mu$ S    | 100 k $\Omega$ / 100 $\mu$ S | 10 k $\Omega$ /1000 $\mu$ S  | 1 k $\Omega$ / 10 mS         |                      |
| R14     | 1 nF        | 10 M $\Omega$ / 1 $\mu$ S    | 1 M $\Omega$ / 10 $\mu$ S    | 100 k $\Omega$ / 100 $\mu$ S | 10 k $\Omega$ /1000 $\mu$ S  |                      |
| R13     | 100 pF      |                              | 10 M $\Omega$ / 1 $\mu$ S    | 1 M $\Omega$ / 10 $\mu$ S    | 100 k $\Omega$ / 100 $\mu$ S |                      |
| R12     | 10 pF       |                              |                              | 10 M $\Omega$ / 1 $\mu$ S    | 1 M $\Omega$ / 10 $\mu$ S    |                      |
| R11     | 1 pF        |                              |                              |                              | 10 M $\Omega$ / 1 $\mu$ S    |                      |

Measuring frequency (Hz)

**REMARKS:**

- 1) How to read the table

ESR range representative/G range representative

- 2) In the highest range for C, ten measurements are made and their average is determined.

Table 1-1. Specifications (Continued)

11.3.4 L-D, Q, ESR/G measurement

(1) For the accuracy of L in L-D, Q, or ESR/G measurement, refer to Table D-1.

- How to read the accuracy table

Accuracy of L:  $\pm(\text{reading \%} + \text{count})$  or  $\pm(\text{reading \%} + \text{count} + \text{residue})$

- The accuracy of L is valid when  $D \leq 0.1$ .
- The accuracy of L is not specified when the display of subparameter D, Q, or ESR/G is OF, CF.
- The accuracy for --- in the table is not specified.
- Accuracy factor

$$\alpha = k_2 \cdot \frac{\text{Measured value of L}}{\text{Range value of L}} \quad (\text{For } k_2, \text{ refer to graph (c) on page 1-21.})$$

**Table D-1. Accuracy of L**

| L range |             |   |   |   |   |
|---------|-------------|---|---|---|---|
| Code    | Value       |   |   |   |   |
| R22     | 10 kH       | $\Delta(3, 2, 1, -)$                          |   |   |   |
| R21     | 1 kH        | $\Delta(3, 3, 2, 1)$<br>$3\%+1$               | $\Delta(3, 2, 1, -)$                          |   |   |
| R20     | 100 H       | $\Delta(3, 3, 3, 2)$<br>$(0.1+0.2\alpha)\%+1$ | $\Delta(3, 3, 2, 1)$<br>$3\%+1$               | $\Delta(3, 2, 1, -)$                          |   |
| R19     | 10 H        |   | $\Delta(3, 3, 3, 2)$<br>$(0.1+0.2\alpha)\%+1$ | $\Delta(3, 3, 2, 1)$<br>$3\%+1$               | $\Delta(3, 2, 1, -)$                          |
| R18     | 1 H         |   |   | $\Delta(3, 3, 3, 2)$<br>$(0.1+0.2\alpha)\%+1$ | $\Delta(3, 3, 2, 1)$<br>$3\%+1$               |
| R17     | 100 mH      |   | $(4, 4, 4, 3)$<br>$0.2\%+3$                   |   | $\Delta(3, 3, 3, 2)$<br>$(0.1+0.2\alpha)\%+1$ |
| R16     | 10 mH       | $(4, 4, 4, 3)$<br>$0.1\%+3$                   | $(4, 4, 4, 3)$<br>$0.2\%+3$                   | $\Delta(3, 3, 3, 2)$<br>$(0.1+0.2\alpha)\%+1$ | $\Delta(3, 3, 3, 2)$<br>$(0.1+0.2\alpha)\%+1$ |
| R15     | 1 mH        | $(4, 4, 3, 2)$<br>$0.3\%+3$                   | $(4, 4, 4, 3)$<br>$0.1\%+3$                   |   |   |
| R14     | 100 $\mu$ H | $(4, 3, 2, 1)$<br>$0.5\%+5$                   | $(4, 4, 3, 2)$<br>$0.3\%+3$                   | $(4, 4, 4, 3)$<br>$0.1\%+3$                   | $(4, 4, 4, 3)$<br>$0.2\%+3$                   |
| R13     | 10 $\mu$ H  |   | $(4, 3, 2, 1)$<br>$0.5\%+5$                   | $(4, 4, 3, 2)$<br>$0.3\%+3$                   | $(4, 4, 4, 3)$<br>$0.1\%+3$                   |
| R12     | 1 $\mu$ H   |   |   | $(4, 3, 2, 1)$<br>$1\%+5+0.0001\mu\text{H}$   | $(4, 4, 3, 2)$<br>$0.3\%+3$                   |
| R11     | 0.1 $\mu$ H |   |   | $0.5\%+5+0.0001\mu\text{H}$                   | $(4, 3, 2, 1)$<br>$1\%+5+0.0001\mu\text{H}$   |

100                      1k                      10k    20k                      100k

Measuring frequency (Hz)

REMARKS:

1) Number of significant display digits

The number of display digits of L in the NORMAL measurement speed mode with  $D \leq 0.1$  (with the range value displayed) is shown in the parenthesis ( ). The number of digits marked with  $\Delta$  varies with the measured value.

2) Measurement range in the 1 V range in the NORMAL mode

L: 0.0001  $\mu$ H to 1.999 kH (depending on the measuring frequency)

Table 1-1. Specifications (Continued)

(2) For the accuracy of D in L-D measurement, refer to Table D-2.

- How to read the accuracy table

Accuracy of D:  $\pm$  (reading % + count + residue)

- The accuracy for --- in the table is not specified.
- Accuracy factor

$$\alpha = k_2 \cdot \frac{\text{Measured value of L}}{\text{Range value of L}} \quad (\text{For } k_2, \text{ refer to Graph (c) on page 1-21.)$$

(3) The result of calculation 1/D is displayed as Q in L measurement.

(The measurement accuracy of Q is not specified.)

Table D-2. Accuracy of D in L-D Measurement

| L range |             |  |  |  |  |
|---------|-------------|--|--|--|--|
| Code    | Value       |  |  |  |  |
| R22     | 10 kH       | ----   |  |  |  |
| R21     | 1 kH        | 3%+1<br>+(0.001+0.002 $\alpha$ )                       | ----   |  |  |
| R20     | 100 H       |  | 3%+1<br>+(0.001+0.002 $\alpha$ )   | ----   |  |
| R19     | 10 H        | (0.3+0.1 $\alpha$ )%+1<br>+(0.001+0.002 $\alpha$ )     |  | 3%+1<br>+(0.001+0.002 $\alpha$ )                       | ----   |
| R18     | 1 H         |  | (0.3+0.1 $\alpha$ )%+1<br>+(0.001+0.002 $\alpha$ )   |  | 3%+1<br>+(0.001+0.002 $\alpha$ )                       |
| R17     | 100 mH      | (0.3+0.03/ $\alpha$ )%+1<br>+(0.001+0.0003/ $\alpha$ ) |  | (0.3+0.1 $\alpha$ )%+1<br>+(0.001+0.002 $\alpha$ )     | (0.3+0.1 $\alpha$ )%+1<br>+(0.001+0.002 $\alpha$ )     |
| R16     | 10 mH       |  | (0.3+0.03/ $\alpha$ )%+1<br>+(0.001+0.0003/ $\alpha$ )   |  |  |
| R15     | 1 mH        | (0.5+0.05/ $\alpha$ )%+1<br>+(0.001+0.0005/ $\alpha$ ) |  | (0.3+0.03/ $\alpha$ )%+1<br>+(0.001+0.0003/ $\alpha$ ) | (0.3+0.03/ $\alpha$ )%+1<br>+(0.001+0.0003/ $\alpha$ ) |
| R14     | 100 $\mu$ H | (1+0.3/ $\alpha$ )%+1<br>+(0.001+0.003/ $\alpha$ )     | (0.5+0.05/ $\alpha$ )%+1<br>+(0.001+0.0005/ $\alpha$ )   |  |  |
| R13     | 10 $\mu$ H  |  | (1+0.3/ $\alpha$ )%+1<br>+(0.001+0.003/ $\alpha$ )   | (0.5+0.05/ $\alpha$ )%+1<br>+(0.001+0.0005/ $\alpha$ ) | (0.5+0.05/ $\alpha$ )%+1<br>+(0.001+0.0005/ $\alpha$ ) |
| R12     | 1 $\mu$ H   |  |  |  |  |
| R11     | 0.1 $\mu$ H |  | (1+0.3/ $\alpha$ )%+1+(0.001+0.003/ $\alpha$ )<br>(2+0.3/ $\alpha$ )%+1+(0.001+0.003/ $\alpha$ ) |  | (2+0.3/ $\alpha$ )%+1<br>+(0.001+0.003/ $\alpha$ )     |

Measuring frequency (Hz)

REMARKS: Measurement range in the 1 V range in the NORMAL mode



D: 0.0001 to 9.99

Q: 0.1 to 9000 (The result of calculation 1/D is displayed.)

The number of display digits of D or Q varies with the measurement range for L, signal level range, and measured value.

Table 1-1. Specifications (Continued)

(4) For the accuracy of ESR or G in L-ESR/G measurement, refer to Table D-3.

- The subparameter is ESR in the  measuring circuit mode and G in the  measuring circuit mode.
- The measurement range for ESR or G is automatically selected according to the range for L and the measuring frequency. Refer to Table D-4.
- How to read the accuracy table


Upper column: Accuracy of ESR  
Lower column: Accuracy of G

Accuracy:  $\pm$  (reading % + count + residue)

- The accuracy for --- in the table is not specified.
- Accuracy factor

$$\alpha = k_2 \cdot \frac{\text{Measured value of L}}{\text{Range value of L}} \quad (\text{For } k_2, \text{ refer to graph (c) on page 1-21.})$$

| Range value    |              |                                      |  |
|----------------|--------------|--------------------------------------|--|
| ESR            | G            |                                      |  |
| 10 M $\Omega$  | 1 $\mu$ S    | $\Delta(3, 2, 1, -)$<br>(4, 3, 2, 1) | ----   |
| 1 M $\Omega$   | 10 $\mu$ S   | $\Delta(3, 3, 2, 1)$<br>(4, 4, 3, 2) | 1%+2+(0.003 $\alpha$ +0.01 $\alpha^2$ )M $\Omega$<br>1%+3+(0.002/ $\alpha$ ) $\mu$ S |
| 100 k $\Omega$ | 100 $\mu$ S  | $\Delta(3, 3, 3, 2)$<br>(4, 4, 4, 3) | 0.2%+2+(0.3 $\alpha$ + $\alpha^2$ )k $\Omega$<br>0.1%+3+(0.02/ $\alpha$ ) $\mu$ S    |
| 10 k $\Omega$  | 1000 $\mu$ S | $\Delta(3, 3, 3, 2)$<br>(4, 4, 4, 3) | 0.2%+2+(0.03 $\alpha$ +0.1 $\alpha^2$ )k $\Omega$<br>0.1%+3+(0.2/ $\alpha$ ) $\mu$ S |
| 1 k $\Omega$   | 10 mS        | $\Delta(3, 3, 3, 2)$<br>(4, 4, 4, 3) | 0.2%+2+(0.003 $\alpha$ +0.01 $\alpha^2$ )k $\Omega$<br>0.1%+3+(0.002/ $\alpha$ )mS   |
| 100 $\Omega$   | 100 mS       | (4, 4, 4, 3)<br>$\Delta(3, 3, 3, 2)$ | 0.1%+2+(0.06 $\alpha$ ) $\Omega$<br>0.1%+1+(0.2/ $\alpha$ +0.2/ $\alpha^2$ )mS       |
| 10 $\Omega$    | 1000 mS      | (4, 4, 4, 3)<br>$\Delta(3, 3, 3, 2)$ | 0.1%+2+(0.006 $\alpha$ ) $\Omega$<br>0.1%+1+(2/ $\alpha$ +2/ $\alpha^2$ )mS          |
| 1 $\Omega$     | 10 S         | (4, 4, 3, 2)<br>$\Delta(3, 3, 2, 1)$ | 0.3%+3+(0.0006 $\alpha$ ) $\Omega$<br>0.3%+1+(0.02/ $\alpha$ +0.02/ $\alpha^2$ )S    |
| 0.1 $\Omega$   | 100 S        | (4, 3, 2, 1)<br>$\Delta(3, 2, 1, -)$ | 0.8%+2+(0.0001 $\alpha$ ) $\Omega$<br>1%+1+(0.3/ $\alpha$ +0.5/ $\alpha^2$ )S        |



#### REMARKS:

1) Number of significant display digits

Upper column( ): Number of display digits of ESR  
Lower column( ): Number of display digits of G

The number of display digits is one in the case where the measurement speed mode is NORMAL and the range representative is displayed. The number of digits marked with  $\Delta$  varies with the measured value.

2) Measurement range in the 1 V range in the NORMAL mode

ESR: 0.0001  $\Omega$  to 1.999 M $\Omega$


G : 0.001  $\mu$ S to 199 S



Table 1-1. Specifications (Continued)

Table D-4. ESR/G Range Selection in L-ESR/G Measurement

| L range |        |                 |                 |                 |                 |
|---------|--------|-----------------|-----------------|-----------------|-----------------|
| Code    | Value  |                 |                 |                 |                 |
| R22     | 10 kH  | 10 MΩ / 1 μS    |                 |                 |                 |
| R21     | 1 kH   | 1 MΩ / 10 μS    | 10 MΩ / 1 μS    |                 |                 |
| R20     | 100 H  | 100 kΩ / 100 μS | 1 MΩ / 10 μS    | 10 MΩ / 1 μS    |                 |
| R19     | 10 H   | 10 kΩ / 1000 μS | 100 kΩ / 100 μS | 1 MΩ / 10 μS    | 10 MΩ / 1 μS    |
| R18     | 1 H    | 1 kΩ / 10 mS    | 10 kΩ / 1000 μS | 100 kΩ / 100 μS | 1 MΩ / 10 μS    |
| R17     | 100 mH | 100 Ω / 100 mS  | 1 kΩ / 10 mS    | 10 kΩ / 1000 μS | 100 kΩ / 100 μS |
| R16     | 10 mH  | 10 Ω / 1000 mS  | 100 Ω / 100 mS  | 1 kΩ / 10 mS    | 10 kΩ / 1000 μS |
| R15     | 1 mH   | 1 Ω / 10 S      | 10 Ω / 1000 mS  | 100 Ω / 100 mS  | 1 kΩ / 10 mS    |
| R14     | 100 μH | 0.1 Ω / 100 S   | 1 Ω / 10 S      | 10 Ω / 1000 mS  | 100 Ω / 100 mS  |
| R13     | 10 μH  |                 | 0.1 Ω / 100 S   | 1 Ω / 10 S      | 10 Ω / 1000 mS  |
| R12     | 1 μH   |                 |                 | 0.1 Ω / 100 S   | 1 Ω / 10 S      |
| R11     | 0.1 μH |                 |                 |                 | 0.1 Ω / 100 S   |




REMARKS: How to read the table


ESR range value/G range value

Table 1-1. Specifications (Continued)

Graph (a) Accuracy factor  $\beta$  in C measurement (High impedance)



Graph (b) Accuracy factor  $k_0$  in C measurement (Low impedance)



Graph (c) Accuracy factor  $k_2$  in L measurement




Table 1-1. Specifications (Continued)

**12. External Interface**

(1) GP-IB interface: Remote control and measured data output (IEEE-488 compatible)

|                         |   |
|-------------------------|---|
| Interface function      | SH1, AH1, T5, L4, SR1, RL1, DT1, DC1  |
| Remote program function | Remote programming of all front panel key functions, except the power switch and OSC LEVEL FINE adjuster  |
| Data output             | Data shown on the main and sub displays: Measured value, deviation measurement reference, judgment limits, monitor signal voltage or current, and internal settings |

(2) External control interface: External measurement start input signal, comparator judgment output signal, and overall judgment relay contact output

(3) External frequency input and external frequency data interface:

Measurement can be made at an external frequency by entering a signal whose frequency is 16 times higher than the measuring frequency and specifying the frequency value.

|                               |   |
|-------------------------------|---|
| Measuring frequency range     | 100Hz - 100kHz  |
| Input frequency               | A signal whose frequency is 16 times higher than the measuring frequency is entered. (1.6 kHz to 1.6 MHz) |
| Frequency value specification | Specification can be made through the GP-IB interface or external frequency data interface                |

**13. General Specifications**

(1) Power requirements: 100/120/220/240 VAC  $\pm$  10%, 50/60 Hz

(2) Power consumption: 55 VA maximum

(3) Operating temperature/humidity ranges: temperature +5 to +35°C, relative humidity 40% to 80%

(4) Working temperature range: 0 to +40°C

(5) Storage temperature range: -20 to +60°C

(6) Dimensions: approx. 177(H)  $\times$  425(W)  $\times$  450(D) mm (The protrusions are not included.)

(7) Mass: approx. 17 kg

Table 1-2. Reference Data

## 1. Measurement Accuracy

(1) Errors with the signal level range is set for 10 mV (with the OSC LEVEL FINE adjuster set for MAX)

|                           |  |
|---------------------------|--|
| Z  - $\theta$ measurement | For  Z , the term containing $a_0$ is multiplied by 10. (The accuracy of $\theta$ is not specified.) |
| R-X/B, LC measurement     | All % error terms that contain $a_0$ or $\gamma$ are multiplied by 10.                               |
| C-D/Q measurement         | All terms that contain $\alpha$ are multiplied by 10.  |
| C-ESR/G measurement       | Same as given in the specification. However, the error increases as the number of digits decreases.  |
| L-D/Q measurement         | All terms that contain $\alpha$ are multiplied by 10.  |
| L-ESR/G measurement       | Same as given in the specification. However, the error increases as the number of digits decreases.  |

(2) Accuracy of C or L when  $D > 0.1$  and accuracy of R when  $Q > 0.1$

|   |   |
|---|---|
| Accuracy of C or L when $D > 0.1$         | The specified accuracy is multiplied by $(1 + D^2)$ . |
| Accuracy of R when $Q > 0.1$ ( $D < 10$ ) | The specified accuracy is multiplied by $(1 + Q^2)$ . |


(3) Error with the OSC LEVEL FINE adjuster set to a position other than MAX

When the OSC LEVEL FINE adjuster is set to a position other than MAX, the following factor is multiplied.

$$\left(1 + \frac{0.1}{\text{*relative level ratio}}\right)$$

\* Relative level ratio when the open voltage at  $H_{CUR}$  is 1 with the OSC LEVEL FINE adjuster set for MAX

(About  $0.1 \leq (\text{relative level ratio}) < 1$ )



## 2. Level Monitor Display Range and Accuracy

| Level Monitor | Display Range              | Accuracy  |
|---------------|----------------------------|---|
| Voltage (V)   | 0.001 mV to 5.00 V or more | $\pm (3\% \text{ of reading} + 1 \text{ count})$ at 1 mV to 5 V |
| Current (mA)  | 0.001 mA to 100 mA or more | $\pm (3\% \text{ of reading} + 1 \text{ count})$                |

3.  $H_{CUR}$  Signal Output Impedance: about  $50 \Omega$

Table 1-2. Reference Data (Continued)

**4. Measurement Time (Typical)**

The measurement time varies with the measuring frequency and measurement speed mode.

| Measurement Speed Mode | Measurement Time (Typical)                            |
|------------------------|---|
| FAST                   | About 150 to 200 ms ( $f \geq 1$ kHz)                 |
|                        | About 150 to 250 ms ( $f < 1$ kHz)                    |
| NORMAL                 | About 250 to 300 ms ( $f \geq 1$ kHz)                 |
|                        | About 250 to 350 ms ( $f < 1$ kHz)                    |
| SLOW                   | About 9 times the measurement time in the NORMAL mode |

**REMARKS:**

- 1) The measurement time is the time interval from the instant an external measurement through the external control interface is started to the moment the measurement end signal is output. It is measured by the internal frequency.
- 2) When the measuring voltage or current is monitored, the measurement time is increased by about 100 to 150 ms.
- 3) When the measurement range is changed, the time for changing the range, 0.2 to 1.5 sec, is added.
- 4) When the comparator is used, about 10 ms is added.

**5. Signal Stabilization Time**

- (1) When the measuring frequency or signal level range is changed: about 600 to 850 ms  
(The apparatus automatically waits for the above time period.)
- (2) When the OSC LEVEL FINE adjuster is used: about 2 to 3 sec

**6. Internal Measuring Frequency and Frequency Accuracy**

- (1) Internal measuring frequency

The measuring frequency is calculated by the following formula.

$$f = \frac{20 \times 10^6}{16 \cdot N} \text{ (Hz)} \quad (\text{N is the frequency division ratio shown on the next page.})$$

- (2) Frequency accuracy

For 100, 200, 250, 500, 1k, 2k, 2.5k, 5k, 10k, 25k, 50k, 62.5k, 100kHz,

the accuracy is within  $\pm 1 \times 10^{-4}$ .

For other frequencies, the fractions below the lowest-order digit of their nominal values are ignored.

Table 1-2. Reference Data (Continued)

| Measuring Frequency and Frequency Division Ratio |                           |                    |                    |                           |                    |
|--|---------------------------|--------------------|--------------------|---------------------------|--------------------|
| Nominal Value (Hz)                               | Measuring Frequency (kHz) | Division Ratio (N) | Nominal Value (Hz) | Measuring Frequency (kHz) | Division Ratio (N) |
| 100  | 0.1                       | 12500              | 4.01 k             | 4.00641                   | 312                |
| 120  | 0.120077                  | 10410              | 5.00 k             | 5.                        | 250                |
| 150  | 0.150060                  | 8330               | 6.01 k             | 6.00962                   | 208                |
| 200  | 0.2                       | 6250               | 8.01 k             | 8.01282                   | 156                |
| 250  | 0.25                      | 5000               | 10.0 k             | 10.                       | 125                |
| 300  | 0.300481                  | 4160               | 12.0 k             | 12.0192                   | 104                |
| 401  | 0.400641                  | 3120               | 15.1 k             | 15.0602                   | 83                 |
| 500  | 0.5                       | 2500               | 20.2 k             | 20.1613                   | 62                 |
| 601  | 0.600962                  | 2080               | 25.0 k             | 25.                       | 50                 |
| 801  | 0.801282                  | 1560               | 30.5 k             | 30.4878                   | 41                 |
| 1.00 k   | 1.                        | 1250               | 40.3 k             | 40.3226                   | 31                 |
| 1.20 k   | 1.20077                   | 1041               | 50.0 k             | 50.                       | 25                 |
| 1.50 k   | 1.50060                   | 833                | 62.5 k             | 62.5                      | 20                 |
| 2.00 k   | 2.                        | 625                | 78.1 k             | 78.125                    | 16                 |
| 2.50 k   | 2.5                       | 500                | 100 k              | 100                       | (12.5)             |
| 3.00 k   | 3.00481                   | 416                |                    |                           |                    |

(The above measuring frequencies are calculated values.)

#### 7. Measurement by an External Frequency

- (1) Input frequency: A signal whose frequency is 16 times higher than the measuring frequency is entered. (1.6 kHz to 1.6 MHz)
- (2) Input level: 100 mVp-p to 5 Vp-p, sine wave or square wave
- (3) Input impedance: 1 k $\Omega$  or more
- (4) Input frequency specification: Specification is made through the GP-IB interface or external frequency data interface. (The value 16 times the measuring frequency is specified.)
- (5) Measurement accuracy: Conforms to the accuracy of measurement by the internal frequency when the external frequency accuracy is within  $\pm 1 \times 10^{-4}$ , the frequency value is specified by five digits, and the phase noise (residual FM) is -50 dB or less.

## SECTION 2 PREPARATION FOR USE

### 2.1 INTRODUCTION

This section deals with unpacking, acceptance inspection, power, and repacking.

### 2.2 UNPACKING AND ACCEPTANCE INSPECTION

This apparatus has been factory inspected, mechanically and electrically, prior to shipment to ensure that it gives satisfactory performance. When your order is received, promptly unpack it and check it for damage in transit.

When unpacking the apparatus, save the wooden box, corrugated cardboard box, cushions, and other packing materials except consumables like steel bands and wrapping paper where possible so that they may be reused when the apparatus is to be packed again for shipment.

#### (1) Mechanical inspection

inspect the apparatus for damage in transit, and check its switches, terminals, and other parts exposed to view for looseness or other faults. Check the types and quantity of accessories and spare parts against the packing list.

#### (2) Performance test

If the apparatus is found by the mechanical inspection to be in good order externally, then test it to check its performance. If the apparatus is found damaged or faulty in the acceptance inspection, immediately report the damage or fault to your nearest Ando dealer.

### 2.3 POWER

This apparatus is designed to operate on 100, 120, 220, or 240 VAC. The AC voltage setting should be set by the AC line voltage selector located on the rear panel of the apparatus. The voltage setting procedure is shown in Fig. 2-1.

A power fuse with an appropriate capacity should be used according to the line voltage. If the voltage setting is changed, replace the fuse in the fuse holder with a proper one shown in Table 2-1.

The AC voltage setting of the apparatus has been factory set at 100 V (standard setting).

#### NOTE

Before turning on the apparatus, be sure to check that the voltage setting of the AC line voltage selector on the rear panel agrees with the AC line voltage to be used, and also check that the power fuse is suited for the line voltage.

The power fuse is installed inside the AC line connector module on the rear panel of the apparatus. The power fuse replacement procedure is shown in Fig. 2-2.




Fig. 2-1. Line Voltage Setting Procedure

Table 2-1. Power Fuse

| AC Line Voltage |             | Power Fuse | Remarks                             |
|-----------------|-------------|------------|-------------------------------------|
| 240 V           | 216 - 264 V | 0.5A/250 V | Fast acting type<br>(5.2 φ × 20 mm) |
| 220 V           | 198 - 242 V |            |                                     |
| 120 V           | 108 - 132 V | 1A/250 V   |                                     |
| 100 V           | 90 - 110 V  |            |                                     |






Fig. 2-2. Power Fuse Replacement Procedure

## 2.4 POWER CORD

This apparatus is supplied with a removable 3-core power cord. On the ends of the power cord are provided plugs for connection with the apparatus and power outlet.

Connect the apparatus side plug to the AC line connector module on the rear panel of the apparatus, and the other plug to a grounded 3-pole power outlet. Use of the supplied 3-core power plug shorts the apparatus to ground via the ground line so that accidental electrical shocks from the AC line can be prevented.

### NOTE

The shape of plug on the apparatus side may differ with supply voltages. The maximum rated voltage for the power cord (UL3P type) supplied as a standard accessory is 125 VAC. When a voltage higher than 125 VAC is to be used, use a power plug-attached power cord suited for the operating voltage.

**REMARKS**

If a 2-pole power outlet with no ground terminal is to be used, use the supplied 3-to-2 pole conversion adapter. When using the adapter, short its ground terminal or the FG (frame ground) terminal on the rear panel to ground for safety. (The conversion adapter is provided only when the UL3P power cord (100-120 VAC) is supplied.)

**2.5 REPACKING**

When repacking the apparatus, use the packing materials, if saved for later use. If they have not been saved, repack the apparatus exercising care as suggested below.

- (1) Wrap the apparatus in strong paper like tarpaulin paper or vinyl sheeting. Protect all the protrusions with cushions against damage.
- (2) Place the wrapped apparatus in a wooden or cardboard box which is larger by about 10 cm than the apparatus on all sides.
- (3) Fill all open spaces between the apparatus and the box with polyurethane foam or any other suitable cushioning material. The apparatus may rattle and be damaged in transit, if cushioning is insufficient.
- (4) Cover the wooden box and brace it up with steel bands. If a corrugated cardboard box is used, seal it with adhesive tape.
- (5) Indicate the contents and shipping marks in a legible and durable way.

## SECTION 3 OPERATION

### 3.1 INTRODUCTION

This section describes the functions of the panel controls of the apparatus, operating precautions, and typical measuring procedures. Be sure to observe the precautions given in this section so as to protect the operator and the apparatus against accidents.

### 3.2 DESCRIPTION OF THE CONTROLS

The names and functions of the panel controls are shown in Tables 3-1 and 3-2. As these controls will be referred to by the names given in this section throughout this manual, it is recommended that the operator familiarize himself with their names and functions before operation. The letters or symbols in brackets indicate markings provided on the front and rear panels of the apparatus.

### 3.3 OPERATING PRECAUTIONS

#### CAUTION

Improper operation of the apparatus not only provides incorrect measurements but also causes malfunction of or damage to the apparatus. To ensure proper operation, be sure to observe the precautions given in this section.

#### (1) Installation

- ① Place the apparatus on a stable flat table.

If the apparatus is set on a wobbling or inclined table, it may drop to the floor, causing damage to itself or hurting the operator.

- ② Do not install the apparatus in a place subject to direct sunlight.

The apparatus should be used indoors at a temperature of 5 to 35°C and at a relative humidity of 40% to 80%.

If the apparatus is exposed to direct sunlight, it may be excessively heated and damaged.

- ③ Allow at least 10 cm clearance between the rear panel and the wall or any other instrument.

The inside of the apparatus is cooled by the fan motor provided on the rear panel. If the rear panel is blocked or the apparatus is used in an ill-ventilated place, the inside of the apparatus will be excessive heated, causing damage to the apparatus. Also avoid using the apparatus in a place subject to excessive dust or corrosive gases.

- ④ Do not use the apparatus in a location near noise sources.

If the apparatus is used near a noise-generating device (fluorescent lamp, motor, television set, or large current switch), it may not make measurements correctly.

**(2) Operating voltage and grounding**

- ① Before connecting the power cord, check that the setting of AC line voltage selector agrees with the AC line voltage to be used. (To change the AC voltage setting, perform the steps described in Section 2.3.)
- ② As the power cord, use the 3-core cord supplied. Be sure to short the apparatus to ground. When using a 2-pole conversion adapter with no grounding terminal, be sure to short the grounding terminal of the conversion adapter or the FG terminal on the rear panel to ground.

**— WARNING —**


If you touch a metallic part of the apparatus while it is being used without being grounded, you may receive an electric shock or the sample may be destroyed. To avoid electric shock hazards, be sure to short the apparatus to ground before operation.

**(3) Connection of a charged capacitor****— CAUTION —**

Before connecting a capacitor with the apparatus, be sure to discharge the capacitor.

This apparatus is provided with an input protective circuit which blocks the flow of excessive discharge current from a capacitor connected with the apparatus. However, if the apparatus is connected with a capacitor charged at a voltage higher than 35 V, the apparatus may be damaged. When a capacitor is to be measured, be sure to discharge it before connecting it with the apparatus.

Table 3-1. Front Panel



| No. | Name and Marking   | Function  |
|-----|--|---|
| ①   | Power switch<br>[POWER]    [  ON ]<br>[  OFF ]   | <ul style="list-style-type: none"> <li>• If this switch is pressed, it is set to ON to apply power to the apparatus.</li> <li>• If it is pressed again, its knob comes up and it is set to OFF.</li> </ul>  |
| ②   | MAIN DISPLAY   | <ul style="list-style-type: none"> <li>• The measured value of main parameter L, C, R, or  Z , its unit, and the result of comparator judgment are displayed.</li> <li>• When a reference value or limit values are set, the reference value or main parameter upper and lower limits are displayed.</li> </ul>   |
| ③   | SUB DISPLAY  | <ul style="list-style-type: none"> <li>• The measured value of subparameter D, Q, ESR, G, X, B, L, C, or <math>\theta</math>, its unit, and the result of comparator judgment are displayed.</li> <li>• When limit values are set, the subparameter upper and lower limits are displayed.</li> </ul>  |
| ④   | CHECK DISPLAY  | <ul style="list-style-type: none"> <li>• The measuring frequency, signal level range, signal voltage monitor value, or current monitor value is displayed. The item to be displayed should be selected by the SIGNAL CHECK key.</li> </ul>  |
| ⑤   | GP-IB status LEDs<br>[SRQ]    [LISTEN]<br>[TALK]    [REMOTE]   | <ul style="list-style-type: none"> <li>• The status of the apparatus in the GP-IB control mode is indicated.</li> </ul>   |
| ⑥   | Measurement terminals<br>[UNKNOWN]<br>[H<sub>CUR</sub>]    [H<sub>POT</sub>]<br>[L<sub>POT</sub>]    [L<sub>CUR</sub>] | <ul style="list-style-type: none"> <li>• These terminals are used for connecting the sample or measuring tools (test fixture, test lead, measurement cable, etc.).</li> <li>• These terminals consist of the following pairs: current terminal H&lt;sub&gt;CUR&lt;/sub&gt; and voltage terminal H&lt;sub&gt;POT&lt;/sub&gt; on the HIGH side, and current terminal L&lt;sub&gt;CUR&lt;/sub&gt; and voltage terminal L&lt;sub&gt;POT&lt;/sub&gt; on the LOW side.</li> </ul> |
| ⑦   | Guard terminal<br>[G]  | <ul style="list-style-type: none"> <li>• This terminal is used to guard the apparatus. It is connected to the chassis of the apparatus.</li> </ul>  |

Table 3-1. Front Panel (Continued)



















| No.           | Name and Marking   | Function  |   |              |               |                     |                           |                             |       |  |   |   |   |                 |   |                |   |   |   |                               |          |          |
|---------------|--|---|---|--------------|---------------|---------------------|---------------------------|-----------------------------|-------|--|---|---|---|-----------------|---|----------------|---|---|---|-------------------------------|----------|----------|
| 8             | <p>PARAMETER keys</p>       | <p>These keys are used for measurement parameter selection.</p> <ul style="list-style-type: none"> <li>The main parameter can be selected directly by these keys.</li> <li>The subparameter can be selected by repetitively pressing the same key.</li> </ul> <table border="1" data-bbox="683 454 1430 909"> <thead> <tr> <th rowspan="2">PARAMETER key</th> <th rowspan="2">MAIN DISPLAY</th> <th colspan="2">SUB DISPLAY</th> </tr> <tr> <th>Series equivalent circuit</th> <th>Parallel equivalent circuit</th> </tr> </thead> <tbody> <tr> <td>L</td> <td>L (Inductance)</td> <td rowspan="2">  </td> <td rowspan="2">  </td> </tr> <tr> <td>C</td> <td>C (Capacitance)</td> </tr> <tr> <td>R</td> <td>R (Resistance)</td> <td>  </td> <td>  </td> </tr> <tr> <td>Z</td> <td> Z  (Absolute impedance value)</td> <td><math>\theta</math></td> <td><math>\theta</math></td> </tr> </tbody> </table> <p>When a reference value or limit values are to be set (the LIMIT or REF key LED is on), these keys are used as 0-3 number keys.</p> | PARAMETER key   | MAIN DISPLAY | SUB DISPLAY   |                     | Series equivalent circuit | Parallel equivalent circuit | L     | L (Inductance)                             |  |  | C | C (Capacitance) | R | R (Resistance) |  |  | Z | Z  (Absolute impedance value) | $\theta$ | $\theta$ |
| PARAMETER key | MAIN DISPLAY   | SUB DISPLAY   |   |              |               |                     |                           |                             |       |  |   |   |   |                 |   |                |   |   |   |                               |          |          |
|               |  | Series equivalent circuit   | Parallel equivalent circuit   |              |               |                     |                           |                             |       |  |   |   |   |                 |   |                |   |   |   |                               |          |          |
| L             | L (Inductance)   |    |  |              |               |                     |                           |                             |       |  |   |   |   |                 |   |                |   |   |   |                               |          |          |
| C             | C (Capacitance)  |   |   |              |               |                     |                           |                             |       |  |   |   |   |                 |   |                |   |   |   |                               |          |          |
| R             | R (Resistance)   |    |  |              |               |                     |                           |                             |       |  |   |   |   |                 |   |                |   |   |   |                               |          |          |
| Z             | Z  (Absolute impedance value)  | $\theta$  | $\theta$  |              |               |                     |                           |                             |       |  |   |   |   |                 |   |                |   |   |   |                               |          |          |
| 9             | <p>CIRCUIT MODE keys</p>  | <p>These keys are used for equivalent circuit mode selection.</p> <ul style="list-style-type: none"> <li>If AUTO is pressed, either the series () or parallel () equivalent circuit is automatically selected, according to the impedance of the sample.</li> </ul> <p>When a reference value or limit values are to be set, these keys are used as 4-6 number keys.</p>  |   |              |               |                     |                           |                             |       |  |   |   |   |                 |   |                |   |   |   |                               |          |          |
| 10            | <p>SIGNAL CHECK keys</p>  | <p>These keys are used to select the item to be shown on the check display.</p> <table border="1" data-bbox="683 1263 1422 1496"> <thead> <tr> <th>SIGNAL CHECK</th> <th>Display Item</th> </tr> </thead> <tbody> <tr> <td>FREQUENCY Key</td> <td>Measuring frequency</td> </tr> <tr> <td>LEVEL Key</td> <td>Signal level range</td> </tr> <tr> <td>V Key</td> <td>Signal voltage (voltage across the sample)</td> </tr> <tr> <td>mA Key</td> <td>Signal current (current flowing through the sample)</td> </tr> </tbody> </table> <p>When a reference value or limit values are to be set, these keys are used as 7-9 number keys and a CE (clear) key.</p>  | SIGNAL CHECK  | Display Item | FREQUENCY Key | Measuring frequency | LEVEL Key                 | Signal level range          | V Key | Signal voltage (voltage across the sample) | mA Key  | Signal current (current flowing through the sample)                                 |   |                 |   |                |   |   |   |                               |          |          |
| SIGNAL CHECK  | Display Item   |   |   |              |               |                     |                           |                             |       |  |   |   |   |                 |   |                |   |   |   |                               |          |          |
| FREQUENCY Key | Measuring frequency  |   |   |              |               |                     |                           |                             |       |  |   |   |   |                 |   |                |   |   |   |                               |          |          |
| LEVEL Key     | Signal level range   |   |   |              |               |                     |                           |                             |       |  |   |   |   |                 |   |                |   |   |   |                               |          |          |
| V Key         | Signal voltage (voltage across the sample)   |   |   |              |               |                     |                           |                             |       |  |   |   |   |                 |   |                |   |   |   |                               |          |          |
| mA Key        | Signal current (current flowing through the sample)  |   |   |              |               |                     |                           |                             |       |  |   |   |   |                 |   |                |   |   |   |                               |          |          |
| 11            | <p>COMP ENABLE key</p>    | <p>This key is used to turn on or off the comparator.</p> <ul style="list-style-type: none"> <li>Each time the key is pressed, either ON (LED ON) or OFF (LED OFF) is alternately selected.</li> <li>To perform comparator operation, it is necessary to set limit values in advance.</li> </ul> <p>When a reference value or limit values are to be set, the key is used as a DP (decimal point) key.</p>  |   |              |               |                     |                           |                             |       |  |   |   |   |                 |   |                |   |   |   |                               |          |          |

Table 3-1. Front Panel (Continued)




| No.  | Name and Marking   | Function   |      |        |   |   |    |        |      |       |   |        |    |     |  |     |
|------|--|--|------|--------|---|---|----|--------|------|-------|---|--------|----|-----|--|-----|
| 12   | <b>DEVIATION keys</b><br>             | <p>These keys are used to specify deviation measurement (deviation display <math>\Delta</math> or percent deviation display <math>\Delta\%</math>).</p> <ul style="list-style-type: none"> <li>Each time any of these keys is pressed, either ON (LED ON) or OFF (LED OFF) is alternately selected.</li> <li>To make a deviation measurement, it is necessary to set a reference value in advance.</li> </ul> <p>When a reference value or limit values are to be set, these keys are used as <math>\rightarrow</math> (cursor movement) and +/- (polarity change) keys.</p>   |      |        |   |   |    |        |      |       |   |        |    |     |  |     |
| 13   | <b>RANGE keys</b><br>                 | <p>These keys are used for measurement range selection.</p> <ul style="list-style-type: none"> <li>In the AUTO mode, the optimum range is automatically selected, according to the impedance of the sample.</li> <li>If the UP or DOWN key is pressed after measurement in the AUTO mode, the measurement range selected during the measurement is held.</li> <li>If OF or UF is displayed during measurement in the MANUAL range, it means that the measured data is outside the set range. If such is the case, change the measurement range by using the UP or DOWN key, or select AUTO.</li> </ul> <p>When a reference value or limit values are set, these keys are used as unit select keys.</p> <ul style="list-style-type: none"> <li>When limit values are set, the unit at the cursor position (MAIN DISPLAY or SUB DISPLAY) can be selected.</li> </ul>   |      |        |   |   |    |        |      |       |   |        |    |     |  |     |
| 14   | <b>FREQUENCY and LEVEL keys</b><br> | <p><b>FREQUENCY UP/DOWN keys</b><br/> These keys are used for measuring frequency selection.</p> <ul style="list-style-type: none"> <li>Select the desired frequency by pressing the UP or DOWN key.</li> </ul> <table style="margin-left: auto; margin-right: auto;"> <tr> <td style="text-align: center;">DOWN</td> <td style="text-align: center;">100 Hz</td> </tr> <tr> <td style="text-align: center;">↑</td> <td style="text-align: center;">}</td> </tr> <tr> <td style="text-align: center;">UP</td> <td style="text-align: center;">100kHz</td> </tr> </table> <ul style="list-style-type: none"> <li>If the UP or DOWN key is pressed and held down, the frequency is continuously changed until the upper limit (100 kHz) or lower limit (100 Hz) is reached.</li> </ul> <p><b>LEVEL UP/DOWN keys</b><br/> These keys are used for signal level range selection.</p> <ul style="list-style-type: none"> <li>Select the desired level range from among four ranges 5 V, 1 V, 100 mV, and 10 mV, by pressing the UP or DOWN key.</li> </ul> <table style="margin-left: auto; margin-right: auto;"> <tr> <td style="text-align: center;">DOWN</td> <td style="text-align: center;">10 mV</td> </tr> <tr> <td style="text-align: center;">↑</td> <td style="text-align: center;">100 mV</td> </tr> <tr> <td style="text-align: center;">UP</td> <td style="text-align: center;">1 V</td> </tr> <tr> <td></td> <td style="text-align: center;">5 V</td> </tr> </table> <p><b>LEVEL FINE adjuster</b><br/> This adjuster is used to make a fine adjustment of the signal level.</p> <ul style="list-style-type: none"> <li>The signal level can be adjusted over the range of <math>\times 0.1</math> (MIN) to <math>\times 1</math> (MAX) in the range selected by the LEVEL UP or DOWN key.</li> </ul> | DOWN | 100 Hz | ↑ | } | UP | 100kHz | DOWN | 10 mV | ↑ | 100 mV | UP | 1 V |  | 5 V |
| DOWN | 100 Hz   |  |      |        |   |   |    |        |      |       |   |        |    |     |  |     |
| ↑    | }  |  |      |        |   |   |    |        |      |       |   |        |    |     |  |     |
| UP   | 100kHz   |  |      |        |   |   |    |        |      |       |   |        |    |     |  |     |
| DOWN | 10 mV  |  |      |        |   |   |    |        |      |       |   |        |    |     |  |     |
| ↑    | 100 mV   |  |      |        |   |   |    |        |      |       |   |        |    |     |  |     |
| UP   | 1 V  |  |      |        |   |   |    |        |      |       |   |        |    |     |  |     |
|      | 5 V  |  |      |        |   |   |    |        |      |       |   |        |    |     |  |     |

Table 3-1. Front Panel (Continued)




| No.        | Name and Marking  | Function  |   |                   |         |  |       |   |             |   |     |             |     |   |                 |
|------------|---|---|---|-------------------|---------|--|-------|---|-------------|---|-----|-------------|-----|---|-----------------|
| 15         | <b>LIMIT/REF keys</b><br>        | <p>These keys are used to set limit values (upper and lower limits) for comparator measurement or a reference value for deviation measurement.</p> <ul style="list-style-type: none"> <li>• If the LIMIT key is pressed, the key LED comes on, the limit setting mode is entered, and main parameter/subparameter upper and lower values can be set in order named.</li> <li>• If the REF key is pressed, the key LED comes on, the reference setting mode is entered, and a reference value can be set.</li> </ul> <table border="1" data-bbox="663 591 1458 757"> <thead> <tr> <th>Key</th> <th>CHECK DISPLAY</th> <th>Setting</th> <th>Entry</th> </tr> </thead> <tbody> <tr> <td rowspan="2">LIMIT</td> <td>UPL</td> <td>Upper limit</td> <td rowspan="3">Enter the desired value by using the 0-9, DP, CE, →, and UNIT keys.</td> </tr> <tr> <td>LoL</td> <td>Lower limit</td> </tr> <tr> <td>REF</td> <td>—</td> <td>Reference value</td> </tr> </tbody> </table> <ul style="list-style-type: none"> <li>• If the STORE key is pressed in the limit or reference setting mode, the entered value is set.</li> <li>• If the STORE key is pressed with neither the LIMIT or REF key LED on, the value shown on the main display is set as the reference.</li> </ul> | Key   | CHECK DISPLAY     | Setting | Entry                                  | LIMIT | UPL   | Upper limit | Enter the desired value by using the 0-9, DP, CE, →, and UNIT keys. | LoL | Lower limit | REF | — | Reference value |
| Key        | CHECK DISPLAY   | Setting   | Entry   |                   |         |  |       |   |             |   |     |             |     |   |                 |
| LIMIT      | UPL   | Upper limit   | Enter the desired value by using the 0-9, DP, CE, →, and UNIT keys. |                   |         |  |       |   |             |   |     |             |     |   |                 |
|            | LoL   | Lower limit   |   |                   |         |  |       |   |             |   |     |             |     |   |                 |
| REF        | —   | Reference value   |   |                   |         |  |       |   |             |   |     |             |     |   |                 |
| 16         | <b>MEAS START keys</b><br>     | <p>This key is used for measurement start mode selection.</p> <table border="1" data-bbox="663 1021 1439 1245"> <thead> <tr> <th>MEAS START</th> <th>Measurement Start</th> </tr> </thead> <tbody> <tr> <td>AUTO</td> <td>Measurement is automatically repeated.</td> </tr> <tr> <td>EXT</td> <td>Measurement is started when an <u>EXT-MST</u> signal is entered from the EXT CONTROL connector on the rear panel.</td> </tr> <tr> <td>MANUAL</td> <td>Measurement is started each time the key is pressed.</td> </tr> </tbody> </table>   | MEAS START  | Measurement Start | AUTO    | Measurement is automatically repeated. | EXT   | Measurement is started when an <u>EXT-MST</u> signal is entered from the EXT CONTROL connector on the rear panel. | MANUAL      | Measurement is started each time the key is pressed.                |     |             |     |   |                 |
| MEAS START | Measurement Start   |   |   |                   |         |  |       |   |             |   |     |             |     |   |                 |
| AUTO       | Measurement is automatically repeated.  |   |   |                   |         |  |       |   |             |   |     |             |     |   |                 |
| EXT        | Measurement is started when an <u>EXT-MST</u> signal is entered from the EXT CONTROL connector on the rear panel. |   |   |                   |         |  |       |   |             |   |     |             |     |   |                 |
| MANUAL     | Measurement is started each time the key is pressed.  |   |   |                   |         |  |       |   |             |   |     |             |     |   |                 |
| 17         | <b>LOCAL key</b><br>           | <p>This key is used to change the GP-IB remote control mode to the local mode (operations by the panel keys).</p> <div style="border: 1px solid black; padding: 5px;"> <p style="text-align: center;">REMARKS</p> <ul style="list-style-type: none"> <li>• When the apparatus is in the remote mode (the GP-IB status REMOTE LED is on), all keys other than the LOCAL key are inoperative.</li> <li>• In the LLO (local lockout) state, the local mode is not entered even if the LOCAL key is pressed.</li> </ul> </div>  |   |                   |         |  |       |   |             |   |     |             |     |   |                 |



Table 3-1. Front Panel (Continued)





| No.               | Name and Marking   | Function   |                   |                  |      |                        |        |                    |      |  |
|-------------------|--|--|-------------------|------------------|------|------------------------|--------|--------------------|------|--|
| 18                | EXT DC BIAS key<br>             | This key is used to turn on or off the DC bias function. <ul style="list-style-type: none"> <li>Each time this key is pressed, either ON (LED ON) or OFF (LED OFF) is alternately selected.</li> <li>The ON position applies the voltage appearing at the rear panel EXT DC BIAS INPUT terminal to the sample.</li> </ul> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p style="text-align: center;"><b>CAUTION</b></p> <p>The key operation should be performed when no voltage is applied to the rear panel EXT DC BIAS INPUT terminal. Otherwise, an excessively large current may flow into the sample or the internal circuitry of the apparatus may be destroyed.</p> </div>  |                   |                  |      |                        |        |                    |      |  |
| 19                | Zero offset adjustment keys<br> | These keys are used for zero offset adjustment. <ul style="list-style-type: none"> <li>Pressing the SHORT key carries out short ADJ operation.</li> <li>Pressing the OPEN key carries out open ADJ operation.</li> </ul> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p style="text-align: center;"><b>REMARKS</b></p> <p>Zero offset adjustment should be made with the EXT DC BIAS key set to OFF. Otherwise, a proper correction value may not be obtained.</p> </div>   |                   |                  |      |                        |        |                    |      |  |
| 20                | MEAS SPEED key<br>            | This key is used for measurement speed mode selection. <ul style="list-style-type: none"> <li>The desired speed mode can be selected by repetitively pressing the SELECT key.</li> </ul> <table border="1" style="width: 100%; margin-top: 10px;"> <thead> <tr> <th style="text-align: center;">Measurement Speed</th> <th style="text-align: center;">Measurement Mode</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">FAST</td> <td style="text-align: center;">High-speed measurement</td> </tr> <tr> <td style="text-align: center;">NORMAL</td> <td style="text-align: center;">Normal measurement</td> </tr> <tr> <td style="text-align: center;">SLOW</td> <td style="text-align: center;">High-resolution measurement (ten measurements and their averaging)</td> </tr> </tbody> </table> | Measurement Speed | Measurement Mode | FAST | High-speed measurement | NORMAL | Normal measurement | SLOW | High-resolution measurement (ten measurements and their averaging) |
| Measurement Speed | Measurement Mode   |  |                   |                  |      |                        |        |                    |      |  |
| FAST              | High-speed measurement   |  |                   |                  |      |                        |        |                    |      |  |
| NORMAL            | Normal measurement   |  |                   |                  |      |                        |        |                    |      |  |
| SLOW              | High-resolution measurement (ten measurements and their averaging)   |  |                   |                  |      |                        |        |                    |      |  |

Table 3-2. Rear Panel



| No. | Name and Marking   | Function   |
|-----|--|--|
| ①   | AC line connector module<br>[~ LINE 50/60 Hz]  | <ul style="list-style-type: none"> <li>This connector is used for connecting the 3-core power cord. Power is taken from an AC power outlet. A power fuse is installed in this connector module.</li> </ul>   |
| ②   | Line voltage selector<br>[~ LINE VOLTAGE SELECTOR]   | <ul style="list-style-type: none"> <li>This line voltage selector is used to select the desired voltage from among 100, 120, 220, and 240 VAC.</li> </ul>  |
| ③   | FG terminal<br>[ ⚡ ]   | <ul style="list-style-type: none"> <li>A terminal connected with the frame ground of the apparatus. It is also connected with the signal ground inside the apparatus.</li> </ul>   |
| ④   | External DC bias input<br>[EXT DC BIAS]<br>[INPUT][G] terminals<br>[MONITOR] terminal<br>[FUSE][0.1 A] | <ul style="list-style-type: none"> <li>An external DC bias input terminal, monitor terminal, and fuse holder. To apply a DC bias to the sample, connect an external DC power source with the INPUT terminal and press the EXT DC BIAS key on the front panel. A voltage of up to <math>\pm 35</math> V and a current of up to 100 mA can be input from an external power source. A 0.1A fuse is installed in the fuse holder.</li> </ul> |
| ⑤   | GP-IB connector<br>[GP-IB]   | <ul style="list-style-type: none"> <li>This GP-IB interface connector is used to connect the GP-IB cable for data transfer to or from another GP-IB device.</li> </ul>   |
| ⑥   | GP-IB address switch   | <ul style="list-style-type: none"> <li>This switch is used for GP-IB mode selection, GP-IB address setting, and GP-IB output data delimiter setting.</li> </ul>  |
| ⑦   | Speaker volume control<br>[SP VOLUME]  | <ul style="list-style-type: none"> <li>A speaker sound volume control. Turning it fully counterclockwise minimizes the sound volume, and turning it fully clockwise maximizes the sound volume. It should be adjusted so as to obtain an appropriate sound volume.</li> </ul>  |
| ⑧   | External frequency data connector<br>[EXT TEST FREQ DATA]  | <ul style="list-style-type: none"> <li>This connector is used to specify in BCD code the frequency of a signal input to the external frequency input connector (⑨), when making measurement by an external frequency.</li> </ul>   |

Table 3-2. Rear Panel (Continued)

| No. | Name and Marking  | Function  |
|-----|---|---|
| ⑨   | External frequency input connector<br>[EXT TEST FREQ INPUT] | <ul style="list-style-type: none"> <li>This connector is used to input a square or sine wave whose frequency is 16 times higher than the measuring frequency, when making measurement by an external frequency. The maximum input level is 5 Vp-p.</li> </ul> |
| ⑩   | External control connector<br>[EXT CONTROL]                 | <ul style="list-style-type: none"> <li>An external control connector. An external measurement start input signal and comparison result output signals are connected.</li> </ul>   |
| ⑪   | Fan motor ventilating holes                                 | <ul style="list-style-type: none"> <li>Ventilating holes for the internal cooling fan motor.<br/>At least 10 cm should be allowed between the rear panel and the wall or any other instrument.</li> </ul>   |

### 3.4 BASIC OPERATING PROCEDURES

The basic procedures for measuring the sample are shown in Table 3-3. Perform the steps in the order of the numbers shown in the table.

Table 3-3. Basic Operating Procedures













| No.           | Step  | Section to be Referred to   |  |             |  |   |  |   |                |             |           |   |                 |   |  |   |                |       |       |   |                               |          |          |  |
|---------------|---|---|--|-------------|--|---|--|---|----------------|-------------|-----------|---|-----------------|---|--|---|----------------|-------|-------|---|-------------------------------|----------|----------|--|
| 1             | <p><b>Power-on</b></p> <p>(1) Press the power switch to set it to the ON position. The apparatus is then powered up.</p> <p>(2) Check the result of the memory back-up check and self-test.</p> <ul style="list-style-type: none"> <li>On power-on, this apparatus automatically carries out a memory back-up check and self-test. Check that no error display is given.</li> </ul>   | 3.21 BASIC INSPECTION AND MAINTENANCE   |  |             |  |   |  |   |                |             |           |   |                 |   |  |   |                |       |       |   |                               |          |          |  |
| 2             | <p><b>Connecting measuring tools (test fixture, test lead, etc.)</b></p> <ul style="list-style-type: none"> <li>Connect the test fixture or test lead to the measuring terminal of the apparatus.</li> <li>When using the AG-4911 Test Fixture, AG-4912 Test Lead, or any other accessory, connect it properly, following the instructions given in its instruction manual.</li> <li>If using a special tool, refer to Section 3.5.</li> </ul>  | 3.5 CONNECTING THE SAMPLE   |  |             |  |   |  |   |                |             |           |   |                 |   |  |   |                |       |       |   |                               |          |          |  |
| 3             | <p><b>Measurement condition setting</b></p> <p>(1) Select the measurement parameter by using the PARAMETER keys.</p> <ul style="list-style-type: none"> <li>Some of the subparameters (ESR/G, X/B, L/C) are automatically selected, according to the equivalent circuit mode.</li> </ul> <p>Select the equivalent circuit mode by the CIRCUIT MODE key, if necessary.</p> <table border="1" data-bbox="331 1128 1086 1590"> <thead> <tr> <th rowspan="2">PARAMETER key</th> <th rowspan="2">MAIN DISPLAY</th> <th colspan="2">SUB DISPLAY</th> </tr> <tr> <th> (Series equivalent circuit)</th> <th> (Parallel equivalent circuit)</th> </tr> </thead> <tbody> <tr> <td>L</td> <td>L (Inductance)</td> <td>D → Q → ESR</td> <td>D → Q → G</td> </tr> <tr> <td>C</td> <td>C (Capacitance)</td> <td></td> <td></td> </tr> <tr> <td>R</td> <td>R (Resistance)</td> <td>X → L</td> <td>B → C</td> </tr> <tr> <td>Z</td> <td> Z  (Absolute impedance value)</td> <td><math>\theta</math></td> <td><math>\theta</math></td> </tr> </tbody> </table> <p>(2) Select the measuring frequency by using the FREQUENCY key.</p> <p>(3) Select the signal level range by using the LEVEL key.</p> <ul style="list-style-type: none"> <li>The LEVEL FINE adjuster should be set to the MAX (rightmost) position.</li> </ul> <p>(4) Set the measurement range to AUTO.</p> <p>(5) Select the measurement speed mode by using the MEAS SPEED key.</p> | PARAMETER key   | MAIN DISPLAY   | SUB DISPLAY |  |  (Series equivalent circuit) |  (Parallel equivalent circuit) | L | L (Inductance) | D → Q → ESR | D → Q → G | C | C (Capacitance) |  |  | R | R (Resistance) | X → L | B → C | Z | Z  (Absolute impedance value) | $\theta$ | $\theta$ | <p>3.8 MEASUREMENT PARAMETERS</p> <p>3.10 MEASUREMENT SIGNAL SETTING AND MONITORING</p> <p>3.11 MEASUREMENT RANGES</p> <p>3.13 MEASUREMENT SPEED MODES</p> |
| PARAMETER key | MAIN DISPLAY  |   |  | SUB DISPLAY |  |   |  |   |                |             |           |   |                 |   |  |   |                |       |       |   |                               |          |          |  |
|               |   |  (Series equivalent circuit) |  (Parallel equivalent circuit) |             |  |   |  |   |                |             |           |   |                 |   |  |   |                |       |       |   |                               |          |          |  |
| L             | L (Inductance)  | D → Q → ESR   | D → Q → G  |             |  |   |  |   |                |             |           |   |                 |   |  |   |                |       |       |   |                               |          |          |  |
| C             | C (Capacitance)   |                              |                                |             |  |   |  |   |                |             |           |   |                 |   |  |   |                |       |       |   |                               |          |          |  |
| R             | R (Resistance)  | X → L   | B → C  |             |  |   |  |   |                |             |           |   |                 |   |  |   |                |       |       |   |                               |          |          |  |
| Z             | Z  (Absolute impedance value)   | $\theta$  | $\theta$   |             |  |   |  |   |                |             |           |   |                 |   |  |   |                |       |       |   |                               |          |          |  |

Table 3-3. Basic Operating Procedures (Continued)

| No. | Step  | Section to be Referred to  |
|-----|---|----------------------------|
| 4   | <p>Zero offset adjustment</p> <p>(1) Make preparation for open ADJ.<br/>Disconnect the test fixture or test lead from the sample.</p> <ul style="list-style-type: none"> <li>• When using a special tool, connect the <math>H_{CUR}</math> and <math>H_{POT}</math> core conductors, and the <math>L_{CUR}</math> and <math>L_{POT}</math> core conductors on the sample side so that the sample may be disconnected.</li> </ul> <p>(2) Press OFFSET OPEN key to carry out open ADJ.</p> <ul style="list-style-type: none"> <li>• If the main display shows <i>OP-P</i>, it means that the open ADJ has been normally completed.</li> </ul> <p>(3) Make preparation for short ADJ.</p> <ul style="list-style-type: none"> <li>• Connect the shorting bar with the test fixture or test lead.</li> <li>• When using a special tool, connect the <math>H_{CUR}</math>, <math>H_{POT}</math>, <math>L_{CUR}</math>, and <math>L_{POT}</math> core conductors together.</li> </ul> <p>(4) Press the OFFSET ADJ SHORT key to carry out short ADJ.<br/>If the main display shows <i>SH-P</i>, it means that the short ADJ has been normally completed.</p> <div data-bbox="292 869 1129 1070" style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p style="text-align: center;">REMARKS</p> <p>If an error display is given during zero offset adjustment, check the connections. If the connections are correct, it means that the residual parameter value is outside the correction range. In this case, the correction value is cleared and the measured value is displayed without compensating for the residual parameter value.</p> </div> <div data-bbox="292 1115 1129 1317" style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p style="text-align: center;">NOTE</p> <p>The zero offset correction value is valid until power is disconnected. However, after replacing the test fixture or test lead, or after changing the signal level range or measurement speed mode, be sure to make zero offset adjustment (open/short ADJ) again, because the measurement condition differs from the previous one.</p> </div> | 3.7 ZERO OFFSET ADJUSTMENT |

Table 3-3. Basic Operating Procedures (Continued)

| No.   | Step   | Section to be Referred to |         |   |   |                                |  |  |
|---|--|---------------------------|---------|---|---|--------------------------------|--|--|
| 5   | <p><b>Measurement</b></p> <p>(1) Connect the sample with the test fixture or test lead.</p> <p>(2) Set MEAS START to AUTO (repetitive measurement).</p> <ul style="list-style-type: none"> <li>• While the MEASURE LED (LED at the upper left of the MAIN DISPLAY digital display) is on, measurement is in progress. Immediately after a measurement ends, the MEASURE LED goes off and the measured value is displayed.</li> </ul> <p>(3) Monitoring and fine adjustment of the signal level</p> <ul style="list-style-type: none"> <li>• To monitor the signal voltage at the sample end or signal current flowing through the sample, press the SIGNAL CHECK V key or mA key.</li> <li>• To change the signal voltage or signal current, slowly adjust the LEVEL FINE adjuster to the desired voltage or current value, while monitoring the check display.</li> </ul> <p>Messages regarding measured data</p> <table border="1" data-bbox="308 804 1126 1151"> <thead> <tr> <th data-bbox="308 804 547 860">Display</th> <th data-bbox="547 804 1126 860">Meaning</th> </tr> </thead> <tbody> <tr> <td data-bbox="308 860 547 1070"> <i>OF</i><br/>(Over Flow)<br/><i>UF</i><br/>(Under Flow) </td> <td data-bbox="547 860 1126 1070">           When the measurement range is AUTO:<br/>Not within the measurement limits.<br/>When the measurement range is MANUAL:<br/>Not within the measurement limits in the present measurement range. Change the measurement range to AUTO or an appropriate range. </td> </tr> <tr> <td data-bbox="308 1070 547 1151"> <i>CF</i><br/>(Change Function) </td> <td data-bbox="547 1070 1126 1151">           Improper measurement parameter setting.<br/>Change the measurement parameter. </td> </tr> </tbody> </table> | Display                   | Meaning | <i>OF</i><br>(Over Flow)<br><i>UF</i><br>(Under Flow) | When the measurement range is AUTO:<br>Not within the measurement limits.<br>When the measurement range is MANUAL:<br>Not within the measurement limits in the present measurement range. Change the measurement range to AUTO or an appropriate range. | <i>CF</i><br>(Change Function) | Improper measurement parameter setting.<br>Change the measurement parameter. | <p>3.12 STARTING MEASUREMENT</p> <p>3.10 MEASUREMENT SIGNAL SETTING AND MONITORING</p> |
| Display   | Meaning  |                           |         |   |   |                                |  |  |
| <i>OF</i><br>(Over Flow)<br><i>UF</i><br>(Under Flow) | When the measurement range is AUTO:<br>Not within the measurement limits.<br>When the measurement range is MANUAL:<br>Not within the measurement limits in the present measurement range. Change the measurement range to AUTO or an appropriate range.  |                           |         |   |   |                                |  |  |
| <i>CF</i><br>(Change Function)                        | Improper measurement parameter setting.<br>Change the measurement parameter.   |                           |         |   |   |                                |  |  |

### 3.5 CONNECTING THE SAMPLE

The UNKNOWN terminals for connecting the sample with the apparatus consist of four BNC connectors:  $H_{CUR}$ ,  $H_{POT}$ ,  $L_{POT}$ , and  $L_{CUR}$ . The  $H_{CUR}$  and  $L_{CUR}$  terminals are used to flow a signal current through the sample. A measurement signal is output from the  $H_{CUR}$  terminal. The  $H_{POT}$  and  $L_{POT}$  terminals are used to detect the signal voltage applied to the sample.

Fig. 3-1 shows how to connect the sample with the apparatus. As shown in the figure, the core conductors of the  $H_{CUR}$  and  $H_{POT}$  terminals on the HIGH side are connected to one end of the sample, and the core conductors of the  $L_{POT}$  and  $L_{CUR}$  terminals on the LOW side are connected to the other end of the sample. The outer conductors of these terminals are connected to the connection with the sample. In this arrangement, the measurement signal current flows from the core conductor of the  $H_{CUR}$  terminal through the sample to the core conductor of the  $L_{CUR}$  terminal. The signal current further flows from the outer conductor of the  $L_{CUR}$  terminal, passes through the cable, and returns to the outer conductor of the  $H_{CUR}$  terminal.




Fig. 3-1. 4-terminal Pair Connection

The signal current flowing through the core conductor of the  $L_{CUR}$  terminal is automatically controlled so that the signal voltage (detection voltage at the  $L_{POT}$  terminal) at one end (LOW side) of the sample may be close to zero. While such a balance is being maintained, the signal voltage between the  $H_{POT}$  and  $L_{POT}$  terminals (voltage across the sample) and the signal current flowing into the  $L_{CUR}$  terminal are detected internally to determine the impedance of the sample. With the connections shown in Fig. 3-1, the error due to the intercable inductance can be minimized and measurement can be made with high accuracy.

To make measurement using the four connectors in the above-described way requires a special test fixture and measurement cables. As accessories directly connectable with the measuring terminal of the apparatus, the AG-4911 Test Fixture, AG-4912 Test Lead, and AG-4917 Test Lead are available. For detailed information on how to use these accessories, refer to the instruction manuals for them.

#### REMARKS

To connect the sample with a special jigs, use coaxial cables as shown in Fig. 3-2.

Table 3-4. Accessories

| Accessory Name       | Description   |
|----------------------|---|
| AG-4911 Test Fixture | Lead-attached parts (radial type/axial type) can be easily connected.   |
| AG-4912 Test Lead    | Measuring lead with a large-sized alligator clip.<br>Operating condition:<br>C: 1000 pF or more, L: 100 $\mu$ H or more, Z: 1 $\Omega$ to 1 M $\Omega$  |
| AG-4917 Test Lead    | Three-terminal type measuring lead with a small-sized alligator clip.<br>Suited for measurement of comparatively high impedance samples.<br>Operating condition:<br>C: 1000 pF or more, L: 100 $\mu$ H or more, Z: 1 $\Omega$ to 1 M $\Omega$ |

 CAUTION

Before connecting a capacitor with the apparatus, be sure to discharge the capacitor.

This apparatus is provided with an input protective circuit which blocks the flow of excessive discharge current from a capacitor connected with the apparatus. However, if the apparatus is connected with a capacitor charged at a voltage higher than 35 V, the apparatus may be damaged. When a capacitor is to be measured, be sure to discharge it before connecting it with the apparatus.

NOTE

Even if once discharged, a capacitor may return to a slightly charged state with the lapse of time, because of the charge absorption effect.

If a charged capacitor is connected with the apparatus, it will be discharged through a direct current resistance (about 153  $\Omega$ ). Since this discharge current may affect the measurement, the measurement should be started after the lapse of time at least ten times longer than the time constant (C·R). This precaution should be observed especially when a large-capacity capacitor is to be measured.






Fig. 3-2. Connection of Special Measuring Jigs

### 3.6 MEASURING GROUNDED SAMPLE

If a sample has a terminal (other than a guard terminal) shorted to ground, theoretically, it cannot be connected to the apparatus in a 4-terminal pair arrangement, so that the apparatus cannot make measurement on such a sample.

In the actual circuit, there exists some impedance between the ground to which the apparatus is connected (front panel G terminal, rear panel FG terminal, power cord grounding terminal) and the sample, and if the ground impedance of the sample is low, a bridge balance may not be attained or the displayed value may be unstable. When one end of the sample connected with the HIGH (H<sub>CUR</sub> or H<sub>POT</sub>) terminal of the apparatus is grounded, the measuring signal is grounded without being supplied to the sample.

When one end of the sample connected with the LOW (L<sub>POT</sub> or L<sub>CUR</sub>) terminal is grounded, the signal current flowing into the sample cannot be detected by the apparatus. Further, in this case, the bridge may not be balanced because of the effect of grounding noise or its operation may be unstable because of the entry of noise current.

For correct measurement, it is necessary to sufficiently insulate the grounding point of the apparatus from the measuring terminal of the sample, and assure a sufficiently high grounding impedance.

Examples in which measurement cannot be made correctly:

- Sample shorted to ground or the grounding point of the apparatus
- Sample to which power is directly supplied from a device other than the apparatus
- Large-sized sample whose grounding impedance relative to the ground or grounding point is extremely low

**NOTE**

When measurement is made on a grounded sample, the performance of the apparatus is affected by the impedance of ground, for example, the measuring range is restricted or the displayed value is unstable, so that the measurement accuracy is not specified for such measurement.

**3.7 ZERO OFFSET ADJUSTMENT**

The test fixture, test lead, and other measuring jigs to be connected with the apparatus have specific amounts of stray capacitance, residual inductance, and residual resistance. The zero offset function is used to measure these residual parameters in advance and automatically remove them from the measured data to minimize the error due to the residual parameters.

Offset adjustment can be made in the open ADJ mode and short ADJ mode. In the open ADJ mode, the stray capacitance and residual conductance of the measuring jigs are measured, whereas, in the short ADJ mode, their residual inductance and residual resistance are measured; the measured values are stored as the correction values.

The ranges of residual parameter values of the measuring jigs that can be covered by offset adjustment, and the measuring frequencies at which offset adjustment can be made are listed in Table 3-5. The apparatus measures the residual parameters at the frequencies shown in Table 3-5. The residual parameter values to correct the parameter values measured at different frequencies are obtained by using the linear interpolation (approximation by a line over the measuring frequency range).

**NOTE**

If the residual parameter values of the measuring jigs are too large, or if the measuring jigs have a resonance characteristic, the difference between the total residual parameter value calculated by approximation and the real total residual parameter value increases, causing a measurement error. Make sure that the residual parameter values are within the allowable ranges shown in Table 3-5.

**Table 3-5. Residual Parameter Value Ranges and Measuring Frequencies Allowable for Offset Adjustment**

|                 | Residual Parameter Value |             | Measuring Frequencies (Hz) at which offset adjustment is made   |
|-----------------|--------------------------|-------------|---|
|                 | Allowable Range          | Limit Value |   |
| Capacitance (C) | 20 pF or less            | 100 pF      | 100, 150, 200, 401, 1k, 2k, 4.01k,<br>10k, 20.2k, 40.3k, 78.1k, 100k<br>(These frequencies are nominal values.) |
| Conductance (G) | 5 $\mu$ S or less        | 100 $\mu$ S |   |
| Resistance (R)  | 0.5 $\Omega$ or less     | 20 $\Omega$ |   |
| Inductance (L)  | 2 $\mu$ H or less        | 200 $\mu$ H |   |

### 3.8 MEASUREMENT PARAMETERS

#### 3.8.1 Description of the Measurement Parameters

##### (1) $|Z|, \theta$

$|Z|$  and  $\theta$  represent the most fundamental parameters of a sample against an AC signal applied between its two terminals; the absolute value and phase angle of impedance.




Fig. 3-3. Vector Representation of Impedance

As shown in Fig. 3-3, the impedance of a sample can be represented by a vector on a complex plane. When the values of effective resistance  $Re$  are laid off along the real axis, and the values of reactance  $Xe$  along the imaginary axis, impedance  $Z$  is expressed as follows.

$$Z = Re + jXe$$

The values of  $|Z|$ , and  $\theta$  of an ideal coil, an ideal capacitor, and an ideal resistor are listed in Table 3-6. In reality, however, a sample has its residual resistance, residual inductance, and stray capacitance, and phase angle  $\theta$  changes depending on the frequency.

The LCR meter measures the two parameters,  $|Z|$  and  $\theta$ , and calculates the values of other parameters based on a given equivalent circuit.

Table 3-6.  $|Z|$  and  $\theta$  of Ideal L, C, and R

|   | $ Z $ ( $\Omega$ ) | $\theta$ (deg) |
|---|--------------------|----------------|
| Coil having inductance L (H)              | $2\pi fL$          | $+90^\circ$    |
| Capacitor having capacitance C (F)        | $1/2\pi fC$        | $-90^\circ$    |
| Resistor having resistance R ( $\Omega$ ) | R                  | $0^\circ$      |

\* f: Measuring frequency (Hz)

## (2) L, C

L and C represent inductance and capacitance, respectively. Their values are calculated differently according to whether the loss resistance is connected in series or in parallel in the equivalent circuit. When the dissipation factor is small, the value of L or C is not affected by the choice of the equivalent circuit. When D is great ( $D > 0.03$ ), there will be a difference between  $L_s$  or  $C_s$  in the series equivalent circuit and  $L_p$  or  $C_p$  in the parallel equivalent circuit.

**REMARKS**

The measurement of L or C may be displayed as a negative value, since L and C are represented as vectors with opposite polarities on the imaginary axis. In terms of reactance, L and C have the following relationship.

$$X_C = - \frac{1}{\omega C} \quad \omega = 2\pi f$$

$$X_L = \omega L \quad f: \text{Measuring frequency}$$

## (3) R

R represents the effective resistance of a sample against AC. Its value is calculated differently according to whether the reactance component (quantity called the C component or L component) is connected in series ( $R_s$ ) or in parallel ( $R_p$ ) in the equivalent circuit.

When the reactance component is great, the L or C parameter is used for measurement.

## (4) D, Q

D represents the dissipation factor which may also be referred to as  $\tan \delta$  (dielectric loss tangent) for a capacitor. A capacitor with a smaller D is regarded as being of higher performance. In terms of  $\tan \delta$ , the dissipation factor is expressed as a power of 10 or a percentage.

$$D = 0.01 \rightarrow \tan \delta = 10^{-2} \text{ (or 1\%)}$$

Q is the value of  $1/D$ . A greater Q represents higher performance. It is often referred to for coils. Resistors are required to have a greater D and a smaller Q.

## (5) ESR (equivalent series resistance)

ESR represents the series resistance component (ESR or  $R_s$ ) of a series equivalent circuit. Its value is used, for example, when estimating the heat generation and loss caused by an alternate current flowing through an electrolytic capacitor.

## (6) G (conductance)

G represents the inverse-number value  $G$  ( $G = 1/R_p$ ) of the parallel resistance component ( $R_p$ ) of a parallel equivalent circuit. It is useful in estimating the loss caused in a capacitor to be used under high voltage.

## (7) X, L

The values of these parameters can be indicated during resistance measurement (the main parameter: R) being made by use of a series equivalent circuit; L represents the residual inductance, and X represents the reactance equal to  $2\pi fL$ . They are used, for example, when estimating the AC characteristics of a wire-wound resistor.

## (8) B, C

The values of these parameters can be indicated during resistance measurement being made by use of a parallel equivalent circuit; C represents the parallel floating capacitance of the resistance component, and B represents the susceptance equal to  $2\pi fC$ . They are used, for example, when estimating the AC characteristics of a high-resistance element.

### 3.8.2 Measurement Parameter Setting and Selection

Measurement parameter setting is performed by using the PARAMETER L, C, R, and Z keys. The main parameter displayed on the main display is determined by these keys. The subparameter shown on the sub display can be selected by pressing the same key again.

The main parameter should be selected according to the properties and characteristics of the sample. Mainly, C should be selected for capacitor measurement, L for coil or transformer measurement, and R for resistance measurement. For composite elements and communication transformers, Z may sometimes be selected. When the properties of the sample is unknown,  $|Z| - \theta$  measurement should be once made, and then the main parameter should be selected based on the values of  $|Z|$  and  $\theta$ . In general, if the value of  $\theta$  is positive (inductive) and within  $+45$  and  $+90^\circ$ , L should be selected. If it is negative (capacitive) and within  $-45$  and  $-90^\circ$ , C should be selected. For a sample whose  $|Z|$  or  $\theta$  value varies with the measuring frequency, it should be evaluated based on  $|Z| - \theta$  measurement.

Examples of uses of the measurement parameters are shown below.

## (1) Low-loss capacitor measurement ..... C-D or C-G

In a measurement of a low-loss ( $D < 10^{-3}$ ) capacitor, the value of capacitance is virtually the same regardless of whether the equivalent circuit is series or parallel. In general, when the impedance is high (the value of C is small), the parallel equivalent circuit (Cp-D or Cp-G measurement) should be selected. When the impedance is low (the value of C is great), the series equivalent circuit (Cs-D measurement) should be selected.

## REMARKS

If the loss caused in a sample is very small, the value of its  $D$  may be indicated as being negative (within the allowable measuring error range).

If a low-loss sample whose dissipation factor is already known or a sample whose dissipation factor is so small as to be negligible is available as the reference sample, the unknown dissipation factor of another low-loss sample can be calculated highly accurately using the following formula:

$D = D_2 - (D_1 - D_5)$  where  $D$  = real dissipation factor of the sample

$D_2$  = dissipation factor of the sample measured by the apparatus

$D_1$  = dissipation factor of the reference sample, whose real dissipation factor is known, measured by the apparatus

$D_5$  = real dissipation factor of the reference sample (If a sample whose dissipation factor is negligible is used as the reference sample, assign 0 as  $D_5$ .)

(2) Large-capacitance capacitor measurement ..... C-D or C-ESR

In a measurement of a low-impedance capacitor such as an electrolytic capacitor, the series equivalent circuit is used to evaluate the series loss caused by the electrode and lead resistances. (Cs-D or Cs-ESR measurement)

By measuring the value of ESR, the heat generation in the capacitor can be easily calculated based on the value of the operating current.

(3) Coil/transformer measurement ..... L-Q or L-ESR

Generally, the loss occurring in a coil or transformer is greater than that occurring in a capacitor (its  $D$  is greater and its  $Q$  is smaller). Select either the parallel equivalent circuit or series equivalent circuit, depending on the actual circuit conditions under which the coil or transformer is to be used, and clearly note the equivalent circuit ( $L_s$  or  $L_p$ ) used for evaluation. Generally, the value of ESR differs from that of the series winding resistance due the properties of the magnetic substance and the manner in which the wire is wound. It may also vary with the measuring frequency or measuring signal level.

(4) High-resistance element measurement ..... R-C or R-B

For a high-resistance element, the parallel equivalent circuit is selected and  $R_p$ -C or  $R_p$ -B measurement is made to evaluate the effect of the stray capacitance. The value of the current to flow through the stray capacitance can be easily calculated as "(applied voltage)  $\times B$ ".

(5) Low-resistance element measurement ..... R-L or R-X

For a low-resistance element, the series equivalent circuit is selected and  $R_s$ -L or  $R_s$ -X measurement is made to evaluate the effect of the resistor or lead wire inductance.

Table 3-7. Parameter Calculation Formulas

|          |  |  |   |  |
|----------|--|--|---|--|
| Z        |  |  |   |  |
| Z        | $\sqrt{\frac{1}{\omega^2 C_x^2} + R_x^2}$            | $\frac{1}{\sqrt{\omega^2 C_x^2 + G_x^2}}$          | $\sqrt{\omega^2 L_x^2 + R_x^2}$                   | $\frac{\omega L_x}{\sqrt{1 + \omega^2 L_x^2 G_x^2}}$ |
| $\theta$ | $-\tan^{-1} \left( \frac{1}{\omega C_x R_x} \right)$ | $-\tan^{-1} \left( \frac{\omega C_x}{G_x} \right)$ | $\tan^{-1} \left( \frac{\omega L_x}{R_x} \right)$ | $\tan^{-1} \left( \frac{1}{\omega L_x G_x} \right)$  |

$$Z = R + jX = |Z| (\cos \theta + j \sin \theta), \quad |Z| = \sqrt{R^2 + X^2} \quad \omega = 2\pi f$$

|  | MAIN DISPLAY |   | SUB DISPLAY              |                            |       |       |  |
|--|--------------|---|--------------------------|----------------------------|-------|-------|--|
|  | C            | Z   | D                        | Q                          | ESR   | G     | $\theta$   |
|  | $C_x$        | $\sqrt{\frac{1}{\omega^2 C_x^2} + R_x^2}$ | $\omega C_x R_x$         | $\frac{1}{\omega C_x R_x}$ | $R_x$ | —     | $-\tan^{-1} \left( \frac{1}{\omega C_x R_x} \right)$ |
|  | $C_x$        | $\frac{1}{\sqrt{\omega^2 C_x^2 + G_x^2}}$ | $\frac{G_x}{\omega C_x}$ | $\frac{\omega C_x}{G_x}$   | —     | $G_x$ | $-\tan^{-1} \left( \frac{\omega C_x}{G_x} \right)$   |

|  | MAIN DISPLAY |  | SUB DISPLAY              |                            |       |       |   |
|--|--------------|--|--------------------------|----------------------------|-------|-------|---|
|  | L            | Z  | D                        | Q                          | ESR   | G     | $\theta$  |
|  | $L_x$        | $\sqrt{\omega^2 L_x^2 + R_x^2}$                      | $\frac{R_x}{\omega L_x}$ | $\frac{\omega L_x}{R_x}$   | $R_x$ | —     | $\tan^{-1} \left( \frac{\omega L_x}{R_x} \right)$   |
|  | $L_x$        | $\frac{\omega L_x}{\sqrt{1 + \omega^2 L_x^2 G_x^2}}$ | $\omega L_x G_x$         | $\frac{1}{\omega L_x G_x}$ | —     | $G_x$ | $\tan^{-1} \left( \frac{1}{\omega L_x G_x} \right)$ |

|  | MAIN DISPLAY |  | SUB DISPLAY             |                         |       |       |  |
|--|--------------|--|-------------------------|-------------------------|-------|-------|--|
|  | R            | Z  | X                       | B                       | L     | C     | $\theta$   |
|  | $R_x$        | $\sqrt{R_x^2 + \frac{1}{\omega^2 C_x^2}}$              | $-\frac{1}{\omega C_x}$ | —                       | —     | —     | $-\tan^{-1} \left( \frac{1}{\omega C_x R_x} \right)$ |
|  | $R_x$        | $\frac{R_x}{\sqrt{1 + \omega^2 C_x^2 R_x^2}}$          | —                       | $\omega C_x$            | —     | $C_x$ | $-\tan^{-1} (\omega C_x R_x)$                        |
|  | $R_x$        | $\sqrt{\omega^2 L_x^2 + R_x^2}$                        | $\omega L_x$            | —                       | $L_x$ | —     | $\tan^{-1} \left( \frac{\omega L_x}{R_x} \right)$    |
|  | $R_x$        | $\frac{\omega L_x R_x}{\sqrt{R_x^2 + \omega^2 L_x^2}}$ | —                       | $-\frac{1}{\omega L_x}$ | —     | —     | $\tan^{-1} \left( \frac{R_x}{\omega L_x} \right)$    |

(6) Transformer impedance measurement .....  $|Z| - \theta$

The impedance of a communication transformer can be measured on the primary winding by terminating the secondary winding in a specified value of resistance. The frequency characteristic can also be easily measured by changing the measuring frequency.

3.8.3 Parameter Calculation Formulas

The parameter calculation formulas are listed in Table 3-7.

3.9 EQUIVALENT CIRCUITS

3.9.1 Equivalent Circuit Expressions

A sample can be represented as impedance Z or admittance Y which is the inverse of the impedance. Z and Y are expressed as follows:

$Z = R + jX$       where R = effective resistance      X = reactance

$Y = G + jB$       where G = conductance      B = susceptance

Each equivalent circuit is expressed using the impedance and admittance as shown in Fig. 3-4. The real-number term and the imaginary-number term of each expression represent the loss resistance elements (R and G) and reactance elements (X and B), respectively.




Fig. 3-4. Equivalent Circuit Expressions



The impedance and admittance have significance only when they are related to a measuring frequency. For example, reactance X of a coil is proportional to the measuring frequency, whereas its susceptance B is inversely proportional to the measuring frequency. Therefore, they are not always appropriate as parameters to evaluate a sample. Depending on the case, therefore, they may be converted into the inductance and capacitance for a specified measuring frequency. Dissipation factor D which is often used in measurement of a capacitor can be obtained from the following expression:

$$D = \frac{R}{X} = \frac{G}{B}$$



The equivalent circuit expression to be used for actual measurement is to be determined by taking into account the specification to be applied to the sample, the properties of the sample, the purposes for which the measured values are to be used, and other conditions. This apparatus is capable of making measurement using any equivalent circuit specified, calculating parameter values, and outputting the values to the displays.

### 3.9.2 Equivalent Circuit Selection

A sample can be represented by a circuit consisting of loss resistance elements (R and G) and reactance elements (L, C, X, and B) connected in series (  ) or parallel (  ), as shown by the equivalent circuit mode markings (CIRCUIT MODE) on the panel. The equivalent circuit with such elements connected in series or parallel is referred to as the series or parallel equivalent circuit. If the same measuring frequency is used, the values of such elements can be correctly measured whether the series equivalent circuit is used or the parallel equivalent circuit is used. As shown in Table 3-8, the values of elements of an equivalent circuit can be related to those of another equivalent circuit using dissipation factor D which has no bearing on the equivalent circuits.

Generally, the value of capacitance of an electrolytic capacitor measured using a series equivalent circuit differs from that measured using a parallel equivalent circuit. The difference is larger, if the dissipation factor of the sample is larger.

For a no-loss capacitor whose dissipation factor D is 0 ( $R_s = 0$ ,  $R_p = \infty$ ), the value of capacitance  $C_s$  of its series equivalent circuit is equal to that of capacitance  $C_p$  of its parallel equivalent circuit. If the values of D and  $C_p$  of a capacitor are 0.1 and 1000 pF respectively, it is equivalent to another capacitor whose  $C_s$  is 1010 pF with the dissipation factor being the same between the two. Where D is 0.03 or smaller, such differences are not larger than 1/1000, that is, different types of equivalent circuits causes virtually no difference in the parameter values.





To correctly evaluate a sample, it is necessary to use a circuit matching the specifications and conditions to be applied to the sample or an equivalent circuit precisely representing the sample.

Generally, for high-impedance samples like ceramic and plastic film capacitors, parallel equivalent circuits are used for measurement; for, the losses caused in them are considered mainly attributable to parallel resistance.

For low-impedance samples like electrolytic capacitors in which the losses are largely attributable to series loss components like the electrode resistance and lead resistance, series equivalent circuits are used for measurement.

If the CIRCUIT MODE is set to AUTO, the apparatus automatically selects the parallel equivalent circuit for a sample whose impedance is about 1.8 k $\Omega$  or more, or the series equivalent circuit for a sample whose impedance is less than 1.8 k $\Omega$ .

Table 3-8. Equivalent Circuits

| Measurement Item | Equivalent Circuit  | Impedance                                       | Dissipation factor                         | Conversion Expression  |
|------------------|---|---|--|--|
| C                |    | $Z = \frac{R_P}{1 + j\omega C_P R_P}$           | $D = \frac{1}{\omega C_P R_P}$             | $C_S = (1 + D^2) C_P$ $R_S = \frac{D^2}{1 + D^2} R_P$  |
|                  |    | $Z = R_S + \frac{1}{j\omega C_P R_P}$           | $D = \omega C_S R_S$                       | $C_P = \frac{1}{1 + D^2} C_S$ $R_P = \frac{1 + D^2}{D^2} R_S$ $\left( G = \frac{D^2}{1 + D^2} \cdot \frac{1}{R_S} \right)$ |
| L                |  | $Z = \frac{j\omega L_P R_P}{R_P + j\omega L_P}$ | $D = \frac{\omega L_P}{R_P} = \frac{1}{Q}$ | $L_S = \frac{1}{1 + D^2} L_P$ $R_S = \frac{D^2}{1 + D^2} R_P$  |
|                  |  | $Z = R_S + j\omega L_S$                         | $D = \frac{R_S}{\omega L_S} = \frac{1}{Q}$ | $L_P = (1 + D^2) L_S$ $R_P = \frac{1 + D^2}{D^2} R_S$ $\left( G = \frac{D^2}{1 + D^2} \cdot \frac{1}{R_S} \right)$         |

\*  $\omega = 2\pi f$      $f$  = measuring frequency (Hz)

### 3.10 SETTING AND MONITORING OF MEASURING SIGNAL

To maintain the reliability of measurement, each sample must be measured under the conditions closely resembling the actual operating conditions for the sample. To meet such requirements, this apparatus offers 31 measuring frequencies and such a wide range of measuring signal level as 1 mV to 5 V. These features of the apparatus are very important for samples which are sensitive to measuring conditions; such as semiconductor elements, and coils and transformers having magnetic cores.

The measuring frequency and measuring signal level can be set using the FREQUENCY and LEVEL keys under OSC and the LEVEL FINE adjuster on the front panel.

To set a desired measuring frequency, use the FREQUENCY UP and DOWN keys. If either key is successively pressed, the frequency is changed successively with the check display indicating the updated frequency every time the key is pressed.

To set the measuring signal level, use the LEVEL UP and DOWN keys, and the LEVEL FINE adjuster. Any one of the four ranges, 5 V, 1 V, 100 mV, and 10 mVrms ranges, can be selected using either the UP or DOWN key. Each time the key is pressed, the selected level range is shown on the check display. The measuring signal level in the selected level range can be finely adjusted using the LEVEL FINE adjuster in the range of  $\times 1$  to  $\times 0.1$ .

The actual level of the signal applied to the sample can be monitored by pressing the UNKNOWN V key under SIGNAL CHECK. Similarly, the signal current flowing through the sample can be monitored by pressing the UNKNOWN mA key. (No monitoring can be made if all four UNKNOWN terminals are open.)

The oscillator output impedance (output impedance of the H<sub>CUR</sub> terminal) of this apparatus has been designed to be about 50  $\Omega$ , and the four level range values are nominal values for a state with the LEVEL FINE adjuster placed at MAX without any sample connected to the apparatus. When measurement is made on a low-impedance sample like a coil, the signal voltage actually applied to the sample may be lower than the level range value.

To finely adjust the signal voltage or current actually applied to or flowing through the sample, press the UNKNOWN V key or mA key under SIGNAL CHECK and, while observing the check display, adjust the LEVEL FINE adjuster.

### 3.11 MEASURING RANGE

If the RANGE is set to AUTO, the apparatus automatically selects the range suitable for the sample. If the MANUAL UP or DOWN key is pressed during measurement in the AUTO mode, the current measuring range is fixed and the MANUAL mode is entered.

In the MANUAL mode, the measuring range is stepped up or down every time the UP or DOWN key is pressed. If an unallowable range is set, *OF* (overflow) or *UF* (underflow) is displayed.

The RANGE should be normally set to AUTO. In the AUTO mode, it takes some time for the apparatus to select the range suitable for the sample. When measuring samples whose approximate data are known one after another, the MANUAL mode should be selected to shorten the measurement time.

#### REMARKS

If the RANGE UP or DOWN key is pressed, the range code is shown on the check display for a short period of time. After measurement in the AUTO mode, the range in which the measurement was made can be checked by pressing the UP or DOWN key.

Display example: In the case of range code R11, *r 11* is displayed.

(When the AUTO key is pressed, *r 00* is displayed.)

For the relationship between the range codes and measuring ranges, refer to the accuracy table in paragraph 11 in Table 1-1 Specifications.

### 3.12 STARTING MEASUREMENT

Measurement can be started automatically, manually, or by the use of an external signal. If the MEAS START AUTO key is pressed, the AUTO mode is entered and measurement is automatically repeated according to the internal timing. If the MANUAL key is pressed during measurement in the AUTO mode, the measurement is discontinued and the most recently measured values are kept on the displays. After that, measurement is executed every time the MANUAL key is pressed.


If the EXT key is pressed, the external start mode is entered. In the external start mode, measurement is made every time a trigger signal is input to the EXT CONTROL connector on the rear panel.

#### REMARKS

For information on the external trigger signal, refer to the description of the external control interface function in Table 3-13.

### 3.13 MEASUREMENT SPEED MODES

Each time the MEAS SPEED SELECT key is pressed, the measurement speed is changed as shown below.



The measurement speed has an effect on the resolution and accuracy of measured data. Select an appropriate measurement speed, according to the purpose of the measurement.

**NORMAL:** Standard measurement mode. The maximum number of measurement display digits is 4 1/2 (19999 counts). The cycle period in AUTO measurement is about 250 to 350 ms.

**FAST:** High-speed measurement mode. Since the time for integration by the integrating A/D converter is reduced to speed up measurement, the measurement accuracy is lower than that in the NORMAL mode. The maximum number of measurement display digits is 4 (4999 counts). The cycle period in AUTO measurement is about 150 to 250 ms.

**SLOW:** High-resolution measurement mode. Measurements are made ten times in the NORMAL mode, the measured values are averaged, and the average value is displayed. Although the accuracy is not improved, the display variation is reduced to about 1/3 to 1/4 and the number of display digits is greater by one than that in the NORMAL mode. The maximum number of display digits is 5 1/2 (199999 counts). The cycle period in AUTO measurement is about nine times longer (about 2 to 3 sec) than that in the NORMAL mode.

#### REMARKS

The measurement accuracy and the number of display digits are affected by the measuring range, measuring frequency, signal level range, and measured data. For details, refer to Table 1-1 Specifications.

### 3.14 DEVIATION MEASUREMENT

#### 3.14.1 Deviation Value Indication, and Deviation Percentage Indication

Deviation measurement can be made for parameters L, C, R, and |Z|. Deviation measurement is useful in measuring small changes in the value of a specified parameter or deviation of the parameter value from a specified value, or for part quality inspection. Deviation measurement can be specified by pressing the  $\Delta$  key or  $\Delta\%$  key under DEVIATION; pressing the  $\Delta$  key causes the measured deviation value to be indicated, and pressing the  $\Delta\%$  key causes the measured deviation percentage to be indicated. Deviation measurement requires a reference value to be set beforehand; if deviation measurement is specified without any reference value set, an error indication is displayed.

Value indicated in  $\Delta$  mode = (measured value) – (reference value)

Value indicated in  $\Delta\%$  mode =  $\frac{(\text{measured value}) - (\text{reference value})}{(\text{reference value})} \times 100$  (Unit: percent)

Table 3-9. Reference Value Range

| Parameter | Allowable Reference Value Range |
|-----------|---------------------------------|
| C         | 0 - 9999.9 mF                   |
| L         | 0 - 99.999 kH                   |
| R,  Z     | 0 - 99.999 M $\Omega$           |

#### 3.14.2 Deviation Reference Value Setting

A deviation measurement reference value can be set for each of main parameters L, C, R, and |Z|. Either a measured value shown on the main display or an arbitrary numerical value can be set as the reference value by keying-in operation.

##### (1) Setting arbitrary numeric value as reference value

- ① Select the measurement parameter for the reference value to be set, using the PARAMETER key.
- ② Press the REF key. Then, the key LED comes on and the reference value setting mode is entered. The previously set reference value (or — if no reference value has been set) is shown on the main display.
- ③ Set the reference value using the 0-9, DP (decimal point), CE (clear),  $\rightarrow$  (cursor movement), and UNIT (unit selection) UP and DOWN keys.

##### REMARKS

The  $\rightarrow$  key is used to move the cursor (blinking display). If no setting is set, the cursor will not move.

- ④ Press the STORE key to store the set value as the reference value. If the value is correctly stored, the REF key LED goes off. If an error display is given and the REF key LED remains on, the setting is outside the allowable reference value range. Check the setting, and perform the steps ③ onward again.

Example: Setting R = 1.2 k $\Omega$  as the reference value

- a. Select R measurement by pressing the PARAMETER R key.
- b. Press the REF key to enter the reference value setting mode.
- c. Press the 1, DP, and 2 keys in order named, and select unit k $\Omega$  by using the UNIT UP or DOWN key. If you inadvertently specified a wrong value, press the CE key and enter the correct value again, or move the cursor to the setting to be changed by using the  $\rightarrow$  key.
- d. After verifying the setting shown on the main display, press the STORE key to store the setting.

(2) Entering measured value

- ① Select the measurement parameter for the reference value to be set, using the PARAMETER key.
- ② Measure the reference sample, and display the measured value on the main display.

REMARKS

Deviation measurement should be made in the OFF condition (both the  $\Delta$  and  $\Delta$  % key LEDs being on).

- ③ After verifying the measured value shown on the main display, press the STORE key to store the value as the reference value.  
If the value is correctly stored, the REF key LED comes on and the stored value is shown on the main display. If an error display is given and the REF key LED remains off, it means that the measured value is outside the allowable range and cannot be set as the reference value.
- ④ To change the displayed reference value, perform the steps ③ and subsequent steps in (1) Setting arbitrary numerical value as the reference value.  
When the reference value need not be changed, press the REF key. Then, the key LED goes off and the display returns to normal.

### 3.15 COMPARATOR FUNCTION

For the main parameter and subparameter, the measured value can be compared with the preset limits. If the COMP ENABLE key is pressed, the key LED comes on and the apparatus becomes ready for comparator operation. To perform the comparator operation, upper and lower limits have to be set in advance. For a parameter whose limit values are not set, no comparison can be made.

Desired upper and lower limits can be set for each parameter by keying-in operation.

Table 3-10. Allowable Limit Value Ranges

| Main Parameter | Allowable Setting Range | Subparameter | Allowable Setting Range |
|----------------|-------------------------|--------------|-------------------------|
| C              | 0 - 9999.9 mF           | D            | 0 - 9.9999              |
| L              | 0 - 99.999 kH           | Q            | 0 - 9999                |
| R              | 0 - 99.999 MΩ           | G            | 0 - 999.99 S            |
| Z              | 0 - 99.999 MΩ           | ESR          | 0 - 99.999 MΩ           |
|                |                         | X            | - 99.999 MΩ - 99.999 MΩ |
|                |                         | B            | - 999.99 S - 999.99 S   |
|                |                         | L            | 0 - 99.999 MΩ           |
|                |                         | C            | 0 - 9999.9 mF           |
|                |                         | $\theta$     | - 180.00 - 180.00 deg   |

(1) Setting comparator limit values

- ① Select the measurement parameter for the limit values to be set, using the PARAMETER key.
- ② Press the LIMIT key. Then, the key LED comes on and the limit setting mode is entered.  
Make sure that *UPL* (upper limit setting mode) is shown on the check display. The previously set upper limit (--- if no upper limit is set) is shown on the main and sub displays.
- ③ Set the main parameter upper limit on the main display and the subparameter upper limit on the sub display by using the 0-9, DP (decimal point), CE (clear), → (cursor movement), and UNIT (unit selection) UP and DOWN keys.

**REMARKS**

The → key is used to move the cursor (blinking display). Selection of the unit can be made for the main or sub display over which the cursor is located.



- ④ Press the STORE key to store the setting as the upper limit. If the upper limit is correctly stored, the indication on the check display changes to *LoL* (lower limit setting mode). If an error display is given and the indication on the check display remain unchanged, it means that the set value is outside the allowable limit setting range. Check the setting, and perform the steps ③ onward again.
- ⑤ Set the main parameter and sub parameter lower limits in the same manner as in ④.
- ⑥ Press the STORE key to store the setting as the lower limit. If the lower limit is correctly set, the LIMIT key LED goes off and the apparatus leaves the limit setting mode. If an error display is given and the indication on the check display remain the same (*LoL*), check the setting and perform the steps ⑤ onward again.

Setting example: Setting C = 1.05  $\mu$ F and D = 0.12 as the upper limits and C = 0.95  $\mu$ F and D = 0.01 as the lower limits for C-D measurement

- a. Select C-D measurement by pressing the PARAMETER C key.
- b. Press the LIMIT key to enter the limit setting mode. Check that *UPL* is shown on the check display.
- c. Check that the indication on the main display is blinking, and set the upper limit of C. (If a numerical value is already set, press the CE key to clear it.)  
Press the 1, DP, 0, and 5 keys in order named, and select unit  $\mu$ F by pressing the UNIT UP or DOWN key.
- d. Move the blinking display to the sub display by pressing the  $\rightarrow$  key, and set the upper limit of D. (If a numerical value is already set, press the CE key to clear it.)  
Press the DP, 1, and 2 keys in order named.
- e. After checking the upper limit settings of C and D, press the STORE key to store these values.
- f. Check that *LoL* is shown on the check display.
- g. Set the lower limit of C in the same manner as in c. Press the DP, 9, and 5 keys in order named, and select unit  $\mu$ F by pressing the UNIT UP or DOWN key.
- h. Set the lower limit of D in the same manner as in d. Press the DP, 0, and 1 keys in order named.
- i. After checking the lower limit settings of C and D, press the STORE key to store these values.

## (2) Comparator judgment result

The main parameter judgment result is indicated by the HIGH, PASS, or LOW LED on the main display, while the subparameter judgment result is indicated by the HIGH, PASS, or LOW LED on the sub display.

Table 3-11. Comparator Judgment Condition

| Judgment Result | Judgment Condition                                   |
|-----------------|--|
| HIGH            | Measured value > Upper limit                         |
| PASS            | Upper limit $\geq$ Measured value $\geq$ Lower limit |
| LOW             | Measured value < Lower limit                         |

Thus, in this case, a judgment is made as to whether the measured value is greater than the upper limit or smaller than the lower limit. (When only the upper limit is set, the display is either HIGH or PASS. When only the lower limit is set, the display is either PASS or LOW.)

**REMARKS**

If the limit settings are such that the upper limit is smaller than the lower limit, they are judged to be inappropriate and the HIGH and LOW LEDs come on at the same time. When *OF*, *UF*, and *CF* are shown on the main or sub display, the HIGH and LOW LEDs also come on at the same time.

The loudspeaker inside the apparatus sounds at the same time an indication is given by the LEDs. In the case of PASS, a PASS tone (normally about 2 kHz) is produced. Otherwise, an NG tone (normally about 500 Hz) is produced.

**REMARKS**

A PASS tone is produced by the loudspeaker only when the overall judgment result is PASS. For the loudspeaker ON/OFF control and tone frequency setting, refer to the description of the internal DIP switch function in Appendix C.

**(3) Judgment result output**

A comparator judgment result signal (indicating the same state as given by the HIGH, PASS, and LOW LEDs on the front panel) is output to the EXT CONTROL connector on the rear panel. An overall judgment result relay contact output (PASS, COM,  $\overline{\text{PASS}}$ ) is also available.

**REMARKS**

For information on the EXT CONTROL connector, refer to Table 3-13 External Control Interface Functions.

### 3.16 EXTERNAL DC BIAS

There are many samples which require a DC bias to be applied to them during measurement. For example, an electrolytic capacitor requires a DC voltage corresponding to its polarity to be applied to it, and a variable capacitance diode also requires a DC voltage to be applied to it when its capacity characteristic is to be measured. This apparatus allows the use of an external DC power supply to apply a bias to the sample. Fig. 3-6 shows how to obtain an external DC bias.

#### ⚠ CAUTION


Be sure that the external DC bias voltage is within  $\pm 35$  V.

The external DC bias must remain within the following ranges.

Maximum applied voltage :  $\pm 35$  VDC

Maximum current : 100 mA DC

(The maximum bias current is further limited, depending on the measuring frequency and signal level range. See Fig. 3-5.)



**NOTE:** The maximum bias current depends on the measuring frequency and signal level range. The maximum bias current should be within the range indicated by the above graph.

Fig. 3-5. Maximum Bias Current

**⚠ CAUTION**

The external DC bias voltage is applied to the H<sub>CUR</sub> and H<sub>POT</sub> terminals through the internal protective resistor. If a charged capacitor is connected while an external DC bias is being applied, an excessive discharge current (DC current) may flow into the internal circuit, causing damage to it.

Before apply a DC bias, be sure to set the external DC supply voltage to zero and discharge the capacitor to be connected.

When superimposition of a DC bias voltage is necessary, some time is required before the bias voltage applied to the sample reaches the designated value. The time is determined by the capacitance of the sample connected to the measuring terminal, the protective resistor (about 153  $\Omega$ ) inside the apparatus, and the signal-bypass capacitor (about 1000  $\mu\text{F}$ ), as long as the output resistance of the external DC power source is negligibly small.

Where a DC bias voltage is applied to a capacitor, the charging time constant is roughly expressed by the following formula ( $C_x$  being the capacitance of the sample), on the assumption that the output resistance of the external DC power source is negligible.

$$\text{Charging time constant} \approx (C_x + 1000\mu\text{F}) \times 153 \Omega$$

The settling time from the instant the DC bias is applied to the moment the measurement is started must be several to several tens of times longer than the charging time constant.

**REMARKS**

For a sample with a low capacitance (1  $\mu\text{F}$  or less), for example, the time (about seven times the time constant) required for the bias voltage to reach 0.999 times the voltage setting is about one second.

When the capacitance of the sample is large, more settling time is required.

The voltage applied to the sample can be monitored using the MONITOR terminal. Its output impedance is about 30 k $\Omega$ . Use the terminal when the bias current is small (2 mA or less).

**REMARKS**

The voltage value monitored using the MONITOR terminal without any bias current flowing agrees with the voltage actually applied to the sample. If a bias current is made to flow, however, the two voltages differ because of the impedance of the internal circuit. Therefore, use the MONITOR terminal only if the bias current is small (2 mA or less).

**NOTE**

When no DC bias is to be used, press the EXT DC BIAS key on the front panel to turn off the key LED (DC bias OFF).




Fig. 3-6. Application of External DC Bias

**CAUTION**

- Make sure that neither the voltage nor current applied to the sample exceeds the maximum rating of the sample. For a sample like an electrolytic capacitor whose operation is dependent on its polarity, observe the correct polarity.
- Be careful not to short the HIGH measuring terminal and LOW measuring terminal (or coaxial connector/coaxial cable outer conductor or grounding terminal) with a DC bias voltage or current applied.

4. Read the measurements after the applied bias voltage or current has settled.
5. After completing the measurement, gradually change the output voltage of the external DC power supply to 0 V.
6. When another sample is to be measured, replace the sample with the new one, and perform the steps 3 onward.
7. When no DC bias is required, press the EXT DC BIAS key on the front panel to turn off the key LED (DC bias OFF).

**NOTE**

To prevent the apparatus from being damaged by an excessive current, a protective fuse is install in the fuse holder in the EXT DC BIAS section of the rear panel. If the fuse is blown, replace it with a 0.1A fuse. Before replacing the fuse, set the bias voltage to 0 V and check that the EXT DC BIAS key LED is off.

DC bias fuse: 0.1 A/250 V Fast acting type (6.35 mm in diam. x 31.75 mm)

**REMARKS**

The voltage applied to the sample can be monitored using the MONITOR terminal. Its output impedance is about 30 k $\Omega$ . Use the terminal only when the bias current is small (2 mA or less). The value of the bias current to flow through the sample can be approximated by the following expression:

$$\text{Bias current (A)} = \frac{\text{external supply voltage (V)}}{R_{\text{XDC}} + 153 \Omega}$$

$R_{\text{XDC}}$ : DC resistance ( $\Omega$ ) of the sample

Fig. 3-6. Application of External DC Bias (Continued)

### 3.17 MEASUREMENT BY USE OF EXTERNAL FREQUENCY

To make measurement by use of an external frequency, an external oscillator (for example, a frequency synthesizer) to generate an external frequency signal is required and the external frequency information must be input to the apparatus; input an external frequency signal (1.6 kHz to 1.6 MHz) whose frequency is 16 times the measuring frequency to the EXT TEST FREQ INPUT connector on the rear panel of the apparatus, and specify the frequency information via the GP-IB interface or the external frequency data interface.

Fig. 3-7 shows schematic diagrams of setups for making measurement using an external frequency. Setup ① is for making measurement using an external frequency and specifying the external frequency value via the GP-IB interface. In the setup, the controller is to control the external oscillator and input the frequency value to the apparatus. In this way, measurement can be made in a frequency range of 100 Hz to 100 kHz. For the method of external frequency specification via the GP-IB interface, see Table 3-14.

Setups ② and ③ shown in Fig. 3-7 are for making measurement using the external frequency and specifying the external frequency value via the external frequency data interface. Setup ② includes an external oscillator and an external frequency counter; setup ③ includes a special oscillator containing a crystal oscillator circuit. In both setups, the external frequency value is to be input in BCD code to the EXT TEST FREQ DATA connector. For the functions of the external frequency data interface, see Table 3-12. The operator is required to familiarize himself with the signal names and connector pin numbers listed in the table beforehand. Also, be sure to observe the precautions set forth in the table so as to use the apparatus correctly and safely.

#### NOTE

To make measurement using an external frequency, an external frequency signal whose frequency is 16 times the measuring frequency and the frequency value information must be input to the apparatus. If they are not consistent with each other, correct measurement cannot be made. Use an external oscillator whose frequency accuracy is  $\pm 1 \times 10^{-4}$  or less and whose phase noise (residual FM) is -50 dB or less.




Fig. 3-7. Setups for Measurement by Use of External Frequency



Table 3-12. Functions of External Frequency Interface

### 1. General

This apparatus can make measurement at any frequency between 100 Hz and 100 kHz through use of an external frequency interface.

To make measurement using an external frequency, a frequency signal generated by an external oscillator (for example, a frequency synthesizer) must be input to the apparatus, and its frequency must be specified. The external frequency (1.6 kHz to 1.6 MHz) must be 16 times the measuring frequency. The frequency can be specified via the GP-IB interface or the external frequency data interface.

The external frequency data interface is for use in specifying an external frequency. Data consisting of a mantissa, a decimal point, and a unit can be specified in BCD code using the interface.

### 2. EXT TEST FREQ DATA Connector

The EXT TEST FREQ DATA connector is a 50-pole connector. Its pin assignment and the names of signals connected to it are shown at right.

Matching connector: 57-30500 (male)  
connector or equivalent

#### REMARKS

As the male connector to engage with the EXT TEST FREQ DATA connector, use the accessory to the apparatus or equivalent.

### 3. Signal Level

TTL level only

"0": 0 V (nominal)

"1": +5 V (nominal)

#### EXT TEST FREQ DATA




Table 3-12. Functions of External Frequency Interface (Continued)

| 4. Signals and Functions                                 |                              |  |   |
|--|------------------------------|--|---|
| Pin No.  | Signal Name                  | FUNCTION   |   |
| 1  | GND                          | Signal ground  |   |
| 2<br>3<br>4<br>5   | F0D0<br>F0D1<br>F0D2<br>F0D3 | } 1st digit of mantissa ( $F \times 10^0 \cdot D_0 - D_3$ )                    |   |
| 6<br>7<br>8<br>9   | F1D0<br>F1D1<br>F1D2<br>F1D3 |  |   |
| 10<br>11<br>12<br>13                                     | F2D0<br>F2D1<br>F2D2<br>F2D3 |  |   |
| 14<br>15<br>16<br>17                                     | F3D0<br>F3D1<br>F3D2<br>F3D3 |  |   |
| 18<br>19<br>20<br>21                                     | F4D0<br>F4D1<br>F4D2<br>F4D3 | } 5th digit of mantissa ( $F \times 10^4 \cdot D_0 - D_3$ )                    |   |
| 22<br>23<br>24<br>25                                     | F5D0<br>F5D1<br>F5D2<br>F5D3 |  |   |
| 26   | EXTEL                        |  | When this signal is set to 0 or connected to ground, the external frequency data interface is enabled.<br>If DTSTB signal is not used, keep this signal at 0 or connected to GND. |
| 27   | STBDL                        |  |   |
| 28   | GND                          |  |   |
| 29   | GND                          |  |   |
| 30<br>31<br>32<br>33<br>34<br>35<br>36<br>37<br>38<br>39 |                              | No used  |   |
| 40<br>41<br>42   | UTD0<br>UTD1<br>UTD2         | } Unit data ( $UNIT \cdot D_0 - D_2$ )   |   |
| 43   | GND                          |  |   |
| 44<br>45<br>46   | DPD0<br>DPD1<br>DPD2         |  |   |
| 47   | DTSTB                        | Strobe signal to be input for data latching                                    |   |
| 48   | MEST                         | This signal is output to start the external frequency counter.                 |   |
| 49   | BUSY                         | This signal being 1 indicates the busy state in which data cannot be received. |   |
| 50   | GND                          | Signal ground  |   |

Table 3-12. Functions of External Frequency Interface (Continued)

## 5. External Frequency Input Format

The external frequency data is divided into a mantissa, a decimal point position, and a unit. The mantissa may consist of up to six digits, and it can be specified in BCD code. The decimal point position data consists of three bits which can specify six different positions. The unit data consists of three bits used to specify either Hz or kHz. The possible decimal point positions for a mantissa are shown below.

|        |        |        |        |        |        |       |                                 |
|--------|--------|--------|--------|--------|--------|-------|---------------------------------|
| $10^5$ | $10^4$ | $10^3$ | $10^2$ | $10^1$ | $10^0$ | ..... | $F \times 10^5 - F \times 10^0$ |
| 1.     | 6.     | 0.     | 0.     | 0.     | 0.     |       |                                 |
| ↑      | ↑      | ↑      | ↑      | ↑      | ↑      | ..... | Decimal point position          |
| DP5    | DP4    | DP3    | DP2    | DP1    | DP0    |       |                                 |

| Mantissa data   |         |    |    |    | Decimal point data |    |    | Unit data |         |    |    |    |
|-----------------|---------|----|----|----|--------------------|----|----|-----------|---------|----|----|----|
| Numerical value | F5 - F0 |    |    |    | Decimal point      | DP |    | Unit      | UT      |    |    |    |
|                 | D3      | D2 | D1 | D0 |                    | D2 | D1 | D0        |         | D2 | D1 | D0 |
| 0               | 0       | 0  | 0  | 0  | DP0                | 0  | 0  | 0         | Hz      | 0  | 0  | 0  |
| 1               | 0       | 0  | 0  | 1  | DP1                | 0  | 0  | 1         | kHz     | 0  | 0  | 1  |
| 2               | 0       | 0  | 1  | 0  | DP2                | 0  | 1  | 0         | No used | 0  | 1  | 0  |
| 3               | 0       | 0  | 1  | 1  | DP3                | 0  | 1  | 1         |         | 0  | 1  | 1  |
| 4               | 0       | 1  | 0  | 0  | DP4                | 1  | 0  | 0         |         | 1  | 0  | 0  |
| 5               | 0       | 1  | 0  | 1  | DP5                | 1  | 0  | 1         |         | 1  | 0  | 0  |
| 6               | 0       | 1  | 1  | 0  | No used            | 1  | 1  | 0         |         | 1  | 1  | 0  |
| 7               | 0       | 1  | 1  | 1  |                    | 1  | 1  | 1         | 1       | 1  | 1  |    |
| 8               | 1       | 0  | 0  | 0  |                    |    |    |           |         |    |    |    |
| 9               | 1       | 0  | 0  | 1  |                    |    |    |           |         |    |    |    |
| No used         | 1       | 0  | 1  | 0  |                    |    |    |           |         |    |    |    |
|                 | 1       | 1  | 1  | 1  |                    |    |    |           |         |    |    |    |

Example: Inputting 160.000 kHz.

Specify mantissa 160000, decimal point position DP3, and unit kHz.

| Mantissa | F5      | F4      | F3      | F2      | F1      | F0      |
|----------|---------|---------|---------|---------|---------|---------|
|          | D3 - D0 | D3 - D0 | D3 - D0 | D3 - D0 | D3 - D0 | D3 - D0 |
| 160000   | 0001    | 0110    | 0000    | 0000    | 0000    | 0000    |

| Decimal point | DP      |
|---------------|---------|
|               | D2 - D0 |
| DP3           | 011     |

| Unit | UT      |
|------|---------|
|      | D2 - D0 |
| kHz  | 001     |


Table 3-12. Functions of External Frequency Interface (Continued)

## 6. Control Signals

Control signals  $\overline{\text{EXTEL}}$  and  $\overline{\text{STBDL}}$ , and the control signals concerning the fetching of the DTSTB, MEST, and BUSY data are connected to the EXT TEST FREQ DATA connector.

The  $\overline{\text{EXTEL}}$  signal must be set to "0" when the external frequency data interface is to be used. While it is at "0", the MEST signal is output every time measurement is started.

The MEST signal can therefore be used as the frequency measurement starting signal for an external frequency counter. After the MEST signal is set to "0", the BUSY signal is set to "0" to indicate that frequency data may be input. While the BUSY signal is at "0", the external frequency counter if connected to the apparatus may output the numerical, unit, and decimal point data, and also a strobe signal (DTSTB) for data fetching to the apparatus. When the DTSTB signal is received, the apparatus latches the data. At the same time, the BUSY signal is reset to "1".



- NOTES: ① When the  $\overline{\text{EXTEL}}$  signal is set to "0", the external frequency data interface is enabled.
- ② After the  $\overline{\text{EXTEL}}$  signal is set to "0", the MEST signal is output, and the BUSY signal is then set to "0", enabling the input of the frequency data.
- ③ Input the DTSTB signal when the external frequency data input from the outside settles.
- ④ The apparatus latches the data upon receipt of the DTSTB signal. When data latching is completed, the BUSY signal is reset to "1".


The DTSTB signal must have a pulse width of 100  $\mu\text{s}$  or more.

## REMARKS

When the external frequency data is input and latched, the apparatus calculates the measuring frequency as being 1/16 of the external frequency and then calculates various parameter values for the calculated measuring frequency. Therefore, specify the external frequency to be 16 times the desired measuring frequency. Setting the  $\overline{\text{EXTEL}}$  signal to "0" sets the external frequency mode causing the MEST signal to be output. When the DTSTB signal is subsequently set to 1 in the external frequency mode, the external frequency data is read and measurement is started. The MEST signal is output every time measurement is started, so that the measuring time used by the apparatus for each measurement is equal to the time from the output of a MEST signal to the output of the subsequent DTSTB signal. Resetting the  $\overline{\text{EXTEL}}$  signal to "1" restores the internal frequency mode.


Table 3-12. Functions of External Frequency Interface (Continued)

While the  $\overline{\text{STDBL}}$  signal is at "0", the apparatus latches the data at each MEST signal without depending on the DTSTB signal. This mode can be used when the external frequency is fixed.




7. External Interface


(1) Data input circuit



(2) Control signal output circuit



(3) Control signal input circuit



REMARKS

Use an external driver circuit of open collector type TTL or 74HC series TTL.  
 Use an external input circuit of 74 HC series TTL.  
 Use connection cables not longer than 0.5 m each.

8. Precautions

- (1) The allowable external frequency range is from 1.6 kHz to 1.6 MHz. The number of significant digits of the external frequency is five. Inputting an external frequency outside the allowable range causes an error indication to be displayed.
- (2) The mantissa to be input as the external frequency data may consist of up to six digits. Since the input circuit for each mantissa digit is of positive logic, keep the unused digits at "0" or connected to a GND pin.
- (3) When connecting an external frequency counter and/or other external devices to the apparatus, interconnect their frame ground (FG) terminals and short the interconnected terminals to ground.
- (4) The connection cable should be 0.5 m or less in length. Be sure to connect it to the frame ground. To prevent the apparatus from malfunctioning due to external noise, shield the entire cable. (The shield should be connected to pin 50.)

### 3.18 EXTERNAL CONTROL INTERFACE

Various signals related to the external measurement start input and comparator are available at the EXT CONTROL connector on the rear panel of the apparatus. By using these signals, the apparatus can be controlled by external devices or the external devices can be controlled by the apparatus.

A description of the functions of the external control interface is given in Table 3-13. The operator is required to familiarize himself with the signal names and connector pin numbers shown in the table.

Be sure to observe the precautions set forth in the table so as to use the apparatus correctly and safely.

Table 3-13. Functions of External Control Interface

### 1. General

An external measurement start signal, measurement end signal, and comparator measurement result signal can be obtained from the EXT CONTROL connector on the rear panel.

The external measurement start signal becomes effective when the MEAS START EXT key on the front panel is pressed to enter the external start mode. Measurement is made each time a start signal is entered from outside.

The measurement end signal is output as a pulse the moment the measured data is displayed. The comparator measurement result output signal indicates the same state as represented by the LEDs on the front panel. In addition, an overall judgment result relay contact output is provided.

By using these control signals, the apparatus can be remotely controlled by external devices, and the external devices can be controlled based on the result of the judgment by the comparator.

### 2. EXT CONTROL Connector


The EXT CONTROL connector is a 14-pole connector.

Its pin assignment and signal names are shown at right.

Matching connector: 57-30140 (male) plug  
or equivalent

#### REMARKS

As the connector to engage with the EXT CONTROL connector, use the accessory to the apparatus or equivalent.



### 3. Signal Level

For all signals except PASS, COM, and PASS, a TTL level is used.

"0": 0 V (nominal)


"1": +5 V (nominal)

Table 3-13. Functions of External Control Interface (Continued)

| 4. Signal Names and Functions |                             |              |  |
|-------------------------------|-----------------------------|--------------|--|
| Pin No.                       | Signal Name                 | Input/Output | Description of the Function  |
| 1                             | $\overline{\text{EXT-MST}}$ | Input        | An external measurement start signal is input.   |
| 2                             | GND                         | —            | Signal ground  |
| 3                             | $\overline{\text{MEND}}$    | Output       | A pulse is output the moment a measurement ends.   |
| 4                             | +5V                         | Output       | +5 V power supply (output impedance: about 50 $\Omega$ )   |
| 5                             | $\overline{\text{PASS}}$    | —            | Overall judgment relay contact output<br>(A current path is formed between COM and PASS only when the result of the overall judgment is PASS.) |
| 6                             | COM                         | —            |  |
| 7                             | PASS                        | —            |  |
| 8                             | $\overline{\text{SUB H}}$   | Output       | "0" level when the subparameter judgment result is HIGH.   |
| 9                             | $\overline{\text{SUB P}}$   | Output       | "0" level when the subparameter judgment result is PASS.   |
| 10                            | $\overline{\text{SUB L}}$   | Output       | "0" level when the subparameter judgment result is LOW.  |
| 11                            | $\overline{\text{MAIN H}}$  | Output       | "0" level when the main parameter judgment result is HIGH.   |
| 12                            | $\overline{\text{MAIN P}}$  | Output       | "0" level when the main parameter judgment result is PASS.   |
| 13                            | $\overline{\text{MAIN L}}$  | Output       | "0" level when the main parameter judgment result is LOW.  |
| 14                            | FG                          | —            | Connected with the frame ground of the apparatus.  |

5. Measurement Start Signal


If the MEAS START EXT key on the front panel is valid (the EXT key LED is on), measurement is made each time the  $\overline{\text{EXT-MST}}$  signal is input.



**REMARKS**


If the  $\overline{\text{EXT MST}}$  signal is successively set to the "0" level, measurement is repeatedly made. If much chattering occurs when measurement is started directly by a foot switch, adequate provision should be made against chattering.

Input circuit



6. Measurement End Signal

The measurement end signal ( $\overline{\text{MEND}}$ ) is output as a pulse the moment a measurement and display is completed.



Output circuit






Table 3-13. Functions of External Control Interface (Continued)

**7. Overall Judgment Relay Contact Output**


Normally, a current path is formed between the  $\overline{\text{PASS}}$  and COM terminals. Current can flow between the PASS and COM terminals only when the result of the overall judgment is PASS.

Internal relay contact capacity


Maximum allowable voltage : 10 VDC

Maximum allowable current : 100 mA DC

Example of application of the relay contact output circuit

**8. Judgement Result Signal**

The main parameter/subparameter judgment result output is the same as indicated by the HIGH, PASS, and LOW LEDs on the front panel.

**9. Precautions**

- (1) Use the 74LS series TTL or equivalent as the external input circuit that receives a measurement end signal or judgment result output signal.
- (2) The connection cable should be 0.5 m or less in length. Be sure to connect it to the frame ground. To prevent the apparatus from malfunctioning due to external noise, shield the entire length of the cable. (The shield should be connected to pin 14 (FG).)
- (3) When the apparatus is to be connected with another instrument, connect their frame ground (FG) terminals together and short them to ground.

### 3.19 GP-IB INTERFACE

The GP-IB interface (complying with IEEE-488) enables a controller (for example, a personal computer) to remotely control the apparatus and process the data obtained by the apparatus, so that the apparatus can be incorporated into an automatic measuring system to process data on various parts or to inspect parts to determine whether they are acceptable for use.

The functions of the GP-IB interface are explained in Table 3-14. To remotely control the apparatus via the GP-IB interface, the controller requires a GP-IB control program. The programmer to generator such a program must familiarize himself with the program codes and data formats shown in the table beforehand. Also, be sure to observe the precautions set forth in the table so as to use the apparatus correctly and safely.

**REMARKS**

For the GP-IB control program, refer to the instruction manual for the controller.

Table 3-14. Functions of GP-IB Interface (1/32)

**1. General**

The GP-IB interface, a remote interface for automatic measurement, enables the apparatus to be remotely controlled by the controller and to output data to an external device.

- (1) It can become a talker and a listener in a GP-IB system which has a controller.
- (2) It can become a talker (TALK ONLY) in a GP-IB system which has no controller.
- (3) GP-IB interface functions: SH1, AH1, T5, L4, SR1, RL1, DT1, DC1

**2. Connection with Other GP-IB Devices**

When connecting other GP-IB devices to the apparatus via the GP-IB interface using GP-IB cables, use the following procedure:

- (1) Set the power switches of the apparatus and the GP-IB devices to be connected to it to OFF.
- (2) Interconnect the frame ground (FG) terminals of all devices to be connected, and short them to ground.
- (3) Connect the GP-IB devices to the apparatus, using GP-IB cables.
- (4) Set the power switches of the apparatus and the GP-IB devices to ON.

**REMARKS**

The GP-IB connector is a 24-pin connector.

Its pin assignment and the names of signals connected to it are shown in the right figure.

(IEEE-488 compatible)




Table 3-14. Functions of GP-IB Interface (Continued) (2/32)

**3. GP-IB Status Indications**

When the apparatus is used in a GP-IB system, its status is indicated by its GP-IB status LEDs as follows:

|        |  |
|--------|--|
| SEQ    | The apparatus has sent a SRQ (service request) signal to the GP-IB bus line. |
| LISTEN | The apparatus has been designated as listener.                               |
| TALK   | The apparatus has been designated as talker.                                 |
| REMOTE | The apparatus is under remote control by the controller.                     |

In the TALK ONLY mode, only the TALK LED is on.

**4. LOCAL Mode and REMOTE Mode**


|             |  |
|-------------|--|
| LOCAL mode  | When the apparatus is switched on, it is set in the LOCAL mode (for manual-controlled operation). The LOCAL mode is also entered when a GTL (Go To Local) signal is received in the REMOTE mode, or when the LOCAL key is pressed in a state other than LLO (Local Lockout) state. |
| REMOTE mode | The REMOTE mode is entered when a MLA (My Listen Address) signal is received from the controller.  |

The LOCAL key is used to restore the apparatus that has been under remote control by the controller via the GP-IB interface into the LOCAL mode in which it can be controlled by keying on its front panel. The LOCAL key is not operable when a LLO state has been set by the controller.

Table 3-14. Functions of GP-IB Interface (Continued) (3/32)

5. GP-IB Address Switches

The GP-IB address switches are used to make switching between ADDRESSABLE and TALK ONLY and to set the GP-IB address of the apparatus. Prior to shipment from the factory, the switches have been set to ADDRESSABLE and MA (My Address) = 3.



| DELIMITER | <p>An output data format is set.</p> <table border="1"> <thead> <tr> <th>2</th> <th>1</th> <th>Mode</th> <th>Description of the Function</th> </tr> </thead> <tbody> <tr> <td>OFF</td> <td>OFF</td> <td>MODE0</td> <td> <ul style="list-style-type: none"> <li>Measured data (MAIN, SUB) is output as one line, being separated by commas.</li> <li>CR LF is sent at the end of the output data. EOI is transmitted at the same time LF is sent.</li> </ul> </td> </tr> <tr> <td>OFF</td> <td>ON</td> <td>MODE1</td> <td> <ul style="list-style-type: none"> <li>Measured data is output as one line, being separated by commas.</li> <li>CR LF is not sent at the end of the output data. EOI is transmitted when the final byte of the data is sent.</li> </ul> </td> </tr> <tr> <td>ON</td> <td>OFF</td> <td>MODE2</td> <td> <ul style="list-style-type: none"> <li>Measured data is divided into two lines and output.</li> <li>CR LF is sent at the end of each line. EOI is transmitted at the same time the LF on the second line is sent.</li> </ul> </td> </tr> <tr> <td>ON</td> <td>ON</td> <td>Unused</td> <td>Same operation as MODE2.</td> </tr> </tbody> </table> | 2      | 1   | Mode                        | Description of the Function | OFF     | OFF | MODE0 | <ul style="list-style-type: none"> <li>Measured data (MAIN, SUB) is output as one line, being separated by commas.</li> <li>CR LF is sent at the end of the output data. EOI is transmitted at the same time LF is sent.</li> </ul> | OFF | ON                   | MODE1 | <ul style="list-style-type: none"> <li>Measured data is output as one line, being separated by commas.</li> <li>CR LF is not sent at the end of the output data. EOI is transmitted when the final byte of the data is sent.</li> </ul> | ON | OFF | MODE2 | <ul style="list-style-type: none"> <li>Measured data is divided into two lines and output.</li> <li>CR LF is sent at the end of each line. EOI is transmitted at the same time the LF on the second line is sent.</li> </ul> | ON | ON | Unused | Same operation as MODE2. |   |    |                             |   |   |   |    |
|-----------|---|--------|---|-----------------------------|-----------------------------|---------|-----|-------|---|-----|----------------------|-------|---|----|-----|-------|--|----|----|--------|--------------------------|---|----|-----------------------------|---|---|---|----|
| 2         | 1   | Mode   | Description of the Function   |                             |                             |         |     |       |   |     |                      |       |   |    |     |       |  |    |    |        |                          |   |    |                             |   |   |   |    |
| OFF       | OFF   | MODE0  | <ul style="list-style-type: none"> <li>Measured data (MAIN, SUB) is output as one line, being separated by commas.</li> <li>CR LF is sent at the end of the output data. EOI is transmitted at the same time LF is sent.</li> </ul>     |                             |                             |         |     |       |   |     |                      |       |   |    |     |       |  |    |    |        |                          |   |    |                             |   |   |   |    |
| OFF       | ON  | MODE1  | <ul style="list-style-type: none"> <li>Measured data is output as one line, being separated by commas.</li> <li>CR LF is not sent at the end of the output data. EOI is transmitted when the final byte of the data is sent.</li> </ul> |                             |                             |         |     |       |   |     |                      |       |   |    |     |       |  |    |    |        |                          |   |    |                             |   |   |   |    |
| ON        | OFF   | MODE2  | <ul style="list-style-type: none"> <li>Measured data is divided into two lines and output.</li> <li>CR LF is sent at the end of each line. EOI is transmitted at the same time the LF on the second line is sent.</li> </ul>            |                             |                             |         |     |       |   |     |                      |       |   |    |     |       |  |    |    |        |                          |   |    |                             |   |   |   |    |
| ON        | ON  | Unused | Same operation as MODE2.  |                             |                             |         |     |       |   |     |                      |       |   |    |     |       |  |    |    |        |                          |   |    |                             |   |   |   |    |
| TALK ONLY | <p>OFF (ADDRESSABLE):</p> <p>The address setting switches are operable. (Normal GP-IB system)</p> <p>ON (TALK ONLY):</p> <p>The address setting process as performed in the command mode is omitted, and data can be transferred by three-line handshaking. If a printer having the LISTEN ONLY function is connected to the apparatus, only measured data can be output to the printer.</p>  |        |   |                             |                             |         |     |       |   |     |                      |       |   |    |     |       |  |    |    |        |                          |   |    |                             |   |   |   |    |
| ADDRESS   | <p>Address setting switches</p> <table border="1"> <thead> <tr> <th>16</th> <th>4</th> <th>1</th> <th>Address (decimal)</th> <th>Remarks</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td rowspan="3">Arbitrarily settable</td> </tr> <tr> <td>0</td> <td>0</td> <td>0</td> <td>1</td> </tr> <tr> <td colspan="3" style="text-align: center;">}</td> <td style="text-align: center;">}</td> </tr> <tr> <td>1</td> <td>1</td> <td>1</td> <td>30</td> <td rowspan="2">Unusable (replaced with 30)</td> </tr> <tr> <td>1</td> <td>1</td> <td>1</td> <td>30</td> </tr> </tbody> </table>  | 16     | 4   | 1                           | Address (decimal)           | Remarks | 0   | 0     | 0   | 0   | Arbitrarily settable | 0     | 0   | 0  | 1   | }     |  |    | }  | 1      | 1                        | 1 | 30 | Unusable (replaced with 30) | 1 | 1 | 1 | 30 |
| 16        | 4   | 1      | Address (decimal)   | Remarks                     |                             |         |     |       |   |     |                      |       |   |    |     |       |  |    |    |        |                          |   |    |                             |   |   |   |    |
| 0         | 0   | 0      | 0   | Arbitrarily settable        |                             |         |     |       |   |     |                      |       |   |    |     |       |  |    |    |        |                          |   |    |                             |   |   |   |    |
| 0         | 0   | 0      | 1   |                             |                             |         |     |       |   |     |                      |       |   |    |     |       |  |    |    |        |                          |   |    |                             |   |   |   |    |
| }         |   |        | }   |                             |                             |         |     |       |   |     |                      |       |   |    |     |       |  |    |    |        |                          |   |    |                             |   |   |   |    |
| 1         | 1   | 1      | 30  | Unusable (replaced with 30) |                             |         |     |       |   |     |                      |       |   |    |     |       |  |    |    |        |                          |   |    |                             |   |   |   |    |
| 1         | 1   | 1      | 30  |                             |                             |         |     |       |   |     |                      |       |   |    |     |       |  |    |    |        |                          |   |    |                             |   |   |   |    |

REMARKS

- 1) In a GP-IB system, the GP-IB address of every device must be unique.
- 2) The apparatus is represented by a one-level address.
- 3) GP-IB address 31 is unusable. If all address switches are set to ON (1), the address is automatically replaced with 30.

Table 3-14. Functions of GP-IB Interface (Continued) (4/32)


## 7. Remote Program

The program codes usable to control the apparatus are listed in the table of remote program codes for the AG-4311B. Using a code which is not listed in the table constitutes a program error; an error indication is displayed.

### 7.1 Function setting format

To set functions, for example, to define measuring conditions, use the format as shown below. In the format, each function constitutes a string; two or more strings make up a message block. Each message block must end with a block delimiter to indicate the end of the message.

#### <Basic function setting format>



- H: Header ..... Control character assigned to each function  
 B: Body ..... Number assigned to each function (omitted depending on the case)  
 X: String delimiter .... "," (comma) code to delimit a string. This delimiter is omissible.  
 Y: Block delimiter .... LF, or CR + LF to delimit the message block. ("EOI" alone can be a block delimiter.)

#### <Function setting example>

A10, C0, H0, V3, F21, R00, T2, I0      CR LF  
 (1) (2) (3) (5) (6) (7) (8) (10)              (EOI)

#### NOTES:

- 1) Numbers shown in ( ) correspond to numbers in the table of remote program codes.
- 2) The "," (comma) code may be omitted.
- 3) Strings may be entered in any order.
- 4) When the last specifications need not be changed, the corresponding strings may be omitted.
- 5) If a program code error is detected, an error indication is output. If a program code error is detected with SRQ READY (I1) specified, the SRQ LED goes on and the error is indicated by status byte bit 1.
- 6) Execution of the above message block results in the following settings:
 

|                 |       |        |
|-----------------|-------|--------|
| PARAMETER       | ..... | C-D    |
| CIRCUIT MODE    | ..... | AUTO   |
| MEAS SPEED      | ..... | NORMAL |
| OSC LEVEL RANGE | ..... | 1 V    |
| TEST FREQUENCY  | ..... | 1 kHz  |
| RANGE           | ..... | AUTO   |
| MEAS START      | ..... | MANUAL |
| SRQ READY       | ..... | OFF    |

Table 3-14. Functions of GP-IB Interface (Continued) (5/32)



| Remote Program Codes for the AG-4311B (1/8) |                 |  |   |  |
|---|-----------------|--|---|--|
| No.   | FUNCTION        | Setting  | Program Code  | Remarks  |
| 1   | PARAMETER       | L-D<br>L-Q<br>L-ESR/G<br><br>C-D<br>C-Q<br>C-ESR/G<br><br>R-X/B<br>R-L/C<br><br>$ Z -\theta$   | A00<br>A01<br>A02<br><br>A10<br>A11<br>A12<br><br>A20<br>A21<br><br>A30 | <ul style="list-style-type: none"> <li>• A <input type="checkbox"/> <input type="checkbox"/> <pre> graph TD     A["A <input type="checkbox"/><input "]="" ---="" <="" a="" b["main="" c["subparameter="" parameter="" pre="" selection"]="" type="checkbox"/> </pre></li> <li>• A02, A12, A20, and A21 cause the subparameter to be determined by the circuit mode.</li> </ul> |
| 2   | CIRCUIT MODE    | AUTO<br><br><br><br> | C0<br><br>C1<br><br>C2  |  |
| 3   | MEAS SPEED      | NORMAL<br>SLOW<br>FAST   | H0<br>H1<br>H2  |  |
| 4   | DEVIATION       | OFF<br>$\Delta$<br>$\Delta\%$  | D0<br>D1<br>D2  | <ul style="list-style-type: none"> <li>• Setting <math>\Delta</math> or <math>\Delta\%</math> requires a reference value to be input beforehand.</li> </ul>  |
| 5   | OSC LEVEL RANGE | 10 mV<br>100 mV<br>1 V<br>5 V  | V1<br>V2<br>V3<br>V4  | <ul style="list-style-type: none"> <li>• Values are nominal values for a state with the OSC LEVEL FINE adjuster placed at MAX (right most position).</li> </ul>  |

Table 3-14. Functions of GP-IB Interface (Continued) (6/32)

| Remote Program Codes for the AG-4311B (2/8) |                |                    |              |  |
|---|----------------|--------------------|--------------|--|
| No.   | FUNCTION       | Setting            | Program Code | Remarks  |
| 6   | TEST FREQUENCY | EXT<br>FREQ DATA   | F00          | <ul style="list-style-type: none"> <li>• Execution of F00 sets the mode requiring the external frequency to be specified via the external frequency data interface.</li> <li>• Execution of F01 sets the mode requiring the external frequency to be specified via the GP-IB interface.<br/>(The external frequency must be specified in GF code.)</li> <li>• F11 to F14 (31 frequencies)<br/>Internal oscillator frequency selection<br/>(Frequencies are nominal values.)</li> </ul> |
|   |                | GP-IB<br>FREQ DATA | F01          |  |
|   |                | 100 Hz             | F11          |  |
|   |                | 120 Hz             | F12          |  |
|   |                | 150 Hz             | F13          |  |
|   |                | 200 Hz             | F14          |  |
|   |                | 250 Hz             | F15          |  |
|   |                | 300 Hz             | F16          |  |
|   |                | 401 Hz             | F17          |  |
|   |                | 500 Hz             | F18          |  |
|   |                | 601 Hz             | F19          |  |
|   |                | 801 Hz             | F20          |  |
|   |                | 1.00 kHz           | F21          |  |
|   |                | 1.20 kHz           | F22          |  |
|   |                | 1.50 kHz           | F23          |  |
|   |                | 2.00 kHz           | F24          |  |
|   |                | 2.50 kHz           | F25          |  |
|   |                | 3.00 kHz           | F26          |  |
|   |                | 4.01 kHz           | F27          |  |
|   |                | 5.00 kHz           | F28          |  |
|   |                | 6.01 kHz           | F29          |  |
|   |                | 8.01 kHz           | F30          |  |
|   |                | 10.0 kHz           | F31          |  |
| 12.0 kHz                                    | F32            |                    |              |  |
| 15.1 kHz                                    | F33            |                    |              |  |
| 20.2 kHz                                    | F34            |                    |              |  |
| 25.0 kHz                                    | F35            |                    |              |  |
| 30.5 kHz                                    | F36            |                    |              |  |
| 40.3 kHz                                    | F37            |                    |              |  |
| 50.0 kHz                                    | F38            |                    |              |  |
| 62.5 kHz                                    | F39            |                    |              |  |
| 78.1 kHz                                    | F40            |                    |              |  |
| 100 kHz                                     | F41            |                    |              |  |



Table 3-14. Functions of GP-IB Interface (Continued) (7/32)

| Remote Program Codes for the AG-4311B (3/8) |                 |                                 |              |  |
|---|-----------------|---------------------------------|--------------|--|
| No.   | FUNCTION        | Setting                         | Program Code | Remarks  |
| 7   | RANGE           | AUTO                            | R00          | <ul style="list-style-type: none"> <li>• Execution of R00 sets the AUTO mode.</li> <li>• Execution of R10 causes the current range to be fixed.</li> <li>• Execution of one of R11 to R23 causes the specified range to be fixed. If the specified range is not allowable for the specified parameter or measuring frequency, the nearest allowable range is set.</li> </ul>     |
|   |                 | MANUAL/HOLD                     | R10          |  |
|   |                 | 1pF/ 0.1 $\mu$ H/ 0.1 $\Omega$  | R11          |  |
|   |                 | 10pF/ 1 $\mu$ H/ 1 $\Omega$     | R12          |  |
|   |                 | 100pF/ 10 $\mu$ H/ 10 $\Omega$  | R13          |  |
|   |                 | 1nF/ 100 $\mu$ H/ 100 $\Omega$  | R14          |  |
|   |                 | 10nF/ 1mH/ 1k $\Omega$          | R15          |  |
|   |                 | 100nF/ 10mH/ 10k $\Omega$       | R16          |  |
|   |                 | 1 $\mu$ F/ 100mH/ 100k $\Omega$ | R17          |  |
|   |                 | 10 $\mu$ F/ 1 H/ 1M $\Omega$    | R18          |  |
|   |                 | 100 $\mu$ F/ 10 H/ 10M $\Omega$ | R19          |  |
|   |                 | 1mF/ 100 H                      | R20          |  |
|   |                 | 10mF/ 1kH                       | R21          |  |
|   |                 | 100mF/ 10kH                     | R22          |  |
| 1000mF                                      | R23             |                                 |              |  |
| 8   | MEAS<br>START   | AUTO                            | T0           | <ul style="list-style-type: none"> <li>• Execution of T0 sets the AUTO mode.</li> <li>• Execution of T1 sets the external trigger mode in which measurement is started by an <u>EXT-MST</u> signal input to the EXT CONTROL connector.</li> <li>• Execution of T2 causes measurement to be made every time a measurement starting command is received from the GP-IB.</li> </ul> |
|   |                 | EXT                             | T1           |  |
|   |                 | MANUAL                          | T2           |  |
| 9   | SIGNAL<br>CHECK | OSC FREQUENCY                   | M0           | <ul style="list-style-type: none"> <li>• Used to select the item to be indicated on the check display.</li> </ul>  |
|   |                 | OSC LEVEL                       | M1           |  |
|   |                 | UNKNOWN V                       | M2           |  |
|   |                 | UNKNOWN mA                      | M3           |  |

Table 3-14. Functions of GP-IB Interface (Continued) (8/32)

| Remote Program Codes for the AG-4311B (4/8) |             |           |              |  |
|---|-------------|-----------|--------------|--|
| No.   | FUNCTION    | Setting   | Program Code | Remarks  |
| 10  | SRQ READY   | OFF<br>ON | I0<br>I1     | <ul style="list-style-type: none"> <li>Control codes related to the service request function. If the service request function is to be used, set the SRQ READY state by executing I1; if the function is not to be used, set I0.</li> <li>When measurement is terminated with the SRQ READY (I1) set, a SRQ signal is output. (The readiness of output data is indicated by status byte bit 0.)</li> </ul> |
| 11  | EXT DC BIAS | OFF<br>ON | B0<br>B1     | <ul style="list-style-type: none"> <li>DC bias ON/OFF selection</li> <li>When an external DC bias is to be used, execute B1.</li> </ul>  |
| 12  | COMP ENABLE | OFF<br>ON | P0<br>P1     | <ul style="list-style-type: none"> <li>Comparator ON/OFF selection</li> <li>Execution of P1 makes the comparator ready for operation. The result of the judgment is output to the measured data status.</li> </ul> <p>(When comparator operation is to be performed, it is necessary to set the limit values (upper and lower limits) beforehand.)</p>   |
| 13  | HEADER      | OFF<br>ON | HR0<br>HR1   | <ul style="list-style-type: none"> <li>Used to specify whether a GP-IB output data header is to be provided or not.</li> <li>If HR0 is executed, the header for GP-IB output data is not output.</li> </ul>  |

Table 3-14. Functions of GP-IB Interface (Continued) (9/32)

| Remote Program Codes for the AG-4311B (5/8) |                                   |         |                      |   |
|---|-----------------------------------|---------|----------------------|---|
| No.   | FUNCTION                          | Setting | Program Code         | Remarks   |
| 14  | REFERENCE VALUE                   | SET     | SL<br>SC<br>SR<br>SZ | <ul style="list-style-type: none"> <li>• SL, SC, SR, and SZ are used to set the reference values for parameters L, C, R, and  Z , respectively. The numeric value must be specified in an exponential format.</li> <li>• Execution of ST causes the current measurement to be stored as the reference value.</li> <li>• Execution of SA recalls the reference value.</li> </ul> |
|   |                                   | STORE   | ST                   |   |
|   |                                   | SA      |                      |   |
| 15  | OSC FREQUENCY & LEVEL RANGE       |         | OF                   | <ul style="list-style-type: none"> <li>• Execution of OF causes the measuring frequency to be output.</li> <li>• Execution of OV causes the measuring signal level range to be output.</li> </ul>   |
|   |                                   |         | OV                   |   |
| 16  | UNKNOWN VOLTAGE & CURRENT         |         | LV                   | <ul style="list-style-type: none"> <li>• Execution of LV causes the signal voltage being applied to the sample to be output.</li> <li>• Execution of LA causes the signal current flowing through the sample to be output.</li> </ul>   |
|   |                                   |         | LA                   |   |
| 17  | KEY STATUS                        |         | K                    | <ul style="list-style-type: none"> <li>• Execution of this code causes the current status of internal settings to be output.</li> </ul>   |
| 18  | EXT TEST FREQUENCY<br>(For GP-IB) |         | GF                   | <ul style="list-style-type: none"> <li>• This code is used by the controller to set an external frequency, which is 16 times the measuring frequency. The numerical value must be input in an exponential format.</li> <li>• F01 must be executed in advance of execution of this code to make measurement by the use of an external frequency.</li> </ul>                      |

Table 3-14. Functions of GP-IB Interface (Continued) (10/32)

| Remote Program Codes for the AG-4311B (6/8) |                                |               |              |  |
|---|--------------------------------|---------------|--------------|--|
| No.   | FUNCTION                       | Setting       | Program Code | Remarks  |
| 19  | OFFSET ADJ                     | OPEN<br>SHORT | Y1<br>Y2     | <ul style="list-style-type: none"> <li>• Offset adjustment starting commands. Execute Y1 to make offset adjustment in open ADJ mode; execute Y2 to make offset adjustment in short ADJ mode. An open mode loop and a short mode loop must be arranged beforehand.</li> <li>• The resultant data is output the moment the offset adjustment is completed.</li> <li>• When measurement is terminated with the SRQ READY set, a SRQ signal is output. (The termination is indicated by status byte bit 2, and the NG/PASS decision is indicated by status byte bit 3.)</li> </ul> |
| 20  | SELF TEST                      |               | Z            | <ul style="list-style-type: none"> <li>• Execution of this code starts the self test (the same test as that initially executed when the apparatus is switched on.)</li> <li>• The resultant data is output the moment the self test is terminated.</li> <li>• When the test is terminated with the SRQ READY set, a SRQ signal is output. (The termination is indicated by status byte bit 2, and the NG/PASS decision is indicated by status byte bit 3.)</li> </ul>  |
| 21  | EXECUTE<br>(Measurement start) |               | E            | <ul style="list-style-type: none"> <li>• Execution of this code starts measurement (measurement starting command). (Measurement can also be started by address command, GET message.)</li> <li>• The measured data is output the moment the measurement is completed.</li> </ul>   |

Table 3-14. Functions of GP-IB Interface (Continued) (11/32)

| Remote Program Codes for the AG-4311B (7/8) |                 |         |  |   |
|---|-----------------|---------|--|---|
| No.   | FUNCTION        | Setting | Program Code   | Remarks   |
| 22  | LIMIT VALUE SET |         | SUL<br>SLL<br>SUC<br>SLC<br>SUR<br>SLR<br>SUZ<br>SLZ<br><br>SUD<br>SLD<br>SUQ<br>SLQ<br>SUG<br>SLG<br>SUER<br>SLER<br><br>SUSL<br>SLSL<br>SUSC<br>SLSC<br>SUX<br>SLX<br>SUB<br>SLB<br><br>SUT<br>SLT | <ul style="list-style-type: none"> <li>These codes are used to set comparator limit values (upper and lower limits). Numerical values should be entered in an exponential format.</li> <li> </li> </ul> <p>( ER: ESR<br/>                     SL: Subparameter L<br/>                     SC: Subparameter C<br/>                     T : <math>\theta</math> )</p> |

93

Table 3-14. Functions of GP-IB Interface (Continued) (12/32)

| Remote Program Codes for the AG-4311B (8/8) |                    |         |              |  |   |
|---|--------------------|---------|--------------|--|---|
| No.   | FUNCTION           | Setting | Program Code | Remarks  |   |
| 23  | LIMIT VALUE RECALL |         | UL           | <ul style="list-style-type: none"> <li>• These codes are used to read comparator limit values (upper and lower limits).</li> <li>• Execution of these codes causes the specified limit value to be output in an exponential format.</li> </ul> <div style="margin-left: 20px;"> <p>Limit value code<br/>                     U: Upper limit<br/>                     L: Lower limit</p> <p>Parameter code<br/>                     L, C, R, Z,<br/>                     D, Q, G, ER,<br/>                     SL, SC, X, B, T</p> </div> |   |
|   |                    |         | LL           |  |   |
|   |                    |         | UC           |  |   |
|   |                    |         | LC           |  |   |
|   |                    |         | UR           |  |   |
|   |                    |         | LR           |  |   |
|   |                    |         | UZ           |  |   |
|   |                    |         | LZ           |  |   |
|   |                    |         | UD           |  |   |
|   |                    |         | LD           |  |   |
|   |                    |         | UQ           |  |   |
|   |                    |         | LQ           |  |   |
|   |                    |         | UG           |  |   |
|   |                    |         | LG           |  |   |
|   |                    |         | UER          |  |   |
|   |                    |         | LER          |  |   |
|   |                    |         | USL          |  | ( ER: ESR<br>SL: Subparameter L<br>SC: Subparameter C<br>T : $\theta$ ) |
|   |                    |         | LSL          |  |   |
|   |                    |         | USC          |  |   |
|   |                    |         | LSC          |  |   |
|   |                    |         | UX           |  |   |
|   |                    |         | LX           |  |   |
|   |                    |         | UB           |  |   |
| LB  |                    |         |              |  |   |
| UT  |                    |         |              |  |   |
| LT  |                    |         |              |  |   |

Table 3-14. Functions of GP-IB Interface (Continued) (13/32)

### 7.2 Starting measurement

There are two commands that can be used to start measurement on the apparatus; remote program code E (Execute) and GP-IB address command, GET message. (The apparatus outputs measured data when it is designated as a talker after measurement is started by execution of an E code or GET message.)

#### (1) Inputting E code

- ① Inputting E code along

E CR LF  
(EOI)

- ② Inputting E code together with function settings

Function settings, E CR LF  
(EOI)  
↑  
— Enter as the last string.

#### (2) GET message

When address command, GET (08H) message, is received, the apparatus starts measurement.

(For information on the use of the GET message, refer to the instruction manual for the controller.)

### 7.3 Setting deviation reference value

Either a measured value or an arbitrary value can be set under control by the GP-IB as the reference value for use in the deviation measurement mode.

#### (1) Setting measured value as reference value

Execution of remote program code ST causes the measured value currently indicated to be stored as the reference value.

ST CR LF  
(EOI)

**NOTE:** Execution of ST requires measurement to be started and a measured value to be indicated beforehand; if no value is indicated, an error indication is displayed.

#### (2) Setting arbitrary value as reference value

Specify an arbitrary value of parameter L, C, R, or |Z| in an exponential format using remote program code SL, SC, SR, or SZ.


Table 3-14. Functions of GP-IB Interface (Continued) (14/32)

<Reference value range>

| PARAMETER | Allowable reference value range |
|-----------|---------------------------------|
| C         | 0 - 9999.9 mF                   |
| L         | 0 - 99.999 kH                   |
| R,  Z     | 0 - 99.999 MΩ                   |

NOTE: The number of significant digits is five. If a value outside the allowable range is set, an error indication is displayed.

<Reference value input format>



- NOTES:
- 1) The positive polarity (+) of the fractional part is represented by a space. (In the example, it is represented by Δ.)
  - 2) The number of significant digits of the mantissa is five.
  - 3) The exponent part consists of four characters.

|               |       |                     |
|---------------|-------|---------------------|
| E + 06        | ..... | × 10 <sup>6</sup>   |
| E + 03        | ..... | × 10 <sup>3</sup>   |
| E + 00 (E-00) | ..... | × 1                 |
| E - 03        | ..... | × 10 <sup>-3</sup>  |
| E - 06        | ..... | × 10 <sup>-6</sup>  |
| E - 12        | ..... | × 10 <sup>-12</sup> |

Example: Setting 1.2345 μF as the reference value for parameter C.

SCΔ1.23450E-06 CR LF  
(EOI)

<Clearing reference value>

To clear (reset) the reference value, set 1E-30 as numerical data.






Table 3-14. Functions of GP-IB Interface (Continued) (15/32)

7.4 Setting external frequency (for GP-IB)

This apparatus can make measurement using an external frequency. To make such measurement, an external frequency 16 times the measuring frequency must be input to the EXT TEST FREQ INPUT connector, and the frequency value must be specified via the GP-IB interface or the external frequency data interface.


To specify an external frequency under control by the GP-IB, use remote program code GF, and input the numerical data in an exponential format. (The numerical data must specify the external frequency that is 16 times the measuring frequency.)

<External frequency range>

| Program code | Allowable range   |
|--------------|-------------------|
| GF           | 1.6 kHz - 1.6 MHz |

NOTE: The number of significant digits is five. If a value outside the allowable range is set, an error indication is output.

<External frequency input format>



- NOTES: 1) The positive polarity (+) of the fraction part is represented by a space. (In the example, it is represented by Δ.)
- 2) The number of significant digits of the mantissa is five.
- 3) The exponent part consists of four characters.

|        |       |                         |
|--------|-------|-------------------------|
| E + 06 | ..... | × 10 <sup>6</sup> (MHz) |
| E + 03 | ..... | × 10 <sup>3</sup> (kHz) |
| E + 00 | ..... | × 1 (Hz)                |

Example: Setting an external frequency of 16 kHz (with the measuring frequency being 1 kHz).

GFΔ16.0000E + 03 CR LF  
(EOI)

Table 3-14. Functions of GP-IB Interface (Continued) (16/32)


7.5 Setting comparator limit values

Limit values (upper and lower limits) for comparator operation can be specified for each measurement parameter. Specify numerical data in an exponential format, using remote program code S  .

<Limit value input range>

| Main parameter | Allowable range | Subparameter | Allowable range         |
|----------------|-----------------|--------------|-------------------------|
| C              | 0 - 9999.9 mF   | D            | 0 - 9.9999              |
| L              | 0 - 99.999 kH   | Q            | 0 - 9999                |
| R              | 0 - 99.999 MΩ   | G            | 0 - 999.99 S            |
| Z              | 0 - 99.999 MΩ   | ESR          | 0 - 99.999 MΩ           |
|                |                 | X            | - 99.999 MΩ - 999.99 MΩ |
|                |                 | B            | - 999.99 S - 999.99 S   |
|                |                 | L            | 0 - 99.999 MΩ           |
|                |                 | C            | 0 - 9999.9 mF           |
|                |                 | θ            | - 180.00 - 180.00 deg   |

<Limit value input format>



NOTES:

- 1) The positive polarity (+) of the fractional part is represented by a space. (In the example, it is represented by Δ.)
- 2) The maximum number of significant digits of the mantissa is five.
- 3) The exponent part consists of four characters.

|        |       |                   |        |       |                     |
|--------|-------|-------------------|--------|-------|---------------------|
| E + 06 | ..... | × 10 <sup>6</sup> | E - 03 | ..... | × 10 <sup>-3</sup>  |
| E + 03 | ..... | × 10 <sup>3</sup> | E - 06 | ..... | × 10 <sup>-6</sup>  |
| E + 00 | ..... | × 1               | E - 09 | ..... | × 10 <sup>-9</sup>  |
|        |       |                   | E - 12 | ..... | × 10 <sup>-12</sup> |

Table 3-14. Functions of GP-IB Interface (Continued) (17/32)

Example 1: Setting the upper limit for parameter C to 1.2345  $\mu$ F

SUC  $\Delta\Delta$ 1.2345E-06 CR LF  
(EOI)

Example 2: Setting the lower limit for parameter C to 1  $\mu$ F

SLC  $\Delta\Delta$ 1E-06 CR LF  
(EOI)

<Clearing limit values>

To clear (reset) limit values, set 1E-30 as numerical data.

S    $\Delta$ 1E-30 CR LF  
(EOI)

Limit value code  $\uparrow$

Parameter code  $\uparrow$

Table 3-14. Functions of GP-IB Interface (Continued) (18/32)


## 8. Data Output

This apparatus can output the following ten items of data.

| No. | Output data                           | Relevant remote program code       |
|-----|---------------------------------------|------------------------------------|
| 1   | Measured values (MAIN, SUB)           | E ( GET message )                  |
| 2   | Measuring frequency                   | OF                                 |
| 3   | OSC output level range                | OV                                 |
| 4   | Signal voltage applied to sample      | LV                                 |
| 5   | Signal current flowing through sample | LA                                 |
| 6   | REFERENCE VALUE                       | SA                                 |
| 7   | Internal setting                      | K                                  |
| 8   | LIMIT VALUE                           | Limit value code    Parameter code |
| 9   | Self test result data                 | Z                                  |
| 10  | Offset adjustment result data         | Y1, Y2                             |

## 8.1 Basic output format for numerical data

Numerical data is output in an exponential format (fractional part + exponent part) to which data status and data item codes are attached as shown below. (For HR1)





## NOTES:

- 1) The positive polarity (+) of the fractional part is represented by a space. (In the example, it is represented by  $\Delta$ .)
- 2) The exponent part consists of four characters; for the percent deviation mode ( $\Delta\%$ ),  $\Delta\text{PER}$  is entered.

|                    |       |                   |
|--------------------|-------|-------------------|
| E + 06             | ..... | $\times 10^6$     |
| E + 03             | ..... | $\times 10^3$     |
| E + 00             | ..... | $\times 1$        |
| E - 03             | ..... | $\times 10^{-3}$  |
| E - 06             | ..... | $\times 10^{-6}$  |
| E - 09             | ..... | $\times 10^{-9}$  |
| E - 12             | ..... | $\times 10^{-12}$ |
| $\Delta\text{PER}$ | ..... | percent           |

Table 3-14. Functions of GP-IB Interface (Continued) (19/32)

| Data Output Codes for the AG-4311B (1/2) |                   |  |  |  |
|--|-------------------|--|--|--|
| No.                                      | FUNCTION          | Setting  | Output Code  | Remarks  |
| ①  | CIRCUIT MODE      | <br> | S<br>P   | Series Mode<br>Parallel Mode   |
| ②  | TEST FREQUENCY    | F00, F01<br>F11 - F41  | F □ □  | Same as remote program code  |
| ③  | OSC LEVEL RANGE   | V1 - V4  | V □  | Same as remote program code  |
| ④  | MEAS SPEED        | NORMAL<br>FAST<br>SLOW   | △<br>F<br>H  | (Space)  |
| ⑤  | DATA STATUS       | Normal<br>OF<br>UF<br>CF<br><br>HIGH<br>PASS<br>LOW<br>Warning   | N<br>O<br>U<br>C<br><br>H<br>P<br>L<br>W           | Over Flow<br>Under Flow<br>Change Function<br><br>Judgment result output with<br>COMP ENABLE on (P1)<br>(Output when DEVIATION is off<br>(D0) and the data is normal.<br>The W code indicates a limit<br>value setting error.) |
| ⑥  | PARAMETER<br>MAIN | L<br>C<br>R<br> Z <br>△ or △% of L<br>△ or △% of C<br>△ or △% of R<br>△ or △% of  Z  | △L<br>△C<br>△R<br>△Z<br>DL<br>DC<br>DR<br>DZ       | Deviation measurement  |
|  | SUB               | D<br>Q<br>ESR<br>G<br>X<br>B<br>L<br>C<br>θ  | △D<br>△Q<br>ER<br>△G<br>△X<br>△B<br>△L<br>△C<br>△T |  |

NOTE: The mark △ in output codes represents a space.

Table 3-14. Functions of GP-IB Interface (Continued) (20/32)

| Data Output Codes for the AG-4311B (2/2) |   |   |  |  |
|--|---|---|--|--|
| No.                                      | FUNCTION                                      | Setting   | Output Code  | Remarks  |
| ⑦  | Fractional part of data                       |   |  | Characters including a sign and decimal point. They are displayed from the rightmost position. |
| ⑧  | Exponent part of data                         |   | E □ □ □<br>△ PER   | E + 06, E + 03, E + 00<br>E - 03, E - 06, E - 09, E - 12<br>In △% mode (MAIN only)             |
| ⑨  | Limit value code                              | Upper limit<br>Lower limit  | U<br>L   |  |
| ⑩  | LIMIT VALUE<br>Parameter code MAIN<br><br>SUB | L<br>C<br>R<br> Z <br><br>D<br>Q<br>ESR<br>G<br>X<br>B<br>L<br>C<br>θ | L△<br>C△<br>R△<br>Z△<br><br>D△<br>Q△<br>ER<br>G△<br>X△<br>B△<br>SL<br>SC<br>T△ |  |

NOTE: The mark △ in output codes represents a space.

Table 3-14. Functions of GP-IB Interface (Continued) (21/32)

8.2 Measured data (MAIN, SUB) output format


This apparatus starts measurement when remote program code E or GET message is received, and it outputs measured data when it is designated as the talker. The data is output in one of the two formats depending on the setting of the DIP switch DELIMITER on the rear panel.

(1) DELIMITER mode 0/1

When DELIMITER mode 0 or 1 is selected, measured data is separated by commas and output as one line.

NOTE: In DELIMITER mode 1, CR LF is not added, and EOI is output at the same time the final data is output.


<HEADER ON (HR1)>



Example:  $\Delta PF21V3\Delta\Delta N\Delta C\Delta\Delta 23.05000E-09, N\Delta D\Delta\Delta\Delta 0.00120E+00$

Parallel Mode      MAIN PARAMETER      SUB PARAMETER  
 1kHz, 1 V Range      (C = 23.05nF)      (D = 0.0012)  
 MEAS SPEED Normal

<HEADER OFF (HR0)>





Example:  $\Delta\Delta 23.05000E-09, \Delta\Delta\Delta 0.00120E+00$

Table 3-14. Functions of GP-IB Interface (Continued) (22/32)

(2) DELIMITER mode 2



Measured data is divided into two lines and output.

<HEADER ON (HR1)>



Example:  $\Delta$  PF 21 V3 $\Delta$ N $\Delta$ C $\Delta$  $\Delta$ 23.05000E-09  
 $\Delta$  $\Delta$  $\Delta$  $\Delta$  $\Delta$  $\Delta$  $\Delta$  $\Delta$  $\Delta$ N $\Delta$ D $\Delta$  $\Delta$ 0.00120E+00

<HEADER OFF (HR0)>



Example:  $\Delta$  $\Delta$ 23.05000E-09  
 $\Delta$  $\Delta$  $\Delta$ 0.00120E+00



Table 3-14. Functions of GP-IB Interface (Continued) (23/32)

## NOTES:

- 1) The mark  $\Delta$  represents a space. The circled numbers correspond to those in the table of data output codes.
- 2) When deviation measurement is OFF (D0) and comparator operation is ON (P1), the normal data status becomes comparator judgment result H, P, L, or W.
- 3) When the data status is O (OF), U (UF), or C (CF), numerical data is as shown in the table below.


| Status | Numerical data |
|--------|----------------|
| O      | 1E + 20        |
| U      | 1E - 20        |
| C      | 1E - 30        |

- 4) In the deviation measurement (DEVIATION  $\Delta$ ,  $\Delta\%$ ) mode, a space is set in the SUB DATA part.
- 5) In the deviation percent measurement (DEVIATION  $\Delta\%$ ) mode, the exponent part (Ⓢ) is  $\Delta$ PER for normal data.

Table 3-14. Functions of GP-IB Interface (Continued) (24/32)


**8.3 Measuring frequency output format**

When remote program code OF is executed, the measuring frequency value (in Hz) is output in the following format.

**<HEADER ON (HR1)>**

Example: 1 kHz


$\Delta\text{NOF}\Delta\Delta\Delta 1.00000\text{E} + 03$

**<HEADER OFF (HR0)>**

Example:  $\Delta\Delta\Delta 1.00000\text{E} + 03$


**8.4 Level range output format**

When remote program code OV is executed, the value (in V) of the OSC level range is output in the following format.

**<HEADER ON (HR1)>**

Example: 1 V range

$\Delta\text{NOV}\Delta\Delta\Delta 1.000\text{E} + 00$


**<HEADER OFF (HR0)>**

Example:  $\Delta\Delta\Delta 1.000\text{E} + 00$

Table 3-14. Functions of GP-IB Interface (Continued) (25/32)


**8.5 Signal voltage output format**

When remote program code LV is executed, the value (in V) of the signal voltage applied to the sample is output in the following format.

**<HEADER ON (HR1)>**

Example: 39.9 mV


$\Delta$ NLV $\Delta\Delta$ 39.900E-03

**<HEADER OFF (HR0)>**

Example:  $\Delta\Delta$ 39.900E-03


**8.6 Signal current output format**

When remote program code LA is executed, the value (in A) of the signal current flowing through the sample is output in the following format.

**<HEADER ON (HR1)>**

Example: 18.2 mA

$\Delta$ NLA $\Delta\Delta$ 18.200E-03

**<HEADER OFF (HR0)>**


Example:  $\Delta\Delta$ 18.200E-03

Table 3-14. Functions of GP-IB Interface (Continued) (26/32)

8.7 Reference value output format


When remote program code SA is executed, the reference value is output in the following format.

<HEADER ON (HR1)>



Example: ΔSAΔNΔLΔΔΔ1.00000E-03, NΔCΔΔΔ1.25000E-09,  
NΔRΔΔΔ1.20000E+03, NΔZΔΔΔ4.72000E+00

<HEADER OFF (HR0)>



Example: ΔΔΔ1.00000E-03, ΔΔΔ1.25000E-09, ΔΔΔ1.20000E+03, ΔΔΔ4.72000E+00


108

Table 3-14. Functions of GP-IB Interface (Continued) (27/32)

8.8 Limit value output format

When remote program code **limit value code** **parameter code** is executed, the limit values are output in the following format.


<HEADER ON (HR1)>



Example: When the lower limit for C is 1.23 pF

$\Delta$ NUC $\Delta\Delta\Delta$ 1.23000E - 12

<HEADER OFF (HR0)>



Example:  $\Delta\Delta\Delta$ 1.23000E - 12

8.9 Internal setting output format

When remote program code K is executed, the internal settings are output in the following format.


$\Delta$ A□□C□H□D□F□□V□R□□T□M□I□B□P□HR□ CR LF  
 (1) (2) (3) (4) (5) (6) (7) (8) (9) (10) (11) (12) (13) (EOI)

NOTE: The numbers in ( ) correspond to the numbers listed in the table of remote program codes.

Table 3-14. Functions of GP-IB Interface (Continued) (28/32)

**8.10 Self test result output format**

When remote program code Z is executed, the result of the self test is output in the following format.

**8.11 Offset adjustment result output format**

When remote program code Y1 or Y2 is executed, offset adjustment is made and its result is output in the following format.




Table 3-14. Functions of GP-IB Interface (Continued) (29/32)

### 9. Service Request Status Byte (STB)

Remote program code I1 (SRQ READY) enables the apparatus to make a service request by serial polling. To use the service request function, set I1.

The contents of the status byte are shown below. If any one or more of the low-order four bits are set to 1, the RQS (Request Service) bit if set to 1 and the SRQ line turns true.

<STB bit arrangement>

| BIT 7  | 6   | 5   | 4   | 3             | 2           | 1                | 0             |
|--------|-----|-----|-----|---------------|-------------|------------------|---------------|
| 0      | RQS | 0   | 0   | TEST<br>ERROR | TEST<br>END | PROGRAM<br>ERROR | DATA<br>READY |
| (DIO8) | (7) | (6) | (5) | (4)           | (3)         | (2)              | (1)           |

#### BIT 6: RQS (Request Service)

If any event represented by bits 0-3 occurs, this bit is set to "1" causing the SRQ line to turn true.

#### BIT 3: TEST ERROR

If the self test or offset adjustment fails, this bit is set to "1".

#### BIT 2: TEST END

When the self test is terminated, this bit is set to "1".

#### BIT 1: PROGRAM ERROR

If an erroneous remote program code or numerical data is received, this bit is set to "1".

#### BIT 0: DATA READY

When data to be output after receipt of a remote program code has been prepared, this bit is set to "1".

Table 3-14. Functions of GP-IB Interface (Continued) (30/32)

**10. TALK ONLY Mode**

The TALK ONLY mode is entered when the TALK ONLY GP-IB address switch is set to ON. In the TALK ONLY mode, the address setting process as performed in the command mode is omitted so that data transfer by three-line handshaking can be made. If a proper output device, for example, a printer having the LISTEN ONLY function is connected to the apparatus, the measured values of the main parameter and subparameter can be output to it every time measurement is executed. For the data output format, see Section 8.2 in this table.

**CAUTIONS**

- 1) If MEAS START is set to AUTO, measurement is repeated, and data is output for each measurement.
- 2) As shown in 8.2, the data output format in the TALK ONLY mode varies depending on the DELIMITER MODE and HEADER ON/OFF settings.

The DELIMITER MODE can be selected by the DIP switches on the rear panel, whereas HEADER ON/OFF control can be exercised only by remote program codes. Operation is performed according to the state (HR0 or HR1) entered when the TALK ONLY mode is set. The apparatus has been factory set to HEADER ON (HR1) prior to shipment.



Table 3-14. Functions of GP-IB Interface (Continued) (31/32)

## 11. Precautions on GP-IB Programming

## (1) Procedures for starting measurement and reading data

To make measurement and read the measured data (MAIN, SUB) by remote control of the apparatus, proceed as follows.

- ① Designate the apparatus as a listener, and set the required functions. At the time, set the MEAS START to MANUAL (T2).
- ② Start measurement by issuing an E code or a GET message from the controller.  
(The E code can start measurement whether it is specified together with the functions to be used or it is specified alone.)
- ③ Designate the apparatus as a talker, and read the measured data (MAIN, SUB).

## REMARKS

If MEAS START is set to AUTO (T0), measurement is repeatedly made. When, with this condition maintained, measurement is started by an external signal from the GP-IB and the apparatus is designated as a talker, measured data is output if it has been obtained at the time when the apparatus is set as a talker.

When the apparatus is to be controlled by a measurement start signal from the GP-IB, set MEAS START to MANUAL (T2).

## (2) Operation performed when output data overlaps

If a program code (e.g., E, K, OF, OV) involving data output is executed without designating the apparatus as a talker after executing such a program code, data for the latter program code is output.

If a program code involving output of two or more data is contained in one line, data for the last program code is output.

## (3) Operation performed when a DCL (device clear) message is received

When a device clear message (DCL or SDC) is received from the controller, the following initial settings are set. If the apparatus is making measurement, self test, or offset adjustment, the processing is discontinued. Further, all service request status bytes are cleared.

| FUNCTION       | Initial setting | Program code | FUNCTION     | Initial setting | Program code |
|----------------|-----------------|--------------|--------------|-----------------|--------------|
| PARAMETER      | C-D             | A10          | MEAS START   | AUTO            | T0           |
| CIRCUIT MODE   | AUTO            | C0           | SIGNAL CHECK | OSC FREQ        | M0           |
| MEAS SPEED     | NORMAL          | H0           | SRQ READY    | OFF             | I0           |
| DEVIATION      | OFF             | D0           | EXT DC BIAS  | OFF             | B0           |
| OSC LEVEL      | 1V              | V3           | COMP ENABLE  | OFF             | P0           |
| TEST FREQUENCY | 1 kHz           | F21          | HEADER       | ON              | HR1          |
| RANGE          | AUTO            | R00          |              |                 |              |

Table 3-14. Functions of GP-IB Interface (Continued) (32/32)

**12. GP-IB Program Example**

An example of GP-IB interface control by NEC's PC-9801 series personal computer system is shown below.

This program shows basic procedures for remotely controlling the apparatus and reading output data.

**REMARKS**

For details on the GP-IB programming by the personal computer, refer to the instruction manual for the computer.

**<Program list>**

(GP-IB address of the AG-4311B: 3)

```

100  REM AG-4311B GP-IB CONTROL PROGRAM (FOR PC-9801)
110  ISET IFC
120  ISET REN
130  CMD DELIM = 0
140  CMD TIMEOUT = 5
150  PRINT@ 3;"T2, E"
160  LINE INPUT@ 3;A$
170  PRINT A$
180  WBYTE 3 + 32, 1;
190  IRESET REN
200  END

```

**<Output data example>**

```
PF21V3 N C 23.05000E-09, N D 0.00120E + 00
```

**<Explanation of the program list>**

Line 110 Transmission of IFC (interface clear)

Line 120 REN (remote enable) is set to true.

Line 130 Specification of a delimiter (CR + LF)

Line 140 Time-out specification

Line 150 Transmission of remote program codes T2 and E

Line 160 Data from the AG-4311B is stored in A\$.

Line 170 The contents of A\$ are displayed on the console.

Line 180 Transmission of a GTL (Go To Local) command

Line 190 REN is set to false.

### 3.20 ERROR INDICATION

If an improper key setting or erroneous sample connection is detected, an error indication appears on the main display. The meanings of the error indications are explained in Table 3-15. If an error indication is output, locate the cause by referring to the table and take proper corrective action.

Table 3-15. Error Indications

| MAIN DISPLAY | Explanation  |
|--------------|--|
| <i>Err01</i> | <ul style="list-style-type: none"> <li>● This indication appears if a residual parameter value is found to be beyond the limit value during offset adjustment in the open or short ADJ mode. If this error indication appears, the correction value is initialized to zero. (Offset adjustment in the open ADJ mode and that in short ADJ mode are independent of each other.)</li> </ul>  |
| <i>Err02</i> | <ul style="list-style-type: none"> <li>● This indication appears if either of the following reference value setting errors is committed; the presently valid reference value is retained.               <ul style="list-style-type: none"> <li>① Pressing the STORE key with the main display showing an OF or UF indication, or no measured value.</li> <li>② Pressing the STORE key with the deviation measurement mode (<math>\Delta</math> or <math>\Delta\%</math>) already set.</li> </ul> </li> </ul> |
| <i>Err03</i> | <ul style="list-style-type: none"> <li>● This indication appears if any of the following operation errors for deviation measurement is detected.               <ul style="list-style-type: none"> <li>① Specifying deviation measurement without any reference value set</li> <li>② Specifying <math>\Delta\%</math> mode with the reference value being 0.</li> </ul> </li> </ul>   |
| <i>Err04</i> | <ul style="list-style-type: none"> <li>● This indication appears if an operation error associated with the reference value or limit values (upper and lower limits).               <ul style="list-style-type: none"> <li>① An attempt is made to input a value outside the allowable range.</li> <li>② The lower limit is greater than the upper limit.</li> </ul> </li> </ul>  |
| <i>Err05</i> | <ul style="list-style-type: none"> <li>● This indication appears if a program error is detected during GP-IB interface operation, that is, if unprocessable data is given by the GP-IB interface.</li> </ul>   |
| <i>Err06</i> | <ul style="list-style-type: none"> <li>● This indication appears if the RANGE UP or DOWN key is pressed after the upper or lower measurement range limit is reached, or if a measuring range inconsistent with the set frequency is selected. If this indication appears, the nearest allowable range is automatically set.</li> </ul>   |
| <i>Err07</i> | <ul style="list-style-type: none"> <li>● This indication appears if an open circuit or a broken wire is detected in the measuring jigs (test fixture, leads, etc.) connected to the UNKNOWN terminals.</li> </ul>  |
| <i>Err08</i> | <ul style="list-style-type: none"> <li>● This indication appears if either of the following errors is committed for measurement by the use of an external frequency.               <ul style="list-style-type: none"> <li>① Making measurement with an external frequency signal connected to the apparatus but without any external frequency specified.</li> <li>② Specifying an external frequency outside the range of 1.6 kHz to 1.6 MHz.</li> </ul> </li> </ul>  |
| <i>Err09</i> | <ul style="list-style-type: none"> <li>● This indication appears if a control signal issued for the external frequency data interface is found improper.</li> </ul>  |

### 3.21 BASIC INSPECTION AND MAINTENANCE PROCEDURES

#### (1) Initial Indication and Memory Back-up Check

Immediately after power is initially turned on, the setting of the GP-IB address switch is shown on the main display. If TALK ONLY is OFF, the display *Ad-* is followed by the GP-IB address. If TALK ONLY is ON, nothing is displayed (the GP-IB status LED TALK comes on).

At the same time, a memory back-up check is made; if an abnormality is detected in the stored data, an error indication is shown on the sub display.

#### REMARKS

If a memory back-up error indication (*Err00*) is given, immediately replace the battery. (For the battery replacement procedure, refer to Appendix B.)

In the event of a memory back-up error, the apparatus is automatically set to the initial settings (shown in Table 3-16), so the apparatus may be used without installing a battery.

Table 3-16. Memory Back-up and Initial Settings

| No. | FUNCTION       | Memory back-up | Initial setting          | Remarks  |
|-----|----------------|----------------|--------------------------|--|
| 1   | PARAMETER      | ○              | C-D                      | <ul style="list-style-type: none"> <li>The mark x in the memory back-up column indicates that the initial value is set when power is turned on.</li> </ul> |
| 2   | CIRCUIT MODE   | ○              | AUTO                     |  |
| 3   | MEAS SPEED     | ○              | NORMAL                   |  |
| 4   | DEVIATION      | ○              | OFF                      |  |
| 5   | OSC LEVEL      | ○              | 1V                       |  |
| 6   | TEST FREQUENCY | ○              | 1kHz                     |  |
| 7   | RANGE          | ○              | AUTO                     |  |
| 8   | MEAS START     | ○              | AUTO                     |  |
| 9   | SIGNAL CHECK   | ○              | FREQUENCY                |  |
| 10  | SRQ READY      | x              | OFF                      |  |
| 11  | COMP ENABLE    | ○              | OFF                      |  |
| 12  | EXT DC BIAS    | x              | OFF                      |  |
| 13  | HEADER         | x              | ON                       |  |
| 14  | REF VALUE      | ○              | Not set                  |  |
| 15  | LIMIT VALUE    | ○              | Not set                  |  |
| 16  | EXT TEST FREQ  | ○              | Not set                  |  |
| 17  | OFFSET ADJ     | x              | Correction value cleared |  |

**(2) Self Test**

After the memory back-up check is made (or GP-IB remote program code Z is received), a self test is carried out.

The self test is a basic check made to ensure that the apparatus performs operations properly. Perform the following steps to check that the self test is normally made.

**① LED turn-on check**

All LEDs on the panel are lit for about 0.8 second. Visually check that all LEDs are on.

**② Main internal circuit operation check**

Six minus signs (-) are shown on the main display to indicate that a self diagnosis is started. The self diagnosis consists of six steps. First, the leftmost minus sign turns into 8, which means execution of step 1. After completion of step 1, the 8 display successively moves to the right and steps 2-6 are performed. If an abnormality is detected during the self diagnosis, the 8 display stays at the step in which the abnormality is found, an error indication is shown on the sub display, and the apparatus proceeds to the next step. The alarm displays in each step and their meanings are given in Table 3-17.

**REMARKS**

If an error indication is given during the main internal circuit operation test, make the following checks.

- (1) Check that the LEVEL FINE adjuster is set at MAX (the rightmost position).
- (2) Check that the EXT CONTROL connector on the rear panel is open.

If the same error indication is given immediately after power is turned on again, the apparatus may not operate properly.

Table 3-17. Self Test Error Indications

| Step | MAIN DISPLAY | SUB DISPLAY             | Function   |
|------|--------------|-------------------------|--|
| 1    | 8 - - - - -  | Err10                   | <ul style="list-style-type: none"> <li>A key open check of the front panel is made. If a key is held down or is faulty, this error indication is given.</li> </ul>   |
|      |              | Err11                   | <ul style="list-style-type: none"> <li>The <math>\overline{\text{EXT}\cdot\text{MST}}</math> signal at the rear panel EXT CONTROL connector is checked for openness. If the <math>\overline{\text{EXT}\cdot\text{MST}}</math> signal is at the "L" level (shorted or faulty), this error indication is given.</li> </ul> |
| 2    | - 8 - - - -  | Err20<br>Err21<br>Err22 | <ul style="list-style-type: none"> <li>The A/D converter is divided into three block and each block is checked for proper operation in the NORMAL MEAS SPEED mode. If an abnormality is detected in any of these blocks, an error indication is given.</li> </ul>  |
|      |              | Err23<br>Err24<br>Err25 | <ul style="list-style-type: none"> <li>The A/D converter is divided into three blocks and each block is checked for proper operation in the FAST MEAS SPEED mode. If an abnormality is detected in any of these blocks, an error indication is given.</li> </ul>   |
| 3    | - - 8 - - -  | Err30<br>Err31          | <ul style="list-style-type: none"> <li>The analog measuring section is divided into two blocks and each block is checked for proper gain control. If an abnormality is detected in any of these blocks, an error indication is given.</li> </ul>   |
| 4    | - - - 8 - -  | Err40<br>Err41          | <ul style="list-style-type: none"> <li>The analog measuring section is divided into two blocks and each block is checked for proper range operation. If an abnormality is detected in any of these blocks, an error indication is given.</li> </ul>  |
| 5    | - - - - 8 -  | Err50<br>Err51          | <ul style="list-style-type: none"> <li>The analog measuring section is divided into two blocks and each block is checked for proper ATT control. If an abnormality is detected in any of these blocks, an error indication is given.</li> </ul>  |
| 6    | - - - - - 8  |                         | (No Operation)   |

## (3) Periodic Inspection

Periodic inspections are effective in obtaining optimum performance from the apparatus throughout its life and finding the malfunctioning elements, if any, before a trouble occurs.

Inspection periods are determined according to the conditions of operation and storage.

The apparatus is designed and constructed to give long periods of stable and reliable service with a minimum amount of maintenance. However, it is recommended that periodic inspection be performed once or twice a year.

The procedures for making basic periodic inspections are shown in Table 3-18.

Table 3-18. Basic Periodic Inspections



| No. | Inspection Item       | Inspection Procedure  |
|-----|-----------------------|---|
| 1   | Self test             | This self test is performed immediately after power is turned on. Check that no error indication is given.  |
| 2   | Open connection check | <p>① Have on hand two about 10 cm-long coaxial cables with BNC plugs on both ends, and connect H<sub>CUR</sub> with H<sub>POT</sub> and L<sub>CUR</sub> with L<sub>POT</sub>, using these cables.</p> <p>② Set the measurement parameter to C-G, the measurement range to AUTO, the level range to 1 V, the measuring frequency to 1 kHz, and the LEVEL FINE adjuster to MAX.</p> <p>③ Check that the indications of C and G are about 0 pF and about 0 <math>\mu</math>S, respectively, in the AUTO MEAS START mode.</p> <p>④ Display the signal voltage and signal current on the check display, and check that the signal voltage is 1 V or more and the signal current is 0 mA.</p> <p>⑤ Make open ADJ and check that the adjustment is normally made.</p> <div style="text-align: center;">  <p style="text-align: center;">Coaxial cables with BNC plugs on both ends</p> </div> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p>REMARKS</p> <p>Open connection may be made by connecting no sample with the AG-4911 Test Fixture.</p> </div> |



Table 3-18. Basic Periodic Inspections (Continued)

| No. | Inspection Item        | Inspection Procedure   |
|-----|------------------------|--|
| 3   | Short connection check | <p>① Have on hand four about 10 cm-long coaxial cables with BNC plugs on both ends and two T-shaped adapters, and short all measuring terminals together, using these cables and adapters.</p> <p>② Set the measurement parameter to R-X, the measurement range to AUTO, the level range to 1 V, the measuring frequency to 1 kHz, and the LEVEL FINE adjuster to MAX.</p> <p>③ Check that the indications of both R and X are about 0 Ω in the AUTO MEAS START mode.</p> <p>④ Display the signal voltage and signal current on the check display, and check that the signal voltage is about 0 V and the signal current is about 20 mA or more.</p> <p>⑤ Make short ADJ and check that the adjustment is normally made.</p> <div style="text-align: center;">  <p style="text-align: center;"> <span style="margin-right: 100px;">T-shaped adapter A<br/>(e.g., BNC-TA-JPJ, UG-274/U)</span> <span>T-shaped adapter B<br/>(e.g., BNC-TA-JJJ)</span> </p> </div> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p style="text-align: center;">REMARKS</p> <p style="text-align: center;">Short adjustment may be made by inserting a low-impedance lead wire into the AG-4911 Test Fixture.</p> </div> |
| 4   | Measured value check   | <p>Measure a standard sample whose data is already known, and check the measured value.</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p style="text-align: center;">REMARKS</p> <p style="text-align: center;">Use a stable sample that varies little with temperature or time.</p> </div>   |

## (3) Troubleshooting

If it seems that the apparatus does not operate properly, locate and remove the cause of trouble, referring to Table 3-19.

## REMARKS

If the apparatus is obviously at fault, immediately turn power off, remove the power cord, and report the trouble and the serial number marked on the rear panel to your nearest Ando dealer for inspection and repair.

Table 3-19. Troubleshooting

| No. | Problem   | Remedy   |
|-----|---|--|
| 1   | Nothing is displayed even if the power switch is turned on.   | <ul style="list-style-type: none"> <li>• Check if the power cord is disconnected from the plug module or if the power cord is broken.</li> <li>• Check if the power fuse is blown.</li> </ul>  |
| 2   | The power fuse is blown.  | <ul style="list-style-type: none"> <li>• Check if the fuse is an appropriate one.</li> <li>• Check if the supply voltage is correct.</li> </ul>  |
| 3   | <i>Err00</i> is displayed when power is turned on.  | <ul style="list-style-type: none"> <li>• Replace the battery. (For the battery replacement procedure, refer to Appendix B.)</li> </ul>   |
| 4   | An error indication is given during self test.<br><i>Err 10</i><br><i>Err 11</i><br><i>Err 20</i><br>}<br><i>Err 51</i> | <ul style="list-style-type: none"> <li>• Check if a key is held down.</li> <li>• Check that the EXT CONTROL connector on the rear panel is open.</li> <li>• The apparatus is obviously at fault. Contact your local dealer to ask for repair.</li> </ul> |
| 5   | No measurement can be made even if a sample is connected, or an abnormal value is displayed.                            | <ul style="list-style-type: none"> <li>• Check the measuring jigs (test fixture, test leads, etc.) for abnormality.<br/>(Check for broken or shorted cables or poor contacts.)</li> </ul>  |
| 6   | No external DC bias voltage is developed at the H <sub>CUR</sub> terminal.  | <ul style="list-style-type: none"> <li>• Check if the fuse in the rear panel EXT DC BIAS section is blown.</li> </ul>  |

## Appendix A. Top Cover Removing Procedure

The PC board installed in the apparatus is equipped with a memory back-up battery and DIP switches. When the battery is to be replaced or the DIP switch settings are to be changed, remove the top cover and the internal shield cover, performing the following steps.

**CAUTION**


After the top cover and the internal shield cover is removed for battery replacement or DIP switch setting change, do not tamper with the internal circuitry of the apparatus except the specified portions.

- (1) Set the power switch to OFF, and remove the power cord.

**NOTE**


Before removing the cover, be sure to set the power switch to OFF and remove the power cord.

- (2) Loosen off the two rear panel cover stopper-retaining screws ①, and remove the cover stoppers.
- (3) Loosen off the top cover-retaining screw ②, and remove the top cover by sliding it toward the rear panel.



## Appendix A. Top Cover Removing Procedure (Continued)

- (4) When the top cover is removed, the internal shield cover is exposed to view. Loosen off the six internal shield cover-retaining screws ③, and remove the internal shield cover.



- (5) Replace the battery or change the DIP switch settings, referring to Appendix B or C.

**REMARKS**

For battery replacement, refer to Appendix B. For internal DIP switch setting change, refer to Appendix C.

- (6) Reinstall the internal shield cover.

**CAUTION**

When reinstalling the shield cover, be careful so that the coaxial cables for internal wiring may not be caught between the board shelf bend and the shield cover.



- (7) Reinstall the top cover and cover stoppers.

## Appendix B. Battery Replacement Procedure

The memory back-up battery is installed in the battery holder on the PC board P8 (PRE-409189) inside the apparatus. If the battery is obviously low on power (a memory back-up error indication (*Err00*) is displayed at all times), replace the battery, performing the following steps.

- (1) Remove the top cover and internal shield cover, performing the steps (1) through (4) given in Appendix A.
- (2) When the internal shield cover is removed, the PC board P8 is exposed to view. Its location is shown in the right figure.

The PC board P8 is of plug-in type. Slowly raise the card ejector to remove the PC board from the board shelf. While holding the card ejector with your fingers, draw out the PC board P8 from the board shelf.



## REMARKS

The battery is installed in the battery holder (BAT1) shown in the right figure.

- (3) Remove the battery by lifting the knob of the battery holder on the PC board P8.

## REMARKS


The battery slips out of the battery holder by lifting the battery holder knob with the card ejector facing downward.

## Appendix B Battery Replacement Procedure (Continued)

- (4) Have a new battery on hand, and install it into the battery holder with the "+" mark on the battery up.

## REMARKS

Battery used: CR2032 Lithium battery



## CAUTION

When installing the battery, be careful not to reverse the battery polarity.

- (5) Reinstall the PC board P8 into the board shelf.

## REMARKS

Align the PC board P8 with the board shelf slot, and push the PC board into the board shelf, while applying equal forces to the two card ejectors with your thumbs. After pushing the PC board into the board shelf, check if it is securely installed.

## CAUTION

The PC board P8 should be installed into the board shelf so that its component side may be on the righthand side (as viewed from the front panel). When inserting the PC board into the board shelf, use care not to apply excessive forces to the PC board.

- (6) Reinstall the internal shield cover and top cover, performing the steps (6) and (7) given in Appendix A.

### Appendix C Functions of the Internal DIP Switches

The PC boards P8 (PRE-409189) and P9 (PRE-409190) inside the apparatus are provided with DIP switches. By using these DIP switches, the PASS/NG tone frequency for comparator operation and key buzzer ON/OFF setting can be set.



To change the DIP switch settings, perform the following steps.

- (1) Remove the top cover and internal shield cover, performing the steps (1) through (4) given in Appendix A.
- (2) When the internal shield cover is removed, the PC boards P8 and P9 are exposed to view. Their locations are shown in the right figure.

The PC board P8 is provided with DIP switches S2 and S3, and the PC board P9 is provided with DIP switches S1 and S2. Their locations are shown in the lower right figure. (The figure is the one viewed from the top side of the board shelf.)


Before changing the DIP switch settings, the description of the DIP switch functions should be thoroughly read and understood.

- (3) After changing the settings, reinstall the internal shield cover and top cover, performing the steps (6) and (7) given in Appendix A.



Appendix C Functions of the Internal DIP Switches (Continued)

P8-S2



| Switch No. | Function   | Standard Setting |
|------------|--|------------------|
| SW1        |  | OFF              |
| SW2        | <ul style="list-style-type: none"> <li>EXT CONTROL connector PASS relay contact output</li> <li>OFF: Relay operation is performed.</li> <li>ON: No relay operation is performed (<math>\overline{\text{PASS}}</math> at all times).</li> </ul> | OFF              |
| SW3        |  | OFF              |
| SW4        |  | OFF              |
| SW5        |  | OFF              |
| SW6        |  | OFF              |
| SW7        |  | OFF              |
| SW8        |  | OFF              |



Appendix C Functions of the Internal DIP Switches (Continued)

P8-S3




SW 1 2 3 4 5 6 7 8 ----- Switch No.

| Switch No. | Function  | Standard Setting |        |               |           |     |     |     |               |     |     |    |        |     |    |     |        |     |    |    |       |    |     |     |        |    |     |    |       |    |    |     |       |    |    |    |        |     |
|------------|---|------------------|--------|---------------|-----------|-----|-----|-----|---------------|-----|-----|----|--------|-----|----|-----|--------|-----|----|----|-------|----|-----|-----|--------|----|-----|----|-------|----|----|-----|-------|----|----|----|--------|-----|
| SW1        | <ul style="list-style-type: none"> <li>Buzzer tone produced when the key is pushed.</li> <li>OFF: The buzzer sounds.</li> <li>ON : The buzzer does not sound.</li> </ul>  | OFF              |        |               |           |     |     |     |               |     |     |    |        |     |    |     |        |     |    |    |       |    |     |     |        |    |     |    |       |    |    |     |       |    |    |    |        |     |
| SW2        | <ul style="list-style-type: none"> <li>Buzzer tone produced when an external measurement start signal is received</li> <li>OFF: The buzzer sounds.</li> <li>ON : The buzzer does not sound.</li> </ul>  | OFF              |        |               |           |     |     |     |               |     |     |    |        |     |    |     |        |     |    |    |       |    |     |     |        |    |     |    |       |    |    |     |       |    |    |    |        |     |
| SW3        | <ul style="list-style-type: none"> <li>Frequency of the PASS tone from the loudspeaker</li> </ul> <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>SW3</th> <th>SW4</th> <th>SW5</th> <th>Frequency</th> </tr> </thead> <tbody> <tr> <td>OFF</td> <td>OFF</td> <td>OFF</td> <td>OFF (No tone)</td> </tr> <tr> <td>OFF</td> <td>OFF</td> <td>ON</td> <td>500 Hz</td> </tr> <tr> <td>OFF</td> <td>ON</td> <td>OFF</td> <td>800 Hz</td> </tr> <tr> <td>OFF</td> <td>ON</td> <td>ON</td> <td>1 kHz</td> </tr> <tr> <td>ON</td> <td>OFF</td> <td>OFF</td> <td>1.5kHz</td> </tr> <tr> <td>ON</td> <td>OFF</td> <td>ON</td> <td>2 kHz</td> </tr> <tr> <td>ON</td> <td>ON</td> <td>OFF</td> <td>3 kHz</td> </tr> <tr> <td>ON</td> <td>ON</td> <td>ON</td> <td>3.4kHz</td> </tr> </tbody> </table> | SW3              | SW4    | SW5           | Frequency | OFF | OFF | OFF | OFF (No tone) | OFF | OFF | ON | 500 Hz | OFF | ON | OFF | 800 Hz | OFF | ON | ON | 1 kHz | ON | OFF | OFF | 1.5kHz | ON | OFF | ON | 2 kHz | ON | ON | OFF | 3 kHz | ON | ON | ON | 3.4kHz | ON  |
| SW3        |   | SW4              | SW5    | Frequency     |           |     |     |     |               |     |     |    |        |     |    |     |        |     |    |    |       |    |     |     |        |    |     |    |       |    |    |     |       |    |    |    |        |     |
| OFF        |   | OFF              | OFF    | OFF (No tone) |           |     |     |     |               |     |     |    |        |     |    |     |        |     |    |    |       |    |     |     |        |    |     |    |       |    |    |     |       |    |    |    |        |     |
| OFF        |   | OFF              | ON     | 500 Hz        |           |     |     |     |               |     |     |    |        |     |    |     |        |     |    |    |       |    |     |     |        |    |     |    |       |    |    |     |       |    |    |    |        |     |
| OFF        |   | ON               | OFF    | 800 Hz        |           |     |     |     |               |     |     |    |        |     |    |     |        |     |    |    |       |    |     |     |        |    |     |    |       |    |    |     |       |    |    |    |        |     |
| OFF        |   | ON               | ON     | 1 kHz         |           |     |     |     |               |     |     |    |        |     |    |     |        |     |    |    |       |    |     |     |        |    |     |    |       |    |    |     |       |    |    |    |        |     |
| ON         |   | OFF              | OFF    | 1.5kHz        |           |     |     |     |               |     |     |    |        |     |    |     |        |     |    |    |       |    |     |     |        |    |     |    |       |    |    |     |       |    |    |    |        |     |
| ON         | OFF   | ON               | 2 kHz  |               |           |     |     |     |               |     |     |    |        |     |    |     |        |     |    |    |       |    |     |     |        |    |     |    |       |    |    |     |       |    |    |    |        |     |
| ON         | ON  | OFF              | 3 kHz  |               |           |     |     |     |               |     |     |    |        |     |    |     |        |     |    |    |       |    |     |     |        |    |     |    |       |    |    |     |       |    |    |    |        |     |
| ON         | ON  | ON               | 3.4kHz |               |           |     |     |     |               |     |     |    |        |     |    |     |        |     |    |    |       |    |     |     |        |    |     |    |       |    |    |     |       |    |    |    |        |     |
| SW4        | ← Standard setting  | OFF              |        |               |           |     |     |     |               |     |     |    |        |     |    |     |        |     |    |    |       |    |     |     |        |    |     |    |       |    |    |     |       |    |    |    |        |     |
| SW5        | ← Standard setting  | ON               |        |               |           |     |     |     |               |     |     |    |        |     |    |     |        |     |    |    |       |    |     |     |        |    |     |    |       |    |    |     |       |    |    |    |        |     |
| SW6        | <ul style="list-style-type: none"> <li>Frequency of the NG tone from the loudspeaker</li> </ul> <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>SW6</th> <th>SW7</th> <th>SW8</th> <th>Frequency</th> </tr> </thead> <tbody> <tr> <td>OFF</td> <td>OFF</td> <td>OFF</td> <td>OFF (No tone)</td> </tr> <tr> <td>OFF</td> <td>OFF</td> <td>ON</td> <td>500 Hz</td> </tr> <tr> <td>OFF</td> <td>ON</td> <td>OFF</td> <td>800 Hz</td> </tr> <tr> <td>OFF</td> <td>ON</td> <td>ON</td> <td>1 kHz</td> </tr> <tr> <td>ON</td> <td>OFF</td> <td>OFF</td> <td>1.5kHz</td> </tr> <tr> <td>ON</td> <td>OFF</td> <td>ON</td> <td>2 kHz</td> </tr> <tr> <td>ON</td> <td>ON</td> <td>OFF</td> <td>3 kHz</td> </tr> <tr> <td>ON</td> <td>ON</td> <td>ON</td> <td>3.4kHz</td> </tr> </tbody> </table>   | SW6              | SW7    | SW8           | Frequency | OFF | OFF | OFF | OFF (No tone) | OFF | OFF | ON | 500 Hz | OFF | ON | OFF | 800 Hz | OFF | ON | ON | 1 kHz | ON | OFF | OFF | 1.5kHz | ON | OFF | ON | 2 kHz | ON | ON | OFF | 3 kHz | ON | ON | ON | 3.4kHz | OFF |
| SW6        |   | SW7              | SW8    | Frequency     |           |     |     |     |               |     |     |    |        |     |    |     |        |     |    |    |       |    |     |     |        |    |     |    |       |    |    |     |       |    |    |    |        |     |
| OFF        |   | OFF              | OFF    | OFF (No tone) |           |     |     |     |               |     |     |    |        |     |    |     |        |     |    |    |       |    |     |     |        |    |     |    |       |    |    |     |       |    |    |    |        |     |
| OFF        |   | OFF              | ON     | 500 Hz        |           |     |     |     |               |     |     |    |        |     |    |     |        |     |    |    |       |    |     |     |        |    |     |    |       |    |    |     |       |    |    |    |        |     |
| OFF        |   | ON               | OFF    | 800 Hz        |           |     |     |     |               |     |     |    |        |     |    |     |        |     |    |    |       |    |     |     |        |    |     |    |       |    |    |     |       |    |    |    |        |     |
| OFF        |   | ON               | ON     | 1 kHz         |           |     |     |     |               |     |     |    |        |     |    |     |        |     |    |    |       |    |     |     |        |    |     |    |       |    |    |     |       |    |    |    |        |     |
| ON         |   | OFF              | OFF    | 1.5kHz        |           |     |     |     |               |     |     |    |        |     |    |     |        |     |    |    |       |    |     |     |        |    |     |    |       |    |    |     |       |    |    |    |        |     |
| ON         | OFF   | ON               | 2 kHz  |               |           |     |     |     |               |     |     |    |        |     |    |     |        |     |    |    |       |    |     |     |        |    |     |    |       |    |    |     |       |    |    |    |        |     |
| ON         | ON  | OFF              | 3 kHz  |               |           |     |     |     |               |     |     |    |        |     |    |     |        |     |    |    |       |    |     |     |        |    |     |    |       |    |    |     |       |    |    |    |        |     |
| ON         | ON  | ON               | 3.4kHz |               |           |     |     |     |               |     |     |    |        |     |    |     |        |     |    |    |       |    |     |     |        |    |     |    |       |    |    |     |       |    |    |    |        |     |
| SW7        | ← Standard setting  | OFF              |        |               |           |     |     |     |               |     |     |    |        |     |    |     |        |     |    |    |       |    |     |     |        |    |     |    |       |    |    |     |       |    |    |    |        |     |
| SW8        | ← Standard setting  | ON               |        |               |           |     |     |     |               |     |     |    |        |     |    |     |        |     |    |    |       |    |     |     |        |    |     |    |       |    |    |     |       |    |    |    |        |     |

Appendix C Functions of the Internal DIP Switches (Continued)

P9-S1




REMARKS: P9-S1 consists of a switch for selecting either the unit (UNIT)/decimal point (DP) internal setting mode or the external setting mode (EXT TEST FREQ DATA connector) for the external frequency data interface, and switches for internal setting of a unit and decimal point.

| Switch No.   | Function   | Standard Setting |     |                        |                        |    |    |    |     |     |    |    |     |                |     |    |     |     |     |    |     |    |    |     |     |     |    |     |     |                |  |  |     |    |
|--|--|------------------|-----|------------------------|------------------------|----|----|----|-----|-----|----|----|-----|----------------|-----|----|-----|-----|-----|----|-----|----|----|-----|-----|-----|----|-----|-----|----------------|--|--|-----|----|
| SW1  | <ul style="list-style-type: none"> <li>Unit data external setting/internal setting selection</li> <li>OFF: EXT (By UTD0-UTD2 signals through the EXT TEST FREQ DATA connector)</li> <li>ON: INT (By the settings of SW2-SW4)</li> </ul>  | OFF              |     |                        |                        |    |    |    |     |     |    |    |     |                |     |    |     |     |     |    |     |    |    |     |     |     |    |     |     |                |  |  |     |    |
| SW2  | <ul style="list-style-type: none"> <li>Unit data internal setting</li> </ul> <table border="1"> <thead> <tr> <th>SW2</th> <th>SW3</th> <th>SW4</th> <th>Unit</th> </tr> </thead> <tbody> <tr> <td>ON</td> <td>ON</td> <td>ON</td> <td>Hz</td> </tr> <tr> <td>OFF</td> <td>ON</td> <td>ON</td> <td>kHz</td> </tr> <tr> <td colspan="3">Other settings</td> <td>kHz</td> </tr> </tbody> </table>   | SW2              | SW3 | SW4                    | Unit                   | ON | ON | ON | Hz  | OFF | ON | ON | kHz | Other settings |     |    | kHz | ON  |     |    |     |    |    |     |     |     |    |     |     |                |  |  |     |    |
| SW2  |  | SW3              | SW4 | Unit                   |                        |    |    |    |     |     |    |    |     |                |     |    |     |     |     |    |     |    |    |     |     |     |    |     |     |                |  |  |     |    |
| ON   |  | ON               | ON  | Hz                     |                        |    |    |    |     |     |    |    |     |                |     |    |     |     |     |    |     |    |    |     |     |     |    |     |     |                |  |  |     |    |
| OFF  | ON   | ON               | kHz |                        |                        |    |    |    |     |     |    |    |     |                |     |    |     |     |     |    |     |    |    |     |     |     |    |     |     |                |  |  |     |    |
| Other settings   |  |                  | kHz |                        |                        |    |    |    |     |     |    |    |     |                |     |    |     |     |     |    |     |    |    |     |     |     |    |     |     |                |  |  |     |    |
| SW3  | ← Standard setting   | ON               |     |                        |                        |    |    |    |     |     |    |    |     |                |     |    |     |     |     |    |     |    |    |     |     |     |    |     |     |                |  |  |     |    |
| SW4  |  | ON               |     |                        |                        |    |    |    |     |     |    |    |     |                |     |    |     |     |     |    |     |    |    |     |     |     |    |     |     |                |  |  |     |    |
| SW5  | <ul style="list-style-type: none"> <li>Decimal point data external setting/internal setting selection</li> <li>OFF: EXT (By DPD0-DPD2 signals through the EXT TEST FREQ DATA connector)</li> <li>ON: INT (By the settings of SW6-SW8)</li> </ul>   | OFF              |     |                        |                        |    |    |    |     |     |    |    |     |                |     |    |     |     |     |    |     |    |    |     |     |     |    |     |     |                |  |  |     |    |
| SW6  | <ul style="list-style-type: none"> <li>Decimal point data internal setting</li> </ul> <table border="1"> <thead> <tr> <th>SW6</th> <th>SW7</th> <th>SW8</th> <th>Decimal point position</th> </tr> </thead> <tbody> <tr> <td>ON</td> <td>ON</td> <td>ON</td> <td>DP0</td> </tr> <tr> <td>OFF</td> <td>ON</td> <td>ON</td> <td>DP1</td> </tr> <tr> <td>ON</td> <td>OFF</td> <td>ON</td> <td>DP2</td> </tr> <tr> <td>OFF</td> <td>OFF</td> <td>ON</td> <td>DP3</td> </tr> <tr> <td>ON</td> <td>ON</td> <td>OFF</td> <td>DP4</td> </tr> <tr> <td>OFF</td> <td>ON</td> <td>OFF</td> <td>DP5</td> </tr> <tr> <td colspan="3">Other settings</td> <td>DP5</td> </tr> </tbody> </table> | SW6              | SW7 | SW8                    | Decimal point position | ON | ON | ON | DP0 | OFF | ON | ON | DP1 | ON             | OFF | ON | DP2 | OFF | OFF | ON | DP3 | ON | ON | OFF | DP4 | OFF | ON | OFF | DP5 | Other settings |  |  | DP5 | ON |
| SW6  |  | SW7              | SW8 | Decimal point position |                        |    |    |    |     |     |    |    |     |                |     |    |     |     |     |    |     |    |    |     |     |     |    |     |     |                |  |  |     |    |
| ON   |  | ON               | ON  | DP0                    |                        |    |    |    |     |     |    |    |     |                |     |    |     |     |     |    |     |    |    |     |     |     |    |     |     |                |  |  |     |    |
| OFF  |  | ON               | ON  | DP1                    |                        |    |    |    |     |     |    |    |     |                |     |    |     |     |     |    |     |    |    |     |     |     |    |     |     |                |  |  |     |    |
| ON   |  | OFF              | ON  | DP2                    |                        |    |    |    |     |     |    |    |     |                |     |    |     |     |     |    |     |    |    |     |     |     |    |     |     |                |  |  |     |    |
| OFF  |  | OFF              | ON  | DP3                    |                        |    |    |    |     |     |    |    |     |                |     |    |     |     |     |    |     |    |    |     |     |     |    |     |     |                |  |  |     |    |
| ON   | ON   | OFF              | DP4 |                        |                        |    |    |    |     |     |    |    |     |                |     |    |     |     |     |    |     |    |    |     |     |     |    |     |     |                |  |  |     |    |
| OFF  | ON   | OFF              | DP5 |                        |                        |    |    |    |     |     |    |    |     |                |     |    |     |     |     |    |     |    |    |     |     |     |    |     |     |                |  |  |     |    |
| Other settings   |  |                  | DP5 |                        |                        |    |    |    |     |     |    |    |     |                |     |    |     |     |     |    |     |    |    |     |     |     |    |     |     |                |  |  |     |    |
| SW7  | ← Standard setting   | ON               |     |                        |                        |    |    |    |     |     |    |    |     |                |     |    |     |     |     |    |     |    |    |     |     |     |    |     |     |                |  |  |     |    |
| SW8  |  | ON               |     |                        |                        |    |    |    |     |     |    |    |     |                |     |    |     |     |     |    |     |    |    |     |     |     |    |     |     |                |  |  |     |    |
| REMARKS: For decimal point positions DP0-DP5, refer to Table 3-12 Functions of the External Frequency Interface. |  |                  |     |                        |                        |    |    |    |     |     |    |    |     |                |     |    |     |     |     |    |     |    |    |     |     |     |    |     |     |                |  |  |     |    |

Appendix C Functions of the Internal DIP Switches (Continued)

P9-S2



| Switch No. | Function  | Standard Setting |
|------------|---|------------------|
| SW1        | GP-IB exponent part output data in the $\Delta\%$ mode<br>OFF: $\Delta$ PER ( $\Delta$ : Indicates a space.)<br>ON : E+00 | OFF              |
| SW2        | /   | OFF              |
| SW3        | /   | OFF              |
| SW4        | /   | OFF              |
| SW5        | /   | OFF              |
| SW6        | /   | OFF              |
| SW7        | /   | OFF              |
| SW8        | /   | OFF              |

MEMO:

Table 1. List of Standard Accessories

| No. | Accessory Name             | Qty              | Remarks   |
|-----|----------------------------|------------------|---|
| 1   | Power cord                 | 1                | About 2.8 m in length   |
| 2   | Voltage conversion adapter | 1* <sup>1</sup>  | For 3-pole/2-pole conversion For 100/120 VAC                                |
| 3   | Power fuse                 | 2** <sup>2</sup> | 1 A (for 100/120 VAC) or 0.5 A (for 220/240 VAC)<br>1 installed, 1 reserved |
| 4   | DC bias fuse               | 1                | 0.1 A (for DC biasing)<br>1 installed, 1 reserved                           |
| 5   | 57-30140 connector         | 1                | For the external control interface  |
| 6   | 57-30500 connector         | 1                | For the external frequency data interface                                   |
| 7   | Instruction manual         | 1                |   |
|     |                            |                  |   |

## NOTES

\*1 Supplied when the power cord is of UL-3P type.

\*2 A 1A fuse is supplied when the supply voltage is 100 or 120 VAC, and a 0.5A fuse is supplied when the supply voltage is 220 or 240 V.

(The spare power fuse is installed in the fuse holder in the AC line connector module.)

134




Fig. 1 Front Panel View of AG-4311B LCR METER

135






Fig. 2 Rear Panel View of AG-4311B LCR METER


281




Top View



Rear View



Front View



Side View

Fig. 3 Outside View of AG-4311B LCR METER



**NOTES**

- (1) No part of this manual shall be reproduced without permission from Ando Electric.
- (2) The contents of this manual are subject to change without prior notice.
- (3) Reasonable efforts have been taken in the preparation of this manual to assure its accuracy. However, if you find an error or omission in the manual or if you have any question on its contents, contact your Ando dealer.
- (4) Ando Electric assumes no liability resulting from any errors or omissions in the manual or from the use of the information contained herein.

|                                   |                            |
|-----------------------------------|----------------------------|
| Serial No.                        | AS-7074                    |
| Date of Issue                     | Sept. 1990 (First edition) |
| Edited by Ando Electric Co., Ltd. |                            |

(All Rights Reserved.)