

MD1260A 40/100G Ethernet Analyzer Remote Control Operation Manual

Sixth Edition


- For safety and warning information, please read this manual before attempting to use the equipment.
- Additional safety and warning information is provided within the MD1260A 40/100G Ethernet Analyzer Operation Manual. Please also refer to this document before using the equipment.
- Keep this manual with the equipment.


ANRITSU CORPORATION


Safety Symbols

To prevent the risk of personal injury or loss related to equipment malfunction, Anritsu Corporation uses the following safety symbols to indicate safety-related information. Ensure that you clearly understand the meanings of the symbols BEFORE using the equipment. Some or all of the following symbols may be used on all Anritsu equipment. In addition, there may be other labels attached to products that are not shown in the diagrams in this manual.

Symbols used in manual

 **DANGER** This indicates a very dangerous procedure that could result in serious injury or death if not performed properly.

 **WARNING** This indicates a hazardous procedure that could result in serious injury or death if not performed properly.

 **CAUTION** This indicates a hazardous procedure or danger that could result in light-to-severe injury, or loss related to equipment malfunction, if proper precautions are not taken.

Safety Symbols Used on Equipment and in Manual

The following safety symbols are used inside or on the equipment near operation locations to provide information about safety items and operation precautions. Ensure that you clearly understand the meanings of the symbols and take the necessary precautions BEFORE using the equipment.



This indicates a prohibited operation. The prohibited operation is indicated symbolically in or near the barred circle.



This indicates an obligatory safety precaution. The obligatory operation is indicated symbolically in or near the circle.



This indicates a warning or caution. The contents are indicated symbolically in or near the triangle.



This indicates a note. The contents are described in the box.



These indicate that the marked part should be recycled.

MD1260A
40/100G Ethernet Analyzer
Remote Control Operation Manual

14 July 2010 (First Edition)
5 November 2012 (Sixth Edition)

Copyright © 2010-2012, ANRITSU CORPORATION.

All rights reserved. No part of this manual may be reproduced without the prior written permission of the publisher.

The contents of this manual may be changed without prior notice.

Printed in Japan

Notes On Export Management


This product and its manuals may require an Export License/Approval by the Government of the product's country of origin for re-export from your country.

Before re-exporting the product or manuals, please contact us to confirm whether they are export-controlled items or not.

When you dispose of export-controlled items, the products/manuals need to be broken/shredded so as not to be unlawfully used for military purpose.

About This Manual

The manuals for the MD1260A 40/100G Ethernet Analyzer are configured in two parts.



This manual explains the remote control commands. For the connection of the power source and peripheral devices, panel operation, and maintenance, refer to the following manual, refer to the MD1260A 40/100G Ethernet Analyzer Operation Manual (W3406AE).

This operation manual assumes the reader has the following information:

- The reader has read through the MD1260A 40/100G Ethernet Analyzer Operation Manual.
- The reader can create the C or Basic program.

Table of Contents

Safety Symbols	ii
About This Manual.....	I
Chapter 1 Outline	1-1
1.1 About Remote Control	1-2
1.2 Main Uses for Remote Control	1-3
1.3 Abbreviation	1-4
Chapter 2 Before Use.....	2-1
2.1 Preparing Equipment	2-2
2.2 Connecting Equipment	2-3
2.3 Setting Interface.....	2-7
2.4 Checking Connection.....	2-11
2.5 Message Format.....	2-17
2.6 Checking Instrument Status.....	2-21
2.7 Confirming Message Execution Status.....	2-26
2.8 Remote Control When Operating Multiport Function.	2-27
Chapter 3 Message Details.....	3-1
3.1 Description of Message Explanations	3-2
3.2 Correspondence between Panel Operation and Messages.....	3-4
3.3 Device Message Details	3-44
Chapter 4 Operation Record Function	4-1
4.1 Outline of Operation Record Function	4-2
4.2 Starting/Stopping Operation Record Function.....	4-3

Appendix A Message Compatibility		
.....	A-1	
Appendix B Message Codes.....		B-1
Appendix C Change Information on Command		C-1
Appendix D Correspondence between Application and Command		D-1
Appendix E Sample Program		E-1
Index		Index-1

1
2
3
4
Appendix
Index

Table of Commands

*CLS [Clear Status]	3-44
*ESE [Event Status Enable]	3-45
*ESR [Standard Event Status Register]	3-46
*IDN [Identification]	3-46
*OPC [Operation Complete]	3-47
*RST [Reset]	3-48
*SRE [Service Request Enable]	3-49
*STB [Status Byte]	3-49
*TRG [Trigger]	3-50
*WAI [Wait to Continue]	3-50
:CALCulate:APS:ERRor:FREE	3-51
:CALCulate:APS:START[:AUNit]	3-51
:CALCulate:APS:START:EVENT[:AUNit]	3-52
:CALCulate:APS:STATus[:AUNit]	3-52
:CALCulate:APS:STOP[:AUNit]	3-53
:CALCulate:APS:TRIGger	3-53
:CALCulate:CAPTure:DATA	3-54
:CALCulate:CAPTure:DATA:RXC	3-55
:CALCulate:CAPTure:DATA:RXD	3-56
:CALCulate:CAPTure:DATA:SIZE	3-57
:CALCulate:CAPTure:DATA:TRIGger:POSition	3-57
:CALCulate:CAPTure:START	3-58
:CALCulate:CAPTure:START:EVENT	3-58
:CALCulate:CAPTure:STATus	3-59
:CALCulate:CAPTure:STOP	3-60
:CALCulate:CAPTure:TRIGger	3-60
:CALCulate:CAPTure:TRIGger:MANual	3-61
:CALCulate:CAPTure:TRIGger:POSition	3-61
:CALCulate:CAPTure:TRIGger:TYPE	3-62
:CALCulate:CAPTure:TYPE	3-63
:CALCulate:COUNter:ETHER:OVERsize	3-64
:CALCulate:COUNter:FLOW:FIELd	3-64
:CALCulate:COUNter:FLOW:FIELd:ID	3-67
:CALCulate:COUNter:FLOW:FIELd:Nfid	3-68
:CALCulate:COUNter:FLOW:TYPE	3-68
:CALCulate:COUNter:GAP	3-69
:CALCulate:COUNter:SERRor	3-69
:CALCulate:COUNter:START[:AUNit]	3-70
:CALCulate:COUNter:START:EVENT[:AUNit]	3-70

:CALCulate:COUNter:STATus[:AUNit]	3-71
:CALCulate:COUNter:STOP[:AUNit].....	3-71
:CALCulate:DATA	3-72
:CALCulate:DATA:TYPE.....	3-73
:CALCulate:DElay:STARt[:AUNit].....	3-73
:CALCulate:DElay:STARt:EVENT[:AUNit].....	3-74
:CALCulate:DElay:STATus[:AUNit]	3-74
:CALCulate:DElay:STOP[:AUNit].....	3-75
:CALCulate:EALarm[:AUNit]	3-75
:CALCulate:MONitor:OTU:COLumn	3-76
:CALCulate:MONitor:OTU:DATA	3-76
:CALCulate:MONitor:OTU:TYPE	3-79
:CALCulate:TRIGger:CONDition.....	3-80
:MDIO:READ	3-81
:MDIO:WRITe.....	3-81
:MMEMory:CATalog.....	3-82
:MMEMory:INITialize.....	3-83
:MMEMory:LOG:FNAME	3-84
:MMEMory:LOG:ITEM.....	3-84
:MMEMory:LOG:PREFix	3-85
:MMEMory:LOG:STARt.....	3-85
:MMEMory:LOG:STATus	3-86
:MMEMory:LOG:STOP	3-86
:MMEMory:LOG:TIMing	3-87
:MMEMory:RECall[:AUNit]	3-88
:MMEMory:STORE[:AUNit]	3-89
:MMEMory:STORE:CAPTure	3-90
:MMEMory:STORE:CAPTure:ITEM	3-90
:MMEMory:STReam:RECall	3-91
:PROTOcol:ARPNs:REPLy:ENABle	3-92
:PROTOcol:GARPNs:DURation:TYPE	3-93
:PROTOcol:GARPNs:ENABle	3-94
:PROTOcol:GARPNs:INTerval.....	3-94
:PROTOcol:GARPNs:STARt.....	3-95
:PROTOcol:GARPNs:STATus	3-95
:PROTOcol:GARPNs:STOP.....	3-95
:PROTOcol:GARPNs:TYPE	3-96
:PROTOcol:PING:COUNT.....	3-96

1
2
3
4
Appendix
Index

:PROTOcol:PING:DST:IPV4	3-97
:PROTOcol:PING:DST:IPV6	3-97
:PROTOcol:PING:DST:MAC	3-98
:PROTOcol:PING:IPMode	3-98
:PROTOcol:PING:MACResolve	3-99
:PROTOcol:PING:PAYLoad	3-99
:PROTOcol:PING:PSIZE:TYPE	3-100
:PROTOcol:PING:PSIZE:VALUe	3-100
:PROTOcol:PING:REPLy:ENABle	3-101
:PROTOcol:PING:RESUlt	3-102
:PROTOcol:PING:SRC:IPV4	3-103
:PROTOcol:PING:SRC:IPV6	3-103
:PROTOcol:PING:SRC:MAC	3-104
:PROTOcol:PING:STARt	3-104
:PROTOcol:PING:STARt:EVENT	3-104
:PROTOcol:PING:STATus	3-105
:PROTOcol:PING:STOP	3-105
:PROTOcol:PING:TIMEout	3-106
:PROTOcol:PING:VLAN	3-106
:ROUte:BERT	3-107
:ROUte:ETHer:NEGotiatiOn:AUTO	3-107
:ROUte:FCONtrol	3-108
:ROUte:LFS:REPLy	3-108
:ROUte:MODE	3-109
:ROUte:MODE:THROugh:OVERwrite:RANGe	3-110
:ROUte:MODE:THROugh:TYPE	3-111
:ROUte:MPLStp:CWORD	3-111
:ROUte:VLAN:NUM	3-112
:ROUte:VLAN:VALue	3-112
:SENSe:MAPPing	3-113
:SENSe:ODTU:MAIN:DETECT	3-113
:SENSe:ODTU:MAIN:TS	3-114
:SENSe:OTN:FEC	3-115
:SENSe:PLM[:L]:PATTern	3-115
:SENSe:TIM:{SM PM[:L] TCM{1 2 3 4 5 6}}	3-116
:SENSe:TIM:{SM PM[:L] TCM{1 2 3 4 5 6}}:PATTern:{DAPI SAPI}	3-117
:SENSe:TPATTern:INVert	3-118
:SENSe:TPATTern:TYPE	3-119
:SENSe:TPATTern:WORD	3-120
:SENSe:TRANsceiver:EQUalizer:CONtrol	3-121
:SENSe:TRANsceiver:EQUalizer:DCGain	3-121

:SOURce:CFP:OPTical:OFF	3-122
:SOURce:CFP:OPTical:ON	3-122
:SOURce:CFP:OPTical:STATus	3-122
:SOURce:CLOCK	3-123
:SOURce:CLOCK:FREQuency:OFFSet	3-124
:SOURce:CLOCK:OUTPut:DIVide	3-124
:SOURce:CLOCK:OUTPut:M10	3-125
:SOURce:CLOCK:PAYLoad:OFFSet[:L]	3-126
:SOURce:EALarm:BIT	3-127
:SOURce:EALarm:FAS:EXCLude	3-128
:SOURce:EALarm:LANE	3-129
:SOURce:EALarm:STARt[:AUNit]	3-129
:SOURce:EALarm:STARt:EVENT[:AUNit]	3-130
:SOURce:EALarm:STATus[:AUNit]	3-130
:SOURce:EALarm:STOP[:AUNit]	3-131
:SOURce:EALarm:SUBRow	3-131
:SOURce:EALarm:TIMing:BURSt	3-132
:SOURce:EALarm:TIMing:ERRor	3-132
:SOURce:EALarm:TIMing:NORMal	3-133
:SOURce:EALarm:TIMing:RATE	3-134
:SOURce:EALarm:TIMing:TYPE	3-135
:SOURce:EALarm:TYPE	3-136
:SOURce:GFP:CSF:REPLacement	3-139
:SOURce:GFP:{PTI UPI}	3-140
:SOURce:MAPPing	3-140
:SOURce:MAPPing:LANE	3-142
:SOURce:ODTU:DUMMy:PATtern	3-143
:SOURce:ODTU:MAIN:TP	3-143
:SOURce:ODTU:MAIN:TS	3-144
:SOURce:OTN:FEC	3-145
:SOURce:OTN:OH[:L]	3-145
:SOURce:SKEW:BIT	3-146
:SOURce:SKEW:LANE	3-146
:SOURce:SKEW:NS	3-147
:SOURce:SKEW:TYPE	3-147
:SOURce:STReam:BURSt:CONTRol:VALue	3-148
:SOURce:STReam:BURSt:ENABLE	3-148
:SOURce:STReam:BURSt:SIZE	3-149
:SOURce:STReam:CONTRol:RANGe	3-149
:SOURce:STReam:CONTRol:TYPE	3-150

1
2
3
4
Appendix
Index

:SOURce:STReam:CONTRol:VALue.....	3-151
:SOURce:STReam:COUNt.....	3-151
:SOURce:STReam:DURation:FRAMES.....	3-152
:SOURce:STReam:DURation:REPeat:COUNt.....	3-152
:SOURce:STReam:DURation:TYPE.....	3-153
:SOURce:STReam:ENABle.....	3-154
:SOURce:STReam:ERRor:TYPE.....	3-154
:SOURce:STReam:FSIZe.....	3-155
:SOURce:STReam:FSIZe:RANGe.....	3-155
:SOURce:STReam:FSIZe:TYPE.....	3-156
:SOURce:STReam:FSIZe:VALue.....	3-157
:SOURce:STReam:HEADer.....	3-158
:SOURce:STReam:HEADer:ETHer:DA.....	3-160
:SOURce:STReam:HEADer:ETHer:SA.....	3-160
:SOURce:STReam:HEADer:ETHer:TYPE.....	3-161
:SOURce:STReam:HEADer:PATTern.....	3-162
:SOURce:STReam:HEADer:VARiable1:RANGe.....	3-163
:SOURce:STReam:HEADer:VARiable1:TYPE.....	3-164
:SOURce:STReam:HEADer:VARiable2:RANGe.....	3-164
:SOURce:STReam:HEADer:VARiable2:TYPE.....	3-165
:SOURce:STReam:HEADer:VARiable{3 4 5}.....	3-166
:SOURce:STReam:ID.....	3-169
:SOURce:STReam:RESolve:IP:TARGeT.....	3-170
:SOURce:STReam:RESolve:IPV4:ROUTer.....	3-170
:SOURce:STReam:RESolve:IPV6:ROUTer.....	3-171
:SOURce:STReam:RESolve:MAC:RETRY.....	3-171
:SOURce:STReam:RESolve:MAC:TIMEout.....	3-172
:SOURce:STReam:RESolve:PING:TRY.....	3-172
:SOURce:STReam:RESolve:PING:PAYLoad.....	3-173
:SOURce:STReam:RESolve:PING:TIMEout.....	3-173
:SOURce:STReam:RESolve:RESult.....	3-174
:SOURce:STReam:RESolve:START.....	3-175
:SOURce:STReam:RESolve:START:EVENT.....	3-175
:SOURce:STReam:RESolve:STATus.....	3-176
:SOURce:STReam:RESolve:STOP.....	3-176
:SOURce:STReam:RESolve:TYPE.....	3-177
:SOURce:STReam:START[:AUNit].....	3-178
:SOURce:STReam:START:EVENT[:AUNit].....	3-178
:SOURce:STReam:STATus[:AUNit].....	3-179
:SOURce:STReam:STOP[:AUNit].....	3-179
:SOURce:STReam:TFRame:ENABle.....	3-180
:SOURce:STReam:TFRame:FID.....	3-180
:SOURce:STReam:TYPE.....	3-181
:SOURce:TPATTern:INVert.....	3-181

:SOURce:TPATtern:TYPE	3-182
:SOURce:TPATtern:WORD	3-183
:SOURce:TRANsceiver:EMPHasis:FIRSt.....	3-184
:SOURce:TRANsceiver:EMPHasis:PRE	3-184
:SOURce:TRANsceiver:EMPHasis:SECond	3-185
:SOURce:TRANsceiver:VOD	3-185
:SYSTem:CONFig.....	3-186
:SYSTem:DATE	3-187
:SYSTem:ERRor	3-188
:SYSTem:PRINt:COPIY	3-189
:SYSTem:STATus.....	3-190
:SYSTem:TERMination	3-190
:SYSTem:TIME	3-191
:SYSTem:VERSion	3-191
:UENTry:ID	3-192
:UENTry:LIST.....	3-192

1
2
3
4
Appendix
Index

Chapter 1 Outline

This chapter explains the outline of the remote control, main uses, and glossary.

1.1	About Remote Control	1-2
1.2	Main Uses for Remote Control	1-3
1.3	Abbreviation	1-4

1.1 About Remote Control

The remote control function sends commands via the communications interface from the remote control PC to set the measuring instrument and read the measurement results and measuring instrument conditions.

The MD1260A 40/100G Ethernet Analyzer supports the Ethernet interface. (When the option is installed, the GPIB interface can be used.) When using either interface, set the number to distinguish the MD1260A from other equipment. When using the Ethernet interface, the IP address is set, and when using the GPIB, the GPIB address is set.

The character strings for controlling the MD1260A are called command. The command is composed by the ASCII character strings. For example, the following command sets when the counter measurement starts.

```
:CALCulate:COUNter:START
```

A command for reading data from this instrument is called a query message. A query command has the question symbol (?) appended to the string. For example, sending the following command queries the clock frequency value set at the instrument.

```
:CALCulate:DATA? RX_FREQ
```

The controller PC receives the following response against the query message from the instrument.

```
103125000000
```

The receiving clock frequency is 103,125,000,000 Hz.

When the MD1260A is measured via remote control, the operation screen is locked. Only the power switch and the key [Local/Panel Unlock] on the system menu are valid in this situation. This situation is called the remote control status. To unlock the remote control status, touch [Local/Panel Unlock] on the system menu.

1.2 Main Uses for Remote Control

The main uses for remote control are listed below.

Automating Measurements

Instead of touch-panel or rotary knob operations, measurement can be automated by controlling the instrument by executing programs. Writing the measurement control procedures using the program makes the measurement automatically.

Remote Control of Instruments

Measuring instruments at remote locations can be controlled over communications lines to collect measurement data.

1.3 Abbreviation

Table 1.3-1 indicates what abbreviations are used in this operation manual.

Table 1.3-1 Abbreviation

Abbreviation	Formal name
ASCII	American Standard Code for Information Interchange
CR	Carriage Return
EOI	End or Identity
ESE	Event Status Enable Register
ESR	Event Status Register
GPIB	General Purpose Interface Bus
IEC	International Electrotechnical Commission
IEEE	Institute of Electrical and Electronics Engineers
LAN	Local Area Network
LF	Line Feed
MAV	Message Available summery
MSS	Master Summery Status
OSER	Operation Status Enable Register
OSR	Operation Status Register
SCPI	Standard Commands for Programmable Interfaces
SRRER	Service Request Enable Register
SRQ	Service Request
STB	Status Byte Register
TR	Transition Filter

Chapter 2 Before Use

This chapter explains the preparations for using remote control.

2.1	Preparing Equipment	2-2
2.2	Connecting Equipment	2-3
2.2.1	Connecting Ethernet.....	2-3
2.2.2	Connecting GPIB.....	2-5
2.3	Setting Interface.....	2-7
2.3.1	Setting Ethernet.....	2-7
2.3.2	Setting GPIB.....	2-10
2.4	Checking Connection.....	2-11
2.4.1	When using Ethernet (Windows XP).....	2-11
2.4.2	When using Ethernet (Windows 7/Vista).....	2-15
2.4.3	When using GPIB	2-16
2.5	Message Format.....	2-17
2.5.1	Message types	2-17
2.5.2	Message configuration	2-18
2.5.3	Common commands	2-20
2.5.4	Device dependent commands.....	2-20
2.6	Checking Instrument Status.....	2-21
2.6.1	Status Byte Register.....	2-21
2.6.2	Standard Event Status Register	2-23
2.7	Confirming Message Execution Status.....	2-26
2.8	Remote Control When Operating Multiport Function..	2-27

2.1 Preparing Equipment

The following equipment/parts are required to perform remote control.

- PC
- Ethernet interface
- Ethernet cable
- GPIB interface (when option installed)
- GPIB cable (when option installed)
- Program development tools

Ethernet Interface

Prepare an interface meeting the following specifications:

10BASE-T

100BASE-TX

Furthermore, use a cable matching both specifications.

GPIB Interface

Use GPIB interfaces that conform to IEEE 488.2.

Program Development Tools

Prepare some tools for developing and running programs for performing remote control. Refer to the VISA and Interface manuals for the specifications required by the program development tools.

PC

Get a PC supporting the operating environment for the GPIB interface and program development tools.

2.2 Connecting Equipment

2.2.1 Connecting Ethernet

Connect the Ethernet connector (upper side) on the side-panel of the MD1260A to the external devices using LAN cables.

Use a LAN crossover cable to connect the MD1260A and the PC controller directly. Use a LAN straight-through cable via a network hub to connect multiple external devices.




Figure 2.2.1-1 Direct Connection between MD1260A and Controller PC

Note:

When connecting the MD1260A via LAN, confirm the network settings before measurement.

- The IP addresses of the MD1260A and the other devices must not overlap.
- The IP address of the PC controller must be in the address range set at the subnet mask.




Figure 2.2.1-2 Typical Connection with Multiple External Devices

Note:

The PC controller may sometimes have difficulty communicating with the MD1260A, depending on the communications status. Direct connection is recommended to ensure stable communications.

2.2.2 Connecting GPIB

Connect the GPIB connector on the rear panel of the MD1260A to the external device using a GPIB cable.

CAUTION

Always connect the GPIB cable BEFORE turning on the power to the MD1260A. Connecting it while the power is on may damage internal circuits.

Up to 15 devices, including the PC controller, can be connected to one MD1260A unit. Always follow the conditions shown below when connecting devices.




Figure 2.2.2-1 GPIB Cable Connection 1

Connect cables without forming ground loops.




Figure 2.2.2-2 GPIB Cable Connection 2

2.3 Setting Interface

2.3.1 Setting Ethernet


Set the remote control interface to Ethernet as follows and input the IP address.

1. Turn on the MD1260A.
2. Touch the [Utility] tab on the Selector screen.
3. Touch [Setup Utility].
4. Touch [Remote Control].
5. Touch the Active Interface button to set the button display to [Ethernet].


The screenshot shows the 'Remote Control' settings window. On the left, under 'Active Interface', the 'Ethernet' button is selected. On the right, the 'GPIB' address is set to '1'. Below that, the 'Ethernet(Windows)' section contains two 'Local Area Connection' settings. The first connection has an IP Address of 192.168.10.94, a Subnet Mask of 255.255.255.0, and a Gateway set to 'Clear'. The second connection, 'Local Area Connection 2', has an IP Address of 169.254.0.15, a Subnet Mask of 255.255.255.0, and an empty Gateway field. At the bottom, the 'Port Number' is set to 5001. 'Apply' and 'Exit' buttons are located at the bottom right of the window.

6. Set the IP address, subnet mask, gateway and port number.
The gateway address may be omitted.
To display the numeric input panel, touch the text box.
You cannot enter numeric values directly into the text box using the attached keyboard.
The port number can be set from 1024 to 5001.
7. Touch [Apply] to complete the settings.
Touch [Exit] to delete the settings.

If Local Area Connection (DHCP) is displayed at step 5, cancel automatic acquisition of the network address as follows:




1. Connect the keyboard and mouse to the MD1260A.
2. Press the Windows key on the connected keyboard.
If there is no Windows key on the keyboard, display the desktop and click [Start].
For how to display the desktop, refer to Section 2.6.1 Displaying windows desktop in the MD1260A 40/100G Ethernet Analyzer Operation Manual.
3. Click [Control Panel].
4. Double-click [Network Connections].



5. Right-click [Local Area Connection], and click [Properties].

6. The Local Area Connection Properties window opens. Click [Internet Protocol (TCP/IP)] in the list box, and click the [Properties] button.



7. Put a checkmark in [Use the following IP address].
The settings at the factory shipment are as follows.
IP address 192.168.100.101, Subnet mask 255.255.255.0
8. Click the [OK] button.
9. Click the [OK] button in [Local Area Connection Properties].

CAUTION

Do not change the setting of [Internal Connection (Don't Change)]. If it is changed, the MD1260A will not function properly.


Do not change the setting of [Local Area Connection2]. If it is changed, the multiport function will be disabled.

2.3.2 Setting GPIB

Set the remote control interface to GPIB as follows and input the GPIB address.

1. Turn on the MD1260A.
2. Touch the [Utility] tab on the Selector screen.
3. Touch [Setup Utility].
4. Touch [Remote Control].
5. Touch the Active Interface button to set the button display to [GPIB].

If Opt-030/130 is not installed, the Active Interface button is disabled.




6. Touch the GPIB address on the test box.
7. Set the GPIB address using the numeric value input panel.
You cannot enter numeric values directly into the text box using the attached keyboard.
8. Touch [Apply] to complete the settings.
Touch [Exit] to delete the settings.

2.4 Checking Connection

Check that the link between the PC and MD1260A has been established via Ethernet.

2.4.1 When using Ethernet (Windows XP)

1. Click Programs at the Windows Start menu.
2. Click [Accessories].
3. Click [HyperTerminal] from the Communication submenu.
4. When the following screen opens, input a name and click [OK].




5. Set the connection method to TCP/IP and input the host address and port number.


The following figure shows how to set the IP address to 192.168.100.2 and the port number to 5001 as described in Section 2.3.1 Setting Ethernet.




6. If the message “192.168.100.2 cannot be connected to the port 5001.” is displayed, the PC cannot recognize the MD1260A. Check that:
 - The application is started.
(Refer to Section 3.1.1 Starting Application in the MD1260A 40/100G Ethernet Analyzer Operation Manual.)
 - The MD1260A IP address and port numbers are correct.
 - The Ethernet cable type (straight through/crossover) is correct.
 - The Ethernet cable is connected to the correct Ethernet connector on the left side of the MD1260A.
 - The cables and connectors are not damaged.
7. When the display changes to “Connected”, the PC controller and the MD1260A can be connected via the Ethernet.




8. Change the HyperTerminal setting to control this equipment using remote commands by selecting [File] – [Properties].




9. Change the HyperTerminal setting to control this equipment using remote commands by clicking [Settings] and clicking the [ASCII Setup...] button.




10. Put checkmarks in [Send line ends with line feeds] and [Echo typed characters locally] and click the [OK] button.



11. To display the response from the equipment correctly with HyperTerminal, responses from the equipment must be terminated with CR+LF. Input :SYSTem:TERMination 1 and press the Enter key. When the command is received by this equipment, the operation screen becomes locked (Remote status).



12. To confirm whether the response from this equipment can be received, input *IDN? and press the Enter key. When the response from the equipment is received, the character string ANRITSU,MD1260A,000000000,1.00.16 is displayed.



The above procedures confirm that control is possible using remote commands. Similar commands can be input to confirm the operation of remote commands.

2


Before Use

2.4.2 When using Ethernet (Windows 7/Vista)

This section explains how to use the free software, Tera Term Version 4.69.


1. When starting Tera Term, the [New connection] window is opened. Enter the IP address and TCP port number in the [Host]. Set the service to [Others] and protocol to [IPv4]. Click [OK].

If the IP address is set to 192.168.100.2 at Section 2.3.1 Setting Ethernet, and the port number is set to 5001, set as follows.



2. When the MD1260A is recognized, the communication window is displayed.
3. Click [Settings (S)] - [Terminal (T)..] on the menu.

4. Set the return cord reception to [LF] and those of counterpart to [CR+LF]. Check the local echo and click [OK].



6. Send *IDN?.
Confirm that the response is displayed from the MD1260A.

Note:

When the panel lock is released by the panel operation, the communication with the MD1260A is terminated and Tera Term will be closed.

2.4.3 When using GPIB

1. Install the software drivers for the GPIB interface.
2. Run the software.
For the operation method, refer to the GPIB interface operation manual.
3. Check the displayed instrument address.

2.5 Message Format

2.5.1 Message types

Messages are composed of character strings indicating the message and message end. The character string indicating the message end is LF (Line Feed) or CR (Carriage Return)+LF.

Messages are composed of the following types depending on the transmission direction:

Program Messages

Messages sent from PC controller to instrument

There are two types of the program messages:

- Command
This can be used for setting measurement conditions and starting measurement.
- Query
This queries the status and settings of the measuring instrument.
When transmitting the query, the instrument creates a response message to the query.

Response Messages

Messages sent from instrument to PC controller

2.5.2 Message configuration

The messages are composed of header and data parts separated by more than a half-width space.

Program messages always have a header but sometimes have no data. Response messages always have data but sometimes have no header.

Header

The command header has the following types:

- Common command header
The header is composed of alphanumeric characters and underbars, and the initial character is an asterisk (*).
Example: *CLS
- Multiple headers
Single headers are linked by colons. Colons can be used at the header. Multiple headers can be used to configure layered processing.
Example: :CALCulate:COUNter:STARt

Queries have a question mark (?) appended to the header.

Example: *ESE?

Data

The data format is character string data, numeric data, and binary data.

String data is ASCII code enclosed in quotation marks.

An example of the program message when inputting `TestResult` at the title is shown below.

Example:

```
:MMEMory:STORe "TestResult",RESULT  
:MMEMory:STORe 'TestResult',RESULT
```

When quotation marks are included in the character string, paired marks are used.

Example:

```
He said "Good product". → "He said ""Good Product""."  
He said 'Good product'. → 'He said ''Good Product''.'
```

In addition, paired quotation marks can be used inside other paired quotation marks.

Example:

```
He said "Good product". → 'He said "Good Product".'  
He said 'Good product'. → "He said 'Good Product'."
```

The numeric values can be described by using numeric data. Input numeric values either as decimal, binary, octal, or hexadecimal numbers. When using binary, octal, or hexadecimal numbers, prefix the data with #B,#O, or #H, respectively.

Example:

```
10    #B1010          #O12          #HA
1550 #B11000001110 #O3016        #H60E
```

When using decimal numbers, use integer numbers, fixed point, and floating point. The following examples indicate the same values.

Example:

```
-10          -10.00          -1E1
1250         1250.000        1.25E3
0.0023              2.3E-4
```

For the binary data, the head string starts with a sign (#) and continues with data after a numeric value indicating the data length.

The data length is displayed when the next character of the sign (#) is other than 0.

The binary data follows the number indicating the data length.

Example: `#42002an%*qe4445+¥...`

When the character after the sharp symbol (#) is 0, binary data continues after 0.

Example: `#0an%*qe4445+¥...`

Messages with multiple data use commas (,) to separate data parts.

Example: `:CALCulate:DATA? RX_FREQ,RX_FREQ_D`

When linking multiple program messages, separate the message using semicolons (;).

Example:

```
:MMEMory:STORe "TestResult",RESULT;:SYSTem:ERRor?
```

2.5.3 Common commands

The GPIB specifications (IEEE 488.2) define equipment commands. In this manual, these commands are called common commands.

The common commands are divided into mandatory and option commands. The MD1260A supports the common commands listed in Table 2.5.3-1.

Table 2.5.3-1 Common Commands

Command	Explanation
*CLS	Clears standard event register and output queue
*ESE	Sets and queries standard event enable register
*ESR	Queries standard event register
*IDN	Queries product information
*OPC	Sets/queries bit setting and bit 0 for status byte indicating message processing completion
*RST	Initializes MD1260A setting conditions
*SRE	Sets and queries SRER
*STB	Queries status byte register
*TRG	Starts measurement
*WAI	Waits for previous sent message completion

2.5.4 Device dependent commands

In this manual, commands that differ according to the functions of the measuring instrument are called Device Dependent Commands.

2.6 Checking Instrument Status

This instrument has registers indicating status, such as errors and command execution status. This section explains these registers.

2.6.1 Status Byte Register

The status byte register (STB) displays the status of equipment defined by the GPIB standards. When the equipment status changes, the value in the STB changes too. It can be used to generate interrupts to the PC controller. These interrupts are called service requests.

There is a service request enable register (SRER) for the STB. The SRER can select the status byte bit generating the service request.




Figure 2.6.1-1 Configuration of Status Byte Register and Service Request Enable Register

Note:

When using the GPIB interface, the service request is enabled.

The following methods are used to read the status byte register.

- Using common *STB? command
- Using GPIB serial poll (when Opt-030 installed)

Read the GPIB interface manual for the serial poll method.

When using serial polling, even if bit 6 is 1, it becomes 0 after reading once.

The `*SRE` and `*SRE?` common commands can be used for setting and reading the SRER for setting reading of the status byte register. To output the STB data, set the bit corresponding to the SRER to 1.

The meaning of each bit of the STB is shown in the following table.

Table 2.6.1-1 Meaning of Status Byte Register

Bit	Explanation
7	Not used; always 0
6	MSS (Master Summary Register) It is the logical sum of the bit 5 to 0, bit 7 logical product of the STB and the SRER.
5	This is the logical sum of each bit of the logical product of the standard event status register and standard event enable register.
4	MAV (Message Available summary) This is always 1 when there is a response message in the output queue of this instrument
3	Not used; always 0
2	Not used; always 0
1	Not used; always 0
0	Not used; always 0

Bit 6 of the STB is called the master summary status (MSS) bit. When it is 1, there is a notification from this instrument to the PC controller. When it changes to 1 from 0, a service request is generated.

Bit 5 of the STB indicates information about the standard status register. For details about the information, refer to section 2.6.2 Standard Event Status Register.

Bits 5 of the STB can be set to 0 using the `*CLS` common command. When `*CLS` is sent after a command or when a query is sent after `*CLS`, the send queue is cleared and bit 4 is set to 0.

The SRER cannot be set to 0 by `*CLS`, so use `*SRE`.

2.6.2 Standard Event Status Register

There is a standard event status enable register (ESE) for the standard event status register (ESR). The logical product of these two registers and the logical sum of each bit of this result is output to bit 5 of the STB.




Figure 2.6.2-1 Configuration of Standard Event Status Register and Standard Event Status Enable Register

2

Before Use

The meaning of each bit of the ESR is listed in the table below.

Table 2.6.2-1 Meaning of Standard Event Status Register

Bit	Explanation
7	Power-on Becomes 1 at power-on and returns 0 when read
6	Not used; always 0
5	Command Error Becomes 1 when received undefined program message, message that cannot executed according to syntax, or message with spelling error
4	Execution Error Becomes 1 when received program message that cannot be executed
3	Device Dependent Error Becomes 1 at errors other than command, execution and query errors
2	Not used; always 0
1	Not used; always 0
0	Operation Complete Becomes 1 when entire command operation completed after *OPC command operation

A bit 5 command error occurs under the following circumstances:

- When instruments received message not described in Section 3.

Examples:

- Typographical error in message
- 2 byte code character in message
- No space separator between message and parameter
- No semicolon separators between multiple messages
- Omitted characters in message that cannot be omitted

- Incorrect parameter count

Examples:

- Sent two parameters when only 1 parameter defined in message
- No comma separators between parameters

- When parameter format incorrect

Example:

- Sent string to message where numerical value defined as parameters
- Character string not enclosed by quotation marks

A bit 4 execution error occurs under the following circumstances:

- When the parameter setting is out of range

Examples:

Bit rate offset set to 150 ppm (Setting range: -100~100)

External attenuation factor set to 100 dB (Setting range:0~30)

- Command correct but cannot be executed in current equipment status

Examples:

PPG/ED2 bit rate set when no PPG/ED Ch2 option installed

CRU Loop Band set when CRU option not installed

Bit 7 to bit 0 of the ESR can be read by the *ESR? command.

The standard event register returns to 0 when read.

The ESE can be set and read using the *ESE and *ESE? commands. To output standard event register data, set the bit corresponding to the enable register to 1.

The bit 0 can be read using the *OPC command.

The standard register can be set to 0 using the *CLS command.

2.7 Confirming Message Execution Status

When using Ethernet interface:

A message can be sent even while the MD1260A is executing a program message. However, the next message is not processed until processing of the previous message is complete.

When using the Ethernet interface, confirm completion of the sent message before sending the next message.

To confirm the message execution end, send the query.

After the previous message processing is completed, the query is processed and the PC receives the response.

Example:

```
:MMEMory:STORe "TestResult",RESULT
                                Saves measurement results
:System:Error?                 Queries error
> 0,"No Error"                 No errors when 0 read
```

In these examples, there may be a delay ranging up to a few seconds until the response message is returned after sending `:System:Error?` Execution of the `:MMEMory:STORe` and `:System:Error?` messages is confirmed by receiving the response message.

When using GPIB interface:

The message cannot be sent to the MD1260A while executing the previously sent message. When using the GPIB interface, set the PC controller GPIB interface timeout to ensure that communications do not time-out while this instrument is executing messages.

2.8 Remote Control When Operating Multiport Function

When controlling the MD1260A using the multiport function via remote operation, connect the PC controller to the master MD1260A.

For the multiport function, refer to Chapter 8 Multiport Function in the MD1260A 40/100G Ethernet Analyzer Operation Manual.

The master and slave displayed on the top menu of the application screen can be controlled via remote operation.

The Unit ID list of the MD1260A can be queried using the command `:UENTry:LIST?`.

To control a specific MD1260A unit, specify the Unit ID of the MD1260A using `:UENTry:ID`.

The `[:AUNit]` command in the header is executed by all MD1260A units by adding `:AUNit`.

Chapter 3 Message Details

This chapter describes the message details of remote control commands for the MD1260A.

3.1	Description of Message Explanations	3-2
3.2	Correspondence between Panel Operation and Messages.....	3-4
3.2.1	Messages Corresponding to Common Operations	3-4
3.2.2	Messages Corresponding to 40GbE/100GbE	3-10
3.2.3	Messages Corresponding to OTU3/OTU4	3-26
3.2.4	Messages Corresponding to No Frame	3-39
3.2.5	Add-on Function	3-41
3.2.6	Messages with No Corresponding Panel Operation.....	3-42
3.2.7	Panel operation not controlled remotely	3-43
3.3	Device Message Details	3-44
3.3.1	Common Messages.....	3-44
3.3.2	Device Dependent Commands	3-51

3.1 Description of Message Explanations

The following table shows the rules for describing messages.

Table 3.1-1 Rules for Describing Messages

Symbols	Usage
<>	Parameters in angled bracket are input by the programmer.
[]	Messages or parameters in square brackets can be omitted.
	One of several choices can be chosen. For example, if A B C D are choices, select one of them.
{ }	Group the choices. When A B({C D}) can be chosen, select one of them.
<CHAR>	Displays a choice for mnemonic Equivalent to IEEE488.2 <CHARACTER PROGRAM DATA>, <CHARACTER RESPONSE DATA>
<BOOLEAN>	Displays enable/disable setting To enable the setting, set ON or 1. To disable the setting, set OFF or 0. 1 is returned for enabled queries and 0 is returned for disabled.
<NR1>	Numeric values Example: 123, -500
<NR2>	Displays binary fixed point format. Example: 12.345, -500.0
<NR3>	Displays numeric value of floating point format. Example: 0.00E-11, 3.05E-11
<HEX>	Displays hexadecimal values. Specifies hexadecimal values after #H Example: #H0011EEFF
<BINARY>	Displays binary numbers. Specifies binary numbers after #B Example: #B0011010
<STRING>	Character string data For details, refer to Section 2.5.2 Message Configuration.

Some parts of the header character strings can be omitted.
The small letter can be omitted, but the capital letter cannot be omitted.

Example :SYSTem:ERRor?

This header can be written as follows:

:SYSTem:ERRor?

:SYST:ERR?

:SYSTEM:ERROR?

:SYSTem:ERR?

These messages are interpreted as the same meanings in the MD1260A.

3.2 Correspondence between Panel Operation and Messages

This section explains correspondence between panel operations and messages.


3.2.1 Messages Corresponding to Common Operations

The screenshot shows a software interface with a top navigation bar containing 'Ethernet', 'OTN', 'Utility', and 'Multi Port' tabs. The 'Multi Port' tab is active. Below the tabs is a table with three columns: 'No', 'Unit ID', and 'Application'. The table contains 13 rows. Row 2 is highlighted in blue. To the right of the table are several control buttons: 'Unit 1', 'Go Slave', 'Update', two arrow buttons (up and down), 'Select', and 'Start'. A label ':SYSTEM:CONFig' with a line pointing to the table is located to the left of the interface.

No	Unit ID	Application
1	This Chassis	40GbE No Frame
2	Unit 3	40GbE
3	None	
4	None	
5	None	
6	None	
7	None	
8	None	
9	None	
10	None	
11	None	
12	None	
13	None	

Figure 3.2.1-1 Messages Corresponding to Multi-port Settings

3.2 Correspondence between Panel Operation and Messages



3

Message Details

Figure 3.2.1-2 Messages Corresponding to System Menu




Figure 3.2.1-3 Messages Corresponding to Operation Area




Figure 3.2.1-4 Messages Corresponding to Summary Message/Time Display Area




Figure 3.2.1-5 Messages Corresponding to Top Menu




Figure 3.2.1-6 Messages Corresponding to Setting Area [MDIO]




Figure 3.2.1-7 Messages Corresponding to Setting Area [Transceiver]




Figure 3.2.1-8 Message Corresponding to Measurement Result Display Area (Opt)

3

Message Details

3.2.2 Messages Corresponding to 40GbE/100GbE

For the Messages Corresponding to the setting area of [MDIO] and [Transceiver], refer to Figure 3.2.1-6 Messages Corresponding to Setting Area [MDIO] and Figure 3.2.1-7 Messages Corresponding to Setting Area [Transceiver].

The screenshot shows the 'Stream' configuration window. It includes fields for Control Unit (Gap Size), Duration (Repeat, count), Test Pattern (Word16, 5555), and Transmission Type (Random). A table lists stream configurations with columns for No., Size (byte), Gap Size (byte), Name, Error, and Flow ID. A Selection panel on the right contains navigation buttons like Control/Header..., Test Frame..., FCS Error Ins..., Copy/Paste to..., and Move to....

No.	Size (byte)	Gap Size (byte)	Name	Error	Flow ID
On 1	120-1000	1,500,000-579,999	Ethernet + IPv4 + ICMPv4 (Echo)	-	0
On 2	84	10,000	Ethernet + IPv6 + ICMPv6 (Echo)	-	1
On 3	108	1,200,000	Ethernet + IPv6 + ICMPv6 (NS)	-	2
On 4	64	18,500,000	Ethernet + IPv4 + ICMPv4 (Echo)	-	3
On 5	64	150,000,128	Ethernet + IPv4	-	4
On 6	64	6,000,000	Ethernet + IPv4 + ICMPv4 (Echo)	-	5
On 7	64	85,000	Ethernet + IPv4 + ICMPv4 (Echo)	-	6
On 8	64	12,000,000	Ethernet + IPv4 + ICMPv4 (Echo)	-	7
On 9	64	9,000,000	Ethernet + IPv4 + ICMPv4 (Echo)	-	8
On 10	64	652,000	Ethernet + IPv4 + ICMPv4 (Echo)	-	9
On 11	64	960,000	Ethernet + IPv4 + ICMPv4 (Echo)	-	10
On 12	64	500,000	Ethernet + IPv4 + ICMPv4 (Echo)	-	11
Off 13	64	1,500,000	Ethernet + IPv4 + ICMPv4 (Echo)	-	12
Off 14	64	600,000	Ethernet + IPv4 + ICMPv4 (Echo)	-	13
Off 15	64	600,000	Ethernet + IPv4 + ICMPv4 (Echo)	-	14
Off 16	64	5,600,000	Ethernet + IPv4 + ICMPv4 (Echo)	-	15

Figure 3.2.2-1 Messages Corresponding to Setting Area [Stream]




Figure 3.2.2-2 Messages Corresponding to Stream-TestFrame Screen




Figure 3.2.2-3 Messages Corresponding to Stream Screen-Control Tab




Figure 3.2.2-4 Messages Corresponding to Stream Screen-Header Tab 1

:SOURCE:STReam:HEADer:VARiable1:TYPE

:SOURCE:STReam:HEADer:VARiable1:RANGe

:SOURCE:STReam:HEADer:VARiable2:TYPE

:SOURCE:STReam:HEADer:VARiable2:RANGe

Stream Control/Header

Stream 1 Name MPLS-TP w/o CW (1) + PBB (B-Tag) + Ethernet + MPLS(3) + IPv4 ... Auto On

Control Header

Frame Format MPLS-TP w/o CW (1) + PBB (B-Tag) + Ethernet + MPLS(3) + IPv4

MPLS-TP | PBB | Ethernet | MPLS | IPv4 | Modifiers | Header | Pattern

Field 1 (MPLS-TP DA) Increment Offset 0 byte Length 1 byte Count 1

Field 2 (MPLS-TP SA) Increment Offset 0 byte Length 1 byte Count 1

Field 3 Random MPLS - MPLS Tags - Tag 1 - Time to Live (8 bits)

Offset 0 bit Length 8 bit Value Range dec 0 to 255
hex 00 to FF
bin 00000000 to 11111111

Field 4 Random IPv4 - Protocol (8 bits)

Offset 0 bit Length 8 bit Value Range dec 0 to 255
hex 00 to FF
bin 00000000 to 11111111

Field 5 Increment Ethernet - Destination Address (48 bits)


Offset 0 bit Length 32 bit Value Range hex 00000000 to FFFFFFFF step 1
dec 0 to 4,294,967,295
00000000000000000000000000000000 to 11

:SOURCE:STReam:HEADer:VARiable{3|4|5}

3

Message Details

Figure 3.2.2-5 Messages Corresponding to Stream Screen-Header Tab 2



:SOURCE:STReam:HEADer

Figure 3.2.2-6 Messages Corresponding to Stream Screen-Header Tab 3




Figure 3.2.2-7 Messages Corresponding to Stream Screen-MAC Resolve




Figure 3.2.2-8 Messages Corresponding to Stream Screen-MAC Setup




Figure 3.2.2-9 Messages Corresponding to Setting Area [Stream] (Frame BER)




Figure 3.2.2-10 Messages Corresponding to Setting Area [Lane Mapping]




Figure 3.2.2-11 Messages Corresponding to Setting Area [Relative Skew]




Figure 3.2.2-12 Messages Corresponding to Setting Area [Error/Alarm]





Figure 3.2.2-13 Messages Corresponding to Setting Area [Error/Alarm] (Rate)



3

Message Details

Figure 3.2.2-14 Messages Corresponding to Setting Area [Capture/Counter]




Figure 3.2.2-15 Messages Corresponding to Setting Area [Port]




Figure 3.2.2-16 Messages Corresponding to Setting Area [Port]-Filter Setting (VLAN)

3.2 Correspondence between Panel Operation and Messages




Figure 3.2.2-17 Messages Corresponding to Setting Area




Figure 3.2.2-18 Messages Corresponding to Measurement Results Area

3

Message Details




Figure 3.2.2-19 Messages Corresponding to Measurement Results Area (Protocol-ARP/ICMP)




Figure 3.2.2-20 Messages Corresponding to Measurement Results Area (Protocol-Ping)




Figure 3.2.2-21 Message Corresponding to Measurement Result Display Area (Test Frames) MultiFlow Screen




Figure 3.2.2-22 Message Corresponding to Measurement Result Display Area (Test Frames) Flow to Count Screen

3.2 Correspondence between Panel Operation and Messages




Figure 3.2.2-23 Messages Corresponding to Measurement Results Area (Capture)

3

Message Details

3.2.3 Messages Corresponding to OTU3/OTU4

For the Messages Corresponding to the setting area of [MDIO] and [Transceiver], refer to Figure 3.2.1-7 Messages Corresponding to Setting Area [Transceiver], and Figure 3.2.2-12 Messages Corresponding to Setting Area [Clock].




Figure 3.2.3-1 Messages Corresponding to [Mapping Select] (OTU4)




Figure 3.2.3-2 Messages Corresponding to [Test Pattern]




Figure 3.2.3-3 Messages Corresponding to Operation Area [Stream]

3

Message Details




Figure 3.2.3-4 Messages Corresponding to Setting Area [GFP-T]




Figure 3.2.3-5 Messages Corresponding to Setting Area [TP/TS]




Figure 3.2.3-6 Messages Corresponding to Operation Area [OH Preset]




Figure 3.2.3-7 Messages Corresponding to Operation Area [Lane Mapping]

3

Message Details




Figure 3.2.3-8 Messages Corresponding to Setting Area [Relative Skew]




Figure 3.2.3-9 Messages Corresponding to Setting Area [Error/Alarm] (Alternate)




Figure 3.2.3-10 Messages Corresponding to Setting Area [Error/Alarm] (Rate)




Figure 3.2.3-11 Messages Corresponding to Setting Area [Error/Alarm] (Burst)




Figure 3.2.3-12 Messages Corresponding to Setting Area [Error/Alarm] (Subrow)

:SOURce:EALarm:BIT





Figure 3.2.3-13 Messages Corresponding to Setting Area [Error/Alarm] (Bit)

:CALCulate:COUNter:ETHer:OVERsize :SENSe:TIM:{SM|PM[:L]|TCM{1|2|3|4|5|6}}



:SENSe:PLM[:L]:PATTERN :SENSe:TIM:{SM|PM[:L]|TCM{1|2|3|4|5|6}}:PATTERN:{DAPI|SAPI}

Figure 3.2.3-14 Messages Corresponding to Setting Area [Counter]




Figure 3.2.3-15 Messages Corresponding to Setting Area [Port/Clock] 1




Figure 3.2.3-16 Messages Corresponding to Setting Area [Port/Clock] 2




Figure 3.2.3-17 Messages Corresponding to Measurement Result Display Area (Statistics)




Figure 3.2.3-18 Messages Corresponding to Measurement Result Display Area (Data Monitor)

3.2 Correspondence between Panel Operation and Messages




Figure 3.2.3-19 Messages Corresponding to Measurement Result Display Area (Delay)

3
Message Details





Figure 3.2.3-20 Messages Corresponding to Measurement Result Display Area (APS)

3.2 Correspondence between Panel Operation and Messages



3

Message Details

Figure 3.2.3-21 Messages Corresponding to Measurement Result Display Area (Capture) 1




Figure 3.2.3-22 Messages Corresponding to Measurement Result Display Area (Capture) 2

3.2.4 Messages Corresponding to No Frame

For the messages corresponding to the setting area of [MDIO], [Clock], and [Transceiver], refer to Figure 3.2.1-6 Messages Corresponding to Setting Area [MDIO], Figure 3.2.1-7 Messages Corresponding to Setting Area [Clock], and Figure 3.2.2-12 Messages Corresponding to Setting Area [Transceiver].

There are no messages corresponding to the setting area of [Counter].




Figure 3.2.4-1 Messages Corresponding to Setting Area [Test Pattern]




Figure 3.2.4-2 Messages Corresponding to Setting Area [Error/Alarm]




Figure 3.2.4-3 Messages Corresponding to Setting Area [Port] (100GbE No Frame/OTU4 No Frame)




Figure 3.2.4-4 Messages Corresponding to Measurement Result Display Area

3.2.5 Add-on Function

There are no messages corresponding to the following Add-on functions.

- RFC2544
- CFP MDIO Analysis
- Lambda Measure
- Service Disruption

The remote control cannot be performed while executing the Add-on function.

3.2.6 Messages with No Corresponding Panel Operation

Command messages with no corresponding panel operation are listed below.

Query-only messages are described by omitting the question mark.

Messages that are both command and query are described as command-only.

Table 3.2.6-1 Messages with No Corresponding Panel Operation (Common Commands)

Command	Details
*CLS	Clears standard event register and output queue
*ESE	Sets/queries standard event enable register
*ESR	Queries standard event register
*OPC	Sets/queries bit setting and bit 0 for status byte indicating message processing completion
*RST	Initializes MD1260A setting conditions
*SRE	Sets/queries service request enable register
*STB	Queries status byte register
*WAI	Waits for previous sent message completion

Table 3.2.6-2 Messages with No Corresponding Panel Operation

Command	Details
:CALCulate:APS:START:EVENT[:AUNit]	Queries APS measurement start event
:CALCulate:CAPTure:DATA:SIZE	Queries captured data size
:CALCulate:CAPTure:START:EVENT	Queries capture start event
:CALCulate:COUNter:START:EVENT[:AUNit]	Queries counter start event
:CALCulate:DELay:START:EVENT[:AUNit]	Queries delay time measurement start event
:MMEMory:LOG:FNAME	Queries latest log file name
:PROTOcol:PING:START:EVENT	Queries Ping measurement start event
:SOURce:EALarm:START:EVENT[:AUNit]	Queries error/alarm start event
:SOURce:STReam:START:EVENT[:AUNit]	Queries delay time measurement start event
:SYSTem:ERRor	Queries command error occurrence
:SYSTem:STATus	Queries application startup status
:SYSTem:TERMination	Queries setting of terminal
:SYSTem:VERSion	Queries SCPI version

3.2.7 Panel operation not controlled remotely

Button operations and data readings without remote commands displayed on the screens in Section 3.2.1 "Messages Corresponding to Common Operations" to Section 3.2.5 "Messages corresponding to No Frame" cannot be controlled remotely.

In addition, the following panel operations cannot be operated remotely.

- Any operation of Utility tab in the Selector screen
- Go Slave button of Multi Port tab in the Selector screen
- Shut Down button in the Selector screen
- Switching of the application screen display with tab operation
- Setting screen display for the system menu and setting area
- Waveform data acquisition with Chart tab in the application screen
- Any operation for the Add-on function
- GMP screen operation and data acquisition with OTU4 application Data Monitor tab
- Acquisition of GMP Capture Viewer screen with OTU4 application Capture tab (GMP)

However, the saving measurement result to files can be controlled remotely.

3.3 Device Message Details

3.3.1 Common Messages

*CLS [Clear Status]

Function

1. The *CLS common command clears the following registers.

- Standard event status register
- Output queue

Therefore, bit 5 of the status byte register becomes 0.

The setting value of each enable register does not change depending on *CLS.

- Standard event status enable register
- Service request enable register
- Operation status register
- Device dependant status register

2. The *CLS common command clears the status byte register when sending *CLS command before the query after the program message terminator.

All unread messages in the output queue are cleared at this time.

Syntax

*CLS

ESE [Event Status Enable]*Function**

This command sets the standard event status enable register.

The standard event status mask bit is set to 0.

*ESE? queries the standard event status enable register value.

Syntax

*ESE <integer>

*ESE?

<integer> = bit0 + bit1 + bit2 + bit3 + bit4 + bit5 + bit6 + bit7

The correspondence between the register bit and hexadecimal value is shown below.

bit7 : $2^7 = 128$	Power-on
bit6 : $2^6 = 64$	Not used
bit5 : $2^5 = 32$	Command error
bit4 : $2^4 = 16$	Operation error
bit3 : $2^3 = 8$	Device dependent error
bit2 : $2^2 = 4$	Not used
bit1 : $2^1 = 2$	Not used
bit0 : $2^0 = 1$	Completion of operation
Range	0 to 255

Response Data

<integer>

*ESE?: Total bits for standard event status enable register are 0 to 255.

Example of Use

The following example shows how to mask bits 0 to 2 and 6 to 7 and permit bits 3 to 5.

```
*ESE 56
```

```
*ESE?
```

```
>56
```

*ESR [Standard Event Status Register]

Function

This command returns the standard event status register value. This value is the logical product of the 8 bits set by *ESE. The standard event status register value is cleared after readout.

Syntax

*ESE?

Response Data

<integer>:

*ESR?: Total bits for standard event status register is 0 to 255.

Example of Use

The following example queries the value of the standard event status register. The data is the value when an execution error or command error occurs.

```
*ESR?
```

```
>48
```

Details of error occurrences can be investigated using the:SYSTem:ERRor? command.

*IDN [Identification]

Function

This command queries the product supplier name, model name, serial number, and version.

Syntax

*IDN?

Response Data

```
ANRITSU,MD1260A,<serial_number>,<version>
```

<serial_number>

This command returns the instrument serial number (10 digits).

<version>

This command returns the version of the software installed in the instrument in the format X.XX.XX.

Example of Use

```
*IDN?
>ANRITSU,MD1260A,6200123456,1.00.16
```

*OPC [Operation Complete]

Function

If a *OPC command is received, the operation completion bit (bit 0) is set to 1 when all active processes are complete.

A*OPC? Queries bit 0 (OPC bit) of the standard event status register. 0 is returned while the processing is performed, and 1 is returned if the processing is completed.

The wait for operation completion set by *OPC/*OPC? is disabled after the following events:

- Power-on
- Reception of DCL or SCL on IEEE488.1 interface
- Reception of *CLS command
- Reception of *RST command
- Completion of all active processing

Note:

This instrument cannot process other messages while processing a message. As a result, processing of the *OPC? query is suspended during execution of the previously sent message. Since *OPC? is processed after processing of the previously sent message is completed, the response data is always 1. For how to confirm the end of the message execution, refer to Section 2.6 Confirming Message Execution Status.

Syntax

```
*OPC
*OPC?
```

Response Data

```
1
```

Example of Use

```
*OPC?
>1
```

*RST [Reset]

Function

This command resets the following items to the factory-default settings. However, the following items cannot be set back to the factory-default settings.

- Windows settings such as GPIB address, IP address, etc.
- Transceiver settings (:SOURce:TRANsceiver:*)
 - :SOURce:TRANsceiver:EMPHasis:FIRSt
 - :SOURce:TRANsceiver:EMPHasis:PRE
 - :SOURce:TRANsceiver:EMPHasis:SECOnd
 - :SOURce:TRANsceiver:VOD
 - :SENSe:TRANsceiver:EQUalizer:CONTRol
 - :SENSe:TRANsceiver:EQUalizer:DCGain
- Response terminator settings (:SYSTem:TERMination)

Note:

When multiple MD1260A are connected, all MD1260A units are initialized by sending *RST.

To initialize individual MD1260A units, send :MMEMory:INITialize.

Syntax

*RST

SRE [Service Request Enable]*Function**

*SRE sets the service request enable register.

The 0 to 255 setting values are equivalent to 8-bit binary.

The bit masking the status byte register is set to 0.

Syntax

*SRE <integer>

*SRE?

<integer>= bit0 + bit1 + bit2 + bit3 + bit4 + bit5 + bit6 + bit7

bit7 : $2^7 = 128$	Not used
bit6 : $2^6 = 64$	Always 0 for Service Request Enable Register
bit5 : $2^5 = 32$	Event status register summary
bit4 : $2^4 = 16$	Indicates output queue is empty
bit3 : $2^3 = 8$	Not used
bit2 : $2^2 = 4$	Indicates error and event queue is empty
bit1 : $2^1 = 2$	Not used
bit0 : $2^0 = 1$	Not used

Range 0 to 255

STB [Status Byte]*Function**

*SRE? queries the service request enable register value.

*STB? reads the status byte register.

Syntax

*STB?

Response Data

<integer>

*STB?: Total bits for status byte register is 0 to 255

Example of Use

To mask bits 2 and 5:

*SRE 36

*SRE?

>36

***TRG [Trigger]**

Function

This is the same operation as sending:CALCulate:COUNter:STARt[:AUNit].

This command starts counting all modules when connecting multiple units.

Syntax

*TRG

***WAI [Wait to Continue]**

Function

This command holds execution of the next message until processing of the preceding message is completed.

Note:

This instrument cannot process other messages while processing a message. Since the message is processed after processing of the previously sent message is complete, using*WAI is not required.

Syntax

*WAI

3.3.2 Device Dependent Commands

`:CALCulate:APS:ERRor:FREE`

Function

This command sets and queries the APS measurement error free evaluation condition for the OTU3 or OTU4 application.

Syntax

`:CALCulate:APS:ERRor:FREE <NR1>`

`:CALCulate:APS:ERRor:FREE?`

`<NR1>:` Error Free Period (ms)
1 | 10 | 100 | 200 | 300 | 400 | 500 | 600 | 700 | 800 | 900 | 1000

Response Data

`<NR1>`

Example of Use

`:CALCulate:APS:ERRor:FREE 200`

`:CALCulate:APS:ERRor:FREE?`

`> 200`

`:CALCulate:APS:STARt[:AUNit]`

Function

This command starts the APS measurement for the OTU3 or OTU4 application.

If APS is already being measured, the measurement is restarted.

If `:AUNit` is added, APS measurements for all units connected are started simultaneously.

Syntax

`:CALCulate:APS:STARt[:AUNit]`

Example of Use

To wait for the error/alarm insertion start:

1. Send `:CALCulate:APS:STARt:EVENT?`.

The start event is cleared.

2. Send `:CALCulate:APS:STARt`.

The APS measurement is started.

3. Send `:CALCulate:APS:STARt:EVENT?`.

Repeat the transmission until the response data becomes 1 (start).

:CALCulate:APS:START:EVENT[:AUNit]

Function

This command queries the APS measurement start event for the OTU3 or OTU4 application.

Syntax

`:CALCulate:APS:START:EVENT[:AUNit]?`

Response Data

0|1

0: Before the start of APS measurement

After this command is read out, the response data becomes 0.

1: The APS measurement has been started.

If :AUNit is added to the header, the response data becomes 1 when APS measurements for all units connected are started.

The event value is cleared to 0 when the response data 1 is read.

Example of Use

Refer to the example for `:SOURCE:EALarm:START[:AUNit]`.

:CALCulate:APS:STATUS[:AUNit]

Function

This command queries the status of APS measurement for the OTU3 or OTU4 application.

Syntax

`:CALCulate:APS:STATUS[:AUNit]?`

Response Data

0|1

0: APS measurement stopped

1: APS measurement in progress

If :AUNit is added to the header, the response data becomes 1 when APS measurements for any one of or multiple connected units are started, and it becomes 0 when APS measurements for all

connected units are stopped.

Example of Use

Refer to the example for `:SOURCE:EALarm:STOP[:AUNit]`.

:CALCulate:APS:STOP[:AUNit]**Function**

This command stops the APS measurement for the OTU3 or OTU4 application.

Adding :AUNit stops the APS measurements for all units connected.

Syntax

```
:CALCulate:APS:STOP[:AUNit]
```

Example of Use

To confirm that the APS measurement is stopped as follows:

Send :CALCulate:APS:STOP to stop the APS measurement.

Send :CALCulate:COUNter:STATus? repeatedly until the response data is 0 (stop).

:CALCulate:APS:TRIGger**Function**

This command queries and sets the trigger of the APS measurement.

Syntax

```
:CALCulate:APS:TRIGger <start>,<stop>
```

<start>,<stop>=<CHAR>

Trigger	<CHAR>
LOF	LOF
OOF	OOF
ODU-AIS	AIS_ODU
ODU-OCI	OCI
ODU-LCK	LCK
SM-BIP8	SM_BIP8
PM-BIP8	PM_BIP8
Any Error (OR for all items)	ANY_ERROR

Example of Use

To confirm that the APS measurement is stopped as follows:

1. Send :CALCulate:APS:STOP to stop the APS measurement.
2. Send :CALCulate:COUNter:STATus?: repeatedly until the response data is 0 (stop).

:CALCulate:CAPTure:DATA

Function

This command queries the capture data of the OTU3 or OTU4 application.

If the capture target is GMP, the data cannot be queried with this command.

Use :MMEMory:STORe:CAPTure.

Syntax

```
:CALCulate:CAPTure:DATA? {<row>,<column>} |  
{<frame_num>[,<offset>,<length>]}
```

<row>,<column>,<frame_num>,<offset>,<length> = <NR1>

When the capture target is OH,

<row>: Row number

<column>: Column number

When the capture target is Frame,

<frame_num>: Frame number

<offset>: Offset (bytes)

<length>: Length (bytes)

Response Data

<STRING>

Comma separated hexadecimal character string. Byte with invalid data is displayed as --.

The maximum buffer size for response data captured at one time is 65536 bytes.

When the capture target is OH, it is the multiframe sequence data of the specified byte position. The data length is the value specified with :CALCulate:CAPTure:DATA:SIZE.

:CALCulate:CAPTure:DATA:RXC**Function**

This command queries the capture data of the control signal (RXC) for the 40 GbE or 100 GbE application. It also specifies the data position querying the offset and length as the number of bits.

Syntax

```
:CALCulate:CAPTure:DATA:RXC? <offset>,<length>
```

```
<offset>,<length> = <NR1>
```

```
<offset>:      Offset (bytes)
```

```
<length>:     Length (bytes)
```

Response Data

```
<BINARY>
```

In the following cases, -220,"Parameter Error" is returned for the :SYSTem:ERRor command.

- <length> that exceeds the buffer size* has been specified.
- The range that exceeds :CALCulate:CAPTure:DATA:SIZE has been specified with <offset> and <length>.

*: The buffer size (maximum number of characters that can be returned as response data) is 65536 bytes. Therefore, the maximum number of RXC data that can be specified with <length> is $65536 \cdot 2 = 65534$ bits.

For details about RXC, refer to IEEE802.3ba Clause 81.

:CALCulate:CAPTure:DATA:RXD

Function

This command queries the transmission capture data (RXD) for the 40 GbE or 100 GbE application. It also specifies the data position querying the offset and length as the number of bits.

Syntax

:CALCulate:CAPTure:DATA:RXD? <offset>,<length>

<offset>,<length> = <NR1>

<offset>: Offset (bytes)

<length>: Length (bytes)


Response Data

<HEX>

In the following cases, -220,"Parameter Error" is returned for the :SYSTem:ERRor command.

- <length> that exceeds the buffer size* has been specified.
- The range that exceeds :CALCulate:CAPTure:DATA:SIZE has been specified with <offset> and <length>.

*: The buffer size (maximum number of characters that can be returned as response data) is 65536 bytes. Therefore, the maximum number of RXD data that can be specified with <length> is $(65536-2)/2 = 32767$ bits.



For details about RXD, refer to IEEE802.3ba Clause 81.

Example of Use

To read bytes 1000 to 1015:

```
:CALCulate:CAPTure:DATA:RXD? 1000,16
```

```
> #H002523FE0A0B55230000000000000111A
```

To set an offset exceeding the capture data:
:CALCulate:CAPTure:DATA:RXD? 100000,16
> OUT_OF_RANGE

:CALCulate:CAPTure:DATA:SIZE

Function

This command queries the transmission data capture size (RXD) using the number of RXD bytes for the 40 GbE or 100 GbE application.

It queries the capture data size using the number of frames for the OTU3 or OTU4 application.

Syntax

:CALCulate:CAPTure:DATA:SIZE?

Response Data

<NR1>: Capture data size (0~131072)
 Displays 0 while capturing

:CALCulate:CAPTure:DATA:TRIGger:POSition

Function

This command queries the trigger position in the capture data using the offset (bytes) from the header of the capture data.

When the trigger condition is the frame sequence, the trigger position is the last byte of the frame sequence.

Syntax

:CALCulate:CAPTure:DATA:TRIGger:POSition?

Response Data

<NR1>: Trigger position

:CALCulate:CAPTure:STARt

Function

This command starts capture.

Syntax

:CALCulate:CAPTure:STARt

Note:

Capture cannot be started simultaneously at multiple MD1260A units.

Example of Use

To start capture as follows:

1. Send :CALCulate:CAPTure:STARt:EVENT? to clear the start event.
2. Send :CALCulate:CAPTure:STARt to start capture.
3. Send repeatedly until :CALCulate:CAPTure:STARt:EVENT? response is 1 (start).

:CALCulate:CAPTure:STARt:EVENT?

Function

This command queries whether to start capture or not.

Syntax

:CALCulate:CAPTure:STARt:EVENT?

Response Data

0|1

- 1: Becomes 1 when capture starts and cleared to 0 at read
- 0: Before capture starts

Note:

Capture starting conditions cannot be queried at multiple MD1260A units.

Example of Use

Refer to the Example of Use for :CALCulate:CAPTure:STARt.

:CALCulate:CAPTure:STATus**Function**

This command queries whether to read capture data.

Syntax

:CALCulate:CAPTure:STATus?

Response Data

0|1

0: Can read capture data

1: Capturing

Capturing is the state when data processing after starting capture is not complete such as when waiting for the trigger or capturing data after capture stops.

When reading captured data at this time, there may be an attempt to read previously captured data and the expected data may not be captured.

Note:

It is not possible to query the existence of capture data for multiple MD1260A units.

Example of Use

Refer to the example for :CALCulate:CAPTure:STOP.

:CALCulate:CAPTure:STOP

Function

This command is sent to forcibly stop capture when in the trigger wait state.

Capture is stopped automatically after starting after the trigger occurs. Consequently, it is not necessary to send this command after capture starts.

Syntax

:CALCulate:CAPTure:STOP

Note:

Capture at multiple MD1260A units cannot be stopped simultaneously.

Example of Use

To stop capture:

1. Stop capture by sending :CALCulate:CAPTure:STOP.
2. Send repeatedly until the :CALCulate:CAPTure:STATus? response becomes 0 (stopped).
3. Send repeatedly until the :CALCulate:CAPTure:DATA:SIZE? response becomes 1 or more.

:CALCulate:CAPTure:TRIGger

Function

This command queries whether a trigger has occurred after capture start.

Syntax

:CALCulate:CAPTure:TRIGger?

Response Data

0 | 1

0: Trigger not generated

1: Trigger generated

Starting capture clears the setting to 0.

Note:

Trigger occurrence query for multiple MD1260A is unavailable.

:CALCulate:CAPTure:TRIGger:MANual

Function

This command generates the manual trigger when the OTU3 or OTU4 applications capture trigger is Manual.

Syntax

:CALCulate:CAPTure:TRIGger:MANual

:CALCulate:CAPTure:TRIGger:POSition

Function

This command sets and queries the capture trigger position of the OTU3 or OTU4 application.

Syntax

:CALCulate:CAPTure:TRIGger:POSition TOP|MIDDLE

:CALCulate:CAPTure:TRIGger:POSition?

TOP: The top of the memory is the trigger position

MIDDLE: The middle of the memory is the trigger position

Response Data

TOP|MIDDLE

:CALCulate:CAPTure:TRIGger:TYPE

Function

This command sets and queries the capture trigger type of the OTU3 or OTU4 application.

Syntax

:CALCulate:CAPTure:TRIGger:TYPE <CHAR>

:CALCulate:CAPTure:TRIGger:TYPE?

Trigger	<CHAR>	Capture target				
		FRAME	GMP	GMP (Low order)	OH	OH (Low order)
Manual	MANUAL	✓	✓	✓	✓	✓
MFAS = 0	MFAS0	–	–	–	✓	✓
MFAS	MFAS<NR1> *1	✓	–	–	–	–
FAS	FAS	–	–	–	✓	✓
OMFI	OMFI<NR1> *2	✓	–	–	–	–
SM-BIP8	SM_BIP8	✓	–	–	✓	–
PM-BIP8	PM_BIP8	✓	–	–	✓	✓
OOF	OOF	–	–	–	✓	✓
OOM	OOM	✓	–	–	✓	✓
ODU-AIS	AIS_ODU	✓	–	–	✓	✓
ODU-OCI	OCI	✓	–	–	✓	✓
ODU-LCK	LCK	✓	–	–	✓	✓
MSIM	MSIM *3	✓	–	–	✓	–
Lock->Unlock	LOCK_UNLOCK	–	✓	✓	–	–
Unlock->Lock	UNLOCK_LOCK	–	✓	✓	–	–
CRC8 Error	GMP_CRC8	–	✓	✓	–	–
CRC5 Error	GMP_CRC5	–	✓	–	–	–

*1: <NR1>=0~255

*2: For OTU3, <NR1> = 0 to 31. For OTU4, <NR1> = 0 to 79.

*3: Can be set with the mapping below.

ODTU4.8-ODU2e-PRBS, ODTU4.8-ODU2e-10GbE,

ODTU4.1-ODU0-PRBS, ODTU4.1-ODU0-GbE

Response Data

<CHAR>

:CALCulate:CAPTure:TYPE**Function**

This command sets and queries the capture target of the OTU3 or OTU4 application.

Syntax

```
:CALCulate:CAPTure:TYPE FRAME|GMP|GMP_L|OH|OH_L
:CALCulate:CAPTure:TYPE?
```

FRAME:	Frame
GMP:	(High order) Cm(t), decode
GMP_L:	Low order Cm(t), decode
OH:	(High order) overhead
OH_L:	Low order overhead

Response Data

```
FRAME|GMP|GMP_L|OH|OH_L
```

Example of Use

Set the capture condition as follows:

Capture target	FRAME
Trigger position	TOP
Trigger type	MFAS=16

```
:CALCulate:CAPTure:TYPE FRAME
:CALCulate:CAPTure:POSition TOP
:CALCulate:CAPTure:TYPE MFAS16
```

:CALCulate:COUNTER:ETHER:OVERsize

Function

This command sets the counter oversize.

Syntax

```
:CALCulate:COUNTER:ETHER:OVERsize <NR1>  
:CALCulate:COUNTER:ETHER:OVERsize?
```

<NR1>

This sets the Oversize evaluation threshold value in byte units.

Response Data

<NR1>

Example of Use

```
:CALCulate:COUNTER:ETHER:OVERsize 1522  
:CALCulate:COUNTER:ETHER:OVERsize?  
> 1522
```

:CALCulate:COUNTER:FLOW:FIELD

Function

This command sets the field and bit range when the Test Frame counter filter method is User Defined or User Defined and Flow ID.

Syntax

```
:CALCulate:COUNTER:FLOW:FIELD  
<format>, <field>, <offset>, <length>  
:CALCulate:COUNTER:FLOW:FIELD?
```

<format>=<STRING>

<field>=<CHAR>

<offset>, <length>=<NR1>

For details on the <format> character string, refer to :SOURCE:STREAM:HEADER.

Specify the string in the following table to <field>. Fields not in this table cannot be set.

Table 3.3.2-3 String to Specify Field

<field>	Field Name
MPLS_TP_DA	MPLS-TP Destination Address
MPLS_TP_SA	MPLS-TP Source Address
MPLS_TP_LABEL{1 2 3 4 5}	MPLS-TP Label
MPLS_TP_EXP{1 2 3 4 5}	MPLS-TP Experimental Use
MPLS_TP_BTM{1 2 3 4 5}	MPLS-TP Bottom of Stack
MPLS_TP_TTL{1 2 3 4 5}	MPLS-TP Time to Live
CW_NIB	PWMCW First nibble
CW_FLAG	PWMCW Flag
CW_FRG	PWMCW FRG
CW_LENGTH	PWMCW Length
CW_SEQ	PWMCW Sequence Number
PBB_DA	PBB Destination Address
PBB_SA	PBB Source Address
PBB_{B I}_TPID	PBB TPID
PBB_{B I}_PCP	PBB PCP
PBB_{B I}_DEI	PBB DEI
PBB_B_VID	PBB VID
PBB_I_SID	PBB SID
PBB_I_RSV	PBB reserved
ETH_DA	Ethernet Destination Address
ETH_SA	Ethernet Source Address
ETH_TYPE	Ethernet Type
VLAN_{1 2}_TPID	Ethernet VLAN TPID
VLAN_{1 2}_PCP	Ethernet VLAN PCP
VLAN_{1 2}_CFI	Ethernet VLAN CFI
VLAN_{1 2}_VID	Ethernet VLAN DEI
MPLS_LABEL{1 2 3}	MPLS Label
MPLS_EXP{1 2 3}	MPLS Experimental Use
MPLS_TTL{1 2 3}	MPLS Time to Live

Table 3.3.2-3 String to Specify Field (Continued)

<field>	Field Name
IPV4_VER	IPv4 Version
IPV4_HLEN	IPv4 Header Length
IPV4_TOS	IPv4 ToS
IPV4_PLEN	IPv4 Packet Length
IPV4_ID	IPv4 Identification
IPV4_FLAG	IPv4 Flags
IPV4_OFFSET	IPv4 Fragment Offset
IPV4_TTL	IPv4 TTL
IPV4_PROT	IPv4 Protocol
IPV4_CHKSUM	IPv4 Header Checksum
IPV4_SA	IPv4 Source Address
IPV4_DA	IPv4 Destination Address
IPV6_VER	IPv6 Version
IPV6_TCLASS	IPv6 Traffic Class
IPV6_FLABEL	IPv6 Flow Label
IPV6_PLEN	IPv6 Packet Length
IPV6_NEXT	IPv6 Next Header
IPV6_HOP	IPv6 Hop Limit
IPV6_SA	IPv6 Source Address
IPV6_DA	IPv6 Destination Address
ARP_SMAC	ARP Source MAC Address
ARP_SIP	ARP Source IP Address
ARP_TMAC	ARP Target MAC Address
ARP_TIP	ARP Target IP Address
ARP_OPE	ARP Operation
ICMPV4_CODE	ICMPv4 Code
ICMPV4_EC_ID	ICMPv4 Identifier
ICMPV4_EC_SEQ	ICMPv4 Sequence No.
ICMPV6_CODE	ICMPv6 Code
ICMPV6_EC_ID	ICMPv6 Identifier
ICMPV6_EC_SEQ	ICMPv6 Sequence No.
ICMPV6_NSNA_TADDR	ICMPv6 Target Address
ICMPV6_NSNA_SADDR	ICMPv6 Source Link Layer Address

Response Data

<format>,<field>,<offset>,<length>

Example of Use

```
:CALCulate:COUNTER:FLOW:FIELD
USER_DEFINED,"ETHERNET",SOURCE_ADDRESS,8,8
:CALCulate:COUNTER:FLOW:FIELD?
> USER_DEFINED,"ETHERNET",SOURCE_ADDRESS,8,8
```


:CALCulate:COUNTER:FLOW:FIELD:ID**Function**

This command sets the filter value of the Test Frame counter. The number of parameters depends on the filter method and test frame count.

Syntax

```
:CALCulate:COUNTER:FLOW:FIELD:ID
MONITOR,<filter>,<num>,<id>,...,<id>
:CALCulate:COUNTER:FLOW:FIELD:ID?
```

<filter>=TEST_FRAME|TF_AND_UD|USER_DEFINED

TEST_FRAME:	Test Frame Flow ID
TF_AND_UD:	User Defined and Flow ID
USER_DEFINED:	User Defined

<num>=<NR1>

When <filter>=TEST_FRAME: <id>=<flow_id>

When <filter>=USER_DEFINED: <id>=<user_id>

When <filter>=TF_AND_UD: <id>=<flow_id>,<user_id>

<flow_id>,<user_id>=<NR1>|<BINARY>|<HEX>

<flow_id> and <user_id> can be set also in a hexadecimal format and binary format.

Response Data

```
MONITOR,<filter>,<num><id>,...,<id>
```

<id> is in a hexadecimal format.

Example of Use

```
:CALCulate:COUNTER:FLOW:FIELD:ID MONITOR,USER_DEFIND,
8,#H10,#H20,#H30,#H40,#H50,#H60,#H70,#H80
:CALCulate:COUNTER:FLOW:FIELD:ID?
> MONITOR,USER_DEFIND,8,#H10,#H20,#H30,#H40,#H50,#H60,
#H70,#H80
```

:CALCulate:COUNTER:FLOW:FIELD:NFID

Function

This command queries the test frame count of the Test Frame counter.

Syntax

```
:CALCulate:COUNTER:FLOW:FIELD:NFID?
```

Response Data

```
<NR1>
```

Example of Use

```
:CALCulate:COUNTER:FLOW:FIELD:NFID 15
:CALCulate:COUNTER:FLOW:FIELD:NFID?
> 15
```

:CALCulate:COUNTER:FLOW:TYPE

Function

This command sets the filter method of the Test Frame counter.

Syntax

```
:CALCulate:COUNTER:FLOW:TYPE <filter>
:CALCulate:COUNTER:FLOW:TYPE?
```

<filter>=TEST_FRAME|TF_AND_UD|USER_DEFINED

TEST_FRAME: Test Frame Flow ID

TF_AND_UD: User Defined and Flow ID

USER_DEFINED: User Defined

Response Data

```
TEST_FRAME|TF_AND_UD|USER_DEFINED
```

Example of Use

```
:CALCulate:COUNTER:FLOW:TYPE TEST_FRAME
:CALCulate:COUNTER:FLOW:TYPE?
> TEST_FRAME
```

:CALCulate:COUNTER:GAP**Function**

This command sets the measurement range of the Gap Size counter.

Syntax

```
:CALCulate:COUNTER:GAP <min>, <step>
```

<min>, <step>=<NR1>

:CALCulate:COUNTER:SERRor**Function**

This command sets whether to stop the test frame counter at a sequence error.

Syntax

```
:CALCulate:COUNTER:SERRor 0|1|ON|OFF
```

```
:CALCulate:COUNTER:SERRor?
```

ON|1: Stops test frame counter at sequence error

OFF|0: Does not stop test frame counter at sequence error

Response Data

0|1

:CALCulate:COUNTER:START[:AUNit]

Function

This command starts counting.

If the counter is already running, it is restarted.

Adding :AUNit starts the counters of all units connected at the same time.

Syntax

`:CALCulate:COUNTER:START[:AUNit]`

Example of Use

To start counting:

1. Clear the start event by sending `:CALCulate:COUNTER:START:EVENT?`.
2. Start counter by sending `:CALCulate:COUNTER:START`.
3. Send repeatedly until the `:CALCulate:COUNTER:START:EVENT?` response becomes 1 (started).

:CALCulate:COUNTER:START:EVENT[:AUNit]

Function

This command queries the counter start event.

Syntax

`:CALCulate:COUNTER:START:EVENT[:AUNit]?`

Response Data

0|1

0: 0 before counter started

1: Cleared to 0 after reading with this command

Adding :AUNit to the header sets the counter of all connected units to 1 when started.

Example of Use

Refer to the example for `:CALCulate:COUNTER:START[:AUNit]`.

:CALCulate:COUNTER:STATus[:AUNit]**Function**

This command confirms the counter operating status.

Syntax

`:CALCulate:COUNTER:STATus[:AUNit]?`

Response Data

0|1

0: Stops operation

1: Running

Adding :AUNit to the header returns 1 when any one of the connected units is started, and 0 when all counters are stopped.

Example of Use

Refer to the example for `:CALCulate:COUNTER:STOP[:AUNit]` .

:CALCulate:COUNTER:STOP[:AUNit]**Function**

This command stops the counter.

Adding :AUNit stops the counters of all connected units.

Syntax

`:CALCulate:COUNTER:STOP[:AUNit]`

***Relationship with Port ID commands**

The value of this event is the logical product of the event for each port. Immediately after 1 is read by this command, the event value for each port is cleared to 0.

Example of Use

To stop counter:

1. Stop counter by sending `:CALCulate:COUNTER:STOP`.
2. Send repeatedly until the `:CALCulate:COUNTER:STATus?` response becomes 0 (stopped).

:CALCulate:DATA

Function

This command queries the measurement results.

Syntax

```
:CALCulate:DATA? <item>[,<item>,...]
```

<item>=<CHAR>

Sets the ID of the measurement items to be acquired.

For the ID to be set, refer to Appendix A Measurement Item List.

Multiple IDs can be set using comma (,) separators.

However, if the response data string overflows the buffer size (65536 characters), an error is returned (-310,"System error").

Response Data

```
<value>[,<value>,...] | -----
```

Measurement data of set ID

The data format varies according to the set items.

It becomes ----- when the measurement data is disabled.

The measurement items per lane are queried, separated by commas (,).

When capturing the counter value, select the type of data to be captured (Current or Accumulated) using :CALCulate:DATA:TYPE.

Example of Use

To query the Rx clock frequency (Hz and ppm):

```
:CALCulate:DATA? RX_FREQ,RX_FREQ_D  
> 103125000000,0.0
```

:CALCulate:DATA:TYPE**Function**

This command sets and queries the counter data types.

Syntax

```
:CALCulate:DATA:TYPE ACCUM|CURRENT
:CALCulate:DATA:TYPE?
```

CURRENT : Current
ACCUM : Accumulated

Response Data

ACCUM|CURRENT

Example of Use

To query Counter elapsed time, bit error count (Accumulated) and Rx clock frequency:

```
:CALCulate:DATA:TYPE ACCUM
:CALCulate:DATA? ELAPSED,BER_CNT,RX_FREQ
> 20,1,103135312400
```

:CALCulate:DElay:STARt[:AUNit]**Function**

This command starts the delay time measurement for the OTU3 or OTU4 application.

[Delay Settings] Mode is [Single].

Adding :AUNit starts the delay time measurements for all units connected at the same time.

Syntax

```
:CALCulate:DElay:STARt
```

Example of Use

To wait for the start of the delay time measurement:

1. Send :CALCulate:DElay STARt to start the capture.
2. Send :CALCulate:DElay:STARt:EVENT? repeatedly until the response data becomes 1 (started).
3. Send :CALCulate:DElay:STARt:STATus? repeatedly until the response data becomes 0 (measurement result readable).
4. Read the measurement result with :CALCulate:DATA? PM_DELAY.

:CALCulate:DElay:STARt:EVENT[:AUNit]

Function

This command queries whether the delay time measurement for the OTU3 or OTU4 application has been started.

Syntax

`:CALCulate:DElay:STARt:EVENT?`

Response Data

0|1

- 1: Becomes 1 when the delay time measurement is started. After reading, it is cleared to 0.
- 0: The delay time measurement has not been started.

Example of Use

Refer to the example for `:CALCulate:DElay:STARt[:AUNit]`.

:CALCulate:DElay:STATus[:AUNit]

Function

This command queries whether the delay time measurement result for the OTU3 or OTU4 application can be read.

Syntax

`:CALCulate:DElay:STATus?`

Response Data

0|1

- 0: The delay time measurement result can be read.
- 1: The delay time measurement in progress
"The delay time measurement in progress" means the status where the measurement result is unavailable because the measurement time has not passed.
When delay time measurement result is read at this time, expected measurement results may not be obtained because the delay time measured last time may be read in some cases.

Example of Use

Refer to the example for `:CALCulate:DElay:STOP[:AUNit]`.

:CALCulate:DElay:STOP[:AUNit]**Function**

This command is sent when the delay time measurement for the OTU3 or OTU4 application is to be stopped.

The delay time measurement stops automatically when the measurement time passes. Therefore, this command does not have to be sent after the measurement time has passed.

Adding :AUNit stops the delay time measurements for all units connected.

Syntax

:CALCulate:DElay:STOP

:CALCulate:EALarm[:AUNit]**Function**

This command queries the Error/Alarm LED status in the summary status/time display area.

Syntax

:CALCulate:EALarm[:AUNit]?

Response Data

0|1|2

Omitting AUNit displays the information only for units set by :UENTry:ID.

- 0: Normal (green)
- 1: Abnormal (red)
- 2: History (orange)

Adding AUNit to the header displays the following status.

- 0: All connected units normal (green)
- 1: One or more connected units abnormal status (red)
- 2: One or more connected units has history log (orange)
No connected units have had abnormal status (red)

Example of Use

When error/alarm does not occur:

```
:CALCulate:EALarm?  
> 0
```

:CALCulate:MONitor:OTU:COLumn

Function

This command sets and queries the read header column when the OTU data monitor is in Frame display.

Syntax

:CALCulate:MONitor:OTU:COLumn <NR1>

:CALCulate:MONitor:OTU:COLumn?

<NR1>: Column number (1 to 4065)

Response Data

<NR1>

Example of Use

Refer to the example for :CALCulate:MONitor:OTU:DATA.

:CALCulate:MONitor:OTU:DATA

Function

This command queries the monitor value of the OTU frame. The header column of the OTU frame monitor data is set by the command, :CALCulate:MONitor:OTU:COLumn.

Syntax

:CALCulate:MONitor:OTU:DATA? [<offset>,<length>]

<offset>=<NR1>: Column number

<length>=<NR1>: Data length

Omitting <offset> and <length> makes the response data the maximum number of bytes data.

The maximum value that can be specified to the data length depends on the setting of :CALCulate:MONitor:OTU:TYPE.

FRAME, FRAME_L: 64, FTFL, FTFL_L: 255, MSI: 80, TTI: 64

Response Data

The response data depends on the setting of :CALCulate:MONitor:OTU:TYPE.

Type of Monitor Data	Response Data	Format
FRAME, FRAME_L	<STRING>	Up to 64 bytes hexadecimal by 1 byte with "," separator. Set the top column of the OTU frame monitor data to be obtained with the :CALCulate:MONitor:OTU:COLumn command.
FTFL	<STRING>	Up to 256 bytes hexadecimal by 1 byte with "," separator
MSI	<STRING>	Up to 80 bytes hexadecimal by 1 byte with "," separator
TTI_PM, TTI_PM_L, TTI_SM, TTI_TCM {1 2 3 4 5 6}	<STRING>	Up to 64 bytes hexadecimal by 1 byte with "," separator

Note:


Wait at least 1 second before capturing column data in case of the following cases.

The column of the frame to be captured has been changed with :CALCulate:MONitor:OTU:COLumn.

Example of Use

To capture the data of column 8 to 14 in the first column of the OUT frame:

```
:CALCulate:MONitor:OTU:TYPE FRAME
:CALCulate:MONitor:OTU:COLumn 1
:CALCulate:MONitor:OTU:DATA? 7,7
>"00,C8,00,00,00,00,00"
```




To capture 16 bytes of SM-TTI data:

```
:CALCulate:MONitor:OTU:TYPE TTI_SM
```

```
:CALCulate:MONitor:OTU:DATA? 16,16
```

```
>"00,4A,50,4E,4D,44,31,32,36,30,41,20,20,20,20,20"
```



:CALCulate:MONitor:OTU:TYPE**Function**

This command sets and queries the monitor data type for the OUT frame.

Syntax

```
:CALCulate:MONitor:OTU:TYPE <CHAR>
```

```
:CALCulate:MONitor:OTU:TYPE?
```

<CHAR>

The header bit becomes bit0.

<CHAR>	Type of Monitor Data
FRAME	() OTU Frame *1
FRAME_L	Low order OTU frame
FTFL	FTFL *1
FTFL_L	Low order FTFL
MSI	MSI
TTI_PM	PM-TTI *1
TTI_PM_L	Low order PM-TTI
TTI_SM	SM-TTI
TTI_TCM{1 2 3 4 5 6}	TCM{1 2 3 4 5 6}-TTI

*1: For the mapping of ODTU4.1 or ODTU4.8, the high order data is specified.

*2: Stuff monitor data cannot be captured with the remote command.

Response Data

<CHAR>

Example of Use

```
:CALCulate:MONitor:OTU:TYPE FTFL
```

```
:CALCulate:MONitor:OTU:TYPE?
```

```
> FTFL
```

```
:CALCulate:MONitor:OTU:TYPE TTI_TCM3
```

```
:CALCulate:MONitor:OTU:TYPE?
```

```
> TTI_TCM3
```

:CALCulate:TRIGger:CONDition

Function

This command sets and queries the capture trigger condition for the 100 GbE or 40 GbE application.

Syntax

```
:CALCulate:TRIGger:CONDition <BINARY>  
:CALCulate:TRIGger:CONDition?
```

At <BINARY>, the bit for enabling the trigger conditions is set to 1. The header bit becomes 0.

bit	Trigger Condition
0	Good Frame
1	LF(Local Fault)
2	RF(Remote Fault)
3	Error Signal
4	FCS Error
5	Undersize
6	Fragment
7	Oversize
8	Oversize & FCS
9-31	Reservation

Response Data

<<BINARY>>

The bit length is 32 bits.

Example of Use

To set Any Frame to the trigger condition:

```
:CALCulate:TRIGger:CONDition #B100011111  
:CALCulate:TRIGger:CONDition?  
> #B10001111100000000000000000000000
```

To set Any Frame Error to trigger condition:

```
:CALCulate:TRIGger:CONDition #B000011111
```

To set Any MII Error to trigger condition:

```
:CALCulate:TRIGger:CONDition #B0111
```

To set Any Error to the trigger condition:

```
:CALCulate:TRIGger:CONDition #B011111111
```

:MDIO:READ**Function**

This command queries the value of the CFP MDIO register.

Syntax

```
:MDIO:READ? <address>
```

<address>=<HEX>

Register address (#H0000 to #HFFFF)

Response Data

<value>=<HEX>

This is the register value to be read. (#H0000 to #HFFFF)

Example of Use

To read 0xA016 details of MDIO register:

```
:MDIO:READ? #HA016  
> #H0020
```

:MDIO:WRITE**Function**

This command sets the value of the CFP MDIO register.

Syntax

```
:MDIO:WRITE <address>,<value>
```

<address>=<HEX>

Register address (#H0000 to #HFFFF)

<value>=<HEX>

Register value (#H0000 to #HFFFF)

:MMEMory:CATalog

Function

This command queries the setting file information to be saved in the following places.

C:\Documents and Settings\Administrator

\My Documents\Anritsu\MD1260A\UserData\Setting

Syntax

:MMEMory:CATalog?

Response Data

<NR1> [,<file_entry>,...]

<NR1>: Number of the setting file to be saved

The file extension is the number of the MD1260A setting file.

<file_entry>

The following is output in comma-separated format for each setting file.

<file_name>: <STRING> Format file name

Including extension of file name

<file type>: Setting file types

E40G: 40GbE

E40G_N: 40GbE No Frame

E100G: 100GbE

E100G_N: 100GbE No Frame

OTU3: OTU3

OTU3_N: OTU3 No Frame

OTU4: OTU4

OTU4_E: ODU4-100GbE

OTU4_ODU2E: ODTU4.8-ODU2e-PRBS

OTU4_ODU2E_E: ODTU4.8-ODU2e-10GbE

OTU4_ODU0: ODTU4.1-ODU0-PRBS

OTU4_ODU0_E: ODTU4.1-ODU0-GbE

OTU4_N: OTU4 No Frame

Example: Response data when the following files are in folder

1. 100 GbE setting file called "Setup100GbE"

2. OTU4 setting file called "SetupOTU4"

> 2, "Setup100GbE", E100G, "SetupOTU4", OTU4, "AllSamp", ALL

Example: Response data when no files in folder

> 0

Example of Use

1. To check currently loading application:

```
:SOURce:MAPPing?
> E100G
```

2. To check file to be saved:

```
:MMEMory:CATalog?
> 2, "Setup100GbE", E100G, "SetupOTU4", OTU4
```

3. To read setting file of currently loading application:

```
:MMEMory:RECall "Setup100GbE"
```

4. To save current measurement result:

```
:MMEMory:STORE "Result100GbE", RESULT
```

:MMEMory:INITialize**Function**

This command returns the settings for the MD1260A with the Unit ID specified by to the factory defaults.

However, the following contents are not returned to the factory defaults.

- GPIB address and Windows settings such as IP address
- Transceiver settings
 - :SOURce:TRANsceiver:EMPHasis:FIRSt
 - :SOURce:TRANsceiver:EMPHasis:PRE
 - :SOURce:TRANsceiver:EMPHasis:SECOnd
 - :SOURce:TRANsceiver:VOD
 - :SENSe:TRANsceiver:EQUalizer:CONTRol
 - :SENSe:TRANsceiver:EQUalizer:DCGain
- Response terminator setting (:SYSTem:TERMination)

Syntax

```
:MMEMory:INITialize
```

Example of Use

To initialize unit with Unit ID2:

```
:UENTry:ID 2
:MMEMory:INITialize
```

:MMEMory:LOG:FNAME

Function

This command queries the latest log file name.
When multiple units are connected, the log file of the unit set by :UENTry:ID is queried.

Syntax

:MMEMory:LOG:FNAME?

Response Data

<STRING>: Following file name or ""

- During Log operation: Name of currently output Log file
- Not during Log operation: Name of Log file output immediately previously
- When not outputting Log file again after running application: Empty string ""

Example of Use

```
:MMEMory:LOG:FNAME?  
> "Test20100301T123456_U010000_0.csv"
```

:MMEMory:LOG:ITEM

Function

This sets the items out to the Log.
When multiple units are connected, the item output to the log for the unit set by :UENTry:ID is set.

Syntax

```
:MMEMory:LOG:ITEM <id1>[,<id2>,...]  
:MMEMory:LOG:ITEM?
```

<id>

Specifies ID of items output to Log
To set the ID, refer to Appendix A Measurement Item List.
ID can be specified as a comma-separated order.

Response Data

<id1>[,<id2>,...]|OFF

When there are no output items, it becomes OFF.

Example of Use

```
:MMEMory:LOG:ITEM?  
> OFF
```

:MMEMory:LOG:PREFix**Function**

This command sets the header of the character strings for the log file name.

When multiple units are connected, the same character string is set at all units.

Syntax

```
:MMEMory:LOG:PREFix <STRING>
```

```
:MMEMory:LOG:PREFix?
```

<STRING>

To set the header of the character strings for the log file name to Test

Example: "Test"

Response Data

<STRING>

Example of Use

```
:MMEMory:LOG:PREFix "Test"
```

```
:MMEMory:LOG:PREFix?
```

```
"Test"
```

:MMEMory:LOG:STARt**Function**

This command starts Log output. If the Log is already being output, it creates a new Log file and starts Log output.

When multiple units are connected, the log output is started at all units.

Syntax

```
:MMEMory:LOG:STARt
```

Example of Use

Refer to the example for :MMEMory:LOG:STATus.

:MMEMory:LOG:STATus

Function

This command queries the Log output operation status.

Syntax

```
:MMEMory:LOG:STATus?
```

Response Data

0|1

0: Log output stopped

1: Outputting Log

Displays following when multiple units connected

0: Log output stopped for all units

1: Outputting Log for one or more units

Example of Use

```
:MMEMory:LOG:START  
:MMEMory:LOG:STATus?  
> 1
```

:MMEMory:LOG:STOP

Function

This command stops Log output.

When multiple units are connected, the log output is stopped at all units.

Syntax

```
:MMEMory:LOG:STOP
```

Example of Use

```
:MMEMory:LOG:STOP  
:MMEMory:LOG:STATus?  
> 0
```

:MMEMory:LOG:TIMing**Function**

This command sets the timing of the log output.

When multiple units are connected, the same log output timing is set at all units.

It also queries the timing setting of the log output.

Syntax

```
:MMEMory:LOG:TIMing <CHAR>
```

```
:MMEMory:LOG:TIMing?
```

<CHAR>

Select as follows:

E1S : Every 1 s

E10S : Every 10 s

E1MIN : Every 1 minute

ERROR : When error occurs

Response Data

<CHAR>

Example of Use

```
:MMEMory:LOG:TIMing E1S
```

```
:MMEMory:LOG:TIMing?
```

```
> E1S
```

:MMEMory:RECall[:AUNit]

Function

This command reads the application settings from a file.
Adding :AUNit reads the applications settings files for all connected units.

Syntax

`:MMEMory:RECall[:AUNit] <filename>[,<select>]`

`<filename>=<STRING>`

Set the name of the file to be read in <STRING> format.
The file name does not include the directory or extension.

This command reads the settings file that matches the currently running application.

`<select>=<CHAR>`

Set the range in the <CHAR> format when only specific information is selected among information included in the file to be loaded.

STREAM : Only Stream setting information in the file

If this parameter is omitted, all information items in the file will be loaded.

For :MMEMory:RECall:AUNit, this parameter is omitted and all information items in the file are loaded.

If a difference is detected between the current configuration and unit configuration saved in the file, the -310 (System) error is returned.

Example of Use

To read settings file for file named "Setup100GbE" in unit specified by :UENTry:ID:

```
:MMEMory:RECall "Setup100GbE"
```

To read the settings file for file named "SetupAll" in all units.

```
:MMEMory:RECall:AUNit "SetupAll"
```

:MMEMory:STORe[:AUNit]**Function**

This command saves the application settings.

Adding :AUNit saves the applications settings files for all connected units

The measurement results report is output.

Adding :AUNit outputs the a measurement results report for all connected units.

Syntax

```
:MMEMory:STORe[:AUNit] <filename>,RESULT|SETUP
```

<filename>

Set the name of the file to be saved in <STRING> format.

The file name does not include the directory or extension.

Select the saved contents from the following.

SETUP: Sets application

RESULT: Outputs the report of the measurement result

Example of Use

Refer to the example for :MMEMory:CATalog.

Example: To save the settings file for the unit specified by :UENTry:ID as the file named "Setup100GbE".

```
:MMEMory:STORe "Setup100GbE",SETUP
```

Example : To save the settings file for the unit specified by :UENTry:ID as the file named " Result100GbE".

```
:MMEMory:STORe "Result100GbE",RESULT
```

Example: To save the settings file for all units as the file named " SetupAll ".

```
:MMEMory:STORe:AUNit "SetupAll",SETUP
```

Example: To save the settings file for all unit results as the file named " ResultAll ".

```
:MMEMory:STORe:AUNit "ResultAll",RESULT
```

:MMEMory:STORe:CAPTure

Function

This command saves the currently displayed capture data to the file.

Syntax

```
:MMEMory:STORe:CAPTure <filename>
```

<filename>

The file name to be saved (not including the directory name and extension) is specified in <STRING> format.

For the 40GbE or 100GbE application, the contents to be output to the file is specified with :MMEMory:STORe:CAPTure:ITEM.

When the captured data is not displayed, the -310 (System) error is displayed.

Captured data files cannot be saved for all connected multiple units.

:MMEMory:STORe:CAPTure:ITEM

Function

This command sets the file output item of the capture data.

Syntax

```
:MMEMory:STORe:CAPTure:ITEM <id>
```

<id>

To set any of the following:

LIBPCAP : Creates nsec libpcap format (*.pcap) file

TEXT_TABLE: Outputs contents of summary area as text file

TEXT_BYTES: Outputs all data contents of detailed areas as text file

Capture file output items cannot be specified for all connected multiple units.

:MMEMory:STReam:RECall**Function**

This command reads out only the stream information from the application setting file.

It can be used with 40GbE/100GbE application.

Syntax

```
:MMEMory:STReam:RECall <filename>[,<file_type>]
```

<filename>=<STRING>

Set the file name to be loaded. The file name does not include a directory name and extension.

<file_type>=E100G | E40G

E100G: 100GbE measurement condition file

E40G: 40GbE measurement condition file

If <file_type> is omitted, the measurement condition file of the currently running application will be set.

-310 (System error) is returned when the specified file has been saved with Frame BERT [On].

Example of Use

To load the setting file with the name of "MPLS_IPv4_100GbE" to the unit set with :UENTry:ID.

```
:MMEMory:STReam:RECall " MPLS_IPv4_100GbE", E100G
```

:PROTOcol:ARPNS:REPLY:ENABLE

Function

This command sets whether to send ARP/NA responses to Streams 1 to 16 and queries whether it is set to send ARP/NA responses to Streams 1 to 16.

Syntax

```
:PROTOcol:ARPNS:REPLY:ENABLE <NR1>,<NR1>,...,<NR1>  
:PROTOcol:ARPNS:REPLY:ENABLE?
```

<NR1>=0|1

- 0: Not transmitting ARP reply
- 1: Transmitting ARP reply

Response Data

<NR1>,<NR1>,...,<NR1>

Example of Use

To send ARP/NA responses to Streams 1 to 8 and not to send ARP/NA responses to Streams 9 to 16.

```
:PROTOcol:ARPNS:REPLY:ENABLE  
1,1,1,1,1,1,1,1,0,0,0,0,0,0,0,0  
:PROTOcol:ARPNS:REPLY:ENABLE?  
> 1,1,1,1,1,1,1,1,0,0,0,0,0,0,0,0
```

:PROTOCOL:GARPns:DURATION:TYPE

Function

This command sets the method of sending GARP or NS.

Syntax

```
:PROTOCOL:GARPns:DURATION:TYPE <char>  
:PROTOCOL:GARPns:DURATION:TYPE?
```

<char>=REPEAT|SINGLE

REPEAT: Repeat

SINGLE: Single

Response Data

REPEAT|SINGLE

Example of Use

```
:PROTOCOL:GARPns:DURATION:TYPE SINGLE  
:PROTOCOL:GARPns:DURATION:TYPE?  
> SINGLE
```

:PROTocol:GARPns:ENABle

Function

This command sets whether to send GARP or NS to Streams 1 to 16 and queries whether it is set to send GARP or NS to Streams 1 to 16.

Syntax

```
:PROTocol:GARPns:ENABle <NR1>,<NR1>,...,<NR1>  
:PROTocol:GARPns:ENABle?
```

<NR1>=0|1

0: Not transmitting GARP/NS reply
1: Transmitting GARP/NS

Response Data

<NR1>,<NR1>,...,<NR1>

Example of Use

To send GARP or NS to Streams 1 to 8 and not to send GARP or NS to Streams 9 to 16.

```
:PROTocol:GARPns:ENABle 1,1,1,1,1,1,1,1,0,0,0,0,0,0,0,0  
:PROTocol:GARPns:ENABle?  
> 1,1,1,1,1,1,1,1,0,0,0,0,0,0,0,0
```

:PROTocol:GARPns:INTerval

Function

This command sets and queries the interval time of sending ARP or NS packets.

Syntax

```
:PROTocol:GARPns:INTerval <NR1>  
:PROTocol:GARPns:INTerval?
```

<NR1>=1 to 100

Response Data

<NR1>

Example of Use

To set the interval time of sending ARP or NS packets to 10:

```
:PROTocol:GARPns:INTerval 10  
:PROTocol:GARPns:INTerval?  
> 10
```

:PROTocol:GARPns:START**Function**

This command starts to send GARP or NS.

Syntax

```
:PROTocol:GARPns:START
```

:PROTocol:GARPns:STATUS**Function**

This command queries the status of sending GARP or NS.

Syntax

```
:PROTocol:GARPns:STATUS?
```

Response Data

```
0|1
```

```
0:   Sending GARP/NS completed.
```

```
1:   Sending GARP/NS in progress.
```

Example of Use

```
:PROTocol:GARPns:START
```

```
:PROTocol:GARPns:STATUS?
```

```
> 1
```

:PROTocol:GARPns:STOP**Function**

This command stops to send GARP or NS.

Syntax

```
:PROTocol:GARPns:STOP
```

Example of Use

```
:PROTocol:GARPns:STOP
```

```
:PROTocol:GARPns:STATUS?
```

```
> 0
```

:PROTOcol:GARPns:TYPE

Function

This command sets and queries the type of GARP.

Syntax

```
:PROTOcol:GARPns:TYPE <CHAR>
:PROTOcol:GARPns:TYPE?
```

<CHAR>=REPLY|REQUEST

REPLY: Reply

REQUEST: Request

Response Data

REPLY|REQUEST

Example of Use

```
:PROTOcol:GARPns:TYPE REQUEST
:PROTOcol:GARPns:TYPE?
> REQUEST
```

:PROTOcol:PING:COUNT

Function

This command sets and queries the number of times the Ping test will run.

Syntax

```
:PROTOcol:PING:COUNT <NR1>
:PROTOcol:PING:COUNT?
```

<NR1>=1 to 100

Response Data

<NR1>

Example of Use

```
:PROTOcol:PING:COUNT 20
:PROTOcol:PING:COUNT?
>20
```

:PROTocol:PING:DST:IPV4**Function**

This command sets and queries the target IP address (IPv4) for the Ping test.

Syntax

```
:PROTocol:PING:DST:IPV4 <HEX>
:PROTocol:PING:DST:IPV4?
```

<HEX>: Target IP address for the Ping test (4-byte hexadecimal number)

Example of Use

To set target IPv4 address for Ping test to 192.168.1.2 (0xC0A80102):

```
:PROTocol:PING:DST:IPV4 #HC0A80102
:PROTocol:PING:DST:IPV4?
>#HC0A80102
```

:PROTocol:PING:DST:IPV6**Function**

This command sets and queries the target IP address (IPv6) for the Ping test.

Syntax

```
:PROTocol:PING:DST:IPV6 <HEX>
:PROTocol:PING:DST:IPV6?
```

<HEX>: Target IP address for the Ping test (16-byte hexadecimal number)

Example of Use

To set target IPv6 address for Ping test to 2001::10:

```
:PROTocol:PING:DST:IPV6
#H2001000000000000000000000000000010
:PROTocol:PING:DST:IPV6?
>#H2001000000000000000000000000000010
```

:PROTocol:PING:DST:MAC

Function

This command sets and queries the target MAC address for the Ping test.

Syntax

```
:PROTocol:PING:DST:MAC <HEX>
:PROTocol:PING:DST:MAC?
```

<HEX>: Target MAC address for the Ping test (6-byte hexadecimal number)

Example of Use

To set target MAC address for Ping test to 0x0A0000123456:

```
:PROTocol:PING:DST:MAC #H0A0000123456
:PROTocol:PING:DST:MAC?
>#H0A0000123456
```

:PROTocol:PING:IPMode

Function

This command sets and queries the IP version of the Ping test.

Syntax

```
:PROTocol:PING:IPMode IPV4|IPV6
:PROTocol:PING:IPMode?
```

```
IPV4:      IPv4
IPV6:      IPv6
```

Response Data

IPV4|IPV6

Example of Use

```
:PROTocol:PING:IPMode IPV6
:PROTocol:PING:IPMode?
> IPV6
```


:PROTocol:PING:MACResolve**Function**

This command sets to turn on and off the MAC address resolution for the Ping test or queries the on/off state.

If the MAC address resolution is turned on, the target IP address automatically resolves the target MAC address.

Syntax

```
:PROTocol:PING:MACResolve 0|1|ON|OFF
:PROTocol:PING:MACResolve?
```

```
ON|1:      MAC Resolve On.
OFF|0:     MAC Resolve Off.
```

Response Data

```
0|1
```

Example of Use

```
:PROTocol:PING:MACResolve 1
:PROTocol:PING:MACResolve?
> 1
```

:PROTocol:PING:PAYLoad**Function**

This command sets and queries the pattern of packet payload for the Ping test.

Syntax

```
:PROTocol:PING:PAYLoad ALL0|ALL1|ALTERNATE
:PROTocol:PING:PAYLoad?
```

```
ALL0:      All 0
ALL1:      All 1
ALTERNATE: 0/1 bit
```

Response Data

```
ALL0|ALL1|ALTERNATE
```

Example of Use

```
:PROTocol:PING:PAYLoad ALL0
:PROTocol:PING:PAYLoad?
> ALL0
```

:PROTocol:PING:PSIZe:TYPE

Function

This command sets and queries the mode of packet size for the Ping test.

Syntax

```
:PROTocol:PING:PSIZe:TYPE FIX|INCREMENT  
:PROTocol:PING:PSIZe:TYPE?
```

FIX:	Fixed
INCREMENT:	Increment

Response Data

FIX|INCREMENT

Example of Use

```
:PROTocol:PING:PSIZe:TYPE FIX  
:PROTocol:PING:PSIZe:TYPE?  
> FIX
```

:PROTocol:PING:PSIZe:VALUe

Function

This command sets and queries the packet size for the Ping test.

Syntax

```
:PROTocol:PING:PSIZe:VALUe <start>[,<step>]  
:PROTocol:PING:PSIZe:VALUe?
```

<start>,<step>=<NR1>

<start>: Lower limit for packet size.

<step>: Change in packet size.

If the packet size increment is Off, then the value in <step> will be ignored.

Response Data

<NR1>,<NR1>

Example of Use

```
:PROTocol:PING:PSIZe:VALUe 64,8  
:PROTocol:PING:PSIZe:VALUe?  
> 64,8
```

:PROTOCOL:PING:REPLY:ENABLE**Function**

This command sets whether to send Ping responses to Streams 1 to 16 and queries whether it is set to send Ping responses to Streams 1 to 16.

Syntax

```
:PROTOCOL:PING:REPLY:ENABLE <NR1>,<NR1>,...,<NR1>
```

```
:PROTOCOL:PING:REPLY:ENABLE?
```

```
<NR1>=0|1
```

```
0:          Not transmitting Ping reply
```

```
1:          Transmitting Ping reply
```

Response Data

```
<NR1>,<NR1>,...,<NR1>
```

Example of Use

To send Ping responses to Streams 1 to 4 and not to send Ping responses to Streams 5 to 16.

```
:PROTOCOL:PING:REPLY:ENABLE
```

```
1,1,1,1,0,0,0,0,0,0,0,0,0,0,0,0
```

```
:PROTOCOL:PING:REPLY:ENABLE?
```

```
> 1,1,1,1,0,0,0,0,0,0,0,0,0,0,0,0
```

:PROTOCOL:PING:RESULT

Function

This command queries the result of the Ping test.

Syntax

:PROTOCOL:PING:RESULT? <CHAR>

<CHAR>=HISTORY1|HISTORY2|...|HISTORY32|TOTAL

HISTORY1 First result in the History table.

HISTORY2 Second result in the History table.

:

HISTORY32 32nd result in the History table.

TOTAL: Result in the Total table.

Response Data

If HISTORY1 to HISTORY32 is specified,

<from>=<HEX>: IP address

<size>=<NR1>: Packet size

<ttl>=<NR1>: TTL

<time>=<NR1>: Round trip time [ms]

Specifying the History number without measurement result causes a parameter error.

If TOTAL is specified,

<tx_arpreq>=<NR1>: Tx ARP Request

<rx_arprep>=<NR1>: Number of times to receive Rx ARP Reply.

<tx_pingreq>=<NR1>: Number of times to send Tx Ping Request.

<rx_pingrep>=<NR1>: Rx Ping Reply

<time_min>=<NR1>: Time Min.

<time_max>=<NR1>: Time Max.

<time_ave>=<NR1>: Time Ave.

<timeout>=<NR1>: Timeout

Example of Use

:PROTOCOL:PING:RESULT? HISTORY2

> #HC0A80101,128,128,10

:PROTocol:PING:SRC:MAC

Function

This command sets and queries the source MAC address for the Ping test.

Syntax

```
:PROTocol:PING:SRC:MAC <HEX>
:PROTocol:PING:SRC:MAC?
```

<HEX>: Source MAC address for Ping test (6-byte hexadecimal number)

Example of Use

To set source MAC address for Ping test to 0x0A0000123478:

```
:PROTocol:PING:DEST:MAC #H0A0000123478
:PROTocol:PING:DEST:MAC?
>#H0A0000123478
```

:PROTocol:PING:START

Function

This command starts the Ping test.

Syntax

```
:PROTocol:PING:START
```

:PROTocol:PING:START:EVENT

Function

This command queries the start event for the Ping test.
If the start event is read, then the response data is 0.

Syntax

```
:PROTocol:PING:START:EVENT?
```

Response Data

0|1

0: Ping test not executed.

Event has been read after the start of Ping test.

1: Ping test started.

Example of Use

```
:PROTocol:PING:START
```

```
:PROTOCOL:PING:START:EVENT?  
> 1  
:PROTOCOL:PING:START:EVENT?  
> 0
```

:PROTOCOL:PING:STATUS

Function

This command queries the status of the Ping test.

Syntax

```
:PROTOCOL:PING:STATUS?
```

Response Data

```
0|1|2
```

```
0: Ping test completed.  
1: Ping test in progress.  
2: Execution error.
```

Example of Use

```
:PROTOCOL:PING:START  
:PROTOCOL:PING:STATUS?  
> 1
```

:PROTOCOL:PING:STOP

Function

This command stops the Ping test.

Syntax

```
:PROTOCOL:PING:STOP
```

Example of Use

```
:PROTOCOL:PING:STOP  
:PROTOCOL:PING:STATUS?  
> 0
```

:PROTocol:PING:TIMEout

Function

This command sets and queries the timeout for the Ping test.

Syntax

```
:PROTocol:PING:TIMEout <NR1>
:PROTocol:PING:TIMEout?
```

<NR1>: Ping timeout 1 to 10 seconds

Response Data

<NR1>

Example of Use

```
:PROTocol:PING:TIMEout 10
:PROTocol:PING:TIMEout?
> 10
```

:PROTocol:PING:VLAN

Function

This command sets and queries VLAN for Ping test transmission frames.

Syntax

```
:PROTocol:PING:VLAN
<stack>[,<tpid1>,<pcp1>,<vid1>[,<tpid2>,<pcp2>,<vid2>]]
:PROTocol:PING:VLAN?
```

<stack>=0|1|2

<tpid1>,<tpid2>=<HEX>

<pcp1>,<vid1>,<pcp2>,<vid2>=<NR1>

If 0 is specified to <stack>, then <tpid1> and later can be omitted.

If 1 is specified to <stack>, then <tpid2> and later can be omitted.

Response Data

<stack>[,<tpid1>,<pcp1>,<vid1>[,<tpid2>,<pcp2>,<vid2>]]

Example of Use

```
:PROTocol:PING:VLAN 2,#H88A8,0,0,#H8100,0,0
:PROTocol:PING:VLAN?
> 2,#H88A8,0,0,#H8100,0,0
```


:ROUte:BERT**Function**

This command sets the Port setting Frame BERT setting On/Off. It can also be used to query the Port setting Frame BERT setting.

Syntax

```
:ROUte:BERT 0|1|OFF|ON
:ROUte:BERT?
```

```
0|OFF:      Frame BERT setting Off
1|ON:       Frame BERT setting On
```

Response Data

```
0|1
```

:ROUte:ETHer:NEGoTiation:AUTO**Function**

This command sets and queries the auto negotiation when the mapping is GbE for the OTU3 or OTU4 application.

Syntax

```
:ROUte:ETHer:NEGoTiation:AUTO 0|1|OFF|ON
:ROUte:ETHer:NEGoTiation:AUTO?
```

```
0|OFF:      Auto negotiation Off
1|ON:       Auto negotiation On
```

Response Data

```
0|1
```

Example of Use

```
:ROUte:ETHer:NEGoTiation:AUTO ON
:ROUte:ETHer:NEGoTiation:AUTO?
> 1
```

:ROUTe:FCONtrol

Function

This command sets the Port setting Flow Control setting On/Off. It can also be used to query the Port setting Flow Control setting.

Syntax

`:ROUTe:FCONtrol 0|1|OFF|ON`

`:ROUTe:FCONtrol?`

0|OFF: Flow Control setting Off

1|ON: Flow Control setting On

Response Data

0|1

:ROUTe:LFS:REPLy

Function

This command sets and queries the On/Off setting of LFS Reply in Port setting for the 40GbE or 100GbE application.

It cannot be used when the mapping is 40GbE or 10GbE for the OTU3 application and when the mapping is 100GbE or 10GbE for the OTU4 application.

Syntax

`:ROUTe:LFS:REPLy 0|1|OFF|ON`

`:ROUTe:LFS:REPLy?`

0|OFF: LFS Reply setting Off

1|ON: LFS Reply setting On

Response Data

0|1

:ROUTe:MODE**Function**

This command sets the Port mode.

Syntax

```
:ROUTe:MODE LOOPBACK|NORMAL|THROUGH  
:ROUTe:MODE?
```

Set any of the following:

NORMAL: Release normal mode

LOOPBACK: Set loopback mode

THROUGH: Through mode

Can be set for the OTN3 or OTN4 application.

Response Data

```
LOOPBACK|NORMAL|THROUGH
```

Example of Use

To set to Loopback:

```
:ROUTe:MODE LOOPBACK  
:ROUTe:MODE?  
> LOOPBACK
```

:ROUte:MODE:THROugh:OVERwrite:RANGe

Function

This command sets and queries the range of data to be overwritten when the through mode is OH Overwrite.

The data range can be set for the OTU3 or OTU4 application.

Syntax

```
:ROUte:MODE:THROugh:OVERwrite:RANGe  
<type>[,<row>,<column>]  
:ROUte:MODE:THROugh:OVERwrite:RANGe
```

<type>=ALL|BYTE|ODU|OPU|OTU|OTU_ODU

<row>=<NR1>: For BYTE of <type>, the data row number is 1 to 4.

<column>=<NR1>: For BYTE of <type>, the data column number is 1 to 16.

Response Data

```
<type>[,<row>,<column>]
```

Example of Use

To set only 1 byte of row 4 and column 13 to overwrite:

```
:ROUte:MODE:THROugh:OVERwrite:RANGe BYTE,4,13  
:ROUte:MODE:THROugh:OVERwrite:RANGe?  
> BYTE,4,13
```

:ROUte:MODE:THROugh:TYPE**Function**

This command sets and queries the type of the through mode.
It can be set for the OTU3 or OTU4 application.

Syntax

```
:ROUte:MODE:THROugh:TYPE ANALYZED|OVERWRITE|TRANSPARENT
:ROUte:MODE:THROugh:TYPE?
```

Set any of the following:

```
ANALYZED
OVERWRITE
TRANSPARENT
```

Response Data

```
ANALYZED|OVERWRITE|TRANSPARENT
```

Example of Use

To set the type of the through mode to OH Overwrite:

```
:ROUte:MODE:THROugh:TYPE OVERWRITE
:ROUte:MODE:THROugh:TYPE?
> OVERWRITE
```

:ROUte:MPLStp:CWORD**Function**

This command sets On/Off of the reception signal MPLS-TP Control Word.
This can be set for the 40 GbE/100 GbE applications.

Syntax

```
:ROUte:MPLStp:CWORD 0|1
:ROUte:MPLStp:CWORD?
```

```
0:      Off (Control Word Off)
1:      On (Control Word On)
```

Response Data

```
0|1
```

:ROUte:VLAN:NUM

Function

For 40GbE/100GbE applications, this command sets and queries the number of VLAN filters for Port setting.

Syntax

```
:ROUte:VLAN:NUM <NR1>
:ROUte:VLAN:NUM?
```

<NR1>=0 to 16

Response Data

<NR1>

Example of Use

To set the number of filters to 4.

```
:ROUte:VLAN:NUM 4
:ROUte:VLAN:NUM?
> 4
```

:ROUte:VLAN:VALue

Function

For 40GbE/100GbE applications, this command sets and queries the VLAN stack and TPID for Port setting.

Syntax

```
:ROUte:VLAN:VALue <no>,<stack>,<tpid1>,<tpid2>
:ROUte:VLAN:VALue? <no>
```

<no>=<NR1>: Filter number 1 to 16

<stack>=1|2: Stack

<tpid1>=<HEX>: VLAN#1 TPID 0x0000 to 0xFFFF

<tpid2>=<HEX>: VLAN#2 TPID 0x0000 to 0xFFFF

Response Data

<no>,<stack>,<tpid1>,<tpid2>

Example of Use

To set the filter number 1 to VLAN stack 2, TPID1 0x88A2, and TPID2 0x8102.

```
:ROUte:VLAN:VALue 1,2,#H88A2,#H8102
:ROUte:VLAN:VALue? 1
```

```
> 2, #H88A2, #H8102
```

:SENSe:MAPPING

Function

This command operates in the same way as :SOURce:MAPPING.

:SENSe:ODTU:MAIN:DETECT

Function

This command sets and queries the Main TS (Tributary Slot) detection method on the receive side.

Setting Main TS detection method sets the Combination of the TP/TS setting to Off.

Syntax

```
:SENSe:ODTU:MAIN:DETECT <CHAR>
:SENSe:ODTU:MAIN:DETECT?
```

Specify either of the following for <CHAR>.

<CHAR>	Description
MANUAL	Specifies TS with :SENSe:ODTU:MAIN:TS.
TP<NR1>	Detects the TP number automatically.
TS<NR1>	Automatically detects the TP number stored in the specified TS number.

<NR1>: For ODTU4.1: 1 to 80. For ODTU4.8: 1 to 10

Response Data

<CHAR>

Example of Use

For ODTU4.1:

```
:SENSe:ODTU:MAIN:DETECT TP80
:SENSe:ODTU:MAIN:DETECT?
> TP80
```

```
:SENSe:ODTU:MAIN:DETECT MANUAL
:SENSe:ODTU:MAIN:DETECT?
> MANUAL
```

:SENSe:ODTU:MAIN:TS

Function

This command sets and queries the Main TS (Tributary Slot) on the receive side.

One TS for ODTU4.1 and 8 TSs for ODTU4.8 are set. Setting TS sets the Combination of the TP/TS setting to Off.

Syntax

```
:SENSe:ODTU:MAIN:TS  
<NR1>|<NR1>,<NR1>,<NR1>,<NR1>,<NR1>,<NR1>,<NR1>,<NR1>  
:SENSe:ODTU:MAIN:TS?
```

<NR1>: For ODTU4.1: 1~80
 For ODTU4.8: 1~10

Response Data

```
<NR1>|{<NR1>,<NR1>,<NR1>,<NR1>,<NR1>,<NR1>,<NR1>,<NR1>}
```

Example of Use

For ODTU4.1:

```
:SENSe:ODTU:MAIN:TS 80  
:SENSe:ODTU:MAIN:TS?  
> 80
```

For ODTU4.8:

```
:SENSe:ODTU:MAIN:TS 1,2,3,4,5,6,7,8  
:SENSe:ODTU:MAIN:TS?  
> 1,2,3,4,5,6,7,8
```


:SENSe:OTN:FEC**Function**

This command sets and queries GFEC Decode for Port setting.

Syntax

```
:SENSe:OTN:FEC 0|1|OFF|ON
:SENSe:OTN:FEC?
```

```
0|OFF:      GFEC Decode setting Off
1|ON:       GFEC Decode setting On
```

Response Data

```
0|1
```

Example of Use

To set GFEC Decode to On.

```
:SENSe:OTN:FEC ON
:SENSe:OTN:FEC?
> 1
```

:SENSe:PLM[:L]:PATtern**Function**

This command sets and queries the payload type to detect PLM.
To set and query the low order payload type, describe :L.

Syntax

```
:SENSe:PLM[:L]:PATtern <HEX>
:SENSe:PLM[:L]:PATtern?
```

<HEX>: 1-byte value to indicate the payload type

Response Data

```
<HEX>
```

Example of Use

To set 0x12 to the high order payload type:

```
:SENSe:PLM:PATtern #H21
```

To set 0x07 to the low order payload type:

```
:SENSe:PLM:L:PATtern #H07
```

:SENSe:TIM:{SM|PM[:L]|TCM{1|2|3|4|5|6}}

Function

This command sets and queries the detection method for TIM.
To set and query the low order PM-TIM detection method, describe :L.

Syntax

:SENSe:TIM:{SM|PM[:L]|TCM{1|2|3|4|5|6}} <CHAR>

:SENSe:TIM:{SM|PM[:L]|TCM{1|2|3|4|5|6}}?

<CHAR>

Select the TIM detection method from the following:

- OFF: TIM is not detected.
- DAPI: TIM is detected only for DAPI.
- SAPI: TIM is detected only for SAPI.
- SAPI_DAPI: TIM is detected for SAPI and DAPI.

Response Data

DAPI|DAPI_SAPI|OFF|SAPI

Example of Use

To set SM-TIM detection method to Off:

:SENSe:TIM:SM OFF

To set PM-TIM detection method to DAPI:

:SENSe:TIM:PM DAPI

To set TCM2-TIM detection method to SAPI and DAPI:

:SENSe:TIM:TCM2 SAPI_DAPI

To query the high order PM-TIM detection method:

:SENSe:TIM:PM?

> DAPI_SAPI

To query the low order PM-TIM detection method:

:SENSe:TIM:PM:L?

> OFF

`:SENSe:TIM:{SM|PM[:L]|TCM{1|2|3|4|5|6}}:PATtern:{DAPI|SAPI}`

Function

This command sets and queries the TIM detection pattern.

To set and query the low order PM-TIM detection pattern, describe :L.

Syntax

```
:SENSe:TIM:{SM|PM[:L]|TCM{1|2|3|4|5|6}}:PATtern:{DAPI|SAPI} <HEX>
```

```
:SENSe:TIM:{SM|PM[:L]|TCM{1|2|3|4|5|6}}:PATtern:{DAPI|SAPI}?
```

<HEX>: Value of 16 bytes or less to indicate the pattern data

Response Data

<HEX>

Example of Use

To set "JPNMD1260A" to DAPI for SM-TTI:

```
:SENSe:TIM:SM:PATtern:DAPI
#H004A504E4D443132363041202020202020
```

To set "USAMD1260A" to DAPI for SM-TTI:

```
:SENSe:TIM:TCM6:PATtern:SAPI
#H005553404D443132363041202020202020
```

:SENSe:TPATtern:INVert

Function

In case of application is not No Frame, this command inverts the PRBS test pattern settings (Rx). Use :SOURce:TPATtern:INVert to invert the Tx pattern.

Syntax

```
:SENSe:TPATtern:INVert 0|1|OFF|ON  
:SENSe:TPATtern:INVert?
```

0 OFF:	Invert pattern Off
1 ON:	Invert pattern On

Response Data

0|1

Example of Use

To invert test pattern for both Tx and Rx:

```
:SENSe:TPATtern:INVert ON  
:SOURce:TPATtern:INVert ON  
:SENSe:TPATtern:INVert?  
> 1  
:SOURce:TPATtern:INVert?  
> 1
```

:SENSe:TPATtern:TYPE**Function**

This command selects the test pattern type of receive side (Rx).

It queries the test pattern type of receive side (Rx).

The setting value of this command is linked with :SOURce:TPATtern:TYPE. Sending either one of these commands sets both the transmit side and the receive side.

Syntax

```
:SENSe:TPATtern:TYPE <CHAR>
```

```
:SENSe:TPATtern:TYPE?
```

<CHAR>

Select the test pattern type from the following:

PRBS7

PRBS9

PRBS11

PRBS15

PRBS23

PRBS31

ALL0

ALL1

WORD16

SQUARE : Square Wave

Response Data

ALL0|ALL1|PRBS7|PRBS9|PRBS11|PRBS15|PRBS23|PRBS31|

SQUARE|WORD16

Example of Use

```
:SENSe:TPATtern:TYPE WORD16
```

```
:SENSe:TPATtern:TYPE?
```

```
>WORD16
```

:SENSe:TPATtern:WORD

Function

This command sets the pattern when Word16 is selected for the test pattern of receive side (Rx).

It queries the Word16 pattern of receive side (Rx).

The setting value of this command is linked with :SOURce:TPATtern:WORD. Sending either one of these commands sets both the transmit side and the receive side.

Syntax

:SENSe:TPATtern:WORD <HEX>

:SENSe:TPATtern:WORD?

<HEX>: Value of Data Field (2 bytes)

Response Data

<HEX>

Example of Use

```
:SENSe:TPATtern:TYPE WORD16
```

```
:SENSe:TPATtern:WORD #HFF02
```

```
:SENSe:TPATtern:WORD?
```

```
>#HFF02
```

:SENSe:TRANsceiver:EQUalizer:CONTRol**Function**

This command sets the Equalizer (Control) of the transceiver.
It also queries the settings of the Equalizer (Control) of the transceiver.

Syntax

```
:SENSe:TRANsceiver:EQUalizer:CONTRol <lane>,<value >
:SENSe:TRANsceiver:EQUalizer:CONTRol? <lane>
```

```
<lane>,<value>=<NR1>
```

```
<lane>=<NR1>: Lane number
```

```
<value>=<NR1>: Setting value of Equalizer (Control)
```

Response Data

```
<value>
```

For the setting of Pre-Emphasis and VOD, refer to the following commands.

```
:SOURce:TRANsceiver:EMPHasis:FIRSt
```

```
:SOURce:TRANsceiver:EMPHasis:PRE
```

```
:SOURce:TRANsceiver:EMPHasis:SECOnd
```

```
:SOURce:TRANsceiver:VOD
```

:SENSe:TRANsceiver:EQUalizer:DCGaiN**Function**

This command sets the Equalizer (DC Gain) of the transceiver.
It also queries the settings of the Equalizer (DC Gain) of the transceiver.

Syntax

```
:SENSe:TRANsceiver:EQUalizer:DCGaiN <lane>,<value>
:SENSe:TRANsceiver:EQUalizer:DCGaiN? <lane>
```

```
<lane>,<value>=<NR1>
```

```
<lane>=<NR1>: Lane number
```

```
<value>=<NR1>: Setting value of Equalizer (DC Gain)
```

Response Data

```
<value>
```

:SOURce:CFP:OPTical:OFF

Function

This command turns Off the CFP optical output.

Syntax

:SOURce:CFP:OPTical:OFF

It takes time until CFP optical output is turned off after the command is transmitted.

* Confirm the end of the processing with the *OPC command.

:SOURce:CFP:OPTical:ON

Function

This command turns On the CFP optical output.

Syntax

:SOURce:CFP:OPTical:ON

It takes time until CFP optical output is turned on after the command is transmitted.

* Confirm the end of the processing with the *OPC command.

:SOURce:CFP:OPTical:STATus

Function

This command queries the CFP optical output status.

Syntax

:SOURce:CFP:OPTical:STATus?

Response Data

0: Optical output Off

1: Optical output On

Example of Use

:SOURce:CLOCK INTERNAL

:SOURce:CLOCK?

> INTERNAL

:SOURce:CLOCK**Function**

This command sets the clock source (Tx clock). It also queries the setting of the clock source (Tx clock).

Syntax

```
:SOURce:CLOCK <CHAR>
```

```
:SOURce:CLOCK?
```

For <CHAR>, select any of the following.

<CHAR>	Clock Source for Tx Clock
INTERNAL	Internal oscillator clock
INPUT_10MHZ	Clock input to 10 MHz Input terminal
INPUT_REFCLK	Clock input to x Ref Clock Input terminal
RECEIVE	Clock synchronized with Rx clock
INPUT_SYNC	Clock input to Sync Input terminal

Response Data

```
<char>
```

Example of Use

```
:SOURce:CLOCK INTERNAL
```

```
:SOURce:CLOCK?
```

```
> INTERNAL
```

:SOURce:CLOCK:FREQuency:OFFSet

Function

This command sets the offset of the Tx clock frequency. It also queries the setting of the offset of the Tx clock frequency.

Syntax

```
:SOURce:CLOCK:FREQuency:OFFSet <NR1>  
:SOURce:CLOCK:FREQuency:OFFSet?
```

<NR1>:

Specify the offset (–120 to +120 ppm) from the reference clock frequency.

Response Data

< NR1>

Example of Use

To set the offset of the Tx clock frequency to 1 ppm:

```
:SOURce:CLOCK:FREQuency:OFFSet 1  
:SOURce:CLOCK:FREQuency:OFFSet?  
> 1
```

:SOURce:CLOCK:OUTPut:DIVide

Function

This command sets and queries the clock division rate output to the Tx Ref Clock Output terminal.

Syntax

```
:SOURce:CLOCK:OUTPut:DIVide DIV16|DIV64  
:SOURce:CLOCK:OUTPut:DIVide?
```

Set any of the following.

DIV16: 1/16

DIV64: 1/64

Response Data

DIV16|DIV64

Example of Use

```
:SOURce:CLOCK:OUTPut:DIVide DIV64  
:SOURce:CLOCK:OUTPut:DIVide?  
> DIV64
```

:SOURce:CLOCK:OUTPut:M10**Function**

This command sets the 10 MHz signal output to the 10 MHz Output terminal. It also queries the setting of the 10 MHz signal output to the 10 MHz Output terminal.

Syntax

```
:SOURce:CLOCK:OUTPut:M10 INTERNAL|LOCKED
:SOURce:CLOCK:OUTPut:M10?
```

Set any of the following.

INTERNAL: 10 MHz of internal oscillator

LOCKED: 10 MHz synchronized with Rx clock

Response Data

INTERNAL|LOCKED

Example of Use

```
:SOURce:CLOCK:OUTPut:M10 INTERNAL
:SOURce:CLOCK:OUTPut:M10?
> INTERNAL
```

:SOURce:CLOCK:PAYLoad:OFFSet[:L]

Function

This command sets and queries the payload offset for the OTU3 or OTU4 application.

To set and query the low order payload offset, describe :L.

Syntax

:SOURce:CLOCK:PAYLoad:OFFSet[:L] <NR1>

:SOURce:CLOCK:PAYLoad:OFFSet[:L]?

<NR1>: Payload offset

When the low order does not exist: (–120 to +120ppm)

When the high order/low order exists:

High order: (–40 to +40ppm), low order: (–120 to +120ppm)

Response Data

<NR1>

Example of Use

To set the payload offset to 10ppm:

For the ODTU4.1 or ODTU4.8, set the high order payload offset.

:SOURce:CLOCK:PAYLoad:OFFSet 10

To set the low order payload offset to –50ppm:

:SOURce:CLOCK:PAYLoad:OFFSet:L -50

:SOURce:EALarm:BIT**Function**

This command sets and queries the bit adding errors/alarms.

Syntax

```
:SOURce:EALarm:BIT <BINARY>
```

```
:SOURce:EALarm:BIT?
```

<BINARY>

Specifies bit for adding errors/alarms in binary as 1 and for not adding errors/alarms as 0 (in order from header as bit 0).

For example, specify 8 bits for CRC8 Error, and 5 bits for CRC5 Error.

When a smaller number of bits than the number of lanes is specified, the remaining bits are padded with 0s. When more bits than bits are specified, the surplus bits are ignored.

However, for Invalid JC1&JC2, bits are set in order of Bit 0 to 7 of JC2 and then Bit 0 to 7 of JC1.

Response Data

<BINARY>

The number of digits depends on the number of bits that can be set.

Example of Use

To insert errors/alarms to Bit0 and Bit3 for CRC8 Error:

```
:SOURce:EALarm:BIT #B10010000
```

Or

```
:SOURce:EALarm:BIT #B1001
```

To insert errors to Bit0, 1, and 2 of JC2 and Bit0 of JC1 for Invalid JC1&JC2:

```
:SOURce:EALarm:BIT #B1110000010000000
```

:SOURCE:EALarm:FAS:EXCLude

Function

This command sets and queries whether to exclude FAS of OTN frame from the error insertion range.

Syntax

:SOURCE:EALarm:FAS:EXCLude 0|1|OFF|ON

:SOURCE:EALarm:FAS:EXCLude?

0|OFF: FAS Exclude Off

1|ON: FAS Exclude On

Response Data

0|1

Example of Use

:SOURCE:EALarm:FAS:EXCLude ON

:SOURCE:EALarm:FAS:EXCLude?

> 1

:SOURCE:EALarm:LANE**Function**

This command sets and queries the lane adding errors/alarms.

Syntax

```
:SOURCE:EALarm:LANE <BINARY>
:SOURCE:EALarm:LANE?
```

<BINARY>

Specifies lane for adding errors/alarms in binary as 1 and for not adding errors/alarms as 0 (in order from header as Lane 0, Lane 1, ...)

For example, specify 20 bits (Lane 0~19) for 100GbE, and 4 bits (Lane 0~3) for 40GbE. When a smaller number of bits than the number of lanes is specified, the remaining bits are padded with 0s. When more bits than lanes are specified, the surplus bits are ignored.

Response Data

<BINARY>

Example of Use

To add errors/alarms to Lane 0, 3, 9 at 100GbE:

```
:SOURCE:EALarm:LANE #B10010000010000000000
```

Or

```
:SOURCE:EALarm:LANE #B1001000001
```

:SOURCE:EALarm:START[:AUNit]**Function**

This command starts error/alarm addition.

When error/alarm addition is already running, it restarts.

Adding :AUNit starts simultaneous error/alarm addition for all connected units.

Syntax

```
:SOURCE:EALarm:START[:AUNit]
```

Example of Use

To start error/alarm addition:

1. Clear the start event by sending :SOURCE:EALarm:START:EVENT?.
2. Start the error/alarm addition by sending :SOURCE:EALarm:START .
3. Send repeatedly until the :SOURCE:EALarm:START:EVENT? response becomes 1 (started).

:SOURCE:EALarm:START:EVENT[:AUNit]

Function

This command queries start events added to errors/alarms.

Syntax

`:SOURCE:EALarm:START:EVENT[:AUNit]?`

Response Data

0|1

0: Before start of error/alarm insertion

The response data becomes 0 after this command is read.

1: After error/alarm insertion started

When :AUNit is added to the header, becomes 1 when error/alarm insertion starts at all units

The event value is cleared to 0 when response data 1 is read.

Example of Use

Refer to the example for `:SOURCE:EALarm:START[:AUNit]` .

:SOURCE:EALarm:STATUS[:AUNit]

Function

This command queries operation state added to errors/alarms.

Syntax

`:SOURCE:EALarm:STATUS[:AUNit]?`

Response Data

0|1

0: Error/alarm addition operation stopped

1: Error/alarm addition operation running

When :AUNit is added to the header, becomes 1 when error/alarm insertion starts at any of units and becomes 0 when all units stopped.

Example of Use

Refer to the example for `:SOURCE:EALarm:STOP[:AUNit]` .

:SOURce:EALarm:STOP[:AUNit]**Function**

This command stops error/alarm addition.

Adding :AUNit stops error/alarm addition for all connected units.

Syntax

```
:SOURce:EALarm:STOP[:AUNit]
```

Example of Use

To stop error/alarm addition

1. Send :SOURce:EALarm:STOP.
Error/alarm addition stops.
2. Send :SOURce:EALarm:STATUS?
Sending is repeated until the response data is 0 (stopped).

:SOURce:EALarm:SUBRow**Function**

This command sets and queries SubRow added to errors/alarms.

Syntax

```
:SOURce:EALarm:SUBRow <NR1>
```

```
:SOURce:EALarm:SUBRow?
```

<NR1>: Number for SubRow

Response Data

```
<NR1>
```

Example of Use

```
:SOURce:EALarm:SUBRow 1
```

```
:SOURce:EALarm:SUBRow?
```

```
> 1
```

:SOURce:EALarm:TIMing:BURSt

Function

This command sets the count when the error/alarm addition timing is Burst. It also queries the count setting when the error/alarm addition timing is Burst.

Syntax

```
:SOURce:EALarm:TIMing:BURSt <NR1>  
:SOURce:EALarm:TIMing:BURSt?
```

<NR1>

Specifies error/alarm addition count

Response Data

<NR1>

Example of Use

```
:SOURce:EALarm:TYPE INV_SH00  
:SOURce:EALarm:TIMing:TYPE BURST  
:SOURce:EALarm:TIMing:BURSt 1  
:SOURce:EALarm:TIMing:BURSt?  
> 1
```

:SOURce:EALarm:TIMing:ERRor

Function

This command sets the error addition count when the error/alarm addition timing is Alternate. It also queries the settings of the error addition count when the error/alarm addition timing is Alternate.

Syntax

```
:SOURce:EALarm:TIMing:ERRor <NR1>  
:SOURce:EALarm:TIMing:ERRor?
```

<NR1>:

Frame count of error/alarm addition (Error)

Response Data

<NR1>

Example of Use

Refer to the example for :SOURce:EALarm:TIMing:NORMal.

:SOURce:EALarm:TIMing:NORMal**Function**

This command sets the normal frame count when the error/alarm addition timing is Alternate. It also queries the settings of the normal frame count when the error/alarm addition timing is Alternate.

Syntax

```
:SOURce:EALarm:TIMing:NORMal <NR1>  
:SOURce:EALarm:TIMing:NORMal?
```

<NR1>:

Frame count of no error/alarm (Normal)

Response Data

<NR1>

Example of Use

```
:SOURce:EALarm:TYPE FAS_MLD  
:SOURce:EALarm:TIMing:TYPE ALTERNATE  
:SOURce:EALarm:TIMing:ERRor 1  
:SOURce:EALarm:TIMing:NORMal 2  
:SOURce:EALarm:TIMing:ERRor?  
> 1  
:SOURce:EALarm:TIMing:NORMal?  
> 2
```

:SOURCE:EALarm:TIMing:RATE

Function

This command sets the error/alarm appended rate when selecting Rate using :SOURCE:EALarm:TIMing:TYPE. It also queries the appended error/alarm rate.

Syntax

:SOURCE:EALarm:TIMing:RATE <CHAR>|<NR3>
:SOURCE:EALarm:TIMing:RATE?

<NR3>:Sets the appended rate in numeric values.

When 3.6×10^{-6} is set, 3.6E-6 is set.

<CHAR>

Set the appended rate.

<CHAR>	Appended Rate
R1E_2	1.0E-2
R1E_3	1.0E-3
R1E_4	1.0E-4
R1E_5	1.0E-5
R1E_6	1.0E-6
R1E_7	1.0E-7
R1E_8	1.0E-8
R1E_9	1.0E-9

Response Data

<NR3>

Example of Use

```
:SOURCE:EALarm:TYPE BIT_ERROR
:SOURCE:EALarm:TIMing:TYPE CRATE
:SOURCE:EALarm:TIMing:RATE R1E_6
:SOURCE:EALarm:TIMing:RATE?
> 1.0E-6
```

:SOURCE:EALarm:TIMing:TYPE**Function**

This command sets the error/alarm appended timing. It also queries the setting of the error/alarm appended timing.

Syntax

```
:SOURCE:EALarm:TIMing:TYPE <CHAR>
```

```
:SOURCE:EALarm:TIMing:TYPE?
```

<CHAR>

Select the timing from following.

<CHAR>	Timing
SINGLE	Single
BURST	Burst
RRATE	Rate
ALTERNATE	Alternate
ALL	All

RATE is specified at Bit Error of Ethernet.

When selecting BURST, specify the error/alarm appended volume using :SOURCE:EALarm:TIMing:BURSt.

When selecting RRATE, specify the error/alarm appended rate using :SOURCE:EALarm:TIMing:RATE.

When selecting ALTERNATE, specify the error/alarm appended volume using :SOURCE:EALarm:TIMing:ERRor and :SOURCE:EALarm:TIMing:NORMAl.

The selectable value varies with the selection of the application and error/alarm appended types.

When changing the error/alarm appended types, the values are rounded to the selectable value. For details, refer to the MD1260A 40/100G Ethernet Analyzer Operation Manual.

Response Data

<CHAR>

Example of Use

To set the error/alarm appended timing to Single:

```
:SOURCE:EALarm:TIMing:TYPE SINGLE
```

```
:SOURCE:EALarm:TIMing:TYPE?
```

```
> SINGLE
```

:SOURCE:EALarm:TYPE

Function

This command sets the error/alarm appended types.
It also queries the setting of the error/alarm appended types.

Syntax

:SOURCE:EALarm:TYPE <CHAR>

:SOURCE:EALarm:TYPE?

<CHAR>: Select the error alarm types from the following.
When changing the types, the timing settings are initialized.

40GbE, 100GbE:

Error/Alarm Type	<CHAR>
Invalid Sync Header (00)	INV_SH00
Invalid Sync Header (11)	INV_SH11
Invalid Alignment Marker	INV_MARKER
BIP Error	BIP
Invalid Block Type (0x00)	INV_BT00
Invalid Block Type (0x2d)	INV_BT2D
Invalid Block Type (0x33)	INV_BT33
Invalid Block Type (0x66)	INV_BT66
Hi-BER	HIBER
LF	LF
RF	RF
Bit Errors	BIT_ERROR

OTN3, OTN4:

Layer	Error Type	<CHAR>
LLD	FAS	FAS_LLD
OTU3/ OTU4	FAS	FAS
	SM-BIP8	SM_BIP8
	SM-BEI	SM_BEI
	Uncorrectable Error	BIT_ALL_U
	Correctable Error	BIT_ALL_C
	Bit All	BIT_ALL

OTN3, OTN4 (Cont'd):

Layer	Error Type	<CHAR>
ODU3/ ODU4	PM-BIP8	PM_BIP8
	PM-BEI	PM_BEI
	TCMi-BIP8	TCM{1 2 3 4 5 6}_BIP8
	TCMi -BEI	TCM{1 2 3 4 5 6}_BEI
ODU2e/ ODU0	FAS	FAS_L
	PM-BIP8	PM_BIP8_L
	PM-BEI	PM_BEI_L
GMP	CRC8 Error	GMP_CRC8
	CRC5 Error	GMP_CRC5
	Invalid JC1	GMP_JC1
	Invalid JC2	GMP_JC2
	Invalid JC1&JC2	GMP_JC12
GMP(Lo)	CRC8 Error	GMP_CRC8_L
	Invalid JC1	GMP_JC1_L
	Invalid JC2	GMP_JC2_L
	Invalid JC1&JC2	GMP_JC12_L
GFP-T	Superblock CRC Error	GFP_SCRC
	cHEC Error	GFP_CHEC
	tHEC Error	GFP_THEC
Ethernet	Invalid Sync Header (00)	INV_SH00
	Invalid Sync Header (11)	INV_SH11
	Invalid Block Type (0x00)	INV_BT00
	Invalid Block Type (0x2d)	INV_BT2D
	Invalid Block Type (0x33)	INV_BT33
	Invalid Block Type (0x66)	INV_BT66
	Invalid Alignment Marker	INV_MARKER
	BIP Error	BIP
	LF	LF
	RF	RF
	66B Error	ERR_66B
	10B Error	ERR_10B
Test Pattern	Bit Errors	BIT_ERROR

OTN3, OTN4 (Cont'd):

Layer	Alarm Type	<CHAR>
LLD	OOF/LOF	OOF_LLD
	OOR/LOR	OOR
OTU3/ OTU4	OOF/LOF	OOF
	OOM/LOM	OOM
	SM-TIM	SM_TIM
	SM-BIAE	SM_BIAE
	SM-BDI	SM_BDI
	SM-IAE	SM_IAE
ODU3/ ODU4	ODU-AIS	AIS_ODU
	ODU-OCI	OCI
	ODU-LCK	LCK
	PM-TIM	PM_TIM
	PM-BDI	PM_BDI
	TCMi-TIM	TCM{1 2 3 4 5 6}_TIM
	TCMi-BIAE	TCM{1 2 3 4 5 6}_BIAE
	TCMi IAE	TCM{1 2 3 4 5 6}_IAE
	TCMi BDI	TCM{1 2 3 4 5 6}_BDI
	TCMi-LTC	TCM{1 2 3 4 5 6}_LTC
OPU3/ OPU4	Client-AIS	AIS_C
	CSF	CSF
ODU2e/ ODU0	OOF	OOF_L
	OOM	OOM_L
	ODU-AIS	AIS_ODU_L
	ODU-OCI	OCI_L
	ODU-LCK	LCK_L
	PM-TIM	PM_TIM_L
	PM-BDI	PM_BDI_L
Ethernet	High BER	HIBER

40GbE No Frame: 100GbE No Frame,

OTN3 No Frame: OTN4 No Frame:

Error/Alarm Types	<CHAR>
Bit Errors	BIT_ERROR

Set errors/alarms for which addition timing can be selected as :SOURCE:EALarm:TIMing:TYPE

In addition, when error/alarm insertion into lanes has been specified, specify the insertion lanes as :SOURCE:EALarm:LANE.

For details of each error/alarm, refer to the MD1260A 40/100G Ethernet Analyzer Operation Manual.

Response Data

<CHAR>

Example of Use

```
:SOURCE:EALarm:TYPE?  
> BIT_ERROR
```

:SOURCE:GFP:CSF:REPLACEMENT**Function**

This command sets and queries the data to replace GFP-T errors.

Syntax

```
:SOURCE:GFP:CSF:REPLACEMENT BLOCK|CSF  
:SOURCE:GFP:CSF:REPLACEMENT?
```

Set any of the following.

BLOCK: Ethernet Block

CSF: GFP-T CSF

Response Data

BLOCK|CSF

Example of Use

```
:SOURCE:GFP:CSF:REPLACEMENT BLOCK  
:SOURCE:GFP:CSF:REPLACEMENT?  
> BLOCK
```

:SOURCE:GFP:{PTI|UPI}

Function

This command sets and queries the payload of GFP-T.

Syntax

```
:SOURCE:GFP:{PTI|UPI} <BINARY>
:SOURCE:GFP:{PTI|UPI}?
```

<BINARY>: For PTI: 3 bits
For UPI: 8 bits

Response Data

<BINARY>

Example of Use

```
:SOURCE:GFP:PTI #B000
:SOURCE:GFP:PTI?
> #B001
:SOURCE:GFP:UPI #B00000110
:SOURCE:GFP:UPI?
> #B00000110
```

:SOURCE:MAPPING

Function

This command sets the number of physical lanes when the application is 100GbE No Frame or OTU4 No Frame.

It queries the type of the application running.

The application is set with :SYSTEM:CONFIG.

Syntax

```
:SOURCE:MAPPING <CHAR>
:SOURCE:MAPPING?
```

<CHAR>

Set any of the following.

Application (Number of Lanes)	<CHAR>
100GbE No Frame (10 Lanes)	E100G_N10
100GbE No Frame (20 Lanes)	E100G_N20
OTU4 No Frame (10 Lanes)	OTU4_N10
OTU4 No Frame (20 Lanes)	OTU4_N20

Response Data

<CHAR>

Application/Mapping	<CHAR>
40GbE	E40G
100GbE	E100G
ODU3-PRBS	OTU3
ODU4-PRBS	OTU4
ODU4-100GbE	OTU4_E
ODTU4.8-ODU2e-PRBS	OTU4_ODU2E
ODTU4.8-ODU2e-10GbE	OTU4_ODU2E_E
ODTU4.1-ODU0-PRBS	OTU4_ODU0
ODTU4.1-ODU0-GbE	OTU4_ODU0_E
40GbE No Frame	E40G_N
100GbE No Frame (10Lane)	E100G_N10
100GbE No Frame (20Lane)	E100G_N20
OTU3 No Frame	OTU3_N
OTU4 No Frame (10Lane)	OTU4_N10
OTU4 No Frame (20Lane)	OTU4_N20

Example of Use

When the loading application is 100GbE:

```
:SOURCE:MAPPING?
> E100G
```

When the loading application is 100GbE No Frame and measurement of 10 Lanes is performed:

```
:SOURCE:MAPPING E100G_N10
:SOURCE:MAPPING?
> 100GE_N10
```

:SOURce:MAPPING:LANE

Function

This command sets the number of lanes for the Tx Lane lane marker in sequence from Tx Lane 0.

When this remote command is sent, the Allow to Overlap button on the screen is set to On.

It also queries the value of the lane marker for the Tx Lane.

Syntax

```
:SOURce:MAPPING:LANE <NR1>,<NR1>,<NR1>,...
```

```
:SOURce:MAPPING:LANE?
```

<NR1>

Lane marker value for Tx Lane

Response Data

```
<NR1>,<NR1>,<NR1>,...
```

Example of Use

For 100GbE/OTU4

```
:SOURce:MAPPING:LANE
```

```
0,1,2,3,4,5,6,7,8,9,10,11,12,13,14,15,16,17,18,19
```

For 40GbE/OTU3

```
:SOURce:MAPPING:LANE 0,1,2,3
```

:SOURce:ODTU:DUMMy:PATtern

Function

This command sets and queries the data to be sent to Dummy channel.

Syntax

```
:SOURce:ODTU:DUMMy:PATtern COPY_MAIN|PRBS11
:SOURce:ODTU:DUMMy:PATtern?
```

Set any of the following.

COPY_MAIN: Same data as Main channel

PRBS11: Pseudorandom bit sequence

Response Data

COPY_MAIN|PRBS11

Example of Use

```
:SOURce:ODTU:DUMMy:PATtern COPY_MAIN
:SOURce:ODTU:DUMMy:PATtern?
> COPY_MAIN
```

:SOURce:ODTU:MAIN:TP

Function

This command sets and queries the Main TP (Tributary Port).

Syntax

```
:SOURce:ODTU:MAIN:TP <NR1>
:SOURce:ODTU:MAIN:TP?
```

The setting range of <NR1> is as follows.

Mapping	<NR1>
ODTU4.1-ODU0-GbE/PRBS	1 to 80
ODTU4.8-ODU2e-10GbE/PRBS	1 to 10

Response Data

<NR1>

Example of Use

```
:SOURce:ODTU:MAIN:TP 16
:SOURce:ODTU:MAIN:TP?
> 16
```

:SOURCE:ODTU:MAIN:TS

Function

This command sets and queries the TS (Tributary Slot) that stores Main TP.

One TS for ODTU4.1 and 8 TSs for ODTU4.8 are set.

Syntax

:SOURCE:ODTU:MAIN:TS

<NR1>|<NR1>,<NR1>,<NR1>,<NR1>,<NR1>,<NR1>,<NR1>,<NR1>,<NR1>

:SOURCE:ODTU:MAIN:TS?

<NR1>: 1 to 80

Response Data

<NR1>|<NR1>,<NR1>,<NR1>,<NR1>,<NR1>,<NR1>,<NR1>,<NR1>,<NR1>

Example of Use

For ODTU4.1:

:SOURCE:ODTU:MAIN:TS 2

:SOURCE:ODTU:MAIN:TS?

> 2

For ODTU4.8:

:SOURCE:ODTU:MAIN:TS 33,34,35,36,37,38,39,40

:SOURCE:ODTU:MAIN:TS?

> 33,34,35,36,37,38,39,40

:SOURCE:OTN:FEC**Function**

This command sets and queries the GFEC Encode of OTN frame.

Syntax

```
:SOURCE:OTN:FEC 0|1|OFF|ON
:SOURCE:OTN:FEC?
```

```
0|OFF:      GFEC Encode Off
1|ON:       GFEC Encode On
```

Response Data

```
0|1
```

Example of Use

```
:SOURCE:OTN:FEC OFF
:SOURCE:OTN:FEC?
> 0
```

:SOURCE:OTN:OH[:L]**Function**

This command sets and queries the overhead value of OTN frame.

Omitting :L sets and queries the high order (OTU4) OH.

Adding :L sets and queries the low order (ODU2e or ODU0) OH.

Syntax

```
:SOURCE:OTN:OH[:L] <row>,<column>,<data>
:SOURCE:OTN:OH[:L]? <row>,<column>
```

```
<row>=<NR1>:Row number 1 to 4
```

```
<column>=<NR1>:      Column number 1 to 16
```

```
<data>=<HEX>:      Value #H00 to #HFF
```

Response Data

```
<data>=<HEX>
```

Example of Use

```
:SOURCE:OTN:OH:L 3,2,#H10
:SOURCE:OTN:OH:L? 3,2
> #H10
```

:SOURce:SKEW:BIT

Function

This command sets the skew amount. It also queries the skew amount.

Syntax

```
:SOURce:SKEW:BIT <NR1>
```

```
:SOURce:SKEW:BIT?
```

<NR1>: Skew setting in bit units

Response Data

<NR1>

Example of Use

Refer to the example for :SOURce:SKEW:NS.

:SOURce:SKEW:LANE

Function

This command sets the lane for inserting skew.
It also queries the setting lane for inserting skew.

Syntax

```
:SOURce:SKEW:LANE <BINARY>
```

```
:SOURce:SKEW:LANE?
```

<BINARY>

Specifies lane for adding skew in binary as 1 and for not adding skew as 0 (in order from header as Lane 0, Lane 1, ...)

For example, specify 20 bits (Lane 0~19) for 100GbE, and 4 bits (Lane 0~3) for 40GbE. When a smaller number of bits than the number of lanes is specified, the remaining bits are padded with 0s. When more bits than lanes are specified, the surplus bits are ignored.

Response Data

<BINARY>

Example of Use

To add skew to Tx Lane 0, 3, 9 at 100GbE/OTU4:

```
:SOURce:SKEW:LANE #B10010000010000000000
```

Or

```
:SOURce:SKEW:LANE #B1001000001
```

```
:SOURce:SKEW:LANE?
```



```
> #B10010000010000000000
```

Example:

To add skew Physical Lane 9 at 100GbE/OTU4

```
:SOURce:SKEW:LANE #B0000000001
```

Note:

When the :SOURce:SKEW:TYPE setting is changed, the setting of this command is initialized.

:SOURce:SKEW:NS**Function**

This command queries the skew time.

Syntax

```
:SOURce:SKEW:NS?
```

Response Data

```
<NR2>: Skew setting converted to ns units
```

Example of Use

To generate skew of 66 bits (12.8 ns) at 100GbE:

```
:SOURce:SKEW:BIT 66
```

```
:SOURce:SKEW:NS?
```

```
>12.800
```

:SOURce:SKEW:TYPE**Function**

This command sets the skew insertion lane. It also queries the skew insertion lane.

Syntax

```
:SOURce:SKEW:TYPE PHY_LANE|TX_LANE
```

```
:SOURce:SKEW:TYPE?
```

Select any of the following.

TX_LANE: Tx Lane

PHY_LANE: Physical Lane

:SOURce:SKEW:LANE sets the skew generation lane

and :SOURce:SKEW:BIT sets the bit count for skew generation. Query the time-converted skew generation using :SOURce:SKEW:NS?

Response Data

PHY_LANE|TX_LANE

Example of Use

To insert skew to Tx Lane:
:SOURCE:SKEW:TYPE TX_LANE
:SOURCE:SKEW:TYPE?
> TX_LANE

:SOURCE:STREAM:BURST:CONTROL:VALUE

Function

This command sets the interburst gap. It also queries the interburst gap setting.

Syntax

:SOURCE:STREAM:BURST:CONTROL:VALUE <NR1>
:SOURCE:STREAM:BURST:CONTROL:VALUE?

<NR1>: Gap size (frames)

Response Data

<NR1>

:SOURCE:STREAM:BURST:ENABLE

Function

This command sets whether or not to send the burst. It also queries the burst send setting.

Syntax

:SOURCE:STREAM:BURST:ENABLE 0|1|OFF|ON
:SOURCE:STREAM:BURST:ENABLE?

0|OFF: Does not send burst

1|ON: Sends burst

Response Data

0|1

:SOURCE:STREAM:BURST:SIZE**Function**

This command sets the burst size (frame count sent at one burst). It also queries the burst size.

Syntax

```
:SOURCE:STREAM:BURST:SIZE <NR1>
:SOURCE:STREAM:BURST:SIZE?
```

<NR1>: Frame count

Response Data

<NR1>

:SOURCE:STREAM:CONTROL:RANGE**Function**

This command sets the transmission gap for the Ethernet frame. It also queries the range of the transmission gap of the Ethernet frame.

Syntax

```
:SOURCE:STREAM:CONTROL:RANGE <value1>,<value2>
:SOURCE:STREAM:CONTROL:RANGE?
```

<value1>, <value2> = <NR1>

Sets Min. and Max values of gap size in bytes. The smaller of the two values is the Min. and the larger is the Max. T

Response Data

<value1>, <value2> = <NR1>

<value1>: Min. value of gap size

<value2>: Max value of gap size

Example of Use

To send the gap size in the range of 12 to 96 bytes:

```
:SOURCE:STREAM:CONTROL:TYPE RANDOM
:SOURCE:STREAM:CONTROL:RANGE 12,96
```

:SOURce:STReam:CONTRol:TYPE

Function

This command sets the Ethernet frame gap to a random or fixed value. It also queries the Ethernet frame gap.

Syntax

```
:SOURce:STReam:CONTRol:TYPE FIXED|RANDOM  
:SOURce:STReam:CONTRol:TYPE?
```

Select the setting type from following.

```
FIXED Fixed  
RANDOM Random
```

When selecting FIXED, specify the gap size using :SOURce:STReam:CONTRol:VALue.

When selecting RANDOM, specify the range of the gap size using :SOURce:STReam:CONTRol:RANGe.

Specification of the sending rate as % or bits is set using a command. The gap size corresponding to the required send rate can be confirmed by switching the units of the Stream Control setting at the Test Pattern setting screen of the operation screen.

Response Data

```
FIXED|RANDOM
```

Example of Use

To send the gap size as 12 bytes (100%):

```
:SOURce:STReam:CONTRol:TYPE FIXED  
:SOURce:STReam:CONTRol:VALue 12
```

:SOURce:STReam:CONTRol:VALue**Function**

This command sets the Ethernet frame transmission span (gap size). It also queries the setting of the transmission span.

Syntax

```
:SOURce:STReam:CONTRol:VALue <NR2>  
:SOURce:STReam:CONTRol:VALue?
```

<NR2>: Gap size (bytes)

Response Data

<NR2>

Example of Use

To send the gap size as 12 bytes (100%):

```
:SOURce:STReam:CONTRol:TYPE FIXED  
:SOURce:STReam:CONTRol:VALue 12
```

:SOURce:STReam:COUNT**Function**

This command sets the frame or burst count during the stream. It also queries the frame or burst count during the stream.

Syntax

```
:SOURce:STReam:COUNT <NR1>  
:SOURce:STReam:COUNT?
```

<NR1>: Frame or burst count

Response Data

<NR1>

:SOURce:STReam:DURation:FRAMes

Function

This command sets and queries the number of frames of Test Pattern. It executes the same processing as :SOURce:STReam:DURation:REPeat:COUNT.

Syntax

```
:SOURce:STReam:DURation:FRAMes <NR1>  
:SOURce:STReam:DURation:FRAMes?
```

<NR1>: Number of frames

Response Data

<NR1>

Example of Use

Refer to the example for :SOURce:STReam:DURation:TYPE.

:SOURce:STReam:DURation:REPeat:COUNT

Function

This command sets the repetition rate when the Test Pattern send cycle is Repeat. It also queries the repetition rate. It executes the same processing as :SOURce:STReam:DURation:FRAMes.

Syntax

```
:SOURce:STReam:DURation:REPeat:COUNT <NR1>  
:SOURce:STReam:DURation:REPeat:COUNT?
```

<NR1>: Send repeat count

Response Data

<NR1>

Example of Use

Refer to the example for :SOURce:STReam:DURation:TYPE.

:SOURCE:STREAM:DURATION:TYPE**Function**

This command sets and queries the repetition method of the stream transmission.

Syntax

```
:SOURCE:STREAM:DURATION:TYPE CONT|FRAME|REPEAT
:SOURCE:STREAM:DURATION:TYPE?
```

Select the setting type from the following.

Time cannot be specified by the remote command.

CONT: Continuous

FRAME: Frame

REPEAT: Repeat (Frames)

Sets the stream cycle by :SOURCE:STREAM:DURATION:REPEAT:COUNT when setting REPEAT.

Sets the number of frames by :SOURCE:STREAM:DURATION:FRAMES when setting REPEAT.

Response Data

```
CONT|FRAME|REPEAT
```

When FRAME or REPEAT is set, the query response is as follows depending on the application.

```
100GbE, 40GbE: REPEAT
```

```
OTU4, OTU3: FRAME
```

When Time is set to Duration on the screen, the response data is REPEAT. In this case, the conversion factor for repeat count can be queried with :SOURCE:STREAM:DURATION:REPEAT:COUNT or :SOURCE:STREAM:DURATION:FRAMES.

Example of Use

To send 1000 cycle stream:

```
:SOURCE:STREAM:DURATION:TYPE REPEAT
:SOURCE:STREAM:DURATION:REPEAT:COUNT 1000
```

:SOURce:STReam:ENABle

Function

This command sets sending for each stream. It also queries the sending setting for each stream.

Syntax

```
:SOURce:STReam:ENABle <NR1>[, <NR1>, ...]  
:SOURce:STReam:ENABle?
```

<NR1>[, <NR1>, ...]

Sets number of enabled streams to 1 or more

Response Data

<NR1>[, <NR1>, ...]

Example of Use

To send stream 5, 12, and 15:

```
:SOURce:STReam:ENABle 5,12,15  
:SOURce:STReam:ENABle?  
> 5,12,15
```

:SOURce:STReam:ERRor:TYPE

Function

This command sets and queries the error types appended to the Ethernet frame.

The errors are added to the stream specified by:SOURCE:STReam:ID.

Syntax

```
:SOURce:STReam:ERRor:TYPE FCS|OFF  
:SOURce:STReam:ERRor:TYPE?
```

Selects error type from the following:

```
OFF  None  
FCS  FCS Error
```

Response Data

FCS|OFF

Example of Use

To add the FCS error to all sent frames:

```
:SOURce:STReam:ERRor:TYPE FCS
:SOURce:STReam:ERRor:TYPE?
>FCS
```

:SOURce:STReam:FSIZe**Function**

This command queries the frame size of the sent Ethernet frame.

Syntax

```
:SOURce:STReam:FSIZe?
```

Response Data

```
<NR1>[,<NR1>]
```

<NR1>:

Ethernet frame size in byte units

When the frame size type is set to RANDOM, the Min. and Max. values of the transmitted frame size are returned .

:SOURce:STReam:FSIZe:RANGe**Function**

This command sets the sent Ethernet frame size range. It also queries the size range.

Syntax

```
:SOURce:STReam:FSIZe:RANGe <value1>,<value2>
:SOURce:STReam:FSIZe:RANGe?
```

```
<value1>,<value2> = <NR1>
```

Sets Min. and Max values of frame size in bytes, when selecting

RANDOM. The smaller of the two values is the Min. and the larger is the Max.

Response Data

```
<value1>,<value2> = <NR1>
```

<value1>: Min. value of frame size

<value2>: Max. value of frame size

Example of Use

To change the frame size range randomly from 64 to 1500 bytes:

```
:SOURCE:STReam:FSIZe:TYPE RANDOM  
:SOURCE:STReam:FSIZe:RANGe 64,1500
```

:SOURCE:STReam:FSIZe:TYPE

Function

This command sets whether or not to vary the Ethernet frame size length. It also queries whether the frame size length setting is fixed or variable.

Syntax

```
:SOURCE:STReam:FSIZe:TYPE FIXED|RANDOM  
:SOURCE:STReam:FSIZe:TYPE?
```

Select the setting type from the following.

FIXED
RANDOM

Response Data

FIXED|RANDOM

When selecting FIXED, specify the frame size by :SOURCE:STReam:FSIZe:VALue.

When selecting RANDOM, specify the range of the frame size sent by :SOURCE:STReam:FSIZe:RANGe.

Example of Use

Refer to the example for :SOURCE:STReam:FSIZe:RANGe.

:SOURCE:STReam:FSIZE:VALue**Function**

When the frame size is set to Fixed, the frame size of the Ethernet frame to be sent is set.

This command queries the frame size of the Ethernet frame.

When the pattern setting length*¹ exceeds the Frame Size setting*², frames are sent at the pattern setting length. The actually sent frame size (Min.) is returned at this time.

*1: Pattern setting length: Header Pattern length + Test Frame Min. length (18 at On) + FC length (4)

*2 The Frame Size setting is compared with the Min. setting at Random.

Syntax

```
:SOURCE:STReam:FSIZE:VALue <NR1>
```

```
:SOURCE:STReam:FSIZE:VALue?
```

<NR1>: Frame size when selecting FIXED (in byte unit)

The actually sent frame size can be confirmed using :SOURCE:STReam:FSIZE.

Response Data

<NR1>

Example of Use

To send a 512-byte frame:

```
:SOURCE:STReam:FSIZE:TYPE FIXED
```

```
:SOURCE:STReam:FSIZE:VALue 512
```

:SOURCE:STReam:HEADer

Function

This command sets the stream header format and value, and initializes the setting status of the command below.

:SOURCE:STReam:HEADer:VARiable{3 | 4 | 5}

It queries the stream header format.

Syntax

:SOURCE:STReam:HEADer <format>, <header>

:SOURCE:STReam:HEADer?

<format>=<STRING>: Header format

<header>=<HEX>: Header value

Describe comma-delimited strings in <format> in the order of the following table.

The error (-220) will be generated if the order of group numbers is not in the ascending order or strings with the same order exist.

Set the header pattern (up to 75 bytes) in hexadecimal.

12 bytes of the MAC address (source address and destination address) and 63 bytes of the pattern including EtherType are included in 75 bytes.

Table 3.3.2-4 String to Specify Header Format

Order	<format>	Header
1	NONE	Ethernet only *1
	CUSTOM	Custom Header *1
2	MPLS_TP{1 2 3 4 5}	With MPLS-TP Control Word *2
	MPLS_TP_NOCW{1 2 3 4 5}	Without MPLS-TP Control Word *2
3	B_TAG	PBB (B-TAG+I-TAG)
	I_TAG	PBB (I-TAG)
4	VLAN{1 2}	VLAN *3
5	MPLS{1 2 3}	MPLS *2
6	IPV4	IPv4 *4, *5
	IPV6	IPv6 *4, *6
	ARP	ARP *5, *6
7	ICMPV4_ECHO	ICMPv4 Echo
	ICMPV6_ECHO	ICMPv6 Echo
	ICMPV6_NS	ICMPv6 NS
	ICMPV6_NA	ICMPv6 NA


- * 1: When NONE and CUSTOM are specified, strings of Order 2 and subsequent ones cannot be set. If they are set, the error (-220) will be generated.
- * 2: Set the label count to the number.
- * 3: Set the tag count to the number.
- * 4: This cannot be set at the same time with ARP.
- * 5: This cannot be set at the same time with IPv6.
- * 6: This cannot be set at the same time with IPv4.

Response Data

<STRING>,<HEX>

Example of Use

To set the header format shown in the figure below.



```
:SOURce:STReam:HEADer
"MPLS_TP2,I_TAG,IPV4",&H00FF001000F000FF011000E088470001
0080000101800000000000000500000300000A000008088E700000000
009230001F000092300010000800
:SOURce:STReam:HEADer?
>
"MPLS_TP2,I_TAG,IPV4",&H00FF001000F000FF011000E088470001
0080000101800000000000000500000300000A000008088E700000000
009230001F00009230001000080045000002000040004011B99AC0A8
0000C0A80000
```

:SOURCE:STREAM:HEADER:ETHER:DA

Function

This command sets and queries the value of Destination MAC Address field of the Ethernet frame to be sent.

Syntax

```
:SOURCE:STREAM:HEADER:ETHER:DA <HEX>
:SOURCE:STREAM:HEADER:ETHER:DA?
```

<HEX>: Destination MAC Address (6 octets hexadecimal)

Response Data

<HEX>

Example of Use

Refer to the example for :SOURCE:STREAM:HEADER:ETHER:SA.

:SOURCE:STREAM:HEADER:ETHER:SA

Function

This command sets and queries the value of Source MAC Address field of the Ethernet frame to be sent.

Syntax

```
:SOURCE:STREAM:HEADER:ETHER:SA <HEX>
:SOURCE:STREAM:HEADER:ETHER:SA?
```

<HEX>: Source MAC Address (6 octets hexadecimal)

Response Data

<HEX>

Example of Use

To set the Destination MAC Address field to 00:00:00:00:00:01 and the Source MAC Address field to 00:00:00:00:00:02:

```
:SOURCE:STREAM:HEADER:ETHER:DA #H000000000001
:SOURCE:STREAM:HEADER:ETHER:SA #H000000000002
:SOURCE:STREAM:HEADER:ETHER:DA?
> #H000000000001
:SOURCE:STREAM:HEADER:ETHER:SA?
> #H000000000002
```

:SOURCE:STReam:HEADer:ETHer:TYPE

Function

This command sets the value of Type field of the Ethernet frame to be sent.

Syntax

```
:SOURCE:STReam:HEADer:ETHer:TYPE <HEX>  
:SOURCE:STReam:HEADer:ETHer:TYPE?
```

<HEX>: Type field value (2 octets hexadecimal)

Example of Use

To set the value of Ethernet Type field to 0x0800 (IPv4):

```
:SOURCE:STReam:HEADer:ETHer:TYPE #H0800  
:SOURCE:STReam:HEADer:ETHer:TYPE?  
>#H0800
```

:SOURCE:STREAM:HEADER:PATTERN

Function

This command sets and queries the header pattern of the stream.

Syntax

:SOURCE:STREAM:HEADER:PATTERN <HEX>

:SOURCE:STREAM:HEADER:PATTERN?

<HEX>:

When the ROUTE:BERT command is set to On:

The header pattern (12 bytes of the MAC address (header of source address and destination of source address) and 2 bytes of Ethernet Type field) is set as a hexadecimal number.

When the ROUTE:BERT command is set to Off:

The header pattern (up to 257 bytes) is set as a hexadecimal number.

The 257 bytes include 12 bytes of the MAC address (header of source address and destination of source address) and 2 bytes of the pattern including EtherType field.

Note:

When the ROUTE:BERT command is set to Off, setting the pattern with this command changes the format set with :SOURCE:STREAM:HEADER to CUSTOM.

When the ROUTE:BERT command is set to Off, set the pattern with :SOURCE:STREAM:HEADER.

Response Data

<HEX>

Example of Use

To set value of Ethernet Type field to 0x0800 (IPv4):

```
:SOURCE:STREAM:HEADER:PATTERN
```

```
#H89ABCDABCDEF12345634567888A861008100E0100800450303CE00040004017A199C0A80A14C0A80A18
```

```
:SOURCE:STREAM:HEADER:PATTERN?
```

```
>#H89ABCDABCDEF12345634567888A861008100E0100800450303CE00040004017A199C0A80A14C0A80A18
```


:SOURCE:STReam:HEADer:VARiable1:RANGe**Function**

This command sets the destination MAC address variable range. Also, it sets the variable range of the Stream Control/Header dialog Modifiers tab Field 1 simultaneously.

It queries the destination MAC address variable range.

Syntax

```
:SOURCE:STReam:HEADer:VARiable1:RANGe
```

```
<offset>,<length>,<count>
```

```
:SOURCE:STReam:HEADer:VARiable1:RANGe?
```

```
<offset>,<length>,<count>=<NR1>
```

<offset>: Number of bytes from Ethernet frame header. (0 to 5)

<length>: Variable byte count (1 to 6)

<count>: Generated count (1 to n)

Sets as <offset>+<length>< 7

The value of n varies with <length>.

<length>	<count>
1	1 to 256
2	1 to 65536
3	1 to 16777216
4	1 to 4294967296
5	1099511627776
6	281474976710656

When <length> is set to 5 or 6, the value is ignored even though setting the value other than the numeric values listed in Table to <count>.

Response Data

```
<offset>,<length>,<count>
```

:SOURCE:STReam:HEADer:VARiable1:TYPE

Function

This command sets the destination MAC address variable method (Off/Decrement/Increment/Random). Also, it sets the variable method of the Stream Control/Header dialog Modifiers tab Field 1 simultaneously. It queries the destination MAC address variable method.

Syntax

```
:SOURCE:STReam:HEADer:VARiable1:TYPE  
DECREMENT | INCREMENT | OFF | RANDOM  
:SOURCE:STReam:HEADer:VARiable1:TYPE?
```

Select the type from following.

OFF OFF indicates Fixed at Stream Control/Header screen
DECREMENT
INCREMENT
RANDOM

Response Data

```
DECREMENT | INCREMENT | OFF | RANDOM
```

:SOURCE:STReam:HEADer:VARiable2:RANGe

Function

This command sets the source MAC address variable range. Also, it sets the variable range of the Stream Control/Header dialog Modifiers tab Field 2 simultaneously. It queries the source MAC address variable range.

Syntax

```
:SOURCE:STReam:HEADer:VARiable2:RANGe  
<offset>, <length>, <count>  
:SOURCE:STReam:HEADer:VARiable2:RANGe?
```

<offset>, <length>, <count>=<NR1>

<offset>: Number of bytes from Ethernet frame header. (6 to 11)

<length>: Variable byte count (1 to 6)

<count>: Generated count (1 to n)

Sets as <offset>+<length><13

The value n varies with <length>.

<length>	<count>
1	1 to 256
2	1 to 65536
3	1 to 16777216
4	1 to 4294967296
5	1099511627776
6	281474976710656

When <length> is set to 5 or 6, the value is ignored even though setting the value other than the numeric values listed in Table to <count>.

The offset setting range is different at the screen and by remote command.

At the Stream Control/Header screen, the offset value is from the Source MAC address header but at remote command it is from the Ethernet frame header.

Response Data

<offset>,<length>,<count>

:SOURce:STReam:HEADer:VARiable2:TYPE

Function

This command sets the source MAC address variable method (Off/Decrement/Increment/Random).Also, it sets the variable method of the Stream Control/Header dialog Modifiers tab Field 2 simultaneously. It queries the source MAC address variable method.

Syntax

```
:SOURce:STReam:HEADer:VARiable1:TYPE
DECREMENT | INCREMENT | OFF | RANDOM
:SOURce:STReam:HEADer:VARiable1:TYPE?
```

Select the type from following.

OFF OFF indicates Fixed at Stream Control/Header screen
 DECREMENT
 INCREMENT
 RANDOM

Response Data

DECREMENT | INCREMENT | OFF | RANDOM

:SOURCE:STReam:HEADer:VARiable{3|4|5}

Function

This command sets parameters of the Stream Control/Header dialog Modifiers tab Field 3, 4, and 5.

It queries parameters of the Stream Control/Header dialog Modifiers tab Field 3, 4, and 5.

Syntax

```
:SOURCE:STReam:HEADer:VARiable{3|4|5}
<type>[,<field>,<offset>,<length>,<min>,<max>,<step>]
:SOURCE:STReam:HEADer:VARiable{3|4|5}?
```

<type>==CHAR

Specify the following strings to <type>.

OFF Parameters on the Stream Control/Header dialog are Fixed.

DECREMENT

INCREMENT

RANDOM

When OFF is set to <type>, the second parameter and subsequent ones can be omitted. In addition, even if the second parameter and subsequent ones are set, they are ignored.

<field>==CHAR

Specify the string in the following table to <field>.

Table 3.3.2-5 String to Specify Offset Location

<CHAR>	Header offset location
TOP	Top of Frame *1
MPLS_TP_EXP{1 2 3 4 5}	MPLS-TP Tags Label
MPLS_TP_LABEL{1 2 3 4 5}	MPLS-TP Tags Exp
MPLS_TP_TTL{1 2 3 4 5}	MPLS-TP Tags TTL
CW_NIB	MPLS Control Word first nibble
CW_FLAG	MPLS Control Word flags
CW_FRG	MPLS Control Word FRG (Fragmentation)
CW_LENGTH	MPLS Control Word Length
CW_SEQ	MPLS Control Word Sequence Number
PBB_DA	PBB Destination MAC Address *2
PBB_SA	PBB Source MAC Address *2
PBB_{B I}_PCP	PBB Tags PCP
PBB_B_VID	PBB B-Tag VID
PBB_I_SID	PBB I-Tag SID

Table 3.3.2-5 String to Specify Offset Location (Continued)

<CHAR>	Header offset location
ETH_DA	Ethernet Destination MAC Address * ³
ETH_SA	Ethernet Source MAC Address * ³
ETH_TYPE	Ethernet Type
VLAN_{1 2}_PCP	VLAN Tags PCP
VLAN_{1 2}_VID	VLAN Tags VID
MPLS_EXP{1 2 3}	MPLS Tags Label
MPLS_LABEL{1 2 3}	MPLS Tags Exp
MPLS_TTL{1 2 3}	MPLS Tags TTL
IPV4_DA	IPv4 Destination Address
IPV4_SA	IPv4 Source Address
IPV4_TOS	IPv4 TOS
IPV4_TTL	IPv4 TTL
IPV4_PROT	IPv4 Protocol
IPV6_DA	IPv6 Destination Address
IPV6_SA	IPv6 Source Address
IPV6_TCLASS	IPv6 Traffic Class
IPV6_FLABEL	IPv6 Flow Label
IPV6_HOP	IPv6 Hop Limit
ARP_SMAC	ARP Source MAC Address
ARP_SIP	ARP Source IP Address
ARP_TMAC	ARP Target MAC Address
ARP_TIP	ARP Target IP Address
ARP_OPE	ARP Operation
ICMPV4_CODE	ICMPv4 Code
ICMPV4_EC_ID	ICMPv4 Identifier
ICMPV4_EC_SEQ	ICMPv4 Sequence No.
ICMPV6_CODE	ICMPv6 Code
ICMPV6_EC_ID	ICMPv6 Identifier
ICMPV6_EC_SEQ	ICMPv6 Sequence No.
ICMPV6_NSNA_TADDR	ICMPv6 Target Address
ICMPV6_NSNA_SADDR	ICMPv6 Source Link Layer Address

* 1: When other than CUSTOM is set with :SOURCE:STREAM:HEADER, specifying TOP with this command generates the error (-220).

* 2: Can be specified when MPLS_TP and PBB are set to the stream format

* 3: Can be specified when MPLS_TP or PBB are set to the stream format

The same string cannot be set to <field> among Field 3 to 5. If the same string is set to <field> among Field 3 to 5, the error (-220) will be generated.

Changing the stream frame with :SOURCE:STREAM:HEADER turns OFF the <type> setting.

Specifying a field that does not exist in the frame format set with :SOURCE:STREAM:HEADER to <format> generates the error (-220).

Setting the stream format to Custom Header with :SOURCE:STREAM:HEADER changes the <format> setting of this command to TOP.

Setting the stream format to other than Custom Header with :SOURCE:STREAM:HEADER changes the <format> setting of this command to ETH_TYPE.

<offset>,<length>,<min>,<max>,<step>=<NR1>

<offset>: Bit count from the beginning of the target range
Settable values depend on the target range bit count.

<length>: Bit count (1 to 32) to be changed
Settable values depend on the target range bit count and <offset> values.

<min>: Field minimum value

<max>: Field maximum value

<step>: Field value change amount


Response Data

<CHAR>,<CHAR>,<NR1>,<NR1>,<NR1>,<NR1>,<NR1>

In the order of <type>, <field>, <offset>, <length>, <min>, <max>, and <step>

Example of Use

To set the parameters at the Field 3 in the Modifiers tab as shown in the following screen shot.



```
:SOURCE:STREAM:HEADER:VARIABLE3
RANDOM,MPLS_TTL1,0,8,0,255,1
:SOURCE:STREAM:HEADER:VARIABLE3?
> RANDOM,MPLS_TTL1,0,8,0,255,1
```

:SOURCE:STREAM:ID**Function**

This command sets and queries the stream ID to be edited.

When editing the stream, set ID beforehand.

When connecting multiple units, :SOURCE:STREAM:ID must be set per unit.

Syntax

:SOURCE:STREAM:ID <NR1>

:SOURCE:STREAM:ID?

<NR1>: Stream ID (1 to 16)

Response Data

<NR1>

Example of Use

To set stream No. 2 for unit number 1 through 3:

(Stream setting of the Unit No.1)

:UENTry:ID 1

:SOURCE:STREAM:ID 2

(Stream setting of the Unit No.2)

:UENTry:ID 2

:SOURCE:STREAM:ID 2

(Stream setting of the Unit No.3)

:UENTry:ID 3

:SOURCE:STREAM:ID 2

:SOURCE:STReam:RESolve:IP:TARGet

Function

This command sets and queries the IP address that should be queried by ARP.

Syntax

```
:SOURCE:STReam:RESolve:IP:TARGet <CHAR>
:SOURCE:STReam:RESolve:IP:TARGet?
```

<CHAR>=GATEWAY|IPADDRESS

GATEWAY: Gateway IP Address

IPADDRESS: Destination IP Address

Response Data

GATEWAY|IPADDRESS

Example of Use

```
:SOURCE:STReam:RESolve:IP:TARGet IPADDRESS
:SOURCE:STReam:RESolve:IP:TARGet?
> IPADDRESS
```

:SOURCE:STReam:RESolve:IPV4:ROUTer

Function

This command sets and queries the Gateway IPv4 address that should be queried by ARP.

Syntax

```
:SOURCE:STReam:RESolve:IPV4:ROUTer <HEX>
:SOURCE:STReam:RESolve:IPV4:ROUTer?
```

<HEX>: Gateway IPv4 address (4-byte hexadecimal number)

Example of Use

To set the Gateway IP address to 192.168.1.10 (0xC0A8010A).

```
:SOURCE:STReam:RESolve:IPV4:ROUTer #HC0A8010A
:SOURCE:STReam:RESolve:IPV4:ROUTer?
>#HC0A8010A
```


:SOURCE:STReam:RESolve:IPV6:ROUTer**Function**

This command sets and queries the Gateway IPv6 address that should be queried by NS.

Syntax

```
:SOURCE:STReam:RESolve:IPV6:ROUTer <HEX>  
:SOURCE:STReam:RESolve:IPV6:ROUTer?
```

<HEX>: Gateway IPv6 address (16-byte hexadecimal number)

Example of Use

To set the Gateway IP address to 2001::1.

```
:SOURCE:STReam:RESolve:IPV6:ROUTer  
#H20010000000000000000000000000001  
:SOURCE:STReam:RESolve:IPV6:ROUTer?  
>#H20010000000000000000000000000001
```

:SOURCE:STReam:RESolve:MAC:RETRy**Function**

This command sets and queries the number of retries to resolve the MAC address.

Syntax

```
:SOURCE:STReam:RESolve:MAC:RETRy <NR1>  
:SOURCE:STReam:RESolve:MAC:RETRy?
```

<NR1>=1 to 100

Response Data

<NR1>

Example of Use

To set the number of retries to resolve the MAC address to 10.

```
:SOURCE:STReam:RESolve:MAC:RETRy 10  
:SOURCE:STReam:RESolve:MAC:RETRy?  
> 10
```

:SOURce:STReam:RESolve:MAC:TIMEout

Function

This command sets and queries the timeout for MAC address resolution.

Syntax

```
:SOURce:STReam:RESolve:MAC:TIMEout <NR1>  
:SOURce:STReam:RESolve:MAC:TIMEout?
```

<NR1>: Timeout 3 to 10 seconds

Response Data

<NR1>

Example of Use

```
:SOURce:STReam:RESolve:MAC:TIMEout 10  
:SOURce:STReam:RESolve:MAC:TIMEout?  
> 10
```

:SOURce:STReam:RESolve:PING:TRY

Function

This command sets and queries the number of times to execute the Ping.

Syntax

```
:SOURce:STReam:RESolve:PING:TRY <NR1>  
:SOURce:STReam:RESolve:PING:TRY?
```

<NR1>: Number of Ping execution times 1 to 100

Response Data

<NR1>

Example of Use

```
:SOURce:STReam:RESolve:PING:TRY 20  
:SOURce:STReam:RESolve:PING:TRY?  
> 20
```

:SOURCE:STREAM:RESOLVE:PING:PAYLOAD**Function**

This command sets and queries the payload type to execute the Ping.

Syntax

```
:SOURCE:STREAM:RESOLVE:PING:PAYLOAD ALL0|ALL1|DEFAULT
:SOURCE:STREAM:RESOLVE:PING:PAYLOAD?
```

ALL0:	All 0
ALL1:	All 1
ALTERNATE:	0/1 pattern

Response Data

ALL0|ALL1|ALTERNATE

Example of Use

```
:SOURCE:STREAM:RESOLVE:PING:PAYLOAD ALL0
:SOURCE:STREAM:RESOLVE:PING:PAYLOAD?
> ALL0
```

:SOURCE:STREAM:RESOLVE:PING:TIMEOUT**Function**

This command sets and queries the Ping timeout.

Syntax

```
:SOURCE:STREAM:RESOLVE:PING:TIMEOUT <NR1>
:SOURCE:STREAM:RESOLVE:PING:TIMEOUT?
```

<NR1>: Ping timeout 3 to 10 seconds

Response Data

<NR1>

Example of Use

```
:SOURCE:STREAM:RESOLVE:PING:TIMEOUT 10
:SOURCE:STREAM:RESOLVE:PING:TIMEOUT?
> 10
```

:SOURCE:STReam:RESolve:RESult

Function

This command queries the result of MAC address resolution or Ping execution.

Syntax

`:SOURCE:STReam:RESolve:RESult? <CHAR>`

`<CHAR>=PING|RESOLVE`

PING: Ping

RESOLVE: Resolve

Response Data

`<NR1>,<NR1>,<NR1>,....<NR1>`

`<NR1>`: Result of MAC address resolution or Ping execution

0: Success

1: Excluded or not executed.

2: Failure

Response data is 1 when MAC address resolution or Ping execution is in progress.

The number of response data is 16. Every one of them is a result of Streams 1 to 16.

Example of Use

`:SOURCE:STReam:RESolve:RESult? RESOLVE`

`> 0,0,0,0,0,0,1,2,2,2,2,2,2,2,2,2`

:SOURCE:STREAM:RESOLVE:START**Function**

This command sets Stream(s) to start MAC address resolution or Ping execution.

Syntax

```
:SOURCE:STREAM:RESOLVE:START <CHAR>
```

```
<CHAR>=ALL|IPV4ALL|IPV6ALL|S1|S2|S3|S4|S5|S6|S7|S8|S9|
S10|S11|S12|S13|S14|S15|S16
```

ALL: All Streams

IPV4ALL: All Streams including IPv4 in the frame configuration

IPV6ALL: All Streams including IPv6 in the frame configuration

S1: Stream 1

S2: Stream 2

:

S16: Stream 16

:SOURCE:STREAM:RESOLVE:START:EVENT**Function**

This command queries the start event for MAC address resolution or Ping execution.

If the start event is read, then the response data is 0.

Syntax

```
:SOURCE:STREAM:RESOLVE:START:EVENT?
```

Response Data

```
0|1
```

0: MAC address resolution or Ping execution has not started.

Event has been read after the start of MAC address resolution or Ping execution.

1: MAC address resolution or Ping execution has started.

Example of Use

```
:SOURCE:STREAM:RESOLVE:START ALL
:SOURCE:STREAM:RESOLVE:START:EVENT?
> 1
:SOURCE:STREAM:RESOLVE:START:EVENT?
> 0
```

:SOURCE:STREAM:RESOLVE:STATUS

Function

This command queries the status of MAC address resolution or Ping execution.

Syntax

```
:SOURCE:STREAM:RESOLVE:STATUS?
```

Response Data

0|1|2

0: End of MAC address resolution or Ping execution.

1: MAC address resolution or Ping execution in progress.

2: MAC address resolution or Ping execution ended but results of part or all of Streams are Failure.

Example of Use

```
:SOURCE:STREAM:RESOLVE:START ALL
```

```
:SOURCE:STREAM:RESOLVE:STATUS?
```

```
> 1
```

:SOURCE:STREAM:RESOLVE:STOP

Function

To stop MAC address resolution or Ping execution.

Syntax

```
:SOURCE:STREAM:RESOLVE:STOP
```

Example of Use

```
:SOURCE:STREAM:RESOLVE:STOP
```

```
:SOURCE:STREAM:RESOLVE:STATUS?
```

```
> 2
```

:SOURce:STReam:RESolve:TYPE**Function**

This command sets and queries the type of resolution.

Syntax

```
:SOURce:STReam:RESolve:TYPE <CHAR>  
:SOURce:STReam:RESolve:TYPE?
```

<CHAR>=RES|RES_PING|PING

PING: Ping Only

RES: Resolve Only

RES_PING: Resolve & Ping

Response Data

PING|RES|RES_PING

Example of Use

```
:SOURce:STReam:RESolve:TYPE RES  
:SOURce:STReam:RESolve:TYPE?  
> RES
```

:SOURCE:STReam:STARt[:AUNit]

Function

This command starts the stream transmission.
When already sending the stream, it restarts the stream.
Adding :AUNit starts sending the stream for all connected units simultaneously.

Syntax

:SOURCE:STReam:STARt [:AUNit]

When the remote command for the stream (:SOURCE:STReam:*) is sent, Control Unit at the stream screen is changed to Gap Size (byte).

Example of Use

To start the stream transmission:

1. Clear the start event by sending :SOURCE:STReam:STARt:EVENT? .
2. Start the stream transmission by sending :SOURCE:STReam:STARt .
3. Sending :SOURCE:STReam:STARt:EVENT? is repeated until the response data is 1 (started).

:SOURCE:STReam:STARt:EVENT[:AUNit]

Function

This command queries the start event of the stream transmission.
When sending the stream, it becomes 1.

Syntax

:SOURCE:STReam:STARt:EVENT [:AUNit] ?

Response Data

0 | 1

0: 0 before counter started

1: Cleared to 0 after reading with this command

Adding :AUNit to the header sets the stream transmission of all connected units to 1 when started.

Example of Use

Refer to the example for :SOURCE:STReam:STARt[:AUNit].

:SOURCE:STREAM:STATUS[:AUNIT]**Function**

This command queries the stream sending operation status.
When :AUNIT is added to the header, becomes 1 when the stream transmission starts at any of units and becomes 0 when all units stopped.

Syntax

:SOURCE:STREAM:STATUS[:AUNIT]?

Response Data

0|1

0: Stream transmission stopped

1: Transmitting stream

When :AUNIT is added to the header, becomes 1 when the stream transmission starts at any of units and becomes 0 when all units stopped.

Example of Use

Refer to the example for :SOURCE:STREAM:STOP[:AUNIT].

:SOURCE:STREAM:STOP[:AUNIT]**Function**

This command stops the stream transmission. When adding :AUNIT, this command stops the stream transmission of all units connected.

Syntax

:SOURCE:STREAM:STOP[:AUNIT]

Example of Use

To stop the stream transmission:

1. Stop the stream transmission by sending :SOURCE:STREAM:STOP .
2. Send repeatedly until the :SOURCE:STREAM:STATUS? response becomes 0 (stopped).

:SOURce:STReam:TFRame:ENABle

Function

This command sets and queries whether to enable/disable the test frame specified by :SOURce:STReam:ID.

Syntax

```
:SOURce:STReam:TFRame:ENABle 0|1|OFF|ON  
:SOURce:STReam:TFRame:ENABle?
```

```
0|OFF:      Disables test frame  
1|ON:       Enables test frame
```

Response Data

```
0|1
```

Example of Use

To enable test frame:

```
:SOURce:STReam:TFRame:ENABle ON  
:SOURce:STReam:TFRame:ENABle?  
> 1
```

:SOURce:STReam:TFRame:FID

Function

This command sets the flow ID of the test frame corresponding to the stream being edited.

It also queries the flow ID settings of the test frame.

The stream for setting the test frame can be set using :SOURce:STReam:ID.

Syntax

```
:SOURce:STReam:TFRame:FID <NR1>  
:SOURce:STReam:TFRame:FID?
```

```
<NR1>:      Flow ID(0 to 15)
```

Response Data

```
<NR1>
```

Example of Use

To set the flow ID of the stream No. 5 to 12:

```
:SOURce:STReam:ID 5
:SOURce:STReam:TFRame:FID 12
:SOURce:STReam:TFRame:FID?
> 12
```

:SOURce:STReam:TYPE**Function**

This command sets and queries the stream transmission method.

Syntax

```
:SOURce:STReam:TYPE RANDOM|SEQUENTIAL
:SOURce:STReam:TYPE?
```

SEQUENTIAL: Send the stream number from the smallest one repeatedly.

RANDOM: Send the stream number randomly.

Response Data

RANDOM|SEQUENTIAL

:SOURce:TPATtern:INVert**Function**

This command inverts the PRBS test pattern settings (transmission). It also queries the inverse settings of the PRBS test pattern (transmission).

:SOURce:TPATtern:INVert sets the inverse pattern at the reception side.

Syntax

```
:SOURce:TPATtern:INVert 0|1|OFF|ON
:SOURce:TPATtern:INVert?
```

0|OFF: Inverse pattern Off

1|ON: Inverse pattern On

Response Data

0|1

Example of Use

Refer to the example for :SENSe:TPATtern:INVert.

:SOURce:TPATtern:TYPE

Function

This command sets and queries the test pattern types of the transmission side (Tx).

Syntax

:SOURce:TPATtern:TYPE <CHAR>

:SOURce:TPATtern:TYPE?

<CHAR>

The text pattern types are as shown below. Select any of them.

- PRBS7
- PRBS9
- PRBS11
- PRBS15
- PRBS23
- PRBS31
- ALL0
- ALL1
- WORD16
- SQUARE : Square Wave

Mapping	Text pattern type
40GbE, 100GbE, OTU4 Ethernet Client	PRBS31, ALL0, ALL1, WORD16
OTU3-PRBS, OTU4-PRBS	PRBS11, PRBS15, PRBS23, PRBS31, WORD16
OTU4-ODTU4.8-ODU2e-PRBS, OTU4-ODTU4.1-ODU0-PRBS	PRBS31, Word16
100GbE No Frame, 40GbE No Frame, OTU4 No Frame, OTU3 No Frame,	PRBS7, PRBS9, PRBS11, PRBS15, PRBS23, PRBS31, SQUARE

Response Data

ALL0|ALL1|PRBS7|PRBS9|PRBS11|PRBS15|PRBS23|PRBS31|SQUARE|WORD16

Example of Use

:SOURce:TPATtern:TYPE PRBS31

:SOURce:TPATtern:TYPE?

>PRBS31

:SOURCE:TPATTERN:WORD**Function**

This command sets the pattern when selecting Word16 at the test pattern of the transmission side (Tx). It also queries the Word16 pattern of the transmission side (Tx).

Syntax

```
:SOURCE:TPATTERN:WORD <HEX>  
:SOURCE:TPATTERN:WORD?
```

<HEX>: Values of Data Field (2 bytes)

Response Data

<HEX>

Example of Use

```
:SOURCE:TPATTERN:TYPE WORD16  
:SOURCE:TPATTERN:WORD #H55AA  
:SOURCE:TPATTERN:WORD?  
>#H55AA
```

:SOURCE:TRANSceiver:EMPHasis:FIRSt

Function

This command sets Pre-Emphasis (First) of the transceiver. It also queries the Pre-Emphasis (First) of the transceiver.

Syntax

:SOURCE:TRANSceiver:EMPHasis:FIRSt <lane>,<value>
 :SOURCE:TRANSceiver:EMPHasis:FIRSt? <lane>

<lane>,<value>=<NR1>

<lane>: Lane number

Application	Range of <lane>
40GbE,OTU3	0 to 3
100GbE,OTU4	0 to 19
40GbE No Frame, OTU3 No Frame	0 to 3
100GbE No Frame, OTU4 No Frame	0 to 19

<value>: Setting value (0 to 31)

Response Data

<NR1>

:SOURCE:TRANSceiver:EMPHasis:PRE

Function

This command sets Pre-Emphasis (Pre) of the transceiver. It also queries the Pre-Emphasis (Pre) settings of the transceiver.

Syntax

:SOURCE:TRANSceiver:EMPHasis:PRE <lane>,<value>
 :SOURCE:TRANSceiver:EMPHasis:PRE? <lane>

<lane>,<value>=<NR1>

<lane>: Lane number

For the setting range of the lane number, refer to the explanation of:SOURCE:TRANSceiver:EMPHasis:FIRSt.

<value>: Setting value (-15~+15)

Response Data

<NR1>

:SOURce:TRANsceiver:EMPHasis:SECond**Function**

This command sets the Pre-Emphasis (Second) of the transceiver. It also queries the Pre-Emphasis (Second) settings of the transceiver.

Syntax

```
:SOURce:TRANsceiver:EMPHasis:SECond <lane>,<value>
:SOURce:TRANsceiver:EMPHasis:SECond? <lane>
```

```
<lane>,<value>=<NR1>
```

```
<lane>: Lane number
```

For the setting range of the lane number, refer to the explanation of :SOURce:TRANsceiver :EMPHasis:FIRSt.

```
<value>: Setting value (-15 to +15)
```

Response Data

```
<NR1>
```

:SOURce:TRANsceiver:VOD**Function**

This command sets VOD of the transceiver. It also queries the VOD settings of the transceiver.

Syntax

```
:SOURce:TRANsceiver:VOD <lane>,<value>
:SOURce:TRANsceiver:VOD? <lane>
```

```
<lane>,<value>=<NR1>
```

```
<lane>: Lane number
```

For the setting range of the lane number, refer to the explanation of :SOURce:TRANsceiver :EMPHasis:FIRSt.

```
<value>: Setting value (0 to 6)
```

Response Data

```
<NR1>
```

:SYSTem:CONFig

Function

This command switches the application of the MD1260A. Executing this command restarts the application. It can be checked with :SYSTem:STATus? command whether the restart has been completed or not. Commands other than :SYSTem:ERRor? and :SYSTem:STATus? cannot be used during restart.

Syntax

:SYSTem:CONFig <CHAR> [, <CHAR> [, <CHAR>... [, <CHAR>]...]

<CHAR>

Specify the application/mapping of Unit ID 1, 2, ..., 16 to <CHAR>. Specify NONE to the unit ID not to be connected. However, following NONEs can be omitted.

For <CHAR>, specify any of the following.

Application/Mapping	<CHAR>
None	NONE
40GbE	E40G
100GbE	E100G
ODU3-PRBS	OTU3
ODU4-PRBS	OTU4
ODU4-100GbE	OTU4_E
ODTU4.8-ODU2e-PRBS	OTU4_ODU2E
ODTU4.8-ODU2e-10GbE	OTU4_ODU2E_E
ODTU4.1-ODU0-PRBS	OTU4_ODU0
ODTU4.1-ODU0-GbE	OTU4_ODU0_E
40GbE No Frame	E40G_N
100GbE No Frame	E100G_N
OTU3 No Frame	OTU3_N
OTU4 No Frame	OTU4_N

Example of Use

To specify 40GbE to Unit ID 1 and 100GbE to Unit ID 3:

```
:SYSTem:CONFig E40G,NONE,E100G
```

To specify ODU4-100GbE to Unit ID4:

```
:SYSTem:CONFig NONE,NONE,NONE,OTU4_E
```

Use :SOURce:MAPPING to query the application mapping running.

```
:UENTry:ID 1
```

```
:SOURce:MAPPING?
```

```
> OTU4
```

```
:UENTry:ID 2
```

```
:SOURce:MAPPING?
```



```

> OTU4
To switch the application/mapping of Unit ID1 to Unit ID3:
:SYSTem:CONFIg OTU4_E,OTU4_ODU2E_E
:SYSTem:ERRor?
> 0,"No error"
:SYSTem:STATus? allows checking the restart has been completed.
:SYSTem:STATus?
> 0
:
:
:SYSTem:STATus?
> 1

```

When the restart is completed, other remote commands can be used for operation.

```

:UENTry:ID 1
:SOURce:MAPPing?
> OTU4_E
:UENTry:ID 2
:SOURce:MAPPing?
> OTU4_ODU2E_E

```

To set the number of lanes for 100GbE No Frame or OTU4 No Frame application, use :SOURce:MAPPing.

:SYSTem:DATE

Function

This command queries the date and time. The time is returned by :SYSTem:TIME?.

Syntax

```
:SYSTem:DATE?
```

Response Data

```
<year>, <month>, <day> = <NR1>
```

Returns year, month, and date in comma-separated order

Example of Use

```

:SYSTem:DATE?;:SYSTem:TIME?
> 2010,10,7;12,40,3
(12:40:03 7 June 2010)

```

:SYSTem:ERRor

Function

This command queries the error information saved in the error event queue. One data item is read from the event queue each time.

Syntax

```
:SYSTem:ERRor?
```

Response Data

```
<error_event_number>,"<error_event_description>"
```

```
<error_event_number> = <NR1>
```

The range of the error code is from -32768 to +32767.

0 indicates that no errors or events have occurred.

```
<error_event_description> = <STRING>
```

<error_event_number>: This is the error messages corresponding to the value of <error_event_number>. The maximum length of this character string is 255.

A maximum of 128 error events can be saved in the event queue.

When the error event queue is full, nothing more can be stored so the the generated error information is discarded without discarding error information saved in the event queue. When this happens, the -350 (Queue overflow) error information is stored at the event 128 in the queue.

Example of Use

When sending a command that the application does not support, the -113 (Undefined header) error is returned.

Example: When sending command not supported by 100GbE application:

```
:CALCulate:MONitor:OTU:COLumn 1
:SYSTem:ERRor?
> -113,"Undefined header"
```

When specifying a parameter that the application does not support, -220,"Parameter error" is returned.

Example: When sending parameter not supported by 100GbE application:

```
:SOURce:EALarm:TYPE FAS_MLD
:SYSTem:ERRor?
>-220,"Parameter error"
```

When specifying parameter that cannot be executed in the current application status, -310,"System error" is returned.

Example: When specifying non-existent command that cannot be loaded by :MMEMory:RECall

```
:MMEMory:RECall "nonexistent_file"
:SYSTem:ERRor?
> -310,"System error"
```

In these cases, the error can be confirmed by sending SYSTem:ERRor? immediately after the sent command. Refer to Section 2.6 Confirming Message Execution Status and Appendix B Error Codes.

However, since the errors are saved in the queue, if the queue is not checked each time it is emptied, sometimes it is not possible to capture immediately preceding command errors, as follows:

```
:SOURce:EALarm:TYPE FAS_MLD
:MMEMory:RECall "nonexistent_file"
:SYSTem:ERRor?
> -220,"Parameter error"← :SOURce:EALarm:TYPE error
:SYSTem:ERRor?
> -310,"System error"← :MMEMory:RECall error
:SYSTem:ERRor?
> 0,"No error"← becomes "No error" when queue empty
:SYSTem:ERRor?
> 0,"No error"
```

:SYSTem:PRINT:COPY

Function

This command copies the screen.

Syntax

```
:SYSTem:PRINT:COPY
```

The currently displayed screen is output as a PNG format file. The screen copy file is created in the following path.

```
C:\Documents and Settings\Administrator
\My Documents\Anritsu\MD1260A\UserData\Screen Copy
```

:SYSTem:STATus

Function

This command queries whether the application is running.
Use it after the application is set with :SYSTem:CONFig.

Syntax

:SYSTem:STATus?

Response Data

0|1

0: Stopped or starting

1: Running

:SYSTem:TERMination

Function

This command sets and queries the terminator types of the response data

Syntax

:SYSTem:TERMination 0|1

:SYSTem:TERMination?

Displays terminator types

0: LF

1: CR+LF

Response Data

0|1

The equipment start status is 0 (LF). Since this setting is not backed-up, the start status is always (LF). In addition, this setting cannot be changed with the *RST command.

With the GPIB option, EOI (GPIB bus line signal) is generated simultaneously.

Example of Use

Refer to Section 2.4 Checking Connection for Ethernet.

:SYSTem:TIME**Function**

This command queries the time. The date is queried by :SYSTem:DATE?.

Syntax

:SYSTem:TIME?

Response Data

<hour>,<min>,<sec> = <NR1>

Returns hour, minute, and second in comma-separated order

Example of Use

Refer to :SYSTem:DATE.

:SYSTem:VERSion**Function**

This command queries the SCPI version conforming to the MD1260A software.

Syntax

:SYSTem:VERSion?

Response Data

1999.0

1999.0 is returned in the SCPI version. (year: 1999, revision number : 0)

:UENTry:ID

Function

This command sets and queries the Unit ID for the target operation.

Syntax

:UENTry:ID <NR1>
:UENTry:ID?

<NR1>: Unit ID from Unit 1 to Unit 16 (1~16)

Response Data

<NR1>

The -220 error is returned for out of range or when the set Unit ID is not connected.

Example of Use

To set Unit ID for target operation to ID 16:

```
:UENTry:ID 16  
:UENTry:ID?  
> 16
```

:UENTry:LIST

Function

This command queries operable Unit IDs.

Syntax

:UENTry:LIST?

Response Data

<num of unit>, <unit id> [, <unit id>, <unit id>, ...]= <NR1>
<num of unit>: Count of operable units
<unit id>: ID of Unit ID

When there are multiple operable units, the Unit IDs are arranged in the following order.

Master Unit ID

Slave IDs (from smallest)

Example of Use

```
:UENTry:LIST?  
> 3,1,2,16
```

Chapter 4 Operation Record Function

This chapter explains the function for making a remote control program.

4.1	Outline of Operation Record Function	4-2
4.2	Starting/Stopping Operation Record Function	4-3

4.1 Outline of Operation Record Function

The operation record function supports making a remote control program.

When setting the parameter etc. on the MD1260A screen while executing the operation record function, a remote control command corresponding to the screen operation is saved to the text file.

When using the operation record function, the command querying the setting details and measurement results can be saved to the text file as well.

```
*** Operation Log Start
:UENTry:ID 1
*** Test Pattern Setting
:SOURce:STReam:HEADer:ETHer:SA
#H0123456789AB
:SOURce:STReam:HEADer:ETHer:TYPE #H1234
:SOURce:STReam:ERRor:TYPE FCS
:SOURce:STReam:FSIZe:TYPE FIXED
:SOURce:STReam:FSIZe:VALue 60
:SOURce:STReam:FSIZe:RANGe 60,16376

*** Operation Log End
```

Figure 4.1-1 File Creation Using Operation Record Function

The measurement result file is saved in the following folder.
C:\Documents and Settings\Administrator\My Documents
\Anritsu\MD1260A\UserData\Operation Log

The file name is as follows.

'OperationLog'+ '_' +date +hour, min, second+ millisecond

The file name saved to 55.324 at 16:40:55, October 7, 2010 is as follows.

OperationLog_20101007T164055324.txt

Restrictions

For the operation record function, there are following restrictions.

- The setting dialog operation without the OK button is not recorded.
Example: [Write] and [Read] on the MDIO screen
- The panel operation without the relevant remote commands is not recorded.

Refer to Section 3.2.7 "Panel operation not controlled remotely".

4.2 Starting/Stopping Operation Record Function

Starting operation record function

After starting the application, the operation record function is started according to the following procedure.

1. Touch [System Menu].
2. Touch [Operation REC]. Operation Record Panel opens. The record of a remote command corresponding to the screen operation starts at the time of this. However, the operation for Operation Record Panel, and the operation without corresponding remote command are not recorded in the file.
3. Touching System Menu, setting area, operation area, or button on the top menu operates the MD1260A. The remote command corresponding to the operation is saved in the file.
4. When Operation Record Panel is hidden, touch [Operation REC] of [System Menu].
5. When recording the comments corresponding to the screen operation, touch the comment text box of Operation Record Panel and enter the characters. When touching [Insert], the comment is saved in the file.




Figure 4.2-1 Operation Record Panel

When saving the the Query command to acquire the measurement result to the file, the following operation is performed.

1. Touch [Select] of Operation Record Panel. The Select screen opens.
2. Touch the measurement item to be read.
3. Touch [OK].
4. Touch [Acquisition] of Operation Record Panel.

A remote command reading the measurement item is saved to the file.

Stopping operation record function

Touch [Stop] of Operation Record Panel.

Or, touch the close button of Operation Record Panel.

Appendix A Measurement Item List

This appendix explains the compatibility of measurement items displayed on-screen and remote commands.

"IDs" in tables in Section A.3 "40/100GbE Application", Section A.4 "OTU3/OTU4 Application", and Section A.5 "No Frame Application" are character strings that can be specified with parameters of commands, :CALCulate:DATA and MMEMory:LOG:ITEM.

A.1 Response Data Format

[Response Data Format] in the following table indicates the ID of the measurement items specified by the :CALCulate:DATA? as well as the format of the response data. The format of the response described here is one of the following.

Table A.1-1 Response Data Format

Format	Explanation
<status>	0 1 2 Returns value corresponding to color of status LED displayed on operation screen 0 Normal (green) 1 Abnormal (red) 2 History (orange)
<NR1>	Displays integer value Example: 123, -500
<NR2>	Displays numeric value in fixed-point decimal Example: 12.345, -500.0
<NR3>	Displays numeric value in floating-point decimal Example: 0.00E-11, 3.05E-11

The [-----] character string is displayed on-screen when the measurement value is disabled for any of the measurement items. In addition, a character string in the format >Max. value, <Min. value is displayed (e.g. >200.0, <-200.0) to indicate an out-of-range value.

When there are multiple measurement items per lane, the data is returned for each lane separated by a comma (,).

Note:

Before capturing the counter value using :CALCulate:DATA, set the type of counter data captured by :CALCulate:DATA:TYPE to either Current or Accumulated.

A.2 Common Items

Table A.2-1 List of Common Items

Measurement Items	Command	Response Data Format
Stream Status Display (LED)	:SOURce:STReam:STATUs?	<status>
Error/Alarm Insertion Status Display (LED)	:SOURce:EALarm:STATUs?	<status>
Counter Status Display (LED)	:CALCulate:COUNter:STATUs?)	<status>
Error/Alarm Status Display (LED)	:CALCulate:EALARM?	<status>
Log Status Display (LED)	:MMEMory:LOG:STATUs?	<status>

A.3 40/100GbE Application

Table A.3-1 Measurement Items and ID List

Tab	Measurement Item	ID	Response Data Format
(Common)	Elapsed Time (s)	ELAPSED	<NR1>
	Transmit Duration (ns)	TX_TIME	<NR2>
Test Frame	Tx Test Frame	TX_TFRAME	<NR1>
	Rx Test Frame	RX_TFRAME	
	Tx Rate (Mbit/s)	TX_TBPS	<NR1>
	Rx Rate (Mbit/s)	RX_TBPS	
	Sequence Error	RX_SEQ_ERR	<NR1>
	Current Latency (μ s) *1	LAT_CURR	<NR2>
	Maximum Latency (μ s) *2	LAT_MAX	<NR2>
	Minimum Latency (μ s) *2	LAT_MIN	<NR2>
	Tx Test Frame (Other)	TX_TFRAME_O	<NR1>
	Rx Test Frame (Other)	RX_TFRAME_O	
	Tx Rate (Mbit/s) (Other)	TX_TBPS_O	<NR1>
	Rx Rate (Mbit/s) (Other)	RX_TBPS_O	
Distribution	Tx Frame Size Distribution	TX_FSIZE	<NR1>
	Rx Frame Size Distribution	RX_FSIZE	
	Tx Gap Size Distribution	TX_GSIZE	<NR1>
	Rx Gap Size Distribution	RX_GSIZE	

*1: Before capturing the value of LAT_CURR,
send :CALCulate:DATA:TYPE CURRENT.

*2: Before capturing the values of LAT_MAX and LAT_MIN,
send :CALCulate:DATA:TYPE ACCUM.

Table A.3-1 Measurement Items and ID List (Cont'd)

Tab	Measurement Item	ID	Response Data Format
All Lanes	Tx Clock Status	CSLOSS	<status>
	Rx Clock Status	CUNLOCK	<status>
	Tx Frequency (Hz)	TX_FREQ	<NR1>
	Rx Frequency (Hz)	RX_FREQ	
	Tx Difference (ppm)	TX_FREQ_D	<NR1>
	Rx Difference (ppm)	RX_FREQ_D	
	Tx LF	TX_LF	<NR1>
	Rx LF	RX_LF	
	Tx RF	TX_RF	<NR1>
	Rx RF	RX_RF	
	Error Signals	RX_ERR_SIG	<NR1>
	Tx Errored Bytes	TEBYTE	<NR1>
	Rx Errored Bytes	REBYTE	
	Tx Good Bytes	TGBYTE	<NR1>
	Rx Good Bytes	RGBYTE	
	Tx FCS Errors	TFCS	<NR1>
	Rx FCS Errors	RFCS	
	Tx Fragments	TFRAGMENT	<NR1>
	Rx Fragments	RFRAGMENT	
	Tx Oversize & FCS Errors	TOAF	<NR1>
	Rx Oversize & FCS Errors	ROAF	
	Tx Undersize	TUNDERSIZE	<NR1>
	Rx Undersize	RUNDERSIZE	
	Tx Oversize	TOVERSIZE	<NR1>
	Rx Oversize	ROVERSIZE	
	Tx Good Frames	TGFRAME	<NR1>
	Rx Good Frames	RGFRAME	
	Tx Rate (bit/s)	TBPS	<NR1>
	Rx Rate (bit/s)	RBPS	

*1: Before capturing the value of LAT_CURR,
send :CALCulate:DATA:TYPE CURRENT.

*2: Before capturing the values of LAT_MAX and LAT_MIN,
send :CALCulate:DATA:TYPE ACCUM.

Table A.3-1 Measurement Items and ID List (Cont'd)

Tab	Measurement Item	ID	Response Data Format
All Lanes (Cont'd)	Tx Rate (%)	TRATE	<NR2>
	Rx Rate (%)	RRATE	
	Pause Frame	RX_PAUSE	<NR1>
	Trigger Condition	RX_TRIGGER	<NR1>
	Tx Broadcast	TBCAST_FRAME	<NR1>
	Rx Broadcast	RBCAST_FRAME	
	Tx Broadcast Bytes	TBCAST_BYTE	<NR1>
	Rx Broadcast Bytes	RBCAST_BYTE	
	Tx Multicast Frame	TMCAST_FRAME	<NR2>
	Rx Multicast Frame	RMCAST_FRAME	
	Tx Multicast Bytes	TMCAST_BYTE	<NR2>
	Rx Multicast Bytes	RMCAST_BYTE	
	Tx MPLS-TP	TMPLSTP	<NR2>
	Rx MPLS-TP	RMPLSTP	
	Tx PBB	TPBB	<NR1>
	Rx PBB	RPBB	
	Tx ARP Request	TARP_REQ	<NR1>
	Rx ARP Request	RARP_REQ	
	Tx ARP Reply	TARP_REP	<NR1>
	Rx ARP Reply	RARP_REP	
	Tx PINGv4 Request	TPINGV4_REQ	<NR1>
	Rx PINGv4 Request	RPINGV4_REQ	
	Tx PINGv4 Reply	TPINGV4_REP	<NR1>
	Rx PINGv4 Reply	RPINGV4_REP	
	Tx NDP (NS)	TNDP_NS	<NR1>
	Rx NDP (NS)	RNDP_NS	
	Tx NDP (NA)	TNDP_NA	<NR1>
	Rx NDP (NA)	RNDP_NA	
	Tx PINGv6 Request	TPINGV6_REQ	<NR1>
	Rx PINGv6 Request	RPINGV6_REQ	
	Tx PINGv6 Reply	TPINGV6_REP	<NR1>
	Rx PINGv6 Reply	RPINGV6_REP	
	Bit Errors (bit)	BER_CNT	<NR1>
	Bit Errors (rate)	BER_RATE	<NR3>
Pattern Sync Loss	PSLOSS	<NR2>	

Table A.3-1 Measurement Items and ID List (Cont'd)

Tab	Measurement Item	ID	Response Data Format
Individual	Alignment Status	ALIGNMENT	<status>
	High-BER	HIBER	<status>
	Invalid Block (Count) (Rate)	IBLOCK	<NR1>
		IBLOCK_RATE	<NR3>
	Sync Header Lock	SHLOCK	<status>
	Alignment Marker Lock	AMLOCK	<status>
	Skew Stability	SSTAB	<status>
	Marker Map	MMAP	<NR1>
	Relative Skew (ns)	RSKEW	<NR2>
	Invalid Sync Header (Count) (Rate)	ISH	<NR1>
		ISH_RATE	<NR3>
	Invalid Alignment Marker (Count) (Rate)	IAM	<NR1>
IAM_RATE		<NR3>	
BIP Error (bit) (Count) (Rate)	BIP_CNT	<NR1>	
	BIP_RATE	<NR3>	
Opt	LOS	LOS	<status>
	Programmable Alarm 1	PALARM1	
	Programmable Alarm 2	PALARM2	<status>
	Programmable Alarm 3	PALARM3	
	Global Alarm	GALARM	<status>
	Optical Power (dBm)	OPOWER	<NR1>

A.4 OTU3/OTU4 Application

When the measurement results for the number of frames and time exist, add `_S` to the parameter to read the measurement results in seconds.

Example: To read the number of frames that generated PM-TIM:
PM_TIM

To read the PM-TIM generation time (in seconds): PM_TIM_S

When the measurement results for the number of errors and generation rate exist, add `_R` to the parameter to read the measurement results for the generation rate.

Example: To read the number of PM-BIP8 generation: PM_BIP8

To read the rate of PM-BIP8 generation: PM_BIP8_R

When the high order (OTU4) and low order (ODU2e and ODU0) have the same measurement items, add `_L` to the parameters to read the measurement results for the low order.

Example: To read the number of PM-BIP8 generation for OTU4:
PM_BIP8

To read the rate of PM-BIP8 generation for ODU2e or ODU0:
PM_BIP8_L

Table A.4-1 Measurement Items and ID List

Tab	Measurement Item	ID	Response Data Format
(Common) Summary	Elapsed Time (second)	ELAPSED	<NR1>
	Clock Source Loss	CSLOSS	<status>
	CDR Unlock	CUNLOCK	<status>
	Rx Frequency (Hz)	RX_FREQ	<NR1>
	Rx Frequency Difference (ppm)	RX_FREQ_D	<NR1>
	LOS	LOS	<status>
Statistics			
LLD	ILA/OLA	ILA	<status>
	Skew Stability	SSTAB	<status>
	Marker Map	MMAP	<NR1>
	Relative Skew (ns)	RSKEW	<NR2>
	LOF Lane (ms)	LOF_LLD	<NR2>
	OOF (frame)	OOF_LLD	<NR1>
	LOR (ms)	LOR	<NR2>
	OOR (frame)	OOR	<NR1>
FAS-LLD	FAS_LLD	<NR1>	
OTU3, OTU4	LOF	LOF	<NR2>
	OOF (second)	OOF_S	<NR2>
	(frame)	OOF	<NR1>
	LOM	LOM	<NR2>
	OOM (second)	OOM_S	<NR2>
	(frame)	OOM	<NR1>
	SM-TIM	SM_TIM	<NR1>
	SM-BIAE (second)	SM_BIAE_S	<NR2>
	(frame)	SM_BIAE	<NR1>
	SM-BDI (second)	SM_BDI_S	<NR2>
	(frame)	SM_BDI	<NR1>
	SM-IAE (second)	SM_IAE_S	<NR2>
	(frame)	SM_IAE	<NR1>
	FAS	FAS	<NR1>

Table A.4-1 Measurement Items and ID List (Cont'd)

Tab	Measurement Item	ID	Response Data Format
Statistics (Cont'd)			
OTU3, OTU4 (Cont'd)	SM-BIP8 (count) (rate)	SMBIP8	<NR1>
		SMBIP8_R	<NR3>
	SM-BEI (count) (rate)	SMBEI	<NR1>
		SMBEI_R	<NR3>
	FEC-Uncorr EBs	FUEB	<NR1>
	FEC-Corr Errors	FCB	<NR1>
	FEC-Corr 1s to 0s	FCB1S	<NR1>
FEC-Corr 0s to 1s	FCB0S	<NR1>	
OTU3, OTU4	MSIM	MSIM	<status>
	ODU-AIS (second) (frame)	AIS_ODU_S	<NR2>
		AIS_ODU	<NR1>
	ODU-OCI (second) (frame)	OCI_S	<NR2>
		OCI	<NR1>
	ODU-LCK (second) (frame)	LCK_S	<NR2>
		LCK	<NR1>
	PM-TIM (frame)	PM_TIM	<NR1>
	PM-BDI (second) (frame)	PM_BDI_S	<NR2>
		PM_BDI	<NR1>
	Client-AIS (second) (frame)	AIS_C_S	<NR2>
		AIS_C	<NR1>
	PLM	PLM	<NR1>
CSF	CSF	<NR1>	
PM-BIP8 (count) (rate)	PM_BIP8	<NR1>	
	PM_BIP8_R	<NR3>	
PM-BEI (count) (rate)	PM_BEI	<NR1>	
	PM_BIP8_R	<NR3>	
TCM	TCMi-TIM	TCM{1 2 3 4 5 6}_TIM_S	<NR2>
	TCMi-BIAE (second) (frame)	TCM{1 2 3 4 5 6}_BIAE_S	<NR2>
		TCM{1 2 3 4 5 6}_BIAE	<NR1>
	TCMi-BDI (second) (frame)	TCM{1 2 3 4 5 6}_BDI_S	<NR2>
		TCM{1 2 3 4 5 6}_BDI	<NR1>
	TCMi-IAE (second) (frame)	TCM{1 2 3 4 5 6}_IAE_S	<NR2>
		TCM{1 2 3 4 5 6}_IAE	<NR1>
TCMi-LTC (second) (frame)	TCM{1 2 3 4 5 6}_LTC_S	<NR2>	
	TCM{1 2 3 4 5 6}_LTC	<NR1>	

Table A.4-1 Measurement Items and ID List (Cont'd)

Tab	Measurement Item	ID	Response Data Format
Statistics (Cont'd)			
TCM(Cont'd)	TCMi-BIP8 (count) (rate)	TCM{1 2 3 4 5 6}_BIP8	<NR1>
		TCM{1 2 3 4 5 6}_BIP8_R	<NR3>
	TCMi-BEI (count) (rate)	TCM{1 2 3 4 5 6}_BEI	<NR1>
		TCM{1 2 3 4 5 6}_BEI_R	<NR3>
ODU2e, ODU0	LOFLOM	LOFLOM	<NR2>
	OOF (second) (frame)	OOF_L_S	<NR2>
		OOF_L	<NR1>
	OOM (second) (frame)	OOM_L_S	<NR2>
		OOM_L	<NR1>
	ODU-AIS (second) (frame)	AIS_ODU_L_S	<NR2>
		AIS_ODU_L	<NR1>
	ODU-OCI (second) (frame)	OCI_L_S	<NR2>
		OCI_L	<NR1>
	ODU-LCK (second) (frame)	LCK_L_S	<NR2>
		LCK_L	<NR1>
	PM-TIM (second) (frame)	PM_TIM_L_S	<NR2>
		PM_TIM_L	<NR1>
	PM-BDI (second) (frame)	PM_BDI_L_S	<NR2>
		PM_BDI_L	<NR1>
	PLM	PLM_L	<NR1>
	CSF	CSF_L	<NR1>
	FAS	FAS_L	<NR1>
PM-BIP8 (count) (rate)	PM_BIP8_L	<NR1>	
	PM_BIP8_L_R	<NR3>	
PM-BEI (count) (rate)	PM_BEI_L	<NR1>	
	PM_BEI_L_R	<NR3>	

Table A.4-1 Measurement Items and ID List (Cont'd)

Tab	Measurement Item	ID	Response Data Format
Statistics (Cont'd)			
GMP	Tx Inc 1	GMP_INC1_TX	<NR1>
	Rx Inc 1	GMP_INC1	
	Tx Inc 2	GMP_INC2_TX	<NR1>
	Rx Inc 2	GMP_INC2	
	Tx Dec 1	GMP_DEC1_TX	<NR1>
	Rx Dec 1	GMP_DEC1	
	Tx Dec 2	GMP_DEC2_TX	<NR1>
	Rx Dec 2	GMP_DEC2	
	Tx Inc >2	GMP_INC3_TX	<NR1>
	Rx Inc >2	GMP_INC3	
	Tx Dec >2	GMP_DEC3_TX	<NR1>
	Rx Dec >2	GMP_DEC3	
	Rx Inc Over	GMP_INC_O	<NR1>
	Rx Dec Over	GMP_DEC_O	
	Offset (ppm)	FREQ_D_P	<NR2>
	CRC8 Error	GMP_CRC8	<NR1>
CRC5 Error	GMP_CRC5	<NR1>	
GMP (ODU2e, ODU0)	Tx Inc 1	GMP_INC1_TX_L	<NR1>
	Rx Inc 1	GMP_INC1_L	
	Tx Inc 2	GMP_INC2_TX_L	<NR1>
	Rx Inc 2	GMP_INC2_L	
	Tx Dec 1	GMP_DEC1_TX_L	<NR1>
	Rx Dec 1	GMP_DEC1_L	
	Tx Dec 2	GMP_DEC2_TX_L	<NR1>
	Rx Dec 2	GMP_DEC2_L	
	Tx Inc >2	GMP_INC3_TX_L	<NR1>
	Rx Inc >2	GMP_INC3_L	
	Tx Dec >2	GMP_DEC3_TX_L	<NR1>
	Rx Dec >2	GMP_DEC3_L	
	Rx Inc Over	GMP_INC_O_L	<NR1>
	Rx Dec Over	GMP_DEC_O_L	
	Offset (ppm)	FREQ_D_P_L	<NR2>
	CRC8 Error	GMP_CRC8_L	<NR1>

Table A.4-1 Measurement Items and ID List (Cont'd)

Tab	Measurement Item	ID	Response Data Format
Statistics (Cont'd)			
GFP-T	Invalid GFP-T Frame	GFP_INV_FRM	<status>
	CSF Signal (second)	GFP_CSF_SIG_S	<NR2>
	(frame)	GFP_CSF_SIG	<NR1>
	CSF Sync (second)	GFP_CSF_SYNC_S	<NR2>
	(frame)	GFP_CSF_SYNC	<NR1>
	SSF (second)	GFP_SSF	<NR2>
	Superblock CRC	GFP_SCRC	<NR1>
	Correctable cHEC	GFP_CHEC_C	<NR1>
	Uncorrectable cHEC	GFP_CHEC_U	<NR1>
	Correctable tHEC	GFP_THEC_C	<NR1>
Uncorrectable tHEC	GFP_THEC_U	<NR1>	
PCS Lane	Marker Lock	AMLOCK	<status>
	Marker Map	MMAP	<NR1>
	BIP Error	BIP_CNT	<NR1>
	Invalid Alignment Marker	IAM	<NR1>
Ethernet	Alignment Status	ALIGNMENT	<status>
	High-BER	HIBER	<status>
	Sync Header Lock	SHLOCK	<status>
	Invalid Sync Header	ISH	<NR1>
	Invalid Alignment Marker	IAM	<NR1>
	Invalid Block	IBLOCK	<NR1>
	66B Error	ERR_66B	<NR1>
	10B Error	ERR_10B	<NR1>
	Tx LF	TX_LF	<NR1>
	Rx LF	RX_LF	
	Tx RF	TX_RF	<NR1>
	Rx RF	RX_RF	
	Error Signals	RX_ERR_SIG	<NR1>
	Tx Errored Bytes	TEBYTE	<NR1>
	Rx Errored Bytes	REBYTE	
	Tx Good Bytes	TGBYTE	<NR1>
Rx Good Bytes	RGBYTE		

Table A.4-1 Measurement Items and ID List (Cont'd)

Tab	Measurement Item	ID	Response Data Format
Statistics (Cont'd)			
Ethernet (Cont'd)	Tx FCS Errors	TFCS	<NR1>
	Rx FCS Errors	RFCS	
	Tx Fragments	TFRAGMENT	<NR1>
	Rx Fragments	RFRAGMENT	
	Tx Oversize & FCS Errors	TOAF	<NR1>
	Rx Oversize & FCS Errors	ROAF	
	Tx Undersize	TUNDERSIZE	<NR1>
	Rx Undersize	RUNDERSIZE	
	Tx Oversize	TOVERSIZE	<NR1>
	Rx Oversize	ROVERSIZE	
	Tx Good Frames	TGFRAME	<NR1>
	Rx Good Frames	RGFRAME	
	Tx Rate (bit/s)	TBPS	<NR1>
	Rx Rate (bit/s)	RBPS	
	Tx Rate (%)	TRATE	<NR2>
Rx Rate (%)	RRATE		
Test Pattern	Pattern Sync Loss (second)	PSLOSS	<NR2>
	Bit Errors (bit)	BER_CNT	<NR1>
	Bit Errors (rate)	BER_RATE	<NR3>
Delay* ¹	PM Current (μs)	PM_DELAY	<NR2>
	TCMi Current (μs)	TCM{1 2 3 4 5 6}_DELAY	<NR2>
APS* ²	Current (ms)	APS_TIME	<NR2>

*1: The values of Max, Min, Average, History, Tx Delay Frame, and Rx Delay Frame cannot be read with the remote control.

*2: The values of Max, Min, Average, and History cannot be read with the remote control.

* For the IDs of Opt tab, refer to Section A.3 "40/100GbE Application".

A.5 No Frame Application

Table A.5-1 Measurement Items and ID List

Tab	Measurement Item	ID	Response Data Format
Statistics	Elapsed Time (s)	ELAPSED	<NR1>
	Clock Source Loss	CSLOSS	<status>
	Pattern Sync Loss (s)	PSLOSS	<NR2>
	Bit Errors (Count)	BER_CNT	<NR1>
	Bit Errors (rate)	BER_RATE	<NR3>
	Frequency (Hz)	RX_FREQ	<NR1>
	Frequency (ppm)	RX_FREQ_D	<NR1>
	CDR Unlock	CUNLOCK	<status>
	Clock Count (bit) *	CLK_CNT	<NR1>

* Not displayed on the MD1260A screen
 Clock Count (bit) is the number of received bits to be used for Bit Error Rate calculation.

$$BER = \frac{ErrorBitCount}{ReceivedBitCount}$$

For the IDs of Opt tab, refer to Section A.3 "40/100GbE Application".

Appendix B Message Codes

This appendix explains the code and message responses to the :SYSTem:ERRor? query command.

- Command error
- Execution error
- Device unique error

When these errors occur, the standard event status register bit becomes 1. A service request can be generated when an error occurs depending on the setting of the standard event status enable register bit.

When an error occurs, the standard event status register bit that becomes 1 is listed in the table below.

Table B-1 Relationship between Error Number and Standard Event Register

Error Code	Message	Error Name	Standard Event Register Bit
-113	Undefined header	Command error	5
-220	Parameter error	Execution error	4
-310	System error	Device dependant error	3

Appendix

Appendix B

Command error

Bit 5 of the standard event status register is set when the following errors occur. The errors are generated when the following events occur.

- When sending message not in conformance with syntax described in Section 2.5 Message Format
Example: At typographical error in header
Header includes 2-byte character
- When sending message not in conformance with Common Commands or Device Unique Commands described in Section 3.3 Explanation of Messages
- When sending the command not corresponding to the application
- When ? is not appended to a query.

Execution error

Bit 4 of the standard event status register is set when the following errors occur. The errors are generated when the following events occur.

- When header continuation parameter value out of setting range
Example: When 200 is set even though the setting range of the transmission clock frequency offset is -20 to +120
- When message cannot be executed in current equipment status
Example: When sending message for setting the MDIO register of CFP to instrument without CFP function
- When a parameter not specified by the application is set.

Device dependant error

Bit 3 of the standard event status register is set when the following errors occur.

- When a non-existent file or a file not loaded by :MMEMory:RECall is set
- When an extension is included in the parameter file name at :MMEMory:RECall

Appendix C Change Information on Command

This appendix explains the command changed along with upgrading the software.

C.1 Change Information of Ver.2.0

C.1.1 No used command

Not used and alternative commands are listed in the following table.

Table C.1.1-1 Not Used and Alternative Command

No used command	Alternative command
:CALCulate:COUNter:ETHer:BERRors	:ROUTe:BERT
:SOURce:STReam:DURation:FRAMES	:SOURce:STReam:DURation:REPeat:COUNT
:SOURce:STReam:HEADer:ETHer:SA	:SOURce:STReam:HEADer:PATTern
:SOURce:STReam:HEADer:ETHer:DA	:SOURce:STReam:HEADer:PATTern
:SOURce:STReam:HEADer:ETHer:TYPE	:SOURce:STReam:HEADer:PATTern

:CALCulate:COUNter:ETHer:BERRors

When setting/querying the execution of the counter of the Bit Errors Count in the 40GbE/100GbE application, use :ROUTe:BERT.

:SOURce:STReam:DURation:FRAMES

When setting/querying the execution of the number of transmission frames in the 40GbE/100GbE application, use :
SOURce:STReam:DURation:REPeat:COUNT.

:SOURce:STReam:HEADer:ETHer:DA

:SOURce:STReam:HEADer:ETHer:SA

:SOURce:STReam:HEADer:ETHer:TYPE

When setting/ querying the Header MAC address, MAC address transmission source, and the Type field value of the Ethernet frame to be sent, use : SOURce:STReam:HEADer:PATTern.

C.1.2 Parameter Changed Command

The following command parameters were changed.

:CALCulate:DATA

The parameter is added and deleted to set it to < item >.

Added parameter:

TX_LF,RX_LF,TX_RF,RX_RF,RX_ERR_SIG,TX_TIME,RX_PAUSE,RX_TRIGGER,TX_FSIZE,RX_FSIZE,TX_GSIZE,RX_GSIZE,TX_FRAME,RX_TFRAME,RX_SEQ_ERR,LAT_CURR,LAT_MAX,LAT_MIN, TX_FREQ, TX_FREQ_D

Deleted parameter:

TXRX

 Appendix A measurement item list

:SOURce:STReam:CONTRol:VALue

Parameter format: changes from < NR1> to < NR2>.

:SOURce:STReam:DURation:TYPE

Before changing : SOURce:STReam:DURation:TYPE FRAME

After changing : SOURce:STReam:DURation:TYPE REPEAT

:SOURce:EALarm:LANE

When sending : SOURce:EALarm:LANE? at the measurement of 10 lanes, the response data is changed from 20 to 10 digits.

Before changing 20 digits, Example : #B100000000000000000000

After changing 10 digits, Example: #B100000000

C.1.3 Added Command

The following commands were added.

Capture command

:CALCulate:CAPTure:DATA:RXC
:CALCulate:CAPTure:DATA:RXD
:CALCulate:CAPTure:DATA:SIZE
:CALCulate:CAPTure:DATA:TRIGger:POSition
:CALCulate:CAPTure:STARt
:CALCulate:CAPTure:STARt:EVENT
:CALCulate:CAPTure:STATus
:CALCulate:CAPTure:STOP
:CALCulate:CAPTure:TRIGgered
:CALCulate:TRIGger:CONDition
:MMEMory:STORe:CAPTure
:MMEMory:STORe:CAPTure:ITEM

Lane Mapping command

:SOURce:MAPPing:LANE

Port command

:ROUte:FCONtrol
:ROUte:LFS:REPLy

Relative Skew command

:SOURce:SKEW:TYPE

Stream command

:SOURce:STReam:BURSt:CONTRol:VALue
:SOURce:STReam:BURSt:ENABle
:SOURce:STReam:BURSt:SIZE
:SOURce:STReam:COUNT
:SOURce:STReam:DURation:REPeat:COUNT
:SOURce:STReam:ENABle
:SOURce:STReam:ERRor:TYPE
:SOURce:STReam:FSIZe
:SOURce:STReam:HEADer:PATTern
:SOURce:STReam:HEADer:VARiable1:RANGe
:SOURce:STReam:HEADer:VARiable1:TYPE
:SOURce:STReam:HEADer:VARiable2:RANGe
:SOURce:STReam:HEADer:VARiable2:TYPE

Appendix C Change Information on Command

:SOURce:STReam:ID
:SOURce:STReam:TFRame:ENABle
:SOURce:STReam:TFRame:FID
:SOURce:STReam:TYPE

Test Frame command

:CALCulate:COUNter:GAP
:CALCulate:COUNter:SERRor

Summary status command

:CALCulate:LINK[:AUNit]

Multiport function command

:CALCulate:COUNter:START:AUNit
:CALCulate:COUNter:START:EVENT:AUNit
:CALCulate:COUNter:STATus:AUNit
:CALCulate:COUNter:STOP:AUNit
:CALCulate:EALarm:AUNit
:CALCulate:LINK:AUNit
:MMEMory:INITialize
:MMEMory:RECall:AUNit
:MMEMory:STORe:AUNit
:SOURce:EALarm:START:AUNit
:SOURce:EALarm:START:EVENT:AUNit
:SOURce:EALarm:STATus:AUNit
:SOURce:EALarm:STOP:AUNit
:SOURce:STReam:START:AUNit
:SOURce:STReam:START:EVENT:AUNit
:SOURce:STReam:STATus:AUNit
:SOURce:STReam:STOP:AUNit
:UENTry:ID
:UENTry:LIST

C.2 Change Information of Ver. 3.0

C.2.1 No used command

The following command has been discarded.

:CALCulate:LINK[:AUNit]

To query the status area Link lamp status,
use :CALCulate:DATA? LINK command.

C.2.2 Changed Command

The following command has been changed.

Table C.2.2-1 Changed Command

Before change	After change
:CALCulate:CAPTure:TRIGgered	:CALCulate:CAPTure:TRIGger

C.2.3 Parameter Changed Command

The following command parameters have been changed.

Refer to Table 3.1-1 "Command Description Method" for the parameter description method.

:CALCulate:MONitor:OTU:DATA

Parameters to specify the column position and data length have been added.

:CALCulate:DATA

The parameters to set to <item> have been added and deleted.

Refer to Appendix A "Measurement Item List."

Replaced parameters:

MLOFOTL_SEC → LOF_LLD

MOOF_FRM → OOF_LLD

MFAS_CNT → FAS_LLD

MOOR_FRM → OOR

OLOF_SEC → LOF

OOOF_FRM → OOF

OOOF_SEC → OOF_S

OFAS_CNT → FAS

OLOM_SEC → LOM

OOOM_FRM → OOM

OOOM_SEC → OOM_S

SMBIP8_CNT → SM_BIP8

Appendix C Change Information on Command

SMBIP8_RATE → SM_BIP8_R

PMBIP8_CNT → PM_BIP8

PMBIP8_RATE → PM_BIP8_R

It is possible to be controlled by the parameter before changed for keeping compatibility, but do not use this parameter.

Added parameters:

AIS_C[_S],AIS_ODU[_L][_S],CSF,ERR_10B,
ERR_66B,FAS_L,FREQ_D_P[_L],GFP_CHEC_C,
GFP_CHEC_U,GFP_CSF,GFP_CSF_SIG,GFP_CSF_SYNC,
GFP_INV_FRM,GFP_SCRC,GFP_SSF,GFP_THEC_C,
GFP_THEC_U, GMP_CRC5,GMP_CRC8[_L],GMP_DEC_O[_L],
GMP_DEC{1|2|3}[_L],GMP_DEC{1|2|3}_TX[_L],
GMP_INC_O[_L],GMP_INC{1|2|3}[_L],GMP_INC{1|2|3}_TX[_L],
LCK[_L][_S],LOFLOM,MSIM,OCI[_L][_S],OOF_L,OOM_L,
PLM[_L],PM_BDI[_L][_S],PM_BEI[_L][_R],PM_BIP8_L,
PM_TIM[_L][_S],SM_BDI[_S],SM_BEI[_R],SM_BIAE[_S],
SM_IAE[_S],SM_TIM,TCM{1|2|3|4|5|6}_BDI[_S],
TCM{1|2|3|4|5|6}_BEI[_R],TCM{1|2|3|4|5|6}_BIAE[_S],
TCM{1|2|3|4|5|6}_BIP8[_R],TCM{1|2|3|4|5|6}_IAE[_S],
TCM{1|2|3|4|5|6}_LTC[_S],TCM{1|2|3|4|5|6}_TIM

:MMEMory:CATalog

Replaced parameters:

100GE → E100G

100GE_N → E100G_N

40GE → E40G

40GE_N → E40G_N

Added parameters: OTU4_E,OTU4_ODU0,
OTU4_ODU0_E,OTU4_ODU2E,OTU4_ODU2E_E

Deleted parameters: ALL

:ROUTE:MODE

Added parameters: THROUGH

:SOURCE:MAPPING

Replaced parameters:

100GE → E100G

100GE_10N → E100G_10N

100GE_20N → E100G_20N

40GE → E40G

40GE_N,ALL → E40G_N

Added parameters:

NONE,OTU4_E,OTU4_ODU0,

OTU4_ODU0_E,OTU4_ODU2E,OTU4_ODU2E_E

:SOURce:EALarm:TIMing:RATE

The response format has been changed to <NR3>.

:SOURce:EALarm:TIMing:TYPE

Replaced parameters: CRATE,RRATE → RATE

:SOURce:EALarm:TYPE

Replaced parameters:

FAS_MLD → FAS_LLD

FAS_OTU → FAS

LOFOTL → OOF_LLD

LOF_OTU → OOF

LOM → OOM

OOR → LOR

Added parameters:

AIS_C,AIS_ODU[_L],BIT_ALL_C,

BIT_ALL_U,CSF,ERR_10B,ERR_66B,GFP_CHEC,GFP_SCRC,

GFP_THEC,GMP_CRC5,GMP_CRC8,GMP_JC1,GMP_JC12,

GMP_JC2,LCK[_L],OCI[_L],PM_BDI[_L],PM_BEI[_L],

PM_BIP8_L,PM_TIM[_L],SM_BDI,SM_BEI,SM_BIAE,SM_IAE,

SM_TIM,TCM{1|2|3|4|5|6}_BDI,TCM{1|2|3|4|5|6}_BDI,

TCM{1|2|3|4|5|6}_BIAE,TCM{1|2|3|4|5|6}_BIP8,

TCM{1|2|3|4|5|6}_IAE,TCM{1|2|3|4|5|6}_LTC,

TCM{1|2|3|4|5|6}_TIM

C.2.4 Added Commands

The following commands are added.

Command related to APS

:CALCulate:APS:ERRor:FREE
:CALCulate:APS:STARt[:AUNit]
:CALCulate:APS:STARt:EVENT[:AUNit]
:CALCulate:APS:STATus[:AUNit]
:CALCulate:APS:STOP[:AUNit]
:CALCulate:APS:TRIGger

Command related to Capture

:CALCulate:CAPTure:DATA
:CALCulate:CAPTure:TRIGger:Manual
:CALCulate:CAPTure:TRIGger:POSition
:CALCulate:CAPTure:TRIGger:TYPE
:CALCulate:CAPTure:TYPE

Command related to Clock

:SOURce:CLOCK:PAYload:OFFSet[:L]

Command related to Counter

:SENSe:PLM[:L]:Pattern
:SENSe:TIM:{SM|PM[:L]}TCM{1|2|3|4|5|6}
:SENSe:TIM:{SM|PM[:L]}TCM{1|2|3|4|5|6}:PATTern:{DAPI|SAPI}

Command related to Data Monitor

:CALCulate:MONitor:OTU:TYPE

Command related to Delay

:CALCulate:DELay:STARt[:AUNit]
:CALCulate:DELay:STARt:EVENT[:AUNit]
:CALCulate:DELay:STATus[:AUNit]
:CALCulate:DELay:STOP[:AUNit]

Command related to Error/Alarm

:SOURce:EALarm:BIT
:SOURce:EALarm:FAS:EXCLude
:SOURce:EALarm:SUBRow

Command related to GFP-T

:SOURce:GFP:CSF:REPLacement
:SOURce:GFP:{PTI|UPI}

Command related to OH Preset
:SOURCE:OTN:OH[L]

Command related to Port
:ROUTE:ETHER:NEGtiation:AUTO
:ROUTE:MODE:THROUGH:OVERwite:RANGe
:ROUTE:MODE:THROUGH:TYPE
:SOURCE:OTN:FEC

Command related to Selector
:SYSTEM:CONFig
:SYSTEM:STATus

Command related to Stream
:SOURCE:STReam:DURation:FRAMES
:SOURCE:STReam:HEADer:ETHER:DA
:SOURCE:STReam:HEADer:ETHER:SA
:SOURCE:STReam:HEADer:ETHER:TYPE

Command related to TP/TS
:SENSe:ODTU:MAIN:DETECT
:SENSe:ODTU:MAIN:TS
:SOURCE:ODTU:DUMMy:PATtern
:SOURCE:ODTU:MAIN:TP
:SOURCE:ODTU:MAIN:TS

C.3 Change Information of Ver.3.1

C.3.1 Added Commands

The following commands are added.

Command related to Opt

:SOURce:CFP:OPTical:OFF

:SOURce:CFP:OPTical:ON

:SOURce:CFP:OPTical:STATus

Command related to Port

:ROUte:MPLStp:CWORD

Command related to Stream

:MMEMory:STReam:RECall

:SOURce:STReam:HEADer

:SOURce:STReam:HEADer:VARiable{3|4|5}

Command related to Test Frames

:CALCulate:COUNter:FLOW:FIELD

:CALCulate:COUNter:FLOW:FIELD:ID

:CALCulate:COUNter:FLOW:FIELD:Nfid

:CALCulate:COUNter:FLOW:TYPE

C.3.2 Changed Command

The following commands have been changed.

:SOURce:STReam:HEADer:VARiable1:TYPE

Before change	After change
Sets the Ethernet Destination MAC Address	Sets the Modifiers Field1 Destination MAC Address

:SOURce:STReam:HEADer:VARiable2:TYPE

Before change	After change
Sets the Ethernet Source MAC Address	Sets the Modifiers Field2 Destination MAC Address

C.3.3 Parameter Changed Command

The following command parameters have been changed.

Refer to Table 3.1-1 "Command Description Method" for the parameter description method.

:CALCulate:DATA

The parameters to set to <item> have been added.

Refer to Appendix A "Measurement Item List".

Added parameters:

CLK_CNT,RBCAST_BYTE,RBCAST_FRAME,
RMCAST_BYTE,RMCAST_FRAME,RMPLSTP,RX_TBPS,
RX_TBPS_O,RX_TFRAME_O,TBCAST_BYTE,TBCAST_FRAME,
TMCAST_BYTE,TMCAST_FRAME,TMPLSTP,TX_TBPS,
TX_TBPS_O,TX_TFRAME_O

:SOURce:STReam:HEADer:VARiable1:TYPE

:SOURce:STReam:HEADer:VARiable2:TYPE

Added parameters:

DECREMENT

C.4 Change Information of Ver.3.2

C.4.1 Added Commands

The following commands are added.

Command related to Port

:ROUte:VLAN:NUM

:ROUte:VLAN:VALue

:SENSe:OTN:FEC

Command related to Stream

:SOURce:STReam:RESolve:IP:TARGet

:SOURce:STReam:RESolve:IPV4:ROUter

:SOURce:STReam:RESolve:IPV6:ROUter

:SOURce:STReam:RESolve:MAC:RETRy

:SOURce:STReam:RESolve:MAC:TIMeout

:SOURce:STReam:RESolve:PING:TRY

:SOURce:STReam:RESolve:PING:PAYLoad

:SOURce:STReam:RESolve:PING:TIMeout

:SOURce:STReam:RESolve:RESult

:SOURce:STReam:RESolve:STARt

:SOURce:STReam:RESolve:STARt:EVENT

:SOURce:STReam:RESolve:STATus

:SOURce:STReam:RESolve:STOP

:SOURce:STReam:RESolve:TYPE

Command related to Protocol

:PROTocol:ARPNa:REPLy:ENABle

:PROTocol:GARPns:DURation:TYPE

:PROTocol:GARPns:ENABle

:PROTocol:GARPns:INTerval

:PROTocol:GARPns:STARt

:PROTocol:GARPns:STATus

:PROTocol:GARPns:STOP

:PROTocol:GARPns:TYPE

:PROTocol:PING:COUNT

:PROTocol:PING:DST:IPV4

:PROTocol:PING:DST:IPV6

:PROTocol:PING:DST:MAC

:PROTocol:PING:IPMode

:PROTocol:PING:MACResolve

:PROTocol:PING:PAYLoad

:PROTocol:PING:PSIZe:VALUe

:PROTocol:PING:REPLy:ENABle

:PROToCol:PING:RESult
 :PROToCol:PING:SRC:IPV4
 :PROToCol:PING:SRC:IPV6
 :PROToCol:PING:STARt
 :PROToCol:PING:STARt:ENABle
 :PROToCol:PING:STATus
 :PROToCol:PING:STOP
 :PROToCol:PING:TIMEout
 :PROToCol:PING:VLAN

C.4.2 Parameter Changed Command

The following command parameters have been changed.

Refer to Table 3.1-1 "Command Description Method" for the parameter description method.

:CALCulate:COUNter:FLOW:FIELD

The parameters to set to <field> have been added.

Added parameters:

ARP_SMAC, ARP_SIP, ARP_TMAC, ARP_TIP, ARP_OPE,
 ICMPV4_CODE, ICMPV4_EC_ID ICMPV4_EC_SEQ,
 ICMPV6_CODE, ICMPV6_EC_ID ICMPV6_EC_SEQ,
 ICMPV6_NSNA_TADDR ICMPV6_NSNA_SADDR

:CALCulate:DATA

The parameters to set to <item> have been added.

Refer to Appendix A "Measurement Item List".

:SOURce:STReam:HEADer

The parameters to set to <field> have been added.

Added parameters:

ARP,ICMPV4_ECHO,ICMPV6_ECHO,ICMPV6_NS,ICMPV6_NA

:SOURce:STReam:HEADer:VARiable{3|4|5}

The parameters to set to <field> have been added.

Added parameters:

ARP_SMAC, ARP_SIP, ARP_TMAC, ARP_TIP, ARP_OPE,
 ICMPV4_CODE, ICMPV4_EC_ID ICMPV4_EC_SEQ,
 ICMPV6_CODE, ICMPV6_EC_ID ICMPV6_EC_SEQ,
 ICMPV6_NSNA_TADDR ICMPV6_NSNA_SADDR

Appendix D Correspondence between Application and Command

The following table shows the correspondence between application and command.

- ✓: Supported
- : Not supported

Table D-1 Correspondence between Application and Command

Application Command	100GbE	40GbE	ODU4-PRBS	ODU4-100GbE	ODU4-ODTU4.8-ODU2e-PRBS	ODU4-ODTU4.8-ODU2e-10GbE	ODU4-ODTU4.1-ODU0-PRBS	ODU4-ODTU4.1-ODU0-GbE	ODU3- PRBS	100GbE No Frame	40GbE No Frame	OTU4 No Frame	OTU3 No Frame
:CALCulate:APS:ERRor:FREE	–	–	✓	✓	✓	✓	✓	✓	✓	–	–	–	–
:CALCulate:APS:STARt[:AUNit]	–	–	✓	✓	✓	✓	✓	✓	✓	–	–	–	–
:CALCulate:APS:STARt:EVENT[:AUNit]	–	–	✓	✓	✓	✓	✓	✓	✓	–	–	–	–
:CALCulate:APS:STATus[:AUNit]	–	–	✓	✓	✓	✓	✓	✓	✓	–	–	–	–
:CALCulate:APS:STOP[:AUNit]	–	–	✓	✓	✓	✓	✓	✓	✓	–	–	–	–
:CALCulate:APS:TRIGger	–	–	✓	✓	✓	✓	✓	✓	✓	–	–	–	–
:CALCulate:CAPTure:DATA	–	–	✓	✓	✓	✓	✓	✓	✓	–	–	–	–
:CALCulate:CAPTure:DATA:RXC	✓	✓	–	–	–	–	–	–	–	–	–	–	–
:CALCulate:CAPTure:DATA:RXD	✓	✓	–	–	–	–	–	–	–	–	–	–	–
:CALCulate:CAPTure:DATA:SIZE	✓	✓	✓	✓	✓	✓	✓	✓	✓	–	–	–	–
:CALCulate:CAPTure:DATA:TRIGger:PO Sition	✓	✓	✓	✓	✓	✓	✓	✓	✓	–	–	–	–
:CALCulate:CAPTure:STARt	✓	✓	✓	✓	✓	✓	✓	✓	✓	–	–	–	–
:CALCulate:CAPTure:STARt:EVENT	✓	✓	✓	✓	✓	✓	✓	✓	✓	–	–	–	–
:CALCulate:CAPTure:STATus	✓	✓	✓	✓	✓	✓	✓	✓	✓	–	–	–	–
:CALCulate:CAPTure:STOP	✓	✓	✓	✓	✓	✓	✓	✓	✓	–	–	–	–
:CALCulate:CAPTure:TRIGger:MANual	–	–	✓	✓	✓	✓	✓	✓	✓	–	–	–	–
:CALCulate:CAPTure:TRIGger:POSition	–	–	✓	✓	✓	✓	✓	✓	✓	–	–	–	–
:CALCulate:CAPTure:TRIGger:TYPE	–	–	✓	✓	✓	✓	✓	✓	✓	–	–	–	–
:CALCulate:CAPTure:TRIGger	✓	✓	✓	✓	✓	✓	✓	✓	✓	–	–	–	–
:CALCulate:CAPTure:TYPE	–	–	✓	✓	✓	✓	✓	✓	✓	–	–	–	–
:CALCulate:COUNter:ETHer:OVERsize	✓	✓	–	✓	–	✓	–	✓	–	–	–	–	–
:CALCulate:COUNter:FLOW:FIELD	✓	✓	–	–	–	–	–	–	–	–	–	–	–
:CALCulate:COUNter:FLOW:FIELD:ID	✓	✓	–	–	–	–	–	–	–	–	–	–	–

Table D-1 Correspondence between Application and Command (Cont'd)

Application Command	100GbE	40GbE	ODU4-PRBS	ODU4-100GbE	ODU4-ODTU4.8-ODU2e-PRBS	ODU4-ODTU4.8-ODU2e-10GbE	ODU4-ODTU4.1-ODU0-PRBS	ODU4-ODTU4.1-ODU0-GbE	ODU3- PRBS	100GbE No Frame	40GbE No Frame	OTU4 No Frame	OTU3 No Frame
:CALCulate:COUNter:FLOW:FIELd:NFIID	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:CALCulate:COUNter:FLOW:TYPE	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:CALCulate:COUNter:GAP	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:CALCulate:COUNter:SERRor	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:CALCulate:COUNter:STARt[:AUNit]	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:CALCulate:COUNter:STARt:EVENT[:AU Nit]	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:CALCulate:COUNter:STATus[:AUNit]	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:CALCulate:COUNter:STOP[:AUNit]	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:CALCulate:DATA	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:CALCulate:DATA:TYPE	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:CALCulate:DELAy:STARt[:AUNit]	-	-	✓	✓	✓	✓	✓	✓	✓	-	-	-	-
:CALCulate:DELAy:STARt:EVENT[:AUNit]	-	-	✓	✓	✓	✓	✓	✓	✓	-	-	-	-
:CALCulate:DELAy:STATus[:AUNit]	-	-	✓	✓	✓	✓	✓	✓	✓	-	-	-	-
:CALCulate:DELAy:STOP[:AUNit]	-	-	✓	✓	✓	✓	✓	✓	✓	-	-	-	-
:CALCulate:EALarm[:AUNit]	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:CALCulate:MONitor:OTU:COLumn	-	-	✓	✓	✓	✓	✓	✓	✓	-	-	-	-
:CALCulate:MONitor:OTU:DATA	-	-	✓	✓	✓	✓	✓	✓	✓	-	-	-	-
:CALCulate:MONitor:OTU:TYPE	-	-	✓	✓	✓	✓	✓	✓	✓	-	-	-	-
:CALCulate:TRIGger:CONDition	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:MDIO:READ	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:MDIO:WRITE	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:MMEMory:CATalog	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:MMEMory:INITialize	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:MMEMory:LOG:FNAME	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:MMEMory:LOG:ITEM	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:MMEMory:LOG:PREFix	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:MMEMory:LOG:STARt	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:MMEMory:LOG:STATus	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:MMEMory:LOG:STOP	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓

Table D-1 Correspondence between Application and Command (Cont'd)

Application Command	100GbE	40GbE	ODU4-PRBS	ODU4-100GbE	ODU4-ODTU4.8-ODU2e-PRBS	ODU4-ODTU4.8-ODU2e-10GbE	ODU4-ODTU4.1-ODU0-PRBS	ODU4-ODTU4.1-ODU0-GbE	ODU3- PRBS	100GbE No Frame	40GbE No Frame	OTU4 No Frame	OTU3 No Frame
:MMEMory:LOG:TIMing	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:MMEMory:RECall[:AUNit]	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:MMEMory:STORe[:AUNit]	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:MMEMory:STORe:CAPTure	✓	✓	✓	✓	✓	✓	✓	✓	✓	-	-	-	-
:MMEMory:STORe:CAPTure:ITEM	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:MMEMory:STReam:RECall	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:PROToCol:ARPNa:REPLy:ENABle	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:PROToCol:GARPns:DURation:TYPE	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:PROToCol:GARPns:ENABle	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:PROToCol:GARPns:INTerval	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:PROToCol:GARPns:STARt	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:PROToCol:GARPns:STATe	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:PROToCol:GARPns:STOP	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:PROToCol:GARPns:TYPE	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:PROToCol:PING:COUNT	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:PROToCol:PING:DEST:IPV4	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:PROToCol:PING:DEST:IPV6	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:PROToCol:PING:DEST:MAC	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:PROToCol:PING:IPMode	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:PROToCol:PING:PAYLoad	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:PROToCol:PING:PSIZe:VALUe	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:PROToCol:PING:REPLy:ENABle	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:PROToCol:PING:RESult	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:PROToCol:PING:SRC:IPV4	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:PROToCol:PING:SRC:IPV6	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:PROToCol:PING:SRC:MAC	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:PROToCol:PING:STARt	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:PROToCol:PING:STARt:ENABle	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:PROToCol:PING:STATus	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:PROToCol:PING:STOP	✓	✓	-	-	-	-	-	-	-	-	-	-	-

Table D-1 Correspondence between Application and Command (Cont'd)

Application Command	100GbE	40GbE	ODU4-PRBS	ODU4-100GbE	ODU4-ODTU4.8-ODU2e-PRBS	ODU4-ODTU4.8-ODU2e-10GbE	ODU4-ODTU4.1-ODU0-PRBS	ODU4-ODTU4.1-ODU0-GbE	ODU3- PRBS	100GbE No Frame	40GbE No Frame	OTU4 No Frame	OTU3 No Frame
:PROTOcol:PING:TIMEout	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:PROTOcol:PING:VLAN	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:ROUTE:BERT	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:ROUTE:ETHER:NEGotiation:AUTO	-	-	-	-	-	-	-	✓	-	-	-	-	-
:ROUTE:FCONtrol	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:ROUTE:LFS:REPLY	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:ROUTE:MODE	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:ROUTE:MODE:THROUGH:OVERwrite:RANGe	-	-	✓	✓	✓	✓	✓	✓	✓	-	-	-	-
:ROUTE:MODE:THROUGH:TYPE	-	-	✓	✓	✓	✓	✓	✓	✓	-	-	-	-
:ROUTE:MPLStp:CWORD	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:ROUTE:VLAN:NUM	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:ROUTE:VLAN:VALue	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:SENSe:MAPPing	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:SENSe:ODTU:MAIN:DETECT	-	-	-	-	✓	✓	✓	✓	-	-	-	-	-
:SENSe:ODTU:MAIN:TS	-	-	-	-	✓	✓	✓	✓	-	-	-	-	-
:SENSe:OTN:FEC	-	-	✓	-	✓	✓	✓	✓	✓	-	-	-	-
:SENSe:PLM[:L]:PATTERN	-	-	-	✓	✓	✓	✓	✓	✓	-	-	-	-
:SENSe:TIM:{SM PM[:L] TCM{1 2 3 4 5 6}}	-	-	-	✓	✓	✓	✓	✓	✓	-	-	-	-
:SENSe:TIM:{SM PM[:L] TCM{1 2 3 4 5 6}}:PATTERN:{DAPI SAPI}	-	-	-	✓	✓	✓	✓	✓	✓	-	-	-	-
:SENSe:TPATTERN:INVERT	-	-	✓	-	✓	-	✓	-	✓	✓	✓	✓	✓
:SENSe:TPATTERN:TYPE	-	-	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:SENSe:TPATTERN:WORD	-	-	✓	✓	✓	✓	✓	✓	✓	-	-	-	-
:SENSe:TRANsceiver:EQUalizer:CONtrol	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:SENSe:TRANsceiver:EQUalizer:DCCain	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓

Table D-1 Correspondence between Application and Command (Cont'd)

Application Command	100GbE	40GbE	ODU4-PRBS	ODU4-100GbE	ODU4-ODTU4.8-ODU2e-PRBS	ODU4-ODTU4.8-ODU2e-10GbE	ODU4-ODTU4.1-ODU0-PRBS	ODU4-ODTU4.1-ODU0-GbE	ODU3- PRBS	100GbE No Frame	40GbE No Frame	OTU4 No Frame	OTU3 No Frame
:SOURCE:CFP:OPTical:OFF	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:SOURCE:CFP:OPTical:ON	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:SOURCE:CFP:OPTical:STATUS	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:SOURCE:CLOCK	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:SOURCE:CLOCK:FREQUENCY:OFFSet	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:SOURCE:CLOCK:OUTPut:DIVide	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:SOURCE:CLOCK:OUTPut:M10	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:SOURCE:CLOCK:PAYLoad:OFFSet[:L]	-	-	-	✓	✓	✓	✓	✓	-	-	-	-	-
:SOURCE:EALarm:BIT	-	-	-	✓	✓	✓	✓	✓	-	-	-	-	-
:SOURCE:EALarm:FAS:EXCLude	-	-	✓	-	-	-	-	-	✓	-	-	-	-
:SOURCE:EALarm:LANE	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:SOURCE:EALarm:START[:AUNit]	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:SOURCE:EALarm:START:EVENT[:AUNit]	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:SOURCE:EALarm:STATUS[:AUNit]	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:SOURCE:EALarm:STOP[:AUNit]	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:SOURCE:EALarm:SUBRow	-	-	✓	-	-	-	-	-	✓	-	-	-	-
:SOURCE:EALarm:TIMing:BURSt	✓	✓	✓	✓	✓	✓	✓	✓	✓	-	-	-	-
:SOURCE:EALarm:TIMing:ERRor	✓	-	✓	✓	✓	✓	✓	✓	-	-	-	-	-
:SOURCE:EALarm:TIMing:NORMal	✓	-	✓	✓	✓	✓	✓	✓	-	-	-	-	-
:SOURCE:EALarm:TIMing:RATE	✓	✓	✓	✓	✓	✓	✓	✓	✓	-	-	-	-
:SOURCE:EALarm:TIMing:TYPE	✓	✓	✓	✓	✓	✓	✓	✓	✓	-	-	-	-
:SOURCE:EALarm:TYPE	✓	✓	✓	✓	✓	✓	✓	✓	✓	-	-	-	-
:SOURCE:GFP:CSF:REPLacement	-	-	-	-	-	-	-	✓	-	-	-	-	-
:SOURCE:GFP:{PTI UPI}	-	-	-	-	-	-	-	✓	-	-	-	-	-
:SOURCE:MAPPING	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:SOURCE:MAPPING:LANE	✓	✓	✓	✓	✓	✓	✓	✓	✓	-	-	-	-
:SOURCE:ODTU:DUMMY:PATtern	-	-	-	-	✓	✓	✓	✓	-	-	-	-	-
:SOURCE:ODTU:MAIN:TP	-	-	-	-	✓	✓	✓	✓	-	-	-	-	-
:SOURCE:ODTU:MAIN:TS	-	-	-	-	✓	✓	✓	✓	-	-	-	-	-

Appendix
Appendix D

Table D-1 Correspondence between Application and Command (Cont'd)

Application Command	100GbE	40GbE	ODU4-PRBS	ODU4-100GbE	ODU4-ODTU4.8-ODU2e-PRBS	ODU4-ODTU4.8-ODU2e-10GbE	ODU4-ODTU4.1-ODU0-PRBS	ODU4-ODTU4.1-ODU0-GbE	ODU3- PRBS	100GbE No Frame	40GbE No Frame	OTU4 No Frame	OTU3 No Frame
:SOURCE:OTN:FEC	-	-	-	✓	✓	✓	✓	✓	✓	-	-	-	-
:SOURCE:OTN:OH[:L]	-	-	-	✓	✓	✓	✓	✓	✓	-	-	-	-
:SOURCE:SKEW:BIT	✓	✓	✓	✓	✓	✓	✓	✓	✓	-	-	-	-
:SOURCE:SKEW:LANE	✓	✓	✓	✓	✓	✓	✓	✓	✓	-	-	-	-
:SOURCE:SKEW:NS	✓	✓	✓	✓	✓	✓	✓	✓	✓	-	-	-	-
:SOURCE:SKEW:TYPE	✓	-	✓	✓	✓	✓	✓	✓	-	-	-	-	-
:SOURCE:STReam:BUSt:CONTRol:VALue	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:SOURCE:STReam:BUSt:ENABle	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:SOURCE:STReam:BUSt:SIZE	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:SOURCE:STReam:CONTRol:RANGe	✓	✓	-	✓	-	✓	-	✓	-	-	-	-	-
:SOURCE:STReam:CONTRol:TYPE	✓	✓	-	✓	-	✓	-	✓	-	-	-	-	-
:SOURCE:STReam:CONTRol:VALue	✓	✓	-	✓	-	✓	-	✓	-	-	-	-	-
:SOURCE:STReam:COUNT	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:SOURCE:STReam:DURation:FRAMES	✓	✓	-	✓	-	✓	-	✓	-	-	-	-	-
:SOURCE:STReam:DURation:REPeat:CO UNT	✓	✓	-	✓	-	✓	-	✓	-	-	-	-	-
:SOURCE:STReam:DURation:TYPE	✓	✓	-	✓	-	✓	-	✓	-	-	-	-	-
:SOURCE:STReam:ENABle	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:SOURCE:STReam:ERRor:TYPE	✓	✓	-	✓	-	✓	-	✓	-	-	-	-	-
:SOURCE:STReam:FSIZe	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:SOURCE:STReam:FSIZe:RANG	✓	✓	-	✓	-	✓	-	✓	-	-	-	-	-
:SOURCE:STReam:FSIZe:TYPE	✓	✓	-	✓	-	✓	-	✓	-	-	-	-	-
:SOURCE:STReam:FSIZe:VALue	✓	✓	-	✓	-	✓	-	✓	-	-	-	-	-
:SOURCE:STReam:HEADer	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:SOURCE:STReam:HEADer:ETHer:DA	✓	✓	-	✓	-	✓	-	✓	-	-	-	-	-
:SOURCE:STReam:HEADer:ETHer:SA	✓	✓	-	✓	-	✓	-	✓	-	-	-	-	-
:SOURCE:STReam:HEADer:ETHer:TYPE	✓	✓	-	✓	-	✓	-	✓	-	-	-	-	-
:SOURCE:STReam:HEADer:PATTern	✓	✓	-	-	-	-	-	-	-	-	-	-	-

Table D-1 Correspondence between Application and Command (Cont'd)

Application Command	100GbE	40GbE	ODU4-PRBS	ODU4-100GbE	ODU4-ODTU4.8-ODU2e-PRBS	ODU4-ODTU4.8-ODU2e-10GbE	ODU4-ODTU4.1-ODU0-PRBS	ODU4-ODTU4.1-ODU0-GbE	ODU3- PRBS	100GbE No Frame	40GbE No Frame	OTU4 No Frame	OTU3 No Frame
:SOURCE:STREAM:HEADER:VARIABLE1:RANGE	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:SOURCE:STREAM:HEADER:VARIABLE1:TYPE	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:SOURCE:STREAM:HEADER:VARIABLE2:RANGE	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:SOURCE:STREAM:HEADER:VARIABLE2:TYPE	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:SOURCE:STREAM:HEADER:VARIABLE{3 4 5}	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:SOURCE:STREAM:ID	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:SOURCE:STREAM:RESOLVE:IP:TARGET	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:SOURCE:STREAM:RESOLVE:IPV4:ROUTER	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:SOURCE:STREAM:RESOLVE:IPV6:ROUTER	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:SOURCE:STREAM:RESOLVE:MAC:RETRY	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:SOURCE:STREAM:RESOLVE:MAC:TIMEOUT	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:SOURCE:STREAM:RESOLVE:PING:TRY	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:SOURCE:STREAM:RESOLVE:PING:PAYLOAD	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:SOURCE:STREAM:RESOLVE:PING:TIMEOUT	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:SOURCE:STREAM:RESOLVE:RESULT	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:SOURCE:STREAM:RESOLVE:START	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:SOURCE:STREAM:RESOLVE:START:EVENT	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:SOURCE:STREAM:RESOLVE:STATUS	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:SOURCE:STREAM:RESOLVE:STOP	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:SOURCE:STREAM:RESOLVE:TYPE	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:SOURCE:STREAM:START[:AUNIT]	✓	✓	-	✓	-	✓	-	✓	-	-	-	-	-
:SOURCE:STREAM:START:EVENT[:AUNIT]	✓	✓	-	✓	-	✓	-	✓	-	-	-	-	-
:SOURCE:STREAM:STATUS[:AUNIT]	✓	✓	-	✓	-	✓	-	✓	-	-	-	-	-
:SOURCE:STREAM:STOP[:AUNIT]	✓	✓	-	✓	-	✓	-	✓	-	-	-	-	-
:SOURCE:STREAM:TFRAME:ENABLE	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:SOURCE:STREAM:TFRAME:FID	✓	✓	-	-	-	-	-	-	-	-	-	-	-

Appendix
Appendix D

Table D-1 Correspondence between Application and Command (Cont'd)

Application Command	100GbE	40GbE	ODU4-PRBS	ODU4-100GbE	ODU4-ODTU4.8-ODU2e-PRBS	ODU4-ODTU4.8-ODU2e-10GbE	ODU4-ODTU4.1-ODU0-PRBS	ODU4-ODTU4.1-ODU0-GbE	ODU3- PRBS	100GbE No Frame	40GbE No Frame	OTU4 No Frame	OTU3 No Frame
:SOURce:STReam:TYPE	✓	✓	-	-	-	-	-	-	-	-	-	-	-
:SOURce:TPATtern:INVert	-	-	✓	-	✓	-	✓	-	✓	✓	✓	✓	✓
:SOURce:TPATtern:TYPE	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:SOURce:TPATtern:WORD	✓	✓	✓	✓	✓	✓	✓	✓	✓	-	-	-	-
:SOURce:TRANsceiver:EMPHasis:FIRSt	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:SOURce:TRANsceiver:EMPHasis:PRE	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:SOURce:TRANsceiver:EMPHasis:SECOnd	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:SOURce:TRANsceiver:VOd	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:SYSTem:CONFIg	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:SYSTem:DATE	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:SYSTem:ERRor	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:SYSTem:PRINt:COpy	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:SYSTem:STATus	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:SYSTem:TERMination	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:SYSTem:TIME	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:SYSTem:VERSIon	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:UENTry:ID	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
:UENTry:LIST	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓

This appendix explains the code and message responses to the :SYSTem:ERRor? query command.

- Command error
- Execution error
- Device unique error

When these errors occur, the standard event status register bit becomes 1. A service request can be generated when an error occurs depending on the setting of the standard event status enable register bit.

When an error occurs, the standard event status register bit that becomes 1 is listed in the table below.

Appendix E Sample Program

This appendix describes the sample program using the Tera Term macro function.

E.1 Executing sample Programs

1. Start the test editor such as the Windows memo pad.
2. Copy the sample program in this manual.
3. Past the copied sample program to the test editor.
4. The file can be saved in Tera Term macro format (with ttl extension).
5. Start Tera Term.
6. Confirm that it can be communicated with the MD1260A referring to Section 2.7.1 When using Ethernet (Windows 7/Vista) “
7. Click [Control] →[Macro] from the menu of Tera Term.
8. Open the file selection window.
Select the file saved at step 4.

For the other execution method of macro, refer to the help of Tera Term.

E.2 Example 1: Setting Stream and Reading Counter

This sample program sets the 100 GbE or 40 GbE application stream and reads out the counter value.

Processing Flow

1. The Unit ID defines One MD1260A as the control target.
2. The application is queried by :SOURCE:MAPPING?.
When the application is 100GbE or 40 GbE, the results of the message box are displayed.
3. Set a port as follows.
Mode: Normal
Bert: Off
LFS Reply: On
Flow Control:On
Rx MPLS-TP Control Word: Off
4. Query the link lamp in the status area.
5. Set the stream 1 through 16 as follows.
Frame size: Random, 128 to 1600 (bytes)
Gap size: Random, 2000 to 20000 (bytes)
6. Enable the stream1 through 16 and send the stream.
7. Start counting.
8. Query whether to start counting every one second.
9. Query the time from the start of counting every one second.
10. Query the following data after the time from the start of counting indicates more than 10 seconds.
Opt tab: LOS
Statistics tab: Clock Source Loss, Rx Frequency (Hz), Rx Frequency (ppm), Bit Errors (rate), Bit Errors (Count)

E.2 Example 1: Setting Stream and Reading Counter

```
; sample program for MD1260A ver 3.1
; Anritsu Corporation April,2012
;
; set local echo to on
setecho 1
flushrecv
; specify module number of MD1260A
sendln ':UENT:ID 1'

; time out 3 second
timeout=3

; query application
sendln ':SOURce:MAPPING?'
waitln 'E100G' 'E40G'

result_mapp=result
if result_mapp=0 goto _timeout
if result_mapp=3 then
    messagebox 'Application is not 40GbE nor 100GbE' 'MD1260A Application'
end
endif

call check_error_code

; set port as normal mode
sendln ':ROUTE:MODE NORMAL'
call check_error_code
; set frame BERT off
sendln ':ROUTE:BERT 0'
call check_error_code
; set LFS reply on
sendln ':ROUTE:LFS:REPLY 1'
call check_error_code
; set flow control on
sendln ':ROUTE:FCONTROL 1'
call check_error_code
; set Rx MPLS-TP Control Word to off
sendln ':ROUTE:MPLStp:CWORD 0'
call check_error_code
pause 2

call check_link
```

Appendix E Sample Program

```
; stream configuration
for id 1 16
  int2str id_str id
  spcify_id=':SOURce:STReam:ID '
  strconcat spcify_id id_str
  sendln spcify_id
  call check_error_code
  sendln ':SOURce:STReam:CONTRol:TYPE RANDOM'
  call check_error_code
  sendln ':SOURce:STReam:CONTRol:RANGe 2000,200000'
  call check_error_code
  sendln ':SOURce:STReam:FSIZe:TYPE RANDOM'
  call check_error_code
  sendln ':SOURce:STReam:FSIZe:RANGe 128,1600'
  call check_error_code
next

sendln ':SOURce:STReam:ENABle 1,2,3,4,5,6,7,8,9,10,11,12,13,14,15,16'
call check_error_code
sendln ':SOURce:STReam:STARt'
call check_error_code

; check counter status to clear buffer
sendln ':CALCulate:COUNter:STARt:EVENT?'
pause 1 ; wait 1 second
waitln '0' '1'
call check_error_code

; start counter
sendln ':CALCulate:COUNter:STARt'
call check_error_code
pause 3

; query counter status
for i 1 10
  sendln ':CALCulate:COUNter:STARt:EVENT?'
  pause 1; wait 1 second
  waitln '0' '1'
  counter_start=result
  if result=0 goto _timeout
  if result=2 break
  call check_error_code
next
```

```
if counter_start=1 then
    messagebox 'Counter is not ready' 'Warning !'
endif

; waiting until elapsed time reaches 10 second
for i 1 20
    sendln ':CALCulate:DATA? ELAPSED'
    pause 1; wait 1 second
    recvln
    recvln
    ;call check_response ; debug
    if result=0 goto _timeout
    if result=1 then
        str2int e_time inputstr
        if e_time>9 break
    endif
    call check_error_code
next

; data acquisition
sendln ':CALCulate:DATA? LOS,CSLOSS,RX_FREQ,RX_FREQ_D,BER_CNT,BER_RATE'
call check_error_code
call check_alarm

messagebox 'Macro end successfully' 'Finish'

End

; ----- subroutines -----
:_timeout
    messagebox 'No response from MD1260A.' 'Time out!'
    call check_error_code
    End

:check_link
    ; check status lamp of link
    sendln ':CALCulate:DATA? LINK'
    waitln '0' '1' '2'
    link_state=result
    ; in case of timeout
    if result=0 goto _timeout
    ; in case of link up
    ;if result=1 messagebox 'Link lamp of status area is lit' 'Link Up'
    ; in case of link down
```

Appendix E Sample Program

```
    if result=2 messagebox 'Link lamp of status area is not lit' 'Link Down'

    call check_error_code

return

:check_alarm
; in case of link, check status lamp of error
sendln ':CALCulate:EALarm?'
waitln '0' '1' '2'
; in case of timeout
if result=0 then
    goto _timeout
; in case of no error
elseif result=1 then
    messagebox 'Error lamp of status area is not lit' 'No error occurring'
; in case of error occurring
elseif result=2 then
    messagebox 'Error lamp of status area is red' 'Error occurring'
    end
elseif result=3 then
    messagebox 'Error lamp of status area is orange' 'No error occurring
currently'
endif

    call check_error_code

return

:check_error_code
; query error
sendln ':SYSTem:ERRor?'
waitln 'No error'

; in case of timeout
if result=0 goto _timeout
; in case of error occurring
if result=2 then
    e_message='Error code = '
    strconcat e_message inputstr
    messagebox e_message 'Command Error occurred'
    end
endif
```

```
    ; in case of no error

Return

:check_response
    ;for debug
    messagebox inputstr 'debug1'
    int2str result_str result
    messagebox result_str 'debug2'
    return
```

E.3 Example 2: Reading out Error Insertion and Counter

This sample program sets the errors of the 100 GbE or 40 GbE application and reads out the counter value.

Processing Flow

1. The Unit ID defines One MD1260A as the control target.
2. The application is queried by :SOURCE:MAPPING?.
When the application is not OTU4 or OTU3, the message box is displayed and the processing is suspended.
3. Set the errors as follows.
Type: ErrorODU4-PM-BIP8
Timing: Rate, 10E-8
4. Start counting.
5. Query whether to start counting every one second.
6. Query the time from the start of counting every one second.
7. Query the following data after the time from the start of counting indicates more than 20 seconds.
Summary tab: LOS, Clock Source Loss, Rx Frequency (Hz),
Rx Frequency (ppm)
Statistics tab: PM-BIP8 (count)

E.3 Example 2: Reading out Error Insertion and Counter

```
; sample program for MD1260A ver 3.0
; Anritsu Corporation June,2011
;; set local echo to on
setecho 1
flushrecv
; specify module number of MD1260A
sendln ':UENT:ID 1'

; time out 3 second
timeout=3

; query application
sendln ':SOURce:MAPPING?'
waitln 'OTU3' 'OTU4'

result_mapp=result
if result_mapp=0 goto _timeout
if result_mapp=3 then
    messagebox 'Application is not OTU3 nor OTU4.' 'MD1260A Application'
    end
endif

call check_error_code

; set port parameter
sendln ':ROUTE:MODE NORMAL'
call check_error_code
sendln ':SOURce:OTN:FEC OFF'
call check_error_code

pause 1

; stream configuration
sendln ':SOURce:EALarm:TYPE PM_BIP8'
call check_error_code
sendln ':SOURce:EALarm:TIMing:TYPE RATE'
call check_error_code
sendln ':SOURce:EALarm:TIMing:RATE R1E_8'
call check_error_code
sendln ':SOURce:EALarm:START:EVENT?'; clear event buffer
pause 1 ; wait 1 second
waitln '0' '1'

call check_error_code
```

Appendix E Sample Program

```
; start error insertion
sendln ':SOURce:EALarm:START'
call check_error_code

pause 2

; query error insertion status
for i 1 10
  sendln ':SOURce:EALarm:START:EVENT?'
  pause 1; wait 1 second
  waitln '0' '1'
  error_ins_start=result
  if result=0 goto _timeout
  if result=2 break
  call check_error_code
next

if error_ins_start=1 then
  messagebox 'Error insertion does not start' 'Warning !'
endif

; check counter status to clear buffer
sendln ':CALCulate:COUNter:START:EVENT?'

waitln '0' '1'
call check_error_code

; start counter
sendln ':CALCulate:COUNter:START'
call check_error_code
pause 3

; query counter status
for i 1 10
  sendln ':CALCulate:COUNter:START:EVENT?'
  pause 1; wait 1 second
  waitln '0' '1'
  counter_start=result
  if result=0 goto _timeout
  if result=2 break
  call check_error_code
next
```

E.3 Example 2: Reading out Error Insertion and Counter

```
if counter_start=1 then
    messagebox 'Counter is not ready' 'Warning !'
endif

; waiting until elapsed time reaches 15 second
for i 1 20
    sendln ':CALCulate:DATA? ELAPSED'
    pause 1; wait 1 second
    recvln
    recvln
    ;call check_response ; debug
    if result=0 goto _timeout
    if result=1 then
        str2int e_time inputstr
        if e_time>14 break
    endif
    call check_error_code
next

; data acquisition
sendln ':CALCulate:DATA? LOS,CSLOSS,RX_FREQ,RX_FREQ_D,PM_BIP8'
call check_error_code
call check_alarm

messagebox 'Macro end successfully' 'Finish'
End

; ----- subroutines -----

:check_response
;for debug
int2str result_str result
messagebox result_str 'debug1'

return

:_timeout
messagebox 'No response from MD1260A.' 'Time out!'
End

:check_alarm
; in case of link, check status lamp of error
sendln ':CALCulate:EALarm?'
waitln '0' '1' '2'
```

Appendix E Sample Program

```
; in case of timeout
if result=0 then
    goto _timeout
; in case of no error
elseif result=1 then
    messagebox 'Error lamp of status area is not lit' 'No error occurring'
; in case of error occurring
elseif result=2 then
    messagebox 'Error lamp of status area is red' 'Error occurring'
    end
elseif result=3 then
    messagebox 'Error lamp of status area is orange' 'No error occurring
currently'
endif

call check_error_code

return

:check_error_code
; query error
sendln ':SYSTEM:ERROR?'
waitln 'No error'

; in case of timeout
if result=0 goto _timeout
; in case of error occurring
if result=2 then
    e_message='Error code = '
    strconcat e_message inputstr
    messagebox e_message 'Command Error occurred'
    end
endif

; in case of no error

return
```

E.4 Example 3: Saving Captured Data

This sample program saves the data captured by the 100 GbE or 40 GbE application.

Processing Flow

1. The Unit ID defines One MD1260A as the control target.
2. Query the application by :SOURce:MAPPING?.
When the application is not OTU4 or OTU3, the message box is displayed and the processing is suspended.
3. Query the link lamp in the status area after setting to the normal mode.
4. Query the Error/Alarm lamp in the status area if the link by lamp lights green.
5. Set a port if the Error/Alarm by lamp does not light red.
Bert: Off
LFS Reply: On
Flow Control: On
Rx MPLS-TP Control Word: Off
6. Set the lane mapping.
7. Set the stream 1 through 16 as follows.
Frame size: Random, 128 to 1600 (bytes)
Gap size: Random, 2000 to 20000 (bytes)
8. Enable the stream 1 through 16 as follows.
9. Read out the counter status.
10. Start counting.
11. Read out the counter status.
12. After the captured data is obtained, save data with the file name including the date and time.

Appendix E Sample Program

```
; sample program for MD1260A ver 3.1
; Anritsu Corporation April,2012
;
; set local echo to on
setecho 1
flushrecv
; specify module number of MD1260A
sendln ':UENT:ID 1'

; time out 3 second
timeout=3

; query application
sendln ':SOURce:MAPPING?'
waitln 'E100G' 'E40G'

result_mapp=result
if result_mapp=0 goto _timeout
if result_mapp=3 then
    messagebox 'Application is not 40GbE nor 100GbE' 'MD1260A Application'
end
endif

call check_error_code

; set port as normal mode
sendln ':ROUTE:MODE NORMAL'
call check_error_code
; set frame BERT off
sendln ':ROUTE:BERT 0'
call check_error_code
; set LFS reply on
sendln ':ROUTE:LFS:REPLY 1'
call check_error_code
; set flow control on
sendln ':ROUTE:FCONTROL 1'
call check_error_code
; set Rx MPLS-TP Control Word to off
sendln ':ROUTE:MPLStp:CWORD 0'
call check_error_code

pause 2

call check_link
```

```
call check_alarm

; set lane mapping
if result_mapp=2 sendln ':SOURCE:MAPPING:LANE 0,1,2,3'
if result_mapp=1 sendln ':SOURCE:MAPPING:LANE
0,1,2,3,4,5,6,7,8,9,10,11,12,13,14,15,16,17,18,19'
call check_error_code

; stream configuration
for id 1 16
int2str id_str id
spcify_id=':SOURCE:STReam:ID '
strconcat spcify_id id_str
sendln spcify_id
call check_error_code
sendln ':SOURCE:STReam:CONTRol:TYPE RANDOM'
call check_error_code
sendln ':SOURCE:STReam:CONTRol:RANGe 2000,200000'
call check_error_code
sendln ':SOURCE:STReam:FSIZe:TYPE RANDOM'
call check_error_code
sendln ':SOURCE:STReam:FSIZe:RANGe 128,1600'
call check_error_code
next
sendln ':SOURCE:STReam:ENABle 1,2,3,4,5,6,7,8,9,10,11,12,13,14,15,16'
call check_error_code

; set trigger to oversize
sendln ':CALCulate:TRIGger:CONDition #B00000001'
pause 1 ; wait 1 second
call check_error_code

; clear event buffer
sendln ':CALCulate:CAPTure:START:EVENT?'
call check_error_code

; start capture
sendln ':CALCulate:CAPTure:START'
call check_error_code
flushrecv

for i 1 10
  pause 1
  sendln ':CALCulate:CAPTure:START:EVENT?'
```

Appendix E Sample Program

```
waitln '0' '1'
capture_result=result
if result=0 goto _timeout
if result=2 break
call check_error_code

next

if capture_result=1 then
    messagebox "Capture does not start!" 'Capture error'
end
endif

; stream start
sendln ':SOURCE:STREAM:START'
call check_error_code

; wait trigger of capture
for i 1 10
    pause 1
    sendln ':CALCulate:CAPture:STATus?'
    waitln '0' '1'
    capture_result=result
    ;call check_response
    if result=0 goto _timeout
    if result=1 break
    call check_error_code
next

if capture_result=2 then
    messagebox "Capture trigger doesn't raise!" 'Capture error'
end
endif

; save capture data to file
getdate filename "macro-%Y%m%d-%H%M%S"
header=':MMEMory:STORe:CAPture '
strconcat header filename

sendln ':MMEMory:STORe:CAPture:ITEM LIBPCAP'
call check_error_code
sendln header
call check_error_code
```



```
messagebox 'Macro end successfully' 'Finish'

End

:_timeout
messagebox 'No response from MD1260A.' 'Time out!'
End

:check_link
; check status lamp of link
flushrecv
sendln ':CALCulate:DATA? LINK'
waitln '0' '1' '2'
call check_response
link_state=result
; in case of timeout
if result=0 goto _timeout
; in case of link up
; if result=1  messagebox 'Link lamp of status area is lit' 'Link Up'
; in case of link down
if result=2 messagebox 'Link lamp of status area is not lit' 'Link Down'

call check_error_code

return

:check_alarm
; in case of link, check status lamp of error
sendln ':CALCulate:EALarm?'
waitln '0' '1' '2'

; in case of timeout
if result=0 then
    goto _timeout
; in case of no error
elseif result=1 then
    ;messagebox 'Error lamp of status area is not lit' 'No error occurring'
; in case of error occurring
elseif result=2 then
    messagebox 'Error lamp of status area is red' 'Error occurring'
    end
elseif result=3 then
    messagebox 'Error lamp of status area is orange' 'No error occurring
currently'
```

Appendix E Sample Program

```
endif

call check_error_code

return

:check_error_code
; query error
sendln ':SYSTEM:ERROR?'
waitln 'No error'

; in case of timeout
if result=0 goto _timeout
; in case of error occurring
if result=2 then
    e_message='Error code = '
    strconcat e_message inputstr
    messagebox e_message 'Command Error occurred'
end
endif

; in case of no error

return

:check_response

;for debug
messagebox inputstr 'debug1'
int2str result_str result
messagebox result_str 'debug2'

return
```

References are to page numbers.

A

Abbreviation 1-4

B

binary databinary data 2-19

C

CFP MDIO Analysis..... 3-41

Checking ConnectionChecking Connection
..... 2-11

command error 2-24

Command error B-1

CommandCommand..... 2-17

Common commandsCommon commands . 2-20

Connecting EthernetConnecting Ethernet. 2-3

Connecting GPIBConnecting GPIB 2-5

D

data partsdata parts 2-18

Device dependant error..... B-2

Device dependent commandsDevice
dependent commands..... 2-20

Device Dependents CommandDevice

Dependent Commands..... 3-51

E

Ethernet InterfaceEthernet Interface 2-2

execution error..... 2-24

Execution error..... B-2

G

GPIB Cable ConnectionGPIB Cable
Connection 2-5

GPIB InterfaceGPIB Interface 2-2

H

headerheader..... 2-18

I

IEEE488.2 Common MessageIEEE488.2
Common Messages 3-44

L

Lambda Measure..... 3-41

LAN crossover cableLAN crossover cable ... 2-3

LAN straight-through cableLAN
straight-through cable 2-3

List of Common ItemsList of Common Items
..... A-2

M

Meaning of Status Byte Register..... 2-22

Message configurationMessage configuration
..... 2-18

Message FormatMessage Format 2-17

Message typesMessage types..... 2-17

Messages with No Corresponding Panel
OperationMessages with No Corresponding
Panel Operation..... 3-42

N

numeric datanumeric data 2-19

O

operation record function 4-2

P

Panel operation not controlled remotely ... 3-43

Program MessagesProgram Messages..... 2-17

Q

QueryQuery 2-17

R

Response Data FormatResponse Data
Format..... A-1

Response MessagesResponse Messages.... 2-17

RFC2544 3-41

Rules for Describing MessagesRules for
Describing Messages 3-2

S

Safety Symbols ii

Service Disruption..... 3-41

Index

Setting EthernetSetting Ethernet2-7
Setting GPIBSetting GPIB.....2-10
Standard event status enable register.....2-23
Standard Event Status Register2-24
Status Byte Register2-21
String dataString data.....2-18