

MP1701B
Pulse Pattern Generator
Operation Manual

Third Edition

Read this manual before using the equipment.
Keep this manual with the equipment.

ANRITSU CORPORATION

OCT.
2002

Document No.: M-W0512AE-3.0

Safety Symbols

To prevent the risk of personal injury or loss related to equipment malfunction, Anritsu Corporation uses the following safety symbols to indicate safety-related information. Insure that you clearly understand the meanings of the symbols BEFORE using the equipment.

Symbols used in manual

- DANGER** This indicates a very dangerous procedure that could result in serious injury or death if not performed properly.
- WARNING** This indicates a hazardous procedure that could result in serious injury or death if not performed properly.
- CAUTION** This indicates a hazardous procedure or danger that could result in light-to-severe injury, or loss related to equipment malfunction, if proper precautions are not taken.

Safety Symbols Used on Equipment and in Manual

(Some or all of the following five symbols may not be used on all Anritsu equipment. In addition, there may be other labels attached to products which are not shown in the diagrams in this manual.) The following safety symbols are used inside or on the equipment near operation locations to provide information about safety items and operation precautions. Insure that you clearly understand the meanings of the symbols and take the necessary precautions BEFORE using the equipment.



This indicates a prohibited operation. The prohibited operation is indicated symbolically in or near the barred circle.




This indicates an obligatory safety precaution. The obligatory operation is indicated symbolically in or near the circle.



This indicates warning or caution. The contents are indicated symbolically in or near the triangle.



This indicates a note. The contents are described in the box.



These indicate that the marked part should be recycled.

MP1701B Pulse Pattern Generator Operation Manual

May 1992 (First Edition)
August 1995 (Third Edition)

Copyright © 1992–1995 by Anritsu Corporation

All rights reserved. No part of this manual may be reproduced without the prior written permission of Anritsu Corporation.

The contents of this manual may be changed without prior notice.

Printed in Japan

For Safety

WARNING



Repair

WARNING 

Falling Over

1. Always refer to the operation manual when working near locations at which the alert mark shown on the left is attached. If the operation, etc., is performed without heeding the advice in the operation manual, there is a risk of personal injury. In addition, the equipment performance may be reduced.
Moreover, this alert mark is sometimes used with other marks and descriptions indicating other dangers.
2. When supplying power to this equipment, connect the accessory 3-pin power cord to a 3-pin grounded power outlet. If a grounded 3-pin outlet is not available, before supplying power to the equipment, use a conversion adapter and ground the green wire, or connect the frame ground on the rear panel of the equipment to ground. If power is supplied without grounding the equipment, there is a risk of receiving a severe or fatal electric shock.
3. This equipment cannot be repaired by the user. DO NOT attempt to open the cabinet or to disassemble internal parts. Only Anritsu-trained service personnel or staff from your sales representative with a knowledge of electrical fire and shock hazards should service this equipment. There are high-voltage parts in this equipment presenting a risk of severe injury or fatal electric shock to untrained personnel. In addition, there is a risk of damage to precision parts.
4. This equipment should be used in the correct position. If the cabinet is turned on its side, etc., it will be unstable and may be damaged if it falls over as a result of receiving a slight mechanical shock.

For Safety

CAUTION

Changing Fuse

CAUTION 

1. Before changing the fuses, ALWAYS remove the power cord from the poweroutlet and replace the blown fuses. Always use new fuses of the type and rating specified on the fuse marking on the rear panel of the cabinet.

T□□□ A indicates a time-lag fuse.

□□□A or F□□□ A indicate a normal fusing type fuse.

There is risk of receiving a fatal electric shock if the fuses are replaced with the power cord connected.

Cleaning

2. Keep the power supply and cooling fan free of dust.
 - Clean the power inlet regularly. If dust accumulates around the power pins, there is a risk of fire.
 - Keep the cooling fan clean so that the ventilation holes are not obstructed. If the ventilation is obstructed, the cabinet may overheat and catch fire.
3. Use two or more people to lift and move this equipment, or use a trolley. There is a risk of back injury, if this equipment is lifted by one person.

 CAUTION/注意

>18kg

HEAVY WEIGHT/重量物

Equipment Certificate

Anritsu Corporation certifies that this equipment was tested before shipment using calibrated measuring instruments with direct traceability to public testing organizations recognized by national research laboratories including the Electrotechnical Laboratory, the National Research Laboratory and the Communication Research laboratory, and was found to meet the published specifications.

Anritsu Warranty

Anritsu Corporation will repair this equipment free-of-charge if a malfunction occurs within 1 year after shipment due to a manufacturing fault, provided that this warranty is rendered void under any or all of the following conditions.

- The fault is outside the scope of the warranty conditions described in the operation manual.
- The fault is due to misoperation, misuse, or unauthorized modification or repair of the equipment by the customer.
- The fault is due to severe usage clearly exceeding normal usage.
- The fault is due to improper or insufficient maintenance by the customer.
- The fault is due to natural disaster including fire, flooding and earthquake, etc.
- The fault is due to use of non-specified peripheral equipment, peripheral parts, consumables, etc.
- The fault is due to use of a non-specified power supply or in a non-specified installation location.

In addition, this warranty is valid only for the original equipment purchaser. It is not transferable if the equipment is resold.

Anritsu Corporation will not accept liability for equipment faults due to unforeseen and unusual circumstances, nor for faults due to mishandling by the customer.

Anritsu Corporation Contact

If this equipment develops a fault, contact the head office of Anritsu Corporation at the address in the operation manual, or your nearest sales or service office listed on the following pages.

(Blank)

POWER SUPPLY VOLTAGE

Line Voltage Selection

This instrument is operable on a nominal voltage of 100 to 127 Vac (AC 100 V system) or 200 to 250 Vac (AC 200 V system) by setting the AC 100 V/AC 200 V switch under the left side cover.

The voltage and current ratings are indicated on the rear panel when the instrument is shipped from the factory.

To operate on the other voltage system, change the AC 100 V/AC 200 V switch setting. The plate on the rear panel indicating the voltage and current ratings should be changed to the appropriate one. Order the plate from Anritsu Corporation if needed.

In this manual, the power supply voltage and current ratings are represented by **Vac and ***A, respectively.

Relationship Between Voltage, Current and Fuse

The relationship between power supply voltage and current ratings is shown below:

Vac	*A
100 to 127 Vac (AC 100 V system)	8A (T8A Fuse)
200 to 250 Vac (AC 200 V system)	6.3A (T6.3A Fuse)

STORAGE MEDIUM

This equipment stores data and programs using floppy disk.

Data and programs may be lost due to improper use or failure.

ANRITSU therefore recommends that you back-up the memory.

ANRITSU CANNOT COMPENSATE FOR ANY MEMORY LOSS.

Please pay careful attention to the following points. Do not remove the floppy disk from equipment being accessed.

For details refer to the relevant operation manual.

(Floppy disk)

- Observe the specified environmental conditions. Also, do not use the equipment in a dusty place.
- Keep magnetic objects away from the disk. Do not bend the disk.
- Insert the head protection sheet into the disk slot when moving the equipment.

(Blank)

Power Line Fuse Protection


For safety, Anritsu products have either one or two fuses in the AC power lines as requested by the customer when ordering.

Single fuse: A fuse is inserted in one of the AC power lines.

Double fuse: A fuse is inserted in each of the AC power lines.

Example 1: An example of the single fuse is shown below:

Fuse Holder



Example 2: An example of the double fuse is shown below:

Fuse Holders




TABLE OF CONTENTS

SECTION	1	GENERAL	1-1
	1.1	General	1-1
	1.2	Manual Composition	1-1
	1.3	Composition	1-2
	1.3.1	Standard composition	1-2
	1.4	Optional Accessories and Peripheral Equipment	1-3
	1.5	Specifications	1-4
SECTION	2	PREPARATIONS	2-1
	2.1	Installation Conditions	2-1
	2.2	Safety Measures	2-2
	2.3	Power Supply Voltage	2-3
	2.4	Internal Battery Life	2-4
	2.5	Damage Prevention Measures	2-5
SECTION	3	FRONT AND REAR PANELS	3-1
	3.1	Panel Controls	3-1
SECTION	4	BASIC OPERATION	
	4.1	Setup	4-1
	4.2	Power-On and Operation	4-3

SECTION	5	DETAILED OPERATING INSTRUCTIONS	5-1
	5.1	Internal-Clock-Generator Frequency Setting	5-1
	5.2	Internal-Clock-Generator Reference Signal Setting	5-2
	5.3	Word Pattern Setting	5-3
	5.4	Data Pattern Setting	5-7
	5.5	Programmable Pattern Presetting	5-8
	5.6	Pseudorandom Pattern Setting	5-9
	5.7	Logic Inversion	5-10
	5.8	Error Addition	5-11
	5.9	Output Amplitude, Offset Voltage, and Delay Setting	5-12
	5.10	Memory	5-20
	5.11	External Pattern Input	5-28
	5.12	Parameters Initialization	5-31
SECTION	6	PRINCIPLES OF OPERATION	6-1
	6.1	Block Diagram	6-1
	6.2	Internal Clock Generator (A1)	6-1
	6.3	Programmable Pattern Generator (A8)	6-1
	6.4	Pseudorandom Pattern Generator (A11)	6-1
	6.5	Pattern Sync Output Period	6-4
		6.5.1 Pseudorandom pattern	6-4
		6.5.2 Programmable pattern	6-4
	6.6	1/4 Data Output and 1/4 Clock Output	6-5

SECTION	7	PERFORMANCE TEST	7-1
	7.1	Introduction	7-1
	7.2	Equipment Required	7-1
	7.3	Performance Test	7-2
	7.3.1	Internal clock generator frequency accuracy	7-2
	7.3.2	Internal clock generator SSB phase noise	7-4
	7.3.3	DATA, $\overline{\text{DATA}}$, 1/4DATA rise and fall times	7-7
	7.3.4	DATA, $\overline{\text{DATA}}$, 1/4DATA amplitude and offset voltage	7-9
	7.3.5	DATA, $\overline{\text{DATA}}$ jitter	7-11
	7.3.6	1/4DATA jitter	7-13
	7.3.7	CLOCK1, $\overline{\text{CLOCK1}}$, CLOCK2, 1/4CLOCK rise and fall times	7-14
	7.3.8	CLOCK1, $\overline{\text{CLOCK1}}$, CLOCK2, 1/4CLOCK amplitude and offset voltage	7-16
	7.3.9	Pattern	7-19

(Blank)

SECTION 1

GENERAL

1.1 General

The MP1701B Pulse Pattern Generator operates at clock frequencies from 50 MHz to 10 GHz and generates two patterns: pseudorandom pattern (PRBS) and programmable pattern. The PRBS pattern can have one of 7 periods ranging from 2^7-1 to $2^{31}-1$. The programmable pattern has data and word modes, and can generate patterns that have a maximum length of 512k bits. For the output interface, the offset can be set in 5 mV steps, the amplitude can be set in 10 mV steps and the delay between output data signal and clock signal can be set in 1 ps steps.

The clock signal can be supplied from the outside or from an internal clock generator. The internal clock generator frequency can be set from 50 MHz to 10 GHz in 1 kHz steps.

1.2 Manual Composition



Two manuals are related to handling of the MP1701B Pulse Pattern Generator: this manual and the GP-IB operation manual. When controlling the MP1701B remotely via a GP-IB, refer to the GP-IB operation manual. The GP-IB operation manual is common to the MP1701B, MP1608A, and MP1650A Pulse Pattern Generators.

1.3 Composition

1.3.1 Standard composition

The standard composition of the MP1701B Pulse Pattern Generator is shown in Table 1-1.

Table 1-1 Standard Composition

Item	No.	Name	Qty	Remarks
Instrument	1	MP1701B Pulse Pattern Generator	1	
Accessories supplied	2	Fuses	2	MF51NR8A (8A, F0071) or T6.3A 250 V (6.3A, F0014)
	3	Semirigid cable	2	SMA-P *1 SMA-P  J0500A
	4	Coaxial cable	2	BNC-P BNC-P  J0127B
	5	Adapter	6	APC3.5-J-J Connector, J0496
	6	3.5-inch floppy disk	2	2HD *2, Z0054
	7	GP-IB cable	1	2 m, J0008, 408JE-102
	8	Power cord	1	2.6 m, shielded, 13 A, J0491
	9	Operation manual	1	W0512AE
	10	GP-IB operation manual	1	W0520AE

*1 UT-141AA equivalent semirigid cable

*2 3.5-inch floppy disks are formatted.

Stores the PRBS $2^{10}-1$ equivalent (mark ratio 1/2, 1/4, 1/8) patterns that can be generated by the Anritsu MP1601A and MP1604A Pulse Pattern Generators in one disk.

Another disk is empty.

1.4 Optional Accessories and Peripheral Devices

The MP1701B optional accessories and peripheral devices (sold separately) are shown in Table 1-2.

Table 1-2

Model No./ Order No.	Name	Remarks
J0500A	Semirigid cable, 0.5 m	SMA-P·SX-36·SMA-P
J0500B	Semirigid cable, 1 m	SMA-P·SX-36·SMA-P
J0322A	Coaxial cable, 0.5 m	SUCOFLEX 104, 11SMA-11SMA
J0322B	Coaxial cable, 1 m	SUCOFLEX 104, 11SMA-11SMA
J0498	Coaxial cable, 0.5 m	APC 3.5-P· — · APC 3.5-P*
J0499	Coaxial cable, 1 m	APC 3.5-P· — · APC 3.5-P*
		*Double shielded coaxial cable used
J0007	GP-IB cable, 1 m	408 JE-101
J0008	GP-IB cable, 2 m	408 JE-102
J0127B	Coaxial cable, 2 m	BNC-P·RG58A/U·BNC-P
J0496	APC 3.5J-J connector	
Z0054	3.5 inch floppy disk	2HD
MB24B	Portable Test Rack	
B0171	Carrying case	
B0163	Transport bag	
B0044	Rack mount kit	IMW-5U
PACKET V	Personal Technical Computer	Used as system controller

1.5 Specifications

Operation frequency range	Internal clock		0.05 to 10 GHz			
	External clock		0.05 to 10 GHz			
External clock	Input level		0.7 to 2.0 Vp-p			
	Waveform		0.05 to 0.5 GHz: square wave (duty factor: 50%) >0.5 GHz: sinusoidal or square wave (duty factor: 50%)			
	Connector		APC 3.5 (with female to female adaptor)			
Internal clock	Frequency range		0.05 to 10 GHz			
	Resolution		1 kHz, 1 MHz			
	Frequency accuracy		± 1 ppm			
	SSB phase noise		At 10 kHz offset ≤ -85 dBc/Hz (0.05 to <4.0 GHz) ≤ -80 dBc/Hz (4.0 to <8.0 GHz) ≤ -75 dBc/Hz (8.0 to 10 GHz)			
	Reference signal		10 MHz (INT/EXT selectable)			
Pattern generation	Pseudorandom binary sequence pattern (PRBS)	Pattern length	$2^N - 1$: N = 7, 9, 11, 15, 20, 23, 31			
		Mark ratio	$1/2, 1/4, 1/8, 0/8$ ($1/2, 3/4, 7/8, 8/8$ also possible by logic inversion)			
		Number of "AND bit" shifts when setting mark ratio	1 bit or 3 bit (Selectable using rear panel DIP switch)			
	DATA pattern	Data length	Data length	2 to 4096	Step width	1 step 524288/128 = 4096
				4224 to 524288		128 step 128N (N = 33 to 4096)
			Pattern reset/preset	ALL/PAGE selectable		

Pattern generation (Cont.)	Word pattern	Word length	2 to 16 bits				
		Number of words	1 to 32768	Relationship between Word Length and Number of Words			
			Word length N	Number of Words			
				Range	Step width	Range	Step width
			2	1 to 2048	1 step	2112 to 32768	64 step
			3	1 to 1365	1 step	1408 to 32768	128 step
			4	1 to 1024	1 step	1056 to 32768	32 step
			5	1 to 819	1 step	896 to 32768	128 step
			6	1 to 682	1 step	704 to 32768	64 step
			7	1 to 585	1 step	640 to 32768	128 step
			8	1 to 512	1 step	528 to 32768	16 step
			9	1 to 455	1 step	512 to 32768	128 step
			10	1 to 409	1 step	448 to 32768	64 step
			11	1 to 372	1 step	384 to 32768	128 step
			12	1 to 341	1 step	352 to 32768	32 step
			13	1 to 315	1 step	384 to 32768	128 step
			14	1 to 292	1 step	320 to 32768	64 step
			15	1 to 273	1 step	384 to 32768	128 step
			16	1 to 256	1 step	264 to 32768	8 step
		Pattern reset/preset	ALL/PAGE selectable				

Pattern generation (Cont.)	External pattern input mode	Number of channels	8 CH (1 to 8 CH input settings are possible)	
		Pattern bit rate	1/8 speed of fundamental clock	
		Clock output *1	ECL, 50 Ω , connected with -2 V *1 Output of clock for external 1/8 pattern generation	
		External pattern input level	ECL, 50 Ω , connected with -2 V	
		Connector	SMA	
	Logic inversion		possible	
	Error insertion	Error rate	10^{-n} : n = 4, 5, 6, 7, 8, 9 and single	
		Insertion position	possible to insert into any 1 CH of 32 CH (Selectable with rear panel switch)	
	DATA output	Waveform format		NRZ
		Number of outputs		2 (DATA/ $\overline{\text{DATA}}$)
($\overline{\text{DATA}}$ / $\overline{\text{DATA}}$) tracking mode		ON/OFF selectable		
Amplitude		0.5 to 2 Vp-p, variable in 10 mV steps [Setting error: $\leq \pm 15\%$, ± 100 mV whichever is greater]		
Offset voltage		Voltage: -2 to +2 V (V_{OH}), variable in 5 mV steps [Setting error: $\leq \pm 15\%$, ± 100 mV or $\pm 15\%$ of amplitude whichever is greatest] Display mode: V_{OH} , V_{TH} , V_{OL} , selectable		
Rise/fall time		≤ 30 ps		
Pattern jitter		≤ 25 ps		
Crosspoint adjust function		DATA, $\overline{\text{DATA}}$, adjustable, independently		
Waveform distortion		<10% or <100 mV, whichever is greater		
Load impedance		50 Ω (with back termination)		
Connector		APC 3.5 (with female to female adaptor)		

CLOCK output	Number of outputs	3 (CLOCK 1, $\overline{\text{CLOCK 1}}$, CLOCK 2)
	CLOCK 1, $\overline{\text{CLOCK 1}}$ delay	± 500 ps, variable in 1 ps steps
	CLOCK 1, $\overline{\text{CLOCK 1}}$ amplitude	0.5 to 2 Vp-p, variable in 10 mV steps [Setting error: $\leq \pm 15\%$ or ± 100 mV whichever is greater]
	CLOCK 2 amplitude/offset voltage	2 Vp-p ($\leq \pm 15\%$) fixed/0 V ($\leq \pm 300$ mV) fixed
	Offset voltage	Voltage: -2 to +2 V (V_{OH}), variable in 5 mV steps [Setting error: $\leq \pm 15\%$, ± 100 mV or $\pm 15\%$ of amplitude whichever is greatest] Display mode: V_{OH} , V_{TH} , V_{OL} , selectable
	Rise/fall time	Of 20% to 80% amplitude: ≤ 30 ps (≥ 5 GHz) ≤ 50 ps (< 5 GHz)
	Waveform distortion	$< 10\%$ or 100 mV whichever is greater
	Duty ratio adjust function	Of CLOCK 1, $\overline{\text{CLOCK 1}}$ and CLOCK 2, adjustable independently
	Load impedande	50 Ω (with back termination)
	Connector	APC 3.5 (with female to female adaptor)
Output phase	<p style="text-align: center;"> $t_{pp} \leq 30$ ps $t_{pc1} \leq 30$ ps $t_{pc1} \leq 30$ ps $t_{pc2} \leq 30$ ps </p> <p style="text-align: center;">Where $\overline{\text{CLOCK1/CLOCK1}}$ delay is set to 0ps.</p>	

1/4 DATA/ CLOCK output	Number of outputs	DATA: 4 CLOCK: 1
	Output level	0.5 to 1 Vp-p, variable in 10 mV steps [Setting error : $\leq \pm 15\%$ or ± 100 mV whichever is greater]
	Offset voltage	Voltage: -1.5 to $+1.5$ V (V_{OH}), variable in 5 mV steps [Setting error : $\leq \pm 150$ mV] Display mode : V_{OH} , V_{TH} , V_{OL} , selectable
	Rise/fall time	Of 20% to 80% amplitude ≤ 200 ps
	DATA output jitter	≤ 100 ps
	Waveform distortion	$\leq 15\%$
	Skew	<p> $t_2 \leq 100\text{ps}$ $t_3 \leq 100\text{ps}$ $t_4 \leq 100\text{ps}$ $t_c \leq 100\text{ps}$ </p>
Connector	SMA	

Sync signal output	Number of outputs	Pattern : 1 (BNC connector) 1/2 CLOCK: 1 (SMA connector) 1/32 CLOCK: 1 (BNC connector)
	Output level	1 Vp-p \pm 20% (V _{OH} : 0 V, \leq \pm 200 mV)/50 Ω
External control		GP-IB (IEEE 488.2)
Ambient temperature, rated range of use		0° to 50°C (However, 5° to 45°C applied for pattern memory floppy disk)
Parameter memory	Media	3.5 inch floppy disk (2HD) 1.6 Mbyte (unformat)
	Format	MS-DOS, Rev. 3.1
	Content	Programmable pattern and other parameters
Power		**Vac \pm 10% (max. 250 Vac), 48 ~ 63 Hz, \leq 700 VA
Dimensions and weight		221H x 426W x 450D mm, <33 kg

(Blank)

SECTION 2 PREPARATIONS

2.1 Installation Conditions

Operating temperature and humidity range	0°C to 50°C (However, 5°C to 40°C for floppy disks), Relative humidity \leq 95%
Storage temperature and humidity range	-40 to 70°C, Relative humidity \leq 95%

Use and store the MP1701B within these ranges.

Do not use or store the instrument in locations

- where vibrations are severe.
- where it is damp or dusty.
- where there is exposure to direct sunlight.
- where there is exposure to active gases.

Long-term storage at high temperature will increase the discharge rate of the internal battery. Store the instrument below room temperature.

2.2 Safety Measures

- Use the power cord (an accessory) to connect the instrument to the ac power supply.
Ground either the ground terminal of the power cord or the frame ground terminal on the rear panel.
- Turn off the POWER switch and disconnect the power cord from the socket before changing the fuse.
Use a fuse of the same rating.
- If the MP1701B is operated at room temperature after being used, or stored, for a long time at low temperature, condensation may occur and cause short-circuiting. To prevent this, do not turn the power on until the instrument is completely dry.

2.3 Power Supply Voltage

The power supply voltage rating for the MP1701B is shown on the rear panel. Always use a voltage within the rated voltage range. Excessive voltage may damage the circuits.

2.4 Internal Battery Life

The MP1701B uses lithium primary cells as the timer and memory back-up power supply. The life of the cells depends on the temperatures at which the instrument is stored. It is more than 10 years for storage at room temperature.

Storage at high temperature for long periods will shorten this period.

Replace discharge cells: they cannot be recharged.

Since battery replacement can only be made by Anritsu, contact the nearest Anritsu representative when replacement is required.

2.5 Damage Prevention Measures

- When applying signals to the MP1701B, never apply an excessive voltage because the circuits may be damaged.
- The output is terminated at 50 Ω . Do not feed current. The load must be a real resistance of 50 Ω , and should be terminated at ground potential.
- Always ground the equipment to be connected (including the device under test) before connecting the input and output terminals.
- Since the outer shield and center conductors of a coaxial cable act as a capacitor, discharge the shield and center conductors by shorting them with a piece of metal.




Fig. 2-1 Grounding and Cable Discharging

- The bottom section of the MP1701B includes hybrid ICs and important circuits and parts which are susceptible to static electricity. Do not open it.
- The hybrid ICs used in the MP1701B are air-tight. Do not open them. If they are opened and then do not perform satisfactorily, maintenance service may be refused.
- Ventilation holes exist at the bottom cover. Do not disturb the air flow through the holes.

(Blank)

SECTION 3 FRONT AND REAR PANELS

3.1 Panel Controls (Figs. 3-1, 3-2 and Table 3-1)

Table 3-1 Panel Control Explanation

No.	Label	Function
①	POWER	Power switch and lamp.
②	GP-IB	GP-IB local key and remote lamp
	REMOTE	Lamp that shows that the MP1701B is in the remote state.
	LOCAL	Key for manual switching from the GP-IB remote state to the local state.
③	PANEL LOCK	Panel lock key and lamp In the panel lock state, all switches and keys other than the POWER switch and panel lock key are disabled.
④	CLOCK	Internal/external clock switch and external clock input connector
	INT/EXT	Internal/external clock switch
	EXT INPUT	External clock input connector
⑤	SYNC OUTPUT	Sync signal output connectors when waveform observed with an oscilloscope.
	1/32 CLOCK	Connector for 1/32 divided output of clock frequency
	PATTERN	Pattern sync output connector

Table 3-1 Panel Control Explanation (Cont.)

No.	Label	Function	
⑥	PRESET	Programmable pattern preset function	
	ALL	0	Sets all bits to 0.
		1	Sets all bits to 1.
		GUARD	Guard key for the above.
	PAGE	0	Sets the bits of 1 page to 0.
		1	Sets the bits of 1 page to 1.
⑦	BIT	Programmable pattern setting keys and display lamps	
⑧	OUTPUT	Output connectors	
	DATA	Data output connector	
	$\overline{\text{DATA}}$	Inverse data output connector	
	CLOCK1	Clock output connector (Amplitude, offset, and delay can be varied.)	
	$\overline{\text{CLOCK1}}$	Inverse clock output connector (Amplitude, offset, and delay can be varied.)	
	CLOCK2	Clock output connector (Amplitude, offset, and delay are fixed.)	
⑨	CLOCK1	Clock 1 output parameter setting knobs and displays	
	DELAY TIME	Clock 1 output ($\overline{\text{CLOCK1/CLOCK1}}$) delay setting knob and display	
	BUSY	Display lamp during delay setting	
	AMPLITUDE	Clock 1 output ($\overline{\text{CLOCK1/CLOCK1}}$) amplitude setting knob and display	
	OFFSET	Clock 1 output ($\overline{\text{CLOCK1/CLOCK1}}$) offset voltage setting knob and display	

Table 3-1 Panel Control Explanation (Cont.)



No.	Label	Function
⑩	$\overline{\text{DATA}}$ AMPLITUDE OFFSET	Inverse data output parameter setting knobs and displays Inverse data output amplitude setting knob and display Inverse data output offset voltage setting knob and display
⑪	DATA AMPLITUDE OFFSET	Data output parameter setting knobs and displays Data output amplitude setting knob and display Data output offset voltage setting knob and display
⑫	$\overline{\text{DATA/DATA}}$ TRACKING	Data output parameter and inverse data output parameter tracking key
⑬	DISPLAY	Key which switches the data output and clock output parameter setting knob and display between 1/1 SPEED output (front panel output) and 1/4 SPEED output (rear panel output)
⑭	OFFSET	Offset reference value selector key
⑮	MARK RATIO	Pseudorandom-pattern mark ratio selector keys
⑯	ERROR ADDITION (1 X 10 ^{-N})	Error addition amount selector keys and display lamps
⑰	PRBS	Pseudorandom-pattern period (2 ^N -1) and mark ratio display lamps
⑱	 	Programmable-pattern data mode, word mode, and pseudorandom-pattern period (2 ^N -1) selector keys

Table 3-1 Panel Control Explanation (Cont.)




No.	Label	Function
①9	PROGRAMMABLE PATTERN DATA LENGTH/ NUMBER OF WORD WORD LENGTH PAGE	Programmable pattern setting Data length in data mode and number of words in word mode setting keys and display Number of words in word mode setting keys and display Pattern page specification keys and display; pattern set by ⑦ BIT
②0	PRGM	Programmable pattern mode display lamps
②1	LOGIC POS/NEG	Output logic positive/negative switch and display lamps
②2	RESOLUTION MHz/kHz	Frequency setting resolution switch
②3	FREQUENCY	Internal clock frequency display
②4	 	Frequency change step switch
②5	TUNING	Frequency setting function ON/OFF switch and display lamp
②6		Frequency setting knob

Table 3-1 Panel Control Explanation (Cont.)






No.	Label	Function
<p>②⑦</p>	<p>MEMORY</p> <p>EXIST</p>    <p>DIR/FILE No.</p> <p>RECALL/ DELETE</p> <p>SAVE/RESAVE</p> <p>SHIFT</p> <p>MODE PTN/OTHERS</p>	<p>Patterns and other set conditions memory</p> <p>Lamp which shows that a registered file exists.</p> <p>File number and error code display</p> <p>File number setting keys</p> <p>Above file-number-setting-key function selector key and display lamp</p> <p>Memory contents recall or memory contents delete (shift mode) key and display lamp</p> <p>Save and resave (shift mode) to file key and display lamp</p> <p>Shift mode switch and display lamp</p> <p>Selector key between pattern and other set condition memory functions and display lamp</p>
<p>②⑧</p>		<p>Floppy disk drive</p>
<p>②⑨</p>	<p>STD 10 MHz</p> <p>BUFFER OUTPUT</p> <p>INPUT TTL</p> <p>OUTPUT TTL</p> <p>INT/EXT</p>	<p>Internal synthesizer reference signal input/output</p> <p>Reference signal buffered output connector</p> <p>Reference signal input connector</p> <p>Reference signal output connector</p> <p>Reference signal oscillator internal/external selector switch</p>

Table 3-1 Panel Control Explanation (Cont.)

No.	Label	Function
③⑩	GP-IB	GP-IB connector and address setting switches
③①	FUNCTION	Function selector switches
③②	ERROR ADDITION CH (1-32)	Error addition channel selector switches
③③		U-link for internal synthesizer reference signal OUTPUT/INPUT connector connection
③④	1/8 SPEED	External pattern inputs and external pattern generation clock output
	CLOCK OUTPUT	External pattern generation clock output connector
	EXTERNAL DATA INPUT	External pattern input connectors and display lamps
	CH SELECT EXT/INT	External pattern/internal pattern selector switches
③⑤	AC ** V,  T ***A	Power inlet
③⑥		Frame ground terminal
③⑦	1/2 CLOCK OUTPUT	1/2 clock output connector
③⑧	1/4 SPEED OUTPUT	1/4 clock output connector and 1/4 data output connectors
	CLOCK	1/4 clock output connector
	DATA1	1/4 data 1 output connector
	DATA2	1/4 data 2 output connector
	DATA3	1/4 data 3 output connector
	DATA4	1/4 data 4 output connector

Note : After changing the setting conditions, wait 2 minutes before turning the power OFF.




Fig. 3-1 Front panel




Fig. 3-2 Front panel

SECTION 4

BASIC OPERATION

This section describes the basic operating method and the basic functions of the instrument for those who are using the MP1701B Pulse Pattern Generator for the first time.

Read this section before reading the detailed operating instructions of SECTION 5. Those who have used the MP1601A/MP1604A Pulse Pattern Generator may skip this section.

The number (5), (8), etc. in the text correspond to the controls of Figs. 3-1 and 3-2.

4.1 Setup

To understand the basic operation of the MP1701B, observe its output waveform with a sampling oscilloscope.

Set up the equipment as follows while referring to Fig. 4-1.

Step	Procedure
1	Connect the sampling oscilloscope and MP1701B frame ground terminals to a ground wire. Then, connect the sampling oscilloscope and MP1701B power cords to the AC line and connect the MP1701B to the sampling oscilloscope with coaxial cables.
2	After shorting the shield and internal conductors of the accessory semirigid cables with a piece of metal, connect the DATA and the CLOCK1 output connectors (8) to the sampling oscilloscope channel 1 and channel 2 via 20 dB pad (att.), respectively.
3	Connect the PATTERN SYNC OUTPUT (5) to the sampling oscilloscope sync input connector.
4	Connect the MP1701B and sampling oscilloscope power cords to an AC outlet. (Use a 3-pole plug with ground and connect it to a grounded outlet. If using a 2-pole plug, connect the sampling oscilloscope and MP1701B frame ground terminals to ground before connecting them to the AC outlet.)





Fig. 4-1 Setup



H: 200 ps/div, Top: DATA
 V: 1 V/div, Bottom: CLOCK1
 Freq: 10 GHz

Fig. 4-2 DATA and CLOCK1 Waveforms

4.2 Power-On and Operation

Note: When the following operations are performed, the existing memory contents are cleared and are preset to the factory setting state (paragraph 5.12). Check with the previous user to see if there are any patterns that must not be cleared.

Step	Procedure
1	While pressing [LOCAL] (2), turn on the POWER switch (1). (This operation presets the MP1701B to the factory setting state. When only the power is turned on without pressing [LOCAL], the MP1701B restores the previous setting state.)
2	Press the pattern select key (18) to set PRBS 27-1. Adjust the sampling oscilloscope trigger level to synchronize the waveform display as shown in Fig. 4-2. Adjust the sampling oscilloscope delay to check if this pulse pattern is obtained.
3	Press the pattern select key (18) to set to PRGM (Programmable Pattern) DATA (data mode).
4	Press PROGRAMMABLE PATTERN (19) DATA LENGTH [V] and [^] to set the data length to 16 bits.
5	Press the BIT keys (7) to set an arbitrary pattern for each 16 bits, and check by comparing the key settings to the waveform on the sampling oscilloscope.
6	Change the frequency as follows. Set the frequency with the TUNING knob (26) after pressing the [TUNING] (25).
7	After fixing at a suitable frequency, set the data output amplitude and offset by means of the DATA display and its setting knobs (11). Compare the sampling oscilloscope waveform with the set values.
8	Set the CLOCK1 amplitude, offset, and delay by means of the CLOCK1 display and its setting knobs (9). Compare the sampling oscilloscope waveform with the set values.

(Blank)

SECTION 5

DETAILED OPERATING INSTRUCTIONS

This section describes the control panel detailed operation and setup methods. Those who want to learn the basic functions of the MP1701B should read SECTION 4 "Basic Operation" before performing actual operation.

5.1 Internal-Clock-Generator Frequency Setting

(1) Frequency setting state

Press the [TUNING] (25) to set the MP1701B to the frequency setting state. (Display lamp lights)

(2) Resolution setting

Press [RESOLUTION] to set the frequency setting resolution to 1 kHz or 1 MHz.

Switching the setting resolution does not affect the frequency setting response time or C/N (SSB phase noise). When the resolution is sufficient at 1 MHz, the unnecessary digits are masked and keeps the compatibility with the conventional MP1601A (5 GHz)/MP1604A (3 GHz) PPG.

(3) Frequency change step setting

Set the frequency change step width with the frequency change step setting keys [<][>] (24).

When [<] is pressed, the blinking cursor showing the changeable digit of the frequency display (23) moves to the left. When [>] is pressed, it moves to the right.

(4) Frequency setting

Set the frequency by turning the frequency setting knob (26).

5.2 Internal-Clock-Generator Reference Signal Setting

(1) When internal reference generator used

Normally set to this state.

Set the rear panel STD 10 MHz ②⑨ INT/EXT switch to the INT position, and connect the reference signal input connector (INPUT TTL) to the reference signal output connector (OUTPUT TTL) with the U-link ③③ .

(2) When external reference generator used

Set the rear panel STD 10 MHz ②⑨ INT/EXT switch to the EXT position, and connect an external reference signal generator to the reference signal input connector (INPUT TTL). The input level is TTL level.

5.3 Word Pattern Setting

(1) Pattern selection

Select the output pattern with [\leftarrow] and [\rightarrow] (18) so that the PRGM-WORD lamp (20) lights.

(2) Number of words and word length

When the number of bits making up one word is represented by word length N , and the number of words making up one period is represented by M , the pattern shown in Fig. 5-1 is obtained.

The number of words M setting keys and display are NUMBER OF WORD (19).

The word length N setting keys and display are WORD LENGTH (19).




Fig. 5-1 Word-Mode Programmable Pattern

(3) Number of word setting

Press [\leftarrow] or [\rightarrow] (19) to move the blinking cursor showing the changeable digit of the number. However, the word length and number of words which can be obtained may be restricted. The numbers which can be set conform to Table 5-1.

Note: When the blinking cursor is moved past the left or right end with [\leftarrow] or [\rightarrow] (19), the blinking stops and numbers cannot be set. To perform setting again, blink the cursor at the digit to be changed by pressing [\leftarrow] or [\rightarrow].

Table 5-1 Word length and Number of Words

Word length N	Number of words M			
	Range	Step width	Range	Step width
2	1 to 2048	1 step	2112 to 32768	64 step
3	1 to 1365	1 step	1408 to 32768	128 step
4	1 to 1024	1 step	1056 to 32768	32 step
5	1 to 819	1 step	896 to 32768	128 step
6	1 to 682	1 step	704 to 32768	64 step
7	1 to 585	1 step	640 to 32768	128 step
8	1 to 512	1 step	528 to 32768	16 step
9	1 to 455	1 step	512 to 32768	128 step
10	1 to 409	1 step	448 to 32768	64 step
11	1 to 372	1 step	384 to 32768	128 step
12	1 to 341	1 step	352 to 32768	32 step
13	1 to 315	1 step	384 to 32768	128 step
14	1 to 292	1 step	320 to 32768	64 step
15	1 to 273	1 step	384 to 32768	128 step
16	1 to 256	1 step	264 to 32768	8 step

(4) Page and pattern setting

The display and keys of PAGE (19) identify, or enable modification of, each word in a pattern with M number of words.

When the page is specified as 1, the contents of the set A word in Fig. 5-1 are displayed at BIT (7) and the A word can be modified with the BIT keys (7).

When the page is specified as 2, the contents of the B word are displayed and can be modified.

Perform the same operation for the C word, etc.

Page specification up to M is possible.

When the word length is 15 bits, the BIT keys and lamps (7) up to 15 are enabled.

(5) Pattern setting state after number of words and word length changed

The pattern setting state after the number of words and word length were changed is shown in Fig. 5-2 by using an example in which both the number of words M and word length N are 4. This state is shown in Fig. 5-2 (a).

If the number of words is changed from 4 to 3, the D word is cleared and the repetitive pattern of words A, B and C is set (Fig. 5-2 (b)). If the number of words is reset to 4, the D word set previously reappears and becomes the repetition of the A, B, C, and D words (Fig. 5-2 (c)).

Next, word length N is changed from 4 to 3.

At this time, bit 4 of each word is cleared (Fig. 5-2 (d)). When N is set to 4 again, bit 4 of each word set previously is reset (Fig. 5-2 (e)).

Generally, when the number of words is changed to a value smaller than the previously set number of words, the data of the leading page side is preserved and the data of the trailing page side is cleared. For word length, the leading bits are preserved and the trailing bits are cleared. The 16 bit is disabled and the BIT 16 lamp is fixed at off.




Fig. 5-2 Pattern after Number of Words and Word Length Changed

5.4 Data Pattern Setting

(1) Pattern selection

Select the output pattern to light the PRGM-DATA lamp (20) by pressing [<] and [>] (18) .

(2) Data length setting

In the data mode, if the data length is made N, one period of N bit length pattern is output repeatedly. Set the data length with the PROGRAMMABLE PATTERN (19) DATA LENGTH display, lamp, and keys. The data length can be set from 2 to 524 288 bits. However, when the data length exceeds 4096 bits, setting in 128-bit steps only is possible.

Numbers that are indivisible by 128 cannot be set.

The setting method is the same as that described in paragraph 5.3 (3) "Number of words setting".

(3) Pattern setting

Set the page 1 by pressing the PAGE keys (19).

This allows settings of a pattern of up to bit 16 from the head of the data-length N bits with the BIT keys (7) .

When N is smaller than 16, the keys from N + 1 to 16 are disabled and the corresponding lamps remain off.

If N is larger than 16, set to page 2 to set pattern of bit 17 to bit 32. Bits exceeding this can also be set in 16-bit units by specifying page number.

(4) Output pattern when data length changed

When the data length is changed from P to Q, data from the first bit to bit Q is output repeatedly.

If $P > Q$, since the pattern from bit (Q + 1) to bit P is stored in an internal memory, if the data length is returned to P again, the original pattern is restored and output repeatedly.

5.5 Programmable Pattern Presetting

(1) All bits "0" setting

Set all bits to "0" by pressing PRESET (6) [ALL 0] while pressing [GUARD].

Note: "All bits" involves the setting bits of the current output pattern and the entire (used and unused) buffer memory contents (512k bits) connected to it.

(2) All bits "1" setting

Set all bits to "1" by pressing PRESET (6) [ALL 1] while pressing [GUARD].

(3) One page "0" setting

Set all the bits of the currently displayed page to "0" by pressing the PRESET (6) [PAGE 0].

Only the settable bits are set to "0". (For instance, when the number of words is 15, bit 1 to bit 15 are set to "0".)

(4) One page "1" setting

Set all the bits of the currently displayed page to "1" by pressing the PRESET (6) [PAGE 1].

Only the settable bits are set to "1".

5.6 Pseudorandom Pattern Setting

(1) Pseudorandom (PRBS) pattern length selection

Press [\leftarrow] and [\rightarrow] (18) to select PRBS pattern type.

The bit length of one PRBS pattern period can be selected from among seven bit-lengths from 2^7-1 to $2^{31}-1$ bits (2^N-1 : $N=7, 9, 11, 15, 20, 23, 31$).

(2) Mark ratio selection

Press [\leftarrow] and [\rightarrow] (15) to select a PRBS mark ratio of 0/8, 1/8, 1/4, or 1/2.

Select a mark ratio of 8/8, 7/8, 3/4, or $\overline{1/2}$ by inverting the logic by pressing [LOGIC] (21).

(3) Selection of number of AND bit shifts for mark ratio 1/8, 1/4, 7/8, and 3/4 pattern generation

Select the number of AND bit shifts at mark ratio 1/8, 1/4, 7/8, and 3/4 pattern generation as 1 bit or 3 bits by switching rear panel FUNCTION switch 1 (31). (For details, see paragraph 6.4)

Table 5-2 Number of AND Bit Shifts Selection

FUNCTION switch 1	No. of AND bit shifts
0	1 bit
1	3 bits

5.7 Logic Inversion

(1) Programmable-pattern logic

The BIT (7) lamps, when lit, indicate "1". When off, they indicate "0". When the POS lamp is lit to select positive logic by pressing [LOGIC] (21), "1" corresponds to high level output and "0" corresponds to low level output. When the NEG lamp is lit to select negative logic, "1" corresponds to low level output and "0" corresponds to high level output.

(2) Pseudorandom-pattern logic

For pseudorandom pattern, for positive logic, "1" corresponds to low level output and "0" corresponds to high level output (see block diagram at Table 6-1).

5.8 Error Addition

Step	Procedure
1	Press the ERROR ADDITION (16) [ON]. (The lamp lights.)
2	Select the error addition rate by pressing [<] and [>] (16). For single error addition, on bit error is added each time [SINGLE] is pressed.
3	Select the channel at which error is to be added with the rear panel ERROR ADDITION CH (1-32) switches X10 and X1 (32). (The left switch (X10) sets the tens digits and the right switch (X1) sets the units digit. 01 to 32 can be set. When 00 is set, error is added at CH1 and when 33 to 99 is set, error is added at CH32.)

Note: When the output pattern is divided into each bit as shown in Fig. 5-3, the bit at which error is to be added is selected with these switches X1 and X10.




Fig. 5-3 Error Addition Channel

5.9 Output Amplitude, Offset Voltage, and Delay Setting

(1) DATA, $\overline{\text{DATA}}$, CLOCK1, $\overline{\text{CLOCK1}}$

Light the 1/1 SPEED lamp by pressing [DISPLAY] (13). Turn the $\overline{\text{DATA}}$ (11), DATA (10), and CLOCK1 (9) setting knobs to set the amplitude, offset voltage, and CLOCK1 delay.

(2) DATA, $\overline{\text{DATA}}$ tracking function

Turn on the tracking function by pressing [DATA/ $\overline{\text{DATA}}$ TRACKING] (12). The $\overline{\text{DATA}}$ (10) setting knobs are disabled and the display goes off.

The $\overline{\text{DATA}}$ output amplitude and offset voltage are automatically made the same values as DATA output.

When the DATA (11) amplitude and offset voltage setting knobs are turned in this state, both the DATA and $\overline{\text{DATA}}$ output amplitudes and offset voltages are changed simultaneously.

(3) 1/4 CLOCK, 1/4 DATA

Light the 1/4 SPEED lamp by pressing [DISPLAY] (13).

Set the 1/4 DATA amplitude and offset voltage with the DATA (11) setting knobs, and the 1/4 CLOCK amplitude and offset voltage with the CLOCK (9) setting knobs.

At this time, the $\overline{\text{DATA}}$ (10) amplitude, offset voltage, and $\overline{\text{CLOCK1}}$ delay setting knobs are disabled and the display goes off.

(4) Offset-reference-value selecting function

Set the DATA (11), $\overline{\text{DATA}}$ (10), and CLOCK1 (9) offset voltage reference values to V_{OH} (output high level), V_{TH} (center level between output high and low levels), or V_{OL} (output low level) by selecting V_{OH} , V_{TH} , or V_{OL} with [OFFSET] (14).

The output levels (when the amplitude is changed by switching the offset reference value) are shown in Fig. 5-4.




Fig. 5-4 Offset Reference Value and Amplitude Change

Note: Since the offset-voltage upper and lower limit values are limited by V_{OH} ($-2.0\text{ V} \leq V_{OH} \leq +2.0\text{ V}$), when V_{TH} or V_{OL} are set, the amplitude is limited at a certain value and may not change further.

Example: If V_{OL} is set at $+1.00\text{ V}$ offset voltage and if there is a signal with amplitude 0.5 V_{p-p} added, that amplitude can only be increased to 1.0 V_{p-p} .

This is because their superposition after the increase would be meeting the maximum allowable level $+2.00\text{ V}$.

Figures 5-5 to 5-10 show the relationships between amplitude and offset-voltage settable ranges at three offset references.

- 1/1 SPEED
- Offset reference: VOH




Fig. 5-5 Amplitude and Offset Voltage Setting Range Corresponding to Offset Reference Value

- 1/1 SPEED
- Offset reference: VTH




Fig. 5-6 Amplitude and Offset Voltage Setting Range Corresponding to Offset Reference Value

- 1/1SPEED
- Offset reference: VOL




Fig. 5-7 Amplitude and Offset Voltage Setting Range Corresponding to Offset Reference Value

- 1 / 4 SPEED
- Offset reference: V_{OH}




Fig. 5-8 Amplitude and Offset Voltage Setting Range Corresponding to Offset Reference Value

- 1/4 SPEED
- Offset reference: V_{OH}




Fig. 5-9 Amplitude and Offset Voltage Setting Range Corresponding to Offset Reference Value

- 1 / 4 SPEED
- Offset reference : VOL




Fig. 5-10 Amplitude and Offset Voltage Setting Range Corresponding to Offset Reference Value

5.10 Memory

(1) Floppy disk insertion

Insert a formatted 3.5-inch 2HD-type floppy disk into the floppy disk drive (28). (The accessory floppy disk is formatted. For the formatting method, see paragraph 5.10 (8).)

(2) Mode setting

Set the PTN (pattern) mode or OTHERS mode by pressing MEMORY (27). [MODE PTN/OTHERS]. In the PTN mode, the pattern set contents are stored; in the OTHERS mode, other set conditions (frequency, amplitude, offset voltage, etc.) are stored.

For each mode, file names from 00 to 99 can be selected.

(3) File save

Select the FILE No. display mode by pressing [DIR/FILE No.]. Select the desired file name (00 to 99) by pressing [^] or [v] and then press [SAVE]. In the PTN mode, the pattern set contents are saved; in the OTHERS mode, the other set conditions are saved.

(4) File recall

Select the PTN mode or OTHERS mode, and select the desired file name by pressing [^] or [v].

Press [RECALL] to recall the contents of the file.

(5) Directory

Select the DIR mode with [DIR/FILE No.] to access the floppy disk and check the saved file. Press [^] or [v] to display only the names of the exist files on the inserted floppy disk. When there are no files on the inserted floppy disk, "--" is displayed.

In the DIR mode, recall, resave, and delete operations can be performed, but the save operation cannot be performed.

When returned to the FILE No. mode from the DIR mode, and if the file set with [^] or [v] exists, the EXIST lamp lights.

Note: When the floppy disk is changed after the DIR mode is set, set the DIR mode again.

This is because the read directory information is stored in the MP1701B even if the floppy disk is removed and the directory information will not match when a different floppy disk is inserted.

(6) File resave

After setting the shift mode by pressing [SHIFT], press [RESAVE] to resave an existing file.

However, resave may be impossible, depending on the free storage capacity of the floppy disk. Read the resave operation described in paragraph 5.10 (12).

(7) File delete

After setting the shift mode by pressing [SHIFT], press [DELETE] to delete an existing file.

(8) Floppy disk formatting

Set the OTHERS mode and FILE No. mode, then press [^] to display Fr (Fr follows 99).

After pressing [SHIFT], press [DELETE] to format the floppy disk.

It takes about two minutes to format a floppy disk.

(9) Error message

When a floppy disk error occurs, error code E0 to E9 is displayed on the file name display.

The error messages are shown in Table 5-3.

All the keys in the MEMORY section, other than [v] and [^], are disabled during error message display. To reset the error display, press [v] and [^] once.

Table 5-3 Error Messages

Error item	Error contents
E0	Media error (formatting or media error)
E1	Write protection error
E2	File full (insufficient write area)
E3	File not found (specified file not found at read)
E4	File exists error (save of same file is attempted)
E5	Write error
E6	Read error
E7	File type, file error (file type or file contents error)
E8	FD error (other error)
E9	Hardware error (hardware trouble error)

(10) Memory capacity

Usually, 200 files can be stored on one floppy disk; 100 files in the OTHERS mode and 100 files in the PTN mode. However, when long data length and word length patterns are stored, the number of files that can be stored may decrease.

For example, when 512k bit patterns are stored, only 18 files can be stored (paragraph 5.10(11)(e)).

(11) Floppy disk

(a) Disk type

The floppy disk is formatted in standard MS-DOS format provided by the MS-DOS file handler. The formatted floppy disk becomes data disk type. This is because the MS-DOS handler does not copy the MS-DOS system.

The system disk containing the MS-DOS system can also be used to store data.

(b) Volume label

The volume label is provided when the floppy disk is formatted.

Volume label: MP1701A_DAT

This volume label is used to identify the floppy disk.

(c) File configuration

- Directory configuration

The directory configuration is root directory only.

- File name, extension

The file name and extension have the format shown below.



PTN: Pattern file

OTH: Parameter file for other than pattern

Examples: T99. PTN
T01. OTH

(d) Data format

Since the format of the data stored in floppy disk is not, as a rule, open to the user; operation is not guaranteed when data is generated, modified, etc. by using a personal computer that operates under MS-DOS.

However, file directory checking and file copying are no problem.

(e) 512k bits pattern data and floppy disk capacity

As mentioned previously in paragraph 5.10(10), for 512k bits pattern data, only 18 files can be stored.

The directory is shown below.

T99	PTN	65640	89-11-14	13 : 13
T98	PTN	65640	89-11-14	13 : 13
T97	PTN	65640	89-11-14	13 : 14
T96	PTN	65640	89-11-14	13 : 14
T95	PTN	65640	89-11-14	13 : 15
T94	PTN	65640	89-11-14	13 : 15
T93	PTN	65640	89-11-14	13 : 16
T92	PTN	65640	89-11-14	13 : 16
T91	PTN	65640	89-11-14	13 : 17
T90	PTN	65640	89-11-14	13 : 17
T89	PTN	65640	89-11-14	13 : 18
T88	PTN	65640	89-11-14	13 : 19
T87	PTN	65640	89-11-14	13 : 19
T86	PTN	65640	89-11-14	13 : 20
T85	PTN	65640	89-11-14	13 : 20
T84	PTN	65640	89-11-14	13 : 21
T83	PTN	65640	89-11-14	13 : 22
T82	PTN	65640	89-11-14	13 : 22

Note: Refer to paragraph 5.10 (12).

(f) Actual stored data

The dump list of the data stored on a floppy disk is shown below. This data is for DATA pattern, data length = 512.


Dump Version 2.1.

```
00000000  00 00 00 00 31 2E 30 20-00 00 00 00 00 00 00 01
00000010  00 00 00 01 00 00 00 00-00 00 00 05 00 00 80 00
00000020  00 00 00 06 00 01 86 A0-00 00 00 10 00 00 00 02
00000030  00 00 00 01 00 00 00 06-00 00 00 01 00 00 00 01
00000040  00 00 00 01 00 00 02 00-00 00 00 01 00 00 00 01
00000050  00 00 00 20 00 00 00 01-00 00 00 03 00 00 00 01
00000060  00 00 00 20 00 00 00 01-00 01 00 02 00 04 00 08
00000070  00 10 00 20 00 40 00 80-01 00 02 00 04 00 08 01
00000080  10 00 20 00 40 00 7F FF-80 00 C0 00 E0 00 F0 01
00000090  F8 00 F0 00 FE 00 FF 00-FF 80 FF C0 FF E0 FF F0
000000A0  FF F8 FF FC FF FE FF FF-00 00 00 00 00 00 00 00
```

(12) Resave operation

The resave function performed by the MP1701B is shown below.

When file named 01 is resaved, the following operation sequence is performed.



Resave cannot be performed by the operation above if the free space on the floppy disk is not equal to, or greater than, the size of the file to be resaved.

That is, for paragraph 5.10 (11) (e), since the free space on the floppy disk is only 52 224 bytes, a 65 640-byte file cannot be resaved.

(13) Key operation during floppy disk accessing

While the floppy disk is accessed in the following operations,

- SAVE
- RESAVE
- RECALL
- DELETE
- FORMATTING
- DIRECTORY SEARCH

keys and knobs are almost in the same condition as panel lock and remain in the locked state up to the end of access.

(14) Notes on floppy-disk handling

Please pay careful attention to the following points.

- Do not remove the floppy disk from equipment being accessed.
- Observe the specified environmental conditions. Also, do not use the equipment in a dusty place.
- Keep magnetic objects away from the disk. Do not bend the disk.
- Insert the head protection sheet into the disk slot when moving the equipment.
- Files saved via the MP1701B Pulse Pattern Generator cannot be loaded into the MP1702A or any other instrument.

5.11 External Pattern Input

The MP1701B can be used as an 8:1 multiplexer by inputting external patterns to the rear 1/8 SPEED EXTERNAL DATA INPUT connector (34). An example is shown in Fig. 5-11.




Fig. 5-11 External Pattern Input Setup

Set the CH SELECT switch of the channel to be input from the outside, to the EXT position.

The input level is ECL level (50Ω , -2 V termination).

The relation between external input data and final output is shown in Fig. 5-12. Match the phases of the external input data as shown in Fig. 5-13.





Fig. 5-12 External Input Data and Final Output

Each 1/8 DATA
Input



1/8 CLOCK
Output



$$(9.6 - \frac{8 \times 10^9}{f}) \text{ ns} \leq t \leq 9.2 \text{ ns}$$

f: Fundamental clock frequency [Hz]

Fig. 5-13 External Pattern Input Data Phase Matching

5.12 Parameters Initialization

When desiring to set the pattern type, amplitude, offset voltage, and other setting conditions to the factory-settings, turn on the POWER switch #1 while pressing [LOCAL] #2.

This initializes the settings. The initial state is shown in Table 5-4,

Table 5-4 Initial State

Item	Initial setting
CLOCK	INT
FREQUENCY	10 000 000 kHz
TUNING	ON
MEMORY	00 (PTN mode, FILE NO. mode)
PATTERN	PRBS 2 ¹⁵ - 1
MARK RATIO	1/2
LOGIC	POS
ERROR ADDITION	OFF
OFFSET	V _{OH}
DISPLAY	1/1 SPEED
DATA/DATA TRACKING	OFF
DATA AMPLITUDE	1.000 V _{p-p}
DATA OFFSET	0.000 V
$\overline{\text{DATA}}$ AMPLITUDE	1.000 V _{p-p}
$\overline{\text{DATA}}$ OFFSET	0.000 V
CLOCK1 AMPLITUDE	1.000 V _{p-p}
CLOCK1 OFFSET	0.000 V
CLOCK1 DELAY TIME	0 ps
1/4 DATA AMPLITUDE	1.000 V _{p-p}
1/4 DATA OFFSET	0.000 V
1/4 CLOCK AMPLITUDE	1.000 V _{p-p}
1/4 CLOCK OFFSET	0.000 V

(Blank)

SECTION 6

PRINCIPLES OF OPERATION

6.1 Block Diagram

The MP1701B block diagram is shown in Fig. 6-1.

6.2 Internal Clock Generator (A1)

The clock generator is a synthesized clock generator consisting of PLL circuits with a 10 MHz crystal oscillator as the reference signal.

6.3 Programmable Pattern Generator (A8)

The programmable pattern setting data is stored in RAM.

This RAM has 128 outputs. These outputs are multiplexed sequentially at later stages and are finally converted into one serial output.

6.4 Pseudorandom Pattern Generator (A11)

A PRBS generation LSI generates 32 patterns.

These 32 patterns are multiplexed at later stages and are finally converted into one PRBS pattern.

The PRBS pattern generation principle is shown in Table 6-1. The mark ratio 1/4 and 1/8 pattern generation circuit is shown in Fig. 6-2.

Generally, a PRBS pattern with a period of 2^N-1 bits has one N-bit continuous "1" pattern per period.

Since an inverter circuit is inserted at the final stage as shown in Fig. 6-2, when LOGIC is set to POS (positive logic), DATA output "1" corresponds to low level and "0" corresponds to high level.











Fig. 6-1 MP1701B Block Diagram

Table 6-1 Pseudorandom Pattern Generation Principle

Period	Generaton polynominal	Pattern Generation Block Diagram
$2^7 - 1$	$1 + X^6 + X^7$	
$2^9 - 1$	$1 + X^5 + X^9$	
$2^{11} - 1$	$1 + X^9 + X^{11}$	
$2^{15} - 1$	$1 + X^{14} + X^{15}$	
$2^{20} - 1$	$1 + X^3 + X^{20}$	
$2^{23} - 1$	$1 + X^{18} + X^{23}$	
$2^{31} - 1$	$1 + X^{28} + X^{31}$	




Fig. 6-2 Mark Ratio 1/4, 1/8 Pattern Generator

6.5 Pattern Sync Output Period

6.5.1 Pseudorandom pattern

$$\text{Period} = [1/(\text{set frequency})] \times (2^N - 1) \times 32$$

$$N = 7, 9, 11, 15, 20, 23, 31$$

$$\text{where, plus pulse with pulse width} = [1/(\text{set frequency})] \times 32$$

6.5.2 Programmable pattern

(1) Data mode

(a) When data length is 4096 or less

$$\text{Period} = [1/(\text{set frequency})] \times (\text{least common multiple between 128 and data length})$$

(Examples)

1. When data length is 8.

$$\text{Period} = [1/(\text{set frequency})] \times 128$$

2. When data length is 10.

$$\text{Period} = [1/(\text{set frequency})] \times 640$$

(b) When data length exceeds 4096

$$\text{Period} = [1/(\text{set frequency})] \times (\text{data length})$$

(2) Word mode

Because $(\text{word length}) \times (\text{number of words}) = \text{data length}$, the pattern sync output period is the same as that described in paragraph (1) Data mode.

(3) Pulse width

For all the program patterns, the pulse width = $[1/(\text{set frequency})] \times 64$.

The output signal polarity is plus pulse.

6.6 1/4 Data Output and 1/4 Clock Output


For MUX IC test, etc., a 1/4-speed clock and 4-channel data output are provided. Each data channel signal can be output independently. (However, for the programmable pattern, the maximum capacity per channel is 128k bits.)

The pattern sequence for programmable pattern is shown in Table 6-2. The pattern sequence for the pseudorandom pattern is shown in Fig. 6-3.

Table 6-2 1/4 Data Output Pattern Sequence

DATA output on front panel (Serial)		1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24																								Max. 524 288 bits
		1 0 0 1				0 1 1 1				0 0 1 1				1 0 1 0				1 1 0 0				0 1 1 1				
Output on rear panel (parallel)	1	1			0			0			1			1			0									
	2	0			1			0			0			1			1									
	3	0			1			1			1			0			1									
	4	1			1			1			0			0			1									
			1 bit				2 bit				3 bit				4 bit				5 bit				6 bit			

Note: The pattern set on the front panel are set every 4 bits for each channel.



Note: $2^N/4 = 8192$ bits at PRBS $2^{15}-1$

Fig. 6-3 Pseudorandom Pattern Sequence

(Blank)

SECTION 7 PERFORMANCE TEST

7.1 Introduction

When performing performance tests at receiving inspection, routine tests, operation check after repair, etc., proceed as described below.

Routine tests should be performed at least once every year.

7.2 Equipment Required

The equipment required to perform the performance tests are shown in Table 7-1.

Table 7-1

No.	Equipment name	Main performance	Test item
1	MF76A Microwave Frequency Counter	10 Hz to 18 GHz	Frequency accuracy
2	MS612A Spectrum Analyzer	Up to 5.5 GHz	SSB phase noise
3	Synthesized signal generator (SG)	Up to 6 GHz SSB phase noise: -90 dBc/Hz or less (at 10 kHz offset)	SSB phase noise.
4	Mixer	RF and LO frequencies: 5 to 10 GHz IF output frequency: 0.4 to 5 GHz	SSB phase noise
5	Sampling oscilloscope	<ul style="list-style-type: none"> • Normal mode Frequency band: up to 12.4 GHz or 18 GHz Rise time: ≤ 28.2 ps or ≤ 19.4 ps • Averaging mode Frequency band: up to 20 GHz or 34 GHz Rise time: ≤ 17.5 ps or ≤ 10.3 ps 	Amplitude Offset voltage Rise/fall time Waveform distortion, jitter
6	Trigger count down	Up to 18 GHz	Jitter
7	MP1702A Error Detector	50 MHz to 10 GHz	Pattern

7.3 Performance Test

CAUTION: *Ground the equipment to be setup (including the device under test) and discharge the outer and inner conductors of the cables with a piece of metal before setup (paragraphs 2.5 and 4.1).*

7.3.1 Internal clock generator frequency accuracy

(1) Specifications

Frequency accuracy: $\leq \pm 1$ ppm

(2) Setup




Fig. 7-1 Setup

(3) Procedure

Step	Procedure
1	Set the MP1701B clock selector key (4) to INT.
2	Set the frequency to 10 GHz.
3	Set the MF76A INPUT SELECT to INPUT2.
4	Set the MF76A FUNCTION to MANUAL and input the approximate frequency to be measured (10 GHz here) from the ten key pad.
5	Read the MF76A measured value and compare it to the rating.
6	Change the MP1701B frequency and repeat steps 4 and 5 at each frequency

7.3.2 Internal clock generator SSB phase noise

(1) Specifications

SSB phase noise (10 kHz offset, bandwidth 1 Hz)

- ≤ -85 dBc (< 4 GHz)
- ≤ -80 dBc (4 to 8 GHz)
- ≤ -75 dBc (≥ 8 GHz)

(2) Setup




Fig. 7-2 Setup (5.5 GHz to 10 GHz)




Fig. 7-3 Setup (50 MHz to 5.5 GHz)

(3) Procedure

Step	Procedure
1	Set up the equipment as shown in Fig. 7-2 and set the MP1701B frequency to 10 GHz.
2	Set the synthesized SG frequency to 5.1 GHz.
3	Set the MS612A center frequency to $(10 \text{ GHz} - 5.1 \text{ GHz} + 10 \text{ kHz}) = 4.900 \text{ 01 GHz}$.
4	Set the MS612A frequency span to 20 kHz, resolution bandwidth (RBW) to 300 Hz, and video bandwidth (VBW) to 10 Hz.
5	Using the marker, read the difference between the levels at 4.900 01 GHz and 4.900 00 GHz using the MS612A. When this level difference is made XdB, the SSB phase noise can be obtained from the following equation: SSB phase noise = $X - 10 \log_{10} \left(\frac{300 \times 1.2}{\text{Correction coefficient}} + 2.5 \right)$ <div style="display: flex; justify-content: center; gap: 100px; margin-top: 10px;"> <div style="text-align: center;"> \uparrow RBW </div> <div style="text-align: center;"> \uparrow Correction coefficient </div> <div style="text-align: center;"> \uparrow Correction coefficient </div> </div>
	Example: When $X = -65\text{dB}$, SSB phase noise becomes -88.06 dBc/Hz
6	Change the MP1701B frequency and perform the same test. At this time, set the MS612A center frequency based on the following equation: MS612A center frequency = (MP1701B set frequency) - (synthesized SG frequency) + 10 kHz Note: Select the synthesized SG frequency so that the above center frequency can be set with the MS612A.
7	When testing at 50 MHz to 5.5 GHz, set up the equipment as shown in Fig. 7-3.
8	Read the difference (assumed as X dB) between the levels at (MP1701B set frequency + 10 kHz) and at the MP1701B set frequency, and obtain the SSB phase noise as in step 5.

7.3.3 DATA, $\overline{\text{DATA}}$, 1/4DATA rise and fall times

(1) Specifications

DATA, $\overline{\text{DATA}}$ tr, tf $\cong 30$ ps

1/4DATA tr, tf $\cong 200$ ps




Fig. 7-4 Rise/Fall Time

(2) Setup




Fig. 7-5 Setup

(3) Procedure

Step	Procedure
1	Adjust the sampling oscilloscope trigger level to synchronize the waveform.
2	Set the MP1701B output pattern to PRBS 2 ¹⁵ -1.
3	Measure the DATA tr and tf in accordance with Fig. 7-4.
4	Change the MP1701B frequency, amplitude, and offset voltage, and measure the DATA tr and tf.
5	Change the connection to $\overline{\text{DATA}}$ and measure tr and tf similarly.
6	Change the connection to 1/4DATA1 to 4 and measure each tr and tf similarly.

7.3.4 DATA, $\overline{\text{DATA}}$, 1/4DATA amplitude and offset voltage

(1) Specifications

DATA, $\overline{\text{DATA}}$ amplitude

0.5 to 2 V_{p-p}, 10 mV steps

Setting error: $\leq \pm 15\%$ or ± 100 mV, whichever is greater

DATA, $\overline{\text{DATA}}$ offset voltage

-2 to +2 V (V_{OH}), 5 mV steps

Setting error: $\leq \pm 15\%$, ± 100 mV or $\pm 15\%$ of amplitude, whichever is greatest.

1/4DATA amplitude

0.5 to 1 V_{p-p}, 10 mV steps

Setting error: $\leq \pm 15\%$ or ± 100 mV, whichever is greater

1/4DATA offset voltage

-1.5 to +1.5 V (V_{OH}), 5 mV steps

Setting error: $\leq \pm 150$ mV




Fig. 7-6 Amplitude and Offset Voltage

(2) Set up

The setup is the same as that in paragraph 7.5.3 (2) and is shown in Fig. 7-5.

(3) Procedure

Step	Procedure
1	Calibrate the sampling oscilloscope vertical axis sensitivity.
2	Adjust the sampling oscilloscope trigger level to synchronize the waveform.
3	Set the MP1701B output pattern to PRBS 2 ¹⁵ -1.
4	Set the MP1701B OFFSET reference value to V _{OH} .
5	Measure the DATA amplitude and offset voltage (V _{OH}) in accordance with Fig. 7-6 and check if the error from the set value is within the specifications.
6	Change the connection to <u>DATA</u> and 1/4DATA1 to 4 and check similarly.

7.3.5 DATA, DATA jitter

(1) Specifications

DATA, DATA jitter

≤ 25 ps




Fig. 7-7 Jitter

(2) Setup




Fig. 7-8 Setup

(3) Procedure

Step	Procedure
1	Adjust both the sampling oscilloscope trigger level and trigger-count-down trigger level to minimize CLOCK1 jitter.
2	Set the MP1701B output pattern to PRBS 2 ¹⁵ -1.
3	Measure the DATA jitter in accordance with Fig. 7-7.
4	Change the connection to <u>DATA</u> and measure similarly.

7.3.6 1/4DATA jitter

(1) Specifications

1/4DATA ≤ 100 ps

(2) Setup




Fig. 7-9 Setup

(3) Procedure

Step	Procedure
1	Adjust both the sampling oscilloscope trigger level and trigger-count-down trigger level to minimize jitter.
2	Set the MP1701B output pattern to PRBS 2 ¹⁵ -1.
3	Measure the 1/4DATA1 jitter in accordance with Fig. 7-7.
4	Change the connection to 1/4DATA2 to 4 and measure similarly.

7.3.7 CLOCK1, $\overline{\text{CLOCK1}}$, CLOCK2, 1/4CLOCK rise and fall times

(1) Specifications

CLOCK, $\overline{\text{CLOCK1}}$, CLOCK2 tr, tf

≤ 30 ps (≥ 5 GHz)

≤ 50 ps (< 5 GHz)

1/4CLOCK tr, tf ≤ 200 ps




Fig. 7-10 Rise and Fall Times

(2) Setup




Fig. 7-11 Setup

(3) Procedure

Step	Procedure
1	Adjust the sampling oscilloscope trigger level to synchronize the waveform.
2	Set the sampling oscilloscope mode to average and the bandwidth to 20 GHz (or 34 GHz).
3	Measure the $\overline{\text{CLOCK1}}$ tr and tf in accordance with Fig. 7-10.
4	Change the connection to $\overline{\text{CLOCK1}}$, $\overline{\text{CLOCK2}}$, and $\overline{1/4\text{CLOCK}}$ and measure tr and tf similarly.

7.3.8 CLOCK1, $\overline{\text{CLOCK1}}$, CLOCK2, 1/4CLOCK amplitude and offset voltage

(1) Specifications

CLOCK1, $\overline{\text{CLOCK1}}$ amplitude

0.5 to 2 V_{p-p}, 10 mV steps

Setting error: $\leq \pm 15\%$ or ± 100 mV, whichever is greater

CLOCK1, $\overline{\text{CLOCK1}}$ offset voltage

-2 to +2 V (V_{OH}), 5 mV steps

Setting error: $\leq \pm 15\%$, ± 100 mV or $\pm 15\%$ of amplitude, whichever is greatest

CLOCK2 amplitude

2 V_{p-p}, $\leq \pm 15\%$

CLOCK2 offset voltage

0, $\leq \pm 300$ mV

1/4CLOCK amplitude

0.5 to 1 V_{p-p}, 10 mV steps

Setting error: $\leq \pm 15\%$ or ± 100 mV, whichever is greater

1/4CLOCK offset voltage

-1.5 to +1.5 V (V_{OH}), 5 mV steps

Setting error: $\leq \pm 150$ mV




Fig. 7-12 Amplitude and Offset Voltage

(2) Setup

The setup is the same as that in paragraph 7.3.7 (2) and is shown in Fig. 7-11.

(3) Procedure

Step	Procedure
1	Adjust the sampling oscilloscope trigger level to synchronize the waveform.
2	Set the sampling oscilloscope mode to average and the bandwidth to 20 GHz (or 34 GHz).
3	Measure the CLOCK1 amplitude and offset voltage in accordance with Fig. 7-12.
4	Apply the sampling oscilloscope frequency characteristic correction value to the measured value.

Note: A typical sampling oscilloscope frequency characteristic is shown in Fig. 7-13.




Fig. 7-13 Typical Sampling Oscilloscope Frequency Characteristic

For example, at 10 GHz, since the correction value is -1 dB, the true amplitude is 1.122 times the measured value (1 dB) higher. The true offset voltage is the sum of the measured offset voltage and the measured amplitude multiplied by $(1.122 - 1)/2 = 0.061$. This relation is shown in Fig. 7-14.

Step	Procedure
------	-----------

4
(Cont.)




Fig. 7-14 True Amplitude and Offset Voltage

5 Change the connection to CLOCK1, CLOCK2, and 1/4CLOCK and measure similarly.

7.3.9 Pattern

(1) Specifications

Pseudorandom pattern

Pattern length: $2^N - 1$, $N = 7, 9, 11, 15, 20, 23, 31$

Mark ratio: $0/8, 1/8, 1/4, 1/2$ ($8/8, 7/8, 3/4, 1/2$ also possible by logic inversion)

Programmable pattern

- Data mode

Data length: 2 to 524 288 bits (128 bit steps for more than 4096 bits)

- Word mode

Word length: 2 to 16 bits

Number of words: 1 to 32 768 [When (word length) \times (number of words) exceeds 4096, (word length) \times (number of words) becomes a multiple of 128.]

(2) Setup





Fig. 7-15 Setup

(3) Procedure

Step	Procedure
1	Initialize the MP1701B.
2	Initialize the MP1702A.
3	Adjust the MP1702A CLOCK PHASE and check if the SYNC LOSS and ERRORS lamps are turned off.
4	Check that the MP1702A ERRORS lamp does not light when MP1701B and MP1702A PRBS PATTERN are changed as follows, 2 ⁷ -1, 2 ⁹ -1, 2 ¹¹ -1, 2 ²⁰ -1, 2 ²³ -1, and 2 ³¹ -1.
5	Check that the MP1702A ERRORS lamp does not light when MP1701B and MP1702A MARK RATIO are changed as follows, 1/2, 1/4, 1/8, 7/8, 3/4, and $\overline{1/2}$.
6	Set the MP1701B and MP1702A PATTERN to the DATA mode and DATA LENGTH to 524 288 bits. Set the MP1701B BIT appropriately and the MP1702A FRAME SYNC to ON and check if the MP1702A SYNC LOSS and ERRORS lamps go off.
7	Set MP1701B and MP1702A PATTERN to the WORD mode, WORD LENGTH to 16 bits, and NUMBER OF WORDS to 32 768. Set the MP1701B BIT appropriately and check that the MP1702A SYNC LOSS and ERRORS lamps go off.

Anritsu Service and Sales offices



• Argentina

MULTIRADIO S.A.

Av. Cordoba, 4860 Buenos Aires,
C1414BAT, Argentina
TEL: +55-4779-5522
FAX: +55-4779-5510

• Brazil

ANRITSU ELETRÔNICA LTDA.

Praia de Botafogo 440, Sala 2401-Bota
CEP 22250-040, Rio de Janeiro, RJ, Brazil
TEL: +55-21-5276922
FAX: +55-21-537-1456

ANRITSU ELETRÔNICA LTDA.

(SÃO PAULO BRANCH OFFICE)

Praça Amadeu Amaral 27, Primeira Andar,
Conj. 11, 12, 13, 14, Liberdade, São
Paulo, SP, Brazil CEP 01327-010
TEL: +55-11-283-2511
FAX: +55-11-288-6940

• Canada

ANRITSU ELECTRONICS LIMITED

(OTTAWA OFFICE)

700 Silver Seven Road, Suite 120, Kanata,
ON K2V 1C3, Canada
TEL: +1-613-591-2003
FAX: +1-613-591-1006

ANRITSU ELECTRONICS LIMITED

(TORONTO OFFICE)

4-6810 Kitimat Road, Mississauga, Ontario
L5N 5M2, Canada
TEL: +1-905-286-1207
FAX: +1-905-286-1215

ANRITSU ELECTRONICS LIMITED.

(MONTREAL OFFICE)

200-1405 Trans-Canada Highway, Dorval,
Quebec, H9P 2V9, Canada
TEL: +1-514-421-3737
FAX: +1-514-685-9839

ANRITSU ELECTRONICS LIMITED

(CALGARY OFFICE)

Deerfoot Atrium, 6715-8th Street N.E.,
Ste 129 Calgary, Alberta T2E 7H7,
Canada
TEL: +1-403-275-9855
FAX: +1-403-275-3609

• Chile

SISTEMAS DE INSTRUMENTACION LTDA.

Concha y Toro 65, Stgo Centro
Santiago, Chile 51880
TEL: +56-2-6960031
FAX: +56-2-6969665

• Colombia

RENTAMETRIC LTDA.

Calle 24 No. 32-67, Apartado: 23030
Santafe de Bogota, D.C. Colombia
TEL: +57-1-269-6555
FAX: +57-1-269-0191

• Costa Rica

ELECTRONIC ENGINEERING S.A.

200 metros norte Mall San Pedro, P.O.
Box 10146-1000 San Jose, Costa Rica
TEL: +506-283-3033
FAX: +506-225-1286

SONIVISION, S.A.

P.O. Box 620-1000, San Jose, Costa Rica
TEL: +506-231-5685
FAX: +506-231-6531

• Ecuador

EQUITRONICS S.A.

Belgica N-32 Hy Av. De Los Shyris,
Edificio IVSEMON PARK, Suite 4B, Quito,
Ecuador
TEL: +593-2-255-396
FAX: +593-2-255-396

• El Salvador

EMPRESA DE COMERCIO EXTERIOR S.A. DE C.V.

Centro Comercial Feria Rosa, Alameda
Dr. Manuel Enrique Araujo, Edificio H,
Local 315 San Salvador, El Salvador
TEL: +503-243-3924
FAX: +503-243-3925

• Guatemala

IMPELSA.

17 Calle 31-86 Zona 7, Villa Linda II,
Apartado Postal 482-1 Guatemala,
Guatemala
TEL: +502-594-9977
FAX: +502-594-9468

• Mexico

SIHIKATRONICS mmWAVE S.A. DE C.V.

Luz Savion 9-602 Col. Del Valle Mexico
D.F. 03100, Mexico
TEL: +52-5-5437313
FAX: +52-5-5437317

• Panama

SUMINISTROS INDUSTRIALES, S.A.

P.O. Box 2789 Balboa, Republic of
Panama
TEL: +507-270-2328
FAX: +507-270-2329

• Paraguay

DATALAB S.R.L.

Avda. Artigas No 1645 Edificio "DataLab"
Asuncion, Paraguay
TEL: +595-21-20-9126
FAX: +595-21-20-9127

• Peru

SAKATA INGENIEROS S.A.

AV Canaval Moreyra 748, San Isidro,
Lima 27, Peru
TEL: +51-1-224-2514
FAX: +51-1-224-8148

• U.S.A.

ANRITSU COMPANY

NORTH AMERICAN REGION OPERATIONS HEADQUARTERS, SALES AND SERVICE

1155 East Collins Blvd., Richardson,
TX 75081, U.S.A.
Toll Free: 1-800-ANRITSU (267-4878)
TEL: +1-972-644-1777
FAX: +1-972-671-1877

ANRITSU COMPANY

CORPORATE OFFICES

490 Jarvis Drive, Morgan Hill,
CA 95037-2809, U.S.A.
Toll Free: 1-800-ANRITSU (267-4878)
TEL: +1-408-778-2000
FAX: +1-408-776-1744

ANRITSU COMPANY

SALES AND SERVICE, NJ OFFICE

10 New Maple Avenue, Unit 305,
P. O. Box 836,
Pine Brook, NJ 07058-0836, U.S.A.
Toll Free: 1-800-ANRITSU (267-4878)
TEL: +1-973-227-8999
FAX: +1-973-575-0092

ANRITSU COMPANY

SALES AND SERVICE, FL OFFICE

312 W. First Street, Suite 300, Sanford,
FL 32771, U.S.A.
Toll Free: 1-800-ANRITSU (267-4878)
TEL: +1-407-321-5130
FAX: +1-407-330-2018

ANRITSU COMPANY

SALES AND SERVICE, GA OFFICE

4625 Alexander Drive, Alpharetta,
GA 30022, U.S.A.
Toll Free: 1-800-ANRITSU (267-4878)
TEL: +1-678-566-0454
FAX: +1-678-566-1776

• Uruguay

CABONORTE S.A.

Colonia 1900, Esc. 603, Montevideo,
Uruguay
TEL: +598-2-430522
FAX: +598-2-418594

• Venezuela

RADIOCOMUNICACIONES CRUZ, C.A.

Calle La Colina Quinta. Elison, Frente al
teatro Alberto Mateo Caracas 1050,
Venezuela
TEL: +58-2-793-2322
FAX: +58-2-793-3429

Europe

• Austria

WIEN-SCHALL GmbH

Krichbaumgasse 25, A-1120 Vienna,
Austria

TEL: +43-1-81155140

FAX: +43-1-81155180

• Belgium

ANRITSU GmbH

Grafenberger Allee 54-56, 40237
Düsseldorf, Germany

Local phone: 0800-90001 (toll free)

TEL: +49-211-96855-0

FAX: +49-211-96855-55

• Bulgaria

ELSINCO Representation OFFICE Sofia

h.e. Strelbishte, str. Kotlenski Prohod,
bl. 96/6/14, BG-1408 Sofia, Bulgaria

TEL: +359-2-958-1245

FAX: +359-2-958-1698

• Croatia

ELSINCO REPRESENTATION OFFICE ZAGREB

Korculanska 3A, HR-10000 Zagreb,
Croatia

TEL: +385-1-618-1448

FAX: +385-1-618-1449

• Czech Republic

ELSINCO PRAHA SPOL S.R.O.

Novodvorská 994, CZ-142 21 Praha,
4-Branik, Czech Republic

TEL: +420-2-4149-0147

FAX: +420-2-4447-2169

ELSINCO PRAHA SPOL S.R.O. (BRNO BRANCH OFFICE)

Strmá 19, CZ-616 00 Brno, Czech
Republic

TEL: +420-5-4142-7211

FAX: +420-5-4142-7219

• Denmark

ANRITSU AB

(DENMARK BRANCH OFFICE)

Tonsbakken 10, DK 2740, Skovlunde,
Denmark

TEL: +45-44502160

FAX: +45-44502170

• Finland

ANRITSU AB

(FINLAND BRANCH OFFICE)

Piispanportti 9, FIN-02240 Espoo, Finland

TEL: +358-9-435-522-0

FAX: +358-9-435-522-50

• France

ANRITSU S.A.

9, Avenue du Québec Z.A. de
Courtabœuf, 91951 Les Ulis Cedex,
France

TEL: +33-1-60-92-15-50

FAX: +33-1-64-46-10-65

ANRITSU S.A.

(TOULOUSE OFFICE)

Bureau de Toulouse Région Centre Sud
Ouest, France

TEL: +33-5-62070484

FAX: +33-5-62070668

ANRITSU S.A.

(TOULON OFFICE)

Bureau de Toulon Région Centre Sud Est,
France

TEL: +33-4-94040264

FAX: +33-4-94040265

ANRITSU S.A.

(RENNES OFFICE)

Bureau de Rennes Région Ouest, France

TEL: +33-2-99521214

FAX: +33-2-99521224

• Germany

ANRITSU GmbH

Grafenberger Allee 54-56, 40237
Düsseldorf, Germany

TEL: +49-211-96855-0

FAX: +49-211-96855-55

ANRITSU GmbH

(SALES CENTER SOUTH)

An der Steinernen Brücke 1, 85757
Karlsfeld, Germany

TEL: +49-8131-3825-0

FAX: +49-8131-3825-95

• Greece

KOSTAS KARAYANNIS SA

58 Kapodistriou str, GR-142 35 Nea Ionia,
Athens, Greece

TEL: +30-1-680-0460-4

FAX: +30-1-685-3522

• Hungary

ELSINCO BUDAPEST KFT

Pannónia utca 8. IV/l., H-1136 Budapest,
Hungary

TEL: +36-1-339-0000

FAX: +36-1-339-4444

• Ireland

PEMA LTD.

Dromiskin, Dundalk, Co. Louth, Ireland

TEL: +353-42-72899

FAX: +353-42-72376

• Italy

ANRITSU S.p.A.

Via Elio Vittorini, 129, 00144 Roma EUR,
Italy

TEL: +39-06-509 9711

FAX: +39-06-502-24-25

ANRITSU S.p.A.

(Milano OFFICE)

C.D. Colleoni, Via Paracelso, 4 20041

AGRATE B.ZA (MI), Italy

TEL: +39-039-605-7021

FAX: +39-039-605-63-96

• Netherlands

C.N.ROOD BV

Blauwroodlaan 280 2718 SK Zoetermeer,
The Netherlands

TEL: +31-79-360 00 18

FAX: +31-79-362-81-90

• Norway

ANRITSU AB

(NORWAY BRANCH OFFICE)

Leangbukta 40 1370 Asker, Norway

MAIL: Postboks 188, 1371 Asker, Norway

TEL: +47-66-901190

FAX: +47-66-901212

• Poland

ELSINCO POLSKA SP. Z.O.O

ul Gdanska 50, 01-691 Warszawa, Poland

TEL: +48-22-39-832-4042 (Sat Link)

FAX: +48-22-832-2238

• Slovakia

ELSINCO SLOVENSKO S.R.O

Kudláková 4, SK-844 15 Bratislava,
Slovakia

TEL: +421 7 6428 41 65

FAX: +421 7 6428 44 54

ELSINCO SLOVENSKO S.R.O

(KOŠICE BRANCH OFFICE)

Floriánska 16, SK-043 13 Kosice, Slovakia

TEL: +421 95 62 26 729

FAX: +421 95 62 26 729

CONTACT: Mr. Igor Domorak,

Branch Office Manager

• Slovenia

ELSINCO D.O.O.

Dalmatinova 2, SI-1000 Ljubljana,
Slovenia

TEL: +386-61-133-62-77

FAX: +386-61-317-397

• Spain

ANRITSU ELECTRÓNICA, S.A.

Europa Empresarial Edificio Londres.

Planta 1. Oficina 6 C/ Playa de Liencres, 2
28230 Las Rozas. Madrid, Spain

TEL: +34-91-6404460

FAX: +34-90-6404461

• Sweden

ANRITSU AB

Botvid Center, Fittja Backe 1-3 145

84, Stockholm, Sweden

TEL: +46-8-534-70700

FAX: +46-8-534-70730

• **Switzerland**

GIGACOMP AG

Gewerbezone Laetti CH-3053
Muenchenbuchsee, Switzerland
TEL: +41-31-868-44-55
FAX: +41-31-868-44-50

• **United Kingdom**

ANRITSU LTD.

200 Capability Green, Luton, Bedfordshire,
LU1 3LU, United Kingdom
TEL: +44-1582-433200
FAX: +44-1582-731303

**ANRITSU LTD.
(MANCHESTER OFFICE)**

Landmark House, Station Road, Cheadle
Hulme, Cheshire SK8 7BS, United
Kingdom
TEL: +44-161-488-4990
FAX: +44-161-486-9064

**ANRITSU LTD.
(BRISTOL OFFICE)**

1230 Aztec West, Almondsbury, Bristol
BS12 4SG, United Kingdom
TEL: +44-1454-615252
FAX: +44-1454-618017

**ANRITSU LTD.
(LIVINGSTON OFFICE)**

Unit 1, Knightsridge Industrial Estate,
Turnbull Way, Knightsridge,
Livingston EH54 8RB, United Kingdom
TEL: +44-1506-436111
FAX: +44-1506-436112

**ANRITSU LTD.
(HERTS OFFICE)**

Rutherford Close, Stevenage, Herts SG1
2EF, United Kingdom
TEL: +44-1438-740011
FAX: +44-1438-740202

**Asia, Pacific
and Africa**

• **Australia**

ANRITSU PTY LTD.

Unit 3/170 Forster Road, Mount. Waverley,
Vic., 3149, Australia
TEL: +61-3-9558-8177
FAX: +61-3-9558-8255

**ANRITSU PTY. LTD.
(SYDNEY BRANCH OFFICE)**

Suite 21/1A Ashley Lane,
Westmead NSW 2145, Australia
TEL: +61-2-9635-0800
FAX: +61-2-9635-0899

• **Bahrain**

BASMATECH

P. O. Box 5701, Manama, Bahrain
TEL: +973-273729
FAX: +973-725404

• **China**

ANRITSU COMPANY LTD.

(HONG KONG OFFICE)

Suite 719, 7/F, Chinachem Golden Plaza,
77 Mody Road, Tsimshatsui East,
Kowloon, P.R. China
TEL: +852-2301-4980
FAX: +852-2301-3545

ANRITSU COMPANY LTD.

(BEIJING OFFICE)

Room No. 1515, Beijing Fourtune Building,
5 Dong-San-Huan-Bei-lu, Chao-Yang
District, Beijing 100004, P.R. China
TEL: +86-10-6590-9230 to 9234
FAX: +86-10-6590-9235

ANRITSU COMPANY LTD.

(SHANGHAI OFFICE)

No. 511, Shanghai Jing Tai Building, No.
58 Mao Ming Non Road, Shanghai, P.R.
China
TEL: +86-21-6415-5137 to 5138
FAX: +86-21-6472-6677

ANRITSU COMPANY LTD.

(GUANGZHOU OFFICE)

Room 3008-9, 7/F 30/F., Dongshan Plaza,
69 XianLie Zhong Road, Central,
Guangzhou 510095, P.R. China
TEL: +86-20-8732-2231
FAX: +86-20-8732-2230

ANRITSU COMPANY LTD.

(CHENGDU OFFICE)

Block E, 26/F., New Times Square (Xin
Shi Guang Chang), No. 42, Wen Wu Lu,
XinHua Street Chengdu, 610017, P.R.
China
TEL: +86-28-651-0011, 0022, 0033
FAX: +86-28-651-0055

ANRITSU COMPANY LTD.

(XI'AN OFFICE)

No. 2104, Hua Yuan Building Gao Xin
Road II, High-Technic Development Zone,
Xi'an 710075, P.R. China
TEL: +86-29-8484465, 8479813, 8472712
FAX: +86-29-8484455

ANRITSU COMPANY LTD.

(SHENZHEN OFFICE)

Room 1505, Building A, World Trade
Plaza,
Fuhong Rd., Shenzhen 518033, P.R.
China
TEL: +86-755-366-2848, 2847
FAX: +86-755-366-2849

ANRITSU COMPANY LTD.

(CHONGQING OFFICE)

Unit 9, 3F, Chongqing Marriott Hotel Office
Tower, Chongqing 400010, P.R. China
TEL: +86-23-6383-0218, 0228
FAX: +86-6383-0238

Anritsu Electronics (Shanghai)

CO.,LTD. (SERVICE OFFICE)

2F, Room B, 52 Section Factory Building
No.516 Fu Te Road (N)
Waigaoqiao Free Trade Zone
Pudong, Shanghai 200131, P.R. China
TEL: +86-21-5868-0688

ANRITSU COMPANY LTD.

(SHENYANG OFFICE)

Room 2-185, City Plaza Shenyang
206 Nanjing North Street, Heping District
Shenyang 110001 P.R. China
TEL: +86-24-23341178 / +86-24 23341799
FAX: +86-24-23342838

ANRITSU COMPANY LTD.

(WUHAN OFFICE)

ZhongNan Plaza A1803
No.9 ZhongNan Road, WuChang District
WuHan HuBei 430072 P.R. China
TEL: +86-2787713355
FAX: +86-2787713366

• **Cyprus**

CHRIS RADIOVISION LTD.

23 Crete Street, T.T. 1061
P. O. Box 21989, 1515Nicosia, Cyprus
TEL: +357-2-766121
FAX: +357-2-765177

• **Egypt**

GIZA SYSTEMS ENGINEERING S.A.E

17 Teeba Street Mohandeseen P.O. Box
317 Dokki-Cairo 12311, Egypt
TEL: +20-2-3368095
FAX: +20-2-3385799

• **Indonesia**

PT. SUBUR SAKTI PUTERA

Graha Astri Aniela Angun, Jl. Tanah
Abang III/15, Jakarta 10160, Indonesia
TEL: +62-21-352-4828
FAX: +62-21-352-4831

• **Israel**

TECH-CENT LTD.

P. O. Box 43259 (Mailing Address),
Tel-Aviv 61430 Israel, Street Address:
Raul Valenberg 4 Ramat Haahayal, Tel-
Aviv 69710, Israel
TEL: +972-36-478563
FAX: +972-36-478334

• **Korea**

ANRITSU CORPORATION LTD.

(SEOUL OFFICE)

14F Hyun Juk Bldg. 832-41, Yeoksam-
dong, Kangnam-ku, Seoul, 135-080, Korea
TEL: +82-2-553-6603
FAX: +82-2-553-6604 to 6605

ANRITSU CORPORATION LTD.

(DAEJEON OFFICE)

Room1503, Dong-a Officetel 538-8,
Bangmyung-Dong, Yusong-gu, Taejeon,
305-301, Korea
TEL: +82-2-828-7783
FAX: +82-2-828-7785

ANRITSU CORPORATION LTD.

(SERVICE CENTER)

8F Samwon-Bldg, 1329-8, Seocho-Dong,
Seocho-Ku, Seoul, 137-070, Korea
TEL: +82-2-581-6603
FAX: +82-2-582-6603

• **Kuwait**

TAREQ COMPANY

P.O. Box 20506 Safat, 13066 Safat,
Kuwait
TEL: +965-431-0615
FAX: +965-431-4085

• **Malaysia**

O'CONNOR'S ENGINEERING SDN BHD

3rd Floor Bangnan O'Connor, 13 Jalan
223, 46100 Petaling Jaya,
Selangor Darul Ehsan, Malaysia
TEL: +60-3-753-8400
FAX: +60-30-757-7871

• **Morocco**

SEDEL

24, 26, Bd, Resistance, Casablanca,
Morocco
TEL: +212-2-302444
FAX: +212-2-449311

• **Nepal**

BR INTERNATIONAL PVT. LTD.

P. O. Box 60, Tamrakar Comm. Bldg.,
Bhotabahal Kathmandu, Nepal
TEL: +977-1-224-706
FAX: +977-1-227-956

• **New Zealand**

**NILSEN TECHNOLOGIES
(AUCKLAND OFFICE)**

P. O. Box 9613, New market Unit 4,
Ambury Court, 1 Porters Ave, Eden
Terrace Auckland, New Zealand
TEL: +64-9-309-2464
FAX: +64-9-309-2968

**NILSEN TECHNOLOGIES
(WELLINGTON OFFICE)**

35 Ulric Street, Plimmerton Wellington,
New Zealand
TEL: +64-4-233-9116
FAX: +64-4-233-8366

• **Oman**

**NATIONAL PROJECTS AND
TECHNOLOGY COMPANY L.L.C**

P. O. Box 97, Wadi Al Kabir, Postal Code
117, Sultanate of Oman
TEL: +968-793741
FAX: +968-796158

• **Pakistan**

AETCO

Zia Chambers, 25-Mcleod road, Lahore
54000, Pakistan
TEL: +92-42-7221716, 7311035
FAX: +92-42-7221456

**SUPERIOR ELECTRONICS
ASSOCIATED**

B-98 Block H, North Nasimabad,
Karachi-33, Pakistan
TEL: +92-21-613655

• **Philippines**

**SALRITSU INTERNATIONAL TRADING
CORPORATION**

5QB ODC International Plaza
Condominium, 219 Salcedo St., Legaspi
Village, Makati City 1229, Philippines
TEL: +632-816-2646, 893-8998
FAX: +632-815-0986

• **Qatar**

QATAR COMMUNICATIONS LTD.

P. O. Box 2481, Doha Qatar
TEL: +974-4-424347
FAX: +974-4-324777

• **Saudi Arabia**

A. RAJAB & A. SILSILAH & CO.

P. O. Box 203, Jeddah 21411, Saudi
Arabia
TEL: +966-2-6610006
FAX: +966-2-6610558

**ELECTRONIC EQUIPMENT
MARKETING CO.**

P. O. Box 3750, Riyadh, 11481,
Saudi Arabia
TEL: +966-3-887-0218
FAX: +966-3-887-0268

• **Singapore**

ANRITSU PTE. LTD.

10, Hoe Chiang Road #07-01/02, Keppel
Towers, Singapore 089315
TEL: +65-6282-2400
FAX: +65-6282-2533

• **South Africa**

ETEC SA (PTY) LTD.

12 Surrey Square Office Park, 330 Surrey
Avenue, Ferndale, 2194 Randburg,
South Africa (P. O. Box 4231 Randburg,
2125 South Africa)
TEL: +27-11-787-7200
FAX: +27-11-787-0446

• **Sri Lanka**

INFOTECHS LIMITED

441, Alwitigala Mawatha, Colombo,
Sri Lanka
TEL: +94-1-598237
FAX: +94-1-598112

• **Taiwan**

**ANRITSU COMPANY, INC.
(TAIPEI OFFICE)**

6F, 96, Sec. 3, Chien Kou North Road,
Taipei, Taiwan
TEL: +886-2-2515-6050
FAX: +886-2-2509-5519

**ANRITSU COMPANY, INC.
(HSINCHU OFFICE)**

11F-3, 270, Sec. 1, Kuang-Fu Rd.,
Hsinchu, Taiwan R.O.C.
TEL: +886-3-563-6601, 6602, 6603
FAX: +886-3-564-5819

• **Thailand**

**JASMINE TELECOM SYSTEMS CO.,
LTD.**

200 Moo 4, 9th Floor, Chaengwatana
Road, Tambon Pakkret, Amphoe Pakkret,
Nonthaburi 11120, Thailand
TEL: +66-2-502-3240, 3000
FAX: +66-2-962-2521

• **Turkey**

**INTER INTRADE BILGISAYAR
ELEKTRONIK SAN. TIC. A.S.**

Egitim Mah. Poyraz Sok., Sadikoglu Is
Merkezi 1, No: 11, Kadikoy Istanbul,
Turkey
TEL: +90-216-4144758
FAX: +90-216-4144762

TEST

Sehit Adem Yavuz Sokak No. 14/15
06640, Kizilay-Ankara, Turkey
TEL: +90-312-419-3688
FAX: +90-312-419-4099

• **United Arab Emirates**

**UTMOST ELECTRONICS TRADING
L.L.C.**

(ABU DHABI BRANCH)

P. O. Box: 41175, Abu Dhabi,
United Arab Emirates
TEL: +971-2-6458909
FAX: +971-2-6458907

• **Vietnam**


**SYSTEM & TECHNOLOGIES VIETNAM
LTD.**

Unit # B236, Binh Minh Hotel 27 Ly Thai
To Str Hanoi, Vietnam
TEL: +84-48.264.728
FAX: +84-49.344.111

• **Zimbabwe**

MARTWELL ELECTRONICS (PVT) LTD.

P.O. Box CH 857 Chisipite Harare,
Zimbabwe
TEL: +263-4-494928
FAX: +263-4-494927



• **Japan**

ANRITSU CORPORATION

5-10-27 Minami-azabu, Minato-ku,
Tokyo 106-8570, Japan
TEL: +81-3-3446-1111
FAX: +81-3-3442-0235