



# **COMPONENT MAINTENANCE MANUAL WITH ILLUSTRATED PARTS LIST**

## **AILERON CONTROL TRANSFER MECHANISM ASSEMBLY**

**PART NUMBER  
251A1817-1, -2, -3**

**BOEING PROPRIETARY, CONFIDENTIAL, AND/OR TRADE SECRET**

Copyright © 1995 The Boeing Company  
Unpublished Work - All Rights Reserved

Boeing claims copyright in each page of this document only to the extent that the page contains copyrightable subject matter. Boeing also claims copyright in this document as a compilation and/or collective work.

This document includes proprietary information owned by The Boeing Company and/or one or more third parties. Treatment of the document and the information it contains is governed by contract with Boeing. For more information, contact The Boeing Company, P.O. Box 3707, Seattle, Washington 98124.

Boeing, the Boeing signature, the Boeing symbol, 707, 717, 727, 737, 747, 757, 767, 777, 787, Dreamliner, BBJ, DC-8, DC-9, DC-10, KC-10, KDC-10, MD-10, MD-11, MD-80, MD-88, MD-90, P-8A, Poseidon and the Boeing livery are all trademarks owned by The Boeing Company; and no trademark license is granted in connection with this document unless provided in writing by Boeing.

PUBLISHED BY BOEING COMMERCIAL AIRPLANES GROUP, SEATTLE, WASHINGTON, USA  
A DIVISION OF THE BOEING COMPANY  
PAGE DATE: Jul 01/2009

**27-16-08**

Page 1  
Jul 01/2009



## COMPONENT MAINTENANCE MANUAL

Revision No. 7  
Jul 01/2009

To: All holders of AILERON CONTROL TRANSFER MECHANISM ASSEMBLY 27-16-08.

Attached is the current revision to this COMPONENT MAINTENANCE MANUAL

The COMPONENT MAINTENANCE MANUAL is furnished either as a printed manual, on microfilm, or digital products, or any combination of the three. This revision replaces all previous microfilm cartridges or digital products. All microfilm and digital products are reissued with all obsolete data deleted and all updated pages added.

For printed manuals, changes are indicated on the List of Effective Pages (LEP). The pages which are revised will be identified on the LEP by an R (Revised), A (Added), O (Overflow, i.e. changes to the document structure and/or page layout), or D (Deleted). Each page in the LEP is identified by Chapter-Section-Subject number, page number and page date.

Pages replaced or made obsolete by this revision should be removed and destroyed.

### ATTENTION

IF YOU RECEIVE PRINTED REVISIONS, PLEASE VERIFY THAT YOU HAVE RECEIVED AND FILED THE PREVIOUS REVISION. BOEING MUST BE NOTIFIED WITHIN 30 DAYS IF YOU HAVE NOT RECEIVED THE PREVIOUS REVISION. REQUESTS FOR REVISIONS OTHER THAN THE PREVIOUS REVISION WILL REQUIRE A COMPLETE MANUAL REPRINT SUBJECT TO REPRINT CHARGES SHOWN IN THE DATA AND SERVICES CATALOG.

# 27-16-08

TRANSMITTAL LETTER

Page 1

Jul 01/2009

251A1817



## COMPONENT MAINTENANCE MANUAL

Location of Change

Description of Change

NO HIGHLIGHTS

**27-16-08**

HIGHLIGHTS

Page 1

Jul 01/2009



## COMPONENT MAINTENANCE MANUAL

Subject/Page	Date	Subject/Page	Date	Subject/Page	Date
TITLE PAGE		27-16-08 DISASSEMBLY		27-16-08 ASSEMBLY (cont)	
O 1	Jul 01/2009	301	Mar 01/2006	710	BLANK
2	BLANK	302	Mar 01/2006	27-16-08 FITS AND CLEARANCES	
27-16-08 TRANSMITTAL LETTER		27-16-08 CLEANING		801	Jul 01/2006
O 1	Jul 01/2009	401	Mar 01/2006	802	Mar 01/2006
2	BLANK	402	BLANK	803	Mar 01/2006
27-16-08 HIGHLIGHTS		27-16-08 CHECK		804	Mar 01/2006
O 1	Jul 01/2009	501	Mar 01/2006	805	Mar 01/2006
2	BLANK	502	BLANK	806	BLANK
27-16-08 EFFECTIVE PAGES		27-16-08 REPAIR - GENERAL		27-16-08 SPECIAL TOOLS, FIXTURES, AND EQUIPMENT	
1 thru 2	Jul 01/2009	601	Mar 01/2006	901	Mar 01/2009
27-16-08 CONTENTS		602	BLANK	902	BLANK
1	Mar 01/2006	27-16-08 REPAIR 1-1		27-16-08 ILLUSTRATED PARTS LIST	
2	BLANK	601	Mar 01/2006	1001	Nov 01/2008
27-16-08 TR AND SB RECORD		602	Mar 01/2006	1002	Jul 01/2006
1	Mar 01/2006	27-16-08 REPAIR 2-1		1003	Nov 01/2006
2	BLANK	601	Mar 01/2006	1004	Jul 01/2006
27-16-08 REVISION RECORD		602	Mar 01/2006	1005	Jul 01/2006
1	Mar 01/2006	27-16-08 REPAIR 3-1		1006	Jul 01/2006
2	Mar 01/2006	601	Mar 01/2006	1007	Nov 01/2007
27-16-08 RECORD OF TEMPORARY REVISIONS		602	Mar 01/2006	1008	Mar 01/2006
1	Mar 01/2006	27-16-08 REPAIR 4-1		1009	Mar 01/2006
2	Mar 01/2006	601	Mar 01/2006	1010	Mar 01/2006
27-16-08 INTRODUCTION		602	Mar 01/2006	1011	Mar 01/2006
1	Mar 01/2009	27-16-08 REPAIR 5-1		1012	Mar 01/2006
2	BLANK	601	Mar 01/2006	1013	Mar 01/2006
27-16-08 DESCRIPTION AND OPERATION		602	BLANK	1014	Mar 01/2006
1	Mar 01/2006	27-16-08 REPAIR 6-1		1015	Mar 01/2006
2	Mar 01/2006	601	Mar 01/2006	1016	Mar 01/2006
27-16-08 TESTING AND FAULT ISOLATION		602	BLANK	1017	Mar 01/2006
101	Mar 01/2006	27-16-08 ASSEMBLY		1018	Mar 01/2006
102	Mar 01/2006	701	Nov 01/2008	1019	Mar 01/2006
103	Mar 01/2006	702	Mar 01/2006	1020	Mar 01/2006
104	Mar 01/2006	703	Mar 01/2006	1021	Mar 01/2006
105	Mar 01/2006	704	Mar 01/2006	1022	Mar 01/2006
106	BLANK	705	Mar 01/2006	1023	Nov 01/2007
		706	Mar 01/2006	1024	Mar 01/2006
		707	Mar 01/2006	1025	Mar 01/2006
		708	Mar 01/2006	1026	Mar 01/2006
		709	Mar 01/2006		

A = Added, R = Revised, D = Deleted, O = Overflow

# 27-16-08

EFFECTIVE PAGES

Page 1

Jul 01/2009



**COMPONENT MAINTENANCE MANUAL**

Subject/Page	Date	Subject/Page	Date	Subject/Page	Date
27-16-08 ILLUSTRATED PARTS LIST (cont)					
1027	Mar 01/2006				
1028	Mar 01/2006				
1029	Mar 01/2006				
1030	Mar 01/2006				

A = Added, R = Revised, D = Deleted, O = Overflow

**27-16-08**

EFFECTIVE PAGES

Page 2

Jul 01/2009



## COMPONENT MAINTENANCE MANUAL

### TABLE OF CONTENTS

<u>Paragraph Title</u>	<u>Page</u>
AILERON CONTROL TRANSFER MECHANISM ASSEMBLY - DESCRIPTION AND OPERATION	1
TESTING AND FAULT ISOLATION	101
DISASSEMBLY	301
CLEANING	401
CHECK	501
REPAIR	601
ASSEMBLY	701
FITS AND CLEARANCES	801
SPECIAL TOOLS, FIXTURES, AND EQUIPMENT	901
ILLUSTRATED PARTS LIST	1001

# 27-16-08

CONTENTS

Page 1

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

### TEMPORARY REVISION AND SERVICE BULLETIN RECORD

BOEING SERVICE BULLETIN	BOEING TEMPORARY REVISION	OTHER DIRECTIVE	DATE OF INCORPORATION INTO MANUAL
		PRR 38050	JUL 01/03
		PRR 38060-20	JUL 01/03

# 27-16-08

TR AND SB RECORD

Page 1

Mar 01/2006



**COMPONENT MAINTENANCE MANUAL**

All revisions to this manual will be accompanied by transmittal sheet bearing the revision number. Enter the revision number in numerical order, together with the revision date, the date filed and the initials of the person filing.

Revision		Filed		Revision		Filed	
Number	Date	Date	Initials	Number	Date	Date	Initials

**27-16-08**

REVISION RECORD

Page 1

Mar 01/2006





COMPONENT MAINTENANCE MANUAL

Revision		Filed		Revision		Filed	
Number	Date	Date	Initials	Number	Date	Date	Initials



COMPONENT MAINTENANCE MANUAL

All temporary revisions to this manual will be accompanied by a cover sheet bearing the temporary revision number. Enter the temporary revision number in numerical order, together with the temporary revision date, the date the temporary revision is inserted and the initials of the person filing. When the temporary revision is incorporated or cancelled, and the pages are removed, enter the date the pages are removed and the initials of the person who removed the temporary revision.

Two large tables for recording temporary revisions, each with columns for 'Temporary Revision', 'Inserted', and 'Removed', and sub-columns for 'Number', 'Date', and 'Initials'.



**COMPONENT MAINTENANCE MANUAL**

Temporary Revision		Inserted		Removed	
Number	Date	Date	Initials	Date	Initials

Temporary Revision		Inserted		Removed	
Date	Initials	Number	Date	Date	Initials



## COMPONENT MAINTENANCE MANUAL

### INTRODUCTION

#### 1. General

- A. The instructions in this manual supply the data necessary to do the maintenance functions together with the test, fault isolation, repair, and replacement of the defective parts.
- B. This manual is divided into different parts:
  - (1) Title Page
  - (2) Transmittal Letter
  - (3) Highlights
  - (4) List of Effective Pages
  - (5) Table of Contents
  - (6) Temporary Revision & Service Bulletin Record
  - (7) Record of Revisions
  - (8) Record of Temporary Revisions
  - (9) Introduction
  - (10) Procedures & IPL Sections
- C. Components that can be repaired have a different repair number for each specified repair. To find the repair number location of a component, look in the Repair-General procedure at the beginning of the REPAIR section. The Repair-General procedure also has an explanation of the True Position Dimension symbols used.
- D. All dimensions, measures, quantities and weights included are in English units. When metric equivalents are given they will be in the parentheses that follow the English units.
- E. The introduction to the Illustrated Parts List (IPL) shows how the IPL data is used.
- F. Design changes, optional parts, configuration differences and Service Bulletin modifications may cause different part numbers. These part numbers are identified in the IPL with an alphabetical letter which is added to the end of the basic item number. This new item number is referred to as an alpha-variant. Throughout the manual, IPL basic item number references also apply to alpha-variants unless shown differently.
- G. The tool reference numbers found in the individual procedures and in the Special Tools, Fixtures, and Equipment section are used to identify if a tool is a standard tool (STD-XXXX), a commercial tool (COM-XXXX), or a Special Tool (SPL-XXXX). This reference number is also used to distinguish between tools with similar names in the same procedure. These reference numbers are for use in the documentation only. They are not to be used for ordering tools.

# 27-16-08

INTRODUCTION

Page 1

Mar 01/2009



## COMPONENT MAINTENANCE MANUAL

### AILERON CONTROL TRANSFER MECHANISM ASSEMBLY - DESCRIPTION AND OPERATION

#### **1. Description and Operation**

- A. The aileron control transfer mechanism located at the base of the first officer's control column incorporates a transfer mechanism and a lost motion device. The transfer portion consists basically of a preloaded torsion spring whose ends are held against two similar halves of a spring container. The lost motion device consists of an arm on the bottom portion of the transfer mechanism assembly.
- B. Rotation of either the captain's or first officer's control wheel results in rotational movement of the aileron control bus drum. The spoiler control drum is floating and normally rotates only by feedback through the attached cables or, in case of a jammed aileron system, through action of the lost motion device. Control wheel rotational motion is transmitted between the lost motion device and the aileron control bus drum through the preloaded torsion spring.
- C. If the aileron cable system becomes jammed, the first officer must exert sufficient rotational force on his control wheel to overcome the spring preload and maintain lateral control through operation of the spoiler control system. The first officer's control wheel will turn through the range of lost motion before movement is picked up by the spoiler control drum through the lost motion device.
- D. If the spoiler cable system becomes jammed, the captain must likewise exert sufficient rotational force on his control wheel to overcome the spring preload and maintain lateral control through operation of the aileron control system.

#### **2. Leading Particulars (Approximate)**

- A. Length – 13 inches
- B. Width – 10 inches
- C. Height – 12 inches
- D. Weight – 14.2 pounds


# 27-16-08

DESCRIPTION AND OPERATION

Page 1

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



Aileron Control Transfer Mechanism Assembly  
Figure 1

**27-16-08**

DESCRIPTION AND OPERATION

Page 2

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

### TESTING AND FAULT ISOLATION

#### 1. General

- A. This procedure has the data necessary to do a test of the aileron control transfer mechanism assembly after an overhaul or for fault isolation.
- B. Refer to the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.

#### 2. Preparation for Test

- A. Tools/Equipment

**NOTE:** Equivalent substitutes may be used.

Reference	Description
SPL-5434	Test Bench Assembly, Transfer Mechanism Aileron Control, Functional Test (Part #: F80220-1, Supplier: 81205)

- B. Procedure

- (1) Install the transfer mechanism assembly vertically in Test Bench Assembly, SPL-5434.

**NOTE:** Use F80220-1 Test Bench Assembly, SPL-5434 to hold the transfer mechanism assembly with shaft (195) vertical. Mounting holes in forward and aft beams (80, 85) to hold assembly to test rig (TESTING AND FAULT ISOLATION, Figure 101).

#### 3. Functional Test (IPL Figure 1)

**CAUTION:** DO ALL STEPS SLOWLY AND CAREFULLY. TOO FAST A RELEASE OF SPRING LOAD CAN DAMAGE COMPONENTS OF THE ASSEMBLY.

**NOTE:** If you use a spring scale to apply rotational forces during bus drum torque tests, attach the spring scale to one cable and do all tests requiring rotation in one direction; then attach the scale to the other cable and do the tests again in the opposite direction.

**NOTE:** Spring scale that can accurately measure 0-250 pounds of tension, or torque wrench with range of 0-1000 pound-inches.

- A. Shaft Torque Test

**CAUTION:** HOLD THE PIN OR BOLT TO KEEP THE DRUM STOPPED. DO NOT USE A PIN OR BOLT LONGER THAN 3.375 INCHES OR DAMAGE TO PARTS CAN OCCUR.

- (1) Put a 5/16-inch diameter by 3.375-inch long pin or bolt through the rig pin holes in housings (300, 495) and drum (300).
- (2) Apply torque to the fork end of shaft (520) and turn the shaft gradually to 75 degrees from starting point in both clockwise and counterclockwise directions.
- (3) Make sure the torque values at the spring breakout are 256-400 pound-inches and are not more than 600 pound-inches at the 75-degree position.
- (4) Do TESTING AND FAULT ISOLATION, Paragraph 3.A.(2) and TESTING AND FAULT ISOLATION, Paragraph 3.A.(3) six times. During the operation, make sure parts move freely.

# 27-16-08

TESTING AND FAULT ISOLATION

Page 101

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

(5) After the test, make sure the fork (70) slot centerline is 89-91 degrees compared to the rig pin hole centerlines in drum (435) and housings (300, 495) aligned within 0.015 inch as shown in TESTING AND FAULT ISOLATION, Figure 102.

(6) Remove the rig pin.

### B. Bus Drum Torque, Null Shift, Travel Tests

(1) Hold shaft (520) stopped with a locking device applied to either the shaft or fork (70).

(2) Install the MS21251B5S turnbuckles on cables (10, 15).

(3) Attach a spring scale to the turnbuckle on cable assembly (15).

**NOTE:** The spring is not necessary if the test fixture lets you use a torque wrench as shown in TESTING AND FAULT ISOLATION, Figure 101.

(4) Apply tension to the spring scale or bus drum (435). Make sure the breakout torque is 256-400 pound-inches (64.5-100.5-pound cable tension). Increase the force gradually until bus drum (435) turns 75 degrees from the starting position. Make sure the torque is not more than 600 pound-inches (150.8-pound cable tension).

(5) Increase the force until the drum turns through 130 degrees from the starting position and make sure the torque is not more than 710 pound-inches (178-pound cable tension). During the test, make sure there is no interference between the end of the rig pin or bolt with the parts.

(6) Do TESTING AND FAULT ISOLATION, Paragraph 3.B.(4) and TESTING AND FAULT ISOLATION, Paragraph 3.B.(5) again a minimum of five times.

(7) Turn bus drum (435) clockwise through the total travel to the internal stop. Make sure the total travel from the starting position is a minimum of 138 degrees.

(8) Put bus drum (435) back to the neutral position. Make a note of the radial location of the free drum relative to rib (335).

(9) Do TESTING AND FAULT ISOLATION, Paragraph 3.B.(7) again in the counterclockwise direction.

(10) Put the bus drum back to the neutral position. Make sure the null shift from the position noted in TESTING AND FAULT ISOLATION, Paragraph 3.B.(8) is not more than 1 degree, and that the free play of the bus drum (at neutral position) is not more than 1 degree.

(11) If you used the spring scale, remove the scale from cable (15) and install the scale on cable (10).

(12) Do TESTING AND FAULT ISOLATION, Paragraph 3.B.(4) and TESTING AND FAULT ISOLATION, Paragraph 3.B.(5) again in the counterclockwise direction.

(13) Do TESTING AND FAULT ISOLATION, Paragraph 3.B.(12) again a minimum of five times.

### C. Spoiler Drum Free Travel Test

(1) Hold fork (70), and turn spoiler drum (305) in the clockwise and counterclockwise directions through the 11-13 degree travel range between the stops. Make sure the drum turns freely.

(2) Remove the turnbuckles and the rig pins, and remove the assembly from the fixture.

# 27-16-08


TESTING AND FAULT ISOLATION

Page 102

Mar 01/2006



### COMPONENT MAINTENANCE MANUAL



ITEM NUMBERS REFER TO IPL FIG. 1

Transfer Mechanism Functional Test  
Figure 101


# 27-16-08

TESTING AND FAULT ISOLATION

Page 103

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



ITEM NUMBERS REFER TO IPL FIG. 1

Test Diagram  
Figure 102

**27-16-08**

TESTING AND FAULT ISOLATION

Page 104

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

### 4. Trouble Shooting (IPL Figure 1)

A. Refer to TESTING AND FAULT ISOLATION, Table 101 to do fault isolation with the test results.

**Table 101:** Trouble Shooting Chart

TROUBLE	PROBABLE CAUSE	CORRECTION
Shaft (520) will not turn easily or freely.	Incorrect assembly Defective bearings, flexible coupling (465) tightened too much	Disassemble and assemble correctly. Replace bearings. Replace spring; retighten the coupling.
Interference as bus drum is rotated counterclock- wise TESTING AND FAULT ISOLATION, Paragraph 3.B.(4).	Rig pin is in too far into spoiler drum (305)	Remove the rig pin and install it correctly.
Breakout out torque or maximum torque not within specified limits, TESTING AND FAULT ISOLATION, Paragraph 3.B.(6) and TESTING AND FAULT ISOLATION, Paragraph 3.B.(13).	Defective spring	Replace spring.
Bus drum (435) does not turn freely, TESTING AND FAULT ISOLATION, Paragraph 3.B.(6) and TESTING AND FAULT ISOLATION, Paragraph 3.B.(13).	Incorrect assembly Flexible coupling (465) tightened too much	Disassemble and assemble correctly. Replace bearings; retighten coupling.

# 27-16-08

TESTING AND FAULT ISOLATION

Page 105

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

### DISASSEMBLY

#### 1. General

- A. This procedure contains the data necessary to disassemble the Mechanism Assembly.
- B. Refer to TESTING AND FAULT ISOLATION to find the condition of the component or possible cause of its malfunction. This is to see how much disassembly is necessary without complete disassembly and assembly.
- C. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- D. Refer to IPL Figure 1 for item numbers.

#### 2. Parts Replacement (IPL Figure 1)

**NOTE:** These parts are recommended for replacement. Unless shown differently, replacement of other parts can be by in-service experience.

- A. Bearings (50, 65, 305, 370, 405, 500)
- B. Cotter pins (5)
- C. Bolts (20)

#### 3. Disassembly (IPL Figure 1)

- A. Remove cotter pins (5), bolts (20), and cable assemblies (10, 15, 20, 25).
  - B. Remove nut (45), washer (40) and bolt (30).
  - C. Remove fork assembly (60), spacers (55), and bushing (515) from shaft (520).
  - D. Remove bearing (50) from fork (70).
  - E. Remove nuts (320), washers (315), and bushings (325), bolts (310), and bracket assembly (340).
  - F. Remove nuts (295), washers (290) and bolts (285) and disconnect forward rib (330) and aft rib (335) from bearing housings (300, 495).
  - G. Remove the screws (145, 160 or 165), washers (150, 170 or 175), clamp (185), and plug (180). Remove the bolts (190 or 195), washers (200, 205), and nuts (210), as applicable. Remove the transmitter assembly (215) from the plate assembly.
  - H. Remove the screws (220) and washers (225), then remove the plate (335) and transmitter (270) from the clamp ring assembly (235) or clamp ring (255).
  - I. Remove nuts (130), washers (125), bolts (120), and cable guide (140) from forward rib (330).
- NOTE:** Do not remove grommets (135) unless replacement is necessary.
- J. Remove bearing housing (300) from upper end of shaft (520).
  - K. Remove bolts (360) and collars (365) from upper drum (375).
  - L. Remove upper drum (375) from shaft (520).

**WARNING:** SPRING (420) IS HELD BY RETENTION PLATE (415) AND RETAINER (400). DO NOT REMOVE RETAINER (400) UNLESS YOU HOLD PLATE (415) OR INJURY TO PERSONNEL CAN OCCUR.

- M. Remove nut (395), washers (385, 390), bolt (380) and retainer (400) from upper portion of shaft (520).
- N. Remove bearings (405), spacer (410), retention plate (415), spacer (425) and spring (420) from the upper portion of shaft (520).

# 27-16-08

DISASSEMBLY

Page 301

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

- O. Remove flexible coupling (465) and washer (470) from shaft (520).
- P. Remove bearing housing (495) and remaining washer (470) from shaft (520).
- Q. Remove nuts (485), washers (480), screws (475) and three cable guards (490) from housing (495).
- R. Remove arm (505) from shaft (520).
- S. Remove spacers (430, 440, 445), bearings (405), lower drum (435) and spoiler drum assembly (450) from shaft (520).

**NOTE:** Do not remove marker (530) from lower drum (435) unless replacement is necessary.

- T. Remove retainer (400), bearings (405), spacer (410), retention plate (415) and spacer (425) from the lower portion of shaft (520).
- U. Remove bearings (405) and spacer (445) from spoiler drum assembly (450).

# 27-16-08

DISASSEMBLY

Page 302

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

### CLEANING

#### 1. General

- A. This procedure contains the data necessary to clean special parts.
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.

#### 2. Cleaning

##### A. References

Reference	Title
SOPM 20-30-01	CLEANING AND RELUBRICATING BEARINGS
SOPM 20-30-03	GENERAL CLEANING PROCEDURES

##### B. Procedure

- (1) Clean all parts but bearings by standard industry practices and the instructions in SOPM 20-30-03.
- (2) Clean bearings by the instructions in SOPM 20-30-01.

# 27-16-08

CLEANING

Page 401

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

### CHECK

#### 1. General

- A. This procedure contains the data necessary to find defects in the material of specified parts.
- B. Refer to FITS AND CLEARANCES for the design dimension and wear limits.
- C. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- D. Refer to IPL Figure 1 for item numbers.

#### 2. Check

##### A. References

Reference	Title
SOPM 20-20-01	MAGNETIC PARTICLE INSPECTION
SOPM 20-20-02	PENETRANT METHODS OF INSPECTION

##### B. Procedure

- (1) Examine all parts for defects by standard industry practices.
- (2) Do a magnetic particle check (SOPM 20-20-01) of these parts:
  - (a) Fork (70)
- (3) Do a penetrant check (SOPM 20-20-02) on these parts:
  - (a) Ribs (330, 335)
  - (b) Cable guard (490)
  - (c) Housings (300, 495)
  - (d) Retention plate (415) and retainer (400)
  - (e) Spacers (410, 430, 440, 445)
  - (f) Drums (375, 435, 450)
  - (g) Arm (505)

# 27-16-08

CHECK

Page 501

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

### REPAIR

#### 1. Content

- A. Instructions for repair, refinish, and replacement of the specified subassembly parts are included in each REPAIR when applicable:

**Table 601:**

<b>P/N</b>	<b>NAME</b>	<b>REPAIR</b>
65-55476	BEARING HOUSING	1-1
65C37032	UPPER DRUM	2-1
65C37033	LOWER DRUM	3-1
6-60428	FORK ASSEMBLY	4-1
65C37035	SHAFT ASSEMBLY	5-1
- - - -	MISCELLANEOUS PARTS REFINISH	6-1

#### 2. Standard Practices

- A. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in the individual procedures.
- SOPM 20-10-01 Repair and Refinish of High Strength Steel Parts
  - SOPM 20-30-02 Stripping of Protective Finishes
  - SOPM 20-41-01 Decoding Table for Boeing Finish Codes
  - SOPM 20-60-02 Finishing Materials
  - SOPM 20-60-03 Lubricants
  - SOPM 20-60-04 Miscellaneous Materials

#### 3. Materials

**NOTE:** Equivalent substitutes can be used.

- A. primer, C00259 – BMS 10-11, type 1  
 B. Enamel coating, C00260 – BMS 10-11, type 2  
 C. sealant, A00247 – BMS 5-95  
 D. lubricant, D00113 – Solid Film, BMS 3-8

#### 4. Dimensioning Symbols

- A. Standard True Position Dimensioning Symbols used in the applicable repair procedures are shown in SOPM 20-00-00.

# 27-16-08

REPAIR - GENERAL

Page 601

Mar 01/2006





## COMPONENT MAINTENANCE MANUAL

### BEARING HOUSING - REPAIR 1-1

65-55476-14, -15

#### 1. General

- A. This procedure has the data necessary to refinish the bearing housing (IPL Figure 1, 300,495).
- B. Refer to REPAIR-GENERAL, Paragraph 2. for the Standard Overhaul Practices Manual (SOPM) subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Paragraph 3. for the description of the consumable codes identifies in this procedure.
- D. Refer to IPL Figure 1 for item numbers.

#### 2. Bearing Replacement

- A. Remove the old bearings (305, 500) from bearing housing (300, 495).
- B. Install replacement bearings with sealant, A00247 and roller swage them (SOPM 20-50-03).

#### 3. Refinish

- A. For the repair of surfaces which is only the replacement of the original finish , refer to REFINISH instructions on REPAIR 1-1, Figure 601.


# 27-16-08

REPAIR 1-1



Page 601

Mar 01/2006


COMPONENT MAINTENANCE MANUAL



65-55476-14



65-55476-15



REFINISH

CHROMIC ACID ANODIZE AND APPLY PRIMER  
BMS 10-11, TYPE 1 (F-20.02) UNLESS  
SHOWN DIFFERENTLY

MATERIAL: AL ALLOY  
ALL DIMENSIONS ARE IN INCHES

NO PRIMER THIS SURFACE

65-55476-14,-15 Bearing Housing Repair  
Figure 601

**27-16-08**

REPAIR 1-1  
Page 602  
Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

### UPPER DRUM - REPAIR 2-1

65C37032-1

#### 1. General

- A. This procedure has the data necessary to refinish the upper drum (IPL Figure 1, 375).
- B. Refer to REPAIR-GENERAL, Paragraph 2. for the Standard Overhaul Practices Manual (SOPM) subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Paragraph 3. for the description of the consumable codes identifies in this procedure.
- D. Refer to IPL Figure 1 for item numbers.

#### 2. Bearing Replacement

- A. Remove the old bearing (370) from upper drum (375).
- B. Install a replacement bearing with sealant, A00247 and roller swage it (SOPM 20-50-03).

#### 3. Refinish

- A. For the repair of surfaces which is only the replacement of the original finish , refer to REFINISH instructions on REPAIR 2-1, Figure 601.

# 27-16-08



REPAIR 2-1

Page 601

Mar 01/2006



COMPONENT MAINTENANCE MANUAL



A-A

REFINISH

CHROMIC ACID ANODIZE AND APPLY PRIMER  
BMS 10-11, TYPE 1 (F-20.02) UNLESS  
SHOWN DIFFERENTLY

MATERIAL: AL ALLOY  
ALL DIMENSIONS ARE IN INCHES

1 NO PRIMER ON THIS SURFACE

65C37032-1 Upper Drum Repair  
Figure 601

**27-16-08**

REPAIR 2-1  
Page 602  
Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

### LOWER DRUM - REPAIR 3-1

65C37033-1

#### 1. General

- A. This procedure has the data necessary to refinish the upper drum (IPL Figure 1, 435).
- B. Refer to REPAIR-GENERAL, Paragraph 2. for the Standard Overhaul Practices Manual (SOPM) subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Paragraph 3. for the description of the consumable codes identifies in this procedure.
- D. Refer to IPL Figure 1 for item numbers.

#### 2. Bearing Replacement

- A. Remove the old bearing (370) from lower drum (435).
- B. Install a replacement bearing with sealant, A00247 and roller swage it (SOPM 20-50-03).

#### 3. Refinish

- A. For the repair of surfaces which is only the replacement of the original finish , refer to REFINISH instructions on REPAIR 3-1, Figure 601.

# 27-16-08


REPAIR 3-1

Page 601

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL



A-A

### REFINISH

CHROMIC ACID ANODIZE AND APPLY PRIMER  
BMS 10-11, TYPE 1 (F-20.02) UNLESS  
SHOWN DIFFERENTLY

MATERIAL: AL ALLOY

ALL DIMENSIONS ARE IN INCHES

- 1** NO PRIMER ON THIS SURFACE
- 2** NO PRIMER ON THE AREA BETWEEN  
5.52 DIAMETER LIP AND A 7.21-7.29  
DIAMETER CIRCLE CONCENTRIC TO 5.52  
DIAMETER LIP

65C37033-1 Lower Drum Repair  
Figure 601

# 27-16-08

REPAIR 3-1  
Page 602  
Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

### FORK ASSEMBLY - REPAIR 4-1

6-60428-2, -6

#### 1. General

- A. This procedure has the data necessary to repair or refinish the fork (IPL Figure 1, 60).
- B. Refer to REPAIR-GENERAL, Paragraph 2. for the Standard Overhaul Practices Manual (SOPM) subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Paragraph 3. for the description of the consumable codes identifies in this procedure.
- D. Refer to IPL Figure 1 for item numbers.

#### 2. Bearing Replacement

- A. Remove the old bearing (65) from fork (70).
- B. Install a replacement bearing with sealant, A00247 and roller swage it (SOPM 20-50-03).

#### 3. Fork Repair (REPAIR 4-1, Figure 601)

- A. Machine as required, within repair limits, to remove defects (SOPM 20-10-01).
- B. Do a magnetic particle check (SOPM 20-20-01).
- C. Stress relieve at 300-350°F for 2 hours. Air cool at 65-75°F.
- D. Build up the machined surfaces to design dimensions with nickel plate (SOPM 20-42-09).
- E. Apply solid film lubricant, D00113 to the inside flats.

#### 4. Fork Refinish

- A. For the repair of surfaces which is only the replacement of the original finish , refer to REFINISH instructions on REPAIR 4-1, Figure 601.

# 27-16-08


REPAIR 4-1

Page 601

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL



### REFINISH

CADMIUM PLATE (F-15.23) BUT NOT ON INSIDE FLATS OF FORK OR BEARING SURFACES. APPLY SOLID FILM LUBRICANT TO INSIDE OF FLATS. AS SHOWN BY [2].

- [1] LIMIT FOR NICKEL PLATE BUILDUP (SOPM 20-42-09) TO DESIGN DIMENSIONS SHOWN. PUT A 0.06 PLATING RUNOUT.
- [2] APPLY BMS 3-8 SOLID FILM LUBRICANT (F-19.10)
- [3] 0.010 MAXIMUM MATERIAL REMOVAL FROM EITHER SURFACE
- [4] 6-60428-2
- [5] 6-60428-6

### REPAIR

REF [1] [3]

63/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

### MATERIAL:

4620 OR 9310 CASE HARDENED STEEL  
(CORE STRENGTH 150-210 KSI)

ALL DIMENSIONS ARE IN INCHES

6-60428-2,-6 Fork Assembly Repair and Refinish  
Figure 601

# 27-16-08

REPAIR 4-1  
Page 602  
Mar 01/2006





## COMPONENT MAINTENANCE MANUAL

### SHAFT ASSEMBLY - REPAIR 5-1

65C37035-3

#### **1. General**

- A. This procedure has the data necessary to repair or refinish the shaft assembly (IPL Figure 1, 510).
- B. Refer to REPAIR-GENERAL, Paragraph 2. for the Standard Overhaul Practices Manual (SOPM) subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Paragraph 3. for the description of the consumable codes identifies in this procedure.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
  - (1) Material: Al Alloy

#### **2. Bushing Replacement**

- A. Remove the old bushing (515) from shaft (520).
- B. Install a replacement bushing with sealant, A00247 by the shrink-fit method (SOPM 20-50-03).

#### **3. Refinish (IPL Figure 1)**

- A. Shaft (520)
  - (1) Sulfuric acid anodize (F-17.31).
  - (2) Apply primer, C00259 (F-20.02) to all interior surfaces.

**27-16-08**

REPAIR 5-1

Page 601

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

### MISCELLANEOUS PARTS REFINISH - REPAIR 6-1

#### 1. General

- A. This repair gives the data that is necessary to refinish parts not given in the specified repairs.
- B. Refer to REPAIR-GENERAL, Paragraph 2. for the Standard Overhaul Practices Manual (SOPM) subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Paragraph 3. for the description of the consumable codes identifies in this procedure.
- D. Refer to IPL Figure 1 for item numbers.

**Table 601:** Refinish Details

IPL FIG. & ITEM	MATERIAL	FINISH
Fig. 1		
Spacer (55)	Al alloy	Chromic acid anodize (F-17.02) and apply primer, C00259 (F-20.02).
Cable guide (140), cable guard (490)	Al alloy	Chemical treat or chromic acid anodize and apply primer, C00259 (F-18.05).
Beam (90,115)	Al alloy	Chromic acid anodize and apply primer, C00259 (F-18.13). Apply enamel coating, C50069 (F-21.03).
Ribs (330, 335), retention plate (415)	Al alloy	Chromic acid anodize (F-17.19) and apply primer, C00259 (F-20.02).
Bolt (380)	A286 CRES	Cadmium plate (F-15.06).
Spacer (410,430, 440,445)	Al alloy	Chromic acid anodize (F-17.02).
Retainer (400)	Al alloy	Chromic acid anodize (F-17.19).
Spoiler drum (460)	Al alloy	Boric acid-sulfuric acid anodize (F-17.31). Apply primer, C00259 (F-20.02), but not in bores for bearings.
Arm (505)	Al alloy	Chromic acid anodize (F-17.19). Apply primer, C00259 (F-20.02), but not on splines.

# 27-16-08

REPAIR 6-1

Page 601

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

### ASSEMBLY

#### 1. General

- A. This procedure has the data necessary to assemble the aileron control transfer mechanism assembly.
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.

#### 2. Assembly

##### A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
A00247	Sealant - Pressure And Environmental - Chromate Type	BMS 5-95
C00913	Compound - Corrosion Inhibiting Material, Nondrying Resin Mix	BMS 3-27
D00015	Grease - Aircraft Bearing (Use BMS 3-24 until existing stocks are depleted, BMS 3-33 supersedes BMS 3-24)	BMS3-24 (Superseded by BMS 3-33)
D00633	Grease - Aircraft General Purpose	BMS3-33

##### B. References

Reference	Title
SOPM 20-50-02	INSTALLATION OF SAFETYING DEVICES
SOPM 20-50-03	BEARING AND BUSHING REPLACEMENT
SOPM 20-50-07	LUBRICATION
SOPM 20-50-19	GENERAL SEALING
SOPM 20-60-02	FINISHING MATERIALS
SOPM 20-60-03	LUBRICANTS
SOPM 20-60-04	MISCELLANEOUS MATERIALS

##### C. Procedure (ASSEMBLY, Figure 701, ASSEMBLY, Figure 702)

**NOTE:** For finishing materials, refer to SOPM 20-60-02. For lubricants, refer to SOPM 20-60-03. For miscellaneous materials, refer to SOPM 20-60-04.

- (1) Install bolt (380), washers (385, 390), nut (395), and retainer (400) on the upper portion of shaft (520) as shown in ASSEMBLY, Figure 701, View A-A. Tighten the nut (395) to 12-15 pound-inches.
- (2) Install a bearing (405) with sealant, A00247 by the press-fit method (SOPM 20-50-03) and spacer (410) in the upper retention plate (415) bore adjacent to upper retainer (400). Make sure the bearing (405) is down against the shoulder of the retention plate.
- (3) Install a bearing (405) with grease, D00015 or grease, D00633 by the press-fit method (SOPM 20-50-03) in the opposite bore of retention plate (415).

# 27-16-08

ASSEMBLY

Page 701

Nov 01/2008



## COMPONENT MAINTENANCE MANUAL

- (4) Turn shaft (520) over and install retention plate (415), spacer (425), and spring (420) on the upper portion of the shaft.
- (5) Install a bearing (405) with grease, D00015 or grease, D00633 by the press-fit method (SOPM 20-50-03) in lower retention plate (415) bore adjacent to spacer (425).
- (6) Install a bearing (405) with sealant, A00247 by the press-fit method (SOPM 20-50-03) and spacer (410) in opposite bore of lower retention plate (415). Make the sure bearing (405) is down against the shoulder of the retention plate.

**WARNING:** AFTER YOU TURN THE PLATE AND SPRING, BE SURE TO HOLD THEM IN POSITION UNTIL YOU ATTACH THE LOWER RETAINER.

- (7) Turn retention plate (415) and spring (420) approximately 200 degrees until the retention plate lug engages the shaft tabs. Hold these parts in this position until you attach lower retainer (265) in ASSEMBLY, Paragraph 2.C.(9) below.
- (8) Install spacer (425) and lower retention plate (415) on the lower portion of shaft (520).
- (9) Install bolt (380), washers (385, 390), nut (395) and retainer (400) on the lower portion of shaft (520) as shown in ASSEMBLY, Figure 701, View B-B. Tighten the nut (395) to 12-15 pound-inches.
- (10) Install spacer (430) on shaft (520).
- (11) Apply fillet seal of sealant, A00247 (SOPM 20-50-19) to mating surfaces of lower drum (435) and upper drum (375) and install the drums on shaft (520). Put the upper drum (375) and lower drum (435) together and align the fastener holes.
- (12) Turn the upper drum (375) and lower drum (435) to engage stops on retention plates (250).
- (13) Install bolts (360) and collars (365).
- (14) Install a bearing (405) with grease, D00015 or grease, D00633 by the press-fit method (SOPM 20-50-03) in the spoiler drum (450) bore that is adjacent to arm (505).
- (15) Install spacer (445), then install the other bearing (405) with sealant, A00247 by the press-fit method (SOPM 20-50-03) in the opposite bore of spoiler drum (450).
- (16) Install spacer (440) and spoiler drum (450) on shaft (520).
- (17) Install screws (475), washers (480), nuts (485) and cable guards (490) in housing (495).
- (18) Install arm (505), washers (470), housing (495), and flexible coupling (465) on shaft (520). Tighten the coupling to 300-400 pound-inches.
- (19) Install bearing housing (300) on shaft (520).
- (20) Install nuts (130), washers (125), bolts (120) and cable guide (140) on forward rib (330).
- (21) Attach forward rib (330) and aft rib (335) to bearing housings (300, 495) with nuts (295), washers (290), and bolts (285).
- (22) Put the bracket assembly (340) in position at the bottom of the drum shaft assembly, and attach it to the rib assemblies (330, 335) with the bolts (310), bushings (325), washers (315), and nuts (320). Tighten all of the nuts (320) to complete the assembly.
- (23) Install the transmitter assembly (215) on the bracket assembly (340).
  - (a) Attach the transmitter assembly (260) to the clamp ring assembly (235), or the clamp ring (255), with the plate (230), screws (220), and washers (225).

# 27-16-08

ASSEMBLY

Page 702

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

- (b) Turn the drum shaft assembly (510) to the center of its range of travel. Look in the hole in the bottom of the flex coupling (465) to find the position of the flat in the coupling. Make a mark with a pencil on the bottom flange of the bracket assembly (340) to show the position of the center of the flat.

**WARNING:** BMS 3-27 CORROSION INHIBITING COMPOUND CONTAINS SOLVENTS, CHROMATES, AND A SMALL AMOUNT OF BOUND ASBESTOS. CONSULT THE APPLICABLE SAFETY STANDARDS FOR APPROVED HANDLING PROCEDURES.

**CAUTION:** BMS 3-27 COMPOUND IS USED ONLY IN STATIC JOINTS WHERE GREASE CANNOT BE APPLIED. BMS 3-27 COMPOUND IN DYNAMIC JOINTS WILL NOT LET THEM MOVE FREELY.

- (c) Apply corrosion inhibiting compound, C00913 to the input shaft of the transmitter (270), then put the transmitter assembly (215) in the flex coupling (465) on the drum shaft assembly (510). Install the bolts (190 or 195), washers (200, 205), and nuts (210), as applicable, to hold the transmitter assembly (215). Do not tighten the bolts (190 or 195) fully until the transmitter zero position is set in the steps that follow.
- (d) Turn the transmitter (270) until the zero mark on the transmitter body aligns with the pencil mark on the bracket assembly (340).
- (e) Turn the drum shaft assembly (510) through its full range of travel to align the transmitter (270) with the drum shaft centerline. Make sure that the drum shaft turns freely.
- (f) Move the drum shaft assembly back to the center of its range of travel. On assembly 251A1817-1, tighten the bolts (190) to 25-35 pound-inches to hold the transmitter at the zero position. On assembly 251A1817-2, tighten the nuts (210) to hold the transmitter at the zero position.
- (g) Tighten the capscrew in the flex coupling (465) to 12-15 pound-inches.
- (24) Put clamp (185) and plug (180) on the wire from the transmitter (355). Attach the clamp to the nutplates (350) on the plate assembly (340) with the screws (145, 160 or 165) and washers (150, 170, or 175), as shown in ASSEMBLY, Figure 702.

**NOTE:** The transmitter wire can point in a different direction from that shown in ASSEMBLY, Figure 702. If the wire is too long, make a loop with the wire and use the clamp (185) to hold the loop. If necessary, you can use the larger BACC10DK4 clamp (185A) to hold the loop.

- (25) Install fork assembly (60), spacers (55), bearing (50), bolt (30), washer (40), and nut (45) on shaft (520).
- (a) Install bolt (5) with grease, D00015 or grease, D00633, and put the head of the bolt inboard.
- (b) Make sure the centerline of the fork (70) slot is 89-91 degrees from the rig pin hole centerlines in drum (435) and that housings (300, 495) are aligned within 0.015 inch as shown in TESTING AND FAULT ISOLATION, Figure 102.
- (26) Install cable assembly (10) in the upper groove of the lower drum (435). Install cable assembly (15) in the lower groove of the lower drum. Install cotter pins (5) (SOPM 20-50-02) to hold the cable assemblies.
- (27) Install cable assembly (25) in the upper groove of the spoiler drum (450). Install cable assembly (30) in the lower groove of the spoiler drum. Install bolts (20) to hold the cable assemblies.

# 27-16-08

ASSEMBLY

Page 703

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

- (28) Apply a thin, smooth layer of grease, D00015 or grease, D00633 on the cable assemblies (SOPM 20-50-07).

### 3. Functional Test

#### A. Procedure

- (1) Do the test on the assembled unit per TESTING AND FAULT ISOLATION.

### 4. Storage

#### A. References

Reference	Title
SOPM 20-44-02	TEMPORARY PROTECTIVE COATINGS
SOPM 20-70-01	PROTECTION, STORAGE AND HANDLING OF AIRPLANE COMPONENTS

#### B. Procedure

- (1) Give protection to the unit and put it away by standard industry practices and the instructions in SOPM 20-44-02 and SOPM 20-70-01.


# 27-16-08

ASSEMBLY

Page 704

Mar 01/2006

COMPONENT MAINTENANCE MANUAL





Assembly Details  
 Figure 701 (Sheet 1 of 2)

**27-16-08**

ASSEMBLY  
 Page 705  
 Mar 01/2006

### COMPONENT MAINTENANCE MANUAL




Assembly Details  
Figure 701 (Sheet 2 of 2)

# 27-16-08

ASSEMBLY  
Page 706  
Mar 01/2006



COMPONENT MAINTENANCE MANUAL




Transmitter Installation  
Figure 702 (Sheet 1 of 3)

**27-16-08**

ASSEMBLY  
Page 707  
Mar 01/2006

COMPONENT MAINTENANCE MANUAL




Transmitter Installation  
Figure 702 (Sheet 2 of 3)

**27-16-08**

ASSEMBLY  
Page 708  
Mar 01/2006

## COMPONENT MAINTENANCE MANUAL



- 1 BOND THE FILLER TO THE BEAM WITH TYPE 40 OR 38 ADHESIVE
- 2 TEMPORARILY ATTACH THE CONNECTOR TO THE CLIP WITH STRING OR RUBBER BAND UNTIL INSTALLATION IN THE AIRPLANE
- 3 ANGULAR POSITION CAN BE DIFFERENT THAN AS SHOWN. IF NECESSARY YOU CAN PUT THE WIRE INTO A LOOP IF THE WIRE IS TOO LONG. YOU CAN USE CLAMP (185A) TO HOLD THE LOOP

- 4 INSTALL ONE WASHER BETWEEN CLAMP AND THE AFT RIB (335) AND ONE WASHER BETWEEN CLAMP AND SCREW HEAD. IF THERE IS A THIRD WASHER, INSTALL IT UNDER THE SCREW HEAD

ITEM NUMBERS REFER TO IPL FIG. 1  
ALL DIMENSIONS ARE IN INCHES


Transmitter Installation  
Figure 702 (Sheet 3 of 3)

# 27-16-08

ASSEMBLY  
Page 709  
Mar 01/2006

# COMPONENT MAINTENANCE MANUAL

## FITS AND CLEARANCES



Fits and Clearances  
Figure 801 (Sheet 1 of 4)

# 27-16-08


FITS AND CLEARANCES

Page 801

Jul 01/2006



COMPONENT MAINTENANCE MANUAL



ITEM NUMBERS REFER TO IPL FIG. 1

Fits and Clearances  
Figure 801 (Sheet 2 of 4)

**27-16-08**  
FITS AND CLEARANCES  
Page 802  
Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

REF LETTER	REF IPL	DESIGN DIMENSION*				SERVICE WEAR LIMIT*		
	FIG. 1, MATING ITEM NO.	DIMENSION		ASSEMBLY CLEARANCE		DIMENSION		MAXIMUM CLEARANCE
		MIN	MAX	MIN	MAX	MIN	MAX	
[A]	ID 60	0.3194	0.3208	0.0001	0.0024	0.3160	0.3249	0.0060
	OD	0.3184	0.3193					
[B]	ID 70	0.7498	0.7503	-0.0002	0.0008	0.7495	0.7503	0.0008
	OD 50,65	0.7595	0.7500					
[C]	ID 50,65	0.2495	0.2500	0.0000	0.0015	0.2485	0.2500	0.0015
	OD 30	0.2485	0.2495					
[D]	ID 55	0.2500	0.2540	0.0005	0.0055	0.2485	0.2540	0.0055
	OD 30	0.2485	0.2495					
[E]	ID 510	0.2495	0.2505	0.0000	0.0020	0.2485	0.2505	0.0020
	OD 30	0.2485	0.2495					
[F]	ID 300	2.2500	2.2510	0.0000	0.0020			
	OD 305	2.2490	2.2500					
[G]	ID 305	1.3120	1.3125	0.0004	0.0019			
	OD 510	1.3106	1.3116					
[H]	ID 375,435	1.7505	1.7515	0.0005	0.0025			
	OD 370	1.7490	1.7500					
[I]	ID 370	1.3118	1.3132	0.0002	0.0026			
	OD 510	1.3106	1.3116					
[J]	ID 415	1.7505	1.7515	0.0005	0.0020			
	OD 405	1.7495	1.7500					
[K]	ID 405	1.3120	1.3125	0.0004	0.0019			
	OD 510	1.3106	1.3116					
[L]	ID 450	1.7500	1.7510	0.0000	0.0015			
	OD 405	1.7495	1.7500					

Fits and Clearances  
Figure 801 (Sheet 3 of 4)

# 27-16-08


FITS AND CLEARANCES

Page 803




Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

REF LETTER	REF IPL	DESIGN DIMENSION*				SERVICE WEAR LIMIT*		
	FIG. 1, MATING ITEM NO.	DIMENSION		ASSEMBLY CLEARANCE 		DIMENSION		MAXIMUM CLEARANCE
		MIN	MAX	MIN	MAX	MIN	MAX	
[M]	ID 405	1.3120	1.3125	0.0004	0.0019			
	OD 510	1.3106	1.3116					
[N]	ID 495	1.9373	1.9378	-0.0002	0.0007			
	OD 500	1.9371	1.9375					
[O]	ID 500	0.6247	0.6250	-0.0001	0.0007			
	OD 510	0.6243	0.6248					

\* ALL DIMENSIONS ARE IN INCHES

-  WIDTH OF SLOT AFTER APPLICATION OF BMS 3-8 SOLID FILM LUBRICANT
-  THICKNESS OF MATING PART 6-60429 AFTER APPLICATION OF BMS 3-8 SOLID FILM LUBRICANT
-  NEGATIVE VALUES ARE AN INTERFERENCE FIT

Fits and Clearances  
Figure 801 (Sheet 4 of 4)

**27-16-08**  
FITS AND CLEARANCES  
Page 804  
Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

REF IPL		NAME	TORQUE*	
FIG. NO.	ITEM NO.		POUND-INCHES	POUND-FEET
1	190	Bolt	25-35	
1	395	Nut	12-15	
1	465	Flexible Coupling	300-400	

\* REFER TO SOPM 20-50-01 FOR TORQUE VALUES OF STANDARD FASTENERS.

Torque Table  
Figure 802

**27-16-08**  
FITS AND CLEARANCES  
Page 805  
Mar 01/2006





## COMPONENT MAINTENANCE MANUAL

### SPECIAL TOOLS, FIXTURES, AND EQUIPMENT

#### 1. General

A. This section lists the special tools, fixtures, and equipment necessary for maintenance.

**NOTE:** Equivalent substitutes may be used.

#### Special Tools

Reference	Description	Part Number	Supplier
SPL-5434	Test Bench Assembly, Transfer Mechanism Aileron Control, Functional Test	F80220-1	81205

#### Tool Supplier Information

CAGE Code	Supplier Name	Supplier Address
81205	THE BOEING COMPANY	17930 INTERNATIONAL BLVD. SOUTH SEATAC, WA 98188-4321 Telephone: 206-662-6650 Facsimile: 206-662-7145

# 27-16-08

SPECIAL TOOLS, FIXTURES, AND EQUIPMENT

Page 901

Mar 01/2009



## COMPONENT MAINTENANCE MANUAL

### ILLUSTRATED PARTS LIST

#### 1. Introduction

- A. The Illustrated Parts List (IPL) contains an illustration and a list of component parts you can repair or replace. The Illustrated Parts Catalog (IPC) shows how to use the Boeing part number system.
- B. This shows how parts are related: The relation of each item to its next higher assembly (NHA) is shown in the NOMENCLATURE column. Use the indenture system that follows:

1	2	3	4	5	6	7
.	Assembly					
.	Attaching parts for assembly					
.	.	Detail parts for assembly				
.	.	Subassembly				
.	.	Attaching parts for subassembly				
.	.	.	Detail parts for subassembly			
.	.	.	Sub-subassembly			
.	.	.	Attaching parts for subassembly			
.	.	.	.	Details parts for sub-subassembly		
						Detail Installation Parts (Included only if installation parts may be sent to the shop as part of assembly)

- C. Each top assembly is given one use code letter (A, B, C, etc.) in the USAGE CODE column. All subsequent component parts in the list can have one or more of the use code letters to show effectivity to top assemblies. A component part without a use code applies to all top assemblies.
- D. An alphabetical letter is added after the item number for optional parts, parts changed by a Service Bulletin, configuration differences (except left-handed and right-handed parts), last engineering releases, and parts added between item numbers in a sequence. The alphabetical letter will not be shown on the illustration for equivalent parts of the same part number.
- E. Color-coded parts are identified with a single digit alpha following the dash number or with "SP" suffix. If the "SP" suffix is used, it represents consolidation of all color codes applicable for a given usage which are not separately listed. Orders for color-coded parts should include the registry number of the airplane for which the parts are ordered.
- F. If a part number is 15 characters long but will not fit in the part number column, the part number will be displayed with a "~" at the end of the line and will be continued on the next line. The "~" denotes that the part number continues on the next line.
- G. Parts changed by a Service Bulletin are shown by PRE SB XXXX and POST SB XXXX added to the NOMENCLATURE column.
- (1) When a new top assembly is added by a Service Bulletin, PRE SB XXXX and POST SB XXXX will be added at the top assembly level only. The configuration differences at the detail part level are shown by use code letters.
- (2) When the top assembly part number is not changed by the Service Bulletin, PRE SB XXXX and POST SB XXXX will be added at the detail level.
- H. Interchangeable Parts

# 27-16-08

ILLUSTRATED PARTS LIST

Page 1001

Nov 01/2008



## COMPONENT MAINTENANCE MANUAL

Optional (OPT)	The part is optional to and interchangeable with other parts that have the same item number.
Replaces, Replaced by and not interchangeable with (REPLACES, REPLACED BY AND NOT INTCHG/W)	The part replaces and is not interchangeable with the initial part.
Replaces, Replaced by (REPLACES, REPLACED BY)	The part replaces and is interchangeable with, or is an alternative to, the initial part.

### VENDOR CODES

Code	Name
04169	WESTERN SKY INDUSTRIES A DIVISION OF ATLAS CORPORATION 1280 SAN LUIS OBISPO STREET HAYWARD, CALIFORNIA 94544-7916 FORMERLY WESTERN SKY IND VB0008
06144	INDUSTRIAL TECTONICS BEARING CORP 18301 SOUTH SANTA FE AVENUE RANCHO DOMINGUEZ, CALIFORNIA 90221 FORMERLY IN COMPTON, CALIFORNIA
06725	AIR INDUSTRIES CORPORATION 12570 KNOTT STREET GARDEN GROVE, CALIFORNIA 92641-3932 FORMERLY AIR INDUSTRIES OF CALIF IN GARDENA, CALIF.
08524	Replaced: [V08524] DEUTSCH FASTENER CORP SEE CODE V97928 Replaced: [V97928] SEE V17446 HUCK INTL by Code: Name and Address below 17446: HUCK INTL INC AEROSPACE FASTENER DIV 900 WATSON CENTER ROAD CARSON, CALIFORNIA 90745-4201 FORMERLY V32134 REXNORD INC; FORMERLY V97928 HUCK INTL Referenced in FORMERLY line below [17419] DEUTSCH COMPANY THE WELLS FARGO BANK BLDG 2444 WILSHIRE BLVD #600 SANTA MONICA, CALIFORNIA 90403 FORMERLY DEUTSCH FASTENER CORP V08524 FORMERLY IN LOS ANGELES

# 27-16-08

ILLUSTRATED PARTS LIST

Page 1002

Jul 01/2006



## COMPONENT MAINTENANCE MANUAL

Code	Name
0PTK6	SPS TECHNOLOGIES INC AEROSPACE PRODUCTS DIV 5195 W 4700 SALT LAKE CITY, UTAH 94118 SEE V56878 SPS TECHNOLOGIES INC
11815	CHERRY AEROSPACE FASTENERS DIV OF TEXTRON 1224 EAST WARNER AVENUE PO BOX 2157 SANTA ANA, CALIFORNIA 92707-0157 FORMERLY IN LOS ANGELES, CALIF , FORMERLY CHERRY FASTENERS TOWNSEND DIV OF TEXTRON INC V71087
13201	HELICAL PRODUCT CO 901 WEST MCCOY LANE PO BOX 1069 SANTA MARIA, CALIFORNIA 93456
15653	ALCOA GLOBAL FASTENERS INC DIV KAYNAR PRODUCTS 800 S STATE COLLEGE BLVD FULLERTON, CALIFORNIA 92831-3001 FORMERLY VK6405 MICRODOT AEROSP LTD; FORMERLY KAYNAR TECH FORMERLY FAIRCHILD FASTENERS KAYNAR DIV
17446	HUCK INTL INC AEROSPACE FASTENER DIV 900 WATSON CENTER ROAD CARSON, CALIFORNIA 90745-4201 FORMERLY V32134 REXNORD INC; FORMERLY V97928 HUCK INTL
21335	TIMKEN US CORPORATION DIV FAFNIR 336 MECHANIC STREET LEBANON, NH 03766-0267 FORMERLY FAFNIR BRG AND TEXTRON INC FAFNIR DIV IN NEW BRITAIN, CONNECTICUT ; FORMERLY TORRINGTON CO THE SPECIAL PRODUCTS DIV SUB OF THE INGERSOLL-RAND CO V8D210 FORMERLY TORRINGTON CO FAFNIR BEARING DIV IN TORRINGTON, CT
21760	SCHATZ BEARING CORP 10 FAIRVIEW AVENUE PO BOX 1191 POUGHKEEPSIE, NEW YORK 12601-1312 FORMERLY FEDERAL BRG CO AND SCHATZ MFG CO V53268 FORMERLY SCHATZ MFG CO

# 27-16-08

ILLUSTRATED PARTS LIST

Page 1003

Nov 01/2006



## COMPONENT MAINTENANCE MANUAL

Code	Name
30163	VALENTEC DAYRON INC 333 MAGUIRE BLVD PO BOX 140394 ORLANDO, FLORIDA 32814-0394
38443	MRC BEARINGS 402 CHANDLER STREET JAMESTOWN, NEW YORK 14701-3802 FORMERLY MARLIN-ROCKWELL CORP DIV TRW AND TRW INC
40920	MPB MINIATURE PRECISION BEARING DIV PRECISION PARK PO BOX 547 KEENE, NEW HAMPSHIRE 03431 FORMERLY MPB CORP AND MINIATURE BRG DIV MPB CORP
43991	FAG BEARING INCORPORATED 118 HAMILTON AVENUE STAMFORD, CONNECTICUT 06904 FORMERLY NORMA-HOFFMAN BEARING CORPORATION FORMERLY NORMA FAG BEARINGS CORPORATION
52828	REPUBLIC FASTENER MFG CORP 1300 RANCHO CONEJO BLVD NEWBURY PARK, CALIFORNIA 91320-1405 FORMERLY IN SYLMAR, CALIFORNIA
56878	SPS TECHNOLOGIES INC AEROSPACE AND INDUSTRIAL PRODUCTS DIV 301 HIGHLAND AVE JENKINTOWN, PENNSYLVANIA 19046 FORMERLY STANDARD PRESSED STEEL FORMERLY IN SALT LAKE, UTAH
5M902	ALCOA GLOBAL FASTENERS INC, DIV OF VOI-SHAN PRODUCTS 3000 W LOMITA BLVD TORRANCE, CALIFORNIA 90505-5103 FORMERLY FAIRCHILD INC INC FAIRCHILD AEROSPACE FASTENERS DIV
60516	WEST COAST AEROSPACE INC 812 MIRAFLORES STREET SAN PEDRO, CALIFORNIA 90731-1439

# 27-16-08

ILLUSTRATED PARTS LIST

Page 1004

Jul 01/2006



## COMPONENT MAINTENANCE MANUAL

Code	Name
62554	SIMMONDS MECAERO FASTENERS INC 1734 SEQUOIA AVENUE ORANGE, CALIFORNIA 92668
72962	HARVARD INDUSTRIES INC 3 WERNER WAY SUITE 210 LEBANON, NEW JERSEY 08833 FORMERLY ESNA V7A079 FORMERLY ELASTIC STOP NUT IN UNION, NJ
73197	HI-SHEAR TECHNOLOGY CORP 2600 SKYPARK DRIVE TORRANCE, CALIFORNIA 90509
75345	KIRKHILL RUBBER CO 300 EAST CYPRESS STREET BREA, CALIFORNIA 92821-4097 FORMERLY L.A. STANDARD RUBBER CO V84914
80539	SPS TECHNOLOGIES INC DIV AERPSOACE - SANTA ANA 2701 SOUTH HARBOR BOULEVARD SANTA ANA, CALIFORNIA 92704-5803 FORMERLY NUTT-SHEL DIV OF SPC WESTERN CO V80539 AND STANDARD PRESSED STEEL WESTERN DIV V17279
82686	HORIZON AEROSPACE LLC DBA TRANSICOIL 2560 GENERAL ARMISTEAD AVE NORRISTOWN, PENNSYLVANIA 19403-5214 FORMERLY TRANSCOIL INC. COMPONENTS & CONTROLS
83086	NEW HAMPSHIRE BALL BEARING, INC HITECH DIVISION 172 JAFFREY ROAD PETERBOROUGH, NEW HAMPSHIRE 03458
84914	Replaced: [V84914] LOS ANGELES STD RUBBER CO by Code: Name and Address below 75345: KIRKHILL RUBBER CO 300 EAST CYPRESS STREET BREA, CALIFORNIA 92821-4097 FORMERLY L.A. STANDARD RUBBER CO V84914

# 27-16-08

ILLUSTRATED PARTS LIST

Page 1005

Jul 01/2006



## COMPONENT MAINTENANCE MANUAL

Code	Name
92215	FAIRCHILD IND INC FAIRCHILD AEROSPACE FASTENER DIV 3010 W LOMITA BLVD TORRANCE, CALIFORNIA 90505-5102 FORMERLY VOI-SHAN IN CULVER CITY, CALIF
95272	STILLMAN SEL CORP 6020 AVENIDA ENCINAS CARLSBAD, CALIFORNIA 92009-1001 FORMERLY SARGENT IND
97928	Replaced: [V97928] SEE V17446 HUCK INTL by Code: Name and Address below 17446: HUCK INTL INC AEROSPACE FASTENER DIV 900 WATSON CENTER ROAD CARSON, CALIFORNIA 90745-4201 FORMERLY V32134 REXNORD INC; FORMERLY V97928 HUCK INTL
9N513	VOI SHAN/CHATSWORTH DIV OF VSI CORP SUB OF FAIRCHILD IND CHATSWORTH, CALIFORNIA 91311-5013 COMPANY NO LONGER WISHES TO BE CONSIDERED FOR FED CONTRCTG
K8455	RHP BEARINGS PLC RHP AEROSPACE OLDENDS LANE STONEHOUSE GL10 3RM UK

# 27-16-08

ILLUSTRATED PARTS LIST

Page 1006

Jul 01/2006



## COMPONENT MAINTENANCE MANUAL

### NUMERICAL INDEX

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
102LH9075-3W		1	210	3
109A9201M3		1	245	3
251A1806-1		1	215	1
251A1806-2		1	215A	1
251A1809-2		1	280	1
251A1811-1		1	230	1
251A1817-1		1	1A	RF
251A1817-2		1	1B	RF
251A1817-3		1	1C	RF
251A1817-4		1	155	1
251A1817-5		1	155A	1
251A1818-1		1	340	1
251A1818-2		1	355	1
251A1818-3		1	340A	1
251A1818-4		1	355A	1
251A1819-1		1	90	1
251A1819-2		1	115	1
253T4015-7		1	260	1
253U1116-3		1	235	1
253U1116-4		1	250	1
253U1116-5		1	255	1
2LPYT6-4		1	75	8
		1	75	8
4841		1	180	1
50-3361-4174		1	85	2
6-60428-2		1	60	1
6-60428-3		1	70	1
6-60428-6		1	60A	1
		1	60B	1
6-60428-7		1	70A	1
65-55476-14		1	300	1
65-55476-15		1	495	1
65C37031-3		1	450	1
65C37031-4		1	460	1

# 27-16-08

ILLUSTRATED PARTS LIST

Page 1007

Nov 01/2007





## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
65C37032-1		1	375	1
65C37033-1		1	435	1
65C37034-1		1	505	1
65C37035-3		1	510	1
65C37035-4		1	520	1
65C37036-1		1	400	2
65C37037-1		1	420	1
65C37038-1		1	415	2
65C37039-1		1	425	2
65C37039-2		1	430	1
65C37039-3		1	440	1
65C37039-4		1	445	1
65C37039-5		1	410	2
66-24952-1		1	55	2
69-40961-2		1	35	1
69-41762-3		1	490	3
69-41789-1		1	140	1
69-41858-2		1	330	1
69-41858-3		1	330A	1
69-41859-2		1	335	1
69-78755-1		1	380	2
69308-6A3		1	190	3
7349-6-67MM		1	465	1
ACMB542DDP818LY		1	405	6
ACMKP21BSP510LY		1	305	1
ACMKSP10A3908		1	500	1
ACMKSP10FS428		1	500	1
B542-2TS		1	370	2
B542DD		1	370	2
B542DDFS101		1	370	2
B542DDFS428		1	370	2
B542DDNJC		1	370	2
B542DDP		1	370	2
B542FS101		1	370	2
B542SSG27		1	370	2

# 27-16-08

ILLUSTRATED PARTS LIST

Page 1008

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
BAC27DCT622		1	525	1
BACB10AC10		1	500A	1
BACB10BX4		1	50	1
		1	65	1
BACB10CF21PP		1	370	2
BACB10EX21		1	305A	1
BACB10FP10		1	500	1
BACB10FU21		1	405	6
BACB10FV21		1	305	1
BACB28Y4C034		1	325	4
BACB30DX6-4		1	75	8
BACB30MB6A3		1	190	3
BACB30VT6K4		1	360	8
BACC10DK3		1	185	1
BACC10DK4		1	185A	1
BACC2A4B00321CG		1	10	1
BACC2A4B00321DG		1	15	1
BACC2C4C00262EG		1	30	1
BACC2C4C00385FG		1	25	1
BACC30BL6		1	365	8
BACC63BN10B5P		1	265	1
BACM10S28M		1	530	1
BACN10JC3CD		1	210	3
BACN10JP3ACM		1	245	3
BACN10TL3-3		1	100	1
		1	350	1
BACN10TL3A6		1	110	1
BACN10YR08CD		1	395	2
BACN10YR3CD		1	130	2
		1	485	3
BACN10YR4CD		1	45	1
		1	295	4
		1	320	4
BACP20BA1		1	180	1
BACR15BA4AD7C		1	105	2

# 27-16-08

ILLUSTRATED PARTS LIST

Page 1009

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
BACR15BB3AD5C		1	95	2
		1	345	2
BACR15BB5AD5C		1	275	2
BACR15DR3		1	240	6
BACS12BG04AP3		1	220	4
BACW10BP2NDP		1	390	2
BACW10BP3NDP		1	385	2
BRH10C3D		1	210	3
BRM200C3M		1	245	3
CS204E		1	50	1
		1	65	1
H51650-3BAC		1	210	3
H52732-08CD		1	395	2
H52732-3CD		1	130	2
		1	485	3
H52732-4CD		1	45	1
		1	295	4
		1	320	4
HHKSP10		1	500A	1
HL448UC6-3		1	190	3
		1	190	3
		1	190	3
		1	190	3
		1	190	3
		1	190	3
		1	190	3
HST10AG6-4		1	360	8
		1	360	8
		1	360	8
		1	360	8
HST79-6		1	365	8
HST79CY6		1	365	8
		1	365	8
		1	365	8
KP21BS		1	305A	1

# 27-16-08

ILLUSTRATED PARTS LIST

Page 1010

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
KP21BSFS428		1	305A	1
KP21BSLY196		1	305A	1
KP21BSNJC		1	305A	1
KP21BSSD610		1	305A	1
KP4A		1	50	1
		1	50	1
		1	65	1
		1	65	1
KP4A2TS		1	50	1
		1	65	1
KP4AFS428		1	50	1
		1	65	1
KP4AG27		1	50	1
		1	65	1
KP4ALY196		1	50	1
		1	65	1
KP4ANJC		1	50	1
		1	65	1
KP4ASD610		1	50	1
		1	65	1
KSP10		1	500A	1
KSP10-2TS		1	500A	1
KSP10E9440A		1	500A	1
KSP10FS428		1	500A	1
KSP10G27		1	500A	1
KSP10SD610		1	500A	1
LLKP4A		1	50	1
		1	65	1
MK1001-3BAC		1	245	3
MS21209C0415P		1	455	2
MS24665-132		1	5	2
N2088		1	180	1
NAS1080-06		1	80	8
NAS1149CN416R		1	225	4
NAS1149D0332J		1	125	2

# 27-16-08

ILLUSTRATED PARTS LIST

Page 1011

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
		1	480	3
NAS1149D0416J		1	40	1
		1	290	4
		1	315	4
NAS1149E0316P		1	150	1
		1	170	2
		1	200	3
		1	205	3
NAS1149E0363P		1	175	3
NAS1149F1063P		1	470	2
NAS1351N3-12P		1	475	3
NAS1352ND4-4P		1	20	2
NAS1368N16A		1	135	2
NAS1801-3-6		1	160	1
NAS1801-3-8		1	165	1
NAS623-3-3		1	145	1
NAS6603-3		1	120	2
NAS6604-22		1	285	4
NAS6604-28		1	310	4
NAS6703-3		1	195	3
		1	195A	3
NAS75-4-105		1	515	1
NS103197SE02		1	245	3
NS202486-02		1	210	3
PACMB542DDA3908		1	405	6
PACMB542DDFS428		1	405	6
PACMKP21BSA3908		1	305	1
PACMKP21BSFS428		1	305	1
PLH508CD		1	395	2
PLH53CD		1	130	2
		1	485	3
PLH54CD		1	45	1
		1	295	4
		1	320	4
SSMB542DDSD705		1	405	6

# 27-16-08

ILLUSTRATED PARTS LIST

Page 1012

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
SSMKP21BSSD705		1	305	1
SSMKSP10SD705		1	500	1
SZ7105		1	180	1
T342E		1	370	2
T6C1032JCD		1	210	3
T8080C1032		1	245	3
U221557		1	270	1
VN202D1-02		1	245	3
WC4486-3		1	190	3
WS1-4A6		1	110	1
WSI4-3		1	100	1
		1	350	1


# 27-16-08

ILLUSTRATED PARTS LIST

Page 1013

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



Aileron Control Transfer Mechanism Assembly  
IPL Figure 1 (Sheet 1 of 9)


**27-16-08**

ILLUSTRATED PARTS LIST

Page 1014

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



Aileron Control Transfer Mechanism Assembly  
IPL Figure 1 (Sheet 2 of 9)

(A)

**27-16-08**


ILLUSTRATED PARTS LIST

Page 1015

Mar 01/2006



COMPONENT MAINTENANCE MANUAL



Aileron Control Transfer Mechanism Assembly  
IPL Figure 1 (Sheet 3 of 9)


**27-16-08**

ILLUSTRATED PARTS LIST

Page 1016

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



Aileron Control Transfer Mechanism Assembly  
IPL Figure 1 (Sheet 4 of 9)


**27-16-08**

ILLUSTRATED PARTS LIST

Page 1017


Mar 01/2006

COMPONENT MAINTENANCE MANUAL



Aileron Control Transfer Mechanism Assembly  
IPL Figure 1 (Sheet 5 of 9)

COMPONENT MAINTENANCE MANUAL



(E)

Aileron Control Transfer Mechanism Assembly  
IPL Figure 1 (Sheet 6 of 9)


**27-16-08**

ILLUSTRATED PARTS LIST

Page 1019

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



Aileron Control Transfer Mechanism Assembly  
IPL Figure 1 (Sheet 7 of 9)


**27-16-08**

ILLUSTRATED PARTS LIST

Page 1020

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



Aileron Control Transfer Mechanism Assembly  
IPL Figure 1 (Sheet 8 of 9)


**27-16-08**

ILLUSTRATED PARTS LIST

Page 1021

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



Aileron Control Transfer Mechanism Assembly  
IPL Figure 1 (Sheet 9 of 9)



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
-1A	251A1817-1									A	RF
-1B	251A1817-2									B	RF
-1C	251A1817-3									C	RF
5	MS24665-132										2
10	BAC~ C2A4B00321CG										1
15	BAC~ C2A4B00321DG										1
20	NAS1352ND4-4P										2
25	BACC2C4C00385FG										1
30	BACC2C4C00262EG										1
35	69-40961-2										1
40	NAS1149D0416J										1
45	H52732-4CD										1
											(V15653) (SPEC BACN10YR4CD) (OPT PLH54CD (V62554))
50	KP4ANJC										1
											(V06144) (SPEC BACB10BX4) (OPT KP4AFS428 (V21335)) (OPT KP4A2TS (V43991)) (OPT LLKP4A (V38443)) (OPT KP4AG27 (V30163)) (OPT KP4A (V38443)) (OPT KP4ALY196 (V40920)) (OPT KP4ASD610 (V83086)) (OPT CS204E (VK8455)) (OPT KP4A (V21760))
55	66-24952-1										2
60	6-60428-2									A	1
-60A	6-60428-6									A	1
-60B	6-60428-6									B, C	1

-Item not Illustrated

**27-16-08**

ILLUSTRATED PARTS LIST

Page 1023

Nov 01/2007





## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY	
			1	2	3	4	5	6	7			
1- 65	KP4ANJC		.	.								1
70	6-60428-3		.	.						A		1
-70A	6-60428-7		.	.								1
75	2LPYT6-4		.									8
80	NAS1080-06		.									8
85	50-3361-4174		.									2
90	251A1819-1		.									1
95	BACR15BB3AD5C		.									2
100	WSI4-3		.									1
105	BACR15BA4AD7C		.									2
110	WS1-4A6		.									1
115	251A1819-2		.									1
120	NAS6603-3		.									2
125	NAS1149D0332J		.									2
130	H52732-3CD		.									2
135	NAS1368N16A		.									2

-Item not Illustrated

**27-16-08**

ILLUSTRATED PARTS LIST

Page 1024

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
140	69-41789-1		.								1
145	NAS623-3-3		.							A, B	1
150	NAS1149E0316P		.							A, B	1
-155	251A1817-4		.							C	1
-155A	251A1817-5		.							C	1
160	NAS1801-3-6		.	.						C	1
165	NAS1801-3-8		.	.						C	1
170	NAS1149E0316P		.	.						C	2
175	NAS1149E0363P		.	.						C	3
180	N2088		.								1
185	BACC10DK3		.								1
-185A	BACC10DK4		.								1
190	HL448UC6-3		.							A	3
195	NAS6703-3		.							A	3
-195A	NAS6703-3		.							B, C	3
200	NAS1149E0316P		.							A	3

-Item not Illustrated

# 27-16-08

ILLUSTRATED PARTS LIST

Page 1025

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
205	NAS1149E0316P		.	W	A	S	H	E	R	B, C	3
210	BRH10C3D		.	N	U	T				B, C	3
				(V52828)							
				(SPEC BACN10JC3CD)							
				(OPT T6C1032JCD (V11815))							
				(OPT NS202486-02 (V80539))							
				(OPT 102LH9075-3W (V72962))							
				(OPT H51650-3BAC (V15653))							
215	251A1806-1		.	T	R	A	N	S	M	A	1
-215A	251A1806-2		.	T	R	A	N	S	M	B, C	1
220	BACS12BG04AP3		.	S	C	R	E	W			4
225	NAS1149CN416R		.	W	A	S	H	E	R		4
230	251A1811-1		.	P	L	A	T	E			1
235	253U1116-3		.	R	I	N	G	A	S	S	A
				C	L	A	M	P		A	1
240	BACR15DR3		.	R	I	V	E	T		A	6
				(SIZE DETERMINED ON INST)							
245	BRM200C3M		.	N	U	T	P	L	A	A	3
				(V52828)							
				(SPEC BACN10JP3ACM)							
				(OPT MK1001-3BAC (V15653))							
				(OPT NS103197SE02 (V80539))							
				(OPT VN202D1-02 (V92215))							
				(OPT 109A9201M3 (V72962))							
				(OPT T8080C1032 (V11815))							
250	253U1116-4		.	R	I	N	G			A	1
255	253U1116-5		.	R	I	N	G			B, C	1
260	253T4015-7		.	T	R	A	N	S	M		1
				A	S	S	E	M	B		
				C	O	N	T	W	H		
				L	P	O	S				
265	BACC63BN10B5P		.	C	O	N	N	E	C		1
270	U221557		.	T	R	A	N	S	M		1
				(V82686)							
275	BACR15BB5AD5C		.	R	I	V	E	T			2
280	251A1809-2		.	C	L	I	P				1
285	NAS6604-22		.	B	O	L	T				4
290	NAS1149D0416J		.	W	A	S	H	E	R		4
295	H52732-4CD		.	N	U	T					4
				(V15653)							
				(SPEC BACN10YR4CD)							
				(OPT PLH54CD (V62554))							

-Item not Illustrated

**27-16-08**

ILLUSTRATED PARTS LIST

Page 1026

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
300	65-55476-14		.								1
305	PACMKP21BSF~ S428		.								1
-305A	KP21BSNJC		.								1
310	NAS6604-28		.								4
315	NAS1149D0416J		.								4
320	H52732-4CD		.								4
325	BACB28Y4C034		.								4
330	69-41858-2		.						A		1
-330A	69-41858-3		.						B, C		1
335	69-41859-2		.								1
340	251A1818-1		.						A		1
-340A	251A1818-3		.						B, C		1
345	BACR15BB3AD5C		.	.							2
350	WSI4-3		.	.							1
355	251A1818-2		.	.					A		1
-355A	251A1818-4		.	.					B, C		1

-Item not Illustrated

**27-16-08**

ILLUSTRATED PARTS LIST

Page 1027

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
360	HST10AG6-4		.	BOLT							8
				(V06725)							
				(SPEC BACB30VT6K4)							
				(OPT HST10AG6-4 (V73197))							
				(OPT HST10AG6-4 (V56878))							
				(OPT HST10AG6-4 (V0PTK6))							
365	HST79CY6		.	COLLAR							8
				(V73197)							
				(SPEC BACC30BL6)							
				(OPT HST79-6 (V92215))							
				(OPT HST79CY6 (V56878))							
				(OPT HST79CY6 (V5M902))							
370	B542DDNJC		.	BEARING							2
				(V06144)							
				(SPEC BACB10CF21PP)							
				(OPT B542-2TS (V43991))							
				(OPT B542DDFS428 (V21335))							
				(OPT B542SSG27 (V30163))							
				(OPT T342E (VK8455))							
				(OPT B542DDFS101 (V06144))							
				(OPT B542DD (V38443))							
				(OPT B542FS101 (V06144))							
				(OPT B542DDP (V21760))							
375	65C37032-1		.	DRUM-BUS, UPR							1
380	69-78755-1		.	BOLT							2
385	BACW10BP3NDP		.	WASHER							2
390	BACW10BP2NDP		.	WASHER							2
395	H52732-08CD		.	NUT							2
				(V15653)							
				(SPEC BACN10YR08CD)							
				(OPT PLH508CD (V62554))							
400	65C37036-1		.	RETAINER-SPR							2
405	PACMB542DDF~ S428		.	BEARING							6
				(V21335)							
				(SPEC BACB10FU21)							
				(OPT SSMB542DDSD705 (V83086))							
				(OPT PACMB542DDA3908 (V21335))							
				(OPT ACMB542DDP818LY (V40920))							
410	65C37039-5		.	SPACER							2
415	65C37038-1		.	PLATE-RETENTION							2
420	65C37037-1		.	SPRING							1

-Item not Illustrated

# 27-16-08

ILLUSTRATED PARTS LIST

Page 1028

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
425	65C37039-1		.								2
430	65C37039-2		.								1
435	65C37033-1		.								1
440	65C37039-3		.								1
445	65C37039-4		.								1
450	65C37031-3		.								1
455	MS21209C0415P		.	.							2
460	65C37031-4		.	.							1
465	7349-6-67MM		.								1
470	NAS1149F1063P		.								2
475	NAS1351N3-12P		.								3
480	NAS1149D0332J		.								3
485	H52732-3CD		.								3
490	69-41762-3		.								3
495	65-55476-15		.								1
500	SSMKSP10SD705		.								1
-500A	KSP10FS428		.								1
505	65C37034-1		.								1
510	65C37035-3		.								1
515	NAS75-4-105		.	.							1

-Item not illustrated

# 27-16-08

ILLUSTRATED PARTS LIST

Page 1029

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
520	65C37035-4										1
525	BAC27DCT622										1
530	BACM10S28M										1

-Item not Illustrated

**27-16-08**  
 ILLUSTRATED PARTS LIST  
 Page 1030  
 Mar 01/2006