



COMPONENT MAINTENANCE MANUAL WITH ILLUSTRATED PARTS LIST

FEEL AND CENTERING ELEVATOR CONTROL UNIT ASSEMBLY

PART NUMBER

**65C25465-10, -11, -12, -15, -16, -17, -18, -19, -2, -20,
-21, -22, -23, -4, -8**

BOEING PROPRIETARY, CONFIDENTIAL, AND/OR TRADE SECRET

Copyright © 1995 The Boeing Company
Unpublished Work - All Rights Reserved

Boeing claims copyright in each page of this document only to the extent that the page contains copyrightable subject matter. Boeing also claims copyright in this document as a compilation and/or collective work.

This document includes proprietary information owned by The Boeing Company and/or one or more third parties. Treatment of the document and the information it contains is governed by contract with Boeing. For more information, contact The Boeing Company, P.O. Box 3707, Seattle, Washington 98124.

Boeing, the Boeing signature, the Boeing symbol, 707, 717, 727, 737, 747, 757, 767, 777, 787, Dreamliner, BBJ, DC-8, DC-9, DC-10, KC-10, KDC-10, MD-10, MD-11, MD-80, MD-88, MD-90, P-8A, Poseidon and the Boeing livery are all trademarks owned by The Boeing Company; and no trademark license is granted in connection with this document unless provided in writing by Boeing.

PUBLISHED BY BOEING COMMERCIAL AIRPLANES GROUP, SEATTLE, WASHINGTON, USA
A DIVISION OF THE BOEING COMPANY
PAGE DATE: Jul 01/2009

27-31-95

Page 1
Jul 01/2009



COMPONENT MAINTENANCE MANUAL

Revision No. 28
Jul 01/2009

To: All holders of FEEL AND CENTERING ELEVATOR CONTROL UNIT ASSEMBLY 27-31-95.

Attached is the current revision to this COMPONENT MAINTENANCE MANUAL

The COMPONENT MAINTENANCE MANUAL is furnished either as a printed manual, on microfilm, or digital products, or any combination of the three. This revision replaces all previous microfilm cartridges or digital products. All microfilm and digital products are reissued with all obsolete data deleted and all updated pages added.

For printed manuals, changes are indicated on the List of Effective Pages (LEP). The pages which are revised will be identified on the LEP by an R (Revised), A (Added), O (Overflow, i.e. changes to the document structure and/or page layout), or D (Deleted). Each page in the LEP is identified by Chapter-Section-Subject number, page number and page date.

Pages replaced or made obsolete by this revision should be removed and destroyed.

ATTENTION

IF YOU RECEIVE PRINTED REVISIONS, PLEASE VERIFY THAT YOU HAVE RECEIVED AND FILED THE PREVIOUS REVISION. BOEING MUST BE NOTIFIED WITHIN 30 DAYS IF YOU HAVE NOT RECEIVED THE PREVIOUS REVISION. REQUESTS FOR REVISIONS OTHER THAN THE PREVIOUS REVISION WILL REQUIRE A COMPLETE MANUAL REPRINT SUBJECT TO REPRINT CHARGES SHOWN IN THE DATA AND SERVICES CATALOG.

27-31-95
TRANSMITTAL LETTER
Page 1
Jul 01/2009



COMPONENT MAINTENANCE MANUAL

Location of Change

Description of Change

NO HIGHLIGHTS

27-31-95

HIGHLIGHTS

Page 1

Jul 01/2009



COMPONENT MAINTENANCE MANUAL

Subject/Page	Date	Subject/Page	Date	Subject/Page	Date
TITLE PAGE		27-31-95 TESTING AND FAULT ISOLATION (cont)		27-31-95 REPAIR 5-1	
O 1	Jul 01/2009	108	Mar 01/2006	601	Nov 01/2006
2	BLANK	109	Mar 01/2006	602	BLANK
27-31-95 TRANSMITTAL LETTER		110	Mar 01/2006	27-31-95 REPAIR 6-1	
O 1	Jul 01/2009	111	Mar 01/2006	601	Mar 01/2006
2	BLANK	112	Mar 01/2006	602	BLANK
27-31-95 HIGHLIGHTS		113	Mar 01/2006	27-31-95 REPAIR 7-1	
O 1	Jul 01/2009	114	Mar 01/2006	601	Mar 01/2006
2	BLANK	115	Jul 01/2006	602	BLANK
27-31-95 EFFECTIVE PAGES		116	BLANK	27-31-95 REPAIR 8-1	
1 thru 2	Jul 01/2009	27-31-95 DISASSEMBLY		601	Mar 01/2006
27-31-95 CONTENTS		301	Mar 01/2006	602	BLANK
1	Mar 01/2006	302	Mar 01/2006	27-31-95 REPAIR 9-1	
2	BLANK	27-31-95 CLEANING		601	Nov 01/2006
27-31-95 TR AND SB RECORD		401	Mar 01/2006	602	BLANK
1	Mar 01/2006	402	BLANK	27-31-95 REPAIR 10-1	
2	BLANK	27-31-95 CHECK		601	Nov 01/2006
27-31-95 REVISION RECORD		501	Mar 01/2006	602	BLANK
1	Mar 01/2006	502	Mar 01/2006	27-31-95 REPAIR 11-1	
2	Mar 01/2006	27-31-95 REPAIR - GENERAL		601	Nov 01/2006
27-31-95 RECORD OF TEMPORARY REVISIONS		601	Mar 01/2006	602	BLANK
1	Mar 01/2006	602	Mar 01/2006	27-31-95 REPAIR 12-1	
2	Mar 01/2006	603	Mar 01/2006	601	Nov 01/2006
27-31-95 INTRODUCTION		604	BLANK	602	BLANK
1	Mar 01/2009	27-31-95 REPAIR 1-1		27-31-95 REPAIR 13-1	
2	BLANK	601	Mar 01/2006	601	Mar 01/2006
27-31-95 DESCRIPTION AND OPERATION		602	Mar 01/2006	602	BLANK
1	Mar 01/2006	603	Mar 01/2006	27-31-95 REPAIR 14-1	
2	BLANK	604	BLANK	601	Mar 01/2006
27-31-95 TESTING AND FAULT ISOLATION		27-31-95 REPAIR 2-1		602	BLANK
101	Nov 01/2008	601	Mar 01/2006	27-31-95 ASSEMBLY	
102	Nov 01/2007	602	Mar 01/2006	701	Nov 01/2008
103	Mar 01/2006	27-31-95 REPAIR 3-1		702	Jul 01/2008
104	Mar 01/2006	601	Mar 01/2006	703	Jul 01/2008
105	Mar 01/2006	602	Mar 01/2006	704	Jul 01/2008
106	Mar 01/2006	27-31-95 REPAIR 4-1		705	Mar 01/2006
107	Mar 01/2006	601	Nov 01/2006	706	Mar 01/2006
		602	BLANK	707	Mar 01/2006
				708	Mar 01/2006
				709	Mar 01/2006

A = Added, R = Revised, D = Deleted, O = Overflow

27-31-95

EFFECTIVE PAGES

Page 1

Jul 01/2009



COMPONENT MAINTENANCE MANUAL

Subject/Page	Date	Subject/Page	Date	Subject/Page	Date
27-31-95 ASSEMBLY (cont)		27-31-95 ILLUSTRATED PARTS LIST (cont)			
710	Mar 01/2006	1029	Mar 01/2006		
711	Mar 01/2006	1030	Mar 01/2006		
712	Nov 01/2007	1031	Mar 01/2006		
27-31-95 FITS AND CLEARANCES		1032	Mar 01/2006		
801	Jul 01/2006	1033	Mar 01/2006		
802	BLANK	1034	Mar 01/2006		
27-31-95 SPECIAL TOOLS, FIXTURES, AND EQUIPMENT		1035	Mar 01/2006		
901	Mar 01/2009	1036	Mar 01/2006		
902	BLANK	1037	Mar 01/2006		
27-31-95 ILLUSTRATED PARTS LIST		1038	Mar 01/2006		
1001	Nov 01/2008	1039	Mar 01/2006		
1002	Jul 01/2006	1040	Mar 01/2006		
1003	Mar 01/2006	1041	Mar 01/2006		
1004	Mar 01/2006	1042	Mar 01/2006		
1005	Mar 01/2006				
1006	Mar 01/2006				
1007	Mar 01/2006				
1008	Mar 01/2006				
1009	Mar 01/2006				
1010	Mar 01/2006				
1011	Mar 01/2006				
1012	Mar 01/2006				
1013	Mar 01/2006				
1014	Mar 01/2006				
1015	Mar 01/2006				
1016	Mar 01/2006				
1017	Mar 01/2006				
1018	Mar 01/2006				
1019	Mar 01/2006				
1020	Mar 01/2006				
1021	Mar 01/2006				
1022	Mar 01/2006				
1023	Mar 01/2006				
1024	Mar 01/2006				
1025	Mar 01/2006				
1026	Mar 01/2006				
1027	Mar 01/2006				
1028	Mar 01/2006				

A = Added, R = Revised, D = Deleted, O = Overflow

27-31-95

EFFECTIVE PAGES

Page 2

Jul 01/2009



COMPONENT MAINTENANCE MANUAL

TABLE OF CONTENTS

<u>Paragraph Title</u>	<u>Page</u>
ELEVATOR CONTROL FEEL AND CENTERING UNIT ASSEMBLY - DESCRIPTION AND OPERATION	1
TESTING AND FAULT ISOLATION	101
DISASSEMBLY	301
CLEANING	401
CHECK	501
REPAIR	601
ASSEMBLY	701
FITS AND CLEARANCES	801
SPECIAL TOOLS, FIXTURES, AND EQUIPMENT	901
ILLUSTRATED PARTS LIST	1001

27-31-95

CONTENTS

Page 1

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

Revision		Filed	
Number	Date	Date	Initials

Revision		Filed	
Number	Date	Date	Initials

27-31-95

REVISION RECORD

Page 2

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

All temporary revisions to this manual will be accompanied by a cover sheet bearing the temporary revision number. Enter the temporary revision number in numerical order, together with the temporary revision date, the date the temporary revision is inserted and the initials of the person filing.

When the temporary revision is incorporated or cancelled, and the pages are removed, enter the date the pages are removed and the initials of the person who removed the temporary revision.

Temporary Revision		Inserted		Removed		Temporary Revision		Inserted		Removed	
Number	Date	Date	Initials	Date	Initials	Date	Initials	Number	Date	Date	Initials

BOEING PROPRIETARY - Copyright © Unpublished Work - See title page for details



COMPONENT MAINTENANCE MANUAL

Temporary Revision		Inserted		Removed	
Number	Date	Date	Initials	Date	Initials

Temporary Revision		Inserted		Removed	
Date	Initials	Number	Date	Date	Initials

27-31-95

RECORD OF TEMPORARY REVISION



COMPONENT MAINTENANCE MANUAL

INTRODUCTION

1. General

- A. The instructions in this manual supply the data necessary to do the maintenance functions together with the test, fault isolation, repair, and replacement of the defective parts.
- B. This manual is divided into different parts:
 - (1) Title Page
 - (2) Transmittal Letter
 - (3) Highlights
 - (4) List of Effective Pages
 - (5) Table of Contents
 - (6) Temporary Revision & Service Bulletin Record
 - (7) Record of Revisions
 - (8) Record of Temporary Revisions
 - (9) Introduction
 - (10) Procedures & IPL Sections
- C. Components that can be repaired have a different repair number for each specified repair. To find the repair number location of a component, look in the Repair-General procedure at the beginning of the REPAIR section. The Repair-General procedure also has an explanation of the True Position Dimension symbols used.
- D. All dimensions, measures, quantities and weights included are in English units. When metric equivalents are given they will be in the parentheses that follow the English units.
- E. The introduction to the Illustrated Parts List (IPL) shows how the IPL data is used.
- F. Design changes, optional parts, configuration differences and Service Bulletin modifications may cause different part numbers. These part numbers are identified in the IPL with an alphabetical letter which is added to the end of the basic item number. This new item number is referred to as an alpha-variant. Throughout the manual, IPL basic item number references also apply to alpha-variants unless shown differently.
- G. The tool reference numbers found in the individual procedures and in the Special Tools, Fixtures, and Equipment section are used to identify if a tool is a standard tool (STD-XXXX), a commercial tool (COM-XXXX), or a Special Tool (SPL-XXXX). This reference number is also used to distinguish between tools with similar names in the same procedure. These reference numbers are for use in the documentation only. They are not to be used for ordering tools.

27-31-95

INTRODUCTION

Page 1

Mar 01/2009



COMPONENT MAINTENANCE MANUAL

ELEVATOR CONTROL FEEL AND CENTERING UNIT ASSEMBLY - DESCRIPTION AND OPERATION

1. Description

- A. The elevator control feel and centering unit assembly consists of a mechanical centering unit assembly and a hydraulically-operated feel actuator.
- B. The centering unit assembly consists of a spring loaded cam follower assembly riding on a cam shaft assembly. The camshaft assembly also connects to the lever assembly thru tie assemblies and a link assembly. All these parts are mounted inside a housing assembly. The input crank assembly attaches to the camshaft assembly and activates the centering unit assembly.

2. Operation

- A. The elevator control feel and centering unit assembly provides mechanical centering of the elevator control thru the spring loaded centering cam mechanism. The unit also provides artificial feel thru a mechanical linkage actuated by a hydraulic feel actuator.

3. Leading Particulars (Approximate)

- A. Length – 13 inches
- B. Width – 5 inches
- C. Height – 10 inches
- D. Weight – 10 pounds

27-31-95

DESCRIPTION AND OPERATION

Page 1

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

TESTING AND FAULT ISOLATION

1. General

- A. This procedure has the data necessary to do a test of the elevator control feel and centering unit assembly (1A) after an overhaul or for fault isolation.
- B. Refer to the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 and IPL Figure 2 for item numbers.

2. Testing

- A. Tools/Equipment

NOTE: Equivalent substitutes may be used.

Reference	Description
SPL-5349	X-Y Recorder/Plotter (Part #: 925E, Supplier: 60795)
SPL-5351	Test Equipment - Elevator Feel and Centering Unit (Part #: A27041-175, Supplier: 81205)
SPL-5352	Readout and Control Equipment - Functional Test Stand (Part #: A27081-1, Supplier: 81205)
SPL-5446	X-Y recorder (Part #: RW20IT, Supplier: 31991) (Opt Part #: 7046A, Supplier: 28480) (Opt Part #: 7090A, Supplier: 28480)

- B. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
D00153	Fluid - Hydraulic, Erosion Arresting, Fire Resistant	BMS3-11 Type IV (interchange~ able & intermixable with Type V)

- C. Materials and Equipment

NOTE: Equivalent substitutes may be used.

- (1) X-Y Plotter (Hewlett Packard Co.; Model HP7045B, X-Y recorder, SPL-5446, or Allen Datagraph; Model 925E, X-Y recorder/plotter, SPL-5349, or equivalent) with provisions for recording:
 - (a) Angular displacement up to 30 degrees in both directions from a zero.
 - (b) Torque up to 1900 pound-inches in both directions from a zero.
- (2) Hydraulic test stand capable of supplying BMS 3-11 hydraulic fluid, D00153 at a constant pressure up to 2100 psig. Fluid shall be filtered per TESTING AND FAULT ISOLATION, Table 101.

27-31-95

TESTING AND FAULT ISOLATION

Page 101

Nov 01/2008



COMPONENT MAINTENANCE MANUAL

Table 101: Hydraulic Fluid Filtering Chart

PARTICLE SIZE (MICRONS)	QUANTITY (MAX) 100 ML
10-25	6,000
26-50	1,400
51-100	400
101-150	20
over 150	0

D. Preparation for Test

- (1) Mount unit in A27041-161 Test Equipment - Elevator Feel and Centering Unit, SPL-5351 per TESTING AND FAULT ISOLATION, Figure 101 and attach the A27081-1 Readout Equipment, SPL-5352 per equipment instructions.
- (2) Connect instruments, X-Y plotter and check calibration.

NOTE: The X-Y plotter (Hewlett Packard Co., X-Y recorder, SPL-5446; Allen Datagraph, X-Y recorder/plotter, SPL-5349, or equivalent) shall have provisions for recording:

Angular displacement up to 30 degrees in both directions from zero.

Torque up to 1900 pound-inches in both directions from a zero.


27-31-95

TESTING AND FAULT ISOLATION

Page 102

Nov 01/2007

COMPONENT MAINTENANCE MANUAL



Functional Test Setup
Figure 101

27-31-95

TESTING AND FAULT ISOLATION

Page 103

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

E. Test 65C25465-2, -12, -15, -18 thru -23 Assemblies

- (1) Test unit at 0 psi hydraulic pressure.
 - (a) With actuator assembly (60, IPL Figure 1) ports open, cycle unit a minimum of five times, then rotate input crank clockwise and counterclockwise and check the breakout torque.
 - (b) Check that breakout torque is Clockwise Rotation 58-73 pound-inches Counterclockwise Rotation 49-64 pound-inches
 - (c) If the torque values exceed these limits, loosen retainer (210, IPL Figure 2) and rotate post assembly (410) as required.
 - (d) Repeat check in TESTING AND FAULT ISOLATION, Paragraph 2.E.(1)(a) and TESTING AND FAULT ISOLATION, Paragraph 2.E.(1)(b).
 - (e) Rotate input crank counterclockwise and clockwise through full travel and plot input torque vs. input crank rotation. The resulting curve shall be continuous and smooth and fall entirely within the boundaries shown in TESTING AND FAULT ISOLATION, Figure 102.
- (2) Check input crank rotation.
 - (a) Connect hydraulic pressure supply to actuator assembly pressure ports A and B. Leave return ports open.
 - (b) Apply hydraulic pressure simultaneously to pressure ports A and B and slowly increase pressure from 0 to 190-210 psig. Check that input crank rotation does not exceed 0.05 degree.
 - (c) Remove hydraulic pressure.
 - (d) Apply hydraulic pressure simultaneously to pressure ports A and B and slowly increase pressure from 0 to 2050-2150 psig. Check that input shaft rotation does not exceed 0.10 degree.
 - (e) Remove hydraulic pressure.
- (3) Test unit at 190-210 psig hydraulic pressure.
 - (a) Apply 190-210 psig hydraulic pressure simultaneously to pressure ports A and B.
 - (b) Rotate input crank clockwise and counterclockwise and check that total clockwise plus counterclockwise breakout torque is 150 pound-inches maximum.
 - (c) With 190-210 psig hydraulic pressure applied simultaneously to pressure ports A and B, rotate input crank through a complete cycle, starting from zero in a clockwise direction. The rate of rotation shall be approximately 5-20 degrees/second.
 - (d) Plot input torque versus input crank rotation. Check that the resultant curve is continuous, smooth and falls entirely within the boundaries specified in TESTING AND FAULT ISOLATION, Figure 103.
 - (e) Repeat test in TESTING AND FAULT ISOLATION, Paragraph 2.E.(3)(c) and TESTING AND FAULT ISOLATION, Paragraph 2.E.(3)(d) except apply 190-210 psig hydraulic pressure to pressure port A only.
 - (f) Repeat test in TESTING AND FAULT ISOLATION, Paragraph 2.E.(3)(c) and TESTING AND FAULT ISOLATION, Paragraph 2.E.(3)(d) except apply 190-210 psig hydraulic pressure to pressure port B only.
- (4) Test unit at 2050-2150 psig hydraulic pressure.
 - (a) Apply 2050-2150 psig hydraulic pressure simultaneously to pressure ports A and B.

27-31-95

TESTING AND FAULT ISOLATION

Page 104

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

- (b) Rotate input crank through a complete cycle, starting from a zero in the clockwise direction. The rate of rotation shall be 5-20 degrees/second.
 - (c) Plot input torque versus input crank rotation. Check that the resultant curve is continuous, smooth and falls entirely within the boundaries specified in TESTING AND FAULT ISOLATION, Figure 104.
 - (d) Repeat test in TESTING AND FAULT ISOLATION, Paragraph 2.E.(4)(b) and TESTING AND FAULT ISOLATION, Paragraph 2.E.(4)(c) except apply 2050-2150 psig hydraulic pressure to pressure port A only.
 - (e) Repeat test in TESTING AND FAULT ISOLATION, Paragraph 2.E.(4)(b) and TESTING AND FAULT ISOLATION, Paragraph 2.E.(4)(c) except apply 2050-2150 psig hydraulic pressure to pressure port B only.
- (5) Reduce hydraulic pressure to 200 psig.

CAUTION: TORQUE VALUE AT INTERNAL STOPS MUST NOT EXCEED 1400 POUND-INCHES OR DAMAGE TO PART MAY RESULT.

- (a) Rotate input crank clockwise until internal stop is contacted and check that minimum travel is 21 degrees.
 - (b) Rotate input crank counterclockwise until internal stop is contacted and check that minimum travel is 24.5 degrees.
- (6) After completing the test, prepare actuator assembly for shipping and storage per OHM 27-09-09.

27-31-95


TESTING AND FAULT ISOLATION

Page 105

Mar 01/2006



COMPONENT MAINTENANCE MANUAL



65C25465-2,-12,-15,-18 thru -23 Assemblies Only Input Torque vs Crank Rotation - Zero Psig
Figure 102

27-31-95


TESTING AND FAULT ISOLATION

Page 106

Mar 01/2006



COMPONENT MAINTENANCE MANUAL



65C25465-2,-12,-15,-18 thru -23 Assemblies Only Input Torque vs Crank Rotation - 190 to 210 Psig
Figure 103

27-31-95


TESTING AND FAULT ISOLATION

Page 107

Mar 01/2006



COMPONENT MAINTENANCE MANUAL



65C25465-2,-12,-15,-18 thru -23 Assemblies Only Input Torque vs Crank Rotation - 2050 to 2150 Psig
Figure 104

27-31-95

TESTING AND FAULT ISOLATION

Page 108

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

F. Test 65C25465-4, -8, -10, -11, -16, -17 Assemblies

- (1) Test unit without hydraulic pressure.
 - (a) With actuator assembly (60, IPL Figure 1) ports open, cycle unit a minimum of 5 times, then rotate input crank clockwise and counterclockwise and check the breakout torque.
 - (b) Check that breakout torque is Clockwise Rotation 60-75 pound-inches Counterclockwise Rotation 50-65 pound-inches
 - (c) If the torque values exceed these limits, loosen retainer (210, IPL Figure 2) and rotate post assembly (410) as required.
 - (d) Repeat check per TESTING AND FAULT ISOLATION, Paragraph 2.F.(1)(a) and TESTING AND FAULT ISOLATION, Paragraph 2.F.(1)(b).
 - (e) Rotate input crank counterclockwise and clockwise through full travel and plot input torque vs. input crank rotation. The resultant curve shall be continuous and smooth and fall entirely within the boundaries shown in TESTING AND FAULT ISOLATION, Figure 105.
- (2) Check input crank rotation.
 - (a) Connect hydraulic pressure supply to feel actuator pressure ports A and B. Leave return ports open.
 - (b) Apply hydraulic pressure simultaneously to pressure ports A and B and slowly increase pressure from 0 to 190-210 psig. Check that input crank does not rotate more than 0.05 degree.
 - (c) Remove hydraulic pressure.
 - (d) Apply hydraulic pressure simultaneously to pressure ports A and B and slowly increase pressure from 0 to 2050-2150 psig. Check that input crank does not rotate more than 0.10 degree.
- (3) Test unit at 245-265 psig hydraulic pressure.
 - (a) Apply 245-265 psig hydraulic pressure simultaneous to pressure ports A and B.
 - (b) Rotate input crank clockwise and counterclockwise and check that total clockwise plus counterclockwise breakout torque is 150 pound-inches maximum.
 - (c) With 245-265 psig hydraulic pressure applied simultaneously to pressure ports A and B, rotate input crank through a complete cycle, starting from zero in a clockwise direction. The rate of rotation shall be approximately 5-20 degrees/second.
 - (d) Plot input torque versus input crank rotation. Check that the resultant curve is continuous, smooth and falls entirely within the boundaries specified in TESTING AND FAULT ISOLATION, Figure 106.
 - (e) Repeat test per TESTING AND FAULT ISOLATION, Paragraph 2.F.(3)(c) and TESTING AND FAULT ISOLATION, Paragraph 2.F.(3)(d) except apply 245-255 psig to pressure port A only.
 - (f) Repeat test per TESTING AND FAULT ISOLATION, Paragraph 2.F.(3)(c) and TESTING AND FAULT ISOLATION, Paragraph 2.F.(3)(d) except apply 245-255 psig to pressure port B only.
- (4) Test unit at 2050-2150 psig hydraulic pressure.
 - (a) Apply 2050-2150 psig hydraulic pressure simultaneously to pressure ports A and B.
 - (b) Rotate input crank through a complete cycle, starting from a zero in a clockwise direction. The rate of rotation shall be 5-20 degrees/second.

27-31-95

TESTING AND FAULT ISOLATION

Page 109

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

- (c) Plot input torque versus input crank rotation. Check that the resultant curve is smooth and continuous and falls entirely within the boundaries specified in TESTING AND FAULT ISOLATION, Figure 107.
 - (d) Repeat test per TESTING AND FAULT ISOLATION, Paragraph 2.F.(4)(b) and TESTING AND FAULT ISOLATION, Paragraph 2.F.(4)(c) except apply 2050-2150 psig hydraulic pressure to pressure port A only.
 - (e) Repeat test TESTING AND FAULT ISOLATION, Paragraph 2.F.(4)(b) and TESTING AND FAULT ISOLATION, Paragraph 2.F.(4)(c) except apply 2050-2150 psig hydraulic pressure to pressure port B only.
- (5) Reduce hydraulic pressure to 200 psig.

CAUTION: TORQUE VALUE AT INTERNAL STOPS MUST NOT EXCEED 1400 POUND-INCHES OR DAMAGE TO PART MAY RESULT.

- (a) Rotate input crank clockwise until internal stop is contacted and check that minimum travel is 21 degrees.
 - (b) Rotate input crank counterclockwise until internal stop is contacted and check that minimum travel is 24.5 degrees.
- (6) After completing the test, prepare actuator assembly for shipping and storage per OHM 27-09-09.

Table 102: Trouble Shooting Chart

TROUBLE	PROBABLE CAUSE	CORRECTION
Steps per TESTING AND FAULT ISOLATION, Paragraph 2.E.(1)(e), TESTING AND FAULT ISOLATION, Paragraph 2.F.(1)(e).	Defective camshaft assembly	Replace camshaft assembly per TESTING AND FAULT ISOLATION, Paragraph 2.G.(1).
Steps per TESTING AND FAULT ISOLATION, Paragraph 2.E.(2), TESTING AND FAULT ISOLATION, Paragraph 2.F.(2).	Incorrect cam indexing	Replace camshaft assembly per TESTING AND FAULT ISOLATION, Paragraph 2.G.(1).
Steps per TESTING AND FAULT ISOLATION, Paragraph 2.E.(3)(c), TESTING AND FAULT ISOLATION, Paragraph 2.E.(3)(d); TESTING AND FAULT ISOLATION, Paragraph 2.E.(4)(b), TESTING AND FAULT ISOLATION, Paragraph 2.E.(4)(c); TESTING AND FAULT ISOLATION, Paragraph 2.F.(3)(c), TESTING AND FAULT ISOLATION, Paragraph 2.F.(3)(d); TESTING AND FAULT ISOLATION, Paragraph 2.F.(4)(b), TESTING AND FAULT ISOLATION, Paragraph 2.F.(4)(c).	Defective centering unit assembly	Disassemble and replace part per TESTING AND FAULT ISOLATION, Paragraph 2.G.(2).

27-31-95

TESTING AND FAULT ISOLATION

Page 110

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

Table 102: Trouble Shooting Chart (Continued)

TROUBLE	PROBABLE CAUSE	CORRECTION
Steps per TESTING AND FAULT ISOLATION, Paragraph 2.E.(3)(e), TESTING AND FAULT ISOLATION, Paragraph 2.E.(3)(f); TESTING AND FAULT ISOLATION, Paragraph 2.E.(4)(d), TESTING AND FAULT ISOLATION, Paragraph 2.E.(4)(e); TESTING AND FAULT ISOLATION, Paragraph 2.F.(3)(e), TESTING AND FAULT ISOLATION, Paragraph 2.F.(3)(f); TESTING AND FAULT ISOLATION, Paragraph 2.F.(4)(d), TESTING AND FAULT ISOLATION, Paragraph 2.F.(4)(e).	Defective feel actuator assembly	Disassemble and replace part per TESTING AND FAULT ISOLATION, Paragraph 2.G.(2).
Steps per TESTING AND FAULT ISOLATION, Paragraph 2.E.(5), TESTING AND FAULT ISOLATION, Paragraph 2.F.(5).	Binding or defective centering unit assembly	Disassemble and replace part per TESTING AND FAULT ISOLATION, Paragraph 2.G.(2).
NOTE: Trouble shooting is keyed to the test steps.		

27-31-95


TESTING AND FAULT ISOLATION

Page 111

Mar 01/2006



COMPONENT MAINTENANCE MANUAL



65C25465-4,-8,-10,-11,-16,-17 Assemblies Only Input Torque vs Crank Rotation - Zero Psig
Figure 105

27-31-95


TESTING AND FAULT ISOLATION

Page 112

Mar 01/2006



COMPONENT MAINTENANCE MANUAL



Input Torque vs Crank Rotation - 245 to 265 Psig
Figure 106

27-31-95


TESTING AND FAULT ISOLATION

Page 113

Mar 01/2006



COMPONENT MAINTENANCE MANUAL



65C25465-4,-8,-10,-11,-16,-17 Assemblies Only Input Torque vs Crank Rotation - 2050 to 2150 Psig
Figure 107

27-31-95

TESTING AND FAULT ISOLATION

Page 114

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

G. Corrective Procedures

- (1) Replace camshaft assembly (665A, IPL Figure 2).
 - (a) Completely disassemble unit per DISASSEMBLY and replace camshaft assembly.
 - (b) Assemble parts per ASSEMBLY ASSEMBLY, Paragraph 2.D.(1) thru ASSEMBLY, Paragraph 2.D.(4), ASSEMBLY, Paragraph 2.D.(7) thru ASSEMBLY, Paragraph 2.D.(9), ASSEMBLY, Paragraph 2.E.(1) thru ASSEMBLY, Paragraph 2.E.(6).
 - (c) Retest unit.
- (2) Disassemble feel and centering unit assembly.
 - (a) Disassemble unit per DISASSEMBLY DISASSEMBLY, Paragraph 3.A., DISASSEMBLY, Paragraph 3.B., DISASSEMBLY, Paragraph 3.C..
 - (b) Refer to OHM 27-09-09 for testing and repair procedures of cylinder assembly (90, IPL Figure 1).
 - (c) Disassemble centering unit assembly per DISASSEMBLY DISASSEMBLY, Paragraph 4. as required.
 - (d) Reassemble cylinder assembly and centering unit assembly per ASSEMBLY ASSEMBLY, Paragraph 2.E.(1) thru ASSEMBLY, Paragraph 2.E.(5).
 - (e) Retest unit.

27-31-95

TESTING AND FAULT ISOLATION

Page 115

Jul 01/2006



COMPONENT MAINTENANCE MANUAL

DISASSEMBLY

1. General

- A. Refer to TESTING AND FAULT ISOLATION to establish the condition of the component or most probable cause of its malfunction. This is to determine the extent of disassembly required without completely tearing down and rebuilding the component.

2. Parts Replacement

NOTE: The following parts are recommended for replacement. Unless otherwise specified, actual replacement of parts may be based on in-service experience.

- A. Nuts (5, 15, 95 IPL Figure 1; 50, 90, 180, 215, 530, 580, 630, IPL Figure 2)
- B. Packings (70, 85, IPL Figure 1)
- C. Lock bolts (525A, 575A, 625A, IPL Figure 2) and collars (520A, 570A, 620A)

3. Disassemble Feel and Centering Unit Assemblies (IPL Figure 1)

- A. Remove nuts (5, 15), washers (10, 20), bolt assemblies (25, 40), bushing (55A), and separate actuator assembly (60) from centering unit assembly (120A).
- B. Remove nut (95), washer (100), bushing (105), slide block (110) and fitting (115) from actuator assembly (60).
- C. Remove unions (65, 75), reducer (80) from cylinder assembly (90). Remove packings (70) from unions (65) and packings (85) from union (75) and reducer (80).
- D. Refer to OHM 27-09-09 for disassembly procedures of cylinder assembly (90).

4. Disassembly of Centering Unit Assembly (IPL Figure 2)

CAUTION: DO NOT DISASSEMBLE BONDED ASSEMBLY OR DAMAGE TO PARTS MAY RESULT.

- A. Remove rivet (5) or bolt (5A) and collar (6), retainer (10) and bearing housing assembly (15) from camshaft assembly (665A).
- B. Remove nuts (50), washers (55), bolts (60), input crank assembly (45), and spacer (80) from camshaft assembly (665A).
- C. On 65C25505-6, -9 assemblies, remove nuts (90), washers (95), bolts (100) and crank assembly (85) from camshaft assembly (665D).
- D. Remove rivets (115) or bolt (115A) and collar (116), retainer (120), bearing housing assembly (125) and crank assembly (155) from camshaft assembly (665A).
- E. Remove screws (170) and cover plate (175).

CAUTION: HOUSING ASSEMBLY (250A) COMPRISES MATCHING BOND ASSEMBLIES AND MUST BE KEPT TOGETHER TO ENSURE PROPER OPERATION AFTER ASSEMBLY.

- F. Remove housing assembly (250A).
 - (1) On top assemblies 65C25505-11, -12, -14, remove stop support assembly (192), bushings (187, 188, 189), bolts (152, 153, 157), washers (167, 168, 177) and nuts (182, 183, 184).
 - (2) Remove nut (180), washer (185) and inner shaft (190) from housing assembly (250A).
 - (3) Remove rivets (195A) or lockbolts (195B), washers (197) and collars (196), and push inner shaft (200) out of outer shaft (430).

27-31-95

DISASSEMBLY

Page 301

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

WARNING: SPRING POST ASSEMBLY (410) IS PRELOADED BY SPRINGS (400, 405). USE CARE WHILE REMOVING RETAINER (210) TO AVOID PERSONNEL INJURY.

- (4) Restrain spring post assembly (410) and remove screws (205) and retainer (210). Carefully rotate spring post assembly (410) until minimum spring force is felt.
 - (5) Remove nuts (215), washers (220), bolts (225, 226, 230, 235), bushings (240) and retainers (245). On top assemblies 65C25505-13, 15, -16, remove nut (181), washer (172), bolt (151) and bushing (186).
 - (6) Slide housing bond assembly (325A) off from shafts (430, 515) and camshaft assembly (665A).
 - (7) Restrain cam follower assembly (435) and remove springs (400, 405) from spring post assembly (410). Remove spring post assembly from housing bond assembly (305A).
 - (8) Remove actuator fitting assembly (375) from housing bond assembly (305A).
 - (9) Remove outer shaft (430) from housing bond assembly (305A) and remove cam follower assembly (435).
 - (10) Remove housing bond assembly (305A) from shaft (515) and cam shaft assembly (665A). Tag and keep housing bond assemblies (305A, 325A) together as a matched set.
- G. On 65C25505-4, -6, -8, -9 assemblies, remove rivets (352) and bracket assembly (345) if required.
- H. Remove bearings (500) and bushing (505) from cam follower assembly (435).
- I. Remove bearings (510) and outer shaft (515) from lever assembly (545).
- J. Remove parts (520A thru 540) and separate link assembly (600) and lever assembly (545).
- K. Remove parts (570A thru 595) and remove link assembly (600).
- L. Remove parts (620A thru 645) and remove tie assemblies (650) from camshaft assembly (665).
- NOTE:** Note numbers of washers (627, 637) to facilitate assembly.
- M. Do not separate cam assembly (690A) from feel lever assembly (695).

27-31-95

DISASSEMBLY

Page 302

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

CLEANING

1. General

- A. This procedure contains the data necessary to clean special parts.
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 and IPL Figure 2 for item numbers.

2. Cleaning

A. References

Reference	Title
SOPM 20-30-03	GENERAL CLEANING PROCEDURES

B. Procedure

- (1) Clean all parts except sealed bearings using standard industry practices and information contained in SOPM 20-30-03.
- (2) Clean sealed bearings according to the manufacturer's instructions.

27-31-95

CLEANING

Page 401

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

CHECK

1. General

- A. This procedure contains the data necessary to find defects in the material of specified parts.
- B. Refer to FITS AND CLEARANCES for the design dimension and wear limits.
- C. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- D. Refer to IPL Figure 1 and IPL Figure 2 for item numbers.

2. Check

A. References

Reference	Title
SOPM 20-20-01	MAGNETIC PARTICLE INSPECTION
SOPM 20-20-02	PENETRANT METHODS OF INSPECTION

B. Procedure

- (1) Check all parts for obvious defects in accordance with standard industry practices.
- (2) Magnetic particle check per SOPM 20-20-01 the following parts:
 - (a) Bolts (30, 45, IPL Figure 1)
 - (b) Fitting (115, IPL Figure 1)
 - (c) Shafts (190, 515, IPL Figure 2)
 - (d) Springs (400, P/N 69-73361-1; 405, P/N 69-73360-1, IPL Figure 2)
 - (e) Bolts (535, 585, 635, IPL Figure 2)
 - (f) Tie assemblies (650, IPL Figure 2)
 - (g) Cam assembly (690A, IPL Figure 2)
- (3) Penetrant check per SOPM 20-20-02 the following parts:
 - (a) Retainers (10, 30, 120, 120A, 140, 210, 245, 260, IPL Figure 2)
 - (b) Housing assembly (40, 150, IPL Figure 2)
 - (c) Bonded assembly (75, IPL Figure 2)
 - (d) Spacer (80, IPL Figure 2)
 - (e) Crank (110, 165, IPL Figure 2)
 - (f) Cover plate (175, IPL Figure 2)
 - (g) Shaft (200, IPL Figure 2)
 - (h) Bond assembly (305A, 325A, IPL Figure 2)
 - (i) Bonded assembly (395, IPL Figure 2)
 - (j) Springs (400A, 400B, P/N 251A2184-2, -3; 405A, P/N 251A2190-2, IPL Figure 2)
 - (k) Post (425, IPL Figure 2)
 - (l) Retainer (480, IPL Figure 2)
 - (m) Follower assemblies (490, 495, IPL Figure 2)
 - (n) Lever assemblies (565, IPL Figure 2)

27-31-95

CHECK

Page 501

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

- (o) Bond assembly (615, IPL Figure 2)
- (4) Check spring (400, P/N 69-73361-1, IPL Figure 2).
 - (a) Extend spring to 6.35 inches and check that load is 18.5-20.5 pounds.
 - (b) Extend spring to 7.35 inches and check that load is 76.1-92.9 pounds.
- (5) Check spring (400A, P/N 251A2190-2, IPL Figure 2)
 - (a) Extend spring to 6.35 inches and check that load is 17.60-21.40 pounds.
 - (b) Extend spring to 7.90 inches and check that load is 108.25-132.25 pounds.
- (6) Check spring (405, P/N 69-73360-1, IPL Figure 2).
 - (a) Extend spring to 6.26 inches and check that load is 10-11 pounds.
 - (b) Extend spring to 7.26 inches and check that load is 41-50 pounds.
- (7) Check spring (405A, 405B, P/N 251A2184-2, -3, IPL Figure 2).
 - (a) Extend spring to 5.98 inches and check that load is 9.50-11.50 pounds.
 - (b) Extend spring to 7.53 inches and check that load is 58.25-71.25 pounds.

27-31-95

CHECK
Page 502
Mar 01/2006



COMPONENT MAINTENANCE MANUAL

REPAIR

1. Content

A. Repair, refinish and replacement procedures are included in separate repair sections as follows:

Table 601:

<u>P/N</u>	<u>NAME</u>	<u>REPAIR</u>
65C25439	HOUSING	1-1
65C25485	LEVER	2-1
65C25487	FITTING - ACTUATOR	3-1
65C25504	CRANK	4-1
65C25510	LEVER - FEEL	5-1
65C25511	LEVER - FEEL	5-1
65C25512	FOLLOWER - CAM	6-1
69-73340	RETAINER - SPRING	7-1
69-73349	HOUSING - BEARING	8-1
69-73351-1	SHAFT - OUTER	9-1
69-73352	SHAFT - INNER	10-1
69-73353	SHAFT - OUTER	11-1
69-73435	LINK	12-1
- -	MISC. PARTS REFINISH	13-1
BAC27DCT0346	MARKER	14-1

2. Standard Practices

- A. Refer to the following standard practices as applicable, for details of procedures in individual repairs.
- SOPM 20-30-02 Stripping of Protective Finishes
 - SOPM 20-30-03 General Cleaning Procedures
 - SOPM 20-41-01 Decoding Table for Boeing Finish Codes
 - SOPM 20-41-02 Application of Chemical and Solvent Resistant Finishes
 - SOPM 20-43-01 Chromic Acid Anodizing
 - SOPM 20-50-05 Application of Aluminum Foil and Other Markers
 - SOPM 20-50-03 Bearing Installation and Retention
 - SOPM 20-60-03 Lubricants

3. Materials

NOTE: Equivalent substitutes may be used.

- A. Primer – BMS 10-11, Type 1 primer, C00259
 B. Sealant – BMS 5-95 sealant, A00247
 C. Grease – BMS 3-33 grease, D00633

27-31-95

REPAIR - GENERAL

Page 601

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

4. Dimensioning Symbols

- A. Standard True Position Dimensioning Symbols used in the applicable repair procedures are shown in REPAIR-GENERAL, Figure 601.

27-31-95

REPAIR - GENERAL

Page 602

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

—	STRAIGHTNESS	\oplus	THEORETICAL EXACT POSITION OF A FEATURE (TRUE POSITION)
\square	FLATNESS	\varnothing	DIAMETER
\perp	PERPENDICULARITY (OR SQUARENESS)	$s \varnothing$	SPHERICAL DIAMETER
//	PARALLELISM	R	RADIUS
\bigcirc	ROUNDNESS	SR	SPHERICAL RADIUS
\bigcirc (with slash)	CYLINDRICITY	()	REFERENCE
\frown	PROFILE OF A LINE	BASIC (BSC) OR	A THEORETICALLY EXACT DIMENSION USED TO DESCRIBE SIZE, SHAPE OR LOCATION OF A FEATURE FROM WHICH PERMISSIBLE VARIATIONS ARE ESTABLISHED BY TOLERANCES ON OTHER DIMENSIONS OR NOTES.
\triangle	PROFILE OF A SURFACE	DIM	
\odot	CONCENTRICITY	-A-	DATUM
\equiv	SYMMETRY	\textcircled{M}	MAXIMUM MATERIAL CONDITION (MMC)
\sphericalangle	ANGULARITY	\textcircled{L}	LEAST MATERIAL CONDITION (LMC)
\nearrow	RUNOUT	\textcircled{S}	REGARDLESS OF FEATURE SIZE (RFS)
\nearrow (with double arrow)	TOTAL RUNOUT	\textcircled{P}	PROJECTED TOLERANCE ZONE
\sqsubset	COUNTERBORE OR SPOTFACE	FIM	FULL INDICATOR MOVEMENT
\sphericalangle (with double arrow)	COUNTERSINK	TIR	TOTAL INDICATOR READING

EXAMPLES

$\boxed{-0.002}$	STRAIGHT WITHIN 0.002	$\boxed{\textcircled{\varnothing}0.0005 C}$	CONCENTRIC TO C WITHIN 0.0005 DIAMETER
$\boxed{\perp 0.002 B}$	PERPENDICULAR TO B WITHIN 0.002	$\boxed{\equiv 0.010 A}$	SYMMETRICAL WITH A WITHIN 0.010
$\boxed{\parallel 0.002 A}$	PARALLEL TO A WITHIN 0.002	$\boxed{\sphericalangle 0.005 A}$	ANGULAR TOLERANCE 0.005 WITH A
$\boxed{\bigcirc 0.002}$	ROUND WITHIN 0.002	$\boxed{\oplus \varnothing 0.002 \textcircled{S} B}$	LOCATED AT TRUE POSITION WITHIN 0.002 DIA RELATIVE TO DATUM B, REGARDLESS OF FEATURE SIZE
$\boxed{\bigcirc 0.010}$	CYLINDRICAL SURFACE MUST LIE BETWEEN TWO CONCENTRIC CYLINDERS, ONE OF WHICH HAS A RADIUS 0.010 INCH GREATER THAN THE OTHER	$\boxed{\perp \varnothing 0.010 \textcircled{M} A}$	AXIS IS TOTALLY WITHIN A CYLINDER OF 0.010-INCH DIAMETER, PERPENDICULAR TO, AND EXTENDING 0.510-INCH ABOVE, DATUM A, MAXIMUM MATERIAL CONDITION
$\boxed{\frown 0.006 A}$	EACH LINE ELEMENT OF THE SURFACE AT ANY CROSS SECTION MUST LIE BETWEEN TWO PROFILE BOUNDARIES 0.006 INCH APART RELATIVE TO DATUM PLANE A	$\boxed{0.510 \textcircled{P}}$	
$\boxed{\triangle 0.020 A}$	SURFACES MUST LIE WITHIN PARALLEL BOUNDARIES 0.02 INCH APART AND EQUALLY DISPOSED ABOUT TRUE PROFILE	$\boxed{2.000}$	THEORETICALLY EXACT DIMENSION IS 2.000
		OR	
		2.000	
		BSC	
		$\boxed{0.020 A}$	
		$\boxed{A 0.020}$	

NOTE: DATUM MAY APPEAR AT EITHER SIDE OF TOLERANCE FRAME

True Position Dimensioning Symbols
Figure 601

27-31-95

REPAIR - GENERAL

Page 603

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

HOUSING ASSEMBLY - REPAIR 1-1

65C25439-2, -17

1. General

- A. The procedure has the data necessary to repair and refinish the housing assembly (250A, IPL Figure 2).
- B. Refer to REPAIR-GENERAL, Paragraph 2. for the Standard Overhaul Practice Manual (SOPM) subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Paragraph 3. for the description of the consumable codes identified in this procedure.
- D. Refer to IPL Figure 2 for item numbers.

2. Bearing (265) Replacement (REPAIR 1-1, Figure 601)

- A. Remove rivets (255) and retainers (260).
- B. Remove defective bearings (265).
- C. Install replacement bearings (265) per SOPM 20-50-03 except use wet sealant, A00247.
- D. Install retainers (260) and rivets (255).

3. Bearing (270) Replacement (REPAIR 1-1, Figure 601)

- A. Remove bearing (270) and sleeve (275).
- B. Install replacement bearing and sleeve per SOPM 20-50-03 except use wet sealant, A00247. Orient gap in sleeve as shown.
- C. Roller swage sleeve per SOPM 20-50-03.

4. Bearing (800) Replacement (REPAIR 1-1, Figure 601)

NOTE: Bearing (800) is an installation part that may remain attached when this assembly is removed. During installation the bearing will be free floating in the housing.

- A. Remove bearings (800), if attached.
- B. Install replacement bearings (800).


27-31-95

REPAIR 1-1

Page 601

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



ITEM NUMBERS REFER TO IPL FIG. 2
ALL DIMENSIONS ARE IN INCHES



65C25439-2,-17

Housing Assembly Repair and Refinish
Figure 601 (Sheet 1 of 2)

27-31-95

REPAIR 1-1
Page 602
Mar 01/2006

COMPONENT MAINTENANCE MANUAL



REFINISH

MATCHED SET ASSY (300) -- CHEMICAL TREAT (F-17.10) AND APPLY 1 COAT OF PRIMER (F-20.02) ON ALL MACHINED SURFACES EXCEPT AS NOTED BY 1

MATERIAL: AL ALLOY

ITEM NUMBERS REFER TO IPL FIG. 2

ALL DIMENSIONS ARE IN INCHES

1 OMIT PRIMER THIS SURFACE

65C25439-2,-17

Housing Assembly Repair and Refinish
Figure 601 (Sheet 2 of 2)

27-31-95

REPAIR 1-1

Page 603

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

LEVER ASSEMBLY - REPAIR 2-1

65C25485-1, -3, -5

1. General

- A. The procedure has the data necessary to repair and refinish the lever assembly (545, IPL Figure 2).
- B. Refer to REPAIR-GENERAL, Paragraph 2. for the Standard Overhaul Practices Manual (SOPM) subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Paragraph 3. for the description of the consumable codes identified in this procedure.
- D. Refer to IPL Figure 2 for item numbers.

2. Bushing Replacement (REPAIR 2-1, Figure 601)

- A. Remove bushing.
- B. Install replacement bushing per SOPM 20-50-03.

3. Bearing Replacement

- A. Remove bearing and sleeve.
- B. Install replacement bearing and sleeve per SOPM 20-50-03.
- C. Roller swage sleeve per SOPM 20-50-03.
- D. Maximum breakout torque after bearing installation must not exceed 3 pound-inches.



27-31-95

REPAIR 2-1

Page 601

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



REFINISH

LEVER ASSEMBLY (565) -- CHEMICAL TREAT (F-17.10) AND APPLY 1 COAT OF PRIMER (F-20-02) ON ALL MACHINED SURFACES EXCEPT OMIT PRIMER AS NOTED IN 1

1 OMIT PRIMER THIS SURFACE

MATERIAL: AL ALLOY

ITEM NUMBERS REFER TO IPL FIG. 2

ALL DIMENSIONS ARE IN INCHES

65C25485-1,-3,-5 Lever Assembly Repair and Refinish Figure 601

27-31-95

REPAIR 2-1

Page 602

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

ACTUATOR FITTING ASSEMBLY - REPAIR 3-1

65C25487-1, -3

1. General

- A. The procedure has the data necessary to repair and refinish the fitting assembly (375, IPL Figure 2).
- B. Refer to REPAIR-GENERAL, Paragraph 2. for the Standard Overhaul Practices Manual (SOPM) subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Paragraph 3. for the description of the consumables codes identified in this procedure.
- D. Refer to IPL Figure 2 for item numbers.

2. Bushing Replacement (REPAIR 3-1, Figure 601)

- A. Remove bushing.
- B. Install replacement bushing using shrink fit method per SOPM 20-50-03.

3. Bearing Replacement (REPAIR 3-1, Figure 601)

- A. Remove bearing and sleeve.
- B. Install replacement bearing and sleeve per SOPM 20-50-03 except use wet sealant, A00247.
- C. Roller swage sleeve per SOPM 20-50-03.



27-31-95

REPAIR 3-1
Page 601

Mar 01/2006



COMPONENT MAINTENANCE MANUAL



REFINISH

BONDED ASSY (395) -- CHEMICAL TREAT (F-17.10)
AND APPLY 1 COAT OF PRIMER (F-20.02) ON ALL
MACHINED SURFACES EXCEPT AS NOTED
BY 1

1 OMIT PRIMER THIS SURFACE

MATERIAL: AL ALLOY

ALL DIMENSIONS ARE IN INCHES

ITEM NUMBERS REFER TO IPL FIG. 2

65C25487-1,-3 Fitting Assembly Repair and Refinish
Figure 601

27-31-95

REPAIR 3-1

Page 602

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

INPUT CRANK ASSEMBLY - REPAIR 4-1

65C25504-1, -2

1. General


- A. The procedure has the data necessary to repair and refinish the crank assembly (45, IPL Figure 2).
- B. Refer to REPAIR-GENERAL, Paragraph 2. for the Standard Overhaul Practices Manual (SOPM) subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Paragraph 3. for the description of the consumable codes identified in this procedure.
- D. Refer to IPL Figure 2 for item numbers.

2. Bearing Replacement (REPAIR 4-1, Figure 601)

- A. Remove bearing and sleeve.
- B. Install replacement bearing and sleeve per SOPM 20-50-03 except use wet sealant, A00247.
- C. Roller swage sleeve per SOPM 20-50-03.
- D. Maximum breakout torque after bearing installation must not exceed 0.075 pound-inch.

3. Refinish

- A. For repair of surfaces which may only require restoration of original finish, refer to Refinish instructions, REPAIR 4-1, Figure 601.



REFINISH

BONDED ASSY (75) -- CHEMICAL TREAT (F-17.10) AND APPLY 1 COAT OF PRIMER (F-20.02) ON ALL MACHINED SURFACES EXCEPT AS NOTED BY

OMIT PRIMER THIS SURFACE

MATERIAL: AL ALLOY

ALL DIMENSIONS ARE IN INCHES

ITEM NUMBERS REFER TO IPL FIG. 2

Crank Assembly Repair and Refinish
Figure 601

27-31-95

REPAIR 4-1

Page 601

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

FEEL LEVER ASSEMBLY - REPAIR 5-1


65C25510-1, -3, 65C25511-1, -3

1. General

- The procedure has the data necessary to repair and refinish the crank assembly (694, IPL Figure 2).
- Refer to REPAIR-GENERAL, Paragraph 2. for the Standard Overhaul Practices Manual (SOPM) subjects identified in this procedure.
- Refer to REPAIR-GENERAL, Paragraph 3. for the description of the consumable codes identified in this procedure.
- Refer to IPL Figure 2 for item numbers.

2. Bearing Replacement (REPAIR 5-1, Figure 601)

- Remove bearing and sleeve.
- Install replacement bearing and sleeve per SOPM 20-50-03 except use wet sealant, A00247. Orient gap in sleeve as indicated.
- Roller swage sleeve per SOPM 20-50-03.
- Maximum breakout torque after bearing installation must not exceed 3 pound-inches.



Bearing Replacement
Figure 601

27-31-95

REPAIR 5-1

Page 601

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

CAM FOLLOWER ASSEMBLY - REPAIR 6-1

65C25512-1, -2

1. General

- A. The procedure has the data necessary to repair and refinish the crank assembly (435,IPL Figure 2).
- B. Refer to REPAIR-GENERAL, Paragraph 2. for the Standard Overhaul Practices Manual (SOPM) subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Paragraph 3. for the description of the consumable codes identified in this procedure.
- D. Refer to IPL Figure 2 for item numbers.

2. Parts Replacement

- A. Remove rivets (440) or lockbolts (440A), washers (442) and collars (441).
- B. Remove collars (445), washers (450) and lockbolts (455).
- C. Separate follower assemblies (490, 495) and remove pins (460), bearing (465) and retainer assembly (470).
- D. Replace defective parts.
- E. Apply grease, D00633 to the outer diameter of pin (460) that will be installed into retainer assembly (470).
- F. Reassemble parts and secure rivets (440) or lockbolts (440A), washers (442) and collars (441).
- G. Install lockbolts (455), washers (450) and collars (445).
- H. Verify that retainer assembly (470) is free to rotate on pin (460).

3. Refinish

- A. Cam follower assembly (485) – Chemical treat (F-17.10) and apply primer, C00259 (F-20.02) all over.
Material: Al alloy.

27-31-95

REPAIR 6-1

Page 601

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

SPRING RETAINER ASSEMBLY - REPAIR 7-1

69-73340-1

1. General

- A. The procedure has the data necessary to repair and refinish the crank assembly (470,IPL Figure 1).
- B. Refer to REPAIR-GENERAL, Paragraph 2. for the Standard Overhaul Practices Manual (SOPM) subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Paragraph 3. for the description of the consumable codes identified in this procedure.
- D. Refer to IPL Figure 1 for item numbers.

2. Bushing Replacement

- A. Remove bushing.
- B. Install replacement bushing per SOPM 20-50-03 except use wet sealant, A00247.
- C. Fillet seal bushing flange with sealant, A00247.

3. Refinish

- A. Retainer (480, IPL Figure 2) – Chromic acid anodize and apply primer, C00259(F-18.13) all over except omit primer in bore for bushing. Material: Al alloy.

27-31-95

REPAIR 7-1

Page 601

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

BEARING HOUSING ASSEMBLY - REPAIR 8-1

69-73349-1, -2

1. General

- A. The procedure has the data necessary to repair and refinish the crank assembly (15,IPL Figure 2).
- B. Refer to REPAIR-GENERAL, Paragraph 2. for the Standard Overhaul Practices Manual (SOPM) subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Paragraph 3. for the description of the consumable codes identified in this procedure.
- D. Refer to IPL Figure 2 for item numbers.

2. Bearing Replacement

- A. Remove rivets (20, 25 or 130, 135) and retainer (30 or 140).
- B. Remove defective bearing (35 or 145).
- C. Install replacement bearing per SOPM 20-50-03 except use wet sealant, A00247.
- D. Reinstall retainer and rivets.

3. Refinish

- A. Housing assembly (15 or 150) – Chemical treat (F-17.10) and apply primer, C00259 (F-20.02) on all machined surfaces except omit primer in bore for bearing. Material: Al alloy.
- B. Retainer (30 or 140) – Chemical treat and apply primer, C00259 (F-18.06) all over. Material: Al alloy.

27-31-95

REPAIR 8-1

Page 601

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

OUTER SHAFT - REPAIR 9-1


69-73351-1

1. General

- A. The procedure has the data necessary to repair and refinish the outer shaft (430, IPL Figure 2).
- B. Refer to REPAIR-GENERAL, Paragraph 2. for the Standard Overhaul Practices Manual (SOPM) subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Paragraph 3. for the description of the consumable codes identified in this procedure.
- D. Refer to IPL Figure 2 for item numbers.

2. Plating Repair

- A. Repair consists of stripping and restoration of original finish. Refer to Refinish instruction in REPAIR 9-1, Figure 601.



REFINISH

CHROMIC ACID ANODIZE AND APPLY 1 COAT OF PRIMER (F-20.02) ALL OVER EXCEPT AS NOTED BY

MATERIAL: AL ALLOY

ALL DIMENSIONS ARE IN INCHES

OMIT PRIMER AND APPLY HARD ANODIZE PER BAC5821 CLASS II THIS SURFACE

HARD ANODIZE RUNOUT

Shaft Refinish
Figure 601

27-31-95

REPAIR 9-1

Page 601

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

INNER SHAFT - REPAIR 10-1


69-73352-1

1. General

- A. The procedure has the data necessary to repair and refinish the inner shaft (190, IPL Figure 2).
- B. Refer to REPAIR-GENERAL, Paragraph 2. for the Standard Overhaul Practices Manual (SOPM) subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Paragraph 3. for the description of the consumable codes identified in this procedure.
- D. Refer to IPL Figure 2 for item numbers.

2. Plating Repair


- A. Repair consists of stripping and restoration of original finish. Refer to Refinish instruction in REPAIR 10-1, Figure 601.



REFINISH

PASSIVATE (F-17.09) EXCEPT AS NOTED BY 

MATERIAL: 15-5PH, 180-200 KSI

 CHROME PLATE (F-15.03) 0.001-0.002 THICKNESS INDICATED AREA

ALL DIMENSIONS ARE IN INCHES

 CHROME PLATE RUNOUT

Shaft Refinish
Figure 601

27-31-95

REPAIR 10-1

Page 601

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

OUTER SHAFT - REPAIR 11-1


69-73353-1

1. General

- A. The procedure has the data necessary to repair and refinish the outer shaft (515, IPL Figure 2).
- B. Refer to REPAIR-GENERAL, Paragraph 2. for the Standard Overhaul Practices Manual (SOPM) subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Paragraph 3. for the description of the consumable codes identified in this procedure.
- D. Refer to IPL Figure 2 for item numbers.

2. Plating Repair

- A. Repair consists of stripping and restoration of original finish. Refer to Refinish instruction in REPAIR 11-1, Figure 601.



REFINISH

PASSIVATE (F-17.09) EXCEPT AS NOTED BY

MATERIAL: 15-5PH CRES, 180-200 KSI

CADMIUM PLATE (F-15.06) THIS SURFACE
DIMENSIONS APPLY AFTER PLATING

ALL DIMENSIONS ARE IN INCHES

CADMIUM PLATE AND APPLY 1 COAT OF PRIMER
(F-16.01) THIS SURFACE

PLATING FLASH IN BORE ALLOWABLE

Shaft Refinish
Figure 601

27-31-95

REPAIR 11-1

Page 601

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

LINK ASSEMBLY - REPAIR 12-1

69-73435-1, -2

1. General


- A. The procedure has the data necessary to repair and refinish the crank assembly (600,IPL Figure 2).
- B. Refer to REPAIR-GENERAL, Paragraph 2. for the Standard Overhaul Practices Manual (SOPM) subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Paragraph 3. for the description of the consumable codes identified in this procedure.
- D. Refer to IPL Figure 2 for item numbers.

2. Bearing Replacement (REPAIR 12-1, Figure 601)

- A. Remove bearing and sleeve.
- B. Install replacement bearing and sleeve per SOPM 20-50-03 except use wet sealant, A00247. Orient gap in sleeve as shown.
- C. Roller swage sleeve per SOPM 20-50-03.
- D. Maximum breakout torque after bearing installation must not exceed 0.075 pound-inch.

3. Refinish

- A. For repair of surfaces which may only require restoration of original finish, refer to Refinish instructions, REPAIR 12-1, Figure 601.



REFINISH

BOND ASSY (615) -- CHROMIC ACID ANODIZE AND APPLY 1 COAT OF PRIMER (F-18.13) ALL OVER EXCEPT IN BORES FOR BEARINGS. CHEMICAL TREAT (F-17.10) IN BORES FOR BEARINGS

MATERIAL: AL ALLOY

ALL DIMENSIONS ARE IN INCHES

ITEM NUMBERS REFER TO IPL FIG. 2

Link Assembly Repair and Refinish
Figure 601

27-31-95

REPAIR 12-1

Page 601

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

MISCELLANEOUS PARTS REFINISH - REPAIR 13-1

1. General

- A. This repair gives the data that is necessary to refinish parts not given in the specified repairs.
- B. Refer to REPAIR-GENERAL, Paragraph 2. for the Standard Overhaul Practices Manual (SOPM) subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Paragraph 3. for the description of the consumable codes identified in this procedure.
- D. Refer to IPL Figure 1 and IPL Figure 2 for item numbers.

2. Procedure

- A. Repair of parts listed in REPAIR 13-1, Table 601 consists of restoration of the original finish.

Table 601: Refinish Details

IPL FIG. & ITEM	MATERIAL	FINISH
Fig. 1		
Fitting (115)	15-5PH CRES, 180-200 ksi	Passivate (F-17.09) all over.
Fig. 2		
Retainers (10, 120)	Al alloy	Chromic acid anodize (F-17.04) and apply primer, C00259 (F-20.03) all over.
Crank (110)	Al alloy	Chromic acid anodize and apply primer, C00259 (F-18.13) all over except omit primer in 0.988-0.990 in. dia. hole.
Crank (165)	Al alloy	Chromic acid anodize (F-17.04) all over and apply primer, C00259 (F-20.02) all over except omit primer in 1.085-1.087 in. dia. hole.
Cover plate (175)	Al alloy	Chemical treat and apply primer, C00259 (F-18.06) all over.
Inner shaft (200)	Al alloy	Chromic acid anodize and apply primer, C00259 (F-18.13) all over.
Retainer (210)	Al alloy	Chromic acid anodize and apply primer, C00259 (F-18.13) all over except omit primer on splines.
Springs (400, P/N 69-73361-1; 405, P/N 69-73360-1)	17-7PH CRES wire	Passivate (F-17.09) all over.
Springs (400A P/N 251A2190-2; 405A,405B P/N 251A2184-2,-3)	Ti alloy	Apply no finish (F-25.01).
Post (425)	Al alloy	Chromic acid anodize and apply primer, C00259 (F-18.13) all over except omit primer on splines and in 0.190- 0.194 in. dia. hole.
Tie assembly (650)	17-7PH CRES, 150-170 ksi	Passivate (F-17.09) all over.

27-31-95

REPAIR 13-1

Page 601

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

MARKER - REPAIR 14-1

BAC27DCT0346

1. General

- A. The procedure has the data necessary to replace the marker (125, IPL Figure 1).
- B. Refer to REPAIR-GENERAL, Paragraph 2. for the Standard Overhaul Practices Manual (SOPM) subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Paragraph 3. for the description of the consumable codes identified in this procedure.
- D. Refer to IPL Figure 1 for item numbers.

2. Marker Replacement

- A. Remove damaged marker.
- B. Install new marker on centering unit assembly per SOPM 20-50-05.

27-31-95

REPAIR 14-1

Page 601

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

ASSEMBLY

1. General

- A. This procedure has the data necessary to assemble the elevator control feel and centering unit assembly.
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 and IPL Figure 2 for item numbers.

2. Procedure

A. Tools/Equipment

NOTE: Equivalent substitutes may be used.

Reference	Description
SPL-5371	Elevator Feel and Centering Unit Assembly Equipment (Part #: C27005-19, Supplier: 81205)

B. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
A00028	Adhesive - Modified Epoxy For Rigid PVC, Foam Cored Sandwiches	BAC5010, Type 70 (BMS5-92, Type 1)
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I
C00913	Compound - Corrosion Inhibiting Material, Nondrying Resin Mix	BMS 3-27
D00015	Grease - Aircraft Bearing (Use BMS 3-24 until existing stocks are depleted, BMS 3-33 supersedes BMS 3-24)	BMS3-24 (Superseded by BMS 3-33)
D00054	Fluid - Hydraulic Assembly Lubricant - MCS 352B (Formerly Monsanto MCS 352B)	
D00153	Fluid - Hydraulic, Erosion Arresting, Fire Resistant	BMS3-11 Type IV (interchangeable & intermixable with Type V)

C. References

Reference	Title
SOPM 20-50-12	APPLICATION OF ADHESIVES

27-31-95

ASSEMBLY

Page 701

Nov 01/2008



COMPONENT MAINTENANCE MANUAL

D. Assemble Centering Unit Assembly (IPL Figure 2)

CAUTION: POSITION WASHERS (640) AND BUSHINGS (645) AS SHOWN IN IPL FIG. 2 OR BINDING OF TIE ASSEMBLIES (650) WILL RESULT.

- (1) Position washers (640), bushings (645), tie assemblies (650) on camshaft assembly (665A) as shown in IPL Figure 2 and install washers (627, 637 and/or 637A), hollow bolts (635A) and lock bolts (625A). Use the same amount of washers (627, 637 and/or 637A) as noted during disassembly. Install nuts (630) and tighten to 85-100 pound-inches then install collars (620A). Check that tie assemblies move without any interference or binding.
- (2) Position washers (590), bushings (595) and link assembly (600) between tie assemblies (650) and install hollow bolt (585A) and lock bolt (575A). Install nut (580A) and tighten to 80-100 pound-inches then install collar (570A).
- (3) Coat bearings (510) I.D. with grease, D00015 and install bearing and outer shaft (515) on lever assembly (545).
- (4) Install bushing (540) in lever assembly (545). Position link assembly (600) on lever assembly and install hollow bolt (535A) and lock bolt (525A). Install nut (530) and tighten to 80-100 pound-inches then install collar (520A).
- (5) Refer to ASSEMBLY, Paragraph 2.D.(6) for assembly procedures for unit using an existing camshaft assembly (665A) or to ASSEMBLY, Paragraph 2.D.(7) for assembly procedures for unit using a replacement camshaft assembly (665A).
- (6) Assemble unit with existing camshaft assembly (665A).
 - (a) Apply light coating of grease, D00015 to bores of housing bond assemblies (305A, 325A) which mate with shafts (430, 515).
 - (b) Install camshaft assembly (665A) with attached parts on housing bond assembly (305A) with outer shaft (515) mating with housing bond assembly.
 - (c) Position fitting assembly (375) on housing bond assembly (305A) and install bolts (235), washers (220) and nuts (215). Tighten nuts finger-tight.
 - (d) Install shaft (430) in housing bond assembly (305A).
 - (e) Install bushing (505) and bearings (500) in cam follower assembly (435) and install cam follower assembly on shaft (430) with bearing (465) resting on camshaft assembly (665A).
 - (f) Assemble springs (400, 405). Attach spring ends to cam follower assembly (435) and spring post assembly (410).
 - (g) Install spring post assembly in housing bond assembly (305A).
 - (h) Install housing bond assembly (325A).
 - (i) Install bolts (225 thru 235), washers (220), bushings (240), retainers (245), and nuts (215). On top assemblies 65C25505-13, 15, -16, install bolt (151), washer (172), bushing (186) and nut (181). Tighten nuts including ones installed in step (3) per 20-50-01.
 - (j) Check that bolts (625A, 635A) are centered in housing assembly (250). Remove all parts and add or subtract washers (627, 637 or 637A) as required and reassemble parts.
 - (k) Install inner shaft (200) through outer shaft (430). Align rivet holes in shafts (200, 430) and housing bond assemblies (305A, 325A) and install rivets (195A) or lockbolts (195B), washers (197) and collars (196). If housing assembly (250A) and/or shafts (200, 430) are new parts, drill 0.190-0.191 inch dia. rivet holes through using pilot hole locations in housing bond assemblies (305A, 325A).

27-31-95

ASSEMBLY

Page 702

Jul 01/2008



COMPONENT MAINTENANCE MANUAL

- (l) Install shaft (190) through shaft (515) and secure with washer (185) and nut (180). Tighten nut to 150-200 pound-inches.
 - (m) On top assemblies 65C25505-11, -12, -14, apply compound, C00913 to the threads and shank to bolts (152, 153, 157). Install stop support assembly (192), bushings (187, 188, 189), bolts (152, 153, 157), washers (167, 168, 177) and nuts (182, 183, 184). Remove excess compound, C00913 after installation of parts.
 - (n) Rotate spring post assembly (410) until pointer of spring post assembly aligns with index hole in housing bond assembly (325A) and hold in that position. Install spring post retainer (210) and secure with screws (205).
 - (o) Install spacer (80) and crank assembly (45) on camshaft assembly (665A) and secure with bolts (60), washers (55) and nuts (50). If crank assembly is replaced, drill 0.2485-0.2495 inch diameter boltholes thru crank assembly at pilot hole locations. Break sharp edges 0.008R. Apply alodine to holes per F-17.10. Check that axial play of spacer (80) does not exceed 0.005 inch.
 - (p) Install bearing housing assembly (15) on camshaft assembly (665A). Apply a light coat of grease, D00015 to retainer (10) and install retainer in camshaft assembly. Secure retainer with rivet (5), or bolt (5A) with primer, C00259 per F-20.06 and collar (6). If retainer is a replacement part, first drill 0.190-0.191 inch diameter hole thru retainer using existing hole in camshaft assembly to locate hole.
 - (q) Install crank assembly (155), bearing housing assembly (125) on cam shaft assembly (665A). Apply a light coat of grease, D00015 to retainer (120) and install retainer in camshaft assembly (665A). Install rivets (115), or bolts (115A) with primer, C00259 per F-20.06 and collars (116), through crank assembly (155) to secure. If crank assembly (155) is a replacement part, first drill 0.190-0.191 inch diameter holes through at pilot hole locations on crank assembly. If retainer (120) is a replacement part, first drill 0.190-0.191 inch diameter holes through using existing holes in camshaft assembly (665) as guides.
 - (r) On 65C25505-6, -9 assemblies, install crank assembly (85) and secure with bolts (100), washers (95) and nuts (90). If crank assembly (85) is a replacement part, first drill 0.2485-0.2495 inch diameter boltholes through crank assembly at pilot holes locations. If retainer (120A) is a replacement part, drill 0.2485-0.2495 inch diameter holes through at existing hole locations on camshaft assembly (665D). Apply a light coat of grease, D00015 to retainer (120A) and install onto camshaft assembly (665D).
 - (s) Attach pull actuator assembly C27005-3 (component of C27005-19 Assembly Equipment, SPL-5371) to unit and apply 700-860 lbs force to lever assembly (545) as indicated in ASSEMBLY, Figure 701 to seat cam follower assembly (435) on camshaft assembly (665A). Check that crank assemblies (45, 85, 155) are in positions indicated in ASSEMBLY, Figure 701 using strap assemblies C27005-4, -5, -6 (components of C27005-19 Assembly Equipment, SPL-5371) as applicable. If crank assemblies (45, 85, 155) are not in positions indicated, replace camshaft assembly (665A).
- (7) Assemble unit with a new camshaft assembly (665A).
- (a) Apply a light coating of grease, D00015 to bores of housing bond assemblies (305A, 325A) which mate with shafts (430, 515).
 - (b) Install camshaft assembly with attached parts on housing bond assembly (305A) with outer shaft (515) mating with housing bond assembly.
 - (c) Install shaft (430) in housing bond assembly (305A).

27-31-95

ASSEMBLY

Page 703

Jul 01/2008



COMPONENT MAINTENANCE MANUAL

- (d) Install bushing (505) and bearings (510) in cam follower assembly (435) and install cam follower assembly in shaft (430) with bearing (465) resting on camshaft assembly (665A).
 - (e) Assemble springs (400, 405). Attach spring ends to cam follower assembly (435) and spring post assembly (410).
 - (f) Install spring post assembly (410) in housing bond assembly (305A).
 - (g) Install housing bond assembly (325A).
 - (h) Position actuator fitting assembly (375) between housing bond assemblies (305A, 325A) and secure with bolt (230, 235), washers (220), nuts (215) and retainer (245). Secure housing bond assemblies together with bolts (225, 226), washers (220), bushings (240) and nuts (215). On top assemblies 65C25505-13, -15, -16, install bolt (151), washer (172), bushing (186) and nut (181).
 - (i) Check that bolts (625A, 635A) are centered in housing assembly (250A). Remove parts and add or subtract washers (627, 637, or 637A) as required and reassemble.
 - (j) Rotate spring post assembly (410) until pointer aligns with index hole in housing bond assembly (325A) and hold in place. Install retainer (210) and secure with screws (205).
 - (k) Attach pull actuator assembly C27005-3 (component of C27005-19 Assembly Equipment, SPL-5371) to unit and apply 700-860 pounds force to lever assembly (545) in the direction indicated to engage bearing (465) in camshaft assembly (665A) detent.
 - (l) With bearing (465) positively engaged in cam assembly (690A) detent, drill 0.155-0.161 inch diameter rivet hole for rivet (660) through cam assembly (690A) and lever assembly (695) at pilot hole location on cam assembly.
- NOTE:** A 0.60 inch diameter access hole is provided on the housing assembly (250A) to facilitate drilling.
- (m) Release force and remove pull actuator assembly C27005-3 (component of C27005-19 Assembly Equipment, SPL-5371).
 - (n) Remove camshaft assembly (665A) for final drilling and riveting as follows:
 - 1) Restrain spring post assembly (410) and remove screws (205) and retainer (210). Slowly rotate spring post assembly in the direction that relieves the spring force on the spring post assembly.
 - 2) Remove nuts (215), washers (220), bolts (225 thru 235), bushing (220), retainers (245) and actuator fitting assembly (375).
 - 3) Remove housing bond assembly (325A).
 - 4) Unhook springs (400, 405) from spring post assembly (410).
 - 5) Rotate cam follower assembly (435) and remove camshaft assembly (665A).
 - (o) Align rivet (660) hole in cam assembly (690A) and feel lever assembly (695) and clamp cam assembly to feel lever assembly.
 - (p) Drill four 0.124-0.129 inch diameter holes for rivets (655) through cam assembly (690A) and feel lever assembly (695) at pilot hole locations on cam assembly.
 - (q) Select rivets (655, 660) which yield 0.002 inch maximum diametrical clearance with the rivet holes. Bond cam assembly (690A) to feel lever assembly (695) using adhesive, A00028 per SOPM 20-50-12. Align all rivet holes in cam assembly and feel lever assembly and secure parts together with rivets (655, 660). Install rivets with adhesive, A00028.

27-31-95

ASSEMBLY

Page 704

Jul 01/2008



COMPONENT MAINTENANCE MANUAL

- (r) Reassemble camshaft assembly (665A) and housing assembly (250A) per ASSEMBLY, Paragraph 2.D.(7)(a) thru ASSEMBLY, Paragraph 2.D.(7)(h), ASSEMBLY, Paragraph 2.D.(7)(j).
- (s) On top assemblies 65C25505-11, -12, -14, apply compound, C00913 to the threads and shank to bolts (152, 153, 157). Install stop support assembly (192), bushings (187, 188, 189), bolts (152, 153, 157), washers (167, 168, 177) and nuts (182, 183, 184). Remove excess compound, C00913 after installation of parts.
- (t) Install inner shaft (190) through outer shaft (515) and secure with washer (185) and nut (180). Tighten nut to 150-200 pound-inches.
- (u) Install inner shaft (200) through outer shaft (430) and secure inner and outer shaft to housing assembly (250A) with rivets (195A) or lockbolts (195B), washers (197) and collars (196). If housing assembly (250A), or shafts (200, 430) are new parts, first drill 0.190-0.191 inch diameter holes through housing assembly and shafts at pilot hole locations on housing bond assemblies (305A, 325A).
- (v) On 65C25505-2, -4, -8, -10 thru -16 assemblies, assemble input crank assembly (45) and crank assembly (155) as follows:
 - 1) Install spacer (80), input crank assembly (45), crank assembly (155) and retainer (120) on camshaft assembly (665A).
 - 2) Attach pull actuator assembly C27005-3 (component of C27005-19 Assembly Equipment, SPL-5371) to unit and apply 700-860 pounds force to lever assembly (545) in the direction indicated to positively engage cam follower assembly (435) to camshaft assembly (665A) detent.
 - 3) Locate input crank assembly (45) and crank assembly (155) at positions indicated by attaching strap assemblies C27005-5 and C27005-6 (components of C27005-19 Assembly Equipment, SPL-5371).
 - 4) Drill 0.2485-0.2495 inch dia. holes through input crank assembly (45) and camshaft assembly (665A) at pilot hole locations on input crank assembly.
 - 5) Drill 0.190-0.191 inch diameter holes through crank assembly (155), camshaft assembly (665A) and retainer (120) at pilot hole locations on crank assembly.
 - 6) Remove force and pull actuator assembly C27005-3 (component of C27005-19 Assembly Equipment, SPL-5371).
 - 7) Install bearing housing assembly (15) and retainer (10) on camshaft assembly (665A) and drill 0.190-0.191 inch dia. rivet hole through camshaft assembly and retainer at location shown.
 - 8) Remove retainers (10, 120), bearing housing assembly (15), spacer (80), crank assemblies (45, 155) from camshaft assembly (665A).
 - 9) Break sharp edges 0.008 radius on drilled holes and manually apply alodine per F-17.10 on 0.2485-0.2495 inch diameter holes.
 - 10) Install spacer (80) and input crank assembly (45) on camshaft assembly (665A) and secure input crank assembly with bolts (60), washers (65) and nuts (70). Check that axial play of spacer (80) does not exceed 0.005 inch.

27-31-95

ASSEMBLY

Page 705

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

- 11) Apply a light coat of grease, D00015 to retainers (10, 120). Install bearing housing assemblies (15, 125), crank assembly (155) and retainer (120) on camshaft assembly (665A) and install rivets (5, 115), or bolts (5A, 115A) with primer, C00259 per F-20.06 and collars (6, 116).
- (w) On 65C25505-6, -9 assemblies, assemble crank assemblies (45, 85, 155) as follows:
 - 1) Install spacer (80), input crank assembly (45), crank assemblies (85, 155) and retainer (120A) on camshaft assembly (665D). Install crank assembly (85) and retainer flush with cam shaft assembly.
 - 2) Attach pull actuator assembly C27005-3 (component of C27005-19 Assembly Equipment, SPL-5371) to unit and apply 700-860 lbs force to lever assembly (545) to positively engage cam follower assembly (435) to camshaft assembly (665D) detent.
 - 3) Locate crank assemblies (45, 85, 155) at positions indicated with strap assemblies C27005-4, C27005-5 and C27005-6 (components of C27005-19 Assembly Equipment, SPL-5371), and secure in place.
 - 4) Drill 0.2485-0.2495 inch dia. holes through input crank assembly (45) and camshaft assembly (665D) at pilot hole locations on input crank assembly.
 - 5) Drill 0.190-0.191 inch diameter holes through crank assembly (155), camshaft assembly (665D) and retainer (120A) at pilot hole locations on crank assembly.
 - 6) Drill 0.2485-0.2495 inch diameter holes through crank assembly (85), camshaft assembly (665D) and retainer (120A) at pilot hole locations on crank assembly (85).
 - 7) Remove force and pull actuator assembly C27005-3 (component of C27005-19 Assembly Equipment, SPL-5371).
 - 8) Install bearing housing assembly (15A) and retainer (10) on camshaft assembly (665D) and drill 0.190-0.191 inch diameter hole at location indicated.
 - 9) Remove retainers (10, 120A), bearing housing assembly (15A, 125A), crank assemblies (45, 85, 155), spacer (80) from camshaft assembly (665D).
 - 10) Break sharp edges 0.008R and manually apply alodine per F-17.10 to 0.2485-0.2495 inch diameter holes.
 - 11) Install spacer (80) and input crank assembly (45) on camshaft assembly (665D) and secure input crank assembly with bolts (60), washers (55) and nuts (50). Apply a light coat of grease, D00015 to retainer (10) and install bearing housing assembly (15A) and retainer (10). Secure retainer with rivet (5), or bolt (5A) with primer, C00259 per F-20.06 and collar (6). Check that axial play of spacer (80) does not exceed 0.005 inch.
 - 12) Install crank assemblies (85, 155) and bearing housing assembly (125A) on camshaft assembly (665D). Apply a light coat of grease, D00015 to retainer (120A) and install onto camshaft assembly (665D). Secure crank assembly (155) with rivets (115), or bolts (115A) with primer, C00259 per F-20.06 and collar (116), and secure crank assembly (85) with bolts (100), washers (95) and nuts (90).
- (8) On 65C25505-4, -6, -8, -9 assemblies, install bracket assembly (345) on housing bond assembly (325) at location shown and secure with rivets (352).
- (9) Install coverplate (175) and secure with screws (170).


27-31-95

ASSEMBLY

Page 706

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



FRONT VIEW
 (BEARING HOUSING ASSEMBLY (15) OMITTED FOR CLARITY)
 65C25505-4,-8 ASSEMBLIES SHOWN
 65C25505-2,-10 ASSEMBLIES SIMILAR
 65C25505-6,-9 ASSEMBLIES SIMILAR UNLESS SHOWN DIFFERENTLY


ITEM NUMBERS REFER IPL FIG. 2
 ALL DIMENSIONS ARE IN INCHES

Assembly Details
 Figure 701 (Sheet 1 of 5)

27-31-95

ASSEMBLY
 Page 707
 Mar 01/2006

COMPONENT MAINTENANCE MANUAL



REAR VIEW


ITEM NUMBERS REFER TO IPL FIG. 2
ALL DIMENSIONS ARE IN INCHES

Assembly Details
Figure 701 (Sheet 2 of 5)

27-31-95

ASSEMBLY
Page 708
Mar 01/2006

COMPONENT MAINTENANCE MANUAL



REAR VIEW
65C25505-6,-9 ASSEMBLIES ONLY


ITEM NUMBERS REFER TO IPL FIG. 2
ALL DIMENSIONS ARE IN INCHES

Assembly Details
Figure 701 (Sheet 3 of 5)

27-31-95

ASSEMBLY
Page 709
Mar 01/2006

COMPONENT MAINTENANCE MANUAL



FRONT VIEW

(HOUSING BOND ASSY (325A), CRANK ASSY (45) AND BEARING HOUSING ASSY (15) OMITTED FOR CLARITY)


ITEM NUMBERS REFER TO IPL FIG. 2
ALL DIMENSIONS ARE IN INCHES

Assembly Details
Figure 701 (Sheet 4 of 5)

27-31-95

ASSEMBLY
Page 710
Mar 01/2006

COMPONENT MAINTENANCE MANUAL



- 1 ▷ ALIGN SPRING POST ASSEMBLY (410) WITH INDEX HOLE APPROXIMATELY AS SHOWN
- 2 ▷ APPLY 700-860 LBS FORCE TO LEVER ASSEMBLY (545) IN THE DIRECTION INDICATED TO SEAT CAM FOLLOWER ASSEMBLY (435) IN CAM ASSEMBLY (690A) DETENT
- 3 ▷ LOCATE CRANK ASSEMBLY (45,85,155) ON CAM SHAFT ASSEMBLY (665A) WITH CAM FOLLOWER ASSEMBLY (435) SEATS IN CAM ASSEMBLY (690A) DETENT

ALL DIMENSIONS ARE IN INCHES
ITEM NUMBERS REFER TO IPL FIG. 2

Assembly Details
Figure 701 (Sheet 5 of 5)

27-31-95



COMPONENT MAINTENANCE MANUAL

E. Assemble Feel and Centering Unit Assembly (IPL Figure 1)

- (1) Lightly lubricate packings (70, 85) with hydraulic fluid, D00153 or MCS 352B fluid, D00054 and install packings (70) on unions (65) and packings (85) on union (75) and reducer (80).
- (2) Install unions (65, 75) and reducer (80) on cylinder assembly (90).
- (3) Install fitting (115), sliding block (110), bushing (105), washer (100) and nut (95) on actuator assembly (60). Tighten nut (95) finger-tight.

CAUTION: DO NOT RETIGHTEN NUT (15).

- (4) Position actuator assembly (60) on centering unit assembly (120A) and install bolt assembly (25). Install washer (20) and nut (15) and tighten nut to 85-100 pound-inches. Install washer (10) and nut (5) and tighten nut to 30-35 pound-inches. Do not retighten nut (15).

CAUTION: DO NOT RETIGHTEN NUT (15).

- (5) Position the other end of actuator assembly (60) on centering unit assembly (120A) and install bushing (55A) and bolt assembly (40). Install washer (20) and nut (15) and tighten nut to 85-100 pound-inches. Install washer (10) and nut (5) and tighten nut to 30-35 pound-inches. Do not retighten nut (15). Tighten nut (95) to 100-125 pound-inches.

- (6) Test unit per TESTING AND FAULT ISOLATION.

3. Storage

A. References

Reference	Title
SOPM 20-44-02	TEMPORARY PROTECTIVE COATINGS

B. Procedure

- (1) Prepare actuator assembly for storage per OHM 27-09-09.
- (2) Use standard industry practices and information contained in SOPM 20-44-02 to store this component.

27-31-95


ASSEMBLY

Page 712

Nov 01/2007

COMPONENT MAINTENANCE MANUAL

FITS AND CLEARANCES



Ref Letter	Mating Item No. IPL Fig.2	Design Dimension				Service Wear Limit		
		Dimension		Assembly Clearance		Dimension		Maximum Clearance
		Min	Max	Min	Max	Min	Max	
A	ID 650 OD 645	0.520 0.498	0.530 0.500	0.020	0.032	0.496	0.540	0.044

ITEM NUMBERS REFER TO IPL FIG. 2
ALL DIMENSIONS ARE IN INCHES

Fits and Clearances
Figure 801



COMPONENT MAINTENANCE MANUAL

SPECIAL TOOLS, FIXTURES, AND EQUIPMENT

1. General

A. This section lists the special tools, fixtures, and equipment necessary for maintenance.

NOTE: Equivalent substitutes may be used.

Special Tools

Reference	Description	Part Number	Supplier
SPL-5349	X-Y Recorder/Plotter	925E	60795
SPL-5351	Test Equipment - Elevator Feel and Centering Unit	A27041-175	81205
SPL-5352	Readout and Control Equipment - Functional Test Stand	A27081-1	81205
SPL-5371	Elevator Feel and Centering Unit Assembly Equipment	C27005-19	81205
SPL-5446	X-Y recorder	RW20IT Opt: 7046A Opt: 7090A	31991 28480 28480

Tool Supplier Information

CAGE Code	Supplier Name	Supplier Address
28480	HEWLETT-PACKARD COMPANY	1421 S. MANHATTAN AVE. FULLERTON, CA 92831 Telephone: 714-758-5805 Facsimile: 714-758-7537
31991	SOLTEC CORP	12977 ARROYO ST SAN FERNANDO, CA 91340-1597 Telephone: (818) 365-0800 Facsimile: (818) 365-7839
60795	ALLEN DATAGRAPH INC.	2 INDUSTRIAL WAY SALEM, NH 03079-2837 Telephone: (603) 893-1983 Facsimile: (603) 893-9042
81205	THE BOEING COMPANY	17930 INTERNATIONAL BLVD. SOUTH SEATAC, WA 98188-4321 Telephone: 206-662-6650 Facsimile: 206-662-7145

27-31-95

SPECIAL TOOLS, FIXTURES, AND EQUIPMENT

Page 901

Mar 01/2009



COMPONENT MAINTENANCE MANUAL

ILLUSTRATED PARTS LIST

1. Introduction

- A. The Illustrated Parts List (IPL) contains an illustration and a list of component parts you can repair or replace. The Illustrated Parts Catalog (IPC) shows how to use the Boeing part number system.
- B. This shows how parts are related: The relation of each item to its next higher assembly (NHA) is shown in the NOMENCLATURE column. Use the indenture system that follows:

1	2	3	4	5	6	7
.	Assembly					
.	Attaching parts for assembly					
.	.	Detail parts for assembly				
.	.	Subassembly				
.	.	Attaching parts for subassembly				
.	.	.	Detail parts for subassembly			
.	.	.	Sub-subassembly			
.	.	.	Attaching parts for subassembly			
.	.	.	.	Details parts for sub-subassembly		
						Detail Installation Parts (Included only if installation parts may be sent to the shop as part of assembly)

- C. Each top assembly is given one use code letter (A, B, C, etc.) in the USAGE CODE column. All subsequent component parts in the list can have one or more of the use code letters to show effectivity to top assemblies. A component part without a use code applies to all top assemblies.
- D. An alphabetical letter is added after the item number for optional parts, parts changed by a Service Bulletin, configuration differences (except left-handed and right-handed parts), last engineering releases, and parts added between item numbers in a sequence. The alphabetical letter will not be shown on the illustration for equivalent parts of the same part number.
- E. Color-coded parts are identified with a single digit alpha following the dash number or with "SP" suffix. If the "SP" suffix is used, it represents consolidation of all color codes applicable for a given usage which are not separately listed. Orders for color-coded parts should include the registry number of the airplane for which the parts are ordered.
- F. If a part number is 15 characters long but will not fit in the part number column, the part number will be displayed with a "~" at the end of the line and will be continued on the next line. The "~" denotes that the part number continues on the next line.
- G. Parts changed by a Service Bulletin are shown by PRE SB XXXX and POST SB XXXX added to the NOMENCLATURE column.
- (1) When a new top assembly is added by a Service Bulletin, PRE SB XXXX and POST SB XXXX will be added at the top assembly level only. The configuration differences at the detail part level are shown by use code letters.
- (2) When the top assembly part number is not changed by the Service Bulletin, PRE SB XXXX and POST SB XXXX will be added at the detail level.
- H. Interchangeable Parts

27-31-95

ILLUSTRATED PARTS LIST

Page 1001

Nov 01/2008



COMPONENT MAINTENANCE MANUAL

Optional (OPT)	The part is optional to and interchangeable with other parts that have the same item number.
Replaces, Replaced by and not interchangeable with (REPLACES, REPLACED BY AND NOT INTCHG/W)	The part replaces and is not interchangeable with the initial part.
Replaces, Replaced by (REPLACES, REPLACED BY)	The part replaces and is interchangeable with, or is an alternative to, the initial part.

VENDOR CODES

Code	Name
60380	TORRINGTON CO BEARINGS DIV SUBSIDIARY OF INGERSOLL-RAND CORP 59 FIELD STREET PO BOX 1008 TORRINGTON, CONNECTICUT 06790-1008 FORMERLY TORRINGTON BEARING COMPANY
92563	MCGILL MFG CO INC BEARINGS DIV 909 LAFAYETTE STREET VALPARAISO, INDIANA 46383-4210

27-31-95

ILLUSTRATED PARTS LIST

Page 1002

Jul 01/2006



COMPONENT MAINTENANCE MANUAL

NUMERICAL INDEX

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
251A2184-2		2	405A	1
251A2184-3		2	405B	1
251A2190-2		2	400A	1
251T2125-1		2	645	4
251T2125-2		2	595	2
251T2125-3		2	590	2
251T2125-5		2	637D	AR
		2	637F	AR
		2	640B	4
60B00178-681		2	465A	1
65-38904-2		1	110	1
65-44503-10		1	90A	1
65-44503-8		1	90	1
65C25439-11		2	320A	1
65C25439-12		2	340A	1
65C25439-17		2	250B	1
65C25439-18		2	300B	1
65C25439-19		2	305B	1
65C25439-2		2	250A	1
65C25439-20		2	325B	1
65C25439-21		2	320B	1
65C25439-22		2	340B	1
65C25439-25		2	250C	1
65C25439-26		2	300C	1
65C25439-27		2	305C	1
65C25439-28		2	325C	1
		2	340C	1
65C25439-29		2	320C	1
65C25439-4		2	300A	1
65C25439-7		2	305A	1
65C25439-8		2	325A	1
65C25465-10		1	1G	RF
65C25465-11		1	1H	RF
65C25465-12		1	1J	RF

27-31-95

ILLUSTRATED PARTS LIST

Page 1003

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
65C25465-14		1	60A	1
65C25465-15		1	1K	RF
65C25465-16		1	1L	RF
65C25465-17		1	1M	RF
65C25465-18		1	1N	RF
65C25465-19		1	1P	RF
65C25465-2		1	1A	RF
65C25465-20		1	1Q	RF
65C25465-21		1	1R	RF
65C25465-22		1	1S	RF
65C25465-23		1	1T	RF
65C25465-4		1	1C	RF
65C25465-5		1	60	1
65C25465-8		1	1E	RF
65C25485-1		2	545	1
65C25485-2		2	565	1
65C25485-3		2	545A	1
65C25485-4		2	565A	1
65C25485-5		2	545B	1
65C25487-1		2	375	1
65C25487-2		2	395	1
65C25487-3		2	375A	1
65C25487-4		2	395A	1
65C25504-1		2	45	1
65C25504-2		2	45A	1
65C25504-3		2	75	1
65C25504-4		2	75A	1
65C25505-10		1	120J	1
		2	1J	RF
65C25505-11		1	120K	1
		1	120L	1
		2	1K	1
65C25505-12		1	120M	1
		1	120N	1
		2	1L	1

27-31-95

ILLUSTRATED PARTS LIST

Page 1004

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
65C25505-13		1	120P	1
		1	120Q	1
		2	1M	1
65C25505-14		1	120R	1
		1	120S	1
		1	120T	1
		2	1N	1
65C25505-15		1	120U	1
		2	1P	1
65C25505-16		1	120V	1
		2	1Q	1
65C25505-2		1	120A	1
		2	1A	RF
65C25505-4		1	120C	1
		2	1C	RF
65C25505-6		1	120E	1
		2	1E	RF
65C25505-8		1	120G	1
		2	1G	RF
65C25505-9		1	120H	1
		2	1H	RF
65C25510-1		2	695B	1
65C25510-2		2	710B	1
65C25510-3		2	695C	1
65C25510-4		2	710C	1
65C25511-1		2	695	1
65C25511-2		2	710	1
65C25511-3		2	695A	1
65C25511-4		2	710A	1
65C25512-1		2	435	1
65C25512-10		2	435C	1
65C25512-2		2	435A	1
65C25512-3		2	485	1
65C25512-4		2	485A	1
65C25512-5		2	490	1

27-31-95

ILLUSTRATED PARTS LIST

Page 1005

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
65C25512-6		2	495	1
65C25512-7		2	490A	1
65C25512-8		2	495A	1
65C25512-9		2	435B	1
65C25513-1		2	410	1
65C25513-2		2	425	1
65C25513-3		2	410A	1
65C25513-4		2	425A	1
65C25517-10		2	665M	1
65C25517-2		2	665A	1
65C25517-3		2	665B	1
65C25517-4		2	665C	1
65C25517-5		2	665D	1
65C25517-6		2	665E	1
65C25517-7		2	665F	1
		2	665G	1
65C25517-8		2	665K	1
65C25517-9		2	665H	1
		2	665J	1
		2	665L	1
65C25518-2		2	690A	1
65C25518-7		2	690B	1
65C25518-8		2	690C	1
65C25518-9		2	690D	1
65C25522-1		2	155	1
65C25522-2		2	165	1
65C25533-1		2	85	1
65C25533-2		2	110	1
66-21297-2		1	105	1
69-27158-10		1	40	1
69-27158-4		1	25	1
69-27163-13		1	45	1
69-27163-14		2	585A	1
		2	635A	2
69-27163-15		2	535A	1

27-31-95

ILLUSTRATED PARTS LIST

Page 1006

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
69-27163-5		1	30	1
69-38919-1		2	65	1
69-38919-2		2	380	1
		2	555	1
		2	700	2
69-38919-32		2	275	1
69-38919-33		2	605	2
69-70464-7		2	80	1
69-73340-1		2	470	1
69-73340-2		2	480	1
69-73340-3		2	470A	1
69-73340-4		2	480A	1
69-73342-1		2	40	1
		2	150	1
69-73343-1		2	725	1
69-73343-2		2	725A	1
69-73344-1		2	720	1
69-73344-2		2	720A	1
69-73344-3		2	720B	1
69-73345-1		2	715	1
69-73345-2		2	715A	1
69-73346-2		2	245	2
69-73346-4		2	260	2
69-73348-1		2	460	2
69-73349-1		2	15	1
		2	125	1
69-73349-2		2	15A	1
		2	125A	1
69-73349-3		2	15B	1
		2	125B	1
69-73350-1		2	175	1
69-73350-2		2	175A	1
69-73351-1		2	430	1
69-73351-2		2	200	1
69-73352-1		2	190	1

27-31-95

ILLUSTRATED PARTS LIST

Page 1007

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
69-73353-1		2	515	1
69-73355-1		2	120	1
69-73355-2		2	10	1
69-73355-3		2	120A	1
69-73356-1		2	210	1
69-73358-1		1	115	1
69-73360-1		2	405	1
69-73361-1		2	400	1
69-73378-1		2	345	1
69-73378-2		2	370	1
69-73378-3		2	365	1
69-73434-1		2	650A	4
69-73434-3		2	650	4
69-73434-5		2	650B	4
		2	650C	4
69-73435-1		2	600A	1
69-73435-2		2	600	1
69-73435-3		2	615A	1
69-73435-4		2	615	1
69-73459-3		2	30	1
		2	140	1
69-74649-1		2	298	1
69-87835-1		2	192	2
69-87836-1		2	153B	1
AC69001		2	465A	1
AN960-10L		2	675	6
AN960-416L		1	100	1
AN960B616		2	637	AR
		2	640	4
AN960KD10L		2	450	4
AN960KD616L		2	537	1
		2	637A	AR
AN960PD416		1	10	2
		2	55	4
		2	95	2

27-31-95

ILLUSTRATED PARTS LIST

Page 1008

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
		2	220	10
		2	220B	9
AN960PD616		1	20	2
AN960PD816		2	185	1
AN960XC416L		2	627	AR
BAC27DCT0346		1	125	1
BACB10AP5		2	800	2
BACB10AR5		2	70	1
		2	270	1
BACB10AS10		2	500	2
BACB10AS12		2	510	2
BACB10AS21		2	265	2
BACB10AW16		2	35	1
		2	145	1
BACB10BX6		2	610	2
BACB10ET06		2	465	1
BACB10FV16		2	35A	1
		2	145A	1
BACB28AK04-034		2	189A	1
BACB28AK04-046		2	187A	2
BACB28AK05-014		2	188D	1
BACB28AK05-368		2	188C	1
BACB28AK05-382		2	188	1
BACB28AK06-032		2	540	1
BACB28BA0507382		2	188A	1
BACB28X6-C018		2	550A	1
BACB28Y10D047		2	505	1
BACB28Y10D287		2	390	1
BACB28Y4D034		2	189B	1
BACB28Y4D046		2	187B	2
BACB28Y4D230		2	240	4
BACB28Y5D286		2	186	1
BACB28Z4-034		2	189	1
BACB28Z4-046		2	187	2
BACB30DX6-27		2	680	3

27-31-95

ILLUSTRATED PARTS LIST

Page 1009

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
BACB30DX6-56		2	415	1
BACB30FM8-24		2	525B	1
BACB30FM8-28		2	575B	1
		2	625B	2
BACB30GP6-18		2	455	2
BACB30GW8-24		2	525A	1
BACB30GW8-28		2	575A	1
		2	625A	2
BACB30MB6A56		2	415A	1
BACB30MY6K13		2	195B	2
BACB30MY6K13X		2	195C	2
BACB30MY6K13Y		2	195D	2
BACB30MY6K18		2	5B	1
		2	5D	1
		2	440A	3
		2	455A	2
BACB30MY6K21		2	115B	2
		2	115D	2
BACB30MY6R18		2	5A	1
BACB30MY6R21		2	115A	2
BACB30NF4-43		1	50	1
BACB30NF5-65		2	153A	1
BACB30NM4HK48		2	230B	2
BACB30NM4K46		2	225B	2
BACB30NM4K67		2	226B	2
BACB30NM4K8		2	235A	4
BACB30NR4K64		2	152A	1
		2	157A	1
BACB30NR4K65		2	152	1
		2	157	1
BACB30NR5K47		2	151	1
BACB30NR5K65		2	153	1
BACB30VT6K18		2	5C	1
		2	5E	1
BACB30VT6K21		2	115C	2

27-31-95

ILLUSTRATED PARTS LIST

Page 1010

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
		2	115E	2
BACC30BH6		2	420A	1
BACC30K8		2	520A	1
		2	570A	1
		2	620A	2
BACC30M6		2	6	1
		2	116	2
		2	196	2
		2	441	3
		2	445A	2
BACC30M8		2	520B	1
		2	570B	1
		2	620B	2
BACN10HR4CD		1	95	1
BACN10JC8CM		2	180	1
BACN10JP08A		2	295	4
		2	315	3
		2	335	3
BACN10JP3C		2	285	2
BACN10YR3CD		2	6A	1
		2	116A	2
BACN10YR4CD		1	5A	2
		2	50A	4
		2	182	1
		2	184	1
		2	215B	10
BACN10YR5CD		2	181	1
		2	183	1
BACN10YR6CD		1	15A	2
		2	530A	1
		2	580A	1
		2	630A	2
BACR15BA3D		2	280	4
		2	290	8
		2	310	6

27-31-95

ILLUSTRATED PARTS LIST

Page 1011

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
BACR15BA5D		2	330	6
		2	20	2
		2	130	2
		2	255A	12
		2	297	3
BACR15BB5D		2	25	1
		2	135	1
		2	352	3
		2	360	3
BACR15BB6D		2	195A	2
BACR15BB6D20		2	440	3
BACR15CE5M13		2	660A	1
MS14104-6		2	385	1
		2	560	1
		2	705	2
MS14104-6K		2	560A	1
		2	705A	2
MS20615-4MP13		2	655	4
MS20615-5MP13		2	660	1
MS20615-6M26		2	5	1
		2	115	2
		1	5	2
		2	50	4
MS21042L4		2	90	2
		2	215	10
		2	215A	9
		1	15	2
MS21042L6		2	530	1
		2	580	1
		2	630	2
		2	160	1
MS21209F1-15		2	160	1
MS21902-4		1	65	2
MS21902D6		1	75	1
MS21916D6-5		1	80	1
NAS1057W5-382		2	188B	1

27-31-95

ILLUSTRATED PARTS LIST

Page 1012

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
NAS1080-06		2	420	1
		2	670	3
NAS1080D06		2	445	2
NAS1104-25		1	35	1
NAS11490616J		2	637E	AR
NAS1149B0463H		2	637B	AR
		2	640A	4
		2	637C	AR
NAS1149C0432B		2	627A	AR
NAS1149D0332J		2	197	2
		2	442	3
		2	450A	4
		2	627B	AR
NAS1149D0416J		2	167A	1
NAS1149D0432J		2	177A	1
		1	10A	2
NAS1149D0463J		1	10B	2
		2	55A	4
		2	55B	4
		2	167	1
		2	177	1
		2	220A	10
		2	220C	9
		2	220D	10
		2	168	1
NAS1149D0563J		2	172	1
		2	537B	1
NAS1149D0616J		2	537A	1
NAS1149D0616K		2	20A	2
NAS1149D0663J		1	20B	2
		2	185A	1
NAS1149D0863J		2	185B	1
		2	675A	6
NAS1149F0332P		1	100A	1
NAS1149F0432P		1	100B	1
		1		

27-31-95

ILLUSTRATED PARTS LIST

Page 1013

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
NAS1368N8D		2	105	1
NAS1612-4		1	70	2
NAS1612-6		1	85	2
NAS43DD6-68		1	55A	1
NAS602-6P		2	170	10
NAS623-3-5		2	205	2
NAS6604-24		2	100	2
NAS6604-46		2	225	2
		2	225A	1
NAS6604-67		2	226	2
		2	226A	2
NAS6604-8		2	235	4
NAS6604H48		2	230	2
		2	230A	2
NAS6704-26		2	60	4
NAS75-3-121		2	685	3
NAS77A6-42P		2	475	1
NAS8202A6		2	170A	10
YR1315		2	465A	1


27-31-95

ILLUSTRATED PARTS LIST

Page 1014

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



Elevator Control Feel and Centering Unit Assembly
IPL Figure 1

27-31-95
ILLUSTRATED PARTS LIST
Page 1015
Mar 01/2006



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
-1	65C25465-1										
-1A	65C25465-2									A	RF
-1B	65C25465-3										
-1C	65C25465-4									B	RF
-1D	65C25465-7										
-1E	65C25465-8									C	RF
-1F	65C25465-9										
-1G	65C25465-10									D	RF
-1H	65C25465-11									E	RF
-1J	65C25465-12									F	RF
-1K	65C25465-15									G	RF
-1L	65C25465-16									H	RF
-1M	65C25465-17									I	RF
-1N	65C25465-18									J	RF
-1P	65C25465-19									K	RF
-1Q	65C25465-20									L	RF
-1R	65C25465-21									M	RF
-1S	65C25465-22									N	RF

-Item not Illustrated

27-31-95

ILLUSTRATED PARTS LIST

Page 1016

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
-1T	65C25465-23									P	RF
5	MS21042L4									A-K, M	2
5A	BACN10YR4CD									L, N, P	2
10	AN960PD416									A-K, M	2
10A	NAS1149D0463J									A-K, M	2
10B	NAS1149D0463J									L, N, P	2
15	MS21042L6									A-K, M	2
15A	BACN10YR6CD									L, N, P	2
20	AN960PD616									A-K, M	2
20A	NAS1149D0663J									A-K, M	2
20B	NAS1149D0663J									L, N, P	2
25	69-27158-4										1
30	69-27163-5										1
35	NAS1104-25										1
40	69-27158-10										1
45	69-27163-13										1
50	BACB30NF4-43										1
55	NAS43DD6-44										
55A	NAS43DD6-68										1
60	65C25465-5									A-F	1
-60A	65C25465-14									G-N, P	1
65	MS21902-4										2
70	NAS1612-4										2
75	MS21902D6										1
80	MS21916D6-5										1
85	NAS1612-6										2
90	65-44503-8									A-F	1
-90A	65-44503-10									G-N, P	1

-Item not Illustrated

27-31-95

ILLUSTRATED PARTS LIST

Page 1017

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
95	BACN10HR4CD		.	NUT							1
100	AN960-416L		.	WASHER					A-K, M		1
100A	NAS1149F0432P		.	WASHER (OPT ITEM 100)					A-K, M		1
100B	NAS1149F0432P		.	WASHER					L, N, P		1
105	66-21297-2		.	BUSHING							1
110	65-38904-2		.	BLOCK-SLIDE							1
115	69-73358-1		.	FITTING							1
120	65C25505-1			DELETED							
120A	65C25505-2		.	UNIT ASSY-CENTERING (FOR DETAILS SEE FIG. 2) (PRE ALERT SB 737-27A1194)					A		1
-120B	65C25505-3			DELETED							
-120C	65C25505-4		.	UNIT ASSY-CENTERING (FOR DETAILS SEE FIG. 2)					B		1
-120D	65C25505-5			DELETED							
-120E	65C25505-6		.	UNIT ASSY-CENTERING (FOR DETAILS SEE FIG. 2)					C		1
-120F	65C25505-7			DELETED							
-120G	65C25505-8		.	UNIT ASSY-CENTERING (FOR DETAILS SEE FIG. 2)					D, H		1
-120H	65C25505-9		.	UNIT ASSY-CENTERING (FOR DETAILS SEE FIG. 2)					E, I		1
-120J	65C25505-10		.	UNIT ASSY-CENTERING (FOR DETAILS SEE FIG. 2) (PRE ALERT SB 737-27A1194) (REPLACED BY ITEMS 120N, 120Q, 120T)					F, G		1
-120K	65C25505-11		.	UNIT ASSY-CENTERING (FOR DETAILS SEE FIG. 2)					J		1
-120L	65C25505-11		.	UNIT ASSY-CENTERING (FOR DETAILS SEE FIG. 2) (POST ALERT SB 737-27A1194) (PRE SB 737-27-1197)					A, F		1
-120M	65C25505-12		.	UNIT ASSY-CENTERING (FOR DETAILS SEE FIG. 2)					K		1

-Item not Illustrated

27-31-95

ILLUSTRATED PARTS LIST

Page 1018

Mar 01/2006




COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE	USAGE CODE	UNITS PER ASSY
1-					
-120N	65C25505-12		. UNIT ASSY-CENTERING (FOR DETAILS SEE FIG. 2) (REPLACES ITEM 120J)	F, G	1
-120P	65C25505-13		. UNIT ASSY-CENTERING (FOR DETAILS SEE FIG. 2)	L	1
-120Q	65C25505-13		. UNIT ASSY-CENTERING (FOR DETAILS SEE FIG. 2) (REPLACES ITEM 120J)	F, G	1
-120R	65C25505-14		. UNIT ASSY-CENTERING (FOR DETAILS SEE FIG. 2)	M	1
-120S	65C25505-14		. UNIT ASSY-CENTERING (FOR DETAILS SEE FIG. 2) (POST SB 737-27-1197)	A, F	1
-120T	65C25505-14		. UNIT ASSY-CENTERING (FOR DETAILS SEE FIG. 2) (REPLACES ITEM 120J)	F, G	1
-120U	65C25505-15		. UNIT ASSY-CENTERING (FOR DETAILS SEE FIG. 2)	N	1
-120V	65C25505-16		. UNIT ASSY-CENTERING (FOR DETAILS SEE FIG. 2)	P	1
125	BAC27DCT0346		. MARKER		1

-Item not Illustrated



COMPONENT MAINTENANCE MANUAL



Elevator Control Centering Unit Assembly
IPL Figure 2 (Sheet 1 of 7)

27-31-95
ILLUSTRATED PARTS LIST
Page 1020
Mar 01/2006

COMPONENT MAINTENANCE MANUAL



Elevator Control Centering Unit Assembly
IPL Figure 2 (Sheet 2 of 7)


27-31-95

ILLUSTRATED PARTS LIST

Page 1021

Mar 01/2006


COMPONENT MAINTENANCE MANUAL



Elevator Control Centering Unit Assembly
IPL Figure 2 (Sheet 3 of 7)



27-31-95
ILLUSTRATED PARTS LIST
Page 1022
Mar 01/2006

COMPONENT MAINTENANCE MANUAL



Elevator Control Centering Unit Assembly
IPL Figure 2 (Sheet 4 of 7)

COMPONENT MAINTENANCE MANUAL



Elevator Control Centering Unit Assembly
IPL Figure 2 (Sheet 5 of 7)


27-31-95

ILLUSTRATED PARTS LIST


Page 1024

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



G



665A — 670
THRU
725

H

Elevator Control Centering Unit Assembly
IPL Figure 2 (Sheet 6 of 7)


27-31-95

ILLUSTRATED PARTS LIST

Page 1025

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



Elevator Control Centering Unit Assembly
IPL Figure 2 (Sheet 7 of 7)

27-31-95
ILLUSTRATED PARTS LIST
Page 1026
Mar 01/2006



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
2-											
-1	65C25505-1										
-1A	65C25505-2									A	RF
-1B	65C25505-3										
-1C	65C25505-4									B	RF
-1D	65C25505-5										
-1E	65C25505-6									C	RF
-1F	65C25505-7										
-1G	65C25505-8									D	RF
-1H	65C25505-9									E	RF
-1J	65C25505-10									F	RF
-1K	65C25505-11									G	1
-1L	65C25505-12									H	1
-1M	65C25505-13									I	1
-1N	65C25505-14									J	1
-1P	65C25505-15									K	1
-1Q	65C25505-16									L	1
5	MS20615-6M26									A-H, J	1
5A	BACB30MY6R18									A-H, J	1

-Item not Illustrated

27-31-95

ILLUSTRATED PARTS LIST

Page 1027

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
2-											
-5B	BACB30MY6K18		.	BOLT						A-H, J	1
				(OPT ITEM 5)							
-5C	BACB30VT6K18		.	BOLT						A-H, J	1
				(OPT ITEM 5)							
-5D	BACB30MY6K18		.	BOLT						I, K, L	1
				(OPT ITEM 5E)							
-5E	BACB30VT6K18		.	BOLT						I, K, L	1
				(OPT ITEM 5D)							
6	BACC30M6		.	COLLAR							1
				(USED WITH ITEM 5A, 5B, 5D)							
-6A	BACN10YR3CD		.	NUT							1
				(USED WITH ITEM 5C, 5E)							
10	69-73355-2		.	RETAINER							1
15	69-73349-1		.	HOUSING ASSY-BEARING						A, F, G, H, I, J, K	1
-15A	69-73349-2		.	HOUSING ASSY-BEARING						B-E	1
-15B	69-73349-3		.	HOUSING ASSY-BEARING						L	1
20	BACR15BA5D		.	RIVET							2
25	BACR15BB5D		.	RIVET							1
30	69-73459-3		.	RETAINER							1
35	BACB10AW16		.	BEARING						A-K	1
-35A	BACB10FV16		.	BEARING						L	1
40	69-73342-1		.	HOUSING ASSY							1
45	65C25504-1		.	CRANK ASSY-INPUT							1
-45A	65C25504-2		.	CRANK ASSY-INPUT						A, B, C	1
				(OPT ITEM 45)							
				ATTACHING PARTS							
50	MS21042L4		.	NUT						A-H, J	4
-50A	BACN10YR4CD		.	NUT						I, K, L	4
55	AN960PD416		.	WASHER						A-H, J	4
-55A	NAS1149D0463J		.	WASHER						A-H, J	4
				(OPT ITEM 55)							
-55B	NAS1149D0463J		.	WASHER						I, K, L	4

-Item not Illustrated

27-31-95

ILLUSTRATED PARTS LIST

Page 1028

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
2-											
60	NAS6704-26		.	B	O	L	T				4
			-----*								
65	69-38919-1		.	.	S	L	E	E			1
70	BACB10AR5		.	.	B	E	A	R	I	N	1
75	65C25504-3		.	.	B	O	N	D	E	D	1
											(USED ON ITEM 45)
-75A	65C25504-4		.	.	B	O	N	D	E	D	1
											(USED ON ITEM 45A)
80	69-70464-7		.	S	P	A	C	E	R		1
85	65C25533-1		.	C	R	A	N	K	A	S	1
											C, E
			ATTACHING PARTS								
90	MS21042L4		.	N	U	T					2
											C, E
95	AN960PD416		.	W	A	S	H	E	R		2
											C, E
100	NAS6604-24		.	B	O	L	T				2
											C, E
			-----*								
105	NAS1368N8D		.	.	G	R	O	M	M	E	1
											C, E
110	65C25533-2		.	.	C	R	A	N	K		1
											C, E
115	MS20615-6M26		.	R	I	V	E	T			2
											A-H, J
115A	BACB30MY6R21		.	B	O	L	T				2
											(OPT ITEM 115)
-115B	BACB30MY6K21		.	B	O	L	T				2
											(OPT ITEM 115)
-115C	BACB30VT6K21		.	B	O	L	T				2
											(OPT ITEM 115B)
-115D	BACB30MY6K21		.	B	O	L	T				2
											(OPT ITEM 115E)
-115E	BACB30VT6K21		.	B	O	L	T				2
											(OPT ITEM 115D)
116	BACC30M6		.	C	O	L	L	A	R		2
											(USED WITH ITEM 115A, 115B, 115D)
-116A	BACN10YR3CD		.	N	U	T					2
											(USED WITH ITEM 115C, 115E)
120	69-73355-1		.	R	E	T	A	I	N	E	1
											A, B, D, F, G, H, I, J, K, L

-Item not Illustrated

27-31-95

ILLUSTRATED PARTS LIST

Page 1029

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
2-											
-120A	69-73355-3		.							C, E	1
125	69-73349-1		.							A, F, G, H, I, J, K	1
-125A	69-73349-2		.							B-E	1
-125B	69-73349-3		.							L	1
130	BACR15BA5D		.	.							2
135	BACR15BB5D		.	.							1
140	69-73459-3		.	.							1
145	BACB10AW16		.	.						A-K	1
-145A	BACB10FV16		.	.						L	1
150	69-73342-1		.	.							1
151	BACB30NR5K47		.							I, K, L	1
152	BACB30NR4K65		.							G, H, J	1
										(OPT ITEM 152A)	
-152A	BACB30NR4K64		.							G, H, J	1
										(OPT ITEM 152)	
153	BACB30NR5K65		.							G, H, J	1
										(OPT ITEM 153A, 153B)	
-153A	BACB30NF5-65		.							G, H, J	1
										(OPT ITEM 153, 153B)	
-153B	69-87836-1		.							G, H, J	1
										(OPT ITEM 153, 153A)	
155	65C25522-1		.								1
157	BACB30NR4K65		.							G, H, J	1
										(OPT ITEM 157A)	
-157A	BACB30NR4K64		.							G, H, J	1
										(OPT ITEM 157)	
160	MS21209F1-15		.	.							1
165	65C25522-2		.	.							1
167	NAS1149D0463J		.							G, H, J	1
										(USED WITH ITEM 157)	
-167A	NAS1149D0432J		.							G, H, J	1
										(USED WITH ITEM 157A)	
168	NAS1149D0563J		.							G, H, J	1
170	NAS602-6P		.							A-H, J	10

-Item not Illustrated

27-31-95

ILLUSTRATED PARTS LIST

Page 1030

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
2-											
-170A	NAS8202A6		.	SCREW						I, K, L	10
172	NAS1149D0563J		.	WASHER						I, K, L	1
175	69-73350-1		.	PLATE-COVER						A-I, K, L	1
175A	69-73350-2		.	PLATE-COVER						J	1
177	NAS1149D0463J		.	WASHER (USED WITH ITEM 152)						G, H, J	1
-177A	NAS1149D0432J		.	WASHER (USED WITH ITEM 152A)						G, H, J	1
180	BACN10JC8CM		.	NUT							1
181	BACN10YR5CD		.	NUT						I, K, L	1
182	BACN10YR4CD		.	NUT						G, H, J	1
183	BACN10YR5CD		.	NUT						G, H, J	1
184	BACN10YR4CD		.	NUT						G, H, J	1
185	AN960PD816		.	WASHER						A-H, J	1
-185A	NAS1149D0863J		.	WASHER (OPT ITEM 185)						A-H, J	1
-185B	NAS1149D0863J		.	WASHER						I, K, L	1
186	BACB28Y5D286		.	BUSHING						I, K, L	1
187	BACB28Z4-046		.	BUSHING (OPT ITEM 187A, 187B)						G, H, J	2
-187A	BACB28AK04-046		.	BUSHING (OPT ITEM 187, 187B)						G, H, J	2
-187B	BACB28Y4D046		.	BUSHING (OPT ITEM 187, 187A)						G, H, J	2
188	BACB28AK05-382		.	BUSHING (OPT ITEM 188A, 188B, 188C)						G, H, J	1
-188A	BACB28BA0507382		.	BUSHING (OPT ITEM 188, 188B, 188C)						G, H, J	1
-188B	NAS1057W5-382		.	BUSHING (OPT ITEM 188, 188A, 188C)						G, H, J	1
-188C	BACB28AK05-368		.	BUSHING (OPT ITEM 188, 188A, 188B) (USED WITH ITEM 188D)						G, H, J	1
-188D	BACB28AK05-014		.	BUSHING (USED WITH ITEM 188C)						G, H, J	1

-Item not Illustrated

27-31-95

ILLUSTRATED PARTS LIST

Page 1031

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
2-											
189	BACB28Z4-034		.	BUSHING						G, H, J	1
				(OPT ITEM 189A, 189B)							
189A	BACB28AK04-034		.	BUSHING						G, H, J	1
				(OPT ITEM 189, 189B)							
189B	BACB28Y4D034		.	BUSHING						G, H, J	1
				(OPT ITEM 189, 189A)							
190	69-73352-1		.	SHAFT-INNER							1
192	69-87835-1		.	STOP SUPPORT ASSY						G, H, J	2
195	MS20615-6M			DELETED							
195A	BACR15BB6D		.	RIVET							2
				(OPT ITEM 195B, 195C, 195D)							
195B	BACB30MY6K13		.	LOCKBOLT							2
				(OPT ITEM 195A, 195C, 195D)							
-195C	BACB30MY6K13X		.	LOCKBOLT-OVERSIZE							2
				(OPT ITEM 195A, 195B, 195D)							
-195D	BACB30MY6K13Y		.	LOCKBOLT-OVERSIZE							2
				(OPT ITEM 195A, 195B, 195C)							
196	BACC30M6		.	COLLAR							2
				(USED ON ITEMS 195B, 195C, 195D)							
197	NAS1149D0332J		.	WASHER							2
				(USED ON ITEMS 195B, 195C, 195D)							
200	69-73351-2		.	SHAFT-INNER							1
205	NAS623-3-5		.	SCREW							2
210	69-73356-1		.	RETAINER-SPRING POST							1
215	MS21042L4		.	NUT					A-F		10
-215A	MS21042L4		.	NUT					G, H, J		9
-215B	BACN10YR4CD		.	NUT					I, K, L		10
220	AN960PD416		.	WASHER					A-F		10
-220A	NAS1149D0463J		.	WASHER					A-F		10
				(OPT ITEM 220)							
-220B	AN960PD416		.	WASHER					G, H, J		9
-220C	NAS1149D0463J		.	WASHER					G, H, J		9
				(OPT ITEM 220B)							
-220D	NAS1149D0463J		.	WASHER					I, K, L		10
225	NAS6604-46		.	BOLT					A-F		2

-Item not Illustrated

27-31-95

ILLUSTRATED PARTS LIST

Page 1032

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY	
			1	2	3	4	5	6	7			
2-												
-225A	NAS6604-46		.	B	O	L	T			G, H, J	1	
-225B	BACB30NM4K46		.	B	O	L	T			I, K, L	2	
226	NAS6604-67		.	B	O	L	T			A-H, J	2	
-226A	NAS6604-67		.	B	O	L	T			I, K, L	2	
-226B	BACB30NM4K67		.	B	O	L	T			I, K, L	2	
								(OPT ITEM 226A)				
230	NAS6604H48		.	B	O	L	T			A-H, J	2	
-230A	NAS6604H48		.	B	O	L	T			I, K, L	2	
-230B	BACB30NM4HK48		.	B	O	L	T			I, K, L	2	
								(OPT ITEM 230A)				
235	NAS6604-8		.	B	O	L	T			A-H, J	4	
-235A	BACB30NM4K8		.	B	O	L	T			I, K, L	4	
240	BACB28Y4D230		.	B	U	S	H	I	N		4	
245	69-73346-2		.	R	E	T	A	I	N	E	2	
250	65C25439-1											
250A	65C25439-2		.	H	O	U	S	I	N	G	A	1
								(OPT ITEM 250B)				
-250B	65C25439-17		.	H	O	U	S	I	N	G	A	1
-250C	65C25439-25		.	H	O	U	S	I	N	G	A	1
255	BACR15BB5D											
255A	BACR15BA5D		.	.	R	I	V	E	T		12	
260	69-73346-4		.	.	R	E	T	A	I	N	2	
265	BACB10AS21		.	.	B	E	A	R	I	N	2	
270	BACB10AR5		.	.	B	E	A	R	I	N	1	
275	69-38919-32		.	.	S	L	E	E	V	E	1	
280	BACR15BA3D		.	.	R	I	V	E	T		4	
285	BACN10JP3C		.	.	N	U	T	P	L	A	2	
290	BACR15BA3D		.	.	R	I	V	E	T		8	
295	BACN10JP08A		.	.	N	U	T	P	L	A	4	
297	BACR15BA5D		.	.	R	I	V	E	T		3	
298	69-74649-1		.	.	S	T	O	P	-	A	1	
300	65C25439-3											

-Item not Illustrated

27-31-95

ILLUSTRATED PARTS LIST

Page 1033

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
2-											
300A	65C25439-4								. . MATCHED SET ASSY (USED ON ITEM 250A)		1
-300B	65C25439-18								. . MATCHED SET ASSY (USED ON ITEM 250B)		1
-300C	65C25439-26								. . MATCHED SET ASSY (USED ON ITEM 250C)		1
305	65C25439-5								DELETED		
305A	65C25439-7								. . . BOND ASSY (USED ON ITEM 300A) (MATCHED WITH ITEM 325A)		1
-305B	65C25439-19								. . . BOND ASSY (USED ON ITEM 300B) (MATCHED WITH ITEM 325B)		1
-305C	65C25439-27								. . . BOND ASSY (USED ON ITEM 300C) (MATCHED WITH ITEM 325C)		1
310	BACR15BA3D							 RIVET		6
315	BACN10JP08A							 NUTPLATE		3
320	65C25439-9								DELETED		
320A	65C25439-11							 BOND ASSY (USED ON ITEM 305A)		1
-320B	65C25439-21							 BOND ASSY (USED ON ITEM 305B)		1
-320C	65C25439-29							 BOND ASSY (USED ON ITEM 305C)		1
325	65C25439-6								DELETED		
325A	65C25439-8								. . . BOND ASSY (USED ON ITEM 300A) (MATCHED WITH ITEM 305A)		1
-325B	65C25439-20								. . . BOND ASSY (USED ON ITEM 300B) (MATCHED WITH ITEM 305B)		1
-325C	65C25439-28								. . . BOND ASSY (USED ON ITEM 300C) (MATCHED WITH ITEM 305C)		1
330	BACR15BA3D							 RIVET		6
335	BACN10JP08A							 NUTPLATE		3
340	65C25439-10								DELETED		

-Item not Illustrated

27-31-95

ILLUSTRATED PARTS LIST

Page 1034

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
2-											
340A	65C25439-12							 BOND ASSY (USED ON ITEM 325A)		1
-340B	65C25439-22							 BOND ASSY (USED ON ITEM 325B)		1
-340C	65C25439-28							 BOND ASSY (USED ON ITEM 325C)		1
345	69-73378-1								. BRACKET ASSY	B-E	1
									ATTACHING PARTS		
350	BACB30DX6-5								DELETED		
352	BACR15BB5D								. RIVET	B-E	3
355	NAS1080-06								DELETED		
									----- * -----		
360	BACR15BB5D								. . RIVET		3
365	69-73378-3								. . BRACKET		1
370	69-73378-2								. . ANGLE		1
375	65C25487-1								. FITTING ASSY-ACTUATOR		1
-375A	65C25487-3								. FITTING ASSY-ACTUATOR (OPT ITEM 375)	A, B, C	1
380	69-38919-2								. . SLEEVE		1
385	MS14104-6								. . BEARING		1
390	BACB28Y10D287								. . BUSHING		1
395	65C25487-2								. . BONDED ASSY-FITTING (USED ON ITEM 375)		1
-395A	65C25487-4								. . BONDED ASSY-FITTING (USED ON ITEM 375A)		1
400	69-73361-1								. SPRING-OUTER	A-J	1
400A	251A2190-2								. SPRING-OUTER	K, L	1
405	69-73360-1								. SPRING-INNER	A-J	1
405A	251A2184-2								. SPRING-INNER (OPT ITEM 405B)	K, L	1
405B	251A2184-3								. SPRING-INNER (OPT ITEM 405A)	K, L	1
410	65C25513-1								. POST ASSY-SPRING GROUND	A-J	1
-410A	65C25513-3								. POST ASSY-SPRING GROUND	K, L	1

-Item not Illustrated

27-31-95

ILLUSTRATED PARTS LIST

Page 1035

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
2-											
415	BACB30DX6-56		. .								1
-415A	BACB30MB6A56		. .								1
420	NAS1080-06		. .								1
-420A	BACC30BH6		. .								1
425	65C25513-2		. .						A-J		1
-425A	65C25513-4		. .						K, L		1
430	69-73351-1		. .								1
435	65C25512-1		. .						A-J		1
-435A	65C25512-2		. .						A, B, C		1
-435B	65C25512-9		. .						K		1
-435C	65C25512-10		. .						L		1
440	BACR15BB6D20		. .								3
440A	BACB30MY6K18		. .								3
441	BACC30M6		. .								3
442	NAS1149D0332J		. .								3
445	NAS1080D06		. .								2
-445A	BACC30M6		. .								2
450	AN960KD10L		. .								4
-450A	NAS1149D0332J		. .								4
455	BACB30GP6-18		. .								2
-455A	BACB30MY6K18		. .								2
460	69-73348-1		. .								2

-Item not Illustrated

27-31-95

ILLUSTRATED PARTS LIST

Page 1036

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
2-											
465	BACB10ET06		.	.						A-K	1
-465A	AC69001		.	.						L	1
470	69-73340-1		.	.						A-J	1
-470A	69-73340-3		.	.						K, L	1
475	NAS77A6-42P		.	.	.						1
480	69-73340-2		.	.	.					A-J	1
-480A	69-73340-4		.	.	.					K, L	1
485	65C25512-3		.	.							1
-485A	65C25512-4		.	.							1
490	65C25512-5		.	.	.						1
-490A	65C25512-7		.	.	.						1
495	65C25512-6		.	.	.						1
-495A	65C25512-8		.	.	.						1
500	BACB10AS10		.								2
505	BACB28Y10D047		.								1
510	BACB10AS12		.								2
515	69-73353-1		.								1
520	BACC30K6										DELETED
520A	BACC30K8		.								1
-520B	BACC30M8		.								1
525	BACB30GW6-24										DELETED
525A	BACB30GW8-24		.								1
-525B	BACB30FM8-24		.								1

-Item not Illustrated

27-31-95

ILLUSTRATED PARTS LIST

Page 1037

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
2-											
530	MS21042L6		.	NUT						A-H, J	1
-530A	BACN10YR6CD		.	NUT						I, K, L	1
535	69-27163-11			DELETED							
535A	69-27163-15		.	BOLT-HOLLOW							1
537	AN960KD616L		.	WASHER						A-H, J	1
-537A	NAS1149D0616K		.	WASHER (OPT ITEM 537)						A-H, J	1
-537B	NAS1149D0616J		.	WASHER						I, K, L	1
540	BACB28AK06-032		.	BUSHING							1
545	65C25485-1		.	LEVER ASSY						A-H, J	1
-545A	65C25485-3		.	LEVER ASSY (OPT ITEM 545)						A, B, C	1
-545B	65C25485-5		.	LEVER ASSY						I, K, L	1
550	BACB28X6-018			DELETED							
550A	BACB28X6-C018		.	BUSHING							1
555	69-38919-2		.	SLEEVE							1
560	MS14104-6		.	BEARING (REPLACED BY ITEM 560A)							1
-560A	MS14104-6K		.	BEARING (REPLACES ITEM 560)							1
565	65C25485-2		.	LEVER ASSY-BONDED (USED ON ITEMS 545,545B)							1
-565A	65C25485-4		.	LEVER ASSY-BONDED (USED ON ITEM 545A)							1
570	BACC30K6			DELETED							
570A	BACC30K8		.	COLLAR (USED ON ITEM 575A)							1
-570B	BACC30M8		.	COLLAR (USED ON ITEM 575B)							1
575	BACB30GW6-24			DELETED							
575A	BACB30GW8-28		.	LOCKBOLT (OPT ITEM 575B)							1
-575B	BACB30FM8-28		.	LOCKBOLT (OPT ITEM 575A)							1
580	MS21042L6		.	NUT						A-H, J	1

-Item not Illustrated

27-31-95

ILLUSTRATED PARTS LIST

Page 1038

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
2-											
-580A	BACN10YR6CD		.	NUT						I, K, L	1
585	69-27163-12			DELETED							
585A	69-27163-14		.	BOLT-HOLLOW							1
590	251T2125-3		.	WASHER							2
595	251T2125-2		.	BUSHING							2
600	69-73435-2		.	LINK ASSY						A, F-L	1
-600A	69-73435-1		.	LINK ASSY						B-E	1
605	69-38919-33		.	SLEEVE							2
610	BACB10BX6		.	BEARING							2
615	69-73435-4		.	BOND ASSY						A, F-L	1
-615A	69-73435-3		.	BOND ASSY						B-E	1
620	BACC30K6			DELETED							
620A	BACC30K8		.	COLLAR (USED ON ITEM 625A)							2
-620B	BACC30M8		.	COLLAR (USED ON ITEM 625B)							2
625	BACB30GW6-27			DELETED							
625A	BACB30GW8-28		.	LOCKBOLT (OPT ITEM 625B)							2
-625B	BACB30FM8-28		.	LOCKBOLT (OPT ITEM 625A)							2
627	AN960XC416L		.	WASHER						A-H, J	AR
-627A	NAS1149C0432B		.	WASHER (OPT ITEM 627)						A-H, J	AR
-627B	NAS1149D0416J		.	WASHER						I, K, L	AR
630	MS21042L6		.	NUT						A-H, J	2
-630A	BACN10YR6CD		.	NUT						I, K, L	2
635	69-27163-12			DELETED							
635A	69-27163-14		.	BOLT-HOLLOW							2
637	AN960B616		.	WASHER (OPT ITEM 637B)						A-G, J	AR
-637A	AN960KD616L		.	WASHER (OPT ITEM 637C)						A-G, J	AR

-Item not Illustrated

27-31-95

ILLUSTRATED PARTS LIST

Page 1039

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY	
			1	2	3	4	5	6	7			
2-												
-637B	NAS1149B0463H		.	W	A	S	H				A-G, J	AR
-637C	NAS1149B0616K		.	W	A	S	H				A-G, J	AR
-637D	251T2125-5		.	W	A	S	H				H	AR
-637E	NAS11490616J		.	W	A	S	H				I, K, L	AR
-637F	251T2125-5		.	W	A	S	H				I, K, L	AR
640	AN960B616		.	W	A	S	H				A-G, J	4
-640A	NAS1149B0463H		.	W	A	S	H				A-G, J	4
-640B	251T2125-5		.	W	A	S	H				H, I, K, L	4
645	251T2125-1		.	B	U	S	H					4
650	69-73434-3		.	T	I	E	A	S	S		A, F, G, H, J	4
-650A	69-73434-1		.	T	I	E	A	S	S		B-E	4
-650B	69-73434-5		.	T	I	E	A	S	S		A, F, G, H, J	4
-650C	69-73434-5		.	T	I	E	A	S	S		IKL	4
655	MS20615-4MP13		.	R	I	V	E	T				4
660	MS20615-5MP13		.	R	I	V	E	T			A-G, J	1
-660A	BACR15CE5M13		.	R	I	V	E	T			H	1
665	65C25517-1											
665A	65C25517-2		.	C	A	M	S	H	A	S	A	1
-665B	65C25517-3		.	C	A	M	S	H	A	S	B, D	1
-665C	65C25517-4		.	C	A	M	S	H	A	S	B	1
-665D	65C25517-5		.	C	A	M	S	H	A	S	C, E	1
-665E	65C25517-6		.	C	A	M	S	H	A	S	C	1
-665F	65C25517-7		.	C	A	M	S	H	A	S	F, G, J	1

-Item not Illustrated

27-31-95

ILLUSTRATED PARTS LIST

Page 1040

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
2-											
-665G	65C25517-7		.							A	1
-665H	65C25517-9		.							A	1
-665J	65C25517-9		.							F, G, J	1
-665K	65C25517-8		.							H	1
-665L	65C25517-9		.							I, K	1
-665M	65C25517-10		.							L	1
670	NAS1080-06		.	.							3
675	AN960-10L		.	.							6
-675A	NAS1149F0332P		.	.							6
680	BACB30DX6-27		.	.							3
685	NAS75-3-121		.	.							3
690	65C25518-1										
-690A	65C25518-2		.	.							1
-690B	65C25518-7		.	.							1
-690C	65C25518-8		.	.							1
-690D	65C25518-9		.	.							1
695	65C25511-1		.	.							1
-695A	65C25511-3		.	.							1
-695B	65C25510-1		.	.							1
-695C	65C25510-3		.	.							1
700	69-38919-2		.	.	.						2
705	MS14104-6		.	.	.						2

-Item not Illustrated

27-31-95

ILLUSTRATED PARTS LIST

Page 1041

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY		
			1	2	3	4	5	6	7				
2-													
-705A	MS14104-6K												2
710	65C25511-2												1
-710A	65C25511-4												1
-710B	65C25510-2												1
-710C	65C25510-4												1
715	69-73345-1												1
-715A	69-73345-2												1
720	69-73344-1												1
-720A	69-73344-2												1
-720B	69-73344-3												1
725	69-73343-1												1
-725A	69-73343-2												1
800	BACB10AP5												2

-Item not Illustrated