



COMPONENT MAINTENANCE MANUAL WITH ILLUSTRATED PARTS LIST

STABILIZER TRIM COLUMN ACTUATED CUTOUT SWITCH ASSEMBLY

PART NUMBER

**65C25529-11, -12, -15, -16, -19, -21, -22, -23, -24,
-25, -26, -27, -6, -7**

BOEING PROPRIETARY, CONFIDENTIAL, AND/OR TRADE SECRET

Copyright © 1995 The Boeing Company
Unpublished Work - All Rights Reserved

Boeing claims copyright in each page of this document only to the extent that the page contains copyrightable subject matter. Boeing also claims copyright in this document as a compilation and/or collective work.

This document includes proprietary information owned by The Boeing Company and/or one or more third parties. Treatment of the document and the information it contains is governed by contract with Boeing. For more information, contact The Boeing Company, P.O. Box 3707, Seattle, Washington 98124.

Boeing, the Boeing signature, the Boeing symbol, 707, 717, 727, 737, 747, 757, 767, 777, 787, Dreamliner, BBJ, DC-8, DC-9, DC-10, KC-10, KDC-10, MD-10, MD-11, MD-80, MD-88, MD-90, P-8A, Poseidon and the Boeing livery are all trademarks owned by The Boeing Company; and no trademark license is granted in connection with this document unless provided in writing by Boeing.

PUBLISHED BY BOEING COMMERCIAL AIRPLANES GROUP, SEATTLE, WASHINGTON, USA
A DIVISION OF THE BOEING COMPANY
PAGE DATE: Jul 01/2009

27-41-91

Page 1
Jul 01/2009



COMPONENT MAINTENANCE MANUAL

Revision No. 23
Jul 01/2009

To: All holders of STABILIZER TRIM COLUMN ACTUATED CUTOFF SWITCH ASSEMBLY 27-41-91.

Attached is the current revision to this COMPONENT MAINTENANCE MANUAL

The COMPONENT MAINTENANCE MANUAL is furnished either as a printed manual, on microfilm, or digital products, or any combination of the three. This revision replaces all previous microfilm cartridges or digital products. All microfilm and digital products are reissued with all obsolete data deleted and all updated pages added.

For printed manuals, changes are indicated on the List of Effective Pages (LEP). The pages which are revised will be identified on the LEP by an R (Revised), A (Added), O (Overflow, i.e. changes to the document structure and/or page layout), or D (Deleted). Each page in the LEP is identified by Chapter-Section-Subject number, page number and page date.

Pages replaced or made obsolete by this revision should be removed and destroyed.

ATTENTION

IF YOU RECEIVE PRINTED REVISIONS, PLEASE VERIFY THAT YOU HAVE RECEIVED AND FILED THE PREVIOUS REVISION. BOEING MUST BE NOTIFIED WITHIN 30 DAYS IF YOU HAVE NOT RECEIVED THE PREVIOUS REVISION. REQUESTS FOR REVISIONS OTHER THAN THE PREVIOUS REVISION WILL REQUIRE A COMPLETE MANUAL REPRINT SUBJECT TO REPRINT CHARGES SHOWN IN THE DATA AND SERVICES CATALOG.

27-41-91
TRANSMITTAL LETTER
Page 1
Jul 01/2009



COMPONENT MAINTENANCE MANUAL

Location of Change

Description of Change

NO HIGHLIGHTS

27-41-91

HIGHLIGHTS

Page 1

Jul 01/2009



COMPONENT MAINTENANCE MANUAL

| Subject/Page | Date | Subject/Page | Date | Subject/Page | Date |
|--|-------------|---|-------------|---|-------------|
| TITLE PAGE | | 27-41-91 TESTING AND FAULT ISOLATION (cont) | | 27-41-91 ASSEMBLY (cont) | |
| O 1 | Jul 01/2009 | 108 | Jul 01/2006 | 702 | Mar 01/2006 |
| 2 | BLANK | 109 | Jul 01/2006 | 703 | Mar 01/2006 |
| 27-41-91 TRANSMITTAL LETTER | | 110 | Jul 01/2006 | 704 | Mar 01/2006 |
| O 1 | Jul 01/2009 | 27-41-91 DISASSEMBLY | | 705 | Mar 01/2006 |
| 2 | BLANK | 301 | Mar 01/2006 | 706 | Mar 01/2006 |
| 27-41-91 HIGHLIGHTS | | 302 | BLANK | 707 | Mar 01/2006 |
| O 1 | Jul 01/2009 | 27-41-91 CLEANING | | 708 | BLANK |
| 2 | BLANK | 401 | Mar 01/2006 | 27-41-91 FITS AND CLEARANCES | |
| 27-41-91 EFFECTIVE PAGES | | 402 | BLANK | 801 | Mar 01/2006 |
| 1 | Jul 01/2009 | 27-41-91 CHECK | | 802 | BLANK |
| 2 | BLANK | 501 | Mar 01/2006 | 27-41-91 SPECIAL TOOLS, FIXTURES, AND EQUIPMENT | |
| 27-41-91 CONTENTS | | 502 | Mar 01/2006 | 901 | Mar 01/2009 |
| 1 | Mar 01/2006 | 27-41-91 REPAIR - GENERAL | | 902 | BLANK |
| 2 | BLANK | 601 | Mar 01/2006 | 27-41-91 ILLUSTRATED PARTS LIST | |
| 27-41-91 TR AND SB RECORD | | 602 | Mar 01/2006 | 1001 | Nov 01/2008 |
| 1 | Mar 01/2006 | 27-41-91 REPAIR 1-1 | | 1002 | Jul 01/2006 |
| 2 | BLANK | 601 | Nov 01/2006 | 1003 | Mar 01/2006 |
| 27-41-91 REVISION RECORD | | 602 | Jul 01/2007 | 1004 | Mar 01/2006 |
| 1 | Mar 01/2006 | 27-41-91 REPAIR 2-1 | | 1005 | Mar 01/2006 |
| 2 | Mar 01/2006 | 601 | Nov 01/2006 | 1006 | Mar 01/2006 |
| 27-41-91 RECORD OF TEMPORARY REVISIONS | | 602 | Jul 01/2007 | 1007 | Mar 01/2006 |
| 1 | Mar 01/2006 | 27-41-91 REPAIR 3-1 | | 1008 | Mar 01/2006 |
| 2 | Mar 01/2006 | 601 | Nov 01/2006 | 1009 | Mar 01/2006 |
| 27-41-91 INTRODUCTION | | 602 | BLANK | 1010 | Mar 01/2006 |
| 1 | Mar 01/2009 | 27-41-91 REPAIR 4-1 | | 1011 | Mar 01/2006 |
| 2 | BLANK | 601 | Nov 01/2006 | 1012 | Mar 01/2006 |
| 27-41-91 DESCRIPTION AND OPERATION | | 602 | BLANK | 1013 | Mar 01/2006 |
| 1 | Mar 01/2006 | 27-41-91 REPAIR 5-1 | | 1014 | Mar 01/2006 |
| 2 | BLANK | 601 | Nov 01/2006 | 1015 | Mar 01/2006 |
| 27-41-91 TESTING AND FAULT ISOLATION | | 602 | BLANK | 1016 | Mar 01/2006 |
| 101 | Nov 01/2006 | 27-41-91 REPAIR 6-1 | | 1017 | Mar 01/2006 |
| 102 | Jul 01/2006 | 601 | Mar 01/2006 | 1018 | Mar 01/2006 |
| 103 | Jul 01/2006 | 602 | BLANK | 1019 | Mar 01/2006 |
| 104 | Jul 01/2006 | 27-41-91 REPAIR 7-1 | | 1020 | BLANK |
| 105 | Jul 01/2006 | 601 | Jul 01/2006 | | |
| 106 | Jul 01/2006 | 602 | BLANK | | |
| 107 | Jul 01/2006 | 27-41-91 ASSEMBLY | | | |
| | | 701 | Nov 01/2006 | | |

A = Added, R = Revised, D = Deleted, O = Overflow

27-41-91

EFFECTIVE PAGES

Page 1

Jul 01/2009



COMPONENT MAINTENANCE MANUAL

TABLE OF CONTENTS

| <u>Paragraph Title</u> | <u>Page</u> |
|--|------------------|
| STABILIZER TRIM CONTROL COLUMN ACTUATED SWITCH - CUTOUT SWITCH ASSEMBLY - DESCRIPTION AND OPERATION | 1 |
| TESTING AND FAULT ISOLATION | 101 |
| DISASSEMBLY | 301 |
| CLEANING | 401 |
| CHECK | 501 |
| REPAIR | 601 |
| ASSEMBLY | 701 |
| FITS AND CLEARANCES | (Not Applicable) |
| SPECIAL TOOLS, FIXTURES, AND EQUIPMENT | 901 |
| ILLUSTRATED PARTS LIST | 1001 |

27-41-91

CONTENTS

Page 1

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

TEMPORARY REVISION AND SERVICE BULLETIN RECORD

| BOEING SERVICE BULLETIN | BOEING TEMPORARY REVISION | OTHER DIRECTIVE | DATE OF INCORPORATION INTO MANUAL |
|-------------------------|---------------------------|-----------------|-----------------------------------|
| | | PRR 33329 | MAR 5/84 |
| | | PRR 33596 | SEP 5/84 |
| | | PRR 34475-2 | DEC 5/88 |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

27-41-91

TR AND SB RECORD

Page 1

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

All revisions to this manual will be accompanied by transmittal sheet bearing the revision number. Enter the revision number in numerical order, together with the revision date, the date filed and the initials of the person filing.

| Revision | | Filed | |
|----------|------|-------|----------|
| Number | Date | Date | Initials |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Revision | | Filed | |
|----------|------|-------|----------|
| Number | Date | Date | Initials |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

27-41-91
REVISION RECORD
Page 1
Mar 01/2006



COMPONENT MAINTENANCE MANUAL

All temporary revisions to this manual will be accompanied by a cover sheet bearing the temporary revision number. Enter the temporary revision number in numerical order, together with the temporary revision date, the date the temporary revision is inserted and the initials of the person filing. When the temporary revision is incorporated or cancelled, and the pages are removed, enter the date the pages are removed and the initials of the person who removed the temporary revision.

| Temporary Revision | | Inserted | | Removed | | Temporary Revision | | Inserted | | Removed | |
|--------------------|------|----------|----------|---------|----------|--------------------|----------|----------|------|---------|----------|
| Number | Date | Date | Initials | Date | Initials | Date | Initials | Number | Date | Date | Initials |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |
| | | | | | | | | | | | |

27-41-91

BOEING PROPRIETARY - Copyright © Unpublished Work - See title page for details



COMPONENT MAINTENANCE MANUAL

| Temporary Revision | | Inserted | | Removed | |
|--------------------|------|----------|----------|---------|----------|
| Number | Date | Date | Initials | Date | Initials |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

| Temporary Revision | | Inserted | | Removed | |
|--------------------|----------|----------|------|---------|----------|
| Date | Initials | Number | Date | Date | Initials |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

27-41-91

RECORD OF TEMPORARY REVISION



COMPONENT MAINTENANCE MANUAL

INTRODUCTION

1. General

- A. The instructions in this manual supply the data necessary to do the maintenance functions together with the test, fault isolation, repair, and replacement of the defective parts.
- B. This manual is divided into different parts:
 - (1) Title Page
 - (2) Transmittal Letter
 - (3) Highlights
 - (4) List of Effective Pages
 - (5) Table of Contents
 - (6) Temporary Revision & Service Bulletin Record
 - (7) Record of Revisions
 - (8) Record of Temporary Revisions
 - (9) Introduction
 - (10) Procedures & IPL Sections
- C. Components that can be repaired have a different repair number for each specified repair. To find the repair number location of a component, look in the Repair-General procedure at the beginning of the REPAIR section. The Repair-General procedure also has an explanation of the True Position Dimension symbols used.
- D. All dimensions, measures, quantities and weights included are in English units. When metric equivalents are given they will be in the parentheses that follow the English units.
- E. The introduction to the Illustrated Parts List (IPL) shows how the IPL data is used.
- F. Design changes, optional parts, configuration differences and Service Bulletin modifications may cause different part numbers. These part numbers are identified in the IPL with an alphabetical letter which is added to the end of the basic item number. This new item number is referred to as an alpha-variant. Throughout the manual, IPL basic item number references also apply to alpha-variants unless shown differently.
- G. The tool reference numbers found in the individual procedures and in the Special Tools, Fixtures, and Equipment section are used to identify if a tool is a standard tool (STD-XXXX), a commercial tool (COM-XXXX), or a Special Tool (SPL-XXXX). This reference number is also used to distinguish between tools with similar names in the same procedure. These reference numbers are for use in the documentation only. They are not to be used for ordering tools.

27-41-91

INTRODUCTION

Page 1

Mar 01/2009



COMPONENT MAINTENANCE MANUAL

STABILIZER TRIM CONTROL COLUMN ACTUATED SWITCH - CUTOUT SWITCH ASSEMBLY - DESCRIPTION AND OPERATION

1. Description

- A. The cutout switch assembly consists of 12 switches and 4 relays all attached to the wire bundle assembly. The switches and relays are mounted inside the mechanism assembly.
- B. The mechanism assembly consists of a cam attached to a shaft assembly. An input lever assembly with controlled shearout joint attaches to a gear and drives the cam to actuate the switches.

2. Operation

- A. The cutout switch assembly interrupts power to the main and autopilot trim motor and clutch when control column is moved in a direction opposing electrical trim.
- B. The cutout switch assembly also provides a signal to the flight control computer A and B modules when switches have been actuated.

3. Leading Particulars (Approximate)

- A. Length – 7 inches
- B. Width – 3 inches
- C. Height – 6 inches
- D. Weight – 3 pounds

27-41-91

DESCRIPTION AND OPERATION

Page 1

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

TESTING AND FAULT ISOLATION

1. Test

A. Tools/Equipment

NOTE: Equivalent substitutes may be used.

| Reference | Description |
|-----------|---|
| SPL-5372 | Test Equipment - Stabilizer Trim Control Cutout Switch (Part #: C27006-48, Supplier: 81205) |
| SPL-5374 | Test Equipment - Stabilizer Trim Control Cutout Switch (Part #: C27006-42, Supplier: 81205) |
| SPL-6044 | Test Fixture Assembly (C27006-24 included in C27006-47 & C27006-48) (Part #: C27006-48, Supplier: 81205) (Opt Part #: C27006-47, Supplier: 81205) |
| SPL-6045 | Test Fixture Assembly (C27006-13 included in C27006-42) (Part #: C27006-42, Supplier: 81205) |
| SPL-6046 | Test Box Assembly (C27006-43 included in C27006-42) (Part #: C27006-42, Supplier: 81205) |

B. General

- (1) This procedure has the data necessary to do a test of the stabilizer trim column cutout switch assembly (1A) after an overhaul or for fault isolation.
- (2) Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- (3) Refer to IPL Figure 1 for item numbers.

C. Test Procedure

- (1) Install switch assembly (1, IPL Figure 1) in C27006-24 test fixture assembly, SPL-6044 or C27006-13 test fixture assembly, SPL-6045. The C27006-13 test fixture assembly is part of the C27006-42 stabilizer trim control cutout switch, SPL-5374. The C27006-24 test fixture assembly is part of the C27006-48 test equipment, SPL-5372. See TESTING AND FAULT ISOLATION, Figure 101.

NOTE: Clockwise and counterclockwise rotation of lever assembly (165) are as viewed from the lever side of the switch assembly.

- (2) Check full travel (TESTING AND FAULT ISOLATION, Figure 102).
 - (a) Rotate lever assembly clockwise until internal stop is contacted. Check that lever position is 33.5°-35.5° from rig position.
 - (b) Rotate lever assembly counterclockwise until internal stop is contacted. Check that lever position is 34.5°-36.5° from rig position.
 - (c) Check that lever rotation is smooth and free of binding throughout entire travel.
- (3) Check the operation of the switches.
 - (a) Preparation.
 - 1) Connect switch assembly to C27006-43 test box assembly, SPL-6046.

27-41-91

TESTING AND FAULT ISOLATION

Page 101

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

- 2) Set all switches to OFF (TESTING AND FAULT ISOLATION, Figure 103).
- 3) Set POWER switch to ON (POWER light is ON, all other lights are OFF).

NOTE: POWER light will remain ON for remainder of test.
- (b) Check MAIN STAB TRIM - CLUTCH CUTOUT.
 - 1) Set MAIN STAB TRIM - CLUTCH CUTOUT switch to ON (MAIN STAB TRIM CLUTCH AFT, FWD, and CLUTCH CUTOUT lights are ON).
 - 2) Rotate input lever counterclockwise until MAIN STAB TRIM - CLUTCH AFT light goes OFF (CLUTCH FWD light remains ON). Check that lever position is 7.0°-8.2° from rig position.
 - 3) Rotate input lever clockwise until MAIN STAB TRIM - CLUTCH FWD light goes OFF (CLUTCH AFT light remains ON). Check that lever position is 4.8°-6.0° from rig position.
 - 4) Set MAIN STAB TRIM - CLUTCH CUTOUT switch to OFF.
- (c) Check MAIN STAB TRIM - MOTOR CUTOUT.
 - 1) Set MAIN STAB TRIM - MOTOR CUTOUT switch to ON (MAIN STAB TRIM MOTOR and MOTOR CUTOUT lights are ON).
 - 2) Rotate input lever counterclockwise until MAIN STAB TRIM - MOTOR light goes OFF. Check that lever position is 7.0°-8.2° from rig position.
 - 3) Rotate input lever clockwise until MAIN STAB TRIM - MOTOR light goes OFF. Check that lever position is 4.8°-6.0° from rig position.
 - 4) Set MAIN STAB TRIM - MOTOR CUTOUT switch to OFF.
- (d) Check MAIN STAB TRIM - RELAY.
 - 1) Set MAIN STAB TRIM - RELAY switch to ON (MAIN STAB TRIM - CLUTCH AFT, FWD, MOTOR, CLUTCH CUTOUT, and RELAY lights are ON).
 - 2) Rotate input lever counterclockwise to full travel. Check that MAIN STAB TRIM - CLUTCH AFT, FWD, MOTOR and RELAY lights are ON, and that the CLUTCH CUTOUT goes OFF.
 - 3) Rotate input lever clockwise to full travel. Check that MAIN STAB TRIM - CLUTCH AFT, FWD, MOTOR and RELAY lights are ON, and that the CLUTCH CUTOUT light comes ON.
 - 4) Set MAIN STAB TRIM - RELAY switch to OFF.
- (e) Check MAIN STAB TRIM ground continuity
 - 1) Check that there is continuity between P2-7 and ground.
- (f) Check AUTOPILOT STAB TRIM - CLUTCH CUTOUT.
 - 1) Set AUTOPILOT STAB TRIM - CLUTCH CUTOUT switch to ON (AUTOPILOT STAB TRIM - CLUTCH and CLUTCH CUTOUT lights are ON).
 - 2) Rotate input lever counterclockwise until AUTOPILOT STAB TRIM - CLUTCH light goes OFF. Check that lever position is 7.0°-8.2° from rig position.
 - 3) Rotate input lever clockwise until AUTOPILOT STAB TRIM - CLUTCH light goes OFF. Check that lever position is 4.8°-6.0° from rig position.
 - 4) Set AUTOPILOT STAB TRIM - CLUTCH CUTOUT switch to OFF.
- (g) Check AUTOPILOT STAB TRIM - MOTOR CUTOUT.

27-41-91

TESTING AND FAULT ISOLATION

Page 102

Jul 01/2006



COMPONENT MAINTENANCE MANUAL

- 1) Set AUTOPILOT STAB TRIM - MOTOR CUTOFF switch to ON (AUTOPILOT STAB TRIM - MOTOR AFT, FWD, and MOTOR CUTOFF lights are ON).
 - 2) Rotate input lever counterclockwise until AUTOPILOT STAB TRIM - MOTOR AFT light goes OFF (MOTOR FWD light remains ON). Check that lever position is 7.0°-8.2° from rig position.
 - 3) Rotate input lever clockwise until AUTOPILOT STAB TRIM - MOTOR FWD light goes OFF (MOTOR AFT light remains ON). Check that lever position is 4.8°-6.0° from rig position.
 - 4) Set AUTOPILOT STAB TRIM - MOTOR CUTOFF switch to OFF.
- (h) Check AUTOPILOT STAB TRIM - RELAY.
- 1) Set AUTOPILOT STAB TRIM - RELAY switch to ON (AUTOPILOT STAB TRIM - CLUTCH and RELAY lights are ON).
 - 2) Rotate input lever counterclockwise until AUTOPILOT STAB TRIM - MOTOR AFT and FWD lights come ON (CLUTCH light remains ON). Check that lever position is 7.0°-8.2° from rig position.
 - 3) Rotate input lever clockwise until AUTOPILOT STAB TRIM - MOTOR AFT and FWD lights come ON (CLUTCH light remains ON). Check that lever position is 4.8°-6.0° from rig position.
 - 4) Set AUTOPILOT STAB TRIM - RELAY switch to OFF.
- (i) Check AUTOPILOT STAB TRIM ground continuity
- 1) Check that there is continuity between P1-9 and test box ground.
- (j) Check Flight Control Computer A input.
- 1) Set FCC A INPUT switch to ON (FCC A AFT, A FWD, and FCC A INPUT lights are ON).
 - 2) Rotate input lever counterclockwise until FCC A AFT light goes OFF (FCC A FWD light remains ON). Check that lever position is 7.0°-8.2° from rig position.
 - 3) Rotate input lever clockwise until FCC A FWD light goes OFF (FCC A AFT light remains ON). Check that lever position is 4.8°-6.0° from rig position.
 - 4) Set FCC A INPUT switch to OFF.
- (k) Check Flight Control Computer B input.
- 1) Set FCC B INPUT switch to ON (FCC B AFT, B FWD, and FCC B INPUT lights are ON).
 - 2) Rotate input lever counterclockwise until FCC B AFT light goes OFF (FCC B FWD light remains ON). Check that lever position is 7.0°-8.2° from rig position.
 - 3) Rotate input lever clockwise until FCC B FWD light goes OFF (FCC B AFT light remains ON). Check that lever position is 4.8°-6.0° from rig position.
 - 4) Set FCC B INPUT switch to OFF.
- (l) Check main stab autopilot override.
- 1) Set AUTOPILOT STAB TRIM - RELAY switch to ON (AUTOPILOT STAB TRIM - CLUTCH, and AUTOPILOT STAB TRIM - RELAY lights are ON).
 - 2) Set MAIN STAB TRIM - CLUTCH CUTOFF switch to ON. (MAIN STAB TRIM - CLUTCH AFT and FWD, and MAIN STAB TRIM - CLUTCH CUTOFF lights are ON. AUTOPILOT STAB TRIM - CLUTCH light is OFF.)

27-41-91

TESTING AND FAULT ISOLATION

Page 103

Jul 01/2006



COMPONENT MAINTENANCE MANUAL

- 3) Rotate input lever counterclockwise to full travel. Check that MAIN STAB TRIM - CLUTCH FWD, AUTOPILOT STAB TRIM - MOTOR AFT, AUTOPILOT STAB TRIM - MOTOR FWD, MAIN STAB TRIM - CLUTCH CUTOUT, and AUTOPILOT STAB TRIM - RELAY lights are ON; MAIN STAB TRIM - CLUTCH AFT light goes OFF and AUTOPILOT STAB TRIM - CLUTCH light remains OFF.
 - 4) Rotate input lever clockwise to full travel. Check that MAIN STAB TRIM - CLUTCH AFT, MAIN STAB TRIM - CLUTCH CUTOUT, AUTOPILOT STAB TRIM - MOTOR AFT and FWD, and AUTOPILOT STAB TRIM - RELAY lights are ON; MAIN STAB TRIM - CLUTCH FWD light goes OFF and AUTOPILOT STAB TRIM - CLUTCH light remains OFF.
 - 5) Set MAIN STAB TRIM - CLUTCH CUTOUT switch and AUTOPILOT STAB TRIM - RELAY switch to OFF.
- (m) After the test is completed, set all switches to OFF and disconnect the test equipment from the switch assembly.

Table 101: Trouble Shooting Chart

| TROUBLE | PROBABLE CAUSE | CORRECTION |
|---|---|--|
| TESTING AND FAULT ISOLATION, Paragraph 1.C.(2)(a), TESTING AND FAULT ISOLATION, Paragraph 1.C.(2)(b), TESTING AND FAULT ISOLATION, Paragraph 1.C.(2)(c) | Defective gear (240), shaft assy (245), or cam (270). | Disassemble and replace defective part per TESTING AND FAULT ISOLATION, Paragraph 2.A. |
| TESTING AND FAULT ISOLATION, Paragraph 1.C.(3)(b)2) | Defective switch S10. | Replace defective switch per TESTING AND FAULT ISOLATION, Paragraph 2.B. |
| TESTING AND FAULT ISOLATION, Paragraph 1.C.(3)(b)3) | Defective switch S4. | Replace defective switch per TESTING AND FAULT ISOLATION, Paragraph 2.B. |
| TESTING AND FAULT ISOLATION, Paragraph 1.C.(3)(c)2) | Defective switch S8. | Replace defective switch per TESTING AND FAULT ISOLATION, Paragraph 2.B. |
| TESTING AND FAULT ISOLATION, Paragraph 1.C.(3)(c)3) | Defective switch S2. | Replace defective switch per TESTING AND FAULT ISOLATION, Paragraph 2.B. |
| TESTING AND FAULT ISOLATION, Paragraph 1.C.(3)(d)2) | Defective relay K4 or socket XK4 (CHECK, Figure 501). | Replace defective part (65, 70) TESTING AND FAULT ISOLATION, Paragraph 2.C. |
| TESTING AND FAULT ISOLATION, Paragraph 1.C.(3)(d)3) | Defective relay K3 or socket XK3 (CHECK, Figure 501). | Replace defective part (65, 70) per TESTING AND FAULT ISOLATION, Paragraph 2.C. |

27-41-91

TESTING AND FAULT ISOLATION

Page 104

Jul 01/2006



COMPONENT MAINTENANCE MANUAL

Table 101: Trouble Shooting Chart (Continued)

| TROUBLE | PROBABLE CAUSE | CORRECTION |
|--|---|---|
| TESTING AND FAULT ISOLATION, Paragraph 1.C.(3)(f)2) | Defective switch S11. | Replace defective switch per TESTING AND FAULT ISOLATION, Paragraph 2.B. |
| TESTING AND FAULT ISOLATION, Paragraph 1.C.(3)(f)3) | Defective switch S5. | Replace defective switch per TESTING AND FAULT ISOLATION, Paragraph 2.B. |
| TESTING AND FAULT ISOLATION, Paragraph 1.C.(3)(g)2) | Defective switch S9. | Replace defective switch per TESTING AND FAULT ISOLATION, Paragraph 2.B. |
| TESTING AND FAULT ISOLATION, Paragraph 1.C.(3)(g)3) | Defective switch S3. | Replace defective switch per TESTING AND FAULT ISOLATION, Paragraph 2.B. |
| TESTING AND FAULT ISOLATION, Paragraph 1.C.(3)(h)2)Light L5 goes OFF | Defective relay K2 or socket XK2 (CHECK, Figure 501). | Replace defective part (65, 70) per TESTING AND FAULT ISOLATION, Paragraph 2.C. |
| TESTING AND FAULT ISOLATION, Paragraph 1.C.(3)(h)3)Light L5 goes OFF | Defective relay K1 or socket XK1 (CHECK, Figure 501). | Replace defective part (65, 70) per TESTING AND FAULT ISOLATION, Paragraph 2.C. |
| TESTING AND FAULT ISOLATION, Paragraph 1.C.(3)(j)2) | Defective switch S7. | Replace defective switch per TESTING AND FAULT ISOLATION, Paragraph 2.B. |
| TESTING AND FAULT ISOLATION, Paragraph 1.C.(3)(j)3) | Defective switch S1. | Replace defective switch per TESTING AND FAULT ISOLATION, Paragraph 2.B. |
| TESTING AND FAULT ISOLATION, Paragraph 1.C.(3)(k)2) | Defective switch S12. | Replace defective switch per TESTING AND FAULT ISOLATION, Paragraph 2.B. |
| TESTING AND FAULT ISOLATION, Paragraph 1.C.(3)(k)3) | Defective switch S6. | Replace defective switch per TESTING AND FAULT ISOLATION, Paragraph 2.B. |
| TESTING AND FAULT ISOLATION, Paragraph 1.C.(3)(l)2) | Defective relay K3 or K4, or socket. | Replace defective part (65, 70) per TESTING AND FAULT ISOLATION, Paragraph 2.C. |
| TESTING AND FAULT ISOLATION, Paragraph 1.C.(3)(l)3) | Defective relay K3 or socket. | Replace defective part (65, 70) per TESTING AND FAULT ISOLATION, Paragraph 2.C. |
| TESTING AND FAULT ISOLATION, Paragraph 1.C.(3)(l)4) | Defective relay K4 or socket. | Replace defective part (65, 70) per TESTING AND FAULT ISOLATION, Paragraph 2.C. |

27-41-91

TESTING AND FAULT ISOLATION

Page 105

Jul 01/2006

**COMPONENT MAINTENANCE MANUAL****Table 101:** Trouble Shooting Chart (Continued)

| TROUBLE | PROBABLE CAUSE | CORRECTION |
|--|-----------------------|-------------------|
| NOTE: Trouble shooting is keyed to the test step. | | |


27-41-91

TESTING AND FAULT ISOLATION

Page 106

Jul 01/2006

COMPONENT MAINTENANCE MANUAL



C27006-47 Test Equipment
Figure 101


27-41-91

TESTING AND FAULT ISOLATION

Page 107

Jul 01/2006


COMPONENT MAINTENANCE MANUAL



- 1 BOLT -- MS90726-5
- 1 WASHER -- NAS1149F0463P
- (OPTIONAL: AN960-416)

C27006-24 Test Fixture
Figure 102

COMPONENT MAINTENANCE MANUAL



C27006-43 Test Box
Figure 103

27-41-91

TESTING AND FAULT ISOLATION

Page 109

Jul 01/2006



COMPONENT MAINTENANCE MANUAL

2. Corrective Procedures

- A. Replace gear (240), shaft assembly (245) or cam (270C).
 - (1) Completely disassemble unit per DISASSEMBLY and replace defective parts.
 - (2) Assemble parts per ASSEMBLY and retest unit per TESTING AND FAULT ISOLATION, Paragraph 1.C..
- B. Replace defective switches (100).
 - (1) Remove bolts (5, 20), washers (10, 25) and covers (15, 30).
 - (2) Remove screws (75A), covers (80) and springs (85).
 - (3) Remove pins (90) and expose switches and wire bundle assembly (120A).
 - (4) Replace defective switch(es).
 - (5) Position switches in housing assembly (280) and install pins (90).
 - (6) Install springs (85), covers (80) and screws (75A).
 - (7) Install covers (15, 30), washers (10, 25) and bolts (5, 20).
 - (8) Retest unit per TESTING AND FAULT ISOLATION, Paragraph 1.C..
- C. Replace relays (65) or sockets (70).
 - (1) Remove bolts (5), washers (10) and cover (15).
 - (2) Remove bolts (50), washers (55) and carefully pull the relay mount (60) out of housing assembly (280).
 - (3) Replace defective part(s).
 - (4) Install relay mount (60) in housing assembly (280) and secure with bolts (50), washers (55).
 - (5) Install cover (15) and secure with bolts (5), washers (10).
 - (6) Retest unit per TESTING AND FAULT ISOLATION, Paragraph 1.C..

27-41-91

TESTING AND FAULT ISOLATION

Page 110

Jul 01/2006



COMPONENT MAINTENANCE MANUAL

DISASSEMBLY

1. General

- A. See TESTING AND FAULT ISOLATION to establish the condition of the component or most probable cause of its malfunction. This is to determine the extent of disassembly required without completely tearing down and rebuilding the component.

2. Parts Replacement

NOTE: The following parts are recommended for replacement. Unless otherwise specified, actual replacement of parts may be based on in-service experience.

- A. Nuts (35, 105, 145, 200 or 200A)

3. Disassembly (IPL Figure 1)

- A. Remove bolts (5, 20), washers (10, 25) and covers (15, 30).
- B. Remove nuts (35), washers (40), bolts (45).
- C. Remove bolts (50), washers (55) and relay mount (60).
- D. Remove screws (75A), covers (80) and springs (85).
- E. Tap out pins (90) and rest switches (100) on the bottom of housing assembly (280).
- F. Remove nuts (310), washers (315) and bolts (115). Remove wire bundle assembly (120A) with attached relays (65) and switches (100) from housing assembly (280).
- G. Separate relays (65), mount (60) and sockets (70). Do not detach wires from relay sockets (70), switches (100) or connectors (125, 130) unless replacement of parts is required.
- H. Remove nut (162), washers (163), bolt (164) and lever assembly (165) from gear (240).
NOTE: Do not disassemble lever assembly unless necessary for repair or replacement.
- I. Remove nuts (200 or 200A), washers (205 or 205A), screws (210 or 210A) and remove cover assembly (195). Remove bearings (230, 235).
- J. Remove gear (240), shaft assembly (245) with attached cam (270C) and bearings (275) from housing assembly (280).

NOTE: Do not separate cam (270C) from shaft assembly (245), disassemble housing assembly (280) or remove markers (135, 140) unless necessary for repair or replacement.

27-41-91

DISASSEMBLY

Page 301

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

CLEANING

1. General

- A. This procedure has the data necessary to clean the stabilizer trim column switch assembly.
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.

2. Cleaning

A. References

| Reference | Title |
|---------------|-----------------------------|
| SOPM 20-30-03 | GENERAL CLEANING PROCEDURES |

B. Procedure

- (1) Clean all parts except teflon sealed bearings using standard industry practices and information contained in SOPM 20-30-03.
- (2) Clean teflon sealed bearings according to manufacturer's instructions.

27-41-91

CLEANING

Page 401

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

CHECK

1. General

- A. This procedure has the data necessary to find defects in the material of the specified parts.
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.

2. Check

A. References

| Reference | Title |
|---------------|---------------------------------|
| SOPM 20-20-01 | MAGNETIC PARTICLE INSPECTION |
| SOPM 20-20-02 | PENETRANT METHODS OF INSPECTION |

B. Procedure

- (1) Check all parts for obvious defects in accordance with standard industry practices.
- (2) Check wire bundle assembly (120A) for continuity (CHECK, Figure 501).
- (3) Magnetic particle check per SOPM 20-20-01 – Pin (90A), fitting (180), arm (185), gear (240), shaft (260).
- (4) Penetrant check per SOPM 20-20-02 – Pin (90), cover (225), cam (270C), housing (305).


27-41-91

CHECK

Page 501

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



Wire Bundle Details
Figure 501

27-41-91

CHECK
Page 502
Mar 01/2006



COMPONENT MAINTENANCE MANUAL

REPAIR

1. General

- A. Instructions for repair, refinish, and replacement of the specified subassembly parts are included in each REPAIR when applicable:

Table 601:

| P/N | NAME | REPAIR |
|------------|----------------------|---------------|
| 65C25539 | COVER | 1-1 |
| 65C25540 | HOUSING | 2-1 |
| 65C25551 | MOUNT, RELAY | 3-1 |
| 65C31205 | | |
| 69-73309 | LEVER | 4-1 |
| 69-73314 | PIN | 5-1 |
| 69-73400 | SHAFT, PINION | 6-1 |
| - - - | MISC. PARTS REFINISH | 7-1 |

2. Standard Practices

- A. Refer to the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in these procedures.
- SOPM 20-30-02 Stripping of Protective Finishes
 - SOPM 20-30-03 General Cleaning Procedures
 - SOPM 20-41-01 Decoding Table for Boeing Finish Codes
 - SOPM 20-41-02 Application of Chemical and Solvent Resistant Finishes
 - SOPM 20-43-01 Chromic Acid Andozing
 - SOPM 20-42-03 Hard Chrome Plating
 - SOPM 20-60-02 Finishing Materials

3. Materials

NOTE: Equivalent substitutes may be used.

- A. Primer – primer, C00259 BMS 10-11, Ttype 1
 B. Enamel – coating, C00260 BMS 10-11, Type 2

4. Dimensioning Symbols

- A. Standard True Position Dimensioning Symbols used in the applicable repair procedures are shown in REPAIR-GENERAL, Figure 601.

27-41-91

REPAIR - GENERAL

Page 601

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

| | | | |
|-------------------|----------------------------------|-------------------|---|
| — | STRAIGHTNESS | \oplus | THEORETICAL EXACT POSITION OF A FEATURE (TRUE POSITION) |
| \square | FLATNESS | \varnothing | DIAMETER |
| \perp | PERPENDICULARITY (OR SQUARENESS) | $s \varnothing$ | SPHERICAL DIAMETER |
| // | PARALLELISM | R | RADIUS |
| \bigcirc | ROUNDNESS | SR | SPHERICAL RADIUS |
| \bigcirc | CYLINDRICITY | () | REFERENCE |
| \frown | PROFILE OF A LINE | BASIC (BSC) OR | A THEORETICALLY EXACT DIMENSION USED TO DESCRIBE SIZE, SHAPE OR LOCATION OF A FEATURE FROM WHICH PERMISSIBLE VARIATIONS ARE ESTABLISHED BY TOLERANCES ON OTHER DIMENSIONS OR NOTES. |
| \triangle | PROFILE OF A SURFACE | DIM | |
| \odot | CONCENTRICITY | -A- | DATUM |
| \equiv | SYMMETRY | \textcircled{M} | MAXIMUM MATERIAL CONDITION (MMC) |
| \sphericalangle | ANGULARITY | \textcircled{L} | LEAST MATERIAL CONDITION (LMC) |
| \nearrow | RUNOUT | \textcircled{S} | REGARDLESS OF FEATURE SIZE (RFS) |
| \nearrow | TOTAL RUNOUT | \textcircled{P} | PROJECTED TOLERANCE ZONE |
| \sqcup | COUNTERBORE OR SPOTFACE | FIM | FULL INDICATOR MOVEMENT |
| \sphericalangle | COUNTERSINK | TIR | TOTAL INDICATOR READING |

EXAMPLES

| | | | |
|---|--|--|---|
| $\boxed{-0.002}$ | STRAIGHT WITHIN 0.002 | $\boxed{\textcircled{\varnothing}0.0005 C}$ | CONCENTRIC TO C WITHIN 0.0005 DIAMETER |
| $\boxed{\perp 0.002 B}$ | PERPENDICULAR TO B WITHIN 0.002 | $\boxed{\equiv 0.010 A}$ | SYMMETRICAL WITH A WITHIN 0.010 |
| $\boxed{\parallel 0.002 A}$ | PARALLEL TO A WITHIN 0.002 | $\boxed{\sphericalangle 0.005 A}$ | ANGULAR TOLERANCE 0.005 WITH A |
| $\boxed{\bigcirc 0.002}$ | ROUND WITHIN 0.002 | $\boxed{\oplus \varnothing 0.002 \textcircled{S} B}$ | LOCATED AT TRUE POSITION WITHIN 0.002 DIA RELATIVE TO DATUM B, REGARDLESS OF FEATURE SIZE |
| $\boxed{\bigcirc 0.010}$ | CYLINDRICAL SURFACE MUST LIE BETWEEN TWO CONCENTRIC CYLINDERS, ONE OF WHICH HAS A RADIUS 0.010 INCH GREATER THAN THE OTHER | $\boxed{\perp \varnothing 0.010 \textcircled{M} A}$ $\boxed{0.510 \textcircled{P}}$ | AXIS IS TOTALLY WITHIN A CYLINDER OF 0.010-INCH DIAMETER, PERPENDICULAR TO, AND EXTENDING 0.510-INCH ABOVE, DATUM A, MAXIMUM MATERIAL CONDITION |
| $\boxed{\frown 0.006 A}$ | EACH LINE ELEMENT OF THE SURFACE AT ANY CROSS SECTION MUST LIE BETWEEN TWO PROFILE BOUNDARIES 0.006 INCH APART RELATIVE TO DATUM PLANE A | $\boxed{2.000}$ | THEORETICALLY EXACT DIMENSION IS 2.000 |
| $\boxed{\triangle 0.020 A}$ | SURFACES MUST LIE WITHIN PARALLEL BOUNDARIES 0.02 INCH APART AND EQUALLY DISPOSED ABOUT TRUE PROFILE | OR 2.000 BSC | |
| NOTE: DATUM MAY APPEAR AT EITHER SIDE OF TOLERANCE FRAME | | $\boxed{0.020 A}$ $\boxed{A 0.020}$ | |

True Position Dimensioning Symbols
Figure 601

27-41-91

REPAIR - GENERAL

Page 602

Mar 01/2006

COMPONENT MAINTENANCE MANUAL

COVER - REPAIR 1-1


65C25539-3, -4, -6

1. General

- A. This procedure has the data necessary to refinish the cover (IPL Figure 1, 225).
- B. Refer to REPAIR-GENERAL, Paragraph 2. for the Standard Overhaul Practices Manual (SOPM) subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Paragraph 3. for the description of the consumable codes identified in this procedure.
- D. Refer to IPL Figure 1 for item numbers.

2. Plating Repair

- A. For the repair of surfaces which is only the replacement of the original finish , refer to REFINISH instructions on REPAIR 1-1, Figure 601.



ALL DIMENSIONS ARE IN INCHES

Cover Refinish
Figure 601 (Sheet 1 of 2)


27-41-91

REPAIR 1-1

Page 601

Nov 01/2006

COMPONENT MAINTENANCE MANUAL



A-A

REFINISH

CHROMIC ACID ANODIZE AND APPLY 1 COAT OF PRIMER (F-18.13) EXCEPT OMIT PRIMER IN AREA INDICATED BY

MATERIAL: AL ALLOY

ALL DIMENSIONS ARE IN INCHES

FOR COVER ASSEMBLIES 65C25539-7,-8,-9 ONLY, ALSO APPLY 1 COAT OF ENAMEL (F-21.03) TO ALL EXTERIOR SURFACES EXCEPT OMIT ENAMEL FROM HOLES

65C25539-3,-4,-6

Cover Refinish
Figure 601 (Sheet 2 of 2)

27-41-91

REPAIR 1-1

Page 602

Jul 01/2007



COMPONENT MAINTENANCE MANUAL

HOUSING - REPAIR 2-1


65C25540-3, -4, -6, -15, -16,

1. General

- A. This procedure has the data necessary to refinish the housing (IPL Figure 1, 305).
- B. Refer to REPAIR-GENERAL, Paragraph 2. for the Standard Overhaul Practices Manual (SOPM) subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Paragraph 3. for the description of the consumable codes identified in this procedure.
- D. Refer to IPL Figure 1 for item numbers.

2. Plating Repair

- A. For the repair of surfaces which is only the replacement of the original finish , refer to REFINISH instructions on REPAIR 2-1, Figure 601.



ALL DIMENSIONS ARE IN INCHES

65C25540-3,-4,-6,-15,-16 Housing Refinish
Figure 601 (Sheet 1 of 2)


27-41-91

REPAIR 2-1


Page 601

Nov 01/2006

COMPONENT MAINTENANCE MANUAL



REFINISH

CHROMIC ACID ANODIZE AND APPLY 1 COAT OF PRIMER (F-18.13) EXCEPT OMIT PRIMER IN AREA INDICATED BY 

FOR HOUSING ASSEMBLIES 65C25540-7,-8,-9,-13,-14 ONLY, ALSO APPLY 1 COAT OF ENAMEL (F-21.03) TO ALL EXTERIOR SURFACES EXCEPT OMIT ENAMEL FROM HOLES AND MOUNTING FAYING SURFACE

MATERIAL: AL ALLOY

ALL DIMENSIONS ARE IN INCHES

65C25540-3,-4,-6,-15,-16 Housing Refinish
Figure 601 (Sheet 2 of 2)

27-41-91

REPAIR 2-1

Page 602

Jul 01/2007



COMPONENT MAINTENANCE MANUAL

RELAY MOUNT - REPAIR 3-1


65C25551-1, 65C31205-1, -3, -5

1. General

- A. This procedure has the data necessary to refinish the relay mount (IPL Figure 1, 60).
- B. Refer to REPAIR-GENERAL, Paragraph 2. for the Standard Overhaul Practices Manual (SOPM) subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Paragraph 3. for the description of the consumable codes identified in this procedure.
- D. Refer to IPL Figure 1 for item numbers.

2. Plating Repair

- A. For the repair of surfaces which is only the replacement of the original finish , refer to REFINISH instructions on REPAIR 3-1, Figure 601.



65C25551-1 SHOWN
65C31205-1,-3,-5 SIMILAR

REFINISH

FOR 65C25551-1, CHROMIC ACID ANODIZE AND APPLY 1 COAT OF PRIMER (F-18.13) ALL OVER

FOR 65C31205-1,-3,-5 CHROMIC ACID OR SULFURIC ACID ANODIZE (F-17.05) ALL OVER. APPLY 1 COAT BMS 10-11, TYPE 1 PRIMER (F-20.02) ALL OVER

MATERIAL: AL ALLOY



AFTER REFINISH, SILK SCREEN REFERENCE DESIGNATIONS COLOR BLACK 0.08 IN. HIGH CHARACTERS AS SHOWN PER 20-50-10

65C25551-1 65C31205-1,-3,-5 Relay Mount Refinish
Figure 601

27-41-91

REPAIR 3-1

Page 601

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

LEVER ASSY - REPAIR 4-1


69-73309-1

1. General

- A. This procedure has the data necessary to repair the lever assembly (IPL Figure 1, 165).
- B. Refer to REPAIR-GENERAL, Paragraph 2. for the Standard Overhaul Practices Manual (SOPM) subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.

2. Parts Replacement (REPAIR 4-1, Figure 601)

- A. Position arm (185) on fitting (180) as shown in REPAIR 4-1, Figure 601 and install rivets (170, 175) as indicated.



ITEM NUMBERS REFER TO IPL FIG. 1
ALL DIMENSIONS ARE IN INCHES

Parts Replacement
Figure 601

27-41-91

REPAIR 4-1

Page 601

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

PIN - REPAIR 5-1


69-73314-1, -2

1. General

- A. This procedure has the data necessary to refinish the pin (IPL Figure 1, 90).
- B. Refer to REPAIR-GENERAL, Paragraph 2. for the Standard Overhaul Practices Manual (SOPM) subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.

2. Plating Repair

- A. For the repair of surfaces which is only the replacement of the original finish , refer to REFINISH instructions on REPAIR 5-1, Figure 601.



69-73314-1 SHOWN 3

REFINISH

PASSIVATE (F-17.09) EXCEPT CHROME PLATE AS NOTED BY 1

- 1 CHROME PLATE (F-15.03) 0.001-0.002 THICK
- 2 CHROME PLATE RUN OUT
- 3 NO REFINISH REQUIRED ON 69-73314-2

MATERIAL: 15-5PH CRES, 180-200 KSI
ALL DIMENSIONS ARE IN INCHES

Pin Refinish
Figure 601

27-41-91

REPAIR 5-1
Page 601
Nov 01/2006



COMPONENT MAINTENANCE MANUAL

PINION SHAFT - REPAIR 6-1

69-73400-1

1. General

- A. This procedure has the data necessary to repair the pinion shaft assembly (IPL Figure 1, 245).
- B. Refer to REPAIR-GENERAL, Paragraph 2. for the Standard Overhaul Practices Manual (SOPM) subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.

2. Pinion Replacement

- A. Remove rivet (250) and pinion (255).
- B. Remove and discard set screw supplied with new pinion and install pinion on shaft (260).
- C. Secure pinion to shaft with rivet (250).

27-41-91

REPAIR 6-1

Page 601

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

MISCELLANEOUS PARTS REFINISH - REPAIR 7-1

1. General

- A. This procedure has the data necessary to refinish the parts listed in REPAIR 7-1, Table 601.
- B. Refer to REPAIR-GENERAL, Paragraph 2. for the Standard Overhaul Practices Manual (SOPM) subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Paragraph 3. for the description of the consumable codes identified in this procedure.
- D. Refer to IPL Figure 1 for item numbers.

2. Procedure

- A. Repair of parts listed in REPAIR 7-1, Table 601 consists of restoration of the original finish.

Table 601: Refinish Details

| IPL FIG. & ITEM | MATERIAL | FINISH |
|--------------------------|--------------------------|--|
| Fig. 1 | | |
| Covers (15, 30, 80, 95) | Al alloy | Chemical treat (colored film) and apply primer, C00259 (F-18.06). |
| Covers (15A,80A) | Al alloy | Chemical treat (colored film) and apply primer, C00259 (F-18.06). Apply enamel coating, C00260 (F-21.03) to all exterior surfaces with overspray in holes permitted. |
| Fitting (180), arm (185) | 15-5PH CRES, 150-170 ksi | Passivate (F-17.09). |
| Gear (240) | 15-5PH CRES, 180-200 ksi | Passivate (F-17.09). |
| Shaft (260) | 15-5PH CRES, 180-200 ksi | Passivate (F-17.09) except cadmium plate and apply primer, C00259 (F-16.01) on 0.374-0.375 in. O.D. |
| Cam (270C) | Al alloy | Chromic acid anodize and apply primer, C00259 (F-18.13) all over except omit primer on 0.195-0.196 in. and 0.377-0.378 in. dia. holes |

27-41-91

REPAIR 7-1

Page 601

Jul 01/2006



COMPONENT MAINTENANCE MANUAL

ASSEMBLY

1. General

- A. This procedure has the data necessary to assemble the stabilizer trim control column cutout switch assembly.
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.

2. Assembly

A. References

| Reference | Title |
|---------------|--|
| SOPM 20-11-03 | REPAIR OF ELECTRICAL TERMINATIONS AND ELECTRICAL BONDING AREAS |
| SOPM 20-50-05 | APPLICATION OF ALUMINUM FOIL AND OTHER MARKERS |
| SOPM 20-50-10 | APPLICATION OF STENCILS, INSIGNIA, SILK SCREEN, PART NUMBERING AND IDENTIFICATION MARKINGS |

B. Procedure (IPL Figure 1)

- (1) Install bearings (275) in housing assembly (280).
- (2) Assemble cam (270C) and shaft assembly (245). (If cam is already riveted to shaft assembly, refer to step C.)
 - (a) Install cam (270C) on shaft assembly (245) and install shaft assembly in housing assembly (280).
 - (b) Insert 0.1890-0.1895 in. dia. rigging pin thru cam (270C) and housing assembly (280) to secure cam in place.
 - (c) Install lever assembly (165) on gear (240).
 - (d) Install gear (240) on housing assembly (280) with lever assembly (165) located per ASSEMBLY, Figure 701 and gear (240) meshes with pinion (255).
 - (e) Mark position of cam (270C) on shaft assembly (245). Remove rigging pin, gear (240), lever assembly (165), cam (270C) and shaft assembly (245) from housing assembly (280).
 - (f) With cam (270C) installed on shaft assembly (245) as marked, drill 0.159-0.161 in. dia. holes thru for rivets (265) at hole locations on cam (270). Break sharp edges 0.008R and apply chemical coating (F-17.10) to the hole.
 - (g) Secure cam (270C) to shaft assembly (245) with rivets (265).
- (3) Install bearings (230, 235) in cover assembly (195).
- (4) Install gear (240) in cover assembly (195), then install lever assembly (165) on gear (240).
- (5) Insert 0.1890-0.1895 in. dia. rigging pin thru cover assembly (195).
- (6) Rotate lever assembly (165) to position indicated in ASSEMBLY, Figure 701 and hold in place.
- (7) Install shaft assembly (245) with attached cam (270C) in cover assembly (195) with rigging pin inserted through rigging pin hole in cam. Ensure pinion (255) meshes with gear (240).

27-41-91

ASSEMBLY

Page 701

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

- (8) Install cover assembly (195) on housing assembly (280) and secure with screws (210 or 210A), washers (205 or 205A) and nut (200 or 200A). Remove rigging pin.
NOTE: The directional orientation of the screws (210A) is important in preventing in-service problems. See 737 Service Letter SL-27-80.
- (9) Secure lever assembly (165) to gear (240) with bolt (164), washer (163) and nut (162).
- (10) Assemble wire bundle assembly (120A), switches (100) and relay sockets (70) as required per wire bundle schematic (ASSEMBLY, Figure 702). Assemble relays (65), sockets (70) and mount (60).
- (11) Install markers (135, 140) if required on housing assembly (280) per SOPM 20-50-05 at location shown (ASSEMBLY, Figure 703).
- (12) Position switches (100) and covers (95) in housing assembly (280) and install pins (90) thru cover assembly (195), switches (100), covers (95) and housing assembly (280) to secure switches in place.
- (13) Install springs (85) and covers (80) and secure covers with screws (75A).
NOTE: Install covers (80A) with enamel painted surface facing away from mechanism assembly.
- (14) Install relay mount (60) with attached relays (65) and sockets (70) in housing assembly (280) and secure with bolts (50), washers (55).
- (15) Install screws (50) on housing assembly (280). Install washers (40) and ground terminals (132) of wire bundle assembly (120) on screws and secure with nut (35). Ground per SOPM 20-11-03. Resistance shall be 0.001 ohm.
- (16) Install connectors (125, 130) on housing assembly (280) and secure with bolts (155), washers (315) and nuts (310).
- (17) Rubber stamp (optional: silk screen) information indicated on housing assembly (280) per SOPM 20-50-10.
- (18) Install covers (15, 30) and secure with bolts (5, 20) and washers (10, 25).
- (19) Install marker (320) if required on cover (15) per SOPM 20-50-05 and align arrow with rig pin hole.
- (20) Test unit per TESTING AND FAULT ISOLATION.

27-41-91


ASSEMBLY

Page 702


Mar 01/2006



COMPONENT MAINTENANCE MANUAL



COVER ASSY (195) OMITTED FOR CLARITY



1 WITH 0.1895
 WITH 0.1890 DIA RIG PIN THRU COVER ASSY
 (195), CAM (270C), HOUSING ASSY (280) AND
 LEVER ASSY (165) AT POSITION SHOWN,
 LOCATE AND DRILL RIVET HOLES THRU CAM
 (270C) AND SHAFT ASSY (245) USING HOLE
 LOCATIONS ON CAM

ALL DIMENSIONS ARE IN INCHES

Assembly of Cam and Shaft Assembly
 Figure 701


27-41-91

ASSEMBLY

Page 703

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



Wire Bundle Details
Figure 702



27-41-91

ASSEMBLY


Page 704

Mar 01/2006


COMPONENT MAINTENANCE MANUAL




A-A



B-B



C-C





D-D

Assembly Details
Figure 703 (Sheet 1 of 2)

27-41-91

ASSEMBLY
Page 705
Mar 01/2006

COMPONENT MAINTENANCE MANUAL



RUBBER STAMP OR SILKSCREEN INFORMATION SHOWN PER 20-50-10

Assembly Details
Figure 703 (Sheet 2 of 2)

27-41-91

ASSEMBLY
Page 706
Mar 01/2006



COMPONENT MAINTENANCE MANUAL

3. Storage

- A. Use standard industry practices to store this component.

27-41-91

ASSEMBLY

Page 707

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

FITS AND CLEARANCES

(NOT APPLICABLE)

27-41-91

FITS AND CLEARANCES

Page 801

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

SPECIAL TOOLS, FIXTURES, AND EQUIPMENT

1. General

A. This section lists the special tools, fixtures, and equipment necessary for maintenance.

NOTE: Equivalent substitutes may be used.

Special Tools

| Reference | Description | Part Number | Supplier |
|-----------|---|----------------|----------|
| SPL-5372 | Test Equipment - Stabilizer Trim Control Cutout Switch | C27006-48 | 81205 |
| SPL-5374 | Test Equipment - Stabilizer Trim Control Cutout Switch | C27006-42 | 81205 |
| SPL-6044 | Test Fixture Assembly (C27006-24 included in C27006-47 & C27006-48) | C27006-48 | 81205 |
| | | Opt: C27006-47 | 81205 |
| SPL-6045 | Test Fixture Assembly (C27006-13 included in C27006-42) | C27006-42 | 81205 |
| SPL-6046 | Test Box Assembly (C27006-43 included in C27006-42) | C27006-42 | 81205 |

Tool Supplier Information

| CAGE Code | Supplier Name | Supplier Address |
|-----------|--------------------|---|
| 81205 | THE BOEING COMPANY | 17930 INTERNATIONAL BLVD. SOUTH SEATAC, WA 98188-4321 Telephone: 206-662-6650 Facsimile: 206-662-7145 |

27-41-91

SPECIAL TOOLS, FIXTURES, AND EQUIPMENT

Page 901

Mar 01/2009



COMPONENT MAINTENANCE MANUAL

ILLUSTRATED PARTS LIST

1. Introduction

- A. The Illustrated Parts List (IPL) contains an illustration and a list of component parts you can repair or replace. The Illustrated Parts Catalog (IPC) shows how to use the Boeing part number system.
- B. This shows how parts are related: The relation of each item to its next higher assembly (NHA) is shown in the NOMENCLATURE column. Use the indenture system that follows:

| 1 | 2 | 3 | 4 | 5 | 6 | 7 |
|---|------------------------------|---------------------------------|---------------------------------|-----------------------------------|---|---|
| . | Assembly | | | | | |
| . | Attaching parts for assembly | | | | | |
| . | . | Detail parts for assembly | | | | |
| . | . | Subassembly | | | | |
| . | . | Attaching parts for subassembly | | | | |
| . | . | . | Detail parts for subassembly | | | |
| . | . | . | Sub-subassembly | | | |
| . | . | . | Attaching parts for subassembly | | | |
| . | . | . | . | Details parts for sub-subassembly | | |
| | | | | | | Detail Installation Parts (Included only if installation parts may be sent to the shop as part of assembly) |

- C. Each top assembly is given one use code letter (A, B, C, etc.) in the USAGE CODE column. All subsequent component parts in the list can have one or more of the use code letters to show effectivity to top assemblies. A component part without a use code applies to all top assemblies.
- D. An alphabetical letter is added after the item number for optional parts, parts changed by a Service Bulletin, configuration differences (except left-handed and right-handed parts), last engineering releases, and parts added between item numbers in a sequence. The alphabetical letter will not be shown on the illustration for equivalent parts of the same part number.
- E. Color-coded parts are identified with a single digit alpha following the dash number or with "SP" suffix. If the "SP" suffix is used, it represents consolidation of all color codes applicable for a given usage which are not separately listed. Orders for color-coded parts should include the registry number of the airplane for which the parts are ordered.
- F. If a part number is 15 characters long but will not fit in the part number column, the part number will be displayed with a "~" at the end of the line and will be continued on the next line. The "~" denotes that the part number continues on the next line.
- G. Parts changed by a Service Bulletin are shown by PRE SB XXXX and POST SB XXXX added to the NOMENCLATURE column.
- (1) When a new top assembly is added by a Service Bulletin, PRE SB XXXX and POST SB XXXX will be added at the top assembly level only. The configuration differences at the detail part level are shown by use code letters.
- (2) When the top assembly part number is not changed by the Service Bulletin, PRE SB XXXX and POST SB XXXX will be added at the detail level.
- H. Interchangeable Parts

27-41-91

ILLUSTRATED PARTS LIST

Page 1001

Nov 01/2008



COMPONENT MAINTENANCE MANUAL

| | |
|--|--|
| Optional (OPT) | The part is optional to and interchangeable with other parts that have the same item number. |
| Replaces, Replaced by and not interchangeable with (REPLACES, REPLACED BY AND NOT INTCHG/W) | The part replaces and is not interchangeable with the initial part. |
| Replaces, Replaced by (REPLACES, REPLACED BY) | The part replaces and is interchangeable with, or is an alternative to, the initial part. |

VENDOR CODES

| Code | Name |
|-------|---|
| 12336 | Replaced: [V12336] WELLS-BENRUS CORP TECHNICAL PRODUCTS DIV by Code: Name and Address below 04846: WELLS-BENRUS CO BENSON ROAD PO BOX 1004 MIDDLEBURY, CONNECTICUT 06762 FORMERLY WELLS-BENRUS CORP TECHNICAL PRODUCTS DIV V12336 FORMERLY IN RIDGEFIELD, CONNECTICUT |
| 29440 | WINFRED M BERG INC 499 OCEAN AVENUE EAST ROCKAWAY, L.I. NEW YORK 11518-1226 |
| 29964 | ALLIED DEVICES CORP 2365 MILBURN AVENUE PO DRAWER E BALDWIN, NEW YORK 11510-3321 |
| 91929 | HONEYWELL INC MICRO SWITCH DIV 11 WEST SPRING STREET FREEPORT, ILLINOIS 61032 FORMERLY MICRO SWITCH A DIV OF HONEYWELL FORMERLY V74059 AND V40228 |

27-41-91

ILLUSTRATED PARTS LIST

Page 1002

Jul 01/2006



COMPONENT MAINTENANCE MANUAL

NUMERICAL INDEX

| PART NUMBER | AIRLINE PART NUMBER | FIGURE | ITEM | UNITS PER ASSEMBLY |
|-------------|---------------------|--------|------|--------------------|
| 65C25529-10 | | 1 | 120A | 1 |
| 65C25529-11 | | 1 | 1D | RF |
| 65C25529-12 | | 1 | 1E | RF |
| 65C25529-13 | | 1 | 160D | 1 |
| 65C25529-14 | | 1 | 160E | 1 |
| 65C25529-15 | | 1 | 1F | RF |
| 65C25529-16 | | 1 | 1G | RF |
| 65C25529-17 | | 1 | 160F | 1 |
| 65C25529-18 | | 1 | 160G | 1 |
| 65C25529-19 | | 1 | 1H | RF |
| 65C25529-20 | | 1 | 160H | 1 |
| 65C25529-21 | | 1 | 1J | RF |
| 65C25529-22 | | 1 | 1K | RF |
| 65C25529-23 | | 1 | 1L | RF |
| 65C25529-24 | | 1 | 1M | RF |
| 65C25529-25 | | 1 | 1N | RF |
| 65C25529-26 | | 1 | 1P | RF |
| 65C25529-27 | | 1 | 1Q | RF |
| 65C25529-6 | | 1 | 1B | RF |
| 65C25529-7 | | 1 | 1C | RF |
| 65C25529-8 | | 1 | 160B | 1 |
| 65C25529-9 | | 1 | 160C | 1 |
| 65C25539-1 | | 1 | 195 | 1 |
| 65C25539-2 | | 1 | 195B | 1 |
| 65C25539-3 | | 1 | 225 | 1 |
| 65C25539-4 | | 1 | 225B | 1 |
| 65C25539-5 | | 1 | 195A | 1 |
| 65C25539-6 | | 1 | 225A | 1 |
| 65C25539-7 | | 1 | 195C | 1 |
| 65C25539-8 | | 1 | 195E | 1 |
| 65C25539-9 | | 1 | 195D | 1 |
| 65C25540-1 | | 1 | 280 | 1 |
| 65C25540-13 | | 1 | 280F | 1 |
| 65C25540-14 | | 1 | 280G | 1 |

27-41-91

ILLUSTRATED PARTS LIST

Page 1003

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

| PART NUMBER | AIRLINE PART NUMBER | FIGURE | ITEM | UNITS PER ASSEMBLY |
|-------------|---------------------|--------|------|--------------------|
| 65C25540-15 | | 1 | 305C | 1 |
| 65C25540-16 | | 1 | 305D | 1 |
| 65C25540-2 | | 1 | 280B | 1 |
| 65C25540-3 | | 1 | 305 | 1 |
| 65C25540-4 | | 1 | 305B | 1 |
| 65C25540-5 | | 1 | 280A | 1 |
| 65C25540-6 | | 1 | 305A | 1 |
| 65C25540-7 | | 1 | 280C | 1 |
| 65C25540-8 | | 1 | 280E | 1 |
| 65C25540-9 | | 1 | 280D | 1 |
| 65C25548-1 | | 1 | 240 | 1 |
| 65C25548-2 | | 1 | 240A | 1 |
| 65C25550-4 | | 1 | 270C | 1 |
| 65C25550-5 | | 1 | 270E | 1 |
| 65C25550-6 | | 1 | 270D | 1 |
| 65C25551-1 | | 1 | 60 | 1 |
| 65C31205-1 | | 1 | 60A | 1 |
| 65C31205-3 | | 1 | 60B | 1 |
| 65C31205-5 | | 1 | 60C | 1 |
| 66-25992-1 | | 1 | 170 | 1 |
| 66-25992-2 | | 1 | 175 | 1 |
| 69-73307-1 | | 1 | 180 | 1 |
| 69-73308-1 | | 1 | 185 | 1 |
| 69-73309-1 | | 1 | 165 | 1 |
| 69-73313-1 | | 1 | 260 | 1 |
| 69-73314-1 | | 1 | 90 | 4 |
| 69-73314-2 | | 1 | 90A | 4 |
| 69-73316-1 | | 1 | 30 | 2 |
| 69-73316-2 | | 1 | 95 | 2 |
| 69-73316-3 | | 1 | 80 | 2 |
| 69-73316-4 | | 1 | 80A | 2 |
| 69-73319-1 | | 1 | 15 | 1 |
| 69-73319-2 | | 1 | 15A | 1 |
| 69-73400-1 | | 1 | 245 | 1 |
| AN960D10L | | 1 | 40 | 4 |

27-41-91

ILLUSTRATED PARTS LIST

Page 1004

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

| PART NUMBER | AIRLINE PART NUMBER | FIGURE | ITEM | UNITS PER ASSEMBLY |
|----------------|---------------------|--------|------|--------------------|
| AN960KD8 | | 1 | 163 | 1 |
| AN960PD10 | | 1 | 205 | 6 |
| | | 1 | 205A | 6 |
| AN960PD4 | | 1 | 10 | 6 |
| | | 1 | 25 | 8 |
| | | 1 | 315 | 8 |
| AN960PD6 | | 1 | 55 | 4 |
| AP48KS36 | | 1 | 255 | 1 |
| BAC27DCT0351 | | 1 | 135 | 1 |
| BAC27DCT0352 | | 1 | 140 | 1 |
| BAC27DCT0355 | | 1 | 330 | 1 |
| BAC27DCT0391 | | 1 | 190A | 1 |
| BACB10AP3 | | 1 | 235 | 1 |
| | | 1 | 275 | 2 |
| BACB10AP6 | | 1 | 230 | 1 |
| BACB30LK04-1 | | 1 | 5 | 6 |
| BACB30LK04-10 | | 1 | 50A | 4 |
| BACB30LK04-2 | | 1 | 20 | 8 |
| | | 1 | 115 | 8 |
| BACB30LK06-10 | | 1 | 50 | 4 |
| BACB30LK2-14 | | 1 | 164 | 1 |
| BACC45FN12-12P | | 1 | 130 | 1 |
| BACC45FN16-24P | | 1 | 125 | 1 |
| BACN10JN04CM | | 1 | 300A | 8 |
| BACN10JP04CCD | | 1 | 300 | 8 |
| BACN10NW1 | | 1 | 310A | 8 |
| BACR13CF2AB | | 1 | 65 | 4 |
| BACR15BA3D | | 1 | 295 | 16 |
| BACS16X1A | | 1 | 70 | 4 |
| BACT12AC | | 1 | 132 | 2 |
| DP701T36 | | 1 | 255A | 1 |
| MS20615-3M10 | | 1 | 250A | 1 |
| MS20615-5MP12 | | 1 | 265 | 2 |
| MS21042L04 | | 1 | 310 | 8 |
| MS21042L08 | | 1 | 162 | 1 |

27-41-91

ILLUSTRATED PARTS LIST

Page 1005

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

| PART NUMBER | AIRLINE PART NUMBER | FIGURE | ITEM | UNITS PER ASSEMBLY |
|---------------|---------------------|--------|------|--------------------|
| MS21042L3 | | 1 | 35 | 2 |
| | | 1 | 200 | 6 |
| | | 1 | 200A | 6 |
| MS21209C0410 | | 1 | 290A | 4 |
| MS21209C0415 | | 1 | 215 | 4 |
| | | 1 | 285 | 8 |
| MS21209C0610 | | 1 | 290 | 4 |
| MS24585-1005 | | 1 | 85 | 4 |
| NAS514P1032-7 | | 1 | 45 | 2 |
| NAS514P440-5 | | 1 | 75A | 6 |
| NAS607-2-3P | | 1 | 220 | 3 |
| NAS623-3-4 | | 1 | 210 | 6 |
| | | 1 | 210A | 6 |
| P70-1-36 | | 1 | 255B | 1 |
| V3L2228 | | 1 | 100 | 12 |


27-41-91

ILLUSTRATED PARTS LIST

Page 1006

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



Stab Trim Control Column Actuated Switch Cutout Switch Assembly
IPL Figure 1 (Sheet 1 of 2)


27-41-91

ILLUSTRATED PARTS LIST

Page 1007

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



A

Stab Trim Control Column Actuated Switch Cutout Switch Assembly
IPL Figure 1 (Sheet 2 of 2)

27-41-91

ILLUSTRATED PARTS LIST

Page 1008

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

| FIG/ ITEM | PART NUMBER | AIRLINE PART NUMBER | NOMENCLATURE | | | | | | | USAGE CODE | UNITS PER ASSY |
|--------------|-------------|---------------------------|--------------|---|---|---|---|---|---|---------------|----------------------|
| | | | 1 | 2 | 3 | 4 | 5 | 6 | 7 | | |
| 1- | | | | | | | | | | | |
| -1 | 65C25529-1 | | | | | | | | | | |
| -1A | 65C25529-2 | | | | | | | | | | |
| -1B | 65C25529-6 | | | | | | | | A | RF | |
| | | | | | | | | | | | |
| -1C | 65C25529-7 | | | | | | | | B | RF | |

-Item not Illustrated

27-41-91

ILLUSTRATED PARTS LIST

Page 1009

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

| FIG/ ITEM | PART NUMBER | AIRLINE PART NUMBER | NOMENCLATURE | | | | | | | USAGE CODE | UNITS PER ASSY |
|--------------|-------------|---------------------------|--|---|---|---|---|---|---|---------------|----------------------|
| | | | 1 | 2 | 3 | 4 | 5 | 6 | 7 | | |
| 1- -1D | 65C25529-11 | | SWITCH ASSY-STAB TRIM CONT COLUMN ACTUATED SWITCH CUTOUT (SWITCH ASSYS ITEM 1K, 1L, 1M, 1N, 1P, 1Q MAY BE CREATE FROM SWITCH ASSYS ITEM 1B, 1C, 1D, 1E, 1F, 1G RESPECTIVELY. THE -22 ASSEMBLY IS CREATED FROM THE - 6 ASSEMBLY BY INSTALLING THE SIX NAS623-3-4 SCREWS ITEM 210 SUCH THAT THE HEADS ARE ORIENTED AS SHOWN BY SCREWS ITEM 210A IN IPL FIG. 1, SHEET 2. THE -23 MAY BE CREATED FROM THE -7 IN THE SAME MANNER AND THE OTHERS SIMILARLY. SEE 737 SERVICE LETTER SL-27-80 FOR MORE INFORMATION. ALL CREATED ASSEMBLIES MUST ALSO BE REPART-MARKED, ACCORDINGLY.) | | | | | | | C | RF |
| -1E | 65C25529-12 | | SWITCH ASSY-STAB TRIM CONT COLUMN ACTUATED SWITCH CUTOUT (SWITCH ASSYS ITEM 1K, 1L, 1M, 1N, 1P, 1Q MAY BE CREATE FROM SWITCH ASSYS ITEM 1B, 1C, 1D, 1E, 1F, 1G RESPECTIVELY. THE -22 ASSEMBLY IS CREATED FROM THE - 6 ASSEMBLY BY INSTALLING THE SIX NAS623-3-4 SCREWS ITEM 210 SUCH THAT THE HEADS ARE ORIENTED AS SHOWN BY SCREWS ITEM 210A IN IPL FIG. 1, SHEET 2. THE -23 MAY BE CREATED FROM THE -7 IN THE SAME MANNER AND THE OTHERS SIMILARLY. SEE 737 SERVICE LETTER SL-27-80 FOR MORE INFORMATION. ALL CREATED ASSEMBLIES MUST ALSO BE REPART-MARKED, ACCORDINGLY.) | | | | | | | D | RF |

-Item not Illustrated

27-41-91

ILLUSTRATED PARTS LIST

Page 1010

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

| FIG/ ITEM | PART NUMBER | AIRLINE PART NUMBER | NOMENCLATURE | USAGE CODE | UNITS PER ASSY |
|--------------|-------------|---------------------------|--|---------------|----------------------|
| | | | | | |
| 1- -1F | 65C25529-15 | | SWITCH ASSY-STAB TRIM CONT COLUMN ACTUATED SWITCH CUTOUT (SWITCH ASSYS ITEM 1K, 1L, 1M, 1N, 1P, 1Q MAY BE CREATE FROM SWITCH ASSYS ITEM 1B, 1C, 1D, 1E, 1F, 1G RESPECTIVELY. THE -22 ASSEMBLY IS CREATED FROM THE - 6 ASSEMBLY BY INSTALLING THE SIX NAS623-3-4 SCREWS ITEM 210 SUCH THAT THE HEADS ARE ORIENTED AS SHOWN BY SCREWS ITEM 210A IN IPL FIG. 1, SHEET 2. THE -23 MAY BE CREATED FROM THE -7 IN THE SAME MANNER AND THE OTHERS SIMILARLY. SEE 737 SERVICE LETTER SL-27-80 FOR MORE INFORMATION. ALL CREATED ASSEMBLIES MUST ALSO BE REPART-MARKED, ACCORDINGLY.) | E | RF |
| -1G | 65C25529-16 | | SWITCH ASSY-STAB TRIM CONT COLUMN ACTUATED SWITCH CUTOUT (SWITCH ASSYS ITEM 1K, 1L, 1M, 1N, 1P, 1Q MAY BE CREATE FROM SWITCH ASSYS ITEM 1B, 1C, 1D, 1E, 1F, 1G RESPECTIVELY. THE -22 ASSEMBLY IS CREATED FROM THE - 6 ASSEMBLY BY INSTALLING THE SIX NAS623-3-4 SCREWS ITEM 210 SUCH THAT THE HEADS ARE ORIENTED AS SHOWN BY SCREWS ITEM 210A IN IPL FIG. 1, SHEET 2. THE -23 MAY BE CREATED FROM THE -7 IN THE SAME MANNER AND THE OTHERS SIMILARLY. SEE 737 SERVICE LETTER SL-27-80 FOR MORE INFORMATION. ALL CREATED ASSEMBLIES MUST ALSO BE REPART-MARKED, ACCORDINGLY.) | F | RF |
| -1H | 65C25529-19 | | SWITCH ASSY-STAB TRIM CONT COLUMN ACTUATED SWITCH CUTOUT | G | RF |
| -1J | 65C25529-21 | | SWITCH ASSY-STAB TRIM CONT COLUMN ACTUATED SWITCH CUTOUT | H | RF |

-Item not Illustrated

27-41-91

ILLUSTRATED PARTS LIST

Page 1011

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

| FIG/ ITEM | PART NUMBER | AIRLINE PART NUMBER | NOMENCLATURE | | | | | | | USAGE CODE | UNITS PER ASSY |
|--------------|-------------|---------------------------|--|---|---|---|---|---|---|---------------|----------------------|
| | | | 1 | 2 | 3 | 4 | 5 | 6 | 7 | | |
| 1- -1K | 65C25529-22 | | SWITCH ASSY-STAB TRIM CONT COLUMN ACTUATED SWITCH CUTOUT (SWITCH ASSYS ITEM 1K, 1L, 1M, 1N, 1P, 1Q MAY BE CREATE FROM SWITCH ASSYS ITEM 1B, 1C, 1D, 1E, 1F, 1G RESPECTIVELY. THE -22 ASSEMBLY IS CREATED FROM THE - 6 ASSEMBLY BY INSTALLING THE SIX NAS623-3-4 SCREWS ITEM 210 SUCH THAT THE HEADS ARE ORIENTED AS SHOWN BY SCREWS ITEM 210A IN IPL FIG. 1, SHEET 2. THE -23 MAY BE CREATED FROM THE -7 IN THE SAME MANNER AND THE OTHERS SIMILARLY. SEE 737 SERVICE LETTER SL-27-80 FOR MORE INFORMATION. ALL CREATED ASSEMBLIES MUST ALSO BE REPART-MARKED, ACCORDINGLY.) | | | | | | | J | RF |
| -1L | 65C25529-23 | | SWITCH ASSY-STAB TRIM CONT COLUMN ACTUATED SWITCH CUTOUT (SWITCH ASSYS ITEM 1K, 1L, 1M, 1N, 1P, 1Q MAY BE CREATE FROM SWITCH ASSYS ITEM 1B, 1C, 1D, 1E, 1F, 1G RESPECTIVELY. THE -22 ASSEMBLY IS CREATED FROM THE - 6 ASSEMBLY BY INSTALLING THE SIX NAS623-3-4 SCREWS ITEM 210 SUCH THAT THE HEADS ARE ORIENTED AS SHOWN BY SCREWS ITEM 210A IN IPL FIG. 1, SHEET 2. THE -23 MAY BE CREATED FROM THE -7 IN THE SAME MANNER AND THE OTHERS SIMILARLY. SEE 737 SERVICE LETTER SL-27-80 FOR MORE INFORMATION. ALL CREATED ASSEMBLIES MUST ALSO BE REPART-MARKED, ACCORDINGLY.) | | | | | | | K | RF |

-Item not Illustrated

27-41-91

ILLUSTRATED PARTS LIST

Page 1012

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

| FIG/ ITEM | PART NUMBER | AIRLINE PART NUMBER | NOMENCLATURE | | | | | | | USAGE CODE | UNITS PER ASSY |
|--------------|-------------|---------------------------|--|---|---|---|---|---|---|---------------|----------------------|
| | | | 1 | 2 | 3 | 4 | 5 | 6 | 7 | | |
| 1- -1M | 65C25529-24 | | SWITCH ASSY-STAB TRIM CONT COLUMN ACTUATED SWITCH CUTOUT (SWITCH ASSYS ITEM 1K, 1L, 1M, 1N, 1P, 1Q MAY BE CREATE FROM SWITCH ASSYS ITEM 1B, 1C, 1D, 1E, 1F, 1G RESPECTIVELY. THE -22 ASSEMBLY IS CREATED FROM THE - 6 ASSEMBLY BY INSTALLING THE SIX NAS623-3-4 SCREWS ITEM 210 SUCH THAT THE HEADS ARE ORIENTED AS SHOWN BY SCREWS ITEM 210A IN IPL FIG. 1, SHEET 2. THE -23 MAY BE CREATED FROM THE -7 IN THE SAME MANNER AND THE OTHERS SIMILARLY. SEE 737 SERVICE LETTER SL-27-80 FOR MORE INFORMATION. ALL CREATED ASSEMBLIES MUST ALSO BE REPART-MARKED, ACCORDINGLY.) | | | | | | | L | RF |
| -1N | 65C25529-25 | | SWITCH ASSY-STAB TRIM CONT COLUMN ACTUATED SWITCH CUTOUT (SWITCH ASSYS ITEM 1K, 1L, 1M, 1N, 1P, 1Q MAY BE CREATE FROM SWITCH ASSYS ITEM 1B, 1C, 1D, 1E, 1F, 1G RESPECTIVELY. THE -22 ASSEMBLY IS CREATED FROM THE - 6 ASSEMBLY BY INSTALLING THE SIX NAS623-3-4 SCREWS ITEM 210 SUCH THAT THE HEADS ARE ORIENTED AS SHOWN BY SCREWS ITEM 210A IN IPL FIG. 1, SHEET 2. THE -23 MAY BE CREATED FROM THE -7 IN THE SAME MANNER AND THE OTHERS SIMILARLY. SEE 737 SERVICE LETTER SL-27-80 FOR MORE INFORMATION. ALL CREATED ASSEMBLIES MUST ALSO BE REPART-MARKED, ACCORDINGLY.) | | | | | | | M | RF |

-Item not Illustrated

27-41-91

ILLUSTRATED PARTS LIST

Page 1013

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

| FIG/ ITEM | PART NUMBER | AIRLINE PART NUMBER | NOMENCLATURE 1 2 3 4 5 6 7 | USAGE CODE | UNITS PER ASSY |
|--------------|--------------|---------------------------|--|----------------|----------------------|
| | | | | | |
| 1- -1P | 65C25529-26 | | SWITCH ASSY-STAB TRIM CONT COLUMN ACTUATED SWITCH CUTOUT (SWITCH ASSYS ITEM 1K, 1L, 1M, 1N, 1P, 1Q MAY BE CREATE FROM SWITCH ASSYS ITEM 1B, 1C, 1D, 1E, 1F, 1G RESPECTIVELY. THE -22 ASSEMBLY IS CREATED FROM THE - 6 ASSEMBLY BY INSTALLING THE SIX NAS623-3-4 SCREWS ITEM 210 SUCH THAT THE HEADS ARE ORIENTED AS SHOWN BY SCREWS ITEM 210A IN IPL FIG. 1, SHEET 2. THE -23 MAY BE CREATED FROM THE -7 IN THE SAME MANNER AND THE OTHERS SIMILARLY. SEE 737 SERVICE LETTER SL-27-80 FOR MORE INFORMATION. ALL CREATED ASSEMBLIES MUST ALSO BE REPART-MARKED, ACCORDINGLY.) | N | RF |
| -1Q | 65C25529-27 | | SWITCH ASSY-STAB TRIM CONT COLUMN ACTUATED SWITCH CUTOUT (SWITCH ASSYS ITEM 1K, 1L, 1M, 1N, 1P, 1Q MAY BE CREATE FROM SWITCH ASSYS ITEM 1B, 1C, 1D, 1E, 1F, 1G RESPECTIVELY. THE -22 ASSEMBLY IS CREATED FROM THE - 6 ASSEMBLY BY INSTALLING THE SIX NAS623-3-4 SCREWS ITEM 210 SUCH THAT THE HEADS ARE ORIENTED AS SHOWN BY SCREWS ITEM 210A IN IPL FIG. 1, SHEET 2. THE -23 MAY BE CREATED FROM THE -7 IN THE SAME MANNER AND THE OTHERS SIMILARLY. SEE 737 SERVICE LETTER SL-27-80 FOR MORE INFORMATION. ALL CREATED ASSEMBLIES MUST ALSO BE REPART-MARKED, ACCORDINGLY.) | P | RF |
| 5 | BACB30LK04-1 | | . BOLT | | 6 |
| 10 | AN960PD4 | | . WASHER | | 6 |
| 15 | 69-73319-1 | | . COVER | A, B, J, K | 1 |
| -15A | 69-73319-2 | | . COVER | C-H, L-N, P | 1 |
| 20 | BACB30LK04-2 | | . BOLT | | 8 |

-Item not Illustrated

27-41-91

ILLUSTRATED PARTS LIST

Page 1014

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

| FIG/ ITEM | PART NUMBER | AIRLINE PART NUMBER | NOMENCLATURE | | | | | | | USAGE CODE | UNITS PER ASSY | | | | | | | | | | | | | |
|--------------|---------------|---------------------------|--------------|---|---|---|---|---|---|---------------|----------------------|---|---|---|---|---|---|---|---|---|---|---|----|---|
| | | | 1 | 2 | 3 | 4 | 5 | 6 | 7 | | | | | | | | | | | | | | | |
| 1- | | | | | | | | | | | | | | | | | | | | | | | | |
| 25 | AN960PD4 | | . | W | A | S | H | E | R | | 8 | | | | | | | | | | | | | |
| 30 | 69-73316-1 | | . | C | O | V | E | R | | | 2 | | | | | | | | | | | | | |
| 35 | MS21042L3 | | . | N | U | T | | | | | 2 | | | | | | | | | | | | | |
| 40 | AN960D10L | | . | W | A | S | H | E | R | | 4 | | | | | | | | | | | | | |
| 45 | NAS514P1032-7 | | . | S | C | R | E | W | | | 2 | | | | | | | | | | | | | |
| 50 | BACB30LK06-10 | | . | B | O | L | T | | | A-D, J-M | 4 | | | | | | | | | | | | | |
| -50A | BACB30LK04-10 | | . | B | O | L | T | | | E-H, N, P | 4 | | | | | | | | | | | | | |
| 55 | AN960PD6 | | . | W | A | S | H | E | R | | 4 | | | | | | | | | | | | | |
| 60 | 65C25551-1 | | . | M | O | U | N | T | - | R | E | L | A | D | , | J | - | M | | 1 | | | | |
| -60A | 65C31205-1 | | . | M | O | U | N | T | - | R | E | L | A | | A | - | D | , | J | - | M | | 1 | |
| -60B | 65C31205-3 | | . | M | O | U | N | T | - | R | E | L | A | | E | - | H | , | N | , | P | | 1 | |
| -60C | 65C31205-5 | | . | M | O | U | N | T | - | R | E | L | A | | E | - | H | , | N | , | P | | 1 | |
| 65 | BACR13CF2AB | | . | R | E | L | A | | | | | | | | | | | | | | | 4 | | |
| 70 | BACS16X1A | | . | S | O | C | K | E | T | - | R | E | L | A | | | | | | | | | 4 | |
| 75 | BACB30LU04-1 | | | | | | | | | | | | | | | | | | | | | | | |
| 75A | NAS514P440-5 | | . | S | C | R | E | W | | | | | | | | | | | | | | | 6 | |
| 80 | 69-73316-3 | | . | C | O | V | E | R | | | | | | | A | , | B | , | J | , | K | | 2 | |
| -80A | 69-73316-4 | | . | C | O | V | E | R | | | | | | | C | - | H | , | L | - | N | , | P | 2 |
| 85 | MS24585-1005 | | . | S | P | R | I | N | G | | | | | | | | | | | | | | 4 | |
| 90 | 69-73314-1 | | . | P | I | N | | | | | | | | | | | | | | | | | 4 | |
| -90A | 69-73314-2 | | . | P | I | N | | | | | | | | | | | | | | | | | 4 | |
| 95 | 69-73316-2 | | . | C | O | V | E | R | | | | | | | | | | | | | | | 2 | |
| 100 | V3L2228 | | . | S | W | I | T | C | H | | | | | | | | | | | | | | 12 | |
| 105 | MS21042L04 | | | | | | | | | | | | | | | | | | | | | | | |
| 105A | BACN10NW1 | | | | | | | | | | | | | | | | | | | | | | | |
| 110 | AN960PD4 | | | | | | | | | | | | | | | | | | | | | | | |

-Item not Illustrated

27-41-91

ILLUSTRATED PARTS LIST

Page 1015

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

| FIG/ ITEM | PART NUMBER | AIRLINE PART NUMBER | NOMENCLATURE | | | | | | | USAGE CODE | UNITS PER ASSY | |
|--------------|----------------|---------------------------|--------------|---|---|---|---|---|---|---------------|----------------------|---|
| | | | 1 | 2 | 3 | 4 | 5 | 6 | 7 | | | |
| 1- | | | | | | | | | | | | |
| 115 | BACB30LK04-2 | | . | B | O | L | T | | | | 8 | |
| 120 | 65C25529-5 | | DELETED | | | | | | | | | |
| 120A | 65C25529-10 | | . | B | U | N | D | L | E | | 1 | |
| 125 | BACC45FN16-24P | | . | . | C | O | N | N | E | C | 1 | |
| 130 | BACC45FN12-12P | | . | . | C | O | N | N | E | C | 1 | |
| 132 | BACT12AC | | . | . | T | E | R | M | I | N | 2 | |
| 135 | BAC27DCT0351 | | . | M | A | R | K | E | R | | 1 | |
| 140 | BAC27DCT0352 | | . | M | A | R | K | E | R | | 1 | |
| 145 | MS21042L08 | | DELETED | | | | | | | | | |
| 150 | AN960KD8 | | DELETED | | | | | | | | | |
| 155 | BACB30LK2-14 | | DELETED | | | | | | | | | |
| 160 | 65C25529-3 | | DELETED | | | | | | | | | |
| -160A | 65C25529-4 | | DELETED | | | | | | | | | |
| 160B | 65C25529-8 | | . | M | E | C | H | A | N | I | A | 1 |
| -160C | 65C25529-9 | | . | M | E | C | H | A | N | I | B | 1 |
| -160D | 65C25529-13 | | . | M | E | C | H | A | N | I | C | 1 |
| -160E | 65C25529-14 | | . | M | E | C | H | A | N | I | D | 1 |
| -160F | 65C25529-17 | | . | M | E | C | H | A | N | I | E | 1 |
| -160G | 65C25529-18 | | . | M | E | C | H | A | N | I | F | 1 |
| -160H | 65C25529-20 | | . | M | E | C | H | A | N | I | G | 1 |
| 162 | MS21042L08 | | . | . | N | U | T | | | | 1 | |
| 163 | AN960KD8 | | . | . | W | A | S | H | E | R | 1 | |
| 164 | BACB30LK2-14 | | . | . | B | O | L | T | | | 1 | |
| 165 | 69-73309-1 | | . | . | L | E | V | E | R | A | 1 | |
| 170 | 66-25992-1 | | . | . | . | R | I | V | E | T | 1 | |
| 175 | 66-25992-2 | | . | . | . | R | I | V | E | T | 1 | |
| 180 | 69-73307-1 | | . | . | . | F | I | T | T | I | 1 | |
| 185 | 69-73308-1 | | . | . | . | A | R | M | | | 1 | |
| 190 | BAC27DCT0347 | | DELETED | | | | | | | | | |
| 190A | BAC27DCT0391 | | . | . | . | M | A | R | K | E | 1 | |
| 195 | 65C25539-1 | | . | . | C | O | V | E | R | A | A | 1 |

-Item not Illustrated

27-41-91

ILLUSTRATED PARTS LIST

Page 1016

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

| FIG/ ITEM | PART NUMBER | AIRLINE PART NUMBER | NOMENCLATURE | | | | | | | USAGE CODE | UNITS PER ASSY |
|--------------|--------------|---------------------------|--------------|---|---|---|---|---|--|---------------------|----------------------|
| | | | 1 | 2 | 3 | 4 | 5 | 6 | 7 | | |
| 1- | | | | | | | | | | | |
| -195A | 65C25539-5 | | | | | | | | . . COVER ASSY (OPT ITEM 195) | A, J | 1 |
| -195B | 65C25539-2 | | | | | | | | . . COVER ASSY (OPT ITEM 195) | B, K | 1 |
| -195C | 65C25539-7 | | | | | | | | . . COVER ASSY | C-H, L-N, P | 1 |
| -195D | 65C25539-9 | | | | | | | | . . COVER ASSY (OPT ITEM 195C) | C, E, G, H, L, N | 1 |
| -195E | 65C25539-8 | | | | | | | | . . COVER ASSY (OPT ITEM 195C) | D, F, M, P | 1 |
| | | | | | | | | | ATTACHING PARTS | | |
| 200 | MS21042L3 | | | | | | | | . . NUT | A-F | 6 |
| 200A | MS21042L3 | | | | | | | | . . NUT | G, H, J- N, P | 6 |
| 205 | AN960PD10 | | | | | | | | . . WASHER | A-F | 6 |
| 205A | AN960PD10 | | | | | | | | . . WASHER | G, H, J- N, P | 6 |
| 210 | NAS623-3-4 | | | | | | | | . . SCREW | A-F | 6 |
| 210A | NAS623-3-4 | | | | | | | | . . SCREW | G, H, J- N, P | 6 |
| | | | | | | | | | ----- * | | |
| 215 | MS21209C0415 | | | | | | | | . . . INSERT | | 4 |
| 220 | NAS607-2-3P | | | | | | | | . . . PIN | | 3 |
| 225 | 65C25539-3 | | | | | | | | . . . COVER (USED ON ITEMS 195,195C) | | 1 |
| -225A | 65C25539-6 | | | | | | | | . . . COVER (USED ON ITEMS 195A,195D) | | 1 |
| -225B | 65C25539-4 | | | | | | | | . . . COVER (USED ON ITEMS 195B,195E) | | 1 |
| 230 | BACB10AP6 | | | | | | | | . . BEARING | | 1 |
| 235 | BACB10AP3 | | | | | | | | . . BEARING | | 1 |
| 240 | 65C25548-1 | | | | | | | | . . GEAR | | 1 |
| -240A | 65C25548-2 | | | | | | | | . . GEAR (OPT ITEM 240) | B, D, F | 1 |
| 245 | 69-73400-1 | | | | | | | | . . SHAFT ASSY-PINION | | 1 |

-Item not Illustrated

27-41-91

ILLUSTRATED PARTS LIST

Page 1017

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

| FIG/ ITEM | PART NUMBER | AIRLINE PART NUMBER | NOMENCLATURE | | | | | | | USAGE CODE | UNITS PER ASSY |
|--------------|---------------|---------------------------|--------------|---|---|---|---|--|------------------------------|---------------|----------------------|
| | | | 1 | 2 | 3 | 4 | 5 | 6 | 7 | | |
| 1- | | | | | | | | | | | |
| 250 | MS20615-3M11 | | | | | | | DELETED | | | |
| 250A | MS20615-3M10 | | | | | | | . . . RIVET | | | 1 |
| 255 | AP48KS36 | | | | | | | . . . PINION (V29440) (OPT ITEM 255A,255B) | | | 1 |
| -255A | DP701T36 | | | | | | | . . . PINION (V29964) (OPT ITEM 255,255B) | | | 1 |
| -255B | P70-1-36 | | | | | | | . . . PINION (V12336) (OPT ITEM 255,255A) | | | 1 |
| 260 | 69-73313-1 | | | | | | | . . . SHAFT | | | 1 |
| 265 | MS20615-5MP12 | | | | | | | . . RIVET | | | 2 |
| 270 | 65C25550-1 | | | | | | | DELETED | | | |
| -270A | 65C25550-3 | | | | | | | DELETED | | | |
| -270B | 65C25550-2 | | | | | | | DELETED | | | |
| 270C | 65C25550-4 | | | | | | | . . CAM | | | 1 |
| -270D | 65C25550-6 | | | | | | | . . CAM (OPT ITEM 270C) | A, C, E, G, H, J, L, N | | 1 |
| -270E | 65C25550-5 | | | | | | | . . CAM (OPT ITEM 270C) | B, D, F, K, M, P | | 1 |
| 275 | BACB10AP3 | | | | | | | . . BEARING | | | 2 |
| 280 | 65C25540-1 | | | | | | | . . HOUSING ASSY | A, B, J, K | | 1 |
| -280A | 65C25540-5 | | | | | | | . . HOUSING ASSY (OPT ITEM 280) | A, J | | 1 |
| -280B | 65C25540-2 | | | | | | | . . HOUSING ASSY (OPT ITEM 280) | B, K | | 1 |
| -280C | 65C25540-7 | | | | | | | . . HOUSING ASSY | C, D, L, M | | 1 |
| -280D | 65C25540-9 | | | | | | | . . HOUSING ASSY (OPT ITEM 280C) | C, L | | 1 |
| -280E | 65C25540-8 | | | | | | | . . HOUSING ASSY (OPT ITEM 280C) | D, M | | 1 |
| -280F | 65C25540-13 | | | | | | | . . HOUSING ASSY | E-H, N, P | | 1 |

-Item not Illustrated

27-41-91

ILLUSTRATED PARTS LIST

Page 1018

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

| FIG/ ITEM | PART NUMBER | AIRLINE PART NUMBER | NOMENCLATURE | | | | | | | USAGE CODE | UNITS PER ASSY |
|--------------|---------------|---------------------------|--------------|---|--------------------------------------|---|---|---|---|---------------|----------------------|
| | | | 1 | 2 | 3 | 4 | 5 | 6 | 7 | | |
| 1- | | | | | | | | | | | |
| -280G | 65C25540-14 | | . | . | HOUSING ASSY (OPT ITEM 280F) | | | | | E, G, H, N | 1 |
| 285 | MS21209C0415 | | . | . | INSERT | | | | | | 8 |
| 290 | MS21209C0610 | | . | . | INSERT | | | | | A-D, J-M | 4 |
| -290A | MS21209C0410 | | . | . | INSERT | | | | | E-H, N, P | |
| 295 | BACR15BA3D | | . | . | RIVET | | | | | | 16 |
| 300 | BACN10JP04CCD | | . | . | NUTPLATE | | | | | | 8 |
| -300A | BACN10JN04CM | | . | . | NUTPLATE (OPT ITEM 300) | | | | | | 8 |
| 305 | 65C25540-3 | | . | . | HOUSING (USED ON ITEMS 280,280C) | | | | | | 1 |
| -305A | 65C25540-6 | | . | . | HOUSING (USED ON ITEMS 280A,280D) | | | | | | 1 |
| -305B | 65C25540-4 | | . | . | HOUSING (USED ON ITEMS 280B,280E) | | | | | | 1 |
| -305C | 65C25540-15 | | . | . | HOUSING (USED ON ITEM 280F) | | | | | | 1 |
| -305D | 65C25540-16 | | . | . | HOUSING (USED ON ITEM 280G) | | | | | | 1 |
| 310 | MS21042L04 | | . | | NUT (OPT ITEM 310A) | | | | | | 8 |
| 310A | BACN10NW1 | | . | | NUT-CLIP (OPT ITEM 310, 315) | | | | | | 8 |
| 315 | AN960PD4 | | . | | WASHER (OPT ITEM 310A) | | | | | | 8 |
| 330 | BAC27DCT0355 | | . | | MARKER | | | | | H | 1 |

-Item not Illustrated

27-41-91

ILLUSTRATED PARTS LIST

Page 1019

Mar 01/2006