



**COMPONENT MAINTENANCE
MANUAL
WITH
ILLUSTRATED PARTS LIST**

**POSITIONS 1 AND 8 FLAP ACTUATOR
TRANSMISSION ASSEMBLY**

**PART NUMBER
256A3110-3, -4, -5, -6, -7, -8**

BOEING PROPRIETARY, CONFIDENTIAL, AND/OR TRADE SECRET

Copyright © 1995 The Boeing Company
Unpublished Work - All Rights Reserved

Boeing claims copyright in each page of this document only to the extent that the page contains copyrightable subject matter. Boeing also claims copyright in this document as a compilation and/or collective work.

This document includes proprietary information owned by The Boeing Company and/or one or more third parties. Treatment of the document and the information it contains is governed by contract with Boeing. For more information, contact The Boeing Company, P.O. Box 3707, Seattle, Washington 98124.

Boeing, the Boeing signature, the Boeing symbol, 707, 717, 727, 737, 747, 757, 767, 777, 787, Dreamliner, BBJ, DC-8, DC-9, DC-10, KC-10, KDC-10, MD-10, MD-11, MD-80, MD-88, MD-90, P-8A, Poseidon and the Boeing livery are all trademarks owned by The Boeing Company; and no trademark license is granted in connection with this document unless provided in writing by Boeing.

PUBLISHED BY BOEING COMMERCIAL AIRPLANES GROUP, SEATTLE, WASHINGTON, USA
A DIVISION OF THE BOEING COMPANY
PAGE DATE: Jul 01/2009

27-55-67

Page 1
Jul 01/2009



COMPONENT MAINTENANCE MANUAL

Revision No. 17
Jul 01/2009

To: All holders of POSITIONS 1 AND 8 FLAP ACTUATOR TRANSMISSION ASSEMBLY 27-55-67.

Attached is the current revision to this COMPONENT MAINTENANCE MANUAL

The COMPONENT MAINTENANCE MANUAL is furnished either as a printed manual, on microfilm, or digital products, or any combination of the three. This revision replaces all previous microfilm cartridges or digital products. All microfilm and digital products are reissued with all obsolete data deleted and all updated pages added.

For printed manuals, changes are indicated on the List of Effective Pages (LEP). The pages which are revised will be identified on the LEP by an R (Revised), A (Added), O (Overflow, i.e. changes to the document structure and/or page layout), or D (Deleted). Each page in the LEP is identified by Chapter-Section-Subject number, page number and page date.

Pages replaced or made obsolete by this revision should be removed and destroyed.

ATTENTION

IF YOU RECEIVE PRINTED REVISIONS, PLEASE VERIFY THAT YOU HAVE RECEIVED AND FILED THE PREVIOUS REVISION. BOEING MUST BE NOTIFIED WITHIN 30 DAYS IF YOU HAVE NOT RECEIVED THE PREVIOUS REVISION. REQUESTS FOR REVISIONS OTHER THAN THE PREVIOUS REVISION WILL REQUIRE A COMPLETE MANUAL REPRINT SUBJECT TO REPRINT CHARGES SHOWN IN THE DATA AND SERVICES CATALOG.

27-55-67

TRANSMITTAL LETTER

Page 1

Jul 01/2009



COMPONENT MAINTENANCE MANUAL

Location of Change

Description of Change

NO HIGHLIGHTS

27-55-67

HIGHLIGHTS

Page 1

Jul 01/2009



COMPONENT MAINTENANCE MANUAL

Subject/Page	Date	Subject/Page	Date	Subject/Page	Date
TITLE PAGE		27-55-67 TESTING AND FAULT ISOLATION (cont)		27-55-67 REPAIR 7-1	
O 1	Jul 01/2009	108	Mar 01/2006	601	Mar 01/2006
2	BLANK	27-55-67 DISASSEMBLY		602	Mar 01/2006
27-55-67 TRANSMITTAL LETTER		301	Nov 01/2008	27-55-67 REPAIR 8-1	
O 1	Jul 01/2009	302	Jul 01/2008	601	Mar 01/2006
2	BLANK	303	Mar 01/2007	602	Mar 01/2006
27-55-67 HIGHLIGHTS		304	BLANK	27-55-67 REPAIR 9-1	
O 1	Jul 01/2009	27-55-67 CLEANING		601	Mar 01/2006
2	BLANK	401	Mar 01/2006	602	Mar 01/2006
27-55-67 EFFECTIVE PAGES		402	BLANK	27-55-67 REPAIR 10-1	
1 thru 3	Jul 01/2009	27-55-67 CHECK		601	Mar 01/2006
4	BLANK	501	Nov 01/2007	602	Mar 01/2006
27-55-67 CONTENTS		502	Nov 01/2007	27-55-67 REPAIR 11-1	
1	Jul 01/2007	27-55-67 REPAIR - GENERAL		601	Mar 01/2006
2	BLANK	601	Mar 01/2006	602	Mar 01/2006
27-55-67 TR AND SB RECORD		602	Mar 01/2006	27-55-67 REPAIR 12-1	
1	Mar 01/2006	603	Mar 01/2006	601	Jul 01/2008
2	BLANK	604	BLANK	602	Mar 01/2006
27-55-67 REVISION RECORD		27-55-67 REPAIR 1-1		27-55-67 REPAIR 12-2	
1	Mar 01/2006	601	Nov 01/2007	601	Mar 01/2006
2	Mar 01/2006	602	Nov 01/2007	602	Mar 01/2006
27-55-67 RECORD OF TEMPORARY REVISIONS		603	Nov 01/2007	27-55-67 REPAIR 12-3	
1	Mar 01/2006	604	BLANK	601	Mar 01/2006
2	Mar 01/2006	27-55-67 REPAIR 2-1		602	BLANK
27-55-67 INTRODUCTION		601	Mar 01/2006	27-55-67 REPAIR 13-1	
1	Mar 01/2009	602	Mar 01/2006	601	Mar 01/2006
2	BLANK	27-55-67 REPAIR 3-1		602	Mar 01/2006
27-55-67 DESCRIPTION AND OPERATION		601	Mar 01/2006	27-55-67 REPAIR 14-1	
1	Mar 01/2006	602	Mar 01/2006	601	Mar 01/2006
2	Mar 01/2006	27-55-67 REPAIR 4-1		602	Mar 01/2006
27-55-67 TESTING AND FAULT ISOLATION		601	Mar 01/2006	27-55-67 REPAIR 15-1	
101	Nov 01/2008	602	Mar 01/2006	601	Mar 01/2006
102	Jul 01/2007	27-55-67 REPAIR 5-1		602	Mar 01/2006
103	Mar 01/2007	601	Mar 01/2006	27-55-67 REPAIR 16-1	
104	Mar 01/2007	602	Mar 01/2006	601	Mar 01/2006
105	Mar 01/2007	27-55-67 REPAIR 6-1		602	BLANK
106	Mar 01/2006	601	Mar 01/2006	27-55-67 REPAIR 16-2	
107	Mar 01/2006	602	Mar 01/2006	601	Mar 01/2006
				602	Mar 01/2006

A = Added, R = Revised, D = Deleted, O = Overflow

27-55-67

EFFECTIVE PAGES

Page 1

Jul 01/2009



COMPONENT MAINTENANCE MANUAL

Subject/Page	Date	Subject/Page	Date	Subject/Page	Date
27-55-67 REPAIR 16-3		27-55-67 REPAIR 26-3		27-55-67 FITS AND CLEARANCES (cont)	
601	Mar 01/2006	601	Mar 01/2006	804	Mar 01/2006
602	Mar 01/2006	602	BLANK	805	Mar 01/2006
27-55-67 REPAIR 16-4		27-55-67 REPAIR 27-1		806	BLANK
601	Mar 01/2006	601	Mar 01/2006	27-55-67 SPECIAL TOOLS, FIXTURES, AND EQUIPMENT	
602	BLANK	602	Mar 01/2006	901	Mar 01/2009
27-55-67 REPAIR 17-1		27-55-67 REPAIR 28-1		902	BLANK
601	Mar 01/2006	601	Mar 01/2006	27-55-67 ILLUSTRATED PARTS LIST	
602	Mar 01/2006	602	Mar 01/2006	1001	Nov 01/2008
27-55-67 REPAIR 18-1		27-55-67 ASSEMBLY		1002	Nov 01/2006
601	Mar 01/2006	701	Nov 01/2008	1003	Jul 01/2006
602	Mar 01/2006	702	Jul 01/2007	1004	Jul 01/2006
27-55-67 REPAIR 19-1		703	Mar 01/2007	1005	Mar 01/2006
601	Mar 01/2006	704	Jul 01/2007	1006	Mar 01/2006
602	Mar 01/2006	705	Mar 01/2007	1007	Mar 01/2006
27-55-67 REPAIR 20-1		706	Mar 01/2007	1008	Mar 01/2006
601	Mar 01/2006	707	Mar 01/2007	1009	Mar 01/2006
602	Mar 01/2006	708	Mar 01/2007	1010	Mar 01/2006
27-55-67 REPAIR 21-1		709	Mar 01/2006	1011	Mar 01/2006
601	Mar 01/2006	710	Jul 01/2007	1012	Mar 01/2006
602	Mar 01/2006	711	Mar 01/2006	1013	Mar 01/2006
27-55-67 REPAIR 22-1		712	Jul 01/2008	1014	Mar 01/2006
601	Mar 01/2006	713	Mar 01/2006	1015	Mar 01/2006
602	Mar 01/2006	714	Mar 01/2006	1016	Mar 01/2006
27-55-67 REPAIR 23-1		715	Mar 01/2006	1017	Mar 01/2006
601	Mar 01/2006	716	Mar 01/2006	1018	Mar 01/2006
602	Mar 01/2006	717	Mar 01/2006	1019	Mar 01/2006
27-55-67 REPAIR 24-1		718	Mar 01/2006	1020	Mar 01/2006
601	Mar 01/2006	719	Mar 01/2006	1021	Mar 01/2006
602	Mar 01/2006	720	Mar 01/2006	1022	Mar 01/2006
27-55-67 REPAIR 25-1		721	Mar 01/2006	1023	Mar 01/2006
601	Mar 01/2006	722	Mar 01/2006	1024	Mar 01/2006
602	Mar 01/2006	723	Mar 01/2006	1025	Mar 01/2006
27-55-67 REPAIR 26-1		724	Mar 01/2006	1026	Mar 01/2006
601	Jul 01/2008	725	Mar 01/2006	1027	Mar 01/2006
602	Mar 01/2006	726	Mar 01/2006	1028	Mar 01/2006
27-55-67 REPAIR 26-2		27-55-67 FITS AND CLEARANCES		1029	Mar 01/2006
601	Mar 01/2006	801	Jul 01/2006	1030	Mar 01/2006
602	Mar 01/2006	802	Mar 01/2006	1031	Mar 01/2006
		803	Mar 01/2006		

A = Added, R = Revised, D = Deleted, O = Overflow

27-55-67

EFFECTIVE PAGES

Page 2

Jul 01/2009



COMPONENT MAINTENANCE MANUAL

Subject/Page	Date	Subject/Page	Date	Subject/Page	Date
27-55-67	ILLUSTRATED PARTS LIST				
(cont)					
1032	Mar 01/2006				
1033	Mar 01/2006				
1034	BLANK				

A = Added, R = Revised, D = Deleted, O = Overflow

27-55-67

EFFECTIVE PAGES

Page 3

Jul 01/2009

**COMPONENT MAINTENANCE MANUAL****TABLE OF CONTENTS**

<u>Paragraph Title</u>	<u>Page</u>
TRAILING EDGE FLAP TRANSMISSION ASSEMBLY NO. 1 AND 8 - DESCRIPTION AND OPERATION	1
TESTING AND FAULT ISOLATION	101
DISASSEMBLY	301
CLEANING	401
CHECK	501
REPAIR	601
ASSEMBLY	701
FITS AND CLEARANCES	801
SPECIAL TOOLS, FIXTURES, AND EQUIPMENT	901
ILLUSTRATED PARTS LIST	1001

27-55-67

CONTENTS

Page 1

Jul 01/2007



COMPONENT MAINTENANCE MANUAL

INTRODUCTION

1. General

- A. The instructions in this manual supply the data necessary to do the maintenance functions together with the test, fault isolation, repair, and replacement of the defective parts.
- B. This manual is divided into different parts:
 - (1) Title Page
 - (2) Transmittal Letter
 - (3) Highlights
 - (4) List of Effective Pages
 - (5) Table of Contents
 - (6) Temporary Revision & Service Bulletin Record
 - (7) Record of Revisions
 - (8) Record of Temporary Revisions
 - (9) Introduction
 - (10) Procedures & IPL Sections
- C. Components that can be repaired have a different repair number for each specified repair. To find the repair number location of a component, look in the Repair-General procedure at the beginning of the REPAIR section. The Repair-General procedure also has an explanation of the True Position Dimension symbols used.
- D. All dimensions, measures, quantities and weights included are in English units. When metric equivalents are given they will be in the parentheses that follow the English units.
- E. The introduction to the Illustrated Parts List (IPL) shows how the IPL data is used.
- F. Design changes, optional parts, configuration differences and Service Bulletin modifications may cause different part numbers. These part numbers are identified in the IPL with an alphabetical letter which is added to the end of the basic item number. This new item number is referred to as an alpha-variant. Throughout the manual, IPL basic item number references also apply to alpha-variants unless shown differently.
- G. The tool reference numbers found in the individual procedures and in the Special Tools, Fixtures, and Equipment section are used to identify if a tool is a standard tool (STD-XXXX), a commercial tool (COM-XXXX), or a Special Tool (SPL-XXXX). This reference number is also used to distinguish between tools with similar names in the same procedure. These reference numbers are for use in the documentation only. They are not to be used for ordering tools.

27-55-67

INTRODUCTION

Page 1

Mar 01/2009



COMPONENT MAINTENANCE MANUAL

TRAILING EDGE FLAP TRANSMISSION ASSEMBLY NO. 1 AND 8 - DESCRIPTION AND OPERATION

1. Description

A. The transmission assembly has two bevel gear sets, two spur gear sets, a torque brake assembly, a no-back brake, a housing assembly, and a universal assembly. The bevel gears, spur gears, torque brake, and no-back brake are steel components. The universal assembly has a CRES yoke assembly and CRES internal shaft members. The transmission assembly has an aluminum alloy housing. The no-back brake has a skewed roller assembly, a ratchet plate, and two pawls. The universal joint assembly has two internal shaft members which attach the output shaft to a ballscrew yoke shaft.

2. Operation

A. The transmission assembly transmits power from the torque tubes to the universal joint and the ballscrew of the flap drive. The transmission assembly changes the speed and the turn direction from the torque tube to the ballscrew. The transmission assembly has a no-back mechanism which prevents accidental flap retraction if a drive train failure or a hydraulic failure occurs. The transmission assembly also has a torque brake assembly which limits the maximum torque transmitted to the ballscrew if the flap does not move freely. A trip indicator on the torque brake provides a visual indication if the torque brake operates. The trip indicator is replaced with a cover plate on some assemblies.

3. Leading Particulars (Approximate)

- A. Length – 15.5 inches
- B. Width – 14 inches
- C. Height – 18 inches
- D. Weight – 43 pounds


27-55-67

DESCRIPTION AND OPERATION

Page 1

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



TRANSMISSION ASSEMBLY NO. 1 SHOWN

Trailing Edge Flap Transmission Assembly No. 1 and 8
Figure 1

27-55-67

DESCRIPTION AND OPERATION

Page 2

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

TESTING AND FAULT ISOLATION

1. General

- A. This procedure contains the data necessary to do a test of the transmission after an overhaul or for fault isolation. There are three parts:
- (1) Transmission Assembly Test
 - (a) Run-In Tests
 - (b) Pressure Test
 - (c) No-Load Friction Torque Test
 - (d) Backlash Test
 - (e) Output Torque Test
 - (f) No-Back Brake Test
 - (g) Output Shaft End Play Check
 - (2) Fault Isolation
 - (3) Fault Correction
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.

2. Transmission Assembly Test

A. Tools/Equipment

NOTE: Equivalent substitutes may be used.

Reference	Description
SPL-4720	Test Equipment - Leakage Test (Part #: J27054-1, Supplier: 81205)
SPL-5391	TE Flap Transmission, AFT U-Joint and BallScrew Test Equipment (Part #: C27072-92, Supplier: 81205) (Part #: C27072-93, Supplier: 81205)

B. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
G01048	Lockwire - Corrosion Resistant Steel (0.032 In. Dia.)	NASM20995~ C32

C. References

Reference	Title
SOPM 20-50-02	INSTALLATION OF SAFETYING DEVICES

D. General

- (1) To do these tests, it is necessary to set up the transmission assembly in a transmission test fixture.

27-55-67

TESTING AND FAULT ISOLATION

Page 101

Nov 01/2008



COMPONENT MAINTENANCE MANUAL

- (2) Put the transmission assembly in the position shown in TESTING AND FAULT ISOLATION, Figure 101 when you check the fluid level and do the pressure test. For the other tests, the transmission can be put at an angle of 0-22 degrees, measured as shown in the figure.
- (3) Look into the input shaft coupling (outboard direction on the airplane) to get the clockwise and counterclockwise directions when you turn the input shaft. Look into the output shaft (forward direction on the airplane) to get the directions for the output shaft.

E. Procedure

NOTE: Tests are to be performed at room temperature, 50-110°F.

- (1) Install the transmission assembly, with the ballscrew and ballnut, in the test stand C27072-4, a component of the transmission assembly test equipment, SPL-5391 .

NOTE: The ballscrew and ballnut must be installed on the transmission before it is put in the test fixture. Loads are applied to the output shaft through the ballscrew and ballnut.

- (2) Make sure that the correct quantity of hydraulic fluid is added to the transmission assembly (ASSEMBLY). Measure the fluid level with the transmission installed as shown in TESTING AND FAULT ISOLATION, Figure 101.
- (3) Make sure that the correct quantity of grease is added to each universal joint ASSEMBLY.
- (4) Turn the input coupling sleeve (40) in each direction by hand. All components must turn smoothly and freely without unusual noise or resistance.
- (5) Do the run-in tests on the transmission assembly.
 - (a) Do a no-load run-in test.
 - 1) Apply no load to the output shaft. Turn the input shaft of the transmission assembly at 400-700 rpm for 20 seconds, or 20 revolutions, in both the clockwise and counterclockwise directions.
 - 2) Record that the test is completed.
 - (b) Do a lockout run-in test.
 - 1) Apply no load to the output shaft. Turn the input shaft of the transmission assembly at 60-90 rpm in the clockwise direction.
 - 2) Gradually lock out the hydraulic cylinder on the test fixture until the torque brake locks up and stalls the drive motor.
 - 3) Do the test again in the opposite direction.
 - 4) Do TESTING AND FAULT ISOLATION, Paragraph 2.E.(5)(b)1) thru TESTING AND FAULT ISOLATION, Paragraph 2.E.(5)(b)3) again for a total of 2 clockwise and 2 counterclockwise lockouts.
- (6) Do a pressure test of the seals in the transmission assembly.
 - (a) Remove the lockwire, G01048 and the plug and bleeder (175).
 - (b) Install the air valve adapter of the leakage test test equipment, SPL-4720 in the plug and bleeder hole in the housing assembly (230).
 - (c) Connect the compressed air supply.
 - (d) Pressurize the transmission assembly to 24-26 psig, and remove the pressure source.
 - (e) Monitor the pressure in the transmission for a minimum of 20 minutes. Make sure the pressure does not decrease to less than 22 psig after the first 10 minutes. Record the value.

27-55-67

TESTING AND FAULT ISOLATION

Page 102

Jul 01/2007



COMPONENT MAINTENANCE MANUAL

- (f) During the next 10 minutes, make sure that the pressure does not decrease by more than 1.0 psig from the value after the first 10 minutes. Record this value.
- (g) Make sure that you cannot hear or see any signs of leakage while the transmission is pressurized.
- (h) Make sure that the oil level in the transmission assembly is correct (refer to ASSEMBLY), then install the plug and bleeder (175). Install lockwire, G01048 on the plug and bleeder. Use the double-twist method (SOPM 20-50-02).
- (i) Record the results of the test as PASS or FAIL.

CAUTION: MAKE SURE THAT THERE IS NO LEAKAGE OF OIL DURING ANY OF THE TESTS THAT FOLLOW. LEAKAGE CAN CAUSE DAMAGE TO THE ASSEMBLY AND THE TEST MUST BE STOPPED.

- (7) Do a no-load friction torque test.
 - (a) Apply no load to the output shaft. Gradually increase the input shaft torque until the output shaft turns (breakaway). Increase the input shaft torque until the input shaft turns at approximately 60 rpm.
 - (b) Record the breakaway torque and the maximum running torque. Make sure that the torques are less than 12 lb-in.
 - (c) Apply the input torque in the opposite direction and repeat the test.
 - (d) Make sure the gears and the bearings turn smoothly without binding in each direction.
 - (e) Record the results of the test as PASS or FAIL.
- (8) Do a check of the backlash.
 - (a) Lock the output shaft.
 - (b) Apply a 23-27 lb-in. torque to the input shaft in the clockwise direction, then decrease the torque to 8-12 lb-in. Do not let the torque go to zero.
 - (c) Record the position of the input shaft.
 - (d) Turn the input shaft in the counterclockwise direction and apply a 23-27 lb-in. torque. Decrease the torque to 8-12 lb-in. Do not let the torque go to zero.
 - (e) Record the position of the input shaft.
 - (f) Record the difference between the two positions of the input shaft. This is the total input shaft backlash. Make sure that the backlash is 4.1-7.8 degrees.
- (9) Do a check of the maximum output torque.
 - (a) Lock the output shaft.
 - (b) Manually apply an input torque and gradually increase it until the torque brake locks up and stalls the drive motor.
 - (c) Continue to increase the input torque until it is 350-450 lb-in. Measure and record the output load at lockout.
 - (d) Make sure that the torque brake trip indicator operates. (Not applicable on assemblies 256A3110-3, -4)
 - (e) Decrease the input torque to zero. Set the trip indicator to the retracted position.
 - (f) Do the test again in the opposite direction.

27-55-67

TESTING AND FAULT ISOLATION

Page 103

Mar 01/2007



COMPONENT MAINTENANCE MANUAL

- (g) Do TESTING AND FAULT ISOLATION, Paragraph 2.E.(9)(a) thru TESTING AND FAULT ISOLATION, Paragraph 2.E.(9)(f) two more times for a total of 3 clockwise and 3 counterclockwise lockouts.
 - (h) Make sure that the output load is TBD lb (assemblies 256A3110-3 thru -6) or TBD lb (assemblies 256A3110-7, 8) at each lockout.
- (10) Do a no-back brake test.
- (a) Do a check of the no-back brake in the flap retract direction.
 - 1) Apply no axial load to the output shaft. Turn the input shaft so that the ball nut is between the aft stop and the center of the ball screw.
 - 2) Stop the input shaft.
 - 3) Apply a 9900-10100 lb compression load to the output shaft. Align the load to ± 0.5 degree of the output shaft centerline.
 - 4) Make sure that the input shaft does not turn.
 - 5) With the compression load on the output shaft, apply a torque to the input shaft in the counterclockwise direction until the no-back brake releases and the input shaft begins to turn. Record the input torque value when the brake releases.

NOTE: It is possible that the input shaft will turn initially at approximately 10 lb-in. when the pawls engage.
 - 6) Make sure that the input torque value is 30-105 lb-in.
 - (b) Do a check of the no-back brake in the flap extend direction.
 - 1) Apply no axial load to the output shaft. Turn the input shaft at 60-90 rpm in the clockwise direction.
 - 2) Stop the input shaft.
 - 3) Apply a 980-1020 lb tension load to the output shaft. Align the load to ± 0.5 degree of the output shaft centerline.
 - 4) Make sure that the input shaft does not turn.
 - (c) Do a check of the no-back brake ratchet.
 - 1) Apply a 250-500 lb compression load to the output shaft. Align the load to ± 0.5 degree of the output shaft centerline.
 - 2) With the compression load on the output shaft, turn the input shaft in the clockwise direction.
 - 3) Listen for the sound of the ratchets.
 - 4) Record the result of the test as PASS or FAIL.
- (11) Do a check of the end play of the output shaft.
- (a) Apply a 40-50 lb compression load to the output shaft, and measure the shaft position.
 - (b) Apply a 40-50 lb tension load to the output shaft, and measure the shaft position.
 - (c) Record the total axial movement (end play) of the output shaft. Make sure that the end play is 0.005-0.012 inch.


27-55-67

TESTING AND FAULT ISOLATION

Page 104

Mar 01/2007

COMPONENT MAINTENANCE MANUAL



Transmission Oil Level Verification
Figure 101

27-55-67

TESTING AND FAULT ISOLATION

Page 105

Mar 01/2007



COMPONENT MAINTENANCE MANUAL

3. Fault Isolation

- A. Refer to the TESTING AND FAULT ISOLATION, Table 101, for causes of the problems found and the procedures to correct them.

Table 101: Fault Isolation Chart

TROUBLE	PROBABLE CAUSE	CORRECTION
Does not turn smoothly	Defective bearings (120, 142,210,350,510,605,635, 680,760), gears (170,185, 360,640,650,655), or torque brake (295A,300A) Improper shimming	Replace parts as required. *[1]
External leakage	Defective packings (20, 35A,370,95,100,180,225, 290,355,465,560,710) or seals (50,85,750)	Replace parts as required.
Backlash out of range	Improper shimming or worn components.	*[1]
Axial end play out of range	Improper shimming Worn bearings (510,760) or plates (505,610)	Replace shims (515 thru 530). Replace parts as required.
No-back brake out of range, or ratchet test failed	Worn roller assy (615) or plates (610,630).	Replace parts as required.
Lockout out of range	Defective torque brake assembly (295A,300A)	Repair or replace the torque brake assembly (295A,300A).

*[1] Do a check of the shims used to adjust the mounting of the gears and make corrections as necessary. If the check of shims shows that they are of the correct thickness, then do a check of the tooth contact patterns for each gear set. If necessary, refer to the gear manufacturing industry standards for the full procedures on how to examine the tooth contact pattern in the bevel gear sets.

4. Fault Correction

A. References

Reference	Title
CMM 27-55-82	FLAP ACTUATION LOW SETTING TORQUE BRAKE ASSEMBLY

B. Procedure

- (1) If the gears (170, 185, 360, 640, 650, 655) do not move freely or turn smoothly or the breakaway torque is high, adjust the shims (125 thru 140, 190 thru 205, 260 thru 275, 330 thru 345, 515 thru 530, 660 thru 675) or replace the bearing(s) (120, 142, 210, 350, 510, 605, 635, 680, 760), gears (170, 185, 360, 640, 650, 655), or torque brake (295A, 300A) as follows:
- Fully disassemble the transmission assembly (DISASSEMBLY).
 - Replace the defective bearing(s) (120, 142, 210, 350, 510, 605, 635, 680, 760), gears (170, 185, 360, 640, 650, 655), or torque brake (295A, 300A) if it is necessary.

27-55-67

TESTING AND FAULT ISOLATION

Page 106

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

- (c) Assemble the transmission assembly (ASSEMBLY).
- NOTE:** Shim (125 thru 140, 190 thru 205, 260 thru 275, 330 thru 345, 515 thru 530, 660 thru 675) adjustment is performed during the assembly task.
- (d) Do a motion test on the transmission assembly.
- (2) If air or grease leakage occurs at a seal or any two surfaces that contact, replace the seals (50, 85, 750) or packing (20, 35A, 70, 95, 100, 180, 225, 290, 355, 465, 560, 710) as follows:
- (a) Disassemble the transmission assembly as necessary (DISASSEMBLY)).
- (b) Replace the defective seal (50, 85, 750) or packing (20, 35A, 70, 95, 100, 180, 225, 290, 355, 465, 560, 710) if it is necessary.
- (c) Assemble the transmission assembly as necessary (ASSEMBLY).
- (d) Do a pressure test on the transmission assembly.
- (3) If the backlash is not 4.1-7.8 degrees, adjust the shims (125 thru 140, 190 thru 205, 260 thru 275, 330 thru 345, 515 thru 530, 660 thru 675) or replace the gears (170, 185, 360, 640, 650, 655) as follows:
- (a) Fully disassemble the transmission assembly (DISASSEMBLY).
- (b) Replace the defective gears (170, 185, 360, 640, 650, 655) if it is necessary.
- (c) Assemble the transmission assembly (ASSEMBLY).
- NOTE:** Shims (125 thru 140, 190 thru 205, 260 thru 275, 330 thru 345, 515 thru 530, 660 thru 675) adjustment is performed during the assembly task.
- (d) Do a backlash test on the transmission assembly.
- (4) If the axial end play of the output shaft is not 0.005 to 0.012 inch, adjust the shims (515 thru 530) or replace the bearings (510, 635, 680, 760) or replace the plates (610, 630) as follows:
- (a) Fully disassemble the transmission assembly (DISASSEMBLY).
- (b) Replace the defective bearings (510, 635, 680, 760) or plates (610, 630) if it is necessary.
- (c) Assemble the transmission assembly (ASSEMBLY).
- NOTE:** Shim (125 thru 140, 190 thru 205, 260 thru 275, 330 thru 345, 515 thru 530, 660 thru 675) adjustment is performed during the assembly task.
- (d) Do an axial end play test on the transmission assembly.
- (5) If the no-back brake operates out of the specified ranges or the ratchet test is failed, replace the roller assembly (615) or the plates (610, 630) as follows:
- (a) Disassemble the transmission assembly (DISASSEMBLY) as necessary.
- (b) Replace the roller assembly (615) or the plates (610, 630) if it is necessary.
- (c) Assemble the transmission assembly (ASSEMBLY).
- (d) Do a no-back test on the transmission assembly.
- (6) If the torque brake (295A, 300A) does not lock out at the specified ranges, repair the torque brake as follows:
- (a) Disassemble the transmission assembly (DISASSEMBLY).
- NOTE:** Disassemble the torque brake assembly (Refer to CMM 27-55-82).
- (b) Repair the defective torque brake if it is necessary. Refer to CMM 27-55-82.

27-55-67

TESTING AND FAULT ISOLATION

Page 107

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

- (c) Assemble the torque brake assembly (CMM 27-55-82) and the transmission assembly (ASSEMBLY).
- (d) Do a brake test on the transmission assembly.

27-55-67

TESTING AND FAULT ISOLATION

Page 108

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

DISASSEMBLY

1. General

- A. This procedure has the data necessary to disassemble the transmission assembly.
- B. Disassemble this component sufficiently to isolate the defects, do the necessary repairs, and put the component back to a serviceable condition.
- C. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- D. Refer to IPL Figure 1 for item numbers.

2. Transmission Disassembly

A. Tools/Equipment

NOTE: Equivalent substitutes may be used.

Reference	Description
SPL-5384	Wrench - Coupling Sleeve Flap Actuation (Part #: C27041-1, Supplier: 81205)
SPL-5391	TE Flap Transmission, AFT U-Joint and BallScrew Test Equipment (Part #: C27072-92, Supplier: 81205) (Part #: C27072-93, Supplier: 81205)

B. References

Reference	Title
CMM 27-55-82	FLAP ACTUATION LOW SETTING TORQUE BRAKE ASSEMBLY

C. General

- (1) To disassemble the transmission, it is necessary to install the transmission in the C27072 transmission assembly test equipment, SPL-5391 .

D. Part Replacement

NOTE: The parts which follow are recommended for replacement. Unless a procedure tells you to replace a part, replacement is optional.

- (1) Packings (20, 35A, 70A, 95, 100, 180A, 225, 290, 355, 465, 560, 710)
- (2) Seals (50, 85, 90, 750)
- (3) Lockwashers (480, 690)
- (4) Lockwire – MS20995C32

E. Procedure

- (1) Remove all lockwire, the plug and bleeder (175), and the packing (180A) from the transmission assembly.
- (2) Drain all the hydraulic fluid from the transmission assembly.
- (3) Install the transmission assembly in the C27072 transmission assembly test equipment, SPL-5391 .
- (4) Remove and disassemble the yoke assembly (390).
 - (a) Remove the nut (385), adapter (415), shaft (405, 425), spacer (435), and yoke assembly (390).

27-55-67

DISASSEMBLY

Page 301

Nov 01/2008



COMPONENT MAINTENANCE MANUAL

- (5) Remove the bolts (10), washers (15), packing (20), and cap (25) from the housing assembly (230).
- (6) Remove the coupling (45) from the pinion assembly (160).
 - (a) Use the coupling sleeve wrench, SPL-5384 to hold the coupling sleeve (40).
 - (b) Remove the bolt (30), the packing (35A), the coupling (45), the seal (50), the sleeve (40), and the shield (55A).
- (7) Remove and disassemble the pinion assembly (160).
 - (a) Remove the nut (57) and washer (59).
 - (b) Remove the bolts (60, 445), the washers (65, 455), packing (70A), and retainers (75, 155).
 - (c) Remove the seal (85), packing (95), ring (110), and bearing (142) from the housing (230).
 - (d) Remove the shaft seal (90), spacer (115), packing (100), ring (105), bearing (120), and shims (125 thru 140) from the retainer (75) side of housing (230). Measure and record the shim thickness to facilitate assembly.
 - (e) Remove the pinion assembly (160) from the housing (230).

NOTE: Do not remove the inserts (165) from the pinion (170) unless repair or replacement is necessary.
- (8) Remove the housing assembly (230) and the bevel gear (185).
 - (a) Remove the bevel gear (185), shims (190 thru 205), and bearing (210) from the housing assembly (230). Measure and record the shim thickness to facilitate assembly.
 - (b) Remove the bolts (215) and washers (220) and separate the housing assembly (230) and packing (225), from the torque brake assembly (295A, 300A).

NOTE: Do not remove the inserts (240, 245) from the housing assembly (250) unless repair or replacement is necessary.
 - (c) Remove the shims (260 thru 275) from the torque brake assembly (295A, 300A). Measure and record the shim thickness to facilitate assembly.
- (9) Remove the torque brake assembly (295A, 300A). See CMM 27-55-82 for the torque brake assembly repair instructions.
 - (a) Remove the bolts (280) and washers (285) and separate the torque brake assembly (295A, 300A) and packing (290) from the housing assembly (765).
- (10) Remove the bolts (305), washers (310), packing (290) and cap (315).
- (11) Remove the output shaft assembly (720).
 - (a) Remove the bolts (145), washers (150), packing (465), and cover (470) from the cover assembly (565).
 - (b) Remove the nut (475), lockwasher (480), block (485), roller assembly (490), thrust plate (505), bearing (510), and shims (515 thru 530) from the cover assembly (565). Measure and record the shim thickness to facilitate assembly.
 - (c) Remove the bolts (535, 540), washers (545, 550), and nuts (555) and separate the cover assembly (565) from the housing assembly (765).

NOTE: Do not remove the inserts (570, 770, 775, 780) or dowel pin (572) from the cover and housing assemblies unless repair or replacement is necessary.
 - (d) Remove the roller assembly (615), plate (630), and gear (640) from the shaft assembly (720).

27-55-67

DISASSEMBLY

Page 302

Jul 01/2008



COMPONENT MAINTENANCE MANUAL

- (e) Remove the output shaft assembly (720) from the housing assembly (765).
- (12) Remove the race (645) from the shaft assembly (720).
- (13) Remove the bolts (700), washers (705), packing (710), and retainer (715) from the housing assembly (765).
- (14) Remove the bearing (760), spacer (755), and shaft seal (750) from the housing assembly (765).
- (15) Remove the packing (560), bearing race (600), bearing (605), ratchet plate (610), and bearing (635) from the cover assembly (565).
- (16) Remove the pins (580), springs (585), pawls (590), and spacers (595).
- (17) Remove the shaft and pinion assembly (360) from the housing assembly (765).
 - (a) Remove the bolts (320), retainers (325), shims (330 thru 345), bearings (350), packings (355), and the shaft and pinion assembly (360) from the housing (765). Measure and record the shim thickness to facilitate assembly.
- (18) Remove the pinion (650), gear (655), shims (660 thru 675), bearing (680), spacer (685), lockwasher (690), and nut (695).

27-55-67

DISASSEMBLY

Page 303

Mar 01/2007



COMPONENT MAINTENANCE MANUAL

CLEANING

1. General

- A. This procedure has the data necessary to clean the special parts.
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.

2. Cleaning

A. References

Reference	Title
SOPM 20-30-03	GENERAL CLEANING PROCEDURES

B. Procedure

- (1) Clean sealed bearings as specified in manufacturer's instructions.
- (2) Clean all the parts other than bearings as specified by standard industry practices (SOPM 20-30-03).

27-55-67

CLEANING

Page 401

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

CHECK

1. General

- A. This procedure has the data necessary to find defects in the material of the specified parts.
- B. Refer to FITS AND CLEARANCES for the design dimension and wear limits.
- C. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- D. Refer to IPL Figure 1 for item numbers.

2. Check

A. References

Reference	Title
SOPM 20-20-01	MAGNETIC PARTICLE INSPECTION
SOPM 20-20-02	PENETRANT METHODS OF INSPECTION

B. Procedure

- (1) Use standard industry procedures to do a visual check of all the parts for defects. Do the penetrant or magnetic particle check if the visual check shows possible damage or if you suspect possible damage to parts.
- (2) Examine the gear teeth for pit marks or irregular worn areas.
- (3) Make sure the wear pattern on the gear is in the center of the area of the pitch diameter.
- (4) Do a magnetic particle check (SOPM 20-20-01) of these parts:
 - (a) Coupling assemblies: sleeves (40), coupling half (45)
 - (b) Bolt (30)
 - (c) Shield (55A)
 - (d) Rings (105, 110)
 - (e) Pinion (170)
 - (f) Gears (185, 640, 650, 655)
 - (g) Shaft and pinion assembly: pin (365), pinion (370), shaft (375)
 - (h) Universal joint assembly: shaft (405), internal shaft adapter (415), yoke (400), internal shaft (425), spacer (435)
 - (i) Lockwashers (480, 690)
 - (j) Block (485)
 - (k) Thrust plate (505)
 - (l) Pawl assembly: pin (580), spring (585), pawls (590)
 - (m) Bearing race (600)
 - (n) Plates (610, 630)
 - (o) Race (645)
 - (p) Spacers (595, 685)
 - (q) Shaft (740)

27-55-67

CHECK


Page 501

Nov 01/2007



COMPONENT MAINTENANCE MANUAL

- (5) Do a penetrant check (SOPM 20-20-02) on these parts:
- (a) Caps (25, 315)
 - (b) Retainers (75, 155, 325, 500, 625, 715)
 - (c) Housings (250, 575, 785)
 - (d) Covers (470)
 - (e) Bearing (730)
 - (f) Spacer (755)
- (6) Do a spring check.
- (a) Spring (585) – CHECK, Figure 501



TEST POSITION (DEGREES DEFLECTION)	MOMENT (LB-INS)	
	SINGLE SPRING	BOTH SPRINGS
I (32°)	0.235-0.287	0.469-0.573
II (43°)	0.315-0.385	0.630-0.770

Spring (585) Check Data
Figure 501

27-55-67

CHECK
Page 502
Nov 01/2007



COMPONENT MAINTENANCE MANUAL

REPAIR

1. General

- A. Instructions for repair, refinish, and replacement of the specified subassembly parts are included in each REPAIR when applicable:

Table 601:

PART NUMBER	NAME	REPAIR
- - -	REFINISH OF OTHER PARTS	1-1
251N4103	U-JOINT SPACER	2-1
251N4135	U-JOINT SHAFT	3-1
251N4149	INTERNAL SHAFT	4-1
251N4150	INTERNAL SHAFT ADAPTER	5-1
256A3121	HOUSING	6-1
256A3123	PINION	7-1
256A3124	BEVEL GEAR	8-1
256A3125	RETAINER	9-1
256A3133	SEAL RETAINER	10-1
256A3135	CAP	11-1
256A3136	OUTPUT SHAFT ASSEMBLY	12-1,12-2,12-3
256A3137	GEAR	13-1
256A3138	SPUR PINION	14-1
256A3139	GEAR	15-1
256A3143	SHAFT AND PINION ASSEMBLY	16-1,16-2,16-3,16-4
256A3144	RACE	17-1
256A3145	PLATE	18-1
256A3171	COVER	19-1
256A3172	BLOCK	20-1
256A3176	BEARING RACE	21-1
256A3179	THRUST PLATE	22-1
256A3181	CAP	23-1
256A3187	HOUSING	24-1
256A3188	HOUSING	25-1
256A3191	YOKE ASSEMBLY	26-1,26-2,26-3
256A3741	COUPLING HALF	27-1
256W3244	SEAL RETAINER	28-1

27-55-67

REPAIR - GENERAL

Page 601

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

2. Dimensioning Symbols

- A. Standard True Position Dimensioning Symbols used in the applicable repair procedures are shown in REPAIR-GENERAL, Figure 601.

27-55-67

REPAIR - GENERAL

Page 602

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

—	STRAIGHTNESS	∅	DIAMETER
▭	FLATNESS	S ∅	SPHERICAL DIAMETER
⊥	PERPENDICULARITY (OR SQUARENESS)	R	RADIUS
//	PARALLELISM	SR	SPHERICAL RADIUS
○	ROUNDNESS	()	REFERENCE
⊘	CYLINDRICITY	BASIC	A THEORETICALLY EXACT DIMENSION USED
⌒	PROFILE OF A LINE	(BSC)	TO DESCRIBE SIZE, SHAPE OR LOCATION OF
⌓	PROFILE OF A SURFACE	OR	A FEATURE. FROM THIS FEATURE PERMISSIBLE
◎	CONCENTRICITY	DIM	VARIATIONS ARE ESTABLISHED BY TOLERANCES ON OTHER DIMENSIONS OR
≡	SYMMETRY		NOTES.
∠	ANGULARITY	-A-	DATUM
↗	RUNOUT	Ⓜ	MAXIMUM MATERIAL CONDITION (MMC)
↗↗	TOTAL RUNOUT	Ⓛ	LEAST MATERIAL CONDITION (LMC)
⊐	COUNTERBORE OR SPOTFACE	Ⓢ	REGARDLESS OF FEATURE SIZE (RFS)
∇	COUNTERSINK	Ⓟ	PROJECTED TOLERANCE ZONE
⊕	THEORETICAL EXACT POSITION OF A FEATURE (TRUE POSITION)	FIM	FULL INDICATOR MOVEMENT

EXAMPLES

$\boxed{\text{—}} \boxed{0.002}$	STRAIGHT WITHIN 0.002	$\boxed{\text{◎}} \boxed{\text{∅}} \boxed{0.0005} \boxed{\text{C}}$	CONCENTRIC TO DATUM C WITHIN 0.0005 DIAMETER
$\boxed{\text{⊥}} \boxed{0.002} \boxed{\text{B}}$	PERPENDICULAR TO DATUM B WITHIN 0.002	$\boxed{\text{≡}} \boxed{0.010} \boxed{\text{A}}$	SYMMETRICAL WITH DATUM A WITHIN 0.010
$\boxed{\text{//}} \boxed{0.002} \boxed{\text{A}}$	PARALLEL TO DATUM A WITHIN 0.002	$\boxed{\text{∠}} \boxed{0.005} \boxed{\text{A}}$	ANGULAR TOLERANCE 0.005 WITH DATUM A
$\boxed{\text{○}} \boxed{0.002}$	ROUND WITHIN 0.002	$\boxed{\text{⊕}} \boxed{\text{∅}} \boxed{0.002} \boxed{\text{Ⓢ}} \boxed{\text{B}}$	LOCATED AT TRUE POSITION WITHIN 0.002 DIA RELATIVE TO DATUM B, REGARDLESS OF FEATURE SIZE
$\boxed{\text{⊘}} \boxed{0.010}$	CYLINDRICAL SURFACE MUST LIE BETWEEN TWO CONCENTRIC CYLINDERS, ONE OF WHICH HAS A RADIUS 0.010 INCH GREATER THAN THE OTHER	$\boxed{\text{⊥}} \boxed{\text{∅}} \boxed{0.010} \boxed{\text{Ⓜ}} \boxed{\text{A}}$	AXIS IS TOTALLY WITHIN A CYLINDER OF 0.010 INCH DIAMETER, PERPENDICULAR TO DATUM A, AND EXTENDING 0.510 INCH ABOVE DATUM A, MAXIMUM MATERIAL CONDITION
$\boxed{\text{⌒}} \boxed{0.006} \boxed{\text{A}}$	EACH LINE ELEMENT OF THE SURFACE AT ANY CROSS SECTION MUST LIE BETWEEN TWO PROFILE BOUNDARIES 0.006 INCH APART RELATIVE TO DATUM A	$\boxed{0.510} \boxed{\text{Ⓟ}}$	
$\boxed{\text{⌓}} \boxed{0.020} \boxed{\text{A}}$	SURFACES MUST LIE WITHIN PARALLEL BOUNDARIES 0.020 INCH APART AND EQUALLY DISPOSED ABOUT TRUE PROFILE	$\boxed{2.000}$	THEORETICALLY EXACT DIMENSION IS 2.000
		OR	
		2.000	
		BSC	

True Position Dimensioning Symbols
Figure 601

27-55-67

REPAIR - GENERAL

Page 603

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

REFINISH OF OTHER PARTS - REPAIR 1-1

1. General

- A. This procedure has the data necessary to refinish the parts which are not given in the specified repairs.
- B. Refer to the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.

2. Refinish of Other Parts

A. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-60-02	FINISHING MATERIALS

C. Procedure

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For decoding table for Boeing finish codes, refer to SOPM 20-41-01. For finishing materials, refer to SOPM 20-60-02.

- (1) Instructions for the repair of the parts listed in REPAIR 1-1, Table 601 is for repair of the initial finish.

Table 601: Refinish Details

IPL FIG. & ITEM	MATERIAL	FINISH
Fig. 1		
Coupling sleeve (40)	4140 steel, 150-170 ksi	Cadmium plate (0.0003-0.0005 inch thick) type 2 (F-15.36) and bake at 350-400°F for 3 hours after plating. Apply primer, C00259 (F-20.02) on all surfaces except spline teeth. primer, C00259 is optional on inside surface of curl. Do not allow primer to plug 0.04-0.05 diameter holes.
Bolt (30)	15-5PH CRES, 180-200 ksi	Cadmium plate (F-16.06) per REPAIR 1-1, Figure 601.
Shield (55A)	15-5PH CRES, 180-200 ksi	Passivate (F-17.25).
Ring (105,110)	15.2CR-1.0M0- 0.40N (0.28-0.34C) steel	Passivate (F-17.25).

27-55-67

REPAIR 1-1

Page 601

Nov 01/2007



COMPONENT MAINTENANCE MANUAL

Table 601: Refinish Details (Continued)

IPL FIG. & ITEM	MATERIAL	FINISH
Spacer (115,755)	Al alloy	Boric acid-sulfuric acid anodize or chromic acid anodize (F-17.31).
Bearing retainer (325)	Al alloy	Boric acid-sulfuric acid anodize or chromic acid anodize (F-17.35), and apply primer, C00259 (F-20.02) on edge of flange.
Lockwasher (480,690)	17-7PH CRES, 140-160 ksi	Passivate (F-17.25).
Spring (585)	17-7PH CRES	Passivate (F-17.09) all over.
Pawl (590)	17-4PH CRES, 275-300 ksi	Passivate (F-17.09) all over.
Spacer (595)	15-5PH CRES, 155-193 ksi	Passivate (F-17.09) all over.
Spacer (685)	15-5PH CRES, 150-170 ksi	Passivate (F-17.25).


27-55-67

REPAIR 1-1

Page 602

Nov 01/2007

COMPONENT MAINTENANCE MANUAL



1 CADMIUM PLATE PER F-16.06, EXCEPT FOR THIS AREA

256A3744-1 Bolt Refinish
Figure 601

27-55-67

REPAIR 1-1

Page 603

Nov 01/2007



COMPONENT MAINTENANCE MANUAL

U-JOINT SPACER - REPAIR 2-1

251N4103-1

1. General

- A. This procedure has the data necessary to refinish the U-joint spacer (435).
- B. Refer to the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
 - (1) Material: 15-5PH CRES, BMS 7-240, 180-200 ksi

2. U-Joint Spacer Refinish

A. References

Reference	Title
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

B. Procedure

NOTE: For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Apply chrome plate 0.0003-0.0005 inch thick as shown in REPAIR 2-1, Figure 601 and bake (F-15.04).


27-55-67

REPAIR 2-1

Page 601

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



CHROME PLATE THIS SURFACE

ITEM NUMBERS REFER TO IPL FIG. 1

ALL DIMENSIONS ARE IN INCHES

251N4103-1 U-Joint Spacer Refinish
Figure 601

27-55-67

REPAIR 2-1

Page 602

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

U-JOINT SHAFT - REPAIR 3-1

251N4135-1

1. General

- A. This procedure has the data necessary to repair and refinish the U-joint shaft (405).
- B. Refer to the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
 - (1) Material: 15-5PH CRES, BMS 7-240, 180-200 ksi
 - (2) Shot peen:
 - (a) Intensity 0.014A-0.018A
 - (b) Coverage 2.0

2. U-Joint Shaft Repair

A. References

Reference	Title
SOPM 20-10-03	SHOT PEENING

B. Procedure (REPAIR 3-1, Figure 601)

- (1) Machine within repair limits shown to remove defects.
- (2) Break all sharp edges (SOPM 20-10-03).
- (3) Shot peen as indicated in REPAIR 3-1, Figure 601.
- (4) Refinish per refinish instructions.
- (5) Machine to design dimensions and finish shown.

3. U-Joint Shaft Refinish

A. References

Reference	Title
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

B. Procedure (REPAIR 3-1, Figure 601)

NOTE: For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Apply chrome plate 0.0003-0.0005 inch thick as shown in REPAIR 3-1, Figure 601 and bake (F-15.04).

27-55-67



REPAIR 3-1

Page 601


Mar 01/2006




COMPONENT MAINTENANCE MANUAL



A-A



B-B



C-C
1.080
1.074 AFTER PLATING

- 1 CHROME PLATE THIS SURFACE
- 2 NO PLATING ON THESE SURFACES.
- 3 SHOT PEEN AREA, INCLUDING FILLET RADIUS.

ITEM NUMBERS REFER TO IPL FIG. 1
ALL DIMENSIONS ARE IN INCHES

251N4135-1 U-Joint Shaft Repair
Figure 601

27-55-67

REPAIR 3-1
Page 602
Mar 01/2006



COMPONENT MAINTENANCE MANUAL

INTERNAL SHAFT - REPAIR 4-1

251N4149-1

1. General

- A. This procedure has the data necessary to refinish the internal shaft (425).
- B. Refer to the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
 - (1) Material: 15-5PH CRES, BMS 7-240, 180-200 ksi

2. Internal Shaft Refinish

A. References

Reference	Title
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

B. Procedure (REPAIR 4-1, Figure 601)

NOTE: For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Apply chrome plate 0.0003-0.0005 inch thick as shown in REPAIR 4-1, Figure 601 and bake (F-15.04).



27-55-67

REPAIR 4-1

Page 601

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



A-A

- 1 CHROME PLATE THIS SURFACE
- 2 NO PLATE ON THIS SURFACE.

ITEM NUMBERS REFER TO IPL FIG. 1
ALL DIMENSIONS ARE IN INCHES

251N4149-1 Internal Shaft Refinish
Figure 601

27-55-67

REPAIR 4-1
Page 602
Mar 01/2006



COMPONENT MAINTENANCE MANUAL

INTERNAL SHAFT ADAPTER - REPAIR 5-1

251N4150-1

1. General

- A. This procedure has the data necessary to refinish the internal shaft adapter (415).
- B. Refer to the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
 - (1) Material: 15-5PH CRES, BMS 7-240, 180-200 ksi

2. Internal Shaft Adapter Refinish

A. References

Reference	Title
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

B. Procedure (REPAIR 5-1, Figure 601)

NOTE: For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Apply chrome plate 0.0003-0.0005 inch thick as shown in REPAIR 5-1, Figure 601 and bake (F-15.04).


27-55-67

REPAIR 5-1

Page 601

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



 CHROME PLATE THIS SURFACE

ITEM NUMBERS REFER TO IPL FIG. 1
ALL DIMENSIONS ARE IN INCHES

251N4150-1 Internal Shaft Adapter Refinish
Figure 601

27-55-67

REPAIR 5-1
Page 602
Mar 01/2006



COMPONENT MAINTENANCE MANUAL

HOUSING - REPAIR 6-1

256A3121-3, -4

1. General

- A. This procedure has the data necessary to refinish the housing (250).
- B. Refer to the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
 - (1) Material: Aluminum alloy

2. Housing Refinish

- A. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-60-02	FINISHING MATERIALS

- C. Procedure

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01. For finishing materials, refer to SOPM 20-60-02.

- (1) Boric acid-sulfuric acid anodize or chromic acid anodize (F-17.35) all over.
- (2) Apply primer, C00259 (F-20.02) on all external surfaces except hole diameters and as noted in REPAIR 6-1, Figure 601.

27-55-67



REPAIR 6-1


Page 601

Mar 01/2006



COMPONENT MAINTENANCE MANUAL



 NO PRIMER ON INDICATED SURFACES

ITEM NUMBERS REFER TO IPL FIG. 1

256A3121-3,-4 Housing Refinish
Figure 601

27-55-67

REPAIR 6-1

Page 602

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

PINION - REPAIR 7-1

256A3123-2

1. General

- A. This procedure has the data necessary to refinish the pinion (170).
- B. Refer to the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
 - (1) Material: 9310 steel, 160-190 ksi

2. Pinion Refinish

- A. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-60-02	FINISHING MATERIALS

- C. Procedure

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01. For finishing materials, refer to SOPM 20-60-02.

- (1) Apply cadmium plate (F-15.23) on all surfaces except as noted in REPAIR 7-1, Figure 601. Uncontrolled plating thickness is permitted in the bores.
- (2) Apply primer, C00259 (F-20.02) as noted in REPAIR 7-1, Figure 601.


27-55-67

REPAIR 7-1

Page 601

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



- 1 NO FINISH OR CADMIUM PLATE RUNOUT ON INDICATED SURFACE. CADMIUM PLATE RUNOUT ON ADJACENT SURFACES SHALL NOT EXCEED 0.030 INCH.
- 2 APPLY PRIMER (F-20.02) ON INTERNAL SURFACES, USING FILL AND DRAIN METHOD.

ITEM NUMBERS REFER TO IPL FIG. 1
ALL DIMENSIONS ARE IN INCHES.

256A3123-2 Pinion Refinish
Figure 601

27-55-67

REPAIR 7-1
Page 602
Mar 01/2006



COMPONENT MAINTENANCE MANUAL

BEVEL GEAR - REPAIR 8-1

256A3124-1

1. General

- A. This procedure has the data necessary to refinish the bevel gear (185).
- B. Refer to the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
 - (1) Material: 9310 steel, 160-190 ksi

2. Bevel Gear Refinish

A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

B. Procedure

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Apply cadmium plate (F-15.23) on all exterior surfaces except as noted in REPAIR 8-1, Figure 601. Uncontrolled plating thickness is permitted in the bores.


27-55-67

REPAIR 8-1

Page 601

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



1 NO FINISH OR CADMIUM PLATE RUNOUT ON INDICATED SURFACES. CADMIUM PLATE RUNOUT ON ADJACENT SURFACES SHALL NOT EXCEED 0.03 INCH.

ITEM NUMBERS REFER TO IPL FIG. 1
ALL DIMENSIONS ARE IN INCHES

256A3124-1 Bevel Gear Refinish
Figure 601

27-55-67

REPAIR 8-1
Page 602
Mar 01/2006



COMPONENT MAINTENANCE MANUAL

RETAINER - REPAIR 9-1

256A3125-1, -2

1. General

- A. This procedure has the data necessary to refinish the retainer (75).
- B. Refer to the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
 - (1) Material: Aluminum alloy

2. Retainer Refinish

- A. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-60-02	FINISHING MATERIALS

- C. Procedure

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01. For finishing materials, refer to SOPM 20-60-02.

- (1) Boric acid-sulfuric acid anodize or chromic acid anodize (F-17.35) all over.
- (2) Apply primer, C00259 (F-20.02) to all surfaces except as noted in REPAIR 9-1, Figure 601. Overspray is allowed in holes.


27-55-67

REPAIR 9-1

Page 601

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



- 1 APPLY PRIMER (F-20.02) TO ALL SURFACES EXCEPT AS NOTED IN 2. OVERSPRAY IS ALLOWED IN HOLES.
- 2 APPLY PRIMER TO INDICATED SURFACE EXCEPT NO RUNS, BEADS, OR SAGS ALLOWED.
- 3 PRIMER RUNOUT AREA.

ITEM NUMBERS REFER TO IPL FIG. 1
ALL DIMENSIONS ARE IN INCHES.

256A3125-1,-2 Retainer Refinish
Figure 601

27-55-67

REPAIR 9-1
Page 602
Mar 01/2006



COMPONENT MAINTENANCE MANUAL

SEAL RETAINER - REPAIR 10-1

256A3133-1, -2

1. General

- A. This procedure has the data necessary to refinish the seal retainer (715).
- B. Refer to the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
 - (1) Material: Aluminum alloy

2. Seal Retainer Refinish

- A. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-60-02	FINISHING MATERIALS

- C. Procedure (REPAIR 10-1, Figure 601)

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01. For finishing materials, refer to SOPM 20-60-02.

- (1) Boric acid-sulfuric acid anodize or chromic acid anodize (F-17.35) all over.
- (2) Apply primer, C00259 (F-20.02) to all the indicated surfaces shown in REPAIR 10-1, Figure 601. Overspray allowed in holes except as noted.


27-55-67

REPAIR 10-1

Page 601

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



1 APPLY PRIMER TO INDICATED SURFACES (F-20.02).
OVERSPRAY ALLOWED IN HOLES EXCEPT AS NOTED BY FLAGNOTE 2

2 NO OVERSPRAY ALLOWED IN HOLES

ITEM NUMBERS REFER TO IPL FIG. 1
ALL DIMENSIONS ARE IN INCHES

256A3133-1,-2 Seal Retainer Refinish
Figure 601

27-55-67

REPAIR 10-1
Page 602
Mar 01/2006



COMPONENT MAINTENANCE MANUAL

CAP - REPAIR 11-1

256A3135-1

1. General

- A. This procedure has the data necessary to refinish the cap (315).
- B. Refer to the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
 - (1) Material: Aluminum alloy

2. Cap Refinish

- A. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-60-02	FINISHING MATERIALS

- C. Procedure (REPAIR 11-1, Figure 601)

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01. For finishing materials, refer to SOPM 20-60-02.

- (1) Boric acid-sulfuric acid anodize or chromic acid anodize (F-17.35) all over.
- (2) Apply primer, C00259 (F-20.02) to all the indicated surfaces shown in REPAIR 11-1, Figure 601. Overspray allowed in holes except as noted.


27-55-67

REPAIR 11-1

Page 601

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



1 APPLY PRIMER TO INDICATED SURFACES (F-20.02). OVERSPRAY ALLOWED IN HOLES.

ITEM NUMBERS REFER TO IPL FIG. 1
ALL DIMENSIONS ARE IN INCHES

256A3135-1 Cap Refinish
Figure 601

27-55-67

REPAIR 11-1
Page 602
Mar 01/2006



COMPONENT MAINTENANCE MANUAL

OUTPUT SHAFT ASSEMBLY - REPAIR 12-1

256A3136-1, -4

1. General

- A. This procedure has the data necessary to repair the output shaft assembly (720).
- B. Refer to the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.

2. Bearing Replacement

- A. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
A00247	Sealant - Pressure And Environmental - Chromate Type	BMS 5-95

- B. References

Reference	Title
SOPM 20-50-03	BEARING AND BUSHING REPLACEMENT
SOPM 20-60-04	MISCELLANEOUS MATERIALS

- C. Procedure

NOTE: For miscellaneous materials, refer to SOPM 20-60-04.

- (1) Remove the bearing (730) from the shaft (740).
- (2) Install replacement bearings with sealant, A00247 using the shrink-fit method (SOPM 20-50-03). Make sure bearing flange contacts lug.

27-55-67


REPAIR 12-1

Page 601

Jul 01/2008



COMPONENT MAINTENANCE MANUAL



BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 1

ALL DIMENSIONS ARE IN INCHES

256A3136-1,-4 Output Shaft Assembly Bearing Replacement
Figure 601

27-55-67

REPAIR 12-1

Page 602

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

OUTPUT SHAFT - REPAIR 12-2

256A3136-2, -5

1. General

- A. This procedure has the data necessary to repair and refinish the output shaft (740).
- B. Refer to the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
 - (1) Material: PH13-8MO CRES, 200-220 ksi
 - (2) Shot peen: All surfaces, except in holes less than 0.90 diameter, keyways spline, thread and thread relief.
 - (a) Intensity 0.008A-0.013A
 - (b) Coverage 2.0
 - (3) Glass bead peen: All surfaces, except in holes less than 0.90 diameter, keyways spline, thread and thread relief.
 - (a) Intensity 0.008A-0.013A
 - (b) Coverage 2.0

2. Output Shaft Repair

A. References

Reference	Title
SOPM 20-10-03	SHOT PEENING

B. Procedure (REPAIR 12-2, Figure 601)

- (1) Machine within repair limits shown to remove defects.
- (2) Break all sharp edges (SOPM 20-10-03).
- (3) Shot peen the shaft (740) and plunge grind surfaces as indicated in REPAIR 12-2, Figure 601.
- (4) Refinish per refinish instructions.

3. Output Shaft Refinish

A. References

Reference	Title
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

B. Procedure

NOTE: For Decoding table for Boeing Finish Codes, refer to SOPM 20-41-01.

- (1) Passivate (F-17.25) all over.


27-55-67

REPAIR 12-2

Page 601

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



- 1 DELETED
- 2 PLUNGE GRIND THIS SURFACE AFTER PEENING.
- 3 INDICATED TOLERANCE OR SURFACE FINISH APPLIES AFTER PEENING.

BREAK ALL SHARP EDGES
 ITEM NUMBERS REFER TO IPL FIG. 1
 ALL DIMENSIONS ARE IN INCHES

256A3136-2,-5 Output Shaft Repair and Refinish
 Figure 601

27-55-67



COMPONENT MAINTENANCE MANUAL

BEARING - REPAIR 12-3

251N4105-1

1. General

- A. This procedure has the data necessary to refinish the bearing (730).
- B. Refer to the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
 - (1) Material: Aluminum nickel bronze

2. Bearing Refinish

A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

B. Procedure

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Apply cadmium plate, Type 2, Class 2 (F-15.06) all over, except bearing bore.

27-55-67

REPAIR 12-3

Page 601

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

GEAR - REPAIR 13-1

256A3137-1

1. General

- A. This procedure has the data necessary to refinish the gear (640).
- B. Refer to the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
 - (1) Material: 9310 steel, 160-190 ksi

2. Gear Refinish

A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

B. Procedure (REPAIR 13-1, Figure 601)

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Apply cadmium plate (F-15.23) all over unless shown differently on REPAIR 13-1, Figure 601.


27-55-67

REPAIR 13-1

Page 601

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



1 NO FINISH OR CADMIUM PLATE RUNOUT ON INDICATED SURFACES. CADMIUM PLATE RUNOUT ON ADJACENT SURFACES SHALL NOT EXCEED 0.03 INCH.

ITEM NUMBERS REFER TO IPL FIG. 1
ALL DIMENSIONS ARE IN INCHES

256A3137-1 Gear Refinish
Figure 601

27-55-67

REPAIR 13-1
Page 602
Mar 01/2006



COMPONENT MAINTENANCE MANUAL

SPUR PINION - REPAIR 14-1

256A3138-1, -2

1. General

- A. This procedure has the data necessary to refinish the spur pinion (650).
- B. Refer to the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
 - (1) Material: 9310 steel, 160-190 ksi

2. Spur Pinion Refinish

A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

B. Procedure

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing Finish Codes, refer to SOPM 20-41-01.

- (1) Cadmium plate (F-15.23) all over unless shown differently on REPAIR 14-1, Figure 601.



27-55-67

REPAIR 14-1

Page 601

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



A

1 NO FINISH OR CADMIUM PLATE RUNOUT ON INDICATED SURFACES. CADMIUM PLATE RUNOUT ON ADJACENT SURFACES SHALL NOT EXCEED 0.03 INCH.

2 PLATING THROW-IN IS ACCEPTABLE IN INDICATED BORE.

ITEM NUMBERS REFER TO IPL FIG. 1
ALL DIMENSIONS ARE IN INCHES

256A3138-1,-2 Spur Pinion Repair
Figure 601

27-55-67

REPAIR 14-1
Page 602
Mar 01/2006



COMPONENT MAINTENANCE MANUAL

GEAR - REPAIR 15-1

256A3139-1

1. General

- A. This procedure has the data necessary to refinish the gear (655).
- B. Refer to the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
 - (1) Material: 9310 steel, 160-190 ksi

2. Gear Refinish

A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

B. Procedure

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Apply cadmium plate (F-15.23) all over unless shown differently on REPAIR 15-1, Figure 601.

27-55-67


REPAIR 15-1

Page 601

Mar 01/2006



COMPONENT MAINTENANCE MANUAL



1 NO FINISH OR CADMIUM PLATE RUNOUT ON INDICATED SURFACES. CADMIUM PLATE RUNOUT ON ADJACENT SURFACES SHALL NOT EXCEED 0.03 INCH.

ITEM NUMBERS REFER TO IPL FIG. 1
ALL DIMENSIONS ARE IN INCHES

256A3139-1 Gear Refinish
Figure 601

27-55-67

REPAIR 15-1
Page 602
Mar 01/2006



COMPONENT MAINTENANCE MANUAL

SHAFT AND PINION - REPAIR 16-1

256A3143-1

1. General

- A. This procedure has the data necessary to repair the shaft and pinion assembly (360).
- B. Refer to the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.

2. Shaft and Pinion Assembly Repair

A. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
D00467	Fluid - Landing Gear Shock Strut	BMS3-32, Type II
D00590	Fluid - Flap Drive System - Brayco 795	

B. References

Reference	Title
SOPM 20-60-03	LUBRICANTS

C. Procedure

NOTE: For lubricants, refer to SOPM 20-60-03.

- (1) Remove the pin (365) from the pinion (370) and the shaft (375).
- (2) Remove the pinion (370) from the shaft (375).
- (3) Refinish as necessary.
- (4) Install the pinion (370) with fluid, D00467 or Brayco 795 fluid, D00590 on the shaft (375). Make sure the pinion contacts the shaft shoulder.
- (5) Install the pin (365) with fluid, D00467 or Brayco 795 fluid, D00590 through the pinion (370) and the shaft (375). Make sure that the pin does not extend past the diameter of the pinion.

27-55-67

REPAIR 16-1

Page 601

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

PINION - REPAIR 16-2

256A3141-1

1. General

- A. This procedure has the data necessary to refinish the pinion (370).
- B. Refer to the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
 - (1) Material: 9310 steel, 160-190 ksi

2. Pinion Refinish

A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

B. Procedure

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Apply cadmium plate (F-15.23) all over unless shown differently on REPAIR 16-2, Figure 601.


27-55-67

REPAIR 16-2

Page 601

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



1 NO FINISH OR CADMIUM PLATE RUNOUT ON INDICATED SURFACES. CADMIUM PLATE RUNOUT ON ADJACENT SURFACES SHALL NOT EXCEED 0.03 INCH.

ITEM NUMBERS REFER TO IPL FIG. 1
ALL DIMENSIONS ARE IN INCHES

256A3141-1 Pinion Refinish
Figure 601

27-55-67

REPAIR 16-2
Page 602
Mar 01/2006



COMPONENT MAINTENANCE MANUAL

SHAFT - REPAIR 16-3

256A3142-1

1. General

- A. This procedure has the data necessary to refinish the shaft (375).
- B. Refer to the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
 - (1) Material: 4330 steel, 180-200 ksi

2. Shaft Refinish

A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

B. Procedure

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Apply cadmium plate, type 2, class 2 (F-15.06) all over unless shown differently on REPAIR 16-3, Figure 601.


27-55-67

REPAIR 16-3

Page 601

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



1 NO FINISH OR CADMIUM PLATE RUNOUT ON INDICATED SURFACES. CADMIUM PLATE RUNOUT ON ADJACENT SURFACES SHALL NOT EXCEED 0.03 INCH.

2 PLATING THROW-IN IS ACCEPTABLE IN INDICATED BORE.

ITEM NUMBERS REFER TO IPL FIG. 1
ALL DIMENSIONS ARE IN INCHES

256A3142-1 Shaft Refinish
Figure 601

27-55-67

REPAIR 16-3
Page 602
Mar 01/2006



COMPONENT MAINTENANCE MANUAL

PIN - REPAIR 16-4

256A3149-1

1. General

- A. This procedure has the data necessary to refinish the pin (365).
- B. Refer to the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
 - (1) Material: PH13-8MO CRES, 200-220 ksi

2. Pin Refinish

A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

B. Procedure

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Passivate per method 2 (F-17.25) all over.

27-55-67

REPAIR 16-4

Page 601

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

RACE - REPAIR 17-1

256A3144-1

1. General

- A. This procedure has the data necessary to refinish the race (645).
- B. Refer to the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
 - (1) Material: 52100 steel, 60-65 HRC

2. Race Refinish

A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

B. Procedure (REPAIR 17-1, Figure 601)

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Apply cadmium-titanium plate, bake 12 hours minimum at 350-400°F, and apply chromate post-plate treatment (F-15.01) on all surfaces except as noted in REPAIR 17-1, Figure 601.

27-55-67


REPAIR 17-1

Page 601

Mar 01/2006



COMPONENT MAINTENANCE MANUAL



1 NO FINISH ON INDICATED SURFACE. CADMIUM PLATE RUNOUT ON ADJACENT SURFACES SHALL NOT EXCEED 0.030 INCHES.

ITEM NUMBERS REFER TO IPL FIG. 1
ALL DIMENSIONS ARE IN INCHES

256A3144-1 Race Refinish
Figure 601

27-55-67

REPAIR 17-1
Page 602
Mar 01/2006



COMPONENT MAINTENANCE MANUAL

PLATE - REPAIR 18-1

256A3145-1

1. General

- A. This procedure has the data necessary to refinish the plate (630).
- B. Refer to the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
 - (1) Material: 9310 steel, 160-190 ksi

2. Plate Refinish

A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

B. Procedure (REPAIR 18-1, Figure 601)

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Apply cadmium plate (F-15.23) all over except as indicated in REPAIR 18-1, Figure 601.

27-55-67


REPAIR 18-1

Page 601

Mar 01/2006



COMPONENT MAINTENANCE MANUAL



1 NO FINISH ON INDICATED SURFACE.
 CADMIUM PLATE RUNOUT ON ADJACENT
 SURFACES SHALL NOT EXCEED 0.030
 INCHES.

ITEM NUMBERS REFER TO IPL FIG. 1
 ALL DIMENSIONS ARE IN INCHES

256A3145-1 Race Refinish
 Figure 601

27-55-67

REPAIR 18-1
 Page 602
 Mar 01/2006



COMPONENT MAINTENANCE MANUAL

COVER - REPAIR 19-1

256A3171-1

1. General

- A. This procedure has the data necessary to refinish the cover (470).
- B. Refer to the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
 - (1) Material: Aluminum alloy

2. Cover Refinish

- A. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-60-02	FINISHING MATERIALS

- C. Procedure (REPAIR 19-1, Figure 601)

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01. For finishing materials, refer to SOPM 20-60-02.


- (1) Boric acid-sulfuric acid anodize or chromic acid anodize (F-17.35) all over.
- (2) Apply primer, C00259 (F-20.02) to all indicated surfaces shown in REPAIR 19-1, Figure 601 . Overspray is allowed in holes.

27-55-67

REPAIR 19-1
Page 601
Mar 01/2006



COMPONENT MAINTENANCE MANUAL



1 APPLY PRIMER TO INDICATED SURFACES (F-20.02). OVERSPRAY IS ALLOWED IN HOLES.

ITEM NUMBERS REFER TO IPL FIG. 1

256A3171-1 Cover Refinish
Figure 601

27-55-67

REPAIR 19-1
Page 602
Mar 01/2006



COMPONENT MAINTENANCE MANUAL

BLOCK - REPAIR 20-1

256A3172-1

1. General

- A. This procedure has the data necessary to refinish the block (485).
- B. Refer to the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
 - (1) Material: 9310 steel, 160-190 ksi

2. Block Refinish

A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

B. Procedure (REPAIR 20-1, Figure 601)

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Apply cadmium plate (F-15.23) all over except as indicated in REPAIR 20-1, Figure 601.


27-55-67

REPAIR 20-1

Page 601

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



1 NO FINISH OR CADMIUM PLATE RUNOUT ON INDICATED SURFACE. CADMIUM PLATE RUNOUT ON ADJACENT SURFACES SHALL NOT EXCEED 0.030 INCHES.

ITEM NUMBERS REFER TO IPL FIG. 1
ALL DIMENSIONS ARE IN INCHES

256A3172-1 Block Refinish
Figure 601

27-55-67

REPAIR 20-1
Page 602
Mar 01/2006



COMPONENT MAINTENANCE MANUAL

BEARING RACE - REPAIR 21-1

256A3176-1

1. General

- A. This procedure has the data necessary to refinish the bearing race (600).
- B. Refer to the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
 - (1) Material: 52100 steel, 60-65 HRC

2. Bearing Race Refinish

A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

B. Procedure (REPAIR 21-1, Figure 601)

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Apply cadmium-titanium plate, bake 12 hours minimum at 350-400°F, and apply chromate post-plate treatment (F-15.01) on all surfaces except as noted in REPAIR 21-1, Figure 601.

27-55-67


REPAIR 21-1

Page 601

Mar 01/2006



COMPONENT MAINTENANCE MANUAL



1 NO FINISH OR CADMIUM PLATE
 RUNOUT ON INDICATED SURFACE.
 CADMIUM PLATE RUNOUT ON
 ADJACENT SURFACES SHALL NOT
 EXCEED 0.030 INCHES.

ITEM NUMBERS REFER TO IPL FIG. 1

256A3176-1 Bearing Race Refinish
 Figure 601

27-55-67

REPAIR 21-1
 Page 602
 Mar 01/2006



COMPONENT MAINTENANCE MANUAL

THRUST PLATE - REPAIR 22-1

256A3179-1

1. General

- A. This procedure has the data necessary to refinish the thrust plate (505).
- B. Refer to the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
 - (1) Material: 9310 steel, 160-190 ksi

2. Thrust Plate Refinish

A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

B. Procedure (REPAIR 22-1, Figure 601)

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Apply cadmium plate (F-15.23) all over except as indicated in REPAIR 22-1, Figure 601.


27-55-67

REPAIR 22-1

Page 601

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



1 NO FINISH OR CADMIUM PLATE
 RUNOUT ON INDICATED SURFACE.
 CADMIUM PLATE RUNOUT ON
 ADJACENT SURFACES SHALL NOT
 EXCEED 0.030 INCHES.

ITEM NUMBERS REFER TO IPL FIG. 1

256A3179-1 Thrust Plate Refinish
 Figure 601

27-55-67

REPAIR 22-1
 Page 602
 Mar 01/2006



COMPONENT MAINTENANCE MANUAL

CAP - REPAIR 23-1

256A3181-1

1. General

- A. This procedure has the data necessary to refinish the cap (25).
- B. Refer to the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
 - (1) Material: Aluminum alloy

2. Cap Refinish

- A. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-60-02	FINISHING MATERIALS

- C. Procedure

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For decoding table for Boeing finish codes, refer to SOPM 20-41-01. For finishing materials, refer to SOPM 20-60-02.

- (1) Boric acid-sulfuric acid anodize or chromic acid anodize (F-17.35) all over.
- (2) Apply primer, C00259 (F-20.02) as noted in REPAIR 23-1, Figure 601.


27-55-67

REPAIR 23-1

Page 601

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



1 NO PRIMER IN INDICATED AREAS

ITEM NUMBERS REFER TO IPL FIG. 1
ALL DIMENSIONS ARE IN INCHES.

256A3181-1 Cap Refinish
Figure 601

27-55-67

REPAIR 23-1
Page 602
Mar 01/2006



COMPONENT MAINTENANCE MANUAL

HOUSING - REPAIR 24-1

256A3187-2

1. General

- A. This procedure has the data necessary to refinish the housing (785).
- B. Refer to the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
 - (1) Material: Aluminum alloy

2. Housing Refinish

- A. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-60-02	FINISHING MATERIALS

- C. Procedure (REPAIR 24-1, Figure 601)

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01. For finishing materials, refer to SOPM 20-60-02.

- (1) Boric acid-sulfuric acid anodize or chromic acid anodize (F-17.35) all over.
- (2) Apply primer, C00259 (F-20.02) to all external surfaces and as noted in REPAIR 24-1, Figure 601.

27-55-67


REPAIR 24-1

Page 601

Mar 01/2006



COMPONENT MAINTENANCE MANUAL



- 1 APPLY PRIMER TO INDICATED SURFACES (F-20.02). NO RUNS, BEADS, OR SAGS ARE PERMITTED.
- 2 NO PRIMER ON INDICATED SURFACE.
- 3 APPLY PRIMER (F-20.02) TO HOLE OR COUNTERBORE USING THE FILL AND DRAIN METHOD.

ITEM NUMBERS REFER TO IPL FIG. 1
ALL DIMENSIONS ARE IN INCHES

256A3187-2 Housing Refinish
Figure 601

27-55-67

REPAIR 24-1
Page 602
Mar 01/2006



COMPONENT MAINTENANCE MANUAL

HOUSING - REPAIR 25-1

256A3188-2, -4, -6, -8

1. General

- A. This procedure has the data necessary to refinish the housing (575).
- B. Refer to the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
 - (1) Material: Aluminum alloy

2. Housing Refinish

- A. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-60-02	FINISHING MATERIALS

- C. Procedure (REPAIR 25-1, Figure 601)

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01. For finishing materials, refer to SOPM 20-60-02.

- (1) Boric acid-sulfuric acid anodize or chromic acid anodize (F-17.35) all over.
- (2) Apply primer, C00259 (F-20.02) to all external surfaces and as noted in REPAIR 25-1, Figure 601.

27-55-67



REPAIR 25-1

Page 601

Mar 01/2006



COMPONENT MAINTENANCE MANUAL



- 1 APPLY PRIMER (F-20.02) TO INDICATED COUNTERBORE USING THE FILL AND DRAIN METHOD.
- 2 APPLY PRIMER (F-20.02) TO INDICATED SURFACES. NO RUNS BEADS OR SAGS ARE PERMITTED.

- 3 NO PRIMER ON INDICATED SURFACE.
- 4 OVERSPRAY ALLOWED IN INDICATED HOLES.

ITEM NUMBERS REFER TO IPL FIG. 1
ALL DIMENSIONS ARE IN INCHES

256A3188-2,-4,-6,-8 Housing Refinish
Figure 601

27-55-67

REPAIR 25-1
Page 602
Mar 01/2006



COMPONENT MAINTENANCE MANUAL

YOKE ASSEMBLY - REPAIR 26-1

256A3191-1, -4

1. General

- A. This procedure has the data necessary to repair the yoke assembly (390).
- B. Refer to the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.

2. Bearing Replacement

- A. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
A00247	Sealant - Pressure And Environmental - Chromate Type	BMS 5-95

- B. References

Reference	Title
SOPM 20-50-03	BEARING AND BUSHING REPLACEMENT
SOPM 20-60-04	MISCELLANEOUS MATERIALS

- C. Procedure

NOTE: For miscellaneous materials, refer to SOPM 20-60-04.

- (1) Remove the bearing (395) from the yoke (400).
- (2) Install the replacement bearings with sealant, A00247 using the shrink-fit method (SOPM 20-50-03). Make sure the bearing flange contacts the lug.


27-55-67

REPAIR 26-1

Page 601

Jul 01/2008

COMPONENT MAINTENANCE MANUAL



ITEM NUMBERS REFER TO IPL FIG. 1
ALL DIMENSIONS ARE IN INCHES

256A3191-1,-4 Yoke Assembly Bearing Replacement
Figure 601

27-55-67

REPAIR 26-1
Page 602
Mar 01/2006



COMPONENT MAINTENANCE MANUAL

YOKE - REPAIR 26-2

256A3191-2, -5

1. General

- A. This procedure has the data necessary to repair and refinish the yoke (400).
- B. Refer to the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
 - (1) Material: PH13-8MO CRES, 200-220 ksi
 - (2) Shot peen: All surfaces with hard shot (RC55-65) except mask holes less than 0.50 diameter.
 - (a) Intensity 0.012A-0.17A
 - (b) Coverage 2.0

2. Yoke Repair

A. References

Reference	Title
SOPM 20-10-03	SHOT PEENING
SOPM 20-20-01	MAGNETIC PARTICLE INSPECTION

B. Procedure (REPAIR 26-2, Figure 601)

- (1) Machine within repair limits shown to remove defects.
- (2) Break all sharp edges (SOPM 20-10-03).
- (3) Shot peen all surfaces (SOPM 20-10-03).
- (4) Do a magnetic particle check (SOPM 20-20-01).
- (5) Refinish per refinish instructions.

3. Yoke Refinish

A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

B. Procedure (REPAIR 26-2, Figure 601)

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Passivate all over (F-17.25).


27-55-67

REPAIR 26-2

Page 601

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



ITEM NUMBERS REFER TO IPL FIG. 1
ALL DIMENSIONS ARE IN INCHES

256A3191-2,-5 Yoke Repair
Figure 601

27-55-67

REPAIR 26-2
Page 602
Mar 01/2006



COMPONENT MAINTENANCE MANUAL

BEARING - REPAIR 26-3

251N4105-1

1. General

- A. This procedure has the data necessary to refinish the bearing (395).
- B. Refer to the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
 - (1) Material: Aluminum nickel bronze

2. Bearing Refinish

A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

B. Procedure

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Apply cadmium plate, Type 2, Class 2 (F-15.06) all over, except bearing bore.

27-55-67

REPAIR 26-3

Page 601

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

COUPLING HALF - REPAIR 27-1

256A3741-1

1. General

- A. This procedure has the data necessary to refinish the coupling half (45).
- B. Refer to the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
 - (1) Material: 4330M steel, 180-200 ksi

2. Coupling Half Refinish

- A. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-60-02	FINISHING MATERIALS

- C. Procedure

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01. For finishing materials, refer to SOPM 20-60-02.

- (1) Apply cadmium plate 0.0003-0.0005 inch thick , Type 2, Class 2 (F-15.36) on all surfaces.
- (2) Apply primer, C00259 (F-20.02) as noted in REPAIR 27-1, Figure 601.

27-55-67


REPAIR 27-1

Page 601

Mar 01/2006



COMPONENT MAINTENANCE MANUAL



 APPLY PRIMER (F-20.02) TO THIS SURFACE.

ITEM NUMBERS REFER TO IPL FIG. 1

256A3741-1 Coupling Half Refinish
Figure 601

27-55-67

REPAIR 27-1
Page 602
Mar 01/2006



COMPONENT MAINTENANCE MANUAL

SEAL RETAINER - REPAIR 28-1

256W3244-1

1. General

- A. This procedure has the data necessary to refinish the seal retainer (155).
- B. Refer to the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
 - (1) Material: Aluminum alloy

2. Seal Retainer Refinish

- A. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-60-02	FINISHING MATERIALS

- C. Procedure

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01. For finishing materials, refer to SOPM 20-60-02.

- (1) Boric acid-sulfuric acid anodize or chromic acid anodize (F-17.31) all over.
- (2) Apply primer, C00259 (F-20.02) except as noted in REPAIR 28-1, Figure 601.


27-55-67

REPAIR 28-1

Page 601

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



1 NO PRIMER ON INDICATED SURFACES.

ITEM NUMBERS REFER TO IPL FIG. 1
ALL DIMENSIONS ARE IN INCHES

256W3244-1 Seal Retainer Refinish
Figure 601

27-55-67

REPAIR 28-1
Page 602
Mar 01/2006



COMPONENT MAINTENANCE MANUAL

ASSEMBLY

1. General

- A. This procedure contains the data necessary to assemble the transmission assembly. There are two parts:
- (1) Transmission Assembly
 - (2) Storage
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.

2. Transmission Assembly

A. Tools/Equipment

NOTE: Equivalent substitutes may be used.

Reference	Description
SPL-5384	Wrench - Coupling Sleeve Flap Actuation (Part #: C27041-1, Supplier: 81205)
SPL-5385	Seal Installation Equipment, TE Flap Drive (Part #: C27043-16, Supplier: 81205)
SPL-5391	TE Flap Transmission, AFT U-Joint and BallScrew Test Equipment (Part #: C27072-92, Supplier: 81205) (Part #: C27072-93, Supplier: 81205)
SPL-5447	Bearing Width Measurement Equipment (Part #: J27057-22, Supplier: 81205)

B. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I
C00913	Compound - Corrosion Inhibiting Material, Nondrying Resin Mix	BMS 3-27
D00467	Fluid - Landing Gear Shock Strut	BMS3-32, Type II
D00590	Fluid - Flap Drive System - Brayco 795	
D00633	Grease - Aircraft General Purpose	BMS3-33
G50347	Lockwire - Nickel-copper, 0.032 inch diameter	NASM20995N~ C32

27-55-67

ASSEMBLY

Page 701

Nov 01/2008



COMPONENT MAINTENANCE MANUAL

C. References

Reference	Title
CMM 27-55-82	FLAP ACTUATION LOW SETTING TORQUE BRAKE ASSEMBLY
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-50-01	BOLT AND NUT INSTALLATION
SOPM 20-50-02	INSTALLATION OF SAFETYING DEVICES
SOPM 20-50-03	BEARING AND BUSHING REPLACEMENT
SOPM 20-50-06	INSTALLATION OF O-RINGS AND TEFLON SEALS
SOPM 20-50-07	LUBRICATION
SOPM 20-50-12	APPLICATION OF ADHESIVES
SOPM 20-60-02	FINISHING MATERIALS
SOPM 20-60-03	LUBRICANTS
SOPM 20-60-04	MISCELLANEOUS MATERIALS

D. General

NOTE: For lubricants, refer to SOPM 20-60-03

- (1) To assemble the transmission, it is necessary to check the backlash in the transmission assembly test equipment, SPL-5391 .
- (2) Lubricate bearings, and other parts as indicated, with fluid, D00467 or Brayco 795 fluid, D00590, unless shown differently. Brayco 795 fluid, D00590 is preferred for future use.
- (3) Install all bearings per SOPM 20-50-03.

E. Procedure

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For decoding table for Boeing finish codes, refer to SOPM 20-41-01. For bolt and nut installation, refer to SOPM 20-50-01. For finishing material, refer to SOPM 20-60-02. For lubricants, refer to SOPM 20-60-03. For miscellaneous materials, refer to SOPM 20-60-04.

- (1) Calculate the shim (660 thru 675) thickness S1 as shown in ASSEMBLY, Figure 701, with the bearing (680), gear (655), and housing assembly (765) measurements as follows:

NOTE: Use the minimum number of shims necessary. Actual shim thickness is to the nearest 0.0015 inch.

- (a) Measure the bearing (680) width, using bearing width Measurement Equipment, SPL-5447, from the inner race shoulder on one side to the outer race shoulder on the opposite side, with the end play removed. Remove the end play by applying a 5-15 pound axial load across the bearing. This is dimension W1.

NOTE: This dimension must be measured to the nearest 0.001 inch.

- (b) Measure the width of the gear (655) as shown in ASSEMBLY, Figure 701. This is dimension E.

NOTE: This dimension must be measured to the nearest 0.001 inch.

27-55-67

ASSEMBLY

Page 702

Jul 01/2007



COMPONENT MAINTENANCE MANUAL

- (c) Record the dimension C of the housing assembly (765) as shown in ASSEMBLY, Figure 701.
- (2) Lubricate the pinion (650), gear (655), spacer (685), lockwasher (690), and nut (695) with fluid, D00467 or Brayco 795 fluid, D00590, as applicable.
- (3) Install the nut (695), lockwasher (690), spacer (685), bearing (680), shims (660 thru 675), gear (655), and pinion (650) in the housing assembly (765).
- (4) Tighten the nut (695) to 310-370 lb-in. above run-on torque.

NOTE: Do not crimp the lockwasher (690) until all assembly checks are completed.

- (5) After tightening the nut (695), make sure the witness mark on the lockwasher (690) flange is aligned with the key slot in the pinion (650). If not aligned, replace the lockwasher.
- (6) Calculate the shim (330 thru 345) thickness S2 and S3 as shown in ASSEMBLY, Figure 701, with the bearing (350), retainer (325), and housing assembly (765) measurements as follows:

NOTE: S2 and S3 shim dimensions are measured at different locations for the Position No. 1 and Position No. 8 assemblies.

Use the minimum number of shims necessary. Actual shim thickness is to the nearest 0.0015 inch.

- (a) For Position No. 1 assemblies (256A3110-X, where X is an odd number): Measure the bearing (350) width, using bearing width Measurement Equipment, SPL-5447, adjacent to the cap (315), from the inner race shoulder on one side to the outer race shoulder on the opposite side. Measure the width to the nearest 0.001 inch with the end play removed. Remove end play by applying a 5-15 pound axial load across the bearing. This is dimension W2.
 - (b) For Position No. 8 assemblies (256A3110-Y, where Y is an even number): Measure the bearing (350) width, using bearing width Measurement Equipment, SPL-5447, adjacent to the torque brake (300A), from the inner race shoulder on one side to the outer race shoulder on the opposite side. Measure the width to the nearest 0.001 inch with the end play removed. Remove end play by applying a 5-15 pound axial load across the bearing. This is dimension W2.
 - (c) Measure the shim (330 thru 345) thickness S3 as required to obtain 0.003-0.005 axial backlash of pinion assembly (360) with a 10-20 pound axial load.
 - (d) Measure the distance from the retainer (325) flange to the shoulder. This is dimension F.
- NOTE:** This dimension must be measured to the nearest 0.001 inch.
- (e) Record the dimension D of the housing assembly (765) as shown in ASSEMBLY, Figure 701.
- (7) Install the shaft and pinion assembly (360) in the housing assembly (765).
 - (a) Install the pinion assembly (360), bearings (350), shims (330 thru 345), retainers (325), and bolts (320) in the housing assembly (765).

NOTE: Do not apply compound, C00913 to bolts (320) or faying surfaces of retainers (325) until all assembly checks and adjustments have been completed.

- (8) Measure the backlash and verify tooth contact pattern of the assembled gears.

27-55-67

ASSEMBLY

Page 703

Mar 01/2007



COMPONENT MAINTENANCE MANUAL

- (a) Install the housing assembly (765) in the transmission assembly test equipment, SPL-5391 , which will support the pinion (650) on center for the backlash test.

NOTE: The backlash is the total clearance from one gear position to a different position. A torque is applied to the gear in one direction. This is the first position of the gear. The torque is then applied in the opposite direction. This is the second position of the gear.

- (b) Apply a 5-15 pound axial load to the pinion (650), and a 25-35 pound load to the pinion assembly (360) in the direction shown in ASSEMBLY, Figure 701, with the transmission assembly test equipment, SPL-5391 .

NOTE: Back up the retainers (325) with the torque brake (295) and cap (315) or with a tool that provides equivalent stiffness.

- (c) Apply a torque wrench to prevent movement of the pinion (650) and pinion assembly (360).
 (d) Apply a torque of 10-15 lb-in. to the gear (655).
 (e) Measure the backlash of the gear (655) at three locations approximately 120 degrees apart at the gear pitch diameter, and verify tooth contact pattern.

NOTE: The backlash must be 0.004-0.006 inch at the gear pitch diameter.

- (f) If backlash is not 0.004-.006 inch, and tooth contact pattern is not acceptable, adjust the shim thickness S1 and/or S2.

NOTE: To decrease the backlash, increase the shim thickness. S1 and/or S2. To increase the backlash, decrease the shim thickness S1 and/or S2.

- (g) Measure the backlash and verify tooth contact pattern again.
 (h) Adjust the shim thickness S1 and/or S2 again as necessary.
 (i) Remove all marking compound from the pinion (650) using a rag and solvent.
- (9) Crimp the lockwasher (690) into the nut (695).
 (a) Install the packing (355) in the housing assembly (765) with fluid, D00467 or Brayco 795 fluid, D00590, as applicable.
 (b) Make sure the witness mark on the lockwasher (690) flange is aligned with the key slot in the pinion (650). If not aligned, replace the lockwasher.
 (c) Crimp the lockwasher (690) to deform it into the two slots of the nut (695) 180 degrees apart.
- (10) Reinstall retainers (325) in the housing assembly (765).

WARNING: BMS 3-27 CORROSION INHIBITING COMPOUND CONTAINS SOLVENTS, CHROMATES, AND A SMALL AMOUNT OF BOUND ASBESTOS. CONSULT THE APPLICABLE SAFETY STANDARDS FOR APPROVED HANDLING PROCEDURES.

CAUTION: BMS 3-27 COMPOUND IS USED ONLY IN STATIC JOINTS WHERE GREASE CANNOT BE APPLIED. BMS 3-27 COMPOUND IN DYNAMIC JOINTS WILL NOT LET THEM MOVE FREELY.

- (a) Apply a thin film of compound, C00913 to the faying surface of the retainer (325) flange between outer profile and approximately 0.05 inch from fillet radius.
 (b) Coat entire shank and threads of the bolts (320) with compound, C00913 except bolt tips.
 (c) Install retainers (325) in the housing assembly (765) with the bolts (320). Remove excess compound, C00913 after assembly.

27-55-67

ASSEMBLY
 Page 704
 Jul 01/2007



COMPONENT MAINTENANCE MANUAL

- (11) Lubricate the pawls (590), spacers (595), springs (585), and pins (580) with fluid, D00467 or Brayco 795 fluid, D00590, as applicable, and install in the housing assembly (765).
- (12) Lubricate the packing (560), bearing race (600), and ratchet plate (610) with fluid, D00467 or Brayco 795 fluid, D00590, as applicable, and install with bearing (605) and bearing (635) in the cover assembly (565). Make sure the ratchet plate (610) has adequate support to maintain engagement with the pawls (590), and bearing race (600) engages the pin in the cover assembly (565).
- (13) Install the packing (710) in the retainer (715) with fluid, D00467 or Brayco 795 fluid, D00590, as applicable.
- (14) Install the seal (750) and spacer (755) in the retainer (715).
 - (a) Lubricate the retainer (715) bore with fluid, D00467 or Brayco 795 fluid, D00590, as applicable.
 - (b) Install the seal (750) in the retainer (715). Use the Seal Installation Tool, SPL-5385 to apply even pressure over the full circumference of the seal rim, as near to the seal outside diameter as possible. Make sure the seal is installed flush to 0.01 inch above seal cavity.

NOTE: Make sure to protect the seal lips during assembly.
 - (c) Apply a large quantity of fluid, D00467 or Brayco 795 fluid, D00590 (Assemblies 256A3110-3 thru -6) or grease, D00633 (Assemblies 256A3110-7, -8) to the seal (750) lips.
 - (d) Install the spacer (755) in the retainer (715).
- (15) Install the retainer (715) in the housing assembly (765).

WARNING: BMS 3-27 CORROSION INHIBITING COMPOUND CONTAINS SOLVENTS, CHROMATES, AND A SMALL AMOUNT OF BOUND ASBESTOS. CONSULT THE APPLICABLE SAFETY STANDARDS FOR APPROVED HANDLING PROCEDURES.

CAUTION: BMS 3-27 COMPOUND IS USED ONLY IN STATIC JOINTS WHERE GREASE CANNOT BE APPLIED. BMS 3-27 COMPOUND IN DYNAMIC JOINTS WILL NOT LET THEM MOVE FREELY.

- (a) Apply a thin film of compound, C00913 to the faying surface of the retainer (715) flange between outer profile and approximately 0.05 inch from the fillet radius.
 - (b) Coat entire shank and threads of the bolts (700) with compound, C00913 except bolt tips.
 - (c) Apply fluid, D00467 or Brayco 795 fluid, D00590 as applicable, to the housing assembly (765) bore.
 - (d) Install the bearing (760), retainer (715), washers (705), and bolts (700) in the housing assembly (765).
 - (e) Remove excess compound, C00913 after assembly.
- (16) Lubricate the race (645) with fluid, D00467 or Brayco 795 fluid, D00590, as applicable, and install on the shaft assembly (720).
 - (17) Put grease, D00633 in the space between the seal (750) and retainer (715) as shown in ASSEMBLY, Figure 701.
 - (18) Install the shaft assembly (720) into the housing assembly (765). Temporarily support the shaft assembly to maintain a 0.16 inch minimum gap between the outer face of the retainer (715) and the shoulder of the shaft assembly (720).

27-55-67

ASSEMBLY

Page 705

Mar 01/2007



COMPONENT MAINTENANCE MANUAL

- (19) Lubricate the gear (640), plate (630), and roller assembly (615) with fluid, D00467 or Brayco 795 fluid, D00590, as applicable, and install on the shaft assembly (720). Make sure the roller assembly (615) is installed as shown in ASSEMBLY, Figure 701.
- (20) Install threaded end of the shaft assembly (720) in the cover assembly (565).
- (21) Assemble the cover assembly (565) and the housing assembly (765) together.

WARNING: BMS 3-27 CORROSION INHIBITING COMPOUND CONTAINS SOLVENTS, CHROMATES, AND A SMALL AMOUNT OF BOUND ASBESTOS. CONSULT THE APPLICABLE SAFETY STANDARDS FOR APPROVED HANDLING PROCEDURES.

CAUTION: BMS 3-27 COMPOUND IS USED ONLY IN STATIC JOINTS WHERE GREASE CANNOT BE APPLIED. BMS 3-27 COMPOUND IN DYNAMIC JOINTS WILL NOT LET THEM MOVE FREELY.

- (a) Apply a thin film of compound, C00913 to faying surfaces of the cover assembly (565) and housing assembly (765) between outer profiles and approximately 0.05 inch from the packing (560) groove in the cover assembly (565).
 - (b) Coat entire shank and threads of the bolts (535, 540) with compound, C00913 except bolt tips.
 - (c) Mate the cover assembly (565) and housing assembly (765) together and install the bolts (535, 540), washers (545, 550), and nuts (555).
 - (d) Remove excess compound, C00913 after assembly.
- (22) Calculate the shim (515 thru 530) thickness S4 as shown in ASSEMBLY, Figure 701.

NOTE: Use the minimum number of shims necessary. Initial S4 shim thickness should be 0.061 inch.

- (a) Measure the shim (515 thru 530) thickness S4 as required to obtain 0.005-0.012 axial backlash of the shaft assembly (720) with a \pm 40-50 pound axial load.
- (23) Lubricate the thrust plate (505), roller assembly (490), block (485), lockwasher (480), and nut (475) with fluid, D00467 or Brayco 795 fluid, D00590 and install with the shims (515 thru 530), and bearing (510), in the housing assembly (565). Make sure the roller assembly (490) is oriented as shown in ASSEMBLY, Figure 701.
- (24) Remove temporary support from the shaft assembly (720).
- (25) Tighten the nut (475) to 1600-1900 lb-in. above run-on torque.

NOTE: Do not crimp the lockwasher (480) until all assembly checks are completed.

- (26) After tightening the nut (475), make sure the witness mark on the lockwasher (480) flange is aligned with the key slot in the shaft assembly (720). If not aligned, replace the lockwasher.
- (27) Measure the axial backlash of the shaft assembly (720).

NOTE: The axial backlash is the distance between the axial position of a shaft when a force is applied in one direction to the axial position of the same shaft when the same force is applied in the opposite direction.

- (a) Apply an axial load of 40-50 pounds to the shaft assembly (720) in each direction.
- (b) Measure the axial movement of the shaft assembly (720) after application of the axial loads.
- (c) Adjust the shim(s) (515 thru 530) thickness S4 to obtain an axial backlash of 0.005-0.012 inch.

27-55-67

ASSEMBLY

Page 706

Mar 01/2007



COMPONENT MAINTENANCE MANUAL

- (d) Verify axial backlash by rotating the shaft assembly (720).
 - (e) If backlash is not 0.005-0.012 inch, adjust the shim thickness S4.
 - (f) Measure the backlash again.
 - (g) Adjust the shim thickness S4 again as necessary.
- (28) Crimp the lockwasher (480) into the nut (475).
- (a) Make sure the witness mark on the lockwasher (480) flange is still aligned with the key slot in the shaft assembly (720). If not aligned, replace the lockwasher.
 - (b) Crimp the lockwasher (480) to deform it into two slots of the nut (475) 180 degrees apart.
- (29) Install the cover (470) on the cover assembly (565).
- (a) Install the packing (465) on the cover (470) with fluid, D00467 or Brayco 795 fluid, D00590, as applicable.

WARNING: BMS 3-27 CORROSION INHIBITING COMPOUND CONTAINS SOLVENTS, CHROMATES, AND A SMALL AMOUNT OF BOUND ASBESTOS. CONSULT THE APPLICABLE SAFETY STANDARDS FOR APPROVED HANDLING PROCEDURES.

CAUTION: BMS 3-27 COMPOUND IS USED ONLY IN STATIC JOINTS WHERE GREASE CANNOT BE APPLIED. BMS 3-27 COMPOUND IN DYNAMIC JOINTS WILL NOT LET THEM MOVE FREELY.

- (b) Apply a thin film of compound, C00913 to the faying surface of the cover (470) flange between outer profile and approximately 0.05 inch from fillet radius.
 - (c) Coat entire shank and threads of the bolts (145) with compound, C00913, except bolt tips.
 - (d) Lubricate the cover assembly (565) bore with fluid, D00467 or Brayco 795 fluid, D00590 as applicable.
 - (e) Mate the cover (470) with the cover assembly (565) and install the bolts (145) and washers (150).
 - (f) Remove excess compound, C00913 after assembly.
- (30) Install the cap (315) on the housing assembly (765).
- (a) Install the packing (290) in the cap (315) with fluid, D00467 or Brayco 795 fluid, D00590, as applicable.

WARNING: BMS 3-27 CORROSION INHIBITING COMPOUND CONTAINS SOLVENTS, CHROMATES, AND A SMALL AMOUNT OF BOUND ASBESTOS. CONSULT THE APPLICABLE SAFETY STANDARDS FOR APPROVED HANDLING PROCEDURES.

CAUTION: BMS 3-27 COMPOUND IS USED ONLY IN STATIC JOINTS WHERE GREASE CANNOT BE APPLIED. BMS 3-27 COMPOUND IN DYNAMIC JOINTS WILL NOT LET THEM MOVE FREELY.

- (b) Apply a thin film of compound, C00913 to the faying surface of the cap (315) flange between outer profile and approximately 0.05 inch from fillet radius.
- (c) Coat entire shank and threads of the bolts (305) with compound, C00913, except bolt tips.
- (d) Lubricate the retainer (325) bore with fluid, D00467 or Brayco 795 fluid, D00590, as applicable.

27-55-67

ASSEMBLY
Page 707
Mar 01/2007



COMPONENT MAINTENANCE MANUAL

- (e) Make the cap (315) with the housing assembly (765) and install the bolts (305) and washers (310).
 - (f) Remove excess compound, C00913 after assembly.
- (31) Install the torque brake assembly (295A, 300A) on the housing assembly (765).

NOTE: Refer to CMM 27-55-82 for torque brake assembly instructions.

- (a) Install the packing (290) in the torque brake assembly with fluid, D00467 or Brayco 795 fluid, D00590, as applicable.

WARNING: BMS 3-27 CORROSION INHIBITING COMPOUND CONTAINS SOLVENTS, CHROMATES, AND A SMALL AMOUNT OF BOUND ASBESTOS. CONSULT THE APPLICABLE SAFETY STANDARDS FOR APPROVED HANDLING PROCEDURES.

CAUTION: BMS 3-27 COMPOUND IS USED ONLY IN STATIC JOINTS WHERE GREASE CANNOT BE APPLIED. BMS 3-27 COMPOUND IN DYNAMIC JOINTS WILL NOT LET THEM MOVE FREELY.

- (b) Apply a thin film of compound, C00913 to the faying surface of the torque brake assembly housing flange between outer profile and approximately 0.05 inch from fillet radius.
 - (c) Coat entire shank and threads of the bolts (280) with compound, C00913, except bolt tips.
 - (d) Lubricate the retainer (325) bore with fluid, D00467 or Brayco 795 fluid, D00590, as applicable.
 - (e) Mate the torque brake assembly (295A, 300A) with the housing assembly (765), and install the bolts (280) and washers (285).
 - (f) Remove excess compound, C00913 after assembly.
- (32) Calculate the shim (260 thru 275) thickness S5 as shown in ASSEMBLY, Figure 701, with the torque brake assembly (295A, 300A) and the housing assembly (230) measurements as follows:

NOTE: Use the minimum number of shims necessary. Actual shim thickness is to the nearest 0.0015 inch.

- (a) Measure the actual distance from the torque brake assembly housing flange to the 256A3168 stator housing (Refer to CMM 27-55-82, item 155). This distance is measured with a 25-36 pound load applied to the stator housing in the direction shown. This is dimension W3.

NOTE: This dimension must be measured to the nearest 0.001 inch.

- (b) Measure the distance from the housing assembly (230) flange to the flange shoulder. This is dimension G.

NOTE: This dimension must be measured to the nearest 0.001 inch.

- (33) Install the housing assembly (230) on the torque brake assembly (295).
- (a) Install the packing (225) in the housing assembly (230) base with fluid, D00467 or Brayco 795 fluid, D00590, as applicable.

WARNING: BMS 3-27 CORROSION INHIBITING COMPOUND CONTAINS SOLVENTS, CHROMATES, AND A SMALL AMOUNT OF BOUND ASBESTOS. CONSULT THE APPLICABLE SAFETY STANDARDS FOR APPROVED HANDLING PROCEDURES.

27-55-67

ASSEMBLY

Page 708

Mar 01/2007



COMPONENT MAINTENANCE MANUAL

(WARNING PRECEDES)

CAUTION: BMS 3-27 COMPOUND IS USED ONLY IN STATIC JOINTS WHERE GREASE CANNOT BE APPLIED. BMS 3-27 COMPOUND IN DYNAMIC JOINTS WILL NOT LET THEM MOVE FREELY.

- (b) Apply a thin film of compound, C00913 to the faying surface of the housing assembly (230) flange between outer profile and approximately 0.05 inch from the fillet radius.
 - (c) Coat entire shank and threads of the bolts (215) with compound, C00913, except bolt tips.
 - (d) Lubricate the housing assembly (230) bore with fluid, D00467 or Brayco 795 fluid, D00590, as applicable.
 - (e) Mate the housing assembly (230) with the torque brake assembly (295A, 300A), and install the bolts (215) and washers (220).
 - (f) Remove excess compound, C00913 after assembly.
- (34) Calculate the shim (190 thru 205) thickness S6 as shown in ASSEMBLY, Figure 701, with the bearing (210) measurements as follows:
- (a) Measure the bearing (210) width, using bearing width Measurement Equipment, SPL-5447, from the inner race to the outer race shoulder on the opposite side of the bearing with end play removed. Remove end play by applying a 5-15 pound axial load across the bearing. This is dimension W4.
- NOTE:** This dimension must be measured to the nearest 0.001 inch.
- (b) Record the dimension A on the housing assembly (230) as shown in ASSEMBLY, Figure 701.
- (35) Lubricate the bevel gear (185) with fluid, D00467 or Brayco 795 fluid, D00590, as applicable, and install with the bearing (210), and shims (190 thru 205) in the housing assembly (230).
- (36) Install the packing (70A), seal (90), and spacer (115) in the retainer (75).
- (a) Install the packing (70A) in the retainer (75) with fluid, D00467 or Brayco 795 fluid, D00590, as applicable.
 - (b) Lubricate the retainer (75) bore with fluid, D00467 or Brayco 795 fluid, D00590, as applicable.
 - (c) Install the seal (90) in the retainer (75). Use the Seal Installation Tool, SPL-5385 to apply even pressure over the full circumference of the seal rim, as near to the seal outside diameter as possible. Make sure the seal is installed flush to 0.01 inch above seal cavity.
- NOTE:** Make sure to protect the seal lips during assembly.
- (d) Apply a large quantity of fluid, D00467 or Brayco 795 fluid, D00590 (Assemblies 256A3110-3 thru -6) or grease, D00633 (Assemblies 256A3110-7, -8) to the seal (90) lips.
 - (e) Install the spacer (115) in the retainer (75).
- (37) Calculate the shim (125 thru 140) thickness S7 as shown in ASSEMBLY, Figure 701, with the retainer (75), spacer (115), bearing (120), and housing assembly (230), measurements as follows:

27-55-67

ASSEMBLY

Page 709

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

- (a) Measure the bearing (120) width, using bearing width Measurement Equipment, SPL-5447, from the inner race to the outer race shoulder on the opposite side of the bearing with end play removed. Remove end play by applying a 5-15 pound axial load across the bearing. This is dimension W5.

NOTE: This dimension must be measured to the nearest 0.001 inch.

- (b) Record the dimension B on the housing assembly (230) as shown in ASSEMBLY, Figure 701.
- (c) Measure the dimension H of the retainer (75) and the spacer (115) as shown in ASSEMBLY, Figure 701.
- (38) Install the packings (95, 100) in the rings (105, 110) with fluid, D00467 or Brayco 795 fluid, D00590, as applicable.
- (39) Lubricate the pinion assembly (160) with fluid, D00467 or Brayco 795 fluid, D00590, as applicable, and install in the housing assembly (230) with shims (125 thru 140), bearings (120, 142), and rings (105, 110).
- (40) Lubricate the housing assembly (230) bore with fluid, D00467 or Brayco 795 fluid, D00590, as applicable, and install the retainer (75) in the housing assembly (230) with the bolts (60) and washers (65).

NOTE: Do not apply compound, C00913 to bolts (60) or faying surfaces of retainer (75) until all assembly checks and adjustments have been completed.

- (41) Install the washer (59) and the nut (57) on the pinion assembly (160). Apply a wrench to hold the pinion assembly (160) and tighten the nut to 600-720 lb-in. above run-on torque.
- (42) Measure the backlash and verify tooth contact pattern of the bevel gear (185) and pinion assembly (160).

NOTE: The backlash is the total clearance from one gear position to a different position. A torque is applied to the gear in one direction. This is the first position of the gear. The torque is then applied in the opposite direction. This is the second position of the gear.

- (a) Apply a 5-15 pound axial load to the bevel gear (185) in the direction shown in ASSEMBLY, Figure 701, with the transmission assembly test equipment, SPL-5391.
- (b) Apply a torque wrench to prevent movement of the gear (185).
- (c) Apply a torque of 10-15 lb-in. to the pinion assembly (160).
- (d) Measure the backlash of the pinion assembly (160) at three locations approximately 120 degrees apart at the gear pitch diameter, and make sure of tooth contact pattern.

NOTE: The backlash must be 0.004-0.006 inch at the gear pitch diameter.

- (e) If backlash is not 0.004 to 0.006 inch, and tooth contact pattern is not acceptable, adjust shim thickness S6 and/or S7.

NOTE: To decrease the backlash, increase the shim thickness. To increase backlash, decrease the shim thickness.

- (f) Measure the backlash again and verify tooth contact pattern.
- (g) Adjust the shim thickness S6 and/or S7 as necessary.
- (43) Reinstall the retainer (75) in the housing assembly (230).

27-55-67

ASSEMBLY

Page 710

Jul 01/2007



COMPONENT MAINTENANCE MANUAL

WARNING: BMS 3-27 CORROSION INHIBITING COMPOUND CONTAINS SOLVENTS, CHROMATES, AND A SMALL AMOUNT OF BOUND ASBESTOS. CONSULT THE APPLICABLE SAFETY STANDARDS FOR APPROVED HANDLING PROCEDURES.

CAUTION: BMS 3-27 COMPOUND IS USED ONLY IN STATIC JOINTS WHERE GREASE CANNOT BE APPLIED. BMS 3-27 COMPOUND IN DYNAMIC JOINTS WILL NOT LET THEM MOVE FREELY.

- (a) Apply a thin film of compound, C00913 to the faying surface of the retainer (75) flange between the outer profile and approximately 0.05 inch from the fillet radius.
 - (b) Coat the entire shank and threads of the bolts (60) with compound, C00913, except bolt tips.
 - (c) Mate the retainer (75) with the housing assembly (230) and install the bolts (60) and washers (65).
 - (d) Remove excess compound, C00913 after assembly.
- (44) Put grease, D00633 in the space above the seal (90) and between the seal ring (105) and retainer (75) as shown in ASSEMBLY, Figure 701.
- (45) Apply grease, D00633 to faying surface of the nut (57) and install with washer (59) on the pinion assembly (160). Apply a wrench to hold the pinion assembly (160) and tighten the nut to 600-720 lb-in. above run-on torque.
- (46) Install the seal (85) in the housing assembly (230).
- (a) Lubricate the housing assembly (230) bore with fluid, D00467 or Brayco 795 fluid, D00590, as applicable.
 - (b) Install the seal (85) in the housing assembly (230). Use the Seal Installation Tool, SPL-5385 to apply even pressure over the full circumference of the seal rim, as near to the seal outside diameter as possible. Make sure the seal is installed to a depth of 0.17-0.18 inch.
- NOTE:** Make sure to protect the seal lips during assembly.
- (c) Apply a large quantity of fluid, D00467 or Brayco 795 fluid, D00590 (Assemblies 256A3110-3 thru -6) or grease, D00633 (Assemblies 256A3110-7, -8) to the seal (85) lips.

WARNING: BMS 3-27 CORROSION INHIBITING COMPOUND CONTAINS SOLVENTS, CHROMATES, AND A SMALL AMOUNT OF BOUND ASBESTOS. CONSULT THE APPLICABLE SAFETY STANDARDS FOR APPROVED HANDLING PROCEDURES.

CAUTION: BMS 3-27 COMPOUND IS USED ONLY IN STATIC JOINTS WHERE GREASE CANNOT BE APPLIED. BMS 3-27 COMPOUND IN DYNAMIC JOINTS WILL NOT LET THEM MOVE FREELY.

- (47) Coat the entire shank and threads of the bolts (445) with compound, C00913, except bolt tips.
- (48) Apply a thin film of compound, C00913 to the faying surface of the retainer (155) flange between the outer profile and approximately 0.05 inch from the fillet radius. Mate the retainer (155) with housing assembly (230) and install the bolts (445) and washers (455).
- (49) Put grease, D00633 in the space above the seal (85) and between the seal ring (110) and retainer (135) as shown in ASSEMBLY, Figure 701.
- (50) Lubricate the sleeve (40) and coupling (45) with grease, D00633 (SOPM 20-50-07) and install with the seal (50) and shield (55A) on the pinion assembly (160).
- (51) Install the packing (35A) on the bolt (30) with grease, D00633 (SOPM 20-50-06).

27-55-67

ASSEMBLY

Page 711

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

- (52) Apply grease, D00633 to faying surface of the bolt (30) and install in the pinion assembly (160). Use the coupling sleeve wrench, SPL-5384 to hold the coupling sleeve (40), and tighten the bolt to 600-720 lb-in. above run-on torque.
- (53) Install the cap (25) on the housing assembly (230).
 - (a) Install the packing (20) on the cap (25) with fluid, D00467 or Brayco 795 fluid, D00590, as applicable.

WARNING: BMS 3-27 CORROSION INHIBITING COMPOUND CONTAINS SOLVENTS, CHROMATES, AND A SMALL AMOUNT OF BOUND ASBESTOS. CONSULT THE APPLICABLE SAFETY STANDARDS FOR APPROVED HANDLING PROCEDURES.

CAUTION: BMS 3-27 COMPOUND IS USED ONLY IN STATIC JOINTS WHERE GREASE CANNOT BE APPLIED. BMS 3-27 COMPOUND IN DYNAMIC JOINTS WILL NOT LET THEM MOVE FREELY.

- (b) Coat entire shank and threads of the bolts (10) with compound, C00913, except bolt tips.
 - (c) Lubricate the housing assembly (230) bore with fluid, D00467 or Brayco 795 fluid, D00590, as applicable.
 - (d) Apply a thin film of compound, C00913 to the faying surface of the cap (25) flange between the outer profile and approximately 0.05 inch from the fillet radius. Mate the cap (25) with housing assembly (230) and install the bolts (10) and washers (15).
- (54) Install the yoke assembly (390).
 - (a) Install the spacer (435) and the shaft (425) in the lug end of the shaft assembly (720).
 - (b) Lubricate the nut (385) with grease, D00633.
 - (c) Install the yoke assembly (390) with the shaft (405), adapter (415) and nut (385).
 - (d) Tighten the nut (385) to 440-550 lb-in. above run-on torque.
 - (e) Secure the U-joint assembly to prevent damage.
- (55) Fill the transmission assembly with fluid, D00467 or Brayco 795 fluid, D00590.
 - (a) Put the transmission in the position shown in ASSEMBLY, Figure 702, and fill the unit with fluid to the filler hole.
 - (b) Install the plug and bleeder (175).
 - (c) Set the transmission so that the output shaft points up.
 - (d) Turn the output shaft to remove air caught by the fluid. Operate the trip indicator plunger, if installed.
 - (e) Put the transmission back in the initial position. Remove the plug and bleeder, and fill the unit with fluid to the filler hole.
- (56) Install the plug and bleeder (175) in the housing assembly (230).
 - (a) Install the packing (180A) on the plug and bleeder with fluid, D00467 or Brayco 795 fluid, D00590, as applicable.
 - (b) Install the plug and bleeder in the housing assembly (230) and tighten to 110-130 lb-in. above run-on torque.
- (57) Repair damaged surfaces as necessary on the caps (25, 315), housings (230, 765), retainers (75, 325, 715), covers (470, 565), and torque brake (295) and apply one coat of primer, C00259 to bare surfaces except as noted in ASSEMBLY, Figure 701.

27-55-67

ASSEMBLY
Page 712
Jul 01/2008



COMPONENT MAINTENANCE MANUAL

- (58) Install the markers (790A, 800, 805) with Type 89 or Type 70 adhesive (SOPM 20-50-12). Make sure that all of the marker faying surface has adhesive coverage.
- (59) Install the lockwire, G50347 using the double-twist method (SOPM 20-50-02) as shown in ASSEMBLY, Figure 701, for the bolts (60, 215, 280, 305, 540, 700) and plugs (175).
- (60) Lubricate the fittings (380) in the shafts (405, 425) with grease, D00633(SOPM 20-50-07).
- (61) Do a test of the unit as specified in the transmission assembly test procedures (TESTING AND FAULT ISOLATION).

3. Storage

A. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
D00467	Fluid - Landing Gear Shock Strut	BMS3-32, Type II
D00590	Fluid - Flap Drive System - Brayco 795	

B. References

Reference	Title
SOPM 20-60-03	LUBRICANTS

C. Procedure

NOTE: For lubricants. refer to SOPM 20-60-03.

- (1) Make sure the unit is filled to the correct level with fluid, D00467 or Brayco 795 fluid, D00590, as applicable.
- (2) Cover the top vent of the transmission assembly with masking tape after assembly to prevent introduction of solvents in the unit.
- (3) Use standard industry practices and information contained to store the transmission assembly.

27-55-67


ASSEMBLY

Page 713

Mar 01/2006



COMPONENT MAINTENANCE MANUAL




TRANSMISSION ASSEMBLY NO. 1
256A3110-5 SHOWN
256A3110-3,-7 SIMILAR

Assembly Details
Figure 701 (Sheet 1 of 12)

27-55-67

ASSEMBLY
Page 714
Mar 01/2006

COMPONENT MAINTENANCE MANUAL




Assembly Details
Figure 701 (Sheet 2 of 12)

27-55-67

ASSEMBLY
Page 715
Mar 01/2006

COMPONENT MAINTENANCE MANUAL




TRANSMISSION ASSEMBLY NO. 8
256A3110-6 SHOWN
256A3110-4,-8 SIMILAR

Assembly Details
Figure 701 (Sheet 3 of 12)

27-55-67

ASSEMBLY
Page 716
Mar 01/2006

COMPONENT MAINTENANCE MANUAL



Assembly Details
Figure 701 (Sheet 4 of 12)


27-55-67

ASSEMBLY

Page 717

Mar 01/2006

COMPONENT MAINTENANCE MANUAL




Assembly Details
Figure 701 (Sheet 5 of 12)

27-55-67

ASSEMBLY
Page 718
Mar 01/2006

COMPONENT MAINTENANCE MANUAL




D-D

Assembly Details
Figure 701 (Sheet 6 of 12)

27-55-67

ASSEMBLY
Page 719
Mar 01/2006

COMPONENT MAINTENANCE MANUAL




Assembly Details
Figure 701 (Sheet 7 of 12)

27-55-67

ASSEMBLY
Page 720
Mar 01/2006

COMPONENT MAINTENANCE MANUAL



Assembly Details
Figure 701 (Sheet 8 of 12)

27-55-67



ASSEMBLY

Page 721

Mar 01/2006



COMPONENT MAINTENANCE MANUAL





Assembly Details
Figure 701 (Sheet 9 of 12)

27-55-67

ASSEMBLY
Page 722
Mar 01/2006

COMPONENT MAINTENANCE MANUAL



Assembly Details
Figure 701 (Sheet 10 of 12)

27-55-67


ASSEMBLY

Page 723

Mar 01/2006



COMPONENT MAINTENANCE MANUAL



- 1 OMIT PRIMER FROM THIS SURFACE
- 2 FILL CAVITY WITH BMS 3-33 SEALANT
- 3 OMIT PRIMER FROM HOLE THROUGH HOUSING ASSEMBLY (765) AND COVER ASSEMBLY (565)
- 4 DIRECTION OF AXIAL LOAD APPLIED TO PINION (650) FOR HYPOID/PINION BACKLASH TEST
- 5 DIRECTION OF AXIAL LOAD APPLIED TO BEVEL GEAR (185) FOR BEVEL GEAR BACKLASH TEST

- 6 DIRECTION OF LOAD APPLIED TO 256A3168 STATOR HOUSING TO DETERMINE DIMENSION W3
- 7 DIRECTION OF AXIAL LOAD APPLIED TO SHAFT AND PINION ASSEMBLY (360) FOR HYPOID/PINION BACKLASH TEST

Assembly Details
Figure 701 (Sheet 11 of 12)

27-55-67

ASSEMBLY
Page 724
Mar 01/2006



COMPONENT MAINTENANCE MANUAL

SHIM THICKNESS CALCULATION

SHIM THICKNESS $S1^* = C - W1 - 0.491 - E$

SHIM THICKNESS $S2^* = D - F - W2 - 2.135$

SHIM THICKNESS $S3 =$ AS REQUIRED TO OBTAIN 0.003-0.005 AXIAL BACKLASH OF SHAFT (360) WITH A 5-15 LB AXIAL LOAD.

SHIM THICKNESS $S4 =$ AS REQUIRED TO OBTAIN 0.005-0.012 AXIAL BACKLASH OF SHAFT ASSEMBLY (720) WITH A 40-50 LB AXIAL LOAD.

SHIM THICKNESS $S5^* = W3 - G - 0.005$

SHIM THICKNESS $S6^* = A - W4 - 1.377$

SHIM THICKNESS $S7^* = B - H - W5 - 1.450$

WHERE:

- A = DIMENSION A ENGRAVED ON THE HOUSING ASSEMBLY (230)
- B = DIMENSION B ENGRAVED ON THE HOUSING ASSEMBLY (230)
- C** = DIMENSION C MARKED ON THE HOUSING ASSEMBLY (765)
- D** = DIMENSION D MARKED ON THE HOUSING ASSEMBLY (765)
- E = DIMENSION E IS THE WIDTH OF THE GEAR (655)
- F** = DIMENSION F IS THE DISTANCE FROM FLANGE TO THE SHOULDER ON THE RETAINER (325) TO THE NEAREST 0.001
- G = DIMENSION G IS THE DISTANCE FROM FLANGE TO THE SHOULDER ON THE HOUSING ASSEMBLY (230) TO THE NEAREST 0.001
- H = DIMENSION H IS THE DISTANCE FROM THE FLANGE ON THE RETAINER (75) TO THE SPACER (115) TO THE NEAREST 0.001 INCH
- W1** = DIMENSION W1 IS THE BEARING (680) WIDTH INNER RACE TO OUTER RACE
- W2** = DIMENSION W2 IS THE BEARING (350) WIDTH INNER RACE TO OUTER RACE
- W3 = DIMENSION W3 IS THE ACTUAL DISTANCE FROM THE TORQUE BRAKE HOUSING FLANGE TO THE 256A3168 STATOR HOUSING (CMM 27-55-82, ITEM 155) MEASURED TO THE NEAREST 0.001 INCH. THIS DISTANCE IS MEASURED WITH A 25-35 LB LOAD APPLIED TO THE 256A3168 STATOR HOUSING IN THE DIRECTION SHOWN IN FIGURE 701.
- W4 = DIMENSION W4 IS THE BEARING (210) WIDTH INNER RACE TO OUTER RACE
- W5 = DIMENSION W5 IS THE BEARING (120) WIDTH INNER RACE TO OUTER RACE

* SHIM THICKNESS TO BE WITHIN ± 0.0015 OF CALCULATED VALUE

** DIMENSIONS MEASURED AT DIFFERENT LOCATIONS FOR 256A3110-1 AND -2 ASSEMBLIES

Assembly Details
Figure 701 (Sheet 12 of 12)


27-55-67

ASSEMBLY

Page 725

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



Transmission Oil Fill Procedure
Figure 702

27-55-67


ASSEMBLY

Page 726

Mar 01/2006


COMPONENT MAINTENANCE MANUAL

FITS AND CLEARANCES



Fits and Clearances
Figure 801 (Sheet 1 of 4)





COMPONENT MAINTENANCE MANUAL



Fits and Clearances
Figure 801 (Sheet 2 of 4)



COMPONENT MAINTENANCE MANUAL


REF LETTER	REF IPL	DESIGN DIMENSION*				SERVICE WEAR LIMIT*		
	FIG. 1, MATING ITEM NO.	DIMENSION		ASSEMBLY CLEARANCE 		DIMENSION		MAXIMUM CLEARANCE
		MIN	MAX	MIN	MAX	MIN	MAX	
[A]	ID 740	1.4375	1.4383	0.0014	-0.0001			
	OD 730	1.4384	1.4389					
[B]	ID 760	TBD	TBD	TBD	TBD			
	OD 645	1.9481	1.9485					
[C]	ID 510	TBD	TBD	TBD	TBD			
	OD 485	1.7316	1.7320					
[D]	ID 680	1.1807	1.1811	0.0093	0.0111			
	OD 655	1.1700	1.1900					
[E]	ID 635	0.6690	0.6693	0.0005	0.0001			
	OD 650	0.6692	0.6695					
[F]	ID 350	0.9839	9.9843	0.0000	0.0007			
	OD 360	0.9836	0.9839					
[G]	ID 360 		0.5563					
	OD 295A, 300A  	0.7836						
[H]	ID 142	0.9839	0.9843	0.0001	0.0008			
	OD 160	0.9835	0.9840					
[I]	ID 120	1.1807	1.1811	0.0001	0.0008			
	OD 160	1.1803	1.1808					
[J]	ID 210	1.1807	1.1811	0.0008	-0.0001			
	OD 185	1.1812	1.1815					
[K]	ID 230	1.8506	1.8513	-0.0002	0.0014			
	OD 142	1.8499	1.8504					

Fits and Clearances
Figure 801 (Sheet 3 of 4)


27-55-67
FITS AND CLEARANCES
Page 803
Mar 01/2006



COMPONENT MAINTENANCE MANUAL

REF LETTER	REF IPL	DESIGN DIMENSION*				SERVICE WEAR LIMIT*		
	FIG. 1, MATING ITEM NO.	DIMENSION		ASSEMBLY CLEARANCE 		DIMENSION		MAXIMUM CLEARANCE
		MIN	MAX	MIN	MAX	MIN	MAX	
[L]	ID 240	2.1656	2.1664	-0.0002	0.0015			
	OD 145	2.1649	2.1654					
[M]	ID 240	2.1656	2.1664	-0.0002	0.0015			
	OD 100	2.1649	2.1654					

* ALL DIMENSIONS ARE IN INCHES

 NEGATIVE NUMBERS SHOW INTERFERENCE FIT

 OUTPUT SHAFT OF TORQUE BRAKE ASSEMBLY

 MEASUREMENT BETWEEN TWO 0.0720 DIA PINS

 MEASUREMENT OVER TWO 0.0800 DIA PINS

 DELETED

 DELETED

Fits and Clearances
Figure 801 (Sheet 4 of 4)

27-55-67
FITS AND CLEARANCES
Page 804
Mar 01/2006



COMPONENT MAINTENANCE MANUAL

REF IPL		NAME	TORQUE*	
FIG. NO.	ITEM NO.		POUND-INCHES	POUND-FEET
1	30	Bolt	600-720	
1	175	Plug and Bleeder	110-130	
1	385	Nut	440-550	
1	475	Nut	1600-1900	
1	695,695A	Nut	310-370	
1	695B	Nut	800-950	
1	57	Nut	600-720	

* REFER TO SOPM 20-50-01 FOR TORQUE VALUES OF STANDARD FASTENERS.

Torque Table
Figure 802

27-55-67

FITS AND CLEARANCES

Page 805

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

SPECIAL TOOLS, FIXTURES, AND EQUIPMENT

1. General

A. This section lists the special tools, fixtures, and equipment necessary for maintenance.

NOTE: Equivalent substitutes may be used.

Special Tools

Reference	Description	Part Number	Supplier
SPL-4720	Test Equipment - Leakage Test	J27054-1	81205
SPL-5384	Wrench - Coupling Sleeve Flap Actuation	C27041-1	81205
SPL-5385	Seal Installation Equipment, TE Flap Drive	C27043-16	81205
SPL-5391	TE Flap Transmission, AFT U-Joint and BallScrew Test Equipment	C27072-92	81205
		C27072-93	81205
SPL-5447	Bearing Width Measurement Equipment	J27057-22	81205

Tool Supplier Information

CAGE Code	Supplier Name	Supplier Address
81205	THE BOEING COMPANY	17930 INTERNATIONAL BLVD. SOUTH SEATAC, WA 98188-4321 Telephone: 206-662-6650 Facsimile: 206-662-7145

27-55-67

SPECIAL TOOLS, FIXTURES, AND EQUIPMENT

Page 901

Mar 01/2009



COMPONENT MAINTENANCE MANUAL

ILLUSTRATED PARTS LIST

1. Introduction

- A. The Illustrated Parts List (IPL) contains an illustration and a list of component parts you can repair or replace. The Illustrated Parts Catalog (IPC) shows how to use the Boeing part number system.
- B. This shows how parts are related: The relation of each item to its next higher assembly (NHA) is shown in the NOMENCLATURE column. Use the indenture system that follows:

1	2	3	4	5	6	7
.	Assembly					
.	Attaching parts for assembly					
.	.	Detail parts for assembly				
.	.	Subassembly				
.	.	Attaching parts for subassembly				
.	.	.	Detail parts for subassembly			
.	.	.	Sub-subassembly			
.	.	.	Attaching parts for subassembly			
.	.	.	.	Details parts for sub-subassembly		
						Detail Installation Parts (Included only if installation parts may be sent to the shop as part of assembly)

- C. Each top assembly is given one use code letter (A, B, C, etc.) in the USAGE CODE column. All subsequent component parts in the list can have one or more of the use code letters to show effectivity to top assemblies. A component part without a use code applies to all top assemblies.
- D. An alphabetical letter is added after the item number for optional parts, parts changed by a Service Bulletin, configuration differences (except left-handed and right-handed parts), last engineering releases, and parts added between item numbers in a sequence. The alphabetical letter will not be shown on the illustration for equivalent parts of the same part number.
- E. Color-coded parts are identified with a single digit alpha following the dash number or with "SP" suffix. If the "SP" suffix is used, it represents consolidation of all color codes applicable for a given usage which are not separately listed. Orders for color-coded parts should include the registry number of the airplane for which the parts are ordered.
- F. If a part number is 15 characters long but will not fit in the part number column, the part number will be displayed with a "~" at the end of the line and will be continued on the next line. The "~" denotes that the part number continues on the next line.
- G. Parts changed by a Service Bulletin are shown by PRE SB XXXX and POST SB XXXX added to the NOMENCLATURE column.
- (1) When a new top assembly is added by a Service Bulletin, PRE SB XXXX and POST SB XXXX will be added at the top assembly level only. The configuration differences at the detail part level are shown by use code letters.
- (2) When the top assembly part number is not changed by the Service Bulletin, PRE SB XXXX and POST SB XXXX will be added at the detail level.
- H. Interchangeable Parts

27-55-67

ILLUSTRATED PARTS LIST

Page 1001

Nov 01/2008



COMPONENT MAINTENANCE MANUAL

Optional (OPT)	The part is optional to and interchangeable with other parts that have the same item number.
Replaces, Replaced by and not interchangeable with (REPLACES, REPLACED BY AND NOT INTCHG/W)	The part replaces and is not interchangeable with the initial part.
Replaces, Replaced by (REPLACES, REPLACED BY)	The part replaces and is interchangeable with, or is an alternative to, the initial part.

VENDOR CODES

Code	Name
0FKM1	ALEMITE CORP 167 ROWLAND DR JOHNSON CITY, TENNESSEE 37601
15653	ALCOA GLOBAL FASTENERS INC DIV KAYNAR PRODUCTS 800 S STATE COLLEGE BLVD FULLERTON, CALIFORNIA 92831-3001 FORMERLY VK6405 MICRODOT AEROSP LTD; FORMERLY KAYNAR TECH FORMERLY FAIRCHILD FASTENERS KAYNAR DIV
21335	TIMKEN US CORPORATION DIV FAFNIR 336 MECHANIC STREET LEBANON, NH 03766-0267 FORMERLY FAFNIR BRG AND TEXTRON INC FAFNIR DIV IN NEW BRITAIN, CONNECTICUT ; FORMERLY TORRINGTON CO THE SPECIAL PRODUCTS DIV SUB OF THE INGERSOLL-RAND CO V8D210 FORMERLY TORRINGTON CO FAFNIR BEARING DIV IN TORRINGTON, CT
56878	SPS TECHNOLOGIES INC AEROSPACE AND INDUSTRIAL PRODUCTS DIV 301 HIGHLAND AVE JENKINTOWN, PENNSYLVANIA 19046 FORMERLY STANDARD PRESSED STEEL FORMERLY IN SALT LAKE, UTAH
60380	TORRINGTON CO BEARINGS DIV SUBSIDIARY OF INGERSOLL-RAND CORP 59 FIELD STREET PO BOX 1008 TORRINGTON, CONNECTICUT 06790-1008 FORMERLY TORRINGTON BEARING COMPANY

27-55-67

ILLUSTRATED PARTS LIST

Page 1002

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

Code	Name
72962	HARVARD INDUSTRIES INC 3 WERNER WAY SUITE 210 LEBANON, NEW JERSEY 08833 FORMERLY ESNA V7A079 FORMERLY ELASTIC STOP NUT IN UNION, NJ
78118	SPLIT BALL BEARING DIV OF MPB CORP HIGHWAY 4 LEBANON, NEW HAMPSHIRE 03766-7301
80648	Replaced: [V80648] TORRINGTON CO SEE V80657 Replaced: [V80657] TORRINGTON CO THE BEARINGS DIV SEE V60380 by Code: Name and Address below 60380: TORRINGTON CO BEARINGS DIV SUBSIDIARY OF INGERSOLL- RAND CORP 59 FIELD STREET PO BOX 1008 TORRINGTON, CONNECTICUT 06790-1008 FORMERLY TORRINGTON BEARING COMPANY
83086	NEW HAMPSHIRE BALL BEARING, INC HITECH DIVISION 172 JAFFREY ROAD PETERBOROUGH, NEW HAMPSHIRE 03458
91251	FREUDENBERG-NOK GENERAL PARTNERSHIP PLEASANT STREET PO BOX B BRISTOL, NEW HAMPSHIRE 03222-0501
92215	FAIRCHILD IND INC FAIRCHILD AEROSPACE FASTENER DIV 3010 W LOMITA BLVD TORRANCE, CALIFORNIA 90505-5102 FORMERLY VOI-SHAN IN CULVER CITY, CALIF
97393	SHUR-LOK CORPORATION 2541 WHITE ROAD PO BOX 19584 IRVINE, CALIFORNIA 92623-9584 FORMERLY SHUR LOK CORP VB0060 FORMERLY IN SANTA ANA, CALIFORNIA 92714

27-55-67

ILLUSTRATED PARTS LIST

Page 1003

Jul 01/2006

**COMPONENT MAINTENANCE MANUAL**

Code	Name
97928	Replaced: [V97928] SEE V17446 HUCK INTL by Code: Name and Address below 17446: HUCK INTL INC AEROSPACE FASTENER DIV 900 WATSON CENTER ROAD CARSON, CALIFORNIA 90745-4201 FORMERLY V32134 REXNORD INC; FORMERLY V97928 HUCK INTL
U1068	DOWTY SEALS LTD ASHCHURCH, TEWKESBURY GLOS GL20 8JS ENGLAND

27-55-67

ILLUSTRATED PARTS LIST

Page 1004

Jul 01/2006



COMPONENT MAINTENANCE MANUAL

NUMERICAL INDEX

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
1002423606800		1	90	1
		1	90A	1
1002423607100		1	85	1
		1	85A	1
1002423615800		1	750	1
		1	750A	1
102LH9074-10		1	57	1
102LH9074-12		1	695B	1
1728B		1	380	4
251N4103-1		1	435	1
251N4105-1		1	395	2
		1	730	2
251N4117-1		1	590	2
251N4117-3		1	590A	2
251N4119-1		1	585	2
251N4120-1		1	610	1
251N4135-1		1	405	1
251N4146-1		1	595	4
251N4147-1		1	615	1
251N4149-1		1	425	1
251N4150-1		1	415	1
251N4151-1		1	625	1
256A3110-3		1	1B	RF
256A3110-4		1	5A	RF
256A3110-5		1	1C	RF
256A3110-6		1	5B	RF
256A3110-7		1	1D	RF
256A3110-8		1	5C	RF
256A3121-1		1	230	1
256A3121-2		1	235	1
256A3121-3		1	250	1
256A3121-4		1	255	1
256A3123-1		1	160	1
256A3123-2		1	170	1

27-55-67

ILLUSTRATED PARTS LIST

Page 1005

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
256A3124-1		1	185	1
256A3125-1		1	75	1
256A3125-2		1	80	1
256A3133-1		1	715	1
256A3133-2		1	715A	1
256A3134-1		1	325	2
256A3135-1		1	315	1
256A3136-1		1	720	1
		1	720B	1
256A3136-2		1	740	1
256A3136-4		1	720A	1
256A3136-5		1	740A	1
256A3137-1		1	640	1
256A3138-1		1	650	1
256A3138-2		1	650A	1
256A3139-1		1	655	1
256A3141-1		1	370	1
256A3142-1		1	375	1
256A3143-1		1	360	1
256A3144-1		1	645	1
256A3145-1		1	630	1
256A3147-1		1	580	2
256A3148-1		1	515	AR
256A3148-10		1	335	AR
256A3148-11		1	340	AR
256A3148-12		1	345	AR
256A3148-13		1	260	AR
256A3148-14		1	265	AR
256A3148-15		1	270	AR
256A3148-16		1	275	AR
256A3148-2		1	520	AR
256A3148-25		1	125	AR
		1	190	AR
		1	660	AR
256A3148-26		1	130	AR

27-55-67

ILLUSTRATED PARTS LIST

Page 1006

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
		1	195	AR
		1	665	AR
256A3148-27		1	135	AR
		1	200	AR
		1	670	AR
256A3148-28		1	140	AR
		1	205	AR
		1	675	AR
256A3148-3		1	525	AR
256A3148-4		1	530	AR
256A3148-9		1	330	AR
256A3149-1		1	365	1
256A3150-3		1	295A	1
256A3150-4		1	300A	1
256A3150-5		1	295B	1
256A3150-6		1	300B	1
256A3150-7		1	295C	1
256A3150-8		1	300C	1
256A3171-1		1	470	1
256A3172-1		1	485	1
256A3173-1		1	490	1
256A3173-2		1	500	1
256A3175-1		1	480	1
256A3176-1		1	600	1
256A3179-1		1	505	1
256A3181-1		1	25	1
256A3182-1		1	55A	1
256A3183-1		1	110	1
		1	110B	1
256A3183-10		1	110A	1
256A3183-3		1	105	1
		1	105B	1
256A3183-7		1	105A	1
256A3185-1		1	115	1
256A3185-4		1	685	1

27-55-67

ILLUSTRATED PARTS LIST

Page 1007

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
256A3187-1		1	765	1
256A3187-2		1	785	1
256A3188-1		1	565	1
256A3188-2		1	575	1
256A3188-3		1	565A	1
256A3188-4		1	575A	1
256A3188-5		1	565B	1
256A3188-6		1	575B	1
256A3188-7		1	565C	1
256A3188-8		1	575C	1
256A3191-1		1	390	1
		1	390B	1
256A3191-2		1	400	1
256A3191-4		1	390A	1
256A3191-5		1	400A	1
256A3195-13		1	805	1
256A3195-31		1	790A	1
256A3195-32		1	795A	1
256A3195-39		1	790B	1
256A3195-40		1	795B	1
256A3195-49		1	790C	1
256A3195-50		1	795C	1
256A3195-9		1	800	1
256A3741-1		1	45	1
256A3743-1		1	50	1
256A3744-1		1	30	1
256A3745-1		1	40	1
256W3051-12		1	755	1
256W3052-2		1	690	1
256W3054-1		1	572	1
256W3244-1		1	155	1
		1	155A	1
256W3244-2		1	155B	1
52BA029565		1	495A	17
69233SB8D		1	385	1

27-55-67

ILLUSTRATED PARTS LIST

Page 1008

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
69235-1018CD		1	57	1
69235-1216CD		1	695B	1
700-853-2272-99		1	90	1
		1	90A	1
700-857-2272-99		1	85	1
		1	85A	1
700-868-8862-99		1	750	1
		1	750A	1
82631-1216		1	695A	1
82631-2012		1	475A	1
AN814-4DL		1	175	1
BACB10BA17C		1	635	1
BACB10BA25C		1	142	1
		1	350	2
BACB10BA30C		1	120	1
		1	210	1
		1	680	1
BACB30LE3HK3		1	60	3
BACB30LE3K3		1	60B	3
BACB30LE5HK6		1	215	4
		1	280	4
BACB30LE5K6		1	215A	4
		1	280A	4
BACB30MR3HK3		1	60A	3
BACB30MR3K3		1	60C	3
BACB30MR4HK3		1	700	4
BACB30MR4HK8		1	540	6
BACB30MR4K16		1	535	2
BACB30MR4K3		1	700A	4
BACB30MR4K8		1	540A	6
BACB30NM5HK4		1	305	4
BACB30NM5K4		1	305A	4
BACB30NT3K2		1	10	4
		1	145	4
		1	445	3

27-55-67

ILLUSTRATED PARTS LIST

Page 1009

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
BACB30VF3K1		1	320	4
BACN10HY8M		1	385	1
BACN10JC10CD		1	57	1
BACN10JC12CD		1	695B	1
BACN10RF12		1	695A	1
BACN10RF12C		1	695	1
BACN10RF20		1	475A	1
BACN10RF20C		1	475	1
BACW10BN4AC		1	545	8
		1	705	4
BACW10BN4AP		1	550	2
BACW10BP10DP		1	59	1
BACW10BP3CD		1	15	4
		1	65	3
		1	150	4
		1	455	3
BACW10BP5CD		1	220	4
		1	285	4
		1	310	4
BMN4122CPD8-10		1	57	1
BMN4122CPD8-12		1	695B	1
BR9080-12		1	695A	1
BR9080-20		1	475A	1
H51650-10BAC		1	57	1
H51650-12BAC		1	695B	1
HW29872-8		1	385	1
M25988-1-110		1	180A	1
M25988-1-116		1	100	1
M25988-1-127		1	290	2
M25988-1-136		1	20	1
		1	355	2
M25988-1-140		1	70A	1
M25988-1-150		1	225	1
M25988-1-151		1	710	1
M25988-1-153		1	465	1

27-55-67

ILLUSTRATED PARTS LIST

Page 1010

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
M25988-1-204		1	35A	1
M25988-1-213		1	95	1
M25988-1-259		1	560	1
MS21209F1-15P		1	240	15
		1	570	4
		1	770	4
MS21209F4-15P		1	775	10
MS21209F5-15P		1	780	8
MS21209F7-10P		1	245	1
MS21209F8-10P		1	165	2
NAS1805-4L		1	555	2
NTH3258		1	605	1
QBR62813		1	620	15
RM7X10C1		1	495	17
RMLH9073-8		1	385	1
RUSZ008-174		1	510	1
RUSZ009-119		1	760	1
S256W410-11		1	85	1
		1	85A	1
S256W410-20		1	750	1
		1	750A	1
S256W410-8		1	90	1
		1	90A	1
SL2822-12		1	695A	1
SL2822-12C		1	695	1
SL2822-20		1	475A	1
SL2822-20C		1	475	1
TLN1001W38		1	385	1
		1	385	1
TLN1001WD38		1	385	1
		1	385	1
TPUB1908-10		1	510A	1
TPUB1909-8		1	760A	1
TRJD3258		1	600A	1


27-55-67

ILLUSTRATED PARTS LIST

Page 1011

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



Trailing Edge Flap Transmission Assembly No. 1 and 8
IPL Figure 1 (Sheet 1 of 12)


27-55-67

ILLUSTRATED PARTS LIST

Page 1012

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



A

Trailing Edge Flap Transmission Assembly No. 1 and 8
IPL Figure 1 (Sheet 2 of 12)


27-55-67

ILLUSTRATED PARTS LIST

Page 1013

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



B

Trailing Edge Flap Transmission Assembly No. 1 and 8
IPL Figure 1 (Sheet 3 of 12)


27-55-67

ILLUSTRATED PARTS LIST

Page 1014

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



Trailing Edge Flap Transmission Assembly No. 1 and 8
IPL Figure 1 (Sheet 4 of 12)


27-55-67

ILLUSTRATED PARTS LIST

Page 1015

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



Trailing Edge Flap Transmission Assembly No. 1 and 8
IPL Figure 1 (Sheet 5 of 12)


27-55-67

ILLUSTRATED PARTS LIST

Page 1016

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



Trailing Edge Flap Transmission Assembly No. 1 and 8
IPL Figure 1 (Sheet 6 of 12)


27-55-67

ILLUSTRATED PARTS LIST

Page 1017

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



Trailing Edge Flap Transmission Assembly No. 1 and 8
IPL Figure 1 (Sheet 7 of 12)


27-55-67

ILLUSTRATED PARTS LIST

Page 1018

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



Trailing Edge Flap Transmission Assembly No. 1 and 8
IPL Figure 1 (Sheet 8 of 12)


27-55-67

ILLUSTRATED PARTS LIST

Page 1019

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



Trailing Edge Flap Transmission Assembly No. 1 and 8
IPL Figure 1 (Sheet 9 of 12)



27-55-67

ILLUSTRATED PARTS LIST

Page 1020

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



Trailing Edge Flap Transmission Assembly No. 1 and 8
IPL Figure 1 (Sheet 10 of 12)




27-55-67

ILLUSTRATED PARTS LIST

Page 1021


Mar 01/2006

COMPONENT MAINTENANCE MANUAL




Trailing Edge Flap Transmission Assembly No. 1 and 8
IPL Figure 1 (Sheet 11 of 12)


COMPONENT MAINTENANCE MANUAL




Q




R



S



T



U

Trailing Edge Flap Transmission Assembly No. 1 and 8
IPL Figure 1 (Sheet 12 of 12)

27-55-67

ILLUSTRATED PARTS LIST

Page 1023

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
-110B	256A3183-1		.	R	I	N	G			E, F	1
115	256A3185-1		.	S	P	A	C	E	R		1
120	BACB10BA30C		.	B	E	A	R	I	N		1
125	256A3148-25		.	S	H	I	M				AR
130	256A3148-26		.	S	H	I	M				AR
135	256A3148-27		.	S	H	I	M				AR
140	256A3148-28		.	S	H	I	M				AR
142	BACB10BA25C		.	B	E	A	R	I	N		1
145	BACB30NT3K2		.	B	O	L	T				4
150	BACW10BP3CD		.	W	A	S	H	E	R		4
155	256W3244-1		.	R	E	T	A	I	N	A	1
-155A	256W3244-1		.	R	E	T	A	I	N	A	1
-155B	256W3244-2		.	R	E	T	A	I	N	A	1
160	256A3123-1		.	P	I	N	I	O	N	A	1
165	MS21209F8-10P		.	I	N	S	E	R	T		2
170	256A3123-2		.	P	I	N	I	O	N		1
175	AN814-4DL		.	P	L	U	G	A	N	D	1
180	M25988-1-10										
180A	M25988-1-110		.	P	A	C	K	I	N	G	1
185	256A3124-1		.	G	E	A	R	-	B	E	1
190	256A3148-25		.	S	H	I	M				AR
195	256A3148-26		.	S	H	I	M				AR
200	256A3148-27		.	S	H	I	M				AR
205	256A3148-28		.	S	H	I	M				AR
210	BACB10BA30C		.	B	E	A	R	I	N		1
215	BACB30LE5HK6		.	B	O	L	T			A-D	4
-215A	BACB30LE5K6		.	B	O	L	T			E, F	4
220	BACW10BP5CD		.	W	A	S	H	E	R		4
225	M25988-1-150		.	P	A	C	K	I	N	G	1

-Item not Illustrated

27-55-67

ILLUSTRATED PARTS LIST

Page 1026

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
230	256A3121-1		.							A, C, E	1
-235	256A3121-2		.							B, D, F	1
240	MS21209F1-15P		.	.							15
245	MS21209F7-10P		.	.							1
250	256A3121-3		.	.						A, C	1
-255	256A3121-4		.	.						B, D	1
260	256A3148-13		.								AR
265	256A3148-14		.								AR
270	256A3148-15		.								AR
275	256A3148-16		.								AR
280	BACB30LE5HK6		.							A-D	4
-280A	BACB30LE5K6		.							E, F	4
285	BACW10BP5CD		.								4
290	M25988-1-127		.								2
295	256A3150-1										DELETED
295A	256A3150-3		.							A	1
											(REFER TO CMM 27-55-82)
-295B	256A3150-5		.							C	1
											(REFER TO CMM 27-55-82)
-295C	256A3150-7		.							E	1
											(REFER TO CMM 27-55-82)
-300	256A3150-2										DELETED
-300A	256A3150-4		.							B	1
											(REFER TO CMM 27-55-82)
-300B	256A3150-6		.							D	1
											(REFER TO CMM 27-55-82)
-300C	256A3150-8		.							F	1
											(REFER TO CMM 27-55-82)
305	BACB30NM5HK4		.							A-D	4
-305A	BACB30NM5K4		.							E, F	4
310	BACW10BP5CD		.								4
315	256A3135-1		.								1
320	BACB30VF3K1		.								4

-Item not Illustrated

27-55-67

ILLUSTRATED PARTS LIST

Page 1027

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
325	256A3134-1		.								2
330	256A3148-9		.								AR
335	256A3148-10		.								AR
340	256A3148-11		.								AR
345	256A3148-12		.								AR
350	BACB10BA25C		.								2
355	M25988-1-136		.								2
360	256A3143-1		.								1
365	256A3149-1		.	.							1
370	256A3141-1		.	.							1
375	256A3142-1		.	.							1
380	1728B		.								4
385	HW29872-8		.								1
390	256A3191-1		.							A-D	1
-390A	256A3191-4		.							E, F	1
-390B	256A3191-1		.							E, F	1
395	251N4105-1		.	.							2
400	256A3191-2		.	.							1
-400A	256A3191-5		.	.						E, F	1
405	251N4135-1		.								1
410	251N4135-1										DELETED
415	251N4150-1		.								1
420	251N4150-1										DELETED

-Item not Illustrated

27-55-67

ILLUSTRATED PARTS LIST

Page 1028

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
425	251N4149-1								. SHAFT-INTERNAL		1
430	251N4149-1								DELETED		
435	251N4103-1								. SPACER		1
440	251N4103-1								DELETED		
445	BACB30NT3K2								. BOLT		3
450	BACB30NT3K2								DELETED		
455	BACW10BP3CD								. WASHER		3
460	BACW10BP3CD								DELETED		
465	M25988-1-153								. PACKING		1
470	256A3171-1								. COVER		1
475	SL2822-20C								. NUT (V97393) (SPEC BACN10RF20C) (OPT ITEM 475A)		1
-475A	SL2822-20								. NUT (V97393) (SPEC BACN10RF20) (OPT 82631-2012 (V56878)) (OPT BR9080-20 (V72962)) (OPT ITEM 475)		1
480	256A3175-1								. LOCKWASHER		1
485	256A3172-1								. BLOCK-TNSN		1
490	256A3173-1								. ROLLER ASSY-SKEWED		1
495	RM7X10C1								. . ROLLER (V78118) (OPT ITEM 495A)		17
-495A	52BA029565								. . ROLLER (V21335) (OPT ITEM 495)		17
500	256A3173-2								. . RETAINER		1
505	256A3179-1								. PLATE		1
510	RUSZ008-174								. BEARING-ROLLER (V78118) (OPT ITEM 510A)		1
-510A	TPUB1908-10								. BEARING-ROLLER (V83086) (OPT ITEM 510)		1

-Item not Illustrated

27-55-67

ILLUSTRATED PARTS LIST

Page 1029

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
515	256A3148-1		.	SHIM							AR
520	256A3148-2		.	SHIM							AR
525	256A3148-3		.	SHIM							AR
530	256A3148-4		.	SHIM							AR
535	BACB30MR4K16		.	BOLT							2
540	BACB30MR4HK8		.	BOLT					A-D		6
-540A	BACB30MR4K8		.	BOLT					E, F		6
545	BACW10BN4AC		.	WASHER							8
550	BACW10BN4AP		.	WASHER							2
555	NAS1805-4L		.	NUT							2
560	M25988-1-259		.	PACKING							1
565	256A3188-1		.	COVER ASSY (OPT ITEM 565A)					A-D		1
-565A	256A3188-3		.	COVER ASSY (OPT ITEM 565)					A-D		1
-565B	256A3188-5		.	COVER ASSY (OPT ITEM 565C)					E, F		1
-565C	256A3188-7		.	COVER ASSY (OPT ITEM 565B)					E, F		1
570	MS21209F1-15P		.	INSERT							4
572	256W3054-1		.	PIN-DOWEL							1
575	256A3188-2		.	HOUSING (USED ON ITEM 565)					A-D		1
-575A	256A3188-4		.	HOUSING (USED ON ITEM 565A)					A-D		1
-575B	256A3188-6		.	HOUSING (USED ON ITEM 565C)					E, F		1
-575C	256A3188-8		.	HOUSING (USED ON ITEM 565B)					E, F		1
580	256A3147-1		.	PIN-PAWL							2
585	251N4119-1		.	SPRING							2
590	251N4117-1		.	PAWL					A-D		2
-590A	251N4117-3		.	PAWL					E, F		2
595	251N4146-1		.	SPACER							4

-Item not Illustrated

27-55-67

ILLUSTRATED PARTS LIST

Page 1030

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY	
			1	2	3	4	5	6	7			
1-												
600	256A3176-1		.	R	A	C	E			A-D	1	
-600A	TRJD3258		.	B	E	A	R			E, F	1	
605	NTH3258		.	B	E	A	R				1	
											(V80648)	
610	251N4120-1		.	P	L	A	T	E			1	
615	251N4147-1		.	R	O	L	L	E	R	A	S	S
620	QBR62813		.	.	R	O	L	L	E	R		15
											(V60380)	
625	251N4151-1		.	.	R	E	T	A	I	N	E	1
630	256A3145-1		.	P	L	A	T	E			1	
635	BACB10BA17C		.	B	E	A	R	I	N	G		1
640	256A3137-1		.	G	E	A	R				1	
645	256A3144-1		.	R	A	C	E				1	
650	256A3138-1		.	P	I	N	I	O	N		A-D	1
-650A	256A3138-2		.	P	I	N	I	O	N		E, F	1
655	256A3139-1		.	G	E	A	R				1	
660	256A3148-25		.	S	H	I	M				AR	
665	256A3148-26		.	S	H	I	M				AR	
670	256A3148-27		.	S	H	I	M				AR	
675	256A3148-28		.	S	H	I	M				AR	
680	BACB10BA30C		.	B	E	A	R	I	N	G		1
685	256A3185-4		.	S	P	A	C	E	R		1	
690	256W3052-2		.	L	O	C	K	W	A	S	H	E
695	SL2822-12C		.	N	U	T					A-D	1
											(V97393)	
											(SPEC BACN10RF12C)	
											(OPT ITEM 695A)	
-695A	SL2822-12		.	N	U	T					A-D	1
											(V97393)	
											(SPEC BACN10RF12)	
											(OPT BR9080-12 (V72962))	
											(OPT 82631-1216 (V56878))	
											(OPT ITEM 695)	

-Item not Illustrated

27-55-67

ILLUSTRATED PARTS LIST

Page 1031

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
-695B	H51650-12BAC		.	NUT						E, F	1
				(V15653)							
				(SPEC BACN10JC12CD)							
				(OPT 102LH9074-12 (V72962))							
				(OPT 69235-1216CD (V92215))							
				(OPT BMN4122CPD8-12 (V97928))							
700	BACB30MR4HK3		.	BOLT						A-D	4
-700A	BACB30MR4K3		.	BOLT						E, F	4
705	BACW10BN4AC		.	WASHER							4
710	M25988-1-151		.	PACKING							1
715	256A3133-1		.	RETAINER-SEAL						A-D	1
-715A	256A3133-2		.	RETAINER-SEAL						E, F	1
720	256A3136-1		.	SHAFT ASSY-OUTPUT						A-D	1
-720A	256A3136-4		.	SHAFT ASSY-OUTPUT						E, F	1
				(OPT ITEM 720B)							
-720B	256A3136-1		.	SHAFT ASSY-OUTPUT						E, F	1
				(OPT ITEM 720A)							
725	256A3136-1			DELETED							
730	251N4105-1		.	. BEARING							2
735	251N4105-1			DELETED							
740	256A3136-2		.	. SHAFT							1
				(USED ON ITEMS 720, 720B)							
-740A	256A3136-5		.	. SHAFT-OUTPUT						E, F	1
				(USED ON ITEM 720A)							
745	256A3136-2			DELETED							
750	1002423615800		.	SEAL-SHAFT							1
				(V91251)							
				(SPEC S256W410-20)							
				(OPT 700-868-8862-99 (VU1068))							
-750A	700-868-8862-99		.	SEAL-SHAFT							1
				(VU1068)							
				(SPEC S256W410-20)							
				(OPT 1002423615800 (V91251))							
755	256W3051-12		.	SPACER							1
760	RUSZ009-119		.	BEARING							1
				(V78118)							
				(OPT ITEM 760A)							

-Item not Illustrated

27-55-67

ILLUSTRATED PARTS LIST

Page 1032

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
-760A	TPUB1909-8		.								1
765	256A3187-1		.								1
770	MS21209F1-15P		.	.							4
775	MS21209F4-15P		.	.							10
780	MS21209F5-15P		.	.							8
785	256A3187-2		.	.							1
790	256A3195-1										
790A	256A3195-31		.							A	1
-790B	256A3195-39		.							C	1
-790C	256A3195-49		.							E	1
-795	256A3195-2										
-795A	256A3195-32		.							B	1
-795B	256A3195-40		.							D	1
-795C	256A3195-50		.							F	1
800	256A3195-9		.								1
805	256A3195-13		.								1

-Item not Illustrated

27-55-67

ILLUSTRATED PARTS LIST

Page 1033

Mar 01/2006