



COMPONENT MAINTENANCE MANUAL WITH ILLUSTRATED PARTS LIST

FLAP ACTUATION GEARBOX ASSEMBLY

**PART NUMBER
256A3515-1, -2, -3, -4**

BOEING PROPRIETARY, CONFIDENTIAL, AND/OR TRADE SECRET

Copyright © 1995 The Boeing Company
Unpublished Work - All Rights Reserved

Boeing claims copyright in each page of this document only to the extent that the page contains copyrightable subject matter. Boeing also claims copyright in this document as a compilation and/or collective work.

This document includes proprietary information owned by The Boeing Company and/or one or more third parties. Treatment of the document and the information it contains is governed by contract with Boeing. For more information, contact The Boeing Company, P.O. Box 3707, Seattle, Washington 98124.

Boeing, the Boeing signature, the Boeing symbol, 707, 717, 727, 737, 747, 757, 767, 777, 787, Dreamliner, BBJ, DC-8, DC-9, DC-10, KC-10, KDC-10, MD-10, MD-11, MD-80, MD-88, MD-90, P-8A, Poseidon and the Boeing livery are all trademarks owned by The Boeing Company; and no trademark license is granted in connection with this document unless provided in writing by Boeing.

PUBLISHED BY BOEING COMMERCIAL AIRPLANES GROUP, SEATTLE, WASHINGTON, USA
A DIVISION OF THE BOEING COMPANY
PAGE DATE: Jul 01/2009

27-55-87

Page 1
Jul 01/2009



COMPONENT MAINTENANCE MANUAL

Revision No. 17
Jul 01/2009

To: All holders of FLAP ACTUATION GEARBOX ASSEMBLY 27-55-87.

Attached is the current revision to this COMPONENT MAINTENANCE MANUAL

The COMPONENT MAINTENANCE MANUAL is furnished either as a printed manual, on microfilm, or digital products, or any combination of the three. This revision replaces all previous microfilm cartridges or digital products. All microfilm and digital products are reissued with all obsolete data deleted and all updated pages added.

For printed manuals, changes are indicated on the List of Effective Pages (LEP). The pages which are revised will be identified on the LEP by an R (Revised), A (Added), O (Overflow, i.e. changes to the document structure and/or page layout), or D (Deleted). Each page in the LEP is identified by Chapter-Section-Subject number, page number and page date.

Pages replaced or made obsolete by this revision should be removed and destroyed.

ATTENTION

IF YOU RECEIVE PRINTED REVISIONS, PLEASE VERIFY THAT YOU HAVE RECEIVED AND FILED THE PREVIOUS REVISION. BOEING MUST BE NOTIFIED WITHIN 30 DAYS IF YOU HAVE NOT RECEIVED THE PREVIOUS REVISION. REQUESTS FOR REVISIONS OTHER THAN THE PREVIOUS REVISION WILL REQUIRE A COMPLETE MANUAL REPRINT SUBJECT TO REPRINT CHARGES SHOWN IN THE DATA AND SERVICES CATALOG.

27-55-87
TRANSMITTAL LETTER
Page 1
Jul 01/2009

**COMPONENT MAINTENANCE MANUAL****Location of Change**

27-55-87

ASSEMBLY

FITS AND CLEARANCES

SPECIAL TOOLS FIXTURES
AND EQUIPMENT**Description of Change**

Changed the data in the Tools/Equipment list.

Changed dimensions.

Changed the data in the Tool Supplier Information table.

Added the Commercial Tools table.

Added the Special Tools table.

Added the Tool Supplier Information table.

Changed the data in the Special Tools table.

27-55-87

HIGHLIGHTS

Page 1

Jul 01/2009



COMPONENT MAINTENANCE MANUAL

Subject/Page	Date	Subject/Page	Date	Subject/Page	Date
TITLE PAGE		27-55-87 DISASSEMBLY (cont)		27-55-87 REPAIR 4-1 (cont)	
O 1	Jul 01/2009	303	Nov 01/2006	603	Nov 01/2006
2	BLANK	304	BLANK	604	BLANK
27-55-87 TRANSMITTAL LETTER		27-55-87 CLEANING		27-55-87 REPAIR 5-1	
O 1	Jul 01/2009	401	Nov 01/2006	601	Nov 01/2006
2	BLANK	402	BLANK	602	Nov 01/2006
27-55-87 HIGHLIGHTS		27-55-87 CHECK		603	Nov 01/2006
O 1	Jul 01/2009	501	Nov 01/2006	604	BLANK
2	BLANK	502	BLANK	27-55-87 REPAIR 6-1	
27-55-87 EFFECTIVE PAGES		27-55-87 REPAIR - GENERAL		601	Nov 01/2006
1 thru 3	Jul 01/2009	601	Nov 01/2006	602	Nov 01/2006
4	BLANK	602	Nov 01/2006	603	Nov 01/2006
27-55-87 CONTENTS		27-55-87 REPAIR 1-1		604	BLANK
1	Nov 01/2006	601	Nov 01/2006	27-55-87 REPAIR 7-1	
2	BLANK	602	Nov 01/2006	601	Nov 01/2006
27-55-87 TR AND SB RECORD		27-55-87 REPAIR 2-1		602	Nov 01/2006
1	Nov 01/2006	601	Nov 01/2006	603	Nov 01/2006
2	BLANK	602	Nov 01/2008	604	BLANK
27-55-87 REVISION RECORD		603	Nov 01/2006	27-55-87 REPAIR 7-2	
1	Nov 01/2006	604	Nov 01/2006	601	Nov 01/2006
2	Nov 01/2006	605	Nov 01/2006	602	Nov 01/2006
27-55-87 RECORD OF TEMPORARY REVISIONS		606	Nov 01/2006	603	Nov 01/2006
1	Nov 01/2006	27-55-87 REPAIR 3-1		604	BLANK
2	Nov 01/2006	601	Nov 01/2006	27-55-87 REPAIR 8-1	
27-55-87 INTRODUCTION		602	Nov 01/2006	601	Nov 01/2006
1	Mar 01/2009	603	Nov 01/2006	602	Nov 01/2006
2	BLANK	604	BLANK	603	Nov 01/2006
27-55-87 DESCRIPTION AND OPERATION		27-55-87 REPAIR 3-2		604	Nov 01/2006
1	Nov 01/2006	601	Nov 01/2006	605	Nov 01/2006
2	Nov 01/2006	602	Nov 01/2006	606	Nov 01/2006
27-55-87 TESTING AND FAULT ISOLATION		603	Nov 01/2006	607	Nov 01/2006
101	Jul 01/2008	604	BLANK	608	BLANK
102	Jul 01/2008	27-55-87 REPAIR 3-3		27-55-87 REPAIR 8-2	
103	Nov 01/2006	601	Nov 01/2006	601	Nov 01/2006
104	Nov 01/2006	602	Nov 01/2006	602	Jul 01/2007
27-55-87 DISASSEMBLY		603	Nov 01/2006	603	Jul 01/2007
301	Jul 01/2008	604	BLANK	604	Jul 01/2007
302	Nov 01/2006	27-55-87 REPAIR 4-1		605	Jul 01/2007
		601	Nov 01/2006	606	Jul 01/2007
		602	Nov 01/2006	607	Jul 01/2007

A = Added, R = Revised, D = Deleted, O = Overflow

27-55-87

EFFECTIVE PAGES

Page 1

Jul 01/2009



COMPONENT MAINTENANCE MANUAL

Subject/Page	Date	Subject/Page	Date	Subject/Page	Date
27-55-87 REPAIR 8-2 (cont)		27-55-87 REPAIR 13-1 (cont)		27-55-87 FITS AND CLEARANCES (cont)	
608	Jul 01/2007	603	Nov 01/2006	805	Nov 01/2006
609	Jul 01/2007	604	Jul 01/2008	R 806	Jul 01/2009
610	Jul 01/2007	27-55-87 REPAIR 14-1		R 807	Jul 01/2009
611	Jul 01/2007	601	Nov 01/2006	R 808	Jul 01/2009
612	Jul 01/2007	602	Nov 01/2006	27-55-87 SPECIAL TOOLS, FIXTURES, AND EQUIPMENT	
613	Jul 01/2007	27-55-87 REPAIR 14-2		R 901	Jul 01/2009
614	Jul 01/2007	601	Nov 01/2006	902	BLANK
615	Jul 01/2007	602	Nov 01/2006	27-55-87 ILLUSTRATED PARTS LIST	
616	Jul 01/2007	603	Nov 01/2006	1001	Nov 01/2008
617	Jul 01/2007	604	BLANK	1002	Nov 01/2006
618	Jul 01/2007	27-55-87 REPAIR 15-1		1003	Nov 01/2006
27-55-87 REPAIR 9-1		601	Nov 01/2006	1004	Nov 01/2006
601	Nov 01/2006	602	Nov 01/2006	1005	Nov 01/2006
602	Nov 01/2006	603	Nov 01/2006	1006	Nov 01/2006
603	Nov 01/2006	604	BLANK	1007	Nov 01/2006
604	BLANK	27-55-87 ASSEMBLY		1008	Nov 01/2006
27-55-87 REPAIR 10-1		R 701	Jul 01/2009	1009	Nov 01/2006
601	Nov 01/2006	702	Nov 01/2006	1010	Nov 01/2006
602	Nov 01/2006	703	Nov 01/2006	1011	Nov 01/2006
603	Nov 01/2006	704	Nov 01/2006	1012	Nov 01/2006
604	BLANK	705	Nov 01/2006	1013	Nov 01/2006
27-55-87 REPAIR 11-1		706	Jul 01/2008	1014	Nov 01/2006
601	Nov 01/2006	707	Nov 01/2006	1015	Nov 01/2006
602	Nov 01/2006	708	Nov 01/2006	1016	Nov 01/2006
27-55-87 REPAIR 11-2		709	Nov 01/2006	1017	Nov 01/2006
601	Nov 01/2006	710	Nov 01/2006	1018	Nov 01/2006
602	Nov 01/2006	711	Nov 01/2006	1019	Nov 01/2006
603	Nov 01/2006	712	Nov 01/2006	1020	Nov 01/2006
604	Nov 01/2006	713	Nov 01/2006	1021	Nov 01/2006
605	Nov 01/2006	714	Nov 01/2006	1022	Nov 01/2006
606	BLANK	715	Nov 01/2006	1023	Nov 01/2006
27-55-87 REPAIR 12-1		716	Nov 01/2006	1024	Nov 01/2006
601	Nov 01/2006	717	Nov 01/2006	1025	Nov 01/2006
602	Nov 01/2006	718	BLANK	1026	Nov 01/2006
603	Nov 01/2006	27-55-87 FITS AND CLEARANCES		1027	Nov 01/2006
604	BLANK	801	Nov 01/2006	1028	Nov 01/2006
27-55-87 REPAIR 13-1		802	Nov 01/2006	1029	Nov 01/2006
601	Nov 01/2006	803	Nov 01/2006		
602	Nov 01/2006	804	Nov 01/2006		

A = Added, R = Revised, D = Deleted, O = Overflow

27-55-87

EFFECTIVE PAGES

Page 2

Jul 01/2009



COMPONENT MAINTENANCE MANUAL

Subject/Page	Date	Subject/Page	Date	Subject/Page	Date
27-55-87 ILLUSTRATED PARTS LIST (cont)					
1030	BLANK				

A = Added, R = Revised, D = Deleted, O = Overflow

27-55-87

EFFECTIVE PAGES

Page 3

Jul 01/2009



COMPONENT MAINTENANCE MANUAL

TABLE OF CONTENTS

<u>Paragraph Title</u>	<u>Page</u>
FLAP ACTUATION GEARBOX ASSEMBLY - DESCRIPTION AND OPERATION	1
TESTING AND FAULT ISOLATION	101
DISASSEMBLY	301
CLEANING	401
CHECK	501
REPAIR	601
ASSEMBLY	701
FITS AND CLEARANCES	801
SPECIAL TOOLS, FIXTURES, AND EQUIPMENT	901
ILLUSTRATED PARTS LIST	1001

27-55-87

CONTENTS

Page 1

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

INTRODUCTION

1. General

- A. The instructions in this manual supply the data necessary to do the maintenance functions together with the test, fault isolation, repair, and replacement of the defective parts.
- B. This manual is divided into different parts:
 - (1) Title Page
 - (2) Transmittal Letter
 - (3) Highlights
 - (4) List of Effective Pages
 - (5) Table of Contents
 - (6) Temporary Revision & Service Bulletin Record
 - (7) Record of Revisions
 - (8) Record of Temporary Revisions
 - (9) Introduction
 - (10) Procedures & IPL Sections
- C. Components that can be repaired have a different repair number for each specified repair. To find the repair number location of a component, look in the Repair-General procedure at the beginning of the REPAIR section. The Repair-General procedure also has an explanation of the True Position Dimension symbols used.
- D. All dimensions, measures, quantities and weights included are in English units. When metric equivalents are given they will be in the parentheses that follow the English units.
- E. The introduction to the Illustrated Parts List (IPL) shows how the IPL data is used.
- F. Design changes, optional parts, configuration differences and Service Bulletin modifications may cause different part numbers. These part numbers are identified in the IPL with an alphabetical letter which is added to the end of the basic item number. This new item number is referred to as an alpha-variant. Throughout the manual, IPL basic item number references also apply to alpha-variants unless shown differently.
- G. The tool reference numbers found in the individual procedures and in the Special Tools, Fixtures, and Equipment section are used to identify if a tool is a standard tool (STD-XXXX), a commercial tool (COM-XXXX), or a Special Tool (SPL-XXXX). This reference number is also used to distinguish between tools with similar names in the same procedure. These reference numbers are for use in the documentation only. They are not to be used for ordering tools.

27-55-87

INTRODUCTION

Page 1

Mar 01/2009



COMPONENT MAINTENANCE MANUAL

FLAP ACTUATION GEARBOX ASSEMBLY - DESCRIPTION AND OPERATION

1. Description

- A. The gearbox assembly has four different types of gears, two pinions, two half couplings, two coupling sleeves, an output shaft, ten bearings, and a cable drum in an aluminum housing. The gears, pinions, and bearings are steel components.

2. Operation

- A. The gearbox assembly transmits mechanical power from the hydraulic motor or the electric motor of the power drive unit to the flap drive system. The gearbox assembly receives input thru a pinion gear, which drives a large gear and the output shaft.

3. Leading Particulars (Approximate)

- A. Length – 15.0 inches
- B. Width – 10.0 inches
- C. Height – 12.0 inches
- D. Weight – 22.6 pounds


27-55-87

DESCRIPTION AND OPERATION

Page 1

Nov 01/2006

COMPONENT MAINTENANCE MANUAL



Flap Actuation Gearbox Assembly
Figure 1

27-55-87

DESCRIPTION AND OPERATION

Page 2

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

TESTING AND FAULT ISOLATION

1. General

- A. This procedure has the data necessary to do a test of the mechanism after an overhaul or for fault isolation. There are three parts:
- (1) Gearbox Assembly Test (TESTING AND FAULT ISOLATION, Paragraph 2.C.)
 - (a) Bearing test (TESTING AND FAULT ISOLATION, Paragraph 2.C.(3))
 - (b) Torque test (TESTING AND FAULT ISOLATION, Paragraph 2.C.(4))
 - (c) Backlash test (TESTING AND FAULT ISOLATION, Paragraph 2.C.(5))
 - (d) Pressure test (TESTING AND FAULT ISOLATION, Paragraph 2.C.(6))
 - (2) Fault Isolation (TESTING AND FAULT ISOLATION, Paragraph 3.)
 - (3) Fault Correction (TESTING AND FAULT ISOLATION, Paragraph 4.)
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.

2. Testing and Fault Isolation

A. Tools/Equipment

NOTE: Equivalent substitutes may be used.

Reference	Description
SPL-4720	Test Equipment - Leakage Test (Part #: J27054-1, Supplier: 81205)
SPL-5384	Wrench - Coupling Sleeve Flap Actuation (Part #: C27041-1, Supplier: 81205)
SPL-5703	Test Equipment - T.E. Flap Drive Gearboxes (Part #: C27068-65, Supplier: 81205)

B. References

Reference	Title
SOPM 20-50-02	INSTALLATION OF SAFETYING DEVICES

C. Gearbox Assembly Test

- (1) Use standard industry practices to examine the gearbox assembly.
- (2) Install the gearbox assembly on the T.E. Flap Drive Gearbox Test Equipment, SPL-5703 (C27068-65 supersedes C27068-1)
- (3) Do a bearing test.
 - (a) Examine the gearbox assembly in accordance with standard industry practices.
 - (b) Turn the gears (215, 230, 250, 425) a minimum of 720 degrees in each direction.
 - (c) See if the gears (215, 230, 250, 425) turn smoothly.
- (4) Do a torque test.

27-55-87

TESTING AND FAULT ISOLATION

Page 101

Jul 01/2008



COMPONENT MAINTENANCE MANUAL

- (a) Turn the gears (215, 230, 250, 425) a minimum of eight turns in each direction at a rate of 10-20 rpm. Use a torque wrench and the coupling sleeve wrench, SPL-5384 on the bolt (30) on the end of the output shaft (270).
 - (b) Make sure that the breakaway and maximum running torque applied at the output shaft (270) is not more than 10 pound-inches.
- (5) Do a backlash test.
- (a) Remove the pin (15) and the cable assembly (20) from the cable drum (335) (DISASSEMBLY).
 - (b) Remove the nut (325), the washer (330) and the cable drum (335) (DISASSEMBLY).
 - (c) Remove the screws (5), the cover (10), the seals (340, 345), and the packing (350) from the shaft (420) (DISASSEMBLY).
 - (d) Clamp the shaft (420) to avoid axial movement.
 - (e) Apply a torque of 5-10 pound-inches to the worm gear (424) or worm gear assembly (425). Measure the backlash at a 2.80-inch radius from the center of the shaft (420).
 - (f) Make sure that the backlash is 0.002-0.008 inch.
 - (g) Remove the gearbox assembly from the T.E. Flap Drive Gearbox Test Equipment, SPL-5703 (C27068-65 supersedes C27068-1). Install the parts which were removed unless more disassembly is required (ASSEMBLY).
- (6) Do a pressure test of the seals in the gearbox assembly.
- (a) Remove the lockwire and the plug (315) and packing (320).
 - (b) Install the air valve adapter of the leakage test test equipment, SPL-4720 in the plug hole in the housing assembly (290).
 - (c) Connect the compressed air supply.
 - (d) Pressurize the transmission assembly to 14-16 psig, and remove the pressure source.
 - (e) Monitor the pressure in the transmission for a minimum of 30 minutes. Make sure the pressure does not decrease to less than 12 psig after the first 10 minutes.
 - (f) During the next 20 minutes, make sure that the pressure does not decrease by more than 1.0 psig from the value after the first 10 minutes.
 - (g) Make sure that you cannot hear or see any signs of leakage while the gearbox assembly is pressurized.
 - (h) Make sure that the oil level in the gearbox assembly is correct, then install the plug (315) and packing (320). Install lockwire on the plug. Use the double-twist method (SOPM 20-50-02).

3. Fault Isolation

A. General

- (1) Refer to TESTING AND FAULT ISOLATION, Table 101 to do fault isolation with the test results.

27-55-87

TESTING AND FAULT ISOLATION

Page 102

Jul 01/2008



COMPONENT MAINTENANCE MANUAL

Table 101: Trouble Shooting Table

TROUBLE	PROBABLE CAUSE	CORRECTIONS
Gears do not turn smoothly or move freely	Defective bearings (195,200,205,235,285, 335,400)	Disassemble and replace the defective bearings (195,200, 205,235,285,335,400).
Breakaway or maximum running torque is more than 10 lb-in.	Defective bearings (195,200,205,235,285, 335,400)	Disassemble and replace the defective bearings (195,200, 205,235,285,335,400).
Backlash is not correct	Shims (380 thru 395,405 thru 415) need adjustment or, Defective or worn gears (215,230, 250,424,425)	Disassemble and adjust the shims (380 thru 395,405 thru 415) or, Disassemble and replace the gears (215,230,250,424,425).
Air or grease leakage during pressure test	Defective seals (70, 100,115,340) or packings (35,95,160, 190,320,350,375)	Disassemble and replace the defective seals (70,100,115, 340) or packings (35,95,160, 190,320, 350,375).

4. Fault Correction

A. Procedure

- (1) If the gears (215, 230, 250, 424, 425) do not move freely or do not turn smoothly, replace the bearing(s) (195, 200, 205, 235, 285, 335, 400) as follows:
 - (a) Fully disassemble the gearbox assembly (DISASSEMBLY).
 - (b) Replace the defective bearing(s) (195, 200, 205, 235, 285, 325, 400) if it is necessary.
 - (c) Assemble the gearbox assembly (ASSEMBLY).
 - (d) Do a backlash test on the gearbox assembly.
 - (e) If the breakaway or maximum running torque is more than 10 pound-inches, replace the bearing(s) (195, 200, 205, 235, 285, 335, 400) as follows:
 - 1) Fully disassemble the gearbox assembly (DISASSEMBLY).
 - 2) Replace the defective bearing(s) (195, 200, 205, 235, 285, 335, 400) if it is necessary.
 - 3) Assemble the gearbox assembly (ASSEMBLY).
 - 4) Do a backlash test on the gearbox assembly.
 - (f) If the backlash is not 0.002-0.008 inch, do the subsequent steps.
 - 1) Disassemble the gearbox assembly (DISASSEMBLY).
 - 2) Adjust the shims (380 thru 395, 405 thru 415) to correct the backlash.

NOTE: To decrease the backlash, increase the shim thickness. To increase the backlash, decrease the shim thickness.
 - 3) Assemble the gearbox assembly (ASSEMBLY).

NOTE: It is not necessary to measure the bearings (195, 200, 205, 235, 285, 335, 400) again to calculate shim thickness.

27-55-87

TESTING AND FAULT ISOLATION

Page 103

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

- 4) Do a backlash test on the gearbox assembly (215, 220, 250, 420). If the backlash is not 0.002-0.008 inch, replace the gears.
- (g) If air or grease leakage occurs at a seal or any two surfaces that contact, replace the coupling seal (45), the seal(s) (70, 100, 115, 340) or packing(s) (35, 80, 95, 160, 190, 320, 375).

27-55-87

TESTING AND FAULT ISOLATION

Page 104

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

DISASSEMBLY

1. General

- A. This procedure has the data necessary to disassemble the gearbox assembly.
- B. Disassemble this component sufficiently to isolate the defects, do the necessary repairs, and put the component back to a serviceable condition.
- C. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- D. Refer to IPL Figure 1 for item numbers.

2. Disassembly

A. Tools/Equipment

NOTE: Equivalent substitutes may be used.

Reference	Description
SPL-5384	Wrench - Coupling Sleeve Flap Actuation (Part #: C27041-1, Supplier: 81205)

B. Part Replacement

NOTE: The parts which follow are recommended for replacement. Unless a procedure tells you to replace a part, replacement is optional.

- (1) Packings (35, 80, 95, 160, 190, 320, 350, 375)
- (2) Seals (70, 100, 115, 340)
- (3) Coupling seal (45)
- (4) Cotter pin (15)

C. Procedure

- (1) Use standard industry procedures and the steps shown below to disassemble this component.
- (2) Remove the plugs (315) and packings (320) and drain the hydraulic fluid from the gearbox assembly.
- (3) Remove the attachment ferrules (150) and the cable (145A) from the housing assembly (165) and the cover (90).
- (4) Remove the pins (15) and the cable assemblies (20) from the cable drum (355).
- (5) Remove the nut (325), washer (330), and drum (335) from the housing assembly (290).
- (6) Remove the screws (5) and the cover (10) from the housing assembly (290).
- (7) Remove the coupling sleeves (25).
 - (a) Use the coupling sleeve wrench, SPL-5384 to hold the coupling sleeves (25) while you remove the retainer bolts (30) and packings (35).
 - (b) Remove the coupling seals (45), coupling halves (40), coupling sleeves (25), and seal shields (50).
- (8) Remove the screws (55), washers (60), and retainers (65) from the housing assemblies (165, 290).

27-55-87

DISASSEMBLY

Page 301

Jul 01/2008



COMPONENT MAINTENANCE MANUAL

- (9) Remove the bolts (85), washers (88), cover (90), and packing (95) from the housing assembly (290).
- NOTE:** Do not remove the marker (430) from the cover (90) unless replacement is necessary.
- (10) Remove the screws (105) and the retainers (110, 112) from the housing assemblies (165, 290).
- (11) Remove the union (155) and the packing (160) from the housing assembly (165).
- (12) Remove the screws (120, 125), washers (130, 135), nuts (140), and remove the housing assembly (165) from the housing assembly (290).
- NOTE:** Do not remove the helicoil inserts (170 thru 180) from the housing (185) unless replacement is necessary.
- (13) Turn and pull the output shaft assembly (270) counterclockwise to remove it from the housing assembly (290).
- NOTE:** Do not remove the inserts from the output shaft assembly unless replacement is necessary.
- (14) Remove the output gear (215) from the output shaft assembly (270).
- (15) Remove the seals (70), seal rings (75) and the packings (80) from the housing assemblies (165, 290).
- (16) Remove the packing (190), seal (115), and the bearings (195 thru 205, 285) from the housing assembly (165).
- (17) Remove the pinion gear assembly (220) from the housing assembly (290).
- (18) Remove the snap ring (240) and the shearout (245) from the pinion gear assembly (220).
- NOTE:** Do not remove the shaft plug (225) from the gear (230) unless replacement is necessary.
- (19) Remove the pinion (255) from the housing assembly (290).
- (20) Remove the seals (100, 115) from the housing assembly (290).
- (21) Remove the countershaft gear (250).
- (a) Pull the countershaft gear (250) with the attached components from the housing assembly (290).
- (b) Remove the nut (265), washer (260), bearing (200), and pinion (210) from the countershaft gear (250).
- (22) Remove the bolts (360), washers (365), cover (370), and packing (375) from the housing assembly (290).
- (23) Remove the shims (380 thru 395) from the housing assembly (290). Measure and record the shim thickness to facilitate assembly.
- (24) Remove the shaft (420), worm gear (424) or worm gear assembly (425), shims (405 thru 415), and bearings (355, 400) from the housing assembly (290). Measure and record the shim thickness to facilitate assembly.
- NOTE:** Do not disassemble the worm gear assembly (425) unless it is necessary to refinish the parts. The gear teeth and splines are machined after the hub (428) and rim (429) are bolted together. Therefore, the machined hub and rim are not interchangeable with parts from other assemblies.
- (25) Remove the seal (340), seal ring (345), and packing (350) from the housing assembly (290).

27-55-87

DISASSEMBLY

Page 302

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

(26) Remove the bearings (195, 235, 285) from the housing assembly (290).

27-55-87

DISASSEMBLY

Page 303

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

CLEANING

1. General

- A. This procedure has the data necessary to clean the gearbox assembly.
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.

2. Cleaning

A. References

Reference	Title
SOPM 20-30-01	CLEANING AND RELUBRICATING BEARINGS
SOPM 20-30-03	GENERAL CLEANING PROCEDURES

B. Procedure

- (1) Clean the bearings (195, 200, 205, 235, 285, 355, 400) as specified in SOPM 20-30-01.
- (2) Use standard industry procedures and refer to SOPM 20-30-03 to clean other parts.

27-55-87

CLEANING

Page 401

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

CHECK

1. General

- A. This procedure has the data necessary to find defects in the material of the specified parts.
- B. Refer to FITS AND CLEARANCES for the design dimension and wear limits.
- C. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- D. Refer to IPL Figure 1 for item numbers.

2. Check

A. References

Reference	Title
SOPM 20-20-01	MAGNETIC PARTICLE INSPECTION
SOPM 20-20-02	PENETRANT METHODS OF INSPECTION

B. Procedure

- (1) Use standard industry procedures to do a visual check of all the parts for defects. Do the penetrant or magnetic particle check if the visual check shows possible damage or if you suspect possible damage on the parts listed below:
- (2) Do a magnetic particle check (SOPM 20-20-01) of these parts:
 - (a) Coupling sleeve (25)
 - (b) Bolt (30)
 - (c) Coupling half (40)
 - (d) Seal ring (75)
 - (e) Pinion (210, 255)
 - (f) Gear (215, 230, 250)
 - (g) Shaft plug (225)
 - (h) Retainer (240)
 - (i) Shearout (245)
 - (j) Shaft (280)
- (3) Do a penetrant check (SOPM 20-20-02) of these parts:
 - (a) Cover (10, 90, 370)
 - (b) Retainer (65, 110)
 - (c) Housing (185, 310)
 - (d) Deleted
 - (e) Worm gear (424)
 - (f) Worm gear assembly (425)

27-55-87

CHECK

Page 501

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

REPAIR

1. General

- A. Instructions for repair, refinish, and replacement of the specified subassembly parts are included in each REPAIR when applicable.

Table 601:

PART NUMBER	NAME	REPAIR
—	REFINISH OF OTHER PARTS	1-1
256A3515	GEARBOX	2-1
256A3532	COVER	3-1
256A3533	COVER	3-2
256A3546	COVER	3-3
256A3745	COUPLING SLEEVE	4-1
256A3744	BOLT	5-1
256A3741	COUPLING HALF	6-1
256W3244	SEAL RETAINER	7-1
256W3547	INPUT SEAL RETAINER	7-2
256A3519	HOUSING	8-1, 8-2
256A3520	HOUSING	8-1, 8-2
256A3524	PINION	9-1
256A3525	OUTPUT GEAR	10-1
256A3528	PINION GEAR	11-1, 11-2
256A3526	COUNTERSHAFT GEAR	12-1
256A3527	PINION	13-1
256A3523	OUTPUT SHAFT	14-1, 14-2
256A3540	WORM GEAR	15-1

2. Dimensioning Symbols

- A. Standard True Position Dimensioning Symbols used in the applicable repair procedures are shown in REPAIR-GENERAL, Figure 601.

27-55-87

REPAIR - GENERAL

Page 601

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

—	STRAIGHTNESS	∅	DIAMETER
▭	FLATNESS	S ∅	SPHERICAL DIAMETER
⊥	PERPENDICULARITY (OR SQUARENESS)	R	RADIUS
//	PARALLELISM	SR	SPHERICAL RADIUS
○	ROUNDNESS	()	REFERENCE
⊘	CYLINDRICITY	BASIC	A THEORETICALLY EXACT DIMENSION USED
⌒	PROFILE OF A LINE	(BSC)	TO DESCRIBE SIZE, SHAPE OR LOCATION OF
⌒	PROFILE OF A SURFACE	OR	A FEATURE. FROM THIS FEATURE PERMISSIBLE
◎	CONCENTRICITY	DIM	VARIATIONS ARE ESTABLISHED BY TOLERANCES ON OTHER DIMENSIONS OR
≡	SYMMETRY		NOTES.
∠	ANGULARITY	-A-	DATUM
↗	RUNOUT	Ⓜ	MAXIMUM MATERIAL CONDITION (MMC)
↗	TOTAL RUNOUT	Ⓛ	LEAST MATERIAL CONDITION (LMC)
⊔	COUNTERBORE OR SPOTFACE	Ⓢ	REGARDLESS OF FEATURE SIZE (RFS)
∇	COUNTERSINK	Ⓟ	PROJECTED TOLERANCE ZONE
⊕	THEORETICAL EXACT POSITION OF A FEATURE (TRUE POSITION)	FIM	FULL INDICATOR MOVEMENT

EXAMPLES

$\boxed{\text{—}} \boxed{0.002}$	STRAIGHT WITHIN 0.002	$\boxed{\text{◎}} \boxed{\text{∅}} \boxed{0.0005} \boxed{C}$	CONCENTRIC TO DATUM C WITHIN 0.0005 DIAMETER
$\boxed{\text{⊥}} \boxed{0.002} \boxed{B}$	PERPENDICULAR TO DATUM B WITHIN 0.002	$\boxed{\text{≡}} \boxed{0.010} \boxed{A}$	SYMMETRICAL WITH DATUM A WITHIN 0.010
$\boxed{\text{//}} \boxed{0.002} \boxed{A}$	PARALLEL TO DATUM A WITHIN 0.002	$\boxed{\text{∠}} \boxed{0.005} \boxed{A}$	ANGULAR TOLERANCE 0.005 WITH DATUM A
$\boxed{\text{○}} \boxed{0.002}$	ROUND WITHIN 0.002	$\boxed{\text{⊕}} \boxed{\text{∅}} \boxed{0.002} \boxed{\text{Ⓢ}} \boxed{B}$	LOCATED AT TRUE POSITION WITHIN 0.002 DIA RELATIVE TO DATUM B, REGARDLESS OF FEATURE SIZE
$\boxed{\text{⊘}} \boxed{0.010}$	CYLINDRICAL SURFACE MUST LIE BETWEEN TWO CONCENTRIC CYLINDERS, ONE OF WHICH HAS A RADIUS 0.010 INCH GREATER THAN THE OTHER	$\boxed{\text{⊥}} \boxed{\text{∅}} \boxed{0.010} \boxed{\text{Ⓜ}} \boxed{A}$	AXIS IS TOTALLY WITHIN A CYLINDER OF 0.010 INCH DIAMETER, PERPENDICULAR TO DATUM A, AND EXTENDING 0.510 INCH ABOVE DATUM A, MAXIMUM MATERIAL CONDITION
$\boxed{\text{⌒}} \boxed{0.006} \boxed{A}$	EACH LINE ELEMENT OF THE SURFACE AT ANY CROSS SECTION MUST LIE BETWEEN TWO PROFILE BOUNDARIES 0.006 INCH APART RELATIVE TO DATUM A	$\boxed{0.510} \boxed{\text{Ⓟ}}$	
$\boxed{\text{⌒}} \boxed{0.020} \boxed{A}$	SURFACES MUST LIE WITHIN PARALLEL BOUNDARIES 0.020 INCH APART AND EQUALLY DISPOSED ABOUT TRUE PROFILE	$\boxed{2.000}$	THEORETICALLY EXACT DIMENSION IS 2.000
		OR	
		2.000	
		BSC	

True Position Dimensioning Symbols
Figure 601

27-55-87

REPAIR - GENERAL

Page 602

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

REFINISH OF OTHER PARTS - REPAIR 1-1

1. General

- A. This procedure has the data necessary to refinish the parts which are not given in the specified repairs.
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.

2. Refinish of Other Parts

- A. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-60-02	FINISHING MATERIALS

- C. General

(1) Instructions for the repair of the parts listed in REPAIR 1-1, Table 601 is for repair of the initial finish.

- D. Procedure

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01. For finishing materials, refer to SOPM 20-60-02.

(1) Refer to REPAIR 1-1, Table 601 for the refinish of other parts.

Table 601: Refinish Details

IPL FIG. & ITEM	MATERIAL	FINISH
Seal shield (50)	15-5PH CRES 180-200 ksi	Passivate (F-17.25).
Seal ring (75)	Cronidur 30 CRES per AMS 5898, HT or case hardened HRC 55	Passivate (F-17.25).
Seal ring (75B)	XD15NW CRES (BMS 7-357), HT or case hardened to HRC 55	Passivate (F-17.25).

27-55-87

REPAIR 1-1

Page 601

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

Table 601: Refinish Details (Continued)

IPL FIG. & ITEM	MATERIAL	FINISH
Seal ring (75E, 345E)	9310 Steel HT or case hardened to Rockwell A80	Cadmium plate (F-15.23).
Shaft plug (225)	15-5PH CRES 125-145 ksi	Passivate (F-17.25).
Retainer (240)	17-7PH CRES wire HT cond CH900	Cadmium plate (F-16.06).
Shearout (245)	15-5PH CRES 180-200 ksi	Cadmium plate (F-16.06) external surfaces. Uncontrolled plate in bore.
Seal ring (345)	Cronidur 30 CRES per AMS 5898, HT or case hardened to HRC 55	Passivate (F-17.25). Apply primer, C00259 (F-18.12) to the smaller end face only.
Seal ring (345A)	XD15NW CRES (BMS 7-357), HT or case hardened to HRC 55	Passivate (F-17.25). Apply primer, C00259 (F-18.12) to the smaller end face only.
Shim (380 thru 395, 405 thru 415)	301 CRES Full hard	Passivate (F-17.25).
Hub (428)	Aluminum alloy	Boric acid-sulfuric acid anodize or chromic acid anodize (F-17.35).
Rim (429)	Aluminum-bronze alloy	Cadmium plate (F-15.05).

27-55-87

REPAIR 1-1

Page 602

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

GEARBOX ASSEMBLY - REPAIR 2-1

256A3515THRU-1, -4

1. General

- A. This procedure has the data necessary to replace external parts of the gearbox assembly.
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.

2. Union and Plug Replacement

- A. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
D00467	Fluid - Landing Gear Shock Strut	BMS3-32, Type II

- B. References

Reference	Title
SOPM 20-50-06	INSTALLATION OF O-RINGS AND TEFLON SEALS
SOPM 20-60-03	LUBRICANTS

- C. Procedure (REPAIR 2-1, Figure 601)

NOTE: For lubricants, refer to SOPM 20-60-03.

- (1) Remove the union (155) and the packing (160) from the housing assembly (165).
- (2) Install the new packing (160) on the union (155) with fluid, D00467 (SOPM 20-50-06).
- (3) Install the new union (155) on the housing assembly (165) with fluid, D00467.
- (4) Tighten the union (155) to 110-130 pound-inches more than the run-on torque.
- (5) Remove the plug (315) and the packing (320) from the housing assembly (290).
- (6) Install the new packing (320) on the new plug (315) with fluid, D00467(SOPM 20-50-06).
- (7) Install the new plug (315) on the housing assembly (290) with fluid, D00467.
- (8) Tighten the plug (315) to 110-130 pound-inches more than the run-on torque.

3. Cable Assembly Replacement

- A. References

Reference	Title
SOPM 20-50-02	INSTALLATION OF SAFETYING DEVICES

- B. Procedure (REPAIR 2-1, Figure 601)

- (1) Remove the cotter pins (15) from the cable assemblies (20).

NOTE: Do not reuse the cotter pins (15).

- (2) Remove the old cable assemblies (20) from the cable drum (335).

27-55-87

REPAIR 2-1

Page 601

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

- (3) Install replacement cable assemblies (20).
 - (a) Align the black ring mark on the cable drum (335) with the white cable guard on the housing assembly (290).
 - (b) Wrap the lower cable assembly (20) on the cable drum (335) for 2-2.5 wraps as shown in REPAIR 2-1, Figure 601.
 - (c) Wrap the upper cable assembly (20) on the cable drum (335) for 0-0.5 wrap as shown in REPAIR 2-1, Figure 601.
 - (d) Install the new cotter pins (15) onto the cable assemblies (20). Make sure that the cotter pin eyes are seated firmly so that there is minimal axial movement of the pin after installation (SOPM 20-50-02).

4. Marker Replacement

A. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
A00028	Adhesive - Modified Epoxy For Rigid PVC, Foam Cored Sandwiches	BAC5010, Type 70 (BMS5-92, Type 1)
A50055	Adhesive - Two-Part, RT Cure, Urethane	BAC5010, Type 89 (BMS5-105)
B00083	Solvent - Aliphatic Naphtha (For Acrylic Plastics)	TT-N-95 Type II, ASTM D-3735 Type III

B. References

Reference	Title
SOPM 20-30-03	GENERAL CLEANING PROCEDURES
SOPM 20-50-12	APPLICATION OF ADHESIVES
SOPM 20-60-01	CLEANING MATERIALS
SOPM 20-60-04	MISCELLANEOUS MATERIALS

C. Procedure (REPAIR 2-1, Figure 601)

NOTE: For cleaning materials, refer to SOPM 20-60-01. For miscellaneous materials, refer to SOPM 20-60-04.

- (1) Remove the damaged or defective marker (430, 435, 440 or 445) from the housing assembly (290).
- (2) Solvent clean the surface with solvent, B00083 (SOPM 20-30-03).
- (3) Install the marker (430, 435, 440 or 445) on the housing assembly (290) with Type 89 urethane adhesive, A50055 or Type 70 adhesive, A00028 (SOPM 20-50-12).


27-55-87

REPAIR 2-1

Page 602

Nov 01/2008

COMPONENT MAINTENANCE MANUAL




256A3515-1,-2,-3 Gearbox Assembly Repair
Figure 601 (Sheet 1 of 4)

27-55-87

REPAIR 2-1
Page 603
Nov 01/2006

COMPONENT MAINTENANCE MANUAL





256A3515-1,-2,-3 Gearbox Assembly Repair
Figure 601 (Sheet 2 of 4)

27-55-87

REPAIR 2-1
Page 604
Nov 01/2006

COMPONENT MAINTENANCE MANUAL



256A3515-1,-2,-3 Gearbox Assembly Repair
Figure 601 (Sheet 3 of 4)

27-55-87

REPAIR 2-1
Page 605
Nov 01/2006



COMPONENT MAINTENANCE MANUAL

- 1 INSTALL PACKING WITH BMS 3-32 FLUID
- 2 INSTALL THE UNION/PLUG WITH BMS 3-32 FLUID AND TIGHTEN TO 110-130 LB-IN MORE THAN THE RUN-IN TORQUE
- 3 WITH THE GEARBOX IN THE POSITION SHOWN, THE BMS 3-32 FLUID LEVEL MUST BE AT THIS FILLER HOLE
- 4 LOCATE THE MARKER AS SHOWN. BOND THE MARKER WITH TYPE 89 OR TYPE 70 ADHESIVE AS SHOWN IN SOPM 20-50-12
- 5 INSTALL THE LOCKWIRE BY THE DOUBLE TWIST PROCEDURE (SOPM 20-50-02)
- 6 SERIAL NUMBER IS FOUND ON THIS MARKER
- 7 THE BLACK RIG MARK ON THE CABLE DRUM MUST BE ALIGNED WITH THE WHITE CABLE GUARD. INSTALL THE LOWER CABLE ASSEMBLY WITH 2-2.5 WRAPS AND THE UPPER CABLE ASSEMBLY WITH 0-0.5 WRAP ON THE CABLE DRUM
- 8 INSTALL THE COTTER PIN EYE DOWN TIGHT AGAINST THE SURFACE

ITEM NUMBERS REFER TO IPL FIG. 1

256A3515-1,-2,-3 Gearbox Assembly Repair
Figure 601 (Sheet 4 of 4)

27-55-87

REPAIR 2-1
Page 606
Nov 01/2006



COMPONENT MAINTENANCE MANUAL

COVER - REPAIR 3-1

256A3532-1

1. General

- A. This procedure has the data necessary to repair and refinish the cover (370).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.
- D. General repair details:
 - (1) Material: Al alloy

2. Cover Refinish

- A. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-60-02	FINISHING MATERIALS

- C. Procedure (REPAIR 3-1, Figure 601)

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01. For finishing materials, refer to SOPM 20-60-02.

- (1) Remove the protective finish from the part (SOPM 20-30-02).
- (2) Boric acid-sulfuric acid anodize, or chromic acid anodize (F-17.35).
- (3) Apply primer, C00259 (F-20.02) as shown by flagnote 1.



27-55-87

REPAIR 3-1

Page 601

Nov 01/2006

COMPONENT MAINTENANCE MANUAL



256A3532-1 Cover Repair
Figure 601 (Sheet 1 of 2)

27-55-87

REPAIR 3-1
Page 602
Nov 01/2006



COMPONENT MAINTENANCE MANUAL

1 → APPLY ONE LAYER OF BMS 10-11,
TYPE I PRIMER (F-20.02) ON THIS
SURFACE AS SHOWN IN SOPM 20-41-02

2 → THE PART NUMBER IS FOUND HERE

125 ✓ ALL MACHINED SURFACES UNLESS
SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 1

ALL DIMENSIONS ARE IN INCHES

256A3532-1 Cover Repair
Figure 601 (Sheet 2 of 2)

27-55-87

REPAIR 3-1

Page 603

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

COVER - REPAIR 3-2

256A3533-1

1. General

- A. This procedure has the data necessary to repair and refinish the cover (10).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.
- D. General repair details:
 - (1) Material: Al alloy

2. Cover Refinish

- A. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-60-02	FINISHING MATERIALS

- C. Procedure (REPAIR 3-2, Figure 601)

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01. For finishing materials, refer to SOPM 20-60-02.

- (1) Remove the protective finish from the part (SOPM 20-30-02).
- (2) Boric acid-sulfuric acid anodize or chromic acid anodize (F-17.35) all over.
- (3) Apply primer, C00259 (F-20.02) but not the surface shown by flagnote 1.


27-55-87

REPAIR 3-2

Page 601

Nov 01/2006

COMPONENT MAINTENANCE MANUAL




256A3533-1 Cover Repair
Figure 601 (Sheet 1 of 2)

27-55-87

REPAIR 3-2
Page 602
Nov 01/2006



COMPONENT MAINTENANCE MANUAL



125/√ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 1

ALL DIMENSIONS ARE IN INCHES

1 NO PRIMER IN THIS SURFACE

256A3533-1 Cover Repair
Figure 601 (Sheet 2 of 2)

27-55-87

REPAIR 3-2

Page 603

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

COVER - REPAIR 3-3

256A3546-1

1. General

- A. This procedure has the data necessary to repair and refinish the cover (90).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.
- D. General repair details:
 - (1) Material: Al alloy

2. Cover Refinish

- A. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-60-02	FINISHING MATERIALS

- C. Procedure (REPAIR 3-3, Figure 601)


NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01. For finishing materials, refer to SOPM 20-60-02.

- (1) Remove the protective finish from the part (SOPM 20-30-02).
- (2) Boric acid-sulfuric acid or chromic acid anodize (F-17.35).
- (3) Apply primer, C00259 (F-20.02) as shown.

27-55-87

REPAIR 3-3
Page 601
Nov 01/2006

COMPONENT MAINTENANCE MANUAL




256A3546-1 Cover Repair
Figure 601 (Sheet 1 of 2)

27-55-87

REPAIR 3-3
Page 602
Nov 01/2006

COMPONENT MAINTENANCE MANUAL



1 APPLY A LAYER OF BMS 10-11, TYPE 1 PRIMER (F-20.02) ON THIS SURFACE AS SHOWN IN SOPM 20-41-02. OVER SPRAY IN THE HOLES IS PERMITTED

2 THE PART NUMBER IS FOUND HERE

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 1

ALL DIMENSIONS ARE IN INCHES

256A3546-1 Cover Repair
Figure 601 (Sheet 2 of 2)

27-55-87

REPAIR 3-3

Page 603

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

COUPLING SLEEVE - REPAIR 4-1

256A3745-1

1. General

- A. This procedure has the data necessary to repair and refinish the coupling sleeve (25).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.
- D. General repair details:
 - (1) Materials: 4140 steel, Heat Treat: 150-170 ksi

2. Coupling Sleeve Refinish

- A. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-60-02	FINISHING MATERIALS

- C. Procedure (REPAIR 4-1, Figure 601)

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01. For finishing materials, refer to SOPM 20-60-02.

- (1) Remove the protective finish from the part (SOPM 20-30-02).
- (2) Cadmium plate (F-15.36).
- (3) Bake the part at 350-400°F for a minimum of 3 hours.
- (4) Apply primer, C00259 (F-20.02) all over but not on the spline teeth. Do not plug the 0.04-0.05 inch diameter holes with primer.



27-55-87

REPAIR 4-1

Page 601

Nov 01/2006

COMPONENT MAINTENANCE MANUAL




256A3745-1 Coupling Sleeve Repair
Figure 601 (Sheet 1 of 2)

27-55-87

REPAIR 4-1
Page 602
Nov 01/2006



COMPONENT MAINTENANCE MANUAL



125 / ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 1

ALL DIMENSIONS ARE IN INCHES

1 NO PRIMER ON THIS SURFACE

256A3745-1 Coupling Sleeve Repair
Figure 601 (Sheet 2 of 2)

27-55-87

REPAIR 4-1

Page 603

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

BOLT - REPAIR 5-1

256A3744-1

1. General

- A. This procedure has the data necessary to repair and refinish the bolt (30).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.
- D. General repair details:
 - (1) Material: 15-5PH CRES, Heat treat: 180-200 ksi

2. Bolt Refinish

A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

B. Procedure (REPAIR 5-1, Figure 601)

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Remove the protective finish from the part (SOPM 20-30-02).
- (2) Cadmium plate (F-16.06) but not the surface shown by flagnote 1.



27-55-87

REPAIR 5-1

Page 601

Nov 01/2006

COMPONENT MAINTENANCE MANUAL




256A3744-1 Bolt Repair
Figure 601 (Sheet 1 of 2)

27-55-87

REPAIR 5-1
Page 602
Nov 01/2006



COMPONENT MAINTENANCE MANUAL



B-B

1 NO CADMIUM PLATE (F-16.06)
 FINISH ON THIS SURFACE

125/ ALL MACHINED SURFACES UNLESS
 SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 1

ALL DIMENSIONS ARE IN INCHES

256A3744-1 Bolt Repair
 Figure 601 (Sheet 2 of 2)

27-55-87

REPAIR 5-1

Page 603

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

HALF COUPLING - REPAIR 6-1

256A3741-1

1. General

- A. This procedure has the data necessary to repair and refinish the half coupling (40).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.
- D. General repair details:
 - (1) Material: 4330M Steel, Heat treat: 180-200 ksi, RC 33 max

2. Half Coupling Refinish

- A. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-60-02	FINISHING MATERIALS

- C. Procedure (REPAIR 6-1, Figure 601)

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01. For finishing materials, refer to SOPM 20-60-02.

- (1) Remove the protective finish from the part (SOPM 20-30-02).
- (2) Cadmium plate (F-15.36).
- (3) Apply primer, C00259 (F-20.02) to the surface identified by flagnote 1.


27-55-87

REPAIR 6-1

Page 601

Nov 01/2006

COMPONENT MAINTENANCE MANUAL



1 APPLY A LAYER OF BMS 10-11,
TYPE 1 PRIMER (F-20.02) ON
THIS SURFACE

2 SPLINE TOOTH PROFILE MUST HAVE
MAXIMUM OF 63 MICROINCHES

125 ✓ ALL MACHINED SURFACES UNLESS
SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 1

ALL DIMENSIONS ARE IN INCHES

256A3741-1 Half Coupling Repair
Figure 601 (Sheet 1 of 2)


27-55-87

REPAIR 6-1

Page 602

Nov 01/2006

COMPONENT MAINTENANCE MANUAL



A-A

256A3741-1 Half Coupling Repair
Figure 601 (Sheet 2 of 2)

27-55-87

REPAIR 6-1
Page 603
Nov 01/2006



COMPONENT MAINTENANCE MANUAL

SEAL RETAINER - REPAIR 7-1

256W3244-1

1. General

- A. This procedure has the data necessary to repair and refinish the seal retainer (65).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.
- D. General repair details:
 - (1) Material: Al alloy

2. Seal Retainer Refinish

- A. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-60-02	FINISHING MATERIALS

- C. Procedure (REPAIR 7-1, Figure 601)

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01. For finishing materials, refer to SOPM 20-60-02.

- (1) Remove the protective finish from the part (SOPM 20-30-02).
- (2) Boric acid-sulfuric acid anodize or chromic acid anodize (F-17.31).
- (3) Apply primer, C00259 (F-20.02) but not on the surface identified by flagnote 1.


27-55-87

REPAIR 7-1

Page 601

Nov 01/2006

COMPONENT MAINTENANCE MANUAL




256W3244-1 Retainer Repair
Figure 601 (Sheet 1 of 2)

27-55-87

REPAIR 7-1
Page 602
Nov 01/2006



COMPONENT MAINTENANCE MANUAL



125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 1

ALL DIMENSIONS ARE IN INCHES

1 NO BMS 10-11, TYPE 1 PRIMER (F-20.02) ON THIS SURFACE

256W3244-1 Retainer Repair
Figure 601 (Sheet 2 of 2)

27-55-87

REPAIR 7-1

Page 603

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

INPUT SEAL RETAINER - REPAIR 7-2

256W3547-1

1. General

- A. This procedure has the data necessary to repair and refinish the input seal retainer (110, 112).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.
- D. General repair details:
 - (1) Material: Al alloy

2. Input Seal Refinish

- A. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-60-02	FINISHING MATERIALS

- C. Procedure (REPAIR 7-2, Figure 601)

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01. For finishing materials, refer to SOPM 20-60-02.

- (1) Remove the protective finish from the part (SOPM 20-30-02).
- (2) Boric acid-sulfuric acid anodize or chromic acid anodize (F-17.31).
- (3) Apply primer, C00259 (F-20.02) as shown. Do not apply primer in holes.



27-55-87

REPAIR 7-2

Page 601

Nov 01/2006

COMPONENT MAINTENANCE MANUAL




256W3547-1 Input Seal Retainer Repair
Figure 601 (Sheet 1 of 2)

27-55-87

REPAIR 7-2
Page 602
Nov 01/2006



COMPONENT MAINTENANCE MANUAL



1 APPLY BMS 10-11, TYPE 1 PRIMER (F-20.02) ON THIS SURFACES. DO NOT APPLY PRIMER IN HOLES

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 1

ALL DIMENSIONS ARE IN INCHES

256W3547-1 Input Seal Retainer Repair
Figure 601 (Sheet 2 of 2)

27-55-87

REPAIR 7-2

Page 603

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

HOUSING ASSEMBLY - REPAIR 8-1

256A3519-1, -3, 256A3520-1, -5

1. General

- A. This procedure has the data necessary to repair and refinish the housing assembly (165, 290).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.

2. Insert Replacement

- A. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

- B. References

Reference	Title
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-50-22	HOW TO INSTALL THREADED INSERTS
SOPM 20-60-02	FINISHING MATERIALS

- C. Procedure (REPAIR 8-1, Figure 601 and REPAIR 8-1, Figure 602)

NOTE: For the decoding table for Boeing finish codes, refer to SOPM 20-41-01. For finishing materials, refer to SOPM 20-60-02.

- (1) Remove the old inserts from the housing (185, 310).
- (2) Install replacement inserts (170 thru 180) as shown in REPAIR 8-1, Figure 601 (SOPM 20-50-22).
 - (a) Apply wet primer, C00259 (F-20.20) to all areas of the hole.
 - (b) Install the inserts (170 and 175) in the housing (185) as identified by flagnote 1.
 - (c) Install the insert (180) into the housing (185) as identified by flagnote 2.
- (3) Install replacement inserts (295 thru 305) as shown in REPAIR 8-1, Figure 602 (SOPM 20-50-22).
 - (a) Apply wet primer, C00259 (F-20.20) to all areas of the hole.
 - (b) Install the inserts (295 and 300) in the housing (310).
 - (c) Install the insert (305) into the housing (310) as identified by flagnote 2.



27-55-87

REPAIR 8-1

Page 601

Nov 01/2006

COMPONENT MAINTENANCE MANUAL



A-A

1 INSTALL INSERT WITH WET BMS 10-11, TYPE 1 PRIMER (F-20.20) AS SHOWN IN SOPM 20-41-02

ITEM NUMBERS REFER TO IPL FIG. 1


2 INSTALL INSERT 0.25-0.50 BELOW THIS SURFACE WITH WET BMS 10-11, TYPE 1 PRIMER (F-20.20) AS SHOWN IN SOPM 20-42-02. REMOVE THE TANG

256A3520-1,-5 Housing Assembly Repair
Figure 601

27-55-87

REPAIR 8-1
Page 602
Nov 01/2006

COMPONENT MAINTENANCE MANUAL




256A3519-1,-3 Housing Assembly Repair
Figure 602 (Sheet 1 of 5)

27-55-87

REPAIR 8-1
Page 603
Nov 01/2006

COMPONENT MAINTENANCE MANUAL




256A3519-1,-3 Housing Assembly Repair
Figure 602 (Sheet 2 of 5)

27-55-87

REPAIR 8-1
Page 604
Nov 01/2006

COMPONENT MAINTENANCE MANUAL



256A3519-1,-3 Housing Assembly Repair
Figure 602 (Sheet 3 of 5)


27-55-87

REPAIR 8-1

Page 605

Nov 01/2006

COMPONENT MAINTENANCE MANUAL



256A3519-1,-3 Housing Assembly Repair
Figure 602 (Sheet 4 of 5)

27-55-87


REPAIR 8-1

Page 606

Nov 01/2006



COMPONENT MAINTENANCE MANUAL



- 1 INSTALL INSERT WITH WET BMS 10-11, TYPE 1 PRIMER (F-20.20) AS SHOWN IN SOPM 20-41-02
- 2 INSTALL INSERT 0.25-0.50 BELOW THIS SURFACE WITH WET BMS 10-11, TYPE 1 PRIMER (F-20.20) AS SHOWN IN SOPM 20-41-02. REMOVE THE TANG

ITEM NUMBER REFER TO IPL FIG. 1

256A3519-1,-3 Housing Assembly Repair
Figure 602 (Sheet 5 of 5)

27-55-87

REPAIR 8-1
Page 607
Nov 01/2006



COMPONENT MAINTENANCE MANUAL

HOUSING - REPAIR 8-2

256A3519-2, -4, 256A3520-2, -6

1. General

- A. This procedure has the data necessary to repair and refinish the housing (185, 310).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.
- D. General repair details:
 - (1) Material: Aluminum alloy

2. Housing Refinish

- A. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I
C00260	Coating - Chemical And Solvent Resistant Finish, Epoxy Resin Enamel	BMS10-11, Type II

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-60-02	FINISHING MATERIALS

- C. Procedure (REPAIR 8-2, Figure 601 and REPAIR 8-2, Figure 602)

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01. For finishing materials, refer to SOPM 20-60-02.

- (1) Remove the protective finish from the housing (185, 310) (SOPM 20-30-02).
- (2) Housing (185) (REPAIR 8-2, Figure 601).
 - (a) Boric acid-sulfuric acid anodize or chromic acid anodize (F-17.35) all over.
 - (b) Apply primer, C00259 (F-20.02) to all outside surfaces. Do not apply primer to O-ring grooves, hole diameters, or surfaces identified by flagnote 1. Overspray is permitted on holes identified by flagnote 4.
- (3) Housing (310) (REPAIR 8-2, Figure 602).
 - (a) Boric acid-sulfuric acid anodize or chromic acid anodize (F-17.35) all over.
 - (b) Apply primer, C00259(F-20.02) to all outside surfaces. Do not apply primer to O-ring grooves, hole diameters, or surfaces identified by flagnote 1. Overspray is permitted on holes identified by flagnote 3.
 - (c) Apply enamel coating, C00260, color 701 white (F-21.03) as shown by flagnote 5.


27-55-87

REPAIR 8-2

Page 601

Nov 01/2006

COMPONENT MAINTENANCE MANUAL




256A3520-2,-6 Housing Repair
Figure 601 (Sheet 1 of 7)

27-55-87

REPAIR 8-2
Page 602
Jul 01/2007

COMPONENT MAINTENANCE MANUAL




256A3520-2,-6 Housing Repair
Figure 601 (Sheet 2 of 7)

27-55-87

REPAIR 8-2
Page 603
Jul 01/2007

COMPONENT MAINTENANCE MANUAL




256A3520-2,-6 Housing Repair
Figure 601 (Sheet 3 of 7)

27-55-87

REPAIR 8-2
Page 604
Jul 01/2007



COMPONENT MAINTENANCE MANUAL




256A3520-2,-6 Housing Repair
Figure 601 (Sheet 4 of 7)

27-55-87

REPAIR 8-2
Page 605
Jul 01/2007

COMPONENT MAINTENANCE MANUAL




256A3520-2,-6 Housing Repair
Figure 601 (Sheet 5 of 7)

27-55-87

REPAIR 8-2
Page 606
Jul 01/2007

COMPONENT MAINTENANCE MANUAL




E-E
(ROTATED)

256A3520-2,-6 Housing Repair
Figure 601 (Sheet 6 of 7)

27-55-87

REPAIR 8-2
Page 607
Jul 01/2007

COMPONENT MAINTENANCE MANUAL




- 1 NO BMS 10-11, TYPE 1 PRIMER (F-20.02) ON THIS SURFACE
- 2 THE PART NUMBER IS FOUND HERE
- 3 OVERSPRAY IS PERMITTED ON THIS HOLE

- 125 ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY
- BREAK ALL SHARP EDGES
- ITEM NUMBERS REFER TO IPL FIG. 1
- ALL DIMENSIONS ARE IN INCHES

256A3520-2,-6 Housing Repair
Figure 601 (Sheet 7 of 7)

27-55-87

COMPONENT MAINTENANCE MANUAL




256A3519-2,-4 Housing Repair
Figure 602 (Sheet 1 of 10)

27-55-87

REPAIR 8-2
Page 609
Jul 01/2007



COMPONENT MAINTENANCE MANUAL




256A3519-2,-4 Housing Repair
Figure 602 (Sheet 2 of 10)

27-55-87

REPAIR 8-2
Page 610
Jul 01/2007

COMPONENT MAINTENANCE MANUAL




256A3519-2,-4 Housing Repair
Figure 602 (Sheet 3 of 10)

27-55-87

REPAIR 8-2
Page 611
Jul 01/2007

COMPONENT MAINTENANCE MANUAL




256A3519-2,-4 Housing Repair
Figure 602 (Sheet 4 of 10)

27-55-87

REPAIR 8-2
Page 612
Jul 01/2007

COMPONENT MAINTENANCE MANUAL




256A3519-2,-4 Housing Repair
Figure 602 (Sheet 5 of 10)

27-55-87

REPAIR 8-2
Page 613
Jul 01/2007



COMPONENT MAINTENANCE MANUAL




256A3519-2,-4 Housing Repair
Figure 602 (Sheet 6 of 10)

27-55-87

REPAIR 8-2
Page 614
Jul 01/2007

COMPONENT MAINTENANCE MANUAL




256A3519-2,-4 Housing Repair
Figure 602 (Sheet 7 of 10)

27-55-87

REPAIR 8-2
Page 615
Jul 01/2007

COMPONENT MAINTENANCE MANUAL




256A3519-2,-4 Housing Repair
Figure 602 (Sheet 8 of 10)

27-55-87

REPAIR 8-2
Page 616
Jul 01/2007


COMPONENT MAINTENANCE MANUAL



256A3519-2,-4 Housing Repair
Figure 602 (Sheet 9 of 10)

27-55-87

REPAIR 8-2
Page 617
Jul 01/2007

COMPONENT MAINTENANCE MANUAL


J-J

- 1 NO BMS 10-11, TYPE 1 PRIMER (F-20.02) ON THIS SURFACE
- 2 THE PART NUMBER IS FOUND HERE
- 3 OVERSPRAY IS PERMITTED ON THIS HOLE
- 4 SEAL CONTACT AREA.
32 MICROINCHES RA SURFACE FINISH APPLIES ON THIS SURFACE ONLY
- 5 APPLY BMS 10-11, TYPE 2 ENAMEL (F-21.03) AS SHOWN IN SOPM 20-41-02 ON THIS SURFACE
- 6 APPLY BMS 10-11, TYPE 1 PRIMER, NO RUNS, BEADS, OR SAGS PERMITTED

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBER REFER TO IPL FIG. 1

ALL DIMENSIONS ARE IN INCHES

256A3519-2,-4 Housing Repair
Figure 602 (Sheet 10 of 10)

27-55-87

REPAIR 8-2
Page 618
Jul 01/2007



COMPONENT MAINTENANCE MANUAL

PINION - REPAIR 9-1

256A3524-1, -2

1. General

- A. This procedure has the data necessary to repair and refinish the pinion (210).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.
- D. General repair details:
 - (1) Material
 - (a) 256A3524-1: 9310 steel, 160-190 ksi
 - (b) 256A3524-2: 4340 steel, 160-180 ksi

2. Pinion Refinish

A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

B. Procedure (REPAIR 9-1, Figure 601)

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Cadmium plate (F-15.23) as shown.



27-55-87

REPAIR 9-1

Page 601

Nov 01/2006

COMPONENT MAINTENANCE MANUAL




256A3524-1,-2 Pinion Repair
Figure 601 (Sheet 1 of 2)

27-55-87

REPAIR 9-1
Page 602
Nov 01/2006



COMPONENT MAINTENANCE MANUAL



B-B

1 NO FINISH OR PLATING RUNOUT IN THIS SURFACE. PLATING RUNOUT ON ADJACENT SURFACE MUST NOT BE MORE THAN 0.030 WIDE

2 THROWN-IN PLATING IS PERMITTED

3 PART NUMBER LOCATION

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 1

ALL DIMENSIONS ARE IN INCHES

256A3524-1,-2 Pinion Repair
Figure 601 (Sheet 2 of 2)

27-55-87

REPAIR 9-1

Page 603

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

OUTPUT GEAR - REPAIR 10-1

256A3525-1, -2

1. General

- A. This procedure has the data necessary to repair and refinish the output gear (215).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.
- D. General repair details:
 - (1) Material
 - (a) 256A3525-1: 9310 steel, 160-190 ksi
 - (b) 256A3525-2: 4340 steel, 160-180 ksi

2. Output Gear Refinish

A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

B. Procedure (REPAIR 10-1, Figure 601)

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Cadmium plate (F-15.23) as shown.

27-55-87


REPAIR 10-1

Page 601

Nov 01/2006



COMPONENT MAINTENANCE MANUAL




256A3525-1,-2 Output Gear Repair
Figure 601 (Sheet 1 of 2)

27-55-87

REPAIR 10-1
Page 602
Nov 01/2006



COMPONENT MAINTENANCE MANUAL



A-A

1 NO FINISH OR PLATING RUNOUT ON THIS SURFACE. PLATING RUNOUT ON ADJACENT SURFACE MUST NOT BE MORE THAN 0.030 WIDE

2 PART NUMBER LOCATION

125 ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 1

ALL DIMENSIONS ARE IN INCHES

256A3525-1,-2 Output Gear Repair
Figure 601 (Sheet 2 of 2)

27-55-87

REPAIR 10-1

Page 603

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

PINION GEAR ASSEMBLY - REPAIR 11-1

256A3528-1, -2

1. General

- A. This procedure has the data necessary to replace the plug in the pinion gear assembly (220).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.

2. Shaft Plug Replacement

- A. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-60-02	FINISHING MATERIALS

- C. Procedure (REPAIR 11-1, Figure 601)

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01. For finishing materials, refer to SOPM 20-60-02.

- (1) Remove the bad plug (225) from the gear (230).
- (2) If you find defects on the gear, refer to REPAIR 11-2 for repair instructions.
- (3) Install a replacement plug (225) into the gear (230) with primer, C00259 as shown.


27-55-87

REPAIR 11-1

Page 601

Nov 01/2006

COMPONENT MAINTENANCE MANUAL



- 1 INSTALL THIS PLUG WITH WET
BMS 10-11 PRIMER (F-20.06).
REMOVE UNWANTED PRIMER

ITEM NUMBERS REFER TO IPL FIG. 1

256A3528-1,-3 Pinion Gear Assembly Repair
Figure 601

27-55-87

REPAIR 11-1

Page 602

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

PINION GEAR - REPAIR 11-2

256A3528-2, -4

1. General

- A. This procedure has the data necessary to repair and refinish the pinion gear (230).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.
- D. General repair details:
 - (1) Material
 - (a) 256A3528-2: 9310 steel, 160-190 ksi
 - (b) 256A3528-4: 4340 steel, 160-180 ksi
 - (2) Shot peen: Machined areas for chrome plate repair
 - (a) Shot Size 0.014-0.016
 - (b) Intensity 0.014A2
 - (c) Coverage 2.0

2. Pinion Gear Repair

- A. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

- B. References

Reference	Title
SOPM 20-10-01	REPAIR AND REFINISH OF HIGH STRENGTH STEEL PARTS
SOPM 20-10-02	MACHINING OF ALLOY STEEL
SOPM 20-10-03	SHOT PEENING
SOPM 20-10-04	GRINDING OF CHROME PLATED PARTS
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-42-03	HARD CHROME PLATING
SOPM 20-60-02	FINISHING MATERIALS

- C. Procedure (REPAIR 11-2, Figure 601)

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01. For finishing materials, refer to SOPM 20-60-02.

- (1) Machine as required, within repair limits, to remove defects (SOPM 20-10-01) (SOPM 20-10-02).
- (2) Shot peen as indicated (SOPM 20-10-03).

27-55-87

REPAIR 11-2

Page 601

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

- (3) Build up with chrome plate (SOPM 20-42-03).
- (4) Grind the chrome plate to design dimensions and finish SOPM 20-10-04.
- (5) Wipe the chrome plate with primer, C00259 (F-19.45).

3. Pinion Gear Refinish

A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

B. Procedure (REPAIR 11-2, Figure 601)

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Cadmium plate (F-15.23) as shown.


27-55-87

REPAIR 11-2

Page 602

Nov 01/2006

COMPONENT MAINTENANCE MANUAL




256A3528-2,-4 Pinion Gear Repair
Figure 601 (Sheet 1 of 3)

27-55-87

REPAIR 11-2
Page 603
Nov 01/2006

COMPONENT MAINTENANCE MANUAL



256A3528-2,-4 Pinion Gear Repair
Figure 601 (Sheet 2 of 3)

27-55-87

REPAIR 11-2
Page 604
Nov 01/2006



COMPONENT MAINTENANCE MANUAL

- 1 NO FINISH OR PLATING RUNOUT ON THIS SURFACE. PLATING RUNOUT ON ADJACENT SURFACE MUST NOT BE MORE THAN 0.030 INCHES WIDE
- 2 PART NUMBER LOCATION
- 3 CADMIUM PLATE THICKNESS 0.0002 MINIMUM ON THIS SURFACE
- 4 LIMIT FOR CHROME PLATE BUILDUP AND GRIND TO DESIGN DIMENSIONS AND FINISH

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 1

ALL DIMENSIONS ARE IN INCHES

256A3528-2,-4 Pinion Gear Repair
Figure 601 (Sheet 3 of 3)

27-55-87

REPAIR 11-2

Page 605

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

COUNTERSHAFT GEAR - REPAIR 12-1

256A3526-1, -2

1. General

- A. This procedure has the data necessary to repair and refinish the countershaft gear (250).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.
- D. General repair details:
 - (1) Material
 - (a) 256A3526-1: 9310 steel, 160-190 ksi
 - (b) 256A3526-2: 4340 steel, 160-180 ksi

2. Countershaft Gear Refinish

A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

B. Procedure (REPAIR 12-1, Figure 601)

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Cadmium plate (F-15.23) as shown.


27-55-87

REPAIR 12-1

Page 601

Nov 01/2006

COMPONENT MAINTENANCE MANUAL



256A3526-1,-2 Countershaft Gear Repair
Figure 601 (Sheet 1 of 2)

27-55-87


REPAIR 12-1

Page 602

Nov 01/2006



COMPONENT MAINTENANCE MANUAL



A-A

- 1 NO FINISH OR PLATING RUNOUT ON THIS SURFACE. PLATING RUNOUT ON ADJACENT SURFACE MUST NOT BE MORE THAN 0.030 WIDE
- 2 PART NUMBER LOCATION

- 125/63 ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY
- BREAK ALL SHARP EDGES
- ITEM NUMBERS REFER TO IPL FIG. 1
- ALL DIMENSIONS ARE IN INCHES

256A3526-1,-2 Countershaft Gear Repair
Figure 601 (Sheet 2 of 2)

27-55-87

REPAIR 12-1
Page 603
Nov 01/2006



COMPONENT MAINTENANCE MANUAL

PINION - REPAIR 13-1

256A3527-1, -2

1. General

- A. This procedure has the data necessary to repair and refinish the pinion (255).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.
- D. General repair details:
 - (1) Material
 - (a) 256A3527-1: 9310 steel, 160-190 ksi
 - (b) 256A3527-2: 4340 steel, 160-180 ksi
 - (2) Shot peen: Machined areas for chrome plate repair
 - (a) Shot Size 0.014-0.016
 - (b) Intensity 0.014A2
 - (c) Coverage 2.0

2. Pinion Gear Repair

- A. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

- B. References

Reference	Title
SOPM 20-10-01	REPAIR AND REFINISH OF HIGH STRENGTH STEEL PARTS
SOPM 20-10-02	MACHINING OF ALLOY STEEL
SOPM 20-10-03	SHOT PEENING
SOPM 20-10-04	GRINDING OF CHROME PLATED PARTS
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-42-03	HARD CHROME PLATING
SOPM 20-60-02	FINISHING MATERIALS

- C. Procedure (REPAIR 13-1, Figure 601)

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01. For finishing materials, refer to SOPM 20-60-02.

- (1) Machine as required, within repair limits, to remove defects (SOPM 20-10-01) (SOPM 20-10-02).
- (2) Shot peen as indicated (SOPM 20-10-03).

27-55-87

REPAIR 13-1
Page 601
Nov 01/2006



COMPONENT MAINTENANCE MANUAL

- (3) Build up with chrome plate (SOPM 20-42-03).
- (4) Grind the chrome plate to design dimensions and finish (SOPM 20-10-04).
- (5) Wipe the chrome plate with primer, C00259 (F-19.45).

3. Pinion Gear Refinish

A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

B. Procedure (REPAIR 13-1, Figure 601)

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Cadmium plate (F-15.23) as shown.


27-55-87

REPAIR 13-1

Page 602

Nov 01/2006

COMPONENT MAINTENANCE MANUAL




256A3527-1,-2 Pinion Repair
Figure 601 (Sheet 1 of 2)

27-55-87

REPAIR 13-1
Page 603
Nov 01/2006

COMPONENT MAINTENANCE MANUAL



1 NO FINISH OR PLATING RUNOUT ON THIS SURFACE. PLATING RUNOUT ON THE ADJACENT SURFACE MUST NOT BE MORE THAN 0.030 WIDE

2 PLATING THICKNESS 0.0002 MINIMUM ON THIS SURFACE

3 PART NUMBER LOCATION

4 LIMIT FOR CHROME PLATE BUILDUP AND GRINDING TO DESIGN DIMENSIONS

125 ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 1

ALL DIMENSIONS ARE IN INCHES

G59012 S0004994940_V2

256A3527-1,-2 Pinion Repair
Figure 601 (Sheet 2 of 2)

27-55-87

REPAIR 13-1

Page 604

Jul 01/2008



COMPONENT MAINTENANCE MANUAL

OUTPUT SHAFT ASSEMBLY - REPAIR 14-1

256A3523-1, -3

1. General

- A. This procedure has the data necessary to replace the inserts of the output shaft assembly (270).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.

2. Insert Replacement

- A. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

- B. References

Reference	Title
SOPM 20-50-22	HOW TO INSTALL THREADED INSERTS
SOPM 20-60-02	FINISHING MATERIALS

- C. Procedure (REPAIR 14-1, Figure 601)

NOTE: For finishing materials, refer to SOPM 20-60-02.

- (1) Remove the bad inserts (275) from the output shaft (280).
- (2) If you find defects on the shaft, refer to REPAIR 14-2 for repair instructions.
- (3) Install the replacement inserts (275) into the output shaft (280) with wet primer, C00259 (SOPM 20-50-22).


27-55-87

REPAIR 14-1

Page 601

Nov 01/2006

COMPONENT MAINTENANCE MANUAL



- 1 INSTALL THE INSERT WITH WET BMS 10-11, TYPE 1 PRIMER
- 2 PART NUMBER LOCATION
- 3 INSTALL THE INSERT 0.25-0.50 TURNS BELOW THIS SURFACE

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY
 BREAK ALL SHARP EDGES
 ITEM NUMBER REFER TO IPL FIG. 1
 ALL DIMENSIONS ARE IN INCHES

256A3523-1,-3 Output Shaft Assembly Repair
 Figure 601

27-55-87

REPAIR 14-1
 Page 602
 Nov 01/2006



COMPONENT MAINTENANCE MANUAL

SHAFT - REPAIR 14-2

256A3523-2, -4

1. General

- A. This procedure has the data necessary to repair and refinish the shaft (280).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.
- D. General repair details:
 - (1) Material
 - (a) 256A3523-2: 9310 steel, 160-190 ksi
 - (b) 256A3523-4: 4340 steel, 160-180 ksi

2. Shaft Refinish

- A. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-41-02	APPLICATION OF CHEMICAL AND SOLVENT RESISTANT FINISHES
SOPM 20-60-02	FINISHING MATERIALS

- C. Procedure (REPAIR 14-2, Figure 601)



NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01. For finishing materials, refer to SOPM 20-60-02.

- (1) Cadmium plate (F-15.23) as shown.
- (2) Apply primer, C00259 (F-20.02) to the bore. Use the fill and drain procedure (SOPM 20-41-02).

27-55-87

REPAIR 14-2
Page 601
Nov 01/2006

COMPONENT MAINTENANCE MANUAL



A

256A3523-2,-4 Output Shaft Repair
Figure 601 (Sheet 1 of 2)

27-55-87


REPAIR 14-2

Page 602

Nov 01/2006



COMPONENT MAINTENANCE MANUAL



- 1 NO FINISH OR PLATING RUNOUT ON THIS SURFACE. PLATING RUNOUT ON ADJACENT SURFACE MUST NOT BE MORE THAN 0.030 WIDE
- 2 PART NUMBER LOCATION
- 3 APPLY A LAYER OF BMS 10-11, TYPE 1 PRIMER (F-20.02) (SOPM 20-41-02) USE THE FILL AND DRAIN METHOD

- 125 ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY
- BREAK ALL SHARP EDGES
- ITEM NUMBER REFER TO IPL FIG. 1
- ALL DIMENSIONS ARE IN INCHES

256A3523-2,-4 Output Shaft Repair
Figure 601 (Sheet 2 of 2)

27-55-87



COMPONENT MAINTENANCE MANUAL

WORM GEAR ASSEMBLY - REPAIR 15-1

256A3540-1

1. General

- A. This procedure has the data necessary to repair and refinish the worm gear assembly (425).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.

2. Parts Replacement

- A. Do not disassemble the worm gear assembly (425) to replace its parts. The worm gear teeth, splines, and bolt holes are machined after the hub (428) and the rim (429) are assembled. Replace the worm gear assembly only as a unit.

3. Worm Gear Assembly Refinish

- A. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
G00009	Compound - Organic Corrosion Inhibiting	BMS3-23

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-44-02	TEMPORARY PROTECTIVE COATINGS
SOPM 20-60-02	FINISHING MATERIALS

- C. Procedure (REPAIR 15-1, Figure 601)

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01. For finishing materials, refer to SOPM 20-60-02.

- (1) Remove the protective finish from the worm gear assembly (425) surfaces identified by flagnote 2.
- (2) Apply no finish (F-25.01) to all surfaces except surfaces identified by flagnote 2. corrosion inhibiting compound, G00009 may be applied as temporary protection for handling, transportation and storage (SOPM 20-44-02).
- (3) Chemical treat (F-17.07) all surfaces of the worm gear assembly (425) identified by flagnote 2.

27-55-87


REPAIR 15-1

Page 601

Nov 01/2006



COMPONENT MAINTENANCE MANUAL




256A3540-1 Worm Gear Assembly Repair
Figure 601 (Sheet 1 of 2)

27-55-87

REPAIR 15-1
Page 602
Nov 01/2006

COMPONENT MAINTENANCE MANUAL



A-A

1 PART NUMBER LOCATION

ITEM NUMBERS REFER TO IPL FIG. 1

2 CHEMICAL TREAT (F-17.07)
THIS SURFACE

256A3540-1 Worm Gear Assembly Repair
Figure 601 (Sheet 2 of 2)

27-55-87

REPAIR 15-1
Page 603
Nov 01/2006



COMPONENT MAINTENANCE MANUAL

ASSEMBLY

1. General

- A. This procedure has the data necessary to assemble the gearbox assembly.
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.

2. Assembly

A. Tools/Equipment

NOTE: Equivalent substitutes may be used.

Reference	Description
SPL-4811	Test Equip - Run-In, Variable Drive (115 VAC) (Opt Part #: J27056-43, Supplier: 81205) (Opt Part #: J27056-45, Supplier: 81205)
SPL-4812	Test Equip - Run-In, Variable Drive (230 VAC) (Opt Part #: J27056-44, Supplier: 81205) (Opt Part #: J27056-46, Supplier: 81205)
SPL-5384	Wrench - Coupling Sleeve Flap Actuation (Part #: C27041-1, Supplier: 81205)
SPL-5385	Seal Installation Equipment, TE Flap Drive (Part #: C27043-16, Supplier: 81205)
SPL-5703	Test Equipment - T.E. Flap Drive Gearboxes (Part #: C27068-65, Supplier: 81205)

B. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
A00028	Adhesive - Modified Epoxy For Rigid PVC, Foam Cored Sandwiches	BAC5010, Type 70 (BMS5-92, Type 1)
A50055	Adhesive - Two-Part, RT Cure, Urethane	BAC5010, Type 89 (BMS5-105)
C00913	Compound - Corrosion Inhibiting Material, Nondrying Resin Mix	BMS 3-27
D00467	Fluid - Landing Gear Shock Strut	BMS3-32, Type II
D00633	Grease - Aircraft General Purpose	BMS3-33
D50011	Grease - Perfluoropolyether - Christo-lube MCG111	
G01912	Lockwire - Monel (0.032 In. Dia.)	NASM20995N~ C32 (QQ-N-281)
G50136	Paste - Corrosion Inhibiting, Non-drying	BMS 3-38

27-55-87

ASSEMBLY

Page 701

Jul 01/2009



COMPONENT MAINTENANCE MANUAL

C. References

Reference	Title
SOPM 20-41-05	APPLICATION OF CORROSION INHIBITING COMPOUNDS
SOPM 20-50-01	BOLT AND NUT INSTALLATION
SOPM 20-50-02	INSTALLATION OF SAFETYING DEVICES
SOPM 20-50-03	BEARING AND BUSHING REPLACEMENT
SOPM 20-50-06	INSTALLATION OF O-RINGS AND TEFLON SEALS
SOPM 20-60-02	FINISHING MATERIALS
SOPM 20-60-03	LUBRICANTS
SOPM 20-60-04	MISCELLANEOUS MATERIALS

D. Procedure (ASSEMBLY, Figure 701)

NOTE: For finishing materials, refer to SOPM 20-60-02. For lubricants, refer to SOPM 20-60-03. For miscellaneous materials, refer to SOPM 20-60-04.

(1) General

- (a) Use standard industry procedures and the steps given in this procedure to assemble this component.
- (b) Install seals (70, 100, 115, 340) as shown in SOPM 20-50-06, and also use these precautions:
 - 1) Lubricate the seal bore in the housing with the applicable grease, D00633.
 - 2) Be careful to prevent damage to the lips of the seal during installation. Use a C27043 Seal Installation Tool, SPL-5385 that applies pressure equally to the full circumference of the seal, as near as possible to the O.D.
 - 3) Apply a large quantity of grease, D00633 to the lips of the seal.
 - 4) Install the seal to the depth given in the instructions.

WARNING: BMS 3-27 CORROSION INHIBITING COMPOUND CONTAINS SOLVENTS, CHROMATES, AND A SMALL AMOUNT OF BOUND ASBESTOS. CONSULT THE APPLICABLE SAFETY STANDARDS FOR APPROVED HANDLING PROCEDURES.

CAUTION: BMS 3-27 COMPOUND IS USED ONLY IN STATIC JOINTS WHERE GREASE CANNOT BE APPLIED. BMS 3-27 COMPOUND IN DYNAMIC JOINTS WILL NOT LET THEM MOVE FREELY.

- (c) Seal the covers (10, 90, 370) and retainers (65, 110, 112) to the housing assemblies (165, 290), and the housing assemblies to each other, with corrosion inhibiting compound, C00913 (assemblies 256A3515-1, 2) or corrosion inhibiting non-drying paste, G50136 (assemblies 251A3515-3, -4) (SOPM 20-41-05). Apply the material as follows:
 - 1) Apply the compound or paste as a thin film to the faying surface of the flange of the cover or retainer. Apply the material from the outer profile to approximately 0.05 inch from the fillet radius.
 - 2) Apply the compound or paste as a thin film to the faying surface between the housing assemblies. Apply the material from the outer profile to approximately 0.05 inch from the O-ring groove. Remove the unwanted material after assembly.

27-55-87

ASSEMBLY
Page 702
Nov 01/2006



COMPONENT MAINTENANCE MANUAL

- (2) Install the bearings (285, 355, and 400) in the housing assembly (290) (SOPM 20-50-03).
- (3) Install the shim, worm gear (424) or worm gear assembly (425), and the shaft (420) in the housing assembly (290).

NOTE: Select the shim thickness from shims (405, 410, 415). Use only one shim. Shim measured during disassembly can be used provided that gears and bearings were not changed.

- (4) Install the packing (350) in the seal ring (345) with fluid, D00467.
- (5) Install the seal ring (345) with the packing (350) on the shaft (420).
- (6) Apply fluid, D00467 to the outer diameter of the seal ring (345) and to the seal (340) inside diameter and lips.
- (7) Install the seal (340) on the seal ring (345) to a depth of 0.10- 0.11 inch as shown in flagnote 5.

WARNING: BMS 3-27 CORROSION INHIBITING COMPOUND CONTAINS SOLVENTS, CHROMATES, AND A SMALL AMOUNT OF BOUND ASBESTOS. CONSULT THE APPLICABLE SAFETY STANDARDS FOR APPROVED HANDLING PROCEDURES.

CAUTION: BMS 3-27 COMPOUND IS USED ONLY IN STATIC JOINTS WHERE GREASE CANNOT BE APPLIED. BMS 3-27 COMPOUND IN DYNAMIC JOINTS WILL NOT LET THEM MOVE FREELY.

- (8) Apply corrosion inhibiting compound, C00913 or corrosion inhibiting non-drying paste, G50136, as applicable, to the faying surfaces of the cover (10) and the housing assembly (290) as identified by flagnote 4.
- (9) Apply corrosion inhibiting compound, C00913 to all of the shank and threads of the screws (5) as shown by flagnote 14. Remove unwanted corrosion inhibiting compound, C00913 from the ends of the screws before installation.
- (10) Install the cover (10) on the housing assembly (290) with the screws (5).
- (11) Apply grease, D00633 on the drum (335) splines.
- (12) Fill the space between the seal (340) and the drum (335) with grease, D00633 as shown by flagnote 3.
- (13) Install the drum (335) on the shaft (420) with the washer (330) and nut (325). Tighten the nut (325) to 100-120 pound-inches more than the run-on torque as shown in flagnote 7 (SOPM 20-50-01).
- (14) Install the packing (375) on the cover (370) with fluid, D00467.
- (15) Calculate the shim thickness as shown in flagnote 11.

NOTE: Select the shim thickness from shims (405, 410, 415). Use only one shim. Shims measured during disassembly can be used if the gears and bearings were not changed.

- (16) Install the shims (380 thru 395) into the housing assembly (290).

WARNING: BMS 3-27 CORROSION INHIBITING COMPOUND CONTAINS SOLVENTS, CHROMATES, AND A SMALL AMOUNT OF BOUND ASBESTOS. CONSULT THE APPLICABLE SAFETY STANDARDS FOR APPROVED HANDLING PROCEDURES.

27-55-87

ASSEMBLY

Page 703

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

(WARNING PRECEDES)

CAUTION: BMS 3-27 COMPOUND IS USED ONLY IN STATIC JOINTS WHERE GREASE CANNOT BE APPLIED. BMS 3-27 COMPOUND IN DYNAMIC JOINTS WILL NOT LET THEM MOVE FREELY.

- (17) Apply corrosion inhibiting compound, C00913 or corrosion inhibiting non-drying paste, G50136, as applicable, to the faying surfaces of the cover (370) and the housing assembly (290) as identified by flagnote 4.
- (18) Apply corrosion inhibiting compound, C00913 to all of the shank and threads of the bolts (360) as shown by flagnote 14. Remove unwanted corrosion inhibiting compound, C00913 from the ends of the bolts before installation.
- (19) Install the cover (370) on the housing assembly (290) with the washers (365) and bolts (360).
- (20) Install the output shaft assembly (270) in the housing assembly (290) and the bearing (285).
- (21) Install the bearings (195, 235) in the housing assembly (290).
- (22) Assemble the countershaft gear (250), bearing (200), and the pinion (210).
 - (a) Apply grease, D00633 on the countershaft gear (250) spline as shown in flagnote 6.
 - (b) Install the countershaft gear (250) and the bearing (200) on the pinion (210).
 - (c) Install the washer (260) and the nut (265) on the pinion (210). Tighten the nut (265) to 500-600 pound-inches more than the run-on torque, as identified by flagnote 13 (SOPM 20-50-01).
- (23) Install the pinion (210) with associated parts in the housing assembly (290).
- (24) Install the pinion (255) in the bearing (195) as shown in ASSEMBLY, Figure 701, Section D-D.
- (25) Apply grease, D00633 to the output gear (215) spline as shown in flagnote 6.
- (26) Install the output gear (215) on the output shaft assembly (270) as shown in ASSEMBLY, Figure 701, Section B-B.
- (27) Apply grease, D00633 on the shearout (245) spline as shown in flagnote 6.
- (28) Install the shearout (245) in the pinion gear assembly (220) with the retainer (240).
- (29) Install the pinion gear assembly (220) with the associated parts in the bearing (235).
- (30) Install the bearings (195, 200, 205, 285) in the housing assembly (165).
- (31) Install the packing (190) in the housing assembly (165) with fluid, D00467 as shown by flagnote 2.

WARNING: BMS 3-27 CORROSION INHIBITING COMPOUND CONTAINS SOLVENTS, CHROMATES, AND A SMALL AMOUNT OF BOUND ASBESTOS. CONSULT THE APPLICABLE SAFETY STANDARDS FOR APPROVED HANDLING PROCEDURES.

CAUTION: BMS 3-27 COMPOUND IS USED ONLY IN STATIC JOINTS WHERE GREASE CANNOT BE APPLIED. BMS 3-27 COMPOUND IN DYNAMIC JOINTS WILL NOT LET THEM MOVE FREELY.

- (32) Apply corrosion inhibiting compound, C00913 or corrosion inhibiting non-drying paste, G50136, as applicable, to the faying surfaces of the housing assemblies (165, 290) as shown by flagnote 4.
- (33) Apply corrosion inhibiting compound, C00913 to all of the shank and threads of the bolts (120, 125) as shown in flagnote 14. Remove unwanted corrosion inhibiting compound, C00913 from the ends of the bolts before installation.

27-55-87

ASSEMBLY

Page 704

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

- (34) Install the housing assembly (165) and the associated parts on the housing assembly (290) with the bolts (120, 125), washers (130, 135), and nuts (140).
- (35) Install the seal (100) on the pinion gear assembly (220) to a depth of 0.25-0.26 inch as shown in flagnote 5.
- (36) Install the packing (95) on the cover (90) with fluid, D00467 as shown in flagnote 2.

WARNING: BMS 3-27 CORROSION INHIBITING COMPOUND CONTAINS SOLVENTS, CHROMATES, AND A SMALL AMOUNT OF BOUND ASBESTOS. CONSULT THE APPLICABLE SAFETY STANDARDS FOR APPROVED HANDLING PROCEDURES.

CAUTION: BMS 3-27 COMPOUND IS USED ONLY IN STATIC JOINTS WHERE GREASE CANNOT BE APPLIED. BMS 3-27 COMPOUND IN DYNAMIC JOINTS WILL NOT LET THEM MOVE FREELY.

- (37) Apply corrosion inhibiting compound, C00913 or corrosion inhibiting non-drying paste, G50136, as applicable, to the faying surfaces of the housing assembly (290) and the cover (90) as shown by flagnote 4.
- (38) Apply corrosion inhibiting compound, C00913 to all of the shank and threads of the bolts (85) as shown by flagnote 14. Remove unwanted corrosion inhibiting compound, C00913 from the ends of the bolts before installation.
- (39) Install the cover (90) on the housing assembly (290) with the washers (88) and the bolts (85).
- (40) Attach the cable (145A) and the ferrules (150) to the housing assembly (165) and the cover (90). Make a loop at each end of the cable and crimp the ferrules as shown in Boeing Standard BACC13Y.
- (41) Install the seals (115) on the pinion gear assembly (220) and the pinion (255) to a depth of 0.32-0.33 inch as shown by flagnote 5.

WARNING: BMS 3-27 CORROSION INHIBITING COMPOUND CONTAINS SOLVENTS, CHROMATES, AND A SMALL AMOUNT OF BOUND ASBESTOS. CONSULT THE APPLICABLE SAFETY STANDARDS FOR APPROVED HANDLING PROCEDURES.

CAUTION: BMS 3-27 COMPOUND IS USED ONLY IN STATIC JOINTS WHERE GREASE CANNOT BE APPLIED. BMS 3-27 COMPOUND IN DYNAMIC JOINTS WILL NOT LET THEM MOVE FREELY.

- (42) Apply corrosion inhibiting compound, C00913 or corrosion inhibiting non-drying paste, G50136, as applicable, to the faying surfaces of the housing assemblies (165, 290) and the retainers (110, 112) as shown by flagnote 4.
- (43) Apply corrosion inhibiting compound, C00913 to all of the shank and threads of the bolts (105) as shown in flagnote 14. Remove unwanted corrosion inhibiting compound, C00913 from the ends of the bolts before installation.
- (44) If retainer (110B or 110D) is used, install the applicable NAS1611-131 packing on the O.D. with fluid, D00467. Apply a large quantity of Christo-lube MCG111 grease, D50011 to the excluder seal on the I.D. of the retainer (110B or 110D). Install the retainers (110, 112) on the housing assemblies (165, 290) with the bolts (105).
- (45) Install the packings (80) in the seal rings (75) with fluid, D00467 as shown in flagnote 2.
- (46) Install the seal rings (75) with the packings (80) on the output shaft assembly (270) as shown in ASSEMBLY, Figure 701, Section B-B.

27-55-87

ASSEMBLY

Page 705

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

(47) Install the seals (70) on the seal rings (75) to a depth of 0.17-0.18 inch as shown in flagnote 5.

WARNING: BMS 3-27 CORROSION INHIBITING COMPOUND CONTAINS SOLVENTS, CHROMATES, AND A SMALL AMOUNT OF BOUND ASBESTOS. CONSULT THE APPLICABLE SAFETY STANDARDS FOR APPROVED HANDLING PROCEDURES.

CAUTION: BMS 3-27 COMPOUND IS USED ONLY IN STATIC JOINTS WHERE GREASE CANNOT BE APPLIED. BMS 3-27 COMPOUND IN DYNAMIC JOINTS WILL NOT LET THEM MOVE FREELY.

- (48) Apply corrosion inhibiting compound, C00913 or corrosion inhibiting non-drying paste, G50136, as applicable, to the faying surfaces of the retainers (65) and the housing assemblies (165, 290) as shown in flagnote 4.
- (49) Apply corrosion inhibiting compound, C00913 to all of the shank and threads of the bolts (55). Remove unwanted corrosion inhibiting compound, C00913 from the ends of the bolts before installation.
- (50) Install the retainers (65) on the housing assemblies (165, 290) with the washers (60) and the bolts (55).
- (51) Fill the space between the retainers (65) and the seal rings (75) with grease, D00633 as shown in flagnote 3.
- (52) Install the seal shields (50) on the output shaft assembly (270) as shown in ASSEMBLY, Figure 701, Section B-B.
- (53) Install the coupling seals (45) on the coupling halves (40).
- (54) Apply grease, D00633 to the coupling sleeve (25) splines as shown by flagnote 6.
- (55) Install the coupling sleeves (25) on the coupling halves (40).
- (56) Apply grease, D00633 on the splines of the coupling halves (40) as shown in flagnote 6.
- (57) Install the coupling halves (40) on the output shaft assembly (270).
- (58) Install the packings (35) on the bolts (30) with grease, D00633 (SOPM 20-50-06).
- (59) Install the bolts (30) and the packings (35) in the output shaft assembly (270) as shown in flagnotes 15 and 16. Use the C27041 coupling sleeve wrench, SPL-5384 to hold the coupling sleeve and tighten the bolt (30) to 600-720 pound-inches more than the run-on torque as shown in flagnote 16 (SOPM 20-50-01).
- (60) Install the packing (160) on the union (155) with fluid, D00467 as shown by flagnote 2 and in View F-F of ASSEMBLY, Figure 701.
- (61) Install the union (155) on the housing assembly (165) with fluid, D00467 as shown in flagnote 17.
- (62) Install the packings (320) on the plugs (315) with fluid, D00467 as shown by flagnote 2.
- (63) Install the plug (315) and the packing (320) on the bottom of the housing assembly (290) as shown in ASSEMBLY, Figure 701, sheet 1, and flagnote 17.
- (64) Fill the gearbox assembly with fluid, D00467 as shown in ASSEMBLY, Figure 701, View E-E and flagnote 23.
- (65) Install the plug (315) and the packing (320) at the upper location on the housing assembly (290) as shown in flagnote 17.
- (66) Do a run-in test.

27-55-87

ASSEMBLY
Page 706
Jul 01/2008



COMPONENT MAINTENANCE MANUAL

- (a) Install the gearbox assembly on the C27068 T.E. Flap Drive Gearbox Test Equipment, SPL-5703 (C27068-65 supersedes C27068-1). Connect the run-in J27056 test equip 115 VAC, SPL-4811 or test equip 230 VAC, SPL-4812.
 - (b) Manually turn the shaft assembly (270) one or more revolutions in each direction.
 - (c) Make sure that the gears (215, 220, 250, 420) and the bearings (195, 200, 205, 235, 285, 335, 400) turn smoothly.
 - (d) Operate the gearbox at an output shaft speed of 500-600 rpm for 15 minutes in both the clockwise and counterclockwise directions.
- (67) Install lockwire, G01912 between the housing assembly (290) and the plug (315) (SOPM 20-50-02 and flagnote 24).
- (68) Install the cable assemblies (20) on the drum (335) with the cotter pins (15) as shown by flagnotes 18 and 19.
- (69) Manually turn the shaft assembly (270) one or more revolutions in each direction.
- (70) Make sure that the gears and the bearings turn smoothly with no indication of binding.
- (71) If necessary, install the markers (430 thru 445) on the housing assemblies (165, 290) as shown in ASSEMBLY, Figure 701 and apply urethane adhesive, A50055 or adhesive, A00028 per flagnote 25. Refer to REPAIR 2-1, Paragraph 4..
- (72) Do a pressure test of the assembly. Refer to TESTING AND FAULT ISOLATION.


27-55-87

ASSEMBLY

Page 707

Nov 01/2006

COMPONENT MAINTENANCE MANUAL




Gearbox Assembly
Figure 701 (Sheet 1 of 10)

27-55-87

ASSEMBLY
Page 708
Nov 01/2006

COMPONENT MAINTENANCE MANUAL



A-A

Gearbox Assembly
Figure 701 (Sheet 2 of 10)


27-55-87

ASSEMBLY

Page 709

Nov 01/2006

COMPONENT MAINTENANCE MANUAL




Gearbox Assembly
Figure 701 (Sheet 3 of 10)


27-55-87

ASSEMBLY
Page 710
Nov 01/2006

COMPONENT MAINTENANCE MANUAL



(A)



(B)

INSTALLATION OF RETAINER WITH EXCLUDER SEAL


(C)

Gearbox Assembly
Figure 701 (Sheet 4 of 10)

27-55-87

ASSEMBLY
Page 711
Nov 01/2006

COMPONENT MAINTENANCE MANUAL




Gearbox Assembly
Figure 701 (Sheet 5 of 10)

27-55-87

ASSEMBLY
Page 712
Nov 01/2006

COMPONENT MAINTENANCE MANUAL




Gearbox Assembly
Figure 701 (Sheet 6 of 10)

27-55-87

ASSEMBLY
Page 713
Nov 01/2006

COMPONENT MAINTENANCE MANUAL



Gearbox Assembly
Figure 701 (Sheet 7 of 10)


27-55-87

ASSEMBLY

Page 714

Nov 01/2006

COMPONENT MAINTENANCE MANUAL



F-F

Gearbox Assembly
Figure 701 (Sheet 8 of 10)

27-55-87

ASSEMBLY
Page 715
Nov 01/2006



COMPONENT MAINTENANCE MANUAL

- 1 USE ONLY ONE SHIM. SELECT SHIM THICKNESS FROM SHIMS (405 THRU 415)
- 2 INSTALL PACKING WITH BMS 3-32, TYPE II FLUID
- 3 FILL SPACE WITH BMS 3-33 GREASE
- 4 APPLY A THIN LAYER OF BMS 3-27 COMPOUND OR BMS 3-38 PASTE TO THE FAYING SURFACE
- 5 APPLY THE APPLICABLE LUBRICANT TO SEAL BORE. APPLY EQUAL PRESSURE TO THE FULL CIRCUMFERENCE NEAR THE EDGE OF THE SEAL. APPLY A LARGE QUANTITY OF LUBRICANT TO THE SEAL LIP
- 6 APPLY BMS 3-33 GREASE TO THE SPLINE
- 7 INSTALL THE NUT WITH BMS 3-33 GREASE. TIGHTEN TO 100-120 POUND-INCHES MORE THAN THE RUN-ON TORQUE
- 8 DIMENSION "W1" IS THE ACTUAL WIDTH OF THE BEARING OUTER RACE TO THE NEAREST 0.001 INCH
- 9 DIMENSION "A" IS THE ACTUAL SHOULDER DEPTH IN THE HOUSING TO THE NEAREST 0.001 INCH
- 10 DIMENSION "B" IS THE ACTUAL LENGTH OF THE COVER
- 11 CALCULATE SHIM THICKNESS AS $S1=A-W1-B+0.001$ INCH. ACTUAL SHIM THICKNESS MUST BE ± 0.0015 OF CALCULATED THICKNESS
- 12 SHIM STACK MUST USE THE MINIMUM NUMBER OF SHIMS. IT IS NOT REQUIRED TO USE ALL SHIM THICKNESSES
- 13 INSTALL THE NUT WITH BMS 3-33 GREASE. TIGHTEN TO 500-600 POUND-INCHES MORE THAN THE RUN-ON TORQUE
- 14 APPLY BMS 3-27 COMPOUND TO ALL OF THE SHANK AND THREADS OF THE BOLT. REMOVE THE UNWANTED COMPOUND FROM THE END OF THE BOLT
- 15 APPLY BMS 3-33 GREASE TO THIS FAYING SURFACE
- 16 INSTALL THE BOLT WITH BMS 3-33 GREASE. TIGHTEN TO 600-720 POUND-INCHES MORE THAN THE RUN-ON TORQUE
- 17 APPLY BMS 3-32, TYPE II FLUID TO THE PLUG/UNION. TIGHTEN TO 110-130 POUND-INCHES MORE THAN THE RUN-ON TORQUE
- 18 COTTER PIN EYE MUST BE SEATED FIRMLY SO THAT THERE IS MINIMUM AXIAL MOVEMENT OF THE PIN AFTER INSTALLATION
- 19 ALIGN THE BLACK RIG MARK ON THE CABLE DRUM WITH THE WHITE CABLE GUARD ON THE HOUSING. INSTALL UPPER CABLE WITH 0.0-0.5 WRAPS AND THE LOWER CABLE WITH 2.0-2.5 WRAPS ON THE CABLE DRUM
- 20 INSTALL THIS WASHER UNDER THE BOLT HEAD
- 21 INSTALL THIS WASHER UNDER THE NUT
- 22 INSTALL THIS CABLE AND FERRULES AT ASSEMBLY
- 23 FILL THE GEARBOX ASSEMBLY WITH BMS 3-32, TYPE II FLUID UP TO THE LEVEL OF THIS PLUG
- 24 USE THE DOUBLE TWIST METHOD TO INSTALL THE MS20995C32 LOCKWIRE
- 25 APPLY ADHESIVE TO ALL OF THE FAYING SURFACE OF THE MARKER
- 26 INSTALL PACKING WITH BMS 3-33 GREASE

Gearbox Assembly
Figure 701 (Sheet 9 of 10)

27-55-87

ASSEMBLY
Page 716
Nov 01/2006



COMPONENT MAINTENANCE MANUAL

26 FILL THE SPACE BEHIND THE
EXCLUDER SEAL WITH CHRISTO-LUBE
MCG111

ITEM NUMBERS REFER TO IPL FIG. 1

Gearbox Assembly
Figure 701 (Sheet 10 of 10)

27-55-87


ASSEMBLY

Page 717

Nov 01/2006


COMPONENT MAINTENANCE MANUAL

FITS AND CLEARANCES



Fits and Clearances
Figure 801 (Sheet 1 of 8)


COMPONENT MAINTENANCE MANUAL



A-A

Fits and Clearances
Figure 801 (Sheet 2 of 8)


COMPONENT MAINTENANCE MANUAL



B-B


Fits and Clearances
Figure 801 (Sheet 3 of 8)

COMPONENT MAINTENANCE MANUAL



Fits and Clearances
Figure 801 (Sheet 4 of 8)

COMPONENT MAINTENANCE MANUAL



D-D

Fits and Clearances
Figure 801 (Sheet 5 of 8)



COMPONENT MAINTENANCE MANUAL

REF LETTER	REF IPL	DESIGN DIMENSION*				SERVICE WEAR LIMIT*		
	FIG. 1, MATING ITEM NO.	DIMENSION		ASSEMBLY CLEARANCE		DIMENSION		MAXIMUM CLEARANCE
		MIN	MAX	MIN	MAX	MIN	MAX	
[A]	ID 310	1.8506	1.8514	0.0002	0.0015	1.8497	1.8518	0.0021
	OD 285	1.8499	1.8504					
[B]	ID 285	0.9839	0.9843	-0.0001	0.0008	0.9833	0.9845	0.0012
	OD 280	0.9835	0.9840					
[C]	ID 180	2.4411	2.4419	0.0002	0.0015	2.4404	2.4423	0.0022
	OD 205	2.4404	2.4409					
[D]	ID 205	1.1807	1.1811	-0.0001	0.0008	1.1801	1.1813	0.0012
	OD 280	1.1803	1.1808					
[E]	ID 310	1.6537	1.6545	0.0002	0.0015	1.6528	1.6549	0.0021
	OD 200	1.6530	1.6535					
[F]	ID 180	1.6537	1.6545	0.0002	0.0015	1.6528	1.6549	0.0021
	OD 200	1.6530	1.6535					
[G]	ID 200	0.7870	0.7874	-0.0008	-0.0001	0.7873	0.7876	0.0003
	OD 210	0.7875	0.7878					
[H]	ID 310	2.1656	2.1664	0.0002	0.0015	2.1646	2.1668	0.0022
	OD 235	2.1649	2.1654					
[I]	ID 235	1.1807	1.1811	-0.0008	-0.0001	1.1810	1.1813	0.0003
	OD 230	1.1812	1.1815					

G56672 S0004994966_V2

Fits and Clearances
Figure 801 (Sheet 6 of 8)

27-55-87



FITS AND CLEARANCES

Page 806

Jul 01/2009



COMPONENT MAINTENANCE MANUAL






REF LETTER	REF IPL	DESIGN DIMENSION*				SERVICE WEAR LIMIT*		
	FIG. 1, MATING ITEM NO.	DIMENSION		ASSEMBLY CLEARANCE 		DIMENSION		MAXIMUM CLEARANCE
		MIN	MAX	MIN	MAX	MIN	MAX	
[J]	ID 180	2.4411	2.4419	0.0002	0.0015	2.4401	2.4423	0.0022
	OD 195	2.4404	2.4409					
[K]	ID 195	1.3775	1.3781	-0.0010	-0.0001	1.3779	1.3782	0.0022
	OD 230	1.3781	1.3785					
[L]	ID 310	2.4411	2.4419	0.0002	0.0015	2.4401	2.4423	0.0022
	OD 195	2.4404	2.4409					
[M]	ID 195	1.3775	1.3780	-0.0010	-0.0001	1.3779	1.3782	0.0003
	OD 255	1.3781	1.3785					
[N]	ID 180	1.8506	1.8514	0.0002	0.0015	1.8596	1.8518	0.0022
	OD 285	1.8499	1.8504					
[O]	ID 285	0.9839	0.9843	-0.0008	-0.0001	0.9842	0.9845	0.0003
	OD 255	0.9844	0.9847					
[P]	ID 310	1.6546	1.6553	0.0011	0.0023	1.6528	1.6555	0.0027
	OD 355	1.6530	1.6535					
[Q]	ID 355	0.9839	0.9843	-0.0001	0.0007	0.9833	0.9845	0.0012
	OD 420	0.9835	0.9840					
[R]	ID 310	1.8515	1.8522	0.0011	0.0023	1.8497	1.8524	0.0027
	OD 400	1.8499	1.8504					
[S]	ID 400	1.1807	1.1811	-0.0008	-0.0002	1.1807	1.1813	0.0006
	OD 420	1.1809	1.1815					
[T]	OD 215 	3.5835	3.5859	0.0040	0.0060	2.1501	3.5835	0.0080
	OD 210	2.1521	2.1542					

G56695 S0004994967_V2


Fits and Clearances
Figure 801 (Sheet 7 of 8)


27-55-87
FITS AND CLEARANCES
Page 807
Jul 01/2009


COMPONENT MAINTENANCE MANUAL


REF LETTER	REF IPL	DESIGN DIMENSION*				SERVICE WEAR LIMIT*		
	FIG. 1, MATING ITEM NO.	DIMENSION		ASSEMBLY CLEARANCE 		DIMENSION		MAXIMUM CLEARANCE
		MIN	MAX	MIN	MAX	MIN	MAX	
[U]	OD 250 	3.1484	3.1507	0.0040	0.0060	3.1460	3.1484	0.0080
	OD 230	1.9067	1.9087			1.9047	1.9067	
[V]	OD 250 	3.1484	3.1507	0.0040	0.0060	3.1460	3.1484	0.0080
	OD 255	3.1484	3.1507			3.1460	3.1484	
[W]	OD 425  			0.0020	0.0060			0.0080
	OD 270	1.0372	1.0427			1.0357	1.0372	

* ALL DIMENSIONS ARE IN INCHES

 NEGATIVE VALUE INDICATES INTERFERENCE.

 BEFORE DISASSEMBLY, HOLD WORM GEAR ASSEMBLY WITH HOUSING TO PREVENT ANGULAR AND AXIAL MOVEMENT OF THE GEAR. MEASURE THE ANGULAR BACKLASH OF THE WORM GEAR AT PITCH DIAMETER OF THE OUTPUT SHAFT ASSEMBLY AFTER DISASSEMBLY, CHECK THE WORM GEAR ASSEMBLY AND OUTPUT SHAFT ASSEMBLY FOR EVIDENCE OF TOOTH WEAR. REPLACE BOTH PARTS IF THE MEASUREMENT ON THE WORM GEAR IS EQUAL TO OR LESS THAN THE MINIMUM SERVICE WEAR LIMIT AND THE TOTAL ASSEMBLY BACKLASH IS MORE THAN THE SERVICE WEAR LIMIT. REPLACE ONLY WORM GEAR IF ASSEMBLY BACKLASH IS MORE THAN THE SERVICE WEAR LIMIT.

 WHEN MEASURING SPLINE TEETH DIAMETER OVER TWO PINS, USE 0.1200 INCH DIAMETER PINS

 WHEN MEASURING SPLINE TEETH DIAMETER OVER TWO WIRES, USE 0.480 INCH DIAMETER WIRES

G56710 S0004994968_V2

Fits and Clearances
Figure 801 (Sheet 8 of 8)

27-55-87
FITS AND CLEARANCES
Page 808
Jul 01/2009



COMPONENT MAINTENANCE MANUAL

SPECIAL TOOLS, FIXTURES, AND EQUIPMENT

1. General

A. This section lists the special tools, fixtures, and equipment necessary for maintenance.

NOTE: Equivalent substitutes may be used.

Special Tools

Reference	Description	Part Number	Supplier
SPL-4720	Test Equipment - Leakage Test	J27054-1	81205
SPL-4811	Test Equip - Run-In, Variable Drive (115 VAC)	Opt: J27056-43	81205
		Opt: J27056-45	81205
SPL-4812	Test Equip - Run-In, Variable Drive (230 VAC)	Opt: J27056-44	81205
		Opt: J27056-46	81205
SPL-5384	Wrench - Coupling Sleeve Flap Actuation	C27041-1	81205
SPL-5385	Seal Installation Equipment, TE Flap Drive	C27043-16	81205
SPL-5703	Test Equipment - T.E. Flap Drive Gearboxes	C27068-65	81205

Tool Supplier Information

CAGE Code	Supplier Name	Supplier Address
81205	THE BOEING COMPANY	17930 INTERNATIONAL BLVD. SOUTH SEATAC, WA 98188-4321 Telephone: 206-662-6650 Facsimile: 206-662-7145

27-55-87

SPECIAL TOOLS, FIXTURES, AND EQUIPMENT

Page 901

Jul 01/2009



COMPONENT MAINTENANCE MANUAL

ILLUSTRATED PARTS LIST

1. Introduction

- A. The Illustrated Parts List (IPL) contains an illustration and a list of component parts you can repair or replace. The Illustrated Parts Catalog (IPC) shows how to use the Boeing part number system.
- B. This shows how parts are related: The relation of each item to its next higher assembly (NHA) is shown in the NOMENCLATURE column. Use the indenture system that follows:

1	2	3	4	5	6	7
.	Assembly					
.	Attaching parts for assembly					
.	.	Detail parts for assembly				
.	.	Subassembly				
.	.	Attaching parts for subassembly				
.	.	.	Detail parts for subassembly			
.	.	.	Sub-subassembly			
.	.	.	Attaching parts for subassembly			
.	.	.	.	Details parts for sub-subassembly		
						Detail Installation Parts (Included only if installation parts may be sent to the shop as part of assembly)

- C. Each top assembly is given one use code letter (A, B, C, etc.) in the USAGE CODE column. All subsequent component parts in the list can have one or more of the use code letters to show effectivity to top assemblies. A component part without a use code applies to all top assemblies.
- D. An alphabetical letter is added after the item number for optional parts, parts changed by a Service Bulletin, configuration differences (except left-handed and right-handed parts), last engineering releases, and parts added between item numbers in a sequence. The alphabetical letter will not be shown on the illustration for equivalent parts of the same part number.
- E. Color-coded parts are identified with a single digit alpha following the dash number or with "SP" suffix. If the "SP" suffix is used, it represents consolidation of all color codes applicable for a given usage which are not separately listed. Orders for color-coded parts should include the registry number of the airplane for which the parts are ordered.
- F. If a part number is 15 characters long but will not fit in the part number column, the part number will be displayed with a "~" at the end of the line and will be continued on the next line. The "~" denotes that the part number continues on the next line.
- G. Parts changed by a Service Bulletin are shown by PRE SB XXXX and POST SB XXXX added to the NOMENCLATURE column.
- (1) When a new top assembly is added by a Service Bulletin, PRE SB XXXX and POST SB XXXX will be added at the top assembly level only. The configuration differences at the detail part level are shown by use code letters.
- (2) When the top assembly part number is not changed by the Service Bulletin, PRE SB XXXX and POST SB XXXX will be added at the detail level.
- H. Interchangeable Parts

27-55-87

ILLUSTRATED PARTS LIST

Page 1001

Nov 01/2008



COMPONENT MAINTENANCE MANUAL

Optional (OPT)	The part is optional to and interchangeable with other parts that have the same item number.
Replaces, Replaced by and not interchangeable with (REPLACES, REPLACED BY AND NOT INTCHG/W)	The part replaces and is not interchangeable with the initial part.
Replaces, Replaced by (REPLACES, REPLACED BY)	The part replaces and is interchangeable with, or is an alternative to, the initial part.

VENDOR CODES

Code	Name
00779	TYCO ELECTRONICS CORP 2800 FULLING MILL ROAD PO BOX 3608 MIDDLETOWN, PENNSYLVANIA 17057 FORMERLY AMP INC; FORMERLY V04618 FORMERLY GENICOM COMP V01526
15653	ALCOA GLOBAL FASTENERS INC DIV KAYNAR PRODUCTS 800 S STATE COLLEGE BLVD FULLERTON, CALIFORNIA 92831-3001 FORMERLY VK6405 MICRODOT AEROSP LTD; FORMERLY KAYNAR TECH FORMERLY FAIRCHILD FASTENERS KAYNAR DIV
17446	HUCK INTL INC AEROSPACE FASTENER DIV 900 WATSON CENTER ROAD CARSON, CALIFORNIA 90745-4201 FORMERLY V32134 REXNORD INC; FORMERLY V97928 HUCK INTL
56878	SPS TECHNOLOGIES INC AEROSPACE AND INDUSTRIAL PRODUCTS DIV 301 HIGHLAND AVE JENKINTOWN, PENNSYLVANIA 19046 FORMERLY STANDARD PRESSED STEEL FORMERLY IN SALT LAKE, UTAH
72962	HARVARD INDUSTRIES INC 3 WERNER WAY SUITE 210 LEBANON, NEW JERSEY 08833 FORMERLY ESNA V7A079 FORMERLY ELASTIC STOP NUT IN UNION, NJ

27-55-87

ILLUSTRATED PARTS LIST

Page 1002

Nov 01/2006

**COMPONENT MAINTENANCE MANUAL**

Code	Name
91251	FREUDENBERG-NOK GENERAL PARTNERSHIP PLEASANT STREET PO BOX B BRISTOL, NEW HAMPSHIRE 03222-0501
92215	FAIRCHILD IND INC FAIRCHILD AEROSPACE FASTENER DIV 3010 W LOMITA BLVD TORRANCE, CALIFORNIA 90505-5102 FORMERLY VOI-SHAN IN CULVER CITY, CALIF
97928	Replaced: [V97928] SEE V17446 HUCK INTL by Code: Name and Address below 17446: HUCK INTL INC AEROSPACE FASTENER DIV 900 WATSON CENTER ROAD CARSON, CALIFORNIA 90745-4201 FORMERLY V32134 REXNORD INC; FORMERLY V97928 HUCK INTL
99862	CARR LANE MANUFACTURING COMPANY 4200 CARR LANE CT ST. LOUIS, MISSOURI 63119-2129
U1068	DOWTY SEALS LTD ASHCHURCH, TEWKESBURY GLOS GL20 8JS ENGLAND

27-55-87

ILLUSTRATED PARTS LIST

Page 1003

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

NUMERICAL INDEX

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
1002423606500		1	100	1
		1	100A	1
		1	340	1
		1	340A	1
1002423606700		1	115	2
		1	115A	2
1002423607000		1	70	2
		1	70A	2
102LH9074-12		1	265	1
102LH9074-8		1	325	1
256A3148-37		1	405	AR
256A3148-38		1	410	AR
256A3148-39		1	415	AR
256A3148-5		1	380	AR
256A3148-6		1	385	AR
256A3148-7		1	390	AR
256A3148-8		1	395	AR
256A3182-1		1	50	2
256A3183-10		1	75B	2
		1	75D	2
		1	345E	1
256A3183-11		1	75E	2
256A3183-12		1	345	1
256A3183-4		1	345A	1
		1	345C	1
		1	75	2
256A3183-5		1	75A	2
		1	75C	2
		1	345B	1
256A3183-9		1	345D	1
		1	440	1
256A3195-18		1	435A	1
256A3195-48		1	435B	1
256A3195-57		1	435C	1
256A3195-59		1		1

27-55-87

ILLUSTRATED PARTS LIST

Page 1004

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
256A3515-1		1	1A	RF
256A3515-2		1	1B	RF
256A3515-3		1	1C	RF
256A3515-4		1	1D	RF
256A3519-1		1	290	1
256A3519-2		1	310	1
256A3519-3		1	290A	1
256A3519-4		1	310A	1
256A3520-1		1	165	1
256A3520-2		1	185	1
256A3520-5		1	165B	1
256A3520-6		1	185B	1
256A3523-1		1	270	1
256A3523-2		1	280	1
256A3523-3		1	270A	1
256A3523-4		1	280A	1
256A3524-1		1	210	1
256A3524-2		1	210A	1
256A3525-1		1	215	1
256A3525-2		1	215A	1
256A3526-1		1	250	1
256A3526-2		1	250A	1
256A3527-1		1	255	1
256A3527-2		1	255A	1
256A3528-1		1	220	1
256A3528-2		1	230	1
256A3528-3		1	220A	1
256A3528-4		1	230A	1
256A3532-1		1	370	1
256A3533-1		1	10	1
256A3540-1		1	425	1
		1	425A	1
256A3540-2		1	425P	1
256A3541-1		1	428	1
256A3541-3		1	428A	1

27-55-87

ILLUSTRATED PARTS LIST

Page 1005

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
256A3542-1		1	335	1
256A3543-1		1	424	1
256A3544-1		1	420	1
256A3545-1		1	240	1
256A3546-1		1	90	1
256A3547-1		1	245	1
256A3741-1		1	40	2
256A3743-1		1	45	2
256A3744-1		1	30	2
256A3745-1		1	25	2
256W3080-14		1	225	1
256W3244-1		1	65	2
256W3547-1		1	110	1
		1	112	1
325167		1	150	2
3SLCC5		1	427	5
		1	427	5
65-63860-3		1	429	2
69235-1216CD		1	265	1
69235-820CD		1	325	1
700-850-8862-99		1	100	1
		1	100A	1
		1	340	1
		1	340A	1
700-852-8862-99		1	115	2
		1	115A	2
700-864-8862-99		1	70	2
		1	70A	2
737-135-7279-19		1	110B	1
		1	110D	1
81669V5K5		1	426	5
AN814-4DL		1	315	2
BAC27DCT540		1	445	1
BAC27DCT542		1	435	1
BAC27DCT544		1	430	1

27-55-87

ILLUSTRATED PARTS LIST

Page 1006

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
BACB10AZ30C		1	205	1
BACB10BA20C		1	200	2
BACB10BA25C		1	285	2
BACB10BA30C		1	235	1
BACB10BA35C		1	195	2
BACB10BB25C		1	355	1
BACB10BB30C		1	400	1
BACB30MR4K12		1	120	8
BACB30MR4K6		1	125	1
BACB30NT3K2		1	55	6
		1	85	3
		1	360	3
BACB30VN5K5		1	426	5
BACC13Y3A95		1	145A	1
BACC2C3D00468CG		1	20	2
BACC30BK5		1	427	5
BACF22U2		1	150	2
BACN10JC12CD		1	265	1
BACN10JC8CD		1	325	1
BACP18BC02C03P		1	15	2
BACS12ER3K7		1	5	3
		1	105	8
BACW10BN3AC		1	60	6
		1	88	3
		1	365	3
BACW10BN4AC		1	130	9
BACW10BN4AP		1	135	8
BACW10BP12DP		1	260	1
BMN4122CPD8-12		1	265	1
BMN4122CPD8-8		1	325	1
CL4F		1	150	2
H51650-12BAC		1	265	1
H51650-8BAC		1	325	1
LGPL2SPV5-5AC		1	426	5
		1	426	5

27-55-87

ILLUSTRATED PARTS LIST

Page 1007

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
		1	426	5
M25988-1-017		1	350	1
M25988-1-029		1	95	1
M25988-1-110		1	160	1
		1	320	2
M25988-1-133		1	375	1
M25988-1-204		1	35	2
M25988-1-213		1	80	2
M25988-1-268		1	190	1
MS21209F1-15P		1	170	7
		1	295	16
MS21209F4-15P		1	300	3
MS21209F5-15P		1	175	4
MS21209F7-10P		1	180	1
		1	305	2
MS21209F8-10P		1	275	2
MS21902D4		1	155	1
NAS1149C0832D		1	330A	1
NAS1149E0832P		1	330B	1
NAS1805-4L		1	140	8
S256W410-10		1	70	2
		1	70A	2
S256W410-201		1	110B	1
		1	110D	1
S256W410-5		1	100	1
		1	100A	1
		1	340	1
		1	340A	1
S256W410-7		1	115	2
		1	115A	2


27-55-87

ILLUSTRATED PARTS LIST

Page 1008

Nov 01/2006

COMPONENT MAINTENANCE MANUAL



Flap Actuation Gearbox Assembly
IPL Figure 1 (Sheet 1 of 14)


27-55-87

ILLUSTRATED PARTS LIST

Page 1009


Nov 01/2006

COMPONENT MAINTENANCE MANUAL



Flap Actuation Gearbox Assembly
IPL Figure 1 (Sheet 2 of 14)

COMPONENT MAINTENANCE MANUAL



Flap Actuation Gearbox Assembly
IPL Figure 1 (Sheet 3 of 14)


27-55-87

ILLUSTRATED PARTS LIST

Page 1011

Nov 01/2006

COMPONENT MAINTENANCE MANUAL



Flap Actuation Gearbox Assembly
IPL Figure 1 (Sheet 4 of 14)


27-55-87

ILLUSTRATED PARTS LIST

Page 1012

Nov 01/2006

COMPONENT MAINTENANCE MANUAL



Flap Actuation Gearbox Assembly
IPL Figure 1 (Sheet 5 of 14)


27-55-87

ILLUSTRATED PARTS LIST

Page 1013

Nov 01/2006

COMPONENT MAINTENANCE MANUAL



Flap Actuation Gearbox Assembly
IPL Figure 1 (Sheet 6 of 14)


27-55-87

ILLUSTRATED PARTS LIST

Page 1014

Nov 01/2006

COMPONENT MAINTENANCE MANUAL



Flap Actuation Gearbox Assembly
IPL Figure 1 (Sheet 7 of 14)


27-55-87

ILLUSTRATED PARTS LIST

Page 1015

Nov 01/2006

COMPONENT MAINTENANCE MANUAL



Flap Actuation Gearbox Assembly
IPL Figure 1 (Sheet 8 of 14)


27-55-87

ILLUSTRATED PARTS LIST

Page 1016

Nov 01/2006

COMPONENT MAINTENANCE MANUAL



L

Flap Actuation Gearbox Assembly
IPL Figure 1 (Sheet 9 of 14)



27-55-87

ILLUSTRATED PARTS LIST

Page 1017

Nov 01/2006

COMPONENT MAINTENANCE MANUAL



Flap Actuation Gearbox Assembly
IPL Figure 1 (Sheet 10 of 14)


27-55-87

ILLUSTRATED PARTS LIST

Page 1018

Nov 01/2006


COMPONENT MAINTENANCE MANUAL



Flap Actuation Gearbox Assembly
IPL Figure 1 (Sheet 11 of 14)

27-55-87
ILLUSTRATED PARTS LIST
Page 1019
Nov 01/2006


COMPONENT MAINTENANCE MANUAL



Flap Actuation Gearbox Assembly
IPL Figure 1 (Sheet 12 of 14)

27-55-87
ILLUSTRATED PARTS LIST
Page 1020
Nov 01/2006

COMPONENT MAINTENANCE MANUAL



Flap Actuation Gearbox Assembly
IPL Figure 1 (Sheet 13 of 14)

27-55-87




ILLUSTRATED PARTS LIST

Page 1021

Nov 01/2006



COMPONENT MAINTENANCE MANUAL



Flap Actuation Gearbox Assembly
IPL Figure 1 (Sheet 14 of 14)



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
-75D	256A3183-10		.	RING-SEAL						C, D	2
				(OPT ITEM 75C, 75E)							
-75E	256A3183-12		.	RING-SEAL						C, D	2
				(OPT ITEM 75C, 75D)							
80	M25988-1-213		.	PACKING							2
-80A	M259881-213			DELETED							
85	BACB30NT3K2		.	BOLT							3
88	BACW10BN3AC		.	WASHER							3
90	256A3546-1		.	COVER							1
95	M25988-1-029		.	PACKING							1
-95A	M259881-029			DELETED							
100	1002423606500		.	SEAL							1
				(V91251)							
				(SPEC S256W410-5)							
				(OPT 700-850-8862-99 (VU1068))							
-100A	700-850-8862-99		.	SEAL							1
				(VU1068)							
				(SPEC S256W410-5)							
				(OPT 1002423606500 (V91251))							
105	BACS12ER3K7		.	SCREW							8
110	256W3547-1		.	RETAINER-SEAL INPUT						A-C	1
				(OPT ITEM 110B)							
-110A	737-135-7279-19			DELETED							
-110B	737-135-7279-19		.	RETAINER-RTNR WITH EXCLUDER						A-C	1
				SEAL							
				(VU1068)							
				(SPEC S256W410-201)							
				(OPT ITEM 110)							
-110C	256W3547-1			DELETED							
-110D	737-135-7279-19		.	RETAINER-RTNR WITH EXCLUDER						D	1
				SEAL							
				(VU1068)							
				(SPEC S256W410-201)							
112	256W3547-1		.	RETAINER-SEAL INPUT							1
115	1002423606700		.	SEAL							2
				(V91251)							
				(SPEC S256W410-7)							
				(OPT 700-852-8862-99 (VU1068))							

-Item not Illustrated

27-55-87

ILLUSTRATED PARTS LIST

Page 1024

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
-115A	700-852-8862-99		.	SEAL							2
				(VU1068)							
				(SPEC S256W410-7)							
				(OPT 1002423606700 (V91251))							
120	BACB30MR4K12		.	BOLT							8
125	BACB30MR4K6		.	BOLT							1
130	BACW10BN4AC		.	WASHER							9
135	BACW10BN4AP		.	WASHER							8
140	NAS1805-4L		.	NUT							8
145	BACC13Y3A095			DELETED							
145A	BACC13Y3A95		.	CABLE							1
150	CL4F		.	FERRULE-ATTACHMENT							2
				(V99862)							
				(SPEC BACF22U2)							
				(OPT 325167 (V00779))							
155	MS21902D4		.	UNION							1
160	M25988-1-110		.	PACKING							1
-160A	M259881-110			DELETED							
165	256A3520-1		.	HOUSING ASSY							1
				(OPT ITEM 165B)							
-165A	256A3520-3			DELETED							
-165B	256A3520-5		.	HOUSING ASSY							1
				(OPT ITEM 165)							
170	MS21209F1-15P		. .	INSERT-HELICOIL							7
175	MS21209F5-15P		. .	INSERT-HELICOIL							4
180	MS21209F7-10P		. .	INSERT-HELICOIL							1
185	256A3520-2		. .	HOUSING							1
				(USED ON ITEM 165)							
-185A	256A3520-4			DELETED							
-185B	256A3520-6		. .	HOUSING							1
				(USED ON ITEM 165B)							
190	M25988-1-268		.	PACKING							1
-190A	M259881-268			DELETED							
195	BACB10BA35C		.	BEARING							2
200	BACB10BA20C		.	BEARING							2

-Item not Illustrated

27-55-87

ILLUSTRATED PARTS LIST

Page 1025

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
205	BACB10AZ30C		.								1
210	256A3524-1		.						A, B		1
-210A	256A3524-2		.						C, D		1
215	256A3525-1		.						A, B		1
-215A	256A3525-2		.						C, D		1
220	256A3528-1		.						A, B		1
-220A	256A3528-3		.						C, D		1
225	256W3080-14		.	.							1
230	256A3528-2		.	.					A, B		1
-230A	256A3528-4		.	.					C, D		1
235	BACB10BA30C		.								1
240	256A3545-1		.								1
245	256A3547-1		.								1
250	256A3526-1		.						A, B		1
-250A	256A3526-2		.						C, D		1
255	256A3527-1		.						A, B		1
-255A	256A3527-2		.						C, D		1
260	BACW10BP12DP		.								1
265	H51650-12BAC		.								1
											(V15653)
											(SPEC BACN10JC12CD)
											(OPT 102LH9074-12 (V72962))
											(OPT 69235-1216CD (V92215))
											(OPT BMN4122CPD8-12 (V97928))
270	256A3523-1		.						A, B		1
-270A	256A3523-3		.						C, D		1
275	MS21209F8-10P		.	.							2
280	256A3523-2		.	.					A, B		1
-280A	256A3523-4		.	.					C, D		1
285	BACB10BA25C		.								2
290	256A3519-1		.								1
											(OPT ITEM 290A)
-290A	256A3519-3		.								1
											(OPT ITEM 290)

-Item not Illustrated

27-55-87

ILLUSTRATED PARTS LIST

Page 1026

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
295	MS21209F1-15P		.	.	INSERT-HELICOIL						16
300	MS21209F4-15P		.	.	INSERT-HELICOIL						3
305	MS21209F7-10P		.	.	INSERT-HELICOIL						2
310	256A3519-2		.	.	HOUSING (USED ON ITEM 290)						1
-310A	256A3519-4		.	.	HOUSING (USED ON ITEM 290A)						1
315	AN814-4DL		.		PLUG AND BLEEDER						2
320	M25988-1-110		.		PACKING						2
-320A	M259881-110				DELETED						
325	H51650-8BAC		.		NUT (V15653) (SPEC BACN10JC8CD) (OPT 102LH9074-8 (V72962)) (OPT 69235-820CD (V92215)) (OPT BMN4122CPD8-8 (V97928))						1
330	NAS1149C0832P				DELETED						
330A	NAS1149C0832D		.		WASHER				C, D		1
-330B	NAS1149E0832P		.		WASHER				A, B		1
335	256A3542-1		.		DRUM-CABLE						1
340	1002423606500		.		SEAL (V91251) (SPEC S256W410-5) (OPT 700-850-8862-99 (VU1068))						1
-340A	700-850-8862-99		.		SEAL (VU1068) (SPEC S256W410-5) (OPT 1002423606500 (V91251))						1
345	256A3183-4		.		RING-SEAL				A		1
-345A	256A3183-4		.		RING-SEAL (OPT ITEM 345B)				B		1
-345B	256A3183-9		.		RING-SEAL (OPT ITEM 345A)				B		1
-345C	256A3183-4		.		RING-SEAL (OPT ITEM 345D, 345E)				C, D		1
-345D	256A3183-9		.		RING-SEAL (OPT ITEM 345C, 345E)				C, D		1

-Item not Illustrated

27-55-87

ILLUSTRATED PARTS LIST

Page 1027

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
-345E	256A3183-11		.	RING-SEAL (OPT ITEM 345C, 345D)						C, D	1
350	M25988-1-017		.	PACKING							1
-350A	M259881-017			DELETED							
355	BACB10BB25C		.	BEARING							1
360	BACB30NT3K2		.	BOLT							3
365	BACW10BN3AC		.	WASHER							3
370	256A3532-1		.	COVER							1
375	M25988-1-133		.	PACKING							1
375A	M259881-133			DELETED							
380	256A3148-5		.	SHIM							AR
385	256A3148-6		.	SHIM							AR
390	256A3148-7		.	SHIM							AR
395	256A3148-8		.	SHIM							AR
400	BACB10BB30C		.	BEARING							1
405	256A3148-37		.	SHIM							AR
410	256A3148-38		.	SHIM							AR
415	256A3148-39		.	SHIM							AR
420	256A3544-1		.	SHAFT							1
424	256A3543-1		.	GEAR-WORM (OPT ITEM 425A)						C, D	1
425	256A3540-1		.	GEAR ASSY-WORM						A, B	1
-425A	256A3540-1		.	GEAR ASSY-WORM (OPT ITEM 424)						C, D	1
-425B	256A3543-1			DELETED							
425P	256A3540-2		.	GEAR ASSY-WORM							1
426	LGPL2SPV5-5AC		.	BOLT (V17446) (SPEC BACB30VN5K5) (OPT LGPL2SPV5-5AC (V92215)) (OPT 81669V5K5 (V56878)) (OPT LGPL2SPV5-5AC (V56878))							5

-Item not Illustrated

27-55-87

ILLUSTRATED PARTS LIST

Page 1028

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY	
			1	2	3	4	5	6	7			
1- 427	3SLCC5		.	.	.							5
428	256A3541-1		.	.	.							1
-428A	256A3541-3		.	.	.							1
429	65-63860-3		.	.	.							2
430	BAC27DCT544		.									1
435	BAC27DCT542		.						A			1
-435A	256A3195-48		.						B			1
-435B	256A3195-57		.						C			1
-435C	256A3195-59		.						D			1
440	256A3195-18		.									1
445	BAC27DCT540		.									1

-Item not Illustrated

27-55-87

ILLUSTRATED PARTS LIST

Page 1029

Nov 01/2006