



# **COMPONENT MAINTENANCE MANUAL WITH ILLUSTRATED PARTS LIST**

## **NOSE GEAR BUILDUP**

**PART NUMBER  
NONE**

**BOEING PROPRIETARY, CONFIDENTIAL, AND/OR TRADE SECRET**

Copyright © 1995 The Boeing Company  
Unpublished Work - All Rights Reserved

Boeing claims copyright in each page of this document only to the extent that the page contains copyrightable subject matter. Boeing also claims copyright in this document as a compilation and/or collective work.

This document includes proprietary information owned by The Boeing Company and/or one or more third parties. Treatment of the document and the information it contains is governed by contract with Boeing. For more information, contact The Boeing Company, P.O. Box 3707, Seattle, Washington 98124.

Boeing, the Boeing signature, the Boeing symbol, 707, 717, 727, 737, 747, 757, 767, 777, 787, Dreamliner, BBJ, DC-8, DC-9, DC-10, KC-10, KDC-10, MD-10, MD-11, MD-80, MD-88, MD-90, P-8A, Poseidon and the Boeing livery are all trademarks owned by The Boeing Company; and no trademark license is granted in connection with this document unless provided in writing by Boeing.

PUBLISHED BY BOEING COMMERCIAL AIRPLANES GROUP, SEATTLE, WASHINGTON, USA  
A DIVISION OF THE BOEING COMPANY  
PAGE DATE: Jul 01/2009

**32-21-38**

Page 1  
Jul 01/2009



## COMPONENT MAINTENANCE MANUAL

Revision No. 61  
Jul 01/2009

To: All holders of NOSE GEAR BUILDUP 32-21-38.

Attached is the current revision to this COMPONENT MAINTENANCE MANUAL

The COMPONENT MAINTENANCE MANUAL is furnished either as a printed manual, on microfilm, or digital products, or any combination of the three. This revision replaces all previous microfilm cartridges or digital products. All microfilm and digital products are reissued with all obsolete data deleted and all updated pages added.

For printed manuals, changes are indicated on the List of Effective Pages (LEP). The pages which are revised will be identified on the LEP by an R (Revised), A (Added), O (Overflow, i.e. changes to the document structure and/or page layout), or D (Deleted). Each page in the LEP is identified by Chapter-Section-Subject number, page number and page date.

Pages replaced or made obsolete by this revision should be removed and destroyed.

### ATTENTION

IF YOU RECEIVE PRINTED REVISIONS, PLEASE VERIFY THAT YOU HAVE RECEIVED AND FILED THE PREVIOUS REVISION. BOEING MUST BE NOTIFIED WITHIN 30 DAYS IF YOU HAVE NOT RECEIVED THE PREVIOUS REVISION. REQUESTS FOR REVISIONS OTHER THAN THE PREVIOUS REVISION WILL REQUIRE A COMPLETE MANUAL REPRINT SUBJECT TO REPRINT CHARGES SHOWN IN THE DATA AND SERVICES CATALOG.

**32-21-38**  
TRANSMITTAL LETTER  
Page 1  
Jul 01/2009

PART NUMBER NONE



## COMPONENT MAINTENANCE MANUAL

Location of Change

Description of Change

NO HIGHLIGHTS

**32-21-38**

HIGHLIGHTS

Page 1

Jul 01/2009



## COMPONENT MAINTENANCE MANUAL

Subject/Page	Date	Subject/Page	Date	Subject/Page	Date
TITLE PAGE		32-21-38 CLEANING		32-21-38 REPAIR 7-1 (cont)	
O 1	Jul 01/2009	401	Mar 01/2006	602	Mar 01/2006
2	BLANK	402	BLANK	603	Mar 01/2006
32-21-38 TRANSMITTAL LETTER		32-21-38 CHECK		604	BLANK
O 1	Jul 01/2009	501	Mar 01/2006	32-21-38 REPAIR 8-1	
2	BLANK	502	Mar 01/2006	601	Mar 01/2006
32-21-38 HIGHLIGHTS		32-21-38 REPAIR - GENERAL		602	Mar 01/2006
O 1	Jul 01/2009	601	Mar 01/2006	603	Mar 01/2006
2	BLANK	602	Mar 01/2006	604	Mar 01/2006
32-21-38 EFFECTIVE PAGES		32-21-38 REPAIR 1-1		32-21-38 ASSEMBLY	
1 thru 2	Jul 01/2009	601	Nov 01/2006	701	Nov 01/2008
32-21-38 CONTENTS		602	Nov 01/2006	702	Nov 01/2008
1	Mar 01/2006	603	Mar 01/2006	703	Nov 01/2008
2	BLANK	604	BLANK	704	Nov 01/2008
32-21-38 TR AND SB RECORD		32-21-38 REPAIR 2-1		705	Nov 01/2008
1	Mar 01/2006	601	Nov 01/2006	706	Nov 01/2008
2	Mar 01/2006	602	Jul 01/2007	707	Nov 01/2008
32-21-38 REVISION RECORD		32-21-38 REPAIR 3-1		708	Mar 01/2008
1	Mar 01/2006	601	Mar 01/2006	709	Mar 01/2008
2	Mar 01/2006	602	Mar 01/2006	710	Mar 01/2008
32-21-38 RECORD OF TEMPORARY REVISIONS		603	Mar 01/2006	711	Mar 01/2008
1	Mar 01/2006	604	Mar 01/2006	712	Mar 01/2008
2	Mar 01/2006	32-21-38 REPAIR 4-1		713	Mar 01/2008
32-21-38 INTRODUCTION		601	Mar 01/2006	714	Mar 01/2008
1	Mar 01/2009	602	Mar 01/2006	32-21-38 FITS AND CLEARANCES	
2	BLANK	32-21-38 REPAIR 4-2		801	Jul 01/2006
32-21-38 DESCRIPTION AND OPERATION		601	Mar 01/2006	802	Mar 01/2006
1	Mar 01/2006	602	Mar 01/2006	803	Mar 01/2006
2	BLANK	603	Mar 01/2006	804	Mar 01/2006
32-21-38 TESTING AND FAULT ISOLATION		604	BLANK	32-21-38 SPECIAL TOOLS, FIXTURES, AND EQUIPMENT	
101	Mar 01/2006	32-21-38 REPAIR 5-1		901	Mar 01/2006
102	BLANK	601	Mar 01/2009	902	BLANK
32-21-38 DISASSEMBLY		602	Mar 01/2009	32-21-38 ILLUSTRATED PARTS LIST	
301	Mar 01/2006	603	Mar 01/2009	1001	Nov 01/2008
302	Mar 01/2006	604	BLANK	1002	Jul 01/2006
303	Jul 01/2006	32-21-38 REPAIR 6-1		1003	Mar 01/2006
304	BLANK	601	Mar 01/2009	1004	Mar 01/2006
		602	Mar 01/2006	1005	Mar 01/2006
		32-21-38 REPAIR 7-1		1006	Mar 01/2006
		601	Mar 01/2006		

A = Added, R = Revised, D = Deleted, O = Overflow

# 32-21-38

EFFECTIVE PAGES

Page 1

Jul 01/2009



## COMPONENT MAINTENANCE MANUAL

Subject/Page	Date	Subject/Page	Date	Subject/Page	Date
32-21-38 ILLUSTRATED PARTS LIST (cont)		32-21-38 ILLUSTRATED PARTS LIST (cont)			
1007	Mar 01/2006	1045	Mar 01/2006		
1008	Mar 01/2006	1046	Mar 01/2006		
1009	Mar 01/2006	1047	Mar 01/2006		
1010	Mar 01/2006	1048	Mar 01/2006		
1011	Mar 01/2007	1049	Mar 01/2006		
1012	Jul 01/2006	1050	Mar 01/2006		
1013	Nov 01/2008	1051	Mar 01/2006		
1014	Jul 01/2006	1052	BLANK		
1015	Jul 01/2006				
1016	Jul 01/2006				
1017	Jul 01/2006				
1018	Mar 01/2006				
1019	Mar 01/2006				
1020	Jul 01/2006				
1021	Mar 01/2006				
1022	Mar 01/2006				
1023	Mar 01/2006				
1024	Mar 01/2006				
1025	Mar 01/2006				
1026	Mar 01/2006				
1027	Mar 01/2006				
1028	Mar 01/2006				
1029	Mar 01/2006				
1030	Jul 01/2006				
1031	Mar 01/2007				
1032	Mar 01/2006				
1033	Mar 01/2006				
1034	Mar 01/2006				
1035	Mar 01/2006				
1036	Mar 01/2006				
1037	Mar 01/2006				
1038	Nov 01/2008				
1039	Mar 01/2006				
1040	Mar 01/2006				
1041	Mar 01/2006				
1042	Mar 01/2006				
1043	Mar 01/2006				
1044	Mar 01/2006				

A = Added, R = Revised, D = Deleted, O = Overflow

**32-21-38**

EFFECTIVE PAGES

Page 2

Jul 01/2009



## COMPONENT MAINTENANCE MANUAL

### TABLE OF CONTENTS

<u>Paragraph Title</u>		<u>Page</u>
NOSE GEAR BUILDUP - DESCRIPTION AND OPERATION		1
TESTING AND FAULT ISOLATION	(Not Applicable)	
DISASSEMBLY		301
CLEANING	(Not Applicable)	
CHECK		501
REPAIR		601
ASSEMBLY		701
FITS AND CLEARANCES		801
SPECIAL TOOLS, FIXTURES, AND EQUIPMENT	(Not Applicable)	
ILLUSTRATED PARTS LIST		1001

# 32-21-38

CONTENTS

Page 1

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

### TEMPORARY REVISION AND SERVICE BULLETIN RECORD

BOEING SERVICE BULLETIN	BOEING TEMPORARY REVISION	OTHER DIRECTIVE	DATE OF INCORPORATION INTO MANUAL
		PRR 33180-3	JUN 05/84
		PRR 33215	JUN 05/84
		PRR 33347	JUN 05/84
		PRR 33391	JUN 05/84
		PRR 33411	JUN 05/84
		PRR 33436	JUN 05/84
		PRR 33540	JUN 05/84
		PRR 33586	SEP 05/84
		PRR 33766	JUN 05/85
		PRR 34477	JUN 05/88
		PRR 34483	MAR 05/89
		PRR 34509	MAR 05/89
		PRR 35005-15	SEP 05/92
32-1289		PRR 35005-132	NOV 01/04
		PRR 35005-153	DEC 01/97
		PRR 35161	SEP 05/93
32-1191			SEP 05/89
		MC 3220MP3006	MAR 05/90
		MC 3342MP3009	MAR 05/91
		PRR 33004-89	JUN 05/91
		RR 97132-145	JUN 05/91
		RR 97132-189	JUN 05/91
		RR 97058-52	JUN 05/91
		MC 3240MP3097	SEP 05/91
32-1213			SEP 05/91
		RR 97058-54	DEC 05/91
		MC 0310MK3241	SEP 05/92
		MC 3240MP3115	SEP 05/92
		RR 97065-200	DEC 05/92
		RR 97132-241	MAR 05/93

# 32-21-38

TR AND SB RECORD

Page 1

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

BOEING SERVICE BULLETIN	BOEING TEMPORARY REVISION	OTHER DIRECTIVE	DATE OF INCORPORATION INTO MANUAL
		MC 0310MK3038	MAR 05/93
		RR 97150-13	SEP 05/93
		MC 3240MP3010	SEP 05/93
		MC 3240MP3093	SEP 05/93
		MC 3240MP3115	SEP 05/93
		MC 3240MP3122	SEP 05/93
		MC 3240MP3123	SEP 05/93
		MC 3240MP3126	DEC 05/93
		MC 3260MP3014	DEC 05/93
32-1191, Rev.3			DEC 05/93
		RR 97065-292	DEC 05/93
		MC 3240MP3219	JUN 01/94
32-1213, Rev.4			SEP 01/94
		MC 3245MP3025	SEP 01/94
		MC 3240MP3233	JUN 01/95
32-1286		MC 3240MK3010	JUN 01/96
		MC 3240MP3240	DEC 01/95
		MC 3245MP3039	SEP 01/96
		MC 3240MP3260	MAR 01/97
		MC 3240MP3269	MAR 01/97
		MC 3240MP3275	JUN 01/97
		MC 3240MP3275A	DEC 01/97
		MC 3240MP3276	MAR 01/97
		MC 3240MP3278	JUN 01/97
		MC 3240MP3279	JUN 01/97
		MC 3241MP3026	JUL 01/98
32-1213, Rev.7			NOV 01/01
32-1346		MC 3240MK3346	NOV 01/01
33-1129		AD 2000-08-17	NOV 01/01
		737-SL-32-114-A	JUL 01/05

# 32-21-38

TR AND SB RECORD

Page 2

Mar 01/2006





**COMPONENT MAINTENANCE MANUAL**

All revisions to this manual will be accompanied by transmittal sheet bearing the revision number. Enter the revision number in numerical order, together with the revision date, the date filed and the initials of the person filing.

Revision		Filed		Revision		Filed	
Number	Date	Date	Initials	Number	Date	Date	Initials



COMPONENT MAINTENANCE MANUAL

Revision		Filed	
Number	Date	Date	Initials

Revision		Filed	
Number	Date	Date	Initials

32-21-38

REVISION RECORD

Page 2

Mar 01/2006



### COMPONENT MAINTENANCE MANUAL

All temporary revisions to this manual will be accompanied by a cover sheet bearing the temporary revision number. Enter the temporary revision number in numerical order, together with the temporary revision date, the date the temporary revision is inserted and the initials of the person filing. When the temporary revision is incorporated or cancelled, and the pages are removed, enter the date the pages are removed and the initials of the person who removed the temporary revision.

Temporary Revision		Inserted		Removed		Temporary Revision		Inserted		Removed	
Number	Date	Date	Initials	Date	Initials	Date	Initials	Number	Date	Date	Initials

**32-21-38**

RECORD OF TEMPORARY REVISION

Page 1

Mar 01/2006



**COMPONENT MAINTENANCE MANUAL**

Temporary Revision		Inserted		Removed	
Number	Date	Date	Initials	Date	Initials

Temporary Revision		Inserted		Removed	
Date	Initials	Number	Date	Date	Initials



## COMPONENT MAINTENANCE MANUAL

### INTRODUCTION

#### 1. General

- A. The instructions in this manual supply the data necessary to do the maintenance functions together with the test, fault isolation, repair, and replacement of the defective parts.
- B. This manual is divided into different parts:
  - (1) Title Page
  - (2) Transmittal Letter
  - (3) Highlights
  - (4) List of Effective Pages
  - (5) Table of Contents
  - (6) Temporary Revision & Service Bulletin Record
  - (7) Record of Revisions
  - (8) Record of Temporary Revisions
  - (9) Introduction
  - (10) Procedures & IPL Sections
- C. Components that can be repaired have a different repair number for each specified repair. To find the repair number location of a component, look in the Repair-General procedure at the beginning of the REPAIR section. The Repair-General procedure also has an explanation of the True Position Dimension symbols used.
- D. All dimensions, measures, quantities and weights included are in English units. When metric equivalents are given they will be in the parentheses that follow the English units.
- E. The introduction to the Illustrated Parts List (IPL) shows how the IPL data is used.
- F. Design changes, optional parts, configuration differences and Service Bulletin modifications may cause different part numbers. These part numbers are identified in the IPL with an alphabetical letter which is added to the end of the basic item number. This new item number is referred to as an alpha-variant. Throughout the manual, IPL basic item number references also apply to alpha-variants unless shown differently.
- G. The tool reference numbers found in the individual procedures and in the Special Tools, Fixtures, and Equipment section are used to identify if a tool is a standard tool (STD-XXXX), a commercial tool (COM-XXXX), or a Special Tool (SPL-XXXX). This reference number is also used to distinguish between tools with similar names in the same procedure. These reference numbers are for use in the documentation only. They are not to be used for ordering tools.

# 32-21-38

INTRODUCTION

Page 1

Mar 01/2009



## COMPONENT MAINTENANCE MANUAL

### NOSE GEAR BUILDUP - DESCRIPTION AND OPERATION

#### 1. Description

A. The nose gear buildup is an interchangeable module consisting of the nose gear assembly, wheel and tire assemblies, taxi light and wiring harness, hydraulic tubing, nose wheel steering depressurization valve, steering cable and nose wheel steering control mechanism.

#### 2. Operation

A. The unit provides rolling support with shock absorbing and steering capabilities. Steering inputs are transferred to the steering actuators through a control cable to the control mechanism and metering valve to provide steering control.

B. Electrical components consist of a taxi light and wiring harness.

#### 3. Leading Particulars (Approximate)

A. Height (extended) – 63 inches

B. Height (compressed) – 51 inches

C. Weight – 320 pounds

# 32-21-38

DESCRIPTION AND OPERATION

Page 1

Mar 01/2006

PART NUMBER NONE



**COMPONENT MAINTENANCE MANUAL**

**TESTING AND FAULT ISOLATION**

**(NOT APPLICABLE)**

**32-21-38**

TESTING AND FAULT ISOLATION

Page 101

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

### DISASSEMBLY

#### 1. General

- A. This procedure has the data necessary to disassemble the nose gear buildup components.
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices identified in this procedure.
- C. Disassemble the components sufficiently to find the defects, do the repairs, and put the components back into a serviceable condition.
- D. Refer to IPL Figure 1, IPL Figure 2 and IPL Figure 3 for item numbers.

#### 2. Equipment

**NOTE:** Equivalent substitutes may be used.

- A. F72913-10 – Axle and Thread Protector (Standard Threads)
- B. F72913-15 – Axle Thread Protector (Undersize Threads)
- C. F80168-1 – Axle Nut Socket

#### 3. Parts Replacement

**NOTE:** The following parts are recommended for replacement. Unless otherwise specified, actual replacement may be based on in-service experience.

- A. Lockwire
- B. All Cotter Pins
- C. Nuts (90, 150, 360, 395, 425, IPL Figure 1), (100, 205, IPL Figure 2), (35, 65, 150, 225, 330, IPL Figure 3)

#### 4. Disassembly

**WARNING:** FAILURE TO RELIEVE ALL AIR FROM THE SHOCK STRUT ASSEMBLY BEFORE STARTING DISASSEMBLY MAY RESULT IN INJURY TO PERSONNEL OR DAMAGE TO PARTS.

- A. Deflate shock strut by turning swivel nut on air valve one or two turns counterclockwise; then open valve fully.
- B. Position gear buildup in fixture in upright position.

**CAUTION:** SHOCK STRUT INNER CYLINDER COULD HAVE UNDERSIZE AXLE THREADS THAT MUST BE USED ONLY WITH SPECIAL UNDERSIZE WHEEL NUT (20, IPL FIG. 1) 69-77849 SERIES.

- C. Remove wheels and tires (IPL Figure 1).
  - (1) Remove screws (15).
  - (2) Using axle nut socket F80168-1, remove nuts (20) and washers (25).
  - (3) Remove wheel and tire assemblies (30).
  - (4) Remove cotter pins (45) and spacers (50) from axles.
  - (5) Install an axle and thread protector on each end of the axle.
- D. Remove left trunnion pin (60, IPL Figure 1).
  - (1) Remove spring pins (125) and lock pins (55).
  - (2) Slide pin (60) out of mounting hole.

# 32-21-38

DISASSEMBLY

Page 301

Mar 01/2006



**COMPONENT MAINTENANCE MANUAL**

- (3) Remove screw (105), lock (110) and nut (115).
- E. Remove right trunnion pin (120, IPL Figure 1).
  - (1) Disconnect hydraulic tubes (235, 250) from swivel (170).
  - (2) Remove spring pins (125) and lock pins (55).
  - (3) Slide pin (120) out of mounting hole.
  - (4) Remove pin (160) and swivel (170).
  - (5) Remove screws (155), clamps (145) and swivels (170) from bracket.
- F. Remove taxi light harness installation (IPL Figure 2).
  - (1) Disconnect harness (175, 180, 181) from taxi light (385, IPL Figure 1).

**NOTE:** At many of the harness attachment points, the fastener types, quantity and thickness were adjusted during assembly to get a good clamp-up. Thus we recommend you keep the fasteners of each attachment point together as a group, and identify each group with their location to help during assembly.
  - (2) Remove screws (5 thru 45), washers (50), spacers (55 thru 98), nuts (100, 105), clamps (110A thru 153), brackets (155 thru 172), and harness (175, 180, 181).
- G. Remove depressurization valve (190) and tube assemblies (235, 240, 245, 250) (IPL Figure 1).
  - (1) Remove tube assemblies (235, 250) from depressurization valve (190).
  - (2) Remove tube assemblies (240, 245) from depressurization valve (190) and metering valve.
- H. Remove the fasteners and the steering control mechanism cover. Late installations have an added bracket (335) and bolt (800, IPL Figure 3) on the bottom for decreased vibration.
- I. Remove nose wheel steering cable (270, IPL Figure 1) and upper pulley mount (80, IPL Figure 3).
  - (1) Remove screws (95, 100), washers (105), nuts (110) and cable guards (85, 90) (IPL Figure 3).
  - (2) Remove bolts (305, 310), washers (315), spacers (320, 325) and nuts (330) (IPL Figure 3).
  - (3) Remove bolts (5), washers (25), nuts (35), pulleys (40) and pulley guards (45) (IPL Figure 3).
  - (4) Remove nut (70), washer (75) and pulley mount (80) (IPL Figure 3).
  - (5) Remove cotter pins (277), or lockwire and spring pins (275) and cable (270) (IPL Figure 1).
  - (6) Remove nuts (65), washers (60) and bolts (55) (IPL Figure 3).
  - (7) Remove bolts (215), washers (220, 225), nuts (230), bracket (210) (IPL Figure 1) and brace (50 IPL Figure 3).
- J. Remove steering control mechanism (IPL Figure 3).
  - (1) Remove bolts (120, 135), washers (140, 145), nuts (150) and link assembly (115).
  - (2) Remove bolt (195), washers (205), nut (225), spacer (235), bushing (240) and bearing (230).
  - (3) Remove bolts (5, 10), washers (30), nuts (35), pulleys (40) and retainers (300).
  - (4) Remove bolts (15), washers (20, 25), nuts (35) and pulleys (40).
  - (5) Remove bolts (200), washers (210), nuts (225) and trunnions (260).
  - (6) Remove bolts (185, 190), washers (205, 210), nuts (225) and bracket (245).
- K. Remove conduit support bracket (185, IPL Figure 2) from the upper steering plate of the shock strut outer cylinder.

**32-21-38**

DISASSEMBLY

Page 302

Mar 01/2006

**COMPONENT MAINTENANCE MANUAL**

- L. Remove sensor support (270, IPL Fig. 2 CMM 32-21-48 ) from the lower steering plate of the shock strut outer cylinder.
- M. Remove door operator brackets (305) and target support assemblies (280A, 281A) (IPL Figure 1).
  - (1) Remove nuts (330), washers (325, 326, 335) and bolts (310, 315, 320).
  - (2) Remove cotter pins (365), nuts (360), washers (352, 355, 350) and bolts (340, 345, 370, 375).
  - (3) Remove target support assemblies (280A, 281A) and brackets (305).

**CAUTION:** THE SHOCK STRUT COULD HAVE THE TOW FITTING ATTACH LUG CUT SHORTER AND A SPECIAL REPAIR TOW FITTING INSTALLED. THIS TOW FITTING IS A MATCHED SET WITH THE INNER CYLINDER BECAUSE THE HOLES IN THE ATTACH LUG WERE DRILLED TO AGREE WITH THE HOLES IN THIS FITTING.

- N. Remove taxi light (380) and tow fitting (410) (IPL Figure 1).
  - (1) Remove nuts (395), washers (400) and bolts (405). If applicable, remove nuts (455), washers (445, 450), and bolts (440).
  - (2) Remove light assembly (385) and tow fitting (410).
  - (3) Remove cotter pin (430), nut (425), washers (420) and bolt (415).

**32-21-38**

DISASSEMBLY

Page 303

Jul 01/2006

PART NUMBER NONE



COMPONENT MAINTENANCE MANUAL

CLEANING

**(NOT APPLICABLE)**

**32-21-38**

CLEANING  
Page 401

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

### CHECK

#### 1. General

- A. The procedure has the data necessary to find defects in the parts of the nose gear buildup.
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1, IPL Figure 2 and IPL Figure 3 for item numbers.

#### 2. Check

##### A. References

Reference	Title
SOPM 20-20-01	MAGNETIC PARTICLE INSPECTION
SOPM 20-20-02	PENETRANT METHODS OF INSPECTION

##### B. Procedure

- (1) Examine all parts for defects by standard industry practices. Refer to FITS AND CLEARANCES for design dimensions and wear limits.
- (2) Examine the axle nut (20) threads for nicks, burrs, defects and wear. Measure the thread pitch diameter and minor diameter and compare them with the thread dimensions shown in FITS AND CLEARANCES, Figure 801. Measure the minor diameters with an F80198 series plug gage or the equivalent Class X Go/No Go vendor tool. Measure the pitch diameter with the applicable No Go nut gage. Be sure to use the correct tools for the thread size.
 

**NOTE:** A Johnson GJ-5/PD-MD thread measuring system (or equivalent) can be used as an option to measure the threads, but a separate measuring segment and master thread gage ring are necessary for each thread size. The gage ring is used to set the dial indicator before you measure the threads.
- (3) Examine all pin and bolt shanks for wear. Carefully examine areas around lubrication and pin retention holes for hairline cracks.
- (4) Examine harness assembly (175, 180, IPL Figure 2) for breaks and kinks. Make a check of the electrical continuity and connector pins of the harness assembly. Bent pins can be carefully straightened.
- (5) Magnetic particle check (SOPM 20-20-01).
  - (a) Nut (20, 115, IPL Figure 1)
  - (b) Washer (25, IPL Figure 1)
  - (c) Pin (55, 60, 120, IPL Figure 1)
  - (d) Lock (110, IPL Figure 1)
  - (e) Brace (50, IPL Figure 3)
  - (f) Washer (75, IPL Figure 3)
  - (g) Trunnion (260, IPL Figure 3)
- (6) Penetrant check (SOPM 20-20-02).
  - (a) Fitting (410, IPL Figure 1)
  - (b) Mount (80, IPL Figure 3)

# 32-21-38

CHECK

Page 501

Mar 01/2006

PART NUMBER NONE



## COMPONENT MAINTENANCE MANUAL

- (c) Bracket (250, IPL Figure 3)
- (d) Crank (270, IPL Figure 3)

**32-21-38**

CHECK  
Page 502  
Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

### REPAIR

#### 1. Content

A. Repair, refinish and replacement procedures are included in separate repair sections as follows:

**Table 601:**

<u>P/N</u>	<u>NAME</u>	<u>REPAIR</u>
65C34776	PIN, LEFT TRUNNION	1-1
69-35398	PIN, LEFT TRUNNION	1-1
69-41248	PIN, RIGHT TRUNNION	2-1
69-41278	FITTING, TOW	3-1
65C22920	CRANK	4-1, 4-2
–	MISCELLANEOUS PARTS REFINISH	5-1
65C36787	FITTING, TOW	6-1
65C22921	BRACKET	7-1
65C25118	MOUNT, UPPER PULLEY	8-1

#### 2. Standard Practices

A. Refer to the following standard practices, as applicable, for details of procedures in individual repairs.

- SOPM 20-10-01 Repair and Refinish of High Strength Steel
- SOPM 20-30-02 Stripping of Protective Finishes
- SOPM 20-30-03 General Cleaning Procedures
- SOPM 20-41-01 Decoding Table for Boeing Finish Codes
- SOPM 20-41-02 Application of Chemical and Solvent Resistant Finishes
- SOPM 20-42-03 Hard Chrome Plating
- SOPM 20-42-05 Bright Cadmium Plating
- SOPM 20-43-01 Chromic Acid Anodizing
- SOPM 20-50-02 Installation of Safetying Devices
- SOPM 20-50-03 Bearing and Bushing Replacement
- SOPM 20-50-05 Application of Aluminum Foil and other Markers
- SOPM 20-60-02 Finishing Materials
- SOPM 20-60-04 Miscellaneous Materials
- 32-00-02 Landing Gear Attachment Parts - Topcoat Application
- 32-00-05 Repair of High Strength Steel Landing Gear Parts

#### 3. Materials

**NOTE:** Equivalent substitutes can be used.

- A. Corrosion preventive Compound – corrosion preventive compound, C00308 MIL-C-11796, Class 1
- B. Enamel – coating, C00260 BMS 10-11, type 2, color 707 gray gloss
- C. Enamel – coating, C50069 BMS 10-11, type 2, color 702 white gloss

# 32-21-38

REPAIR - GENERAL

Page 601

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

- D. Enamel – coating, C50075 BMS 10-60, color 707 gray gloss
- E. Primer – primer, C00259 BMS 10-11, type 1
- F. Sealant – sealant, A00247 BMS 5-95

#### 4. Dimensioning Symbols

- A. Standard True Position Dimensioning Symbols used in applicable repair procedures are shown in SOPM 20-00-00.

**32-21-38**

REPAIR - GENERAL

Page 602

Mar 01/2006

**COMPONENT MAINTENANCE MANUAL****LEFT TRUNNION PIN - REPAIR 1-1****69-35398 65C34776-2, -1****1. General**

- A. This procedure tells how to repair and refinish the left trunnion pin.
- B. Refer to REPAIR-GENERAL, Paragraph 2. the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Paragraph 3. for the description of the consumable codes identified in this procedure.
- D. Refer to REPAIR-GENERAL, Paragraph 4. for the Standard True Position Dimensioning Symbols shown in the repair.
- E. Refer to IPL Figure 1 for item numbers.

**2. Shank Repair - OD (REPAIR 1-1, Figure 601)**

**NOTE:** For repair of surfaces which is only replacement of the original finish, refer to Refinish Instructions, (REPAIR 1-1, Figure 601).

- A. Machine as required, within repair limits, to remove defects.
- B. Shot peen as indicated.
- C. Build up with chrome plate and grind to design dimensions and finish.

**3. Hole for Lockpin (REPAIR 1-1, Figure 601)**

**NOTE:** For repair of surfaces which is only replacement of the original finish, refer to Refinish Instructions, (REPAIR 1-1, Figure 601).

- A. Remove the chrome plate from the OD surface around the hole, but not more than 0.66 inch diameter.
- B. Machine the hole as required, within repair limits, to remove defects.
- C. If the hole repair diameter is not more than 0.412 inch, shot peen, build up with chrome plate and grind to design diameter.
- D. If the hole repair diameter is more than 0.412 inch:
  - (1) Shot peen as indicated (SOPM 20-10-03).
  - (2) Cadmium plate the hole and apply primer, C00259.
  - (3) Make a flanged repair bushing with OD for a 0.0003-0.0013 inch interference fit before plating and primer. Cadmium plate the bushing OD as indicated.
  - (4) Install the bushing by the shrink fit method (SOPM 20-50-03).
  - (5) Trim the ends of the installed bushing until they are smooth with the adjacent OD and ID surfaces.
  - (6) Machine the bushing ID to design dimensions.

**32-21-38**

REPAIR 1-1


Page 601

Nov 01/2006





COMPONENT MAINTENANCE MANUAL



**REFINISH**

CHROME PLATE (F-15.04) DIAMETER -A- AND WIPE CHROME PLATE WITH PRIMER (F-19.45).

ON DIAMETER -A- CADMIUM-TITANIUM PLATE (F-15.01) ALL OTHER SURFACES. APPLY PRIMER AND CORROSION PREVENTIVE COMPOUND TO ID AS SHOWN BY 6

**REPAIR**

REF 1 4

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

SHOT PEEN: 0.016-0.033 SHOT SIZE  
0.015 A2 INTENSITY

MATERIAL: 4340M STEEL (270-300 KSI)

ALL DIMENSIONS ARE IN INCHES

69-35398-2; 65C34776-1 Left Trunnion Pin Repair and Refinish  
Figure 601 (Sheet 1 of 2)

**32-21-38**

REPAIR 1-1  
Page 602  
Nov 01/2006



## COMPONENT MAINTENANCE MANUAL

- 1 LIMIT FOR CHROME PLATE BUILDUP, WITH PLATING RUNOUT AS NOTED. GRIND TO DESIGN DIMENSIONS AND FINISH. WIPE CHROME PLATE WITH PRIMER (F-19.45)
- 2 0.09 MAX CHROME PLATE RUNOUT AROUND HOLES AND KEYWAYS
- 3 NO PRIMER ON THESE SURFACES. WIPE THREADS WITH PRIMER (F-19.45)
- 4 LIMIT FOR INSTALLATION OF REPAIR BUSHING
- 5 CADMIUM PLATE (F-15.06) BUSHING OUTER DIAMETER
- 6 AFTER APPLYING THE CADMIUM-TITANIUM PLATE, APPLY BMS 10-11, TYPE 1 PRIMER (F-20.03) AND CORROSION PREVENTIVE COMPOUND (F-19.03) TO THIS AREA
- 7 IF MORE MATERIAL REMOVAL THAN THIS IS NECESSARY, THE PART MUST BE SCRAPPED

69-35398-2; 65C34776-1 Left Trunnion Pin Repair and Refinish  
Figure 601 (Sheet 2 of 2)

# 32-21-38

REPAIR 1-1  
Page 603  
Mar 01/2006

**COMPONENT MAINTENANCE MANUAL****RIGHT TRUNNION PIN - REPAIR 2-1****69-41248-2, -3****1. General**

- A. This procedure tells how to repair and refinish the right trunnion pin.
- B. Refer to REPAIR-GENERAL, Paragraph 2. the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Paragraph 3. for the description of the consumable codes identified in this procedure.
- D. Refer to REPAIR-GENERAL, Paragraph 4. for the Standard True Position Dimensioning Symbols shown in the repair.
- E. Refer to IPL Figure 1 for item numbers.

**2. Shank Repair - OD (REPAIR 2-1, Figure 601)**

**NOTE:** For repair of surfaces which is only replacement of the original finish, refer to Refinish Instructions, REPAIR 2-1, Figure 601.

- A. Machine as required, within repair limits, to remove defects.
- B. Shot peen as indicated.
- C. Build up with chrome plate and grind to design dimensions and finish.

**3. Hole for Lockpin (REPAIR 2-1, Figure 601)**

**NOTE:** For repair of surfaces which is only replacement of the original finish, refer to Refinish Instructions, REPAIR 2-1, Figure 601.

- A. Remove the chrome plate from the OD surface around the hole, but not more than 0.66 inch diameter.
- B. Machine the hole as required, within repair limits, to remove defects.
- C. If the hole repair diameter is not more than 0.412 inch, shot peen, build up with chrome plate and grind to design diameter.
- D. If the hole repair diameter is more than 0.412 inch:
  - (1) Shot peen as indicated.
  - (2) Cadmium plate the hole and apply primer, C00259.
  - (3) Make a flanged repair bushing with OD for a 0.0003-0.0013 inch interference fit before plating and primer. Cadmium plate the bushing OD as indicated.
  - (4) Install the bushing by the shrink fit method (SOPM 20-50-03).
  - (5) Trim the ends of the installed bushing until they are smooth with the adjacent OD and ID surfaces.
  - (6) Machine the bushing ID to design dimensions.

**4. Bore (REPAIR 2-1, Figure 601)**

**NOTE:** For repair of surfaces which is only replacement of the original finish, refer to Refinish Instructions, REPAIR 2-1, Figure 601.

- A. Machine as required, within repair limits, to remove defects.
- B. Shot peen as indicated (SOPM 20-10-03).
- C. Build up with nickel plate and machine to design dimensions and finish.


**32-21-38**

REPAIR 2-1

Page 601

Nov 01/2006

COMPONENT MAINTENANCE MANUAL



**REFINISH**

CHROME PLATE (F-15.04) DIAMETER -A-. WIPE CHROME PLATE WITH PRIMER (F-19.45). CADMIUM TITANIUM PLATE (F-15.01) ALL OTHER SURFACES. APPLY BMS 10-11, TYPE 1 PRIMER (F-20.03) AND CORROSION PREVENTIVE COMPOUND (F-19.03) TO INTERIOR SURFACES SHOWN BY 7

- 1 LIMIT FOR CHROME PLATE BUILDUP (SOPM 20-42-03), WITH PLATING RUNOUT AS SHOWN. GRIND TO DESIGN DIMENSIONS AND FINISH. WIPE CHROME PLATE WITH PRIMER (F-19.45)
- 2 0.09 MAX CHROME PLATE RUNOUT AROUND HOLES AND KEYWAYS
- 3 WIPE WITH PRIMER (F-19.45)
- 4 LIMIT FOR INSTALLATION OF REPAIR BUSHING
- 5 CADMIUM PLATE (F-15.06) BUSHING OD

**REPAIR**

REF 1 4 6  
 125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY  
 SHOT PEEN: 0.016-0.033 SHOT SIZE  
 0.015 A2 INTENSITY  
 MATERIAL: 4340M STEEL (270-300 KSI)  
 ALL DIMENSIONS ARE IN INCHES

- 6 LIMIT FOR SULFAMATE NICKEL PLATE BUILDUP (SOPM 20-42-09), WITH 0.06 MAX PLATING RUNOUT AT EDGES AND HOLES. MACHINE TO DESIGN DIMENSIONS AND FINISH.
- 7 APPLY PRIMER AND CORROSION PREVENTIVE COMPOUND IN THIS AREA.
- 8 69-41248-2
- 9 69-41248-3

69-41248-2,-3 Right Trunnion Pin Repair and Refinish  
 Figure 601

**32-21-38**

**COMPONENT MAINTENANCE MANUAL****TOW FITTING - REPAIR 3-1****69-41278-3, -4****1. General**

- A. This procedure has the data necessary to repair and refinish the tow fitting.
- B. Refer to REPAIR-GENERAL, Paragraph 2. the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Paragraph 3. for the description of the consumable codes identified in this procedure.
- D. Refer to REPAIR-GENERAL, Paragraph 4. for the Standard True Position Dimensioning Symbols shown in the repair.

**2. Installation of Repair Bushings (REPAIR 3-1, Figure 601)**

**NOTE:** For repair of surfaces which is only replacement of the original finish, refer to Refinish instructions, REPAIR 3-1, Figure 601.

- A. Machine as required, within repair limits, to remove defects.
- B. Shot peen as indicated (SOPM 20-10-03).
- C. Unless shown differently, make repair bushings (REPAIR 3-1, Figure 602) as necessary, to adjust for the material removed.
- D. Install the bushings by the shrink-fit method of SOPM 20-50-03.
- E. Install the bushing flush with or 0.004 maximum below the surface of the lug.
- F. Machine the bushings to design dimensions and finish.



**32-21-38**

REPAIR 3-1

Page 601

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



A-A  
(-4 ONLY)

69-41278-3,-4 Tow Fitting Repair and Refinish  
Figure 601 (Sheet 1 of 2)

**32-21-38**

REPAIR 3-1  
Page 602  
Mar 01/2006



COMPONENT MAINTENANCE MANUAL

	①	②	③	④	⑤
DESIGN DIM	0.760 0.755	0.420 0.400	0.555 0.550	0.760 0.755	0.410 0.390
REPAIR LIMIT	0.815 ① ③	0.372 ② ③	0.641 ②	0.820 ①	0.360 ④

REFINISH

APPLY BMS 10-11, TYPE 1, PRIMER (F-20.02) AND BMS 10-11, TYPE 2, ENAMEL COLOR 707 GRAY GLOSS (F-21.02)

- ① LIMIT FOR INSTALLATION OF REPAIR BUSHING
- ② LIMIT FOR INSTALLATION OF FLANGED REPAIR BUSHING, OR CADMIUM-PLATED 15-5PH OR 17-4PH CRES SHIMS BONDED WITH BMS 5-95 SEALANT
- ③ IF ① AND ② DEFECTS ARE MORE THAN THESE LIMITS, DISCARD THE PART
- ④ RESTORATION TO DESIGN DIMENSIONS NOT REQUIRED. IF DEFECTS ARE MORE THAN THIS LIMIT, DISCARD THE PART

REPAIR

REF ① THRU ④

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK SHARP EDGES 0.01-0.05 R

SHOT PEEN: 0.016-0.033 SHOT SIZE  
0.015A2 INTENSITY

MATERIAL: TI-6Al-4V-2SN TITANIUM ALLOY


ALL DIMENSIONS ARE IN INCHES

69-41278-3,-4 Tow Fitting Repair and Refinish  
Figure 601 (Sheet 2 of 2)

**32-21-38**

REPAIR 3-1  
Page 603  
Mar 01/2006

COMPONENT MAINTENANCE MANUAL



PLAIN REPAIR BUSHING

FLANGED REPAIR BUSHING

HOLE LOCATION (FIG. 601)	D	L	MATERIAL
1	0.760 0.755	0.42 0.39	1 OR 2
4	0.760 0.755	0.41 0.39	1

- 1 AL-NI-BRONZE PER AMS4640
- 2 17-4PH CRES PER AMS 5643, 180-200 KSI
- 3 REPAIR DIAMETER OF THE HOLE PLUS 0.25-0.30

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK SHARP EDGES 0.01-0.02 R

FINISH: NO FINISH

MATERIAL: AS SHOWN BY 1 2

ALL DIMENSIONS ARE IN INCHES

Repair Bushing Details  
Figure 602

**32-21-38**

REPAIR 3-1

Page 604

Mar 01/2006



**COMPONENT MAINTENANCE MANUAL****CRANK ASSEMBLY - REPAIR 4-1****65C22920-1, -4, -6, -8****1. General**

- A. This procedure has the data necessary to repair and refinish the crank assembly.
- B. Refer to REPAIR-GENERAL, Paragraph 2. the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Paragraph 3. for the description of the consumable codes identified in this procedure.
- D. Refer to REPAIR-GENERAL, Paragraph 4. for the Standard True Position Dimensioning Symbols shown in the repair.
- E. Refer to IPL Figure 3

**2. Bushing Replacement (REPAIR 4-1, Figure 601)**

**NOTE:** For repair of surfaces which is only replacement of the original finish, refer to Refinish Instructions, REPAIR 4-2

- A. Remove the old bushing (290).
- B. If you find defects on the crank, refer to for repair instructions.
- C. Install a replacement bushing by the shrink-fit method (SOPM 20-50-03).
- D. Make a check of the dimensions and machine them as necessary.

**3. Bearing Replacement (REPAIR 4-1, Figure 601)**

**NOTE:** For repair of surfaces which is only replacement of the original finish, refer to Refinish Instructions, REPAIR 4-2

- A. Remove the old bearing (285).
- B. If you find defects on the crank, refer to REPAIR 4-2 for repair instructions.
- C. Install a replacement bearing with wet primer (F-20.06).
- D. Roller swage the bearing per SOPM 20-50-03.


**32-21-38**

REPAIR 4-1

Page 601

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



ALL DIMENSIONS ARE IN INCHES

65C22920-1,-4,-6,-8 Crank Assembly Parts Replacement  
Figure 601

**32-21-38**

REPAIR 4-1

Page 602

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

### CRANK AND ARM - REPAIR 4-2

65C22920-2, -5, -7, 69-72652-1

#### 1. General

- A. This procedure has the data necessary to repair and refinish the crank and arm.
- B. Refer to REPAIR-GENERAL, Paragraph 2. the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Paragraph 3. for the description of the consumable codes identified in this procedure.
- D. Refer to REPAIR-GENERAL, Paragraph 4. for the Standard True Position Dimensioning Symbols shown in the repair.
- E. Refer to IPL Figure 3

#### 2. Repair (REPAIR 4-2, Figure 601)

- A. Repair is only replacement of the original finish. Refer to Refinish instructions in REPAIR 4-2, Figure 601.


**32-21-38**

REPAIR 4-2

Page 601

Mar 01/2006

COMPONENT MAINTENANCE MANUAL




65C22920-2,-5,-7 69-72652-1 Crank and Arm Refinish  
Figure 601 (Sheet 1 of 2)

**32-21-38**

REPAIR 4-2  
Page 602  
Mar 01/2006

COMPONENT MAINTENANCE MANUAL



REFINISH

CRANK (270): BORIC ACID-SULFURIC ACID ANODIZE OR CHROMIC ACID ANODIZE (F-17.31). APPLY BMS 10-79, TYPE 3, PRIMER (F-19.47) AND BMS 10-60, TYPE 2 ENAMEL (F-19.39-707) UNLESS SHOWN BY 1

ARM (295): CADMIUM PLATE (F-15.06). APPLY BMS 10-79, TYPE 3, PRIMER (F-19.47) AND BMS 10-60, TYPE 2 ENAMEL (F-19.39-707) BUT NO PRIMER OR ENAMEL IN SLOT

1 NO PRIMER AND ENAMEL

REPAIR

(SAME AS REFINISH)

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

MATERIAL: CRANK (270): AL ALLOY  
ARM (295): 15-5PH CRES (150-170 KSI)

ALL DIMENSIONS ARE IN INCHES

65C22920-2,-5,-7 69-72652-1 Crank and Arm Refinish  
Figure 601 (Sheet 2 of 2)

**32-21-38**

REPAIR 4-2  
Page 603  
Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

### MISCELLANEOUS PARTS REFINISH - REPAIR 5-1

#### 1. General

- A. Use this procedure to refinish the parts which are not in the other repairs.
- B. Refer to REPAIR-GENERAL, Paragraph 2. the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Paragraph 3. for the description of the consumable codes identified in this procedure.
- D. Refer to IPL Figure 1, IPL Figure 2 and IPL Figure 3 for item numbers.

#### 2. Refinish Details

- A. Repair of these parts is only replacement of the original finish. Refer to REPAIR 5-1, Table 601 for refinish details.

**Table 601:** Refinish Details

IPL FIG. & ITEM	MATERIAL	FINISH
Fig. 1		
Pin (55), Lock (110), Nut (115)	17-4PH CRES, 180-200 ksi	Passivate (F-17.25, which replaces F-17.09).
Nut (20)	15-5PH or 17-4PH CRES, 180-200 ksi	Passivate (F-17.25, which replaces F-17.09).
Nut (20A)	17-4PH CRES, 180-200 ksi	Cadmium plate (F-15.02). Apply primer, C00259 (F-20.02) and yellow enamel coating, C00032 (F-14.9815-302, which replaces SRF-14.9815-302), but not on threads or flat face. Wipe threads with primer, C00259 (F-19.45).
Nut (20B)	15-5PH or 17-4PH CRES, 180-200 ksi	Passivate (F-17.25, which replaces F-17.09).
Nut (20C)	17-4PH or 15-5PH CRES, 180-200 ksi	Passivate (F-17.25, which replaces F-17.09) all over. Apply primer, C00259 (F-20.02) and yellow enamel coating, C00032 (F-14.9815-302, which replaces SRF-14.9815-302), but not on threads or flat face.
Spacer (50)	Al alloy	Chromic acid anodize (F-17.04).
Washer (25)	17-4PH CRES, 180-200 ksi	Passivate (F-17.25, which replaces F-17.09).
Washer (25A)	15-5PH or 17-4PH CRES, 180-200 ksi	Thin dense chrome plate (F-15.43, which replaces F-14.892) on faces, and optional on other surfaces, but no chrome plate in ID or threaded holes. Passivate (F-17.25, which replaces F-17.09) surfaces not chrome-plated.
Bracket (210)	Al alloy	Chromic acid anodize and apply primer, C00259 (F-18.13). Apply enamel coating, C00700 (F-14.9813, which replaces SRF-14.9813).
Tubes (235, 240, 245, 250, 253)	BMS 7-185 CRES	No finish (F-8.05)

# 32-21-38

REPAIR 5-1

Page 601

Mar 01/2009



## COMPONENT MAINTENANCE MANUAL

**Table 601:** Refinish Details (Continued)

IPL FIG. & ITEM	MATERIAL	FINISH
Tubes (235A, 240A, 245A, 250A, 253A)	BMS 7-185 CRES	Passivate (F-17.25, which replaces F-17.09). Apply primer, C00259 (F-20.02) and enamel coating, C50069 (F-21.03) on outside surfaces only.
Tubes (253B, 240B, 245B, 253B)	BMS 7-185 CRES	Apply primer, C00259 (F-20.02) on outside surfaces only.
Support (285)	4130 Steel or 304 CRES	Cadmium plate and apply primer, C00259 (F-16.01). Apply enamel coating, C00700 (F-14.9813, which replaces SRF-14.9813).
Target (300)	HYMU 80 Steel or Moly Permalloy No. 1	No finish.
Target (300A)	HYMO 80 Steel or Moly Permalloy No. 1	Cadmium plate and apply primer, C00259 (F-16.01) and enamel coating, C00700(F-14.9813, which replaces SRF-14.9813).
Fig. 2		
Clamps (130, 135, 140, 145, 150)	Al alloy	Chromic acid anodize and apply primer, C00259 (SRF-2.19). Apply enamel coating, C00260 (SRF-12.63).
Clamps (130, 135, 145,150)	Nylon	No finish.
Bracket (155)	Al alloy	Anodize and apply primer, C00259 (F-18.04). Apply enamel coating, C00260 (F-21.02).
Bracket (160, 165, 165A, 170, 171, 185, 185A, 188)	Al alloy	Chemical treat and apply primer, C00259 (F-18.06). Apply enamel coating, C50069 (F-21.03).
Bracket (170A, 170C, 170E)	Al alloy	Chromic acid anodize and apply primer, C00259 (F-18.06). Apply enamel coating, C00700 (F-14.9813, which replaces SRF-14.9813).
Fig. 3		
Guard (45)	Al alloy	Boric acid-sulfuric acid anodize (F-17.31). Apply primer, C00259 (F-20.02). Apply enamel coating, C50075 (F-19.39-707).
Brace (50)	15-5PH CRES	Cadmium plate and apply primer, C00259 (F-16.01). Apply enamel coating, C00700(F-14.9813, which replaces SRF-14.9813).
Washer (75)	4340 steel, 150-170 ksi	Cadmium plate (F-15.06).
Guard (85, 90), Retainer (300)	Al alloy	Boric acid-sulfuric acid anodize (F-17.31). Apply primer, C00175 (F-19.47) and enamel coating, C00033(F-19.39-707).
Trunnion (260)	17-4PH or 15-5PH CRES, 150-170 ksi	Passivate (F-17.25).

# 32-21-38

REPAIR 5-1

Page 602

Mar 01/2009

**COMPONENT MAINTENANCE MANUAL****Table 601:** Refinish Details (Continued)

<b>IPL FIG. &amp; ITEM</b>	<b>MATERIAL</b>	<b>FINISH</b>
Fitting (340)	Al alloy	Chromic acid anodize (F-17.19). Apply primer, C00259 (F-20.02) and enamel coating, C00700 (F-14.9813, which replaces SRF-14.9813), but not in holes.

**32-21-38**

REPAIR 5-1

Page 603

Mar 01/2009





## COMPONENT MAINTENANCE MANUAL

### TOW FITTING - REPAIR 6-1

65C36787-2

#### 1. General

- A. This procedure has the data necessary to repair and refinish the tow fitting.
- B. Refer to REPAIR-GENERAL, Paragraph 2. the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Paragraph 3. for the description of the consumable codes identified in this procedure.
- D. Refer to REPAIR-GENERAL, Paragraph 4. for the Standard True Position Dimensioning Symbols shown in the repair.

#### 2. Repair (REPAIR 6-1, Figure 601)



- A. Repair is only replacement of the original finish. Refer to Refinish instructions in REPAIR 6-1, Figure 601.

**32-21-38**

REPAIR 6-1  
Page 601

Mar 01/2009

COMPONENT MAINTENANCE MANUAL



	1	2	3	4	5	6
DESIGN DIM	0.379 0.375	0.42 0.40	0.555 0.550	0.760 0.755	0.41 0.39	0.773 0.755
REPAIR LIMIT	—	—	—	—	—	—

REFINISH

CADMIUM-TITANIUM PLATE (F-15.01)  
 APPLY PRIMER BMS 10-11, TYPE 1 (F-20.02)  
 AND ENAMEL BMS 10-60 (SRF-14.9813)

REPAIR

(SAME AS REFINISH)  
 125/ ALL MACHINED SURFACES

MATERIAL: 4330M STEEL, 220-240 KSI  
 ALL DIMENSIONS ARE IN INCHES

65C36787-2 Tow Fitting Repair and Refinish  
 Figure 601

**32-21-38**

REPAIR 6-1  
 Page 602  
 Mar 01/2006

**COMPONENT MAINTENANCE MANUAL****BRACKET ASSEMBLY - REPAIR 7-1**

65C22921-1, -4

**1. General**

- A. This procedure has the data necessary to repair and refinish the bracket assembly.
- B. Refer to REPAIR-GENERAL, Paragraph 2. the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Paragraph 3. for the description of the consumable codes identified in this procedure.
- D. Refer to REPAIR-GENERAL, Paragraph 4. for the Standard True Position Dimensioning Symbols shown in the repair.
- E. Refer to IPL Figure 3 for item numbers.

**2. Bearing Replacement (REPAIR 7-1, Figure 601)**

- A. Remove the old bearing (255).
- B. If you find defects on the crank, refer to REPAIR 7-1, Paragraph 3. for repair instructions.
- C. Install a replacement bearing with wet primer, C00259 (F-20.06).
- D. Roller swage the bearing (SOPM 20-50-03).

**3. Lug Faces and Holes (REPAIR 7-1, Figure 601)**

- A. Repair is only replacement of the original finish. Refer to Refinish instructions REPAIR 7-1, Figure 601 for details.


**32-21-38**

REPAIR 7-1

Page 601

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



65C22921-1,-4 Bracket Assembly Repair and Refinish  
Figure 601 (Sheet 1 of 2)

**32-21-38**


REPAIR 7-1  
Page 602  
Mar 01/2006




COMPONENT MAINTENANCE MANUAL


	①	②	③	④	⑤	⑥	⑦	⑧
DESIGN DIM	0.261 0.255	0.261 0.255	0.3135 0.3125	0.7493 0.7488	0.62 0.60	0.7493 0.7488	0.31 0.29	0.234 0.219
REPAIR LIMIT	---	---	---	---	---	---	---	---

REFINISH

BRACKET (250):  
 BORIC ACID - SULFURIC ACID ANODIZE (F-17.31).  
 APPLY BMS 10-11, TYPE 1 PRIMER (F-20.02) AND  
 BMS 10-60 ENAMEL (F-14.9813, WHICH REPLACES  
 SRF-14.9813) UNLESS SHOWN BY 

 NO PRIMER OR ENAMEL

REPAIR

125/  ALL MACHINED SURFACES UNLESS SHOWN  
 DIFFERENTLY

BREAK SHARP EDGES

MATERIAL: AL ALLOY

ITEM NUMBERS REFER TO IPL FIG. 3

ALL DIMENSIONS ARE IN INCHES

65C22921-1,-4 Bracket Assembly Repair and Refinish  
 Figure 601 (Sheet 2 of 2)

**32-21-38**

REPAIR 7-1

Page 603

Mar 01/2006

**COMPONENT MAINTENANCE MANUAL****UPPER PULLEY MOUNT - REPAIR 8-1****65C25118-3, -4****1. General**

- A. This procedure has the data necessary to repair and refinish the upper pulley mount.
- B. Refer to REPAIR-GENERAL, Paragraph 2. the Standard Overhaul Practice Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to REPAIR-GENERAL, Paragraph 3. for the description of the consumable codes identified in this procedure.
- D. Refer to REPAIR-GENERAL, Paragraph 4. for the Standard True Position Dimensioning Symbols shown in the repair.
- E. Refer to IPL Figure 3 for item numbers.

**2. Installation of Repair Bushings (REPAIR 8-1, Figure 601)**

**NOTE:** For repair of surfaces which is only replacement of the original finish, refer to Refinish instructions, REPAIR 8-1, Figure 601.

- A. Machine as required, within repair limits, to remove defects.
- B. Make repair bushings (REPAIR 8-1, Figure 602).
- C. Install the bushings by the shrink-fit method of SOPM 20-50-03.
- D. Install bushings flush with or 0.004 inch maximum below the surface of the lug.
- E. Machine the bushings to design dimensions and finish.


**32-21-38**

REPAIR 8-1


Page 601

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



SPOTFACE  
2.20  
2.18 DIA TO DEPTH SHOWN  
0.09  
0.06 FILLET RADIUS




65C25118-3,-4 Upper Pulley Mount Repair and Refinish  
Figure 601 (Sheet 1 of 2)

**32-21-38**

REPAIR 8-1  
Page 602  
Mar 01/2006

COMPONENT MAINTENANCE MANUAL



	①	②	③	④	⑤	⑥	⑦	⑧
DESIGN DIM	0.254 0.250	1.752 1.750	0.261 0.250	0.68 0.66	0.254 0.250	0.84 0.82	0.254 0.250	0.84 0.82
REPAIR LIMIT	---	1.850 ②	---	---	---	---	---	---

**REFINISH**

CHROMIC ACID ANODIZE OR SULFURIC ACID ANODIZE (F-17.05). APPLY BMS 10-11 TYPE 1 PRIMER (F-20.02) AND BMS 10-60 ENAMEL (F-14.9813, WHICH REPLACES SRF-14.9813) UNLESS SHOWN BY ①

① NO PRIMER OR ENAMEL

② LIMIT FOR INSTALLATION OF REPAIR SLEEVE (FIG. 602)

**REPAIR**

125 ✓ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK SHARP EDGES

MATERIAL: AL ALLOY

ALL DIMENSIONS ARE IN INCHES

65C25118-3,-4 Upper Pulley Mount Repair and Refinish  
Figure 601 (Sheet 2 of 2)


**32-21-38**

REPAIR 8-1  
Page 603  
Mar 01/2006






COMPONENT MAINTENANCE MANUAL



FINISH:

CHEMICAL TREAT (SOPM 20-43-03)  
(OPTIONAL ON INSIDE DIAMETER)

 LUG THICKNESS +0.000/-0.005

125  MACHINE FINISH

BREAK ALL SHARP EDGES

MATERIAL: 7075-T73 OR 6061-T6 AL ALLOY

ALL DIMENSIONS ARE IN INCHES

HOLE LOCATION  FIG. 601

Repair Sleeve Details  
Figure 602

**32-21-38**

REPAIR 8-1

Page 604

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

### ASSEMBLY

#### 1. General

- A. This procedure tells how to assemble the nose gear buildup assembly.
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices in this procedure.
- C. Refer to IPL Figure 1, IPL Figure 2 and IPL Figure 3 for item numbers.

#### 2. Equipment

**NOTE:** Equivalent substitutes can be used.

- A. 1922 or F80168-1 – Axle Nut Socket

#### 3. Assembly

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
A00247	Sealant - Pressure And Environmental - Chromate Type	BMS 5-95
B00571	Coating - Clear Hydraulic Fluid Resistant Topcoat	BAC5710, Type 41
B01006	Solvent - Final Cleaning Of Solvent Resistant Organic Coatings Before Painting (AMM 20-30-86/201) - Series 86	
B01015	Solvent - Final Cleaning Prior To Aerodynamic Smoothing And Fairing (AMM 20-30-95/201) - Series 95	
B50080	Compound - Corrosion Preventive, Solvent Cutback, Cold-Application (Grade 2 - Soft Film)	MIL-PRF-16173, Grade 2 (Supersedes MIL-C-16173, Grade 2)
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I
C00913	Compound - Corrosion Inhibiting Material, Nondrying Resin Mix	BMS 3-27
D00013	Grease - Aircraft And Instrument Grease	MIL-PRF-23827 (NATO G-354) (Supersedes MIL-G-23827)
D00014	Grease - Molybdenum Disulfide, Low & High Temperature	MIL-G-21164 (NATO G-353)
D00378	Grease - Aircraft, General Purpose, Wide Temperature - Aeroshell 22	MIL-PRF-81322
D00633	Grease - Aircraft General Purpose	BMS3-33

# 32-21-38

ASSEMBLY

Page 701

Nov 01/2008



## COMPONENT MAINTENANCE MANUAL

Reference	Description	Specification
G00150	Tape - Teflon Film With Silicon Adhesive, 5 mil - Permacel P-421	
G50152	Tape - Flat Braided Lacing, Nomex, Hydraulic Fluid Resistant, Max 260 degrees F	BMS13-54, Type III, Grade D, Class 1, Finish C
G50347	Lockwire - Nickel-copper, 0.032 inch diameter	NASM20995N~C32

### B. References

Reference	Title
CMM 32-21-48	NOSE GEAR ASSEMBLY
CMM 32-21-58	NOSE GEAR SHOCK STRUT ASSEMBLY
SOPM 20-30-03	GENERAL CLEANING PROCEDURES
SOPM 20-30-86	SOLVENTS FOR FINAL CLEANING OF SOLVENT RESISTANT ORGANIC COATINGS BEFORE PAINTING (SERIES 86)
SOPM 20-30-95	SOLVENTS FOR FINAL CLEANING BEFORE AERODYNAMIC SMOOTHING AND FAIRING (SERIES 95)
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-50-01	BOLT AND NUT INSTALLATION
SOPM 20-50-02	INSTALLATION OF SAFETYING DEVICES
SOPM 20-50-05	APPLICATION OF ALUMINUM FOIL AND OTHER MARKERS
SOPM 20-60-02	FINISHING MATERIALS
SOPM 20-60-03	LUBRICANTS
SOPM 20-60-04	MISCELLANEOUS MATERIALS

### C. Procedure

**NOTE:** For general cleaning procedures, refer to SOPM 20-30-03. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01. For bolt and nut installation, refer to SOPM 20-50-01. For finishing materials, refer to SOPM 20-60-02. For lubricants, refer to SOPM 20-60-03. For miscellaneous materials, refer to SOPM 20-60-04.

- (1) Install tow fitting (410) and taxi light (385) (IPL Figure 1).

**WARNING:** BMS 3-27 CORROSION PREVENTIVE COMPOUND CONTAINS ASBESTOS, TOLUENE, XYLENE, STRONTIUM CHROMATE AND BARIUM CHROMATE. SPEAK TO THE APPLICABLE SAFETY-STANDARDS PERSONS FOR APPROVED HANDLING PRECAUTIONS.

# 32-21-38

ASSEMBLY

Page 702

Nov 01/2008

**COMPONENT MAINTENANCE MANUAL**

(WARNING PRECEDES)

**CAUTION:** BMS 3-27 COMPOUND IS USED ONLY IN STATIC JOINTS WHERE GREASE CANNOT BE APPLIED. BMS 3-27 COMPOUND IN DYNAMIC JOINTS WILL NOT LET THEM MOVE FREELY.

- (a) Put tow fitting (410) in position on the nose gear assembly (5) with shims (435) as necessary to get a gap of 0.000-0.003 inch before you tighten nuts (395). Install the shims with wet or dry primer, C00259.
  - (b) Clean the mating surfaces between nose gear assembly (5) and tow fitting (410) with a Series 86 solvent, B01006 per SOPM 20-30-86. Apply compound, C00913 to bolt (405) undercut, shank, thread relief, threads and on the ends of bolts, on mating surfaces of the lugs on inner cylinder assembly (5), and tow fitting (410) (ASSEMBLY, Figure 703).
  - (c) Install taxi light (385) and tow fitting (410) on nose gear assembly (5) with (as applicable) bolts (405, 440), washers (400, 445, 450) and nuts (395, 455). Apply compound, C00913 to the shank, under the head, and on the end of bolts (405, 440) before installation. Tighten nuts (395) to 700-800 pound-inch (threads lubricated).
  - (d) Install bolt (415), washers (420) and nut (425) on tow fitting (410). Tighten the nut hand-tight and install cotter pin (430) (SOPM 20-50-02).
- (2) Install door operator brackets (305) and sensor target support assemblies (280A, 281A) (IPL Figure 1).
- (a) Clean mating surfaces between nose gear assembly (5) and brackets (305) with a Series 95 solvent, B01015 per (SOPM 20-30-95). Apply sealant, A00247 to one mating surface to make a continuous layer of sealant, A00247 when the parts come together.
  - (b) Install brackets (305) and target support assemblies (280A, 281A). Install bolt (340 or 345A) with compound, C00913, washers (355) under boltheads, washers (350) under nuts, and nuts (360). Use more washers (350) as necessary to make sure the nut does not get to the bottom of the threads. Cotter pins (365) will be installed in ASSEMBLY, Paragraph 3.C.(2)(d) that follows. Use washer (352, 352A) between target support assemblies (280A, 281A) and the trunnion as necessary to clear the trunnion radius. If the outer cylinder has a breakthru hole machined on the inboard bore for bolt (340 or 345A), fill the breakthru hole with sealant, A00247 when you install the bolt (CMM 32-21-58, Repair 1-2).
  - (c) Install bolts (310, 320B) with compound, C00913, washers (335) under bolthead, washers (325) under the nut, and nuts (330). Use one more washer (326) under the nut as necessary to make sure the nut does not get to the bottom of the threads.
  - (d) After the sealant, A00247 is cured, tighten the nuts again. Then install the cotter pins as applicable per SOPM 20-50-02.
- (3) If not installed, install the nose-gear-compressed sensor support (270, IPL Fig. 2 CMM 32-21-48) on the lower steering plate of the shock strut outer cylinder. Refer to CMM 32-21-48, ASSEMBLY.
- (4) If not installed, install conduit support bracket (185, IPL Figure 2) on the upper steering plate of the shock strut outer cylinder. Refer to CMM 32-21-48, ASSEMBLY.
- (5) Assemble and install the nose wheel steering valve control mechanism (IPL Figure 3).
- (a) Install pulleys (40) on the nose gear assembly steering plate.

**32-21-38**

ASSEMBLY

Page 703

Nov 01/2008

**COMPONENT MAINTENANCE MANUAL**

- 1) Apply compound, B50080 to bolts (5, 10).
- 2) On the right side of the steering plate, install retainer (300) and pulley (40) with bolt (5), washer (30) and nut (35). Install bolts (310), spacers (325), washers (315) and nuts (330).
- 3) On the left side of the steering plate, install retainer (300) and pulley (40) with bolt (10), washer (30) and nut (35). Install bolts (305), spacers (320), washers (315) and nuts (330).
- 4) Tighten nuts (35) to 30-40 lb-in.
- (b) Install bracket (245) with bolts (185, 190), washers (210) and nuts (225).
- (c) Assemble and install crank assembly (265) and front pulleys (40).
  - 1) Apply compound, B50080 to the threads of bolts (15, 120, 195, 200).
  - 2) Install trunnions (260) in crank assembly (265) with the trunnion studs at the top, and put them through the bearing holes. Install bearings (230) with wet primer, C00259. Install washers (215, 220) and nuts (265).
  - 3) Install bolts (200) through the trunnions and the crank with washers (210, 220) and nuts (225).
  - 4) Tighten nuts (225) to 30-40 lb-in.
  - 5) On the right side of crank (265), install pulley (40), bolt (15) (head outboard), washers (20, 25) and nut (35).
  - 6) On the left side of crank (265), install pulley (40), bolt (15) (head inboard), washer (20) and nut (35).
  - 7) Tighten nuts (35) to 30-40 lb-in.
  - 8) Install spacer (235) and bushing (240) with bolt (195), washers (205) and nut (225). Tighten nut (225) to 30-40 lb-in.
- (d) Install link assembly (115).
  - 1) Apply compound, B50080 to bolts (120, 135).
  - 2) Put a rig pin in the holes of crank (265) and bracket (245). Adjust the length of link assembly (115) to let bolts go in freely with no movement of the metering valve stem from its neutral position. For coarse adjustment of link, back off nuts (170, 175) and turn rod ends (160, 165) in or out as necessary. For fine adjustment, hold both rod ends and turn coupling (180). After adjustment, tighten nuts (170, 175) and lockwire, G50347 (SOPM 20-50-02).
  - 3) Install link assembly with bolt (135), washer (145), and nut (150) at the valve end, and bolt (120), washer (140) and nut (150) at the crank end. Tighten nuts (150) to 12-15 lb-in.
- (6) Install nose wheel steering cable (270, IPL Figure 1), cable guards (85, IPL Figure 3) and upper pulley mount (80, IPL Figure 3).
  - (a) Put steering cable (270, IPL Figure 1) through steering control mechanism (265, IPL Figure 1) per ASSEMBLY, Figure 701.
  - (b) Install the cable on the steering collar with cotter pins (277, IPL Figure 1) or spring pins (275, IPL Figure 1) and lockwire, G50347 (SOPM 20-50-02) (ASSEMBLY, Figure 701).
  - (c) Install cable guards (85, 90) with screws (95, 100), washers (105) and nuts (110) (IPL Figure 3). Adjust guards (85, 90) to be 0.015-0.045 inch away from the steering collar.

**32-21-38**

ASSEMBLY

Page 704

Nov 01/2008



## COMPONENT MAINTENANCE MANUAL

- (d) Install pulleys (40) and pulley guards (45) on pulley mount (80) with bolts (5), washers (20, 25) and nuts (35) (IPL Figure 3). Assemble the bolts with a thin layer of compound, B50080 on the internal and external mating threads. Tighten the nuts to 30-40 lb-in.
  - (e) Install pulley mount (80, IPL Figure 3) on the nose gear assembly with washer (75, IPL Figure 3), nut (70, IPL Figure 3) and lockwire, G50347 (SOPM 20-50-02).
  - (f) Install brace (50) on upper pulley mount (80) with bolts (55), washers (60) and nuts (65) (IPL Figure 3).
  - (g) Install the control mechanism cover with its fasteners. If fitting (335, IPL Figure 3) is included, be sure to install bolt (800) and washer (805).
- (7) Install depressurization valve (190) and hydraulic tube assemblies (235, 240, 245, 250) (IPL Figure 1).
- (a) Install bracket (210) and brace (50, IPL Figure 3) on the nose gear assembly with bolts (215), washers (220, 225) and nuts (230). Install washers (225) on the forward side of gear and washers (220) on the aft side of the gear.
  - (b) Install valve (190) with bolts (195, 200) and washers (205).
  - (c) Install tube assemblies (235, 250) on valve (190).
  - (d) Install tube assemblies (240, 245) on valve (190) and metering valve.
  - (e) Install marker (185). Apply Type 41 clear coating, B00571 (F-21.34) and seal the edges (SOPM 20-50-05).
- (8) Install electrical conduit and taxi light harness (IPL Figure 2) (ASSEMBLY, Figure 702)

**NOTE:** When you install bracket clamps, if adjustments are necessary, add no more than three NAS1149D0316K washers, or, as an alternative, trim the spacers as necessary for correct clamp-up. Chemical treat or anodize the cut surfaces of aluminum spacers, and apply BMS 10-11, Type 1 primer, C00259 (F-18.05).

**NOTE:** These instructions are with SB 32-1213 incorporated. This is recommended to help prevent wear and damage to the electrical conduit and harness. Refer to SB 32-1213 for more details.

- (a) Install clamp (120, 121) on support bracket (165, 170) with screws (5, 8) and washer (50), spacer (85) and nuts (100) if applicable.
- (b) Apply two complete wraps of 65-49726-2 tape (Scotch X-1155 or Permacel P-421 tape, G00150 or Scotch 61) on the right side of the axle and install lug clamp (125A).
- (c) Install bracket clamps (145), support bracket (155), spacers (55, 80), clamps (115A), screws (5 or 7, 30, 40), washers (50) and nuts (100) on the lower torsion link.
- (d) Install bracket clamps (145, 150), support bracket (155), spacers (80, 90, 95), clamps (115), screws (4 or 5, 30, 40), washers (50) and nuts (100) on the upper torsion link.
- (e) Install bracket clamps (130, 135, 140), spacers (60, 65, 75), clamps (110, 116), screws (10, 15, 20), washers (50) and nuts (100).
- (f) Install harness assembly (175) and sensor conduit (180) in the clamps. Plug in the harness connector on the taxi light.
- (g) Tie the conduit and harness together with tape, G50152 as shown. Paint the ties with Type 41 clear coating, B00571 (F-21.34).

# 32-21-38

ASSEMBLY

Page 705

Nov 01/2008

**COMPONENT MAINTENANCE MANUAL**

**WARNING:** BMS3-27COMPOUND, C00913 CONTAINS ASBESTOS, TOLUENE, XYLENE, STRONTIUM CHROMATE AND BARIUM CHROMATE. CONSULT APPLICABLE SAFETY STANDARDS PERSONS FOR THE APPROVED HANDLING PRECAUTIONS.

**CAUTION:** BMS COMPOUND, C00913 3-27 IS USED ONLY IN STATIC JOINTS WHERE GREASE CANNOT BE APPLIED. BMS COMPOUND, C00913 3-27 IN DYNAMIC JOINTS WILL NOT LET THEM MOVE FREELY.

(9) Install right trunnion pin (120) and swivel (140) (IPL Figure 1).

**CAUTION:** INSTALLATION OF SWIVELS ON BRACKET (165) IN REVERSE DIRECTION WILL CAUSE MALFUNCTIONS AND COULD DAMAGE THE PARTS.

- (a) Apply compound, C00913 from point A to point B around the full circumference of trunnion pin (120). Fill all voids in the area (ASSEMBLY, Figure 703).
- (b) Put swivel assemblies (170) on bracket (165) with the fitting with the flange toward the tubing connections on depressurization valve (190). Install clamps (145), screws (155) and nuts (150).

**NOTE:** Swivel assemblies have two fittings. The male fitting has a flange to fit in clamp (145).

- (c) Put bracket (165) and attached parts in pin (120) and install pin (160). Attach with lockwire, G50347 (SOPM 20-50-02).
- (d) Install pin (120) and attached parts in trunnion. Align the holes and install lock pins (55) and spring pins (125).
- (e) Give protection to the exposed end of pin (120).

**WARNING:** BMS3-27COMPOUND, C00913 CONTAINS ASBESTOS, TOLUENE, XYLENE, STRONTIUM CHROMATE AND BARIUM CHROMATE. CONSULT APPLICABLE SAFETY STANDARDS PERSONS FOR THE APPROVED HANDLING PRECAUTIONS.

**CAUTION:** BMS COMPOUND, C00913 3-27 IS USED ONLY IN STATIC JOINTS WHERE GREASE CANNOT BE APPLIED. BMS COMPOUND, C00913 3-27 IN DYNAMIC JOINTS WILL NOT LET THEM MOVE FREELY.

(10) Install left trunnion pin (60, IPL Figure 1).

- (a) Apply compound, C00913 from point A to point B around the full circumference of trunnion pin (60). Fill all voids in the area (ASSEMBLY, Figure 703).
- (b) Install nut (115) on pin (60) with lock (110) and screw (105).
- (c) Align the holes and install lock pins (55) and spring pins (125).
- (d) Give protection to the exposed end of pin (60).

(11) Install nose wheels (10, IPL Figure 1).

- (a) Remove axle and thread protectors, if installed.
- (b) Install spacers (50) on axles and attach them with cotter pins (45) (SOPM 20-50-02).

**32-21-38**

ASSEMBLY

Page 706

Nov 01/2008



## COMPONENT MAINTENANCE MANUAL

**CAUTION:** THE SHOCK STRUT INNER CYLINDER COULD HAVE UNDERSIZE AXLE THREADS THAT MUST BE USED ONLY WITH SPECIAL UNDERSIZE WHEEL BEARING NUT (20, IPL FIG. 1) 69-77849 SERIES. MAKE SURE THAT STANDARD NUTS ARE NOT USED ON UNDERSIZE AXLE THREADS.

- (c) Make sure that wheel (40) bearings are packed with Aeroshell 22 grease, D00378. Apply a good quantity of Aeroshell 22 grease, D00378 to bearing seals, axle threads and bearing surfaces, and nut (20).
  - (d) Install a wheel and tire assembly (30) on each axle. Install washers (25) and nuts (20). Use socket 1922 or F80168-1, -3 on the axle nut.
  - (e) Turn the wheel. As the wheel turns, tighten nut (20) to 80-100 lb-ft; then loosen the nut completely.
  - (f) Turn the wheel again. As the wheel turns, tighten nut (20) to 20-40 lb-ft with one continuous turn of the nut.
  - (g) Install screws (15) and lockwire, G50347 (SOPM 20-50-02).
- (12) Apply grease, D00014 or grease, D00633 or grease, D00013 to all lube fittings.

### 4. Storage

#### A. References

Reference	Title
CMM 32-21-48	NOSE GEAR ASSEMBLY
SOPM 20-44-02	TEMPORARY PROTECTIVE COATINGS
SOPM 20-70-01	PROTECTION, STORAGE AND HANDLING OF AIRPLANE COMPONENTS

#### B. Procedure

- (1) Put the unit in a stand or fixture which gives support under the inner cylinder to remove the weight from the tires.
- (2) Refer to the applicable vendor instructions for storage of wheel and tire assemblies.
- (3) Give protection to the unit and put it away by standard industry practices and the instructions in SOPM 20-44-02 and SOPM 20-70-01.
- (4) Refer to CMM 32-21-48 for servicing of the shock strut.

# 32-21-38


ASSEMBLY

Page 707

Nov 01/2008



COMPONENT MAINTENANCE MANUAL




ITEM NUMBERS REFER TO IPL FIG. 1

Nose Wheel Steering Cable Installation  
Figure 701

**32-21-38**

ASSEMBLY  
Page 708  
Mar 01/2008

COMPONENT MAINTENANCE MANUAL




Electrical Conduit and Harness Installation  
Figure 702 (Sheet 1 of 4)

**32-21-38**

ASSEMBLY  
Page 709  
Mar 01/2008

### COMPONENT MAINTENANCE MANUAL




Electrical Conduit and Harness Installation  
Figure 702 (Sheet 2 of 4)

# 32-21-38

ASSEMBLY  
Page 710  
Mar 01/2008

COMPONENT MAINTENANCE MANUAL



→ FWD

D-D

LOOKING INBOARD

Electrical Conduit and Harness Installation  
Figure 702 (Sheet 3 of 4)


**32-21-38**

ASSEMBLY

Page 711

Mar 01/2008

COMPONENT MAINTENANCE MANUAL




ITEM NUMBERS REFER TO IPL FIG. 2  
ALL DIMENSIONS ARE IN INCHES

Electrical Conduit and Harness Installation  
Figure 702 (Sheet 4 of 4)

**32-21-38**

ASSEMBLY  
Page 712  
Mar 01/2008

COMPONENT MAINTENANCE MANUAL



Corrosion Preventive Compound Application  
Figure 703 (Sheet 1 of 2)


**32-21-38**

ASSEMBLY

Page 713

Mar 01/2008

COMPONENT MAINTENANCE MANUAL



- 1 APPLY BMS 3-27 CORROSION PREVENTIVE COM-  
POUND TO THE AREAS INDICATED BY THESE  
DARK LINES
- 2 THESE DETAILS APPLY ONLY TO SPECIAL REPAIR  
TOW FITTING 65C36787-2
- 3 INSTALLATION PARTS (REF)

ITEM NUMBERS REFER TO IPL FIG. 1

Corrosion Preventive Compound Application  
Figure 703 (Sheet 2 of 2)



**32-21-38**

ASSEMBLY  
Page 714  
Mar 01/2008



COMPONENT MAINTENANCE MANUAL


FITS AND CLEARANCES



Fits and Clearances  
Figure 801 (Sheet 1 of 3)



COMPONENT MAINTENANCE MANUAL



Fits and Clearances  
Figure 801 (Sheet 2 of 3)



COMPONENT MAINTENANCE MANUAL

Ref Letter Fig.801	Mating Item No. IPL Fig.1	Design Dimension				Service Wear Limit		
		Dimension		Assembly Clearance		Dimension		Maximum Clearance
		Min	Max	Min	Max	Min	Max	
A	ID 5	2.0000	2.0010	0.0002	0.0021	1.9950	2.0048	0.0050
	OD 60	1.9989	1.9998					
A	ID 5	2.0000	2.0010	0.0005	0.0025	1.9950	2.0048	0.0050
	OD 60	1.9985	1.9995					
B	ID 5	2.0000	2.0010	0.0002	0.0021	1.9950	2.0048	0.0050
	OD 120	1.9989	1.9998					
B	ID 5	2.0000	2.0010	0.0005	0.0025	1.9950	2.0048	0.0050
	OD 120	1.9985	1.9995					
C	ID 410	0.7550	0.7600	0.0060	0.0120	0.7463	0.7627	0.0137
	OD 405	0.7480	0.7490					
	ID 20 (MINOR DIA)	1.9950	1.9970				2.0033	
	ID 20 (PITCH DIA)	2.0219	2.0239				2.0271	
	ID 20B (MINOR DIA)	1.9950	1.9970				1.9990	
	ID 20B (PITCH DIA)	2.0219	2.0249				2.0279	
	ID 20A (MINOR DIA)	1.9392	1.9412				1.9476	
	ID 20A (PITCH DIA)	1.9594	1.9614				1.9646	
	ID 20C (MINOR DIA)	1.9392	1.9412				1.9442	
	ID 20C (PITCH DIA)	1.9594	1.9624				1.9654	

ALL DIMENSIONS ARE IN INCHES

- 2.0625-16UNS3B (STANDARD THREADS)
- 2.000-16UNS3B (UNDERSIZE THREADS)
- NO REPAIR PERMITTED. REPLACE THE AXLE NUT WHEN THE ACTUAL PITCH DIAMETER OR MINOR DIAMETER IS LARGER THAN THE SERVICE WEAR LIMIT.

- PIN 65-35398-2
- PIN 65C34776-1
- PIN 65-41248-2
- PIN 65-41248-3

Fits and Clearances  
Figure 801 (Sheet 3 of 3)



COMPONENT MAINTENANCE MANUAL

FOR TORQUE VALUES OF STANDARD FASTENERS, REFER TO 20-50-01			
ITEM NO. IPL FIG.	NAME	TORQUE	
		POUND-INCHES	POUND-FEET
<u>IPL FIG. 1</u> 395	NUT-TOW FITTING	700-800	
<u>IPL FIG. 3</u> 35 150 225	NUT NUT NUT	30-40 12-15 30-40	

Torque Table  
Figure 802

PART NUMBER NONE



**COMPONENT MAINTENANCE MANUAL**

**SPECIAL TOOLS, FIXTURES, AND EQUIPMENT**

**(NOT APPLICABLE)**

**32-21-38**

SPECIAL TOOLS, FIXTURES, AND EQUIPMENT

Page 901

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

### ILLUSTRATED PARTS LIST

#### 1. Introduction

- A. The Illustrated Parts List (IPL) contains an illustration and a list of component parts you can repair or replace. The Illustrated Parts Catalog (IPC) shows how to use the Boeing part number system.
- B. This shows how parts are related: The relation of each item to its next higher assembly (NHA) is shown in the NOMENCLATURE column. Use the indenture system that follows:

1	2	3	4	5	6	7
.	Assembly					
.	Attaching parts for assembly					
.	.	Detail parts for assembly				
.	.	Subassembly				
.	.	Attaching parts for subassembly				
.	.	.	Detail parts for subassembly			
.	.	.	Sub-subassembly			
.	.	.	Attaching parts for subassembly			
.	.	.	.	Details parts for sub-subassembly		
						Detail Installation Parts (Included only if installation parts may be sent to the shop as part of assembly)

- C. Each top assembly is given one use code letter (A, B, C, etc.) in the USAGE CODE column. All subsequent component parts in the list can have one or more of the use code letters to show effectivity to top assemblies. A component part without a use code applies to all top assemblies.
- D. An alphabetical letter is added after the item number for optional parts, parts changed by a Service Bulletin, configuration differences (except left-handed and right-handed parts), last engineering releases, and parts added between item numbers in a sequence. The alphabetical letter will not be shown on the illustration for equivalent parts of the same part number.
- E. Color-coded parts are identified with a single digit alpha following the dash number or with "SP" suffix. If the "SP" suffix is used, it represents consolidation of all color codes applicable for a given usage which are not separately listed. Orders for color-coded parts should include the registry number of the airplane for which the parts are ordered.
- F. If a part number is 15 characters long but will not fit in the part number column, the part number will be displayed with a "~" at the end of the line and will be continued on the next line. The "~" denotes that the part number continues on the next line.
- G. Parts changed by a Service Bulletin are shown by PRE SB XXXX and POST SB XXXX added to the NOMENCLATURE column.
- (1) When a new top assembly is added by a Service Bulletin, PRE SB XXXX and POST SB XXXX will be added at the top assembly level only. The configuration differences at the detail part level are shown by use code letters.
- (2) When the top assembly part number is not changed by the Service Bulletin, PRE SB XXXX and POST SB XXXX will be added at the detail level.
- H. Interchangeable Parts

# 32-21-38

ILLUSTRATED PARTS LIST

Page 1001

Nov 01/2008



## COMPONENT MAINTENANCE MANUAL

Optional (OPT)	The part is optional to and interchangeable with other parts that have the same item number.
Replaces, Replaced by and not interchangeable with (REPLACES, REPLACED BY AND NOT INTCHG/W)	The part replaces and is not interchangeable with the initial part.
Replaces, Replaced by (REPLACES, REPLACED BY)	The part replaces and is interchangeable with, or is an alternative to, the initial part.

### VENDOR CODES

Code	Name
00624	EATON AEROQUIP INC ENGINEERED SYSTEMS DIV 300 S EAST AVE JACKSON, MICHIGAN 49203-1972 FORMERLY AEROQUIP ELBEE PLANT V99879 OR WESTERN PLANT V70128; FORMERLY AEROQUIP AEROSP DIV JACKSON PLANT; FORMERLY V11328 AEROQUIP LINAIR DIV; LAWRENCE PLANT V26622
0A1K8	MICHELIN AIRCRAFT TIRE CORP ONE PARKWAY SOUTH P. O. BOX 19001 GREENVILLE, SOUTH CAROLINA 29615-9001 FORMERLY IN AKRON, OH; IN CHARLOTTE, NC
21335	TIMKEN US CORPORATION DIV FAFNIR 336 MECHANIC STREET LEBANON, NH 03766-0267 FORMERLY FAFNIR BRG AND TEXTRON INC FAFNIR DIV IN NEW BRITAIN, CONNECTICUT ; FORMERLY TORRINGTON CO THE SPECIAL PRODUCTS DIV SUB OF THE INGERSOLL-RAND CO V8D210 FORMERLY TORRINGTON CO FAFNIR BEARING DIV IN TORRINGTON, CT
55284	HONEYWELL INTL INC DBA AIRCRAFT LANDING SYSTEMS/ALS/ 3520 WESTMOOR ST SOUTH BEND, INDIANA 46628-1373 FORMERLY ALLIED-SIGNAL BENDIX WHEELS & BRAKES DIV
91816	CIRCLE SEAL CONTROLS INC A WATTS INDUSTRIES INC CO 2301 WARDLOW CIRCLE PO BOX 3300 CORONA, CALIFORNIA 91718 FORMERLY BRUNSWICK CORP CIRCLE SEAL DIV BRUNSWICK VALVE FORMERLY CIRCLE SEAL DIV BRUNSWICK VALVE & CONTROL V27409; FORMERLY ZEVCO INC V62701

# 32-21-38

ILLUSTRATED PARTS LIST

Page 1002

Jul 01/2006



## COMPONENT MAINTENANCE MANUAL

<b>Code</b>	<b>Name</b>
93351	GENERAL ELECTRIC CO DISTRIBUTION ASSEMBLIES DEPT SEATTLE PLANT 37 S. HUDSON ST. PO BOX 3555 SEATTLE, WASHINGTON 98124
97153	GOODRICH BF ENGINEERED PRODUCTS GROUP PO BOX 340 WACO STREET TROY, OHIO 45373-3835
K1037	DUNLOP LTD AVIATION DIV HOLBROOK LANE COVENTRY CV6 4AA, ENGLAND

**32-21-38**

ILLUSTRATED PARTS LIST

Page 1003

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

NUMERICAL INDEX

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
10-61063-20		1	40	1
10-61063-22		1	40A	1
		1	40D	1
10-61063-23		1	40B	1
10-61063-25		1	40C	1
10-62237-9		1	40E	1
10-73		1	43	1
2607825-1		1	40A	1
		1	40D	1
2607825-2		1	40E	1
3-1348		1	40B	1
3-1348-1		1	40C	1
4551		1	390	1
4554		1	390A	1
50-0128-1		1	385	1
50-0128-3		1	385A	1
50-0199-1		1	385D	1
50-0199-11		1	385F	1
		1	385G	1
50-0199-3		1	385B	1
		1	385C	1
50-0199-9		1	385E	1
60B10055-5		1	43	1
61-32155C3HJ1629L854		1	270	1
65-44003-1		3	335	1
		3	335A	1
65-44003-2		3	340	1
65-44567-1015		1	235	1
65-44567-1016		1	240	1
65-44567-1017		1	245	1
65-44567-1018		1	250	1
65-44567-1021		1	253	1
65-44567-14		1	130B	1
65-44567-3015		1	235A	1

**32-21-38**

ILLUSTRATED PARTS LIST

Page 1004

Mar 01/2006





## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
65-44567-3016		1	240A	1
65-44567-3017		1	245A	1
65-44567-3018		1	250A	1
65-44567-3021		1	253A	1
65-44567-5002		1	135	1
65-44567-6016		1	240B	1
65-44567-6017		1	245B	1
65-44567-6021		1	253B	1
65-44567-6023		1	235B	1
65-44567-9		1	130A	1
65-44970-1		1	140	1
65-49726-()		1	255	1
65-49726-13		2	1	RF
65-49726-14		2	1A	RF
65-49726-17		2	1B	RF
65-49726-18		2	1C	RF
65-49726-19		2	1D	RF
65-49726-20		2	1E	RF
65-49726-21		2	1F	RF
65-49726-22		2	1G	RF
65-49726-23		2	1H	RF
65-49726-25		2	1J	RF
65-49726-27		2	1K	RF
65-49767-11		2	175	1
65-49767-13		2	180	1
65-49767-21		2	175A	1
65-49767-22		2	180A	1
65-49767-26		2	175B	1
65-49767-28		2	175C	1
65-49767-30		2	180B	1
65-49767-31		2	175D	1
65-49767-32		2	175E	1
65-49767-33		2	180C	1
65-49767-35		2	175F	1
65-49767-36		2	175G	1

# 32-21-38

ILLUSTRATED PARTS LIST

Page 1005

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
65-49767-39		2	175H	1
		2	175J	1
65-49767-40		2	180D	1
		2	180E	1
65-49767-42		2	180F	1
65-49767-43		2	175K	1
65-49790-104		2	215	1
65-49790-111		2	215A	1
65-49790-204		2	215B	1
65-52859-3		3	260	2
65-54231-1		3	45	2
65-55870-15		1	380	1
65-55870-19		1	380A	1
65-55870-23		1	380B	1
65-55870-25		1	380C	1
65-58256-213		1	10	1
65-58256-214		1	30	2
65-58256-215		1	35	1
65-58256-227		1	35A	1
65-58256-228		1	30D	2
65-58256-229		1	30A	2
65-58256-230		1	10A	1
65-58256-232		1	30B	2
65-58256-236		1	30C	2
65-58256-241		1	10B	1
65-58256-246		1	35B	1
65-58256-249		1	30E	2
65-58256-253		1	10C	1
65-58256-254		1	30F	2
65-58256-255		1	35D	1
65-58256-278		1	30K	2
65-58256-279		1	35E	1
65-58256-281		1	30G	2
65-58256-285		1	30J	2
65-58256-286		1	30H	2

# 32-21-38

ILLUSTRATED PARTS LIST

Page 1006

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
65-58256-288		1	10D	1
65-58256-289		1	10E	1
65-58256-293		1	30L	2
65-58256-308		1	30M	2
65-58256-311		1	30N	2
65-58256-315		1	30Q	2
65-58256-318		1	35C	1
65-58256-320		1	30P	2
65-58256-326		1	35F	1
65-58256-327		1	30R	2
65-58256-328		1	30S	2
65-58256-331		1	30T	2
65-58256-332		1	30U	2
65-73762-21		1	5	1
65-73762-25		1	5A	1
65-73762-26		1	5B	1
65-73762-27		1	5C	1
65-73762-28		1	5D	1
65C22920-1		3	265	1
65C22920-2		3	270	1
65C22920-4		3	265A	1
		3	265B	1
65C22920-5		3	270A	1
65C22920-6		3	265C	1
65C22920-7		3	270B	1
65C22920-8		3	265D	1
65C22921-1		3	245	1
65C22921-2		3	250	1
65C22921-4		3	245A	1
		3	245B	1
65C22922-1		1	265	1
		3	1	RF
65C22922-2		1	265A	1
		3	1A	RF
65C22922-3		1	265B	1

# 32-21-38

ILLUSTRATED PARTS LIST

Page 1007

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
		3	1B	RF
65C22922-4		1	265C	1
		3	1C	RF
65C25118-3		3	80	1
65C25118-4		3	80A	1
65C26885-1		1	180	1
65C26885-5		1	190	1
65C26885-6		1	190A	1
65C27531-3		1	305	2
65C31786-1		1	305A	2
65C31786-4		1	305B	2
65C34776-1		1	60A	1
65C36787-2		1	410B	1
65C37064-()		1	255A	1
65C37064-1		2	1L	RF
65C37064-2		2	1M	RF
65C37064-3		2	1N	RF
66-22723-1		1	145	2
66-24147-1		3	75	1
69-35398-2		1	60	1
69-35572-1		1	165	1
69-37118-1		2	155	2
69-37182-13		2	145	5
		2	145A	5
69-37182-14		2	130A	2
		2	150	5
		2	150A	5
69-37182-15		2	130B	5
		2	130C	2
69-37182-18		2	135B	2
69-37182-19		2	145B	5
69-37182-20		2	150B	5
69-37182-21		2	130D	2
69-37182-22		2	130E	2
69-37182-6		2	140	2

# 32-21-38

ILLUSTRATED PARTS LIST

Page 1008

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
69-37182-7		2	130	2
69-37182-8		2	135	2
		2	135A	2
69-38248-1		3	115	1
69-38248-2		3	115A	1
		3	115B	1
69-38249-1		3	180	1
69-38260-2		3	120	1
69-38261-5		1	65	1
69-38261-6		1	75	1
69-38263-1		1	100	2
69-39153-1		1	50	2
69-39154-1		1	20	2
69-39154-2		1	20B	2
69-39155-1		1	25	2
69-39155-2		1	25A	2
69-40763-1		3	300	2
69-40942-1		1	70	1
69-41248-2		1	120	1
69-41248-3		1	120A	1
69-41251-1		1	115	1
69-41252-1		1	110	1
69-41262-1		1	55	4
69-41278-3		1	410	1
69-41278-4		1	410A	1
69-54784-1		1	170A	2
69-58327-1		1	435	2
69-72652-1		3	295	1
69-72679-1		1	95	2
69-72804-1		3	50	1
69-72953-13		1	280A	1
69-72953-14		1	281A	1
69-72953-15		1	285B	1
69-72953-16		1	286B	1
69-72953-17		1	280B	1

# 32-21-38

ILLUSTRATED PARTS LIST

Page 1009

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
69-72953-18		1	281B	1
69-72953-19		1	285C	1
69-72953-20		1	286C	1
69-72953-21		1	285D	1
69-72953-22		1	286D	1
69-72953-23		1	280C	1
69-72953-24		1	281C	1
69-72953-25		1	285E	1
69-72953-26		1	286E	1
69-72953-27		1	280D	1
69-72953-28		1	281D	1
69-72953-29		1	285F	1
69-72953-3		1	300	1
69-72953-30		1	286F	1
69-72953-31		1	280E	1
69-72953-32		1	281E	1
69-72953-33		1	285G	1
69-72953-34		1	286G	1
69-72953-35		1	280F	1
69-72953-36		1	281F	1
69-72953-37		1	300A	1
69-72965-11		2	185	1
69-72965-13		2	170A	1
69-72965-22		2	165A	1
69-72965-24		2	170C	1
69-72965-26		2	170D	1
69-72965-28		2	185A	1
69-72965-33		2	188	1
69-72965-35		2	170E	1
69-72965-5		2	170	1
69-72965-9		2	165	1
69-72999-6		1	210	1
69-73336-1		3	85	1
69-73336-2		3	90	1
69-77297-1		3	160B	1

# 32-21-38

ILLUSTRATED PARTS LIST

Page 1010

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
69-77297-2		3	160C	1
69-77849-1		1	20A	2
69-77849-2		1	20C	2
ABR3M5013WGP		3	165B	1
ABR3M5014WGP		3	160A	1
AE96156G		1	170	2
AHA1290		1	40	1
AN42BC13A		1	80	1
AN960-10		1	85	1
AN960-10L		3	145	1
AN960-416		3	215	2
AN960-616		1	350	AR
AN960-716		1	325	2
		1	326	AR
AN960C1216		1	400	2
		1	420	2
AN960C416		1	220	2
AN960C616		1	352A	AR
AN960C616L		1	352	2
AN960KD10		3	105	8
AN960KD416		1	205	3
		1	225	2
AN960PD10		2	50	AR
		2	200	2
		3	140	1
		3	315	4
AN960PD416		3	30	2
		3	205	3
AN960PD416L		3	25	3
		3	60	2
		3	210	4
AN970-4		3	20	4
BAC27DHY0302		1	185	1
BAC27DHY0335		1	187	1
BACB10BX4		3	230	3

# 32-21-38

ILLUSTRATED PARTS LIST

Page 1011

Mar 01/2007



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
		3	255	1
		3	285	2
BACB10FS04J		3	230C	3
		3	285B	2
BACB10FS4		3	230A	3
		3	230B	3
		3	255A	1
		3	285A	2
BACB28AP04P025		3	290	1
BACB30DX5-5		3	275	3
BACB30DX5-6		3	275A	3
BACB30LE7-14		1	310	1
BACB30LE7-17		1	320B	1
BACB30LJ12DU84		1	415	1
BACB30LM6D51		1	340	1
BACB30LM6D55		1	345A	1
BACB30MB5A7		3	275B	3
BACB30NF4-10		3	190A	2
		3	190B	2
BACB30NF4-13		3	15	2
BACB30NF4-15		3	10	1
BACB30NF4-18		1	215	2
BACB30NF4-22		3	5	3
BACB30NF4-4		3	55	2
BACB30NF4-5		3	800	1
BACB30NF4-6		3	185	1
BACB30NF4-8		3	190	2
BACB30NR12K26		1	405	2
BACB30US6K23		1	440	3
BACC10GE104		2	110	3
		2	115	8
		2	120	1
BACC10GE105		2	116A	1
BACC10GU103		2	195	2
BACC10GU104		2	116	1

# 32-21-38

ILLUSTRATED PARTS LIST

Page 1012

Jul 01/2006





## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
BACC10GU105		2	121	1
		2	110A	3
		2	115A	8
		2	120A	1
		2	121A	1
BACC10GU106		2	110C	3
		2	110D	3
		2	115C	8
		2	115D	8
BACC10GW0250-1		2	125A	1
BACC10GW0250-1E		2	125B	1
BACC30BH5		3	280A	3
BACC42Y6A		2	190	1
BACN10HR6CD		1	455	3
BACN10HR7CD		1	330	2
BACN10JC12CD		1	395	2
BACN10JC3		1	90	1
		1	150	2
		2	100	12
		2	205	1
		3	150	2
BACN10JC4		3	330	4
		3	35	6
		3	65	2
		3	225	8
BACN10JD112A		1	425	1
BACN10JD6		1	360	2
BACN10JN4CD		3	345	1
BACN10YR3CD		2	100B	13
BACN20YR3CD		2	205B	1
BACP30J4		3	40	6
BACR15CE3AD		3	350	2
BACS12ER3K40		2	40C	1
BACS12ER3K48		2	45C	1
BACW10BP12ACU		1	420A	2

# 32-21-38

ILLUSTRATED PARTS LIST

Page 1013

Nov 01/2008



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
BACW10BP6CD		1	445	3
BACW10BP6DP		1	450	3
BACW10BP7CD		1	335	2
BACW10DS6T		1	355	2
BACW10P14CC		3	805	1
BACW10P71S		3	220	4
BCREF7631		1	270	1
BFE		1	35G	1
BUILDUP		1	1	RF
M12801		1	35I	1
MS16562-242		1	125	4
MS21042L3		2	100A	13
		2	205A	1
		3	110	4
MS21042L4		1	230	2
MS24665-298		1	45	6
MS24665-300		1	365	2
MS24665-372		1	430	1
MS24665-71		1	277	2
MS24678-9		1	15	4
		1	105	1
MS39086-3		1	275	2
MS51923-329		1	160	1
NAS1080-5		3	280	3
NAS1149D0316H		2	51	AR
NAS1149D0363J		2	50A	AR
		2	200A	2
NAS1303-25D		3	125	1
NAS1801-3-10		2	8A	1
		2	8B	1
		2	210A	2
NAS1801-3-13		2	4	1
NAS1801-3-14		2	8C	1
NAS1801-3-16		2	25	1
NAS1801-3-36		2	30A	2

# 32-21-38

ILLUSTRATED PARTS LIST

Page 1014

Jul 01/2006



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
		2	30B	2
NAS1801-3-38		2	30D	2
NAS1801-3-40		2	30C	2
NAS1801-3-44		2	35	1
NAS1801-3-47		2	35A	1
NAS1801-3-6		2	9	1
NAS1801-3-60		2	15	1
NAS1801-3-64		2	10D	1
NAS1801-3-66		2	10B	1
		2	10C	1
NAS1801-3-7		2	7	2
NAS1801-3-70		2	10A	1
NAS1801-3-72		2	10	1
NAS1801-3-8		2	5	6
		2	6	2
		2	210	2
NAS1801-3-80		2	20A	1
NAS1801-3-84		2	20	1
NAS1801-3-85		2	20B	1
		2	20C	1
NAS1801-3-88		2	10E	1
NAS1801-3-9		2	8	2
NAS42DD6-28FC		3	320	2
NAS42DD6-53FC		3	325	2
NAS43DD3-109		2	60A	1
		2	60B	1
NAS43DD3-112		2	65A	1
NAS43DD3-115FC		2	65B	1
NAS43DD3-116		2	60	1
NAS43DD3-120		2	65	1
NAS43DD3-121		2	65C	1
NAS43DD3-121N		2	65D	1
NAS43DD3-123		2	65E	1
NAS43DD3-141N		2	75A	1
NAS43DD3-143FC		2	65F	1

# 32-21-38

ILLUSTRATED PARTS LIST

Page 1015

Jul 01/2006



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
NAS43DD3-151FC		2	65G	1
NAS43DD3-152FC		2	75B	1
NAS43DD3-179		2	75C	1
NAS43DD3-182		2	75	1
NAS43DD3-186		2	75D	1
NAS43DD3-191		2	75E	1
NAS43DD3-191FC		2	75G	1
NAS43DD3-191N		2	75F	1
NAS43DD3-26FC		2	92	1
		2	92A	1
NAS43DD3-28FC		2	92B	1
NAS43DD3-32		2	80	2
		2	85	1
NAS43DD3-34FC		2	80C	2
NAS43DD3-36		2	80A	2
NAS43DD3-36FC		2	80B	2
NAS43DD3-41		2	55	1
NAS43DD3-41FC		2	55A	1
NAS43DD3-63FC		2	95A	1
NAS43DD3-64		2	95	1
NAS43DD3-69FC		2	90A	1
NAS43DD3-72		2	90	1
NAS43DD4-95		3	235	1
NAS509-18		3	70	1
NAS509-4		3	170	1
NAS509-5		3	175	1
NAS514P1032-36		2	40	1
		2	40A	1
NAS514P1032-40		2	40B	1
NAS514P1032-44		2	45	1
NAS514P1032-46		2	45A	1
NAS514P1032-48		2	45B	1
NAS559-1		3	155	2
NAS603-8P		1	155	2
NAS623-3-16		3	95	2

# 32-21-38

ILLUSTRATED PARTS LIST

Page 1016

Jul 01/2006



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
NAS623-3-17		3	100	2
NAS6603-10		3	135	1
NAS6603-15		3	305	2
NAS6603-22		3	310	2
NAS6604-10		3	200	2
NAS6604-43		3	195	1
NAS6604-44		3	195A	1
		3	195B	1
NAS6604-6		1	195	2
NAS6604-7		1	200	1
NAS75-3-024		3	130	1
NAS75-4-011		3	240	1
NAS75-4-012		3	240A	1
		3	240B	1
RA3M5-3FS428		3	160	1
REP3MS4-6FS428		3	165	1
		3	165A	1
SFE		1	35H	1
TA025149		2	110B	3
		2	115B	8
		2	120B	1
		2	121B	1


# 32-21-38

ILLUSTRATED PARTS LIST

Page 1017

Jul 01/2006

COMPONENT MAINTENANCE MANUAL



Nose Gear Buildup  
IPL Figure 1 (Sheet 1 of 3)


**32-21-38**

ILLUSTRATED PARTS LIST

Page 1018


Mar 01/2006

COMPONENT MAINTENANCE MANUAL



Nose Gear Buildup  
IPL Figure 1 (Sheet 2 of 3)

COMPONENT MAINTENANCE MANUAL



- 1 UNDER HEAD
- 2 UNDER NUT
- 3 BETWEEN TARGET SUPPORT AND TRUNNION

Nose Gear Buildup  
IPL Figure 1 (Sheet 3 of 3)





## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
-1	BUILDUP		NOSE GEAR BUILDUP (REFER TO SERVICE LETTER 737-SL-32-18 FOR DATA ABOUT INTERCHANGEABILITY OF PARTS THAT MAKE UP THESE COMPONENTS AS THEY ARE USED ON AIRPLANES OF DIFFERENT MAXIMUM GROSS WEIGHTS. THIS SERVICE LETTER NOW ALSO INCLUDES LIFE LIMIT DATA)								RF
5	65-73762-21		. NOSE GEAR ASSY (LIMITED USAGE) (REF CMM 32-21-48)								1
-5A	65-73762-25		. NOSE GEAR ASSY (LIMITED USAGE) (REF CMM 32-21-48)								1
-5B	65-73762-26		. NOSE GEAR ASSY (LIMITED USAGE) (REF CMM 32-21-48)								1
-5C	65-73762-27		. NOSE GEAR ASSY (LIMITED USAGE) (REF CMM 32-21-48)								1
-5D	65-73762-28		. NOSE GEAR ASSY (LIMITED USAGE) (REF CMM 32-21-48)								1
10	65-58256-213		. NOSE WHEEL INSTL								1
-10A	65-58256-230		. NOSE WHEEL INSTL								1
-10B	65-58256-241		. NOSE WHEEL INSTL								1
-10C	65-58256-253		. NOSE WHEEL INSTL								1
-10D	65-58256-288		. NOSE WHEEL INSTL								1
-10E	65-58256-289		. NOSE WHEEL INSTL								1
15	MS24678-9		. . SCREW								4
20	69-39154-1		. . NUT-WHEEL BEARING (PRE SB 737-32-1191)								2
20A	69-77849-1		. . NUT-WHEEL BEARING (POST SB 737-32-1191) (1/16 UNDERSIZE) (REPAIR PART)								2

-Item not Illustrated

**32-21-38**

ILLUSTRATED PARTS LIST

Page 1021

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
-20B	69-39154-2								. . NUT-WHEEL BEARING (PREFERED)		2
-20C	69-77849-2								. . NUT-WHEEL BEARING (PREFERED) (POST SB 737-32-1191) (1/16 UNDERSIZE)		2
25	69-39155-1								. . WASHER-WHEEL BEARING		2
-25A	69-39155-2								. . WASHER-WHEEL BEARING (PREFERED) (POST SB 737-32-1191)		2
30	65-58256-214								. . WHEEL AND TIRE ASSY (USED ON ITEM 10) (LIMITED USAGE)		2
-30A	65-58256-229								. . WHEEL AND TIRE ASSY (USED ON ITEMS 10, 10A, 10B) (LIMITED USAGE)		2
-30B	65-58256-232								. . WHEEL AND TIRE ASSY (USED ON ITEM 10A) (LIMITED USAGE)		2
-30C	65-58256-236								. . WHEEL AND TIRE ASSY (USED ON ITEM 10B) (LIMITED USAGE)		2
-30D	65-58256-228								. . WHEEL AND TIRE ASSY (USED ON ITEM 10) (LIMITED USAGE)		2
-30E	65-58256-249								. . WHEEL AND TIRE ASSY (USED ON ITEMS 10, 10B) (LIMITED USAGE)		2
-30F	65-58256-254								. . WHEEL AND TIRE ASSY (USED ON ITEM 10C) (LIMITED USAGE)		2
-30G	65-58256-281								. . WHEEL AND TIRE ASSY (USED ON ITEM 10D) (LIMITED USAGE) (PRE SB 737-32-1286)		2
-30H	65-58256-286								. . WHEEL AND TIRE ASSY (USED ON ITEMS 10A, 10E)		2
-30J	65-58256-285								. . WHEEL AND TIRE ASSY (USED ON ITEM 10B) (LIMITED USAGE) (POST SB 737-32-1286)		2

-Item not Illustrated

**32-21-38**

ILLUSTRATED PARTS LIST

Page 1022

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
-30K	65-58256-278		. .								2
-30L	65-58256-293		. .								2
-30M	65-58256-308		. .								2
-30N	65-58256-311		. .								2
-30P	65-58256-320		. .								2
-30Q	65-58256-315		. .								2
-30R	65-58256-327		. .								2
-30S	65-58256-328		. .								2
-30T	65-58256-331		. .								2
-30U	65-58256-332		. .								2
35	65-58256-215		. . .								1
-35A	65-58256-227		. . .								1
-35B	65-58256-246		. . .								1
-35C	65-58256-318		. . .								1

-Item not Illustrated

**32-21-38**

ILLUSTRATED PARTS LIST

Page 1023

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
-35D	65-58256-255								. . . TIRE-27X7.75-15,12PR, 225 MPH (USED ON ITEMS 30F, 30G, 30H)		1
-35E	65-58256-279								. . . TIRE-27X7.75-15,12PR, 225 MPH (USED ON ITEMS 30K, 30L, 30N, 30T)		1
-35F	65-58256-326								. . . TIRE-27X7.75-15,10PR, 225 MPH (USED ON ITEM 30R)		1
-35G	BFE								. . . TIRE (CUSTOMER OPTION) (USED ON ITEMS 30Q, 30S)		1
-35H	SFE								. . . TIRE (BOEING OPTION) (MC 3245MP3025)		1
-35I	M12801								. . . TIRE-27X7.75R-15,12PR, 225 MPH (V0A1K8) (USED ON ITEM 30U)		1
40	AHA1290								. . . WHEEL (VK1037) (SPEC 10-61063-20) (USED ON ITEMS 30, 30D, 30F, 30U)		1
-40A	2607825-1								. . . WHEEL (V55284) (SPEC 10-61063-22) (USED ON ITEMS 30A, 30B, 30H, 30Q, 30S, 30T)		1
-40B	3-1348								. . . WHEEL (V97153) (SPEC 10-61063-23) (USED ON ITEMS 30C, 30E, 30K)		1
-40C	3-1348-1								. . . WHEEL (V97153) (SPEC 10-61063-25) (USED ON ITEMS 30C, 30G, 30J, 30K, 30L, 30M, 30N, 30P, 30R) (PRE SB 737-32-1346)		1
-40D	2607825-1								. . . WHEEL (V55284) (SPEC 10-61063-22) (POST SB 737-32-1346)		1

-Item not Illustrated

**32-21-38**

ILLUSTRATED PARTS LIST

Page 1024

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
-40E	2607825-2								. . . WHEEL (V55284) (SPEC 10-62237-9) (POST SB 737-32-1346)		1
-43	10-73								. . . VALVE-TIRE FILL (V91816) (SPEC 60B10055-5) (USED ON ITEMS 30B, 30S)		1
45	MS24665-298								. . PIN-COTTER		6
50	69-39153-1								. . SPACER-WHEEL BEARING		2
55	69-41262-1								. PIN-LOCK		4
60	69-35398-2								. PIN-LH TRUNNION (OPT ITEM 60A)		1
60A	65C34776-1								. PIN-LH TRUNNION (OPT ITEM 60)		1
65	69-38261-5								. SEAL INSTL-NG TRUNNION PRESSURE		1
70	69-40942-1								. . RING		1
75	69-38261-6								. . SEAL ASSY		1
80	AN42BC13A								. . . BOLT		1
85	AN960-10								. . . WASHER		1
90	BACN10JC3								. . . NUT		1
-95	69-72679-1								. . . SEAL		2
-100	69-38263-1								. . . RETAINER		2
105	MS24678-9								. SCREW		1
110	69-41252-1								. LOCK-TRUNNION NUT		1
115	69-41251-1								. NUT-TRUNNION PIN		1
120	69-41248-2								. PIN-RH TRUNNION		1
-120A	69-41248-3								. PIN-RH TRUNNION (OPT ITEM 120)		1
125	MS16562-242								. PIN-SPRING		4
-130	65-44567-1								DELETED		
-130A	65-44567-9								. HYDRAULIC INSTL-SECT 67		1
-130B	65-44567-14								. HYDRAULIC INSTL-SECT 67		1
-135	65-44567-5002								. HYDRAULIC INSTL-SECT 67		1

-Item not Illustrated

**32-21-38**

ILLUSTRATED PARTS LIST

Page 1025

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
140	65-44970-1										1
145	66-22723-1										2
150	BACN10JC3										2
155	NAS603-8P										2
160	MS51923-329										1
165	69-35572-1										1
170	AE96156G										2
-170A	69-54784-1										2
-180	65C26885-1										1
185	BAC27DHY0302										1
-187	BAC27DHY0335										1
190	65C26885-5										1
-190A	65C26885-6										1
-195	NAS6604-6										2
200	NAS6604-7										1
205	AN960KD416										3
210	69-72999-6										1
215	BACB30NF4-18										2
220	AN960C416										2
225	AN960KD416										2

-Item not Illustrated

**32-21-38**

ILLUSTRATED PARTS LIST

Page 1026

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY	
			1	2	3	4	5	6	7			
1-												
230	MS21042L4											2
235	65-44567-1015											1
-235A	65-44567-3015											1
-235B	65-44567-6023											1
240	65-44567-1016											1
-240A	65-44567-3016											1
-240B	65-44567-6016											1
245	65-44567-1017											1
-245A	65-44567-3017											1
-245B	65-44567-6017											1
250	65-44567-1018											1
-250A	65-44567-3018											1
-253	65-44567-1021											1
253A	65-44567-3021											1
253B	65-44567-6021											1
255	65-49726-()											1
255A	65C37064-()											1

-Item not Illustrated

**32-21-38**

ILLUSTRATED PARTS LIST

Page 1027

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY		
			1	2	3	4	5	6	7				
1-													
260	69-73753-1											DELETED	
260A	69-73753-3											DELETED	
265	65C22922-1											. MECHANISM INSTL-NOSE WHEEL STEERING VALVE CONTROL (LIMITED USAGE) (FOR DETAILS SEE FIG. 3)	1
-265A	65C22922-2											. MECHANISM INSTL-NOSE WHEEL STEERING VALVE CONTROL (LIMITED USAGE) (FOR DETAILS SEE FIG. 3)	1
-265B	65C22922-3											. MECHANISM INSTL-NOSE WHEEL STEERING VALVE CONTROL (LIMITED USAGE) (FOR DETAILS SEE FIG. 3)	1
-265C	65C22922-4											. MECHANISM INSTL-NOSE WHEEL STEERING VALVE CONTROL (LIMITED USAGE) (FOR DETAILS SEE FIG. 3)	1
270	BCREF7631											. CABLE ASSY-NWS (61-32155C3HJ1629L854)	1
-275	MS39086-3											. PIN-SPRING (OPT ITEM 277)	2
-277	MS24665-71											. PIN-COTTER	2
280	69-72953-9											DELETED	
280A	69-72953-13											. SUPPORT ASSY-SENSOR TARGET (LH SIDE) (LIMITED USAGE)	1
-280B	69-72953-17											. SUPPORT ASSY-SENSOR TARGET (LH SIDE) (LIMITED USAGE)	1
-280C	69-72953-23											. SUPPORT ASSY-SENSOR TARGET (LH SIDE) (LIMITED USAGE)	1
-280D	69-72953-27											. SUPPORT ASSY-SENSOR TARGET (LH SIDE) (LIMITED USAGE)	1
-280E	69-72953-31											. SUPPORT ASSY-SENSOR TARGET (LH SIDE) (LIMITED USAGE)	1

-Item not Illustrated

**32-21-38**

ILLUSTRATED PARTS LIST

Page 1028

Mar 01/2006





## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
-280F	69-72953-35		.								1
281A	69-72953-14		.								1
-281B	69-72953-18		.								1
-281C	69-72953-24		.								1
-281D	69-72953-28		.								1
-281E	69-72953-32		.								1
-281F	69-72953-36		.								1
285	69-72953-10										
285A	69-72953-19										
-285B	69-72953-15		.	.							1
-285C	69-72953-19		.	.							1
-285D	69-72953-21		.	.							1
-285E	69-72953-25		.	.							1
-285F	69-72953-29		.	.							1
-285G	69-72953-33		.	.							1
-286B	69-72953-16		.	.							1

-Item not Illustrated

**32-21-38**

ILLUSTRATED PARTS LIST

Page 1029

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
-286C	69-72953-20		. .								1
-286D	69-72953-22		. .								1
-286E	69-72953-26		. .								1
-286F	69-72953-30		. .								1
-286G	69-72953-34		. .								1
-290	69-72953-11										DELETED
-295	69-72953-12										DELETED
-300	69-72953-3		. .								1
-300A	69-72953-37		. .								1
305	65C27531-3		. BRACKET ASSY-DOOR OPERATOR (REF OHM 32-01-03)								2
-305A	65C31786-1		. BRACKET ASSY-DOOR OPERATOR (REF OHM 32-01-03) (REPLACED BY ITEM 305B)								2
-305B	65C31786-4		. BRACKET ASSY-DOOR OPERATOR (REF OHM 32-01-03) (REPLACES ITEM 305A) (USED WITH ITEMS 280F, 281F)								2
			ATTACHING PARTS								
310	BACB30LE7-14		. BOLT (USED WITH ITEM 305)								1
315	BACB30LE7-16										DELETED
-315A	BACB30LE7-14										DELETED
320	BACB30LE7-16										DELETED
-320A	BACB30LE7-14										DELETED
-320B	BACB30LE7-17		. BOLT (USED WITH ITEMS 305A,305B)								1
325	AN960-716		. WASHER								2

-Item not Illustrated

**32-21-38**

ILLUSTRATED PARTS LIST

Page 1030

Jul 01/2006



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
326	AN960-716		.	W	A	S	H	E	R		AR
330	BACN10HR7CD		.	N	U	T					2
335	BACW10BP7CD		.	W	A	S	H	E	R		2
340	BACB30LM6D51		.	B	O	L	T				1
345	BACB30LM6D51										
345A	BACB30LM6D55		.	B	O	L	T				1
350	AN960-616		.	W	A	S	H	E	R		AR
352	AN960C616L		.	W	A	S	H	E	R		2
-352A	AN960C616			W	A	S	H	E	R		AR
355	BACW10DS6T		.	W	A	S	H	E	R		2
360	BACN10JD6		.	N	U	T					2
365	MS24665-300		.	P	I	N	-	C	O	T	2
370	BACB30LM6D54										
-370A	BACB30LM6D55										
375	BACB30LM6D54										
-375A	BACB30LM6D55										
-380	65-55870-15		.	L	I	G	H	T	I	N	1
-380A	65-55870-19		.	L	I	G	H	T	I	N	1
-380B	65-55870-23		.	L	I	G	H	T	I	N	1
-380C	65-55870-25		.	L	I	G	H	T	I	N	1

-Item not Illustrated

**32-21-38**

ILLUSTRATED PARTS LIST

Page 1031

Mar 01/2007



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1- 385	50-0128-1		.	.	.	.	.	.	.	.	1
-385A	50-0128-3		.	.	.	.	.	.	.	.	1
-385B	50-0199-3		.	.	.	.	.	.	.	.	1
-385C	50-0199-3		.	.	.	.	.	.	.	.	1
-385D	50-0199-1		.	.	.	.	.	.	.	.	1
-385E	50-0199-9		.	.	.	.	.	.	.	.	1
-385F	50-0199-11		.	.	.	.	.	.	.	.	1
-385G	50-0199-11		.	.	.	.	.	.	.	.	1
-390	4551		.	.	.	.	.	.	.	.	1
-390A	4554		.	.	.	.	.	.	.	.	1
395	BACN10JC12CD		.	.	.	.	.	.	.	.	2
400	AN960C1216		.	.	.	.	.	.	.	.	2
405	BACB30NR12K26		.	.	.	.	.	.	.	.	2
410	69-41278-3		.	.	.	.	.	.	.	.	1

-Item not Illustrated

**32-21-38**

ILLUSTRATED PARTS LIST

Page 1032

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
-410A	69-41278-4								. FITTING-TOW (REPLACES ITEM 410)		1
410B	65C36787-2								. FITTING-TOW (REPAIR PART)		1
415	BACB30LJ12DU84								. BOLT		1
420	AN960C1216								. WASHER (REPLACED BY BACW10BP12ACU)		2
-420A	BACW10BP12ACU								. WASHER (REPLACES AN960C1216)		2
425	BACN10JD112A								. NUT		1
430	MS24665-372								. PIN-COTTER		1
435	69-58327-1								. SHIM-LAMINATED		2
440	BACB30US6K23								. BOLT (USED WITH ITEM 410B)		3
445	BACW10BP6CD								. WASHER (USED WITH ITEM 410B)		3
450	BACW10BP6DP								. WASHER (USED WITH ITEM 410B)		3
455	BACN10HR6CD								. NUT (USED WITH ITEM 410B)		3

-Item not Illustrated


**32-21-38**

ILLUSTRATED PARTS LIST

Page 1033


Mar 01/2006

COMPONENT MAINTENANCE MANUAL



Taxi Light Harness Installation  
IPL Figure 2 (Sheet 1 of 3)

COMPONENT MAINTENANCE MANUAL



65-49726-SERIES THRU -25  
65C37064-SERIES

65-49726-27

Taxi Light Harness Installation  
IPL Figure 2 (Sheet 2 of 3)


**32-21-38**

ILLUSTRATED PARTS LIST

Page 1035

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



Taxi Light Harness Installation  
IPL Figure 2 (Sheet 3 of 3)





## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY	
			1	2	3	4	5	6	7			
2-												
-1	65-49726-13										A	RF
-1A	65-49726-14										B	RF
-1B	65-49726-17										C	RF
-1C	65-49726-18										D	RF
-1D	65-49726-19										E	RF
-1E	65-49726-20										F	RF
-1F	65-49726-21										G	RF
-1G	65-49726-22										H	RF
-1H	65-49726-23										I	RF
-1J	65-49726-25										J	RF
-1K	65-49726-27										K	RF
-1L	65C37064-1										L	RF
-1M	65C37064-2										M	RF
-1N	65C37064-3										N	RF
4	NAS1801-3-13										N	1
5	NAS1801-3-8										A-M	6
6	NAS1801-3-8										N	2
7	NAS1801-3-7										N	2
8	NAS1801-3-9										N	2
8A	NAS1801-3-10										B, D, F, G, I-N	1
8B	NAS1801-3-10										H	1
8C	NAS1801-3-14										H	1
9	NAS1801-3-6										H	1
10	NAS1801-3-72										A	1
10A	NAS1801-3-70										B, E, F, I, K	1
10B	NAS1801-3-66										C	1
10C	NAS1801-3-66										E	1

-Item not Illustrated

**32-21-38**

ILLUSTRATED PARTS LIST

Page 1037

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
2-											
10D	NAS1801-3-64		.	SCREW						D, G, H, J, L, M	1
10E	NAS1801-3-88		.	SCREW						N	1
15	NAS1801-3-60		.	SCREW						A, C, E	1
20	NAS1801-3-84		.	SCREW						A, B, F	1
20A	NAS1801-3-80		.	SCREW						C, D, E, G, H, J, L, M	1
20B	NAS1801-3-85		.	SCREW						E	1
20C	NAS1801-3-85		.	SCREW						I	1
25	NAS1801-3-16		.	SCREW						A, C, E	1
30	NAS1801-3-34			DELETED							
30A	NAS1801-3-36		.	SCREW						A-H, L, M	2
30B	NAS1801-3-36		.	SCREW (OPT ITEM 30C)						E, G	2
30C	NAS1801-3-40		.	SCREW						E, G, I	2
30D	NAS1801-3-38		.	SCREW						N	2
35	NAS1801-3-44		.	SCREW						A-I	1
35A	NAS1801-3-47		.	SCREW						N	1
40	NAS514P1032-36		.	SCREW						A-H	1
40A	NAS514P1032-36		.	SCREW (OPT ITEM 40B)						E, G	1
40B	NAS514P1032-40		.	SCREW						E, G, I	1
40C	BACS12ER3K40		.	SCREW						N	1
45	NAS514P1032-44		.	SCREW (OPT ITEM 45B)						E, G	1
-45A	NAS514P1032-46		.	SCREW						A-D, F, H, L, M	1
-45B	NAS514P1032-48		.	SCREW						E, G, I	1
-45C	BACS12ER3K48		.	SCREW						N	1
50	AN960PD10		.	WASHER						A-J	AR
-50A	NAS1149D0363J		.	WASHER (REPLACES AN960PD10)							AR
-51	NAS1149D0316H		.	WASHER						L, M	AR

-Item not Illustrated

**32-21-38**

ILLUSTRATED PARTS LIST

Page 1038

Nov 01/2008



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
2-											
55	NAS43DD3-41		.	SPACER						A-I, L, M	1
55A	NAS43DD3-41FC		.	SPACER						N	1
60	NAS43DD3-116		.	SPACER						A	1
60A	NAS43DD3-109		.	SPACER						C	1
60B	NAS43DD3-109		.	SPACER (LIMITED USAGE)						E	1
65	NAS43DD3-120		.	SPACER						A	1
65A	NAS43DD3-112		.	SPACER						B, F	1
65B	NAS43DD3-115FC		.	SPACER						K	1
65C	NAS43DD3-121		.	SPACER						D, G, H, L	1
65D	NAS43DD3-121N		.	SPACER						M	1
65E	NAS43DD3-123		.	SPACER						C, E, I	1
65F	NAS43DD3-143FC		.	SPACER						N	1
65G	NAS43DD3-151FC		.	SPACER						J	1
75	NAS43DD3-182		.	SPACER						A	1
75A	NAS43DD3-141N		.	SPACER						J	1
75B	NAS43DD3-152FC		.	SPACER						K	1
75C	NAS43DD3-179		.	SPACER						B, F	1
75D	NAS43DD3-186		.	SPACER						C, D, E, G, I	1
75E	NAS43DD3-191		.	SPACER						H, L	1
75F	NAS43DD3-191N		.	SPACER						M	1
75G	NAS43DD3-191FC		.	SPACER						N	1
80	NAS43DD3-32		.	SPACER						A-G, I	2
80A	NAS43DD3-36		.	SPACER						H, L	2
80B	NAS43DD3-36FC		.	SPACER						M	2
80C	NAS43DD3-34FC		.	SPACER						N	2
85	NAS43DD3-32		.	SPACER						A, C, E	1
90	NAS43DD3-72		.	SPACER						A-I, L, M	1
-90A	NAS43DD3-69FC		.	SPACER						N	1
-92	NAS43DD3-26FC		.	SPACER						N	1

-Item not Illustrated

**32-21-38**

ILLUSTRATED PARTS LIST

Page 1039

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
2-											
-92A	NAS43DD3-26FC		.							A-M	1
-92B	NAS43DD3-28FC		.							A-M	1
95	NAS43DD3-64		.							A-I, L, M	1
95A	NAS43DD3-63FC		.							N	1
100	BACN10JC3		.							A-K	12
100A	MS21042L3		.							L, M	13
100B	BACN10YR3CD		.							N	13
110	BACC10GE104		.							A-I	3
-110A	BACC10GU105		.							A-I	3
-110B	TA025149		.							L, M	3
-110C	BACC10GU106		.							N	3
-110D	BACC10GU106		.							A-M	3
115	BACC10GE104		.							A-I	8
115A	BACC10GU105		.							A-I	8
115B	TA025149		.							L, M	8
115C	BACC10GU106		.							N	8
115D	BACC10GU106		.							A-M	8
116	BACC10GU104		.							A, C, E, I	1
116A	BACC10GE105		.							C, E, I	1
120	BACC10GE104		.							A-1	1
-120A	BACC10GU105		.							A-I	1

-Item not Illustrated

**32-21-38**

ILLUSTRATED PARTS LIST

Page 1040

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
2-											
-120B	TA025149		.							A-I	1
-121	BACC10GU104		.							A-I	1
-121A	BACC10GU105		.							B-I	1
-121B	TA025149		.							L, M	1
125	BACC10GW0250-1A										
125A	BACC10GW0250-1		.							A-I, L, M	1
125B	BACC10GW0250-1E		.							N	1
130	69-37182-7		.							A, B	2
-130A	69-37182-14		.							F	2
-130B	69-37182-15		.							C, D	5
-130C	69-37182-15		.							E	2
-130D	69-37182-21		.							E, G-N	2
-130E	69-37182-22		.							F	2
135	69-37182-8		.							A-D	2
135A	69-37182-8		.							E, F, G	2
135B	69-37182-18		.							E-N	2
140	69-37182-6		.							A	2
145	69-37182-13		.							A-D	5

-Item not Illustrated

**32-21-38**

ILLUSTRATED PARTS LIST

Page 1041

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE	USAGE CODE	UNITS PER ASSY
2-					
145A	69-37182-13		. CLAMP-BRACKET (ALUMINUM) (OPT ITEM 145B)	E, F, G	5
145B	69-37182-19		. CLAMP-BRACKET (NYLON)	E-N	5
150	69-37182-14		. CLAMP-BRACKET (ALUMINUM)	A-D	5
-150A	69-37182-14		. CLAMP-BRACKET (ALUMINUM) (OPT ITEM 150B)	E, F, G	5
-150B	69-37182-20		. CLAMP-BRACKET (NYLON)	E-N	5
155	69-37118-1		. BRACKET-SUPPORT	A-I, L, M, N	2
165	69-72965-9		. BRACKET ASSY-SUPPORT (PRE SB 737-32-1213)	A, C	1
165A	69-72965-22		. BRACKET ASSY-SUPPORT (LIMITED USAGE) (PRE SB 737-32-1213)	E	1
-170	69-72965-5		. BRACKET ASSY-SUPPORT (LIMITED USAGE) (PRE SB 737-32-1213)	B	1
-170A	69-72965-13		. BRACKET ASSY-SUPPORT (LIMITED USAGE) (PRE SB 737-32-1213)	B, D, G	1
-170C	69-72965-24		. BRACKET ASSY-SUPPORT (LIMITED USAGE) (PRE SB 737-32-1213)	H, I, L, M	1
-170D	69-72965-26		. BRACKET ASSY-SUPPORT (PRE SB 737-32-1213)	E, I	1
-170E	69-72965-35		. BRACKET ASSY-SUPPORT (PRE SB 737-32-1213)	J, K	1
175	65-49767-11		. HARNESS ASSY (LIMITED USAGE) (PRE SB 737-32-1213)	A, C, E	1
-175A	65-49767-21		. HARNESS ASSY (LIMITED USAGE) (PRE SB 737-32-1213)	B, D, F, G	1

-Item not Illustrated

**32-21-38**

ILLUSTRATED PARTS LIST

Page 1042

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE	USAGE CODE	UNITS PER ASSY
2-					
-175B	65-49767-26		. HARNESS ASSY (LIMITED USAGE) (PRE SB 737-32-1213)	A, E, I	1
-175C	65-49767-28		. HARNESS ASSY (LIMITED USAGE) (PRE SB 737-32-1213)	A, C, E	1
-175D	65-49767-31		. HARNESS ASSY (LIMITED USAGE) (PRE SB 737-32-1213)	G	1
-175E	65-49767-32		. HARNESS ASSY (LIMITED USAGE) (PRE SB 737-32-1213)	H	1
-175F	65-49767-35		. HARNESS ASSY (LIMITED USAGE) (PRE SB 737-32-1213)	H	1
-175G	65-49767-36		. HARNESS ASSY (LIMITED USAGE) (OPT ITEM 175E) (PRE SB 737-32-1213)	H	1
-175H	65-49767-39		. HARNESS ASSY (POST SB 737-32-1213)	H	1
-175J	65-49767-39		. HARNESS ASSY	L, M, N	1
-175K	65-49767-43		. HARNESS ASSY (POST SB 737-32-1213)	A-G, I	1
180	65-49767-13		. HARNESS ASSY (REPLACED BY ITEM 181A) (PRE SB 737-32-1213)	A, C	1
-180A	65-49767-22		. HARNESS ASSY (PRE SB 737-32-1213)	B, D	1
-180B	65-49767-30		. HARNESS ASSY (REPLACES ITEM 181) (PRE SB 737-32-1213)	A, C, E, F, G, I	1
-180C	65-49767-33		. HARNESS ASSY (PRE SB 737-32-1213)	H	1
-180D	65-49767-40		. HARNESS ASSY (POST SB 737-32-1213)	A-I	1
-180E	65-49767-40		. HARNESS ASSY	L, M, N	1
-180F	65-49767-42		. HARNESS ASSY	J, K	1

-Item not Illustrated

**32-21-38**

ILLUSTRATED PARTS LIST

Page 1043

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
2-											
185	69-72965-11		.							A-I, L, M, N	1
-185A	69-72965-28		.							J, K	1
188	69-72965-33		.							K	1
190	BACC42Y6A		.								1
195	BACC10GU103		.								2
200	AN960PD10		.							A-I	2
-200A	NAS1149D0363J		.							J-N	2
205	BACN10JC3		.							A-G, I	1
-205A	MS21042L3		.							H, L, M	1
-205B	BACN20YR3CD		.							N	1
210	NAS1801-3-8		.							A-J, L-N	2
-210A	NAS1801-3-10		.							K	2
215	65-49790-104		.							A-I, L, M, N	1
-215A	65-49790-111		.							J, K	1
-215B	65-49790-204		.							L, M, N	1
											(REPLACES ITEM 215)

-Item not Illustrated

**32-21-38**


ILLUSTRATED PARTS LIST

Page 1044

Mar 01/2006



COMPONENT MAINTENANCE MANUAL



Nose Wheel Steering Valve Control Mechanism Installation  
IPL Figure 3 (Sheet 1 of 2)


**32-21-38**

ILLUSTRATED PARTS LIST

Page 1045

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



Nose Wheel Steering Valve Control Mechanism Installation  
IPL Figure 3 (Sheet 2 of 2)

**32-21-38**

ILLUSTRATED PARTS LIST

Page 1046

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
3-											
-1	65C22922-1									A	RF
-1A	65C22922-2									B	RF
-1B	65C22922-3									C	RF
-1C	65C22922-4									D	RF
5	BACB30NF4-22										3
10	BACB30NF4-15										1
15	BACB30NF4-13										2
20	AN970-4										4
25	AN960PD416L										3
30	AN960PD416										2
35	BACN10JC4										6
40	BACP30J4										6
45	65-54231-1										2
50	69-72804-1										1
55	BACB30NF4-4										2
60	AN960PD416L										2
65	BACN10JC4										2
70	NAS509-18										1
75	66-24147-1										1
80	65C25118-3										1
-80A	65C25118-4										1
85	69-73336-1										1
90	69-73336-2										1
95	NAS623-3-16										2

-Item not Illustrated

**32-21-38**

ILLUSTRATED PARTS LIST

Page 1047

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
3-											
100	NAS623-3-17								. SCREW		2
105	AN960KD10								. WASHER		8
110	MS21042L3								. NUT		4
									----- * -----		
115	69-38248-1								. LINK ASSY-ADJUSTABLE (LIMITED USAGE)	A	1
-115A	69-38248-2								. LINK ASSY-ADJUSTABLE (LIMITED USAGE)	A	1
-115B	69-38248-2								. LINK ASSY-ADJUSTABLE ATTACHING PARTS	B, C, D	1
120	69-38260-2								. BOLT ASSY		1
-125	NAS1303-25D								. . BOLT		1
-130	NAS75-3-024								. . BUSHING		1
135	NAS6603-10								. BOLT		1
140	AN960PD10								. WASHER		1
145	AN960-10L								. WASHER		1
150	BACN10JC3								. NUT		2
									----- * -----		
155	NAS559-1								. . LOCK		2
160	RA3M5-3FS428								. . ROD END (V21335) (USED ON ITEM 115)		1
-160A	ABR3M5014WGP								. . ROD END (V21335) (USED ON ITEMS 115A, 115B)		1
-160B	69-77297-1								. . ROD END (USED ON ITEMS 115A, 115B) (OPT ITEM 160A)		1
-160C	69-77297-2								. . ROD END (USED ON ITEMS 115A, 115B) (OPT ITEM 160A)		1
165	REP3MS4-6FS428								. . ROD END (V21335) (USED ON ITEM 115)		1

-Item not Illustrated

**32-21-38**

ILLUSTRATED PARTS LIST

Page 1048

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
3-											
-165A	REP3MS4-6FS428										1
-165B	ABR3M5013WGP										1
170	NAS509-4										1
175	NAS509-5										1
180	69-38249-1										1
180A	69-38249-2										
185	BACB30NF4-6										1
190	BACB30NF4-8								A		2
-190A	BACB30NF4-10								A		2
-190B	BACB30NF4-10								B, C, D		2
195	NAS6604-43								A		1
-195A	NAS6604-44								A		1
-195B	NAS6604-44								B, C, D		1
200	NAS6604-10										2
205	AN960PD416										3
210	AN960PD416L										4
215	AN960-416										2
220	BACW10P71S										4
225	BACN10JC4										8
230	BACB10BX4								A		3
-230A	BACB10FS4								A		3
-230B	BACB10FS4								B		3
-230C	BACB10FS04J								C, D		3
235	NAS43DD4-95										1

-Item not Illustrated

**32-21-38**

ILLUSTRATED PARTS LIST

Page 1049

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
3-											
240	NAS75-4-011		.	BUSHING (LIMITED USAGE)						A	1
-240A	NAS75-4-012		.	SPACER (LIMITED USAGE)						A	1
-240B	NAS75-4-012		.	SPACER						B, C, D	1
245	65C22921-1		.	BRACKET ASSY (LIMITED USAGE)						A	1
-245A	65C22921-4		.	BRACKET ASSY (LIMITED USAGE)						A	1
-245B	65C22921-4		.	BRACKET ASSY						B, C, D	1
-250	65C22921-2		. .	BRACKET							1
-255	BACB10BX4		. .	BEARING (USED ON ITEM 245)							1
-255A	BACB10FS4		. .	BEARING (USED ON ITEMS 245A, 245B)							1
260	65-52859-3		.	TRUNNION							2
265	65C22920-1		.	CRANK ASSY (LIMITED USAGE)						A	1
-265A	65C22920-4		.	CRANK ASSY (LIMITED USAGE)						A	1
-265B	65C22920-4		.	CRANK ASSY						B	1
-265C	65C22920-6		.	CRANK ASSY						C	1
-265D	65C22920-8		.	CRANK ASSY						D	1
270	65C22920-2		. .	CRANK							1
-270A	65C22920-5		. .	CRANK (USED ON ITEM 265C)							1
-270B	65C22920-7		. .	CRANK (USED ON ITEM 265D)							1
-275	BACB30DX5-5		. .	LOCKBOLT (USED ON ITEM 265)							3
-275A	BACB30DX5-6		. .	LOCKBOLT (USED ON ITEMS 265A, 265B, 265C)							3
-275B	BACB30MB5A7		. .	LOCKBOLT (USED ON ITEM 265D)							3
-280	NAS1080-5		. .	COLLAR (USED ON ITEMS 265-265C)							3

-Item not Illustrated

**32-21-38**

ILLUSTRATED PARTS LIST

Page 1050

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
3-											
-280A	BACC30BH5		. .								3
285	BACB10BX4		. .								2
-285A	BACB10FS4		. .								2
-285B	BACB10FS04J		. .								2
290	BACB28AP04P025		. .								1
-295	69-72652-1		. .								1
300	69-40763-1		. .								2
305	NAS6603-15		. .								2
310	NAS6603-22		. .								2
315	AN960PD10		. .								4
320	NAS42DD6-28FC		. .								2
325	NAS42DD6-53FC		. .								2
330	BACN10JC3		. .								4
335	65-44003-1		. .							A	1
-335A	65-44003-1		. .							B, C, D	1
340	65-44003-2		. .								1
345	BACN10JN4CD		. .								1
350	BACR15CE3AD		. .								2
800	BACB30NF4-5		BOLT								1
805	BACW10P14CC		WASHER								1

-Item not Illustrated

**32-21-38**

ILLUSTRATED PARTS LIST

Page 1051

Mar 01/2006