



# **COMPONENT MAINTENANCE MANUAL WITH ILLUSTRATED PARTS LIST**

## **NOSE LANDING GEAR RETRACT ACTUATOR ASSEMBLY**

**PART NUMBER  
273A1101-1**

**BOEING PROPRIETARY, CONFIDENTIAL, AND/OR TRADE SECRET**

Copyright © 1995 The Boeing Company  
Unpublished Work - All Rights Reserved

Boeing claims copyright in each page of this document only to the extent that the page contains copyrightable subject matter. Boeing also claims copyright in this document as a compilation and/or collective work.

This document includes proprietary information owned by The Boeing Company and/or one or more third parties. Treatment of the document and the information it contains is governed by contract with Boeing. For more information, contact The Boeing Company, P.O. Box 3707, Seattle, Washington 98124.

Boeing, the Boeing signature, the Boeing symbol, 707, 717, 727, 737, 747, 757, 767, 777, 787, Dreamliner, BBJ, DC-8, DC-9, DC-10, KC-10, KDC-10, MD-10, MD-11, MD-80, MD-88, MD-90, P-8A, Poseidon and the Boeing livery are all trademarks owned by The Boeing Company; and no trademark license is granted in connection with this document unless provided in writing by Boeing.

PUBLISHED BY BOEING COMMERCIAL AIRPLANES GROUP, SEATTLE, WASHINGTON, USA  
A DIVISION OF THE BOEING COMPANY  
PAGE DATE: Jul 01/2009

**32-33-12**

Page 1  
Jul 01/2009



## COMPONENT MAINTENANCE MANUAL

Revision No. 14  
Jul 01/2009

To: All holders of NOSE LANDING GEAR RETRACT ACTUATOR ASSEMBLY 32-33-12.

Attached is the current revision to this COMPONENT MAINTENANCE MANUAL

The COMPONENT MAINTENANCE MANUAL is furnished either as a printed manual, on microfilm, or digital products, or any combination of the three. This revision replaces all previous microfilm cartridges or digital products. All microfilm and digital products are reissued with all obsolete data deleted and all updated pages added.

For printed manuals, changes are indicated on the List of Effective Pages (LEP). The pages which are revised will be identified on the LEP by an R (Revised), A (Added), O (Overflow, i.e. changes to the document structure and/or page layout), or D (Deleted). Each page in the LEP is identified by Chapter-Section-Subject number, page number and page date.

Pages replaced or made obsolete by this revision should be removed and destroyed.

### ATTENTION

IF YOU RECEIVE PRINTED REVISIONS, PLEASE VERIFY THAT YOU HAVE RECEIVED AND FILED THE PREVIOUS REVISION. BOEING MUST BE NOTIFIED WITHIN 30 DAYS IF YOU HAVE NOT RECEIVED THE PREVIOUS REVISION. REQUESTS FOR REVISIONS OTHER THAN THE PREVIOUS REVISION WILL REQUIRE A COMPLETE MANUAL REPRINT SUBJECT TO REPRINT CHARGES SHOWN IN THE DATA AND SERVICES CATALOG.

**32-33-12**  
TRANSMITTAL LETTER  
Page 1  
Jul 01/2009



## COMPONENT MAINTENANCE MANUAL

### Location of Change

32-33-12

REPAIR 3-1

REPAIR 3-2

### Description of Change

Added a note to use tighter bushings in the head end if bushing migration is a problem.

Changed the data in the References list.

Added clarifications.

Added the References list.

# 32-33-12

HIGHLIGHTS

Page 1

Jul 01/2009



## COMPONENT MAINTENANCE MANUAL

Subject/Page	Date	Subject/Page	Date	Subject/Page	Date
TITLE PAGE		32-33-12 DISASSEMBLY		32-33-12 REPAIR 6-1 (cont)	
O 1	Jul 01/2009	301	Mar 01/2007	602	Mar 01/2006
2	BLANK	302	Mar 01/2007	603	Mar 01/2006
32-33-12 TRANSMITTAL LETTER		32-33-12 CLEANING		604	BLANK
O 1	Jul 01/2009	401	Mar 01/2006	32-33-12 REPAIR 7-1	
2	BLANK	402	BLANK	601	Mar 01/2006
32-33-12 HIGHLIGHTS		32-33-12 CHECK		602	Mar 01/2006
O 1	Jul 01/2009	501	Mar 01/2006	32-33-12 REPAIR 8-1	
2	BLANK	502	BLANK	601	Mar 01/2006
32-33-12 EFFECTIVE PAGES		32-33-12 REPAIR - GENERAL		602	Mar 01/2006
1 thru 2	Jul 01/2009	601	Mar 01/2006	603	Mar 01/2006
		602	Mar 01/2006	604	BLANK
32-33-12 CONTENTS		32-33-12 REPAIR 1-1		32-33-12 REPAIR 9-1	
1	Mar 01/2006	601	Mar 01/2006	601	Mar 01/2006
2	BLANK	602	Mar 01/2006	602	Mar 01/2006
32-33-12 TR AND SB RECORD		32-33-12 REPAIR 2-1		32-33-12 REPAIR 10-1	
1	Mar 01/2006	601	Mar 01/2006	601	Mar 01/2006
2	BLANK	602	Mar 01/2006	602	Mar 01/2006
32-33-12 REVISION RECORD		603	Mar 01/2006	32-33-12 REPAIR 11-1	
1	Mar 01/2006	604	Mar 01/2006	601	Jul 01/2006
2	Mar 01/2006	32-33-12 REPAIR 3-1		602	BLANK
32-33-12 RECORD OF TEMPORARY REVISIONS		R 601	Jul 01/2009	32-33-12 ASSEMBLY	
1	Mar 01/2006	602	Mar 01/2006	701	Jul 01/2008
2	Mar 01/2006	32-33-12 REPAIR 3-2		702	Mar 01/2007
32-33-12 INTRODUCTION		R 601	Jul 01/2009	703	Mar 01/2007
1	Mar 01/2009	602	Jul 01/2008	704	Mar 01/2006
2	BLANK	603	Jul 01/2008	32-33-12 FITS AND CLEARANCES	
32-33-12 DESCRIPTION AND OPERATION		604	Jul 01/2008	801	Mar 01/2009
1	Mar 01/2006	32-33-12 REPAIR 4-1		802	Mar 01/2009
2	Mar 01/2006	601	Mar 01/2006	803	Mar 01/2006
32-33-12 TESTING AND FAULT ISOLATION		602	Mar 01/2006	804	BLANK
101	Jul 01/2008	603	Mar 01/2006	32-33-12 SPECIAL TOOLS, FIXTURES, AND EQUIPMENT	
102	Mar 01/2006	604	Mar 01/2006	901	Mar 01/2006
103	Mar 01/2006	605	Mar 01/2006	902	BLANK
104	Mar 01/2006	606	Mar 01/2006	32-33-12 ILLUSTRATED PARTS LIST	
105	Jul 01/2008	32-33-12 REPAIR 5-1		1001	Nov 01/2008
106	BLANK	601	Mar 01/2006	1002	Nov 01/2006
		602	Mar 01/2006	1003	Jul 01/2006
		32-33-12 REPAIR 6-1		1004	Jul 01/2006
		601	Jul 01/2008		

A = Added, R = Revised, D = Deleted, O = Overflow

# 32-33-12

EFFECTIVE PAGES

Page 1

Jul 01/2009



## COMPONENT MAINTENANCE MANUAL

Subject/Page	Date	Subject/Page	Date	Subject/Page	Date
32-33-12 ILLUSTRATED PARTS LIST (cont)					
1005	Mar 01/2007				
1006	Mar 01/2007				
1007	Mar 01/2007				
1008	Jul 01/2006				
1009	Mar 01/2007				
1010	Mar 01/2007				
1011	Mar 01/2007				
1012	Mar 01/2007				
1013	Jul 01/2006				
1014	Jul 01/2006				
1015	Mar 01/2007				
1016	Mar 01/2007				
1017	Mar 01/2007				
1018	BLANK				

A = Added, R = Revised, D = Deleted, O = Overflow

# 32-33-12

EFFECTIVE PAGES

Page 2

Jul 01/2009



## COMPONENT MAINTENANCE MANUAL

### TABLE OF CONTENTS

<u>Paragraph Title</u>	<u>Page</u>
NOSE LANDING GEAR RETRACT ACTUATOR ASSEMBLY - DESCRIPTION AND OPERATION	1
TESTING AND FAULT ISOLATION	101
DISASSEMBLY	301
CLEANING	401
CHECK	501
REPAIR	601
ASSEMBLY	701
FITS AND CLEARANCES	801
SPECIAL TOOLS, FIXTURES, AND EQUIPMENT	(Not Applicable)
ILLUSTRATED PARTS LIST	1001

# 32-33-12

CONTENTS

Page 1

Mar 01/2006



**COMPONENT MAINTENANCE MANUAL**

**TEMPORARY REVISION AND SERVICE BULLETIN RECORD**

BOEING SERVICE BULLETIN	BOEING TEMPORARY REVISION	OTHER DIRECTIVE	DATE OF INCORPORATION INTO MANUAL
		PRR 38036	DEC 01/97

**32-33-12**

TR AND SB RECORD

Page 1

Mar 01/2006



**COMPONENT MAINTENANCE MANUAL**

All revisions to this manual will be accompanied by transmittal sheet bearing the revision number. Enter the revision number in numerical order, together with the revision date, the date filed and the initials of the person filing.

Revision		Filed		Revision		Filed	
Number	Date	Date	Initials	Number	Date	Date	Initials







**COMPONENT MAINTENANCE MANUAL**

All temporary revisions to this manual will be accompanied by a cover sheet bearing the temporary revision number. Enter the temporary revision number in numerical order, together with the temporary revision date, the date the temporary revision is inserted and the initials of the person filing. When the temporary revision is incorporated or cancelled, and the pages are removed, enter the date the pages are removed and the initials of the person who removed the temporary revision.

Temporary Revision		Inserted		Removed		Temporary Revision		Inserted		Removed	
Number	Date	Date	Initials	Date	Initials	Date	Initials	Number	Date	Date	Initials





## COMPONENT MAINTENANCE MANUAL

### INTRODUCTION

#### 1. General

- A. The instructions in this manual supply the data necessary to do the maintenance functions together with the test, fault isolation, repair, and replacement of the defective parts.
- B. This manual is divided into different parts:
  - (1) Title Page
  - (2) Transmittal Letter
  - (3) Highlights
  - (4) List of Effective Pages
  - (5) Table of Contents
  - (6) Temporary Revision & Service Bulletin Record
  - (7) Record of Revisions
  - (8) Record of Temporary Revisions
  - (9) Introduction
  - (10) Procedures & IPL Sections
- C. Components that can be repaired have a different repair number for each specified repair. To find the repair number location of a component, look in the Repair-General procedure at the beginning of the REPAIR section. The Repair-General procedure also has an explanation of the True Position Dimension symbols used.
- D. All dimensions, measures, quantities and weights included are in English units. When metric equivalents are given they will be in the parentheses that follow the English units.
- E. The introduction to the Illustrated Parts List (IPL) shows how the IPL data is used.
- F. Design changes, optional parts, configuration differences and Service Bulletin modifications may cause different part numbers. These part numbers are identified in the IPL with an alphabetical letter which is added to the end of the basic item number. This new item number is referred to as an alpha-variant. Throughout the manual, IPL basic item number references also apply to alpha-variants unless shown differently.
- G. The tool reference numbers found in the individual procedures and in the Special Tools, Fixtures, and Equipment section are used to identify if a tool is a standard tool (STD-XXXX), a commercial tool (COM-XXXX), or a Special Tool (SPL-XXXX). This reference number is also used to distinguish between tools with similar names in the same procedure. These reference numbers are for use in the documentation only. They are not to be used for ordering tools.

# 32-33-12

INTRODUCTION

Page 1

Mar 01/2009



## COMPONENT MAINTENANCE MANUAL

### NOSE LANDING GEAR RETRACT ACTUATOR ASSEMBLY - DESCRIPTION AND OPERATION

#### 1. Description

A. The nose landing gear retract actuator assembly is a hydraulic piston type which consists of a CRES piston, a CRES cylinder assembly and a titanium head end assembly.

#### 2. Operation

A. The actuator extends and retracts when hydraulic pressure is applied. There is a snubber that slows the rate of the piston when it gets to the end of the extend and retract strokes.

#### 3. Leading Particulars (Approximate)

- A. Length (retracted) – 18; (extended) – 26 inches
- B. Diameter – 3.5 inches
- C. Weight – 26.5 pounds
- D. Pressure (proof) – 4500 psi
- E. Pressure (operate) – 3000 psi
- F. Fluid (operate) – BMS 3-11 hydraulic fluid fluid, D00153


# 32-33-12

DESCRIPTION AND OPERATION

Page 1

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



Retract Actuator Assembly - Nose Landing Gear  
Figure 1

**32-33-12**

DESCRIPTION AND OPERATION

Page 2

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

### TESTING AND FAULT ISOLATION

#### 1. General

- A. This procedure has the data necessary to do a test of the nose gear retract actuator after an overhaul or for fault isolation. There are three parts:
- (1) Nose Gear Retract Actuator Test
    - (a) External leakage
    - (b) Internal leakage
    - (c) Seal friction
    - (d) Extend rate
    - (e) Retract rate
    - (f) Proof pressure
  - (2) Fault Isolation
  - (3) Fault Correction
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.

#### 2. Nose Gear Retract Actuator Test

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
D00153	Fluid - Hydraulic, Erosion Arresting, Fire Resistant	BMS3-11 Type IV (interchangeable & intermixable with Type V)
G50347	Lockwire - Nickel-copper, 0.032 inch diameter	NASM20995N~C32

- B. References

Reference	Title
SOPM 20-50-02	INSTALLATION OF SAFETYING DEVICES
SOPM 20-60-03	LUBRICANTS
SOPM 20-60-04	MISCELLANEOUS MATERIALS

- C. Test Requirements

- (1) A hydraulic test stand with these requirements:
  - (a) Can operate with fluid, D00153.
  - (b) Can operate in a range of 0 - 4700 psi.
  - (c) The fluid must be continuously filtered by a filter no larger than 15 micron absolute.

# 32-33-12

TESTING AND FAULT ISOLATION

Page 101

Jul 01/2008



## COMPONENT MAINTENANCE MANUAL

(d) The fluid temperature to be 60-120°F.

### D. Prepare for Test

- (1) Install the actuator in the C32036-2 – Stand
- (2) Attach the hydraulic test stand lines to the ports.
- (3) Fill the actuator with fluid, D00153.

**NOTE:** The actuator will stay full of fluid, D00153 for each test.

- (4) Remove all of the air from the actuator.

### E. Procedure

**WARNING:** DO NOT APPLY AIR PRESSURE TO THE PORTS. THIS CAN CAUSE DAMAGE TO THE UNIT OR INJURY TO YOU.

**NOTE:** For the lubricants, refer to SOPM 20-60-03. For the miscellaneous materials, refer to SOPM 20-60-04.

#### (1) Do an external leakage test:

- (a) Clean around the dynamic rod seal to permit leak detection.
- (b) Operate the actuator for 25 full cycles:
  - 1) Fully retract the piston.
  - 2) Apply the minimum hydraulic pressure to the extend port that is necessary to move the piston.
  - 3) Increase the pressure to 3000-3100 psi when the actuator stops at the end of the piston travel and maintain the pressure for 0.5 to 2 seconds.
  - 4) Remove the pressure from the extend port.
  - 5) Change the fluid, D00153 direction.

**NOTE:** The actuator is in the fully extended position.

- 6) Apply the minimum hydraulic pressure to the retract port that is necessary to move the piston.
- 7) Increase the pressure to 3000-3100 psi when the actuator stops at the end of the piston travel and maintain the pressure for 0.5 to 2 seconds.
- 8) Remove the pressure from the retract port.
- 9) Do steps 1-8 for 25 full cycles.
- (c) After 25 cycles, do a visual check for leakage around the dynamic rod seal:
  - 1) Recommended leakage is zero.
  - 2) The leakage limit for the rod seal is 3 drops.
  - 3) The leakage limit for static seals is zero.

#### (2) Do an internal leakage test:

- (a) Fully extend the piston.
- (b) Remove the hydraulic line from the retract port.
- (c) Apply 3000-3100 psi to the extend port for a minimum of 1 minute.
- (d) Do a visual check for leakage from the open retract port:

# 32-33-12

TESTING AND FAULT ISOLATION

Page 102

Mar 01/2006





## COMPONENT MAINTENANCE MANUAL

- 1) Recommended leakage is zero.
- 2) The leakage limit is one (1) cc per minute.
- (e) Remove the pressure from the extend port.
- (f) Attach the hydraulic line to the retract port.
- (g) Fully retract the piston.
- (h) Remove the hydraulic line from the extend port.
- (i) Apply 3000-3100 psi to the retract port for a minimum of 1 minute.
- (j) Do a visual check for leakage from the open extend port:
  - 1) Recommended leakage is zero.
  - 2) The leakage limit is one (1) cc per minute.
- (k) Remove the pressure from the retract port.
- (l) Attach the hydraulic line to the extend port.
- (3) Do a seal friction test:
  - (a) Retract the piston fully.
  - (b) With no load applied to the piston, slowly increase the pressure at 50 psid maximum pressure at the extend port until the rod extends smoothly and continuously. Monitor the rod motion through the complete range of travel to make sure the rod moves smoothly.
  - (c) Make sure the piston is fully extended.
  - (d) With no load applied to the piston, slowly increase the pressure at 100 psid maximum pressure at the retract port until the rod retracts smoothly and continuously. Monitor the rod motion through the complete range of travel to make sure the rod moves smoothly.
  - (e) Decrease the pressure applied to the ports to zero.
- (4) Do an extend rate test:
  - (a) Retract the piston fully.
  - (b) Let the fluid, D00153 flow freely from the retract port to a reservoir.
  - (c) Apply 3000-3200 psi pressure to the extend port:
    - 1) Keep a record of the piston position related to the time.
    - 2) The piston must fully extend, from the retracted position, in 4.5-6.0 seconds.
    - 3) Make sure the piston speed decreases at the end of the travel.
  - (d) Remove the pressure from the extend port.
- (5) Do a retract rate test:
  - (a) Extend the piston fully.
  - (b) Let the fluid, D00153 flow freely from the extend port to a reservoir.
  - (c) Apply 3000-3200 psi pressure to the retract port:
    - 1) Keep a record of the piston position related to the time.
    - 2) The piston must fully retract, from the extended position, in 9.0-11.0 seconds.
    - 3) Make sure the piston speed decreases at the end of the travel.
  - (d) Remove the pressure from the retract port.

# 32-33-12

TESTING AND FAULT ISOLATION

Page 103

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

(6) Do a proof pressure test:

**CAUTION:** DO NOT EXTEND OR RETRACT THE PISTON AT PROOF PRESSURE (4500-4600 PSI).

- (a) Retract the piston fully.
  - (b) Apply 4500-4600 psi pressure to the retract port for a minimum of 30 seconds.
  - (c) Make sure there is no sign of external leakage or permanent damage to the actuator.
  - (d) Remove the pressure from the retract port.
  - (e) Extend the piston fully.
  - (f) Apply 4500-4600 psi pressure to the extend port for a minimum of 30 seconds.
  - (g) Make sure there is no sign of external leakage or permanent damage to the actuator.
  - (h) Remove the pressure from the extend port.
- (7) Make sure that the actuator has a minimum extend length of 25.77 inches and maximum retract length of 18.01 inches.
- (8) Remove the actuator from the stand after the test.
- (9) Lockwire the nut (125) to the key (120) by the double-twist method (SOPM 20-50-02) using lockwire, G50347.
- (10) Fill the unit with fluid, D00153 and install the shipping caps.

### 3. Fault Isolation

#### A. Procedure

- (1) Refer to TESTING AND FAULT ISOLATION, Table 101 for fault isolation.

**Table 101:** Fault Isolation Chart

TROUBLE	PROBABLE CAUSE	CORRECTIONS
Excessive leakage at the rod assembly end	Defective excluder (290), seal (285), packing (280), or rings (275)	Disassemble and replace the parts as shown in TESTING AND FAULT ISOLATION, Paragraph 4..
Binding or irregular movement of the rod assembly	Defective piston (305), head (115), bearing (130) or cylinder (150)	Disassemble and replace the parts as shown TESTING AND FAULT ISOLATION, Paragraph 4.in .
	Dirt or foreign material in the cylinder	Disassemble and clean parts.
The actuator failed the extend or retract rate test	Defective snubber (235) or related part	Disassemble and replace the parts as shown in TESTING AND FAULT ISOLATION, Paragraph 4.

### 4. Fault Correction

#### A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

# 32-33-12

TESTING AND FAULT ISOLATION

Page 104

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

Reference	Description	Specification
D00153	Fluid - Hydraulic, Erosion Arresting, Fire Resistant	BMS3-11 Type IV (interchangeable & intermixable with Type V)
G50227	Tie - Plastic, Adjustable, Self-clinching, Tiedown Strap	AS33671

### B. References

Reference	Title
CMM 32-33-23	NOSE GEAR LOCK VALVE MANIFOLD ASSEMBLY

### C. Procedure

- (1) Drain all the fluid, D00153 from the unit.
- (2) Replacement of excluder (290), seal (285), rings (275) or packing (280):
  - (a) Remove the bearing (65) from piston (305). Remove bearing (130) and lockwasher (135) from cylinder assembly (140).
  - (b) Remove the excluder (290), seal (285), rings (275) and packing (280).
  - (c) Replace parts as necessary.
  - (d) Install packing (280), rings (275), seal (285), and excluder (290) on bearing (130).
  - (e) Install lockwasher (135) and bearing (130) in cylinder assembly (140) per ASSEMBLY. Do the test again to see if the problem was corrected.
- (3) Replacement of the packing (260) or the rings (235):
  - (a) Do steps TESTING AND FAULT ISOLATION, Paragraph 4.C.(1), TESTING AND FAULT ISOLATION, Paragraph 4.C.(2).
  - (b) Remove the piston (305) from the cylinder (140).
  - (c) Replace the defective packing (260) or the rings (235).
  - (d) Install the piston (305) in the cylinder (140).
  - (e) Do steps TESTING AND FAULT ISOLATION, Paragraph 4.C.(1), TESTING AND FAULT ISOLATION, Paragraph 4.C.(2).
- D. Replacement of the piston (305), the cylinder (140) or the snubber (235):
  - (1) Drain the fluid, D00153 from the actuator.
  - (2) Disassemble the actuator CMM 32-33-23, DISASSEMBLY.
  - (3) Replace the defective parts.
  - (4) Assemble the actuator CMM 32-33-23, ASSEMBLY.
  - (5) Test as shown in TESTING AND FAULT ISOLATION, Paragraph 2..
  - (6) Install the bearing (65) and secure it with a tie wrap, G50227.

# 32-33-12

TESTING AND FAULT ISOLATION

Page 105

Jul 01/2008



## COMPONENT MAINTENANCE MANUAL

### DISASSEMBLY

#### 1. General

- A. This procedure tells how to disassemble the nose gear retract actuator assembly.
- B. Disassemble this component sufficiently to isolate the defects, do the necessary repairs, and put the component back to a serviceable condition.
- C. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- D. Refer to IPL Figure 1 for item numbers.

#### 2. Disassembly

##### A. Part Replacement

**NOTE:** These parts are recommended for replacement. Replacement of other parts can be by service experience.

- (1) Packings, O-rings and seals (25, 160, 165A, 205, 260, 280, 285)
- (2) Excluder (290)
- (3) Backup rings (155, 200, 255, 275)

**NOTE:** Do not remove orifice (90B) or insert (95, 145) unless it is damaged or to clean the area.

- (4) Lockwasher (135, 265)

##### B. Procedure

- (1) Use standard industry practices and these steps.
- (2) Install the actuator in the C32036-2 – Stand.
- (3) Remove the lockwire from the nut (125), the key (120) and the head end assembly (80).
- (4) Bend the tab of the lockwasher (135) to release the bearing (130).
- (5) With the C32036-10 – Spanner wrench, loosen the bearing (130) in the cylinder (140).
- (6) Remove the fittings (100) from the piston (305).
- (7) With the C32036-8 – Large Crowfoot Wrench, loosen the nut (125) on the head end assembly (80).
- (8) Remove the key (120) from the head end assembly (80).
- (9) Turn the cylinder (140) to remove it from the head end assembly (80).
- (10) Move the piston (305) from the cylinder (140).
- (11) Bend the tabs of the lockwasher (265) to release the jamnut (270).
- (12) Loosen the jamnut (270) with the C32036-7 – Small Crowfoot Wrench.
- (13) Remove the jamnut (270), the lockwasher (265) and the guide assembly (220) from the piston (305).
- (14) Remove the seal (165A) from the piston (305).
- (15) Turn the bearing (130) to remove it from the cylinder (140).
- (16) Remove the lockwasher (135) from the cylinder (140).
- (17) Turn the nut (125) to remove it from the cylinder (140).
- (18) Remove the packing (160) and the backup rings (155) from the head end assembly (80).
- (19) Remove the snubber stop (190) from the pull tube (195).

# 32-33-12

DISASSEMBLY

Page 301

Mar 01/2007



## COMPONENT MAINTENANCE MANUAL

- (a) Loosen the nut (185).
- (b) Remove the nut (185), the washers (175, 180), the bolt (170) and the snubber stop (190) from the pull tube (195).
- (20) Remove the guide (220), lockwasher (265) and jamnut (270) from the pull tube (195).
- (21) Remove the bolts (70) and washers (75) from the retainer (215).
- (22) Remove the retainer (215), the snubber assembly (235), the spring (210) and the pull tube (195) from the head end assembly (80).
- (23) Remove the head end assembly (80) from the C32036-2 – Stand.

# 32-33-12

DISASSEMBLY

Page 302

Mar 01/2007



## COMPONENT MAINTENANCE MANUAL

### CLEANING

#### 1. General

- A. This procedure has the data necessary to clean the nose gear retract actuator assembly.
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.

#### 2. Cleaning

##### A. References

Reference	Title
SOPM 20-30-01	CLEANING AND RELUBRICATING BEARINGS
SOPM 20-30-03	GENERAL CLEANING PROCEDURES

##### B. Procedure

- (1) Clean the bearing (65) as specified in SOPM 20-30-01.
- (2) Clean the other parts by standard industry procedures and the instructions in SOPM 20-30-03.

# 32-33-12

CLEANING

Page 401

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

### CHECK

#### 1. General

- A. This procedure has the data necessary to find defects in the material of the specified parts.
- B. Refer to FITS AND CLEARANCES for the design dimension and wear limits.
- C. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- D. Refer to IPL Figure 1 for item numbers.

#### 2. Check

##### A. References

Reference	Title
SOPM 20-20-01	MAGNETIC PARTICLE INSPECTION
SOPM 20-20-02	PENETRANT METHODS OF INSPECTION

##### B. Procedure

- (1) Use standard industry procedures to do a visual check of all the parts for defects.
- (2) Do a magnetic particle check (SOPM 20-20-01) of these parts:
  - (a) Fitting (20)
  - (b) Cylinder (150)
  - (c) Pull tube (195)
  - (d) Retainer (215)
  - (e) Retract slide (240)
  - (f) Extend slide (245)
  - (g) Sleeve (250)
  - (h) Piston (305)
- (3) Do a penetrant check (SOPM 20-20-02) of these parts:
  - (a) Head end (115)
  - (b) Locknut (125)
  - (c) Bearing (130)
  - (d) Jamnut (270)

# 32-33-12

CHECK

Page 501

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

### REPAIR

#### 1. General

- A. Instructions for repair, refinish, and replacement of the specified subassembly parts are included in each REPAIR when applicable:

**Table 601:**

<b>PART NUMBER</b>	<b>NAME</b>	<b>REPAIR</b>
—	REFINISH OF OTHER PARTS	1-1
273A1102	CYLINDER ASSEMBLY	2-1
273A1103	HEAD END ASSEMBLY	3-1
273A1103	HEAD END ASSEMBLY	3-2
273A1104	PISTON	4-1
273A1105	BEARING	5-1
273A1106	SNUBBER ASSEMBLY	6-1
273A1115	RETAINER	7-1
273A1116	BEARING	8-1
273A2110	PULL TUBE	9-1
273A2121	FITTING	10-1
273A2508	NAMEPLATE	11-1

#### 2. Dimensioning Symbols

- A. Standard True Position Dimensioning Symbols used in the applicable repair procedures are shown in REPAIR-GENERAL, Figure 601.

# 32-33-12

REPAIR - GENERAL

Page 601

Mar 01/2006





## COMPONENT MAINTENANCE MANUAL

—	STRAIGHTNESS	∅	DIAMETER
▭	FLATNESS	S ∅	SPHERICAL DIAMETER
⊥	PERPENDICULARITY (OR SQUARENESS)	R	RADIUS
//	PARALLELISM	SR	SPHERICAL RADIUS
○	ROUNDNESS	( )	REFERENCE
⊘	CYLINDRICITY	BASIC	A THEORETICALLY EXACT DIMENSION USED
⌒	PROFILE OF A LINE	(BSC)	TO DESCRIBE SIZE, SHAPE OR LOCATION OF
⌓	PROFILE OF A SURFACE	OR	A FEATURE. FROM THIS FEATURE PERMISSIBLE
◎	CONCENTRICITY	DIM	VARIATIONS ARE ESTABLISHED BY TOLERANCES ON OTHER DIMENSIONS OR
≡	SYMMETRY		NOTES.
∠	ANGULARITY	-A-	DATUM
↗	RUNOUT	Ⓜ	MAXIMUM MATERIAL CONDITION (MMC)
↗↗	TOTAL RUNOUT	Ⓛ	LEAST MATERIAL CONDITION (LMC)
⊔	COUNTERBORE OR SPOTFACE	Ⓢ	REGARDLESS OF FEATURE SIZE (RFS)
∇	COUNTERSINK	Ⓟ	PROJECTED TOLERANCE ZONE
⊕	THEORETICAL EXACT POSITION OF A FEATURE (TRUE POSITION)	FIM	FULL INDICATOR MOVEMENT

### EXAMPLES

$\boxed{\text{—}} \boxed{0.002}$	STRAIGHT WITHIN 0.002	$\boxed{\text{◎}} \boxed{\text{∅}} \boxed{0.0005} \boxed{\text{C}}$	CONCENTRIC TO DATUM C WITHIN 0.0005 DIAMETER
$\boxed{\text{⊥}} \boxed{0.002} \boxed{\text{B}}$	PERPENDICULAR TO DATUM B WITHIN 0.002	$\boxed{\text{≡}} \boxed{0.010} \boxed{\text{A}}$	SYMMETRICAL WITH DATUM A WITHIN 0.010
$\boxed{\text{//}} \boxed{0.002} \boxed{\text{A}}$	PARALLEL TO DATUM A WITHIN 0.002	$\boxed{\text{∠}} \boxed{0.005} \boxed{\text{A}}$	ANGULAR TOLERANCE 0.005 WITH DATUM A
$\boxed{\text{○}} \boxed{0.002}$	ROUND WITHIN 0.002	$\boxed{\text{⊕}} \boxed{\text{∅}} \boxed{0.002} \boxed{\text{Ⓢ}} \boxed{\text{B}}$	LOCATED AT TRUE POSITION WITHIN 0.002 DIA RELATIVE TO DATUM B, REGARDLESS OF FEATURE SIZE
$\boxed{\text{⊘}} \boxed{0.010}$	CYLINDRICAL SURFACE MUST LIE BETWEEN TWO CONCENTRIC CYLINDERS, ONE OF WHICH HAS A RADIUS 0.010 INCH GREATER THAN THE OTHER	$\boxed{\text{⊥}} \boxed{\text{∅}} \boxed{0.010} \boxed{\text{Ⓜ}} \boxed{\text{A}}$	AXIS IS TOTALLY WITHIN A CYLINDER OF 0.010 INCH DIAMETER, PERPENDICULAR TO DATUM A, AND EXTENDING 0.510 INCH ABOVE DATUM A, MAXIMUM MATERIAL CONDITION
$\boxed{\text{⌒}} \boxed{0.006} \boxed{\text{A}}$	EACH LINE ELEMENT OF THE SURFACE AT ANY CROSS SECTION MUST LIE BETWEEN TWO PROFILE BOUNDARIES 0.006 INCH APART RELATIVE TO DATUM A	$\boxed{0.510} \boxed{\text{Ⓟ}}$	THEORETICALLY EXACT DIMENSION IS 2.000
$\boxed{\text{⌓}} \boxed{0.020} \boxed{\text{A}}$	SURFACES MUST LIE WITHIN PARALLEL BOUNDARIES 0.020 INCH APART AND EQUALLY DISPOSED ABOUT TRUE PROFILE		OR 2.000 BSC

True Position Dimensioning Symbols  
Figure 601

# 32-33-12

REPAIR - GENERAL

Page 602

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

### REFINISH OF OTHER PARTS - REPAIR 1-1

#### 1. General

- A. This procedure has the data necessary to refinish the parts which are not given in the specified repairs.
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.

#### 2. Refinish of other parts

##### A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
D00113	Lubricant - Liquid Dispersed Solid Film Lubricant	BMS3-8, BAC 5811, TYPE VIII

##### B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-60-02	FINISHING MATERIALS
SOPM 20-60-04	MISCELLANEOUS MATERIALS

##### C. General

- (1) Instructions for the repair of the parts listed in REPAIR 1-1, Table 601 is for repair of the initial finish.

##### D. Procedure

**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For decoding table for Boeing finish codes, refer to SOPM 20-41-01. For finishing materials, refer to SOPM 20-60-02. For miscellaneous materials, refer to SOPM 20-60-04.

- (1) Refer to REPAIR 1-1, Table 601 for refinish details.

**Table 601:** Refinish Details

IPL FIG. & ITEM	MATERIAL	FINISH
Locknut (125)	Titanium Alloy	Apply lubricant, D00113 (F-19.10) to the face of the nut that is opposite the notches.
Nut (270)	Aluminum Alloy	Anodize (F-17.35) all over.
Stop (190)	Aluminum Alloy	Anodize (F-17.35) all over.
Spring (210)	Titanium Wire	Apply no finish (F-25.01).

# 32-33-12

REPAIR 1-1

Page 601

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

**Table 601:** Refinish Details (Continued)

IPL FIG. & ITEM	MATERIAL	FINISH
Key (120)	15-5PH CRES	Anodize (F-17.25) all over.
Bracket (51)	301 CRES	Passivate (F-17.25).
Retract slide (240)	440C CRES	Passivate (F-17.25).
Extend slide (245)	440C CRES	Passivate (F-17.25).
Sleeve (250)	440C CRES	Passivate (F-17.25).

# 32-33-12

REPAIR 1-1

Page 602

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

### CYLINDER - REPAIR 2-1

273A1102-2

#### 1. General

- A. This procedure has the data necessary to repair and refinish the cylinder (150).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to the REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
  - (1) Material: 15-5PH CRES, AMS 5659, 180-200 ksi
  - (2) Shot Peen: See the flagnote in REPAIR 2-1, Figure 601.
    - (a) Shot size 0.017 - 0.046
    - (b) Intensity 0.005 - 0.010A2

#### 2. Cylinder Repair

##### A. References

Reference	Title
SOPM 20-10-03	SHOT PEENING
SOPM 20-10-04	GRINDING OF CHROME PLATED PARTS
SOPM 20-20-01	MAGNETIC PARTICLE INSPECTION
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-42-03	HARD CHROME PLATING
SOPM 20-42-09	ELECTRODEPOSITED NICKEL PLATING
SOPM 20-60-02	FINISHING MATERIALS
SOPM 20-60-04	MISCELLANEOUS MATERIALS

##### B. Procedure (REPAIR 2-1, Figure 601)

**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For decoding table for Boeing finish codes, refer to SOPM 20-41-01. For finishing materials, refer to SOPM 20-60-02. For miscellaneous materials, refer to SOPM 20-60-04.

- (1) Repair the cylinder (150).
  - (a) Machine as required, within the repair limits to remove any defects.
    - 1) Obey the flagnotes in REPAIR 2-1, Figure 601.
  - (b) Do a magnetic particle check (SOPM 20-20-01).
  - (c) Shot peen the cylinder (150) (SOPM 20-10-03).
    - 1) Obey the flagnote in REPAIR 2-1, Figure 601.
  - (d) Nickel plate if necessary (SOPM 20-42-09).

# 32-33-12

REPAIR 2-1

Page 601

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

- 1) Obey the flagnotes in REPAIR 2-1, Figure 601.
- (e) Chrome plate (F-15.34) to a maximum finish plating thickness of 0.01 inches, if required (SOPM 20-42-03), and grind as shown (SOPM 20-10-04).
  - 1) Obey the flagnotes in REPAIR 2-1, Figure 601.
- (f) Do a magnetic particle check (SOPM 20-20-01).

### 3. Cylinder Refinish

#### A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
D00113	Lubricant - Liquid Dispersed Solid Film Lubricant	BMS3-8, BAC 5811, TYPE VIII

#### B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-50-08	APPLICATION OF BONDED SOLID FILM LUBRICANTS
SOPM 20-60-02	FINISHING MATERIALS
SOPM 20-60-04	MISCELLANEOUS MATERIALS

#### C. Procedure (REPAIR 2-1, Figure 601)



**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For decoding table for Boeing finish codes, refer to SOPM 20-41-01. For finishing materials, refer to SOPM 20-60-02. For miscellaneous materials, refer to SOPM 20-60-04.

- (1) Put a finish on the cylinder (150).
  - (a) Prepare the surface and passivate per method 2 (F-17.25).
  - (b) Apply lubricant, D00113 (F-19.10) ( SOPM 20-50-08) as shown by flagnote 1.

# 32-33-12

REPAIR 2-1  
Page 602  
Mar 01/2006

COMPONENT MAINTENANCE MANUAL



A-A


273A1102-2 Cylinder Assembly Repair  
Figure 601 (Sheet 1 of 2)

**32-33-12**

REPAIR 2-1  
Page 603  
Mar 01/2006



## COMPONENT MAINTENANCE MANUAL



- 1 APPLY BMS 3-8, TYPE 8, SOLID FILM LUBRICANT.
- 2 SHOT PEEN THIS AREA.
- 3 AFTER SHOT PEEN, PLATE THE NOTED SURFACE (F-15.33, F-15.34).
- 4 PLATE RUNOUT THIS AREA.

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 1

ALL DIMENSIONS ARE IN INCHES

273A1102-2 Cylinder Assembly Repair  
Figure 601 (Sheet 2 of 2)

# 32-33-12

REPAIR 2-1

Page 604

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

### HEAD END ASSEMBLY - REPAIR 3-1

273A1103-1

#### 1. General

- A. Use this procedure to replace the bushings in head end assembly (80).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to the REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair figures.
- D. Refer to IPL Figure 1 for item numbers.

#### 2. Bushing Replacement

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
A00551	Sealant - Fuel Tank	BAC5010, Type 44 (BMS5-44, BMS5-45)

- B. References

Reference	Title
SOPM 20-50-03	BEARING AND BUSHING REPLACEMENT
SOPM 20-60-04	MISCELLANEOUS MATERIALS

- C. Procedure (REPAIR 3-1, Figure 601)

**NOTE:** For miscellaneous materials, refer to SOPM 20-60-04.

**NOTE:** If you find that bushing migration is a problem (the old bushings are not down against the lugs), we recommend that you install replacement bushings with a tighter fit, such as the repair equivalents made in REPAIR 3-2.




- (1) Remove the old bushings (SOPM 20-50-03).
- (2) If you find defects on the head end surfaces, refer to REPAIR 3-2 for repair instructions.
- (3) Install replacement bushings by the shrink fit procedure (SOPM 20-50-03).
- (4) Machine the bushing bores to design dimensions and finish.
- (5) Seal the bushings with sealant, A00551 (flagnote 3).
- (6) If necessary, replace lube fittings (100) and tighten the replacements to 20 to 25 pound-inches.

# 32-33-12

REPAIR 3-1  
Page 601  
Jul 01/2009



COMPONENT MAINTENANCE MANUAL



- 1 PART MARK THIS AREA
- 2 IDENTIFY THE EXTEND PORT AS FOLLOWS - EXT.
- 3 APPLY A BEAD OF SEALANT TO THE JOINT BETWEEN THE HEAD AND THE BUSHING.

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 1

ALL DIMENSIONS ARE IN INCHES

273A1103-1 Head End Assembly  
Figure 601

**32-33-12**

REPAIR 3-1  
Page 602  
Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

### HEAD END - REPAIR 3-2

273A1103-2

#### 1. General

- A. Use this procedure to repair head end (115).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to the REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair figures.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
  - (1) Material: Titanium, annealed
  - (2) Shot peen: Not necessary

#### 2. Repair

##### A. References

Reference	Title
SOPM 20-10-07	MACHINING OF TITANIUM
SOPM 20-20-02	PENETRANT METHODS OF INSPECTION
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES

##### B. Procedure (REPAIR 3-2, Figure 601)

**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For machining of titanium, refer to SOPM 20-10-07.

- (1) Machine as necessary, within repair limits, to remove defects.
- (2) Penetrant examine (SOPM 20-20-02).
- (3) Make oversize bushings (REPAIR 3-1) as necessary to adjust for the material removed.

#### 3. Refinish

##### A. References

Reference	Title
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

##### B. Procedure (REPAIR 3-2, Figure 601)

**NOTE:** For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Apply no finish (F-25.01)



# 32-33-12

REPAIR 3-2

Page 601

Jul 01/2009

COMPONENT MAINTENANCE MANUAL



125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 1


ALL DIMENSIONS ARE IN INCHES

273A1103-2 Head End Repair  
Figure 601 (Sheet 1 of 2)

**32-33-12**

REPAIR 3-2  
Page 602  
Jul 01/2008

COMPONENT MAINTENANCE MANUAL




273A1103-2 Head End Repair  
Figure 601 (Sheet 2 of 2)

**32-33-12**

REPAIR 3-2  
Page 603  
Jul 01/2008

COMPONENT MAINTENANCE MANUAL



63/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES 0.02-0.04 R

MATERIAL: AL-NI-BRZ (AMS 4640 OR AMS 4880)

FINISH: NO FINISH

ITEM NUMBERS REFER TO IPL FIG. 1

ALL DIMENSIONS ARE IN INCHES

F94345 S0004999132\_V2

Oversize Bushing Details  
Figure 602

**32-33-12**

REPAIR 3-2  
Page 604  
Jul 01/2008



## COMPONENT MAINTENANCE MANUAL

### PISTON - REPAIR 4-1

273A1104-1

#### 1. General

- A. This procedure has the data necessary to repair and refinish the piston (90).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to the REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
  - (1) Material: 15-5PH CRES, AMS 5659, 180-200 ksi
  - (2) Shot peen: All surfaces, unless as shown
    - (a) Intensity 0.008 - 0.013A2
    - (b) Overspray is permitted

#### 2. Piston Repair

##### A. References

Reference	Title
SOPM 20-10-03	SHOT PEENING
SOPM 20-10-04	GRINDING OF CHROME PLATED PARTS
SOPM 20-20-01	MAGNETIC PARTICLE INSPECTION
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-42-03	HARD CHROME PLATING
SOPM 20-42-09	ELECTRODEPOSITED NICKEL PLATING
SOPM 20-60-02	FINISHING MATERIALS

##### B. Procedure (REPAIR 4-1, Figure 601)

**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For decoding table for Boeing finish codes, refer to SOPM 20-41-01. For finishing materials, refer to SOPM 20-60-02.

- (1) Repair the piston (305):
  - (a) Machine as required, within the repair limits to remove any defects.
  - (b) Obey the flagnotes in REPAIR 4-1, Figure 601.
  - (c) Do a magnetic particle check (SOPM 20-20-01).
  - (d) Shot peen the piston (305) (SOPM 20-10-03).
    - 1) Obey the flagnote 2.
  - (e) Apply nickel plate if necessary (SOPM 20-42-09).
    - 1) Obey the flagnotes 3, 4 and 5.
  - (f) The maximum total plating thickness is 0.015 inches.

# 32-33-12

REPAIR 4-1

Page 601

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

- (g) Apply chrome plate (F-15.34) (SOPM 20-42-03) to a maximum finish plating thickness of 0.01 inches and grind (SOPM 20-10-04) as shown.
  - 1) Obey the flagnotes 4 and 5.
- (h) Do a magnetic particle check (SOPM 20-20-01).

### 3. Piston Refinish

#### A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-60-02	FINISHING MATERIALS

#### B. Procedure (REPAIR 4-1, Figure 601)

**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For decoding table for Boeing finish codes, refer to SOPM 20-41-01. For finishing materials, refer to SOPM 20-60-02.

- (1) Put a finish on the piston (305):
  - (a) Passivate (F-17.25).


# 32-33-12

REPAIR 4-1

Page 602

Mar 01/2006

COMPONENT MAINTENANCE MANUAL





273A1104-1 Piston Repair  
Figure 601 (Sheet 1 of 4)

**32-33-12**

REPAIR 4-1  
Page 603  
Mar 01/2006



COMPONENT MAINTENANCE MANUAL




273A1104-1 Piston Repair  
Figure 601 (Sheet 2 of 4)


**32-33-12**

REPAIR 4-1  
Page 604  
Mar 01/2006

COMPONENT MAINTENANCE MANUAL



(B)



(C)

B-B


273A1104-1 Piston Repair  
Figure 601 (Sheet 3 of 4)

**32-33-12**

REPAIR 4-1  
Page 605  
Mar 01/2006



## COMPONENT MAINTENANCE MANUAL



- 1 SHOT PEEN THIS AREA.
- 2 DO NOT SHOT PEEN THIS AREA.
- 3 PLATE THIS AREA (F-15.33, F-15.34).
- 4 PLATE RUNOUT IN THIS AREA.
- 5 DO NOT PLATE THIS FACE.
- 6 THE PART NUMBER IS HERE.

125 ✓ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 1

ALL DIMENSIONS ARE IN INCHES

273A1104-1 Piston Repair  
Figure 601 (Sheet 4 of 4)

# 32-33-12

REPAIR 4-1

Page 606

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

### BEARING - REPAIR 5-1

273A1105-1

#### 1. General

- A. This procedure has the data necessary to repair the bearing (65).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to the REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
  - (1) Material: AL-NI-Bronze, AMS 4640

#### 2. Bearing Refinish

- A. Procedure
  - (1) Put a finish on the bearing (65):
    - (a) Apply no finish. You can use a temporary compound for transportation and storage.



# 32-33-12

REPAIR 5-1

Page 601

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



- 1 THE MATING INDEX MARKS ARE ON THIS SIDE ONLY.
- 2 THE PART NUMBER AND THE SERIAL NUMBER ARE ON THIS SIDE.

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 1

ALL DIMENSIONS ARE IN INCHES

273A1105-1 Bearing Refinish  
Figure 601

**32-33-12**

REPAIR 5-1

Page 602

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

### SNUBBER ASSEMBLY - REPAIR 6-1

273A1106-1

#### 1. General

- A. This procedure has the data necessary to refinish the snubber assembly (235).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to the REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
  - (1) Material: 440C CRES HRC 57-60

#### 2. Snubber Assembly Refinish

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
D00153	Fluid - Hydraulic, Erosion Arresting, Fire Resistant	BMS3-11 Type IV (interchangeable & intermixable with Type V)

- B. References

Reference	Title
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-60-02	FINISHING MATERIALS
SOPM 20-60-03	LUBRICANTS
SOPM 20-60-04	MISCELLANEOUS MATERIALS

- C. Procedure (REPAIR 6-1, Figure 601)

**CAUTION:** THE SNUBBER (235) IS A PRECISION ASSEMBLY. BE CAREFUL NOT TO DAMAGE IT.

**NOTE:** For decoding table for Boeing finish codes, refer to SOPM 20-41-01. For finishing materials, refer to SOPM 20-60-02. For miscellaneous materials, refer to SOPM 20-60-04.

- (1) Install the retract slide (240) and the extend slide (245) in the sleeve (250):
  - (a) Obey the flagnotes in REPAIR 6-1, Figure 601.
  - (b) Lubricate the retract slide (240), the extend slide (245) and the sleeve (250) with fluid, D00153 (SOPM 20-60-03).
  - (c) Install the retract slide (240) in the sleeve (250) so that they align at one end.

# 32-33-12

REPAIR 6-1  
Page 601  
Jul 01/2008



## COMPONENT MAINTENANCE MANUAL

- (d) Install the extend slide (245) in the retract slide (240) so that one end of the retract slide (240), the extend slide (245) and the sleeve (250) align.
- (2) Tilt the sleeve approximately 45 degrees so that the slides move by their own weight.
- (3) Align one end of the three parts.
- (4) Turn the snubber assembly (235) approximately 120 degrees.
- (5) Do REPAIR 6-1, Paragraph 2.C.(2), REPAIR 6-1, Paragraph 2.C.(3) and REPAIR 6-1, Paragraph 2.C.(4) again.
- (6) Replace the snubber assembly (235) if the slides do not move by their own weight.



# 32-33-12

REPAIR 6-1

Page 602

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



A-A

1 MAKE SURE THAT THE CLEARANCE BETWEEN THE TWO DIAMETERS IS 0.0006 TO 0.0008.

2 THE SERIAL NUMBER OF THIS MATCHED SET IS ON THIS SURFACE.

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES 0.0005 MAX.

ITEM NUMBERS REFER TO IPL FIG. 1

ALL DIMENSIONS ARE IN INCHES

273A1106-1 Snubber Assembly  
Figure 601

**32-33-12**

REPAIR 6-1

Page 603

Mar 01/2006





## COMPONENT MAINTENANCE MANUAL

### RETAINER - REPAIR 7-1

273A1115-1

#### 1. General

- A. This procedure has the data necessary to refinish the retainer (215).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to the REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
  - (1) Material: 15-5PH CRES, AMS 5659, 180-200 ksi

#### 2. Retainer Refinish

##### A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-60-02	FINISHING MATERIALS

##### B. Procedure (REPAIR 7-1, Figure 601)

**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For decoding table for Boeing finish codes, refer to SOPM 20-41-01. For finishing materials, refer to SOPM 20-60-02.

- (1) Put a finish on the retainer (215):
  - (a) Passivate (F-17.25).


# 32-33-12

REPAIR 7-1

Page 601

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



273A1115-2 Retainer Repair  
Figure 601

**32-33-12**

REPAIR 7-1  
Page 602  
Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

### BEARING - REPAIR 8-1

273A1116-1

#### 1. General

- A. This procedure has the data necessary to replace and refinish the bearing (130).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to the REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
  - (1) Material: AL-NI-Bronze, AMS 4640

#### 2. Bearing Refinish

##### A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-60-02	FINISHING MATERIALS

##### B. Procedure (REPAIR 8-1, Figure 601)

**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For decoding table for Boeing finish codes, refer to SOPM 20-41-01. For finishing materials, refer to SOPM 20-60-02.

- (1) Put a finish on the bearing (130):
  - (a) Apply no finish (F-25.01). You can use a temporary compound for transportation and storage.



# 32-33-12

REPAIR 8-1

Page 601

Mar 01/2006

COMPONENT MAINTENANCE MANUAL




273A1116-1 Bearing Repair  
Figure 601 (Sheet 1 of 2)

**32-33-12**

REPAIR 8-1  
Page 602  
Mar 01/2006



COMPONENT MAINTENANCE MANUAL



125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 1

ALL DIMENSIONS ARE IN INCHES

273A1116-1 Bearing Repair  
Figure 601 (Sheet 2 of 2)

**32-33-12**

REPAIR 8-1

Page 603

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

### PULL TUBE - REPAIR 9-1

273A2110-2

#### 1. General

- A. This procedure has the data necessary to repair and refinish the pull tube (195).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to the REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
  - (1) Material: 15-5PH CRES, 150-170 ksi

#### 2. Pull Tube Refinish

##### A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-60-02	FINISHING MATERIALS

##### B. Procedure (REPAIR 9-1, Figure 601)

**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For decoding table for Boeing finish codes, refer to SOPM 20-41-01. For finishing materials, refer to SOPM 20-60-02.

- (1) Put a finish on the pull tube (195):
  - (a) Passivate (F-17.25).



# 32-33-12

REPAIR 9-1

Page 601

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



A-A

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 1

ALL DIMENSIONS ARE IN INCHES

273A2110-2 Pull Tube Refinish  
Figure 601

**32-33-12**

REPAIR 9-1

Page 602

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

### FITTING - REPAIR 10-1

273A2121-1

#### 1. General

- A. This procedure has the data necessary to refinish the fitting (20).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to the REPAIR-GENERAL, Figure 601 for the Standard True Position Dimensioning Symbols shown in the repair.
- D. Refer to IPL Figure 1 for item numbers.
- E. General repair details:
  - (1) Material: 15-5PH CRES, AMS 5659, 180-200 ksi

#### 2. Fitting Refinish

##### A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-60-02	FINISHING MATERIALS

##### B. Procedure (REPAIR 10-1, Figure 601)

**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For decoding table for Boeing finish codes, refer to SOPM 20-41-01. For finishing materials, refer to SOPM 20-60-02.

- (1) Put a finish on the fitting (20):
  - (a) Apply no finish (F-25.01). You can use a temporary compound for transportation and storage.

# 32-33-12


REPAIR 10-1

Page 601

Mar 01/2006



COMPONENT MAINTENANCE MANUAL



125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 1

ALL DIMENSIONS ARE IN INCHES

273A2121-1 Fitting Repair  
Figure 601

**32-33-12**

REPAIR 10-1

Page 602

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

### NAMEPLATE INSTALLATION - REPAIR 11-1

273A2508-7, -8

#### 1. General

- A. This repair has instructions for the replacement of the nameplate (310, 315).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices shown in the repair.
- C. Refer to IPL Figure 1 for item numbers.

#### 2. Nameplate Replacement

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
A00551	Sealant - Fuel Tank	BAC5010, Type 44 (BMS5-44, BMS5-45)

- B. References

Reference	Title
SOPM 20-50-05	APPLICATION OF ALUMINUM FOIL AND OTHER MARKERS
SOPM 20-60-04	MISCELLANEOUS MATERIALS

- C. General

(1) Use each strap only one time.

- D. Procedure

**NOTE:** For miscellaneous materials, refer to SOPM 20-60-04.

(1) Prepare the nameplates (310, 315) (SOPM 20-50-05).

**NOTE:** Make sure the serial number and the part number are steel stamped on the nameplate.

- (a) Bend the nameplate in a curve smaller than the barrel radius.
- (b) Make a small bend in the nameplate corners to the mounting surface.

(2) Attach the nameplate to the barrel :

- (a) Hold the nameplate on the barrel.
- (b) Install the straps through the slot of the nameplate.
- (c) Pull the strap tight. Make sure the strap and the nameplate are tight against the barrel.
- (d) Bend the strap down around the end of the nameplate. Keep the strap tight.
- (e) Cut the strap 0.35-0.50 inch from the nameplate slot.
- (f) Bend the strap end down with a soft-nosed hammer.

(3) Seal the edges of the nameplate and strap with sealant, A00551 (SOPM 20-60-04).

# 32-33-12

REPAIR 11-1

Page 601

Jul 01/2006



## COMPONENT MAINTENANCE MANUAL

### ASSEMBLY

#### 1. General

- A. This procedure tells how to assemble the nose landing gear retract actuator assembly.
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.

#### 2. Assembly

##### A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
D00153	Fluid - Hydraulic, Erosion Arresting, Fire Resistant	BMS3-11 Type IV (interchangeable & intermixable with Type V)
D00633	Grease - Aircraft General Purpose	BMS3-33
D50025	Grease - PAG No. 2 Lithium Based - BATCO X8401-2	
G50227	Tie - Plastic, Adjustable, Self-clinching, Tiedown Strap	AS33671

##### B. References

Reference	Title
SOPM 20-50-01	BOLT AND NUT INSTALLATION
SOPM 20-50-02	INSTALLATION OF SAFETYING DEVICES
SOPM 20-60-03	LUBRICANTS
SOPM 20-60-04	MISCELLANEOUS MATERIALS

##### C. Special Tools and Equipment

**NOTE:** Equivalent substitutes can be used.

- (1) C32036-2 – Stand
- (2) C32036-7 – Small Crowfoot Wrench
- (3) C32036-8 – Large Crowfoot Wrench
- (4) C32036-10 – Spanner Wrench

##### D. Procedure

**NOTE:** For bolt and nut installation, refer to SOPM 20-50-01. For lubricants, refer to SOPM 20-60-03. For miscellaneous materials, refer to SOPM 20-60-04.

- (1) Use standard industry practices and these steps. See ASSEMBLY, Figure 701.
- (2) Put the head end assembly (80) in the stand.
- (3) Install the restrictor (30B) and the packing (25) in the head end assy (80):

# 32-33-12

ASSEMBLY  
Page 701  
Jul 01/2008



## COMPONENT MAINTENANCE MANUAL

- (a) Lubricate the packing (25) with fluid, D00153.
- (b) Install the packing (25) on the restrictor (30B).
- (c) Install the restrictor (30B) in the head end assembly (80).
- (4) Install the packings (205) and rings (200) on the snubber assembly (235):
  - (a) Lubricate the packings (205) with fluid, D00153.
  - (b) Install the packings (205) and rings (200) on the snubber assembly (235).
- (5) Install the snubber assembly (235) in the head end assembly (80):
  - (a) Remove the extend slide (245) from the snubber assembly (235).
  - (b) Install the spring (210) on the extend slide (245).
  - (c) Install the extend slide (245) in the snubber assembly (235).
  - (d) Install the pull tube (195) in the snubber assembly (235).
  - (e) Install the snubber assembly (235) in the head end assembly (80).
- (6) Install the retainer (215) in the head end assembly (80):
  - (a) Lubricate the packing (260) with fluid, D00153.
  - (b) Install the packing (260) and the rings (255) on the retainer (215).
  - (c) Install the retainer (215) with the bolts (70) and washers (75) in the head end assembly (80).
  - (d) Tighten the bolts (70) to 30-40 pound-inches.
- (7) Install the guide (220) on the pull tube (195):
  - (a) Move the jamnut (270) and the lockwasher (265) along the pull tube (195) to put them on top of the retainer (215).
  - (b) Install the guide (220) on the pull tube (195).
- (8) Install the snubber stop (190) on the pull tube (195):
  - (a) Install the snubber stop (190) with the bolt (170), washers (175, 180) and the nut (185) on the pull tube (195).
  - (b) Tighten the nut (185) to 30-40 pound-inches.
- (9) Install the rings (275), packing (280), seal (285), and rod excluder (290) in the bearing (130):
  - (a) Lubricate the packing (280) and seal (285) with fluid, D00153.
  - (b) Install the rings (275), packing (280), seal (285) and rod excluder (290) in the bearing (130).
- (10) Install the bearing (130) and the lockwasher (135) in the cylinder assembly (140), finger tight.
- (11) Install the seal (165A) on the piston (305):
  - (a) Lubricate the seal (165A) with fluid, D00153.
  - (b) Install the seal (165A) on the piston (305).
- (12) Install the piston (305) in the cylinder assembly (140).
- (13) Install the piston (305) on the guide (220):
  - (a) Move the guide (220) along the pull tube (195) until it touches the snubber stop (190).
  - (b) Install the guide (220), the lockwasher (265) and the jamnut (270) in the piston (305).
  - (c) Hold the piston (305) with a wrench, then tighten the jamnut (270) to 100 to 200 pound-inches with the small crowfoot wrench.

# 32-33-12

ASSEMBLY

Page 702

Mar 01/2007



## COMPONENT MAINTENANCE MANUAL

- (d) Break the flange of the lockwasher (265) into three equally spaced slots of the jamnut (270).
- (14) Install the packing (160) and the rings (155) in the head end assembly (80):
  - (a) Lubricate the packing (160) with fluid, D00153.
  - (b) Install the packing (160) and the rings (155) in the head end assy (80).
- (15) Install the cylinder assembly (140) in the head end assembly (80):
  - (a) Apply BATCO X8401-2 grease, D50025 to the external threads of cylinder assembly (140).
  - (b) Turn the locknut (125) on the cylinder assembly (140) until it starts to come off the threads at the far end.
  - (c) Turn the cylinder assembly (140) into the head end assembly (80) until it stops.
  - (d) Turn the cylinder assembly (140) back, less than one turn, to align the key slots on the cylinder assembly (140) and the head end assembly (80).
- (16) Install the key (120) in the key slot of the cylinder assembly (140).
- (17) Tighten the locknut (125) on the head end assembly (80) by hand, to keep the key (120) in its position.
- (18) With the large crowfoot wrench, tighten the locknut (125) to 1500-1700 pound-inches.
- (19) Move the piston (305) in and out by hand to make sure it moves freely.
- (20) With the spanner wrench, tighten the bearing (130) to 1400-1600 pound-inches.
- (21) Bend the lockwasher (135) over the two opposite flats of the bearing (130) (SOPM 20-50-02).
- (22) Install the fitting (20), fittings (100), packing (300), rings (295), bracket assembly (36), washers (15) and bolts (10A).
  - (a) Lubricate the packing (300) with fluid, D00153.
  - (b) Install the packing (300) and the rings (295) in the fitting (20).
  - (c) Install the fitting (20) and the bracket assembly on the cylinder assembly (140) with the bolts (10A) and the washers (15).
  - (d) Tighten the bolts (10A) to 30-40 pound-inches.
  - (e) Install the fittings (100) in the piston (305).
- (23) Install the nameplate (310, 315) (REPAIR 11-1), if it is necessary.
- (24) Install the bearing (65) in the piston (305):
  - (a) Apply grease, D00633 to the bearing bore of the piston (305).
  - (b) Install the bearing (65) in the bearing bore.
  - (c) Tie the bearing (65) in position with a tie wrap, G50227 for transportation or storage.
- (25) Do the test of the actuator (TESTING AND FAULT ISOLATION).


# 32-33-12

ASSEMBLY

Page 703

Mar 01/2007

## COMPONENT MAINTENANCE MANUAL



Assembly Details  
Figure 701

# 32-33-12

ASSEMBLY


Page 704

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

FITS AND CLEARANCES



ITEM NUMBERS REFER TO IPL FIG. 1

F95180 S0004999156\_V3

Fits and Clearances  
Figure 801 (Sheet 1 of 2)



**32-33-12**

FITS AND CLEARANCES


Page 801

Mar 01/2009

## COMPONENT MAINTENANCE MANUAL

REF LETTER	REF IPL	DESIGN DIMENSION*				SERVICE WEAR LIMIT*		
	FIG. 1, MATING ITEM NO.	DIMENSION		ASSEMBLY CLEARANCE		DIMENSION		MAXIMUM CLEARANCE
		MIN	MAX	MIN	MAX	MIN	MAX	
[A]	ID 140	3.243	3.245	0.003	0.007	3.236	3.247	0.009
	OD 305	3.238	3.240					
[B]	ID 130	2.751	2.753	0.003	0.007	2.745	2.755	0.009
	OD 305	2.746	2.748					
[C]	ID 305	2.1885	2.1905	0.001	0.0035	2.185	2.1925	0.007
	OD 65	2.1870	2.1875					
[D]	ID 65	1.5003	1.5008	0.0013	0.0028	1.496	1.503	0.006
	OD 	1.4980	1.4990					
[E]	ID 85	1.5003	1.5013	0.0013	0.0033	1.496	1.5025	0.006
	OD 	1.4980	1.4970					

\* ALL DIMENSIONS ARE IN INCHES

 RETRACT ACTUATOR PIN 273A1121-1,-2  
(INSTALLATION PART)

F93904 S0004999157\_V2

Fits and Clearances  
Figure 801 (Sheet 2 of 2)

**32-33-12**  
FITS AND CLEARANCES  
Page 802  
Mar 01/2009





## COMPONENT MAINTENANCE MANUAL

REF IPL		NAME	TORQUE*	
FIG. NO.	ITEM NO.		POUND-INCHES	POUND-FEET
1	70	Bolt	30-40	
1	125	Nut, Lock	1500-1700	
1	130	Bearing	1400-1600	
1	185	Nut, Snubber	30-40	
1	270	Nut, Jam	100-120	

\* REFER TO SOPM 20-50-01 FOR TORQUE VALUES OF STANDARD FASTENERS.

Torque Table  
Figure 802

**32-33-12**  
FITS AND CLEARANCES  
Page 803  
Mar 01/2006



**COMPONENT MAINTENANCE MANUAL**

**SPECIAL TOOLS, FIXTURES, AND EQUIPMENT**

**(NOT APPLICABLE)**

**32-33-12**

SPECIAL TOOLS, FIXTURES, AND EQUIPMENT

Page 901

Mar 01/2006



## COMPONENT MAINTENANCE MANUAL

### ILLUSTRATED PARTS LIST

#### 1. Introduction

- A. The Illustrated Parts List (IPL) contains an illustration and a list of component parts you can repair or replace. The Illustrated Parts Catalog (IPC) shows how to use the Boeing part number system.
- B. This shows how parts are related: The relation of each item to its next higher assembly (NHA) is shown in the NOMENCLATURE column. Use the indenture system that follows:

1	2	3	4	5	6	7
.	Assembly					
.	Attaching parts for assembly					
.	.	Detail parts for assembly				
.	.	Subassembly				
.	.	Attaching parts for subassembly				
.	.	.	Detail parts for subassembly			
.	.	.	Sub-subassembly			
.	.	.	Attaching parts for subassembly			
.	.	.	.	Details parts for sub-subassembly		
						Detail Installation Parts (Included only if installation parts may be sent to the shop as part of assembly)

- C. Each top assembly is given one use code letter (A, B, C, etc.) in the USAGE CODE column. All subsequent component parts in the list can have one or more of the use code letters to show effectivity to top assemblies. A component part without a use code applies to all top assemblies.
- D. An alphabetical letter is added after the item number for optional parts, parts changed by a Service Bulletin, configuration differences (except left-handed and right-handed parts), last engineering releases, and parts added between item numbers in a sequence. The alphabetical letter will not be shown on the illustration for equivalent parts of the same part number.
- E. Color-coded parts are identified with a single digit alpha following the dash number or with "SP" suffix. If the "SP" suffix is used, it represents consolidation of all color codes applicable for a given usage which are not separately listed. Orders for color-coded parts should include the registry number of the airplane for which the parts are ordered.
- F. If a part number is 15 characters long but will not fit in the part number column, the part number will be displayed with a "~" at the end of the line and will be continued on the next line. The "~" denotes that the part number continues on the next line.
- G. Parts changed by a Service Bulletin are shown by PRE SB XXXX and POST SB XXXX added to the NOMENCLATURE column.
- (1) When a new top assembly is added by a Service Bulletin, PRE SB XXXX and POST SB XXXX will be added at the top assembly level only. The configuration differences at the detail part level are shown by use code letters.
- (2) When the top assembly part number is not changed by the Service Bulletin, PRE SB XXXX and POST SB XXXX will be added at the detail level.
- H. Interchangeable Parts

# 32-33-12

ILLUSTRATED PARTS LIST

Page 1001

Nov 01/2008



## COMPONENT MAINTENANCE MANUAL

Optional (OPT)	The part is optional to and interchangeable with other parts that have the same item number.
Replaces, Replaced by and not interchangeable with (REPLACES, REPLACED BY AND NOT INTCHG/W)	The part replaces and is not interchangeable with the initial part.
Replaces, Replaced by (REPLACES, REPLACED BY)	The part replaces and is interchangeable with, or is an alternative to, the initial part.

### VENDOR CODES

<b>Code</b>	<b>Name</b>
02107	FLOUROCARBON CO OHIO DIV DOVER, OHIO 44622 CANCELLED NO REPLACEMENT FORMERLY SPARTA MANUFACTURING CO
07128	TETRAFLUOR INC 2051 EAST MAPLE AVENUE EL SEGUNDO, CALIFORNIA 90245-5009 FORMERLY ROYAL IND TETRAFLUOR DIV V0667B ENGLEWOOD CALIF
11815	CHERRY AEROSPACE FASTENERS DIV OF TEXTRON 1224 EAST WARNER AVENUE PO BOX 2157 SANTA ANA, CALIFORNIA 92707-0157 FORMERLY IN LOS ANGELES, CALIF , FORMERLY CHERRY FASTENERS TOWNSEND DIV OF TEXTRON INC V71087
15653	ALCOA GLOBAL FASTENERS INC DIV KAYNAR PRODUCTS 800 S STATE COLLEGE BLVD FULLERTON, CALIFORNIA 92831-3001 FORMERLY VK6405 MICRODOT AEROSP LTD; FORMERLY KAYNAR TECH FORMERLY FAIRCHILD FASTENERS KAYNAR DIV
26303	GREENE TWEED IND INC ADVANTEC DIV 7101 PATTERSON DRIVE PO BOX 5037 GARDEN GROVE, CALIFORNIA 92645-5037 FORMERLY OHIO AIRCRAFT SUPPLIES INC IN INGLEWOOD, CALIFORNIA FORMERLY ADVANTEC DIV OF IFP INC, LOS ANGELES, CA V5P801

# 32-33-12

ILLUSTRATED PARTS LIST

Page 1002

Nov 01/2006



## COMPONENT MAINTENANCE MANUAL

Code	Name
26879	CORONADO MFG INC 11069 PENROSE AVENUE SUN VALLEY, CALIFORNIA 90352-2722 FORMERLY CORONADO PLASTICS INC IN BURBANK, CALIFORNIA
52828	REPUBLIC FASTENER MFG CORP 1300 RANCHO CONEJO BLVD NEWBURY PARK, CALIFORNIA 91320-1405 FORMERLY IN SYLMAR, CALIFORNIA
53551	ALLFAST FASTENING SYSTEMS INC 15200 EAST DON JULIAN ROAD PO BOX 3166 CITY OF INDUSTRY, CALIFORNIA 91745-1001 FORMERLY V0736B FORMERLY ALLFAST INC V5K545
72962	HARVARD INDUSTRIES INC 3 WERNER WAY SUITE 210 LEBANON, NEW JERSEY 08833 FORMERLY ESNA V7A079 FORMERLY ELASTIC STOP NUT IN UNION, NJ
92215	FAIRCHILD IND INC FAIRCHILD AEROSPACE FASTENER DIV 3010 W LOMITA BLVD TORRANCE, CALIFORNIA 90505-5102 FORMERLY VOI-SHAN IN CULVER CITY, CALIF
92555	LEE COMPANY 2 PETTIPAUG ROAD PO BOX 424 WESTBROOK, CONNECTICUT 06498-1543
94878	RAYBESTOS-MANHATTAN INC PACIFIC COAST DIV FULLERTON, CALIFORNIA 92631 BUSINESS DISCONTINUED
97820	BUSAK AND SHAMBAN INC BEARING DIV 711 MITCHELL ROAD PO BOX 665 NEWBURY PARK, CALIFORNIA 91320-2214 FORMERLY IN CULVER CITY, CALIF; FORMERLY SHAMBAN W S & CO

# 32-33-12

ILLUSTRATED PARTS LIST

Page 1003

Jul 01/2006



## COMPONENT MAINTENANCE MANUAL

Code	Name
98996	OLYMPIC FASTENING SYSTEMS INC DOWNEY, CALIFORNIA 90241-4986 OBSOLETE RECORD

**32-33-12**

ILLUSTRATED PARTS LIST

Page 1004

Jul 01/2006



## COMPONENT MAINTENANCE MANUAL

### NUMERICAL INDEX

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
109F9207-3		1	46	2
2100-012		1	295	2
273A1101-1		1	1A	RF
273A1102-1		1	140	1
273A1102-2		1	150	1
273A1103-1		1	80	1
273A1103-2		1	115	1
273A1104-1		1	305	1
273A1105-1		1	65	1
273A1106-1		1	235	1
273A1108-1		1	240	1
273A1109-1		1	245	1
273A1112-1		1	220	1
273A1112-2		1	230	1
273A1112-3		1	220A	1
273A1113-1		1	270	1
273A1114-1		1	265	1
273A1115-1		1	215	1
273A1116-1		1	130	1
273A1117-1		1	135	1
273A1118-1		1	125	1
273A1119-1		1	36	1
273A1119-2		1	51	1
273A2107-1		1	250	1
273A2110-2		1	195	1
273A2111-1		1	190	1
273A2117-1		1	210	1
273A2119-1		1	120	1
273A2121-1		1	20	1
273A2508-7		1	310	1
273A2508-8		1	315	1
273T0050-8		1	5	2
AF5141-3-4		1	41	4
BACB28AT24B033A		1	85	4

# 32-33-12

ILLUSTRATED PARTS LIST

Page 1005

Mar 01/2007



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
BACB28AU07B025A		1	225	2
BACB30LE3U3		1	70	4
BACB30LE3U4		1	10A	2
BACN10KB3CFM		1	46	2
BACR12BM012		1	295	2
BACR12BM123		1	200	4
BACR12BM128		1	255	2
BACR12BM235		1	275	2
BACR12BM342		1	155	2
BACR15DR3A4		1	41	4
BACW10BP3ACU		1	15	2
		1	75	4
		1	175	1
BACW10BP3APU		1	180	1
BRF100C3M		1	46	2
C11236-012B		1	295	2
CCR264CS3-4		1	41	4
CCR264CS3-4TT		1	41	4
F2001-3		1	46	2
		1	46	2
JEHX0517450B		1	30B	1
JETA1875100D		1	90B	1
MS15004-1		1	100	4
MS21209F1-15L		1	95	4
		1	145	2
NAS1611-012A		1	300A	1
NAS1611-123		1	205	2
NAS1611-128A		1	260A	1
NAS1611-235A		1	280A	1
NAS1611-342A		1	160A	1
NAS1612-6		1	25	1
NAS1805-3		1	185	1
NAS6703U12		1	170	1
RMR12BM012		1	295	2
RV541A3-4		1	41	4

# 32-33-12

ILLUSTRATED PARTS LIST

Page 1006

Mar 01/2007





## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
S30294-012-1		1	295	2
S32925-27H99		1	290	1
S34711-335H99		1	285	1
S34721-336H99N		1	165A	1
STF800-012		1	295	2
T8113C1032C		1	46	2
TF450-012A		1	295	2
VN151D1-02		1	46	2



# 32-33-12

ILLUSTRATED PARTS LIST


Page 1007

Mar 01/2007

COMPONENT MAINTENANCE MANUAL




(A)



(B)


Retract Actuator Assembly - Nose Landing Gear  
IPL Figure 1 (Sheet 1 of 6)

COMPONENT MAINTENANCE MANUAL



Retract Actuator Assembly - Nose Landing Gear  
IPL Figure 1 (Sheet 2 of 6)

COMPONENT MAINTENANCE MANUAL



Retract Actuator Assembly - Nose Landing Gear  
IPL Figure 1 (Sheet 3 of 6)


**32-33-12**

ILLUSTRATED PARTS LIST

Page 1010

Mar 01/2007

COMPONENT MAINTENANCE MANUAL



Retract Actuator Assembly - Nose Landing Gear  
IPL Figure 1 (Sheet 4 of 6)


**32-33-12**

ILLUSTRATED PARTS LIST

Page 1011

Mar 01/2007

COMPONENT MAINTENANCE MANUAL



Retract Actuator Assembly - Nose Landing Gear  
IPL Figure 1 (Sheet 5 of 6)


**32-33-12**

ILLUSTRATED PARTS LIST

Page 1012

Mar 01/2007

COMPONENT MAINTENANCE MANUAL



Retract Actuator Assembly - Nose Landing Gear  
IPL Figure 1 (Sheet 6 of 6)

## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE	USAGE CODE	UNITS PER ASSY
1-					
-1A	273A1101-1		ACTUATOR ASSY-NOSE GEAR RETRACT		RF
5	273T0050-8		. STRAP		2
10	BACB30LE3U3		DELETED		
10A	BACB30LE3U4		. BOLT		2
15	BACW10BP3ACU		. WASHER		2
20	273A2121-1		. FITTING		1
25	NAS1612-6		. PACKING		1
30	6F3810		DELETED		
-30A	JEKC2815175L		DELETED		
30B	JEHX0517450B		. RESTRICTOR (V92555)		1
35	BACN10YA6N		DELETED		
36	273A1119-1		. BRACKET ASSY		1
40	C11236-110B		DELETED		
41	AF5141-3-4		. . RIVET (V53551) (SPEC BACR15DR3A4) (OPT CCR264CS3-4 (V11815)) (OPT RV541A3-4 (V98996)) (OPT CCR264CS3-4TT (V11815))		4
45	NAS1611-110		DELETED		
46	BRF100C3M		. . NUTPLATE (V52828) (SPEC BACN10KB3CFM) (OPT F2001-3 (V15653)) (OPT T8113C1032C (V11815)) (OPT VN151D1-02 (V92215)) (OPT 109F9207-3 (V72962)) (OPT F2001-3 (V15653))		2
50	273A2122-2		DELETED		
51	273A1119-2		. . BRACKET		1
55	DB0S13BX06H		DELETED		
60	273A2122-4		DELETED		
65	273A1105-1		. BEARING		1

-Item not Illustrated

# 32-33-12

ILLUSTRATED PARTS LIST  
Page 1014  
Jul 01/2006





## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
70	BACB30LE3U3		.	B	O	L	T				4
75	BACW10BP3ACU		.	W	A	S	H	E	R		4
80	273A1103-1		.	E	N	D	A	S	S	Y	1
85	BACB28AT24B033A		.	.	B	U	S	H	I	N	4
90	JETA1875150D		D	E	L	E	T	E	D		
-90A	6F3818		D	E	L	E	T	E	D		
90B	JETA1875100D		.	.	O	R	I	F	I	C	1
					(V92555)						
95	MS21209F1-15L		.	.	I	N	S	E	R	T	4
100	MS15004-1		.	.	F	I	T	T	I	N	4
105	PLGA2506020		D	E	L	E	T	E	D		
110	PLGA2507020		D	E	L	E	T	E	D		
115	273A1103-2		.	.	H	E	A	D			1
120	273A2119-1		.	K	E	Y					1
125	273A1118-1		.	L	O	C	K	N	U	T	1
130	273A1116-1		.	B	E	A	R	I	N	G	1
135	273A1117-1		.	L	O	C	K	W	A	S	1
140	273A1102-1		.	C	Y	L	I	N	D	E	1
145	MS21209F1-15L		.	.	I	N	S	E	R	T	2
150	273A1102-2		.	.	C	Y	L	I	N	D	1
155	BACR12BM342		.	R	I	N	G				2
160	NAS1611-342		D	E	L	E	T	E	D		
160A	NAS1611-342A		.	P	A	C	K	I	N	G	1
165A	S34721-336H99N		.	S	E	A	L				1
				(V97820)							
170	NAS6703U12		.	B	O	L	T				1
175	BACW10BP3ACU		.	W	A	S	H	E	R		1
180	BACW10BP3APU		.	W	A	S	H	E	R		1
185	NAS1805-3		.	N	U	T					1
190	273A2111-1		.	S	T	O	P	-	S	N	1
195	273A2110-2		.	T	U	B	E	-	P	U	1
200	BACR12BM123		.	R	I	N	G				4

-Item not Illustrated

# 32-33-12

ILLUSTRATED PARTS LIST

Page 1015

Mar 01/2007



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE 1 2 3 4 5 6 7	USAGE CODE	UNITS PER ASSY
1-					
205	NAS1611-123		. PACKING		2
210	273A2117-1		. SPRING		1
215	273A1115-1		. RETAINER-NLG		1
220	273A1112-1		. GUIDE ASSY		1
220A	273A1112-3		. GUIDE		1
225	BACB28AU07B025A		. . BUSHING (USED ON ITEM 220)		2
230	273A1112-2		. . GUIDE (USED ON ITEM 220)		1
235	273A1106-1		. SNUBBER ASSY		1
240	273A1108-1		. . SLIDE-RETRACT		1
245	273A1109-1		. . SLIDE-EXTEND		1
250	273A2107-1		. . SLEEVE		1
255	BACR12BM128		. RING		2
260	NAS1611-128		DELETED		
260A	NAS1611-128A		. PACKING		1
265	273A1114-1		. LOCKWASHER-CUP		1
270	273A1113-1		. NUT-JAM		1
275	BACR12BM235		. RING		2
280	NAS1611-235		DELETED		
280A	NAS1611-235A		. PACKING		1
285	S34711-335H99		. SEAL (V97820)		1
290	S32925-27H99		. ROD-EXCLUDER DC (V97820)		1
295	C11236-012B		. RING (V26879) (SPEC BACR12BM012) (OPT RMR12BM012 (V94878)) (OPT STF800-012 (V02107)) (OPT S30294-012-1 (V97820)) (OPT TF450-012A (V07128)) (OPT 2100-012 (V26303))		2
300	NAS1611-012		DELETED		
300A	NAS1611-012A		. PACKING		1

-Item not Illustrated

# 32-33-12

ILLUSTRATED PARTS LIST

Page 1016

Mar 01/2007



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
305	273A1104-1										1
310	273A2508-7										1
315	273A2508-8										1

-Item not Illustrated