



COMPONENT MAINTENANCE MANUAL WITH ILLUSTRATED PARTS LIST

BRAKE METERING VALVE CONTROL INSTALLATION COMPONENTS

PART NUMBER

**65C25416-10, -13, -14, -9, 65C25442-10, -7,
65C25479-13, -14, -7, -8, 65C25576-1, -2, -3, -4,
69-74714-1, -2**

BOEING PROPRIETARY, CONFIDENTIAL, AND/OR TRADE SECRET

Copyright © 1995 The Boeing Company
Unpublished Work - All Rights Reserved

Boeing claims copyright in each page of this document only to the extent that the page contains copyrightable subject matter. Boeing also claims copyright in this document as a compilation and/or collective work.

This document includes proprietary information owned by The Boeing Company and/or one or more third parties. Treatment of the document and the information it contains is governed by contract with Boeing. For more information, contact The Boeing Company, P.O. Box 3707, Seattle, Washington 98124.

Boeing, the Boeing signature, the Boeing symbol, 707, 717, 727, 737, 747, 757, 767, 777, 787, Dreamliner, BBJ, DC-8, DC-9, DC-10, KC-10, KDC-10, MD-10, MD-11, MD-80, MD-88, MD-90, P-8A, Poseidon and the Boeing livery are all trademarks owned by The Boeing Company; and no trademark license is granted in connection with this document unless provided in writing by Boeing.

PUBLISHED BY BOEING COMMERCIAL AIRPLANES GROUP, SEATTLE, WASHINGTON, USA
A DIVISION OF THE BOEING COMPANY
PAGE DATE: Jul 01/2009

32-41-20



COMPONENT MAINTENANCE MANUAL

Revision No. 7
Jul 01/2009

To: All holders of BRAKE METERING VALVE CONTROL INSTALLATION COMPONENTS 32-41-20.

Attached is the current revision to this COMPONENT MAINTENANCE MANUAL

The COMPONENT MAINTENANCE MANUAL is furnished either as a printed manual, on microfilm, or digital products, or any combination of the three. This revision replaces all previous microfilm cartridges or digital products. All microfilm and digital products are reissued with all obsolete data deleted and all updated pages added.

For printed manuals, changes are indicated on the List of Effective Pages (LEP). The pages which are revised will be identified on the LEP by an R (Revised), A (Added), O (Overflow, i.e. changes to the document structure and/or page layout), or D (Deleted). Each page in the LEP is identified by Chapter-Section-Subject number, page number and page date.

Pages replaced or made obsolete by this revision should be removed and destroyed.

ATTENTION

IF YOU RECEIVE PRINTED REVISIONS, PLEASE VERIFY THAT YOU HAVE RECEIVED AND FILED THE PREVIOUS REVISION. BOEING MUST BE NOTIFIED WITHIN 30 DAYS IF YOU HAVE NOT RECEIVED THE PREVIOUS REVISION. REQUESTS FOR REVISIONS OTHER THAN THE PREVIOUS REVISION WILL REQUIRE A COMPLETE MANUAL REPRINT SUBJECT TO REPRINT CHARGES SHOWN IN THE DATA AND SERVICES CATALOG.

32-41-20

TRANSMITTAL LETTER

Page 1

Jul 01/2009

65C25416, 65C25442, 65C25479,
65C25576, 69-74714



COMPONENT MAINTENANCE MANUAL

Location of Change

Description of Change

NO HIGHLIGHTS

32-41-20

HIGHLIGHTS

Page 1

Jul 01/2009



COMPONENT MAINTENANCE MANUAL

Subject/Page	Date	Subject/Page	Date	Subject/Page	Date
TITLE PAGE		32-41-20 REPAIR - GENERAL		32-41-20 REPAIR 7-1	
O 1	Jul 01/2009	601	Mar 01/2007	601	Mar 01/2006
2	BLANK	602	Mar 01/2006	602	Mar 01/2006
32-41-20 TRANSMITTAL LETTER		32-41-20 REPAIR 1-1		603	Mar 01/2006
O 1	Jul 01/2009	601	Mar 01/2007	604	BLANK
2	BLANK	602	Mar 01/2007	32-41-20 REPAIR 8-1	
32-41-20 HIGHLIGHTS		32-41-20 REPAIR 2-1		601	Mar 01/2006
O 1	Jul 01/2009	601	Mar 01/2006	602	Mar 01/2006
2	BLANK	602	Mar 01/2006	32-41-20 REPAIR 9-1	
32-41-20 EFFECTIVE PAGES		603	Mar 01/2006	601	Mar 01/2006
1 thru 2	Jul 01/2009	604	BLANK	602	Mar 01/2006
32-41-20 CONTENTS		32-41-20 REPAIR 3-1		603	Mar 01/2006
1	Mar 01/2006	601	Mar 01/2006	604	BLANK
2	BLANK	602	Mar 01/2006	32-41-20 REPAIR 10-1	
32-41-20 TR AND SB RECORD		32-41-20 REPAIR 3-2		601	Mar 01/2006
1	Mar 01/2006	601	Mar 01/2006	602	Mar 01/2006
2	BLANK	602	Mar 01/2006	32-41-20 REPAIR 10-2	
32-41-20 REVISION RECORD		32-41-20 REPAIR 3-3		601	Mar 01/2006
1	Mar 01/2006	601	Mar 01/2006	602	Mar 01/2006
2	Mar 01/2006	602	Mar 01/2006	32-41-20 ASSEMBLY	
32-41-20 RECORD OF TEMPORARY REVISIONS		32-41-20 REPAIR 3-4		701	Mar 01/2006
1	Mar 01/2006	601	Mar 01/2006	702	BLANK
2	Mar 01/2006	602	Mar 01/2006	32-41-20 FITS AND CLEARANCES	
32-41-20 INTRODUCTION		32-41-20 REPAIR 4-1		801	Mar 01/2006
1	Mar 01/2009	601	Mar 01/2006	802	BLANK
2	BLANK	602	Mar 01/2006	32-41-20 SPECIAL TOOLS, FIXTURES, AND EQUIPMENT	
32-41-20 TESTING AND FAULT ISOLATION		32-41-20 REPAIR 5-1		901	Mar 01/2006
101	Mar 01/2006	601	Mar 01/2006	902	BLANK
102	BLANK	602	Mar 01/2006	32-41-20 ILLUSTRATED PARTS LIST	
32-41-20 DISASSEMBLY		603	Mar 01/2006	1001	Nov 01/2008
301	Mar 01/2006	604	Mar 01/2006	1002	Jul 01/2006
302	BLANK	605	Mar 01/2006	1003	Mar 01/2006
32-41-20 CLEANING		606	Mar 01/2006	1004	Mar 01/2006
401	Mar 01/2006	607	Mar 01/2006	1005	Mar 01/2006
402	BLANK	608	BLANK	1006	Mar 01/2006
32-41-20 CHECK		32-41-20 REPAIR 6-1		1007	Mar 01/2006
501	Mar 01/2006	601	Mar 01/2006	1008	Mar 01/2006
502	BLANK	602	Mar 01/2006	1009	Mar 01/2006
		603	Mar 01/2006	1010	Mar 01/2006
		604	BLANK		

A = Added, R = Revised, D = Deleted, O = Overflow

32-41-20

EFFECTIVE PAGES

Page 1

Jul 01/2009



COMPONENT MAINTENANCE MANUAL

Subject/Page	Date	Subject/Page	Date	Subject/Page	Date
32-41-20 ILLUSTRATED PARTS LIST (cont)					
1011	Mar 01/2006				
1012	Mar 01/2006				
1013	Mar 01/2006				
1014	Mar 01/2006				
1015	Mar 01/2006				
1016	Mar 01/2006				
1017	Mar 01/2006				
1018	Mar 01/2006				
1019	Mar 01/2006				
1020	Mar 01/2006				
1021	Mar 01/2006				
1022	Mar 01/2006				
1023	Mar 01/2006				
1024	Mar 01/2006				

A = Added, R = Revised, D = Deleted, O = Overflow

32-41-20

EFFECTIVE PAGES

Page 2

Jul 01/2009



COMPONENT MAINTENANCE MANUAL

TABLE OF CONTENTS

<u>Paragraph Title</u>		<u>Page</u>
TESTING AND FAULT ISOLATION	(Not Applicable)	
DISASSEMBLY	(Not Applicable)	
CLEANING	(Not Applicable)	
CHECK	(Not Applicable)	
REPAIR		601
ASSEMBLY	(Not Applicable)	
FITS AND CLEARANCES	(Not Applicable)	
SPECIAL TOOLS, FIXTURES, AND EQUIPMENT	(Not Applicable)	
ILLUSTRATED PARTS LIST		1001



COMPONENT MAINTENANCE MANUAL

TEMPORARY REVISION AND SERVICE BULLETIN RECORD

BOEING SERVICE BULLETIN	BOEING TEMPORARY REVISION	OTHER DIRECTIVE	DATE OF INCORPORATION INTO MANUAL
		PRR 33382	SEP 01/97
		PRR 33718	SEP 01/97
		PRR 35310	SEP 01/97
		PRR 38029	SEP 01/97

All revisions to this manual will be accompanied by transmittal sheet bearing the revision number. Enter the revision number in numerical order, together with the revision date, the date filed and the initials of the person filing.

[illegible]

BOEING PROPRIETARY - Copyright © Unpublished Work - See title page for details

[illegible]

BOEING PROPRIETARY - Copyright © Unpublished Work - See title page for details

[illegible]

BOEING PROPRIETARY - Copyright © Unpublished Work - See title page for details



COMPONENT MAINTENANCE MANUAL

INTRODUCTION

1. General

- A. The instructions in this manual supply the data necessary to do the maintenance functions together with the test, fault isolation, repair, and replacement of the defective parts.
- B. This manual is divided into different parts:
 - (1) Title Page
 - (2) Transmittal Letter
 - (3) Highlights
 - (4) List of Effective Pages
 - (5) Table of Contents
 - (6) Temporary Revision & Service Bulletin Record
 - (7) Record of Revisions
 - (8) Record of Temporary Revisions
 - (9) Introduction
 - (10) Procedures & IPL Sections
- C. Components that can be repaired have a different repair number for each specified repair. To find the repair number location of a component, look in the Repair-General procedure at the beginning of the REPAIR section. The Repair-General procedure also has an explanation of the True Position Dimension symbols used.
- D. All dimensions, measures, quantities and weights included are in English units. When metric equivalents are given they will be in the parentheses that follow the English units.
- E. The introduction to the Illustrated Parts List (IPL) shows how the IPL data is used.
- F. Design changes, optional parts, configuration differences and Service Bulletin modifications may cause different part numbers. These part numbers are identified in the IPL with an alphabetical letter which is added to the end of the basic item number. This new item number is referred to as an alpha-variant. Throughout the manual, IPL basic item number references also apply to alpha-variants unless shown differently.
- G. The tool reference numbers found in the individual procedures and in the Special Tools, Fixtures, and Equipment section are used to identify if a tool is a standard tool (STD-XXXX), a commercial tool (COM-XXXX), or a Special Tool (SPL-XXXX). This reference number is also used to distinguish between tools with similar names in the same procedure. These reference numbers are for use in the documentation only. They are not to be used for ordering tools.

32-41-20

INTRODUCTION

Page 1

Mar 01/2009



COMPONENT MAINTENANCE MANUAL

TESTING AND FAULT ISOLATION

(NOT APPLICABLE)

32-41-20

TESTING AND FAULT ISOLATION

Page 101

Mar 01/2006

65C25416, 65C25442, 65C25479,
65C25576, 69-74714



COMPONENT MAINTENANCE MANUAL

DISASSEMBLY

(NOT APPLICABLE)

32-41-20

DISASSEMBLY

Page 301

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

CLEANING

(NOT APPLICABLE)

32-41-20

CLEANING
Page 401

Mar 01/2006

65C25416, 65C25442, 65C25479,
65C25576, 69-74714



COMPONENT MAINTENANCE MANUAL

CHECK

(NOT APPLICABLE)

32-41-20

CHECK

Page 501

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

REPAIR

1. Content

- A. Instructions for repair, refinish, and replacement of the specified subassembly parts are included in each REPAIR when applicable:

PART NUMBER	NAME	REPAIR
	MISCELLANEOUS PARTS REFINISH	1-1
65C25416	SUPPORT ASSEMBLY	2-1
65C25442	LEVER ASSEMBLY	3-1
65C25479	SPRING PLATE ASSEMBLY	4-1
65C25576-1, -2	QUADRANT AND SHAFT ASSEMBLY	5-1
65C25576-3, -4	QUADRANT AND SHAFT ASSEMBLY	6-1
65-49954	QUADRANT	7-1
69-74409	INNER SHAFT	8-1
69-74411	OUTER SHAFT	9-1
69-74714	LEVER ASSEMBLY	10-1

2. Dimensioning Symbols

- A. Standard True Position Dimensioning Symbols used in applicable repair procedures are shown in REPAIR-GENERAL, Figure 601.

32-41-20

REPAIR - GENERAL

Page 601

Mar 01/2007



COMPONENT MAINTENANCE MANUAL

—	STRAIGHTNESS	∅	DIAMETER
▭	FLATNESS	S ∅	SPHERICAL DIAMETER
⊥	PERPENDICULARITY (OR SQUARENESS)	R	RADIUS
//	PARALLELISM	SR	SPHERICAL RADIUS
○	ROUNDNESS	()	REFERENCE
⊘	CYLINDRICITY	BASIC	A THEORETICALLY EXACT DIMENSION USED
⌒	PROFILE OF A LINE	(BSC)	TO DESCRIBE SIZE, SHAPE OR LOCATION OF
⌓	PROFILE OF A SURFACE	OR	A FEATURE. FROM THIS FEATURE PERMISSIBLE VARIATIONS ARE ESTABLISHED BY TOLERANCES ON OTHER DIMENSIONS OR NOTES.
◎	CONCENTRICITY	DIM	
≡	SYMMETRY		
∠	ANGULARITY	-A-	DATUM
↗	RUNOUT	Ⓜ	MAXIMUM MATERIAL CONDITION (MMC)
↗↗	TOTAL RUNOUT	Ⓛ	LEAST MATERIAL CONDITION (LMC)
⊔	COUNTERBORE OR SPOTFACE	Ⓢ	REGARDLESS OF FEATURE SIZE (RFS)
∇	COUNTERSINK	Ⓟ	PROJECTED TOLERANCE ZONE
⊕	THEORETICAL EXACT POSITION OF A FEATURE (TRUE POSITION)	FIM	FULL INDICATOR MOVEMENT

EXAMPLES

— 0.002	STRAIGHT WITHIN 0.002	◎ ∅ 0.0005 C	CONCENTRIC TO DATUM C WITHIN 0.0005 DIAMETER
⊥ 0.002 B	PERPENDICULAR TO DATUM B WITHIN 0.002	≡ 0.010 A	SYMMETRICAL WITH DATUM A WITHIN 0.010
// 0.002 A	PARALLEL TO DATUM A WITHIN 0.002	∠ 0.005 A	ANGULAR TOLERANCE 0.005 WITH DATUM A
○ 0.002	ROUND WITHIN 0.002	⊕ ∅ 0.002 Ⓢ B	LOCATED AT TRUE POSITION WITHIN 0.002 DIA RELATIVE TO DATUM B, REGARDLESS OF FEATURE SIZE
⊘ 0.010	CYLINDRICAL SURFACE MUST LIE BETWEEN TWO CONCENTRIC CYLINDERS, ONE OF WHICH HAS A RADIUS 0.010 INCH GREATER THAN THE OTHER	⊥ ∅ 0.010 Ⓜ A	AXIS IS TOTALLY WITHIN A CYLINDER OF 0.010 INCH DIAMETER, PERPENDICULAR TO DATUM A, AND EXTENDING 0.510 INCH ABOVE DATUM A, MAXIMUM MATERIAL CONDITION
⌒ 0.006 A	EACH LINE ELEMENT OF THE SURFACE AT ANY CROSS SECTION MUST LIE BETWEEN TWO PROFILE BOUNDARIES 0.006 INCH APART RELATIVE TO DATUM A	0.510 Ⓟ	
⌓ 0.020 A	SURFACES MUST LIE WITHIN PARALLEL BOUNDARIES 0.020 INCH APART AND EQUALLY DISPOSED ABOUT TRUE PROFILE	2.000	THEORETICALLY EXACT DIMENSION IS 2.000
		OR	
		2.000	
		BSC	

True Position Dimensioning Symbols
Figure 601

32-41-20

REPAIR - GENERAL

Page 602

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

MISCELLANEOUS PARTS REFINISH - REPAIR 1-1

1. General

- A. This procedure has the data necessary to refinish the parts which are not given in the other repairs.
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to the identified IPL Figure for the item numbers.

2. Check

- A. Do a strength check of the springs as follows:

Table 601: Spring Check

IPL FIG. & ITEM NO.	APPROXIMATE FREE LENGTH (INCHES) (REF) ^{*[1]}	TEST LENGTH (INCHES) ^{*[1]}	LOAD LIMITS (POUNDS)
Fig. 1			
800	4.17	5.00	19-23
		5.49	27-33
805	4.585	5.920	17.50-21.50
		6.302	22.58-27.58

^{*[1]} Measured between hook inside faces.

3. Refinish of Other Parts

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01. For finishing materials, refer to SOPM 20-60-02.

- A. Instructions for the repair of the parts in REPAIR 1-1, Table 602 are for replacement of the original finish.

Table 602: Refinish Details

IPL FIG. & ITEM	MATERIAL	FINISH
Fig. 1		
Spring (800)	Music wire per QQ-W-470	Cadmium plate (F-15.02), 0.0002-0.0003 inch thick.
Spring (805)	17-7PH CRES, CH 900	Passivate (F-17.09).
Spacers (810)	321 CRES	Passivate (F-17.09).
Spacers (815,820, 825)	Al alloy	Chemical treat and apply primer, C00259(F-18.07).
Angles (830)	Al alloy	Chromic acid anodize and apply primer, C00259 and enamel coating, C00260 (F-21.18), but no enamel in holes or on spotfaces.
Fig. 2		
Retainer (45)	Al alloy	Chromic acid anodize and apply primer, C00259 (F-18.13).
Plug (70)	Phenolic resin	No finish.

32-41-20

REPAIR 1-1

Page 601

Mar 01/2007



COMPONENT MAINTENANCE MANUAL

Table 602: Refinish Details (Continued)

IPL FIG. & ITEM	MATERIAL	FINISH
Pin (80)	15-5PH CRES, 180-200 ksi	Passivate (F-17.09)
Fig. 3		
Retainer (40)	Al alloy	Chromic acid anodize and apply primer, C00259 (F-18.13).
Spacer (55)	Al alloy	Chemical treat and apply primer, C00259 (F-18.07).
Spacer (110)	321 CRES	Passivate (F-17.09).
Fig. 5		
Retainer (50)	Al alloy	Chromic acid anodize and apply primer, C00259 (F-18.13).
Plates (55,60)	Al alloy	Chromic acid anodize and apply primer, C00259 (F-18.13). Then apply enamel coating, C00260 (F-21.03).
Bracket (70)	Al alloy	Chemical treat and apply primer, C00259 (F-18.06). Then apply enamel coating, C00260 (F-21.03).
Fig. 6		
Bushing (40)	15-5PH CRES, 180-200 ksi	Passivate (F-17.09).
Fig. 7		
Retainer (35)	Al-Ni-Bronze per AMS 4640 or QQ-C-465 alloy number 630	No finish.

32-41-20

REPAIR 1-1

Page 602

Mar 01/2007



COMPONENT MAINTENANCE MANUAL

SUPPORT ASSEMBLY - REPAIR 2-1

65C25416-9, -10, -13, -14

1. General

- A. This procedure has the data to replace the inserts (IPL Figure 4, 20) in the support assembly (IPL Figure 4; 10), .
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 4 for the item numbers.

2. Inserts

- A. Remove the bad inserts (20).
- B. Install replacement inserts with wet primer, C00259. Turn the inserts in until the outer end is 0.215-0.240 inch below the surface. Remove the tangs.

3. Coating Repair (REPAIR 2-1, Figure 601)

- A. Repair is only replacement of the original finish. Refer to Refinish instructions for details.
 - (1) Anodize (F-17.05).
 - (2) Apply primer, C00259 as shown in REPAIR 2-1, Figure 601.
 - (3) Apply enamel coating, C00260 as shown in REPAIR 2-1, Figure 601.




32-41-20

REPAIR 2-1

Page 601

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



65C25416-11,-12,-15,-16 Support Repair and Refinish
Figure 601 (Sheet 1 of 2)

32-41-20


REPAIR 2-1

Page 602

Mar 01/2006



COMPONENT MAINTENANCE MANUAL



	1	2	3	4	5
DESIGN DIM	0.291 0.279	1.751 1.750	1.626 1.624	1.751 1.750	0.222 0.218
REPAIR LIMIT	---	---	---	---	---

REFINISH

ANODIZE (F-17.05). APPLY PRIMER BMS 10-11, TYPE 1 (F-20.02) BUT NOT IN HOLES OR AS SHOWN BY 1. APPLY ENAMEL AS SHOWN BY 2.

- 1 NO PRIMER
- 2 APPLY BMS 10-11, TYPE 2 ENAMEL TO THIS SURFACE, BUT NOT IN THE HOLES

REPAIR

(SAME AS REFINISH)

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

MATERIAL: AL ALLOY
ALL DIMENSIONS ARE IN INCHES

65C25416-11,-12,-15,-16 Support Repair and Refinish
Figure 601 (Sheet 2 of 2)

32-41-20



COMPONENT MAINTENANCE MANUAL

LEVER ASSEMBLY, AFT TRUNNION OUTER - REPAIR 3-1

65C25442-7, -10

1. General

- A. This procedure has the data to repair the lever assembly (45, 45A).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 6 for item numbers.

2. Parts Replacement (REPAIR 3-1, Figure 601)



NOTE: For finishing materials, refer to SOPM 20-60-02.

- A. Disassemble by standard industry practices.
- B. Replace parts as necessary.
- C. Refer to REPAIR 3-2 for repair of the clevis assembly (15).
- D. Refer to REPAIR 3-4 for repair of the lever (45).
- E. Assemble the unit by standard industry practices. Be sure to install clevis (15), bushing (40) if applicable, and nut (5) with corrosion preventive compound, B50080 on the mating threads, as shown in REPAIR 3-1, Figure 601.

32-41-20

REPAIR 3-1
Page 601
Mar 01/2006

COMPONENT MAINTENANCE MANUAL



1 INSTALL WITH MIL-C-16173, GRADE 2
CORROSION PREVENTIVE COMPOUND ON THE
MATING THREADS.

ITEM NUMBERS REFER TO IPL FIG. 6

65C25442-7,-10 Lever Assembly Parts Replacement
Figure 601

32-41-20

REPAIR 3-1

Page 602

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

CLEVIS ASSEMBLY - REPAIR 3-2

69-74408-2

1. General

- A. This procedure has the data to repair the clevis assembly (15).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 6 for item numbers.

2. Parts Replacement REPAIR 3-2, Figure 601

- A. Disassemble by standard industry practices.
- B. Replace parts as necessary.
- C. Refer to REPAIR 3-3 for repair of clevis (35).
- D. Assemble parts by standard industry practices. Be sure to install bolt (20) and nut (25) with corrosion preventive compound, B50080 on the mating threads, as shown in REPAIR 3-2, Figure 601.

32-41-20



REPAIR 3-2

Page 601

Mar 01/2006



COMPONENT MAINTENANCE MANUAL



A-A



INSTALL WITH MIL-C-16173, GRADE 2
CORROSION PREVENTIVE COMPOUND ON THE
MATING THREADS

ITEM NUMBERS REFER TO IPL FIG. 6

69-74408-2 Clevis Assembly Parts Replacement
Figure 601

32-41-20

REPAIR 3-2

Page 602

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

CLEVIS - REPAIR 3-3

69-74407-1

1. General

- A. This procedure has the data to repair the clevis (35).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 6 for item numbers.
- D. Material: 15-5PH CRES, 180-200 KSI

2. Coating Repair (REPAIR 3-3, Figure 601)

NOTE: For the decoding table for the Boeing finish codes, refer to SOPM 20-41-01.

- A. Repair is only replacement of the original finish.
 - (1) Passivate (F-17.09) the clevis (35).

32-41-20

REPAIR 3-3

Page 601

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

LEVER - REPAIR 3-4

69-74439-1, -2

1. General

- A. This procedure has the data to repair the lever (45, 45A).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 6 for item numbers.
- D. Material: 15-5PH CRES, 180-200 KSI

2. Coating Repair (REPAIR 3-4, Figure 601)

NOTE: For the decoding table for the Boeing finish codes, refer to SOPM 20-41-01.

- A. Repair is only replacement of the original finish. Refer to Refinish instructions for details.
 - (1) Passivate (F-17.09) the lever (45).


32-41-20

REPAIR 3-4

Page 601

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



REFINISH

PASSIVATE (F-17.09)

REPAIR

(SAME AS REFINISH)

125/ ALL MACHINED SURFACES UNLESS SHOWN

MATERIAL: 15-5PH CRES, 180-200 KSI

ALL DIMENSIONS ARE IN INCHES

69-74439-1,-2 Lever Refinish
Figure 601

32-41-20

REPAIR 3-4

Page 602

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

SPRING PLATE ASSEMBLY - REPAIR 4-1

65C25479-7, -8, -13, -14

1. General

- A. This procedure has the data to repair the spring plate assembly (1, 5).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 5 for item numbers.

2. Parts Replacement (REPAIR 4-1, Figure 601)

NOTE: For finishing materials, refer to SOPM 20-60-02.

- A. Disassemble by standard industry practices.
- B. Replace parts as necessary.
- C. Refer to REPAIR 1-1 for refinish of retainer (50), plates (55, 60) and bracket (70).
- D. Assemble parts by standard industry practices. Be sure to apply corrosion preventive compound, B50080 to the bore of the retainer (50) before you install it.


32-41-20

REPAIR 4-1


Page 601

Mar 01/2006


COMPONENT MAINTENANCE MANUAL




65C25479-7 SHOWN
65C25479-8 OPPOSITE



65C25479-7,-8,-13,-14
A-A



65C25479-7,-8
B-B



65C25479-13,-14
B-B

1 APPLY MIL-C-11796, CLASS 1 CORROSION
PREVENTIVE COMPOUND TO THE BORE OF THIS
PART BEFORE INSTALLATION

ITEM NUMBERS REFER TO IPL FIG. 5

65C25479-7,-8,-13,-14 Spring Plate Assembly Parts Replacement
Figure 601

32-41-20

REPAIR 4-1

Page 602

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

QUADRANT AND SHAFT ASSEMBLY - REPAIR 5-1

65C25576-1, -2

1. General

- A. The 65C25576-1, -2 quadrant and shaft assembly could come in for overhaul as a unit with the 65C25416-series support IPL Figure 4 because the bearings in the support could be an interference fit with the shaft for some combinations of shaft OD and bearing ID sizes. If this is the case, use the instructions of REPAIR 5-1, Paragraph 2. to remove the quadrant and shaft assembly from the other components. Then refer to REPAIR 5-1, Paragraph 3. for the overhaul of the quadrant and shaft assembly itself. After overhaul is complete, you can install the quadrant and shaft assembly back into the support to have a unit that can be installed in the airplane. If the bearings are not an interference fit on the shaft, or if the quadrant and shaft assembly did not come installed on the support, start with the instructions of REPAIR 5-1, Paragraph 3..
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers, unless shown differently.

2. Disassembly of Quadrant and Shaft Assembly From Installation Components (REPAIR 5-1, Figure 601)

- A. Remove spring (800) from between the quadrant and spring plate (25).
- B. Remove nuts (IPL Figure 2;65), washers (IPL Figure 2;60) and bolts (IPL Figure 2;55). Remove plug (IPL Figure 2;70) from the end of the shaft (IPL Figure 2;90).
- C. Remove the quadrant from the shaft.
- D. Remove spacer (815) from the top end of the shaft.
- E. Remove the nuts, washers, and bolts that hold spring plate assembly (25) to support assembly (15). Remove the plate.
- F. Try to remove the shaft from the support assembly. The bearings in the upper and lower locations could be an interference fit with the outer shaft for some combinations of shaft OD and bearing ID sizes. If necessary, push the shaft out with a press.
- G. Remove the bearings, the seal, and spacer (810) from support assembly (15).
- H. Refer to REPAIR 5-1, Paragraph 3., as necessary, for more instructions to disassemble the parts of the quadrant and shaft assembly. Refer to REPAIR 2-1 for repair of the support assembly. Refer to REPAIR 4-1 for repair of the spring plate assembly.

3. Disassembly of Quadrant and Shaft Assembly (REPAIR 5-1, Figure 602)

NOTE: Refer to IPL Figure 2 for item numbers.

NOTE: Bearings could be on the shaft when the unit comes in for overhaul. These bearings could be an interference fit on the shaft for some combinations of shaft OD and bearing ID sizes.

- A. Remove nuts (65), washers (60) and bolts (55). Remove plug (70). Pull the quadrants (75) as a unit from the shaft. The plug and the quadrants were installed on the shaft with wet primer.
- B. Quadrants
 - (1) Remove nuts (25), washers (20) and bolts (10).
 - (2) Remove cotter pins (20) and pins (15).
 - (3) Remove cotter pin (50), washer (40), pin (35) and spring retainers (45).
 - (4) Pull the two quadrants (75) apart.

32-41-20

REPAIR 5-1

Page 601

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

- (5) Refer to REPAIR 7-1 for repair of the quadrants. Refer to REPAIR 1-1 for refinish of retainer (45).

C. Shafts

- (1) Push out pins (80). These pins were installed with retaining compound.
- (2) Push or pull inner shaft (90) from outer shaft (85). Remove bearings (100) from the outer shaft (85), if necessary.
- (3) Refer to REPAIR 8-1 and REPAIR 9-1 for repair of the inner shafts (90) and outer shafts (85), respectively. Refer to REPAIR 1-1 for refinish of pins (80).

4. Assembly of Quadrant and Shaft Assembly (REPAIR 5-1, Figure 602)

NOTE: Refer to IPL Figure 2 for item numbers.

NOTE: If the bearings in the support are not a clearance fit with the outer shaft, do only the procedures for REPAIR 5-1, Paragraph 4.A. and REPAIR 5-1, Paragraph 4.B. below. Then do the procedure of REPAIR 5-1, Paragraph 5. as an alternative to the procedure for REPAIR 5-1, Paragraph 4.C..

NOTE: For finishing materials, refer to SOPM 20-60-02. For lubricants, refer to SOPM 20-60-03.

A. Shafts

- (1) Install inner shaft (90) in outer shaft (85). Adjust the shafts as necessary to align the holes. If a replacement shaft is used, be sure to drill holes in it with the old shaft or the mating shaft as a guide.
- (2) Install pins (80) with Type 3 retaining compound, G00106 per SOPM 20-50-12. Be sure to push the pins in lower than the surfaces of the splines.

B. Quadrants

- (1) Put the two quadrants together. Adjust their positions as necessary to align the holes and to be aligned within the limit shown. If a quadrant is replaced, be sure to drill holes in it as shown with the other quadrant and the pilot holes as a guide.
- (2) Install spring retainer (45) with pin (35) and washer (40), with grease, D00015 on mating surfaces. Install cotter pin (50).
- (3) Install pins (15) with grease, D00015. Install cotter pins (20).
- (4) Install bolts (10), washers (20), and nuts (25) with grease, D00015 on mating surfaces.

NOTE: If the bearings are not a clearance fit with the shaft, do the procedure of REPAIR 5-1, Paragraph 5. as an alternative to this step, REPAIR 5-1, Paragraph 4.C..

- C. Apply primer, C00259 to the mating splines of the shaft and the quadrant unit. Then install the quadrant unit on the shaft. Install plug (70) in the end of the shaft with wet primer, C00259. Be sure to align the holes in the plug with the mating holes in the shaft and the quadrant. Then install bolts (55), washers (60), and nuts (65) with grease, D00015 on the mating surfaces.

5. Assembly of Quadrant and Shaft Assembly into Installation Components (REPAIR 5-1, Figure 601)

NOTE: Refer to IPL Figure 1 for item numbers, unless shown differently.

NOTE: For finishing materials, refer to SOPM 20-60-02. For lubricants, refer to SOPM 20-60-03.

32-41-20

REPAIR 5-1
Page 602
Mar 01/2006



COMPONENT MAINTENANCE MANUAL

- A. Install the outer shaft (with installed inner shaft) in support assembly (15) with the bearings at the upper and lower locations, with spacer (810) and the seal in between, and with grease, D00013 on the mating surfaces of the bearings, spacer, and shaft. If the bearings are an interference fit with the shaft, press them on the shaft in the locations shown, with the shaft, spacer, and seal installed in the support.
- B. Install spacer (815) on the top end of the shaft.
- C. Install spring plate assembly (25) on support assembly (15) with the bolts, washers, and nuts (4 locations) (IPL Figure 2).
- D. Apply primer, C00259 to the mating splines of the shaft and the quadrant unit. Then install the quadrant unit on the shaft.
- E. Install plug (70) in the end of the shaft with wet primer, C00259. Be sure to align the holes in the plug with the mating holes in the shaft and the quadrant. Then install bolts (55), washers (60), and nuts (65) with grease, D00013 on the mating surfaces (IPL Figure 2).


32-41-20

REPAIR 5-1

Page 603

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



65C25576-1,-2 Quadrant and Shaft Assembly with Installation Parts
Figure 601


32-41-20

REPAIR 5-1

Page 604

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



65C25576-1,-2 Quadrant and Shaft Assembly Parts Replacement
Figure 602 (Sheet 1 of 3)



32-41-20

REPAIR 5-1

Page 605

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



65C25576-1,-2 Quadrant and Shaft Assembly Parts Replacement
Figure 602 (Sheet 2 of 3)


32-41-20

REPAIR 5-1

Page 606

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



- 1 INSTALL OR ASSEMBLE WITH WET PRIMER BMS 10-11, TYPE 1 (F-20.06) ON MATING SURFACES.
- 2 THIS HOLE MUST BE MADE IN REPLACEMENT PARTS. THE QUADRANTS COME WITH ONLY A SMALLER PILOT HOLE AT THIS LOCATION.
- 3 THESE HOLES MUST BE MADE IN REPLACEMENT PARTS. THE ANGULAR POSITION IS OPTIONAL.
- 4 INSTALL AND BOND WITH MIL-R-46082, TYPE 3 RETAINING COMPOUND PER SOPM 20-50-12.
- 5 INSTALL WITH BMS 3-27 CORROSION PREVENTIVE COMPOUND PER SOPM 20-50-19, CORROSION PROTECTION SEALING METHOD 2.

ITEM NUMBERS REFER TO IPL FIG. 2
ALL DIMENSIONS ARE IN INCHES

65C25576-1,-2 Quadrant and Shaft Assembly Parts Replacement
Figure 602 (Sheet 3 of 3)

32-41-20

REPAIR 5-1
Page 607
Mar 01/2006



COMPONENT MAINTENANCE MANUAL

QUADRANT AND SHAFT ASSEMBLY - REPAIR 6-1

65C25576-3, -4

1. General

- A. This procedure has the data to repair the quadrant and shaft assembly (5A, 10A).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 3 for item numbers.

2. Disassembly (REPAIR 6-1, Figure 601)

- A. Remove spring (45) from quadrant (50) and spring plate (75).
- B. Remove bolt (10), washers (15), nuts (20).
- C. Remove quadrant (50) from shaft (115). If necessary, remove collar (35), bolt (25), washers (30) and spring retainer (40) from the quadrant. Refer to REPAIR 7-1 for repair of the quadrant.
- D. Remove spacer (55) from the end of the shaft.
- E. Remove bolts (60), washers (65), nuts (70), and plate (75).
- F. Try to remove shaft (115) from support (85). Bearings (100) could be an interference fit on the shaft for some combinations of shaft OD and bearing ID sizes. If necessary, push the shaft out with a press.
- G. Remove bearings (100), spacer (110) and seal (105) from support (85).
- H. Refer to REPAIR 2-1 for repair of the support. Refer to REPAIR 4-1 for repair of the spring plate. Refer to REPAIR 9-1 for repair of the shaft.

3. Assembly (REPAIR 6-1, Figure 601)

NOTE: For finishing materials, refer to SOPM 20-60-02. For lubricants, refer to SOPM 20-60-03.

- A. Install shaft (115) in support (85) with bearings (100), spacer (110) and seal (105) with grease, D00015 or grease, D00013 on mating surfaces. If the bearings are an interference fit with the shaft, press them on the shaft to get the dimension shown.
- B. Install spacer (55) on shaft (115).
- C. Install spring plate (75) with bolts (60), washers (65) and nuts (70), with corrosion preventive compound, C00913. Tighten the nuts as shown.
- D. Install spring retainer (40) on quadrant (50) with bolt (25), washer (30), and collar (35).
- E. Apply primer, C00259 to the mating splines of the shaft and the quadrant. Then install the quadrant on the shaft. Apply primer, C00259 to the hole surfaces of the shaft and quadrant. Then install bolt (10), washer (15) and nut (20). Tighten the nut as shown.
- F. Connect spring (45) between the quadrant and the spring plate as shown.


32-41-20

REPAIR 6-1


Page 601

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



65C25576-3 SHOWN
65C25576-4 OPPOSITE




65C25576-3,-4 Quadrant and Shaft Assembly Parts Replacement
Figure 601 (Sheet 1 of 2)

32-41-20

REPAIR 6-1
Page 602
Mar 01/2006



COMPONENT MAINTENANCE MANUAL



B-B

- 1 INSTALL THE QUADRANT ON THE SHAFT WITH WET BMS 10-11, TYPE 1 PRIMER (F-20.06).
- 2 INSTALL THE FASTENERS WITH BMS 3-27 CORROSION PREVENTIVE COMPOUND PER SOPM 20-50-19, CORROSION PROTECTION SEALING METHOD 2.
- 3 APPLY BMS 10-11, TYPE 1 PRIMER TO THE HOLE SURFACES AND IMMEDIATELY INSTALL BOLT, WASHER AND NUT. TIGHTEN THE NUT TO 20 POUND-INCHES ABOVE DRIVE TORQUE.
- 4 THIS HOLE MUST BE MADE IN REPLACEMENT PARTS. CHEMICAL TREAT THE NEW HOLE PER SOPM 20-43-03.
- 5 INSTALL THESE PARTS WITH GREASE BMS 3-24 OR MIL-G-23827.
- 6 LUBRICATE THE SPACER OUTSIDE DIAMETER WITH MIL-G-23827 GREASE BEFORE INSTALLATION.

ITEM NUMBERS REFER TO IPL FIG. 3

ALL DIMENSIONS ARE IN INCHES

65C25576-3,-4 Quadrant and Shaft Assembly Parts Replacement
Figure 601 (Sheet 2 of 2)

32-41-20

REPAIR 6-1

Page 603

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

QUADRANT - REPAIR 7-1

65-49954-5, -7

1. General

- A. This procedure has the data to repair the quadrant (IPL Figure 2;75) and (IPL Figure 3;50).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 2 and IPL Figure 3 for item numbers.
- D. Material: ALUM ALLOY

2. Coating Repair (REPAIR 7-1, Figure 601 and REPAIR 7-1, Figure 602)

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01. For finishing materials, refer to SOPM 20-60-02.

- A. Repair is only replacement of the original finish of quadrant (IPL Figure 2;75).
 - (1) Anodize and apply primer, C00259 (F-18.04) as shown in REPAIR 7-1, Figure 601.
- B. Repair is only replacement of the original finish of quadrant (IPL Figure 3;50).
 - (1) Boric acid-sulfuric acid anodize (F-17.31) and apply primer, C00259 (F-20.03) as shown in REPAIR 7-1, Figure 602.

32-41-20


REPAIR 7-1

Page 601

Mar 01/2006



COMPONENT MAINTENANCE MANUAL



REFINISH

ANODIZE AND APPLY PRIMER BMS 10-11, TYPE 1
(F-18.04), BUT NO PRIMER ON DIA -X-

REPAIR

(SAME AS REFINISH)

125/ ALL MACHINED SURFACES

MATERIAL: AL ALLOY

ALL DIMENSIONS ARE IN INCHES

65-49954-5 Quadrant Refinish
Figure 601

32-41-20



REPAIR 7-1

Page 602

Mar 01/2006



COMPONENT MAINTENANCE MANUAL



REFINISH

BORIC ACID-SULFURIC ACID ANODIZE (F-17.31).
APPLY PRIMER BMS 10-11, TYPE 1 (F-20.03), BUT
NOT IN DIA -X-

REPAIR

(SAME AS REFINISH)

125/ ALL MACHINED SURFACES

MATERIAL: AL ALLOY

ALL DIMENSIONS ARE IN INCHES

65-49954-7 Quadrant Refinish
Figure 602

32-41-20

REPAIR 7-1

Page 603

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

INNER SHAFT - REPAIR 8-1

69-74409-1

1. General

- A. This procedure has the data to repair the inner shaft (IPL Figure 2;90).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 2 for item numbers.
- D. Material: 15-5PH CRES, 180-200 KSI

2. Coating Repair (REPAIR 8-1, Figure 601)

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- A. Repair is only replacement of the original finish of inner shaft (IPL Figure 2;90).
 - (1) Passivate (F-17.09).

32-41-20



REPAIR 8-1

Page 601

Mar 01/2006



COMPONENT MAINTENANCE MANUAL



	1	2	3	4	5	6
DESIGN DIM	0.747 0.745	0.710 0.690	0.500 0.490	0.41 0.40	0.470 0.467	0.260 0.240
REPAIR LIMIT	---	---	---	---	---	---

REFINISH
PASSIVATE (F-17.09)

REPAIR
(SAME AS REFINISH)
125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY
MATERIAL: 15-5PH CRES, 180-200 KSI
ALL DIMENSIONS ARE IN INCHES

69-74409-1 Inner Shaft Repair and Refinsh
Figure 601

32-41-20



COMPONENT MAINTENANCE MANUAL

OUTER SHAFT - REPAIR 9-1

69-74411-1, -2

1. General

- A. This procedure has the data to repair the outer shaft (IPL Figure 2;85) and (IPL Figure 3;115).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 2 and IPL Figure 3 for item numbers.
- D. Material: 15-5PH CRES, 180-200 KSI

2. Coating Repair (REPAIR 9-1, Figure 601 and REPAIR 9-1, Figure 602)

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01. For finishing materials, refer to SOPM 20-60-02.

- A. Repair is only replacement of the original finish of outer shaft (IPL Figure 2;85).
 - (1) Passivate (F-17.09) all over.
 - (2) Cadmium plate and apply primer, C00259 (F-16.01) as shown in REPAIR 9-1, Figure 601.
- B. Repair is only replacement of the original finish of outer shaft (IPL Figure 3;115).
 - (1) Passivate (F-17.25) all over.
 - (2) Cadmium plate (F-16.06) as shown in REPAIR 9-1, Figure 602.

32-41-20


REPAIR 9-1

Page 601

Mar 01/2006



COMPONENT MAINTENANCE MANUAL



	1	2	3	4	5	6
DESIGN DIM	0.995 0.992	0.9995 0.9990	0.97 0.95	0.659 0.652	0.750 0.748	0.510 0.505
LIMIT	---	---	---	---	---	---

REFINISH

PASSIVATE (F-17.09) ALL OVER.
CADMIUM PLATE AND APPLY PRIMER TO AREA
SHOWN BY 1

1 CADMIUM PLATE AND APPLY PRIMER BMS 10-11,
TYPE 1 (F-16.01) TO THIS AREA

REPAIR

(SAME AS REFINISH)
125/ ALL MACHINED SURFACES UNLESS SHOWN
DIFFERENTLY
MATERIAL: 15-5PH CRES, 180-200 KSI
ALL DIMENSIONS ARE IN INCHES

69-74411-1 Outer Shaft Repair and Refinish
Figure 601


32-41-20

REPAIR 9-1
Page 602

Mar 01/2006



COMPONENT MAINTENANCE MANUAL



	1	2	3	4	5	6	7
DESIGN DIM	0.9995 0.9990 2	0.097 0.095	0.659 0.652	0.151 0.131	0.500 0.490	0.76 0.74	0.26 0.24
REPAIR LIMIT	---	---	---	---	---	---	---

REFINISH

PASSIVATE (F-17.25). CADMIUM PLATE OUTER DIAMETER AREAS AS SHOWN BY 1

1 CADMIUM PLATE (F-16.06) THIS AREA OF OUTER DIAMETER, 0.0002-0.0003 THICK WITH PLATING RUNOUT IN SPLINE RUNOUT.

2 DIMENSION AFTER PLATING.

REPAIR

(SAME AS REFINISH)

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

MATERIAL: 15-5PH CRES, 180-200 KSI

ALL DIMENSIONS ARE IN INCHES

69-74411-2 Outer Shaft Repair and Refinish
Figure 602

32-41-20

REPAIR 9-1

Page 603

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

LEVER ASSEMBLY - REPAIR 10-1

69-74714-1, -2

1. General

- A. This procedure has the data to repair the lever assembly (IPL Figure 7; 1,5).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 7 for item numbers.

2. Parts Replacement (REPAIR 10-1, Figure 601)



- A. Disassemble by standard industry practices.
- B. Refer to REPAIR 10-2 for repair of lever (40).
- C. Refer to REPAIR 1-1 for refinish of bushing (30) and retainer (35).
- D. Assemble parts by standard industry practices.

32-41-20

REPAIR 10-1
Page 601
Mar 01/2006



COMPONENT MAINTENANCE MANUAL



69-74714-1 SHOWN
69-74714-2 OPPOSITE

ITEM NUMBERS REFER TO IPL FIG. 7

69-74714-1,-2 Lever Assembly Parts Replacement
Figure 601

32-41-20

REPAIR 10-1
Page 602
Mar 01/2006



COMPONENT MAINTENANCE MANUAL

LEVER - REPAIR 10-2

69-74712-1

1. General

- A. This procedure has the data to repair the lever (IPL Figure 7;40).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 7 for item numbers.
- D. Material: 15-5PH CRES, 150-170 KSI

2. Coating Repair (REPAIR 10-2, Figure 601)

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- A. Repair is only replacement of the original finish of lever (IPL Figure 7;40).
 - (1) Passivate (F-17.09) all over.

32-41-20

REPAIR 10-2
Page 601
Mar 01/2006

65C25416, 65C25442, 65C25479,
65C25576, 69-74714



COMPONENT MAINTENANCE MANUAL

ASSEMBLY

(NOT APPLICABLE)

32-41-20

ASSEMBLY

Page 701

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

FITS AND CLEARANCES

(NOT APPLICABLE)

32-41-20

FITS AND CLEARANCES

Page 801

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

SPECIAL TOOLS, FIXTURES, AND EQUIPMENT

(NOT APPLICABLE)

32-41-20

SPECIAL TOOLS, FIXTURES, AND EQUIPMENT

Page 901

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

ILLUSTRATED PARTS LIST

1. Introduction

- A. The Illustrated Parts List (IPL) contains an illustration and a list of component parts you can repair or replace. The Illustrated Parts Catalog (IPC) shows how to use the Boeing part number system.
- B. This shows how parts are related: The relation of each item to its next higher assembly (NHA) is shown in the NOMENCLATURE column. Use the indenture system that follows:

1	2	3	4	5	6	7
.	Assembly					
.	Attaching parts for assembly					
.	.	Detail parts for assembly				
.	.	Subassembly				
.	.	Attaching parts for subassembly				
.	.	.	Detail parts for subassembly			
.	.	.	Sub-subassembly			
.	.	.	Attaching parts for subassembly			
.	.	.	.	Details parts for sub-subassembly		

Detail Installation Parts (Included only if installation parts may be sent to the shop as part of assembly)

- C. Each top assembly is given one use code letter (A, B, C, etc.) in the USAGE CODE column. All subsequent component parts in the list can have one or more of the use code letters to show effectivity to top assemblies. A component part without a use code applies to all top assemblies.
- D. An alphabetical letter is added after the item number for optional parts, parts changed by a Service Bulletin, configuration differences (except left-handed and right-handed parts), last engineering releases, and parts added between item numbers in a sequence. The alphabetical letter will not be shown on the illustration for equivalent parts of the same part number.
- E. Color-coded parts are identified with a single digit alpha following the dash number or with "SP" suffix. If the "SP" suffix is used, it represents consolidation of all color codes applicable for a given usage which are not separately listed. Orders for color-coded parts should include the registry number of the airplane for which the parts are ordered.
- F. If a part number is 15 characters long but will not fit in the part number column, the part number will be displayed with a "~" at the end of the line and will be continued on the next line. The "~" denotes that the part number continues on the next line.
- G. Parts changed by a Service Bulletin are shown by PRE SB XXXX and POST SB XXXX added to the NOMENCLATURE column.
 - (1) When a new top assembly is added by a Service Bulletin, PRE SB XXXX and POST SB XXXX will be added at the top assembly level only. The configuration differences at the detail part level are shown by use code letters.
 - (2) When the top assembly part number is not changed by the Service Bulletin, PRE SB XXXX and POST SB XXXX will be added at the detail level.
- H. Interchangeable Parts

32-41-20

ILLUSTRATED PARTS LIST

Page 1001

Nov 01/2008



COMPONENT MAINTENANCE MANUAL

Optional (OPT)	The part is optional to and interchangeable with other parts that have the same item number.
Replaces, Replaced by and not interchangeable with (REPLACES, REPLACED BY AND NOT INTCHG/W)	The part replaces and is not interchangeable with the initial part.
Replaces, Replaced by (REPLACES, REPLACED BY)	The part replaces and is interchangeable with, or is an alternative to, the initial part.

VENDOR CODES

Code	Name
73680	GARLOCK INC MECHANICAL PACKING DIV SUB OF COLT IND 1666 DIVISION STREET PALMYRA, NEW YORK 14522-9343



COMPONENT MAINTENANCE MANUAL

NUMERICAL INDEX

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
		1		1
21923-0351		3	105	1
21959-0351		3	105A	1
65-49954-5		2	75	2
65-49954-7		3	50	1
65C20899-1		1	830	1
65C20899-3		1	830A	1
65C20899-4		1	830B	1
65C20899-5		1	830C	1
65C25416-10		1	20	RF
		4	5	RF
65C25416-11		4	10	1
65C25416-12		4	15	1
65C25416-13		1	15A	RF
		3	85	1
		4	1A	RF
65C25416-14		1	20A	RF
		3	90	1
		4	5A	RF
65C25416-15		4	10A	1
65C25416-16		4	15A	1
65C25416-9		1	15	RF
		4	1	RF
65C25442-10		1	35A	RF
		6	1A	RF
65C25442-7		1	35	RF
		6	1	RF
65C25479-10		5	60	1
65C25479-11		5	70	1
65C25479-13		1	25A	RF
		3	75	1
		5	1A	RF
65C25479-14		1	30A	RF
		3	80	1

32-41-20

ILLUSTRATED PARTS LIST

Page 1003

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
65C25479-7		5	5A	RF
		1	25	RF
		5	1	RF
65C25479-8		1	30	RF
		5	5	RF
		5	55	1
65C25479-9		1	5	RF
65C25576-1		2	1	RF
		1	10	RF
		2	5	RF
65C25576-2		1	5A	RF
		3	1	RF
		1	10A	RF
65C25576-3		3	5	RF
		1	815	1
		3	55	1
65C25576-4		1	820	1
		1	825	1
		2	45	1
66-24188-3		3	40	1
		5	50	1
		1	800	1
66-24188-4		3	45	1
		2	70	1
		6	35	1
66-24188-6		6	15	2
69-73422-1		2	90	1
		2	80	2
		2	85	1
69-73423-1		2	85	1
		3	115	1
		1	810	1
69-73499-1		3	110	1
		6	45	1
		6	45A	1
69-74407-1		7	40	1
69-74408-2				
69-74409-1				
69-74410-1				
69-74411-1				
69-74411-2				
69-74412-1				
69-74439-1				
69-74439-2				
69-74712-1				

32-41-20

ILLUSTRATED PARTS LIST

Page 1004

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
69-74713-1		7	35	1
69-74714-1		1	40	RF
		7	1	RF
69-74714-2		1	45	RF
		7	5	RF
69-75945-1		1	805	1
69-78716-1		6	40	2
AN960C10L		7	15	1
AN960JD10		5	25	1
AN960PD10		2	20	4
AN960PD10L		2	40	1
		5	20	1
AN960PD416		2	60	2
AN970-3		3	30	1
BACB10BW16		3	100	2
BACB10ET03		6	30	1
BACB28X3N035		7	30	1
BACB30LK3-16		7	10	1
BACB30LT4D28		3	10	1
BACB30NT3K5		3	60	4
BACB30VT6K19		5	15	1
BACB30VT6K7		3	25	1
BACC30BL6		3	35	1
BACN10JC3		2	25	2
BACN10JC3CD		3	70	4
BACN10JC4		2	65	2
BACN10YR4CD		3	20	1
BACR15BB5D		5	65	4
BACS18K10-54W		5	35	1
MS20392-2C19		2	35	1
MS20392-2C27		2	15	2
MS20392-2C41		5	10	1
MS21042L3		5	40	1
		7	20	1
MS21209F4-20P		4	20	4

32-41-20

ILLUSTRATED PARTS LIST

Page 1005

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
MS21438-103G		7	25	1
MS24665-132		2	30	2
		2	50	1
MS24665-134		5	45	1
NAS1149D0332J		3	15	1
		3	65	4
NAS1805-3		6	25	1
NAS43DD3-41		5	30	1
NAS509-6		6	5	2
NAS513-6		6	10	2
NAS623-3-10		2	10	2
NAS623-3-8		6	20	1
NAS6604-28		2	55	2


32-41-20

ILLUSTRATED PARTS LIST

Page 1006

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



Brake Metering Valve Control Installation Components
IPL Figure 1 (Sheet 1 of 2)


32-41-20

ILLUSTRATED PARTS LIST

Page 1007

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



Brake Metering Valve Control Installation Components
IPL Figure 1 (Sheet 2 of 2)

32-41-20

ILLUSTRATED PARTS LIST

Page 1008

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE 1 2 3 4 5 6 7	USAGE CODE	UNITS PER ASSY
1-			BRAKE METERING VALVE CONTROL INSTALLATION COMPONENTS		
5	65C25576-1		QUADRANT AND SHAFT ASSY (LH) (FOR DETAILS SEE FIG. 2)		RF
5A	65C25576-3		QUADRANT AND SHAFT ASSY (LH) (FOR DETAILS SEE FIG. 3)		RF
-10	65C25576-2		QUADRANT AND SHAFT ASSY (RH) (FOR DETAILS SEE FIG. 2)		RF
-10A	65C25576-4		QUADRANT AND SHAFT ASSY (RH) (FOR DETAILS SEE FIG. 3)		RF
-15	65C25416-9		SUPPORT ASSY (FOR DETAILS SEE FIG. 4)		RF
-15A	65C25416-13		SUPPORT ASSY (FOR DETAILS SEE FIG. 4)		RF
-20	65C25416-10		SUPPORT ASSY (FOR DETAILS SEE FIG. 4)		RF
-20A	65C25416-14		SUPPORT ASSY (FOR DETAILS SEE FIG. 4)		RF
-25	65C25479-7		PLATE ASSY-SPRING (FOR DETAILS SEE FIG. 5)		RF
-25A	65C25479-13		PLATE ASSY-SPRING (FOR DETAILS SEE FIG. 5)		RF
-30	65C25479-8		PLATE ASSY-SPRING (FOR DETAILS SEE FIG. 5)		RF
-30A	65C25479-14		PLATE ASSY-SPRING (FOR DETAILS SEE FIG. 5)		RF
35	65C25442-7		LEVER ASSY (FOR DETAILS SEE FIG. 6)		RF
-35A	65C25442-10		LEVER ASSY (FOR DETAILS SEE FIG. 6)		RF
40	69-74714-1		LEVER ASSY (FOR DETAILS SEE FIG. 7)		RF
-45	69-74714-2		LEVER ASSY (FOR DETAILS SEE FIG. 7)		RF

-Item not Illustrated

32-41-20

ILLUSTRATED PARTS LIST

Page 1009

Mar 01/2006




COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1—											
800	69-73423-1										1
805	69-75945-1										1
810	69-74412-1										1
815	66-24188-3										1
820	66-24188-4										1
825	66-24188-6										1
830	65C20899-1										1
830A	65C20899-3										1
830B	65C20899-4										1
830C	65C20899-5										1

—Item not Illustrated

COMPONENT MAINTENANCE MANUAL



65C25576-1 SHOWN
65C25576-2 OPPOSITE

Quadrant and Shaft Assembly
IPL Figure 2 (Sheet 1 of 2)


32-41-20

ILLUSTRATED PARTS LIST

Page 1011

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



65C25576-1 SHOWN
65C25576-2 OPPOSITE

A

Quadrant and Shaft Assembly
IPL Figure 2 (Sheet 2 of 2)

32-41-20

ILLUSTRATED PARTS LIST

Page 1012

Mar 01/2006




COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE 1 2 3 4 5 6 7	USAGE CODE	UNITS PER ASSY
2-					
-1	65C25576-1		QUADRANT AND SHAFT ASSY (LH)	A	RF
-5	65C25576-2		QUADRANT AND SHAFT ASSY (RH)	B	RF
10	NAS623-3-10		. SCREW		2
15	MS20392-2C27		. PIN		2
20	AN960PD10		. WASHER		4
25	BACN10JC3		. NUT		2
30	MS24665-132		. PIN-COTTER		2
35	MS20392-2C19		. PIN		1
40	AN960PD10L		. WASHER		1
45	69-73422-1		. RETAINER-SPRING		1
50	MS24665-132		. PIN-COTTER		1
55	NAS6604-28		. BOLT		2
60	AN960PD416		. WASHER		2
65	BACN10JC4		. NUT		2
70	69-73499-1		. PLUG		1
75	65-49954-5		. QUADRANT		2
80	69-74410-1		. PIN		2
85	69-74411-1		. SHAFT-OUTER		1
90	69-74409-1		. SHAFT-INNER		1

-Item not Illustrated

COMPONENT MAINTENANCE MANUAL



65C25576-3 SHOWN
65C25576-4 OPPOSITE

Quadrant and Shaft Assembly
IPL Figure 3

32-41-20

ILLUSTRATED PARTS LIST

Page 1014

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE 1 2 3 4 5 6 7	USAGE CODE	UNITS PER ASSY
3-					
-1	65C25576-3		QUADRANT AND SHAFT ASSY	A	RF
-5	65C25576-4		QUADRANT AND SHAFT ASSY	B	RF
10	BACB30LT4D28		. BOLT		1
15	NAS1149D0332J		. WASHER		1
20	BACN10YR4CD		. NUT		1
25	BACB30VT6K7		. BOLT		1
30	AN970-3		. WASHER		1
35	BACC30BL6		. COLLAR		1
40	69-73422-1		. RETAINER-SPRING		1
45	69-73423-1		. SPRING		1
50	65-49954-7		. QUADRANT		1
55	66-24188-3		. SPACER		1
60	BACB30NT3K5		. BOLT		4
65	NAS1149D0332J		. WASHER		4
70	BACN10JC3CD		. NUT		4
75	65C25479-13		. PLATE ASSY-SPRING (FOR DETAILS SEE FIG. 5)	A	1
-80	65C25479-14		. PLATE ASSY-SPRING (FOR DETAILS SEE FIG. 5)	B	1
85	65C25416-13		. SUPPORT ASSY (FOR DETAILS SEE FIG. 4)	A	1
-90	65C25416-14		. SUPPORT ASSY (FOR DETAILS SEE FIG. 4)	B	1
100	BACB10BW16		. BEARING		2
105	21923-0351		. SEAL (V73680)		1
-105A	21959-0351		. SEAL (V73680) (OPT ITEM 105)		1
110	69-74412-1		. SPACER		1
115	69-74411-2		. SHAFT		1

-Item not Illustrated


32-41-20

ILLUSTRATED PARTS LIST

Page 1015

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



65C25416-9,-13 SHOWN
65C25416-10,-14 OPPOSITE

Support Assembly
IPL Figure 4

32-41-20

ILLUSTRATED PARTS LIST

Page 1016

Mar 01/2006




COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE 1 2 3 4 5 6 7	USAGE CODE	UNITS PER ASSY
4-					
-1	65C25416-9		SUPPORT ASSY	A	RF
-1A	65C25416-13		SUPPORT ASSY	C	RF
-5	65C25416-10		SUPPORT ASSY	B	RF
-5A	65C25416-14		SUPPORT ASSY	D	RF
10	65C25416-11		. SUPPORT	A	1
-10A	65C25416-15		. SUPPORT	C	1
15	65C25416-12		. SUPPORT	B	1
-15A	65C25416-16		. SUPPORT	D	1
20	MS21209F4-20P		. INSERT-HELICAL COIL		4

-Item not Illustrated

COMPONENT MAINTENANCE MANUAL



65C25479-7 SHOWN
65C25479-8 OPPOSITE

Spring Plate Assembly
IPL Figure 5 (Sheet 1 of 2)


32-41-20

ILLUSTRATED PARTS LIST

Page 1018

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



65C25479-13 SHOWN
65C25479-14 OPPOSITE

Spring Plate Assembly
IPL Figure 5 (Sheet 2 of 2)

32-41-20

ILLUSTRATED PARTS LIST

Page 1019

Mar 01/2006






COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE 1 2 3 4 5 6 7	USAGE CODE	UNITS PER ASSY
5-					
-1	65C25479-7		PLATE ASSY-SPRING	A	RF
-1A	65C25479-13		PLATE ASSY-SPRING	C	RF
-5	65C25479-8		PLATE ASSY-SPRING	B	RF
-5A	65C25479-14		PLATE ASSY-SPRING	D	RF
10	MS20392-2C41		. PIN	A, B	1
15	BACB30VT6K19		. BOLT	C, D	1
20	AN960PD10L		. WASHER	A, B	1
25	AN960JD10		. WASHER	C, D	1
30	NAS43DD3-41		. SPACER	A, B	1
35	BACS18K10-54W		. SPACER	C, D	1
40	MS21042L3		. NUT	C, D	1
45	MS24665-134		. PIN-COTTER	A, B	1
50	69-73422-1		. RETAINER		1
55	65C25479-9		. PLATE	A, C	1
60	65C25479-10		. PLATE	B, D	1
65	BACR15BB5D		. RIVET		4
70	65C25479-11		. BRACKET		1

-Item not Illustrated

COMPONENT MAINTENANCE MANUAL



Lever Assembly
IPL Figure 6




COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE 1 2 3 4 5 6 7	USAGE CODE	UNITS PER ASSY
6-					
-1	65C25442-7		LEVER ASSY	A	RF
-1A	65C25442-10		LEVER ASSY	B	RF
5	NAS509-6		. NUT		2
10	NAS513-6		. WASHER		2
15	69-74408-2		. CLEVIS ASSY		2
20	NAS623-3-8		. . BOLT		1
25	NAS1805-3		. . NUT		1
30	BACB10ET03		. . BEARING		1
35	69-74407-1		. . CLEVIS		1
40	69-78716-1		. BUSHING	B	2
45	69-74439-1		. LEVER	A	1
-45A	69-74439-2		. LEVER	B	1

-Item not Illustrated

COMPONENT MAINTENANCE MANUAL



69-74714-1 SHOWN
69-74714-2 OPPOSITE

Brake Force Augmenter Lever Assembly
IPL Figure 7

32-41-20

ILLUSTRATED PARTS LIST

Page 1023

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE 1 2 3 4 5 6 7	USAGE CODE	UNITS PER ASSY
7-					
-1	69-74714-1		LEVER ASSY-BRAKE FORCE AUGMENTER	A	RF
-5	69-74714-2		LEVER ASSY-BRAKE FORCE AUGMENTER (OPPOSITE TO ITEM 1)	B	RF
10	BACB30LK3-16		. BOLT		1
15	AN960C10L		. WASHER		1
20	MS21042L3		. NUT		1
25	MS21438-103G		. BEARING		1
30	BACB28X3N035		. BUSHING		1
35	69-74713-1		. RETAINER		1
40	69-74712-1		. LEVER		1

-Item not Illustrated