



COMPONENT MAINTENANCE MANUAL WITH ILLUSTRATED PARTS LIST

NOSE LANDING GEAR STEERING ACTUATOR ASSEMBLY

**PART NUMBER
275A1101-3, -4, -5, -6, -7, -8**

BOEING PROPRIETARY, CONFIDENTIAL, AND/OR TRADE SECRET

Copyright © 1995 The Boeing Company
Unpublished Work - All Rights Reserved

Boeing claims copyright in each page of this document only to the extent that the page contains copyrightable subject matter. Boeing also claims copyright in this document as a compilation and/or collective work.

This document includes proprietary information owned by The Boeing Company and/or one or more third parties. Treatment of the document and the information it contains is governed by contract with Boeing. For more information, contact The Boeing Company, P.O. Box 3707, Seattle, Washington 98124.

Boeing, the Boeing signature, the Boeing symbol, 707, 717, 727, 737, 747, 757, 767, 777, 787, Dreamliner, BBJ, DC-8, DC-9, DC-10, KC-10, KDC-10, MD-10, MD-11, MD-80, MD-88, MD-90, P-8A, Poseidon and the Boeing livery are all trademarks owned by The Boeing Company; and no trademark license is granted in connection with this document unless provided in writing by Boeing.

PUBLISHED BY BOEING COMMERCIAL AIRPLANES GROUP, SEATTLE, WASHINGTON, USA
A DIVISION OF THE BOEING COMPANY
PAGE DATE: Jul 01/2009

32-51-52

Page 1
Jul 01/2009



COMPONENT MAINTENANCE MANUAL

Revision No. 20
Jul 01/2009

To: All holders of NOSE LANDING GEAR STEERING ACTUATOR ASSEMBLY 32-51-52.

Attached is the current revision to this COMPONENT MAINTENANCE MANUAL

The COMPONENT MAINTENANCE MANUAL is furnished either as a printed manual, on microfilm, or digital products, or any combination of the three. This revision replaces all previous microfilm cartridges or digital products. All microfilm and digital products are reissued with all obsolete data deleted and all updated pages added.

For printed manuals, changes are indicated on the List of Effective Pages (LEP). The pages which are revised will be identified on the LEP by an R (Revised), A (Added), O (Overflow, i.e. changes to the document structure and/or page layout), or D (Deleted). Each page in the LEP is identified by Chapter-Section-Subject number, page number and page date.

Pages replaced or made obsolete by this revision should be removed and destroyed.

ATTENTION

IF YOU RECEIVE PRINTED REVISIONS, PLEASE VERIFY THAT YOU HAVE RECEIVED AND FILED THE PREVIOUS REVISION. BOEING MUST BE NOTIFIED WITHIN 30 DAYS IF YOU HAVE NOT RECEIVED THE PREVIOUS REVISION. REQUESTS FOR REVISIONS OTHER THAN THE PREVIOUS REVISION WILL REQUIRE A COMPLETE MANUAL REPRINT SUBJECT TO REPRINT CHARGES SHOWN IN THE DATA AND SERVICES CATALOG.

32-51-52
TRANSMITTAL LETTER
Page 1
Jul 01/2009

275A1101



COMPONENT MAINTENANCE MANUAL

Location of Change

Description of Change

NO HIGHLIGHTS

32-51-52

HIGHLIGHTS

Page 1

Jul 01/2009



COMPONENT MAINTENANCE MANUAL

Subject/Page	Date	Subject/Page	Date	Subject/Page	Date
TITLE PAGE		32-51-52 DISASSEMBLY		32-51-52 REPAIR 7-1	
O 1	Jul 01/2009	301	Mar 01/2006	601	Jul 01/2006
2	BLANK	302	Mar 01/2006	602	Mar 01/2006
32-51-52 TRANSMITTAL LETTER		32-51-52 CLEANING		32-51-52 REPAIR 8-1	
O 1	Jul 01/2009	401	Mar 01/2006	601	Jul 01/2008
2	BLANK	402	BLANK	602	Mar 01/2006
32-51-52 HIGHLIGHTS		32-51-52 CHECK		603	Mar 01/2006
O 1	Jul 01/2009	501	Mar 01/2006	604	BLANK
2	BLANK	502	BLANK	32-51-52 REPAIR 8-2	
32-51-52 EFFECTIVE PAGES		32-51-52 REPAIR - GENERAL		601	Jul 01/2006
1 thru 2	Jul 01/2009	601	Mar 01/2006	602	Mar 01/2006
		602	BLANK	603	Mar 01/2006
32-51-52 CONTENTS		32-51-52 REPAIR 1-1		604	BLANK
1	Mar 01/2006	601	Jul 01/2006	32-51-52 REPAIR 9-1	
2	BLANK	602	BLANK	601	Jul 01/2006
32-51-52 TR AND SB RECORD		32-51-52 REPAIR 2-1		602	Mar 01/2006
1	Mar 01/2006	601	Jul 01/2006	32-51-52 REPAIR 10-1	
2	BLANK	602	Mar 01/2006	601	Jul 01/2006
32-51-52 REVISION RECORD		32-51-52 REPAIR 3-1		602	Mar 01/2006
1	Mar 01/2006	601	Mar 01/2006	32-51-52 ASSEMBLY	
2	Mar 01/2006	602	BLANK	701	Jul 01/2008
32-51-52 RECORD OF TEMPORARY REVISIONS		32-51-52 REPAIR 4-1		702	Nov 01/2007
1	Mar 01/2006	601	Nov 01/2006	703	Jul 01/2006
2	Mar 01/2006	602	Jul 01/2006	704	BLANK
32-51-52 INTRODUCTION		603	Mar 01/2006	32-51-52 FITS AND CLEARANCES	
1	Mar 01/2009	604	Mar 01/2006	801	Jul 01/2006
2	BLANK	32-51-52 REPAIR 5-1		802	Mar 01/2006
32-51-52 DESCRIPTION AND OPERATION		601	Mar 01/2006	32-51-52 SPECIAL TOOLS, FIXTURES, AND EQUIPMENT	
1	Mar 01/2006	602	Jul 01/2006	901	Mar 01/2009
2	Mar 01/2006	603	Jul 01/2006	902	BLANK
32-51-52 TESTING AND FAULT ISOLATION		604	BLANK	32-51-52 ILLUSTRATED PARTS LIST	
		32-51-52 REPAIR 6-1		1001	Nov 01/2008
101	Jul 01/2008	601	Mar 01/2008	1002	Jul 01/2006
102	Jul 01/2006	602	Mar 01/2008	1003	Jul 01/2006
103	Jul 01/2006	603	Mar 01/2006	1004	Jul 01/2006
104	Jul 01/2006	604	Mar 01/2006	1005	Mar 01/2007
105	Jul 01/2006	605	Mar 01/2006	1006	Mar 01/2007
106	Jul 01/2006	606	Mar 01/2006	1007	Mar 01/2007
		607	Mar 01/2006	1008	Mar 01/2007
		608	Mar 01/2008		

A = Added, R = Revised, D = Deleted, O = Overflow

32-51-52

EFFECTIVE PAGES

Page 1

Jul 01/2009



COMPONENT MAINTENANCE MANUAL

Subject/Page	Date	Subject/Page	Date	Subject/Page	Date
32-51-52 ILLUSTRATED PARTS LIST (cont)					
1009	Mar 01/2007				
1010	Mar 01/2007				
1011	Mar 01/2007				
1012	Mar 01/2007				
1013	Mar 01/2007				
1014	Mar 01/2007				
1015	Mar 01/2007				
1016	Mar 01/2007				

A = Added, R = Revised, D = Deleted, O = Overflow

32-51-52

EFFECTIVE PAGES

Page 2

Jul 01/2009



COMPONENT MAINTENANCE MANUAL

TABLE OF CONTENTS

<u>Paragraph Title</u>	<u>Page</u>
NOSE LANDING GEAR STEERING ACTUATOR ASSEMBLY - DESCRIPTION AND OPERATION	1
TESTING AND FAULT ISOLATION	101
DISASSEMBLY	301
CLEANING	401
CHECK	501
REPAIR	601
ASSEMBLY	701
FITS AND CLEARANCES	801
SPECIAL TOOLS, FIXTURES, AND EQUIPMENT	901
ILLUSTRATED PARTS LIST	1001

32-51-52

CONTENTS

Page 1

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

INTRODUCTION

1. General

- A. The instructions in this manual supply the data necessary to do the maintenance functions together with the test, fault isolation, repair, and replacement of the defective parts.
- B. This manual is divided into different parts:
 - (1) Title Page
 - (2) Transmittal Letter
 - (3) Highlights
 - (4) List of Effective Pages
 - (5) Table of Contents
 - (6) Temporary Revision & Service Bulletin Record
 - (7) Record of Revisions
 - (8) Record of Temporary Revisions
 - (9) Introduction
 - (10) Procedures & IPL Sections
- C. Components that can be repaired have a different repair number for each specified repair. To find the repair number location of a component, look in the Repair-General procedure at the beginning of the REPAIR section. The Repair-General procedure also has an explanation of the True Position Dimension symbols used.
- D. All dimensions, measures, quantities and weights included are in English units. When metric equivalents are given they will be in the parentheses that follow the English units.
- E. The introduction to the Illustrated Parts List (IPL) shows how the IPL data is used.
- F. Design changes, optional parts, configuration differences and Service Bulletin modifications may cause different part numbers. These part numbers are identified in the IPL with an alphabetical letter which is added to the end of the basic item number. This new item number is referred to as an alpha-variant. Throughout the manual, IPL basic item number references also apply to alpha-variants unless shown differently.
- G. The tool reference numbers found in the individual procedures and in the Special Tools, Fixtures, and Equipment section are used to identify if a tool is a standard tool (STD-XXXX), a commercial tool (COM-XXXX), or a Special Tool (SPL-XXXX). This reference number is also used to distinguish between tools with similar names in the same procedure. These reference numbers are for use in the documentation only. They are not to be used for ordering tools.

32-51-52

INTRODUCTION

Page 1

Mar 01/2009



COMPONENT MAINTENANCE MANUAL

NOSE LANDING GEAR STEERING ACTUATOR ASSEMBLY - DESCRIPTION AND OPERATION

1. Description

- A. The nose landing gear steering actuator assembly is a double action hydraulic piston type which includes a piston, a cylinder assembly and a rod end assembly.

2. Operation

- A. Two of these actuators are attached by the trunnion assembly between the top and the bottom steering plates on the nose gear outer cylinder. The actuator rod ends are attached to the steering collar of the torque links. Mechanical movement is transmitted through the torque links to the inner cylinder of the nose landing gear.

3. Leading Particulars (Approximate)

- A. Length – 15 inches
- B. Diameter – 4 inches
- C. Weight – 18 pounds
- D. Pressure (proof) – 4500 psi
- E. Pressure (operate) – 3000 psi
- F. Hydraulic Fluid – fluid, D00153


32-51-52

DESCRIPTION AND OPERATION

Page 1

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



Nose Landing Gear Steering Actuator Assembly
Figure 1

32-51-52

DESCRIPTION AND OPERATION

Page 2

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

TESTING AND FAULT ISOLATION

1. General

- A. This procedure has the data necessary to do a test of the nose gear steering actuator after an overhaul or for fault isolation. There are three parts:
- (1) Nose Gear Steering Actuator Assembly Test
 - (a) External leakage
 - (b) Internal leakage
 - (c) Seal friction
 - (d) Proof pressure
 - (2) Fault Isolation
 - (3) Fault Correction
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.

2. Nose Gear Steering Actuator Test

A. Tools/Equipment

NOTE: Equivalent substitutes may be used.

Reference	Description
SPL-5401	NLG Actuator Assembly Removal/Installation Fixture Equipment (Part #: C32036-45, Supplier: 81205)
SPL-5405	Adapter-Functional Test, NLG Steering Actuator (Part #: C32039-1, Supplier: 81205)

B. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
D00153	Fluid - Hydraulic, Erosion Arresting, Fire Resistant	BMS3-11 Type IV (interchangeable & intermixable with Type V)
G01912	Lockwire - Monel (0.032 In. Dia.)	NASM20995N~ C32 (QQ-N-281)

C. References

Reference	Title
SOPM 20-50-02	INSTALLATION OF SAFETYING DEVICES
SOPM 20-60-03	LUBRICANTS
SOPM 20-60-04	MISCELLANEOUS MATERIALS

32-51-52

TESTING AND FAULT ISOLATION

Page 101

Jul 01/2008



COMPONENT MAINTENANCE MANUAL

D. General

- (1) You will visibly monitor the actuator for leaks and measure the rate of the piston.

E. Standard Tools and Equipment

- (1) A hydraulic test stand with these requirements:
 - (a) Can operate with fluid, D00153.
 - (b) Can operate in a range of 0 - 4700 psi.
 - (c) The fluid must be continuously filtered by a filter no larger than 15 micron absolute.
 - (d) The fluid temperature to be 60-100°F.

F. Prepare for Test

- (1) Install the functional test adapter tool, SPL-5405 on the actuator.
- (2) Attach the Removal/Installation Fixture Equipment, SPL-5401 lines to the ports.
- (3) Fill the actuator with hydraulic fluid.

NOTE: The actuator will stay full of hydraulic fluid, D00153 for each test.

- (4) Remove all of the air from the actuator.

NOTE: Use the minimum pressure that is necessary to extend and retract the actuator until the hydraulic fluid has no air.

- (5) Tighten the nut (35).
 - (a) Use the minimum pressure to extend the piston (90).
 - (b) Apply 2900-3100 psi to the extend port.
 - (c) With the spanner wrench, tighten the nut (35) to 1000-1200 pound-inches.

G. Procedure

NOTE: For lubricants, refer to SOPM 20-60-03. For miscellaneous materials, refer to SOPM 20-60-04.

WARNING: DO NOT APPLY COMPRESSED AIR TO PORT AT ANY TIME. IF COMPRESSED AIR IS APPLIED, THE UNIT CAN OPERATE ACCIDENTALLY. THIS CAN CAUSE INJURY TO PERSONNEL AND DAMAGE TO EQUIPMENT.

- (1) Do an external leakage test.
 - (a) Clean around the dynamic rod seal to permit leak detection.
 - (b) Operate the actuator for 25 full cycles.
 - 1) Fully retract the actuator.
 - 2) Apply the minimum hydraulic pressure to the extend port that is necessary to move the piston.
 - 3) Increase the pressure to 3000-3100 psi when the actuator stops at the end of the piston travel and maintain the pressure for 0.5 to 2 seconds.
 - 4) Remove the pressure from the extend port.
 - 5) Change the hydraulic fluid direction.

NOTE: The actuator is in the fully extended position.

32-51-52

TESTING AND FAULT ISOLATION

Page 102

Jul 01/2006



COMPONENT MAINTENANCE MANUAL

- 6) Apply the minimum hydraulic pressure to the retract port that is necessary to move the piston.
- 7) Increase the pressure to 3000-3100 psi when the actuator stops at the end of the piston travel and maintain the pressure for 0.5 to 2 seconds.
- 8) Remove the pressure from the retract port.
- 9) Do steps 1-8 for 25 full cycles.
- (c) After 25 cycles, do a visual check for leakage around the dynamic rod seal.
 - 1) Recommended leakage is zero.
 - 2) The leakage limit for the rod seal is 2 drops.
 - 3) The leakage limit for static seals is zero.
- (2) Do an internal leakage test.
 - (a) Fully extend the rod.
 - (b) Remove the hydraulic line from the retract port.
 - (c) Apply 2900-3100 psi to the extend port for a minimum of 1 minute.
 - (d) Do a visual check for leakage from the open retract port:
 - 1) Recommended leakage is zero.
 - 2) The leakage limit is 2 drops per minute.
 - (e) Apply 100 psi to the extend port of a minimum of 1 minute.
 - (f) Do a visual check for leakage from the open retract port:
 - 1) Recommended leakage is zero.
 - 2) The leakage limit is 2 drops per minute.
 - (g) Remove the pressure from the extend port.
 - (h) Attach the hydraulic line to the retract port.
 - (i) Fully retract the rod.
 - (j) Remove the hydraulic line from the extend port.
 - (k) Apply 2900-3100 psi to the retract port for a minimum of 1 minute.
 - (l) Do a visual check for leakage from the open extend port.
 - 1) Recommended leakage is zero.
 - 2) The leakage limit is 2 drops per minute.
 - (m) Apply 100 psi to the retract port of a minimum of 1 minute.
 - (n) Do a visual check for leakage from the open extend port.
 - 1) Recommended leakage is zero.
 - 2) The leakage limit is 2 drops per minute.
 - (o) Remove the pressure from the retract port.
 - (p) Attach the hydraulic line to the extend port.
- (3) Do a seal friction test.
 - (a) Retract the actuator rod fully.

32-51-52

TESTING AND FAULT ISOLATION

Page 103

Jul 01/2006



COMPONENT MAINTENANCE MANUAL

- (b) Apply no pressure to the retract port.
- (c) With no load applied to the rod, slowly increase the pressure to 50 psi maximum at the extend port.
 - 1) The rod must extend fully with a smooth, continuous movement.
- (d) Remove the pressure applied to the extend port.
- (e) Make sure the rod is fully extended.
- (f) Apply no pressure to the extend port.
- (g) With no load applied to the rod, slowly increase the pressure to 50 psi maximum at retract port.
 - 1) The rod must retract fully with a smooth, continuous movement.
- (h) Remove the pressure applied to the retract port.
- (4) Do a proof pressure test.
 - (a) Retract the actuator rod fully.

CAUTION: DO NOT EXTEND OR RETRACT THE PISTON AT PROOF PRESSURE (4500-4700 PSI).

- (b) Apply 4500-4700 psi pressure to the retract port for a minimum of 1 minute.
- (c) Make sure there is no sign of external leakage or permanent damage to the actuator.
- (d) Remove the pressure from the retract port.
- (e) Extend the actuator rod fully.
- (f) Apply 4500-4700 psi pressure to the extend port for a minimum of 1 minute.
- (g) Make sure there is no sign of external leakage or permanent damage to the actuator.
- (h) Remove the pressure from the extend port.
- (5) Make sure that the actuator has an extend dimension of 13.5309-13.6309 inches and a retract length of 5.6525-5.8158 inches between the centerline of the trunnion and the centerline of the rod end bearing.
- (6) Remove the actuator from the holding fixture.
- (7) Lockwire the bearing (15) to the trunnion assembly (40), and lockwire the nut (35) to the key (37A) using lockwire, G01912. Use the double-twist method (SOPM 20-50-02).
- (8) Fill the unit with hydraulic fluid, D00153 and install the shipping caps.

3. Fault Isolation

- A. Refer to the TESTING AND FAULT ISOLATION, Table 101 for causes of the problems found and the procedures to correct them.

32-51-52

TESTING AND FAULT ISOLATION

Page 104

Jul 01/2006



COMPONENT MAINTENANCE MANUAL

Table 101: Fault Isolation Chart

TROUBLE	PROBABLE CAUSE	CORRECTIONS
Too much leakage at the rod end assembly	Defective scraper (55B), seal (60), rings (65B), seal (70A) or rings (75A)	Disassemble and replace the parts as shown in TESTING AND FAULT ISOLATION, Paragraph 4.A. and TESTING AND FAULT ISOLATION, Paragraph 4.B..
Too much internal leakage	Defective seal (80) or rings (85B), or scored barrel (130)	Disassemble and replace the parts as shown in TESTING AND FAULT ISOLATION, Paragraph 4.A. and TESTING AND FAULT ISOLATION, Paragraph 4.B..
Movement of the rod assembly not smooth	Defective piston (90), bearing (15), cylinder (130) or trunnion assembly (40)	Disassemble and replace the parts as shown in TESTING AND FAULT ISOLATION, Paragraph 4.A. and TESTING AND FAULT ISOLATION, Paragraph 4.B..
	Dirt or unwanted matter in the cylinder	Disassemble and clean the parts.

4. Fault Correction

A. Procedure

- (1) Drain all the hydraulic fluid from the unit.
- (2) Replacement of scraper (55B), seal (60), rings (65B), packing (70A) and rings (75A):
 - (a) Remove the rod end assembly (100A) from piston (90). Remove rod end (110A) and cup lockwasher (95A) from piston (90).
 - (b) Remove the gland (15) from trunnion assembly (40).
 - (c) Remove the scraper (55B), seal (60), rings (65B), gland (15), packing (70A) and rings (75A).
 - (d) Replace parts as necessary.
 - (e) Install gland (15) with packing (70A) and rings (75A), scraper (55B), rings (65B), seal (60), and cup lockwasher (95) on piston (90). Push these parts back into trunnion assembly (40).
 - (f) Install gland (15) in trunnion assembly (40). Install cup lockwasher (95) and rod end assembly (100A) on piston (90) as shown in ASSEMBLY. Do the test again to see if the problem was corrected.
- (3) Replacement of piston seal (80) and rings (85B).
 - (a) Do steps TESTING AND FAULT ISOLATION, Paragraph 4.A.(1), TESTING AND FAULT ISOLATION, Paragraph 4.A.(2).
 - (b) Remove piston (90) from cylinder (130).
 - (c) Replace defective seal (80) and rings (85B).
 - (d) Install piston (90) in cylinder (130).
 - (e) Do steps TESTING AND FAULT ISOLATION, Paragraph 4.A.(1), TESTING AND FAULT ISOLATION, Paragraph 4.A.(2).

B. Replacement of piston (90) or cylinder (130).

- (1) Drain the hydraulic fluid from the actuator.

32-51-52

TESTING AND FAULT ISOLATION

Page 105

Jul 01/2006



COMPONENT MAINTENANCE MANUAL

- (2) Disassemble the actuator (DISASSEMBLY).
- (3) Replace the defective parts.
- (4) Assemble the actuator (ASSEMBLY).
- (5) Test as shown in TESTING AND FAULT ISOLATION, Paragraph 2.G..

32-51-52

TESTING AND FAULT ISOLATION

Page 106

Jul 01/2006



COMPONENT MAINTENANCE MANUAL

DISASSEMBLY

1. General

- A. This procedure has the data necessary to disassemble the nose gear steering actuator assembly.
- B. Disassemble this component sufficiently to isolate the defects, do the necessary repairs, and put the component back to a serviceable condition.
- C. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- D. Refer to IPL Figure 1 for item numbers.

2. Disassembly

A. Tools/Equipment

NOTE: Equivalent substitutes may be used.

Reference	Description
SPL-5401	NLG Actuator Assembly Removal/Installation Fixture Equipment (Part #: C32036-45, Supplier: 81205)

B. General

- (1) To disassemble the actuator, it is necessary to hold the actuator in the holding fixture.

C. Part Replacement

NOTE: The parts which follow are recommended for replacement. Unless a procedure tells you to replace a part, replacement is optional.

- (1) Packings, O-rings and seals (25, 60, 67, 70A, 80, 140, 160)
- (2) Scraper (55B)
- (3) Backup rings (30, 65B, 68, 75A, 85B, 155)

NOTE: Do not remove pin (45B), plug (47) unless necessary to stop a leak here or to clean the area.

D. Procedure

- (1) Use standard industry procedures and the steps shown below to disassemble this component.
- (2) Install the actuator in the Removal/Installation Fixture Equipment, SPL-5401.
- (3) Remove the lockwire from the nut (35) and the key (37A).
- (4) Loosen the transfer tube assembly (165) on the union (145).
- (5) Move the transfer tube assembly (165) into the trunnion assembly (40) until it is clear of the cylinder (130).
- (6) Loosen the nut (35) with the spanner wrench.
- (7) Remove the key (37A) from the trunnion assembly (40).
- (8) Turn the cylinder (130) to remove it from the trunnion assembly (40) and the piston (90).
- (9) Turn the nut (35) to remove it from the cylinder (130).
- (10) Remove the transfer tube assembly (165), the union (145) and the packing (140) from the cylinder (130) and the trunnion assembly (40).
- (11) Remove the piston seal (80) and the backup rings (85B) from the piston (90).

32-51-52

DISASSEMBLY

Page 301

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

- (12) Remove the packing (67, 160) and the backup rings (68, 155) from the trunnion assembly (40).
- (13) Install the piston (90) and the attached items in the torque adapter.
- (14) Bend the tab of the lockwasher cup (95A) to release the rod end assembly (100A).
- (15) Loosen the rod end assembly (100A) on the piston (90).
- (16) Loosen the bearing (15) in the trunnion assembly (40).
- (17) Turn the rod end assembly (100A) to remove it from the piston (90).
- (18) Remove the lockwasher cup (95A) from the rod end assembly (100A).
- (19) Remove the piston (90) from the trunnion assembly (40).
- (20) Remove the scraper (55B), the seal (60) and the backup rings (65B) from the bearing (15).
- (21) Turn the bearing (15) to remove it from the trunnion assembly (40).
- (22) Remove the packing (70A) and the backup rings (75A) from the bearing (15).
- (23) Remove the transfer tubes (20) from the trunnion assembly (40).
- (24) Remove the packing (25) and backup rings (30) from the transfer tubes (20).

32-51-52

DISASSEMBLY

Page 302

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

CLEANING

1. General

- A. This procedure has the data necessary to clean the nose gear steering actuator assembly.
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.

2. Cleaning

A. References

Reference	Title
SOPM 20-30-01	CLEANING AND RELUBRICATING BEARINGS
SOPM 20-30-03	GENERAL CLEANING PROCEDURES

B. Procedure

- (1) Clean the bearings (105) as specified in SOPM 20-30-01.
- (2) Clean the other parts by standard industry procedures and the instructions in SOPM 20-30-03.

32-51-52

CLEANING

Page 401

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

CHECK

1. General

- A. This procedure has the data necessary to find defects in the material of the specified parts.
- B. Refer to FITS AND CLEARANCES for the design dimension and wear limits.
- C. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- D. Refer to IPL Figure 1 for item numbers.

2. Check

A. References

Reference	Title
SOPM 20-20-01	MAGNETIC PARTICLE INSPECTION
SOPM 20-20-02	PENETRANT METHODS OF INSPECTION

B. Procedure

- (1) Use standard industry procedures to do a visual check of all the parts for defects.
- (2) Do a magnetic particle check (SOPM 20-20-01) of these parts:
 - (a) Transfer tube (20)
 - (b) Nut (35)
 - (c) Trunnion (50)
 - (d) Piston (90)
 - (e) Rod end (110A, 110B)
 - (f) Cylinder (130)
 - (g) Tube (175)
 - (h) Key (37A)
- (3) Do a penetrant check (SOPM 20-20-02) of these parts:
 - (a) Bearing (15)

32-51-52

CHECK

Page 501

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

REPAIR

1. General

- A. Instructions for repair, refinish, and replacement of the specified subassembly parts are included in each REPAIR when applicable:

Table 601:

PART NUMBER	NAME	REPAIR
—	REFINISH OF OTHER PARTS	1-1
273A2122	TRANSFER TUBE ASSEMBLY	2-1
273A2508	NAMEPLATE	3-1
275A1102	CYLINDER	4-1
275A1103	PISTON	5-1
275A1104	TRUNNION ASSEMBLY	6-1
275A1105	BEARING, ROD GLAND	7-1
275A1106	ROD END ASSEMBLY	8-1, 8-2
275A1107	NUT, CYLINDER RETAINING	9-1
275A1108	TRANSFER TUBE	10-1

2. Dimensioning Symbols

- A. Standard True Position Dimensioning Symbols used in the applicable repair procedures are shown in SOPM 20-00-00.

32-51-52

REPAIR - GENERAL

Page 601

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

REFINISH OF OTHER PARTS - REPAIR 1-1

1. General

- A. This procedure has the data necessary to refinish the parts which are not given in the specified repairs.
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.

2. Refinish of other parts

A. References

Reference	Title
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

B. Procedure

NOTE: For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Refer to REPAIR 1-1, Table 601 for refinish details.

Table 601: Refinish Details

IPL FIG. & ITEM	MATERIAL	FINISH
IPL Fig. 1		
Bearing (97)	Al-Ni-Bronze	No finish (F-25.01).

32-51-52

REPAIR 1-1

Page 601

Jul 01/2006



COMPONENT MAINTENANCE MANUAL

TRANSFER TUBE ASSEMBLY - REPAIR 2-1

273A2122-5

1. General

- A. This procedure has the data necessary to repair and refinish the transfer tube assembly (165).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.
- D. General repair details:
 - (1) Material: Steel tubing 21-6-9

2. Transfer Tube Assembly Refinish

A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

B. Procedure (REPAIR 2-1, Figure 601)

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Passivate (F-17.25).
- (2) Chrome plate (F-15.43, which replaces F-14.892) the area shown.


32-51-52

REPAIR 2-1

Page 601

Jul 01/2006

COMPONENT MAINTENANCE MANUAL



1 CHROME PLATE (F-15.43, WHICH REPLACES F-14.892) THIS AREA, 0.0005-0.0007 THICK

2 CHROME PLATE RUNOUT AREA

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 1

ALL DIMENSIONS ARE IN INCHES

273A2122-5 Transfer Tube Assembly Repair and Refinish
Figure 601

32-51-52

REPAIR 2-1

Page 602

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

NAMEPLATE INSTALLATION - REPAIR 3-1

273A2508-4

1. General

- A. This repair has instructions for the replacement of the nameplate (180).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices shown in the repair.
- C. Refer to IPL Figure 1 for item numbers.

2. Nameplate Replacement

A. References

Reference	Title
SOPM 20-50-21	HOW TO INSTALL NAMEPLATE STRAPS AND SEALS

B. General

- (1) Use a new strap (130) each time you install the nameplate (180).

C. Procedure

- (1) Install a replacement nameplate (180) as shown in SOPM 20-50-21.

32-51-52

REPAIR 3-1

Page 601

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

CYLINDER - REPAIR 4-1

275A1102-1

1. General

- A. This procedure has the data necessary to repair and refinish the cylinder (130).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.
- D. General repair details:
 - (1) Material: 15-5PH CRES, AMS 5659, 180-200 ksi
 - (2) Shot peen: As shown Intensity 0.008-0.013A2

2. Cylinder Repair

A. References

Reference	Title
SOPM 20-10-01	REPAIR AND REFINISH OF HIGH STRENGTH STEEL PARTS
SOPM 20-10-02	MACHINING OF ALLOY STEEL
SOPM 20-10-03	SHOT PEENING
SOPM 20-10-04	GRINDING OF CHROME PLATED PARTS
SOPM 20-20-01	MAGNETIC PARTICLE INSPECTION
SOPM 20-42-03	HARD CHROME PLATING

B. Procedure (REPAIR 4-1, Figure 601)

- (1) Machine as required (SOPM 20-10-01 and SOPM 20-10-02), within the repair limits, to remove any defects.
- (2) Do a magnetic particle check (SOPM 20-20-01).
- (3) Shot peen the surfaces (SOPM 20-10-03).
- (4) Build up with chrome plate (SOPM 20-42-03) and grind to design dimensions and finish (SOPM 20-10-04).
- (5) Do a magnetic particle check (SOPM 20-20-01).

3. Cylinder Refinish

A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-60-03	LUBRICANTS

B. Procedure (REPAIR 4-1, Figure 601)

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01. For lubricants, refer to SOPM 20-60-03.

32-51-52

REPAIR 4-1

Page 601

Nov 01/2006



COMPONENT MAINTENANCE MANUAL

- (1) Passivate (F-17.25).
- (2) Apply solid film lubricant (F-19.10) as shown.


32-51-52

REPAIR 4-1

Page 602

Jul 01/2006

COMPONENT MAINTENANCE MANUAL



275A1102-1 Cylinder Repair and Refinish
Figure 601 (Sheet 1 of 2)

32-51-52

REPAIR 4-1
Page 603
Mar 01/2006



COMPONENT MAINTENANCE MANUAL

REFERENCE NUMBER	[1]	[2]
DESIGN DIMENSION	2.873 2.871	2.620 2.618
REPAIR LIMIT 3	2.843	2.648

1 DO NOT SHOT PEEN THIS AREA

2 APPLY SOLID FILM LUBRICANT (F-19.10) (F-19.81 OR F-19.82 OPTIONAL) TO THE THREADS. OVERSPRAY IS PERMITTED

3 LIMIT FOR CHROME PLATE BUILDUP (SOPM 20-42-03) AND GRIND (SOPM 20-10-04) TO DESIGN DIMENSIONS AND FINISH

125 ✓ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 1

ALL DIMENSIONS ARE IN INCHES

275A1102-1 Cylinder Repair and Refinish
Figure 601 (Sheet 2 of 2)

32-51-52

REPAIR 4-1

Page 604

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

PISTON - REPAIR 5-1

275A1103-1, -2

1. General

- A. This procedure has the data necessary to repair and refinish the piston (90).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.
- D. General repair details:
 - (1) Material: 15-5PH CRES, AMS 5659, 180-200 ksi
 - (2) Shot peen: All surfaces, unless shown, Intensity 0.008-0.013A2
 - (3) Make sure the edges of the slot are not sharp.

2. Piston Repair and Refinish

A. References

Reference	Title
SOPM 20-10-01	REPAIR AND REFINISH OF HIGH STRENGTH STEEL PARTS
SOPM 20-10-02	MACHINING OF ALLOY STEEL
SOPM 20-10-03	SHOT PEENING
SOPM 20-10-04	GRINDING OF CHROME PLATED PARTS
SOPM 20-20-01	MAGNETIC PARTICLE INSPECTION
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-42-03	HARD CHROME PLATING

B. Procedure (REPAIR 5-1, Figure 601)

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

(1) Repair

- (a) Machine as required, within repair limits to remove defects (SOPM 20-10-01 and SOPM 20-10-02).
- (b) Do a magnetic particle check (SOPM 20-20-01).
- (c) Shot peen the surfaces (SOPM 20-10-03).
- (d) Build up with chrome plate (SOPM 20-42-03) and grind to design dimensions (SOPM 20-10-04).

(2) Refinish

- (a) Passivate (F-17.25); chrome plate the surfaces shown.


32-51-52

REPAIR 5-1

Page 601

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



REFERENCE NUMBER	[1]	[2]	[3]
DESIGN DIMENSION	2.615 2.613	1.185 1.183	2.246 2.244
REPAIR LIMIT [6]	2.585	1.155	----

- [1] CHROME PLATE (F-15.34) AND GRIND TO DESIGN DIMENSIONS AND FINISH
- [2] NO SHOT PEEN IN THIS AREA
- [3] CHROME PLATE RUNOUT IN THIS AREA
- [4] 275A1103-1
- [5] 275A1103-2
- [6] LIMIT FOR CHROME PLATE BUILDUP (SOPM 20-42-03) AND GRIND (SOPM 20-10-04) TO DESIGN DIMENSIONS AND FINISH

- 125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY
- BREAK ALL SHARP EDGES
- ITEM NUMBERS REFER TO IPL FIG. 1
- ALL DIMENSIONS ARE IN INCHES

275A1103-1,-2 Piston Repair and Refinish
Figure 601 (Sheet 2 of 2)

32-51-52

REPAIR 5-1
Page 603
Jul 01/2006



COMPONENT MAINTENANCE MANUAL

TRUNNION ASSEMBLY - REPAIR 6-1

275A1104-1, -3, -5, -6, -9, -10

1. General

- A. This procedure tells how to repair and refinish the trunnion assembly (40).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.
- D. General repair details:
 - (1) Material: 15-5PH CRES, AMS 5659, 180-200 ksi
 - (2) Shot peen: Surfaces as noted, Intensity 0.014-0.019A2

2. Trunnion Assembly Repair

A. References

Reference	Title
SOPM 20-10-01	REPAIR AND REFINISH OF HIGH STRENGTH STEEL PARTS
SOPM 20-10-02	MACHINING OF ALLOY STEEL
SOPM 20-10-03	SHOT PEENING
SOPM 20-10-04	GRINDING OF CHROME PLATED PARTS
SOPM 20-20-01	MAGNETIC PARTICLE INSPECTION
SOPM 20-42-03	HARD CHROME PLATING
SOPM 20-50-04	INSTALLATION OF PERMANENT PINS AND PLUGS IN DRILL PASSAGES

B. Procedure (REPAIR 6-1, Figure 601)

- (1) Plug (47) and pin (45A) replacement – Install replacements per SOPM 20-50-04.
- (2) Trunnion (50)
 - (a) Machine as required, within repair limits, to remove defects (SOPM 20-10-01 and SOPM 20-10-02). On the old trunnions 275A1104-1, -3 increase the fillet radius to the 0.05-0.07-inch value, with an undercut, as shown for the later trunnions, to let the shot get into the radius. You can then change the part number of the trunnion to 275A1104-5, -6.
 - (b) Do a magnetic particle check (SOPM 20-20-01).
 - (c) Shot peen machined surfaces (SOPM 20-10-03).
 - (d) Build up with chrome plate (SOPM 20-42-03) to design dimensions and grind (SOPM 20-10-04) to design dimensions and finish.
 - (e) Do a magnetic particle check (SOPM 20-20-01).

32-51-52

REPAIR 6-1

Page 601

Mar 01/2008



COMPONENT MAINTENANCE MANUAL

3. Trunnion Assembly Refinish

A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

B. Procedure (REPAIR 6-1, Figure 601)

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Passivate (F-17.25) the trunnion (50).
- (2) On trunnions 275A1104-9, -10, chrome plate as indicated.


32-51-52

REPAIR 6-1


Page 602

Mar 01/2008

COMPONENT MAINTENANCE MANUAL



275A1104-1,-5,-9 SHOWN
275A1104-3,-6,-10 OPPOSITE




275A1104-1,-3,-5,-6,-9,-10 Trunnion Assembly Repair and Refinish
Figure 601 (Sheet 1 of 6)

32-51-52

REPAIR 6-1
Page 603
Mar 01/2006

COMPONENT MAINTENANCE MANUAL





275A1104-1,-3,-5,-6,-9,-10 Trunnion Assembly Repair and Refinish
Figure 601 (Sheet 2 of 6)

32-51-52

REPAIR 6-1
Page 604
Mar 01/2006

COMPONENT MAINTENANCE MANUAL




275A1104-1,-3,-5,-6,-9,-10 Trunnion Assembly Repair and Refinish
Figure 601 (Sheet 3 of 6)

32-51-52


REPAIR 6-1
Page 605
Mar 01/2006

COMPONENT MAINTENANCE MANUAL




275A1104-1,-3

(C)



275A1104-5,-6

(C)



275A1104-9,-10


(C)

275A1104-1,-3,-5,-6,-9,-10 Trunnion Assembly Repair and Refinish
Figure 601 (Sheet 4 of 6)

32-51-52


REPAIR 6-1
Page 606
Mar 01/2006

COMPONENT MAINTENANCE MANUAL



275A1104-9,-10

D



275A1104-9,-10

E

275A1104-1,-3,-5,-6,-9,-10 Trunnion Assembly Repair and Refinish
Figure 601 (Sheet 5 of 6)

32-51-52


REPAIR 6-1

Page 607

Mar 01/2006



COMPONENT MAINTENANCE MANUAL



C-C

REFERENCE NUMBER	[1]	[2]	[3]	[4]	[5]	[6]	[7]	[8]	[9]	
DESIGN DIMENSION	0.198 0.194	0.198 0.194	1.3735 1.3535	1.7865 1.7765	3.150 3.140	0.253 0.247	0.245 0.235	2.1250 2.1230	1.629 1.625	
REPAIR LIMIT	----	----	----	----	----	----	----	2.0950 1	----	

REFERENCE NUMBER	[10]	[11]	[12]	[13]	[14]
DESIGN DIMENSION	0.615 0.613	1.680 1.678	2.878 2.876	1.747 1.737	1.375 1.373
REPAIR LIMIT	0.643 1	1.708 1	2.906 1	----	1.345 1

1 LIMIT FOR CHROME PLATE BUILDUP (SOPM 20-42-03) AND GRIND (SOPM 20-10-04) TO DESIGN DIMENSIONS AND FINISH

2 CHROME PLATE (F-15.03)

125 ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 1

ALL DIMENSIONS ARE IN INCHES

G44289 S0004999674_V2

275A1104-1,-3,-5,-6,-9,-10 Trunnion Assembly Repair and Refinish
Figure 601 (Sheet 6 of 6)

32-51-52

REPAIR 6-1

Page 608

Mar 01/2008



COMPONENT MAINTENANCE MANUAL

BEARING, ROD GLAND - REPAIR 7-1

275A1105-1

1. General

- A. This procedure has the data necessary to repair and refinish the bearing (15).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.
- D. General repair details:
 - (1) Material: Al-Ni-Bronze, AMS 4640

2. Bearing Refinish

- A. References

<u>Reference</u>	<u>Title</u>
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

- B. Procedure (REPAIR 7-1, Figure 601)

NOTE: For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Apply no finish (F-25.01). You can use a temporary protection for transportation and storage.


32-51-52

REPAIR 7-1

Page 601

Jul 01/2006

COMPONENT MAINTENANCE MANUAL



125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 1

ALL DIMENSIONS ARE IN INCHES

275A1105-1 Bearing - Rod Gland Repair
Figure 601

32-51-52

REPAIR 7-1

Page 602

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

ROD END ASSEMBLY - REPAIR 8-1

275A1106-3, -5

1. General

- A. This procedure has the data necessary to replace the parts of the rod end assembly (100A, 100B).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.

2. Bearing Replacement (275A1106-3)

- A. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
D00015	Grease - Aircraft Bearing (Use BMS 3-24 until existing stocks are depleted, BMS 3-33 supersedes BMS 3-24)	BMS3-24 (Superseded by BMS 3-33)
D00633	Grease - Aircraft General Purpose	BMS3-33

- B. References

Reference	Title
SOPM 20-50-03	BEARING AND BUSHING REPLACEMENT
SOPM 20-60-03	LUBRICANTS

- C. Procedure (REPAIR 8-1, Figure 601)

NOTE: For lubricants, refer to SOPM 20-60-03.

- (1) Remove the bearing (105) from the rod end (110A).
- (2) If you find defects on the rod end, refer to REPAIR 8-2 for repair instructions.
- (3) Install a replacement bearing with grease, D00633 or grease, D00015 (SOPM 20-50-03) on the mating surfaces.
- (4) Roller swage (SOPM 20-50-03) the bearing on each side.

3. Lube Fitting Replacement (275A1106-5)

- A. Procedure (REPAIR 8-1, Figure 602)

- (1) Remove the old lube fittings (107).
- (2) Install replacement lube fittings.



32-51-52

REPAIR 8-1

Page 601

Jul 01/2008

COMPONENT MAINTENANCE MANUAL




ROLLER SWAGE

275A1106-3 Rod End Assembly Bearing Replacement
Figure 601

32-51-52

REPAIR 8-1
Page 602
Mar 01/2006

COMPONENT MAINTENANCE MANUAL



275A1106-5 Rod End Assembly Lube Fitting Replacement
Figure 602

32-51-52

REPAIR 8-1

Page 603

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

ROD END - REPAIR 8-2

275A1106-4, -6

1. General

- A. This procedure has the data necessary to repair and refinish the rod end (110A, 110B).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.
- D. General repair details:
 - (1) Material: 15-5PH CRES, AMS 5659, 180-200 ksi

2. Rod End Refinish

- A. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
D00113	Lubricant - Liquid Dispersed Solid Film Lubricant	BMS3-8, BAC 5811, TYPE VIII

- B. References

Reference	Title
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-50-08	APPLICATION OF BONDED SOLID FILM LUBRICANTS
SOPM 20-60-03	LUBRICANTS

- C. Procedure (REPAIR 8-2, Figure 601 and REPAIR 8-2, Figure 602)



NOTE: For the decoding table for Boeing finish codes, refer to SOPM 20-41-01. For lubricants, refer to SOPM 20-60-03.

- (1) Passivate (F-17.25, which replaces F-17.09).
- (2) Apply lubricant, D00113 (SOPM 20-50-08) (F-19.10) (F-19.81 or F-19.82 optional) to the threads, as shown.

32-51-52

REPAIR 8-2
Page 601
Jul 01/2006

COMPONENT MAINTENANCE MANUAL



A-A

- 1 DO NOT SHOT PEEN THIS AREA
- 2 APPLY SOLID FILM LUBRICANT (F-19.10) (F-19.81 OR F-19.82 OPTIONAL) TO THIS AREA

125 ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 1

ALL DIMENSIONS ARE IN INCHES

275A1106-4 Rod End Repair
Figure 601


32-51-52

REPAIR 8-2

Page 602

Mar 01/2006

COMPONENT MAINTENANCE MANUAL



125 ✓ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ALL DIMENSIONS ARE IN INCHES

275A1106-6 Rod End Repair
Figure 602

32-51-52

REPAIR 8-2

Page 603

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

NUT - REPAIR 9-1

275A1107-1

1. General

- A. This procedure has the data necessary to refinish the nut (35).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.
- D. General repair details:
 - (1) Material: 15-5PH CRES, AMS 5659, 180-200 ksi

2. Nut Refinish

- A. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
D00113	Lubricant - Liquid Dispersed Solid Film Lubricant	BMS3-8, BAC 5811, TYPE VIII

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-50-08	APPLICATION OF BONDED SOLID FILM LUBRICANTS
SOPM 20-60-03	LUBRICANTS

- C. Procedure (REPAIR 9-1, Figure 601)

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For decoding table for Boeing finish codes, refer to SOPM 20-41-01. For lubricants, refer to SOPM 20-60-03.



- (1) Passivate (F-17.25).
- (2) Apply lubricant, D00113 (SOPM 20-50-08) (F-19.10) (F-19.81 or F-19.82 optional) to the surfaces shown.

32-51-52

REPAIR 9-1
Page 601
Jul 01/2006



COMPONENT MAINTENANCE MANUAL



1 APPLY SOLID FILM LUBRICANT (F-19.10) (F-19.81 OR F-19.82 OPTIONAL) THIS SURFACE. OVERSPRAY PERMITTED

125 ✓ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 1

ALL DIMENSIONS ARE IN INCHES

275A1107-1 Nut Refinish
Figure 601

32-51-52

REPAIR 9-1

Page 602

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

TRANSFER TUBE - REPAIR 10-1

275A1108-1

1. General

- A. This procedure has the data necessary to repair and refinish the transfer tube (20).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.
- D. General repair details:
 - (1) Material: 15-5PH CRES, AMS 5659, 150-170 ksi

2. Transfer Tube Refinish

- A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

- B. Procedure (REPAIR 10-1, Figure 601)

NOTE: For stripping of protective finishes, refer to SOPM 20-30-02. For decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Passivate (F-17.25).

32-51-52


REPAIR 10-1

Page 601

Jul 01/2006



COMPONENT MAINTENANCE MANUAL



125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 1

ALL DIMENSIONS ARE IN INCHES

275A1108-1 Transfer Tube Refinish
Figure 601

32-51-52

REPAIR 10-1

Page 602

Mar 01/2006



COMPONENT MAINTENANCE MANUAL

ASSEMBLY

1. General

- A. This procedure has the data necessary to assemble the nose landing gear steering actuator assembly.
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 for item numbers.

2. Assembly

A. Tools/Equipment

NOTE: Equivalent substitutes may be used.

Reference	Description
SPL-5401	NLG Actuator Assembly Removal/Installation Fixture Equipment (Part #: C32036-45, Supplier: 81205)

B. Consumable Materials

NOTE: Equivalent substitutes may be used.

Reference	Description	Specification
D00153	Fluid - Hydraulic, Erosion Arresting, Fire Resistant	BMS3-11 Type IV (interchangeable & intermixable with Type V)
D00633	Grease - Aircraft General Purpose	BMS3-33

C. References

Reference	Title
SOPM 20-50-01	BOLT AND NUT INSTALLATION
SOPM 20-50-02	INSTALLATION OF SAFETYING DEVICES
SOPM 20-60-03	LUBRICANTS

D. Procedure

NOTE: For bolt and nut installation, refer to SOPM 20-50-01. For installation of safety devices, refer to SOPM 20-50-02. For lubricants, refer to SOPM 20-60-03.

- (1) To assemble the actuator, it is necessary to hold the actuator in the holding fixture.
- (2) Use standard industry procedures and the steps shown below to assemble this component.
 - (a) Install the cylinder (130) in the Removal/Installation Fixture Equipment, SPL-5401.
 - (b) Install the piston seal (80) and backup rings (85B) on the piston (90).
 - 1) Lubricate the piston seal (80) with hydraulic fluid, D00153.
 - 2) Install the piston seal (80) and backup rings (85B) on the piston (90).

32-51-52

ASSEMBLY

Page 701

Jul 01/2008



COMPONENT MAINTENANCE MANUAL

- (c) Install the bearing (15) in the trunnion assembly (40).
 - 1) Lubricate the seal (60) with hydraulic fluid, D00153.
 - 2) Install the seal (60) and backup rings (65B) in the bearing (15).
 - 3) Lubricate the packing (70A) with hydraulic fluid, D00153.
 - 4) Install the rings (75A) and the packing (70A) on the bearing (15).
 - 5) Install the bearing (15) in the trunnion assembly (40).
 - 6) Lubricate the scraper (55B) with hydraulic fluid, D00153.
 - 7) Install the scraper (55B) in the bearing (15).
 - 8) Install the packing (67) and backup rings (68) in the trunnion assembly (40).
 - 9) Install the packing (160) and backup rings (155) in the trunnion assembly (40).
- (d) Install the piston (90) in the bearing (15).
- (e) Apply a thin coat of grease, D00633 to the internal threads of the piston (90) lockwasher-face of the rod end (100).
- (f) Install the lockwasher cup (95A) on the rod end assembly (100A).
- (g) Install the rod end assembly (100A) or the rod end (100B) with bearing (97), on the piston (90).
- (h) Put the piston (90), and the attached items, in the torque adapter.
- (i) Tighten the rod end assembly (100A, 100B) to 2200 to 2500 pound-inches.
- (j) Tighten the bearing (15) to 1000 to 1200 pound-inches.
- (k) Break the flange of the lockwasher cup (95A) fully into the slot on the rod end assembly (100A, 100B) that is away from the slot used in the piston (90). Make sure the break is complete.
- (l) Remove the piston (90), and the attached items, from the torque adapter.
- (m) Install the nut (35) on the cylinder (130).
- (n) Continue to turn the nut on the cylinder. The internal threads of the nut (35) must start to come off the far end of the cylinder (130) threads.
- (o) Install the transfer tube (165) into the trunnion assembly (40) until it stops.
- (p) Install the packing (140) and the union (145) on the cylinder (130) and tighten the union (145).
- (q) Put the piston (90) into the cylinder (130) and turn the cylinder (130) into the trunnion assembly (40) until it stops at the bottom of the trunnion.
- (r) Turn the cylinder (130) back, less than one turn, to align the keyslots on the cylinder (130) and the trunnion assembly (40) and to align the transfer tube (165) with the union (145) on the cylinder (130).
- (s) Install the key (37A) in the keyslot of the trunnion assembly (40).
- (t) Attach the transfer tube (165) on the union (145).
- (u) Tighten the transfer tube (165).
- (v) Tighten the nut (35) on the cylinder by hand.
- (w) Move the piston rod in and out by hand to make sure it moves freely.

32-51-52

ASSEMBLY

Page 702

Nov 01/2007



COMPONENT MAINTENANCE MANUAL

- (x) Torque the nut (35) to 3000-3200 pound-inches. Optional method: During the functional test, apply 2900-3100 psi to the extend port of the actuator assembly and torque the nut (35) to 1000-1200 pound-inches.
- (y) Install the transfer tubes (20) with the backup rings (30) and the packings (25) in the trunnion assembly (40):
 - 1) Lubricate the packings (25) with hydraulic fluid, D00153.
 - 2) Install the packings (25) and the backup rings (30) on the transfer tubes (20).
 - 3) Install the transfer tubes (20) in the trunnion assembly (40).
- (z) Install the nameplate (180) and strap (125) (REPAIR 3-1) if it is necessary.
- (aa) Do the test of the actuator (TESTING AND FAULT ISOLATION).

32-51-52


ASSEMBLY

Page 703

Jul 01/2006

COMPONENT MAINTENANCE MANUAL

FITS AND CLEARANCES



Fits and Clearances
Figure 801 (Sheet 1 of 2)

32-51-52


FITS AND CLEARANCES

Page 801


Jul 01/2006



COMPONENT MAINTENANCE MANUAL

REF LETTER	REF IPL	DESIGN DIMENSION*				SERVICE WEAR LIMIT*		
	FIG. 1, MATING ITEM NO.	DIMENSION		ASSEMBLY CLEARANCE		DIMENSION		MAXIMUM CLEARANCE
		MIN	MAX	MIN	MAX	MIN	MAX	
[A]	ID 130	2.618	2.620	0.003	0.007	2.612	2.622	0.010
	OD 90	2.613	2.615					
[B]	ID 15	1.187	1.188	0.002	0.005	1.182	1.189	0.007
	OD 90	1.183	1.185					
[C]	ID 105, 107	1.000	1.001	0.001	0.003	0.997	1.002	0.004
	OD 	0.998	0.999					
[D]	ID 50	1.678	1.680	0.002	0.005	1.674	1.681	0.007
	OD 15	1.675	1.676					
[E]	ID 50	0.613	0.615	0.002	0.005	0.609	0.615	0.006
	OD 20	0.610	0.611					
[F]	ID 50	2.876	2.878	0.003	0.007	2.869	2.880	0.011
	OD 130	2.871	2.873					
[G]	OD 50	2.123	2.125			2.120		
[H]	OD 50	1.373	1.375			1.371		
[I]	ID 110B	1.6500	1.6515	0.0010	0.0030			
	OD 107	1.6485	1.6490					

* ALL DIMENSIONS ARE IN INCHES

 PIN 162A1411-1 (INSTALLATION PART)
(CMM 32-21-16)

Fits and Clearances
Figure 801 (Sheet 2 of 2)

32-51-52
FITS AND CLEARANCES
Page 802
Mar 01/2006



COMPONENT MAINTENANCE MANUAL

SPECIAL TOOLS, FIXTURES, AND EQUIPMENT

1. General

A. This section lists the special tools, fixtures, and equipment necessary for maintenance.

NOTE: Equivalent substitutes may be used.

Special Tools

Reference	Description	Part Number	Supplier
SPL-5401	NLG Actuator Assembly Removal/Installation Fixture Equipment	C32036-45	81205
SPL-5405	Adapter-Functional Test, NLG Steering Actuator	C32039-1	81205

Tool Supplier Information

CAGE Code	Supplier Name	Supplier Address
81205	THE BOEING COMPANY	17930 INTERNATIONAL BLVD. SOUTH SEATAC, WA 98188-4321 Telephone: 206-662-6650 Facsimile: 206-662-7145

32-51-52

SPECIAL TOOLS, FIXTURES, AND EQUIPMENT

Page 901

Mar 01/2009



COMPONENT MAINTENANCE MANUAL

ILLUSTRATED PARTS LIST

1. Introduction

- A. The Illustrated Parts List (IPL) contains an illustration and a list of component parts you can repair or replace. The Illustrated Parts Catalog (IPC) shows how to use the Boeing part number system.
- B. This shows how parts are related: The relation of each item to its next higher assembly (NHA) is shown in the NOMENCLATURE column. Use the indenture system that follows:

1	2	3	4	5	6	7
.	Assembly					
.	Attaching parts for assembly					
.	.	Detail parts for assembly				
.	.	Subassembly				
.	.	Attaching parts for subassembly				
.	.	.	Detail parts for subassembly			
.	.	.	Sub-subassembly			
.	.	.	Attaching parts for subassembly			
.	.	.	.	Details parts for sub-subassembly		
						Detail Installation Parts (Included only if installation parts may be sent to the shop as part of assembly)

- C. Each top assembly is given one use code letter (A, B, C, etc.) in the USAGE CODE column. All subsequent component parts in the list can have one or more of the use code letters to show effectivity to top assemblies. A component part without a use code applies to all top assemblies.
- D. An alphabetical letter is added after the item number for optional parts, parts changed by a Service Bulletin, configuration differences (except left-handed and right-handed parts), last engineering releases, and parts added between item numbers in a sequence. The alphabetical letter will not be shown on the illustration for equivalent parts of the same part number.
- E. Color-coded parts are identified with a single digit alpha following the dash number or with "SP" suffix. If the "SP" suffix is used, it represents consolidation of all color codes applicable for a given usage which are not separately listed. Orders for color-coded parts should include the registry number of the airplane for which the parts are ordered.
- F. If a part number is 15 characters long but will not fit in the part number column, the part number will be displayed with a "~" at the end of the line and will be continued on the next line. The "~" denotes that the part number continues on the next line.
- G. Parts changed by a Service Bulletin are shown by PRE SB XXXX and POST SB XXXX added to the NOMENCLATURE column.
- (1) When a new top assembly is added by a Service Bulletin, PRE SB XXXX and POST SB XXXX will be added at the top assembly level only. The configuration differences at the detail part level are shown by use code letters.
- (2) When the top assembly part number is not changed by the Service Bulletin, PRE SB XXXX and POST SB XXXX will be added at the detail level.
- H. Interchangeable Parts

32-51-52

ILLUSTRATED PARTS LIST

Page 1001

Nov 01/2008



COMPONENT MAINTENANCE MANUAL

Optional (OPT)	The part is optional to and interchangeable with other parts that have the same item number.
Replaces, Replaced by and not interchangeable with (REPLACES, REPLACED BY AND NOT INTCHG/W)	The part replaces and is not interchangeable with the initial part.
Replaces, Replaced by (REPLACES, REPLACED BY)	The part replaces and is interchangeable with, or is an alternative to, the initial part.

VENDOR CODES

Code	Name
01673	AIRDROME PRECISION COMPONENTS 3251 E AIRPORT WAY LONG BEACH, CALIFORNIA 90806-2407 FORMERLY AIRDROME PARTS CO
02107	FLOUROCARBON CO OHIO DIV DOVER, OHIO 44622 CANCELLED NO REPLACEMENT FORMERLY SPARTA MANUFACTURING CO
07128	TETRAFLUOR INC 2051 EAST MAPLE AVENUE EL SEGUNDO, CALIFORNIA 90245-5009 FORMERLY ROYAL IND TETRAFLUOR DIV V0667B ENGLEWOOD CALIF
08199	SIERRACIN CORPORATION DBA HARRISON 3020 EMPIRE AVENUE BURBANK, CALIFORNIA 91504-3109 FORMERLY TECHNICAL IND INC OR HARRISON MFG CO DIV AXIAL CORP
09257	BUSAK AND SHAMBAN INC SEALS DIV 2531 BREMER DR PO BOX 176 FORT WAYNE, INDIANA 46801 FORMERLY SHAMBAN, W S AND CO

32-51-52

ILLUSTRATED PARTS LIST

Page 1002

Jul 01/2006



COMPONENT MAINTENANCE MANUAL

Code	Name
11328	<p>Replaced: [V11328] AEROQUIP SEE EATON AEROQUIP V00624 LINAIR ENG A TELEDYNE CO SEE TELEDYNE LINAIR ENGINEERING TELEDYNE INC SEE LINAIR ENGINEERING TELEDYNE LINAIR ENG SEE AEROQUIP CORP LINAIR DIV by Code: Name and Address below 00624: EATON AEROQUIP INC ENGINEERED SYSTEMS DIV 300 S EAST AVE JACKSON, MICHIGAN 49203-1972 FORMERLY AEROQUIP ELBEE PLANT V99879 OR WESTERN PLANT V70128; FORMERLY AEROQUIP AEROSP DIV JACKSON PLANT; FORMERLY V11328 AEROQUIP LINAIR DIV</p>
14798	<p>DEUTSCH CO METAL COMPONENTS DIV 14800 SOUTH FIGUEROA STREET GARDEN, CALIFORNIA 90248-1795 FORMERLY WEATHERHEAD V79470 FOR AEROSPACE PROD V 61498 DEUSCH CO THE DEUTSCH AEROSPACE FITTINGS CO DIV</p>
26303	<p>GREENE TWEED IND INC ADVANTEC DIV 7101 PATTERSON DRIVE PO BOX 5037 GARDEN GROVE, CALIFORNIA 92645-5037 FORMERLY OHIO AIRCRAFT SUPPLIES INC IN INGLEWOOD, CALIFORNIA FORMERLY ADVANTEC DIV OF IFP INC, LOS ANGELES, CA V5P801</p>
26879	<p>CORONADO MFG INC 11069 PENROSE AVENUE SUN VALLEY, CALIFORNIA 90352-2722 FORMERLY CORONADO PLASTICS INC IN BURBANK, CALIFORNIA</p>
30974	<p>AEROFIT PRODUCTS INC 6460 DALE STREET BUENA PARK, CALIFORNIA 90621-3115</p>
50632	<p>KAMATICS CORP SUB OF KAMAN CORP 1335 BLUE HILLS ROAD BLOOMFIELD, CONNECTICUT 06002-1304</p>
5F573	<p>GREENE TWEED AND CO ILP DBA GREENE TWEED AND CO 2075 DETWILER RD KULPSVILLE, PENNSYLVANIA 19443-0305</p>

32-51-52

ILLUSTRATED PARTS LIST
 Page 1003
 Jul 01/2006

**COMPONENT MAINTENANCE MANUAL**

Code	Name
92555	LEE COMPANY 2 PETTIPAUG ROAD PO BOX 424 WESTBROOK, CONNECTICUT 06498-1543
94878	RAYBESTOS-MANHATTAN INC PACIFIC COAST DIV FULLERTON, CALIFORNIA 92631 BUSINESS DISCONTINUED
97820	BUSAK AND SHAMBAN INC BEARING DIV 711 MITCHELL ROAD PO BOX 665 NEWBURY PARK, CALIFORNIA 91320-2214 FORMERLY IN CULVER CITY, CALIF; FORMERLY SHAMBAN W S & CO
97829	SINGER, JOSEPH B. CO PHILADELPHIA, PENNSYLVANIA BUSINESS DISCONTINUED

32-51-52

ILLUSTRATED PARTS LIST

Page 1004

Jul 01/2006



COMPONENT MAINTENANCE MANUAL

NUMERICAL INDEX

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
2-02903-06H		1	170	1
2100-110		1	155	2
2100-111		1	30	8
2100-221		1	75A	2
2100-336		1	68A	2
2270-712-66-21		1	55C	1
273A2122-5		1	165	1
273A2122-6		1	175	1
273A2508-4		1	180	1
273T0050-6		1	125	1
275A1101-3		1	1C	RF
275A1101-4		1	1D	RF
275A1101-5		1	1E	RF
275A1101-6		1	1F	RF
275A1101-7		1	1G	RF
275A1101-8		1	1H	RF
275A1102-1		1	130	1
275A1103-1		1	90	1
275A1103-2		1	90A	1
275A1104-1		1	40	1
275A1104-10		1	40E	1
		1	40J	1
275A1104-11		1	50D	1
275A1104-12		1	50E	1
275A1104-2		1	50	1
275A1104-3		1	40A	1
275A1104-4		1	50A	1
275A1104-5		1	40B	1
		1	40F	1
275A1104-6		1	40C	1
		1	40G	1
275A1104-7		1	50B	1
275A1104-8		1	50C	1
275A1104-9		1	40D	1

32-51-52

ILLUSTRATED PARTS LIST

Page 1005

Mar 01/2007



COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
		1	40H	1
275A1105-1		1	15	1
275A1106-3		1	100A	1
275A1106-4		1	110A	1
275A1106-5		1	100B	1
275A1106-6		1	110B	1
275A1107-1		1	35	1
275A1108-1		1	20	2
275A1111-1		1	37A	1
275A1112-1		1	95A	1
293W2521-20		1	97	1
35235V06		1	170	1
591-21760-952-043		1	60A	1
591-21760-952-0432		1	60C	1
592-33100-952-0432		1	80A	1
5979P33100-042D		1	85C	2
5979R21700-042D		1	65C	2
AFP175V06		1	170	1
AP2097-06H		1	170	1
BACN10YE6N		1	150	1
BACP20AX31		1	47	1
BACP20AX31P		1	45A	1
BACR12BM110		1	155	2
BACR12BM111		1	30	8
BACR12BM221		1	75A	2
BACR12BM336		1	68A	2
BACS13BX06H		1	170	1
BCREF12313		1	60A	1
BCREF12314		1	80A	1
BCREF51149		1	60C	1
C11236-110B		1	155	2
C11236-111B		1	30	8
C11236-221B		1	75A	2
C11236-336B		1	68A	2
DB0S13BX06H		1	170	1

32-51-52

ILLUSTRATED PARTS LIST

Page 1006

Mar 01/2007



COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
KSC135216B		1	105	1
MS15004-1		1	107	2
MS21902-6T		1	145	1
NAS1611-110		1	160	1
NAS1611-110A		1	160A	1
NAS1611-111		1	25	4
NAS1611-111A		1	25A	4
NAS1611-221		1	70A	1
NAS1611-221A		1	70B	1
NAS1611-336		1	67	1
NAS1611-336A		1	67A	1
NAS1612-6		1	140A	1
NAS1612-6A		1	140B	1
PLGA3436020		1	45A	1
PLGA3437020		1	47	1
RMR12BM110		1	155	2
RMR12BM111		1	30	8
RMR12BM221		1	75A	2
RMR12BM336		1	68A	2
S30294-110-1		1	155	2
S30294-111-1		1	30	8
S30294-221-1		1	75A	2
S30294-336-1		1	68A	2
S30855-217H99N		1	60	1
		1	60B	1
S32925-712H99		1	55B	1
S33157-217-99C		1	65B	2
S33157-331-99C		1	85B	2
S34760-331H99N		1	80	1
STF800-110		1	155	2
STF800-111		1	30	8
STF800-221		1	75A	2
STF800-336		1	68A	2
TF450-110A		1	155	2
TF450-111A		1	30	8

32-51-52

ILLUSTRATED PARTS LIST

Page 1007

Mar 01/2007

**COMPONENT MAINTENANCE MANUAL**

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
TF450-221A		1	75A	2
TF450-336A		1	68A	2


32-51-52

ILLUSTRATED PARTS LIST

Page 1008

Mar 01/2007

COMPONENT MAINTENANCE MANUAL



Steering Actuator Assembly - Nose Landing Gear
IPL Figure 1 (Sheet 1 of 2)


32-51-52

ILLUSTRATED PARTS LIST

Page 1009

Mar 01/2007

COMPONENT MAINTENANCE MANUAL



Steering Actuator Assembly - Nose Landing Gear
IPL Figure 1 (Sheet 2 of 2)

32-51-52

ILLUSTRATED PARTS LIST

Page 1010

Mar 01/2007



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
-1A	275A1101-1										
-1B	275A1101-2										
-1C	275A1101-3								A		RF
-1D	275A1101-4								B		RF
-1E	275A1101-5								C		RF
-1F	275A1101-6								D		RF
-1G	275A1101-7								E		RF
-1H	275A1101-8								F		RF
5	BACB30NM3K2										
10	BACW10BP32NAPU										
15	275A1105-1										1
20	275A1108-1										2
25	NAS1611-111										4
-25A	NAS1611-111A										4
30	C11236-111B										8
35	275A1107-1										1
37	295W1714-1										
37A	275A1111-1										1
40	275A1104-1								A		1

-Item not Illustrated

32-51-52

ILLUSTRATED PARTS LIST

Page 1011

Mar 01/2007



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
-40A	275A1104-3		.	TRUNNION ASSY (OPT ITEM 40C)						B	1
-40B	275A1104-5		.	TRUNNION ASSY (OPT ITEM 40, 40H)						A	1
-40C	275A1104-6		.	TRUNNION ASSY (OPT ITEM 40A, 40J)						B	1
-40D	275A1104-9		.	TRUNNION ASSY (OPT ITEM 40F)						C, E	1
-40E	275A1104-10		.	TRUNNION ASSY (OPT ITEM 40G)						D, F	1
-40F	275A1104-5		.	TRUNNION ASSY (OPT ITEM 40D)						C, E	1
-40G	275A1104-6		.	TRUNNION ASSY (OPT ITEM 40E)						D, F	1
-40H	275A1104-9		.	TRUNNION ASSY (OPT ITEM 40B)						A	1
-40J	275A1104-10		.	TRUNNION ASSY (OPT ITEM 40C)						B	1
45	MS21209F1-15L			DELETED							
45A	PLGA3436020		.	PIN (V92555) (SPEC BACP20AX31P)							1
47	PLGA3437020		.	PLUG (V92555) (SPEC BACP20AX31)							1
50	275A1104-2		.	TRUNNION (USED ON ITEM 40)							1
-50A	275A1104-4		.	TRUNNION (USED ON ITEM 40A)							1
-50B	275A1104-7		.	TRUNNION (USED ON ITEM 40B, 40F)							1
-50C	275A1104-8		.	TRUNNION (USED ON ITEM 40C, 40G)							1
-50D	275A1104-11		.	TRUNNION (USED ON ITEM 40D, 40H)							1
-50E	275A1104-12		.	TRUNNION (USED ON ITEM 40E, 40J)							1
55	S32925-12H99			DELETED							

-Item not Illustrated

32-51-52

ILLUSTRATED PARTS LIST

Page 1012

Mar 01/2007



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
-55A	2270-12-66-21										
55B	S32925-712H99										1
-55C	2270-712-66-21										1
60	S30855-217H99N										1
-60A	BCREF12313										1
-60B	S30855-217H99N										1
-60C	BCREF51149										1
65	S33157-217-99										
-65A	5979R21700-043D										
65B	S33157-217-99C										2
-65C	5979R21700-042D										2
67	NAS1611-336										1
-67A	NAS1611-336A										1
68	BACR10BM336										

-Item not Illustrated



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
68A	2100-336		.								2
70	NAS1611-331										
70A	NAS1611-221		.								1
-70B	NAS1611-221A		.								1
75	BACR12BM331										
75A	C11236-221B		.								2
80	S34760-331H99N		.								1
-80A	BCREF12314		.								1
85	S33157-331-99										
-85A	5979P33100-043D										
85B	S33157-331-99C		.								2
-85C	5979P33100-042D		.								2
90	275A1103-1		.								1
-90A	275A1103-2		.								1

-Item not Illustrated

32-51-52

ILLUSTRATED PARTS LIST

Page 1014

Mar 01/2007



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
-90B	275A1103-1										
95	66-12156-4										
95A	275A1112-1										1
97	293W2521-20								E, F		1
100	275A1106-1										
100A	275A1106-3								A-D		1
100B	275A1106-5								E, F		1
105	KSC135216B										1
107	MS15004-1										2
110	275A1106-2										
110A	275A1106-4										1
110B	275A1106-6										1
115	PLGA3436020										
120	PLGA3437020										
125	273T0050-6										1
130	275A1102-1										1
135	273A2508-4										
140	NAS1612-06										
140A	NAS1612-6										1
-140B	NAS1612-6A										1
145	MS21902-6T										1
150	BACN10YE6N										1

-Item not Illustrated

32-51-52

ILLUSTRATED PARTS LIST

Page 1015

Mar 01/2007



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY		
			1	2	3	4	5	6	7				
1- 155	C11236-110B		.	R	I	N	G	-	B	A	C	U	2
				(V26879)	(SPEC BACR12BM110)	(OPT RMR12BM110 (V94878))	(OPT STF800-110 (V02107))	(OPT S30294-110-1 (V97820))	(OPT TF450-110A (V07128))	(OPT 2100-110 (V26303))			
160	NAS1611-110		.	P	A	C	K	I	N	G			1
				(OPT ITEM 160A)									
-160A	NAS1611-110A		.	P	A	C	K	I	N	G			1
				(OPT ITEM 160)									
165	273A2122-5		.	T	U	B	E	A	S	S	-	T	1
				R	A	N	S	F	E	R			
170	DB0S13BX06H		.	.	S	L	E	E	V	E			1
				(V14798)	(SPEC BACS13BX06H)	(OPT 2-02903-06H (V11328))	(OPT 35235V06 (V08199))	(OPT AP2097-06H (V01673))	(OPT AFP175V06 (V30974))				
175	273A2122-6		.	.	T	U	B	E					1
180	273A2508-4		.	N	A	M	E	P	L	A	T	E	1

-Item not Illustrated

32-51-52

ILLUSTRATED PARTS LIST

Page 1016

Mar 01/2007