



**COMPONENT MAINTENANCE  
MANUAL  
WITH  
ILLUSTRATED PARTS LIST**

**MID EXIT DOOR ASSEMBLY**

**PART NUMBER  
146A6200-1**

**BOEING PROPRIETARY, CONFIDENTIAL, AND/OR TRADE SECRET**

Copyright © 1995 The Boeing Company  
Unpublished Work - All Rights Reserved

Boeing claims copyright in each page of this document only to the extent that the page contains copyrightable subject matter. Boeing also claims copyright in this document as a compilation and/or collective work.

This document includes proprietary information owned by The Boeing Company and/or one or more third parties. Treatment of the document and the information it contains is governed by contract with Boeing. For more information, contact The Boeing Company, P.O. Box 3707, Seattle, Washington 98124.

Boeing, the Boeing signature, the Boeing symbol, 707, 717, 727, 737, 747, 757, 767, 777, 787, Dreamliner, BBJ, DC-8, DC-9, DC-10, KC-10, KDC-10, MD-10, MD-11, MD-80, MD-88, MD-90, P-8A, Poseidon and the Boeing livery are all trademarks owned by The Boeing Company; and no trademark license is granted in connection with this document unless provided in writing by Boeing.

PUBLISHED BY BOEING COMMERCIAL AIRPLANES GROUP, SEATTLE, WASHINGTON, USA  
A DIVISION OF THE BOEING COMPANY  
PAGE DATE: Jul 01/2009

**52-21-03**

Page 1  
Jul 01/2009



## COMPONENT MAINTENANCE MANUAL

Revision No. 5  
Jul 01/2009

To: All holders of MID EXIT DOOR ASSEMBLY 52-21-03.

Attached is the current revision to this COMPONENT MAINTENANCE MANUAL

The COMPONENT MAINTENANCE MANUAL is furnished either as a printed manual, on microfilm, or digital products, or any combination of the three. This revision replaces all previous microfilm cartridges or digital products. All microfilm and digital products are reissued with all obsolete data deleted and all updated pages added.

For printed manuals, changes are indicated on the List of Effective Pages (LEP). The pages which are revised will be identified on the LEP by an R (Revised), A (Added), O (Overflow, i.e. changes to the document structure and/or page layout), or D (Deleted). Each page in the LEP is identified by Chapter-Section-Subject number, page number and page date.

Pages replaced or made obsolete by this revision should be removed and destroyed.

### ATTENTION

IF YOU RECEIVE PRINTED REVISIONS, PLEASE VERIFY THAT YOU HAVE RECEIVED AND FILED THE PREVIOUS REVISION. BOEING MUST BE NOTIFIED WITHIN 30 DAYS IF YOU HAVE NOT RECEIVED THE PREVIOUS REVISION. REQUESTS FOR REVISIONS OTHER THAN THE PREVIOUS REVISION WILL REQUIRE A COMPLETE MANUAL REPRINT SUBJECT TO REPRINT CHARGES SHOWN IN THE DATA AND SERVICES CATALOG.

# 52-21-03

TRANSMITTAL LETTER

Page 1

Jul 01/2009



## COMPONENT MAINTENANCE MANUAL

### Location of Change

52-21-03

REPAIR 22-1

REPAIR 40-1

### Description of Change

Changed the data in the Consumable Materials list.

Changed consumable from "DC3145 adhesive, A00281" to "Dow Corning 3145 RTV adhesive, A00281"

Changed the data in the Consumable Materials list.

Changed consumable from "lubricant, D50081" to "solid film lubricant, D50081"

# 52-21-03

HIGHLIGHTS

Page 1

Jul 01/2009



## COMPONENT MAINTENANCE MANUAL

Subject/Page	Date	Subject/Page	Date	Subject/Page	Date
TITLE PAGE		52-21-03 CLEANING (cont)		52-21-03 REPAIR 4-1 (cont)	
O 1	Jul 01/2009	402	BLANK	606	Jul 01/2007
2	BLANK	52-21-03 CHECK		607	Jul 01/2007
52-21-03 TRANSMITTAL LETTER		501	Jul 01/2007	608	Jul 01/2007
O 1	Jul 01/2009	502	Jul 01/2007	609	Jul 01/2007
2	BLANK	503	Jul 01/2007	610	Jul 01/2007
52-21-03 HIGHLIGHTS		504	Jul 01/2007	611	Jul 01/2007
O 1	Jul 01/2009	505	Jul 01/2007	612	Jul 01/2007
2	BLANK	506	Jul 01/2007	52-21-03 REPAIR 4-2	
52-21-03 EFFECTIVE PAGES		507	Jul 01/2007	601	Jul 01/2007
1 thru 6	Jul 01/2009	508	Jul 01/2007	602	BLANK
52-21-03 CONTENTS		509	Jul 01/2007	52-21-03 REPAIR 5-1	
1	Jul 01/2007	510	BLANK	601	Jul 01/2007
2	BLANK	52-21-03 REPAIR - GENERAL		602	Jul 01/2007
52-21-03 TR AND SB RECORD		601	Jul 01/2007	52-21-03 REPAIR 6-1	
1	Jul 01/2007	602	Jul 01/2007	601	Jul 01/2008
2	BLANK	603	Jul 01/2007	602	Jul 01/2007
52-21-03 REVISION RECORD		604	BLANK	603	Jul 01/2007
1	Jul 01/2007	52-21-03 REPAIR 1-1		604	Jul 01/2007
2	Jul 01/2007	601	Jul 01/2007	52-21-03 REPAIR 6-2	
52-21-03 RECORD OF TEMPORARY REVISIONS		602	Jul 01/2007	601	Jul 01/2007
1	Jul 01/2007	52-21-03 REPAIR 2-1		602	Jul 01/2007
2	Jul 01/2007	601	Jul 01/2007	603	Jul 01/2007
52-21-03 INTRODUCTION		602	Jul 01/2007	604	Jul 01/2007
1	Mar 01/2009	52-21-03 REPAIR 2-2		605	Jul 01/2007
2	BLANK	601	Mar 01/2009	606	BLANK
52-21-03 DESCRIPTION AND OPERATION		602	Mar 01/2009	52-21-03 REPAIR 7-1	
1	Jul 01/2007	603	Jul 01/2007	601	Jul 01/2008
2	Jul 01/2007	604	BLANK	602	Jul 01/2007
52-21-03 TESTING AND FAULT ISOLATION		52-21-03 REPAIR 3-1		603	Jul 01/2007
101	Jul 01/2007	601	Jul 01/2007	604	Jul 01/2007
102	BLANK	602	Jul 01/2007	52-21-03 REPAIR 8-1	
52-21-03 DISASSEMBLY		603	Jul 01/2007	601	Jul 01/2008
301	Jul 01/2007	604	Jul 01/2007	602	Jul 01/2007
302	Jul 01/2007	52-21-03 REPAIR 4-1		603	Jul 01/2007
52-21-03 CLEANING		601	Jul 01/2008	604	BLANK
401	Jul 01/2007	602	Jul 01/2007	52-21-03 REPAIR 8-2	
		603	Jul 01/2007	601	Jul 01/2007
		604	Jul 01/2007	602	Jul 01/2007
		605	Jul 01/2007	603	Jul 01/2007

A = Added, R = Revised, D = Deleted, O = Overflow

# 52-21-03

EFFECTIVE PAGES

Page 1

Jul 01/2009



## COMPONENT MAINTENANCE MANUAL

Subject/Page	Date	Subject/Page	Date	Subject/Page	Date
52-21-03 REPAIR 8-2 (cont)		52-21-03 REPAIR 13-2 (cont)		52-21-03 REPAIR 19-1	
604	Jul 01/2007	603	Jul 01/2007	601	Jul 01/2008
52-21-03 REPAIR 9-1		604	BLANK	602	Jul 01/2007
601	Jul 01/2008	52-21-03 REPAIR 14-1		52-21-03 REPAIR 19-2	
602	Jul 01/2007	601	Jul 01/2008	601	Jul 01/2007
603	Jul 01/2007	602	Jul 01/2007	602	Jul 01/2007
604	BLANK	603	Jul 01/2007	603	Jul 01/2007
52-21-03 REPAIR 9-2		604	BLANK	604	BLANK
601	Jul 01/2007	52-21-03 REPAIR 14-2		52-21-03 REPAIR 20-1	
602	Jul 01/2007	601	Jul 01/2007	601	Jul 01/2007
603	Jul 01/2007	602	Jul 01/2007	602	Jul 01/2007
604	Jul 01/2007	603	Jul 01/2007	52-21-03 REPAIR 21-1	
605	Jul 01/2007	604	BLANK	601	Jul 01/2008
606	BLANK	52-21-03 REPAIR 15-1		602	Jul 01/2007
52-21-03 REPAIR 10-1		601	Jul 01/2008	603	Jul 01/2007
601	Jul 01/2008	602	Jul 01/2007	604	Jul 01/2007
602	Jul 01/2007	52-21-03 REPAIR 15-2		605	Jul 01/2007
603	Jul 01/2007	601	Jul 01/2007	606	BLANK
604	Jul 01/2007	602	Jul 01/2007	52-21-03 REPAIR 22-1	
605	Jul 01/2007	52-21-03 REPAIR 16-1		601	Jul 01/2008
606	Jul 01/2007	601	Jul 01/2008	R 602	Jul 01/2009
607	Jul 01/2007	602	Jul 01/2007	603	Jul 01/2007
608	Jul 01/2007	603	Jul 01/2007	604	Jul 01/2007
52-21-03 REPAIR 11-1		604	BLANK	605	Jul 01/2007
601	Jul 01/2007	52-21-03 REPAIR 16-2		606	Jul 01/2007
602	Jul 01/2007	601	Jul 01/2007	52-21-03 REPAIR 22-2	
603	Jul 01/2007	602	Jul 01/2007	601	Jul 01/2007
604	BLANK	52-21-03 REPAIR 17-1		602	Jul 01/2007
52-21-03 REPAIR 12-1		601	Jul 01/2007	603	Jul 01/2007
601	Jul 01/2007	602	Jul 01/2007	604	Jul 01/2007
602	Jul 01/2007	603	Jul 01/2007	52-21-03 REPAIR 23-1	
52-21-03 REPAIR 12-2		604	BLANK	601	Jul 01/2007
601	Jul 01/2007	52-21-03 REPAIR 18-1		602	Jul 01/2007
602	Jul 01/2007	601	Jul 01/2008	603	Jul 01/2007
52-21-03 REPAIR 13-1		602	Jul 01/2007	604	Jul 01/2007
601	Jul 01/2008	52-21-03 REPAIR 18-2		52-21-03 REPAIR 24-1	
602	Jul 01/2007	601	Jul 01/2007	601	Jul 01/2008
52-21-03 REPAIR 13-2		602	Jul 01/2007	602	Jul 01/2007
601	Jul 01/2007	603	Jul 01/2007	52-21-03 REPAIR 24-2	
602	Jul 01/2007	604	BLANK	601	Jul 01/2007

A = Added, R = Revised, D = Deleted, O = Overflow

# 52-21-03

EFFECTIVE PAGES

Page 2

Jul 01/2009



## COMPONENT MAINTENANCE MANUAL

Subject/Page	Date	Subject/Page	Date	Subject/Page	Date
52-21-03 REPAIR 24-2 (cont)		52-21-03 REPAIR 29-1 (cont)		52-21-03 REPAIR 34-2 (cont)	
602	Jul 01/2007	602	Jul 01/2007	604	Jul 01/2007
603	Jul 01/2007	52-21-03 REPAIR 29-2		605	Jul 01/2007
604	BLANK	601	Jul 01/2007	606	BLANK
52-21-03 REPAIR 25-1		602	Jul 01/2007	52-21-03 REPAIR 35-1	
601	Jul 01/2008	603	Jul 01/2007	601	Jul 01/2008
602	Jul 01/2007	604	BLANK	602	Jul 01/2007
52-21-03 REPAIR 25-2		52-21-03 REPAIR 30-1		603	Jul 01/2007
601	Jul 01/2007	601	Jul 01/2008	604	BLANK
602	Jul 01/2007	602	Jul 01/2007	52-21-03 REPAIR 35-2	
603	Jul 01/2007	52-21-03 REPAIR 30-2		601	Jul 01/2007
604	BLANK	601	Jul 01/2007	602	Jul 01/2007
52-21-03 REPAIR 26-1		602	Jul 01/2007	603	Jul 01/2007
601	Jul 01/2008	603	Jul 01/2007	604	Jul 01/2007
602	Jul 01/2007	604	BLANK	605	Jul 01/2007
603	Jul 01/2007	52-21-03 REPAIR 31-1		606	BLANK
604	BLANK	601	Jul 01/2007	52-21-03 REPAIR 36-1	
52-21-03 REPAIR 26-2		602	Jul 01/2007	601	Jul 01/2008
601	Jul 01/2007	52-21-03 REPAIR 32-1		602	Jul 01/2007
602	Jul 01/2007	601	Jul 01/2008	52-21-03 REPAIR 36-2	
603	Jul 01/2007	602	Jul 01/2007	601	Jul 01/2007
604	Jul 01/2007	603	Jul 01/2007	602	Jul 01/2007
52-21-03 REPAIR 27-1		604	BLANK	603	Jul 01/2007
601	Jul 01/2007	52-21-03 REPAIR 32-2		604	BLANK
602	Jul 01/2007	601	Jul 01/2007	52-21-03 REPAIR 37-1	
52-21-03 REPAIR 27-2		602	Jul 01/2007	601	Jul 01/2008
601	Jul 01/2007	603	Jul 01/2007	602	Jul 01/2007
602	Jul 01/2007	604	BLANK	52-21-03 REPAIR 37-2	
603	Jul 01/2007	52-21-03 REPAIR 33-1		601	Jul 01/2007
604	BLANK	601	Jul 01/2008	602	Jul 01/2007
52-21-03 REPAIR 28-1		602	Jul 01/2007	603	Jul 01/2007
601	Jul 01/2007	52-21-03 REPAIR 34-1		604	BLANK
602	Jul 01/2007	601	Jul 01/2008	52-21-03 REPAIR 38-1	
52-21-03 REPAIR 28-2		602	Jul 01/2007	601	Jul 01/2008
601	Jul 01/2007	603	Jul 01/2007	602	Jul 01/2007
602	Jul 01/2007	604	BLANK	52-21-03 REPAIR 38-2	
603	Jul 01/2007	52-21-03 REPAIR 34-2		601	Jul 01/2007
604	BLANK	601	Jul 01/2007	602	Jul 01/2007
52-21-03 REPAIR 29-1		602	Jul 01/2007	603	Jul 01/2007
601	Jul 01/2008	603	Jul 01/2007	604	BLANK

A = Added, R = Revised, D = Deleted, O = Overflow

# 52-21-03

EFFECTIVE PAGES

Page 3

Jul 01/2009



## COMPONENT MAINTENANCE MANUAL

Subject/Page	Date	Subject/Page	Date	Subject/Page	Date
52-21-03 REPAIR 39-1		52-21-03 REPAIR 44-1		52-21-03 ASSEMBLY (cont)	
601	Jul 01/2008	601	Jul 01/2008	721	Jul 01/2007
602	Jul 01/2007	602	Jul 01/2007	722	Jul 01/2007
603	Jul 01/2007	52-21-03 REPAIR 44-2		723	Jul 01/2007
604	BLANK	601	Jul 01/2007	724	Jul 01/2007
52-21-03 REPAIR 39-2		602	Jul 01/2007	725	Jul 01/2007
601	Jul 01/2007	52-21-03 REPAIR 45-1		726	Jul 01/2007
602	Jul 01/2007	601	Jul 01/2007	727	Jul 01/2007
603	Jul 01/2007	602	Jul 01/2007	728	Jul 01/2007
604	Jul 01/2007	603	Jul 01/2007	729	Jul 01/2007
605	Jul 01/2007	604	BLANK	730	Jul 01/2007
606	BLANK	52-21-03 REPAIR 46-1		731	Jul 01/2007
52-21-03 REPAIR 40-1		601	Jul 01/2007	732	Jul 01/2007
R 601	Jul 01/2009	602	Jul 01/2007	733	Jul 01/2007
602	Jul 01/2007	52-21-03 REPAIR 46-2		734	Jul 01/2007
603	Jul 01/2007	601	Jul 01/2007	735	Jul 01/2007
604	BLANK	602	Jul 01/2007	736	Jul 01/2007
52-21-03 REPAIR 41-1		603	Jul 01/2007	737	Jul 01/2007
601	Jul 01/2007	604	BLANK	738	Jul 01/2007
602	Jul 01/2007	52-21-03 ASSEMBLY		739	Jul 01/2007
603	Jul 01/2007	701	Jul 01/2008	740	Jul 01/2007
604	Jul 01/2007	702	Jul 01/2007	741	Jul 01/2007
605	Jul 01/2007	703	Jul 01/2007	742	Jul 01/2007
606	Jul 01/2007	704	Jul 01/2007	743	Jul 01/2007
52-21-03 REPAIR 42-1		705	Jul 01/2007	744	Jul 01/2007
601	Jul 01/2008	706	Jul 01/2007	745	Jul 01/2007
602	Jul 01/2007	707	Jul 01/2007	746	Jul 01/2007
52-21-03 REPAIR 42-2		708	Jul 01/2007	747	Jul 01/2007
601	Jul 01/2007	709	Jul 01/2007	748	Jul 01/2007
602	Jul 01/2007	710	Jul 01/2007	749	Jul 01/2007
603	Jul 01/2007	711	Jul 01/2007	750	Jul 01/2007
604	BLANK	712	Jul 01/2007	751	Jul 01/2007
52-21-03 REPAIR 43-1		713	Jul 01/2007	752	Jul 01/2007
601	Jul 01/2008	714	Jul 01/2007	753	Jul 01/2007
602	Jul 01/2007	715	Jul 01/2007	754	Jul 01/2007
52-21-03 REPAIR 43-2		716	Jul 01/2007	755	Jul 01/2007
601	Jul 01/2007	717	Jul 01/2007	756	Jul 01/2007
602	Jul 01/2007	718	Jul 01/2007	757	Jul 01/2007
603	Jul 01/2007	719	Jul 01/2007	758	Jul 01/2007
604	BLANK	720	Jul 01/2007	759	Jul 01/2007

A = Added, R = Revised, D = Deleted, O = Overflow

# 52-21-03

EFFECTIVE PAGES

Page 4

Jul 01/2009



## COMPONENT MAINTENANCE MANUAL

Subject/Page	Date	Subject/Page	Date	Subject/Page	Date
52-21-03 ASSEMBLY (cont)		52-21-03 ILLUSTRATED PARTS LIST (cont)		52-21-03 ILLUSTRATED PARTS LIST (cont)	
760	Jul 01/2007	1019	Jul 01/2007	1057	Jul 01/2007
761	Jul 01/2007	1020	Jul 01/2007	1058	Jul 01/2007
762	Jul 01/2007	1021	Jul 01/2007	1059	Jul 01/2007
763	Jul 01/2007	1022	Jul 01/2007	1060	Jul 01/2007
764	Jul 01/2007	1023	Jul 01/2007	1061	Jul 01/2007
765	Jul 01/2007	1024	Jul 01/2007	1062	Jul 01/2007
766	Jul 01/2007	1025	Jul 01/2007	1063	Jul 01/2007
767	Jul 01/2007	1026	Jul 01/2007	1064	Jul 01/2007
768	Jul 01/2007	1027	Jul 01/2007	1065	Jul 01/2007
769	Jul 01/2007	1028	Jul 01/2007	1066	Jul 01/2007
770	Jul 01/2007	1029	Jul 01/2007	1067	Jul 01/2007
771	Jul 01/2007	1030	Jul 01/2007	1068	Jul 01/2007
772	BLANK	1031	Jul 01/2007	1069	Jul 01/2007
52-21-03 FITS AND CLEARANCES		1032	Jul 01/2007	1070	Jul 01/2007
801	Jul 01/2007	1033	Jul 01/2007	1071	Jul 01/2007
802	BLANK	1034	Jul 01/2007	1072	Jul 01/2007
52-21-03 SPECIAL TOOLS, FIXTURES, AND EQUIPMENT		1035	Jul 01/2007	1073	Jul 01/2007
901	Jul 01/2007	1036	Jul 01/2007	1074	Jul 01/2007
902	BLANK	1037	Jul 01/2007	1075	Jul 01/2007
52-21-03 ILLUSTRATED PARTS LIST		1038	Jul 01/2007	1076	Jul 01/2007
1001	Nov 01/2008	1039	Jul 01/2007	1077	Jul 01/2007
1002	Jul 01/2007	1040	Jul 01/2007	1078	Jul 01/2007
1003	Jul 01/2007	1041	Jul 01/2007	1079	Jul 01/2007
1004	Jul 01/2007	1042	Jul 01/2007	1080	Jul 01/2007
1005	Jul 01/2007	1043	Jul 01/2007	1081	Jul 01/2007
1006	Jul 01/2007	1044	Jul 01/2007	1082	Jul 01/2007
1007	Jul 01/2007	1045	Jul 01/2007	1083	Jul 01/2007
1008	Jul 01/2007	1046	Jul 01/2007	1084	Jul 01/2007
1009	Jul 01/2007	1047	Jul 01/2007	1085	Jul 01/2007
1010	Jul 01/2007	1048	Jul 01/2007	1086	Jul 01/2007
1011	Jul 01/2007	1049	Jul 01/2007	1087	Jul 01/2007
1012	Jul 01/2007	1050	Jul 01/2007	1088	Jul 01/2007
1013	Jul 01/2007	1051	Jul 01/2007	1089	Jul 01/2007
1014	Jul 01/2007	1052	Jul 01/2007	1090	Jul 01/2007
1015	Jul 01/2007	1053	Jul 01/2007	1091	Jul 01/2007
1016	Jul 01/2007	1054	Jul 01/2007	1092	Jul 01/2007
1017	Jul 01/2007	1055	Jul 01/2007	1093	Jul 01/2007
1018	Jul 01/2007	1056	Jul 01/2007	1094	Jul 01/2007

A = Added, R = Revised, D = Deleted, O = Overflow

# 52-21-03

EFFECTIVE PAGES

Page 5

Jul 01/2009





## COMPONENT MAINTENANCE MANUAL

Subject/Page	Date	Subject/Page	Date	Subject/Page	Date
52-21-03 ILLUSTRATED PARTS LIST (cont)		52-21-03 ILLUSTRATED PARTS LIST (cont)			
1095	Jul 01/2007	1098.35	Jul 01/2007		
1096	Jul 01/2007	1098.36	Jul 01/2007		
1097	Jul 01/2007	1098.37	Jul 01/2007		
1098	Jul 01/2007	1098.38	Jul 01/2007		
1098.1	Jul 01/2007				
1098.2	Jul 01/2007				
1098.3	Jul 01/2007				
1098.4	Jul 01/2007				
1098.5	Jul 01/2007				
1098.6	Jul 01/2007				
1098.7	Jul 01/2007				
1098.8	Jul 01/2007				
1098.9	Jul 01/2007				
1098.10	Jul 01/2007				
1098.11	Jul 01/2007				
1098.12	Jul 01/2007				
1098.13	Jul 01/2007				
1098.14	Jul 01/2007				
1098.15	Jul 01/2007				
1098.16	Jul 01/2007				
1098.17	Jul 01/2007				
1098.18	Jul 01/2007				
1098.19	Jul 01/2007				
1098.20	Jul 01/2007				
1098.21	Jul 01/2007				
1098.22	Jul 01/2007				
1098.23	Jul 01/2007				
1098.24	Jul 01/2007				
1098.25	Jul 01/2007				
1098.26	Jul 01/2007				
1098.27	Jul 01/2007				
1098.28	Jul 01/2007				
1098.29	Jul 01/2007				
1098.30	Jul 01/2007				
1098.31	Jul 01/2007				
1098.32	Jul 01/2007				
1098.33	Jul 01/2007				
1098.34	Jul 01/2007				

A = Added, R = Revised, D = Deleted, O = Overflow

# 52-21-03

EFFECTIVE PAGES

Page 6

Jul 01/2009

**COMPONENT MAINTENANCE MANUAL****TABLE OF CONTENTS**

<b><u>Paragraph Title</u></b>		<b><u>Page</u></b>
MID EXIT DOOR ASSEMBLY - DESCRIPTION AND OPERATION		1
TESTING AND FAULT ISOLATION	(Not Applicable)	
DISASSEMBLY		301
CLEANING		401
CHECK		501
REPAIR		601
ASSEMBLY		701
FITS AND CLEARANCES	(Not Applicable)	
SPECIAL TOOLS, FIXTURES, AND EQUIPMENT	(Not Applicable)	
ILLUSTRATED PARTS LIST		1001

**52-21-03**

CONTENTS

Page 1

Jul 01/2007













## COMPONENT MAINTENANCE MANUAL

### INTRODUCTION

#### 1. General

- A. The instructions in this manual supply the data necessary to do the maintenance functions together with the test, fault isolation, repair, and replacement of the defective parts.
- B. This manual is divided into different parts:
  - (1) Title Page
  - (2) Transmittal Letter
  - (3) Highlights
  - (4) List of Effective Pages
  - (5) Table of Contents
  - (6) Temporary Revision & Service Bulletin Record
  - (7) Record of Revisions
  - (8) Record of Temporary Revisions
  - (9) Introduction
  - (10) Procedures & IPL Sections
- C. Components that can be repaired have a different repair number for each specified repair. To find the repair number location of a component, look in the Repair-General procedure at the beginning of the REPAIR section. The Repair-General procedure also has an explanation of the True Position Dimension symbols used.
- D. All dimensions, measures, quantities and weights included are in English units. When metric equivalents are given they will be in the parentheses that follow the English units.
- E. The introduction to the Illustrated Parts List (IPL) shows how the IPL data is used.
- F. Design changes, optional parts, configuration differences and Service Bulletin modifications may cause different part numbers. These part numbers are identified in the IPL with an alphabetical letter which is added to the end of the basic item number. This new item number is referred to as an alpha-variant. Throughout the manual, IPL basic item number references also apply to alpha-variants unless shown differently.
- G. The tool reference numbers found in the individual procedures and in the Special Tools, Fixtures, and Equipment section are used to identify if a tool is a standard tool (STD-XXXX), a commercial tool (COM-XXXX), or a Special Tool (SPL-XXXX). This reference number is also used to distinguish between tools with similar names in the same procedure. These reference numbers are for use in the documentation only. They are not to be used for ordering tools.

# 52-21-03

INTRODUCTION

Page 1

Mar 01/2009





## COMPONENT MAINTENANCE MANUAL

### MID EXIT DOOR ASSEMBLY - DESCRIPTION AND OPERATION

#### 1. Description

A. The emergency exit door assembly is a hinged, plug-type door. Attached to the door are a mechanism installation (with internal and external handles, torque tube assembly with latching cranks and rollers, snubbers with release assembly, and attaching linkage), pressure relief door installation, and two support fittings for guide pins. Cabin pressure load on the door is transmitted to the fuselage at five discrete pressure stops - forward and aft. A view port lets you see the escape slide ground contact area.

#### 2. Operation

A. The inside handle or the outside handle operates the mechanism linkage and turns the door assembly torque tube. The vent door immediately opens, to release remaining air pressure in the passenger cabin. Latch cranks on the forward and aft ends of the torque tube turn. Rollers on the latch cranks engage fittings on the fuselage, to lift the door up from the fuselage. Pawl latch mechanisms then engage to hold the door in this position. Further operation of the handle lifts the door more to let the forward and aft guide pins clear the support fittings. Manual outward force applied to the door turns it until its center of gravity is past the vertical. By its own weight, the door continues to turn out and down, until it hangs from its hinges. Two hydraulic snubbers control the rate that the door moves and they stop the door before it can hit the underside of the fuselage.

#### 3. Leading Particulars (approximate)

- A. Length - 52 inches
- Width - 24 inches
- Depth - 12 inches
- Weight - 75 pounds


# 52-21-03

DESCRIPTION AND OPERATION

Page 1

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



Emergency Exit Door Assembly  
Figure 1

**52-21-03**

DESCRIPTION AND OPERATION

Page 2

Jul 01/2007



**COMPONENT MAINTENANCE MANUAL**

**TESTING AND FAULT ISOLATION**

**(NOT APPLICABLE)**

**52-21-03**

TESTING AND FAULT ISOLATION

Page 101

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### DISASSEMBLY

#### 1. General

- A. This procedure tells how to disassemble the emergency exit door unit.
- B. Disassemble this unit only sufficiently to isolate defects, to do the necessary repairs, and to put the unit back in a serviceable condition.
- C. Refer to IPL Figure 1 thru IPL Figure 4 for item numbers, as applicable.

#### 2. Disassembly

##### A. Special tools

- (1) Reserved.

##### B. Parts Replacement

**NOTE:** These parts are recommended for replacement. Replacement of other parts can be by in-service experience.

- (1) Cotter pins
- (2) Rubber parts
- (3) Rub strips
- (4) Cork parts

##### C. Procedure

- (1) Use standard industry practices and these steps.
- (2) Do not disassemble these subassemblies unless necessary for repair or replacement. (Refer to REPAIR for procedures to overhaul these subassemblies.)
  - (a) Activation modules (85, 90, 120, 125, IPL Figure 1)
  - (b) Structure installations (150, 155, 225, 230, IPL Figure 1)
  - (c) Prism assembly (180, IPL Figure 1)
  - (d) Beam assemblies (335, 375, 400, 405, 425, 450, 475, IPL Figure 1)
  - (e) Viewport frame assembly (520, IPL Figure 1)
  - (f) Handle box assembly (575, IPL Figure 1)
  - (g) Left edge frame assembly (685, IPL Figure 1)
  - (h) Right edge frame assembly (765, IPL Figure 1)
  - (i) Vent door mechanism assembly (55, IPL Figure 2)
  - (j) Push rod assembly (90, 140, IPL Figure 2)
  - (k) Bearing housing assembly (325, IPL Figure 2)
  - (l) Shaft assembly (380, IPL Figure 2)
  - (m) Pin assembly (480, 530, IPL Figure 2)
  - (n) Link assembly (620, IPL Figure 2)
  - (o) Handle assembly (635, IPL Figure 2)
  - (p) Cover assembly (670, IPL Figure 2)
  - (q) Clutch link assembly (780, IPL Figure 2)
  - (r) Cam assembly (90, 231, IPL Figure 3)

# 52-21-03

DISASSEMBLY

Page 301

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

- (s) Fitting assembly (120, 129, 159, 303, IPL Figure 3)
- (t) Idler assembly (288, IPL Figure 3)
- (u) Link assembly (315, IPL Figure 3)
- (v) Pressure lock mechanism assembly (414, IPL Figure 3)
- (w) Flight lock assembly (525, IPL Figure 3)
- (x) Latch shaft assembly (576, IPL Figure 3)
- (y) Snubber mechanism assembly (225, 230, IPL Figure 4)
- (z) Idler assembly (295, 300, 380, IPL Figure 4)
- (aa) Spring assembly (330, IPL Figure 4)
- (ab) Link assembly (400, 405, IPL Figure 4)

# 52-21-03

DISASSEMBLY

Page 302

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### CLEANING

#### 1. General

- A. This procedure tells how to clean the specified parts.
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for details of the standard practices specified in the procedure.
- C. Refer to IPL Figure 1 thru IPL Figure 4 for item numbers.

#### 2. Cleaning

##### A. References

Reference	Title
SOPM 20-30-03	GENERAL CLEANING PROCEDURES
SOPM 20-44-02	TEMPORARY PROTECTIVE COATINGS
SOPM 20-70-01	PROTECTION, STORAGE AND HANDLING OF AIRPLANE COMPONENTS

##### B. Procedure

- (1) Clean all parts but prism (190A, IPL Figure 1) by standard industry practices and the instructions in SOPM 20-30-03.
- (2) Prism (190A, IPL Figure 1)

**NOTE:** The prism material is acrylic plastic per AMS-L-P-391, Grade C, Type 1.

**CAUTION:** DO NOT RUB SURFACES OF THE PRISM WITH ABRASIVES UNLESS AS NECESSARY DURING REPAIR. DO NOT USE ALCOHOL, KEROSENE, BENZENE, XYLENE, KETONES SUCH AS ACETONE, CARBON TETRACHLORIDE, DE-ICING FLUIDS, LACQUER THINNERS, AROMATIC HYDROCARBONS, ETHERS, GLASS CLEANING COMPOUNDS OR OTHER UNAPPROVED SOLVENTS, BECAUSE THEY WILL DAMAGE THE PRISM SURFACE.

- (a) Clean the prism with lukewarm water and castile soap. Use a soft, clean chamois cloth to apply the soap solution to the prism surface.
- (b) Rinse with clean water and wipe dry with a clean, damp chamois cloth.
- (c) Give protection to the cleaned prism and put it away by standard industry practices and the instructions in SOPM 20-44-02 and SOPM 20-70-01.

# 52-21-03

CLEANING  
Page 401  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### CHECK

#### 1. General

- A. This procedure tells how to find defects in the specified parts.
- B. Refer to FITS AND CLEARANCES for design dimensions and wear limits.
- C. Refer to the Standard Overhaul Practices Manual (SOPM) for details of the standard practices specified in the procedure.
- D. Refer to IPL Figure 1 thru IPL Figure 4 for item numbers, as applicable.

#### 2. Check

##### A. References

Reference	Title
SOPM 20-20-01	MAGNETIC PARTICLE INSPECTION
SOPM 20-20-02	PENETRANT METHODS OF INSPECTION

##### B. Procedure

- (1) Examine all parts for defects by standard industry practices.
- (2) Do a magnetic particle check (SOPM 20-20-01) of these parts:
  - (a) Switch actuator (145, IPL Figure 1)
  - (b) Push rod (105, IPL Figure 2)
  - (c) Stop (445, IPL Figure 2)
  - (d) Shafts (78, 522, 651, IPL Figure 3)
  - (e) Cams (99, 233, IPL Figure 3)
  - (f) Washer (141, IPL Figure 3)
  - (g) Idlers (156, 300, IPL Figure 3)
  - (h) Fittings (175, 207, 312, IPL Figure 3)
  - (i) Target (200A, IPL Figure 3)
  - (j) Cranks (489, 513, 618, 630, IPL Figure 3)
  - (k) Catches (639, 648, IPL Figure 3)
  - (l) Washers (365, 370, IPL Figure 4)
- (3) Do a penetrant check (SOPM 20-20-02) of these parts:
  - (a) Handle (115, IPL Figure 1)
  - (b) Springs (195, 200, 665, 642, IPL Figure 2). Be sure to extend the spring during the check to look for defects between the coils.
  - (c) Sleeve (205, IPL Figure 2)
  - (d) Door (310, IPL Figure 2)
  - (e) Spacers (81, 84, 87, IPL Figure 3)
  - (f) Fittings (126, 135, 168, 324, IPL Figure 3)
  - (g) Springs (138, 519, 633, IPL Figure 3). Be sure to extend the spring during the check to look for defects between the coils.

# 52-21-03

CHECK

Page 501

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL



- (h) Washer (141, IPL Figure 3)
  - (i) Link (321, IPL Figure 3)
  - (j) Plate (332, IPL Figure 3)
  - (k) Housings (459, 462, IPL Figure 3)
  - (l) Fittings (265, 270, 290, IPL Figure 4)
  - (m) Idlers (320, 325, IPL Figure 4)
  - (n) Spring (375, IPL Figure 4)
  - (o) Idler (395, IPL Figure 4)
  - (p) Links (415, 420, IPL Figure 4)
- (4) Springs
- (a) Do a load check on each spring as shown in CHECK, Figure 501 thru CHECK, Figure 506.
- (5) Prism (190A, IPL Figure 1)
- (a) Defect definitions (CHECK, Figure 507):
    - 1) Cracks: Fissures with visible width when viewed parallel to the surface. A crack can grow at any angle to the surface, based on the direction of the force. A scratched or crazed surface can let the crack become longer.
    - 2) Crazing: Very fine fissures on the surface. They have no visible depth or width. They will start to be noticeable when they are 0.002-0.004 inch deep. In dim light, and light perpendicular to the surface, they are not easy to see. But in a bright light at an angle to the surface, the surface has a frosted appearance.
    - 3) Scratch: The removal of material from the surface, usually along a straight line or a curve. The depth of a scratch is not usually more than its width.
    - 4) Chips: Pieces of material broken from the surface. Shell type chips have a curved edge with many fine hairlines or ridges that follow the outer edge and become smaller towards the center of the chip (almost the same as the growth lines on a clamshell). V-shaped chips have a sharp, narrow cross-section and become larger towards the center.
  - (b) Examine the prism for defects such as cracks, crazing, scratches and chips. If you find defects, refer to REPAIR 2-1 for repair instructions.

# 52-21-03

CHECK  
Page 502  
Jul 01/2007



COMPONENT MAINTENANCE MANUAL




POSITION	MOMENT (INCH-POUNDS)
144.6°	0 (FREE POSITION)
241.6°	5.85-7.15
331.6°	11.25-13.75

146A6511-3 Spring Check  
Figure 501

**52-21-03**

CHECK  
Page 503  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL





POSITION	MOMENT (INCH-POUNDS)
117.0°	0 (FREE POSITION)
247.0°	5.85-7.15
337.0°	9.90-12.10

146A6511-4 Spring Check  
Figure 502

**52-21-03**

CHECK  
Page 504  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL





POSITION	MOMENT (INCH-POUNDS)
148.54°	0 (FREE POSITION)
275.44°	36.81-44.99
298.09°	43.38-53.02

146A6511-5 Spring Check  
Figure 503

**52-21-03**

CHECK  
Page 505  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL





POSITION	MOMENT (INCH-POUNDS)
10.06°	0 (FREE POSITION)
262.37°	16.38-20.02
310.27°	19.26-23.54

146A6511-7,-8 Spring Check  
Figure 504

**52-21-03**

CHECK  
Page 506  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL





POSITION	MOMENT (INCH-POUNDS)
0°	0 (FREE POSITION)
29.76°	13.50-16.50
115.07°	52.20-63.80

146A6511-9 Spring Check  
Figure 505

**52-21-03**

CHECK  
Page 507  
Jul 01/2007

**COMPONENT MAINTENANCE MANUAL**


A-A


PART NUMBER	APPROXIMATE FREE LENGTH (INCHES)	TEST LENGTH (INCHES)	LOAD LIMITS (POUNDS)
146A6558-1	5.4090	2.5000 3.0470	107.00-127.00 85.00-105.00
146A6558-3	4.6677	2.5000 3.0600	193.73-237.73 144.00-176.00
146A6585-1	3.1240	1.8100 2.4000	260.00-280.00 140.00-160.00

 Spring Check  
 Figure 506


**52-21-03**

 CHECK  
 Page 508  
 Jul 01/2007

### COMPONENT MAINTENANCE MANUAL



PRISM SURFACE WITH DEFECTS



Prism Surface Defects  
Figure 507

**52-21-03**



## COMPONENT MAINTENANCE MANUAL

### REPAIR

#### 1. General

A. Instructions for repair, refinish, and replacement of the specified subassembly parts are included in each REPAIR when applicable:

PART NUMBER	NAME	REPAIR
_____	REFINISH OF OTHER PARTS	1-1
140N2035	PRISM ASSEMBLY	2-1
140N2764	PRISM	2-2
146A6251	INSIDE HANDLE	3-1
146A6421	BEAM ASSEMBLY #1	4-1, 4-2
146A6422	BEAM ASSEMBLY #2	4-1, 4-2
146A6423	BEAM ASSEMBLY #3	4-1, 4-2
146A6424	BEAM ASSEMBLY #4	4-1, 4-2
146A6425	BEAM ASSEMBLY #5	4-1, 4-2
146A6426	BEAM ASSEMBLY #6	4-1, 4-2
146A6428	VIEWPORT FRAME ASSEMBLY	5-1
146A6445	HANDLE BOX ASSEMBLY	6-1, 6-2
146A6509	PRESSURE LOCK MECHANISM ASSEMBLY	7-1
146A6510	CRANK ASSEMBLY	8-1, 8-2
146A6512	BEARING HOUSING ASSEMBLY	9-1, 9-2
146A6520	LATCH SHAFT ASSEMBLY	10-1
146A6521	SHAFT	11-1
146A6522	LATCH CRANK ASSEMBLY	12-1, 12-2
146A6524	HANDLE CRANK ASSEMBLY	13-1, 13-2
146A6526	OUTSIDE HANDLE ASSEMBLY	14-1, 14-2
146A6527	HANDLE LINK ASSEMBLY	15-1, 15-2
146A6530	PUSH ROD ASSEMBLY	16-1, 16-2
146A6532	OUTSIDE HANDLE SHAFT ASSEMBLY	17-1
146A6535	OUTSIDE CRANK ASSEMBLY	18-1, 18-2
146A6536	HANDLE LINK CRANK ASSEMBLY	19-1, 19-2
146A6537	OUTSIDE HANDLE CRANK SHAFT	20-1
146A6539	VENT DOOR MECHANISM ASSEMBLY	21-1

# 52-21-03

REPAIR - GENERAL

Page 601

Jul 01/2007





## COMPONENT MAINTENANCE MANUAL

PART NUMBER	NAME	REPAIR
146A6540	VENT DOOR ASSEMBLY	22-1
146A6545	SHAFT	23-1
146A6546	BEARING HOUSING ASSEMBLY	24-1, 24-2
146A6547	VENT DOOR CRANK ASSEMBLY	25-1, 25-2
146A6551	SNUBBER FITTING ASSEMBLY	26-1, 26-2
146A6552	UPPER SNUBBER SUPPORT IDLER ASSEMBLY	27-1, 27-2
146A6553	LOWER SNUBBER SUPPORT IDLER ASSEMBLY	28-1, 28-2
146A6554	SNUBBER LINK ASSEMBLY	29-1, 29-2
146A6555	LIFT ASSIST FITTING ASSEMBLY	30-1, 30-2
146A6556	LIFT ASSIST SPRING ASSEMBLY	31-1
146A6557	END FITTING ASSEMBLY	32-1, 32-2
146A6562	MECHANISM SNUBBER ASSEMBLY	33-1
146A6575	LOCK SHAFT IDLER ASSEMBLY	34-1, 34-2
146A6576	LOCK FITTING ASSEMBLY	35-1, 35-2
146A6577	OVERCENTER SPRING FITTING ASSEMBLY	36-1, 36-2
146A6578	LINK ASSEMBLY	37-1, 37-2
146A6579	LOCK TARGET ASSEMBLY	38-1
146A6580	LOCK CAM ASSEMBLY	39-1
146A6581	LOCK SHAFT	40-1
146A6586	LOCK FITTING	41-1
146A6589	OUTSIDE HANDLE COVER ASSEMBLY	42-1
146A6590	OUTSIDE HANDLE CLUTCH LINK ASSEMBLY	43-1
146A6591	BEARING HOUSING ASSEMBLY	44-1, 44-2
146A6592	OUTSIDE HANDLE SUPPORT	45-1
146A6597	OUTSIDE HANDLE PIN ASSEMBLY	46-1, 46-2

### 2. Dimensioning Symbols

- A. Standard True Position Dimensioning Symbols used in the applicable repair procedures are shown in REPAIR-GENERAL, Figure 601

# 52-21-03

REPAIR - GENERAL

Page 602

Jul 01/2007





## COMPONENT MAINTENANCE MANUAL

### REFINISH OF OTHER PARTS - REPAIR 1-1

#### 1. General

- A. This procedure tells how to refinish the parts which are not in the other repairs.
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the SOPM subjects identified in this procedure.
- C. Refer to IPL Figure 1 thru IPL Figure 4 for item numbers, as applicable.

#### 2. Refinish of Other Parts

##### A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I
C00802	Coating - Nylon	BAC5710, Type 49

##### B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-60-02	FINISHING MATERIALS

##### C. Procedure

- (1) Instructions for the repair of the parts in REPAIR 1-1, Table 601 is for replacement of the original finish.
- (2) Refer to REPAIR 1-1, Table 601 for the refinish details. Refer to SOPM 20-30-02 for stripping of protective finishes. Refer to SOPM 20-41-01 for the decoding table for Boeing finish codes. Refer to SOPM 20-60-02 for finishing materials.

**Table 601:** Refinish Details

IPL FIG. & ITEM	MATERIAL	FINISH
IPL Fig. 1		
Switch Actuator (145)	15-5PH CRES, 180-200 ksi	Passivate (F-17.25).
Retainer (175)	Al alloy	Chemical treat (F-17.07). Apply BMS 10-11, Type 1 primer, C00259 (F-20.03).
Frames (535, 760, 905)	Al alloy	Boric acid-sulfuric acid anodize or chromic acid anodize (F-17.31). Apply BMS 10-11, Type 1 primer, C00259 (F-20.03).
Cover plate (580)	Al alloy	Boric acid-sulfuric acid anodize or chromic acid anodize (F-17.31). Apply BMS 10-11, Type 1 primer, C00259 (F-20.03).
Support (595)	Al alloy	Boric acid-sulfuric acid anodize or chromic acid anodize (F-17.31). Apply BMS 10-11, Type 1 primer, C00259 (F-20.03).

# 52-21-03

REPAIR 1-1  
Page 601  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

**Table 601: Refinish Details (Continued)**

IPL FIG. & ITEM	MATERIAL	FINISH
Retainer (855)	Al alloy	Boric acid-sulfuric acid anodize or chromic acid anodize (F-17.31). Apply BMS 10-11, Type 1 primer, C00259 (F-20.03).
IPL Fig. 2		
Springs (195, 200, 665)	Ti alloy	With the spring extended, apply primer and Type 49 coating, C00802 (F-21.14).
Sleeve (205)	15-15PH CRES, 180-200 ksi	Passivate (F-17.25).
Stop (445)	15-15PH CRES, 180-200 ksi	Cadmium plate (F-16.06). Apply BMS 10-11, Type 1 primer, C00259 (F-20.02).
Sleeve (660)	Nylon	No finish.
Sleeve (730)	17-4PH	Cadmium plate (F-15.06).
Cover (740)	Al alloy	Boric acid-sulfuric acid anodize or chromic acid anodize (F-17.31). Apply BMS 10-11, Type 1 primer, C00259 (F-20.03).
IPL Fig. 3		
Spacers (81, 84, 87)	Al alloy	Boric acid-sulfuric acid anodize or chromic acid anodize (F-17.31). Apply BMS 10-11, Type 1 primer, C00259 (F-20.03).
Springs (138, 519, 636, 642)	Ti alloy	With the spring extended, apply primer and Type 49 coating, C00802 (F-21.14).
Washer (141)	15-15PH CRES, 180-200 ksi	Passivate (F-17.25).
Target (200A)	15-15PH CRES, 180-200 ksi	Passivate (F-17.25).
Fitting (207)	15-15PH CRES, 180-200 ksi	Cadmium plate (F-15.06). Apply BMS 10-11, Type 1 primer, C00259 (F-20.03), but not on lug faces or around the large hole.
Fitting (324)	Al alloy	Boric acid-sulfuric acid anodize or chromic acid anodize (F-17.31). Apply BMS 10-11, Type 1 primer, C00259 (F-20.03).
Plate (332)	Al alloy	Chemical treat (F-17.07). Apply BMS 10-11, Type 1 primer, C00259 (F-20.03).
Sleeves (516, 633, 645)	Nylon	No finish.
Catches (639, 648)	15-15PH CRES, 180-200 ksi	Passivate (F-17.25).
IPL Fig. 4		
Washer (365, 370)	15-15PH CRES, 180-200 ksi	Passivate (F-17.25).

# 52-21-03

REPAIR 1-1  
Page 602  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### PRISM ASSEMBLY - REPAIR 2-1

140N2035-1

#### 1. General

- A. This procedure tells how to replace the parts of prism assembly (180).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 1 for item numbers.

#### 2. Parts Replacement

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
A00027	Adhesive - Silicone Rubber, 1 Part, RTV	BAC5010, Type 60
A00923	Adhesive - Silicone	BAC5010, Type 77

- B. References

Reference	Title
SOPM 20-50-12	APPLICATION OF ADHESIVES
SOPM 20-60-04	MISCELLANEOUS MATERIALS

- C. Procedure (REPAIR 2-1, Figure 601)

**NOTE:** For application of adhesives, refer to SOPM 20-50-12. For miscellaneous materials, refer to SOPM 20-60-04.

- (1) Remove the old tape and sleeve from the prism.
- (2) If you find defects on the prism surfaces, refer to REPAIR 2-2 for repair instructions.
- (3) Install a replacement sleeve on the prism and bond it in position with a 1/4 inch wide bead of Type 60 adhesive, A00027 (SOPM 20-50-12). You can use duct tape to temporarily hold the sleeve in position until the adhesive cures.
- (4) Or bond the sleeve to the prism and bond the end of the sleeve together with Type 77 adhesive, A00923 (SOPM 20-50-12). Remove unwanted adhesive from the inboard flat surface of the prism.

# 52-21-03



REPAIR 2-1

Page 601

Jul 01/2007



COMPONENT MAINTENANCE MANUAL



ITEM NUMBERS REFER TO IPL FIG. 1  
 ALL DIMENSIONS ARE IN INCHES

140N2035-1 Prism Assembly Parts Replacement  
 Figure 601

**52-21-03**

REPAIR 2-1  
 Page 602  
 Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### PRISM - REPAIR 2-2

140N2764-1

#### 1. General

- A. This procedure tells how to repair prism (190A).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 1 for item numbers.

#### 2. Prism Repair

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
B00027	Compound - Buffing - Learok 884E (Formerly Learock 888)	

- B. References

Reference	Title
SOPM 20-60-04	MISCELLANEOUS MATERIALS

- C. Procedure (REPAIR 2-2, Figure 601)

**NOTE:** For miscellaneous materials, refer to SOPM 20-60-04.

**CAUTION:** MAKE SURE THE SURFACE OF THE PRISM STAYS COOL DURING REPAIR PROCEDURES. APPLY A SUFFICIENT QUANTITY OF WATER TO COOL IT DURING POLISHING OR SANDING OPERATIONS.

- (1) Cover the sides of the prism with protective tape or coating.
- (2) Remove small surface scratches with polish on a wet, clean cloth. Use a circular motion, start at the center, and work outward. Use clean, flannel cloth for each operation.
- (3) Remove small scratches by machine polishing or buffing as follows:
  - (a) Buff if necessary with coarse compound (Learok S-30) on a stitched muslin wheel at a wheel surface speed of 3200 feet per minute. Be sure to keep the curvature of the surface.
  - (b) Polish to a high gloss with Learok 884E compound, B00027 on a loosely stitched flannel wheel at a wheel surface speed of 4200 feet per minute.
- (4) Remove chips or major scratches by sanding as follows (REPAIR 2-2, Figure 601).
  - (a) Rub the surface of the prism with 100-grit abrasive paper, with a sanding block or a vibrating sander at 800 cpm. Remove a minimum of 0.005 inch of acrylic from the surface of the prism. Be sure to keep the curvature of the surface. Rub the surface until all surface defects are removed. Change the abrasive paper frequently.
  - (b) Smooth the surface with a vibrating sander with 100-grit abrasive paper. After 2 to 3 minutes, change to 200-grit abrasive paper. Then change to micromesh cloth. Start with 1600-grit micromesh cloth and go to 8000-grit micromesh cloth.
  - (c) Remove all unwanted material and water from the surface of the prism.

# 52-21-03

REPAIR 2-2

Page 601

Mar 01/2009



## COMPONENT MAINTENANCE MANUAL

- (d) Use buffing compound on a clean flannel cloth to polish the repaired surface of the prism.
- (5) Examine the prism for optical quality. If the prism has unsatisfactory optical quality, replace the prism.
- (6) Polish the prism with wax and apply a protective finish or protective tape.

### 3. Prism Refinish

#### A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
C00566	Coating - Urethane	MIL-C-83286

#### B. References

Reference	Title
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES
SOPM 20-50-10	APPLICATION OF STENCILS, INSIGNIA, SILK SCREEN, PART NUMBERING AND IDENTIFICATION MARKINGS
SOPM 20-60-04	MISCELLANEOUS MATERIALS

#### C. Procedure (REPAIR 2-2, Figure 601)

**NOTE:** For the decoding table for Boeing finish codes, refer to SOPM 20-41-01. For miscellaneous materials, refer to SOPM 20-60-04.

- (1) Apply Aquadex urethane coating, C00566 (F-30.004-701).
- (2) Rubber stamp or stencil markings (SOPM 20-50-10) as shown.

# 52-21-03


REPAIR 2-2

Page 602

Mar 01/2009



COMPONENT MAINTENANCE MANUAL



- 1 APPLY AQUADEX URETHANE COATING COLOR BAC701 BLACK (F-30.004-701)
- 2 MAXIMUM DEPTH OF REPAIR 0.06 INCH. KEEP THE CURVATURE OF SURFACE DURING REPAIR
- 3 MAXIMUM DEPTH OF REPAIR 0.03 INCH, ON SEAL FACE

- 4 RUBBER STAMP OR STENCIL "UP" AND VERTICAL BAR (SOPM 20-50-10) (COLOR WHITE)

125 ✓ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

ALL DIMENSIONS ARE IN INCHES

140N2764-1 Prism Repair and Refinish  
Figure 601

**52-21-03**

REPAIR 2-2  
Page 603  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### INSIDE HANDLE - REPAIR 3-1

146A6251-1

#### 1. General

- A. This procedure tells how to repair and refinish inside handle (115).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 1 for item numbers.
- D. General repair details:
  - (1) Material: Al alloy
  - (2) Shot peen: not necessary
- E. This handle can be seen from the airplane interior. Be careful not to damage surfaces the passengers will see.

#### 2. Pin Repair

- A. Procedure (REPAIR 3-1, Figure 601)
  - (1) Attachment holes
    - (a) Repair is only replacement of the original finish. Refer to REPAIR 3-1, Paragraph 3. below for details.
    - (b) If you think there are defects on important surfaces, see REPAIR 3-1, Figure 601 for dimension details.
  - (2) Handle surfaces
    - (a) Remove small defects by standard industry practices.
    - (b) Refinish as indicated.

#### 3. Pin Refinish

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
C00040	Coating - Interior Decorative Urethane Topcoat, Semigloss	BMS10-83, Type II
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I
C00260	Coating - Chemical And Solvent Resistant Finish, Epoxy Resin Enamel	BMS10-11, Type II

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

# 52-21-03

REPAIR 3-1  
Page 601  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### C. Procedure

**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Apply directional coarse grain finish and sulfuric acid anodize (F-14.29) in the areas shown.
- (2) Apply BMS 10-11, Type 1 primer, C00259 all over unless shown.
- (3) Apply white BMS 10-11, Type 2 coating, C00260 and red BMS 10-83, Type 2 coating, C00040 to the surfaces shown.


# 52-21-03

REPAIR 3-1

Page 602

Jul 01/2007

COMPONENT MAINTENANCE MANUAL




146A6251-1 Inside Handle Repair and Refinish  
Figure 601 (Sheet 1 of 2)

**52-21-03**

REPAIR 3-1  
Page 603  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL



B-B

- 1 APPLY DIRECTIONAL COARSE SATIN FINISH AND SULFURIC ACID ANODIZE (F-14.29) IN THIS AREA. NO PRIMER OR ENAMEL.
- 2 GRAIN DIRECTION: LONGITUDINAL
- 3 APPLY RED BMS 10-83 TYPE 2 ENAMEL (F-22.06-101) IN THIS AREA ONLY

146A6251-1 Inside Handle Repair and Refinish  
Figure 601 (Sheet 2 of 2)

**52-21-03**

REPAIR 3-1  
Page 604  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### BEAM #1 THRU #6 ASSEMBLY - REPAIR 4-1

146A6421-1, 146A6422-1, -3, 146A6423-1, 146A6424-1, 146A6425-1, 146A6426-1, -3

#### 1. General

- A. This procedure tells how to replace the parts of beam assemblies (335, 375, 400, 425, 450, 475).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 1 for item numbers.
- D. These beams can be seen from the airplane interior. Be careful not to damage surfaces the passengers will see.

#### 2. Bushing Replacement

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
A00247	Sealant - Pressure And Environmental - Chromate Type	BMS 5-95

- B. References

Reference	Title
SOPM 20-50-03	BEARING AND BUSHING REPLACEMENT

- C. Stop bushings (REPAIR 4-1, Figure 601 thru REPAIR 4-1, Figure 606)

- (1) Remove the old bushing. It is a clearance fit, but the bushing tail was flared against the hole chamfer.
- (2) If you find defects on the hole surfaces, refer to REPAIR 4-2 for repair instructions.
- (3) Apply BMS 5-95 sealant, A00247 to the mating surfaces of the bushing and the lug hole, to make sure there will be a complete fay seal.
- (4) Push the bushing flange tightly against the lug face, and then roller or anvil swage the bushing tail against the 45-degree countersink of the lug hole. Complete the swage during the cure time of the sealant. Be careful not to damage the lug face by the swaging operation.
- (5) Immediately after the swage is complete, make sure the bushing does not turn if a maximum of 5 pound-inches torque is applied to the bushing flange.
- (6) Wipe unwanted sealant from each end of the installed bushing. A small fillet of sealant can stay around the bushing flange.

- D. Other bushings (REPAIR 4-1, Figure 606)

- (1) Remove the old bushings.
- (2) If you find defects on the hole surfaces, refer to REPAIR 4-2 for repair instructions.
- (3) Install replacement bushings by the shrink fit method (SOPM 20-50-03) with BMS 5-95 sealant, A00247 as the installation finish.

#### 3. Nutplate Replacement (REPAIR 4-1, Figure 601 thru REPAIR 4-1, Figure 606)

- A. Remove the rivets and the bad nutplate.

# 52-21-03

REPAIR 4-1

Page 601

Jul 01/2008




## COMPONENT MAINTENANCE MANUAL

- B. Install a replacement nutplate with new rivets.
- 4. **Spring Retainer Hardware Replacement (REPAIR 4-1, Figure 602, REPAIR 4-1, Figure 603)**
  - A. Remove the old BACB30NR4K9 bolts and related fasteners from the holes.
  - B. Remove old sealant and clean the holes.
  - C. Apply BMS 5-95 sealant, A00247 to the hole surfaces.
  - D. Install replacement bolts and related fasteners with wet BMS 5-95 sealant, A00247 (SOPM 20-50-19, Method 1).

# 52-21-03

REPAIR 4-1  
Page 602  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL




ITEM NUMBERS REFER TO IPL FIG. 1  
ALL DIMENSIONS ARE IN INCHES

146A6421-1 Beam #1 Assembly Parts Replacement  
Figure 601

**52-21-03**



COMPONENT MAINTENANCE MANUAL




146A6422-1,-3 Beam #2 Assembly Parts Replacement  
Figure 602 (Sheet 1 of 2)

**52-21-03**

REPAIR 4-1  
Page 604  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL



1 INSTALL THIS BOLT WITH BMS 5-95 SEALANT ON MATING SURFACES. SEE TEXT FOR PROCEDURE.

2 IPL FIG. 2

ITEM NUMBERS REFER TO IPL FIG. 1 UNLESS SHOWN BY 2

ALL DIMENSIONS ARE IN INCHES

146A6422-1,-3 Beam #2 Assembly Parts Replacement  
Figure 602 (Sheet 2 of 2)


# 52-21-03

REPAIR 4-1

Page 605

Jul 01/2007

COMPONENT MAINTENANCE MANUAL






146A6423-1 Beam #3 Assembly Parts Replacement  
Figure 603 (Sheet 1 of 2)

**52-21-03**

REPAIR 4-1  
Page 606  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL



1 INSTALL THIS BOLT WITH BMS 5-95 SEALANT ON MATING SURFACES. SEE TEXT FOR PROCEDURE.

2 IPL FIG. 3

ITEM NUMBERS REFER TO IPL FIG. 1 UNLESS SHOWN BY 2


ALL DIMENSIONS ARE IN INCHES

146A6423-1 Beam #3 Assembly Parts Replacement  
Figure 603 (Sheet 2 of 2)

**52-21-03**

REPAIR 4-1  
Page 607  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL




146A6424-1 Beam #4 Assembly Parts Replacement  
Figure 604

**52-21-03**

REPAIR 4-1  
Page 608  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL





146A6425-1 Beam #5 Assembly Parts Replacement  
Figure 605

**52-21-03**

REPAIR 4-1  
Page 609  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL




146A6426-1,-3 Beam #6 Assembly Parts Replacement  
Figure 606 (Sheet 1 of 3)

**52-21-03**

REPAIR 4-1  
Page 610  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL



146A6426-1,-3 Beam #6 Assembly Parts Replacement  
Figure 606 (Sheet 2 of 3)

**52-21-03**



REPAIR 4-1

Page 611

Jul 01/2007



COMPONENT MAINTENANCE MANUAL



ITEM NUMBERS REFER TO IPL FIG. 1  
ALL DIMENSIONS ARE IN INCHES

146A6426-1,-3 Beam #6 Assembly Parts Replacement  
Figure 606 (Sheet 3 of 3)

**52-21-03**

REPAIR 4-1  
Page 612  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### BEAM - REPAIR 4-2

146A6421-101, 146A6422-101, -103, 146A6423-101, 146A6424-101, 146A6425-101, 146A6426-101, -103

#### 1. General

- A. This procedure tells how to repair and refinish beams (370, 395, 420, 445, 470, 515).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 1 for item numbers.
- D. General repair details:
  - (1) Material: Al alloy
  - (2) Shot peen: not necessary

#### 2. Beam Repair

- A. Procedure
  - (1) Repair is only replacement of the original refinish. Refer to REPAIR 4-2, Paragraph 3. for details.

#### 3. Beam Refinish

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

- C. Procedure

**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Boric acid-sulfuric acid anodize or chromic acid anodize (F-17.31) all over.
- (2) Apply BMS 10-11, Type 1 primer, C00259 (F-20.03) but not in the holes for the bushings.

# 52-21-03

REPAIR 4-2  
Page 601  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### VIEWPORT FRAME ASSEMBLY - REPAIR 5-1

146A6428-1

#### 1. General

- A. This procedure tells how to repair viewport frame assembly (520).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 1 for item numbers.
- D. General repair details:
  - (1) Material: Al alloy
  - (2) Shot peen: not necessary
- E. This frame can be seen from the airplane interior. Be careful not to damage surfaces the passengers will see.

#### 2. Nutplate Replacement

- A. Procedure (REPAIR 5-1, Figure 601)
  - (1) Remove the rivets and the bad nutplate.
  - (2) Install a replacement nutplate with new rivets.

#### 3. Frame Refinish

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

- C. Procedure



**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Boric acid-sulfuric acid anodize or chromic acid anodize (F-17.31).
- (2) Apply BMS 10-11, Type 1 primer, C00259 (F-20.03) all over.

# 52-21-03

REPAIR 5-1  
Page 601  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL



ITEM NUMBERS REFER TO IPL FIG. 1  
ALL DIMENSIONS ARE IN INCHES

146A6428-1 Viewport Frame Assembly Repair  
Figure 601

**52-21-03**

REPAIR 5-1  
Page 602  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### HANDLE BOX ASSEMBLY - REPAIR 6-1

146A6445-1

#### 1. General

- A. This procedure tells how to replace the parts of handle box assembly (575).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 1 for item numbers.

#### 2. Support Replacement

- A. Procedure (REPAIR 6-1, Figure 601)
  - (1) Remove bolt (600), collar (605) and the old support (595).
  - (2) Refer to REPAIR 1-1 for refinish of the support.
  - (3) Install a replacement support with the bolts and collars.

#### 3. Bushing Replacement

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
A00247	Sealant - Pressure And Environmental - Chromate Type	BMS 5-95

- B. References

Reference	Title
SOPM 20-50-03	BEARING AND BUSHING REPLACEMENT

- C. Procedure (REPAIR 6-1, Figure 601)

- (1) Remove the old bushings.
- (2) If you find defects on the hole surfaces, refer to REPAIR 6-2 for repair instructions.
- (3) Install replacement bushings by the shrink fit method (SOPM 20-50-03) with BMS 5-95 sealant, A00247 as the installation finish.

#### 4. Nutplate Replacement (REPAIR 6-1, Figure 601)

- A. Remove the rivets and the bad nutplate.
- B. Install a replacement nutplate with new rivets.


#### 5. Cover Plate Replacement (REPAIR 6-1, Figure 601)

- A. Remove bolts (585), collars (590) and the old cover plate (580).
- B. Refer to REPAIR 1-1 for refinish of the cover plate.
- C. Install a replacement cover plate in the hole in the box, with BMS 3-38 corrosion inhibiting non-drying paste, G50136 on mating surfaces.
- D. Install the bolts and collars, with BMS 3-38 corrosion inhibiting non-drying paste, G50136 on mating surfaces.

# 52-21-03

REPAIR 6-1  
Page 601  
Jul 01/2008

COMPONENT MAINTENANCE MANUAL




146A6445-1 Handle Box Assembly Parts Replacement  
Figure 601 (Sheet 1 of 3)

**52-21-03**

REPAIR 6-1  
Page 602  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL




146A6445-1 Handle Box Assembly Parts Replacement  
Figure 601 (Sheet 2 of 3)

**52-21-03**

REPAIR 6-1  
Page 603  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL



1 INSTALL WITH BMS 3-38 CORROSION PREVENTIVE COMPOUND ON MATING SURFACES

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

ITEM NUMBERS REFER TO IPL FIG. 1  
ALL DIMENSIONS ARE IN INCHES

146A6445-1 Handle Box Assembly Parts Replacement  
Figure 601 (Sheet 3 of 3)

**52-21-03**

REPAIR 6-1  
Page 604  
Jul 01/2007





## COMPONENT MAINTENANCE MANUAL

### HANDLE BOX - REPAIR 6-2

146A6445-101

#### 1. General

- A. This procedure tells how to repair and refinish handle box (630).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 1 for item numbers.
- D. General repair details:
  - (1) Material: Al alloy
  - (2) Shot peen: not necessary

#### 2. Handle Box Repair (REPAIR 6-2, Figure 601)

- A. Procedure
  - (1) Repair is only replacement of the original refinish. Refer to REPAIR 6-2, Paragraph 3. for details.
  - (2) If you think there are defects on important surfaces, see REPAIR 6-2, Figure 601 for dimension details.

#### 3. Handle Box Refinish (REPAIR 6-2, Figure 601)

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I
C50069	Coating - Enamel, Color 702 Gloss White	BMS10-11, Type II

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

- C. Procedure

**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Boric acid-sulfuric acid anodize or chromic acid anodize (F-17.31) all over.
- (2) Apply BMS 10-11, Type 1 primer, C00259 (F-20.03) to all surfaces unless shown by flagnotes 1 and 3. Apply BMS 10-11, Type 1 primer, C00259 (F-20.02) and BMS 10-11, Type 2 coating, C50069 (F-21.02) to the areas shown by flagnote 3.



# 52-21-03

REPAIR 6-2

Page 601

Jul 01/2007

COMPONENT MAINTENANCE MANUAL




A-A  
(ROTATED 90° CW)

146A6445-101 Handle Box Repair and Refinish  
Figure 601 (Sheet 1 of 4)

**52-21-03**

REPAIR 6-2  
Page 602  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL




B-B

146A6445-101 Handle Box Repair and Refinish  
Figure 601 (Sheet 2 of 4)

**52-21-03**

REPAIR 6-2  
Page 603  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL



146A6445-101 Handle Box Repair and Refinish  
Figure 601 (Sheet 3 of 4)

**52-21-03**

REPAIR 6-2  
Page 604  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

REFERENCE NUMBER	[1]	[2]	[3]
DESIGN DIMENSION	0.5006	1.0634	1.3135
	0.5000	1.0625	1.3125
REPAIR LIMIT	—	—	—

- 1 NO PRIMER OR ENAMEL
- 2 APPLY BMS 10-11, TYPE 1 PRIMER (F-20.03)
- 3 APPLY BMS 10-11, TYPE 1 PRIMER (F-20.02) AND GRAY BMS 10-11, TYPE 2 ENAMEL (F-21.02)

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ALL DIMENSIONS ARE IN INCHES

146A6445-101 Handle Box Repair and Refinish  
Figure 601 (Sheet 4 of 4)

# 52-21-03

REPAIR 6-2  
Page 605  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### PRESSURE LOCK MECHANISM ASSEMBLY - REPAIR 7-1

146A6509-1

#### 1. General

- A. This procedure tells how to replace the parts of pressure lock mechanism assembly (414).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices shown in the repair.
- C. Refer to IPL Figure 3 for item numbers.

#### 2. Parts Replacement

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
A00247	Sealant - Pressure And Environmental - Chromate Type	BMS 5-95

- B. Procedure (REPAIR 7-1, Figure 601)

- (1) Remove the sealant from the fasteners.
- (2) Remove nuts (429), bolts (417, 420), washers (423, 426).
- (3) Remove bearing housing assemblies (435, 438), crank assemblies (465, 492).
- (4) Pull out shaft (522) and remove spring (519) and sleeve (516).
- (5) If you find defects on the spring, sleeve, cranks, bearing housings, or shaft, refer to REPAIR 1-1, REPAIR 8-1, REPAIR 9-1 and REPAIR 23-1 for repair instructions.
- (6) Install a replacement spring (522) and sleeve (516) on the shaft.
- (7) Install crank assemblies (435, 438) on the shaft with bolts (417, 420), washers (423, 426) and nuts (429) with wet BMS 5-95 sealant, A00247 on mating surfaces. If you replaced the cranks or shaft with new ones, drill holes as shown for these fasteners, because the new cranks and shaft come with only pilot holes.
- (8) With a brush, apply BMS 5-95 sealant, A00247 to the threads and the mating components.




# 52-21-03

REPAIR 7-1

Page 601

Jul 01/2008

COMPONENT MAINTENANCE MANUAL




146A6509-1 Pressure Lock Mechanism Assembly Parts Replacement  
Figure 601 (Sheet 1 of 3)


**52-21-03**

REPAIR 7-1  
Page 602  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL



C-C



D-D

146A6509-1 Pressure Lock Mechanism Assembly Parts Replacement  
Figure 601 (Sheet 2 of 3)


**52-21-03**

REPAIR 7-1  
Page 603  
Jul 01/2007





## COMPONENT MAINTENANCE MANUAL



E-E

(SOME PARTS NOT SHOWN FOR CLARITY)

1 INSTALL WITH WET BMS 5-95  
SEALANT (SOPM 20-50-19 METHOD 2)  
THEN BRUSH SEALANT ON THREADED  
END OF FASTENER AND MATING  
COMPONENTS

125 ✓ ALL MACHINED SURFACES UNLESS  
SHOWN DIFFERENTLY

ITEM NUMBERS REFER TO IPL FIG. 3

ALL DIMENSIONS ARE IN INCHES

146A6509-1 Pressure Lock Mechanism Assembly Parts Replacement  
Figure 601 (Sheet 3 of 3)

# 52-21-03

REPAIR 7-1  
Page 604  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### CRANK ASSEMBLY - REPAIR 8-1

146A6510-1, -3

#### 1. General

- A. This procedure tells how to replace the parts of crank assemblies (465, 492).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 3 for item numbers.

#### 2. Fastener Replacement

- A. Procedure (REPAIR 8-1, Figure 601 or REPAIR 8-1, Figure 602)
  - (1) Remove the nut, washers, bushing and bolt from the lug.
  - (2) If you find defects on the lug surfaces, refer to REPAIR 8-2 for repair instructions.
  - (3) Install replacement bolt, washers, bushing and nut on the lug as shown.

#### 3. Bushing Replacement

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
A00247	Sealant - Pressure And Environmental - Chromate Type	BMS 5-95

- B. References

Reference	Title
SOPM 20-50-03	BEARING AND BUSHING REPLACEMENT

- C. Procedure (REPAIR 8-1, Figure 601)

- (1) Remove the old bushings.
- (2) If you find defects on the hole surfaces, refer to REPAIR 8-2 for repair instructions.
- (3) Install replacement bushings by the shrink fit method (SOPM 20-50-03) with BMS 5-95 sealant, A00247 as the installation finish.




# 52-21-03

REPAIR 8-1

Page 601

Jul 01/2008

COMPONENT MAINTENANCE MANUAL




125 ✓ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

ITEM NUMBERS REFER TO IPL FIG. 3

ALL DIMENSIONS ARE IN INCHES

146A6510-1 Crank Assembly Parts Replacement  
 Figure 601

COMPONENT MAINTENANCE MANUAL



125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

ITEM NUMBERS REFER TO IPL FIG. 3

ALL DIMENSIONS ARE IN INCHES

146A6510-3 Crank Assembly Parts Replacement  
Figure 602

**52-21-03**

REPAIR 8-1

Page 603

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### CRANK - REPAIR 8-2

146A6510-101, -103

#### 1. General

- A. This procedure tells how to repair and refinish cranks (489, 513).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 3 for item numbers.
- D. General repair details:
  - (1) Material: 15-5PH CRES, 180-200 ksi
  - (2) Shot peen: not necessary

#### 2. Crank Repair (REPAIR 8-2, Figure 601 or REPAIR 8-2, Figure 602)

- A. Procedure
  - (1) Repair is only replacement of the original refinish. Refer to REPAIR 8-2, Paragraph 3. for details.
  - (2) If you think there are defects on important surfaces, see REPAIR 8-2, Figure 601 or REPAIR 8-2, Figure 602 for dimension details.

#### 3. Crank Refinish (Fig 601 or 602)

##### A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

##### B. Procedure

**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Passivate (F-17.25).


# 52-21-03

REPAIR 8-2

Page 601

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



REFERENCE NUMBER	[1]	[2]	[3]	[4]	[5]
DESIGN DIMENSION	0.1600 0.1400	1.0100 0.9900	0.1600 0.1400	0.5785 0.5765	0.3756 0.3750
REPAIR LIMIT	—	—	—	—	—

1 PILOT HOLE ON NEW CRANKS, TO BE DRILLED TO FINAL SIZE FOR FASTENER INSTALLATION (REPAIR 7-1)

125 ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ALL DIMENSIONS ARE IN INCHES

146A6510-101 Crank Repair and Refinish  
Figure 601


**52-21-03**

REPAIR 8-2

Page 602

Jul 01/2007

COMPONENT MAINTENANCE MANUAL




146A6510-103 Crank Repair and Refinish  
Figure 602 (Sheet 1 of 2)

**52-21-03**

REPAIR 8-2  
Page 603  
Jul 01/2007



COMPONENT MAINTENANCE MANUAL



C-C

REFERENCE NUMBER	[1]	[2]	[3]	[4]	[5]	[6]	[7]
DESIGN DIMENSION	0.2600 0.2500	0.5785 0.5765	0.1600 0.1400	1.0400 1.0200	0.1600 0.1400	0.3756 0.3750	0.5006 0.5000
REPAIR LIMIT	—	—	—	—	—	—	—

[1] PILOT HOLE ON NEW CRANKS, TO BE DRILLED TO FINAL SIZE FOR FASTENER INSTALLATION (REPAIR 7-1)

125 ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ALL DIMENSIONS ARE IN INCHES

146A6510-103 Crank Repair and Refinish  
Figure 602 (Sheet 2 of 2)

**52-21-03**





## COMPONENT MAINTENANCE MANUAL

### BEARING HOUSING ASSEMBLY - REPAIR 9-1

146A6512-1, -3

#### 1. General

- A. This procedure tells how to replace the parts of bearing housing assemblies (435, 438).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 3 for item numbers.

#### 2. Fastener Replacement

- A. Procedure (REPAIR 9-1, Figure 601 or REPAIR 9-1, Figure 602)
  - (1) Remove the nut, washers, bushing and bolt from the lug.
  - (2) If you find defects on the housing surfaces, refer to REPAIR 9-2 for repair instructions.
  - (3) Install a replacement bolt, washers, bushing and nut on the lug as shown.

#### 3. Bearing Replacement

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
A00247	Sealant - Pressure And Environmental - Chromate Type	BMS 5-95

- B. References

Reference	Title
SOPM 20-50-03	BEARING AND BUSHING REPLACEMENT

- C. Procedure (REPAIR 9-1, Figure 601 or REPAIR 9-1, Figure 602)

- (1) Remove the old bearings.
- (2) If you find defects on the hole surfaces, refer to REPAIR 9-2 for repair instructions.
- (3) Install replacement bearings by the press fit method (SOPM 20-50-03) with BMS 5-95 sealant, A00247 as the installation finish. Swaging is not necessary.


# 52-21-03

REPAIR 9-1

Page 601

Jul 01/2008

COMPONENT MAINTENANCE MANUAL



ITEM NUMBERS REFER TO IPL FIG. 3

146A6512-1 Bearing Housing Assembly Parts Replacement  
Figure 601


**52-21-03**

REPAIR 9-1

Page 602

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



ITEM NUMBERS REFER TO IPL FIG. 3

146A6512-3 Bearing Housing Assembly Parts Replacement  
Figure 602

**52-21-03**

REPAIR 9-1  
Page 603  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### HOUSING - REPAIR 9-2

146A6512-101, -103

#### 1. General

- A. This procedure tells how to repair and refinish housing (459, 462).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 3 for item numbers.
- D. General repair details:
  - (1) Material: Al alloy
  - (2) Shot peen: not necessary

#### 2. Housing Repair

- A. Procedure (REPAIR 9-2, Figure 601 or REPAIR 9-2, Figure 602)
  - (1) Repair is only replacement of the original refinish. Refer to REPAIR 9-2, Paragraph 3. for details.
  - (2) If you think there are defects on important surfaces, see REPAIR 9-2, Figure 601 or REPAIR 9-2, Figure 602 for dimension details.

#### 3. Housing Refinish

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

- C. Procedure (REPAIR 9-2, Figure 601 or REPAIR 9-2, Figure 602)



**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Boric acid-sulfuric acid anodize or chromic acid anodize (F-17.31) all over.
- (2) Apply BMS 10-11, Type 1 primer, C00259 (F-20.03) but not in the hole for the bearing.

# 52-21-03

REPAIR 9-2  
Page 601  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL




146A6512-101 Bearing Housing Repair and Refinish  
Figure 601 (Sheet 1 of 2)

**52-21-03**

REPAIR 9-2  
Page 602  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL



REFERENCE NUMBER	[1]	[2]	[3]	[4]	[5]
DESIGN DIMENSION	0.2600 0.2500	0.1200 0.1000	0.7823 0.7813	0.3500 0.3450	0.7000 0.6750
REPAIR LIMIT	---	---	---	---	---

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES


ALL DIMENSIONS ARE IN INCHES

146A6512-101 Bearing Housing Repair and Refinish  
Figure 601 (Sheet 2 of 2)

**52-21-03**

REPAIR 9-2  
Page 603  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL




146A6512-103 Bearing Housing Repair and Refinish  
Figure 602 (Sheet 1 of 2)

**52-21-03**

REPAIR 9-2  
Page 604  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL



REFERENCE NUMBER	[1]	[2]	[3]	[4]	[5]
DESIGN DIMENSION	0.2600 0.2500	1.1300 0.1100	0.7823 0.7813	0.7000 0.6750	0.3500 0.3450
REPAIR LIMIT	—	—	—	—	—

**1** PILOT HOLE ON NEW HOUSINGS, TO BE DRILLED TO FINAL SIZE FOR FASTENER INSTALLATION (REPAIR 7-1)

ALL DIMENSIONS ARE IN INCHES

146A6512-103 Bearing Housing Repair and Refinish  
Figure 602 (Sheet 2 of 2)

**52-21-03**

REPAIR 9-2  
Page 605  
Jul 01/2007





## COMPONENT MAINTENANCE MANUAL

### LATCH SHAFT ASSEMBLY - REPAIR 10-1

146A6520-1

#### 1. General

- A. This procedure tells how to replace the parts of latch shaft assembly (576).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices shown in the repair.
- C. Refer to IPL Figure 3 for item numbers.

#### 2. Parts Replacement

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
A00247	Sealant - Pressure And Environmental - Chromate Type	BMS 5-95

- B. Procedure (REPAIR 10-1, Figure 601)

- (1) Remove the sealant from the fasteners.
- (2) Remove nuts (591), bolts (579, 582), washers (585, 588).
- (3) Remove bearing housing assemblies (435, 438), crank assemblies (465, 492).
- (4) Pull out shaft (651) and remove springs (636, 642) and sleeves (633, 645).
- (5) If you find defects on the springs, sleeves, catches, cranks, bearing housings, or shaft, refer to REPAIR 1-1, REPAIR 11-1, REPAIR 12-1 and REPAIR 13-1 for repair instructions.
- (6) Install replacement springs (636, 642) and sleeves (633, 645) on the shaft.
- (7) Install catches (633, 648), and crank assemblies (597, 621) on the shaft with bolts (579, 582), washers (585, 588) and nuts (591) with wet BMS 5-95 sealant, A00247 on mating surfaces unless shown differently by flagnote 4. If you replaced the catches, cranks or shaft with new ones, drill holes as shown for these fasteners, because the new catches, cranks and shaft come with only pilot holes.
- (8) If you replaced the shaft, also drill drain holes in the new shaft as shown, because the new shaft does not come with them.
- (9) With a brush, apply BMS 5-95 sealant, A00247 to the threads and the mating components.


# 52-21-03

REPAIR 10-1

Page 601

Jul 01/2008

COMPONENT MAINTENANCE MANUAL




146A6520-1 Latch Shaft Assembly Parts Replacement  
Figure 601 (Sheet 1 of 7)

**52-21-03**

REPAIR 10-1  
Page 602  
Jul 01/2007



COMPONENT MAINTENANCE MANUAL




146A6520-1 Latch Shaft Assembly Parts Replacement  
Figure 601 (Sheet 3 of 7)

**52-21-03**

REPAIR 10-1  
Page 604  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL







146A6520-1 Latch Shaft Assembly Parts Replacement  
Figure 601 (Sheet 4 of 7)

**52-21-03**

REPAIR 10-1  
Page 605  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL







146A6520-1 Latch Shaft Assembly Parts Replacement  
Figure 601 (Sheet 5 of 7)

**52-21-03**

REPAIR 10-1  
Page 606  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL




146A6520-1 Latch Shaft Assembly Parts Replacement  
Figure 601 (Sheet 6 of 7)

**52-21-03**

REPAIR 10-1  
Page 607  
Jul 01/2007

## COMPONENT MAINTENANCE MANUAL



S-S

- 1 ASSEMBLE PARTS WITH BMS 5-95 CORROSION FAYING SURFACE SEALANT (SOPM 20-50-19), BUT NOT SPRINGS OR PARTS NOTED BY 4
- 2 APPLY A LAYER OF BMS 5-95 SEALANT TO ALL HOLE SURFACES ON EACH SIDE BY THE BRUSH, INJECTION, OR OTHER METHODS (SOPM 20-50-19). THEN INSTALL THE FASTENER WITH WET BMS 5-95 SEALANT (SOPM 20-50-19, METHOD 1)
- 3 BRUSH SEAL THREADED END OF FASTENER AND MATING COMPONENTS (SOPM 20-50-19)
- 4 AFTER YOU DRILL THE HOLE AND REMOVE BURRS, TEMPORARILY ASSEMBLE THE COMPONENTS WITH PANDUIT STRAPS OR EQUIVALENT

125 ✓ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 3

ALL DIMENSIONS ARE IN INCHES

146A6520-1 Latch Shaft Assembly Parts Replacement  
Figure 601 (Sheet 7 of 7)

# 52-21-03

REPAIR 10-1

Page 608

Jul 01/2007





## COMPONENT MAINTENANCE MANUAL

### SHAFT - REPAIR 11-1

146A6521-1

#### 1. General

- A. This procedure tells how to repair and refinish shaft (651).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 3 for item numbers.
- D. General repair details:
  - (1) Material: 15-5PH CRES, 180-200 ksi
  - (2) Shot peen: not necessary
- E. The engineering requirements for this shaft are controlled by sections. Note the zones in REPAIR 11-1, Figure 601.

#### 2. Shaft Repair

- A. Procedure (REPAIR 11-1, Figure 601)
  - (1) Attachment holes
    - (a) Repair is only replacement of the original finish. Refer to REPAIR 11-1, Paragraph 3. below for details.
    - (b) If you think there are defects on important surfaces, see REPAIR 11-1, Figure 601 for dimension details.
  - (2) Shaft surfaces
    - (a) Remove small defects by standard industry practices.
    - (b) Refinish as indicated.

#### 3. Shaft Refinish

##### A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

##### B. Procedure

**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Passivate (F-17.25).


# 52-21-03

REPAIR 11-1

Page 601

Jul 01/2007

COMPONENT MAINTENANCE MANUAL




146A6521-1 Shaft Repair and Refinish  
Figure 601 (Sheet 1 of 2)

**52-21-03**

REPAIR 11-1  
Page 602  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL



(A)

(B)

REFERENCE NUMBER	[1]	[2]	[3]	[4]	[5]	[6]	[7]	[8]	[9]
DESIGN DIMENSION	0.9995 0.9990	0.9995 0.9895	0.9995 0.9895	0.9995 0.9895	0.9995 0.9895	0.9995 0.9990	0.7990 0.7970	0.6900 0.6800	0.7990 0.7970
REPAIR LIMIT	---	---	---	---	---	---	---	---	---

- 1 PILOT HOLE ON NEW SHAFTS TO BE DRILLED TO FINAL SIZE FOR FASTENER INSTALLATION (REPAIR 10-1)
  - 2 0.1100-0.1300 TOOL RUNOUT RADIUS AT LOCATIONS F THRU K IS PERMITTED FOR TOLERANCE TRANSITIONS OF OD
- 125 ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY  
BREAK ALL SHARP EDGES  
ALL DIMENSIONS ARE IN INCHES

146A6521-1 Shaft Repair and Refinish  
Figure 601 (Sheet 2 of 2)

**52-21-03**



## COMPONENT MAINTENANCE MANUAL

### LATCH CRANK ASSEMBLY - REPAIR 12-1

146A6522-1

#### 1. General

- A. This procedure tells how to replace the parts of latch crank assembly (597).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 3 for item numbers.

#### 2. Parts Replacement

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
D00633	Grease - Aircraft General Purpose	BMS3-33

- B. References

Reference	Title
SOPM 20-50-02	INSTALLATION OF SAFETYING DEVICES
SOPM 20-50-03	BEARING AND BUSHING REPLACEMENT

- C. Procedure (REPAIR 12-1, Figure 601)

- (1) Remove the cotter pin, nut, washers and bearing from the lug.
- (2) If you find defects on the crank surfaces, refer to REPAIR 12-2 for repair instructions.
- (3) Install a replacement bearing, washers and nut on the lug by the procedure for studed track roller bearings in SOPM 20-50-03, and as shown, with BMS 3-33 grease, D00633 on the threads.
- (4) Install a new cotter pin (SOPM 20-50-02).


# 52-21-03

REPAIR 12-1

Page 601

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



ITEM NUMBERS REFER TO IPL FIG. 3

146A6522-1 Latch Crank Assembly Parts Replacement  
Figure 601

**52-21-03**

REPAIR 12-1  
Page 602  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### LATCH CRANK - REPAIR 12-2

146A6522-101

#### 1. General

- A. This procedure tells how to repair and refinish latch crank (618).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 3 for item numbers.
- D. General repair details:
  - (1) Material: 15-5PH CRES, 180-200 ksi
  - (2) Shot peen: not necessary

#### 2. Latch Crank Repair

- A. Procedure (REPAIR 12-2, Figure 601)
  - (1) Repair is only replacement of the original refinish. Refer to REPAIR 12-2, Paragraph 3. for details.
  - (2) If you think there are defects on important surfaces, see REPAIR 12-2, Figure 601 for dimension details.

#### 3. Crank Refinish

##### A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

##### B. Procedure (REPAIR 12-2, Figure 601)

**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Passivate (F-17.25).


# 52-21-03

REPAIR 12-2

Page 601

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



REFERENCE NUMBER	[1]	[2]	[3]
DESIGN DIMENSION	0.3756 0.3750	0.5460 0.5410	0.7960 0.7950
REPAIR LIMIT	—	—	—

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ALL DIMENSIONS ARE IN INCHES

146A6522-101 Latch Crank Repair and Refinish  
Figure 601

**52-21-03**

REPAIR 12-2

Page 602

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### HANDLE CRANK ASSEMBLY - REPAIR 13-1

146A6524-1

#### 1. General

- A. This procedure tells how to replace the parts of handle crank assembly (621).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 3 for item numbers.

#### 2. Bushing Replacement

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
A00247	Sealant - Pressure And Environmental - Chromate Type	BMS 5-95

- B. References

Reference	Title
SOPM 20-50-03	BEARING AND BUSHING REPLACEMENT

- C. Procedure (REPAIR 13-1, Figure 601)

- (1) Remove the old bushings.
- (2) If you find defects on the crank surfaces, refer to REPAIR 13-2 for repair instructions.
- (3) Install replacement bushings by the shrink fit procedure (SOPM 20-50-03) with BMS 5-95 sealant, A00247 as the installation finish.
- (4) Machine the bushings to design dimensions and finish.

# 52-21-03


REPAIR 13-1

Page 601

Jul 01/2008



COMPONENT MAINTENANCE MANUAL



146A6524-1 Handle Crank Assembly Bushing Replacement  
Figure 601

**52-21-03**

REPAIR 13-1  
Page 602  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### HANDLE CRANK - REPAIR 13-2

146A6524-101

#### 1. General

- A. This procedure tells how to repair and refinish handle crank (630).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 3 for item numbers.
- D. General repair details:
  - (1) Material: 15-5PH CRES, 180-200 ksi
  - (2) Shot peen: not necessary

#### 2. Handle Crank Repair

- A. Procedure (REPAIR 13-2, Figure 601)
  - (1) Repair is only replacement of the original refinish. Refer to REPAIR 13-2, Paragraph 3. for details.
  - (2) If you think there are defects on important surfaces, see REPAIR 13-2, Figure 601 for dimension details.

#### 3. Handle Crank Refinish

##### A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

##### B. Procedure (REPAIR 13-2, Figure 601)

**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Passivate (F-17.25).





# 52-21-03

REPAIR 13-2

Page 601

Jul 01/2007

COMPONENT MAINTENANCE MANUAL




146A6524-101 Handle Crank Repair and Refinish  
Figure 601 (Sheet 1 of 2)

**52-21-03**

REPAIR 13-2  
Page 602  
Jul 01/2007



COMPONENT MAINTENANCE MANUAL



REFERENCE NUMBER	[1]	[2]	[3]	[4]	[5]	[6]
DESIGN DIMENSION	0.2600 0.2400	1.0385 1.0185	0.2600 0.2400	1.0035 1.0015	0.5006 0.5000	0.3756 0.3750
REPAIR LIMIT	—	—	—	—	—	—

1 PILOT HOLE ON NEW CRANKS, TO BE DRILLED TO FINAL SIZE FOR FASTENER INSTALLATION (REPAIR 10-1)

125 ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ALL DIMENSIONS ARE IN INCHES

146A6524-101 Handle Crank Repair and Refinish  
Figure 601 (Sheet 2 of 2)

**52-21-03**

REPAIR 13-2  
Page 603  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### OUTSIDE HANDLE ASSEMBLY - REPAIR 14-1

146A6526-1

#### 1. General

- A. This procedure tells how to replace the parts of outside handle assembly (635).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 2 for item numbers.

#### 2. Bushing Replacement

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
A00247	Sealant - Pressure And Environmental - Chromate Type	BMS 5-95

- B. References

Reference	Title
SOPM 20-50-03	BEARING AND BUSHING REPLACEMENT

- C. Procedure (REPAIR 14-1, Figure 601)

- (1) Remove the old bushings.
- (2) If you find defects on the handle surfaces, refer to REPAIR 14-2 for repair instructions.
- (3) Install replacement bushings by the shrink fit method (SOPM 20-50-03) with BMS 5-95 sealant, A00247 as the installation finish.

#### 3. Bearing Replacement

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
A00247	Sealant - Pressure And Environmental - Chromate Type	BMS 5-95

- B. References

Reference	Title
SOPM 20-50-03	BEARING AND BUSHING REPLACEMENT

- C. Procedure (REPAIR 14-1, Figure 601)

- (1) Remove the old bearings.
- (2) If you find defects on the handle surfaces, refer to REPAIR 14-2 for repair instructions.
- (3) Install replacement bearings by the press fit method (SOPM 20-50-03) with BMS 5-95 sealant, A00247 as the installation finish. Swaging is not necessary.


# 52-21-03

REPAIR 14-1

Page 601

Jul 01/2008

COMPONENT MAINTENANCE MANUAL




146A6526-1 Outside Handle Assembly Parts Replacement  
Figure 601 (Sheet 1 of 2)

**52-21-03**


REPAIR 14-1  
Page 602  
Jul 01/2007



COMPONENT MAINTENANCE MANUAL



B-B



C-C

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 2

ALL DIMENSIONS ARE IN INCHES

146A6526-1 Outside Handle Assembly Parts Replacement  
Figure 601 (Sheet 2 of 2)

**52-21-03**

REPAIR 14-1

Page 603

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### OUTSIDE HANDLE - REPAIR 14-2

146A6526-101

#### 1. General

- A. This procedure tells how to repair and refinish outside handle (655).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 2 for item numbers.
- D. General repair details:
  - (1) Material: Al alloy
  - (2) Shot peen: not necessary

#### 2. Handle Repair

- A. Procedure (REPAIR 14-2, Figure 601)
  - (1) Repair is only replacement of the original refinish. Refer to REPAIR 14-2, Paragraph 3. for details.
  - (2) If you think there are defects on important surfaces, see REPAIR 14-2, Figure 601 for dimension details.

#### 3. Handle Refinish

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
C00033	Coating - Exterior Protective Enamel, Flexibility Use	BMS10-60, Type II
C00175	Primer - Urethane Compatible, Corrosion Resistant (Less Than 1% Aromatic Amines)	BMS10-79, Type III

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

- C. Procedure (REPAIR 14-2, Figure 601)

**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Boric acid-sulfuric acid anodize or chromic acid anodize (F-17.31) all over.
- (2) Apply BMS 10-79, Type 3 primer, C00175 (F-19.66) but not in the holes for the bushings or bearings.
- (3) Apply BMS 10-60, Type 2 coating, C00033 (F-19.39-707) but not in the holes for the bushings or bearings.

# 52-21-03


REPAIR 14-2

Page 601

Jul 01/2007



COMPONENT MAINTENANCE MANUAL




146A6526-101 Outside Handle Repair and Refinish  
 Figure 601 (Sheet 1 of 2)

**52-21-03**

REPAIR 14-2  
 Page 602  
 Jul 01/2007



COMPONENT MAINTENANCE MANUAL



REFERENCE NUMBER	[1]	[2]	[3]	[4]
DESIGN DIMENSION	0.6882 0.6875	0.5006 0.5000	0.8752 0.8747	0.5725 0.5525
REPAIR LIMIT	—	—	—	—

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ALL DIMENSIONS ARE IN INCHES

146A6526-101 Outside Handle Repair and Refinish  
Figure 601 (Sheet 2 of 2)

**52-21-03**

REPAIR 14-2  
Page 603  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### HANDLE LINK ASSEMBLY - REPAIR 15-1

146A6527-1

#### 1. General

- A. This procedure tells how to replace the parts of handle link assembly (620).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 2 for item numbers.

#### 2. Bearing Replacement

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
A00247	Sealant - Pressure And Environmental - Chromate Type	BMS 5-95

- B. References

Reference	Title
SOPM 20-50-03	BEARING AND BUSHING REPLACEMENT

- C. Procedure (REPAIR 15-1, Figure 601)

- (1) Remove the old bearings.
- (2) If you find defects on the link surfaces, refer to REPAIR 15-2 for repair instructions.
- (3) Install replacement bearings and roller swage them (SOPM 20-50-03) with BMS 5-95 sealant, A00247 as the installation finish.


# 52-21-03

REPAIR 15-1

Page 601

Jul 01/2008

### COMPONENT MAINTENANCE MANUAL



ITEM NUMBERS REFER TO IPL FIG. 2

146A6527-1 Handle Link Assembly Parts Replacement  
Figure 601

# 52-21-03

REPAIR 15-1  
Page 602  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### HANDLE LINK - REPAIR 15-2

146A6527-101

#### 1. General

- A. This procedure tells how to repair and refinish handle link (630).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 2 for item numbers.
- D. General repair details:
  - (1) Material: 15-5PH CRES, 180-200 ksi
  - (2) Shot peen: not necessary

#### 2. Link Repair

- A. Procedure (REPAIR 15-2, Figure 601)
  - (1) Repair is only replacement of the original refinish. Refer to REPAIR 15-2, Paragraph 3. for details.
  - (2) If you think there are defects on important surfaces, see REPAIR 15-2, Figure 601 for dimension details.

#### 3. Link Refinish

- A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

- B. Procedure (REPAIR 15-2, Figure 601)

**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Passivate (F-17.25).



# 52-21-03

REPAIR 15-2


Page 601

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



CHAMFER  
 50° X 0.0350  
 40° X 0.0300  
 (4 LOCATIONS)



⊕	∅ 0.0100	M	A	B
⊥	∅ 0.0040	A		

(2 LOCATIONS)

REFERENCE NUMBER	[1]	[2]
DESIGN DIMENSION	0.8755 0.8750	0.3600 0.3400
REPAIR LIMIT	—	—

146A6527-101 Handle Link Repair and Refinish  
 Figure 601

**52-21-03**

REPAIR 15-2  
 Page 602  
 Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### PUSH ROD ASSEMBLY - REPAIR 16-1

146A6530-1, -2

#### 1. General

- A. This procedure tells how to replace the parts of push rod assemblies (90, 140).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices shown in the repair.
- C. Refer to IPL Figure 2 for item numbers.

#### 2. Parts Replacement

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
G50136	Paste - Corrosion Inhibiting, Non-drying	BMS 3-38

- B. Procedure (REPAIR 16-1, Figure 601 or REPAIR 16-1, Figure 602)
  - (1) Disassemble the push rod assemblies by standard industry practices.
  - (2) Replace parts as necessary.
  - (3) If you find defects on vent door push rod (105), refer to REPAIR 16-2 for repair instructions.
  - (4) Assemble the parts with BMS 3-38 corrosion inhibiting non-drying paste, G50136 on the mating threads. Remove unwanted compound after assembly.
  - (5) Adjust the push rod assemblies to the length shown.
  - (6) Tighten the jam nuts only hand-tight, because the push rod assemblies will be adjusted to final length when they are installed in the door assembly.



# 52-21-03

REPAIR 16-1

Page 601

Jul 01/2008

COMPONENT MAINTENANCE MANUAL



A-A

1 APPLY A THIN LAYER OF BMS 3-38  
 CORROSION PREVENTIVE COMPOUND TO  
 THREADS

2 TIGHTEN HAND-TIGHT

ITEM NUMBERS REFER TO IPL FIG. 2

ALL DIMENSIONS ARE IN INCHES

146A6530-1 Push Rod Assembly Parts Replacement  
 Figure 601

**52-21-03**



REPAIR 16-1

Page 602

Jul 01/2007



COMPONENT MAINTENANCE MANUAL



A-A

1 APPLY A THIN LAYER OF BMS 3-38  
CORROSION PREVENTIVE COMPOUND TO  
THREADS

2 TIGHTEN HAND-TIGHT

ITEM NUMBERS REFER TO IPL FIG. 2

ALL DIMENSIONS ARE IN INCHES

146A6530-2 Push Rod Assembly Parts Replacement  
Figure 602

**52-21-03**

REPAIR 16-1

Page 603

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### VENT DOOR PUSH ROD - REPAIR 16-2

146A6531-1

#### 1. General

- A. This procedure tells how to repair and refinish vent door push rod (105).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 2 for item numbers.
- D. General repair details:
  - (1) Material: 15-5PH CRES, 180-200 ksi
  - (2) Shot peen: not necessary

#### 2. Rod Repair

- A. Procedure (REPAIR 16-2, Figure 601)
  - (1) Repair is only replacement of the original refinish. Refer to REPAIR 16-2, Paragraph 3. for details.
  - (2) If you think there are defects on important surfaces, see REPAIR 16-2, Figure 601 for dimension details.

#### 3. Rod Refinish

- A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

- B. Procedure (REPAIR 16-2, Figure 601)

**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Passivate (F-17.25).

# 52-21-03


REPAIR 16-2

Page 601

Jul 01/2007




COMPONENT MAINTENANCE MANUAL



CHAMFER TO  
MINOR DIA  
(EACH END)

0.3125-24 UNJF-3A  
THREAD (SAE AS8879)  
(EACH END)



A-A

ALL DIMENSIONS ARE IN INCHES

146A6531-1 Vent Door Push Rod Repair and Refinish  
Figure 601

**52-21-03**

REPAIR 16-2

Page 602

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### OUTSIDE HANDLE SHAFT ASSEMBLY - REPAIR 17-1

146A6532-1

#### 1. General

- A. This procedure tells how to replace the parts of outside handle shaft assembly (380).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices shown in the repair.
- C. Refer to IPL Figure 2 for item numbers.

#### 2. Parts Replacement

- A. Procedure (REPAIR 17-1, Figure 601)
  - (1) Remove the fasteners if any are installed.
  - (2) Remove crank assemblies (385, 420) from shaft (440).
  - (3) If you find defects on the cranks or shaft, refer to REPAIR 18-1, REPAIR 19-1 and REPAIR 20-1 for repair instructions.
  - (4) Install crank assemblies (385, 420) on the shaft. If you replaced the cranks or shaft with new ones, drill holes as shown for the fasteners, because the new cranks and shaft come with only pilot holes.
  - (5) Temporarily hold the components together with Panduit straps or something equivalent.



# 52-21-03

REPAIR 17-1

Page 601

Jul 01/2007

COMPONENT MAINTENANCE MANUAL




146A6532-1 Outside Handle Shaft Assembly Parts Replacement  
Figure 601 (Sheet 1 of 2)

**52-21-03**

REPAIR 17-1  
Page 602  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL



1 USE THE PILOT HOLE IN THE CRANK AS A GUIDE. REMOVE THE BURRS. TEMPORARILY ASSEMBLE THE COMPONENTS WITH PANDUIT STRAPS OR EQUIVALENT.

ITEM NUMBERS REFER TO IPL FIG. 2  
ALL DIMENSIONS ARE IN INCHES

146A6532-1 Outside Handle Shaft Assembly Parts Replacement  
Figure 601 (Sheet 2 of 2)

# 52-21-03

REPAIR 17-1  
Page 603  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### OUTSIDE HANDLE CRANK ASSEMBLY - REPAIR 18-1

146A6535-1

#### 1. General

- A. This procedure tells how to replace the parts of outside handle crank assembly (420).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 2 for item numbers.

#### 2. Bushing Replacement

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
A00247	Sealant - Pressure And Environmental - Chromate Type	BMS 5-95

- B. References

Reference	Title
SOPM 20-50-03	BEARING AND BUSHING REPLACEMENT

- C. Procedure (REPAIR 18-1, Figure 601)

- (1) Remove the old bushings.
- (2) If you find defects on the hole surfaces, refer to REPAIR 18-2 for repair instructions.
- (3) Install replacement bushings by the shrink fit method (SOPM 20-50-03) with BMS 5-95 sealant, A00247 as the installation finish.
- (4) Machine the bushings to design dimensions and finish.



# 52-21-03

REPAIR 18-1

Page 601

Jul 01/2008

COMPONENT MAINTENANCE MANUAL



125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

ITEM NUMBERS REFER TO IPL FIG. 2

ALL DIMENSIONS ARE IN INCHES

146A6535-1 Outside Handle Crank Assembly Parts Replacement  
Figure 601

**52-21-03**

REPAIR 18-1

Page 602

Jul 01/2007





## COMPONENT MAINTENANCE MANUAL

### CRANK - REPAIR 18-2

146A6535-101

#### 1. General

- A. This procedure tells how to repair and refinish crank (435).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 2 for item numbers.
- D. General repair details:
  - (1) Material: 15-5PH CRES, 180-200 ksi
  - (2) Shot peen: not necessary

#### 2. Crank Repair

- A. Procedure (REPAIR 18-2, Figure 601)
  - (1) Repair is only replacement of the original refinish. Refer to REPAIR 18-2, Paragraph 3. for details.
  - (2) If you think there are defects on important surfaces, see REPAIR 18-2, Figure 601 for dimension details.

#### 3. Crank Refinish

- A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

- B. Procedure (REPAIR 18-2, Figure 601)

**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Passivate (F-17.25).




# 52-21-03

REPAIR 18-2

Page 601

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



146A6535-101 Outside Handle Crank Assembly Parts Replacement  
Figure 601 (Sheet 1 of 2)

**52-21-03**

REPAIR 18-2  
Page 602  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

REFERENCE NUMBER	[1]	[2]	[3]	[4]	[5]	[6]	[7]
DESIGN DIMENSION	0.8785 0.8765	0.6882 0.6875	0.2100 0.1900	0.2100 0.1900	0.6750 0.6550	1.2850 1.2650	0.5006 0.5000
REPAIR LIMIT	—	—	—	—	—	—	—

125/√ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ALL DIMENSIONS ARE IN INCHES

146A6535-101 Outside Handle Crank Assembly Parts Replacement  
Figure 601 (Sheet 2 of 2)

# 52-21-03

REPAIR 18-2

Page 603

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### HANDLE LINK CRANK ASSEMBLY - REPAIR 19-1

146A6536-1

#### 1. General

- A. This procedure tells how to replace the parts of handle link crank assembly (385).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 2 for item numbers.

#### 2. Fastener Replacement

- A. Procedure (REPAIR 19-1, Figure 601)
  - (1) Remove the collar, bushing, washer and bolt from the lug.
  - (2) If you find defects on the lug surfaces, refer to REPAIR 19-2 for repair instructions.
  - (3) Install replacement bolt, washer, bushing and collar on the lug as shown.

#### 3. Bushing Replacement

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
A00247	Sealant - Pressure And Environmental - Chromate Type	BMS 5-95

- B. References

Reference	Title
SOPM 20-50-03	BEARING AND BUSHING REPLACEMENT

- C. Procedure (REPAIR 19-1, Figure 601)

- (1) Remove the old bushing.
- (2) If you find defects on the hole surfaces, refer to REPAIR 19-2 for repair instructions.
- (3) Install a replacement bushing by the shrink fit method (SOPM 20-50-03) with BMS 5-95 sealant, A00247 as the installation finish.
- (4) Machine the bushing to design dimensions and finish.


# 52-21-03

REPAIR 19-1

Page 601

Jul 01/2008

COMPONENT MAINTENANCE MANUAL



125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 2

ALL DIMENSIONS ARE IN INCHES

146A6536-1 Handle Link Crank Assembly Parts Replacement  
Figure 601

**52-21-03**

REPAIR 19-1

Page 602

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### CRANK - REPAIR 19-2

146A6536-101

#### 1. General

- A. This procedure tells how to repair and refinish crank (415).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 2 for item numbers.
- D. General repair details:
  - (1) Material: 15-5PH CRES, 180-200 ksi
  - (2) Shot peen: not necessary

#### 2. Crank Repair

- A. Procedure (REPAIR 19-2, Figure 601)
  - (1) Repair is only replacement of the original refinish. Refer to REPAIR 19-2, Paragraph 3. for details.
  - (2) If you think there are defects on important surfaces, see REPAIR 19-2, Figure 601 for dimension details.

#### 3. Crank Refinish

- A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

- B. Procedure (REPAIR 19-2, Figure 601)

**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Passivate (F-17.25).



# 52-21-03

REPAIR 19-2


Page 601

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



A-A



B-B

146A6536-101 Handle Link Crank Repair and Refinish  
Figure 601 (Sheet 1 of 2)

**52-21-03**

REPAIR 19-2  
Page 602  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

REFERENCE NUMBER	[1]	[2]	[3]	[4]	[5]	[6]	[7]	[8]	[9]
DESIGN DIMENSION	0.8785	0.5100	0.2100	0.4500	1.0600	0.1500	0.5006	0.2540	0.1920
	0.8765	0.4900	0.1900	0.4300	1.0400	0.1300	0.5000	0.2500	0.1890
REPAIR LIMIT	—	—	—	—	—	—	—	—	—

125/ ✓ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ALL DIMENSIONS ARE IN INCHES

146A6536-101 Handle Link Crank Repair and Refinish  
Figure 601 (Sheet 2 of 2)

# 52-21-03

REPAIR 19-2

Page 603

Jul 01/2007





## COMPONENT MAINTENANCE MANUAL

### OUTSIDE HANDLE CRANK SHAFT - REPAIR 20-1

146A6537-1

#### 1. General

- A. This procedure tells how to repair and refinish shaft (440).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 2 for item numbers.
- D. General repair details:
  - (1) Material: 15-5PH CRES, 180-200 ksi
  - (2) Shot peen: not necessary

#### 2. Shaft Repair

- A. Procedure (REPAIR 20-1, Figure 601)
  - (1) Repair is only replacement of the original refinish. Refer to REPAIR 20-1, Paragraph 3. for details.
  - (2) If you think there are defects on important surfaces, see REPAIR 20-1, Figure 601 for dimension details.

#### 3. Shaft Refinish

##### A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

##### B. Procedure (REPAIR 20-1, Figure 601)

**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Passivate (F-17.25).


# 52-21-03

REPAIR 20-1

Page 601

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



REFERENCE NUMBER	[1]	[2]
DESIGN DIMENSION	0.8745 0.8735	0.4995 0.4985
REPAIR LIMIT	—	—

125/√ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ALL DIMENSIONS ARE IN INCHES

146A6537-1 Outside Handle Crank Shaft Repair and Refinish  
Figure 601

**52-21-03**

REPAIR 20-1  
Page 602  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### VENT DOOR MECHANISM ASSEMBLY - REPAIR 21-1

146A6539-1, -3

#### 1. General

- A. This procedure tells how to replace the parts of vent door mechanism assembly (55).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices shown in the repair.
- C. Refer to IPL Figure 2 for item numbers.

#### 2. Parts Replacement

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
A00247	Sealant - Pressure And Environmental - Chromate Type	BMS 5-95

- B. References

Reference	Title
SOPM 20-50-19	GENERAL SEALING

- C. Procedure (REPAIR 21-1, Figure 601)

- (1) Remove the sealant from the fasteners.
- (2) Remove cotter pins (60, 110), nuts (80, 130), bolts (65, 115), washers (70, 75, 120, 125), bushings (85, 135) and push rod assemblies (90, 140).
- (3) Remove bearing housing assemblies (210, 215).
- (4) Remove door fasteners and crank assembly (235). Put the door fasteners back on the lugs of the door.
- (5) Pull out shaft (255) and remove springs (195, 200), washers (175, 180, 185, 190) and sleeve (205).
- (6) If you find defects on the push rods (90, 140), springs (195, 200), bearing housings (210, 215), cranks (235), shaft (255), or vent door (260), refer to REPAIR 16-1, REPAIR 21-1, REPAIR 22-1, REPAIR 23-1, REPAIR 24-1 and REPAIR 25-1 for repair instructions.
- (7) Install replacement springs (195, 200), and sleeve (205) with washers (175, 180, 185, 190) on the shaft.
- (8) Install crank assembly (235) on the shaft with the door fasteners.
- (9) Install bearing housing assemblies (210, 215) on the ends of the shaft.
- (10) Install push rod assemblies (90, 140) with bolts (65, 115), washers (70, 75, 120, 125), bushings (85, 135) and nuts (80, 130). Install the fasteners with wet BMS 5-95 sealant, A00247 on mating surfaces (SOPM 20-50-19, Method 2). If you replaced the crank or shaft with new ones, drill holes as shown for these fasteners, because the new cranks and shaft come with only pilot holes. But before you drill holes in a new shaft, be sure the shaft lobes are in the positions shown.
- (11) With a brush, apply BMS 5-95 sealant, A00247 to the threads and the mating components.


# 52-21-03

REPAIR 21-1

Page 601

Jul 01/2008

COMPONENT MAINTENANCE MANUAL





146A6539-1,-3 Vent Door Mechanism Assembly Parts Replacement  
Figure 601 (Sheet 1 of 4)

**52-21-03**

REPAIR 21-1  
Page 602  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL




146A6539-1,-3 Vent Door Mechanism Assembly Parts Replacement  
Figure 601 (Sheet 2 of 4)

**52-21-03**

REPAIR 21-1  
Page 603  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL




D-D  
(PUSH RODS NOT SHOWN FOR CLARITY)

146A6539-1,-3 Vent Door Mechanism Assembly Parts Replacement  
Figure 601 (Sheet 3 of 4)

**52-21-03**

REPAIR 21-1  
Page 604  
Jul 01/2007

## COMPONENT MAINTENANCE MANUAL



E-E

- 1 INSTALL WITH WET BMS 5-95 SEALANT (SOPM 20-50-19 METHOD 2) THEN BRUSH SEALANT ON THREADED END OF FASTENER AND MATING COMPONENTS
- 2 BE SURE THE SHAFT LOBES ARE IN THIS POSITION BEFORE YOU DRILL HOLES FOR FASTENERS

125 ✓ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

ITEM NUMBERS REFER TO IPL FIG. 2  
ALL DIMENSIONS ARE IN INCHES

146A6539-1,-3 Vent Door Mechanism Assembly Parts Replacement  
Figure 601 (Sheet 4 of 4)

# 52-21-03

REPAIR 21-1  
Page 605  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### VENT DOOR ASSEMBLY - REPAIR 22-1

146A6540-1

#### 1. General

- A. This procedure tells how to replace the parts of vent door assembly (260).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 2 for item numbers.

#### 2. Fastener Replacement

##### A. References

Reference	Title
SOPM 20-50-19	GENERAL SEALING

##### B. Procedure (REPAIR 22-1, Figure 601)

- (1) Remove the nuts, bushings, washers and bolts from the lugs.
- (2) If you find defects on the lug surfaces, refer to REPAIR 22-2 for repair instructions.
- (3) Install replacement bolts, washers, bushings and nuts on the lug with BMS 5-95 sealant (SOPM 20-50-19) as shown.
- (4) With a brush, apply BMS 5-45, Class A sealant (SOPM 20-50-19) to the fasteners as shown.

#### 3. Bushing Replacement

##### A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
A00247	Sealant - Pressure And Environmental - Chromate Type	BMS 5-95

##### B. References

Reference	Title
SOPM 20-50-03	BEARING AND BUSHING REPLACEMENT

##### C. Procedure (REPAIR 22-1, Figure 601)

- (1) Remove the old bushings.
- (2) If you find defects on the hole surfaces, refer to REPAIR 22-2 for repair instructions.
- (3) Install replacement bushings by the shrink fit method (SOPM 20-50-03) with BMS 5-95 sealant, A00247 as the installation finish.
- (4) Machine the indicated bushings to design dimensions and finish.

#### 4. Seal Replacement

##### A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

# 52-21-03

REPAIR 22-1

Page 601

Jul 01/2008





## COMPONENT MAINTENANCE MANUAL

Reference	Description	Specification
A00027	Adhesive - Silicone Rubber, 1 Part, RTV	BAC5010, Type 60
A00281	Adhesive - Dow Corning 3145 RTV	MIL-A-46146 (BAC5010, Type 79)

### B. References

Reference	Title
SOPM 20-50-12	APPLICATION OF ADHESIVES


### C. Procedure (REPAIR 22-1, Figure 601)

- (1) Remove the old seal (305).
- (2) If you find defects on the door surfaces, refer to REPAIR 22-2 for repair instructions.
- (3) Install a replacement seal as shown with Type 60 adhesive, A00027 or Type 79 Dow Corning 3145 RTV adhesive, A00281 (SOPM 20-50-12). Be careful to keep the vent holes open.

# 52-21-03

REPAIR 22-1  
Page 602  
Jul 01/2009

COMPONENT MAINTENANCE MANUAL




146A6540-1,-3 Vent Door Assembly Parts Replacement  
Figure 601 (Sheet 1 of 4)

**52-21-03**

REPAIR 22-1  
Page 603  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL




146A6540-1,-3 Vent Door Assembly Parts Replacement  
Figure 601 (Sheet 2 of 4)

**52-21-03**

REPAIR 22-1  
Page 604  
Jul 01/2007




COMPONENT MAINTENANCE MANUAL



E-E

FASTENERS NOT SHOWN FOR CLARITY  
(SEE VIEW G-G FOR FASTENERS)




146A6540-1,-3 Vent Door Assembly Parts Replacement  
Figure 601 (Sheet 3 of 4)

**52-21-03**

REPAIR 22-1  
Page 605  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL



BUSHINGS (297) NOT SHOWN FOR CLARITY  
(SEE VIEW E-E FOR BUSHINGS)

- 1 MAKE SURE VENT HOLES ARE NOT CLOGGED WITH ADHESIVE
- 2 ADJUSTMENT OF BUSHING BORES NOT NECESSARY AFTER INSTALLATION
- 3 PUT SEAL TABS INTO DOOR AND BOND SEAL WITH TYPE 60 OR 79 ADHESIVE (SOPM 20-50-12)
- 4 INSTALL BUSHINGS AND FASTENERS WITH BMS 5-95 SEALANT (SOPM 20-50-19 METHOD 2)
- 5 BRUSH SEAL HEAD SIDE OF FASTENER AND MATING COMPONENTS WITH BMS 5-45 CLASS A SEALANT (SOPM 20-50-19)

- 125 ✓ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY
- BREAK ALL SHARP EDGES
- ITEM NUMBERS REFER TO IPL FIG. 2
- ALL DIMENSIONS ARE IN INCHES

146A6540-1,-3 Vent Door Assembly Parts Replacement  
Figure 601 (Sheet 4 of 4)

# 52-21-03

REPAIR 22-1  
Page 606  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### VENT DOOR - REPAIR 22-2

146A6540-101

#### 1. General

- A. This procedure tells how to repair and refinish vent door (310).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 2 for item numbers.
- D. General repair details:
  - (1) Material: Al alloy
  - (2) Shot peen: not necessary

#### 2. Housing Repair

- A. Procedure (REPAIR 22-2, Figure 601)
  - (1) Repair is only replacement of the original refinish. Refer to REPAIR 22-2, Paragraph 3. for details.
  - (2) If you think there are defects on important surfaces, see REPAIR 22-2, Figure 601 for dimension details.

#### 3. Housing Refinish

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
C00033	Coating - Exterior Protective Enamel, Flexibility Use	BMS10-60, Type II
C00175	Primer - Urethane Compatible, Corrosion Resistant (Less Than 1% Aromatic Amines)	BMS10-79, Type III

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

- C. Procedure (REPAIR 22-2, Figure 601)



**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Boric acid-sulfuric acid anodize or chromic acid anodize (F-17.31) all over.
- (2) Apply BMS 10-79, Type 3 primer, C00175 (F-19.66) but not in the holes.
- (3) Apply BMS 10-60, Type 2 coating, C00033 (F-19.39-707) to the surfaces shown.

# 52-21-03

REPAIR 22-2  
Page 601  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL




146A6540-101 Vent Door Repair and Refinish  
Figure 601 (Sheet 1 of 3)

**52-21-03**

REPAIR 22-2  
Page 602  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL



146A6540-101 Vent Door Repair and Refinish  
 Figure 601 (Sheet 2 of 3)


**52-21-03**

REPAIR 22-2  
 Page 603  
 Jul 01/2007





COMPONENT MAINTENANCE MANUAL



D-D

REFERENCE NUMBER	[1]	[2]	[3]	[4]
DESIGN DIMENSION	0.2540	0.2540	0.7509	0.3756
	0.2500	0.2500	0.7500	0.3750
REPAIR LIMIT	—	—	—	—

1 THIS IS AN EXTERIOR AERODYNAMIC SURFACE. APPLY BMS 10-60, TYPE 2 ENAMEL (F-19.39-707) TO THIS SURFACE. APPROXIMATELY ONE INCH OVERSPRAY IS PERMITTED.

125 ✓ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY  
 BREAK ALL SHARP EDGES  
 ALL DIMENSIONS ARE IN INCHES

146A6540-101 Vent Door Repair and Refinish  
 Figure 601 (Sheet 3 of 3)

**52-21-03**

REPAIR 22-2  
 Page 604  
 Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### SHAFT - REPAIR 23-1

146A6545-1, -3

#### 1. General

- A. This procedure tells how to repair and refinish shaft (255, IPL Figure 2; 522, IPL Figure 3).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 2 or IPL Figure 3 for item numbers.
- D. General repair details:
  - (1) Material: 15-5PH CRES, 180-200 ksi
  - (2) Shot peen: not necessary

#### 2. Shaft Repair

- A. Procedure (REPAIR 23-1, Figure 601 or REPAIR 23-1, Figure 602)
  - (1) Repair is only replacement of the original finish. Refer to REPAIR 23-1, Paragraph 3. below for details.
  - (2) If you think there are defects on important surfaces, see REPAIR 23-1, Figure 601 or REPAIR 23-1, Figure 602 for dimension details.

#### 3. Shaft Refinish

##### A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

##### B. Procedure

**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Passivate (F-17.25).



# 52-21-03

REPAIR 23-1

Page 601


Jul 01/2007

COMPONENT MAINTENANCE MANUAL




CHAMFER  
 46° X 0.03  
 44° X 0.01  
 (EACH END)

A-A



B-B




146A6545-1 Shaft Repair and Refinish  
 Figure 601

**52-21-03**

REPAIR 23-1  
 Page 602  
 Jul 01/2007



COMPONENT MAINTENANCE MANUAL



REFERENCE NUMBER	[1]	[2]	[3]	[4]	[5]	[6]	[7]	[8]	[9]
DESIGN DIMENSION	0.3120 0.3115	0.5455 0.5450	0.6245 0.6235	0.3800 0.3650	0.6245 0.6235	1.0300 0.9700	0.5050 0.4900	0.3120 0.3115	0.1260 0.1250
REPAIR LIMIT	—	—	—	—	—	—	—	—	—

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES


ALL DIMENSIONS ARE IN INCHES

146A6545-1 Shaft Repair and Refinish  
Figure 602

**52-21-03**

REPAIR 23-1  
Page 603  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL



REFERENCE NUMBER	[1]	[2]	[3]	[4]	[5]
DESIGN DIMENSION	0.1260 0.1250	0.3130 0.3120	0.5755 0.5745	0.3130 0.3120	4.7900 4.7800
REPAIR LIMIT	—	—	—	—	—

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ALL DIMENSIONS ARE IN INCHES

146A6545-3 Shaft Repair and Refinish  
 Figure 603

**52-21-03**

REPAIR 23-1

Page 604

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### BEARING HOUSING ASSEMBLY - REPAIR 24-1

146A6546-1, -2

#### 1. General

- A. This procedure tells how to replace the parts of bearing housing assemblies (210, 215).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 2 for item numbers.

#### 2. Bearing Replacement

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
A00247	Sealant - Pressure And Environmental - Chromate Type	BMS 5-95

- B. References

Reference	Title
SOPM 20-50-03	BEARING AND BUSHING REPLACEMENT

- C. Procedure (REPAIR 24-1, Figure 601)

- (1) Remove the old bearing.
- (2) If you find defects on the hole surfaces, refer to REPAIR 24-2 for repair instructions.
- (3) Install a replacement bearing by the press fit method (SOPM 20-50-03) with BMS 5-95 sealant, A00247 as the installation finish. Swaging is not necessary.


# 52-21-03

REPAIR 24-1


Page 601

Jul 01/2008

COMPONENT MAINTENANCE MANUAL



146A6546-1 SHOWN  
146A6546-2 OPPOSITE



A-A

ITEM NUMBERS REFER TO IPL FIG. 2

146A6546-1,-2 Bearing Housing Assembly Parts Replacement  
Figure 601

**52-21-03**

REPAIR 24-1

Page 602

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### HOUSING - REPAIR 24-2

146A6546-101, -102

#### 1. General

- A. This procedure tells how to repair and refinish housing (225, 230).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 2 for item numbers.
- D. General repair details:
  - (1) Material: Al alloy
  - (2) Shot peen: not necessary

#### 2. Housing Repair

- A. Procedure (REPAIR 24-2, Figure 601)
  - (1) Repair is only replacement of the original refinish. Refer to REPAIR 24-2, Paragraph 3. for details.
  - (2) If you think there are defects on important surfaces, see REPAIR 24-2, Figure 601 for dimension details.

#### 3. Housing Refinish

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

- C. Procedure (REPAIR 24-2, Figure 601)

**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Boric acid-sulfuric acid anodize or chromic acid anodize (F-17.31) all over.
- (2) Apply BMS 10-11, Type 1 primer, C00259 (F-20.03) but not in the hole for the bearing.

# 52-21-03


REPAIR 24-2

Page 601


Jul 01/2007



COMPONENT MAINTENANCE MANUAL



146A6546-101 SHOWN  
146A6546-102 OPPOSITE




146A6546-101,-102 Bearing Housing Repair and Refinish  
Figure 601 (Sheet 1 of 2)

**52-21-03**

REPAIR 24-2  
Page 602  
Jul 01/2007



COMPONENT MAINTENANCE MANUAL



REFERENCE NUMBER	[1]	[2]	[3]
DESIGN DIMENSION	0.7823 0.7813	0.350 0.345	0.700 0.675
REPAIR LIMIT	—	—	—

125  $\checkmark$  ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ALL DIMENSIONS ARE IN INCHES

146A6546-101,-102 Bearing Housing Repair and Refinish  
Figure 601 (Sheet 2 of 2)

**52-21-03**

REPAIR 24-2

Page 603

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### VENT DOOR CRANK ASSEMBLY - REPAIR 25-1

146A6547-1

#### 1. General

- A. This procedure tells how to replace the parts of vent door crank assembly (235).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 2 for item numbers.

#### 2. Bushing Replacement

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
A00247	Sealant - Pressure And Environmental - Chromate Type	BMS 5-95

- B. References

Reference	Title
SOPM 20-50-03	BEARING AND BUSHING REPLACEMENT

- C. Procedure (REPAIR 25-1, Figure 601)

- (1) Remove the old bushings.
- (2) If you find defects on the hole surfaces, refer to REPAIR 25-2 for repair instructions.
- (3) Install replacement bushings by the shrink fit method (SOPM 20-50-03) with BMS 5-95 sealant, A00247 as the installation finish.
- (4) Machine the bushings to design dimensions and finish.



# 52-21-03

REPAIR 25-1


Page 601

Jul 01/2008

COMPONENT MAINTENANCE MANUAL



A-A



0.3756  
0.3750 DIA

32

$\oplus \ominus 0.0005 \text{ (M)}$   
(2 COAXIAL HOLES)

B-B

125  $\checkmark$  ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 2

ALL DIMENSIONS ARE IN INCHES

146A6547-1 Vent Door Crank Assembly Parts Replacement  
Figure 601

**52-21-03**

REPAIR 25-1

Page 602

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### CRANK - REPAIR 25-2

146A6547-101

#### 1. General

- A. This procedure tells how to repair and refinish crank (250).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 2 for item numbers.
- D. General repair details:
  - (1) Material: 15-5PH CRES, 180-200 ksi
  - (2) Shot peen: not necessary

#### 2. Crank Repair

- A. Procedure (REPAIR 25-2, Figure 601)
  - (1) Repair is only replacement of the original refinish. Refer to REPAIR 25-2, Paragraph 3. for details.
  - (2) If you think there are defects on important surfaces, see REPAIR 25-2, Figure 601 for dimension details.

#### 3. Crank Refinish

##### A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

##### B. Procedure (REPAIR 25-2, Figure 601)

**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Passivate (F-17.25).



# 52-21-03

REPAIR 25-2

Page 601

Jul 01/2007

COMPONENT MAINTENANCE MANUAL




146A6547-101 Vent Door Crank Repair and Refinish  
Figure 601 (Sheet 1 of 2)

**52-21-03**

REPAIR 25-2  
Page 602  
Jul 01/2007



COMPONENT MAINTENANCE MANUAL



REFERENCE NUMBER	[1]	[2]	[3]	[4]	[5]	[6]	[7]
DESIGN DIMENSION	0.3756 0.3750	0.1100 0.0900	0.9100 0.8900	0.1600 0.1400	0.5006 0.5000	0.5485 0.5465	0.1300 0.1260
REPAIR LIMIT	—	—	—	—	—	—	—

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ALL DIMENSIONS ARE IN INCHES

146A6547-101 Vent Door Crank Repair and Refinish  
Figure 601 (Sheet 2 of 2)

**52-21-03**

REPAIR 25-2  
Page 603  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### SNUBBER FITTING ASSEMBLY - REPAIR 26-1

146A6551-1

#### 1. General

- A. This procedure tells how to replace the parts of snubber fitting assembly (275).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 4 for item numbers.

#### 2. Bushing Replacement

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
A00247	Sealant - Pressure And Environmental - Chromate Type	BMS 5-95

- B. References

Reference	Title
SOPM 20-50-03	BEARING AND BUSHING REPLACEMENT

- C. Procedure (REPAIR 26-1, Figure 601)

- (1) Remove the old bushings.
- (2) If you find defects on the hole surfaces, refer to REPAIR 26-2 for repair instructions.
- (3) Install replacement bushings by the shrink fit method (SOPM 20-50-03) with BMS 5-95 sealant, A00247 as the installation finish.
- (4) Machine only bushing (280) to design dimensions and finish. Do not machine bushings (285), because they have a self-lubricated liner and flange face and are made to give final dimensions after installation without adjustment.

# 52-21-03


REPAIR 26-1

Page 601

Jul 01/2008



COMPONENT MAINTENANCE MANUAL




146A6551-1 Snubber Fitting Assembly Bushing Replacement  
Figure 601 (Sheet 1 of 2)

**52-21-03**

REPAIR 26-1  
Page 602  
Jul 01/2007



COMPONENT MAINTENANCE MANUAL



125/ ✓ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 4

ALL DIMENSIONS ARE IN INCHES

146A6551-1 Snubber Fitting Assembly Bushing Replacement  
Figure 601 (Sheet 2 of 2)

**52-21-03**

REPAIR 26-1

Page 603

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### SNUBBER FITTING - REPAIR 26-2

146A6551-101

#### 1. General

- A. This procedure tells how to repair and refinish snubber fitting (290).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 4 for item numbers.
- D. General repair details:
  - (1) Material: Al alloy
  - (2) Shot peen: not necessary

#### 2. Fitting Repair

- A. Procedure (REPAIR 26-2, Figure 601)
  - (1) Repair is only replacement of the original refinish. Refer to REPAIR 26-2, Paragraph 3. for details.
  - (2) If you think there are defects on important surfaces, see REPAIR 26-2, Figure 601 for dimension details.

#### 3. Fitting Refinish

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

- C. Procedure (REPAIR 26-2, Figure 601)


**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Boric acid-sulfuric acid anodize or chromic acid anodize (F-17.31) all over.
- (2) Apply BMS 10-11, Type 1 primer, C00259 (F-20.03) but not in the hole for the bearing.

# 52-21-03

REPAIR 26-2  
Page 601  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL



A-A  
(BASIC DIMENSIONS)

146A6551-101 Snubber Fitting Repair and Refinish  
Figure 601 (Sheet 1 of 3)


**52-21-03**

REPAIR 26-2

Page 602

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



A-A  
(REPAIR DIMENSIONS)

146A6551-101 Snubber Fitting Repair and Refinish  
Figure 601 (Sheet 2 of 3)

**52-21-03**



REPAIR 26-2  
Page 603  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL

[4] DIA

$\oplus$	$\varnothing$ 0.0100	(M)	B	A	C
	$\varnothing$ 0.0050	(M)			
$\perp$	$\varnothing$ 0.0040	(M)	B		

(2 COAXIAL HOLES)



REFERENCE NUMBER	[1]	[2]	[3]	[4]	[5]	[6]	[7]
DESIGN DIMENSION	0.1300 0.1200	0.1940 0.1900	0.1940 0.1900	0.5006 0.5000	0.5627 0.5620	0.5631 0.5625	0.5631 0.5625
REPAIR LIMIT	—	—	—	—	—	—	—

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ALL DIMENSIONS ARE IN INCHES

146A6551-101 Snubber Fitting Repair and Refinish  
Figure 601 (Sheet 3 of 3)

**52-21-03**



## COMPONENT MAINTENANCE MANUAL

### UPPER SNUBBER SUPPORT IDLER ASSEMBLY - REPAIR 27-1

146A6552-1, -2

#### 1. General

- A. This procedure tells how to replace the parts of upper snubber support idler assemblies (295, 300).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 4 for item numbers.

#### 2. Bearing (305) Replacement

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
D00633	Grease - Aircraft General Purpose	BMS3-33

- B. References

Reference	Title
SOPM 20-50-03	BEARING AND BUSHING REPLACEMENT

- C. Procedure (REPAIR 27-1, Figure 601)

- (1) Remove the old bearings (305) and the bushing (315) between them.
- (2) If you find defects on the hole surfaces, refer to REPAIR 27-2 for repair instructions.
- (3) Install replacement bearings (305), with bushing (315) between them, by the press fit method (SOPM 20-50-03) with BMS 3-33 grease, D00633 as the installation finish. Swaging is not necessary.

#### 3. Bearing (310) Replacement

- A. References

Reference	Title
SOPM 20-50-03	BEARING AND BUSHING REPLACEMENT

- B. Procedure (REPAIR 27-1, Figure 601)

- (1) Remove the old bearing.
- (2) If you find defects on the hole surfaces, refer to REPAIR 27-2 for repair instructions.
- (3) Install a replacement bearing and roller swage it (SOPM 20-50-03).
- (4) Give the bearing an 1150-pound push-out proof load test.


# 52-21-03

REPAIR 27-1

Page 601

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



146A6552-1 SHOWN  
146A6552-2 OPPOSITE

ITEM NUMBERS REFER TO IPL FIG. 4

146A6552-1,-2 Upper Snubber Support Idler Assembly Parts Replacement  
Figure 601

**52-21-03**

REPAIR 27-1

Page 602

Jul 01/2007





## COMPONENT MAINTENANCE MANUAL

### UPPER SNUBBER SUPPORT IDLER - REPAIR 27-2

146A6552-101, -102

#### 1. General

- A. This procedure tells how to repair and refinish upper snubber support idler (320, 325).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 4 for item numbers.
- D. General repair details:
  - (1) Material: Al alloy
  - (2) Shot peen: not necessary

#### 2. Idler Repair

- A. Procedure (REPAIR 27-2, Figure 601)
  - (1) Repair is only replacement of the original refinish. Refer to REPAIR 27-2, Paragraph 3. for details.
  - (2) If you think there are defects on important surfaces, see REPAIR 27-2, Figure 601 for dimension details.

#### 3. Idler Refinish

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

- C. Procedure (REPAIR 27-2, Figure 601)



**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Boric acid-sulfuric acid anodize or chromic acid anodize (F-17.31) all over.
- (2) Apply BMS 10-11, Type 1 primer, C00259 (F-20.03) but not in the hole for the bearing.

# 52-21-03

REPAIR 27-2  
Page 601  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL




A-A  
 146A6552-101 SHOWN  
 146A6552-1022 OPPOSITE

146A6552-101,-102 Upper Snubber Support Idler Repair and Refinish  
 Figure 601 (Sheet 1 of 2)

**52-21-03**

REPAIR 27-2  
 Page 602  
 Jul 01/2007

COMPONENT MAINTENANCE MANUAL



REFERENCE NUMBER	[1]	[2]	[3]
DESIGN DIMENSION	0.6885 0.6875	0.2540 0.2500	0.8135 0.8125
REPAIR LIMIT	---	---	---

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ALL DIMENSIONS ARE IN INCHES

146A6552-101,-102 Upper Snubber Support Idler Repair and Refinish  
Figure 601 (Sheet 2 of 2)

**52-21-03**

REPAIR 27-2  
Page 603  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### LOWER SNUBBER SUPPORT IDLER ASSEMBLY - REPAIR 28-1

146A6553-1

#### 1. General

- A. This procedure tells how to replace the parts of lower snubber support idler assembly (380).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 4 for item numbers.

#### 2. Bearing (385) Replacement

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
D00633	Grease - Aircraft General Purpose	BMS3-33

- B. References

Reference	Title
SOPM 20-50-03	BEARING AND BUSHING REPLACEMENT

- C. Procedure (REPAIR 28-1, Figure 601)

- (1) Remove the old bearings (385) and the bushing (390) between them.
- (2) If you find defects on the hole surfaces, refer to REPAIR 28-2 for repair instructions.
- (3) Install replacement bearings (385), with bushing (390) between them, by the press fit method (SOPM 20-50-03) with BMS 3-33 grease, D00633 as the installation finish. Swaging is not necessary.



# 52-21-03

REPAIR 28-1

Page 601

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



A-A

ITEM NUMBERS REFER TO IPL FIG. 4

146A6553-1 Lower Snubber Support Idler Assembly Parts Replacement  
Figure 601

**52-21-03**

REPAIR 28-1  
Page 602  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### LOWER SNUBBER SUPPORT IDLER - REPAIR 28-2

146A6553-101

#### 1. General

- A. This procedure tells how to repair and refinish lower snubber support idler (395).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 4 for item numbers.
- D. General repair details:
  - (1) Material: Al alloy
  - (2) Shot peen: not necessary

#### 2. Idler Repair

- A. Procedure (REPAIR 28-2, Figure 601)
  - (1) Repair is only replacement of the original refinish. Refer to REPAIR 28-2, Paragraph 3. for details.
  - (2) If you think there are defects on important surfaces, see REPAIR 28-2, Figure 601 for dimension details.

#### 3. Idler Refinish

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

- C. Procedure (REPAIR 28-2, Figure 601)



**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Boric acid-sulfuric acid anodize or chromic acid anodize (F-17.31) all over.
- (2) Apply BMS 10-11, Type 1 primer, C00259 (F-20.03) but not in the hole for the bearing.

# 52-21-03

REPAIR 28-2  
Page 601  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL



A-A

146A6553-101 Lower Snubber Support Idler Repair and Refinish  
Figure 601 (Sheet 1 of 2)

**52-21-03**

REPAIR 28-2  
Page 602  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

REFERENCE NUMBER	[1]	[2]
DESIGN DIMENSION	0.8135 0.8125	0.2540 0.2500
REPAIR LIMIT	---	---

125/√ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ALL DIMENSIONS ARE IN INCHES

146A6553-101 Lower Snubber Support Idler Repair and Refinish  
Figure 601 (Sheet 2 of 2)

# 52-21-03

REPAIR 28-2

Page 603

Jul 01/2007





## COMPONENT MAINTENANCE MANUAL

### SNUBBER LINK ASSEMBLY - REPAIR 29-1

146A6554-1, -2

#### 1. General

- A. This procedure tells how to replace the parts of snubber link assemblies (400, 405).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 4 for item numbers.

#### 2. Bushing Replacement

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
A00247	Sealant - Pressure And Environmental - Chromate Type	BMS 5-95

- B. References

Reference	Title
SOPM 20-50-03	BEARING AND BUSHING REPLACEMENT

- C. Procedure (REPAIR 29-1, Figure 601)

- (1) Remove the old bushing.
- (2) If you find defects on the hole surfaces, refer to REPAIR 29-2 for repair instructions.
- (3) Install a replacement bushing by the shrink fit method (SOPM 20-50-03) with BMS 5-95 sealant, A00247 as the installation finish.
- (4) Do not machine this bushing, because it has a self-lubricated liner and flange face and is made to give final dimensions after installation without adjustment.


# 52-21-03

REPAIR 29-1


Page 601

Jul 01/2008

COMPONENT MAINTENANCE MANUAL



146A6554-1 SHOWN  
146A6554-2 OPPOSITE



ITEM NUMBERS REFER TO IPL FIG. 4

146A6554-1,-2 Snubber Link Assembly Bushing Replacement  
Figure 601

**52-21-03**

REPAIR 29-1  
Page 602  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### SNUBBER LINK - REPAIR 29-2

146A6554-101, -102

#### 1. General

- A. This procedure tells how to repair and refinish snubber links (415, 420).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 4 for item numbers.
- D. General repair details:
  - (1) Material: Al alloy
  - (2) Shot peen: not necessary

#### 2. Link Repair

- A. Procedure (REPAIR 29-2, Figure 601)
  - (1) Repair is only replacement of the original refinish. Refer to REPAIR 29-2, Paragraph 3. for details.
  - (2) If you think there are defects on important surfaces, see REPAIR 29-2, Figure 601 for dimension details.

#### 3. Link Refinish

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

- C. Procedure (REPAIR 29-2, Figure 601)


**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Boric acid-sulfuric acid anodize or chromic acid anodize (F-17.31) all over.
- (2) Apply BMS 10-11, Type 1 primer, C00259 (F-20.03) but not in the holes.



# 52-21-03

REPAIR 29-2  
Page 601  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL



146A6554-101 SHOWN  
146A6554-102 OPPOSITE



B-B


146A6554-101,-102 Snubber Link Repair and Refinish  
Figure 601 (Sheet 1 of 2)

**52-21-03**

REPAIR 29-2  
Page 602  
Jul 01/2007



COMPONENT MAINTENANCE MANUAL



REFERENCE NUMBER	[1]	[2]	[3]	[4]
DESIGN DIMENSION	0.3160 0.3120	0.5631 0.5625	0.3790 0.3750	0.2500 0.2300
REPAIR LIMIT	---	---	---	---

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ALL DIMENSIONS ARE IN INCHES

146A6554-101,-102 Snubber Link Repair and Refinish  
Figure 601 (Sheet 2 of 2)

**52-21-03**

REPAIR 29-2  
Page 603  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### LIFT ASSIST FITTING ASSEMBLY - REPAIR 30-1

146A6555-1, -2

#### 1. General

- A. This procedure tells how to replace the parts of lift assist fitting assemblies (250, 255).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 4 for item numbers.

#### 2. Bearing Replacement

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
A00247	Sealant - Pressure And Environmental - Chromate Type	BMS 5-95

- B. References

Reference	Title
SOPM 20-50-03	BEARING AND BUSHING REPLACEMENT

- C. Procedure (REPAIR 30-1, Figure 601)

- (1) Remove the old bearing.
- (2) If you find defects on the hole surfaces, refer to REPAIR 30-2 for repair instructions.
- (3) Install a replacement bearing and roller swage it (SOPM 20-50-03) with BMS 5-95 sealant, A00247 as the installation finish.
- (4) Give the bearing an 1150-pound push-out proof load test.


# 52-21-03

REPAIR 30-1


Page 601

Jul 01/2008

COMPONENT MAINTENANCE MANUAL



146A6555-1 SHOWN  
146A6555-2 OPPOSITE



A-A

ITEM NUMBERS REFER TO IPL FIG. 4

146A6555-1,-2 Lift Assist Fitting Assembly Bearing Replacement  
Figure 601

**52-21-03**

REPAIR 30-1  
Page 602  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### LIFT ASSIST FITTING - REPAIR 30-2

146A6555-101, -102

#### 1. General

- A. This procedure tells how to repair and refinish lift assist fitting (265, 270).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 4 for item numbers.
- D. General repair details:
  - (1) Material: Al alloy
  - (2) Shot peen: not necessary

#### 2. Fitting Repair

- A. Procedure (REPAIR 30-2, Figure 601)
  - (1) Repair is only replacement of the original refinish. Refer to REPAIR 30-2, Paragraph 3. for details.
  - (2) If you think there are defects on important surfaces, see REPAIR 30-2, Figure 601 for dimension details.

#### 3. Fitting Refinish

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

- C. Procedure (REPAIR 30-2, Figure 601)

**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.


- (1) Boric acid-sulfuric acid anodize or chromic acid anodize (F-17.31) all over.
- (2) Apply BMS 10-11, Type 1 primer, C00259 (F-20.03) but not in the hole for the bearing.

# 52-21-03


REPAIR 30-2  
Page 601  
Jul 01/2007



COMPONENT MAINTENANCE MANUAL



146A6555-101 SHOWN  
146A6555-102 OPPOSITE




146A6555-101,-102 Lift Assist Fitting Repair and Refinish  
Figure 601 (Sheet 1 of 2)

**52-21-03**

REPAIR 30-2  
Page 602  
Jul 01/2007



COMPONENT MAINTENANCE MANUAL



REFERENCE NUMBER	[1]	[2]	[3]	[4]
DESIGN DIMENSION	0.1940 0.1900	0.1300 0.1200	0.6885 0.6875	0.2600 0.2500
REPAIR LIMIT	—	—	—	—

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ALL DIMENSIONS ARE IN INCHES

146A6555-101,-102 Lift Assist Fitting Repair and Refinish  
 Figure 601 (Sheet 2 of 2)

**52-21-03**

REPAIR 30-2

Page 603

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### LIFT ASSIST SPRING ASSEMBLY - REPAIR 31-1

146A6556-1, -3

#### 1. General

- A. This procedure tells how to replace the parts of lift assist spring assembly (330).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices shown in the repair.
- C. Refer to IPL Figure 4 for item numbers.

#### 2. Parts Replacement

- A. Procedure (REPAIR 31-1, Figure 601)
  - (1) Pull the assembly apart.
  - (2) If you find defects on the spring, washers or end fittings, refer to REPAIR 1-1 and REPAIR 32-1 for repair instructions.
  - (3) Install a replacement spring and washers on the end fitting assemblies and put them together as shown.
  - (4) Use something to tie the parts together until the unit can be installed in the door linkage.


# 52-21-03

REPAIR 31-1

Page 601

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



ITEM NUMBERS REFER TO IPL FIG. 4

146A6556-1,-3 Lift Assist Spring Assembly Parts Replacement  
Figure 601

**52-21-03**

REPAIR 31-1

Page 602

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### END FITTING ASSEMBLY - REPAIR 32-1

146A6557-1, -2

#### 1. General

- A. This procedure tells how to replace the parts of end fitting assembly (335, 340).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 4 for item numbers.

#### 2. Bushing Replacement

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
A00247	Sealant - Pressure And Environmental - Chromate Type	BMS 5-95

- B. References

Reference	Title
SOPM 20-50-03	BEARING AND BUSHING REPLACEMENT

- C. Procedure (REPAIR 32-1, Figure 601 or REPAIR 32-1, Figure 602)

- (1) Remove the old bushings.
- (2) If you find defects on the hole surfaces, refer to REPAIR 32-2 for repair instructions.
- (3) Install replacement bushings by the shrink fit method (SOPM 20-50-03) with BMS 5-95 sealant, A00247 as the installation finish.
- (4) Machine the bushings to design dimensions and finish.



# 52-21-03

REPAIR 32-1

Page 601

Jul 01/2008

COMPONENT MAINTENANCE MANUAL



125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 4

ALL DIMENSIONS ARE IN INCHES

146A6557-1 End Fitting Assembly Bushing Replacement  
Figure 601



**52-21-03**

REPAIR 32-1

Page 602

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



A-A

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 4

ALL DIMENSIONS ARE IN INCHES

146A6557-2 End Fitting Assembly Bushing Replacement  
Figure 602

**52-21-03**

REPAIR 32-1

Page 603

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### END FITTING - REPAIR 32-2

146A6557-101, -102

#### 1. General

- A. This procedure tells how to repair and refinish end fittings (355, 360).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 4 for item numbers.
- D. General repair details:
  - (1) Material: Al-Ni-Bronze
  - (2) Shot peen: not necessary

#### 2. Fitting Repair

- A. Procedure (REPAIR 32-2, Figure 601 or REPAIR 32-2, Figure 602)
  - (1) Repair is only replacement of the original refinish. Refer to REPAIR 32-2, Paragraph 3. for details.
  - (2) If you think there are defects on important surfaces, see REPAIR 32-2, Figure 601 or REPAIR 32-2, Figure 602 for dimension details.

#### 3. Fitting Refinish

- A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

- B. Procedure (REPAIR 32-2, Figure 601 or REPAIR 32-2, Figure 602)

**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Apply no finish (F-25.01).

# 52-21-03


REPAIR 32-2

Page 601

Jul 01/2007



COMPONENT MAINTENANCE MANUAL



REFERENCE NUMBER	[1]	[2]	[3]	[4]	[5]	[6]	[7]
DESIGN DIMENSION	0.5100 0.4800	0.3756 0.3750	0.1300 0.1100	0.3536 0.3336	0.5770 0.5570	0.6970 0.6770	0.5006 0.5000
REPAIR LIMIT	—	—	—	—	—	—	—

125/63 ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ALL DIMENSIONS ARE IN INCHES

146A6557-101 End Fitting Repair and Refinish  
Figure 601


**52-21-03**

REPAIR 32-2

Page 602

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



REFERENCE NUMBER	[1]	[2]	[3]	[4]	[5]	[6]	[7]
DESIGN DIMENSION	0.3756 0.3750	0.1300 0.1100	0.3445 0.3425	0.5770 0.5570	0.6970 0.6770	0.5006 0.5000	0.5500 0.5300
REPAIR LIMIT	---	---	---	---	---	---	---

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ALL DIMENSIONS ARE IN INCHES

146A6557-102 End Fitting Repair and Refinish  
Figure 602

**52-21-03**

REPAIR 32-2

Page 603

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### SNUBBER MECHANISM ASSEMBLY - REPAIR 33-1

146A6562-1, -2

#### 1. General

- A. This procedure tells how to replace the parts of snubber mechanism assemblies (225, 230).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices shown in the repair
- C. Refer to IPL Figure 4 for item numbers.

#### 2. Parts Replacement

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
A00247	Sealant - Pressure And Environmental - Chromate Type	BMS 5-95

- B. References

Reference	Title
SOPM 20-50-19	GENERAL SEALING

- C. Procedure (REPAIR 33-1, Figure 601)

- (1) Remove the sealant from the fasteners.
- (2) Remove collars (245) and bolts (235, 240).
- (3) Remove lift assist fitting assembly (250 or 255) from snubber fitting assembly (275).
- (4) If you find defects on the fitting assemblies, refer to REPAIR 26-1 and REPAIR 30-1 for repair instructions.
- (5) Install a replacement lift assist fitting assembly (250 or 255) on the snubber fitting assembly (275).
- (6) Install bolts (235, 240) and collars (245) with BMS 5-95 sealant, A00247 on mating surfaces (SOPM 20-50-19, Method 2).



# 52-21-03

REPAIR 33-1

Page 601

Jul 01/2008

COMPONENT MAINTENANCE MANUAL



ITEM NUMBERS REFER TO IPL FIG. 4

146A6562-1,-2 Snubber Mechanism Assembly Parts Replacement  
Figure 601

**52-21-03**

REPAIR 33-1  
Page 602  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### LOCK SHAFT IDLER ASSEMBLY - REPAIR 34-1

146A6575-1, -3

#### 1. General

- A. This procedure tells how to replace the parts of lock shaft idler assemblies (144, 288).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 3 for item numbers.

#### 2. Bushing Replacement

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
A00247	Sealant - Pressure And Environmental - Chromate Type	BMS 5-95

- B. References

Reference	Title
SOPM 20-50-03	BEARING AND BUSHING REPLACEMENT

- C. Procedure (REPAIR 34-1, Figure 601 or REPAIR 34-1, Figure 602)

- (1) Remove the old bushings.
- (2) If you find defects on the hole surfaces, refer to REPAIR 34-2 for repair instructions.
- (3) Install replacement bushings by the shrink fit method (SOPM 20-50-03) with BMS 5-95 sealant, A00247 as the installation finish.
- (4) Machine the bushings to design dimensions and finish.


# 52-21-03

REPAIR 34-1

Page 601

Jul 01/2008

COMPONENT MAINTENANCE MANUAL



125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES


ITEM NUMBERS REFER TO IPL FIG. 3

ALL DIMENSIONS ARE IN INCHES


146A6575-1 Lock Shaft Idler Assembly Bushing Replacement  
Figure 601

**52-21-03**

COMPONENT MAINTENANCE MANUAL



A-A  
(ROTATED 90° CW)



125  $\sqrt{\quad}$  ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 3

ALL DIMENSIONS ARE IN INCHES

146A6575-3 Lock Shaft Idler Assembly Bushing Replacement  
Figure 602

**52-21-03**

REPAIR 34-1

Page 603

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### LOCK SHAFT IDLER - REPAIR 34-2

146A6575-101, -103

#### 1. General

- A. This procedure tells how to repair and refinish idlers (156, 300).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 3 for item numbers.
- D. General repair details:
  - (1) Material: 15-5PH CRES, 180-200 ksi
  - (2) Shot peen: not necessary

#### 2. Idler Repair

- A. Procedure (REPAIR 34-2, Figure 601 or REPAIR 34-2, Figure 602)
  - (1) Repair is only replacement of the original finish. Refer to REPAIR 34-2, Paragraph 3. below for details.
  - (2) If you think there are defects on important surfaces, see REPAIR 34-2, Figure 601 or REPAIR 34-2, Figure 602 for dimension details.

#### 3. Idler Refinish

##### A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

##### B. Procedure

**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Passivate (F-17.25).

# 52-21-03


REPAIR 34-2

Page 601

Jul 01/2007





COMPONENT MAINTENANCE MANUAL



[1] DIA

$\oplus$	$\ominus$	$\varnothing$ 0.0100	(M)	A	B	C	(S)
$\perp$	$\varnothing$	0.0040	(M)	A			




146A6575-101 Lock Shaft Idler Repair and Refinish  
Figure 601 (Sheet 1 of 2)

**52-21-03**

REPAIR 34-2  
Page 602  
Jul 01/2007



COMPONENT MAINTENANCE MANUAL



REFERENCE NUMBER	[1]	[2]	[3]	[4]	[5]	[6]	[7]	[8]
DESIGN DIMENSION	0.3773 0.3767	0.5631 0.5625	1.1500 1.1300	0.5006 0.5000	0.2600 0.2400	0.5370 0.5170	0.2600 0.2400	0.3756 0.3750
REPAIR LIMIT	---	---	---	---	---	---	---	---

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES



ALL DIMENSIONS ARE IN INCHES

146A6575-101 Lock Shaft Idler Repair and Refinish  
Figure 601 (Sheet 2 of 2)

**52-21-03**

REPAIR 34-2  
Page 603  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL




146A6575-103 Lock Shaft Idler Repair and Refinish  
Figure 602 (Sheet 1 of 2)

**52-21-03**

REPAIR 34-2  
Page 604  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL



REFERENCE NUMBER	[1]	[2]	[3]	[4]	[5]	[6]	[7]	[8]
DESIGN DIMENSION	0.5006 0.5000	0.2540 0.2500	1.5400 1.5200	0.3756 0.3750	0.5006 0.5000	0.2100 0.1900	0.5370 0.5170	0.9370 0.9170
REPAIR LIMIT	---	---	---	---	---	---	---	---

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ALL DIMENSIONS ARE IN INCHES

146A6575-103 Lock Shaft Idler Repair and Refinish  
Figure 602 (Sheet 2 of 2)

**52-21-03**

REPAIR 34-2  
Page 605  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### LOCK FITTING ASSEMBLY - REPAIR 35-1

146A6576-1, -3

#### 1. General

- A. This procedure tells how to replace the parts of lock fitting assemblies (159, 303).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 3 for item numbers.

#### 2. Bushing Replacement

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
A00247	Sealant - Pressure And Environmental - Chromate Type	BMS 5-95

- B. References

Reference	Title
SOPM 20-50-03	BEARING AND BUSHING REPLACEMENT

- C. Procedure (REPAIR 35-1, Figure 601 or REPAIR 35-1, Figure 602)

- (1) Remove the old bushings.
- (2) If you find defects on the hole surfaces, refer to REPAIR 35-2 for repair instructions.
- (3) Install replacement bushings by the shrink fit method (SOPM 20-50-03) with BMS 5-95 sealant, A00247 as the installation finish.
- (4) Machine the bushings to design dimensions and finish.



# 52-21-03

REPAIR 35-1

Page 601

Jul 01/2008

COMPONENT MAINTENANCE MANUAL



125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 3

ALL DIMENSIONS ARE IN INCHES

146A6576-1 Lock Fitting Assembly Bushing Replacement  
Figure 601


**52-21-03**

REPAIR 35-1

Page 602

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



146A6576-3 Lock Fitting Assembly Bushing Replacement  
Figure 602

**52-21-03**

REPAIR 35-1  
Page 603  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### LOCK FITTING - REPAIR 35-2

146A6576-101, -103

#### 1. General

- A. This procedure tells how to repair and refinish fittings (168, 312).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 3 for item numbers.
- D. General repair details:
  - (1) Material: 15-5PH CRES, 180-200 ksi
  - (2) Shot peen: not necessary

#### 2. Fitting Repair

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

- C. Procedure (REPAIR 35-2, Figure 601 or REPAIR 35-2, Figure 602)

**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) (1) Cadmium plate (F-16.06), but not in holes for bushings.
- (2) (2) Apply BMS 10-11, Type 1 primer, C00259 (F-20.03), but not in holes for bushings.

# 52-21-03



REPAIR 35-2

Page 601

Jul 01/2007



COMPONENT MAINTENANCE MANUAL




146A6576-101 Lock Fitting Repair and Refinish  
Figure 601 (Sheet 1 of 2)

**52-21-03**

REPAIR 35-2  
Page 602  
Jul 01/2007



COMPONENT MAINTENANCE MANUAL



C-C

REFERENCE NUMBER	[1]	[2]	[3]	[4]	[5]
DESIGN DIMENSION	1.7400 1.7200	1.4400 1.4200	0.1600 0.1400	0.5631 0.5625	0.4381 0.4375
REPAIR LIMIT	---	---	---	---	---

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES



ALL DIMENSIONS ARE IN INCHES

146A6576-101 Lock Fitting Repair and Refinish  
Figure 601 (Sheet 2 of 2)

**52-21-03**

REPAIR 35-2  
Page 603  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL




146A6576-103 Lock Fitting Repair and Refinish  
Figure 602 (Sheet 1 of 2)

**52-21-03**

REPAIR 35-2  
Page 604  
Jul 01/2007



COMPONENT MAINTENANCE MANUAL



[4] DIA

$\varnothing$	0.0100	(M)	A	B	C
$\varnothing$	0.0040	(M)	A	B	

(2 COAXIAL HOLES)

C-C

REFERENCE NUMBER	[1]	[2]	[3]	[4]	[5]
DESIGN DIMENSION	2.2400 2.2200	1.8400 1.8200	0.2100 0.1900	0.3756 0.3750	0.5006 0.5000
REPAIR LIMIT	---	---	---	---	---

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ALL DIMENSIONS ARE IN INCHES

146A6576-103 Lock Fitting Repair and Refinish  
Figure 602 (Sheet 2 of 2)

**52-21-03**

REPAIR 35-2  
Page 605  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### OVERCENTER SPRING FITTING ASSEMBLY - REPAIR 36-1

146A6577-1, -3

#### 1. General

- A. This procedure tells how to replace the parts of lift assist fitting assemblies (120, 129).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 3 for item numbers.

#### 2. Bearing Replacement

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
A00247	Sealant - Pressure And Environmental - Chromate Type	BMS 5-95

- B. References

Reference	Title
SOPM 20-50-03	BEARING AND BUSHING REPLACEMENT

- C. Procedure (REPAIR 36-1, Figure 601)

- (1) Remove the old bearing.
- (2) If you find defects on the hole surfaces, refer to REPAIR 36-2 for repair instructions.
- (3) Install a replacement bearing and roller swage it (SOPM 20-50-03) with BMS 5-95 sealant, A00247 as the installation finish.
- (4) Give the bearing an 1150-pound push-out proof load test.


# 52-21-03

REPAIR 36-1


Page 601

Jul 01/2008

COMPONENT MAINTENANCE MANUAL




146A6577-1 SHOWN  
146A6577-3 SIMILAR



A-A

FITTING (126,135)



BEARING (123A,132)

B-B

ITEM NUMBERS REFER TO IPL FIG. 3

146A6577-1,-3 Overcenter Spring Fitting Assembly Bearing Replacement  
Figure 601

**52-21-03**

REPAIR 36-1  
Page 602  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### OVERCENTER SPRING FITTING - REPAIR 36-2

146A6577-101, -103

#### 1. General

- A. This procedure tells how to repair and refinish fittings (126, 135).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 3 for item numbers.
- D. General repair details:
  - (1) Material (146A6577-101): 15-5PH CRES, 180-200 ksi
  - (2) Material (146A6577-103): Al-Ni-Bronze
  - (3) Shot peen: not necessary

#### 2. Fitting Repair

- A. Procedure (REPAIR 36-2, Figure 601 or REPAIR 36-2, Figure 602)
  - (1) Repair is only replacement of the original finish. Refer to REPAIR 36-2, Paragraph 3. below for details.
  - (2) If you think there are defects on important surfaces, see REPAIR 36-2, Figure 601 or REPAIR 36-2, Figure 602 for dimension details.

#### 3. Fitting Refinish

- A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

- B. Procedure (REPAIR 36-2, Figure 601 or REPAIR 36-2, Figure 602)

**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) 146A6577-101: No finish (F-25.01).
- (2) 146A6577-103: Passivate (F-17.25).


# 52-21-03

REPAIR 36-2

Page 601

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



REFERENCE NUMBER	[1]	[2]	[3]	[4]
DESIGN DIMENSION	1.0950 1.0700	0.8450 0.8200	0.6260 0.6250	0.3270 0.3170
REPAIR LIMIT	—	—	—	—



125  $\sqrt{\quad}$  ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY  
 BREAK ALL SHARP EDGES  
 ALL DIMENSIONS ARE IN INCHES

146A6577-101 Overcenter Spring Fitting Repair and Refinish  
 Figure 601

**52-21-03**



COMPONENT MAINTENANCE MANUAL



A-A

REFERENCE NUMBER	[1]	[2]	[3]	[4]
DESIGN DIMENSION	1.0950 1.0700	0.9000 0.8750	0.6260 0.6250	0.3270 0.3170
REPAIR LIMIT	—	—	—	—

125 ✓ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY  
BREAK ALL SHARP EDGES  
ALL DIMENSIONS ARE IN INCHES

146A6577-103 Overcenter Spring Fitting Repair and Refinish  
Figure 602

**52-21-03**



## COMPONENT MAINTENANCE MANUAL

### LINK ASSEMBLY - REPAIR 37-1

146A6578-1

#### 1. General

- A. This procedure tells how to replace the parts of link assembly (315).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 3 for item numbers.

#### 2. Bearing Replacement

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
A00247	Sealant - Pressure And Environmental - Chromate Type	BMS 5-95

- B. References

Reference	Title
SOPM 20-50-03	BEARING AND BUSHING REPLACEMENT

- C. Procedure (REPAIR 37-1, Figure 601)

- (1) Remove the old bearing.
- (2) If you find defects on the hole surfaces, refer to REPAIR 37-2 for repair instructions.
- (3) Install a replacement bearing and roller swage it (SOPM 20-50-03) with BMS 5-95 sealant, A00247 as the installation finish.
- (4) Give the bearing a 1050-pound push-out proof load test.


# 52-21-03

REPAIR 37-1

Page 601

Jul 01/2008

COMPONENT MAINTENANCE MANUAL



ITEM NUMBERS REFER TO IPL FIG. 3

146A6578-1 Link Assembly Bearing Replacement  
Figure 601

**52-21-03**

REPAIR 37-1  
Page 602  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### LINK - REPAIR 37-2

146A6578-101

#### 1. General

- A. This procedure tells how to repair and refinish link (321).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 3 for item numbers.
- D. General repair details:
  - (1) Material: Al alloy
  - (2) Shot peen: not necessary

#### 2. Link Repair

- A. Procedure (REPAIR 37-2, Figure 601)
  - (1) Repair is only replacement of the original refinish. Refer to REPAIR 37-2, Paragraph 3. for details.
  - (2) If you think there are defects on important surfaces, see REPAIR 37-2, Figure 601 for dimension details.

#### 3. Link Refinish

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

- C. Procedure (REPAIR 37-2, Figure 601)


**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Boric acid-sulfuric acid anodize or chromic acid anodize (F-17.31) all over.
- (2) Apply BMS 10-11, Type 1 primer, C00259 (F-20.03) but not in the holes for the bearings.

# 52-21-03

REPAIR 37-2  
Page 601  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL




146A6578-101 Link Repair and Refinish  
Figure 601 (Sheet 1 of 2)

**52-21-03**

REPAIR 37-2  
Page 602  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL



REFERENCE NUMBER	[1]	[2]	[3]
DESIGN DIMENSION	0.6260 0.6250	0.6260 0.6250	0.3270 0.3170
REPAIR LIMIT	—	—	—

125 / ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ALL DIMENSIONS ARE IN INCHES

146A6578-101 Link Repair and Refinish  
 Figure 601 (Sheet 2 of 2)

**52-21-03**

REPAIR 37-2

Page 603

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### LOCK TARGET ASSEMBLY - REPAIR 38-1

146A6579-1

#### 1. General

- A. This procedure tells how to replace the parts of lock target assembly (199).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 3 for item numbers.

#### 2. Bushing Replacement

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
A00247	Sealant - Pressure And Environmental - Chromate Type	BMS 5-95

- B. References

Reference	Title
SOPM 20-50-03	BEARING AND BUSHING REPLACEMENT

- C. Procedure (REPAIR 38-1, Figure 601)

- (1) Remove the old bushing.
- (2) If you find defects on the hole surfaces, refer to REPAIR 38-2 for repair instructions.
- (3) Install a replacement bushing by the shrink fit method (SOPM 20-50-03) with BMS 5-95 sealant, A00247 as the installation finish
- (4) Machine the bushing to design dimensions and finish. Be careful, because this bushing has a self-lubricating liner.



# 52-21-03

REPAIR 38-1

Page 601

Jul 01/2008

COMPONENT MAINTENANCE MANUAL



125/√ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 3

ALL DIMENSIONS ARE IN INCHES

146A6579-1 Lock Target Assembly Bushing Replacement  
Figure 601

**52-21-03**

REPAIR 38-1

Page 602

Jul 01/2007





## COMPONENT MAINTENANCE MANUAL

### LOCK TARGET - REPAIR 38-2

146A6579-101

#### 1. General

- A. This procedure tells how to repair and refinish lock target (200A).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 3 for item numbers.
- D. General repair details:
  - (1) Material: 15-5PH CRES, 180-200 ksi
  - (2) Shot peen: not necessary

#### 2. Target Repair

- A. Procedure (REPAIR 38-2, Figure 601)
  - (1) Repair is only replacement of the original finish. Refer to REPAIR 38-2, Paragraph 3. below for details.
  - (2) If you think there are defects on important surfaces, see REPAIR 38-2, Figure 601 for dimension details.

#### 3. Target Refinish

##### A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

##### B. Procedure

**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Passivate (F-17.25).



# 52-21-03

REPAIR 38-2

Page 601

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



146A6579-101 Lock Target Repair and Refinish  
Figure 601 (Sheet 1 of 2)

**52-21-03**


REPAIR 38-2

Page 602

Jul 01/2007



COMPONENT MAINTENANCE MANUAL



REFERENCE NUMBER	[1]	[2]	[3]	[4]
DESIGN DIMENSION	0.5631 0.5625	0.5300 0.5100	0.0730 0.0530	0.1400 0.1200
REPAIR LIMIT	—	—	—	—

125 / ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ALL DIMENSIONS ARE IN INCHES

146A6579-101 Lock Target Repair and Refinish  
Figure 601 (Sheet 2 of 2)

**52-21-03**

REPAIR 38-2

Page 603

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### LOCK CAM ASSEMBLY - REPAIR 39-1

146A6580-1, -3

#### 1. General

- A. This procedure tells how to replace the parts of lock cam assemblies (90, 231).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 3 for item numbers.

#### 2. Bushing Replacement

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
A00247	Sealant - Pressure And Environmental - Chromate Type	BMS 5-95

- B. References

Reference	Title
SOPM 20-50-03	BEARING AND BUSHING REPLACEMENT

- C. Procedure (REPAIR 39-1, Figure 601 or REPAIR 39-1, Figure 602)

- (1) Remove the old bushings.
- (2) If you find defects on the hole surfaces, refer to REPAIR 39-2 for repair instructions.
- (3) Install replacement bushings by the shrink fit method (SOPM 20-50-03) with BMS 5-95 sealant, A00247 as the installation finish.
- (4) Machine the bushings to design dimensions and finish.



# 52-21-03

REPAIR 39-1

Page 601

Jul 01/2008

COMPONENT MAINTENANCE MANUAL



125 / ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 3

146A6580-1 Lock Cam Assembly Bushing Replacement  
Figure 601



**52-21-03**

REPAIR 39-1

Page 602

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 3

ALL DIMENSIONS ARE IN INCHES

146A6580-3 Lock Cam Assembly Bushing Replacement  
Figure 602

**52-21-03**

REPAIR 39-1

Page 603

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### LOCK CAM - REPAIR 39-2

146A6580-101, -103

#### 1. General

- A. This procedure tells how to repair and refinish lock cams (99, 233).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 3 for item numbers.
- D. General repair details:
  - (1) Material: 15-5PH CRES, 180-200 ksi
  - (2) Shot peen: not necessary

#### 2. Cam Repair

- A. Procedure (REPAIR 39-2, Figure 601 or REPAIR 39-2, Figure 602)
  - (1) Repair is only replacement of the original finish. Refer to REPAIR 39-2, Paragraph 3. below for details.
  - (2) If you think there are defects on important surfaces, see REPAIR 39-2, Figure 601 or REPAIR 39-2, Figure 602 for dimension details.

#### 3. Cam Refinish

##### A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

##### B. Procedure

**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Passivate (F-17.25).


# 52-21-03

REPAIR 39-2

Page 601

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



146A6580-101 Lock Cam Repair and Refinish  
Figure 601 (Sheet 1 of 2)


**52-21-03**

REPAIR 39-2  
Page 602  
Jul 01/2007





COMPONENT MAINTENANCE MANUAL



REFERENCE NUMBER	[1]	[2]	[3]	[4]	[5]	[6]	[7]	[8]
DESIGN DIMENSION	0.2540	0.1300	0.2540	0.9665	0.7165	0.5321	0.4381	0.5631
	0.2500	0.1260	0.2500	0.9465	0.6965	0.5221	0.4375	0.5625
REPAIR LIMIT	—	—	—	—	—	—	—	—



125/√ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY  
 BREAK ALL SHARP EDGES  
 ALL DIMENSIONS ARE IN INCHES

146A6580-101 Lock Cam Repair and Refinish  
 Figure 601 (Sheet 2 of 2)

**52-21-03**

REPAIR 39-2  
 Page 603  
 Jul 01/2007

COMPONENT MAINTENANCE MANUAL



146A6580-103 Lock Cam Repair and Refinish  
Figure 602 (Sheet 1 of 2)

**52-21-03**

REPAIR 39-2  
Page 604  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

REFERENCE NUMBER	[1]	[2]	[3]
DESIGN DIMENSION	1.2386 1.2286	1.1310 1.1110	0.3756 0.3750
REPAIR LIMIT	—	—	—

125/√ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ALL DIMENSIONS ARE IN INCHES

146A6580-103 Lock Cam Repair and Refinish  
Figure 602 (Sheet 2 of 2)

# 52-21-03

REPAIR 39-2

Page 605

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### LOCK SHAFT - REPAIR 40-1

146A6581-1

#### 1. General

- A. This procedure tells how to repair and refinish lock shaft (78, IPL Figure 3).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 3 for item numbers.
- D. General repair details:
  - (1) Material: 15-5PH CRES, 180-200 ksi
  - (2) Shot peen: not necessary

#### 2. Shaft Repair

- A. Procedure (REPAIR 40-1, Figure 601)
  - (1) Repair is only replacement of the original finish. Refer to REPAIR 40-1, Paragraph 3. below for details.
  - (2) If you think there are defects on important surfaces, see REPAIR 40-1, Figure 601 for dimension details.

#### 3. Shaft Refinish

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
D50081	Lubricant - Solid Film Lubricant, Liquid Dispersed	BMS 3-8

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

- C. Procedure

**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Passivate (F-17.25).
- (2) Apply BMS 3-8 solid film solid film lubricant, D50081 (F-19.10) to the surfaces shown.


# 52-21-03

REPAIR 40-1

Page 601

Jul 01/2009

COMPONENT MAINTENANCE MANUAL




A-A

146A6581-1 Lock Shaft Repair and Refinish  
Figure 601 (Sheet 1 of 2)

**52-21-03**

COMPONENT MAINTENANCE MANUAL



REFERENCE NUMBER	[1]	[2]	[3]	[4]	[5]	[6]	[7]	[8]
DESIGN DIMENSION	0.1510 0.1310	0.5350 0.5150	0.9500 0.9450	1.3120 1.3110	0.9500 0.9450	0.6245 0.6235	0.4100 0.3900	0.1190 0.0990
REPAIR LIMIT	—	—	—	—	—	—	—	—

1 APPLY BMS 3-8 SOLID FILM LUBRICANT (F-19.10), 0.0002-0.0005 THICK

125 / ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ALL DIMENSIONS ARE IN INCHES

146A6581-1 Lock Shaft Repair and Refinish  
Figure 601 (Sheet 2 of 2)

**52-21-03**

REPAIR 40-1  
Page 603  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### LOCK FITTING - REPAIR 41-1

146A6586-1, -3

#### 1. General

- A. This procedure tells how to repair and refinish lock fittings (175, 207).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 3 for item numbers.
- D. General repair details:
  - (1) Material: 15-5PH CRES, 180-200 ksi
  - (2) Shot peen: not necessary

#### 2. Fitting Repair

- A. Procedure (REPAIR 41-1, Figure 601 or REPAIR 41-1, Figure 602)
  - (1) Repair is only replacement of the original finish. Refer to REPAIR 41-1, Paragraph 3. below for details.
  - (2) If you think there are defects on important surfaces, see REPAIR 41-1, Figure 601 or REPAIR 41-1, Figure 602 for dimension details.

#### 3. Fitting Refinish

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

- C. Procedure (REPAIR 41-1, Figure 601 or REPAIR 41-1, Figure 602)



**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) 146A6586-1: Cadmium plate (F-15.06). Apply BMS 10-11, Type 1 primer, C00259 (F-20.03) unless shown differently.
- (2) 146A6586-3: Passivate (F-17.25).

# 52-21-03

REPAIR 41-1  
Page 601  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL




146A6586-1 Lock Fitting Repair and Refinish  
Figure 601 (Sheet 1 of 3)

**52-21-03**

REPAIR 41-1  
Page 602  
Jul 01/2007



COMPONENT MAINTENANCE MANUAL



146A6586-1 Lock Fitting Repair and Refinish  
Figure 601 (Sheet 2 of 3)

**52-21-03**

REPAIR 41-1

Page 603

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

REFERENCE NUMBER	[1]	[2]	[3]	[4]	[5]	[6]	[7]	[8]
DESIGN DIMENSION	0.1663	0.1990	0.9500	0.6750	0.0900	0.3780	0.1990	0.0700
	0.1463	0.1900	0.9300	0.6550	0.0700	0.3580	0.1900	0.0500
REPAIR LIMIT	---	---	---	---	---	---	---	---

1 NO PRIMER ON THE TWO FACES OF THIS AREA

125 ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ALL DIMENSIONS ARE IN INCHES

146A6586-1 Lock Fitting Repair and Refinish  
Figure 601 (Sheet 3 of 3)


# 52-21-03

REPAIR 41-1

Page 604

Jul 01/2007

COMPONENT MAINTENANCE MANUAL




146A6586-3 Lock Fitting Repair and Refinish  
Figure 602 (Sheet 1 of 2)

**52-21-03**

REPAIR 41-1  
Page 605  
Jul 01/2007



COMPONENT MAINTENANCE MANUAL



C-C

REFERENCE NUMBER	[1]	[2]	[3]	[4]
DESIGN DIMENSION	0.1300 0.1260	0.1310 0.1290	0.0700 0.0500	0.0730 0.0530
REPAIR LIMIT	---	---	---	---

125/√ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ALL DIMENSIONS ARE IN INCHES

146A6586-3 Lock Fitting Repair and Refinish  
Figure 602 (Sheet 2 of 2)

**52-21-03**

REPAIR 41-1

Page 606

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### OUTSIDE HANDLE COVER ASSEMBLY - REPAIR 42-1

146A6589-1

#### 1. General

- A. This procedure tells how to replace the parts of outside handle cover assembly (670).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices shown in the repair.
- C. Refer to IPL Figure 2 for item numbers.

#### 2. Parts Replacement

- A. Procedure (REPAIR 42-1, Figure 601)
  - (1) Remove the fasteners and the spring from the holes.
  - (2) Replace parts as necessary. Replace bushings (735) per REPAIR 42-1, Paragraph 3. below.
  - (3) If you find defects on the sleeve or the cover, refer to REPAIR 1-1 and REPAIR 42-2 for repair instructions.
  - (4) Install a replacement spring and fasteners on the cover as shown.
  - (5) Use something to tie the parts together until the unit can be installed in the door linkage.

#### 3. Bushing (735) Replacement

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
A00247	Sealant - Pressure And Environmental - Chromate Type	BMS 5-95

- B. References

Reference	Title
SOPM 20-50-03	BEARING AND BUSHING REPLACEMENT

- C. Procedure (REPAIR 42-1, Figure 601)

- (1) Remove the old bushings.
- (2) If you find defects on the cover surfaces, refer to REPAIR 42-2 for repair instructions.
- (3) Install replacement bushings by the shrink fit method (SOPM 20-50-03) with BMS 5-95 sealant, A00247 as the installation finish.
- (4) Machine the bushings to design dimensions and finish.


# 52-21-03

REPAIR 42-1


Page 601

Jul 01/2008

COMPONENT MAINTENANCE MANUAL



A-A



125 ✓ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 2

ALL DIMENSIONS ARE IN INCHES

146A6589-1 Outside Handle Cover Assembly Parts Replacement  
 Figure 601

**52-21-03**

REPAIR 42-1

Page 602

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### OUTSIDE HANDLE COVER - REPAIR 42-2

146A6589-101

#### 1. General

- A. This procedure tells how to repair and refinish outside handle cover (740).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 2 for item numbers.
- D. General repair details:
  - (1) Material: Al alloy
  - (2) Shot peen: not necessary

#### 2. Cover Repair

- A. Procedure (REPAIR 42-2, Figure 601)
  - (1) Repair is only replacement of the original refinish. Refer to REPAIR 42-2, Paragraph 3. for details.
  - (2) If you think there are defects on important surfaces, see REPAIR 42-2, Figure 601 for dimension details.

#### 3. Cover Refinis

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
C00033	Coating - Exterior Protective Enamel, Flexibility Use	BMS10-60, Type II
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

- C. Procedure (REPAIR 42-2, Figure 601)


**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Boric acid-sulfuric acid anodize or chromic acid anodize (F-17.31) all over.
- (2) Apply BMS 10-11, Type 1 primer, C00259 (F-20.03) and BMS 10-60, Type 2 coating, C00033 (F-19.39-701) but not in the holes for the bushings.

# 52-21-03

REPAIR 42-2  
Page 601  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL



146A6589-101 Outside Handle Cover Repair and Refinish  
Figure 601 (Sheet 1 of 2)

**52-21-03**


REPAIR 42-2

Page 602

Jul 01/2007



COMPONENT MAINTENANCE MANUAL



B-B

REFERENCE NUMBER	[1]	[2]	[3]	[4]	[5]	[6]	[7]	[8]
DESIGN DIMENSION	0.5006	0.1940	0.2540	0.1300	1.0100	0.2100	0.2600	0.2600
	0.5006	0.1900	0.2500	0.1100	0.9900	0.1900	0.2400	0.2400
REPAIR LIMIT	---	---	---	---	---	---	---	---

125 / ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ALL DIMENSIONS ARE IN INCHES

146A6589-101 Outside Handle Cover Repair and Refinish  
Figure 601 (Sheet 2 of 2)

**52-21-03**

REPAIR 42-2

Page 603

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### CLUTCH LINK ASSEMBLY - REPAIR 43-1

146A6590-1

#### 1. General

- A. This procedure tells how to replace the parts of clutch link assembly (780).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 2 for item numbers.

#### 2. Bearing Replacement

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
A00247	Sealant - Pressure And Environmental - Chromate Type	BMS 5-95

- B. References

Reference	Title
SOPM 20-50-03	BEARING AND BUSHING REPLACEMENT

- C. Procedure (REPAIR 43-1, Figure 601)

- (1) Remove the old bearing.
- (2) If you find defects on the hole surfaces, refer to REPAIR 43-2 for repair instructions.
- (3) Install a replacement bearing and roller swage it (SOPM 20-50-03) with BMS 5-95 sealant, A00247 as the installation finish.
- (4) Give the bearing an 1150-pound push-out proof load test.

#### 3. Fastener Replacement

- A. Procedure (REPAIR 43-1, Figure 601)

- (1) Remove the retainer and loosen the nuts.
- (2) Remove the screw and the other fasteners.
- (3) Install replacements by standard industry practices.


# 52-21-03

REPAIR 43-1

Page 601

Jul 01/2008

COMPONENT MAINTENANCE MANUAL



ITEM NUMBERS REFER TO IPL FIG. 2

146A6590-1 Clutch Link Assembly Parts Replacement  
Figure 601

**52-21-03**

REPAIR 43-1  
Page 602  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### CLUTCH LINK - REPAIR 43-2

146A6590-101

#### 1. General

- A. This procedure tells how to repair and refinish clutch link (815).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 2 for item numbers.
- D. General repair details:
  - (1) Material: 15-5PH CRES, 180-200 ksi
  - (2) Shot peen: not necessary

#### 2. Link Repair

- A. Procedure (REPAIR 43-2, Figure 601)
  - (1) Repair is only replacement of the original finish. Refer to REPAIR 43-2, Paragraph 3. below for details.
  - (2) If you think there are defects on important surfaces, see REPAIR 43-2, Figure 601 for dimension details.

#### 3. Link Refinish

##### A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

##### B. Procedure

**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Passivate (F-17.25).



# 52-21-03

REPAIR 43-2

Page 601

Jul 01/2007

COMPONENT MAINTENANCE MANUAL




146A6590-101 Clutch Link Repair and Refinish  
Figure 601 (Sheet 1 of 2)

**52-21-03**

REPAIR 43-2  
Page 602  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL



REFERENCE NUMBER	[1]	[2]	[3]	[4]	[5]	[6]
DESIGN DIMENSION	0.6880 0.6875	0.5910 0.5765	0.3270 0.3170	0.4090 0.4050	0.0670 0.0620	0.2290 0.2180
REPAIR LIMIT	—	—	—	—	—	—

125 / ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ALL DIMENSIONS ARE IN INCHES

146A6590-101 Clutch Link Repair and Refinish  
 Figure 601 (Sheet 2 of 2)

**52-21-03**



## COMPONENT MAINTENANCE MANUAL

### OUTSIDE HANDLE BEARING HOUSING ASSEMBLY - REPAIR 44-1

146A6591-1

#### 1. General

- A. This procedure tells how to replace the parts of outside handle bearing housing assembly (325).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 2 for item numbers.

#### 2. Bearing Replacement

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
A00247	Sealant - Pressure And Environmental - Chromate Type	BMS 5-95

- B. References

Reference	Title
SOPM 20-50-03	BEARING AND BUSHING REPLACEMENT

- C. Procedure (REPAIR 44-1, Figure 601)

- (1) Remove the old bearing.
- (2) If you find defects on the hole surfaces, refer to REPAIR 44-2 for repair instructions.
- (3) Install a replacement bearing and roller swage it (SOPM 20-50-03) with BMS 5-95 sealant, A00247 as the installation finish.
- (4) Give the bearing a 2555-pound push-out proof load test.




# 52-21-03

REPAIR 44-1

Page 601

Jul 01/2008

COMPONENT MAINTENANCE MANUAL



ITEM NUMBERS REFER TO IPL FIG. 2

146A6591-1 Outside Handle Bearing Housing Assembly Bearing Replacement  
Figure 601

**52-21-03**

REPAIR 44-1  
Page 602  
Jul 01/2007





## COMPONENT MAINTENANCE MANUAL

### BEARING HOUSING - REPAIR 44-2

146A6591-101

#### 1. General

- A. This procedure tells how to repair and refinish bearing housing (335).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 2 for item numbers.
- D. General repair details:
  - (1) Material: Al alloy
  - (2) Shot peen: not necessary

#### 2. Bearing Housing Repair

- A. Procedure (REPAIR 44-2, Figure 601)
  - (1) Repair is only replacement of the original finish. Refer to REPAIR 44-2, Paragraph 3. below for details.
  - (2) If you think there are defects on important surfaces, see REPAIR 44-2, Figure 601 for dimension details.

#### 3. Bearing Housing Refinish

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

- C. Procedure



**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Boric acid-sulfuric acid anodize or chromic acid anodize (F-17.31).
- (2) Apply BMS 10-11, Type 1 primer, C00259 (F-20.03) all over, but not on bore surfaces.


# 52-21-03

REPAIR 44-2  
Page 601  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL



A-A



REFERENCE NUMBER	[1]	[2]	[3]	[4]
DESIGN DIMENSION	1.3438 1.3238	1.0943 1.0938	0.4490 0.4390	0.1100 0.0900
REPAIR LIMIT	—	—	—	—

125 / ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ALL DIMENSIONS ARE IN INCHES

146A6591-101 Outside Handle Bearing Housing Repair and Refinish  
 Figure 601

**52-21-03**

REPAIR 44-2

Page 602

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### OUTSIDE HANDLE SUPPORT - REPAIR 45-1

146A6592-1

#### 1. General

- A. This procedure tells how to repair and refinish outside handle support (595).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 1 for item numbers.
- D. General repair details:
  - (1) Material: Al alloy
  - (2) Shot peen: not necessary

#### 2. Support Repair

- A. Procedure (REPAIR 45-1, Figure 601)
  - (1) Repair is only replacement of the original finish. Refer to REPAIR 45-1, Paragraph 3. below for details.
  - (2) If you think there are defects on important surfaces, see (REPAIR 45-1, Figure 601) for dimension details.

#### 3. Support Refinish

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
C00259	Primer - Chemical And Solvent Resistant Finish, Epoxy Resin	BMS10-11, Type I

- B. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

- C. Procedure

**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Boric acid-sulfuric acid anodize or chromic acid anodize (F-17.31).
- (2) Apply BMS 10-11, Type 1 primer, C00259 (F-20.03) all over, but not on bore surfaces.



# 52-21-03

REPAIR 45-1

Page 601

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



146A6592-1 Outside Handle Support Repair and Refinish  
Figure 601 (Sheet 1 of 2)

**52-21-03**

REPAIR 45-1  
Page 602  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

REFERENCE NUMBER	[1]	[2]	[3]	[4]
DESIGN DIMENSION	0.1300 0.1260	0.1940 0.1900	0.1100 0.0900	0.1300 0.1100
REPAIR LIMIT	—	—	—	—

125/ ALL MACHINED SURFACES UNLESS  
 ✓ SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ALL DIMENSIONS ARE IN INCHES

146A6592-1 Outside Handle Support Repair and Refinish  
 Figure 601 (Sheet 2 of 2)

# 52-21-03

REPAIR 45-1

Page 603

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### OUTSIDE HANDLE PIN ASSEMBLY - REPAIR 46-1

146A6597-1, -2

#### 1. General

- A. This procedure tells how to replace the parts of outside handle pin assembly (480. 530).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 2 for item numbers.

#### 2. Packing Replacement

- A. Procedure (REPAIR 46-1, Figure 601)
  - (1) Remove the old packings.
  - (2) If you find defects on the pin surfaces, refer to REPAIR 46-2 for repair instructions.
  - (3) Install replacement packings in the pin grooves.



# 52-21-03

REPAIR 46-1

Page 601

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



A-A

ITEM NUMBERS REFER TO IPL FIG. 2

146A6597-1,-2 Outside Handle Pin Assembly Parts Replacement  
Figure 601

**52-21-03**

REPAIR 46-1  
Page 602  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### OUTSIDE HANDLE PIN - REPAIR 46-2

146A6597-101, -102

#### 1. General

- A. This procedure tells how to repair and refinish outside handle pins (490A, 530).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for the standard practices specified in the procedure.
- C. Refer to IPL Figure 2 for item numbers.
- D. General repair details:
  - (1) Material: A286 CRES, 180-200 ksi
  - (2) Shot peen: not necessary

#### 2. Pin Repair

- A. Procedure (REPAIR 46-2, Figure 601)
  - (1) Repair is only replacement of the original finish. Refer to REPAIR 46-2, Paragraph 3. below for details.
  - (2) If you think there are defects on important surfaces, see REPAIR 46-2, Figure 601 for dimension details.

#### 3. Pin Refinish

##### A. References

Reference	Title
SOPM 20-30-02	STRIPPING OF PROTECTIVE FINISHES
SOPM 20-41-01	DECODING TABLE FOR BOEING FINISH CODES

##### B. Procedure

**NOTE:** For stripping of protective finishes, refer to SOPM 20-30-02. For the decoding table for Boeing finish codes, refer to SOPM 20-41-01.

- (1) Cadmium plate (F-15.06).

# 52-21-03

REPAIR 46-2

Page 601


Jul 01/2007







COMPONENT MAINTENANCE MANUAL



(B)

REFERENCE NUMBER	[1] 1	[1] 2	[2]	[3]	[4]	[5]	[6]	[7]
DESIGN DIMENSION	2.9525 2.9225	2.7025 2.6725	0.3745 0.3740	0.880 0.820	0.2540 0.2510	0.0830 0.0420	0.2520 0.2470	0.0770 0.0760
REPAIR LIMIT	—	—	—	—	—	—	—	—

- 1 146A6597-101
- 2 146A6597-102

125 / ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY  
 BREAK ALL SHARP EDGES  
 ALL DIMENSIONS ARE IN INCHES

146A6597-101,-102 Outside Handle Pin Repair and Refinish  
 Figure 601 (Sheet 2 of 2)

**52-21-03**

REPAIR 46-2  
 Page 603  
 Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### ASSEMBLY

#### 1. General

- A. This procedure tells how to assemble the emergency exit door unit.
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for details of the standard practices specified in the procedure.
- C. Refer to IPL Figure 1 thru IPL Figure 4 for item numbers, as applicable.

#### 2. Assembly

- A. Consumable Materials

**NOTE:** Equivalent substitutes may be used.

Reference	Description	Specification
A00247	Sealant - Pressure And Environmental - Chromate Type	BMS 5-95
A02315	Sealant - Low Density, Synthetic Rubber. 2 Part	BMS5-142
G00009	Compound - Organic Corrosion Inhibiting	BMS3-23
G50136	Paste - Corrosion Inhibiting, Non-drying	BMS 3-38

- B. References

Reference	Title
SOPM 20-41-05	APPLICATION OF CORROSION INHIBITING COMPOUNDS
SOPM 20-50-01	BOLT AND NUT INSTALLATION
SOPM 20-50-02	INSTALLATION OF SAFETYING DEVICES
SOPM 20-50-12	APPLICATION OF ADHESIVES
SOPM 20-50-19	GENERAL SEALING
SOPM 20-60-02	FINISHING MATERIALS
SOPM 20-60-04	MISCELLANEOUS MATERIALS

- C. Application of primer, sealant and corrosion inhibiting compound (ASSEMBLY, Figure 701)

**NOTE:** This procedure starts with the basic door structure. If this was not disassembled, and the paint, sealant and compound on the structure are serviceable, go to ASSEMBLY, Paragraph 2.D. to install the mechanical parts.

**NOTE:** Some of these steps apply sealant and compound to mechanical parts after they are installed. Then the subsequent procedures that install those parts will refer to the applicable steps in this paragraph.

**NOTE:** For finishing materials, refer to SOPM 20-60-02. For miscellaneous materials, refer to SOPM 20-60-04.

- (1) Use standard industry practices and these steps.
- (2) Put the door unit in an assembly cradle or fixture
- (3) Inject BMS 5-142 sealant, A02315 (SOPM 20-50-19) as shown (flagnote 5).

# 52-21-03

ASSEMBLY

Page 701

Jul 01/2008



## COMPONENT MAINTENANCE MANUAL

- (4) Fillet seal around the parts with BMS 5-142 sealant, A02315 (SOPM 20-50-19) as shown (flagnote 1). Make a smooth joint with the injection seals that could be around the same part.
  - (5) Fill all gaps and fillet seal all seams on the inside handle box assembly (575, IPL Figure 1) with BMS 5-142 sealant, A02315 (SOPM 20-50-19) as shown (flagnote 7). To get at the lower corners, release the handle as necessary.
  - (6) Fill and make smooth with BMS 5-142 sealant, A02315 (SOPM 20-50-19) all along the interface between the door skin seal and the seal depressor as shown (flagnote 6). Make a smooth joint with the injection seals that could be around the same part.
  - (7) Fill the gaps between the seal depressors with BMS 5-142 sealant, A02315 as shown (flagnote 8). Make sure the sealant is flush, to help prevent air leaks through the pressure seal.
  - (8) Aerodynamic seal with BMS 5-142 sealant, A02315 between the view port or prism assembly (180, IPL Figure 1) and the upper seal depressor (flagnote 2). Make a smooth joint with the injection seals that could be around the same part.
  - (9) Mask the rub strips, bushings, bearings, and ground strap studs as shown (flagnote 4).
  - (10) Touch up with primer as necessary. Let the primer cure for a minimum of 1 hour before you apply the corrosion inhibiting compound.
  - (11) Apply BMS 3-23, Type 2 (such as Ardrex AV8) corrosion inhibiting compound, G00009 (SOPM 20-41-05) to all accessible internal surfaces of the door structure (flagnote 4).
- D. Mechanical Parts - - General (ASSEMBLY, Figure 702 thru ASSEMBLY, Figure 707)
- (1) Use standard industry practices and these steps.
  - (2) Some parts have holes which are machined at assembly to the sizes shown, or are adjusted to give dimensions shown. If you replaced these parts with new ones, the new parts could have only pilot holes or no holes at all. Then be sure to machine the holes as shown. Otherwise, if you use the old parts, it is not necessary to machine the holes or parts if these parts, when assembled, give the dimensions shown.
  - (3) Install the noted fasteners with BMS 3-38 corrosion inhibiting non-drying paste, G50136 (SOPM 20-60-02).
  - (4) Tighten the noted fasteners and install cotter pins (SOPM 20-50-02).
- E. Exterior Door Handle Mechanism in Handle Box (ASSEMBLY, Figure 702)
- (1) Install the bolts, bushings and springs of handle cover assembly (670, IPL Figure 2) on the outside handle support (595, IPL Figure 1), with the handle laying loose in the box.
  - (2) Make sure the spring is between the washers (flagnote 5). Apply a thin layer of BMS 3-38 corrosion inhibiting non-drying paste, G50136 to the mating surfaces of the washers (flagnote 11).
  - (3) Remove the Panduit straps from shaft assembly (380, IPL Figure 2). Remove crank shaft (440, IPL Figure 2) and lubricate the shaft with BMS 3-33 grease.
  - (4) Install bearings (378, IPL Figure 2) and washers (377, IPL Figure 2) in the handle box. Use the crankshaft to put the washers in position and adjust the washers for end play (flagnote 3).
  - (5) Apply sealant to the bearings and let it cure.
  - (6) Install handle cover (670, IPL Figure 2) on the handle box with bolts (480, 530, IPL Figure 2), bushings and washers as necessary for a good fit (flagnote 3).

# 52-21-03

ASSEMBLY

Page 702

Jul 01/2007




## COMPONENT MAINTENANCE MANUAL

- (7) Install link (620, IPL Figure 2) between crank (420, IPL Figure 2) and handle (635, IPL Figure 2) with the bolts, washers, bushing, nut and cotter pin.
  - (8) Install handle link (620, IPL Figure 2), shaft assembly (380, IPL Figure 2), and handle assembly (635, IPL Figure 2) with bolts (480, 530, IPL Figure 2). Use washers as necessary for a good fit (flagnote 2).
  - (9) Install crank assembly (420, IPL Figure 2) inside the box with its fasteners.
  - (10) Loosely install catch stop (445, IPL Figure 2) with shim (460, IPL Figure 2) as supplied. Make a check for a good aerodynamic fit with a shim as skin thickness against the flange of the box. Adjust the thickness of shim (460) for a good aerodynamic fit (flagnote 4).
- F. Vent Door (ASSEMBLY, Figure 703)
- (1) Get vent door mechanism assembly (55, IPL Figure 2) and remove the two end fittings.
  - (2) Install the two end fittings and lock fittings (159, 303, IPL Figure 3) on the #2 stop beam (375, IPL Figure 1).
  - (3) If necessary, drill the holes for fasteners for the tension springs (ASSEMBLY, Figure 702, View F-F).
  - (4) Now install the mechanism on the #2 beam with the fasteners as shown (ASSEMBLY, Figure 702, Views C-C, D-D; ASSEMBLY, Figure 703, Views R-R, X-X). Adjust the shim thickness and install with fasteners, with wet BMS 5-95 sealant, A00247 (flagnotes 10, 11). Fay surface seal (ASSEMBLY, Figure 701).
  - (5) Install fasteners, bushings and washers for the springs (ASSEMBLY, Figure 702, View F-F).
- G. Retention Plate (ASSEMBLY, Figure 703)
- (1) Install retention plate (332, IPL Figure 3) with a fay surface seal (SOPM 20-50-19) of BMS 5-95 sealant on mating surfaces (ASSEMBLY, Figure 703, View K-K).
  - (2) Install bolts (333) and collars (336) with BMS 5-95 sealant, A00247.
- H. Activation Module and Inside Door Handle (ASSEMBLY, Figure 706  
ASSEMBLY, Figure 705, ASSEMBLY, Figure 705) (IPL Figure 1)
- (1) Install the activation module deep details as shown in ASSEMBLY, Figure 705. Install bolt (130) with ASTM D 5363 AN0313 or MIL-S-46163, Type 2, Grade M retaining compound by the BAC5011 Procedure for Application of Retaining Compounds in SOPM 20-50-12.
  - (2) Connect inside door handle (115, IPL Figure 1) to lock cam (90, 231, IPL Figure 3) on lock shaft assembly (78, IPL Figure 3) with the hardware (ASSEMBLY, Figure 706, Views B-B, C-C).
  - (3) If this is an activated door, install screws in the nutplates with wet BMS 5-95 sealant, A00247 (ASSEMBLY, Figure 706, View D-D).
- I. Viewport Prism (ASSEMBLY, Figure 707)
- (1) Install prism assembly (180, IPL Figure 1) with seal (195, IPL Figure 1) and retainer (175, IPL Figure 1).
  - (2) Push the retainer tightly against the seal and make sure there is the pull-up gap between the retainer and each of the nutplates, as shown. To adjust the gap, use washers (165, 170) as necessary between the retainer and the nutplate.
  - (3) Then install the bolts and tighten them to standard torque (SOPM 20-50-01).

# 52-21-03

ASSEMBLY  
Page 703  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL




LEFT SIDE SEAL APPLICATION SHOWN (4)  
 RIGHT SIDE SAME

Emergency Exit Door Primer, Sealant and Corrosion Inhibiting Compound Details  
 Figure 701 (Sheet 1 of 14)

**52-21-03**

ASSEMBLY  
 Page 704  
 Jul 01/2007

COMPONENT MAINTENANCE MANUAL



Emergency Exit Door Primer, Sealant and Corrosion Inhibiting Compound Details  
Figure 701 (Sheet 2 of 14)



**52-21-03**

ASSEMBLY

Page 705

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



Emergency Exit Door Primer, Sealant and Corrosion Inhibiting Compound Details  
Figure 701 (Sheet 3 of 14)

**52-21-03**


ASSEMBLY

Page 706

Jul 01/2007



COMPONENT MAINTENANCE MANUAL




Emergency Exit Door Primer, Sealant and Corrosion Inhibiting Compound Details  
 Figure 701 (Sheet 4 of 14)

**52-21-03**

ASSEMBLY  
 Page 707  
 Jul 01/2007

COMPONENT MAINTENANCE MANUAL



Emergency Exit Door Primer, Sealant and Corrosion Inhibiting Compound Details  
Figure 701 (Sheet 5 of 14)


**52-21-03**

ASSEMBLY

Page 708

Jul 01/2007

COMPONENT MAINTENANCE MANUAL




Emergency Exit Door Primer, Sealant and Corrosion Inhibiting Compound Details  
Figure 701 (Sheet 6 of 14)

**52-21-03**

ASSEMBLY  
Page 709  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL



Emergency Exit Door Primer, Sealant and Corrosion Inhibiting Compound Details  
Figure 701 (Sheet 7 of 14)


**52-21-03**

ASSEMBLY

Page 710

Jul 01/2007

### COMPONENT MAINTENANCE MANUAL



H-H

Emergency Exit Door Primer, Sealant and Corrosion Inhibiting Compound Details  
Figure 701 (Sheet 8 of 14)


# 52-21-03

ASSEMBLY

Page 711

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



I-I

Emergency Exit Door Primer, Sealant and Corrosion Inhibiting Compound Details  
Figure 701 (Sheet 9 of 14)


**52-21-03**

ASSEMBLY

Page 712

Jul 01/2007

### COMPONENT MAINTENANCE MANUAL



Emergency Exit Door Primer, Sealant and Corrosion Inhibiting Compound Details  
Figure 701 (Sheet 10 of 14)


# 52-21-03

ASSEMBLY

Page 713

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



Emergency Exit Door Primer, Sealant and Corrosion Inhibiting Compound Details  
Figure 701 (Sheet 11 of 14)

**52-21-03**


ASSEMBLY

Page 714

Jul 01/2007



### COMPONENT MAINTENANCE MANUAL




Emergency Exit Door Primer, Sealant and Corrosion Inhibiting Compound Details  
Figure 701 (Sheet 12 of 14)

# 52-21-03

ASSEMBLY  
Page 715  
Jul 01/2007

### COMPONENT MAINTENANCE MANUAL




0-0

Emergency Exit Door Primer, Sealant and Corrosion Inhibiting Compound Details  
Figure 701 (Sheet 13 of 14)

# 52-21-03

ASSEMBLY  
Page 716  
Jul 01/2007

## COMPONENT MAINTENANCE MANUAL




- 1 FILLET SEAL AROUND THE INTERFACE BETWEEN THIS PART AND THE DOOR SKIN BOND ASSEMBLY WITH BMS 5-142 SEALANT (SOPM 20-50-19). MAKE A SMOOTH JOINT WITH INJECTION SEALS THAT COULD BE AROUND THIS SAME PART
- 2 MAKE AN AERODYNAMIC QUALITY SEAL. FILL THE GAP WITH BMS 5-142 SEALANT, AND MAKE IT SMOOTH WITH THE ADJACENT SURFACES. MAKE A SMOOTH JOINT WITH INJECTION SEALS THAT COULD BE AROUND THIS SAME PART
- 3 FAY SURFACE SEAL (SOPM 20-50-19) DURING ASSEMBLY
- 4 APPLY BMS 3-23 TYPE 2 CORROSION INHIBITING COMPOUND (SOPM 20-41-05) TO ALL ACCESSIBLE INTERNAL SURFACES OF THE DOOR STRUCTURE
- 5 INJECTION SEAL THE CHAMFER OR FILLET WITH BMS 5-142 SEALANT (SOPM 20-50-19)
- 6 FILL WITH BMS 5-142 SEALANT ALL ALONG THE INTERFACE BETWEEN THE SEAL DEPRESSOR AND THE DOOR SKIN, AND MAKE IT SMOOTH WITH THE ADJACENT SURFACES
- 7 SEAL THE INSIDE CORNERS OF THE HANDLE BOX. FILL ALL GAPS AND FILLET SEAL ALL SEAMS IN THIS AREA WITH BMS 5-142 SEALANT (SOPM 20-50-19)
- 8 FILL THE GAP BETWEEN THE SEAL DEPRESSOR WITH BMS 5-142 SEALANT. REMOVE THE SEALANT FROM THE EXTERIOR SURFACES OF THE SEAL DEPRESSORS. MAKE SURE THE SEALANT IS FLUSH, TO HELP PREVENT AIR LEAKS THROUGH THE PRESSURE SEAL
- 9 KEEP THE DRAIN HOLE OPEN. DO NOT LET SEALANT CAUSE A BLOCKAGE
- 10 SEAL INSTRUCTIONS ARE TYPICAL FOR EACH END OF THE CENTER AND LOWER SEAL DEPRESSORS
- 11 SEAL INSTRUCTIONS ARE TYPICAL FOR EACH END OF THE INTERCOSTAL
- 12 TYPICAL FOR LAP AREAS BETWEEN THE SIDE AND LOWER CORNER SEAL DEPRESSORS

Emergency Exit Door Primer, Sealant and Corrosion Inhibiting Compound Details  
Figure 701 (Sheet 14 of 14)

# 52-21-03


ASSEMBLY  
Page 717  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL



146A6500-5 SHOWN  
146A6500-6 SAME

STA  
7271+2  
(REF)





**NOTE:** MECHANISM SHOWN IN CLOSED, LATCHED, LOCKED POSITION UNLESS SHOWN DIFFERENTLY.

146A6500-5,-6 Door Upper Region Mechanism Installation Details  
Figure 702 (Sheet 1 of 12)

**52-21-03**

ASSEMBLY  
Page 718  
Jul 01/2007

### COMPONENT MAINTENANCE MANUAL




146A6500-5,-6 Door Upper Region Mechanism Installation Details  
Figure 702 (Sheet 2 of 12)


# 52-21-03

ASSEMBLY  
Page 719  
Jul 01/2007


COMPONENT MAINTENANCE MANUAL



D-D



E-E




F-F

146A6500-5,-6 Door Upper Region Mechanism Installation Details  
Figure 702 (Sheet 3 of 12)

**52-21-03**

ASSEMBLY  
Page 720  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL




146A6500-5,-6 Door Upper Region Mechanism Installation Details  
Figure 702 (Sheet 4 of 12)

**52-21-03**

ASSEMBLY  
Page 721  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL




146A6500-5,-6 Door Upper Region Mechanism Installation Details  
Figure 702 (Sheet 5 of 12)

**52-21-03**

ASSEMBLY  
Page 722  
Jul 01/2007



COMPONENT MAINTENANCE MANUAL





146A6500-5,-6 Door Upper Region Mechanism Installation Details  
 Figure 702 (Sheet 6 of 12)

**52-21-03**

ASSEMBLY  
 Page 723  
 Jul 01/2007

COMPONENT MAINTENANCE MANUAL




146A6500-5,-6 Door Upper Region Mechanism Installation Details  
Figure 702 (Sheet 7 of 12)

**52-21-03**

ASSEMBLY  
Page 724  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL



M-M



(VIEW TURNED 93° CCW)

146A6500-5,-6 Door Upper Region Mechanism Installation Details  
Figure 702 (Sheet 8 of 12)

**52-21-03**

ASSEMBLY  
Page 725  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL



(ADJACENT STRUCTURE NOT SHOWN)



146A6500-5,-6 Door Upper Region Mechanism Installation Details  
Figure 702 (Sheet 9 of 12)

**52-21-03**

ASSEMBLY  
Page 726  
Jul 01/2007



COMPONENT MAINTENANCE MANUAL




146A6500-5,-6 Door Upper Region Mechanism Installation Details  
Figure 702 (Sheet 10 of 12)

**52-21-03**

ASSEMBLY  
Page 727  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL



146A6500-5,-6 Door Upper Region Mechanism Installation Details  
Figure 702 (Sheet 11 of 12)

**52-21-03**

ASSEMBLY  
Page 728  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

- 1 BEFORE INSTALLATION, BACK OFF THIS SCREW TO REMOVE INTERFERENCE WITH RIGGING OF OUTSIDE HANDLE OR ITS COVER. AFTER RIGGING IS COMPLETE, TIGHTEN THIS SCREW TO 10 POUND-INCHES MAXIMUM, THEN BACK IT OFF 1/2 TURN AND LOCK IT DOWN WITH THE JAM NUT. LOCKWIRE THE JAM NUT (SOPM 20-50-02).
- 2 INSTALL WASHERS AS NECESSARY TO GET 0.0010-0.0160 INCH SIDE FREE PLAY AT THE HANDLE AND TO GET THE GAP SHOWN AT THE OUTSIDE HANDLE. THE SIDE GAPS MUST BE MORE THAN 0.0300 INCH DIFFERENT.
- 3 INSTALL THESE WASHERS AS NECESSARY, MINIMUM OF ONE PER SIDE, TO GET 0.0100-0.0300 INCH PLAY.
- 4 REMOVE 0.003-INCH LAMINATIONS FROM THE SHIM AS NECESSARY TO MAKE THE SURFACE OF THE OUTSIDE DOOR HANDLE SMOOTH WITH THE DOOR OUTSIDE SKIN SURFACE WITHIN 0.030 INCH. FAY SURFACE SEAL ALL OF THE SHIM MATING SURFACES WITH BMS 5-95 SEALANT (SOPM 20-50-19)
- 5 BE SURE THE SPRING HOOKS ARE BETWEEN THE ADJACENT WASHERS AT EACH END, AS SHOWN.
- 6 INSTALL THE COTTER PIN (SOPM 20-50-02)
- 7 APPLY BMS 3-8 SOLID FILM LUBRICANT (F-19.10) ALL AROUND THIS SURFACE.
- 8 USE THESE WASHERS AS NECESSARY TO GET THE DIMENSIONS SHOWN, WITH 0.0010-0.0160 INCH FREEPLAY.
- 9 USE THE PILOT HOLES IN THE BEARING HOUSING ASSEMBLY.
- 10 APPLY BMS 3-33 GREASE TO THE SHAFT AS NECESSARY TO BE SURE THERE IS A LAYER OF GREASE AT THE O-RING.
- 11 APPLY A THIN LAYER OF BMS 3-38 CORROSION PREVENTITIVE COMPOUND TO THE MATING SURFACES OF THIS WASHER BEFORE YOU INSTALL IT.

ITEM NUMBERS REFER TO IPL FIG. 2  
UNLESS SHOWN DIFFERENTLY



ALL DIMENSIONS ARE IN INCHES

146A6500-5,-6 Door Upper Region Mechanism Installation Details  
Figure 702 (Sheet 12 of 12)

# 52-21-03

ASSEMBLY  
Page 729  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL



146A6500-3,-4 More Door Upper Region Mechanism Installation Details  
Figure 703 (Sheet 1 of 23)

**52-21-03**


ASSEMBLY

Page 730

Jul 01/2007



COMPONENT MAINTENANCE MANUAL



FLIGHT LOCK ASSEMBLY

A

146A6500-3,-4 More Door Upper Region Mechanism Installation Details  
Figure 703 (Sheet 2 of 23)


**52-21-03**

ASSEMBLY

Page 731

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



146A6500-3,-4 More Door Upper Region Mechanism Installation Details  
Figure 703 (Sheet 3 of 23)



**52-21-03**

ASSEMBLY

Page 732

Jul 01/2007

COMPONENT MAINTENANCE MANUAL




146A6500-3,-4 More Door Upper Region Mechanism Installation Details  
Figure 703 (Sheet 4 of 23)

**52-21-03**

ASSEMBLY  
Page 733  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL




146A6500-3,-4 More Door Upper Region Mechanism Installation Details  
Figure 703 (Sheet 5 of 23)

**52-21-03**


ASSEMBLY  
Page 734  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL




G-G  
(TURNED 90° CCW)

BEAM NO. 3 ASSEMBLY  
(IPL FIG. 1; 400)



H-H




I-I

146A6500-3,-4 More Door Upper Region Mechanism Installation Details  
Figure 703 (Sheet 6 of 23)

**52-21-03**

ASSEMBLY  
Page 735  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL



146A6500-3,-4 More Door Upper Region Mechanism Installation Details  
Figure 703 (Sheet 7 of 23)



**52-21-03**

ASSEMBLY

Page 736

Jul 01/2007

COMPONENT MAINTENANCE MANUAL





146A6500-3,-4 More Door Upper Region Mechanism Installation Details  
Figure 703 (Sheet 8 of 23)

**52-21-03**

ASSEMBLY  
Page 737  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL



146A6500-3,-4 More Door Upper Region Mechanism Installation Details  
Figure 703 (Sheet 9 of 23)

**52-21-03**



ASSEMBLY

Page 738

Jul 01/2007



### COMPONENT MAINTENANCE MANUAL



146A6500-3,-4 More Door Upper Region Mechanism Installation Details  
Figure 703 (Sheet 10 of 23)


# 52-21-03

ASSEMBLY

Page 739

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



146A6500-3,-4 More Door Upper Region Mechanism Installation Details  
Figure 703 (Sheet 11 of 23)


**52-21-03**

ASSEMBLY

Page 740

Jul 01/2007

COMPONENT MAINTENANCE MANUAL





146A6500-3,-4 More Door Upper Region Mechanism Installation Details  
Figure 703 (Sheet 12 of 23)

**52-21-03**

ASSEMBLY  
Page 741  
Jul 01/2007

**COMPONENT MAINTENANCE MANUAL**




(SOME PARTS NOT SHOWN)

146A6500-3,-4 More Door Upper Region Mechanism Installation Details  
 Figure 703 (Sheet 13 of 23)

**52-21-03**

ASSEMBLY  
 Page 742  
 Jul 01/2007

COMPONENT MAINTENANCE MANUAL



S-S

146A6500-3,-4 More Door Upper Region Mechanism Installation Details  
Figure 703 (Sheet 14 of 23)


**52-21-03**

ASSEMBLY

Page 743

Jul 01/2007

COMPONENT MAINTENANCE MANUAL




146A6500-3,-4 More Door Upper Region Mechanism Installation Details  
 Figure 703 (Sheet 15 of 23)

**52-21-03**

ASSEMBLY  
 Page 744  
 Jul 01/2007

COMPONENT MAINTENANCE MANUAL



146A6500-3,-4 More Door Upper Region Mechanism Installation Details  
Figure 703 (Sheet 16 of 23)


**52-21-03**

ASSEMBLY

Page 745

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



146A6500-3,-4 More Door Upper Region Mechanism Installation Details  
Figure 703 (Sheet 17 of 23)

**52-21-03**



ASSEMBLY

Page 746

Jul 01/2007



COMPONENT MAINTENANCE MANUAL





146A6500-3,-4 More Door Upper Region Mechanism Installation Details  
Figure 703 (Sheet 18 of 23)

**52-21-03**

ASSEMBLY  
Page 747  
Jul 01/2007



COMPONENT MAINTENANCE MANUAL





146A6500-3,-4 More Door Upper Region Mechanism Installation Details  
Figure 703 (Sheet 19 of 23)

**52-21-03**

ASSEMBLY  
Page 748  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL




146A6500-3,-4 More Door Upper Region Mechanism Installation Details  
Figure 703 (Sheet 20 of 23)

**52-21-03**

ASSEMBLY  
Page 749  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL



AC-AC

146A6500-3,-4 More Door Upper Region Mechanism Installation Details  
Figure 703 (Sheet 21 of 23)

**52-21-03**


ASSEMBLY

Page 750

Jul 01/2007



COMPONENT MAINTENANCE MANUAL



146A6500-3,-4 More Door Upper Region Mechanism Installation Details  
Figure 703 (Sheet 22 of 23)

**52-21-03**

ASSEMBLY

Page 751

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

- 1 USE THE PILOT HOLES IN THE BEARING HOUSING ASSEMBLY
- 2 THESE DIMENSIONS MUST BE EQUAL WITHIN 0.01 INCH
- 3 INSTALL THE COTTER PIN (SOPM 20-50-02)
- 4 INSTALL WASHERS AS NECESSARY TO GET 0.015-0.031 INCH SIDE-TO-SIDE FREE PLAY. USE THE SAME NUMBER OF EACH WASHER SIZE ON EACH SIDE OF THE LATCH SHAFT, BUT YOU CAN INSTALL ONE MORE 0.016-THICK WASHER ON ONE SIDE OR THE OTHER IF EQUAL NUMBERS DO NOT GIVE THE SPECIFIED FREE PLAY
- 5 ADJUST THIS SCREW TO GET THE DIMENSION SHOWN. TIGHTEN THE NUTS TO STANDARD TORQUE (SOPM 20-50-01). LOCKWIRE THE SCREW HEAD AND THE TWO NUTS (SOPM 20-50-02)
- 6 HOLD THESE DIMENSIONS FOR THE FIRST SETUP TO BE SURE YOU CAN RIG AND SET RELATIVE LINKS DURING LATER ASSEMBLY PROCEDURES. GET THE DIMENSION SHOWN IN VIEW U-U (REF 5) BEFORE YOU GET THE DIMENSIONS FOR THE FLIGHT LOCK (VIEW B-B) AND THE PRESSURE LOCK (VIEW G-G)
- 7 FAY SURFACE SEAL WITH BMS 5-95 SEALANT (SOPM 20-50-19)
- 8 IF YOU INSTALL REPLACEMENT PARTS, USE THE PILOT HOLES TO PUT THE PARTS IN POSITION
- 9 IF YOU ADJUST THIS FASTENER AFTER THE FIRST SETUP, YOU COULD CHANGE THE POSITION SHOWN IN VIEW G-G
- 10 APPLY A LAYER OF BMS 5-95 SEALANT TO ALL HOLE SURFACES ON EACH SIDE. THEN INSTALL THE FASTENERS WITH WET BMS 5-95 SEALANT (SOPM 20-50-19 METHOD 1)
- 11 REMOVE 0.003 INCH LAMINATIONS FROM THE SHIM AS NECESSARY. FAY SURFACE SEAL ALL OF THE SHIM MATING SURFACES WITH BMS 5-95 SEALANT (SOPM 20-50-19)
- 12 USE A THIN LAYER OF BMS 3-33 GREASE AS THE INSTALLATION FINISH

ITEM NUMBERS REFER TO IPL FIG. 3  
UNLESS SHOWN DIFFERENTLY


ALL DIMENSIONS ARE IN INCHES

146A6500-3,-4 More Door Upper Region Mechanism Installation Details  
Figure 703 (Sheet 23 of 23)

# 52-21-03

ASSEMBLY  
Page 752  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL



146A6500-1,-2 Door Lower Region Mechanism Installation Details  
Figure 704 (Sheet 1 of 9)


**52-21-03**

ASSEMBLY

Page 753

Jul 01/2007

COMPONENT MAINTENANCE MANUAL





146A6500-1,-2 Door Lower Region Mechanism Installation Details  
Figure 704 (Sheet 2 of 9)

**52-21-03**

ASSEMBLY  
Page 754  
Jul 01/2007



COMPONENT MAINTENANCE MANUAL





146A6500-1,-2 Door Lower Region Mechanism Installation Details  
Figure 704 (Sheet 3 of 9)

**52-21-03**

ASSEMBLY  
Page 755  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL





146A6500-1,-2 Door Lower Region Mechanism Installation Details  
Figure 704 (Sheet 4 of 9)

**52-21-03**

ASSEMBLY  
Page 756  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL




146A6500-1,-2 Door Lower Region Mechanism Installation Details  
Figure 704 (Sheet 5 of 9)

**52-21-03**

ASSEMBLY  
Page 757  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL




146A6500-1,-2 Door Lower Region Mechanism Installation Details  
Figure 704 (Sheet 6 of 9)

**52-21-03**

ASSEMBLY  
Page 758  
Jul 01/2007

### COMPONENT MAINTENANCE MANUAL




146A6500-1,-2 Door Lower Region Mechanism Installation Details  
Figure 704 (Sheet 7 of 9)

# 52-21-03

ASSEMBLY  
Page 759  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL




146A6500-1,-2 Door Lower Region Mechanism Installation Details  
Figure 704 (Sheet 8 of 9)

**52-21-03**

ASSEMBLY  
Page 760  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL



- 1 INSTALL THE BOLT WITH ITS HEAD IN THE DIRECTION SHOWN
- 2 APPLY A THIN LAYER OF BMS 3-38 CORROSION PREVENTIVE COMPOUND TO THE MATING SURFACES OF BUSHINGS AND BOLTS BEFORE INSTALLATION
- 3 USE BMS 3-33 GREASE AS THE INSTALLATION FINISH ON THE BEARING OD, THE HOUSING ID, AND THE MATING BOLT
- 4 PARTS OF DOOR INSTALLATION  
146A6210
- 5 APPLY A THIN LAYER OF BMS 3-33 GREASE AT ASSEMBLY

ITEM NUMBERS REFER TO IPL FIG. 4  
UNLESS SHOWN DIFFERENTLY


ALL DIMENSIONS ARE IN INCHES

146A6500-1,-2 Door Lower Region Mechanism Installation Details  
Figure 704 (Sheet 9 of 9)

# 52-21-03

ASSEMBLY  
Page 761  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL



Activation Module Deep Details  
Figure 705 (Sheet 1 of 4)

**52-21-03**

ASSEMBLY

Page 762


Jul 01/2007



COMPONENT MAINTENANCE MANUAL

STA  
727I + 12.0350 RIGHT SIDE INSTALLATION  
(REF)

STA  
727H + 13.9650 LEFT SIDE INSTALLATION  
(REF)



A-A  
LEFT SIDE INSTALLATION SHOWN  
RIGHT SIDE INSTALLATION SIMILAR  
(SOME MECHANISM PARTS NOT SHOWN)


Activation Module Deep Details  
Figure 705 (Sheet 2 of 4)

**52-21-03**

ASSEMBLY  
Page 763  
Jul 01/2007



COMPONENT MAINTENANCE MANUAL




Activation Module Deep Details  
Figure 705 (Sheet 3 of 4)

**52-21-03**

ASSEMBLY  
Page 764  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL



1 INSTALL THIS BOLT WITH ASTM D5363 AN0311 OR MIL-S-46163 TYPE 2, GRADE M COMPOUND (SOPM 20-50-12)


ITEM NUMBERS REFER TO IPL FIG. 1 UNLESS SHOWN DIFFERENTLY

Activation Module Deep Details  
Figure 705 (Sheet 4 of 4)

**52-21-03**

ASSEMBLY  
Page 765  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL



Inside Door Handle Installation Details  
Figure 706 (Sheet 1 of 4)

**52-21-03**

ASSEMBLY


Page 766

Jul 01/2007

**COMPONENT MAINTENANCE MANUAL**

STA  
727I + 12.0350 RIGHT SIDE  
(REF) INSTALLATION

STA  
727H + 13.9650 LEFT SIDE  
(REF) INSTALLATION




LEFT SIDE INSTALLATION SHOWN  
RIGHT SIDE INSTALLATION SIMILAR

Inside Door Handle Installation Details  
Figure 706 (Sheet 2 of 4)

**52-21-03**

ASSEMBLY  
Page 767  
Jul 01/2007

### COMPONENT MAINTENANCE MANUAL




Inside Door Handle Installation Details  
Figure 706 (Sheet 3 of 4)

# 52-21-03

ASSEMBLY  
Page 768  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL



1 INSTALL WITH WET BMS 5-95 SEALANT (SOPM 20-50-19, METHOD 2)

ITEM NUMBERS REFER TO IPL FIG. 1 UNLESS SHOWN DIFFERENTLY



ALL DIMENSIONS ARE IN INCHES

Inside Door Handle Installation Details  
Figure 706 (Sheet 4 of 4)

**52-21-03**

ASSEMBLY  
Page 769  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL



Inside Door Handle Installation Details  
Figure 707 (Sheet 1 of 2)

**52-21-03**


ASSEMBLY

Page 770

Jul 01/2007



COMPONENT MAINTENANCE MANUAL



1 MEASURE THIS GAP WITH THE RETAINER PUSHED AGAINST THE SEAL. USE WASHERS (165,170) AS NECESSARY BETWEEN RETAINER AND NUTPLATE TO GET THIS GAP

ITEM NUMBERS REFER TO IPL FIG. 1  
ALL DIMENSIONS ARE IN INCHES

Inside Door Handle Installation Details  
Figure 707 (Sheet 2 of 2)

**52-21-03**

ASSEMBLY  
Page 771  
Jul 01/2007



**COMPONENT MAINTENANCE MANUAL**

**FITS AND CLEARANCES**

**(NOT APPLICABLE)**

**52-21-03**

FITS AND CLEARANCES

Page 801

Jul 01/2007



**COMPONENT MAINTENANCE MANUAL**

**SPECIAL TOOLS, FIXTURES, AND EQUIPMENT**

**(NOT APPLICABLE)**

**52-21-03**

SPECIAL TOOLS, FIXTURES, AND EQUIPMENT

Page 901

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### ILLUSTRATED PARTS LIST

#### 1. Introduction

- A. The Illustrated Parts List (IPL) contains an illustration and a list of component parts you can repair or replace. The Illustrated Parts Catalog (IPC) shows how to use the Boeing part number system.
- B. This shows how parts are related: The relation of each item to its next higher assembly (NHA) is shown in the NOMENCLATURE column. Use the indenture system that follows:

1	2	3	4	5	6	7
.	Assembly					
.	Attaching parts for assembly					
.	.	Detail parts for assembly				
.	.	Subassembly				
.	.	Attaching parts for subassembly				
.	.	.	Detail parts for subassembly			
.	.	.	Sub-subassembly			
.	.	.	Attaching parts for subassembly			
.	.	.	.	Details parts for sub-subassembly		
						Detail Installation Parts (Included only if installation parts may be sent to the shop as part of assembly)

- C. Each top assembly is given one use code letter (A, B, C, etc.) in the USAGE CODE column. All subsequent component parts in the list can have one or more of the use code letters to show effectivity to top assemblies. A component part without a use code applies to all top assemblies.
- D. An alphabetical letter is added after the item number for optional parts, parts changed by a Service Bulletin, configuration differences (except left-handed and right-handed parts), last engineering releases, and parts added between item numbers in a sequence. The alphabetical letter will not be shown on the illustration for equivalent parts of the same part number.
- E. Color-coded parts are identified with a single digit alpha following the dash number or with "SP" suffix. If the "SP" suffix is used, it represents consolidation of all color codes applicable for a given usage which are not separately listed. Orders for color-coded parts should include the registry number of the airplane for which the parts are ordered.
- F. If a part number is 15 characters long but will not fit in the part number column, the part number will be displayed with a "~" at the end of the line and will be continued on the next line. The "~" denotes that the part number continues on the next line.
- G. Parts changed by a Service Bulletin are shown by PRE SB XXXX and POST SB XXXX added to the NOMENCLATURE column.
- (1) When a new top assembly is added by a Service Bulletin, PRE SB XXXX and POST SB XXXX will be added at the top assembly level only. The configuration differences at the detail part level are shown by use code letters.
- (2) When the top assembly part number is not changed by the Service Bulletin, PRE SB XXXX and POST SB XXXX will be added at the detail level.
- H. Interchangeable Parts

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1001

Nov 01/2008



## COMPONENT MAINTENANCE MANUAL

Optional (OPT)	The part is optional to and interchangeable with other parts that have the same item number.
Replaces, Replaced by and not interchangeable with (REPLACES, REPLACED BY AND NOT INTCHG/W)	The part replaces and is not interchangeable with the initial part.
Replaces, Replaced by (REPLACES, REPLACED BY)	The part replaces and is interchangeable with, or is an alternative to, the initial part.

### VENDOR CODES

<b>Code</b>	<b>Name</b>
02758	NETWORKS ELECTRONIC CORP U S BEARING DIV 9750 DE SOTO AVENUE CHATSWORTH, CALIFORNIA 91311-4409 FORMERLY U S BEARING DIV NETWORKS ELEC CORP
04169	WESTERN SKY INDUSTRIES A DIVISION OF ATLAS CORPORATION 1280 SAN LUIS OBISPO STREET HAYWARD, CALIFORNIA 94544-7916 FORMERLY WESTERN SKY IND VB0008
06144	INDUSTRIAL TECTONICS BEARING CORP 18301 SOUTH SANTA FE AVENUE RANCHO DOMINGUEZ, CALIFORNIA 90221 FORMERLY IN COMPTON, CALIFORNIA
06725	AIR INDUSTRIES CORPORATION 12570 KNOTT STREET GARDEN GROVE, CALIFORNIA 92641-3932 FORMERLY AIR INDUSTRIES OF CALIF IN GARDENA, CALIF.
06950	SCREWCORP VSI AEROSPACE PRODUCTS DIV FAIRCHILD IND DIV 13001 EAST TEMPLE AVENUE PO BOX 730 CITY OF INDUSTRY, CALIFORNIA 91746-1417 FORMERLY VB0096 AND VSI CORP SCREWCORP DIV FORMERLY IN CULVER CITY, CALIFORNIA SCREW CORP SEE V.S.I. CORP SCREWCORP DIVISION

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1002

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

Code	Name
09455	RBC TRANSPORT DYNAMICS CORP 3131 W SEGERSTROM AVE SANTA ANA, CALIFORNIA 92704-5872 FORMERLY TRANSPORT DYNAMICS AEROSPACE DIV; FABROID DIV TRANSPORT DYNAMICS V17571 & LEAR SEIGLER INC TRANSPORT DIV V98076; FORMERLY BFM TRANSPORT DYNAMICS
0PTK6	SPS TECHNOLOGIES INC AEROSPACE PRODUCTS DIV 5195 W 4700 SALT LAKE CITY, UTAH 94118 SEE V56878 SPS TECHNOLOGIES INC
11815	CHERRY AEROSPACE FASTENERS DIV OF TEXTRON 1224 EAST WARNER AVENUE PO BOX 2157 SANTA ANA, CALIFORNIA 92707-0157 FORMERLY IN LOS ANGELES, CALIF , FORMERLY CHERRY FASTENERS TOWNSEND DIV OF TEXTRON INC V71087
15653	ALCOA GLOBAL FASTENERS INC DIV KAYNAR PRODUCTS 800 S STATE COLLEGE BLVD FULLERTON, CALIFORNIA 92831-3001 FORMERLY VK6405 MICRODOT AEROSP LTD; FORMERLY KAYNAR TECH FORMERLY FAIRCHILD FASTENERS KAYNAR DIV
15860	NEW HAMPSHIRE BALL BEARINGS, INC ASTRO DIVISION 155 LEXINGTON AVENUE LACONIA, NEW HAMPSHIRE 03246-2937 FORMERLY ASTRO BEARING CORP, LOS ANGELES, CALIF.
16746	SPECLINE INCORPORATED 2230 MOUTON DR CARSON CITY, NV 89706 FORMERLY IN SUN VALLEY, CAIFORNIA
17446	HUCK INTL INC AEROSPACE FASTENER DIV 900 WATSON CENTER ROAD CARSON, CALIFORNIA 90745-4201 FORMERLY V32134 REXNORD INC; FORMERLY V97928 HUCK INTL

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1003

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

Code	Name
21335	TIMKEN US CORPORATION DIV FAFNIR 336 MECHANIC STREET LEBANON, NH 03766-0267 FORMERLY FAFNIR BRG AND TEXTRON INC FAFNIR DIV IN NEW BRITAIN, CONNECTICUT ; FORMERLY TORRINGTON CO THE SPECIAL PRODUCTS DIV SUB OF THE INGERSOLL-RAND CO V8D210 FORMERLY TORRINGTON CO FAFNIR BEARING DIV IN TORRINGTON, CT
21760	SCHATZ BEARING CORP 10 FAIRVIEW AVENUE PO BOX 1191 POUGHKEEPSIE, NEW YORK 12601-1312 FORMERLY FEDERAL BRG CO AND SCHATZ MFG CO V53268 FORMERLY SCHATZ MFG CO
29666	HUCK MANUFACTURING CO SUB OF FEDERAL-MOGUL CORP 6 THOMAS IRVINE, CALIFORNIA 92714 FORMERLY HUCK MFG CO VB0016 IN DETROIT, MICHIGAN
40920	MPB MINIATURE PRECISION BEARING DIV PRECISION PARK PO BOX 547 KEENE, NEW HAMPSHIRE 03431 FORMERLY MPB CORP AND MINIATURE BRG DIV MPB CORP
50294	NEW HAMPSHIRE BALL BEARINGS, INC PRECISION DIVISION 9700 INDEPENDENCE AVENUE CHATSWORTH, CALIFORNIA 91311 FORMERLY NIPPON MINATURE BEARING CORP V23589 AND NMB AMERICA INC AND NMB INC
50632	KAMATICS CORP SUB OF KAMAN CORP 1335 BLUE HILLS ROAD BLOOMFIELD, CONNECTICUT 06002-1304
52828	REPUBLIC FASTENER MFG CORP 1300 RANCHO CONEJO BLVD NEWBURY PARK, CALIFORNIA 91320-1405 FORMERLY IN SYLMAR, CALIFORNIA
56644	AURORA BEARING CO 970 SOUTH LAKE STREET AURORA, ILLINOIS 60506-5929

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1004

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

Code	Name
56878	SPS TECHNOLOGIES INC AEROSPACE AND INDUSTRIAL PRODUCTS DIV 301 HIGHLAND AVE JENKINTOWN, PENNSYLVANIA 19046 FORMERLY STANDARD PRESSED STEEL FORMERLY IN SALT LAKE, UTAH
5M902	ALCOA GLOBAL FASTENERS INC, DIV OF VOI-SHAN PRODUCTS 3000 W LOMITA BLVD TORRANCE, CALIFORNIA 90505-5103 FORMERLY FAIRCHILD INC INC FAIRCHILD AEROSPACE FASTENERS DIV
60516	WEST COAST AEROSPACE INC 812 MIRAFLORES STREET SAN PEDRO, CALIFORNIA 90731-1439
62554	SIMMONDS MECAERO FASTENERS INC 1734 SEQUOIA AVENUE ORANGE, CALIFORNIA 92668
71895	DELAVAN INC GAS TURBINE PRODUCTS DIV 811 4TH ST PO BOX 65100 WEST DES MOINES, IOWA 50265-0100
71985	DOW-ELCO INCORPORATED 1313 W OLYMPIC BOULEVARD, PO BOX 669 MONTEBELLO, CALIFORNIA 90641-5010
72962	HARVARD INDUSTRIES INC 3 WERNER WAY SUITE 210 LEBANON, NEW JERSEY 08833 FORMERLY ESNA V7A079 FORMERLY ELASTIC STOP NUT IN UNION, NJ
73134	ROLLER BEARING COMPANY OF AMER DBA HEIM BEARINGS DIV 60 ROUND HILL RD FAIRFIELD, CONNECTICUT 06430-0000 FORMERLY INCOM INTL HEIM DIV; HEIM UNIVERSAL CORP INCOM; FORMERLY HEIM DIV INCOM INTL; IMO IND HEIM BEARINGS DIV

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1005

Jul 01/2007



**COMPONENT MAINTENANCE MANUAL**

<b>Code</b>	<b>Name</b>
73197	HI-SHEAR TECHNOLOGY CORP 2600 SKYPARK DRIVE TORRANCE, CALIFORNIA 90509
80539	SPS TECHNOLOGIES INC DIV AERPSOACE - SANTA ANA 2701 SOUTH HARBOR BOULEVARD SANTA ANA, CALIFORNIA 92704-5803 FORMERLY NUTT-SHEL DIV OF SPC WESTERN CO V80539 AND STANDARD PRESSED STEEL WESTERN DIV V17279
81376	SMITH ACQUISITION COMPANY 2240 BUENA VISTA BALDWIN PARK, CALIFORNIA 91706
83086	NEW HAMPSHIRE BALL BEARING, INC HITECH DIVISION 172 JAFFREY ROAD PETERBOROUGH, NEW HAMPSHIRE 03458
91812	ESTERLINE MASON 13955 BALVOA ROAD SYLMAR, CALIFORNIA 91342 FORMERLY JANCO CORPORATION
92215	FAIRCHILD IND INC FAIRCHILD AEROSPACE FASTENER DIV 3010 W LOMITA BLVD TORRANCE, CALIFORNIA 90505-5102 FORMERLY VOI-SHAN IN CULVER CITY, CALIF
97393	SHUR-LOK CORPORATION 2541 WHITE ROAD PO BOX 19584 IRVINE, CALIFORNIA 92623-9584 FORMERLY SHUR LOK CORP VB0060 FORMERLY IN SANTA ANA, CALIFORNIA 92714
97415	SMITHS AEROSPACE ACTUATION SYSTEMS-YAKIMA 2720 W WASHINGTON AVE YAKIMA, WASHINGTON 98909-0907 FORMERLY DECOTO AIRCRAFT AND DOWTY DECOTO; FORMERLY DOWTY AEROSPACE YAKIMA

**52-21-03**

ILLUSTRATED PARTS LIST

Page 1006

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

Code	Name
97613	SARGENT CONTROLS & AEROSPACE/KAHR BEARING DIV 5675 W BURLINGAME RD TUCSON, ARIZONA 85743 FORMERLY AETNA STEEL PROD KAHR BEARING DIV V96579 FORMERLY SARGENT IND KAHR BEARING DIV, BURBANK, CALIFORNIA
97928	Replaced: [V97928] SEE V17446 HUCK INTL by Code: Name and Address below 17446: HUCK INTL INC AEROSPACE FASTENER DIV 900 WATSON CENTER ROAD CARSON, CALIFORNIA 90745-4201 FORMERLY V32134 REXNORD INC; FORMERLY V97928 HUCK INTL
9N513	VOI SHAN/CHATSWORTH DIV OF VSI CORP SUB OF FAIRCHILD IND CHATSWORTH, CALIFORNIA 91311-5013 COMPANY NO LONGER WISHES TO BE CONSIDERED FOR FED CONTRCTG
S0352	NIPPON MINIATURE BEARING CO LTD TOKYO, JAPAN

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1007

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

### NUMERICAL INDEX

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
102B13171-3		2	805	1
102F9201-3		1	385	2
		1	410	6
		1	485	2
102F9220-3		1	565	4
109LH9075-4W		3	54	1
10E4-116M		2	155	1
12E4-117M		2	100	2
		2	150	1
140N2035-1		1	180	1
140N2036-1		1	185A	1
140N2612-3		1	195	1
140N2623-7		1	365	2
		1	390	2
		1	415	2
		1	440	2
		1	465	2
		1	500	2
140N2764-1		1	190A	1
146A6200-1		1	1A	RF
146A6200-2		1	5	RF
146A6210-1REVA		1	10	1
146A6210-1REVB		1	10A	1
146A6210-1REVC		1	10B	1
146A6210-2REVA		1	15	1
146A6210-2REVB		1	15A	1
146A6210-2REVC		1	15B	1
146A6249-1		1	145	1
146A6250-1REVA		1	85	1
146A6250-2REVA		1	90	1
146A6250-3REVA		1	120	1
146A6250-4REVA		1	125	1
146A6251-1		1	115	1
146A6400-3REVA		1	225	1

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1008

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
146A6400-3REVB		1	225A	1
146A6400-3REVC		1	225B	1
146A6400-4REVA		1	230	1
146A6400-4REVB		1	230A	1
146A6400-4REVC		1	230B	1
146A6400-5REVA		1	150	1
146A6400-6REVA		1	155	1
146A6418-1		1	510	2
146A6418-3		1	610	1
146A6420-1		1	765	1
146A6420-101		1	905	1
146A6420-103		1	760	1
146A6420-105		1	850	1
146A6420-107		1	905A	1
146A6420-3		1	685	1
146A6420-7		1	765A	1
146A6421-1		1	335	1
146A6421-101		1	370	1
146A6422-1		1	375	1
146A6422-101		1	395	1
146A6423-1		1	400	1
146A6423-101		1	420	1
146A6424-1		1	425	1
146A6424-101		1	445	1
146A6425-1		1	450	1
146A6425-101		1	470	1
146A6426-1		1	475	1
146A6426-101		1	515	1
146A6428-1		1	520	1
146A6428-101		1	535	1
146A6431-1		1	640	1
146A6431-2		1	645	1
146A6432-1		1	635	1
146A6433-1		1	650	1
146A6433-2		1	655	1

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1009

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
146A6434-1		1	660	1
146A6435-105		3	332	1
146A6439-1		1	570	1
146A6439-3		1	675	1
146A6439-4		1	680	1
146A6445-1		1	575	1
146A6445-101		1	630	1
146A6445-103		1	580	1
146A6447-1		1	815	1
146A6447-2		1	700	1
146A6449-1		1	900	1
146A6449-2		1	755	1
146A6454-1		1	215	2
146A6454-3		1	220	2
146A6456-1		1	175	1
146A6500-1REVA		1	930	1
		4	1A	RF
146A6500-2REVA		1	935	1
		4	5	RF
146A6500-3REVA		1	920	1
		3	1A	RF
146A6500-3REVB		1	920A	1
		3	1B	RF
146A6500-3REVC		1	920B	1
		3	1C	RF
146A6500-4REVA		1	925	1
		3	3	RF
146A6500-4REVB		1	925A	1
		3	3A	RF
146A6500-4REVC		1	925B	1
		3	3B	RF
146A6500-5REVA		1	910	1
		2	1A	RF
146A6500-5REVB		1	910A	1
		2	1B	RF

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1010

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
146A6500-6REVA		1	915	1
		2	5	RF
146A6500-6REVB		1	915A	1
		2	5A	RF
146A6509-1		3	414	1
146A6510-1		3	492	1
146A6510-101		3	513	1
146A6510-103		3	489	1
146A6510-3		3	465	1
146A6511-3		3	642	1
146A6511-4		3	636	1
146A6511-5		3	519	1
146A6511-7		2	195	1
146A6511-8		2	200	1
146A6511-9		2	665	1
146A6512-1		3	435	1
146A6512-101		3	459	1
146A6512-103		3	462	1
146A6512-3		3	438	1
146A6516-1		3	525	1
146A6520-1		3	576	1
146A6521-1		3	651	1
146A6522-1		3	597	2
146A6522-101		3	618	1
146A6523-1		3	639	1
146A6523-3		3	648	1
146A6524-1		3	621	1
146A6524-101		3	630	1
146A6526-1		2	635	1
146A6526-101		2	655	1
146A6527-1		2	620	1
146A6527-101		2	630	1
146A6529-1		2	445	1
146A6530-1		2	140	1
146A6530-2		2	90	1

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1011

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
146A6531-1		2	105	1
146A6532-1		2	380	1
146A6535-1		2	420	1
146A6535-101		2	435	1
146A6536-1		2	385	1
146A6536-101		2	415	1
146A6537-1		2	440	1
146A6539-1		2	55	1
146A6540-1		2	260	1
146A6540-101		2	310	1
146A6542-1		2	305	1
146A6545-1		2	255	1
146A6545-3		3	522	1
146A6546-1		2	210	1
146A6546-101		2	225	1
146A6546-102		2	230	1
146A6546-2		2	215	1
146A6547-1		2	235	1
146A6547-101		2	250	1
146A6551-1		4	275	1
146A6551-101		4	290	1
146A6552-1		4	295	1
146A6552-101		4	320	1
146A6552-102		4	325	1
146A6552-2		4	300	1
146A6553-1		4	380	2
146A6553-101		4	395	1
146A6554-1		4	400	2
146A6554-101		4	415	1
146A6554-102		4	420	1
146A6554-2		4	405	2
146A6555-1		4	250	1
146A6555-101		4	265	1
146A6555-102		4	270	1
146A6555-2		4	255	1

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1012

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
146A6556-1		4	330	2
146A6556-3		4	330A	1
146A6557-1		4	335	1
146A6557-101		4	355	1
146A6557-102		4	360	1
146A6557-2		4	340	1
146A6558-1		4	375A	1
146A6558-3		4	375B	1
146A6559-1		4	365	1
146A6559-2		4	370	1
146A6562-1		4	225	1
146A6562-2		4	230	1
146A6568-1		3	645	1
146A6568-2		3	633	1
146A6568-4		2	660	1
146A6568-5		3	516	1
146A6575-1		3	288	1
146A6575-101		3	300	1
146A6575-103		3	156	1
146A6575-3		3	144	1
146A6576-1		3	303	1
146A6576-101		3	312	1
146A6576-103		3	168	1
146A6576-3		3	159	1
146A6577-1		3	129	1
146A6577-101		3	135	1
146A6577-103		3	126	1
146A6577-3		3	120	1
146A6578-1		3	315	1
146A6578-101		3	321	1
146A6579-1		3	199	1
146A6579-101		3	200A	1
146A6580-1		3	90	1
146A6580-101		3	99	1
146A6580-103		3	233	1

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1013

Jul 01/2007





## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
146A6580-3		3	231	1
146A6581-1		3	78	1
146A6582-1		3	81	1
146A6582-3		3	84	1
146A6582-5		3	87	1
146A6583-1		3	141	2
146A6583-3		2	205	1
146A6585-1		3	138	1
146A6586-1		3	207	1
146A6586-3		3	175	1
146A6587-1		3	324	1
146A6589-1		2	670	1
146A6589-101		2	740	1
146A6590-1		2	780	1
146A6590-101		2	815	1
146A6591-1		2	325	1
146A6591-101		2	335	1
146A6592-1		1	595	1
146A6597-1		2	530	1
146A6597-101		2	540	1
146A6597-102		2	490A	1
146A6597-2		2	480	1
2-7892-2		4	220	2
51588-041DD		2	155	1
51589-041DD		2	100	2
		2	150	1
69-47407-3		2	730	1
740C14-6		1	80	2
		1	555	2
92834-1032CD		2	805	1
97E48		3	54	1
ACMKP04JAP510LY		4	55	8
ACMKP05JAP510LY		4	305	2
		4	385	2
ACMKP06JAP510LY		2	640	2

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1014

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
ACMKP3AFS428		4	55	8
ADB06V301NC		2	625	2
ADB08V301NC		2	330	1
ADW4VNC		3	123A	1
		3	318	2
ADW5VNC		2	810	1
AMB540DDNJC		2	378	2
AMKP16BSNJC		1	715	1
		1	860	1
AR4-7W13		2	100	2
		2	150	1
AR4E7W13		2	155	1
ARB4-61MW		2	100	2
		2	150	1
ARB4E60MW		2	155	1
ASMK4-1DM		2	155	1
ASWK4-1DM		2	100	2
		2	150	1
BACB10ES04GC		4	260	1
		4	310	1
BACB10ES10C		1	855A	1
BACB10FB05C		2	220	1
		3	456	1
BACB10FB06GC		2	625	2
BACB10FB08GC		2	330	1
BACB10FB10C		1	855	1
BACB10FE04C		3	123A	1
		3	318	2
BACB10FE05C		2	810	1
BACB10FE4C		3	132	1
BACB10FS04J		4	55	8
BACB10FS05J		4	305	2
		4	385	2
BACB10FS06J		2	640	2
BACB10FU14J		2	378	2

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1015

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
BACB10FV16J		1	715	1
		1	860	1
BACB10HS06ARBSP2		3	261	1
BACB10HS06ARNSP6		3	615	1
BACB10Y4M		2	155	1
BACB10Z4M		2	100	2
		2	150	1
BACB28AK03-012		2	355	1
		2	695	1
BACB28AK03-022		2	360	1
		2	690	1
BACB28AK03-035		1	880	1
		2	405	1
BACB28AK03-258		4	215	2
BACB28AK04-011		3	118	1
BACB28AK04-015		2	85	1
BACB28AK04-025		2	295	3
		3	486	1
BACB28AK04-026		4	125	4
BACB28AK04-027		2	35	2
BACB28AK04-030		2	135	1
		3	369	1
		3	453	1
		3	594	2
BACB28AK04-031		3	18	1
BACB28AK04-035		3	387	1
BACB28AK04-037		3	255	2
BACB28AK04-055		3	507	1
BACB28AK04-080		2	775	1
BACB28AK04-200		3	48	1
BACB28AK05-037		3	195	1
BACB28AK05-038		4	90	2
BACB28AK05-051		1	65	4
		4	160	4
BACB28AK05-055		3	198	1

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1016

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
		4	95	2
BACB28AK05-090		4	165	2
BACB28AK05-120		1	70	2
BACB28AK05-155		3	285	1
BACB28AK05-42		1	60	4
BACB28AK06-007		2	565A	2
BACB28AK06-018		2	515	1
BACB28AK06-039		2	590	1
		2	615	1
BACB28AK06-048		2	520	1
BACB28AK06-053		2	770	1
BACB28AP04-009		2	240	1
BACB28AP04-011		4	345	1
BACB28AP04-014		3	480	1
		3	510	2
BACB28AP04-018		3	150	1
BACB28AP04-022		3	294	1
		3	624	1
BACB28AP05-011		3	93A	2
BACB28AP06P018		2	425	1
		2	645	1
BACB28AP06P052		4	280	1
BACB28AT06B012A		2	410	1
		4	350	1
BACB28AT06B014A		3	483	1
BACB28AT06B015A		2	245	1
BACB28AT06B018A		3	153	1
BACB28AT06B018C		3	162	1
BACB28AT06B022A		3	297	1
		3	627	1
BACB28AT06B027C		1	620	2
BACB28AT06B037C		1	625	2
BACB28AT06B045C		2	735	2
BACB28AT07B022C		1	505	2
		1	720	1

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1017

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
		1	885	1
		3	96	1
BACB28AT07C015A		3	306	1
BACB28AT09B018A		2	430	1
BACB28AT09B018C		2	650	1
BACB28AX04B053		3	232	2
BACB28AX04C018		3	165	1
BACB28AX04C022		2	300	1
BACB28AX05B014		3	309	1
BACB28AX05C014		3	309A	1
BACB28AY07A026C		4	285	4
BACB28AY07A028C		4	410	1
BACB28AY10A025C		2	297	2
BACB28AZ06A065B		3	147	2
BACB28AZ07A056B		3	291	2
BACB28BC07A052B		3	199J	1
BACB28BG06A06381		4	35	2
BACB28Y3M035		1	140	1
BACB28Y4C035		2	725	1
BACB28Y5C390		4	315	1
		4	390	1
BACB30LE4U16		2	270	1
BACB30LH3-13		2	450	2
BACB30LH4-10		4	40	8
BACB30LM3-17		2	705	1
BACB30LM3-19		2	365	4
BACB30LM3-9		2	340	1
		2	675	1
BACB30LR4D16		2	750	1
BACB30MR4A10		3	342	2
BACB30MR4A6		3	339	2
BACB30NR4DK13		4	105	4
BACB30NR4DK16		2	65	1
BACB30NR4DK17		2	115	1
BACB30NR4DK18		3	375	1

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1018

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
BACB30NR4DK20		3	237	2
BACB30NR4DK27		3	108	1
BACB30NR4DK28		3	105	1
BACB30NR4DK38		3	36	1
BACB30NR4K10		2	265	1
BACB30NR4K11		2	160	1
BACB30NR4K13		3	417	1
BACB30NR4K14		1	95	2
		3	420	1
BACB30NR4K18		3	390	3
BACB30NR4K20		3	393	1
BACB30NR4K22		3	396A	1
		3	579	2
BACB30NR4K24		3	582	4
BACB30NR4K7		3	441	1
BACB30NR4K8		3	468	1
BACB30NR4K9		2	10	2
		3	354	1
BACB30NR5DK29		3	183	1
		3	273	1
BACB30NR5DK42		4	135	2
BACB30NR5DK84		4	65	2
BACB30NR5DK88		4	70	2
BACB30NR5K27		1	20	2
BACB30NR5K43		1	25	2
BACB30NR6DK16		2	575	1
		2	600	1
		4	175	2
BACB30NR6DK33		4	15	2
BACB30NT3K3		1	160	3
BACB30NT3K4		3	201	2
BACB30NT3K6		1	130	1
BACB30NT4DK17		3	9	1
BACB30NX6K5		3	213	1
BACB30NX6K7		3	210	1

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1019

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
BACB30PW4U18		3	495	1
BACB30VT5HK4		1	585	4
		1	600	2
		1	835	1
BACB30VT5HK6		1	830	1
BACB30VT5K3		3	333	4
BACB30VT5K4		1	665	6
BACB30VT6K11		4	235	2
BACB30VT6K3		1	235	29
BACB30VT6K4		1	240	162
		1	835A	1
		2	315	3
BACB30VT6K5		1	245	40
		1	705	4
		1	820	4
BACB30VT6K6		1	250	4
		1	745	3
		1	830A	1
		1	890	3
BACB30VT6K7		1	255	5
BACB30VT6K8		1	865	1
BACB30VT6K9		2	390	1
BACB30VT8K5		3	327	6
BACB30YL6K4		2	40	6
BACB30YL6K6		3	21	2
		3	219	4
BACB30YL6K7		3	24	2
BACB30YP5K3		1	262	2
BACB30YP5K4		1	264	6
BACB30YP5K5		3	171	2
BACB30YP6K11		4	240	1
BACB30YP6K4		1	265	2
BACB30YP6K5		1	270	2
BACB30YP6K7		1	275	2
BACB30YP6K8		1	277	6

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1020

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY	
BACB31A3-46		4	195	2	
BACC30BH6S		3	216	2	
BACC30BL5		1	282	4	
		1	590	4	
		1	605	2	
		1	670	6	
		1	840	2	
		3	174	2	
		3	336	4	
	BACC30BL6		1	260	240
			1	280	12
			1	710	4
		1	750	3	
		1	825	4	
		1	840A	2	
		2	320	3	
		4	245	3	
BACC30BL8			3	330	6
BACC30BS6S			1	875	1
		2	400	1	
BACC30CP6C		2	45	6	
BACC30CQ6CR		3	27	4	
BACC30L6		1	895	3	
BACG20ZB001510		1	200	2	
BACJ40CG6G		1	80	2	
		1	555	2	
BACN10BP6CD		4	30	2	
BACN10GH3A10		1	355	1	
BACN10JC4CM		3	54	1	
BACN10JD104CD		4	120	4	
BACN10JD106AU		3	612	1	
BACN10JD106CD		2	585	1	
		2	610	1	
		4	190	2	
BACN10JD108ASU		3	72	1	

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1021

Jul 01/2007





## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
BACN10JD110ASU		3	75	1
BACN10JD4ASU		2	130	1
BACN10JD4AU		3	249	1
BACN10JD4CD		2	80	1
		2	765	1
		3	15	1
		3	45	1
		3	117	2
		3	252	1
		3	384	1
BACN10JD5ASU		2	510	1
		2	560	1
		3	192	1
BACN10JD5CD		3	282	1
		4	85	4
		4	155	2
BACN10JD6CD		3	267	1
BACN10JR3CFD		1	385	2
		1	410	6
		1	485	2
BACN10JZ3B2CDM		1	565	4
BACN10KJ3CD		1	530	3
BACN10TL3A12		1	345	3
		1	735	3
BACN10TL3A16		1	740	1
		1	800	1
BACN10TL3A3		1	435	1
		1	460	1
		1	495	1
BACN10YR3CD		2	350	1
		2	375	4
		2	470	2
		2	685	1
		2	720	1
		4	210	2

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1022

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
BACN10YR3CM		3	504	1
BACN10YR4CD		1	110	2
		2	30	2
		3	366	1
		3	450	1
		4	50	8
BACN10YR4CM		2	170	1
		2	290	2
		3	405	5
		3	429	2
		3	477	1
		3	591	6
BACN10YR5CD		1	40	4
		1	55	2
		1	550	2
BACN10YT3CD		3	222	4
BACN10ZC3CD		2	805	1
BACN11U3CM1		2	795	1
BACN11U5CD2		3	228	2
BACN11U5CM1N		2	95	2
		2	145	1
BACN11Z4CD		3	351	4
BACP18BC02A03P		4	100	4
BACP18BC02A04P		4	60	4
		4	130A	2
BACP18BC02A05P		3	6	1
		3	33	1
		3	102	2
		3	234	2
		3	372	1
BACP18BC02A06P		2	60	1
		2	110	1
		2	475	1
		2	525A	1
		3	180	1

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1023

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
		3	270	1
BACP18BC03A04P		3	63A	1
BACP18BC03A05P		4	10	2
		4	170	2
BACP18BC03A08P		2	570	1
		2	595	1
BACP18BC03A10P		3	258	1
		3	600	1
BACP18BC04A08P		3	60A	1
BACP18C02A06P		2	745	1
BACR10AL3A		2	800	1
BACR15BA3AD2C		1	525A	6
BACR15BA3ADC		1	380	4
		1	405	12
		1	480	4
BACR15BA4ADC		1	560	8
BACR15BB3ADC		1	340	6
		1	805	10
BACR15BB4ADC		1	350	2
		1	430	2
		1	455	2
		1	490	2
		1	690	10
		1	730	8
		1	795	2
BACR15GF5D		1	632	144
BACR15GF6D		1	634	65
BACS12CK3U26		2	785	1
BACS12HN3-12		1	770	1
BACS12HN5-10		1	540	2
BACS12HN5-12		1	45	2
BACS12HN5-14D		3	225	1
BACS31H1B		1	360	1
		1	725	4
		1	790	1

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1024

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
BACS40R008A017F		1	320	3
BACS40R008E026F		2	460	1
BACS40R009A009F		1	285	16
BACS40R009A017F		1	315	1
BACS40R009A028F		1	325	2
BACS40R009A029F		1	305	2
BACS40R009A033F		1	290	2
BACS40R009A034F		1	295	6
BACS40R010A016F		1	310	1
BACS40R012A022F		1	330	1
BACS40R015A022F		1	300	1
BACS40R020Y023P		3	30	1
BACS40U3L3		1	845	2
BACW10BN10AC		2	180	1
BACW10BN4AP		2	25	2
		2	75	2
		3	363	1
BACW10BN5AC		2	175	1
BACW10BP10APU		3	69	1
BACW10BP3CD		4	200	2
BACW10BP3DP		4	205	2
BACW10BP3NAPU		3	204	2
BACW10BP4AC		3	357	1
		3	378	1
BACW10BP4ACU		1	100	2
		2	15	2
		2	70	1
		2	120	1
		2	275	2
		3	39	1
		3	111	2
		3	240	2
		3	399	5
		3	423	2
		3	444	1

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1025

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
		3	471	1
		3	498	1
		3	585	6
		4	110	4
BACW10BP4AP		3	381	2
BACW10BP4APU		2	125	2
		2	165	1
		2	280	2
		3	51	1
		3	243	1
		3	402	5
		3	426	2
		3	447	1
		3	474	2
		3	588	8
		4	115	4
BACW10BP4CD		3	345	4
		4	45	8
BACW10BP4DP		1	105	2
		3	12	1
		3	42	1
		3	114	2
		3	246	1
		3	348	4
BACW10BP5ACU		3	186	1
		3	276	1
BACW10BP5APU		3	189	1
		3	279	1
BACW10BP5CD		1	30	8
		4	75	4
		4	140	2
BACW10BP5DP		4	80	4
		4	145	2
BACW10BP6ACU		3	432	2
BACW10BP6CD		4	20	2

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1026

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
		4	180	2
BACW10BP6DP		3	264	1
		4	25	2
		4	185	2
BACW10EC3S		1	775	1
BACW10P271TF		2	715	2
BACW10P399CD		2	190	1
BACW10P435CG		2	20	2
		3	360A	1
BACW10P5CC		1	870	1
		2	395	1
BCREF50875		3	615	1
BCREF51111		4	35	2
BCREF51180		3	261	1
BRES4-2236M1		2	155	1
BRES4-2242M1		2	100	2
		2	150	1
BRF200C3D		1	385	2
		1	410	6
		1	485	2
BRH10C4M		3	54	1
DCM6E		1	895	3
		1	895	3
DE847		1	695	5
		1	810	5
F51646-3BAC		1	565	4
F51652-3		1	530	3
FSSK4AS1		2	100	2
		2	150	1
H01-4BAC		3	54	1
H52732-3CD		2	350	1
		2	375	4
		2	470	2
		2	685	1
		2	720	1

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1027

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
		4	210	2
H52732-3CM		3	504	1
H52732-4CD		1	110	2
		2	30	2
		3	366	1
		3	450	1
		4	50	8
H52732-4CM		2	170	1
		2	290	2
		3	405	5
		3	429	2
		3	477	1
		3	591	6
H52732-5CD		1	40	4
		1	55	2
		1	550	2
HB4-201KM		2	100	2
		2	150	1
HB4E212KM		2	155	1
HL1012AZ6-5		3	213	1
		3	213	1
		3	213	1
		3	213	1
		3	213	1
		3	213	1
		3	213	1
		3	213	1
		3	213	1
		3	213	1
HL1012AZ6-7		3	210	1
		3	210	1
		3	210	1
		3	210	1
		3	210	1
		3	210	1
		3	210	1
		3	210	1
		3	210	1

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1028

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
HL1087DU6		3	216	2
		3	216	2
		3	216	2
		3	216	2
HL12VAZ6-5		3	213	1
		3	213	1
		3	213	1
		3	213	1
HL12VAZ6-7		3	210	1
		3	210	1
		3	210	1
		3	210	1
HLT420AP6-4		2	40	6
		2	40	6
		2	40	6
HST1094DU6		1	875	1
		2	400	1
HST10AG5-3		3	333	4
		3	333	4
		3	333	4
		3	333	4
HST10AG5-4		1	665	6
		1	665	6
		1	665	6
		1	665	6
HST10AG6-11		4	235	2
		4	235	2
		4	235	2
		4	235	2
HST10AG6-3		1	235	29
		1	235	29
		1	235	29
		1	235	29
HST10AG6-4		1	240	162
		1	240	162

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1029

Jul 01/2007





## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY	
HST10AG6-5		1	240	162	
		1	240	162	
		1	835A	1	
		1	835A	1	
		1	835A	1	
		1	835A	1	
		2	315	3	
		2	315	3	
		2	315	3	
		2	315	3	
		1	245	40	
		1	245	40	
		1	245	40	
		1	245	40	
	HST10AG6-6		1	705	4
			1	705	4
		1	705	4	
		1	705	4	
		1	820	4	
		1	820	4	
		1	820	4	
		1	820	4	
		1	250	4	
		1	250	4	
		1	250	4	
		1	250	4	
		1	745	3	
		1	745	3	
		1	745	3	
		1	745	3	
	1	830A	1		
	1	830A	1		
	1	830A	1		
	1	830A	1		
	1	890	3		

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1030

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
HST10AG6-7		1	890	3
		1	890	3
		1	890	3
		1	255	5
		1	255	5
		1	255	5
HST10AG6-8		1	865	1
		1	865	1
		1	865	1
		1	865	1
HST10AG6-9		2	390	1
		2	390	1
		2	390	1
		2	390	1
HST10AG8-5		3	327	6
		3	327	6
		3	327	6
		3	327	6
HST79-5		1	282	4
		1	590	4
		1	605	2
		1	670	6
		1	840	2
		3	174	2
		3	336	4
HST79-6		1	260	240
		1	280	12
		1	710	4
		1	750	3
		1	825	4
		1	840A	2
		2	320	3
		4	245	3
HST79-8		3	330	6

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1031

Jul 01/2007



COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
HST79CY5		1	282	4
		1	282	4
		1	282	4
		1	590	4
		1	590	4
		1	590	4
		1	605	2
		1	605	2
		1	605	2
		1	670	6
		1	670	6
		1	670	6
		1	840	2
		1	840	2
		1	840	2
		3	174	2
		3	174	2
		3	174	2
		3	336	4
		3	336	4
3	336	4		
HST79CY6		1	260	240
		1	260	240
		1	260	240
		1	280	12
		1	280	12
		1	280	12
		1	710	4
		1	710	4
		1	710	4
		1	750	3
		1	750	3
		1	750	3
		1	825	4
1	825	4		

**52-21-03**

ILLUSTRATED PARTS LIST

Page 1032

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
		1	825	4
		1	840A	2
		1	840A	2
		1	840A	2
		2	320	3
		2	320	3
		2	320	3
		4	245	3
		4	245	3
		4	245	3
HST79CY8		3	330	6
		3	330	6
		3	330	6
HTES04VC		4	260	1
		4	310	1
HTFB06GC		2	625	2
HTFB08GC		2	330	1
K0540-075		1	205	1
K0540-125		1	210	4
K51602-3BAC		1	385	2
		1	410	6
		1	485	2
KB4-150WD5		2	100	2
		2	150	1
KBE4-150WD5		2	155	1
KNDB06-70		2	625	2
KNDB08-70		2	330	1
KPD4434		1	75	12
KR4CWGBZC		3	123A	1
		3	318	2
KR5CWGBZC		2	810	1
KRP146004BT		3	57	1
KSC145700BZ06GC		2	625	2
KSC145700BZ08GC		2	330	1
KWDB4-39		3	123A	1

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1033

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
		3	318	2
KWDB5-39		2	810	1
L802-6K5		3	213	1
L802-6K7		3	210	1
MODREF284105		1	85	1
MODREF284106		1	90	1
MODREF284107		1	120	1
MODREF284108		1	125	1
MODREF284217		1	225	1
MODREF284218		1	230	1
MODREF284219		1	150	1
MODREF284220		1	155	1
MODREF285799		1	10	1
MODREF285800		1	15	1
MODREF287697		1	930	1
		4	1A	RF
MODREF287698		1	935	1
		4	5	RF
MODREF287699		1	920	1
		1	925	1
		3	1A	RF
		3	3	RF
MODREF287701		1	910	1
		2	1A	RF
MODREF287702		1	915	1
		2	5	RF
MODREF291630		1	10A	1
MODREF291631		1	15A	1
MODREF292663		1	225A	1
MODREF292664		1	230A	1
MODREF294875		1	10B	1
MODREF294876		1	15B	1
MODREF295479		1	920A	1
		3	1B	RF
MODREF295480		1	925A	1

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1034

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
		3	3A	RF
MODREF297445		1	920B	1
		3	1C	RF
MODREF297446		1	925B	1
		3	3B	RF
MODREF297447		1	910A	1
		2	1B	RF
MODREF297448		1	915A	1
		2	5A	RF
MODREF304975		1	225B	1
MODREF304976		1	230B	1
MS24586C201		2	700A	1
MS24586C65		3	177	2
MS29513-010		2	485	2
		2	535	2
MS29513-020		1	615	1
MS35650-305T		1	785	1
MSSK4AS1		2	155	1
NAS1149C0332R		2	790	1
NAS1149C1616R		3	408	2
NAS1149C1632R		3	411	2
NAS1149D0316H		1	780	2
NAS1149D0463J		2	285	2
NAS1149D0516H		1	50	6
		1	545	6
NAS1149E0316P		1	165	6
NAS1149E0316R		1	135	2
NAS1149E0332P		1	170	9
		2	345	4
		2	370	8
		2	680	4
		2	710	2
NAS1149E0363P		2	455	2
NAS1149E0363R		3	501	1
NAS1149E0416P		2	377	2

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1035

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
NAS1149E0432P		2	755	1
NAS1149E0516P		2	50	AR
NAS1149E0532P		2	500	1
		2	550	1
NAS1149E0616P		2	505	2
		2	555	2
NAS1149E0616R		3	603	1
NAS1149E0632P		2	495	1
		2	545	1
		2	580	2
		2	605	2
NAS1149E0632R		3	606	1
NAS1149E0663R		3	609	1
NAS1149E0716P		1	35	AR
		4	150	16
NAS1149E0863R		3	66	2
NAS1149E0932P		2	760	5
NAS1149V0932M		2	185	1
NC04TG5C		4	260	1
		4	310	1
NES06FBGC		2	625	2
NES08FBGC		2	330	1
NS202101SE048		3	54	1
NS202476-02		1	385	2
		1	410	6
		1	485	2
PACMB540DDFS428		2	378	2
PACMKP04JAA3908		4	55	8
PACMKP04JAFS428		4	55	8
PACMKP05JAA3908		4	305	2
		4	385	2
PACMKP06JAA3908		2	640	2
PACMKP06JAFS428		2	640	2
PACMKP16BSFS428		1	715	1
		1	860	1

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1036

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
PACMKP5AFS428		4	305	2
		4	385	2
PACMKP6AFS428		2	640	2
PLH53CD		2	350	1
		2	375	4
		2	470	2
		2	685	1
		2	720	1
		4	210	2
		3	504	1
PLH53CM		3	504	1
PLH54CD		1	110	2
		2	30	2
		3	366	1
		3	450	1
		4	50	8
PLH54CM		2	170	1
		2	290	2
		3	405	5
		3	429	2
		3	477	1
		3	591	6
PLH55CD		1	40	4
		1	55	2
		1	550	2
S411T100-1010		1	695	5
		1	810	5
SL4113-3CDBAC		2	805	1
SLR4001-3A		2	800	1
SLR50-3A		2	800	1
SSMB540DDSD624		2	378	2
SSMKP04AP		4	55	8
SSMKP04JASD705		4	55	8
SSMKP05AP		4	305	2
		4	385	2
SSMKP05JAP		4	305	2

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1037

Jul 01/2007





## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
SSMKP05JASD705		4	385	2
		4	305	2
		4	385	2
SSMKP06AP		2	640	2
SSMKP06JAP		2	640	2
SSMKP06JASD705		2	640	2
SSMKP4ASD524		4	55	8
SSMKP5ASD524		4	305	2
		4	385	2
SSMKP6ASD524		2	640	2
T6C428JM		3	54	1
T8092C1032CD		1	385	2
		1	410	6
		1	485	2
VL310AG5-4		1	585	4
		1	585	4
		1	585	4
		1	600	2
		1	600	2
		1	600	2
		1	835	1
		1	835	1
		1	835	1
VL310AG5-6		1	830	1
		1	830	1
		1	830	1
VN303D048		3	54	1
WC331K5-3		1	262	2
WC331K5-4		1	264	6
WC331K5-5		3	171	2
WC331K6-11		4	240	1
WC331K6-4		1	265	2
WC331K6-5		1	270	2
WC331K6-7		1	275	2
WC331K6-8		1	277	6

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1038

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NUMBER	FIGURE	ITEM	UNITS PER ASSEMBLY
WES04B10GC		3	123A	1
		3	318	2
WES05B10GC		2	810	1
WHT04VSBC		3	123A	1
		3	318	2
WHT05VSBC		2	810	1
WRRS04B10GC		3	123A	1
		3	318	2
WRRS05B10GC		2	810	1
WS1-332A10		1	355	1
WS14A12		1	345	3
		1	735	3
WSI4A16		1	740	1
		1	800	1


# 52-21-03

ILLUSTRATED PARTS LIST

Page 1039

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



Emergency Exit Door Assembly  
IPL Figure 1 (Sheet 1 of 21)


**52-21-03**

ILLUSTRATED PARTS LIST


Page 1040

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



**(A)**



**(B)**

Emergency Exit Door Assembly  
IPL Figure 1 (Sheet 2 of 21)


**52-21-03**

ILLUSTRATED PARTS LIST

Page 1041

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



Emergency Exit Door Assembly  
IPL Figure 1 (Sheet 3 of 21)


**52-21-03**

ILLUSTRATED PARTS LIST

Page 1042

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



Emergency Exit Door Assembly  
IPL Figure 1 (Sheet 4 of 21)



**52-21-03**

ILLUSTRATED PARTS LIST

Page 1043

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



Emergency Exit Door Assembly  
IPL Figure 1 (Sheet 5 of 21)



**52-21-03**

ILLUSTRATED PARTS LIST

Page 1044

Jul 01/2007

COMPONENT MAINTENANCE MANUAL




Emergency Exit Door Assembly  
IPL Figure 1 (Sheet 6 of 21)

**52-21-03**  
ILLUSTRATED PARTS LIST  
Page 1045  
Jul 01/2007



COMPONENT MAINTENANCE MANUAL



Emergency Exit Door Assembly  
IPL Figure 1 (Sheet 7 of 21)


**52-21-03**

ILLUSTRATED PARTS LIST

Page 1046

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



Emergency Exit Door Assembly  
IPL Figure 1 (Sheet 8 of 21)

**52-21-03**


ILLUSTRATED PARTS LIST

Page 1047

Jul 01/2007



# COMPONENT MAINTENANCE MANUAL



Emergency Exit Door Assembly  
IPL Figure 1 (Sheet 10 of 21)


## 52-21-03

ILLUSTRATED PARTS LIST

Page 1049

Jul 01/2007


COMPONENT MAINTENANCE MANUAL



Emergency Exit Door Assembly  
IPL Figure 1 (Sheet 11 of 21)

**52-21-03**  
ILLUSTRATED PARTS LIST  
Page 1050  
Jul 01/2007


COMPONENT MAINTENANCE MANUAL



Emergency Exit Door Assembly  
IPL Figure 1 (Sheet 12 of 21)

**52-21-03**  
ILLUSTRATED PARTS LIST  
Page 1051  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL



Emergency Exit Door Assembly  
IPL Figure 1 (Sheet 13 of 21)


**52-21-03**

ILLUSTRATED PARTS LIST

Page 1052

Jul 01/2007

COMPONENT MAINTENANCE MANUAL




Emergency Exit Door Assembly  
IPL Figure 1 (Sheet 14 of 21)

**52-21-03**  
ILLUSTRATED PARTS LIST  
Page 1053  
Jul 01/2007





COMPONENT MAINTENANCE MANUAL



Emergency Exit Door Assembly  
IPL Figure 1 (Sheet 16 of 21)


**52-21-03**

ILLUSTRATED PARTS LIST

Page 1055

Jul 01/2007

### COMPONENT MAINTENANCE MANUAL



Emergency Exit Door Assembly  
IPL Figure 1 (Sheet 17 of 21)


# 52-21-03

ILLUSTRATED PARTS LIST

Page 1056

Jul 01/2007

# COMPONENT MAINTENANCE MANUAL



**AD**

Emergency Exit Door Assembly  
IPL Figure 1 (Sheet 18 of 21)



## 52-21-03

ILLUSTRATED PARTS LIST

Page 1057


Jul 01/2007

COMPONENT MAINTENANCE MANUAL



Emergency Exit Door Assembly  
IPL Figure 1 (Sheet 19 of 21)

COMPONENT MAINTENANCE MANUAL



Emergency Exit Door Assembly  
IPL Figure 1 (Sheet 20 of 21)


**52-21-03**

ILLUSTRATED PARTS LIST

Page 1059

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



Emergency Exit Door Assembly  
IPL Figure 1 (Sheet 21 of 21)

**52-21-03**

ILLUSTRATED PARTS LIST

Page 1060

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
-1A	146A6200-1									A	RF
-5	146A6200-2									B	RF
-10	M0DREF285799									A	1
-10A	M0DREF291630									A	1
-10B	M0DREF294875									A	1
-15	M0DREF285800									B	1
-15A	M0DREF291631									B	1
-15B	M0DREF294876									B	1
20	BACB30NR5K27										2
25	BACB30NR5K43										2
30	BACW10BP5CD										8
35	NAS1149E0716P										AR
40	PLH55CD										4
45	BACS12HN5-12										2
50	NAS1149D0516H										6
55	PLH55CD										2

-Item not Illustrated

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1061

Jul 01/2007





## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
60	BACB28AK05-42		.	.							4
65	BACB28AK05-051		.	.							4
70	BACB28AK05-120		.	.							2
75	KPD4434		.	.							12
-80	740C14-6		.	.							2
85	M0DREF284105		.							A	1
-90	M0DREF284106		.							B	1
95	BACB30NR4K14		.	.							2
100	BACW10BP4ACU		.	.							2
105	BACW10BP4DP		.	.							2
110	PLH54CD		.	.							2
115	146A6251-1		.	.							1
120	M0DREF284107		.							A	1
-125	M0DREF284108		.							B	1
130	BACB30NT3K6		.	.							1
135	NAS1149E0316R		.	.							2
140	BACB28Y3M035		.	.							1
145	146A6249-1		.	.							1
-150	M0DREF284219		.							A	1
-155	M0DREF284220		.							B	1
160	BACB30NT3K3		.	.							3

-Item not Illustrated

**52-21-03**

ILLUSTRATED PARTS LIST

Page 1062

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
165	NAS1149E0316P								. . WASHER		6
170	NAS1149E0332P								. . WASHER		9
175	146A6456-1								. . RETAINER-VIEWPORT SEAL		1
180	140N2035-1								. . PRISM ASSY		1
185A	140N2036-1								. . . SLEEVE-INSULATION		1
190A	140N2764-1								. . . PRISM		1
195	140N2612-3								. . SEAL-VIEWPORT		1
200	BACG20ZB001510								. . GROMMET		2
205	K0540-075								. . DAMPER-STAND-OFF		1
210	K0540-125								. . DAMPER-STAND-OFF		4
215	146A6454-1								. . STRIP-RUB, ESCAPE SLIDE		2
220	146A6454-3								. . STRIP-RUB, ESCAPE SLIDE		2
-225	MODREF284217								. STRUCTURE INSTL (LIMITED USAGE) (146A6400-3REVA)	A	1
-225A	MODREF292663								. STRUCTURE INSTL (LIMITED USAGE) (146A6400-3REVB)	A	1
-225B	MODREF304975								. STRUCTURE INSTL (LIMITED USAGE) (146A6400-3REVC)	A	1
-230	MODREF284218								. STRUCTURE INSTL (LIMITED USAGE) (146A6400-4REVA)	B	1
-230A	MODREF292664								. STRUCTURE INSTL (LIMITED USAGE) (146A6400-4REVB)	B	1
-230B	MODREF304976								. STRUCTURE INSTL (LIMITED USAGE) (146A6400-4REVC)	B	1
235	HST10AG6-3								. . BOLT (V0PTK6) (SPEC BACB30VT6K3) (OPT HST10AG6-3 (V06725)) (OPT HST10AG6-3 (V56878)) (OPT HST10AG6-3 (V73197))		29

-Item not Illustrated

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1063

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
240	HST10AG6-4		. .	BOLT							162
				(V06725)							
				(SPEC BACB30VT6K4)							
				(OPT HST10AG6-4 (V73197))							
				(OPT HST10AG6-4 (V56878))							
				(OPT HST10AG6-4 (V0PTK6))							
245	HST10AG6-5		. .	BOLT							40
				(V0PTK6)							
				(SPEC BACB30VT6K5)							
				(OPT HST10AG6-5 (V06725))							
				(OPT HST10AG6-5 (V56878))							
				(OPT HST10AG6-5 (V73197))							
250	HST10AG6-6		. .	BOLT							4
				(V0PTK6)							
				(SPEC BACB30VT6K6)							
				(OPT HST10AG6-6 (V06725))							
				(OPT HST10AG6-6 (V56878))							
				(OPT HST10AG6-6 (V73197))							
255	HST10AG6-7		. .	BOLT							5
				(V0PTK6)							
				(SPEC BACB30VT6K7)							
				(OPT HST10AG6-7 (V06725))							
				(OPT HST10AG6-7 (V56878))							
				(OPT HST10AG6-7 (V73197))							
260	HST79CY6		. .	COLLAR							240
				(V73197)							
				(SPEC BACC30BL6)							
				(OPT HST79-6 (V92215))							
				(OPT HST79CY6 (V56878))							
				(OPT HST79CY6 (V5M902))							
262	WC331K5-3		. .	BOLT							2
				(V60516)							
				(SPEC BACB30YP5K3)							
264	WC331K5-4		. .	BOLT							6
				(V60516)							
				(SPEC BACB30YP5K4)							
265	WC331K6-4		. .	BOLT							2
				(V60516)							
				(SPEC BACB30YP6K4)							
270	WC331K6-5		. .	BOLT							2
				(V60516)							
				(SPEC BACB30YP6K5)							

-Item not Illustrated

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1064

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
275	WC331K6-7		. .	BOLT							2
				(V60516)							
				(SPEC BACB30YP6K7)							
277	WC331K6-8		. .	BOLT							6
				(V60516)							
				(SPEC BACB30YP6K8)							
280	HST79CY6		. .	COLLAR							12
				(V73197)							
				(SPEC BACC30BL6)							
				(OPT HST79-6 (V92215))							
				(OPT HST79CY6 (V56878))							
				(OPT HST79CY6 (V5M902))							
282	HST79CY5		. .	COLLAR							4
				(V73197)							
				(SPEC BACC30BL5)							
				(OPT HST79-5 (V92215))							
				(OPT HST79CY5 (V56878))							
				(OPT HST79CY5 (V5M902))							
285	BACS40R009A009F		. .	SHIM							16
290	BACS40R009A033F		. .	SHIM							2
295	BACS40R009A034F		. .	SHIM							6
300	BACS40R015A022F		. .	SHIM							1
305	BACS40R009A029F		. .	SHIM							2
310	BACS40R010A016F		. .	SHIM							1
315	BACS40R009A017F		. .	SHIM							1
320	BACS40R008A017F		. .	SHIM							3
325	BACS40R009A028F		. .	SHIM							2
330	BACS40R012A022F		. .	SHIM							1
335	146A6421-1		. .	BEAM ASSY-#1							1
340	BACR15BB3ADC		. . .	RIVET							6
				(SIZE DETERMINED ON INST)							
345	WS14A12		. . .	NUTPLATE							3
				(V04169)							
				(SPEC BACN10TL3A12)							
350	BACR15BB4ADC		. . .	RIVET							2
				(SIZE DETERMINED ON INST)							

-Item not Illustrated

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1065

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
355	WS1-332A10		. . .	NUTPLATE							1
				(V04169)							
				(SPEC BACN10GH3A10)							
360	BACS31H1B		. . .	RINGPOST							1
365	140N2623-7		. . .	BUSHING-STOP							2
370	146A6421-101		. . .	BEAM-STOP							1
375	146A6422-1		. .	BEAM ASSY-#2							1
380	BACR15BA3ADC		. . .	RIVET							4
				(SIZE DETERMINED ON INST)							
385	BRF200C3D		. . .	NUTPLATE							2
				(V52828)							
				(SPEC BACN10JR3CFD)							
				(OPT K51602-3BAC (V15653))							
				(OPT NS202476-02 (V80539))							
				(OPT 102F9201-3 (V72962))							
				(OPT T8092C1032CD (V11815))							
390	140N2623-7		. . .	BUSHING-STOP							2
395	146A6422-101		. . .	BEAM							1
400	146A6423-1		. .	BEAM ASSY-#3							1
405	BACR15BA3ADC		. . .	RIVET							12
				(SIZE DETERMINED ON INST)							
410	BRF200C3D		. . .	NUTPLATE							6
				(V52828)							
				(SPEC BACN10JR3CFD)							
				(OPT K51602-3BAC (V15653))							
				(OPT NS202476-02 (V80539))							
				(OPT 102F9201-3 (V72962))							
				(OPT T8092C1032CD (V11815))							
415	140N2623-7		. . .	BUSHING-STOP							2
420	146A6423-101		. . .	BEAM							1
425	146A6424-1		. .	BEAM ASSY-#4							1
430	BACR15BB4ADC		. . .	RIVET							2
				(SIZE DETERMINED ON INST)							
435	BACN10TL3A3		. . .	NUTPLATE-SPACER							1
440	140N2623-7		. . .	BUSHING-STOP							2
445	146A6424-101		. . .	BEAM							1
450	146A6425-1		. .	BEAM ASSY-#5							1

-Item not Illustrated

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1066

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
455	BACR15BB4ADC		. . .	RIVET							2
				(SIZE DETERMINED ON INST)							
460	BACN10TL3A3		. . .	NUTPLATE							1
465	140N2623-7		. . .	BUSHING-STOP							2
470	146A6425-101		. . .	BEAM							1
475	146A6426-1		. .	BEAM ASSY-#6							1
480	BACR15BA3ADC		. . .	RIVET							4
				(SIZE DETERMINED ON INST)							
485	BRF200C3D		. . .	NUTPLATE							2
				(V52828)							
				(SPEC BACN10JR3CFD)							
				(OPT K51602-3BAC (V15653))							
				(OPT NS202476-02 (V80539))							
				(OPT 102F9201-3 (V72962))							
				(OPT T8092C1032CD (V11815))							
490	BACR15BB4ADC		. . .	RIVET							2
				(SIZE DETERMINED ON INST)							
495	BACN10TL3A3		. . .	NUTPLATE							1
500	140N2623-7		. . .	BUSHING-STOP							2
505	BACB28AT07B022C		. . .	BUSHING							2
510	146A6418-1		. . .	BUSHING							2
515	146A6426-101		. . .	BEAM							1
520	146A6428-1		. .	FRAME ASSY-VIEWPORT							1
525A	BACR15BA3AD2C		. . .	RIVET							6
530	F51652-3		. . .	NUTPLATE							3
				(V15653)							
				(SPEC BACN10KJ3CD)							
535	146A6428-101		. . .	FRAME							1
540	BACS12HN5-10		. .	SCREW							2
				(USED ON ITEMS 225A, 225B, 230A, 230B)							
545	NAS1149D0516H		. .	WASHER							6
				(USED ON ITEMS 225A, 225B, 230A, 230B)							

-Item not Illustrated

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1067

Jul 01/2007



COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
550	PLH55CD		. .	NUT							2
				(V62554)							
				(SPEC BACN10YR5CD)							
				(OPT H52732-5CD (V15653))							
				(USED ON ITEMS 225A, 225B, 230A, 230B)							
555	740C14-6		. .	JUMPER							2
				(V91812)							
				(SPEC BACJ40CG6G)							
				(USED ON ITEMS 225A, 225B, 230A, 230B)							
560	BACR15BA4ADC		. .	RIVET							8
				(SIZE DETERMINED ON INST)							
565	F51646-3BAC		. .	NUTPLATE							4
				(V15653)							
				(SPEC BACN10JZ3B2CDM)							
				(OPT 102F9220-3 (V72962))							
570	146A6439-1		. .	ANGLE-HANDLE BOX							1
575	146A6445-1		. .	BOX ASSY-HANDLE							1
580	146A6445-103		. . .	PLATE-COVER							1
				ATTACHING PARTS							
585	VL310AG5-4		. . .	BOLT							4
				(V06950)							
				(SPEC BACB30VT5HK4)							
				(OPT VL310AG5-4 (V9N513))							
				(OPT VL310AG5-4 (V97928))							
590	HST79CY5		. . .	COLLAR							4
				(V73197)							
				(SPEC BACC30BL5)							
				(OPT HST79-5 (V92215))							
				(OPT HST79CY5 (V56878))							
				(OPT HST79CY5 (V5M902))							
				----- * -----							
595	146A6592-1		. . .	SUPPORT-OUTSIDE HANDLE							1
				ATTACHING PARTS							
600	VL310AG5-4		. . .	BOLT							2
				(V06950)							
				(SPEC BACB30VT5HK4)							
				(OPT VL310AG5-4 (V9N513))							
				(OPT VL310AG5-4 (V97928))							

-Item not Illustrated

**52-21-03**

ILLUSTRATED PARTS LIST

Page 1068

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
605	HST79CY5		. . .	COLLAR							2
				(V73197)							
				(SPEC BACC30BL5)							
				(OPT HST79-5 (V92215))							
				(OPT HST79CY5 (V56878))							
				(OPT HST79CY5 (V5M902))							
			-----*								
610	146A6418-3		. . .	BUSHING							1
615	MS29513-020		. . .	PACKING							1
620	BACB28AT06B027C		. . .	BUSHING-FLANGED							2
625	BACB28AT06B037C		. . .	BUSHING-FLANGED							2
630	146A6445-101		. . .	BOX							1
632	BACR15GF5D		. .	RIVET							144
				(SIZE DETERMINED ON INST)							
				(FOR NHA SEE 146A6400)							
634	BACR15GF6D		. .	RIVET							65
				(SIZE DETERMINED ON INST)							
				(FOR NHA SEE 146A6400)							
635	146A6432-1		. .	DEPRESSOR-SEAL, UPR							1
640	146A6431-1		. .	DEPRESSOR-SEAL, SIDE							1
645	146A6431-2		. .	DEPRESSOR-SEAL, SIDE							1
650	146A6433-1		. .	DEPRESSOR-SEAL, LWR CORNER							1
655	146A6433-2		. .	DEPRESSOR-SEAL, LWR CORNER							1
660	146A6434-1		. .	DEPRESSOR-SEAL, LWR CENTER							1
665	HST10AG5-4		. .	BOLT							6
				(V0PTK6)							
				(SPEC BACB30VT5K4)							
				(OPT HST10AG5-4 (V06725))							
				(OPT HST10AG5-4 (V56878))							
				(OPT HST10AG5-4 (V73197))							
670	HST79CY5		. .	COLLAR							6
				(V73197)							
				(SPEC BACC30BL5)							
				(OPT HST79-5 (V92215))							
				(OPT HST79CY5 (V56878))							
				(OPT HST79CY5 (V5M902))							
675	146A6439-3		. .	ANGLE-ESCAPE SLIDE SPRT							1
680	146A6439-4		. .	ANGLE-ESCAPE SLIDE SPRT							1

-Item not Illustrated

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1069

Jul 01/2007





## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
685	146A6420-3										1
690	BACR15BB4ADC										10
695	DE847										5
700	146A6447-2										1
705	HST10AG6-5										4
710	HST79CY6										4
715	PACMKP16BSF~ S428										1
720	BACB28AT07B022C										1
725	BACS31H1B										4
730	BACR15BB4ADC										8
735	WS14A12										3
740	WSI4A16										1

-Item not Illustrated

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1070

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
745	HST10AG6-6		. . .	BOLT							3
				(V0PTK6)							
				(SPEC BACB30VT6K6)							
				(OPT HST10AG6-6 (V06725))							
				(OPT HST10AG6-6 (V56878))							
				(OPT HST10AG6-6 (V73197))							
750	HST79CY6		. . .	COLLAR							3
				(V73197)							
				(SPEC BACC30BL6)							
				(OPT HST79-6 (V92215))							
				(OPT HST79CY6 (V56878))							
				(OPT HST79CY6 (V5M902))							
755	146A6449-2		. . .	PIN-GUIDE, LWR							1
760	146A6420-103		. . .	FRAME							1
765	146A6420-1		. .	FRAME ASSY-R EDGE							1
				(USED ON ITEMS 225, 225A, 230, 230A)							
-765A	146A6420-7		. .	FRAME ASSY-R EDGE							1
				(USED ON ITEMS 225B, 230B)							
770	BACS12HN3-12		. . .	SCREW							1
775	BACW10EC3S		. . .	WASHER							1
780	NAS1149D0316H		. . .	WASHER							2
785	MS35650-305T		. . .	NUT							1
790	BACS31H1B		. . .	RINGPOST							1
795	BACR15BB4ADC		. . .	RIVET							2
				(SIZE DETERMINED ON INST)							
800	WSI4A16		. . .	NUTPLATE							1
				(V04169)							
				(SPEC BACN10TL3A16)							
805	BACR15BB3ADC		. . .	RIVET							10
				(SIZE DETERMINED ON INST)							
810	DE847		. . .	MOUNT-SHOCK							5
				(V71985)							
				(SPEC S411T100-1010)							
815	146A6447-1		. . .	TRACK-GUIDE, UPR							1

-Item not Illustrated

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1071

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-			ATTACHING PARTS								
820	HST10AG6-5		. . .	BOLT							4
				(V0PTK6)							
				(SPEC BACB30VT6K5)							
				(OPT HST10AG6-5 (V06725))							
				(OPT HST10AG6-5 (V56878))							
				(OPT HST10AG6-5 (V73197))							
825	HST79CY6		. . .	COLLAR							4
				(V73197)							
				(SPEC BACC30BL6)							
				(OPT HST79-6 (V92215))							
				(OPT HST79CY6 (V56878))							
				(OPT HST79CY6 (V5M902))							
			-----*-----								
830	VL310AG5-6		. . .	BOLT							1
				(V06950)							
				(SPEC BACB30VT5HK6)							
				(OPT VL310AG5-6 (V9N513))							
				(OPT VL310AG5-6 (V97928))							
				(USED ON ITEM 765)							
-830A	HST10AG6-6		. . .	BOLT							1
				(V0PTK6)							
				(SPEC BACB30VT6K6)							
				(OPT HST10AG6-6 (V06725))							
				(OPT HST10AG6-6 (V56878))							
				(OPT HST10AG6-6 (V73197))							
				(USED ON ITEM 765A)							
835	VL310AG5-4		. . .	BOLT							1
				(V06950)							
				(SPEC BACB30VT5HK4)							
				(OPT VL310AG5-4 (V9N513))							
				(OPT VL310AG5-4 (V97928))							
				(USED ON ITEM 765)							
-835A	HST10AG6-4		. . .	BOLT							1
				(V06725)							
				(SPEC BACB30VT6K4)							
				(OPT HST10AG6-4 (V73197))							
				(OPT HST10AG6-4 (V56878))							
				(OPT HST10AG6-4 (V0PTK6))							
				(USED ON ITEM 765A)							

-Item not Illustrated

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1072

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
840	HST79CY5		. . .	COLLAR							2
				(V73197)							
				(SPEC BACC30BL5)							
				(OPT HST79-5 (V92215))							
				(OPT HST79CY5 (V56878))							
				(OPT HST79CY5 (V5M902))							
				(USED ON ITEM 765)							
-840A	HST79CY6		. . .	COLLAR							2
				(V73197)							
				(SPEC BACC30BL6)							
				(OPT HST79-6 (V92215))							
				(OPT HST79CY6 (V56878))							
				(OPT HST79CY6 (V5M902))							
				(USED ON ITEM 765A)							
845	BACS40U3L3		. . .	SHIM							2
850	146A6420-105		. . .	RETAINER-LOCK SHAFT							1
855	BACB10FB10C		. . .	BEARING							1
				(USED ON ITEM 765)							
-855A	BACB10ES10C		. . .	BEARING							1
				(USED ON ITEM 765A)							
860	PACMKP16BSF~ S428		. . .	BEARING							1
				(V21335)							
				(SPEC BACB10FV16J)							
				(OPT AMKP16BSNJJC (V06144))							
865	HST10AG6-8		. . .	BOLT							1
				(V0PTK6)							
				(SPEC BACB30VT6K8)							
				(OPT HST10AG6-8 (V06725))							
				(OPT HST10AG6-8 (V56878))							
				(OPT HST10AG6-8 (V73197))							
870	BACW10P5CC		. . .	WASHER							1
875	HST1094DU6		. . .	COLLAR							1
				(V73197)							
				(SPEC BACC30BS6S)							
880	BACB28AK03-035		. . .	BUSHING							1
885	BACB28AT07B022C		. . .	BUSHING							1

-Item not illustrated

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1073

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
1-											
890	HST10AG6-6		. . .	BOLT							3
				(V0PTK6)							
				(SPEC BACB30VT6K6)							
				(OPT HST10AG6-6 (V06725))							
				(OPT HST10AG6-6 (V56878))							
				(OPT HST10AG6-6 (V73197))							
895	DCM6E		. . .	COLLAR							3
				(V11815)							
				(SPEC BACC30L6)							
				(OPT DCM6E (V29666))							
900	146A6449-1		. . .	PIN-GUIDE, LWR							1
905	146A6420-101		. . .	FRAME							1
				(USED ON ITEM 765)							
-905A	146A6420-107		. . .	FRAME							1
				(USED ON ITEM 765A)							
-910	MODREF287701		. MECHANICAL INSTL						A		1
				(LIMITED USAGE)							
				(146A6500-5REVA)							
				(FOR DETAILS SEE FIG. 2)							
-910A	MODREF297447		. MECHANICAL INSTL						A		1
				(LIMITED USAGE)							
				(146A6500-5REVB)							
				(FOR DETAILS SEE FIG. 2)							
-915	MODREF287702		. MECHANICAL INSTL						B		1
				(LIMITED USAGE)							
				(146A6500-6REVA)							
				(FOR DETAILS SEE FIG. 2)							
-915A	MODREF297448		. MECHANICAL INSTL						B		1
				(LIMITED USAGE)							
				(146A6500-6REVB)							
				(FOR DETAILS SEE FIG. 2)							
-920	MODREF287699		. MECHANICAL INSTL						A		1
				(LIMITED USAGE)							
				(146A6500-3REVA)							
				(FOR DETAILS SEE FIG. 3)							
-920A	MODREF295479		. MECHANICAL INSTL						A		1
				(LIMITED USAGE)							
				(146A6500-3REVB)							
				(FOR DETAILS SEE FIG. 3)							

-Item not Illustrated

**52-21-03**

ILLUSTRATED PARTS LIST

Page 1074

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY	
			1	2	3	4	5	6	7			
1- -920B	M0DREF297445		.								A	1
-925	M0DREF287699		.								B	1
-925A	M0DREF295480		.								B	1
-925B	M0DREF297446		.								B	1
-930	M0DREF287697		.								A	1
-935	M0DREF287698		.								B	1

-Item not Illustrated


# 52-21-03

ILLUSTRATED PARTS LIST

Page 1075

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



Mechanical Installation  
IPL Figure 2 (Sheet 1 of 11)


**52-21-03**

ILLUSTRATED PARTS LIST

Page 1076

Jul 01/2007

COMPONENT MAINTENANCE MANUAL





Mechanical Installation  
IPL Figure 2 (Sheet 2 of 11)






COMPONENT MAINTENANCE MANUAL




Mechanical Installation  
IPL Figure 2 (Sheet 4 of 11)

COMPONENT MAINTENANCE MANUAL



Mechanical Installation  
IPL Figure 2 (Sheet 5 of 11)

COMPONENT MAINTENANCE MANUAL



Mechanical Installation  
IPL Figure 2 (Sheet 6 of 11)



**52-21-03**

ILLUSTRATED PARTS LIST

Page 1081

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



(L)

Mechanical Installation  
IPL Figure 2 (Sheet 7 of 11)


**52-21-03**

ILLUSTRATED PARTS LIST

Page 1082

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



Mechanical Installation  
IPL Figure 2 (Sheet 8 of 11)


**52-21-03**

ILLUSTRATED PARTS LIST

Page 1083

Jul 01/2007

# COMPONENT MAINTENANCE MANUAL



(P)

Mechanical Installation  
IPL Figure 2 (Sheet 9 of 11)

## 52-21-03

ILLUSTRATED PARTS LIST


Page 1084

Jul 01/2007





COMPONENT MAINTENANCE MANUAL



Mechanical Installation  
IPL Figure 2 (Sheet 11 of 11)



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
2-											
-1A	M0DREF287701									A	RF
-1B	M0DREF297447									A	RF
-5	M0DREF287702									B	RF
-5A	M0DREF297448									B	RF
10	BACB30NR4K9										2
15	BACW10BP4ACU										2
20	BACW10P435CG										2
25	BACW10BN4AP										2
30	PLH54CD										2
35	BACB28AK04-027										2
40	HLT420AP6-4										6
45	BACC30CP6C										6
50	NAS1149E0516P										AR
55	146A6539-1										1
60	BACP18BC02A06P										1
65	BACB30NR4DK16										1
70	BACW10BP4ACU										1
75	BACW10BN4AP										2
80	BACN10JD4CD										1
85	BACB28AK04-015										1
90	146A6530-2										1

-Item not Illustrated

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1087

Jul 01/2007





## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
2-											
155	10E4-116M		. . .	BEARING							1
				(V16746)							
				(SPEC BACB10Y4M)							
				(OPT BRES4-2236M1 (V81376))							
				(OPT HB4E212KM (V02758))							
				(OPT KBE4-150WD5 (V97613))							
				(OPT MSSK4AS1 (V73134))							
				(OPT 51588-041DD (V09455))							
				(OPT ASMK4-1DM (V56644))							
				(OPT AR4E7W13 (VS0352))							
				(OPT ARB4E60MW (V15860))							
160	BACB30NR4K11		. .	BOLT							1
165	BACW10BP4APU		. .	WASHER							1
170	PLH54CM		. .	NUT							1
				(V62554)							
				(SPEC BACN10YR4CM)							
				(OPT H52732-4CM (V15653))							
175	BACW10BN5AC		. .	WASHER							1
180	BACW10BN10AC		. .	WASHER							1
185	NAS1149V0932M		. .	WASHER							1
190	BACW10P399CD		. .	WASHER							1
195	146A6511-7		. .	SPRING-TORSION							1
200	146A6511-8		. .	SPRING-TORSION							1
205	146A6583-3		. .	SLEEVE-TORSION SPRING							1
210	146A6546-1		. .	HOUSING ASSY-BEARING							1
215	146A6546-2		. .	HOUSING ASSY-BEARING							1
220	BACB10FB05C		. . .	BEARING							1
225	146A6546-101		. . .	HOUSING							1
				(USED ON ITEM 210)							
230	146A6546-102		. . .	HOUSING							1
				(USED ON ITEM 215)							
235	146A6547-1		. .	CRANK ASSY-VENT DOOR							1
240	BACB28AP04-009		. . .	BUSHING							1
245	BACB28AT06B015A		. . .	BUSHING							1
250	146A6547-101		. . .	CRANK							1
255	146A6545-1		. .	SHAFT-UPR MECHANISM							1

-Item not illustrated

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1089

Jul 01/2007





## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
2-											
350	PLH53CD		.								1
355	BACB28AK03-012		.								1
360	BACB28AK03-022		.								1
365	BACB30LM3-19		.								4
370	NAS1149E0332P		.								8
375	PLH53CD		.								4
377	NAS1149E0416P		.								2
378	SSMB540DDSD624		.								2
380	146A6532-1		.								1
385	146A6536-1		..								1
390	HST10AG6-9		...								1
395	BACW10P5CC		...								1
400	HST1094DU6		...								1
405	BACB28AK03-035		...								1
410	BACB28AT06B012A		...								1
415	146A6536-101		...								1
420	146A6535-1		..								1
425	BACB28AP06P018		...								1
430	BACB28AT09B018A		...								1
435	146A6535-101		...								1

-Item not Illustrated

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1091

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
2-											
440	146A6537-1		.	.	SHAFT						1
445	146A6529-1		.		STOP-CATCH						1
					ATTACHING PARTS						
450	BACB30LH3-13		.		BOLT						2
455	NAS1149E0363P		.		WASHER						2
460	BACS40R008E026F		.		SHIM						1
470	PLH53CD		.		NUT						2
					(V62554)						
					(SPEC BACN10YR3CD)						
					(OPT H52732-3CD (V15653))						
					----- * -----						
475	BACP18BC02A06P		.		PIN-COTTER						1
480	146A6597-2		.		PIN ASSY-OUTSIDE HANDLE						1
485	MS29513-010		.	.	PACKING						2
490	146A6597-101				DELETED						
490A	146A6597-102		.	.	PIN						1
495	NAS1149E0632P		.		WASHER						1
500	NAS1149E0532P		.		WASHER						1
505	NAS1149E0616P		.		WASHER						2
510	BACN10JD5ASU		.		NUT						1
515	BACB28AK06-018		.		BUSHING						1
520	BACB28AK06-048		.		BUSHING						1
525	BACP18BC02A026P				DELETED						
525A	BACP18BC02A06P		.		PIN-COTTER						1
530	146A6597-1		.		PIN ASSY						1
535	MS29513-010		.	.	PACKING						2
540	146A6597-101		.	.	PIN						1
545	NAS1149E0632P		.		WASHER						1
550	NAS1149E0532P		.		WASHER						1
555	NAS1149E0616P		.		WASHER						2
560	BACN10JD5ASU		.		NUT						1
565A	BACB28AK06-007		.		BUSHING						2

-Item not Illustrated

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1092

Jul 01/2007







## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
2-											
675	BACB30LM3-9		. .								1
680	NAS1149E0332P		. .								4
685	PLH53CD		. .								1
								(V62554)			
								(SPEC BACN10YR3CD)			
								(OPT H52732-3CD (V15653))			
690	BACB28AK03-022		. .								1
695	BACB28AK03-012		. .								1
700A	MS24586C201		. .								1
705	BACB30LM3-17		. .								1
710	NAS1149E0332P		. .								2
715	BACW10P271TF		. .								2
720	PLH53CD		. .								1
								(V62554)			
								(SPEC BACN10YR3CD)			
								(OPT H52732-3CD (V15653))			
725	BACB28Y4C035		. .								1
730	69-47407-3		. .								1
735	BACB28AT06B045C		. .								2
740	146A6589-101		. .								1
745	BACP18C02A06P		. .								1
750	BACB30LR4D16		. .								1
755	NAS1149E0432P		. .								1
760	NAS1149E0932P		. .								5
765	BACN10JD4CD		. .								1
770	BACB28AK06-053		. .								1
775	BACB28AK04-080		. .								1
780	146A6590-1		. .								1
785	BACS12CK3U26		. .								1
790	NAS1149C0332R		. .								1
795	BACN11U3CM1		. .								1

-Item not Illustrated

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1094

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
2- 800	SLR4001-3A		. . RETAINER (V97393) (SPEC BACR10AL3A) (OPT SLR50-3A (V97393))								1
805	SL4113-3CDBAC		. . NUT (V97393) (SPEC BACN10ZC3CD) (OPT 102B13171-3 (V72962)) (OPT 92834-1032CD (V56878))								1
810	WES05B10GC		. . BEARING (V73134) (SPEC BACB10FE05C) (OPT ADW5VNC (V15860)) (OPT KR5CWGBZC (V50632)) (OPT KWDB5-39 (V97613)) (OPT WRRS05B10GC (V73134)) (OPT WHT05VSBC (VS0352))								1
815	146A6590-101		. . LINK								1

-Item not Illustrated


# 52-21-03

ILLUSTRATED PARTS LIST

Page 1095

Jul 01/2007

# COMPONENT MAINTENANCE MANUAL



Mechanical Installation  
IPL Figure 3 (Sheet 1 of 18)


## 52-21-03

ILLUSTRATED PARTS LIST

Page 1096

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



Mechanical Installation  
IPL Figure 3 (Sheet 2 of 18)


**52-21-03**

ILLUSTRATED PARTS LIST

Page 1097


Jul 01/2007

COMPONENT MAINTENANCE MANUAL



Mechanical Installation  
IPL Figure 3 (Sheet 3 of 18)

COMPONENT MAINTENANCE MANUAL



Mechanical Installation  
IPL Figure 3 (Sheet 4 of 18)


**52-21-03**

ILLUSTRATED PARTS LIST

Page 1098.1

Jul 01/2007


COMPONENT MAINTENANCE MANUAL



Mechanical Installation  
IPL Figure 3 (Sheet 5 of 18)

**52-21-03**  
ILLUSTRATED PARTS LIST  
Page 1098.2  
Jul 01/2007

### COMPONENT MAINTENANCE MANUAL



Mechanical Installation  
IPL Figure 3 (Sheet 6 of 18)

# 52-21-03


ILLUSTRATED PARTS LIST

Page 1098.3

Jul 01/2007




COMPONENT MAINTENANCE MANUAL



Mechanical Installation  
IPL Figure 3 (Sheet 7 of 18)


COMPONENT MAINTENANCE MANUAL



Mechanical Installation  
IPL Figure 3 (Sheet 8 of 18)

**52-21-03**  
ILLUSTRATED PARTS LIST  
Page 1098.5  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL



(N)

Mechanical Installation  
IPL Figure 3 (Sheet 9 of 18)


**52-21-03**

ILLUSTRATED PARTS LIST

Page 1098.6

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



Mechanical Installation  
IPL Figure 3 (Sheet 10 of 18)

**52-21-03**


ILLUSTRATED PARTS LIST

Page 1098.7

Jul 01/2007




COMPONENT MAINTENANCE MANUAL



Mechanical Installation  
IPL Figure 3 (Sheet 12 of 18)

**52-21-03**  
ILLUSTRATED PARTS LIST  
Page 1098.9  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL



Mechanical Installation  
IPL Figure 3 (Sheet 13 of 18)



**52-21-03**

ILLUSTRATED PARTS LIST

Page 1098.10

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



Mechanical Installation  
IPL Figure 3 (Sheet 14 of 18)

**52-21-03**



ILLUSTRATED PARTS LIST

Page 1098.11

Jul 01/2007



COMPONENT MAINTENANCE MANUAL



Mechanical Installation  
IPL Figure 3 (Sheet 15 of 18)


**52-21-03**

ILLUSTRATED PARTS LIST

Page 1098.12

Jul 01/2007


COMPONENT MAINTENANCE MANUAL



Mechanical Installation  
IPL Figure 3 (Sheet 16 of 18)


**52-21-03**  
ILLUSTRATED PARTS LIST  
Page 1098.13  
Jul 01/2007

COMPONENT MAINTENANCE MANUAL



Mechanical Installation  
IPL Figure 3 (Sheet 17 of 18)

COMPONENT MAINTENANCE MANUAL



AE

Mechanical Installation  
IPL Figure 3 (Sheet 18 of 18)

**52-21-03**  
ILLUSTRATED PARTS LIST  
Page 1098.15  
Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
3-											
-1A	M0DREF287699									A	RF
-1B	M0DREF295479									A	RF
-1C	M0DREF297445									A	RF
-3	M0DREF287699									B	RF
-3A	M0DREF295480									B	RF
-3B	M0DREF297446									B	RF
6	BACP18BC02A05P										1
9	BACB30NT4DK17										1
12	BACW10BP4DP										1
15	BACN10JD4CD										1
18	BACB28AK04-031										1
21	BACB30YL6K6										2
24	BACB30YL6K7										2
27	BACC30CQ6CR										4
30	BACS40R020Y023P										1
33	BACP18BC02A05P										1
36	BACB30NR4DK38										1
39	BACW10BP4ACU										1
42	BACW10BP4DP										1
45	BACN10JD4CD										1
48	BACB28AK04-200										1
51	BACW10BP4APU										1

-Item not Illustrated

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1098.16

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
3-											
54	BRH10C4M		.	NUT							1
				(V52828)							
				(SPEC BACN10JC4CM)							
				(OPT T6C428JM (V11815))							
				(OPT 97E48 (V80539))							
				(OPT 109LH9075-4W (V72962))							
				(OPT VN303D048 (V92215))							
				(OPT H01-4BAC (V15653))							
				(OPT NS202101SE048 (V80539))							
57	KRP146004BT		.	BEARING							1
				(V50632)							
60A	BACP18BC04A08P		.	PIN-COTTER							1
63A	BACP18BC03A04P		.	PIN-COTTER							1
66	NAS1149E0863R		.	WASHER							2
69	BACW10BP10APU		.	WASHER							1
72	BACN10JD108ASU		.	NUT							1
75	BACN10JD110ASU		.	NUT							1
78	146A6581-1		.	SHAFT-LOCK							1
81	146A6582-1		.	SPACER-LOCK SHAFT ASSY							1
84	146A6582-3		.	SPACER-LOCK SHAFT ASSY							1
87	146A6582-5		.	SPACER-LOCK SHAFT ASSY							1
90	146A6580-1		.	CAM ASSY-LOCK							1
93A	BACB28AP05-011		.	BUSHING							2
96	BACB28AT07B022C		.	BUSHING							1
99	146A6580-101		.	CAM							1
102	BACP18BC02A05P		.	PIN-COTTER							2
105	BACB30NR4DK28		.	BOLT							1
108	BACB30NR4DK27		.	BOLT							1
111	BACW10BP4ACU		.	WASHER							2
114	BACW10BP4DP		.	WASHER							2
117	BACN10JD4CD		.	NUT							2
118	BACB28AK04-011		.	BUSHING							1
120	146A6577-3		.	FITTING ASSY-OVERCENTER SPRING							1

-Item not Illustrated

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1098.17

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
3-											
123A	WES04B10GC		.	.	BEARING (V73134) (SPEC BACB10FE04C) (OPT ADW4VNC (V15860)) (OPT KR4CWGBZC (V50632)) (OPT KWDB4-39 (V97613)) (OPT WRRS04B10GC (V73134)) (OPT WHT04VSBC (VS0352))						1
126	146A6577-103		.	.	FITTING						1
129	146A6577-1		.		FITTING ASSY-OVERCENTER SPRING						1
132	BACB10FE4C		.	.	BEARING						1
135	146A6577-101		.	.	FITTING						1
138	146A6585-1		.		SPRING-OVERCENTER						1
141	146A6583-1		.		WASHER						2
144	146A6575-3		.		IDLER ASSY-LOCK SHAFT						1
147	BACB28AZ06A065B		.	.	BUSHING-FLANGED						2
150	BACB28AP04-018		.	.	BUSHING						1
153	BACB28AT06B018A		.	.	BUSHING-FLANGED						1
156	146A6575-103		.	.	IDLER						1
159	146A6576-3		.		FITTING ASSY-LOCK						1
162	BACB28AT06B018C		.	.	BUSHING						1
165	BACB28AX04C018		.	.	BUSHING						1
168	146A6576-103		.	.	FITTING						1
171	WC331K5-5		.		BOLT (V60516) (SPEC BACB30YP5K5)						2
174	HST79CY5		.		COLLAR (V73197) (SPEC BACC30BL5) (OPT HST79-5 (V92215)) (OPT HST79CY5 (V56878)) (OPT HST79CY5 (V5M902))						2
175	146A6586-3		.		FITTING-LOCK						1
177	MS24586C65		.		SPRING						2
180	BACP18BC02A06P		.		PIN						1
183	BACB30NR5DK29		.		BOLT						1

-Item not Illustrated

**52-21-03**

ILLUSTRATED PARTS LIST

Page 1098.18

Jul 01/2007









## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
3-											
291	BACB28AZ07A056B		.	.	BUSHING						2
294	BACB28AP04-022		.	.	BUSHING						1
297	BACB28AT06B022A		.	.	BUSHING						1
300	146A6575-101		.	.	IDLER						1
303	146A6576-1		.		FITTING ASSY						1
306	BACB28AT07C015A		.	.	BUSHING						1
309	BACB28AX05B014		.	.	BUSHING (OPT ITEM 309A)						1
-309A	BACB28AX05C014		.	.	BUSHING (OPT ITEM 309)						1
312	146A6576-101		.	.	FITTING						1
315	146A6578-1		.		LINK ASSY						1
318	WES04B10GC		.	.	BEARING (V73134) (SPEC BACB10FE04C) (OPT ADW4VNC (V15860)) (OPT KR4CWGBZC (V50632)) (OPT KWDB4-39 (V97613)) (OPT WRRS04B10GC (V73134)) (OPT WHT04VSBC (VS0352))						2
321	146A6578-101		.	.	LINK						1
324	146A6587-1		.		FITTING-STOP						1
327	HST10AG8-5		.		BOLT (V0PTK6) (SPEC BACB30VT8K5) (OPT HST10AG8-5 (V06725)) (OPT HST10AG8-5 (V56878)) (OPT HST10AG8-5 (V73197))						6
330	HST79CY8		.		COLLAR (V73197) (SPEC BACC30BL8) (OPT HST79-8 (V92215)) (OPT HST79CY8 (V56878)) (OPT HST79CY8 (V5M902))						6
332	146A6435-105		.		PLATE-SHAFT RETENTION						1

-Item not Illustrated

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1098.21

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
3-			ATTACHING PARTS								
333	HST10AG5-3		.								4
336	HST79CY5		.								4
339	BACB30MR4A6		.								2
342	BACB30MR4A10		.								2
345	BACW10BP4CD		.								4
348	BACW10BP4DP		.								4
351	BACN11Z4CD		.								4
354	BACB30NR4K9		.								1
357	BACW10BP4AC		.								1
360A	BACW10P435CG		.								1
363	BACW10BN4AP		.								1
366	PLH54CD		.								1
369	BACB28AK04-030		.								1
372	BACP18BC02A05P		.								1
375	BACB30NR4DK18		.								1
378	BACW10BP4AC		.								1
381	BACW10BP4AP		.								2
384	BACN10JD4CD		.								1
387	BACB28AK04-035		.								1
390	BACB30NR4K18		.								3
393	BACB30NR4K20		.								1

-Item not Illustrated

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1098.22

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
3-											
396A	BACB30NR4K22		.								1
399	BACW10BP4ACU		.								5
402	BACW10BP4APU		.								5
405	PLH54CM		.								5
408	NAS1149C1616R		.								2
411	NAS1149C1632R		.								2
414	146A6509-1		.								1
417	BACB30NR4K13		..								1
420	BACB30NR4K14		..								1
423	BACW10BP4ACU		..								2
426	BACW10BP4APU		..								2
429	PLH54CM		..								2
432	BACW10BP6ACU		..								2
435	146A6512-1		..								1
438	146A6512-3		..								1
441	BACB30NR4K7		...								1
444	BACW10BP4ACU		...								1
447	BACW10BP4APU		...								1
450	PLH54CD		...								1
453	BACB28AK04-030		...								1
456	BACB10FB05C		...								1
459	146A6512-101		...								1
462	146A6512-103		...								1
465	146A6510-3		..								1

-Item not Illustrated

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1098.23

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY	
			1	2	3	4	5	6	7			
3-												
468	BACB30NR4K8								...	BOLT		1
471	BACW10BP4ACU								...	WASHER		1
474	BACW10BP4APU								...	WASHER		2
477	PLH54CM								...	NUT (V62554) (SPEC BACN10YR4CM) (OPT H52732-4CM (V15653))		1
480	BACB28AP04-014								...	BUSHING		1
483	BACB28AT06B014A								...	BUSHING		1
486	BACB28AK04-025								...	BUSHING		1
489	146A6510-103								...	CRANK		1
492	146A6510-1								..	CRANK ASSY		1
495	BACB30PW4U18								...	BOLT		1
498	BACW10BP4ACU								...	WASHER		1
501	NAS1149E0363R								...	WASHER		1
504	PLH53CM								...	NUT (V62554) (SPEC BACN10YR3CM) (OPT H52732-3CM (V15653))		1
507	BACB28AK04-055								...	BUSHING		1
510	BACB28AP04-014								...	BUSHING		2
513	146A6510-101								...	CRANK		1
516	146A6568-5								..	SLEEVE-TORSION SPRING		1
519	146A6511-5								..	SPRING-TORSION		1
522	146A6545-3								..	SHAFT		1
525	146A6516-1								.	LOCK ASSY-FLIGHT (FOR DETAILS SEE CMM 52-21-04)		1
528	BACB30LE5K45									DELETED		
531	BACW10DS5S									DELETED		
534	BACW10BP5DP									DELETED		
537	PLH55CD									DELETED		
540	SSMKP5ASD524									DELETED		
543	BACB30NM3K10									DELETED		
546A	BACW10DS3S									DELETED		

-Item not Illustrated

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1098.24

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY		
			1	2	3	4	5	6	7				
3-													
549	BACW10BP3NDP											DELETED	
552	NAS43DD3-32FC											DELETED	
555	PLH53CD											DELETED	
558	MS24586C59											DELETED	
561	258A4704-1											DELETED	
564	BACB28AK05-006											DELETED	
567	258A4703-2											DELETED	
570	PACMKP16BSF~ S428											DELETED	
573	146A6517-1											DELETED	
576	146A6520-1											. SHAFT ASSY-LATCH	1
579	BACB30NR4K22											. . BOLT	2
582	BACB30NR4K24											. . BOLT	4
585	BACW10BP4ACU											. . WASHER	6
588	BACW10BP4APU											. . WASHER	8
591	PLH54CM											. . NUT (V62554) (SPEC BACN10YR4CM) (OPT H52732-4CM (V15653))	6
594	BACB28AK04-030											. . BUSHING	2
597	146A6522-1											. . CRANK ASSY-LATCH	2
600	BACP18BC03A10P											. . . PIN-COTTER	1
603	NAS1149E0616R											. . . WASHER	1
606	NAS1149E0632R											. . . WASHER	1
609	NAS1149E0663R											. . . WASHER	1
612	BACN10JD106AU											. . . NUT	1
615	BCREF50875											. . . BEARING (BACB10HS06ARNSP6)	1
618	146A6522-101											. . . CRANK	1
621	146A6524-1											. . CRANK ASSY-HANDLE	1
624	BACB28AP04-022											. . . BUSHING	1
627	BACB28AT06B022A											. . . BUSHING	1
630	146A6524-101											. . . CRANK	1

-Item not Illustrated

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1098.25

Jul 01/2007




## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
3-											
633	146A6568-2										1
636	146A6511-4										1
639	146A6523-1										1
642	146A6511-3										1
645	146A6568-1										1
648	146A6523-3										1
651	146A6521-1										1

-Item not Illustrated

**52-21-03**  
 ILLUSTRATED PARTS LIST  
 Page 1098.26  
 Jul 01/2007

COMPONENT MAINTENANCE MANUAL



Mechanical Installation  
IPL Figure 4 (Sheet 1 of 7)

**52-21-03**


ILLUSTRATED PARTS LIST

Page 1098.27

Jul 01/2007



COMPONENT MAINTENANCE MANUAL



Mechanical Installation  
IPL Figure 4 (Sheet 2 of 7)


**52-21-03**

ILLUSTRATED PARTS LIST

Page 1098.28

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



Mechanical Installation  
IPL Figure 4 (Sheet 3 of 7)


**52-21-03**

ILLUSTRATED PARTS LIST

Page 1098.29


Jul 01/2007

COMPONENT MAINTENANCE MANUAL



Mechanical Installation  
IPL Figure 4 (Sheet 4 of 7)

COMPONENT MAINTENANCE MANUAL



Mechanical Installation  
IPL Figure 4 (Sheet 5 of 7)


**52-21-03**

ILLUSTRATED PARTS LIST

Page 1098.31

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



Mechanical Installation  
IPL Figure 4 (Sheet 6 of 7)


**52-21-03**

ILLUSTRATED PARTS LIST

Page 1098.32

Jul 01/2007

COMPONENT MAINTENANCE MANUAL



Mechanical Installation  
IPL Figure 4 (Sheet 7 of 7)



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
4-											
-1A	M0DREF287697									A	RF
-5	M0DREF287698									B	RF
10	BACP18BC03A05P										2
15	BACB30NR6DK33										2
20	BACW10BP6CD										2
25	BACW10BP6DP										2
30	BACN10BP6CD										2
35	BCREF51111										2
40	BACB30LH4-10										8
45	BACW10BP4CD										8
50	PLH54CD										8
55	ACMKP3AFS428										8
60	BACP18BC02A04P										4
65	BACB30NR5DK84										2
70	BACB30NR5DK88										2
75	BACW10BP5CD										4
80	BACW10BP5DP										4
85	BACN10JD5CD										4
90	BACB28AK05-038										2
95	BACB28AK05-055										2
100	BACP18BC02A03P										4

-Item not Illustrated

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1098.34

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY	
			1	2	3	4	5	6	7			
4-												
105	BACB30NR4DK13		.	B	O	L	T				4	
110	BACW10BP4ACU		.	W	A	S	H	E	R		4	
115	BACW10BP4APU		.	W	A	S	H	E	R		4	
120	BACN10JD104CD		.	N	U	T					4	
125	BACB28AK04-026		.	B	U	S	H	I	N	G	4	
130A	BACP18BC02A04P		.	P	I	N	-	C	O	T	T	2
135	BACB30NR5DK42		.	B	O	L	T				2	
140	BACW10BP5CD		.	W	A	S	H	E	R		2	
145	BACW10BP5DP		.	W	A	S	H	E	R		2	
150	NAS1149E0716P		.	W	A	S	H	E	R		16	
155	BACN10JD5CD		.	N	U	T					2	
160	BACB28AK05-051		.	B	U	S	H	I	N	G	4	
165	BACB28AK05-090		.	B	U	S	H	I	N	G	2	
170	BACP18BC03A05P		.	P	I	N	-	C	O	T	T	2
175	BACB30NR6DK16		.	B	O	L	T				2	
180	BACW10BP6CD		.	W	A	S	H	E	R		2	
185	BACW10BP6DP		.	W	A	S	H	E	R		2	
190	BACN10JD106CD		.	N	U	T					2	
195	BACB31A3-46		.	B	O	L	T				2	
200	BACW10BP3CD		.	W	A	S	H	E	R		2	
205	BACW10BP3DP		.	W	A	S	H	E	R		2	
210	PLH53CD		.	N	U	T					2	
				(V62554)								
				(SPEC BACN10YR3CD)								
				(OPT H52732-3CD (V15653))								
215	BACB28AK03-258		.	B	U	S	H	I	N	G	2	
220	2-7892-2		.	S	N	U	B	B	E	R	2	
				(V97415)								
225	146A6562-1		.	M	E	C	H	A	N	I	S	1
				MECHANISM ASSY-SNUBBER								
230	146A6562-2		.	M	E	C	H	A	N	I	S	1
				MECHANISM ASSY-SNUBBER								

-Item not Illustrated

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1098.35

Jul 01/2007





## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
4- 235	HST10AG6-11		. .	BOLT							2
				(V0PTK6)							
				(SPEC BACB30VT6K11)							
				(OPT HST10AG6-11 (V06725))							
				(OPT HST10AG6-11 (V56878))							
				(OPT HST10AG6-11 (V73197))							
240	WC331K6-11		. .	BOLT							1
				(V60516)							
				(SPEC BACB30YP6K11)							
245	HST79CY6		. .	COLLAR							3
				(V73197)							
				(SPEC BACC30BL6)							
				(OPT HST79-6 (V92215))							
				(OPT HST79CY6 (V56878))							
				(OPT HST79CY6 (V5M902))							
250	146A6555-1		. .	FITTING ASSY							1
				(USED ON ITEM 225)							
255	146A6555-2		. .	FITTING ASSY							1
				(USED ON ITEM 230)							
260	HTES04VC		. . .	BEARING							1
				(VS0352)							
				(SPEC BACB10ES04GC)							
				(OPT NC04TG5C (V56644))							
265	146A6555-101		. . .	FITTING							1
				(USED ON ITEM 250)							
270	146A6555-102		. . .	FITTING							1
				(USED ON ITEM 255)							
275	146A6551-1		. .	FITTING ASSY-SNUBBER							1
280	BACB28AP06P052		. . .	BUSHING							1
285	BACB28AY07A026C		. . .	BUSHING							4
290	146A6551-101		. . .	FITTING							1
295	146A6552-1		. .	IDLER ASSY							1
300	146A6552-2		. .	IDLER ASSY							1

-Item not Illustrated

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1098.36

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY
			1	2	3	4	5	6	7		
4-											
305	SSMKP5ASD524		. .	BEARING							2
				(V50294)							
				(SPEC BACB10FS05J)							
				(OPT PACMKP05JAA3908 (V21335))							
				(OPT SSMKP05JASD705 (V83086))							
				(OPT PACMKP5AFS428 (V21335))							
				(OPT ACMKP05JAP510LY (V40920))							
				(OPT SSMKP05JAP (V21760))							
				(OPT SSMKP05AP (V21760))							
310	HTES04VC		. .	BEARING							1
				(VS0352)							
				(SPEC BACB10ES04GC)							
				(OPT NC04TG5C (V56644))							
315	BACB28Y5C390		. .	BUSHING							1
320	146A6552-101		. .	IDLER							1
				(USED ON ITEM 295)							
325	146A6552-102		. .	IDLER							1
				(USED ON ITEM 300)							
330	146A6556-1		. .	SPRING ASSY-LIFT ASSIST							2
-330A	146A6556-3		. .	SPRING ASSY-LIFT ASSIST							1
335	146A6557-1		. .	FITTING ASSY-END							1
340	146A6557-2		. .	FITTING ASSY-END							1
345	BACB28AP04-011		. . .	BUSHING							1
350	BACB28AT06B012A		. . .	BUSHING							1
355	146A6557-101		. . .	FITTING							1
				(USED ON ITEM 335)							
360	146A6557-102		. . .	FITTING							1
				(USED ON ITEM 340)							
365	146A6559-1		. .	WASHER							1
370	146A6559-2		. .	WASHER							1
375	146A3558-1			DELETED							
-375A	146A6558-1		. .	SPRING							1
				(USED ON ITEM 330)							
-375B	146A6558-3		. .	SPRING							1
				(USED ON ITEM 330A)							
380	146A6553-1		. .	IDLER ASSY-SNUBBER SPRT							2

-Item not Illustrated

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1098.37

Jul 01/2007



## COMPONENT MAINTENANCE MANUAL

FIG/ ITEM	PART NUMBER	AIRLINE PART NUMBER	NOMENCLATURE							USAGE CODE	UNITS PER ASSY	
			1	2	3	4	5	6	7			
4- 385	SSMKP5ASD524		.	.	BEARING (V50294) (SPEC BACB10FS05J) (OPT PACMKP05JAA3908 (V21335)) (OPT SSMKP05JASD705 (V83086)) (OPT PACMKP5AFS428 (V21335)) (OPT ACMKP05JAP510LY (V40920)) (OPT SSMKP05JAP (V21760)) (OPT SSMKP05AP (V21760))							2
390	BACB28Y5C390		.	.	BUSHING							1
395	146A6553-101		.	.	IDLER							1
400	146A6554-1		.		LINK ASSY-SNUBBER							2
405	146A6554-2		.		LINK ASSY-SNUBBER							2
410	BACB28AY07A028C		.	.	BUSHING							1
415	146A6554-101		.	.	LINK (USED ON ITEM 400)							1
420	146A6554-102		.	.	LINK (USED ON ITEM 405)							1

-Item not Illustrated

# 52-21-03

ILLUSTRATED PARTS LIST

Page 1098.38

Jul 01/2007