



COMPONENT MAINTENANCE MANUAL

POSITIVE LOCK FASTENER INSTALLATION (ASP AND MAF FASTENERS)

**PART NUMBER
NONE**

BOEING PROPRIETARY, CONFIDENTIAL, AND/OR TRADE SECRET

Copyright © 1995 The Boeing Company
Unpublished Work - All Rights Reserved

Boeing claims copyright in each page of this document only to the extent that the page contains copyrightable subject matter. Boeing also claims copyright in this document as a compilation and/or collective work.

This document includes proprietary information owned by The Boeing Company and/or one or more third parties. Treatment of the document and the information it contains is governed by contract with Boeing. For more information, contact The Boeing Company, P.O. Box 3707, Seattle, Washington 98124.

Boeing, the Boeing signature, the Boeing symbol, 707, 717, 727, 737, 747, 757, 767, 777, 787, Dreamliner, BBJ, DC-8, DC-9, DC-10, KC-10, KDC-10, MD-10, MD-11, MD-80, MD-88, MD-90, P-8A, Poseidon and the Boeing livery are all trademarks owned by The Boeing Company; and no trademark license is granted in connection with this document unless provided in writing by Boeing.

PUBLISHED BY BOEING COMMERCIAL AIRPLANES GROUP, SEATTLE, WASHINGTON, USA
A DIVISION OF THE BOEING COMPANY
PAGE DATE: Jul 01/2009

78-00-08

Page 1
Jul 01/2009



COMPONENT MAINTENANCE MANUAL

Revision No. 5
Jul 01/2009

To: All holders of POSITIVE LOCK FASTENER INSTALLATION (ASP AND MAF FASTENERS) 78-00-08.

Attached is the current revision to this COMPONENT MAINTENANCE MANUAL

The COMPONENT MAINTENANCE MANUAL is furnished either as a printed manual, on microfilm, or digital products, or any combination of the three. This revision replaces all previous microfilm cartridges or digital products. All microfilm and digital products are reissued with all obsolete data deleted and all updated pages added.

For printed manuals, changes are indicated on the List of Effective Pages (LEP). The pages which are revised will be identified on the LEP by an R (Revised), A (Added), O (Overflow, i.e. changes to the document structure and/or page layout), or D (Deleted). Each page in the LEP is identified by Chapter-Section-Subject number, page number and page date.

Pages replaced or made obsolete by this revision should be removed and destroyed.

ATTENTION

IF YOU RECEIVE PRINTED REVISIONS, PLEASE VERIFY THAT YOU HAVE RECEIVED AND FILED THE PREVIOUS REVISION. BOEING MUST BE NOTIFIED WITHIN 30 DAYS IF YOU HAVE NOT RECEIVED THE PREVIOUS REVISION. REQUESTS FOR REVISIONS OTHER THAN THE PREVIOUS REVISION WILL REQUIRE A COMPLETE MANUAL REPRINT SUBJECT TO REPRINT CHARGES SHOWN IN THE DATA AND SERVICES CATALOG.

78-00-08
TRANSMITTAL LETTER
Page 1
Jul 01/2009

PART NUMBER NONE



COMPONENT MAINTENANCE MANUAL

Location of Change

Description of Change

NO HIGHLIGHTS

78-00-08

HIGHLIGHTS

Page 1

Jul 01/2009



COMPONENT MAINTENANCE MANUAL

Subject/Page	Date	Subject/Page	Date	Subject/Page	Date
TITLE PAGE		78-00-08 CLEANING (cont)			
O 1	Jul 01/2009	402	BLANK		
2	BLANK	78-00-08 CHECK			
78-00-08 TRANSMITTAL LETTER		501	Jul 01/2008		
O 1	Jul 01/2009	502	BLANK		
2	BLANK	78-00-08 REPAIR - GENERAL			
78-00-08 HIGHLIGHTS		601	Nov 01/2008		
O 1	Jul 01/2009	602	Nov 01/2008		
2	BLANK	603	Jul 01/2008		
78-00-08 EFFECTIVE PAGES		604	Jul 01/2008		
1	Jul 01/2009	605	Jul 01/2008		
2	BLANK	606	Jul 01/2008		
78-00-08 CONTENTS		607	Jul 01/2008		
1	Jul 01/2008	608	Jul 01/2008		
2	BLANK	609	Jul 01/2008		
78-00-08 TR AND SB RECORD		610	Jul 01/2008		
1	Jul 01/2008	78-00-08 ASSEMBLY			
2	BLANK	701	Jul 01/2008		
78-00-08 REVISION RECORD		702	BLANK		
1	Jul 01/2008	78-00-08 FITS AND CLEARANCES			
2	Jul 01/2008	801	Jul 01/2008		
78-00-08 RECORD OF TEMPORARY REVISIONS		802	BLANK		
1	Jul 01/2008	78-00-08 SPECIAL TOOLS, FIXTURES, AND EQUIPMENT			
2	Jul 01/2008	901	Jul 01/2008		
78-00-08 INTRODUCTION		902	BLANK		
1	Mar 01/2009	78-00-08 ILLUSTRATED PARTS LIST			
2	BLANK	1001	Jul 01/2008		
78-00-08 DESCRIPTION AND OPERATION		1002	BLANK		
1	Jul 01/2008				
2	BLANK				
78-00-08 TESTING AND FAULT ISOLATION					
101	Jul 01/2008				
102	BLANK				
78-00-08 DISASSEMBLY					
301	Jul 01/2008				
302	BLANK				
78-00-08 CLEANING					
401	Jul 01/2008				

A = Added, R = Revised, D = Deleted, O = Overflow

78-00-08

EFFECTIVE PAGES

Page 1

Jul 01/2009



COMPONENT MAINTENANCE MANUAL

TABLE OF CONTENTS

<u>Paragraph Title</u>		<u>Page</u>
POSITIVE LOCK FASTENER INSTALLATION - DESCRIPTION AND OPERATION		1
TESTING AND FAULT ISOLATION	(Not Applicable)	
DISASSEMBLY	(Not Applicable)	
CLEANING	(Not Applicable)	
CHECK	(Not Applicable)	
REPAIR		601
ASSEMBLY	(Not Applicable)	
FITS AND CLEARANCES	(Not Applicable)	
SPECIAL TOOLS, FIXTURES, AND EQUIPMENT		901
ILLUSTRATED PARTS LIST	(Not Applicable)	

78-00-08

CONTENTS

Page 1

Jul 01/2008



COMPONENT MAINTENANCE MANUAL

TEMPORARY REVISION AND SERVICE BULLETIN RECORD

BOEING SERVICE BULLETIN	BOEING TEMPORARY REVISION	OTHER DIRECTIVE	DATE OF INCORPORATION INTO MANUAL

78-00-08

TR AND SB RECORD

Page 1

Jul 01/2008



COMPONENT MAINTENANCE MANUAL

All revisions to this manual will be accompanied by transmittal sheet bearing the revision number. Enter the revision number in numerical order, together with the revision date, the date filed and the initials of the person filing.

Revision		Filed		Revision		Filed	
Number	Date	Date	Initials	Number	Date	Date	Initials

78-00-08

REVISION RECORD

Page 1

Jul 01/2008



COMPONENT MAINTENANCE MANUAL

Revision		Filed		Revision		Filed	
Number	Date	Date	Initials	Number	Date	Date	Initials

78-00-08

REVISION RECORD

Page 2

Jul 01/2008



COMPONENT MAINTENANCE MANUAL

All temporary revisions to this manual will be accompanied by a cover sheet bearing the temporary revision number. Enter the temporary revision number in numerical order, together with the temporary revision date, the date the temporary revision is inserted and the initials of the person filing.

When the temporary revision is incorporated or cancelled, and the pages are removed, enter the date the pages are removed and the initials of the person who removed the temporary revision.

Temporary Revision		Inserted		Removed		Temporary Revision		Inserted		Removed	
Number	Date	Date	Initials	Date	Initials	Date	Initials	Number	Date	Date	Initials



COMPONENT MAINTENANCE MANUAL

Temporary Revision		Inserted		Removed	
Number	Date	Date	Initials	Date	Initials

Temporary Revision		Inserted		Removed	
Date	Initials	Number	Date	Date	Initials

78-00-08
 RECORD OF TEMPORARY REVISION
 Page 2
 Jul 01/2008



COMPONENT MAINTENANCE MANUAL

INTRODUCTION

1. General

- A. The instructions in this manual supply the data necessary to do the maintenance functions together with the test, fault isolation, repair, and replacement of the defective parts.
- B. This manual is divided into different parts:
 - (1) Title Page
 - (2) Transmittal Letter
 - (3) Highlights
 - (4) List of Effective Pages
 - (5) Table of Contents
 - (6) Temporary Revision & Service Bulletin Record
 - (7) Record of Revisions
 - (8) Record of Temporary Revisions
 - (9) Introduction
 - (10) Procedures & IPL Sections
- C. Components that can be repaired have a different repair number for each specified repair. To find the repair number location of a component, look in the Repair-General procedure at the beginning of the REPAIR section. The Repair-General procedure also has an explanation of the True Position Dimension symbols used.
- D. All dimensions, measures, quantities and weights included are in English units. When metric equivalents are given they will be in the parentheses that follow the English units.
- E. The introduction to the Illustrated Parts List (IPL) shows how the IPL data is used.
- F. Design changes, optional parts, configuration differences and Service Bulletin modifications may cause different part numbers. These part numbers are identified in the IPL with an alphabetical letter which is added to the end of the basic item number. This new item number is referred to as an alpha-variant. Throughout the manual, IPL basic item number references also apply to alpha-variants unless shown differently.
- G. The tool reference numbers found in the individual procedures and in the Special Tools, Fixtures, and Equipment section are used to identify if a tool is a standard tool (STD-XXXX), a commercial tool (COM-XXXX), or a Special Tool (SPL-XXXX). This reference number is also used to distinguish between tools with similar names in the same procedure. These reference numbers are for use in the documentation only. They are not to be used for ordering tools.

78-00-08

INTRODUCTION

Page 1

Mar 01/2009



COMPONENT MAINTENANCE MANUAL

POSITIVE LOCK FASTENER INSTALLATION - DESCRIPTION AND OPERATION

1. Description

- A. This procedure is for installation and removal of Huck (ASP) and Monogram (MAF) fasteners.
- B. ASP and MAF fasteners are used when fastening metal surfaces to soft core composite materials without crushing the composite core.

78-00-08

DESCRIPTION AND OPERATION

Page 1

Jul 01/2008

PART NUMBER NONE



COMPONENT MAINTENANCE MANUAL

TESTING AND FAULT ISOLATION

(NOT APPLICABLE)

78-00-08

TESTING AND FAULT ISOLATION

Page 101

Jul 01/2008

PART NUMBER NONE



COMPONENT MAINTENANCE MANUAL

DISASSEMBLY

(NOT APPLICABLE)

78-00-08

DISASSEMBLY

Page 301

Jul 01/2008

PART NUMBER NONE



COMPONENT MAINTENANCE MANUAL

CLEANING

(NOT APPLICABLE)

78-00-08

CLEANING

Page 401

Jul 01/2008

PART NUMBER NONE



COMPONENT MAINTENANCE MANUAL

CHECK

(NOT APPLICABLE)

78-00-08

CHECK
Page 501
Jul 01/2008



COMPONENT MAINTENANCE MANUAL

REPAIR

1. General

A. This section has the necessary information that is required to install and remove the ASP and MAF fasteners:

- (1) ASP = Adjustable clamping force self-sustaining positive lock
- (2) MAF = Monogram Aerospace Fasteners

2. Installation of Positive Lock Fasteners

A. Procedure

NOTE: For installation tools, see REPAIR-GENERAL, Figure 601.

NOTE: Refer to BAC5004-2, for permanent straight shank fastener installation. Refer to 012W6100 for Materials, Part and Process Substitution and Equivalents

- (1) Install the pin as shown in REPAIR-GENERAL, Figure 601.
- (2) Install the sleeve on the pin as shown in REPAIR-GENERAL, Figure 601.
- (3) Tighten the sleeve with the tools as shown in REPAIR-GENERAL, Figure 602, Table A.
- (4) Place the lock collar over the pin as shown in REPAIR-GENERAL, Figure 601.
- (5) Set the lock collar with the tools as shown in REPAIR-GENERAL, Figure 601 and REPAIR-GENERAL, Figure 602, Table B.
 - (a) The pin protrusion after installation and break-off must be in the limits as shown in REPAIR-GENERAL, Figure 602, Table C. Pin protrusion is measured from the sleeve head to the outside diameter of the break-off groove as shown in REPAIR-GENERAL, Figure 602, (Sheet 1).
 - (b) The driven collar is permitted to have a thin concentric ring of flash adjacent to the pin thread as shown in REPAIR-GENERAL, Figure 602, (Sheet 1), or a non-concentric ring of flash thicker on one side than the other as shown in REPAIR-GENERAL, Figure 602, (Sheet 1). Flash must be in the height limits as shown in REPAIR-GENERAL, Figure 602, Table D when it is measured from the top of the sleeve at the widest area of the flash.
 - (c) The height of the driven collar in the area away from the flash must be in the limits as shown in REPAIR-GENERAL, Figure 602, Table D when it is measured from the top surface of the sleeve as shown in REPAIR-GENERAL, Figure 602, (Sheet 1).
- (6) Shave the broken pin end flush with head using a Zephyr Super Shaver, SPL-4697 with a ZT507-20B cutter or equivalent.
 - (a) The broken pin end and lock collar protrusion may be shaved to a 0.002-inch minimum above the sleeve for the necessary flushness. The sleeve head must not be shaved.
 - (b) Sleeves and pins must be shear as shown in BAC5004-2.

3. Removal of Positive Lock Fasteners

A. Procedure

NOTE: For removal tools, see REPAIR-GENERAL, Figure 603.

- (1) Use REPAIR-GENERAL, Figure 603, Table E for the selection of the drill and bushing.

78-00-08

REPAIR - GENERAL

Page 601

Nov 01/2008



COMPONENT MAINTENANCE MANUAL

- (2) Place the drill and bushing on the fastener as shown in REPAIR-GENERAL, Figure 603 and drill to the depth shown in REPAIR-GENERAL, Figure 603, Table E.
- (3) Remove the lock collar.
- (4) Unscrew the sleeve from the pin.



78-00-08

REPAIR - GENERAL

Page 602

Nov 01/2008

COMPONENT MAINTENANCE MANUAL



STEP 1
PIN IS
INSERTED
FROM ONE
SIDE OF
THE WORK

STEP 2
SLEEVE IS
PLACED OVER
PINTAIL AND
TIGHTENED
INTO POSITION

STEP 3
LOCK COLLAR
IS PLACED
OVER PINTAIL

STEP 4
HUCK
INSTALLATION
TOOL LOCKS
FASTENER IN
PLACE

Installation Procedure
Figure 601



78-00-08

REPAIR - GENERAL

Page 603

Jul 01/2008

COMPONENT MAINTENANCE MANUAL



Installation Tools Inspection
Figure 602 (Sheet 1 of 3)

78-00-08

REPAIR - GENERAL

Page 604

Jul 01/2008



COMPONENT MAINTENANCE MANUAL

FASTENER DIAMETER	HEX WRENCH SIZE	SLEEVE DRIVER HUCK PART NO.	MAXIMUM* TORQUE
13/64 (6)	5/64	106524	10-20 INCH-LBS
17/64 (8)	3/32	106525	20-30 INCH-LBS
21/64 (10)	1/8	107735	30-40 INCH-LBS

* MINIMUM INSTALLATION TORQUE MUST BE ADJUSTED TO DETERMINE THE CONTROLLED CLAMPING FORCE REQUIRED FOR THE SOFT-CORE MATERIAL OF THE JOINT DESIGN SPECIFICATION.

**INSTALLATION TOOLING
TABLE A**

FASTENER DIAMETER	HUCK INSTALLATION TOOL NUMBERS	HUCK NOSE ASSEMBLY PART NUMBER
13/64 (6)	MODEL 200,352,229,210 OR 2702	99-895
17/64 (8)	MODEL 200,352,229,210 OR 2702	99-852
21/64 (10)	MODEL 353/4,225,4802 OR 4802	99-867

**TOOL AND NOSE ASSEMBLY SELECTION
TABLE B**

Installation Tools Inspection
Figure 602 (Sheet 2 of 3)

78-00-08

REPAIR - GENERAL

Page 605

Jul 01/2008



COMPONENT MAINTENANCE MANUAL

FASTENER DIAMETER	B MINIMUM PIN PROTRUSION ABOVE SLEEVE	C MINIMUM PIN PROTRUSION ABOVE SLEEVE
13/64 (6)	0.020	0.107
17/64 (8)	0.030	0.119
21/64 (10)	0.035	0.129

PIN PROTRUSION
TABLE C

FASTENER DIAMETER	A MAXIMUM FLASH HEIGHT (WIDEST POINT)	B MAXIMUM COLLAR HEIGHT (NOT INCLUDING FLASH)
13/64 (6)	0.020	0.010
17/64 (8)	0.030	0.013
21/64 (10)	0.035	0.016

COLLAR HEIGHT
TABLE D

ALL DIMENSIONS ARE IN INCHES

Installation Tools Inspection
Figure 602 (Sheet 3 of 3)

78-00-08


REPAIR - GENERAL

Page 606

Jul 01/2008



COMPONENT MAINTENANCE MANUAL



LOCK REMOVAL

FASTENER DIAMETER	A DRILL BUSHING HUCK P/N	B DRILL DIAMETER	C DRILL DEPTH
13/64 (6)	103617	0.1562	3/64
17/64 (8)	103618	0.1875	1/16
21/64 (10)	103619	0.2280	5/64

TABLE E

ALL DIMENSIONS ARE IN INCHES

Removal Procedure
Figure 603


78-00-08

REPAIR - GENERAL


Page 607

Jul 01/2008


COMPONENT MAINTENANCE MANUAL




FLUSH HEAD PIN
AND PROTRUDING SLEEVE



FLUSH HEAD PIN
AND FLUSH SLEEVE



PROTRUDING HEAD PIN
AND FLUSH SLEEVE



PROTRUDING HEAD PIN
AND PROTRUDING SLEEVE

DIAMETER	SHANK DIAMETER	HOLE DIAMETER
06	0.2025	0.203
	0.2005	0.208
08	0.2650	0.266
	0.2630	0.271
10	0.3275	0.328
	0.3255	0.333

FASTENER DIAMETERS
TABLE F

ALL DIMENSIONS ARE IN INCHES

Installed ASP and MAF Fastener Showing Head Style Combination
Figure 604

78-00-08

REPAIR - GENERAL

Page 608

Jul 01/2008



COMPONENT MAINTENANCE MANUAL

PIN PART NUMBER	CSK PIN HD DIA			SLEEVE PART NUMBER	CSK PIN HD DIA			COLLAR PART NUMBER
	06	08	10		06	08	10	
2ASPPF-DT()-()	0.302 MAX	0.399 MAX	0.479 MAX	ASPF-S-DT()	0.386 MAX	0.507 MAX	0.634 MAX	ASP-LC-2AC()
2ASFPF-DT()-()	0.302 MAX	0.399 MAX	0.479 MAX	2ASPP-S-DT()				ASP-LC-2AC()
2ASPPF-DT()-()				ASPF-S-DT()	0.386 MAX	0.507 MAX	0.634 MAX	ASP-LC-2AC()
2ASPPP-DT()-()				2ASPP-S-DT()				ASP-LC-2AC()
2ASP509F-DT()-()	0.386 MAX	0.507 MAX	0.634 MAX	ASPF-S-DT()	0.386 MAX	0.507 MAX	0.634 MAX	ASP-LC-2AC()
2ASP509P-DT()-()	0.386 MAX	0.507 MAX	0.634 MAX	2ASPP-S-DT()				ASP-LC-2AC()
ASPPF-DT()-()	0.386 MAX	0.507 MAX	0.634 MAX	ASPF-S-DT()	0.386 MAX	0.507 MAX	0.634 MAX	ASP-LC-2AC()
ASFPF-DT()-()	0.386 MAX	0.507 MAX		2ASPP-S-DT()				ASP-LC-2AC6
ASPPF-DT6-()				ASPF-S-DT6	0.386 MAX			ASP-LC-2AC8
ASP100F-DT08-18		0.399 MAX		ASPF-S-DT8		0.507 MAX		ASP-LC-2AC()
ASP100P-DT()-()	0.302 MAX	0.399 MAX		2ASPP-S-DT()				ASP-LC-2AC()
ASPPF-EU()-()AC	0.386 MAX	0.507 MAX	0.634 MAX	ASPF-S-DT()	0.386 MAX	0.507 MAX	0.634 MAX	ASP-LC-2AC()
ASFPF-EU()-()AC	0.386 MAX	0.507 MAX	0.634 MAX	2ASPP-S-DT-()				ASP-LC-2AC()
ASFPF-MU10-()-()			0.634 MAX	2ASPP-S-DT10- ()				ASP-LC-2AC10
ASPPF-MU10-()-()			0.634 MAX	ASPF-S-DT10- ()			0.634 MAX	ASP-LC-2AC10
ASPSFP-MU10-()-()			0.479 MAX	2ASPP-S-DT10- ()				ASP-LC-2AC10
ASPSFF-MU10-()-()			0.479 MAX	ASPF-S-DT10- ()			0.634 MAX	ASP-LC-2AC10
ASPSPF-MU10-()-()				ASPF-S-DT10- ()			0.634 MAX	ASP-LC-2AC10

Fastener Specifications
Figure 605 (Sheet 1 of 2)

78-00-08

REPAIR - GENERAL

Page 609

Jul 01/2008



COMPONENT MAINTENANCE MANUAL

PIN PART NUMBER	CSK PIN HD DIA			SLEEVE PART NUMBER	CSK PIN HD DIA			COLLAR PART NUMBER
	06	08	10		06	08	10	
ASPPF-V()-()	0.386 MAX	0.507 MAX		ASPF-S-V()-()	0.386 MAX	0.507 MAX		ASP-LC-MV()
ASPPF-V()-()	0.386 MAX	0.507 MAX	0.634 MAX	ASPF-S-V()-()	0.386 MAX	0.507 MAX	0.634 MAX	ASP-LC-2AC()
MAFFP-DT()-()	0.386 MAX	0.507 MAX	0.634 MAX	2MAFP-S-DT()				MAF-LC-2AC()
MAFFF-DT()-()	0.386 MAX	0.507 MAX	0.634 MAX	MAFF-S-DT()	0.386 MAX	0.507 MAX	0.634 MAX	MAF-LC-2AC()
MAFPF-DT()-()				MAFF-S-DT()	0.386 MAX	0.507 MAX	0.634 MAX	MAF-LC-2AC()
MAFFF-EU()-()AC	0.386 MAX	0.507 MAX	0.634 MAX	MAFF-S-DT()	0.386 MAX	0.507 MAX	0.634 MAX	MAF-LC-2AC()
MAFFP-EU()-()AC	0.386 MAX	0.507 MAX	0.634 MAX	2MAFP-S-DT()				MAF-LC-2AC()
2MAFFF-DT()-()	0.302 MAX	0.399 MAX	0.479 MAX	MAFF-S-DT()	0.386 MAX	0.507 MAX	0.634 MAX	MAF-LC-2AC()
2MAFFP-DT()-()	0.302 MAX	0.399 MAX	0.479 MAX	2MAFP-S-DT()				MAF-LC-2AC()
2MAFPF-DT()-()				MAFF-S-DT()	0.386 MAX	0.507 MAX	0.634 MAX	MAF-LC-2AC()
2MAFPP-DT()-()				2MAFP-S-DT()				MAF-LC-2AC()
2MAF509F-DT()-()	0.386 MAX	0.507 MAX	0.634 MAX	MAFF-S-DT()	0.386 MAX	0.507 MAX	0.634 MAX	MAF-LC-2AC()
2MAF509P-DT()-()	0.386 MAX	0.507 MAX	0.634 MAX	2MAFP-S-DT()				MAF-LC-2AC()
ASPPF-V()-()AC	0.302 MAX	0.399 MAX	0.479 MAX	ASPF-S-V()AC	0.332 MAX	0.432 MAX	0.522 MAX	ASP-LC-MV()
ASPPF-V()-()AC	0.302 MAX	0.399 MAX	0.479 MAX	2ASPP-S-V()AC	0.332 MAX	0.432 MAX	0.522 MAX	ASP-LC-MV()
ASPPF-V()-()-()	0.386 MAX	0.507 MAX		ASPF-S-V()-()	0.386 MAX	0.507 MAX		ASP-LC-MV()

TABLE VII

Fastener Specifications
Figure 605 (Sheet 2 of 2)

78-00-08

REPAIR - GENERAL

Page 610

Jul 01/2008

PART NUMBER NONE



COMPONENT MAINTENANCE MANUAL

ASSEMBLY

(NOT APPLICABLE)

78-00-08

ASSEMBLY

Page 701

Jul 01/2008

PART NUMBER NONE



COMPONENT MAINTENANCE MANUAL

FITS AND CLEARANCES

(NOT APPLICABLE)

78-00-08

FITS AND CLEARANCES

Page 801

Jul 01/2008



COMPONENT MAINTENANCE MANUAL

SPECIAL TOOLS, FIXTURES, AND EQUIPMENT

1. General

A. This section lists the special tools, fixtures, and equipment necessary for maintenance.

NOTE: Equivalent substitutes may be used.

Special Tools

Reference	Description	Part Number	Supplier
SPL-4697	Zephyr Super Shaver, ZT507	ZT507	3JKA4

Tool Supplier Information

CAGE Code	Supplier Name	Supplier Address
3JKA4	GENERAL TOOL & INSTRUMENTS	80 WHITE STREET NEW YORK, NY 10013 Telephone: 212-431-6100 Facsimile: 212-431-6499

78-00-08

SPECIAL TOOLS, FIXTURES, AND EQUIPMENT

Page 901

Jul 01/2008

PART NUMBER NONE



COMPONENT MAINTENANCE MANUAL

ILLUSTRATED PARTS LIST

(NOT APPLICABLE)

78-00-08

ILLUSTRATED PARTS LIST

Page 1001

Jul 01/2008