

OVERHAUL MANUAL

TO: ALL HOLDERS OF GENERATOR DRIVE AND STANDBY POWER MODULE ASSEMBLY P5-5
OVERHAUL MANUAL, 31-10-05

REVISION NO. 5, DATED DEC 5/93

HIGHLIGHTS

DESCRIPTION OF CHANGE	TOPICS AFFECTED												
	D & O	D / A s s y	C l e a n i n g	I n s p / C h k	R e p a i r	A s s y	F / C	T e s t	T / S h o o t i n g	S / T o o l s	S t o r a g e	I P L	L / O v e r h a u l
<p>Changed pin P2-3 on A2 PCA to read pin P2-8 instead, on Schematic Diagram Fig. 7A (Sheet 3) for 69-76472-4, -5, -6</p> <p>Added optional printed circuit assembly P/N 69-54338-7 (A3) to IPL Fig. 8 (Item 17A) and IPL Fig. 9 (Item 85A)</p>								X				X	

GENERATOR DRIVE AND STANDBY POWER MODULE ASSEMBLY P5-5

31-10-05

BOEING P/N 69-76472-1 thru -13

AIRLINE P/N

THE FOLLOWING DIRECTIVES APPLY TO THIS SUBJECT:

BOEING SERVICE BULLETIN	BOEING TEMPORARY REVISION	OTHER DIRECTIVES	DATE DIRECTIVE INCORPORATED INTO TEXT
24-1056		MRR 3245-036	Sep 5/86

OVERHAUL MANUAL

LIST OF EFFECTIVE PAGES					
* Indicates pages revised, added or deleted in latest revision					
F Indicates foldout pages - print one side only					
PAGE	DATE	PAGE	DATE	PAGE	DATE
31-10-05		F 39	Dec 5/86		
T-1	Dec 5/86	40	BLANK		
T-2	BLANK	41	Jun 5/92		
* LEP-1	Dec 5/93	42	BLANK		
LEP-2	BLANK	43	BLANK		
T/C-1	Jun 5/92	44	Dec 5/86		
T/C-2	BLANK	F 45	Dec 5/86		
1	Sep 5/86	46	BLANK		
2	Sep 5/86	47	Dec 5/86		
3	Sep 5/86	48	Dec 5/86		
4	Dec 5/86	* 49	Dec 5/93		
5	Dec 5/86	50	Dec 5/86		
6	Dec 5/86	* 51	Dec 5/93		
7	Dec 5/88	52	BLANK		
8	Dec 5/86	53	Dec 5/86		
9	Dec 5/86	54	Dec 5/86		
10	Dec 5/87	55	Dec 5/86		
11	Dec 5/86	* 56	Dec 5/93		
12	Dec 5/86	57	Dec 5/86		
13	Dec 5/86	* 58	Dec 5/93		
14	Dec 5/86	59	Dec 5/86		
15	Dec 5/86	60	BLANK		
16	Dec 5/86				
17	Dec 5/86				
18	BLANK				
19	Jun 5/92				
20	BLANK				
21	BLANK				
22	Dec 5/87				
F 23	Dec 5/87				
24	BLANK				
25	Jun 5/92				
26	BLANK				
27	Dec 5/86				
28	BLANK				
29	BLANK				
* 30	Dec 5/93				
F 31	Dec 5/86				
32	BLANK				
33	Jun 5/92				
34	BLANK				
35	Dec 5/86				
36	BLANK				
37	BLANK				
38	Dec 5/86				

OVERHAUL MANUAL

TABLE OF CONTENTS

<u>Paragraph Title</u>	<u>Page</u>
Description and Operation	1
Disassembly*[1]	
Cleaning.*[1]	
Inspection/Check.*[1]	
Repair.	8
Assembly.*[2]	
Fits and Clearances (not applicable)	
Testing	9
Trouble Shooting.	15
Storage Instructions.*[1]	
Special Tools, Fixtures, and Equipment.*[1]	
Illustrated Parts List.	47

*[1] Use applicable procedures in 20-11-04 and standard industry practices.

*[2] Special instructions not required.



OVERHAUL MANUAL

GENERATOR DRIVE AND STANDBY POWER MODULE ASSEMBLY P5-51. DESCRIPTION AND OPERATION

- A. The generator drive and standby power module assembly consists of switches, indicator lights, and printed circuit assemblies mounted on support plates that are attached to the baseplate along with a rear mounted connector to mate with the airplane wire bundle. Six quick disconnect studs are provided to mount the module on the captain's and first officer's forward overhead instrument panel.
- B. The module assembly controls the performance of the main power generators. Indicator lights on the module assembly alert the crew of generator drive low oil pressure and high oil temperature. Switches are provided to disconnect the generators from the line and to convert to a standby power system in the event of a complete loss of AC power.
- C. Functional Description (Fig. 1)
- (1) Indicator Lamps
- (a) Indicator lamps L1 thru L4 terminal number 4 are grounded from pin P4-10. Voltage of +28 volts dc is applied at terminal number 1 from P4-21 and P5-51, L1 thru L4 will illuminate individually when pressed. The number 3 terminals of L1 thru L4 may be connected to ground through the external master test switch connected at pin P4-3 to illuminate them all at once. The lamps serve their indicator function when the terminal number 2 are grounded.
- (b) Indicator lamp L5 terminal number 2 is grounded from P5-28. Voltage of +28 volts dc is applied at terminal number 4 from P5-13, L5 will illuminate when pressed. Terminal number 3 may be connected to +28 volts dc through the external master test switch connected at pin P5-12 to illuminate L5. The lamp serve its indicator function when +28 volts dc is applied to terminal number 1.

OVERHAUL MANUAL

(2) The external master caution indicator is connected at pin P5-41. Voltage of +28 volts dc is applied at pin P5-13 and ground is connected at pin P4-10. The master caution indicator is illuminated by completing a ground path from pin P5-41 through printed circuit assembly A1 to pin P4-10. (Refer to 31-36-05 for A1 operation.)

(a) Master Caution, L1 and L2 Indicators


1) Pin P4-20 is grounded, 115 vac is applied to pins P4-6 and P5-32, and the engine 1 and 2 oil pressure sensors are connected to pins P4-7 and P5-33, respectively. If either of the pressure sensors sense low oil pressure, they reduce the impedance to the printed circuit assembly A3. The A3 current sensing circuit senses an increase in current and A3 operates to apply a ground to L1 or L2 and A1. L1 or L2 and the external master caution indicator are illuminated. (Refer to 31-10-70 for A3 operation.)

(b) Master Caution, L3, L4, and L5 indicators


1) If pins P4-40 or P5-50 are grounded through the engine 1 or 2 overheat sensors, respectively, lamps L3 or L4, and the master caution indicator will illuminate. If +28 volts dc is applied (through the transfer power relays) to pin P5-24, lamp L5 and the master caution indicator will illuminate.

(c) The ac system generator and APU module assembly (P5-4) supplies a ground input to pin P5-44 and an input pulse to pin P4-55 to illuminate the master caution indicator (Fig. 2). (Refer to 31-36-30 for P5-4 operation.)

BOEING
COMMERCIAL JET
OVERHAUL MANUAL



Master Caution, L1, L2, L3, L4, and L5
 Indicator Diagram
 Figure 1



Master Caution Indicator Diagram
 Figure 2

(3) Master Caution Recall (Fig. 2)

- (a) The master caution indicator, when illuminated, may be extinguished by opening the ground path from pin P5-41 through A1 to pin P4-10. At a later time, activating the external master caution recall, which momentarily grounds pin P5-23, will illuminate the master caution indicator provided one or more of the inputs discussed in paragraph 3.C.(1), 3.C.(2) or the ground input discussed in paragraph 3.C.(3) are present.


(4) Master Test

- (a) Activating master test illuminates lamps L1 through L5 and the master caution indicator by providing a ground input to terminal number 3 of lamps L1 through L4, supplying +28 volts dc to terminal number 3 of lamp L5 and completing the ground path through A1 for the master caution indicator.

BOEING 
COMMERCIAL JET
OVERHAUL MANUAL

(5) Standby Power Transfer Time Delay (Fig. 2A).


- (a) On those assemblies with printed circuit assembly A2, the circuit operates as a time delay in the standby power transfer circuit. (Refer to 31-10-69, for description of A2 operation.) Pin P5-42 is grounded and +18 volts dc is supplied to A2 from A1. With pin P5-43 grounded through an external transfer relay, S4 in AUTO, and +28 volts dc supplied (through the external standby power transfer relay and ac voltage sensor) to pin P5-27, the A2 circuit is activated, supplying a ground path from pin P5-27 through A2 to pin P5-42. Removing ground from pin P5-43 causes the A2 circuit to open the ground path from pin P5-27 to P5-42 after a delay of 225 to 600 milliseconds. The time delay prevents nuisance transfers of the standby buses during switching of the transfer relay.



Standby Power Transfer Time Delay
 Figure 2A


OVERHAUL MANUAL

- (6) Master Caution 1 Second Time Delay with Power and Ground Seeking Circuits (Fig. 2B).
- (a) On those assemblies with printed circuit assembly A2 (69-71571-3), the circuit operates as a master caution 1 second time delay with power or ground seeking inputs (refer to 33-10-06).
 - (b) In the ground seeking circuit pin P4-10 is grounded and +18 volts dc is supplied to A2 from A1, and pin P2-7 (A2) is the ground seeking input. When pin P2-7 is grounded, amplifier U1's output is initially high and in approximately 1 second C3 charges to a voltage which is higher than the voltage at U1-3, then U1 switches low and supplies a master caution negative pulse at pin P2-2. Pin P2-1 has a ground path thru R7, CR3 for the master caution holding circuit.
 - (c) The preceding circuit is converted to a power seeking circuit by connecting pins P2-5 and P2-7. Then when power is applied at pin P2-4, Q1 turns on supplying the ground path previously obtained by grounding pin P2-7.




Master Caution 1 Second Time Delay Circuit
Figure 2B

BOEING
COMMERCIAL JET
OVERHAUL MANUAL



69-76472-1



69-76472-2, -3

Component Identification
 Figure 3

2. REPAIR

A. All repair can be accomplished with standard industry practices and instructions contained in 20-11-04 except as noted in paragraphs below:

- (1) If keying plugs (23, Fig. 8) require replacement, insert as follows:

NOTE: On assemblies 69-76472-1, -2, -3, -13, reference designators P1 and P3 have been replaced by XA1 and XA3.

- (a) Connector P1: Install keying plug into contact position 9.
(b) Connector P2: Install keying plug into contact position 13.
(c) Connector P3: Install keying plug into contact position 10.
- (2) If screws (29, 44, Fig. 1101) are replaced, coat threaded areas with Loctite primer Grade T, and nutlock compound 74 (Loctite Corporation, 705 North Mountain Road, Newington, Connecticut 06111) per manufacturer's instructions.

BOEING 
COMMERCIAL JET
OVERHAUL MANUAL


3. TESTING

A. Test Equipment (69-76472-1, -2, -3)

- (1) Power Supplies
 - (a) 28 volts dc
 - (b) 115 volts ac, 400Hz
- (2) Test lamp (LA), 28 volts dc, 440 mA
- (3) Capacitor, luf (C1)
- (4) Switches
 - (a) SPST switch, 11 required (S2 thru S11)
 - (b) Pushbutton switch, normally closed (S1)
- (5) Connectors
 - (a) BACC45FT22-55S (J4) mates with P4
 - (b) BACC45FT22-55S6 (J5) mates with P5

B. Test Preparation

- (1) Connect test setup shown in Fig. 4.
- (2) Refer to Fig. 3 for component identification, Fig. 7 for schematic diagram



OVERHAUL MANUAL

C. Functional Test (69-76472-1, -2, -3)

NOTE: On assembly 69-76472-3 use lamp designators DS1 through DS5 wherever L1 thru L5 appears in test.

- (1) Connect test setup to module assembly, set test switches S2 through S12 to OFF, and turn on power supplies.
- (2) Depress indicators L1 through L5. Each shall illuminate when pressed and extinguish when released.
- (3) Set switches and verify lamp indications per Fig. 5.
- (4) Set test switches and power supplies to OFF and disconnect test setup.

Test Step	Test Switch Position	Lamps Illuminated
1	S9 ON	L5 and LA
2	S6 ON	L1 thru L5, LA
3	S6 OFF	L5 and LA
4	S9 OFF	NONE
5	S11 ON	L5
6	S11 OFF	NONE
7	S2 ON	L1 and LA
8	S2 OFF	NONE
9	S3 ON	L2 and LA
10	S3 OFF	NONE
11	S4 ON	L3 and LA
12	S4 OFF	NONE
13	S5 ON	L4 and LA
14	S5 OFF	NONE
15	S12 ON	NONE
16	S7 ON	LA
17	S1 PRESSED	NONE
18	S1 RELEASED	NONE
19	S12 OFF	NONE
20	S8 ON	LA
21	S7, S8 OFF	NONE

Functional Test, 69-76472-1, -2, -3
 Figure 5

BOEING 
COMMERCIAL JET
OVERHAUL MANUAL

- (5) Verify continuity between pin P5-2 and center of power connector L6, and between pin P5-1 and chassis ground.
- (6) Verify continuity or no continuity as specified in Fig. 6.
- (7) Verify continuity between pins P5-19 and P4-34.

Test Step	Switch Position	Continuity		No Continuity	
		P4	P5	P4	P5
1	S1 OFF	52-53		51-50 51-53	
2	S1 ON	51-50 51-53		52-53	
3	S2 OFF		36-37		35-34 35-37
4	S2 ON		35-34 35-37		36-37
5	S3 RISE	39-34 32-33 32-35 37-38	16-18 16-55 17-19 20-39	39-37 39-38 32-36 33-36	16-38 18-38 17-20 17-39
6	S3 IN	32-36 39-37	16-38 17-20	32-35 39-34	16-55 17-19
7	S4 OFF				26-11 26-25 27-42
8	S4 AUTO		26-11 27-42		26-25
9	S4 BATT		26-25		26-11 27-42

OVERHAUL MANUAL


D. Test Equipment (69-76472-4 thru -13)

(1) Power Supplies

- (a) 28 volts dc
- (b) 115 volts ac, 400 Hz

(2) Test Setup, consisting of the following items: (See Fig. 6A)

- (a) Switches, SPST (11 required)
- (b) Switch, pushbutton, N.C.
- (c) Test Lamp (LB) 28 volts dc, 40 mA, 327 (General Electric Company, Lamp Division of Consumer Products Group, Nela Park, Cleveland, Ohio)
- (d) Connectors, BACC45FT22-55S (J4) and BACC45FT22-55S6 (J5)
- (e) Capacitor, 1 uf
- (f) Oscilloscope, capable of measuring from 225 to 600 millisecond time intervals (69-76472-4, -5, -6, only).
- (g) Test Lamp (LA), 28 volts dc, 440 mA



Test Setup, 69-76472-4 thru -13
Figure 6A

OVERHAUL MANUAL

E. Functional Test (69-76472-4 thru -13)

NOTE: On assemblies 69-76472-13, use lamp designators DS1 thru DS5 wherever L1 thru L5 appears in test.

- (1) Connect test setup to module assembly, set test switches S2 through S12 to OFF, and turn on power supplies.
- (2) Depress indicators L1 thru L5. Each shall illuminate when pressed and extinguish when released.
- (3) Set switches and verify lamp indications per Fig. 6B.
- (4) Set test switches and power supplies to OFF and disconnect test setup.

Step	Test Switch		Module Switch		Lamp Indications
	Number	Position	Number	Position	Illuminated
1	S1, S10	ON	S4	OFF	NONE
1a	S9	ON			L5 and LA
2	S6	ON			L1 thru L5, LA
3	S6	OFF			L5 and LA
4	S9	OFF			NONE
5	S11	ON			L5
6	S11	OFF			NONE
7	S2	ON			L1 and LA
8	S2	OFF			NONE
9	S3	ON			L2 and LA
10	S3	OFF			NONE
11	S4	ON			L3 and LA
12	S4	OFF			NONE
13	S5	ON			L4 and LA
14	S5	OFF			NONE
14A	S12	ON			NONE
15	S7	ON			LA
16	S1	PRESSED			NONE
17	S1	RELEASED			NONE
18	S8	ON			LA
19	S7, S8	OFF			NONE
20			S4	AUTO	LB
21	S10	OFF			LB *[1]
22			S4	OFF	NONE

*[1] On 69-76472-4, -5, -6 lamp LB shall extinguish within 225 to 600 milliseconds after setting S10 to OFF. Connect vertical lead "V" of oscilloscope to J5-27. Adjust vertical sensitivity of oscilloscope for a 28-volt dc signal and set the sweep frequency to provide for a 225 to 600 millisecond pulse. Pin J5-43 may be used as an external trigger.

OVERHAUL MANUAL

- (5) Verify continuity between pin P5-2 and center of power connector L6, and between pin P5-1 and chassis ground.
- (6) Verify continuity or no continuity as specified in Fig. 703.
- (7) Verify continuity between pins P5-19 and P4-34.

Step	Switch	Position	Continuity		No Continuity	
			P4	P5	P4	P5
1	S1	OFF	52-53		51-50 51-53	
2	S1	ON	51-50 51-53		52-53	
3	S2	OFF		36-37		35-34 35-37
4	S2	ON		35-34 35-37		36-37
5 *[1]	S3	RISE	39-34 32-33 32-35 37-38	16-18 16-55 17-19 20-39	39-37 39-38 32-36 33-36	16-38 18-38 17-20 17-39
6 *[2]	S3	RISE	32-33 39-34 33-35	16-18 17-19 16-55	32-36 39-32	16-38 17-16
7 *[1]	S3	IN	32-36 39-37	16-38 17-20	32-35 39-34	16-55 17-19
8 *[2]	S3	OUT	39-33 36-33	16-17 16-38	39-34 33-35	16-55 17-19
9 *[3]	S4	AUTO		26-11		26-25
10 *[4]	S4	AUTO		26-11 27-42		26-25
11 *[3]	S4	BATT		26-25		26-11 27-43
12 *[4]	S4	BATT		26-25		26-11 27-42
13 *[3]	S4	OFF				26-11 26-25 27-43
14 *[4]	S4	OFF				26-11 26-25 27-42

*[1] 69-76472-4, -6, -7, -9, -10, -12, -13

*[2] 69-76472-5, -8, -11

*[3] 69-76472-4, -5, -6

*[4] 69-76472-7 thru -13

BOEING 
COMMERCIAL JET
OVERHAUL MANUAL

4. TROUBLE SHOOTING

- A. Trouble shooting is keyed to the steps of the test procedures. Paragraph and step references are to that portion of TESTING wherein the fault specified could occur. The presumption is made that when a fault indication is encountered, the results of all previous steps were normal.
- B. (69-76472-1, -2, -3) Whenever a fault has been isolated to a printed circuit assembly, the assembly must be repaired or replaced. Refer to 31-36-05 for A1 and 31-10-70 for A3.

<u>Trouble</u>	<u>Possible Cause and Corrective Action</u>
(1) Failure of test par. 3.C.	1, L2, L3, L4, or L5
(2) Failure of test par. 3.C.	
Step 1	A1, L5 or R3
Step 2	L1, L2, L3, L4, L5 or A1
Step 3	A1, L5, or R3
Step 5	L5
Step 7	R1, A1, or A3
Step 9	R2, A1, or A3
Step 11	L3 or A1
Step 13	L4 or A1
Step 15 thru 21	A1
(3) Failure of test par. 3.C.(5)	L6
(4) Failure of test par. 3.C.(6)	Switch noted in Fig. 6
(5) Failure of test par. 3.C.(7)	Incorrect wiring connection on S3

OVERHAUL MANUAL


C. (69-76472-4 thru -13) Whenever a fault has been isolated to a printed circuit assembly, the assembly must be repaired or replaced. Refer to 31-36-05 for A1, 31-10-69 (for 69-76472-4, -5, -6 only) for A2, and 31-10-70 for A3.

<u>Trouble</u>	<u>Possible Cause and Corrective Action</u>
(1) Failure of test paragraph 3.E. L1, L2, L3, L4, or L5	
(2) Failure of test paragraph 3.E.	
Step 1	S4
Step 1a	L5, A2 or A1
Step 2	L1, L2, L3, L4, L5 or A1
Step 3	A1, R3, L5 or A2
Step 5	L5
Step 7	R1, A1, or A3
Step 9	R2, A1 or A3
Step 11	L3 or A1
Step 13	L4 or A1
Step 15, 16, 17, or 18	A1
Step 20	S4 or A2
Step 21	Calibrate A2. Refer to 31-10-69


BOEING 
COMMERCIAL JET
OVERHAUL MANUAL

<u>Trouble</u>	<u>Possible Cause and Corrective Action</u>
(3) Failure of test paragraph 3.E.(5)	L6
(4) Failure of test paragraph 3.E.(6)	Switch noted in figure 703
(5) Failure of test paragraph 3.E.(7)	Incorrect wiring connection on S3

OVERHAUL MANUAL




69-76472-1, -2, -3



69-76472-1, -2, -3

Schematic Diagram
Figure 7 (Sheet 2)




69-76472-1, -2, -3

Schematic Diagram
Figure 7 (Sheet 3)

31-10-05
Page 23

Dec 5/87


OVERHAUL MANUAL



69-76472-4, -6


Schematic Diagram
Figure 7A (Sheet 1)

BOEING
COMMERCIAL JET
OVERHAUL MANUAL



69-76472-5


OVERHAUL MANUAL



69-76472-4, -5, -6

Schematic Diagram
Figure 7A (Sheet 3)


BOEING
COMMERCIAL JET
OVERHAUL MANUAL



NOTE: ALL WIRE BMS 13-16 TYPE 1, CLASS 1, SIZE AWG 24 EXCEPT AS NOTED

69-76472-4, -5, -6


OVERHAUL MANUAL



69-76472-7, -9, -10, -12


Schematic Diagram
Figure 7B (Sheet 1)

BOEING
COMMERCIAL JET
OVERHAUL MANUAL



69-76472-8, -11


Schematic Diagram
Figure 7B (Sheet 2)



69-76472-7 THRU -12

Schematic Diagram
 Figure 7B (Sheet 3)

BOEING
COMMERCIAL JET
OVERHAUL MANUAL




A1 PRINTED CIRCUIT ASSEMBLY

NOTE ALL WIRE BMS 13-16 TYPE 1, CLASS 1,
 SIZE AWG 24 EXCEPT AS NOTED


69-76472-7 THRU -12

OVERHAUL MANUAL



69-76472-13


Schematic Diagram
Figure 7C (Sheet 1)



69-76472-13

Schematic Diagram
 Figure 7C (Sheet 2)

BOEING
COMMERCIAL JET
OVERHAUL MANUAL




A1 PRINTED CIRCUIT ASSEMBLY

NOTE ALL WIRE BMS 13- 16 TYPE 1, CLASS 1.
SIZE AWG 24 EXCEPT AS NOTED


69-76472-13

Schematic Diagram
Figure 7C (Sheet 3)

BOEING 
COMMERCIAL JET
OVERHAUL MANUAL

5. Illustrated Parts List

Generator Drive and Standby Power Module Assembly (P5-5)
 Figure 8 (Sheet 1)



Generator Drive and Standby Power Module Assembly (P5-5)
Figure 8 (Sheet 2)

OVERHAUL MANUAL

FIG. & ITEM NO.	PART NO.	AIRLINE PART NUMBER	N O M E N C L A T U R E							USE CODE	QTY PER ASSY
			1	2	3	4	5	6	7		
8-	69-76472-1		GENERATOR DRIVE AND STANDBY POWER MODULE ASSY (P5-5) (SB 24-1056)							A	RF
	69-76472-2		GENERATOR DRIVE AND STANDBY POWER MODULE ASSY (P5-5) (SB 24-1056)							B	RF
	69-76472-3		GENERATOR DRIVE AND STANDBY POWER MODULE ASSY (P5-5) (SB 24-1056)							C	RF
1	NAS514P440-4		. SCREW								8
2	69-39694-22		. COVER ASSY								1
3	69-39694-23		. . COVER								1
4	69-39694-15		. . INSULATOR								2
5	69-39694-24		. . COVER ASSY								1
6	69-39694-25		. . COVER								1
7	69-39694-21		. . FOAM SUPPORT								1
7	69-39694-20		. . FOAM (OPT)								1
8	BACS12CB04-5		. SCREW								4
9	BACN10NW1		. CLIP NUT								4
10	BACC45FN22-55P		. CONNECTOR								1
11	BACC45FN22-55P6		. CONNECTOR								1
12	BACS12CB06-5		. SCREW								4
13	MS35338-41		. WASHER								4
14	69-39694-3		. BACKPLATE								1
15	69-51810-8		. PRINTED CIRCUIT ASSY (REF 31-36-05)								1
17	69-54338-6		. PRINTED CIRCUIT ASSY (REF 31-10-70)								1
17A	69-54338-7		. PRINTED CIRCUIT ASSY (REF 31-10-70) (OPT)								1
18	BACS12CB06-14		. SCREW								4
19	NAS43DD1-17		. SPACER								4
20	BACN10JC06		. NUT								4
21	582557-1		. CONNECTOR, V00779								1
22	582553-1		. CONNECTOR, V00779								1
23	582507-1		. KEYING PLUG, V00779								2
24	BACS12CB04-16		. SCREW								2
25	NAS43DD1-35		. SPACER								2
26	BACN10JC06		. NUT								2
27	69-39694-7		. HEAT SINK								1
28	RE70G1001		. RESISTOR, 1K OHM, 1%, 20W								2
29	BACS12CB04-4		. SCREW								4
30	69-39694-16		. SUPPORT PLATE								1
31	11170		. GUARD, V72914								2
32	MS24524-26		. SWITCH								2
33	64ATT22-3		. SWITCH, TOGGLE, V81640								1

OVERHAUL MANUAL

FIG. & ITEM NO.	PART NO.	AIRLINE PART NUMBER	N O M E N C L A T U R E							USE CODE	QTY PER ASSY
			1	2	3	4	5	6	7		
33	A3-1110-05-01		.	S	W	I	T	C	H		1
34	69-44578-2		.	C	A	P					1
35	138-102		.	P	O	W	E	C	O	N	1
35	SCN001		.	P	O	W	E	C	O	N	1
36	BACS12BF02-4		.	S	C	R	E	W			2
37	BACN10DN26		.	N	U	T					2
38	RER60F5110FM		.	R	E	S	I	S	T	O	1
39	318-630-1001-014		.	I	N	D	I	C	A	T	2
39	318-630-1001-152		.	I	N	D	I	C	A	T	2
40	318-630-1001-020		.	I	N	D	I	C	A	T	2
40	318-630-1001-166		.	I	N	D	I	C	A	T	2
41	318-630-1002-008		.	I	N	D	I	C	A	T	1
41	318-630-1002-036		.	I	N	D	I	C	A	T	1
42	60-0730-5		.	G	U	A	R	D			1
43	MS24524-21		.	S	W	I	T	C			1
44	NAS514P632-5		.	S	C	R	E	W			4
45	69-37315-4		.	S	T	A	N	O	F	F	2
46	69-37268-21		.	S	T	A	N	O	F	F	2
47	BACN10PA06-6		.	N	U	T	,	P	R	E	4
48	69-37315-6		.	B	A	S	E	P	L	A	1
48	69-37315-24		.	B	A	S	E	P	L	A	1
48A	BACF10U0637G		.	.	B	A	S	E	P	L	1
48B	BACS21DDIG		.	.	S	T	A	S	S		6
49	69-37315-42		.	W	I	R	E	B	U	N	1
49	69-37315-44		.	W	I	R	E	B	U	N	1
50	66143-2LP		.	T	A	B	T	E	R	M	AR
50	66144-2LP		.	T	A	B	T	E	R	M	AR
51	BACT12S		.	T	E	R	M	I	N	A	AR
52	BACT12AC		.	T	E	R	M	I	N	A	AR
53	BACM10L001CU		.	M	A	R	K	E	R		1
54	BAC27DCC229		.	M	A	R	K	E	R		1
55	BACC10EL3		.	C	L	A	M	P			2


OVERHAUL MANUAL

REFERENCE DESIGNATION INDEX (SEE SCHEMATIC DIAGRAM)		
REFERENCE DESIGNATION	PART NUMBER	ITEM NO.
A1	69-51810-8	15
A3	69-54338-6	17
A3	69-54338-7	17A
L1, L2 *[1]	318-630-1001-014	39
L1, L2 *[1]	318-630-1001-152	39
L3, L4 *[1]	318-630-1001-020	40
L3, L4 *[1]	318-630-1001-166	40
L5 *[1]	318-630-1002-008	41
L5 *[1]	318-630-1002-036	41
P4	BACC45FN22-55P	10
P5	BACC45FN22-55P6	11
R1, R2	RE70G1001	28
R3	RER60F5110FM	38
S1, S2	MS24524-26	32
S3	A3-1110-05-1	33
S3	64ATT22-3*	33
S4	MS24524-21	43
XA1	582557-1	21
XA3	582553-1	22

* PREFERRED PART


*[1] DS1 THRU DS5 FOR 69-76472-3

BOEING 
COMMERCIAL JET
OVERHAUL MANUAL



69-76472-4 THRU -13

Generator Drive and Standby Power Module Assembly (P5-5)
 Figure 9 (Sheet 1)



Generator Drive and Standby Power Module Assembly (P5-5)
Figure 9 (Sheet 2)

OVERHAUL MANUAL

FIG. & ITEM NO.	PART NO.	AIRLINE PART NUMBER	N O M E N C L A T U R E							USE CODE	QTY PER ASSY
			1	2	3	4	5	6	7		
9- 1	69-76472-4		GENERATOR DRIVE AND STBY POWER MODULE ASSY (P5-5) (SB 24-1056)							A	
1A	69-76472-5		GENERATOR DRIVE AND STBY POWER MODULE ASSY (P5-5) SB 24-1056							B	
1B	69-76472-6		GENERATOR DRIVE AND STBY POWER MODULE ASSY (P5-5) (SB 24-1056)							C	
1C	69-76472-7		GENERATOR DRIVE AND STBY POWER MODULE ASSY (P5-5) (SB 24-1056)							D	
1D	69-76472-8		GENERATOR DRIVE AND STBY POWER MODULE ASSY (P5-5) (SB 24-1056)							E	
1E	69-76472-9		GENERATOR DRIVE AND STBY POWER MODULE ASSY (P5-5) (SB 24-1056)							F	
1F	69-76472-10		GENERATOR DRIVE AND STBY POWER MODULE ASSY (P5-5) (SBV 24-1056)							G	
1G	69-76472-11		GENERATOR DRIVE AND STBY POWER MODULE ASSY (P5-5) (SB 24-1056)							H	
1H	69-76472-12		GENERATOR DRIVE AND STBY POWER MODULE ASSY (P5-5) (SB 24-1056)							J	
1J	69-76472-13		GENERATOR DRIVE AND STBY POWER MODULE ASSY (P5-5) (SB 24-1056)							K	
5	NAS514P440-4		. SCREW								8
10	69-39694-22		. COVER ASSY								1
15	69-39694-23		. . COVER								1
22	69-39694-15		. . INSULATOR								2
25	69-39694-24		. COVER ASSY								1
30	69-39694-25		. . COVER								1
35	69-39694-21		. . FOAM SUPPORT								1
35A	69-39694-20		. . FOAM (OPT)								1
40	BACS12CB04-5		. SCREW								4
45	BACN1ONW1		. CLIP NUT								4
50	BACC45FN22- 55P		. CONNECTOR								1
55	BACC45FN22- 55P6		. CONNECTOR								1
60	BACS12CB06-5		. SCREW								4
65	MS35337-41		. WASHER								4
70	69-39694-3		. BACKPLATE								1
75	69-51810-8		. PRINTED CIRCUIT ASSY (REF 31-36-05)							ABC	
75A	69-51810-1		. PRINTED CIRCUIT ASSY (REF 31-36- 05) (OPT)								
75B	69-51810-8		. PRINTED CIRCUIT ASSY (REF 31-36-05)								

OVERHAUL MANUAL

FIG. & ITEM NO.	PART NO.	AIRLINE PART NUMBER	N O M E N C L A T U R E							USE CODE	QTY PER ASSY	
			1	2	3	4	5	6	7			
9-80	69-41756-3		.	P	R	I	N	T	E	A	ABC	1
85	69-54338-6		.	P	R	I	N	T	E	A		1
85A	69-54338-7		.	P	R	I	N	T	E	A		1
				(O	P	T)				
90	BACS12CB06-14		.	S	C	R	E	W			ABC	6
90A	BACS12CB06-14		.	S	C	R	E	W			D-K	4
95	NAS43DD1-17		.	S	P	A	C	E	R		ABC	6
95A	NAS43DD1-17		.	S	P	A	C	E	R		D-K	4
100	NAS679A06W		.	N	U	T					ABC	6
100A	NAS679A06W		.	N	U	T					D-K	4
105	582557-1		.	C	O	N	N	E	C	T		1
110	582553-1		.	C	O	N	N	E	C	T		2
110A	582553-1		.	C	O	N	N	E	C	T		1
115	582507-1		.	K	E	Y	I	N	G	P		ABC
115A	582507-1		.	K	E	Y	I	N	G	P		D-K
120	BACS12CB04-16		.	S	C	R	E	W				2
125	NAS43DD1-35		.	S	P	A	C	E	R			2
130	NAS679A04W		.	N	U	T					A-K	2
135	69-39694-7		.	H	E	A	T	S	I	N	K	1
140	RE70G1001		.	R	E	S	I	S	T	O	R	2
145	BACS12CB04-4		.	S	C	R	E	W				4
150	69-39694-16		.	S	U	P	P	O	R	T	P	1
155	11170		.	G	U	A	R	D				2
160	MS24524-26		.	S	W	I	T	C	H			2
165	A3-127T7		.	S	W	I	T	C	H			1
										ACDFG		
165A	64AT11-3		.	S	W	I	T	C	H			1
										JK		
										ACDFG		
										JK		
170	4PB11T2		.	S	W	I	T	C	H			1
175	69-44578-2		.	C	A	P						1
										ACDFG		
										JK		
180	138-102		.	P	O	W	E	R	C	O	N	1
180A	SCN001		.	P	O	W	E	R	C	O	N	1
185	BACS12BF02-4		.	S	C	R	E	W				2
190	BACN10DN26		.	N	U	T						2
195	RH5-330-1PCT		.	R	E	S	I	S	T	O	R	1
										ABC		
195A	3105M330-1PCT		.	R	E	S	I	S	T	O	R	1
										ABC		
195B	RH5-510-3PCT		.	R	E	S	I	S	T	O	R	1
										D-K		

OVERHAUL MANUAL

REFERENCE DESIGNATION INDEX (SEE SCHEMATIC DIAGRAM)		
REFERENCE DESIGNATION	PART NUMBER	ITEM NO.
A1	69-51810-1	75A
A1	69-51810-8	75,75B
A2	69-41756-3	80
A3	69-54338-6	85
A3	69-54338-7	85A
DS1, DS2	318-630-1001-152	200B
DS3, DS4	318-630-1001-166	205B
DS5	318-630-1002-036	210B
J6	138-102	180
J6	SCN001	180A
L1, L2	319-619-1001-014	200
L1, L2	318-630-1001-014	200A
L3, L4	319-619-1001-021	205
L3, L4	318-630-1001-020	205A
L5	319-619-1002-008	210
L5	318-630-1002-008	210A
L6	138-102	180
L6	SCN001	180A
P1	582557-1	105
P2, P3	582553-1	110
P4	BACC45FN22-55P	50
P5	BACC45FN22-55P6	55
R1, R2	RE70GF1001	140
R3	RH5-330-1PCT	195
R3	3105M330-1PCT	195A
R3	RH5-510-3PCT	195B
R3	3105M510-3PCT	195C
S1, S2	MS24524-26	160
S3	A3-127T7	165
S3	64AT11-3	165A
S3	4PB11T-2	170
S4	MS24524-21	220
XA1	582557-1	105
XA3	582553-1	110A

OVERHAUL MANUAL

VENDORS

V00213 NYTRONICS COMPONENTS GROUP INC., SUBSIDIARY OF NYTRONICS INC.,
ORANGE STREET, DARLINGTON, SOUTH CAROLINA 29532

V00779 AMP INC., P.O. BOX 3608, HARRISBURG, PENNSYLVANIA 17105

V05617 BELL INDUSTRIES INC., FARWEST MFG DIV., 18225 NE 76TH ST.,
REDMOND, WA 98052

V72914 MIDLAND-ROSS CORP., GRIMES DIV., 550 STATE ROUTE 55 CHAMPAIGN,
URBANA, OHIO 43078

V81590 KORRY ELECTRONICS INCORPORATED, SUBDIVISION OF CRITON CORPORATION,
901 DEXTER AVENUE NORTH, SEATTLE, WASHINGTON 98109

V81640 EATON CORP., AEROSPACE CONTROL/SYSTEM DIV., MANATEE PLANT, 2074
WHITFIELD AVE., E. P.O. BOX 1978, SARASOTA, FLORIDA 34243

V91637 DALE ELECTRONICS INC., P.O. BOX 609, COLUMBUS, NEBRASKA 68601

V91929 HONEYWELL INC., MICRO SWITCH DIV., 11 W. SPRING STREET, FREEPORT,
ILLINOIS 61032

V95354 METHODE MFG. CORP., 1700 SOUTH HICKS ROAD, ROLLING MEADOWS,
ILLINOIS 60008