



OVERHAUL MANUAL

TO: ALL HOLDERS OF LANDING GEAR ACCESSORY UNIT ASSEMBLY M338 OVERHAUL MANUAL, 32-66-40

REVISION NO. 18, DATED SEP 1/97

HIGHLIGHTS

| DESCRIPTION OF CHANGE   | TOPICS AFFECTED |             |                 |                 |             |         |       |         |                     |               |               |       |                     |
|---|-----------------|-------------|-----------------|-----------------|-------------|---------|-------|---------|---------------------|---------------|---------------|-------|---------------------|
|   | D & O           | D / A s s y | C l e a n i n g | I n s p / C h k | R e p a i r | A s s y | F / C | T e s t | T / S h o o t i n g | S / T o o l s | S t o r a g e | I P L | L / O v e r h a u l |
| <p>Added optional test for antiskid test, paragraph 2.R.</p> <p>Renumbered paragraph 2.S. to V.</p> <p>Updated vendors list</p> |                 |             |                 |                 |             |         |       | X       |                     |               |               | X     |                     |



OVERHAUL MANUAL

# LANDING GEAR ACCESSORY UNIT ASSEMBLY M338

## 32-66-40

BOEING P/N 65-52811-21, 23, -25, -30, -31, -44, -51, -54, -73 thru -77,  
-84, -85, -117 thru -121, -135, -137, -144 thru 148, -151

AIRLINE P/N

THE FOLLOWING DIRECTIVES APPLY TO THIS SUBJECT:

| BOEING SERVICE BULLETIN | BOEING TEMPORARY REVISION | OTHER DIRECTIVES | DATE DIRECTIVE INCORPORATED INTO TEXT |
|-------------------------|---------------------------|------------------|---------------------------------------|
|                         |                           | MC 3010-8        | May 15/68                             |
|                         |                           | PRR 30042-1      | May 15/68                             |
|                         |                           | PRR 30042-3      | May 15/68                             |
| 24-1001                 |                           | PRR 30202        | May 15/68                             |
|                         |                           | PRR 30319        | May 15/68                             |
|                         |                           | PRR 30503        | May 15/68                             |
|                         |                           | PRR 30940        | May 15/68                             |
|                         |                           | PRR 31550        | Aug 15/69                             |
|                         |                           | PRR 31611        | Aug 15/69                             |
| 21-1030                 |                           |                  | Sep 10/70                             |
| 78-1005, Rev 1          |                           | PRR 31030K       | Sep 10/70                             |
| 32-1093, Rev 2          |                           | PRR 32675        | Jan 5/80                              |
|                         |                           | MR 39121-26      | Jan 5/82                              |
| 27-1114, Rev 2          | 32-6                      | PRR 33143        | Dec 5/83                              |

**OVERHAUL MANUAL**

LIST OF EFFECTIVE PAGES

\* Indicates pages revised, added or deleted in latest revision  
F Indicates foldout pages - print one side only

| PAGE     | DATE      | PAGE   | DATE     | PAGE   | DATE     |
|----------|-----------|--------|----------|--------|----------|
| 32-66-40 |           | 711    | Jun 5/92 | 1104   | Dec 5/85 |
| T-1      | Dec 5/85  | 712    | Dec 5/83 | 1105   | Mar 5/90 |
| T-2      | BLANK     | 713    | Dec 5/83 | 1106   | Mar 5/90 |
| * LEP-1  | Sep 1/97  | 714    | Dec 5/85 | 1107   | Dec 5/85 |
| LEP-2    | BLANK     | 715    | Jun 5/92 | 1108   | Dec 5/85 |
| T/C-1    | Dec 5/83  | 716    | Jun 5/92 | 1108A  | Dec 5/85 |
| T/C-2    | BLANK     | 717    | Jun 5/92 | 1108B  | BLANK    |
| 1        | Jul 5/79  | 718    | Sep 5/88 | 1109   | Dec 5/85 |
| 2        | Nov 10/69 | 719    | Dec 5/85 | 1110   | Mar 5/90 |
| 3        | Nov 10/69 | 720    | Dec 5/85 | 1111   | Dec 5/83 |
| 4        | Nov 10/69 | 721    | Mar 5/89 | * 1112 | Sep 1/97 |
| 5        | Dec 5/85  | 722    | Dec 5/85 |        |          |
| 6        | Dec 5/85  | 723    | Dec 5/85 |        |          |
| 7        | Nov 10/69 | 724    | Dec 5/83 |        |          |
| 8        | Nov 10/69 | 725    | Dec 5/85 |        |          |
| 9        | Nov 10/69 | 726    | Dec 5/83 |        |          |
| 10       | Nov 10/69 | * 727  | Sep 1/97 |        |          |
| 11       | Nov 10/69 | * 728  | Sep 1/97 |        |          |
| 12       | Dec 5/85  | 801    | Dec 5/85 |        |          |
| 13       | Nov 10/69 | 802    | Dec 5/85 |        |          |
| 14       | Nov 10/69 | 803    | Dec 5/83 |        |          |
| 15       | Jan 5/82  | 804    | BLANK    |        |          |
| 16       | Dec 5/85  | 805    | BLANK    |        |          |
| 16A      | Jan 5/82  | F 806  | Dec 5/85 |        |          |
| 16B      | BLANK     | F 807  | Dec 5/85 |        |          |
| F 16C    | Dec 5/85  | 808    | BLANK    |        |          |
| 16D      | BLANK     | F 808A | Dec 5/83 |        |          |
| F 17     | Dec 5/85  | 808B   | BLANK    |        |          |
| 18       | BLANK     | 808C   | Dec 5/85 |        |          |
| 18A      | Jan 5/82  | 808D   | BLANK    |        |          |
| 18B      | Dec 5/83  | 809    | BLANK    |        |          |
| 19       | Nov 10/69 | F 810  | Sep 5/88 |        |          |
| 20       | Jul 5/79  | F 811  | Dec 5/85 |        |          |
| 401      | Dec 5/85  | 812    | BLANK    |        |          |
| 402      | BLANK     | F 812A | Dec 5/83 |        |          |
| 701      | Dec 5/85  | 812B   | BLANK    |        |          |
| * 702    | Sep 1/97  | 813    | BLANK    |        |          |
| * 703    | Sep 1/97  | F 814  | Dec 5/83 |        |          |
| 704      | Dec 5/83  | F 815  | Dec 5/83 |        |          |
| 705      | Dec 5/85  | 816    | BLANK    |        |          |
| 706      | Dec 5/85  | F 817  | Dec 5/83 |        |          |
| 707      | Dec 5/85  | 818    | BLANK    |        |          |
| * 708    | Sep 1/97  | 1101   | Mar 5/85 |        |          |
| 709      | Dec 5/85  | 1102   | Dec 5/83 |        |          |
| 710      | Jun 5/85  | 1103   | Dec 5/83 |        |          |



OVERHAUL MANUAL

TABLE OF CONTENTS

| <u>Paragraph Title</u>                          | <u>Page</u> |
|---|-------------|
| Description and Operation . . . . .             | 1           |
| Disassembly . . . . .                           | *[1]        |
| Cleaning. . . . .                               | *[1]        |
| Inspection/Check. . . . .                       | *[1]        |
| Repair. . . . .                                 | 401         |
| Assembly. . . . .                               | *[2]        |
| Fits and Clearances (not applicable)            |             |
| Testing . . . . .                               | 701         |
| Trouble Shooting. . . . .                       | 801         |
| Storage Instructions. . . . .                   | *[1]        |
| Special Tools, Fixtures, and Equipment. . . . . | *[1]        |
| Illustrated Parts List. . . . .                 | 1101        |

- | \*[1] Use applicable overhaul procedures in 20-11-05 and standard industry practices.
- \*[2] Special instructions not required.

**BOEING**   
**COMMERCIAL JET**  
**OVERHAUL MANUAL**

LANDING GEAR ACCESSORY UNIT ASSEMBLY (M338)

Figure 1 - Deleted

DESCRIPTION AND OPERATION

1. Description

- A. The landing gear accessory unit assembly consists of control and safety relays, solid-state circuits, and related wiring and connectors mounted in a chassis assembly. The accessory unit assembly includes air and ground sensing indicators and test switches.

2. Operation

- A. The landing gear accessory unit assembly receives signals from proximity sensors on the landing gear. These signals are transmitted to solid-state switching circuits in the accessory unit assembly to control the relays. The relays provide the required control and indication of the landing gear. The air and ground sensing indicators and test switches are used to check for malfunction in the accessory unit assembly and to isolate the safety relays for airplane maintenance purposes.

**BOEING**   
**COMMERCIAL JET**  
**OVERHAUL MANUAL**

65-52811

B. The assembly controls and monitors the following systems.

- (1) Safety Relay System (squat switches)
- (2) Landing Gear Wheel Seal System
- (3) Landing Gear Warning System
- (4) Automatic Ground Speed Brake System
- (5) Takeoff Warning System

3. Functional Description (See Schematic Diagram.)

A. The safety relay system (squat switches) consists of the air safety relays and the ground safety relays.


- (1) The air safety relay system consists of normally open proximity switch A1, relays K3 and K5, test switch S1, test indicator L1, and an external proximity sensor S106. The air safety relays provide the functions listed in figure 2 to the ground critical systems.

| Ground Critical Systems    | Air Mode   | Ground Mode   |
|----------------------------|--|---|
| 1. Drain mast heater       | Switches the heater from 28-volt to 115-volt power source to provide higher heating of the drain mast. | Switches the heater from 115-volt to 28-volt power source to reduce heating of the drain mast.                          |
| 2. Stall Warning           | Arms the stall warning system.   | Deactivates the stall warning system.   |
| 3. Antiskid System         | Prevents inboard brake application by actuating the antiskid control valves to the full dump position. | Deactivates the antiskid touchdown protection circuit and allows normal braking application.                            |
| 4. APU Fire Detection Horn | Deactivates the APU wheel well fire warning horn circuit.  | Arms the APU wheel well fire warning horn circuit.  |
| 5. Landing Gear Latch      | Energizes the lever latch solenoid to enable the landing gear retraction without override.             | De-energizes the landing gear lever latch solenoid to prevent the landing gear handle from operated to the up position. |

Air Safety Relay Functions  
Figure 2

**BOEING**   
**COMMERCIAL JET**  
**OVERHAUL MANUAL**

Sensor S106 and switch A1 are connected at pins B35 and B36 and form a bridge circuit. S106 appears as an inductance to A1. (See Manufacturer's Overhaul Manual for details.) S106 is located in the right main landing gear wheel well and will actuate A1 when the landing gear oleo is extended. Twenty-eight volt dc circuit power is provided at pin A33. Circuit ground is at pin A17. (See figure 3.)



▷ EFFECTIVE FOR AIRPLANES WITH DUAL STALL WARNING SYSTEM ONLY

Air Safety Relays  
Figure 3

- (a) K3 and K5 are energized when A1 is actuated and provides a ground path for the relay coils. K3 and K5 provide the switching to activate (or deactivate) the circuits indicated in figure 2.
- (b) The relays can be tested while the airplane is on the ground by pressing S1. This actuates A1 and simulates air mode. L1 will illuminate while S1 is depressed.

**BOEING**   
**COMMERCIAL JET**  
**OVERHAUL MANUAL**

65-52811

- (2) The ground safety relays system consists of normally open proximity switch A2, relays K1, K2, K4, K7 and K8, test switch S2, test indicator L2, and an external proximity sensor (S105). The ground safety relays provide the functions indicated in figure 4 to the air critical systems.

| Air Critical System   | Ground Mode  | Air Mode  |
|---|--|---|
| 1. Pressurization Control   | Deactivates the pressurization control circuit         | Activates the automatic control circuit to maintain cabin pressurization when airplane is in the air. |
| 2. Wing Anti-Ice  | Prevents hot air from entering anti-ice duct           | Permits hot air entering anti-ice duct.   |
| 3. Stall Warning  | Deactivates the stall warning system                   | Activates the stall warning system.   |
| 4. Turbofans  | Opens turbofan valves                                  | Closes turbofan valves.   |
| 5. Flight Recorder  | Deactivates flight recorder                            | Activates flight recorder.  |
| 6. Comparator-NAV (when installed)  | Prevents a NAV warning                                 | Permits a NAV warning.  |
| 7. Static Inverter  | Prevents automatic operation of the static inverter    | Permits automatic operation of the static inverter.   |
| 8. Engine gravel protection   | Activates gravel protection valve                      | Deactivates gravel protection valve.  |
| 9. Thrust Reversal Flap Retraction  | Activates thrust reversal flap retract valve "By-pass" | Activates thrust reversal flap retract valve "Normal"   |
| 10. Thrust Reversers  | Deactivates thrust reverser disarming circuits         | Activates thrust reverser disarming circuits.   |
| <p>The ground safety relays when activated by the parking brake switch provide the following functions to the air critical systems:</p> |  |   |



OVERHAUL MANUAL


| Air Critical System             | Ground Mode and Parking Brake Set                | Air Mode or Parking Brake NOT Set   |
|---------------------------------|--|---|
| 1. Hydraulic Interconnect Valve | Permits hydraulic system interconnection         | Automatically closes the hydraulic interconnect valve to isolate the A and B hydraulic systems. |
| 2. Voice Recorder               | Permits the erasure of recorder tape             | Deactivates the voice recorder erasure circuit.   |
| 3. Main Cargo Door Control      | Permits cargo door operation                     | Deactivates the cargo door control circuit.   |
| 4. Antiskid System              | Permits antiskid trouble shooting isolation test | Removes antiskid system tests electrical power.   |

Ground Safety Relay Functions  
Figure 4 (Sheet 2)

Sensor S105 and switch A2 are connected at pins A-1 and A-2. S105 is in the right main gear wheel well and will actuate A2 when the landing gear oleo is compressed. Twenty-eight volt dc circuit power is provided at pin A-33. Circuit ground is at pins A-29. In addition, when the parking brake switch is set, 28 volts dc is applied at pin B-17. (See Fig. 5.)

- (a) K1, K2, and K8 are energized when A2 is actuated. (K8 used on 65-52811-21, -51, -54, -73, -117, -135, -137, -144 is a two-coil relay. See paragraph 3.A.(2)(b). K4 will energize when the parking brake switch is set and A2 is actuated. K7 will energize when the parking brake switch is set and K3 is not energized.
- (b) K8 on 65-52811-21, -51, -54, -73, -117, -135, -137, -144 is a two-coil relay energized by A1 or A2. When one coil has been energized and de-energized, the other coil must be energized to switch contacts.
- (c) Relays K1, K2, K4, and K8 (except K8 on 65-52811-21, -51, -54, -73, -117, -135, -137, -144) can be tested while the airplane is on the ground by pressing S2. This deactuates A2 and simulates air mode (or brake switch not set). L2 will remain lit while S2 is depressed.

OVERHAUL MANUAL



- NOTE:  
DIODES CR2 THRU  
CR6 ARE IN4385
- 1 ▷ RELAYS K1, K2 AND K8 SHOWN IN ENERGIZED POSITION:  
SWITCH A2 SHOWN ACTUATED
  - 2 ▷ EFFECTIVE FOR AIRPLANES WITH  
DUAL STALL WARNING SYSTEM ONLY
  - 3 ▷ EFFECTIVE FOR CARGO AIRPLANES ONLY
  - 4 ▷ EFFECTIVE FOR  
TARGET-TYPE ONLY
  - 5 ▷ 65-52811-21,-51,-54,-73,-117,-135,-137,  
-144 ONLY USES TWO-COIL RELAY (K8)


Ground Safety and Parking Brake Relays  
Figure 5

**BOEING**   
**COMMERCIAL JET**  
**OVERHAUL MANUAL**

- B. The wheel seal system consists of logic card A10, relay K6, proximity switches A3, A4, A7 and A8 and their associated external sensors, external switches, valves, and a lamp. Twenty-eight volt dc power is applied through K6 to energize external seal control valves (deflate seals), or removed to de-energize the valve (inflate seals). Twenty-eight volt dc circuit power is applied at pin B48. Circuit grounds are at pins A7 and A30. (See figure 6 schematic and figure 7 logic diagram.)
- (1) Power is available to K6 coil and contacts from J10 pin 2. When a ground path is available at pins B7, or B47 or through A10Q1 and A10Q2, K6 is energized and provides power to the seal control valves at pin B2. Pins B7 and B47 are connected to ground through external switches.
  - (2) A10Q1 and A10Q2 are connected in series with A10Q2 emitter connected to ground at pin A7. Twenty-eight volts dc is applied at J10 pin 4 to provide base voltage for the transistors. With the transistors on, the ground path for K6 is available.
  - (3) Ground through transistors A10Q1 and A10Q2 can be removed by either of the following:
    - (a) Removal of A10Q1 base voltage when the following conditions exist:
      - 1) Landing gear lever switch S265 in up or neutral position to ground pin B6.
      - 2) Left main gear in up and locked position to actuate A4 and ground J10 pin 18.
      - 3) Right main gear in up and locked position to actuate A8 and ground J10 pin 16.
    - (b) Removal of A10Q2 base voltage when the following conditions exist:
      - 1) Left main gear in down and locked position to actuate A7 and ground J10 pin 14.
      - 2) Right main gear in down and locked position to actuate A3 and ground J10 pin 14.

**BOEING**  
**COMMERCIAL JET**  
**OVERHAUL MANUAL**


65-52811




NOTE:  
A3, A4, A7 & A8 ARE 10-61226 SWITCHES  
DIODES CR1 THRU CR8, CR11 AND CR14 ARE 1N4385  
UNLESS OTHERWISE SPECIFIED ALL RESISTANCES ARE IN OHMS ±5%

Wheel Seal System  
Figure 6

**BOEING**   
**COMMERCIAL JET**  
**OVERHAUL MANUAL**




Wheel Seal Deflation Logic Diagram  
 Figure 7



Red Indicator Lamp "ON" Logic Diagram  
 Figure 8

- C. The landing gear warning system consists of logic cards A11 and A12, proximity switches A3 through A8 and their associated external proximity sensors, and external indicator lamps and switches. The system provides green lamp indications when the landing gears are down and locked. Also, it provides red lamp indications indicating unsafe conditions (see figure 8) when:
- (1) The landing gear is in transit.
  - (2) The landing gear position and the landing gear control lever are not in agreement.
  - (3) The engine throttles are retarded to the idle range and the landing gear is not down and locked.
- D. Since the lamp indication circuits are the same, only the right main gear circuit will be explained. (See figure 9.) Circuit power (Q1, Q2 base drive) is provided at pin A33 (J11 pin 12). Circuit grounds are at pin A30 and pin A55 (J11 pin 2).
- (1) A ground path will be provided at pin A41 to turn on the green lamp when normally-open proximity switch A7 is actuated. A7 is connected to an external proximity sensor. When the landing gear is down and locked, the sensor will actuate A7.
  - (2) A ground path will be provided for the red lamp at pin A42 when either of the following conditions exist:
    - (a) AllQ1 will provide ground when:
      - 1) The landing gear lever is not down (open circuit to pin A35) and:
      - 2) The landing gear is not in the up and locked position (normally-open proximity switch A8 not actuated).
    - (b) AllQ2 will provide ground when the landing gear is not in the down and locked position (normally-open proximity switch A7 is not actuated) and one of the following occur:
      - 1) The landing gear lever is down (ground to pin A35).
      - 2) Engine No. 1 throttle is retarded (ground to pin A52).
      - 3) Engine No. 2 throttle is retarded (ground to pin A51).
- E. The landing gear aural warning system consists of logic card A9, load card A13, normally-open proximity switches and associated landing gear position sensors, and external switches and a horn. Figure 10, sheet 1,

**BOEING**  
**COMMERCIAL JET**  
**OVERHAUL MANUAL**



NOTE:  
 UNLESS OTHERWISE SPECIFIED  
 ALL RESISTANCES ARE IN OHMS ± 5%  
 ALL DIODES ARE IN4385

## OVERHAUL MANUAL

illustrates aural warning circuitry for assemblies 65-52811-21, -23, -30, -44, -51, -54, -73, -74, -76, -84, -85, -117, -118, -120, -135, -137, -144, -145, -147, -151. Figure 10, Sheet 2, illustrates aural warning circuitry for assemblies 65-52811-25, -31, -75, -77, -119, -121, -146, -148. The module will provide a ground path for the horn when unsafe conditions exist. Circuit power, +28 volts dc, is applied at pin A-33 (pin B-51 for 65-52811-25, -31, -75, -77, -119, -121, -146, -148). (See Fig. 11 for logic diagram.)


- (1) When one or more of the landing gears are not down and locked (proximity switches not actuated) and the flaps are not up, base voltage is available to A9Q1. A9Q1 will conduct and provide a ground path for the horn when one of the following conditions exist:
  - (a) The flaps are extended beyond 25-handle units (and for airplanes with 25-degree flap takeoff capability, both engine pressure ratios are below 1.55 or the flaps are extended beyond 30 degrees). This provides ground at pin A49 and allows A9Q1 to conduct.
  - (b) Either engine is retarded to idle. This provides a ground at pins A-51 and A-52 and allows A9Q2 or A9Q3 to conduct.
    - 1) In this condition, depressing the horn reset switch provides a positive voltage to the gate of SCR's to turn off A9Q2 and A9Q3 by grounding their base. Advancing either will reset one SCR to again enable the horn circuit.

F. The automatic ground speed brake system actuates the ground and flight spoilers to aid braking after touchdown (Fig. 12). The system consists of logic card A14, relays K9 thru K13, and external switches, lamps and modules. The landing gear module controls the automatic mode of operation of the spoilers when the system is armed. It will provide voltage to cause the spoilers to be raised (pin B-13) or lowered (pin B-5) and provide ground to cause indicator lamps L441 (pin A-34) or L442 (pin A-18) to illuminate. When either lamp is illuminated, the other must be extinguished. Circuit power (system armed) is provided at pin A-56 (and pin B-3 on 65-52811-117 thru -121, -137, -144 thru -148). Pins A-7 and A-67 are circuit grounds.

- (1) When the speed brake control lever is set to the ARMED position, 28 volts dc is provided to pin 12 of circuit card A14 through pin A-56. This provides base voltage for Q1 through R1, for Q2 through CR11 and CR9/CR7, and for Q3 through CR5. When Q1 is on, L442 (DO NOT ARM) is illuminated. When Q2 is on, L441 (ARMED) is illuminated, and at the same time Q1 is turned off by shunting its base voltage to ground. When Q3 is on, base voltage to Q2 received through CR9 or CR7 is shunted to ground.




**BOEING**  
**COMMERCIAL JET**  
**OVERHAUL MANUAL**




APPLICABLE TO AIRPLANES WITH 25° FLAP TAKEOFF CAPABILITY ONLY

NOTE: UNLESS OTHERWISE SPECIFIED  
RESISTANCE = OHMS (5%)  
CAPACITANCE = UF (10%)  
DIODES ARE 1N4385

Landing Gear Aural System (FAA Certified only)  
Figure 10 (Sheet 1 of 2)



Landing Gear Aural System (FAA Certified only)  
 Figure 10 (Sheet 2 of 2)




## OVERHAUL MANUAL

- (2) At the time the speed brake control lever is set to ARMED, if both inboard and outboard antiskid systems are inoperative, Q2 base voltage is shunted to ground through CR8 and CR10. Q2 will be off, Q1 will be on, and the DO NOT ARM indicator will be illuminated.
- (3) Presuming antiskid systems operative, and control lever set to ARMED, the 28-volt dc input to pin A-56 (and B-3 on 65-52811-117 thru -121, -137, -144 thru -148) can be passed through two of relays K9, K10, K11, or K12 provided main landing gear speeds have reached 60 knots. Wheel speed inputs from the antiskid control system energize the wheel speed relays individually. Sixty knots on both outboard wheels, both inboard wheels, or both wheels on one side, is the minimum combination required to energize two relays such that 28 volts dc is passed through pin B-13 to the raise coils of the handle actuator (M359). The handle will be driven to the raise position. The lower limit switch shunts A14-Q3 base voltage (received through R4) to ground. As the handle departs the lower limit, the shunt is removed. However, the combination of relays that provided power to the raise windings also passes 28 volts dc to pin 4 of card A14. This holds Q2 on, L441 (ARMED) illuminated even though Q3 is turned on. On 65-52811-51, -54, -137, the combination of K9, K10, K11, and K12 relays also passes 28 volts dc from pin B-46 to the automatic brake control module (M577) autobrake output relay.
- (4) On 65-52811-51, -54, -135, -137, a ground input to the automatic brake control module (M577) wheel speed relay is provided at pin A-55 until all four wheels reach 60 knots (K9, K10, K11, and K12 all energized). When any wheel speed reaches 60 knots (any of the four relays energized) a ground output to the M577 wheel speed relay is provided at B-7.
- (5) When either throttle is advanced to the 25-degree position, K13 coil is grounded, K13 is energized, and 28 volts dc is provided through pin B-5 to lower the handle actuator.
- (6) The following are self-check test circuits that simulate the system operation (control in ARMED position).
  - (a) Test circuit 1 simulates K9 or K10. Twenty-eight volts is applied at pin A-58 (J14 pin 3) to remove the ground path at pin A-34 (J14 pin 11).
  - (b) Test circuit 2 simulates K11 or K12. J14 pin 5 is grounded through a 150-ohm resistor at pin A-60. This removes the ground path at pin A-34 (J14 pin 11).
  - (c) Test circuit 3 simulates engine throttle advance. It grounds pin B-4 to actuate K13. Also, it applies 28 volts dc from pin A-60, through K13 to J14 pin 6. This removes the ground path at pin A-34 (J14 pin 11).

**BOEING**   
**COMMERCIAL JET**  
**OVERHAUL MANUAL**


- G. The takeoff aural warning system (figures 13 and 14) consists of logic card A12, relay K3, external switches and the M315 aural warning module (which contains the horn). The landing gear module provides a ground path to M315 when an unsafe flight control condition exists prior to takeoff. The intermittent horn will operate and will not turn off until the condition is corrected. Twenty-eight volt dc circuit power is applied at pin A33. Circuit ground is at pin A30. The ground to M315 to operate the horn is available at pin A22 when the following conditions exist.
- (1) Airplane is on ground (K3 de-energized). This removes the ground at pin A17 (A12Q2 base) and:
  - (2) Either engine throttle is in the advanced position. This grounds pin B4 (A12Q1 base) and prevents A12Q1 from conducting, and:
  - (3) Pin A23 is grounded (A12Q2 emitter) due to any of the following conditions:
    - (a) Stabilizer set too high or too low, or:
    - (b) Flaps extended too far, or
    - (c) Speed brake lever not in proper position.



65-52811-21, -23, -25, -30, -44, -51, -54, -73 THRU -77, -84, -85


- 1 CR3 ON 65-52811-23, -30, -44, -74, -75, -84, -85
- 2 65-52811-21, -25, -51, -54, -73, -75, -77
- 3 65-52811-23, -30, -44, -74, -76, -84, -85

**BOEING**  
**COMMERCIAL JET**  
**OVERHAUL MANUAL**




65-52811-117 THRU -121, -135, -137, -144, THRU -148, -151


- 1 CR3 ON 65-52811-118, -120, -145, -147, -151
- 2 65-52811-117, -119, -121, -135, -137, -144, -146, -148
- 3 65-52811-118, -120, -145, -147, -151







OVERHAUL MANUAL





 25 ± 2% TO FULL ADVANCE

NOTE:  
 UNLESS OTHERWISE SPECIFIED  
 ALL RESISTANCES ARE IN OHMS ± 5%  
 DIODES CR5, CR7 AND CR9 ARE 1N4385



Takeoff Warning System Logic Diagram  
Figure 14

4. Deleted



OVERHAUL MANUAL

REPAIR

1. Repair

- A. Repair can be accomplished using applicable instructions in 20-11-05 and standard industry practices, except as noted below.
- B. If keying plugs (55, Fig. 1101) require replacement, install in connectors as indicated in Fig. 401.

| Connector          | Position     |
|--------------------|--------------|
| J1, J2, J4, J5, J8 | 10-L         |
| J3, J7*[1]         | 10-L         |
| J3, J7*[2]         | 2-B          |
| J6                 | 2-B          |
| J9                 | 23-24, 25-26 |
| J10                | 5-6, 11-12   |
| J11                | 8-J, 9-K     |
| J12                | 15-16, 17-18 |
| J13                | 3-C, 12-N    |
| J14                | 8-J, 13-P    |

\*[1] 65-52811-21, -23, -25, -30, -31, -51, -54, -117 thru -121, -135, -137

\*[2] 65-52811-44, -73 thru -77, -84, -85, -144 thru -148, -151

Keying Plug Installation  
Figure 401

- C. When installing relay K8 (65-52811-21, -51, -54, -73, -117, -135, -137, -144), orient with contrasting bead at pin 2 of socket.

TESTING

1. Test Equipment

A. Power Supplies:

- (1)  $28 \pm 1$  vdc, 1 amp
- (2)  $28 \pm 1$  vac,  $400 \pm 5$  Hz

B. Multimeter:

- (1) Simpson 260P or equivalent

C. Oscilloscope:

- (1) Tektronix 475 or equivalent

D. Test Lamps:

- (1) 28 vdc, 100 ma (1820 or equivalent) (9 required) (L1-L7, L10, L11)
- (2) 28 vdc, 40 ma (327,387,1819 or equivalent) (2 required) (L8, L9)
- (3) 28 vdc, 500 ma (three 313 or 1821 lamps in parallel or equivalent) (L12)

E. Test Sensors:

- (1) ELDEC P/N 1-899-3 \*[1] (Boeing 10-61226-3)(10-61226-2 optional)  
(4 required) (S72, S74, S105, S106) (65-52811-21, -51, -54, -73,  
-117, -135, -137, -144 only)
- (2) ELDEC P/N 1-899-3 \*[1] (Boeing 10-61226-3) (2 required) (S71,  
S73) (65-52811-21, -51, -54, -117, -135, -137 only)

F. Test Gage \*[2]:

- (1) ELDEC P/N 8-005100-1 \*[1]

G. Actuating Slug \*[2]: Hi-Mu 80 or Permalloy steel

- (1) 1.20 x 0.50 x 0.05  $\pm 0.01$  inches (4 required) (65-52811-21, -51,  
-54, -73, -117, -135, -137, -144 only)
- (2) 1.20 x 0.50 x 0.05  $\pm 0.01$  inches (2 required) (65-52811-21, -51,  
-54, -117, -135, -137, only)

H. Plexiglass spacer \*[2]:

- (1) 2 x 3 x 0.150 +0/-0.01 inches (4 required) (65-52811-21, -51, -54, -73, -117, -135, -137, -144 only)
- (2) 2 x 3 x 0.150 +0/-0.01 inches (2 required) (65-52811-21, -51, -54, -117, -135, -137 only)
- (3) 2 x 3 x 0.250 +0.01/-0 inches (4 required) (65-52811-21, -51, -54, -73, -117, -135, -137, -144 only)
- (4) 2 x 3 x 0.250 +0.01/-0 inches (2 required) (65-52811-21, -51, -54, -117, -135, -137 only)

I. Switches:

- (1) SPST
  - (a) 22 required (S1-S16, S18, S20, S23, S26, S75, S76)
  - (b) 1 required (S24) (65-52811-25, -31, -75, -77, -119, -121, -146, -148 only)
  - (c) 1 required (S25) (65-52811-117 thru -121, -137, -144 thru -148 only)
  - (d) 2 required (S71, S73) (65-52811-23, -25, -30, -31, -44, -73 thru -77, -84, -85, -118 thru -121, -144 thru -148, -151 only)
  - (e) 4 required (S72, S74, S105, S106) (65-52811-23, -25, -30, -31, -44, -74 thru -77, -84, -85, -118 thru -121, -145 thru -148, -151 only)
- (2) SPDT 3-position (2 required) (S17, S22)
- (3) Pushbutton, normally open (S21)

J. Banana Jacks and Plugs:

- (1) Jacks
  - (a) Dual
    - 1) 2 required (J75, J76)
    - 2) 2 required (J71, J73) (65-52811-23, -25, -30, -31, -44, -73 thru -77, -84, -85, -118 thru -121, -144 thru -148, -151 only)
    - 3) 4 required (J72, J74, J105, J106) (65-52811-23, -25, -30, -31, -44, -74 thru -77, -84, -85, -118 thru -121, -145 thru -148, -151 only)
  - (b) Single (J23)

J. (Continued)

(2) Plugs (used with centerpoint sensor)

(a) Dual

(b) Single

K. Resistors:

(1) 8.2K, 10PCT, 1W (2 required) (R5, R6)

(2) 8.2K, 10PCT, 1W (2 required) (R3, R7) (65-52811-23, -25, -30, -31, -44, -73 thru -77, -84, -85, -118 thru -121, -144 thru -148, -151 only)

(3) 8.2K, 10PCT, 1W (4 required) (R1, R2, R4, R8) (65-52811-23, -25, -30, -31, -44, -74 thru -77, -84, -85, -118 thru -121, -145 thru -148, -151 only)

(4) 1K, 10 pct, 1w (R10)

L. Calibration Test (Dial) Stand (including 1.2" x 0.5" x 0.05" target and dial indicator):

(1) ELDEC P/N 3-455-16 \*[1]

M. Centerpoint Sensor Kit (including 1-899-15CP02 centerpoint sensor):

(1) ELDEC P/N 1-899-15CP01 \*[1]

N. Connector (with pigtail lead):

(1) DPX2MB67S67S33B0000 \*[3]

O. Diode: 1N4385 or equivalent.

\*[1] ELDEC Corp., 16700 13th Ave. West, P.O. Box 100, Lynnwood, Washington 98036

\*[2] Actuating slug and plexiglass spacer optional to test gage.

\*[3] International Telephone and Telegraph Corp., ITT Cannon Electric Div., 10550 Talbert Ave., P.O. Box 8040, Fountain Valley, California 92708.

**OVERHAUL MANUAL**

2. Functional Test

A. Using of Sensors in Testing

- (1) When sensor actuation is required, use zero gap between test slug and sensor.
- (2) When proximity switch tolerance test specified, use three-step procedure specified in Fig. 701 when using actuating slug and plexiglass spacers or steps 2 and 3 when using test gage with sensor actuating and non-actuating sides.

| Step | Procedure  |
|------|--|
| 1    | Use zero gap between slug and sensor. Test results shall indicate actuated sensor. If not actuated, suspect defective proximity switch.  |
| 2    | Use 0.250-inch plexiglass spacer between slug and sensor. Test results shall indicate deactuated sensor. If actuated, suspect defective proximity switch.  |
| 3    | Use 0.150-inch plexiglass spacer between slug and sensor. Test results shall indicate actuated sensor. If not actuated, suspect defective proximity switch, or extension of red and blue leads between connector and card crossed. |

NOTE: Tolerance vary with permeability of actuating slug. Those given are for Hi-Mu 80.

Proximity Switch Tolerance Selection  
Figure 701



OVERHAUL MANUAL

B. Verify continuity between pin-pairs listed in Fig. 702. Use position lead of multimeter on pin listed in from pin column.

| Component Tested | From Pin (+) | To Pin (-) | Component Tested | From Pin (+) | To Pin (-) |
|------------------|--------------|------------|------------------|--------------|------------|
| K2               | A-29         | A-9        | K5               | B-19         | A-17       |
|                  | A-29         | B-1        |                  | A-62         | A-63       |
|                  | A-16         | A-21       |                  | A-65         | A-66 *[2]  |
|                  | B-29         | B-23       |                  | B-21         | B-49 *[2]  |
| K1               | B-25         | B-32       | K3               | B-43         | A-17       |
|                  | A-26         | A-25       |                  | B-33         | B-28       |
|                  | A-29         | A-14       |                  | A-11         | A-12       |
|                  | A-29         | B-45       | K3/CR6 *[3]      | A-17         | B-17 *[4]  |
| K4               | A-19         | B-30       | K8 *[2]          | B-58         | B-56       |
|                  | A-31         | A-15       |                  | B-61         | B-60       |
|                  | B-8          | B-14       |                  | B-64         | B-63       |
|                  | B-11         | B-10       |                  | B-67         | B-66       |
| K7/R2            | B-15         | B-16*[1]   |                  |              |            |

\*[1] 4 to 6 ohms

\*[2] 65-52811-23, -25, -30, -31, -44, -74 thru -77 -84, -85, -118 thru -121, -145 thru -148, -151 only

\*[3] CR6 on 65-52811-21, -25, -31, -51, -54, -73, -75, -77, -117, -119, -121, -135, -137, -144, -146, -148

CR4 on 65-52811-23, -30, -44, -74, -76, -84, -85, -118, -120, -145, -147, -151

\*[4] 25 ohms max

Continuity Tests  
Figure 702

OVERHAUL MANUAL

C. Verify no continuity (50 K minimum) between pin-pairs per Fig. 703.  
Use positive lead of multimeter on pin listed in from pin column.

| Component Tested | From Pin (+) | To Pin (-) | Component Tested | From Pin (+) | To Pin (-) |           |
|------------------|--------------|------------|------------------|--------------|------------|-----------|
| K2               | A-6          | A-29       | K7               | B-18         | A-32       |           |
|                  | A-13         | A-29       |                  | K5           | A-61       | A-63      |
|                  | A-20         | A-21       |                  |              | B-64       | A-66 *[1] |
|                  | B-24         | B-29       |                  |              | B-20       | A-17      |
| K1               | A-27         | A-25       | B-22             |              | B-49 *[1]  |           |
|                  | A-57         | A-29       | K3               | A-10         | A-12       |           |
|                  | B-9          | A-29       |                  | B-27         | B-28       |           |
|                  | B-26         | B-32       | K3/S1            | B-44         | A-17       |           |
| K4               | A-28         | A-31       | K8 *[1]          | B-57         | B-56       |           |
|                  | B-12         | B-10       |                  | B-59         | B-61       |           |
|                  | B-31         | A-19       |                  | B-62         | B-64       |           |
|                  | B-34         | B-8        |                  | B-65         | B-67       |           |

\*[1] 65-52811-23, -25, -30, -31, -44, -74 thru -77, -84, -85, -118 thru -121, -145 thru -148, -151 only

No-Continuity Tests  
Figure 703

**BOEING**   
**COMMERCIAL JET**  
**OVERHAUL MANUAL**

- D. Verify  $1150 \pm 10\%$  between pins A-58 and A-60.
- E. Verify  $1000 \pm 25\%$  between pins A-59 and A-56.
- F. Connect test setup per Fig. 704. Turn on both power supplies.


NOTE: The centerpoint sensor leads are terminated in banana plugs. The red and blue leads are terminated in a dual banana plug such that they are inserted and removed as a pair. The yellow lead is terminated in a single banana plug which is inserted into the Y jack (J23) of the test setup, Fig. 704. It is important that the red lead connects to the red banana jack and that the blue lead connects to the blue banana jack throughout the entire test.

Figure 705 lists the functions simulated by the test setup. The reference designators are the same as the airplane reference designators for that function. The M reference designators are for the module within which a function occurs.

Reference Designators DS1 and DS2 are used in place of module indicators L1 and L2 for 65-52811-23, -30, -44, -54, -74, -76, -84, -85, -118, -120, -137, -145, -147, -151.

The test setup and module both have indicators L1 and L2, and switches S1 and S2. Consider all indicators and switches as part of test setup unless module indicators and switches are specifically listed.


OVERHAUL MANUAL



- 1 NOT APPLICABLE TO 65-52811-54,-137
- 2 65-52811-25,-31,-75,-77,-119,-121,-146,-148 ONLY
- 3 INTERCHANGE PINS 39 AND 40 WHEN TESTING  
65-52811-44,-73 THRU -77,-84,-144 THRU -148
- 4 65-52811-117 THRU -121,-137,-144 THRU -148 ONLY
- 5 65-52811-21,-51,-54,-73,-117,-135,-137,-144 ONLY

Test Setup  
Figure 704 (Sheet 1)

OVERHAUL MANUAL



**OVERHAUL MANUAL**

| Test Item     | Initial Condition | Aircraft Circuit Function               | Aircraft Ref Desig. |
|---------------|-------------------|---|---------------------|
| S1            | On                | Simulates Inboard Antiskid Inoperative  | M162F               |
| S2            | On (Beyond 25°)   | Flap Position Warning Switch            | S130                |
| S3            | Off (Not Down)    | Landing Gear Lever Switch               | S78                 |
| S4            | On (Down)         | Landing Warning Switch                  | S138                |
| S5            | On (Up)           | Flap Up Limit Switch                    | S245                |
| S6            | Off (Advanced)    | Engine No. 1 Throttle                   | S139                |
| S7            | Off (Advanced)    | Engine No. 2 Throttle                   | S140                |
| S8            | On                | Simulates Speed Brake Handle Actuator   | M359B               |
| S9            | On                | Simulates Outboard Antiskid Inoperative | M162E               |
| S10           | Off (Retard)      | Engine Throttle Switch                  | S133                |
| S11           | Off (Down)        | Landing Gear Lever Switch               | S265                |
| S12           | On (Door Open)    | Manual Extension Access Door Switch     | S264                |
| S13           | Off               | Simulates Left Outboard Wheelspeed      | M162C               |
| S14           | Off               | Simulates Left Inboard Wheelspeed       | M162A               |
| S15           | Off               | Simulates Right Inboard Wheelspeed      | M162D               |
| S16           | Off               | Simulates Right Outboard Wheelspeed     | M162B               |
| S17           | Position 2        | Simulates Speed Brake Handle Actuator   | M359A               |
| S20           | Off (Not Armed)   | Speed Brake Handle                      | S276                |
| S21           | Off               | Throttle Horn Reset                     | S77                 |
| S22           | Off               | Ground Spoiler Test Switch No. 2        | S315                |
| S23           | Off               | Ground Spoiler Test Switch No. 1        | S289                |
| S24*[1]       | On                | Simulates ARB Configuration             | M278A               |
| S25           | Off (Not Armed)   | Speed Brake Arming Warning Switch       | S276                |
| S26           | Off (Not Set)     | Parking Brake Switch                    | S100                |
| S106,J106*[3] | Deactuated(Off)   | Air Sensing Sensor                      | S106,J106           |
| S105,J105*[3] | Deactuated(Off)   | Ground Sensing Sensor                   | S105,J105           |
| S71,J71*[3]   | Deactuated(Off)   | Left Main Gear Downlock Sensor          | S71,J71             |
| S72,J72*[3]   | Deactuated(Off)   | Left Main Gear Uplock Sensor            | S72,J72             |
| S76,J76       | Deactuated(Off)   | Nose Gear Uplock Sensor                 | S76,J76             |
| S75,J75       | Deactuated(Off)   | Nose Gear Downlock Sensor               | S75,J75             |
| S73,J73*[3]   | Deactuated(Off)   | Right Main Gear Downlock Sensor         | S73,J73             |
| S74,J74*[3]   | Deactuated(Off)   | Right Main Gear Uplock Sensor           | S74,J74             |
| L1            | Illuminated       | Simulates Wheel Seal Valve              | V55                 |
| L2            | Illuminated       | Left Main Gear (Red)                    | L367                |
| L3            | Not Illuminated   | Left Main Gear Downlock (Green)         | L368                |
| L4            | Illuminated       | Nose Gear (Red)                         | L365                |
| L5            | Not Illuminated   | Nose Gear Downlock (Green)              | L366                |
| L6            | Illuminated       | Right Main Gear (Red)                   | L369                |
| L7            | Not Illuminated   | Right Main Gear Downlock (Green)        | L370                |
| L8            | Not Illuminated   | Simulates Continuous Horn               | M315B               |
| L9            | Not Illuminated   | Simulates Interrupted Horn              | M315A               |
| L10           | Not Illuminated   | Speed Brake Armed (Green)               | L441                |
| L11           | Not Illuminated   | Speed Brake Do Not Arm (Amber)          | L442                |
| L12           | Not Illuminated   | Simulates Speed Brake Handle Actuator   | M359                |

OVERHAUL MANUAL

- \*[1] 65-52811-25, -31, -75, -77, -119, -121, -146, -148 only
- \*[2] J72, J74, J105 and J106 on 65-52811-23, -25, -30, -31, -44, -74 thru -77, -84, -85, -118 thru -121, -145 thru -148, -151
- \*[3] J71 and J73 on 65-52811-23, -25, -30, -31, -44, -73 thru -77, -84, -85, -118 thru -121, -144 thru -148, -151

Item Simulated by Test Setup  
Figure 705 (Sheet 2)

- G. Set switches per initial conditions listed in Fig. 705. Verify initial condition for L1 thru L12.
- H. Verify module lamp L1 is extinguished and module lamp L2 is illuminated.
- I. Perform functional test per Fig. 706.

NOTE: (65-52811-21, -51, -54, -73, -117, -135, -137, -144 only). Use 3-step procedures listed in Fig. 701 to actuate or deactuate test sensors S105 and S106.  
(65-52811-23, -25, -30, -31, -44, -74 thru -77, -84, -85, -118 thru -121, -145 thru -148, 151 only). Module indicators L1 and L2 respond to the test centerpoint sensor as actuation is accomplished. Actuation shall occur as the target bar is brought within 0.275 to 0.325 inches from the sensor. The proximity switch card shall remain actuated as the gap is decreased to zero. Deactuation shall occur as the bar is moved away from the sensor 0.005 to 0.030 inches from the actuation point.

OVERHAUL MANUAL

| Step | Procedure   | Required Results   |
|------|---|--|
|      | <u>Air Sensing Squat Switch</u>   |  |
| 1    | Measure resistance between:<br>(K1,K2) A-9 to B-45<br>(K7,R2) B-15 to B-16<br>(K3,K5) B-19 to B-43<br>(K4) B-30 to A-19   | Con<br>4 to 6 ohms<br>Con<br>Con   |
| 2    | *[1] Connect deactuated sensor to test jack J106  |  |
| 3    | Set S26 to ON   |  |
| 4    | Measure resistance between:<br>(K7) B-18 to A-32<br>(K4) B-30 to A-19<br>(K7) B-16 to B-15  | Con<br>Con<br>No Con   |
| 5    | Press module switch S1, hold  | Module lamp L1 on  |
| 6    | Measure resistance between:<br>(K3,S1) B-44 to A-17   | No Con   |
| 7    | Release module switch S1  | Module lamp L1 off   |
| 8    | *[1] Actuate test sensor<br>*[2] Actuate sensor S106  | Module lamp L1 on<br>Module lamp L1 on   |
| 9    | Measure resistance between:<br>(K1,K2) A-9 to A-14<br>(K3) A-10 to A-12<br>(K5) A-61 to A-63<br>(K5) B-20 to A-17<br><br>(K7,R2) B-16 to B-15<br>*[1] (K5) A-64 to A-66<br>*[1] (K5) B-22 to B-49<br>(K3) B-27 to B-28<br>(K4) B-30 to A-19<br><br>(K3,S1) B-44 to A-17<br>*[2] (K8) B-56 to B-58<br>*[2] (K8) B-61 to B-60<br>*[2] (K8) B-64 to B-63<br>*[2] (K8) B-67 to B-66 | Con<br>Con<br>Con<br>Con<br><br>4 to 6 ohms<br>Con<br>Con<br>Con<br>Con<br>Con<br>Con<br>Con<br>Con<br>Con<br>Con<br>Con |
| 10   | Verify both module lamps L1 and L2 illuminated  |  |
| 11   | Measure resistance between:<br>(K3) A-11 to A-12<br>(K5) A-17 to B-19<br>(K5) A-62 to A-63  | No Con<br>No Con<br>No Con   |

Functional Test  
Figure 706 (Sheet 1)





OVERHAUL MANUAL

| Step | Procedure   | Required Results          |
|------|---|---------------------------|
|      | *[1] (K5) A-65 to A-66                              | No Con                    |
|      | *[1] (K5) B-21 to B-49                              | No Con                    |
|      | (K3) B-33 to B-28                                   | No Con                    |
|      | (K3) A-17 to B-43                                   | No Con                    |
|      | *[2] (K8) B-56 to B-57                              | No Con                    |
|      | *[2] (K8) B-61 to B-59                              | No Con                    |
|      | *[2] (K8) B-64 to B-62                              | No Con                    |
|      | *[2] (K8) B-67 to B-65                              | No Con                    |
| 12   | *[1] Deactuate test sensor                          | Module lamp L1 off        |
|      | *[2] Deactuate sensor S106                          | Module lamp L1 off        |
| 13   | *[1] Disconnect sensor from test<br>jack J106       |                           |
|      | <u>Take-Off Warning</u>                             |                           |
| 14   | Set S10 to ON                                       | L9 on                     |
| 15   | Measure voltage between:<br>(A12) A-22 to GND       | 1 vdc max                 |
| 16   | *[1] Set S106 to ON                                 | L9 off, module lamp L1 on |
|      | *[2] Actuate test sensor S106                       | L9 off, module lamp L1 on |
| 17   | *[1] Set S106 to OFF                                | L9 on, module lamp L1 off |
|      | *[2] Deactuate test sensor S106                     | L9 on, module lamp L1 off |
| 18   | Set S2 to OFF                                       | L9 off                    |
|      | <u>Ground Sensing Squat Switch</u>                  |                           |
| 19   | *[1] Connect deactuated sensor to test<br>jack J105 |                           |
| 20   | *[1] Actuate test sensor                            | Module lamp L2 off        |
|      | *[2] Actuate sensor S105                            | Module lamp L2 off        |
| 21   | Measure resistance between:                         |                           |
|      | (K1) B-9 to A-29                                    | Con                       |
|      | (K1) A-57 to A-29                                   | Con                       |
|      | (K1) A-27 to A-25                                   | Con                       |
|      | (K1) B-26 to B-32                                   | Con                       |
|      | (K2) A-6 to A-29                                    | Con                       |
|      | (K2) A-13 to A-29                                   | Con                       |
|      | (K2) A-20 to A-21                                   | Con                       |
|      | (K2) B-24 to B-29                                   | Con                       |
|      | (K4) B-31 to A-19                                   | Con                       |
|      | (K4) B-34 to B-8                                    | Con                       |
|      | (K4) B-12 to B-10                                   | Con                       |
|      | (K4) A-28 to A-31                                   | Con                       |

Functional Test  
Figure 706 (Sheet 2)

OVERHAUL MANUAL

| Step | Procedure   | Required Results                        |
|------|---|---|
|      | (K7) B-18 to A-32                                   | Con                                     |
|      | (K8) B-57 to B-56                                   | Con                                     |
|      | (K8) B-59 to B-61                                   | Con                                     |
|      | (K8) B-62 to B-64                                   | Con                                     |
|      | (K8) B-65 to B-67                                   | Con                                     |
| 22   | Measure voltage between:<br>(K2) B-1(+) to A-29     | 26 to 28 vdc                            |
| 23   | Measure resistance between:<br>(K1) B-45 to A-29    | No Con                                  |
|      | (K1) A-14 to A-29                                   | No Con                                  |
|      | (K1) A-26 to A-25                                   | No Con                                  |
|      | (K1) B-25 to B-32                                   | No Con                                  |
|      | (K2) A-9 to A-29                                    | No Con                                  |
|      | (K2) A-16 to A-21                                   | No Con                                  |
|      | (K2) B-23 to B-29                                   | No Con                                  |
|      | (K4) B-30 to A-19                                   | No Con                                  |
|      | (K4) B-14 to B-8                                    | No Con                                  |
|      | (K4) B-11 to B-10                                   | No Con                                  |
|      | (K4) A-15 to A-31                                   | No Con                                  |
|      | (K8) B-58 to B-56                                   | No Con                                  |
|      | (K8) B-60 to B-61                                   | No Con                                  |
|      | (K8) B-63 to B-64                                   | No Con                                  |
|      | (K8) B-66 to B-67                                   | No Con                                  |
| 24   | Set S26 to OFF                                      |   |
| 25   | Measure resistance between:<br>(K7,R2) B-16 to B-15 | 4 to 6 ohms                             |
|      | (K4) B-30 to A-19                                   | Con                                     |
|      | (K1,K2) A-57 to A-13                                | Con                                     |
| 26   | Press module switch S2, release                     | Module lamp L2 on while pressed         |
| 27   | Press-to-test module lamps L1 and L2                | Module lamps L1 and L2 on while pressed |
| 28   | *[1] Deactuate test sensor                          | Module lamp L2 on                       |
|      | *[2] Deactuate sensor S105                          | Module lamp L2 on                       |
| 29   | *[1] Disconnect sensor from test jack J105          |   |

\*[1] 65-52811-23, -25, -30, -31, -44, -74 thru -77, -84, -85, -118 thru -121, -145 thru -148, -151 only

\*[2] 65-52811-21, -51, -54, -73, -117, -135, -137, -144 only

Functional Test  
Figure 706 (Sheet 3)

OVERHAUL MANUAL

J. Nose and Main Landing Gear Proximity Switch Card Tests

- (1) Verify all test switches and lamps are in the initial conditions listed in Fig. 705.
- (2) Perform proximity switch card test per Fig. 707.

| Step | Procedure  | Required Results |
|------|--|------------------|
|      | <p><u>NOTE:</u> (65-52811-21,-51,-54,-73,-117,-135,-137,-144 only). Use 3-step procedures listed in Fig. 701 to actuate or deactuate sensors S72 and S74. (65-52811-23,-25,-30,-31,-44,-74 thru -77,-84,-85,-118 thru -121,-145 thru -148,-151 only). Indicators L2 and L6 respond to the test centerpoint sensor as actuation is accomplished. Actuation shall occur as the target bar is brought within 0.275 to 0.325 inches from the sensor. The proximity switch card shall remain actuated as the gap is decreased to zero. Deactuation shall occur as the bar is moved away from the sensor 0.005 to 0.030 inches from the actuation point.</p> |                  |
| 1    | *[1] Connect deactuated sensor to test jack J72  |                  |
| 2    | *[1] Actuate test sensor   | L2 off           |
| 3    | *[2] Actuate sensor S72  | L2 off           |
| 3    | *[1] Deactuate test sensor   | L2 on            |
| 3    | *[2] Deactuate sensor S72  | L2 on            |
| 4    | *[1] Disconnect sensor from test jack J72  |                  |
| 5    | *[1] Connect deactuated sensor to test jack J74  |                  |
| 6    | *[1] Actuate test sensor   | L6 off           |
| 6    | *[2] Actuate sensor S74  | L6 off           |
| 7    | *[1] Deactuate test sensor   | L6 on            |
| 7    | *[2] Deactuate sensor S74  | L6 on            |
| 8    | *[1] Disconnect sensor from test jack J74  |                  |
|      | <p><u>NOTE:</u> Indicator L4 responds to the test centerpoint sensor as actuation is accomplished. Actuation shall occur as the target bar is brought within 0.275 to 0.325 inches from the sensor. The proximity switch card shall remain actuated as the gap is decreased to zero. Deactuation shall occur as the bar is moved away from the sensor 0.005 to 0.030 inches from the actuation point.</p>  |                  |

OVERHAUL MANUAL

| Step | Procedure   | Required Results |
|------|---|------------------|
| 9    | Connect deactuated sensor to test jack J76  |                  |
| 10   | Actuate sensor  | L4 off           |
| 11   | Deactuate sensor  | L4 on            |
| 12   | Disconnect sensor from test jack J76  |                  |
|      | <p><u>NOTE:</u> (65-52811-21,-51,-54,-117,-135,-137, only). Use 3-step procedures listed in Fig. 701 to actuate or deactuate sensors S71 and S73. (65-52811-23,-25,-30,-31,-44,-73 thru -77,-84,-85,-118 thru-121,-144 thru -148,-151 only). Indicators L3 and L7 respond to the test centerpoint sensor as actuation is accomplished. Actuation shall occur as the target bar is brought within 0.275 to 0.325 *[3] inches from the sensor. The proximity switch card shall remain actuated as the gap is decreased to zero. Deactuation shall occur as the bar is moved away from the sensor 0.005 to 0.030 *[4] inches from the actuation point.</p> |                  |
| 13   | *[5] Connect deactuated sensor to test jack J71   |                  |
| 14   | *[5] Actuate test sensor  | L3 on            |
| 15   | *[6] Actuate sensor S71   | L3 on            |
| 15   | *[5] Deactuate test sensor  | L3 off           |
| 15   | *[6] Deactuate sensor S71   | L3 off           |
| 16   | *[5] Disconnect sensor from test jack J71   |                  |
| 17   | *[5] Connect deactuated sensor to test jack J73   |                  |
| 18   | *[5] Actuate test sensor  | L7 on            |
| 18   | *[6] Actuate sensor S73   | L7 on            |
| 19   | *[5] Deactuate test sensor  | L7 off           |
| 19   | *[6] Deactuate sensor S73   | L7 off           |
| 20   | *[5] Disconnect sensor from test jack J73   |                  |
|      | <p><u>NOTE:</u> Indicator L5 responds to the test centerpoint sensor as actuation is accomplished. Actuation shall occur as the target bar is brought within 0.130 to 0.160 inches from the sensor. The proximity switch card shall remain actuated as the gap is decreased to zero. Deactuation shall occur as the bar is moved away from the sensor 0.005 to 0.020 inches from the actuation point.</p>   |                  |

OVERHAUL MANUAL

| Step | Procedure                                  | Required Results |
|------|--|------------------|
| 21   | Connect deactuated sensor to test jack J75 |                  |
| 22   | Actuate sensor                             | L5 on            |
| 23   | Deactuate sensor                           | L5 off           |
| 24   | Disconnect sensor from test jack J75       |                  |

- \*[1] 65-52811-23, -25, -30, -31, -44, -74 thru -77, -84, -85, -118 thru -121, -145 thru -148, -151 only
- \*[2] 65-52811-21, -51, -54, -73, -117, -135, -137, -144 only
- \*[3] 0.275 to 0.325 inches for 65-52811-23, -25, -30, -31, -44, -84, -85, -118 thru -121, -151  
0.130 to 0.160 inches for 65-52811-73 thru -77, -144 thru -148
- \*[4] 0.005 to 0.030 inches for 65-52811-23, -25, -30, -31, -44, -84, -85, -118 thru -121, -151  
0.005 to 0.020 inches for 65-52811-73 thru -77, -144 thru -148
- \*[5] 65-52811-23, -25, -30, -31, -44, -73 thru -77, -84, -85, -118 thru -121, -144 thru -148, -151 only
- \*[6] 65-52811-21, -51, -54, -117, -135, -137 only

Proximity Switch Card Tests  
Figure 707 (Sheet 3)

K. Wheel Seal Circuitry Test

- (1) Verify all test switches and lamps are in the initial condition listed in Fig. 705.
- (2) Perform wheel seal circuitry tests per Fig. 708.

NOTE: L4 must remain illuminated. L5 and L8 thru L12 must remain extinguished.  
(65-52811-21, -51, -54, -117, -135, -137 only). Use 3-step procedures listed in Fig. 701 to actuate or deactuate sensors S71 thru S74.  
(65-52811-73, -144 only). Use 3-step procedures listed in Fig. 701 to actuate or deactuate sensors S72 and S74.

| Step | Condition        | Procedure                 | Required Results |           |           |           |           |
|------|------------------|---------------------------|------------------|-----------|-----------|-----------|-----------|
|      |                  |                           | L1               | LM Red L2 | LM Grn L3 | RM Red L6 | RM Grn L7 |
| 1    | Door Close       | Set S12 to OFF            |                  |           |           |           |           |
| 1A   | LM Gear Down     | *[1] Actuate sensor S71   | On               | On        | On        | On        | Off       |
|      |                  | *[2] Set S71 to ON        | On               | On        | On        | On        | Off       |
| 2    | RM Gear Down     | *[1] Actuate sensor S73   | Off              | On        | On        | On        | On        |
|      |                  | *[2] Set S73 to ON        | Off              | On        | On        | On        | On        |
| 3    | RM Gear Up       | *[3] Actuate sensor S74   | Off              | On        | On        | Off       | On        |
|      |                  | *[4] Set S74 to ON        | Off              | On        | On        | Off       | On        |
| 4    | LM Gear Up       | *[3] Actuate sensor S72   | Off              | Off       | On        | Off       | On        |
|      |                  | *[4] Set S72 to ON        | Off              | Off       | On        | Off       | On        |
| 5    | Door Open        | Set S12 to ON             | On               | Off       | On        | Off       | On        |
| 6    | RM Gear Not Down | *[1] Deactuate sensor S73 | On               | Off       | On        | Off       | Off       |
|      |                  | *[2] Set S73 to OFF       | On               | Off       | On        | Off       | Off       |
| 7    | Gear Handle Up   | Set S11 to ON             | On               | Off       | On        | Off       | Off       |
| 8    | LM Gear Not Up   | *[3] Deactuate sensor S72 | On               | On        | On        | Off       | Off       |
|      |                  | *[4] Set S72 to OFF       | On               | On        | On        | Off       | Off       |
| 9    | RM Gear Down     | *[1] Actuate sensor S73   | On               | On        | On        | Off       | On        |
|      |                  | *[2] Set S73 to ON        | On               | On        | On        | Off       | On        |
| 10   | LM Gear Not Down | *[1] Deactuate sensor S71 | On               | On        | Off       | Off       | On        |
|      |                  | *[2] Set S71 to OFF       | On               | On        | Off       | Off       | On        |
| 11   | LM Gear Up       | *[3] Actuate sensor S72   | On               | Off       | Off       | Off       | On        |
|      |                  | *[4] Set S72 to ON        | On               | Off       | Off       | Off       | On        |
| 12   | RM Gear Not Up   | *[3] Deactuate sensor S74 | On               | Off       | Off       | On        | On        |
|      |                  | *[4] Set S74 to OFF       | On               | Off       | Off       | On        | On        |

\*[1] 65-52811-21, -51, -54, -117, -135, -137 only

\*[2] 65-52811-23, -25, -30, -31, -44, -73 thru -77, -84, -85, -118 thru -121, -144 thru -148, -151 only

\*[3] 65-52811-21, -51, -54, -73, -117, -135, -137, -144 only

\*[4] 65-52811-23, -25, -30, -31, 44, -74 thru -77, -84, -85, -118 thru -121, -145 thru -148, -151 only

Wheel Seal Circuitry Tests  
Figure 708



OVERHAUL MANUAL

L. Left Main Gear Indication Circuitry Test

- (1) Verify all test switches and lamps are in the initial condition listed in Fig. 705.
- (2) Perform left main gear indication circuitry test per Fig. 709.

NOTE: L1, L4 and L6 must remain illuminated. L5 and L7 thru L12 must remain extinguished.  
(65-52811-21,-51,-54,-117,-135,-137 only). Use 3-step procedures listed in Fig. 701 to actuate or deactuate sensors S71 and S72.  
(65-52811-73,-144 only). Use 3-step procedures listed in Fig. 701 to actuate or deactuate sensor S72.

| Step | Condition            | Procedure                 | Required Results |           |
|------|----------------------|---------------------------|------------------|-----------|
|      |                      |                           | LM Red L2        | LM Grn L3 |
| 1    | LM Gear Down         | *[1] Actuate sensor S71   | On               | On        |
| 2    |                      | *[2] Set S71 to ON        | On               | On        |
| 3    | Gear Handle Down     | Verify voltage at A-38    | 1 vdc max        |           |
| 4    | LM Gear Not Down     | Set S3 to ON              | Off              | On        |
| 5    |                      | *[1] Deactuate sensor S71 | On               | Off       |
| 6    |                      | *[2] Set S71 to OFF       | On               | Off       |
| 7    | Gear Handle Not Down | Set S3 to OFF             | On               | Off       |
| 8    | LM Gear Up           | *[3] Actuate sensor S72   | Off              | Off       |
| 9    |                      | *[4] Set S72 to ON        | Off              | Off       |
| 10   | Throttle 1 Retard    | Set S6 to ON              | On               | Off       |
|      | Throttle 1 Advance   | Set S6 to OFF             | Off              | Off       |
|      | Throttle 2 Retard    | Set S7 to ON              | On               | Off       |
|      |                      | Verify voltage at A-38    | 2.5 vdc max      |           |

- \*[1] 65-52811-21, -51, -54, -117, -135, -137 only
- \*[2] 65-52811-23, -25, -30, -31, -44, -73 thru -77, -84, -85, -118 thru -121, -144 thru -148, -151 only
- \*[3] 65-52811-21,-51, -54, -73, -117, -135, -137, -144 only
- \*[4] 65-52811-23, -25, -30, -31, -44, -74 thru -77, -84, -85, -118 thru -121, -145 thru -148, -151 only

OVERHAUL MANUAL

M. Right Main Gear Indication Circuitry Test

- (1) Verify all test switches and lamps are in the initial condition listed in Fig. 705.
- (2) Perform right main gear indication circuitry test per Fig. 710.

NOTE: L1, L2 and L4 must remain illuminated. L3, L5 and L8 thru L12 must remain extinguished.  
(65-52811-21,-51,-54,-117,-135,-137 only). Use 3-step procedures listed in Fig. 701 to actuate or deactuate sensors S73 and S74.  
(65-52811-73,-144 only). Use 3-step procedures listed in Fig. 701 to actuate or deactuate sensor S74.

| Step | Condition            | Procedure                 | Required Results |           |
|------|----------------------|---------------------------|------------------|-----------|
|      |                      |                           | LM Red L6        | LM Grn L7 |
| 1    | RM Gear Down         | *[1] Actuate sensor S73   | On               | On        |
| 2    |                      | *[2] Set S73 to ON        | On               | On        |
| 3    | Gear Handle Down     | Verify voltage at A-42    | 1 vdc max        |           |
| 4    | RM Gear Not Down     | Set S3 to ON              | Off              | On        |
|      |                      | *[1] Deactuate sensor S73 | On               | Off       |
|      |                      | *[2] Set S73 to OFF       | On               | Off       |
| 5    | Gear Handle Not Down | Set S3 to OFF             | On               | Off       |
| 6    | RM Gear Up           | *[3] Actuate sensor S74   | Off              | Off       |
|      |                      | *[4] Set S74 to ON        | Off              | Off       |
| 7    | Throttle 1 Retard    | Set S6 to ON              | On               | Off       |
| 8    | Throttle 1 Advance   | Set S6 to OFF             | Off              | Off       |
| 9    | Throttle 2 Retard    | Set S7 to ON              | On               | Off       |
| 10   |                      | Verify voltage at A-42    | 2.5 vdc max      |           |

\*[1] 65-52811-21, -51, -54, -117, -135, -137 only

\*[2] 65-52811-23, -25, -30, -31, -44, -73 thru -77, -84, -85, -118 thru -121, -144 thru -148, -151 only

\*[3] 65-52811-21, -51, -54, -73, -117, -135, -137, -144 only

\*[4] 65-52811-23, -25, -30, -31, -44, -74 thru -77, -84, -85, -118 thru -121, -145 thru -148, -151 only



OVERHAUL MANUAL

N. Nose Gear Indication Circuitry Test

- (1) Verify all test switches and lamps are in the initial condition listed in Fig. 705.
- (2) Perform nose gear indication circuitry test per Fig. 711.

NOTE: L1, L2 and L6 must remain illuminated. L3 and L7 thru L12 must remain extinguished.

| Step | Condition            | Procedure                   | Required Results  |                   |
|------|----------------------|-----------------------------|-------------------|-------------------|
|      |                      |                             | LM Red<br>L4 *[2] | LM Grn<br>L5 *[2] |
| 1    | Nose Gear Downlock   | Set S75 to ON               | On                | On                |
| 2    |                      | Verify voltage at A-40 *[1] | 1 vdc max         |                   |
| 3    | Gear Handle Down     | Set S3 to ON                | Off               | On                |
| 4    | Nose Gear Not Down   | Set S75 to OFF              | On                | Off               |
| 5    | Gear Handle Not Down | Set S3 to OFF               | On                | Off               |
| 6    | Nose Gear Uplock     | Set S76 to ON               | Off               | Off               |
| 7    | Throttle 1 Retard    | Set S6 to ON                | On                | Off               |
| 8    | Throttle 1 Advance   | Set S6 to Off               | Off               | Off               |
| 9    | Throttle 2 Retard    | Set S7 to ON                | On                | Off               |
| 10   |                      | Verify voltage at A-40 *[1] | 2.5 vdc max       |                   |

\*[1] Use A-39 on 65-52811-44, -73 thru -77, -84, -144 thru -148.

\*[2] On 65-52811-44, -73 thru -77, -84, -144 thru -148. Connect L4 to pin A-39 and L5 to pin A-40.

Nose Gear Indication Circuitry Tests  
Figure 711

OVERHAUL MANUAL

0. Aural Warning Circuitry Test

- (1) Verify all test switches and lamps are in the initial condition listed in Fig. 705.
- (2) Perform aural warning circuitry test per Fig. 712.

**NOTE:** L1,L2,L4 and L6 must remain illuminated. L9 thru L12 must remain extinguished.  
(65-52811-21,-51,-54,-117,-135,-137 only). Use 3-step procedures listed in Fig. 701 to actuate or deactuate sensors S71 and S73.

| Step | Condition              | Procedure                 | Required Results |                   |                 |            |
|------|------------------------|---------------------------|------------------|-------------------|-----------------|------------|
|      |                        |                           | LM<br>Grn<br>L3  | Nose<br>Grn<br>L5 | RM<br>Grn<br>L7 | Horn<br>L8 |
| 1    | Flap Not Up            | Set S5 to OFF             | Off              | Off               | Off             | On         |
| 2    | Landing Warning SW. Up | Set S4 to OFF             | Off              | Off               | Off             | Off        |
| 3    | Throttle 1 Retard      | Set S6 to ON              | Off              | Off               | Off             | On         |
| 4    | Horn Reset             | Press and release S21     | Off              | Off               | Off             | Off        |
| 5    | Throttle 2 Retard      | Set S7 to ON              | Off              | Off               | Off             | On         |
| 6    | Horn Reset             | Press and release S21     | Off              | Off               | Off             | Off        |
| 7    | Throttle 1 Advance     | Set S6 to OFF             | Off              | Off               | Off             | Off        |
| 8    | Throttle 1 Retard      | Set S6 to ON              | Off              | Off               | Off             | On         |
| 9    | Horn Reset             | Press and release S21     | Off              | Off               | Off             | Off        |
| 10   | Throttle 2 Advance     | Set S7 to OFF             | Off              | Off               | Off             | Off        |
| 11   | Throttle 2 Retard      | Set S7 to ON              | Off              | Off               | Off             | On         |
| 12   | Horn Reset             | Press and release S21     | Off              | Off               | Off             | Off        |
| 13   | Landing Warn SW. Down  | Set S4 to ON              | Off              | Off               | Off             | On         |
| 14   | LM Gear Down           | *[1] Actuate sensor S71   | On               | Off               | Off             | On         |
|      |                        | *[2] Set S71 to ON        | On               | Off               | Off             | On         |
| 15   | RM Gear Down           | *[1] Actuate sensor S73   | On               | Off               | On              | On         |
|      |                        | *[2] Set S73 to ON        | On               | Off               | On              | On         |
| 16   | Nose Downlock          | Set S75 to ON             | On               | On                | On              | Off        |
| 17   | RM Gear Not Down       | *[1] Deactuate sensor S73 | On               | On                | Off             | On         |
|      |                        | *[2] Set S73 to OFF       | On               | On                | Off             | On         |

Aural Warning Circuitry Tests  
Figure 712 (Sheet 1)



OVERHAUL MANUAL

| Step | Condition        | Procedure  | Required Results |                   |                 |            |
|------|------------------|--|------------------|-------------------|-----------------|------------|
|      |                  |  | LM<br>Grn<br>L3  | Nose<br>Grn<br>L5 | RM<br>Grn<br>L7 | Horn<br>L8 |
| 18   | RM Gear Down     | *[1] Actuate sensor S73<br>*[2] Set S73 to ON    | On<br>On         | On<br>On          | On<br>On        | Off<br>Off |
| 19   | LM Gear Not Down | *[1] Deactuate sensor S71<br>*[2] Set S71 to OFF | Off<br>Off       | On<br>On          | On<br>On        | On<br>On   |
| 20   |                  | *[3] Set S24 to OFF                              | Off              | On                | On              | Off        |
| 21   | LM Gear Down     | *[1] Actuate sensor S71<br>*[2] Set S71 to ON    | On<br>On         | On<br>On          | On<br>On        | Off<br>Off |
| 22   |                  | Verify voltage at A-39*[4]                       | 1 vdc max        |                   |                 |            |
| 23   |                  | Verify voltage at A-41                           | 1 vdc max        |                   |                 |            |
| 24   |                  | Verify voltage at A-37                           | 1 vdc max        |                   |                 |            |

- \*[1] 65-52811-21, -51, -54, -117, -135, -137 only
- \*[2] 65-52811-23, -25, -30, -31, -44, -73 thru -77, -84, -85, -118 thru -121, -144 thru -148, -151 only
- \*[3] 65-52811-25, -31, -75, -77, -119, -121, -146, -148 only
- \*[4] A-39 on 65-52811-21, -23, -25, -30, -31, -51, -54, -85, -117 thru -121, -135, -137, -151  
A-40 on 65-52811-44, -73 thru -77, -84, -144 thru -148

Aural Warning Circuitry Tests  
Figure 712 (Sheet 2)

OVERHAUL MANUAL

P. Automatic Ground Spoiler Circuitry Test

- (1) Verify all test switches and lamps are in the initial condition listed in Fig. 705.
- (2) Perform automatic ground spoiler circuitry test per Fig. 713.

NOTE: L1, L2, L4 and L6 must remain illuminated. L3, L5, L7 and L8 must remain extinguished.

| Step | Condition              | Procedure   | Required Results |     |     |     |
|------|------------------------|---|------------------|-----|-----|-----|
|      |                        |   | L9               | L10 | L11 | L12 |
| 1    |                        | *[1] Set S25 to ON  |                  |     |     |     |
| 2    | Speed Brake Armed      | Set S20 to ON   | Off              | Off | On  | Off |
| 3    | Park Switch            | Set S17 to position 3   | Off              | On  | Off | Off |
| 4    | Park Switch            | Set S17 to position 2   | Off              | Off | On  | Off |
| 5    | Inbd Antiskid Off      | Set S1 to OFF   | Off              | On  | Off | Off |
| 6    | Inbd Antiskid On       | Set S1 to ON  | Off              | Off | On  | Off |
| 7    | Outbd Antiskid Off     | Set S9 to OFF   | Off              | On  | Off | Off |
| 8    | Inbd Antiskid Off      | Set S1 to OFF   | Off              | On  | Off | Off |
| 9    | Speed Brake Handle Off | Set S8 to OFF   | Off              | Off | On  | Off |
| 10   | Speed Brake Handle On  | Set S8 to ON  | Off              | On  | Off | Off |
| 11   | Auto Spoiler Test 1    | Set S22 to position 1   | Off              | Off | On  | Off |
| 12   | Auto Spoiler Test Off  | Set S22 to OFF  | Off              | On  | Off | Off |
| 13   | Auto Spoiler Test On   | Set S23 to ON   | Off              | Off | On  | Off |
| 14   | Auto Spoiler Test Off  | Set S23 to OFF  | Off              | On  | Off | Off |
| 15   | Auto Spoiler Test 2    | Set S22 to position 2   | Off              | Off | On  | Off |
| 16   | Eng. Throttle Advance  | Set S10 to ON   | On               | Off | On  | Off |
| 17   |                        | *[1] Measure voltage between: (+) B-5 and B-4                           | 26 to 28 vdc     |     |     |     |
|      |                        | *[2] Measure resistance between: B-3 and B-5                            | 2 ohms max       |     |     |     |
| 18   |                        | Measure voltage between: A-18 and GND                                   | 1 vdc max        |     |     |     |
| 19   |                        | Verify all test switches are in the initial condition listed in Fig.705 | Off              | Off | Off | Off |
| 20   |                        | *[1] Set S25 to ON  |                  |     |     |     |
| 21   | Speed Brake Armed      | Set S20 to ON   | Off              | Off | On  | Off |
| 22   | Right Inbd Power On    | Set S15 to ON   | Off              | Off | On  | Off |
| 23   | Right Outbd Power On   | Set S16 to ON   | Off              | On  | Off | Off |

Automatic Ground Spoiler Circuitry Tests  
Figure 713 (Sheet 1)



OVERHAUL MANUAL

| Step | Condition                                    | Procedure                                | Required Results |     |     |     |
|------|--|--|------------------|-----|-----|-----|
|      |  |  | L9               | L10 | L11 | L12 |
| 24   | Speed Brake Actuator                         | Set S17 to position 1                    | Off              | On  | Off | On  |
| 25   | Eng. Throttle Advance                        | Set S10 to ON                            | On               | Off | On  | Off |
| 26   | Eng. Throttle Retard                         | Set S10 to OFF                           | Off              | On  | Off | On  |
| 27   | Right Outbd Power Off                        | Set S16 to OFF                           | Off              | Off | On  | Off |
| 28   | Left Inbd Power On                           | Set S14 to ON                            | Off              | On  | Off | On  |
| 29   | Eng. Throttle Advance                        | Set S10 to ON                            | On               | Off | On  | Off |
| 30   | Eng. Throttle Retard                         | Set S10 to OFF                           | Off              | On  | Off | On  |
| 31   | Right Inbd Power Off                         | Set S15 to OFF                           | Off              | Off | On  | Off |
| 32   | Left Outbd Power On                          | Set S13 to ON                            | Off              | On  | Off | On  |
| 33   | Eng. Throttle Advance                        | Set S10 to ON                            | On               | Off | On  | Off |
| 34   | Eng. Throttle Retard                         | Set S10 to OFF                           | Off              | On  | Off | On  |
| 35   | Left Inbd Power Off                          | Set S14 to OFF                           | Off              | Off | On  | Off |
| 36   | Right Outbd Power On                         | Set S16 to ON                            | Off              | On  | Off | On  |
| 37   | Eng. Throttle Advance                        | Set S10 to ON                            | On               | Off | On  | Off |
| 38   | Eng. Throttle Retard                         | Set S10 to OFF                           | Off              | On  | Off | On  |
| 39   | Right Outbd Power Off                        | Set S16 to OFF                           | Off              | Off | On  | Off |
| 40   | Right Inbd Power On                          | Set S15 to ON                            | Off              | Off | On  | Off |
| 41   | Left Inbd Power On<br>Right Outbd Power On   | Set S14, S16 to ON                       |                  |     |     |     |
| 42   | Left Outbd Power Off<br>Right Inbd Power Off | Set S13, S15 to OFF                      | Off              | Off | On  | Off |
| 43   | Left Outbd Power On<br>Right Inbd Power On   | Set S13, S15 to ON                       |                  |     |     |     |
| 44   | Eng. Throttle Advance                        | Set S10 to ON                            | On               | Off | On  | Off |
| 45   | Eng. Throttle Retard                         | Set S10 to OFF                           | Off              | On  | Off | On  |
| 46   |  | Measure voltage between:<br>A-34 and GND | 1 vdc max        |     |     |     |

\*[1] 65-52811-117 thru -121, -137, -144 thru -148 only

\*[2] 65-52811-21, -23, -25, -30, -31, -44, -51, -54, -73 thru -77,  
-84, -85, -135, -151 only

Automatic Ground Spoiler Circuitry Tests  
Figure 713 (Sheet 2)

OVERHAUL MANUAL

Q. (65-52811-54, -137 only). Auto-Brake and Auto-Land Circuitry Test

- (1) Verify all test switches and lamps are in the initial condition listed in Fig. 705.
- (2) Perform auto-brake and auto-land circuitry tests per Fig. 714.

NOTE: No Test lamps change state during test.

| Step              | Condition             | Procedure      | Measure Between Pins: | Required Results |
|-------------------|-----------------------|----------------|-----------------------|------------------|
| <u>Auto-Brake</u> |                       |                |                       |                  |
| 1                 | Left Outbd Power On   | Set S13 to ON  |                       |                  |
| 2                 | Left Inbd Power On    | Set S14 to ON  |                       |                  |
| 3                 | Right Inbd Power On   | Set S15 to ON  |                       |                  |
| 4                 | Right Outbd Power On  | Set S16 to ON  | A-55 and A-7          | No Con           |
| 5                 | Right Inbd Power Off  | Set S15 to OFF | A-55 and A-7          | Con              |
| 6                 | Right Inbd Power On   | Set S15 to ON  |                       |                  |
| 7                 | Left Inbd Power Off   | Set S14 to OFF | A-55 and A-7          | Con              |
| 8                 | Left Inbd Power On    | Set S14 to ON  |                       |                  |
| 9                 | Right Outbd Power Off | Set S16 to OFF | A-55 and A-7          | Con              |
| 10                | Right Outbd Power On  | Set S16 to ON  |                       |                  |
| 11                | Left Outbd Power Off  | Set S13 to OFF | A-55 and A-7          | Con              |
| 12                | Right Inbd Power Off  | Set S15 to OFF | A-24 and B-46         | Con              |
| 13                | Left Inbd Power Off   | Set S14 to OFF | A-24 and B-46         | No Con           |
| 14                | Left Outbd Power On   | Set S13 to ON  | A-24 and B-46         | Con              |
| 15                | Right Outbd Power Off | Set S16 to OFF |                       |                  |
| 16                | Right Inbd Power On   | Set S15 to ON  | A-24 and B-46         | Con              |
| 17                | Left Outbd Power Off  | Set S13 to OFF | A-24 and B-46         | No Con           |
| 18                | Left Inbd Power On    | Set S14 to ON  | A-24 and B-46         | Con              |
| 19                | Left Outbd Power On   | Set S13 to On  |                       |                  |
| 20                | Right Outbd Power On  | Set S16 to ON  | A-24 and B-46         | Con              |
| <u>Auto-Land</u>  |                       |                |                       |                  |
| 21                | Right Outbd Power Off | Set S16 to OFF |                       |                  |
| 22                | Left Outbd Power Off  | Set S13 to OFF |                       |                  |
| 23                | Right Inbd Power Off  | Set S15 to OFF | A-33 and B-21         | Con              |
|                   |                       |                | A-33 and A-64         | No Con           |
|                   |                       |                | A-33 and A-65         | No Con           |
|                   |                       |                | A-33 and A-66         | No Con           |

Auto-Brake and Auto-Land Circuitry Tests, 65-52811-54, -137 only  
Figure 714 (Sheet 1)

| Step     | Condition                                    | Procedure                       | Measure Between Pins   | Required Results                  |
|----------|--|---------------------------------|--|-----------------------------------|
| 24<br>25 | Left Inbd Power Off<br>Right Outbd Power On  | Set S14 to OFF<br>Set S16 to ON | A-33 and A-66<br>A-33 and A-65<br>A-33 and A-64<br>A-33 and B-21 | Con<br>No Con<br>No Con<br>No Con |
| 26<br>27 | Right Outbd Power Off<br>Left Outbd Power On | Set S16 to OFF<br>Set S13 to ON | A-33 and B-21<br>A-33 and A-64<br>A-33 and A-65<br>A-33 and A-66 | No Con<br>No Con<br>Con<br>No Con |
| 28<br>29 | Left Outbd Power Off<br>Right Inbd Power On  | Set S13 to OFF<br>Set S15 to ON | A-33 and A-66<br>A-33 and A-65<br>A-33 and A-64<br>A-33 and B-21 | No Con<br>No Con<br>Con<br>No Con |
| 30       | Right Inbd Power Off                         | Set S15 to OFF                  |  |                                   |

Auto-Brake and Auto-Land Circuitry Tests, 65-52811-54, -137 only  
Figure 714 (Sheet 2)

R. Antiskid Test (Optional Test)

- (1) Set S18 to ON.
- (2) Connect oscilloscope between B-15 and ground. Verify that voltage is between 28 and 50 vdc with a ripple content of less than 5 volts peak to peak.
- (3) Set S18 to OFF.


S. Turn off both power supplies.

T. Disconnect test setup, Fig. 704.

U. Antiskid Test

- (1) Connect test setup per Fig. 715.
- (2) Turn on power supply.
- (3) Verify dc voltage at pin B-15 shall be greater than 28 vdc but less than 50 vdc.
- (4) Verify ripple voltage shall be less than 5 volts peak to peak.
- (5) Turn off power supply.
- (6) Disconnect test setup, Fig. 715.

OVERHAUL MANUAL



Test Setup  
Figure 715

V. Verify indexing on rear connector as follows:

65-52811-21, -51, -54, -117, -135, -137



65-52811-23, -30, -44, -84, -85, -118,  
-120, -151




65-52811-25, -31, -119, -121



65-52811-73, -74, -76, -144,  
-145, -147



65-52811-75, -77, -146, -148



**NOTE:** Darkened portion indicates extended part of keying post.





OVERHAUL MANUAL  
TROUBLE SHOOTING

1. Trouble shooting is keyed to the steps of the functional test procedures. Check for defective connections or wiring prior to replacing components.

NOTE: L1 and L2 refer to test lamps unless module lamp specifically stated.

| <u>Trouble</u>                                   | <u>Possible Cause and Correction</u> |
|--|--------------------------------------|
| Fig. 702 and 703<br>Par. 2.D and .E<br>Par. 2.F. | Component listed<br>A13              |
| L1 fault   | A10, A11, K6                         |
| L2 fault   | A4, A11                              |
| L3 fault   | A3 or A9 CR12 shorted                |
| L4 fault   | A5, A12                              |
| L5 fault   | A6 or A9 CR13 shorted                |
| L6 fault   | A8, A11                              |
| L7 fault   | A7 or A9 CR14 shorted                |
| L8 fault   | A9                                   |
| L9 fault   | A12                                  |
| L10, L11 fault                                   | A14                                  |
| Par. 2.H.  |                                      |
| Module lamp L1 *[1]                              | A1, K3, L1 *[1]                      |
| Module lamp L2 *[1]                              | A2, K2, L2 *[1]                      |
| Fig. 706   |                                      |
| Steps 1, 4, 9, 11                                | Listed components                    |
| Steps 5-7  |                                      |
| Continuity fault                                 | R1, S1                               |
| Module lamp L1 *[1]                              | A1, K3, R1, S1                       |
| fault  |                                      |
| Steps 8, 10, 12                                  | A1                                   |
| Steps 14-18                                      | A12                                  |
| Steps 20, 28                                     | A2                                   |
| Steps 21-25                                      | Listed component                     |
| Step 26  | A2, S2                               |
| Step 27  | Module lamp L1 or L2 *[1]            |

\*[1] L1, L2 on 65-52811-21, -25, -31, -51, -73, -75, -77, -117, -119, -121, -135, -144, -146, -148  
DS1, DS2 on 65-52811-23, -30, -44, -54, -74, -76, -84, -85, -118, -120, -137, -145, -147

OVERHAUL MANUAL

| <u>Trouble</u>            | <u>Possible Cause and Correction</u>  |
|---------------------------|---|
| Fig. 707                  |   |
| Steps 1-4                 | A4  |
| Steps 5-8                 | A8  |
| Steps 9-12                | A5  |
| Steps 13-16               | A3  |
| Steps 17-20               | A7  |
| Steps 21-24               | A6  |
| Fig. 708                  |   |
| L3, L7 fault              | A3, A7  |
| L2, L6 fault              | A4, A8, A11   |
| L1 fault, step 1 or 5     | K6  |
| L1 fault, all other steps | A10, A11  |
| Fig. 709, 710             | A11   |
| Fig. 711                  | A12   |
| Fig. 712                  |   |
| L3, L5, L7 fault          | A3, A6, A7 respectively   |
| L8 fault                  | A9, or if reset failure, A13 involved   |
| Voltage fault             | A3 (pin A-37), A6 (pin A-39 *[2]), A7 (pin A-41)  |
| Fig. 713                  |   |
| Step 2, L9 fault          | A12   |
| L10, L11 fault            | A14   |
| Steps 3, 5, 7, 8, 15,     |   |
| L10, L11 fault            | A14   |
| Steps 11, 12,             |   |
| L10, L11 fault            | A13, A14  |
| Step 16, L9 fault         | A12   |
| Step 17                   | K13   |
| Step 18                   | A14   |
| Steps 21-45,              |   |
| L9 fault                  | A12   |
| L10, L11 fault            | If combined with L12 failure to illuminate, suspect one of relays K9 thru K13.<br>If L12 illuminated, replace A14.<br>Replace relays by trial and error except:<br>At Step 25 - Relay K13 first |

\*[2] Pin A-39 on 65-52811-21, -23, -25, -30, -31, -51, -54, -85, -117 thru -121, -135, -137  
Pin A-40 on 65-52811-44, -73 thru -77, -84, -144 thru -148




OVERHAUL MANUAL

Trouble


Possible Cause and Correction

|          |   |
|----------|---|
|          | At S13 actuation - Replace K11<br>first |
|          | At S14 actuation - Replace K9<br>first  |
|          | At S15 actuation - Replace K12<br>first |
|          | At S16 actuation - Replace K10<br>first |
| Step 46  | A14                                     |
| Fig. 714 | K9 thru K12 (65-52811-54, -137<br>only) |
| Par.2.T. | A13                                     |



65-52811-21,-51,-54,-73,-117,-135,-137,-144


NOTE: ALL WIRE BMS13-16, SIZE AWG 24  
 UNLESS OTHERWISE NOTED



65-52811-21,-51,-54,-73,-117,-135,-137,-144

- |   |  |    |                              |
|---|--|----|------------------------------|
| 1 | REFER TO APPLICABLE MANUFACTURER'S INSTRUCTIONS                | 6  | 65-52811-21, -73, -117, -144 |
| 2 | REFER TO SUBJECT 32-66-41                                      | 7  | 65-52811-54, -137            |
| 3 | WIRE SIZE AWG 20   | 8  | REFER TO SUBJECT 32-66-42    |
| 4 | WIRE SIZE AWG 22   | 9  | 65-52811-135                 |
| 5 | PINS 39-40 INTERCHANGED ON<br>65-52811-73 (SB 32-1093R1), -144 | 10 | 65-52811-51,-54,-135,-137    |


Schematic Diagram  
Figure 801 (Sheet 2)




65-52811-117, -137, -144


- 1 REFER TO APPLICABLE MANUFACTURER'S INSTRUCTIONS
- 2 REFER TO SUBJECT 32-66-41
- 3 WIRE SIZE AWG 20
- 4 WIRE SIZE AWG 22
- 5 PINS 38-40 INTERCHANGED ON 65-52811-73 (SB 32-1093R1), -144
- 6 65-52811-21, -73, -117, -144
- 7 65-52811-64, -137
- 8 REFER TO SUBJECT 32-66-42

OVERHAUL MANUAL



 65-52811-54,-137

65-52811-51,-54,-135,-137




65-52811-23,-30,-44,-74,-76,-84,-85,-118,-120,-145,-147,-151

NOTE: ALL WIRE BMS13-16, SIZE AWG 24  
 UNLESS OTHERWISE MOTED NOTED

REFER TO APPLICABLE MANUFACTURER'S INSTRUCTION






65-52811-23,-30,-44,-74,-76,-84,-85,-151

- REFER TO APPLICABLE MANUFACTURER'S INSTRUCTIONS
- REFER TO SUBJECT 32-66-41
- WIRE SIZE AWG 20
- WIRE SIZE AWG 22
- INTERCHANGE PINS 39-40 ON 65-52811-44, -74, -76, -84, -145, -146
- REFER TO SUBJECT 32-66-42
- 65-52811-151


Schematic Diagram  
Figure 802 (Sheet 2)




65-52811-118, -120, -145, -147

- REFER TO APPLICABLE MANUFACTURER'S INSTRUCTIONS
- REFER TO SUBJECT 32-66-41
- WIRE SIZE AWG 20
- WIRE SIZE AWG 22
- INTERCHANGE PINS 39-40 ON 65-52811-74, -76, -145, -147
- REFER TO SUBJECT 32-66-42

Schematic Diagram  
Figure 802 (Sheet 3)






65-52811-25, -31, -75, -77

Schematic Diagram  
Figure 803 (Sheet 2)

- ▶ REFER TO APPLICABLE MANUFACTURER'S INSTRUCTIONS
- ▶ REFER TO SUBJECT 32-66-41
- ▶ INTERCHANGE PINS 39-40 ON 65-52811-75, -77, -146, -148
- ▶ REFER TO SUBJECT 32-66-42
- ▶ WIRE SIZE AWG 20
- ▶ WIRE SIZE AWG 22



65-52811-119, -121, -146, -148

Dec 5/83

Schematic Diagram  
Figure 803 (Sheet 3)


32-66-40  
Page 817

- 1 REFER TO APPLICABLE MANUFACTURER'S INSTRUCTIONS
- 2 REFER TO SUBJECT 32-66-41
- 3 WIRE SIZE AWG 20

- 4 WIRE SIZE AWG 22
- 5 INTERCHANGE PINS 39-40 ON 65-52811-75, -77, -146, -148
- 6 REFER TO SUBJECT 32-66-42

OVERHAUL MANUAL

ILLUSTRATED PARTS LIST



VIEW 1

65-52811-23, -25, -30, -31, -44, -74 THRU -77,  
-84, -118 THRU -121, -145 THRU -148


Landing Gear Accessory Unit Assembly (M338)

Figure 1101 (Sheet 1)

Mar 5/85

32-66-40  
Page 1101

OVERHAUL MANUAL



VIEW 2

DETAIL A  
 65-52811-21, -54, -73, -117, -137, -144

Landing Gear Accessory Unit Assembly (M338)  
 Figure 1101 (Sheet 2)

OVERHAUL MANUAL

| FIG. & ITEM NO. | PART NO.     | AIRLINE PART NUMBER | N O M E N C L A T U R E                               |   |   |   |   |   |   | USE CODE | QTY PER ASSY |
|-----------------|--------------|---------------------|---|---|---|---|---|---|---|----------|--------------|
|                 |              |                     | 1   | 2 | 3 | 4 | 5 | 6 | 7 |          |              |
| 1101-           | 65-52811-21  |                     | LANDING GEAR ACCESSORY UNIT ASSY (M338)               |   |   |   |   |   |   | A        |              |
|                 | 65-52811-23  |                     | LANDING GEAR ACCESSORY UNIT ASSY (M338)(SB 24-1001)   |   |   |   |   |   |   | B        |              |
|                 | 65-52811-25  |                     | LANDING GEAR ACCESSORY UNIT ASSY (M338)               |   |   |   |   |   |   | C        |              |
|                 | 65-52811-30  |                     | LANDING GEAR ACCESSORY UNIT ASSY (M338)               |   |   |   |   |   |   | D        |              |
|                 | 65-52811-31  |                     | LANDING GEAR ACCESSORY UNIT ASSY (M338)               |   |   |   |   |   |   | E        |              |
|                 | *[1]         |                     | LANDING GEAR ACCESSORY UNIT ASSY (M338)(SB 21-1030)   |   |   |   |   |   |   | F        |              |
|                 | 65-52811-73  |                     | LANDING GEAR ACCESSORY UNIT ASSY (M338)(SB 32-1093)   |   |   |   |   |   |   | G        |              |
|                 | 65-52811-74  |                     | LANDING GEAR ACCESSORY UNIT ASSY (M338)(SB 32-1093)   |   |   |   |   |   |   | H        |              |
|                 | 65-52811-75  |                     | LANDING GEAR ACCESSORY UNIT ASSY (M338)(SB 32-1093)   |   |   |   |   |   |   | I        |              |
|                 | 65-52811-76  |                     | LANDING GEAR ACCESSORY UNIT ASSY (M338)(SB 32-1093)   |   |   |   |   |   |   | J        |              |
|                 | 65-52811-77  |                     | LANDING GEAR ACCESSORY UNIT ASSY (M338)(SB 32-1093)   |   |   |   |   |   |   | K        |              |
|                 | 65-52811-54  |                     | LANDING GEAR ACCESSORY UNIT ASSY (M338)(SB 32-1093)   |   |   |   |   |   |   | L        |              |
|                 | 65-52811-117 |                     | LANDING GEAR ACCESSORY UNIT ASSY (M338)(SB 27-1114R2) |   |   |   |   |   |   | M        |              |
|                 | 65-52811-118 |                     | LANDING GEAR ACCESSORY UNIT ASSY (M338)(SB 27-1114R2) |   |   |   |   |   |   | N        |              |
|                 | 65-52811-119 |                     | LANDING GEAR ACCESSORY UNIT ASSY (M338)(SB 27-1114R2) |   |   |   |   |   |   | O        |              |
|                 | 65-52811-120 |                     | LANDING GEAR ACCESSORY UNIT ASSY (M338)(SB 27-1114R2) |   |   |   |   |   |   | P        |              |
|                 | 65-52811-121 |                     | LANDING GEAR ACCESSORY UNIT ASSY (M338)(SB 27-1114R2) |   |   |   |   |   |   | Q        |              |
|                 | 65-52811-137 |                     | LANDING GEAR ACCESSORY UNIT ASSY (M338)(SB 27-1114R2) |   |   |   |   |   |   | R        |              |
|                 | 65-52811-144 |                     | LANDING GEAR ACCESSORY UNIT ASSY (M338)(SB 27-1114R2) |   |   |   |   |   |   | S        |              |
|                 | 65-52811-145 |                     | LANDING GEAR ACCESSORY UNIT ASSY (M338)(SB 27-1114R2) |   |   |   |   |   |   | T        |              |
|                 | 65-52811-146 |                     | LANDING GEAR ACCESSORY UNIT ASSY (M338)(SB 27-1114R2) |   |   |   |   |   |   | U        |              |



OVERHAUL MANUAL

| FIG. & ITEM NO. | PART NO.     | AIRLINE PART NUMBER | N O M E N C L A T U R E                                |   |   |   |   |   |   | USE CODE                     | QTY PER ASSY |
|-----------------|--------------|---------------------|--|---|---|---|---|---|---|------------------------------|--------------|
|                 |              |                     | 1  | 2 | 3 | 4 | 5 | 6 | 7 |                              |              |
| 1101-           | 65-52811-147 |                     | LANDING GEAR ACCESSORY UNIT ASSY (M338)(SB 27-1114R2)  |   |   |   |   |   |   | V                            |              |
|                 | 65-52811-148 |                     | LANDING GEAR ACCESSORY UNIT ASSY (M338)(SB 27-1114R2)  |   |   |   |   |   |   | W                            |              |
|                 | 65-52811-44  |                     | LANDING GEAR ACCESSORY UNIT ASSY (M338) (SB 21-1030)   |   |   |   |   |   |   | X                            |              |
|                 | 65-52811-84  |                     | LANDING GEAR ACCESSORY UNIT ASSY (M338) (SB 32-1093R2) |   |   |   |   |   |   | Y                            |              |
|                 | 65-52811-51  |                     | LANDING GEAR ACCESSORY UNIT ASSY (M338)                |   |   |   |   |   |   | Z                            |              |
|                 | 65-52811-85  |                     | LANDING GEAR ACCESSORY UNIT ASSY (M338)(SB 32-1093R2)  |   |   |   |   |   |   | BA                           |              |
|                 | 65-52811-135 |                     | LANDING GEAR ACCESSORY UNIT ASSY (M338)(SB 27-1114R2)  |   |   |   |   |   |   | CA                           |              |
|                 | 65-52811-151 |                     | LANDING GEAR ACCESSORY UNIT ASSY (M338)(SB 27-1114R2)  |   |   |   |   |   |   | DA                           |              |
| 1               | 65-51805-68  |                     | . CHASSIS ASSY (PREF)(REF 24-01-05)                    |   |   |   |   |   |   | ABCGH<br>IL-O<br>R-UZ-<br>DA | 1            |
| 1               | 65-51805-35  |                     | . CHASSIS ASSY (OPT)(REF 24-01-05)                     |   |   |   |   |   |   | ABCGH<br>IL-O<br>R-UZ-<br>DA | 1            |
| 1               | 65-51805-60  |                     | . CHASSIS ASSY (OPT)(REF 24-01-05)                     |   |   |   |   |   |   | ABCGH<br>IL-O<br>R-UZ-<br>DA | 1            |
| 1               | 65-51805-78  |                     | . CHASSIS ASSY (PREF)(REF 24-01-05)                    |   |   |   |   |   |   | DEJK<br>PQV-Y                | 1            |
| 1               | 65-51805-75  |                     | . CHASSIS ASSY (OPT)(REF 24-01-05)                     |   |   |   |   |   |   | DEJK<br>PQV-Y                | 1            |
| 1               | 65-51805-76  |                     | . CHASSIS ASSY (OPT)(REF 24-01-05)                     |   |   |   |   |   |   | DEJK<br>PQV-Y                | 1            |
| 1               | 65-73698-58  |                     | . CHASSIS ASSY (OPT)(REF 24-01-05)                     |   |   |   |   |   |   | A-E<br>G-WZ-<br>DA           | 1            |
| 1               | *[1]         |                     | . CHASSIS ASSY (REF 24-01-05 OR 24-01-07)              |   |   |   |   |   |   | F                            | 1            |

OVERHAUL MANUAL

| FIG. & ITEM NO. | PART NO.    | AIRLINE PART NUMBER | N O M E N C L A T U R E |   |   |   |   |   |   | USE CODE                 | QTY PER ASSY |
|-----------------|-------------|---------------------|-------------------------|---|---|---|---|---|---|--------------------------|--------------|
|                 |             |                     | 1                       | 2 | 3 | 4 | 5 | 6 | 7 |                          |              |
| 1101-2          | 2-899-2     |                     | .                       |   |   |   |   |   |   | AGLM<br>RSZCA            | 4            |
| 2               | 8-060-02    |                     | .                       |   |   |   |   |   |   | B-E<br>H-K<br>N-Q<br>T-Y | 4            |
| 2               | 2-899-111   |                     | .                       |   |   |   |   |   |   | B-E<br>H-K<br>N-Q<br>T-Y | 4            |
| 2A              | 8-899-2     |                     | .                       |   |   |   |   |   |   | ALMRZ<br>CA              | 2            |
| 2A              | 8-060-02    |                     | .                       |   |   |   |   |   |   | B-E<br>N-Q               | 2            |
| 2A              | 2-899-111   |                     | .                       |   |   |   |   |   |   | B-E<br>N-Q               | 2            |
| 2A              | 8-060-07    |                     | .                       |   |   |   |   |   |   | G-K<br>S-YBA<br>DA       | 2            |
| 3               | 8-060-02    |                     | .                       |   |   |   |   |   |   |                          | 1            |
| 3               | 2-899-211   |                     | .                       |   |   |   |   |   |   |                          | 1            |
| 4               | 8-060-07    |                     | .                       |   |   |   |   |   |   |                          | 1            |
| 4               | 2-899-113   |                     | .                       |   |   |   |   |   |   |                          | 1            |
| 5               | 69-60177-21 |                     | .                       |   |   |   |   |   |   |                          | 1            |
| 5               | 69-60177-1  |                     | .                       |   |   |   |   |   |   |                          | 1            |
| 5               | 65-58250-25 |                     | .                       |   |   |   |   |   |   |                          | 1            |
| 6               | 65-58250-11 |                     | .                       |   |   |   |   |   |   |                          | 1            |
| 7               | 65-58250-29 |                     | .                       |   |   |   |   |   |   |                          | 2            |

OVERHAUL MANUAL

| FIG. & ITEM NO. | PART NO.    | AIRLINE PART NUMBER | N O M E N C L A T U R E |   |   |   |   |   |   | USE CODE | QTY PER ASSY |
|-----------------|-------------|---------------------|-------------------------|---|---|---|---|---|---|----------|--------------|
|                 |             |                     | 1                       | 2 | 3 | 4 | 5 | 6 | 7 |          |              |
| 1101-8          | 65-58250-31 |                     | .                       |   |   |   |   |   |   |          | 1            |
|                 |             |                     |                         |   |   |   |   |   |   |          |              |
| 8               | 65-58250-27 |                     | .                       |   |   |   |   |   |   |          | 1            |
|                 |             |                     |                         |   |   |   |   |   |   |          |              |
| 9               | 65-58250-23 |                     | .                       |   |   |   |   |   |   |          | 1            |
| 10              | BACR13CE2   |                     | .                       |   |   |   |   |   |   | AGLMR    | 1            |
|                 |             |                     |                         |   |   |   |   |   |   | SZCA     |              |
| 10              | KD4A        |                     | .                       |   |   |   |   |   |   | BCHIN    | 1            |
|                 |             |                     |                         |   |   |   |   |   |   | OTUBA    |              |
| 10              | BACR13CG2   |                     | .                       |   |   |   |   |   |   | DEJKP    | 1            |
|                 |             |                     |                         |   |   |   |   |   |   | QV-Y     |              |
| 10              | BACR13CG1   |                     | .                       |   |   |   |   |   |   | DEJKP    | 1            |
|                 |             |                     |                         |   |   |   |   |   |   | QV-Y     |              |
| 10              | KD4A        |                     | .                       |   |   |   |   |   |   | DEJKP    | 1            |
|                 |             |                     |                         |   |   |   |   |   |   | QV-Y     |              |
| 11              | KD4A        |                     | .                       |   |   |   |   |   |   | ABCG     | 3            |
|                 |             |                     |                         |   |   |   |   |   |   | HIL-O    |              |
|                 |             |                     |                         |   |   |   |   |   |   | R-UZ     |              |
|                 |             |                     |                         |   |   |   |   |   |   | -CA      |              |
| 11              | BACR13CG2   |                     | .                       |   |   |   |   |   |   | DEJKP    | 3            |
|                 |             |                     |                         |   |   |   |   |   |   | QV-Y     |              |
| 11              | BACR13CG1   |                     | .                       |   |   |   |   |   |   | DEJKP    | 3            |
|                 |             |                     |                         |   |   |   |   |   |   | QV-Y     |              |
| 11              | KD4A        |                     | .                       |   |   |   |   |   |   | DEJKP    | 3            |
|                 |             |                     |                         |   |   |   |   |   |   | QV-Y     |              |
| 12              | JD4A        |                     | .                       |   |   |   |   |   |   | AGLMR    | 1            |
|                 |             |                     |                         |   |   |   |   |   |   | SZCA     |              |
| 12              | KD4A        |                     | .                       |   |   |   |   |   |   | BCHIN    | 1            |
|                 |             |                     |                         |   |   |   |   |   |   | OTUBA    |              |
|                 |             |                     |                         |   |   |   |   |   |   | CA       |              |
| 12              | BACR13CG2   |                     | .                       |   |   |   |   |   |   | DEJKP    | 1            |
|                 |             |                     |                         |   |   |   |   |   |   | QV-Y     |              |
| 12              | BACR13CG1   |                     | .                       |   |   |   |   |   |   | DEJKP    | 1            |
|                 |             |                     |                         |   |   |   |   |   |   | QV-Y     |              |
| 12              | KD4A        |                     | .                       |   |   |   |   |   |   | DEJKP    | 1            |
|                 |             |                     |                         |   |   |   |   |   |   | QV-Y     |              |
| 13              | JD4A        |                     | .                       |   |   |   |   |   |   |          | 2            |
| 14              | BR18AXC2V3  |                     | .                       |   |   |   |   |   |   | AGLMR    | 1            |
|                 |             |                     |                         |   |   |   |   |   |   | SZCA     |              |
| 14              | KD4A        |                     | .                       |   |   |   |   |   |   | BCHIN    | 1            |
|                 |             |                     |                         |   |   |   |   |   |   | OTUBA    |              |
|                 |             |                     |                         |   |   |   |   |   |   | DA       |              |



OVERHAUL MANUAL

| FIG. & ITEM NO. | PART NO.               | AIRLINE PART NUMBER | N O M E N C L A T U R E |   |   |   |   |   |   | USE CODE      | QTY PER ASSY |
|-----------------|------------------------|---------------------|-------------------------|---|---|---|---|---|---|---------------|--------------|
|                 |                        |                     | 1                       | 2 | 3 | 4 | 5 | 6 | 7 |               |              |
| 1101-14         | BACR13CG2              |                     | .                       |   |   |   |   |   |   | DEJKP         | 1            |
| 14              | BACR13CG1              |                     | .                       |   |   |   |   |   |   | QV-Y<br>DEJKP | 1            |
| 14              | KD4A                   |                     | .                       |   |   |   |   |   |   | QV-Y<br>DEJKP | 1            |
| 14A             | 69-61700-1             |                     | .                       |   |   |   |   |   |   | QV-Y<br>DEJKP | 6            |
| 15              | 10-60450-3<br>(BOEING) |                     | .                       |   |   |   |   |   |   | DEJKP         | 4            |
| 16              | 9524-6506              |                     | .                       |   |   |   |   |   |   |               | 1            |
| 17              | C2006                  |                     | .                       |   |   |   |   |   |   |               | 2            |
| 18              | MS25041-6              |                     | .                       |   |   |   |   |   |   |               | 2            |
| 19              | MS18209-387            |                     | .                       |   |   |   |   |   |   |               | 2            |
| 20              | 69-34180-30            |                     | .                       |   |   |   |   |   |   |               | 1            |
| 21              | 69-34180-13            |                     | .                       |   |   |   |   |   |   |               | 1            |
| 22              | 69-31184-39            |                     | .                       |   |   |   |   |   |   |               | 1            |
| 23              | 65-52811-22            |                     | .                       |   |   |   |   |   |   | A             | 1            |
| 23              | 65-52811-24            |                     | .                       |   |   |   |   |   |   | BDBADA        | 1            |
| 23              | 65-52811-26            |                     | .                       |   |   |   |   |   |   | CE            | 1            |
| 23              | 65-52811-22            |                     | .                       |   |   |   |   |   |   | G             | 1            |
| 23              | 65-52811-24            |                     | .                       |   |   |   |   |   |   | HJ            | 1            |
| 23              | 65-52811-26            |                     | .                       |   |   |   |   |   |   | IK            | 1            |
| 23              | 65-52811-72            |                     | .                       |   |   |   |   |   |   | L             | 1            |
| 23              | 65-52811-22            |                     | .                       |   |   |   |   |   |   | M             | 1            |
| 23              | 65-52811-24            |                     | .                       |   |   |   |   |   |   | NP            | 1            |
| 23              | 65-52811-26            |                     | .                       |   |   |   |   |   |   | OQ            | 1            |
| 23              | 65-52811-72            |                     | .                       |   |   |   |   |   |   | R             | 1            |
| 23              | 65-52811-22            |                     | .                       |   |   |   |   |   |   | S             | 1            |
| 23              | 65-52811-24            |                     | .                       |   |   |   |   |   |   | TV            | 1            |
| 23              | 65-52811-26            |                     | .                       |   |   |   |   |   |   | UW            | 1            |
| 23              | 65-52811-24            |                     | .                       |   |   |   |   |   |   | X             | 1            |
| 23              | 65-52811-24            |                     | .                       |   |   |   |   |   |   | Y             | 1            |
| 23              | 65-52811-55            |                     | .                       |   |   |   |   |   |   | ZCA           | 1            |
| 24              | NAS600-7P              |                     | .                       |   |   |   |   |   |   | ABCGH         | 28           |
|                 |                        |                     |                         |   |   |   |   |   |   | IL-O          |              |
|                 |                        |                     |                         |   |   |   |   |   |   | R-UZ-         |              |
|                 |                        |                     |                         |   |   |   |   |   |   | DA            |              |

OVERHAUL MANUAL

| FIG. & ITEM NO. | PART NO.     | AIRLINE PART NUMBER | N O M E N C L A T U R E                 |   |   |   |   |   |   | USE CODE                         | QTY PER ASSY |
|-----------------|--------------|---------------------|---|---|---|---|---|---|---|----------------------------------|--------------|
|                 |              |                     | 1                                       | 2 | 3 | 4 | 5 | 6 | 7 |                                  |              |
| 1101-           |              |                     |   |   |   |   |   |   |   |                                  |              |
| 24              | NAS600-9P    |                     | . SCREW (USED WITH 65-73698-58 ONLY)    |   |   |   |   |   |   | A-E                              | 28           |
| 24              | NAS600-9P    |                     | . SCREW                                 |   |   |   |   |   |   | G-DA<br>DEJKP<br>QV-Y            | 28           |
| 25              | BACN10DN40   |                     | . NUT                                   |   |   |   |   |   |   | A-E<br>G-DA                      | 28           |
| 26              | 582553-1     |                     | . CONNECTOR, V00779                     |   |   |   |   |   |   |                                  | 11           |
| 27              | 582585-1     |                     | . CONNECTOR, V00779                     |   |   |   |   |   |   |                                  | 3            |
| 28              | BACG20ZA600  |                     | . GROMMET                               |   |   |   |   |   |   |                                  | 1            |
| 29              | 4444B4       |                     | . TERMINAL, V88245                      |   |   |   |   |   |   |                                  | 13           |
| 30              | 4445B4       |                     | . TERMINAL, V88245                      |   |   |   |   |   |   | AGLMR<br>SZCA                    | 2            |
| 31              | 1N4385       |                     | . DIODE, V14936                         |   |   |   |   |   |   |                                  | 10           |
| 32              | RC32GF102J   |                     | . RESISTOR, 1.0K OHM ( $\pm 5\%$ ), 1 W |   |   |   |   |   |   | AGLMR<br>SZCA                    | 1            |
| 32              | RC32GF332J   |                     | . RESISTOR, 3.3K OHM ( $\pm 5\%$ ), 1 W |   |   |   |   |   |   | B-E<br>H-K<br>N-Q<br>T-YBA<br>DA | 1            |
| 33              | BACN10DN40   |                     | . NUT                                   |   |   |   |   |   |   |                                  | 8            |
| 34              | NAS600-4P    |                     | . SCREW                                 |   |   |   |   |   |   |                                  | 8            |
| 35              | 69-48983-4   |                     | . BRACKET                               |   |   |   |   |   |   | AGLMR<br>SZCA                    | 1            |
| 35              | 69-48983-6   |                     | . BRACKET                               |   |   |   |   |   |   | B-E<br>H-K<br>N-Q<br>T-YBA<br>DA | 1            |
| 36              | BACG20ZA250  |                     | . GROMMET                               |   |   |   |   |   |   |                                  | 1            |
| 37              | BACG20ZA375  |                     | . GROMMET                               |   |   |   |   |   |   |                                  | 1            |
| 38              | HRCC5KM      |                     | . SOCKET, V91663                        |   |   |   |   |   |   | AGLMR<br>SZCA                    | 1            |
| 38              | 18-0006-0000 |                     | . SOCKET, V05574                        |   |   |   |   |   |   | B-E<br>H-K<br>N-Q<br>T-YBA<br>DA | 1            |
| 38              | BACS16W1     |                     | . SOCKET, (OPT)                         |   |   |   |   |   |   | B-E<br>H-K<br>N-Q<br>T-Y         | 1            |
| 39              | 18-0006-0000 |                     | . SOCKET, V05574                        |   |   |   |   |   |   |                                  | 3            |
| 39              | BACS16W1     |                     | . SOCKET (OPT)                          |   |   |   |   |   |   |                                  | 3            |



OVERHAUL MANUAL

| FIG. & ITEM NO. | PART NO.                | AIRLINE PART NUMBER | N O M E N C L A T U R E |   |   |   |   |   |   | USE CODE | QTY PER ASSY |   |   |   |   |   |                                  |   |   |                |   |   |   |  |   |   |   |   |   |   |   |   |  |   |
|-----------------|-------------------------|---------------------|-------------------------|---|---|---|---|---|---|----------|--------------|---|---|---|---|---|----------------------------------|---|---|----------------|---|---|---|--|---|---|---|---|---|---|---|---|--|---|
|                 |                         |                     | 1                       | 2 | 3 | 4 | 5 | 6 | 7 |          |              |   |   |   |   |   |                                  |   |   |                |   |   |   |  |   |   |   |   |   |   |   |   |  |   |
| 1101-40         | 18-0007-0000            |                     | .                       | S | O | C | K | E | T | ,        | V            | 0 | 5 | 5 | 7 | 4 | AGLMR<br>SZCA                    | 1 |   |                |   |   |   |  |   |   |   |   |   |   |   |   |  |   |
| 40              | BACS16X1                |                     | .                       | S | O | C | K | E | T |          | (            | O | P | T | ) |   | AGLMR<br>SZCA                    | 1 |   |                |   |   |   |  |   |   |   |   |   |   |   |   |  |   |
| 40              | 18-0006-0000            |                     | .                       | S | O | C | K | E | T | ,        | V            | 0 | 5 | 5 | 7 | 4 | B-E<br>H-K<br>N-Q<br>T-YBA<br>DA | 1 |   |                |   |   |   |  |   |   |   |   |   |   |   |   |  |   |
| 40              | BACS16W1                |                     | .                       | S | O | C | K | E | T |          | (            | O | P | T | ) |   | B-E<br>H-K<br>N-Q<br>T-YBA<br>DA | 1 |   |                |   |   |   |  |   |   |   |   |   |   |   |   |  |   |
| 41              | 18-0007-0000            |                     | .                       | S | O | C | K | E | T | ,        | V            | 0 | 5 | 5 | 7 | 4 |                                  | 2 |   |                |   |   |   |  |   |   |   |   |   |   |   |   |  |   |
| 41              | BACS16X1                |                     | .                       | S | O | C | K | E | T |          | (            | O | P | T | ) |   |                                  | 2 |   |                |   |   |   |  |   |   |   |   |   |   |   |   |  |   |
| 42              | VB16/1UE20-42           |                     | .                       | S | O | C | K | E | T | ,        | V            | 0 | 5 | 5 | 7 | 4 | AGLMR<br>SZCA                    | 1 |   |                |   |   |   |  |   |   |   |   |   |   |   |   |  |   |
| 42              | 18-0006-0000            |                     | .                       | S | O | C | K | E | T | ,        | V            | 0 | 5 | 5 | 7 | 4 | B-E<br>H-K<br>N-Q<br>T-YBA<br>DA | 1 |   |                |   |   |   |  |   |   |   |   |   |   |   |   |  |   |
| 42              | BACS16W1                |                     | .                       | S | O | C | K | E | T |          | (            | O | P | T | ) |   | B-E<br>H-L<br>N-Q<br>T-YBA<br>DA | 1 |   |                |   |   |   |  |   |   |   |   |   |   |   |   |  |   |
| 43              | 000300-0598             |                     | .                       | S | O | C | K | E | T | ,        | V            | 0 | 5 | 5 | 7 | 4 |                                  | 4 |   |                |   |   |   |  |   |   |   |   |   |   |   |   |  |   |
| 44              | 000300-0596             |                     | .                       | S | O | C | K | E | T | ,        | V            | 0 | 5 | 5 | 7 | 4 |                                  | 1 |   |                |   |   |   |  |   |   |   |   |   |   |   |   |  |   |
| 45              | BACN10DN26              |                     | .                       | N | U | T |   |   |   |          |              |   |   |   |   |   |                                  | 2 |   |                |   |   |   |  |   |   |   |   |   |   |   |   |  |   |
| 46              | MS35190-213             |                     | .                       | S | C | R | E | W |   |          |              |   |   |   |   |   |                                  | 2 |   |                |   |   |   |  |   |   |   |   |   |   |   |   |  |   |
| 47              | RH5-5                   |                     | .                       | R | E | S | I | S | T | O        | R            | , | 5 |   | O | H | M                                | S | , | 3              | % | , | 5 |  | W | , | V | 9 | 1 | 6 | 3 | 7 |  | 1 |
| 48              | 22NM107-62              |                     | .                       | N | U | T | , | V | 7 | 2        | 9            | 6 | 2 |   |   |   |                                  |   | 1 |                |   |   |   |  |   |   |   |   |   |   |   |   |  |   |
| 49              | AN960PD6L               |                     | .                       | W | A | S | H | E | R |          |              |   |   |   |   |   |                                  | 2 |   |                |   |   |   |  |   |   |   |   |   |   |   |   |  |   |
| 50              | NAS514P632-()           |                     | .                       | S | C | R | E | W |   |          |              |   |   |   |   |   |                                  | 1 |   |                |   |   |   |  |   |   |   |   |   |   |   |   |  |   |
| 51              | BACN10DN40              |                     | .                       | N | U | T |   |   |   |          |              |   |   |   |   |   |                                  | 4 |   |                |   |   |   |  |   |   |   |   |   |   |   |   |  |   |
| 52              | NAS514P440-6            |                     | .                       | S | C | R | E | W |   |          |              |   |   |   |   |   |                                  | 4 |   |                |   |   |   |  |   |   |   |   |   |   |   |   |  |   |
| 53              | DPX2MB67P67P<br>34B0058 |                     | .                       | C | O | N | N | E | C | T        | O            | R | , | V | 7 | 1 | 4                                | 6 | 8 | ALMRZ<br>CA    | 1 |   |   |  |   |   |   |   |   |   |   |   |  |   |
| 53              | DPX2MB67P67P<br>34B0059 |                     | .                       | C | O | N | N | E | C | T        | O            | R | , | V | 7 | 1 | 4                                | 6 | 8 | BDNPXY<br>BADA | 1 |   |   |  |   |   |   |   |   |   |   |   |  |   |

| FIG. & ITEM NO. | PART NO.                | AIRLINE PART NUMBER | N O M E N C L A T U R E |   |   |   |   |   |   | USE CODE                          | QTY PER ASSY |
|-----------------|-------------------------|---------------------|-------------------------|---|---|---|---|---|---|-----------------------------------|--------------|
|                 |                         |                     | 1                       | 2 | 3 | 4 | 5 | 6 | 7 |                                   |              |
| 1101-53         | DPX2MB67P67P<br>34B0060 |                     | .                       |   |   |   |   |   |   | CEOQ                              | 1            |
| 53              | DPX2MB67P67P<br>34B0065 |                     | .                       |   |   |   |   |   |   | GHJST<br>V                        | 1            |
| 53              | DPX2MB67P67P<br>34B0064 |                     | .                       |   |   |   |   |   |   | IKUW                              | 1            |
| 54              | BACS38C100C3            |                     | .                       |   |   |   |   |   |   |                                   | 14           |
| 55              | 582507-1                |                     | .                       |   |   |   |   |   |   |                                   | 20           |
| 56              | NAS67904W               |                     | .                       |   |   |   |   |   |   | AGLMR<br>SZCA                     | 4            |
| 56              | BACN10DN40              |                     | .                       |   |   |   |   |   |   | B-E<br>H-K<br>N-Q<br>T-YBA<br>DA  | 4            |
| 57              | BACS12BF04-8            |                     | .                       |   |   |   |   |   |   | AGMSZ<br>CA                       | 4            |
| 57              | BACS12BE04-8            |                     | .                       |   |   |   |   |   |   | LR                                | 4            |
| 57              | NAS514P440-8P           |                     | .                       |   |   |   |   |   |   | B-E<br>H-K<br>N-Q<br>T-WY<br>BADA | 4            |
| 58              | 411GMF1903-4            |                     | .                       |   |   |   |   |   |   |                                   | 2            |
| 59              | BACT12AC                |                     | .                       |   |   |   |   |   |   |                                   | AR           |
| 60              | 66143-2LP               |                     | .                       |   |   |   |   |   |   |                                   | AR           |
| 61              | BAC27DEX861             |                     | .                       |   |   |   |   |   |   | ADEG<br>J-M<br>P-SV-Y<br>ZCA      | 1            |

\*[1] No Boeing part number assigned

OVERHAUL MANUAL

FIGURE 1101 REFERENCE DESIGNATION INDEX (SEE SCHEMATIC DIAGRAM)

| REFERENCE DESIGNATION     | PART NUMBER  | ITEM NO. |
|---------------------------|--------------|----------|
| A1, A2, A4, A8            | 2-899-2      | 2        |
| A1, A2, A4, A8            | 2-899-111    | 2        |
| A1, A2, A4, A8            | *8-060-02    | 2        |
| A3, A7                    | 2-899-2      | 2A       |
| A3, A7                    | 2-899-111    | 2A       |
| A3, A7                    | 8-060-07     | 2A       |
| A3, A7                    | *8-060-02    | 2A       |
| A5                        | *2-899-111   | 3        |
| A5                        | 2-899-211    | 3        |
| A5                        | *8-060-02    | 3        |
| A6                        | *2-899-113   | 4        |
| A6                        | 2-899-213    | 4        |
| A6                        | *8-060-07    | 4        |
| A9                        | 65-58250-25  | 5        |
| A9                        | *69-60177-21 | 5        |
| A9                        | 69-60177-1   | 5        |
| A10                       | 65-58250-11  | 6        |
| A11, A12                  | 65-58250-29  | 7        |
| A13                       | 65-58250-27  | 8        |
| A13                       | *65-58250-31 | 8        |
| A14                       | 65-58250-23  | 9        |
| CR1 THRU CR10             | 1N4385       | 31       |
| DS1, DS2                  | MS25041-6    | 18       |
| J1 THRU J8, J11, J13, J14 | 582553-1     | 26       |
| J9, J10, J12              | 582585-1     | 27       |
| K1                        | BACR13CE2    | 10       |
| K1                        | KD4A         | 10       |
| K1                        | *BACR13CG2   | 10       |
| K1                        | BACR13CG1    | 10       |
| K2, K3, K4                | KD4A         | 11       |
| K2, K3, K4                | *BACR13CG2   | 11       |
| K2, K3, K4                | BACR13CG1    | 11       |
| K5                        | KD4A         | 12       |
| K5                        | JD4A         | 12       |
| K5                        | *BACR13CG2   | 12       |
| K5                        | BACR13CG1    | 12       |
| K6, K7                    | JD4A         | 13       |
| K8                        | BR18AXC2V3   | 14       |
| K8                        | KD4A         | 14       |
| K8                        | *BACR13CG2   | 14       |
| K8                        | BACR13CG1    | 14       |
| K9 THRU K12               | 10-60450-3   | 15       |



OVERHAUL MANUAL

| FIGURE 1101 REFERENCE DESIGNATION INDEX (SEE SCHEMATIC DIAGRAM) |                     |          |
|---|---------------------|----------|
| REFERENCE DESIGNATION   | PART NUMBER         | ITEM NO. |
| K13   | 9524-6506           | 16       |
| L1, L2  | MS25041-6           | 18       |
| P1A, P1B  | DPX2MB67P67P34B0058 | 53       |
| P1A, P1B  | DPX2MB67P67P34B0059 | 53       |
| P1A, P1B  | DPX2MB67P67P34B0060 | 53       |
| P1A, P1B  | DPX2MB67P67P34B0064 | 53       |
| P1A, P1B  | DPX2MB67P67P34B0065 | 53       |
| R1  | RC32GF102J          | 32       |
| R1  | RC32GF332J          | 32       |
| R2  | RH5-5               | 47       |
| S1, S2  | C2006               | 17       |
| TB1, TB2  | 411GMF1903-4        | 58       |
| XK1   | HRCC5KM             | 38       |
| XK1   | *18-0006-000        | 38       |
| XK1   | BACS16W1            | 38       |
| XK2, XK3, XK4   | *18-0006-0000       | 39       |
| XK2, XK3, XK4   | BACS16W1            | 39       |
| XK5   | *18-0006-000        | 40       |
| XK5   | BACS16W1            | 40       |
| XK5   | *18-0007-0000       | 40       |
| XK5   | BACS16X1            | 40       |
| XK6, XK7  | *18-0007-0000       | 41       |
| XK5, XK7  | BACS16X1            | 41       |
| XK8   | VB16/1UE20-42       | 42       |
| XK8   | *18-0006-0000       | 42       |
| XK8   | BACS16W1            | 42       |
| XK9 THRU XK12   | 000300-0598         | 43       |
| XK13  | 000300-0596         | 44       |

\*PREFERRED PART

VENDORS

V00779 AMP, INC., 2800 FULLING MILL, MIDDLETOWN, PENNSYLVANIA 17057

V05574 VIKING ELECTRONICS INC., 9250 INDEPENDENCE AVENUE, CHATSWORTH,  
CALIFORNIA 91311

V08748 ELDEC CORP., 16700 13TH PLACE WEST, P.O. BOX 100, LYNNWOOD,  
WASHINGTON 98036

V14936 GENERAL INSTRUMENT CORP., POWER SEMI-CONDUCTOR DIV., 600 WEST  
JOHN STREET, HICKSVILLE, NEW YORK 11802

V35344 LEACH CORPORATION, CONTROL PRODUCTS DIV., 6900 ORANGE THORPE AVE,  
BUENA PARK, CALIFORNIA 90620-1351

V71468 ITT CANNON DIV. OF ITT CORP., 666 EAST DYER ROAD, SANTA ANA,  
CALIFORNIA 92702

V72962 ELASTIC STOPNUT, A DIV. OF HARTFORD INDUSTRIES INC., 2330 VAUXHALL  
ROAD, UNION, NEW JERSEY 07083-5038

V73949 GUARDIAN ELECTRIC MFG. COMPANY, 1425 LAKE AVE., WOODSTOCK, ILLINOIS  
60098

V75382 DIALIGHT CORP. MANASQUAN DIV., 1913 ATLANTIC AVE., MANASQUAN, NEW  
YORK 08736-1005

V81640 EATON CORP., AEROSPACE AND COMMERCIAL CONTROL DIV., 2250 WHITFIELD  
AVE E., SARASOTA, FLORIDA 34243-9703

V82050 ESTERLINE ELECTRONICS CORP., 3501 HARBOR BLVD, P.O. BOX 1499, COSTA  
MESA, CALIFORNIA 92626

V88245 WINCHESTER ELECTRONICS, LITTON SYSTEMS INC., USECO DIV., 13536  
SATICOY ST., VAN NUYS, CALIFORNIA 91409

V91637 DALE ELECTRONICS, INC., P.O. BOX 609, 1122 23RD STREET, COLUMBUS,  
NEBRASKA 68601-3632

V91663 ARMEL ELECTRONICS INC., 1601-75TH STREET, NORTH BERGEN, NEW JERSEY  
07047-4046