

GPA Group plc

PAGE	DATE	CODE	PAGE	DATE	CODE	PAGE	DATE	CODE
CHAPTER 80 TAB			80-11-01		CONT.			
			605	SEP 28/04	RO2A			
			606	BLANK				
STARTING			80-11-02					
EFFECTIVE PAGES			401	JUN 20/93	R01			
SEE LAST PAGE OF LIST FOR			402	JUN 20/93	R01			
NUMBER OF PAGES			403	JUN 20/93	R01			
80-CONTENTS			404	MAY 28/01	R01			
1	JAN 28/00	RGUI	405	JUN 20/93	R01			
2	BLANK		406	JAN 28/03	R01			
80-11-00			80-11-07					
1	DEC 20/90	R01	401	MAR 20/94	R01			
2	JAN 28/02	R01	402	MAR 20/94	R01			
3	JUN 20/93	R01	403	SEP 20/93	R01			
4	JUN 20/93	R01	404	MAR 20/94	R01			
5	JAN 28/02	R01	80-11-08					
6	JAN 28/02	R02	201	MAY 20/98	R01			
7	JUN 20/93	R01	202	JUN 20/93	R01			
8	JAN 28/00	R01	203	MAY 20/98	R01			
9	JAN 28/00	R01	204	JUN 20/96	R01			
10	JAN 28/00	R01	80-11-09					
80-11-00			401	JUN 20/93	R01			
101	SEP 20/92	R02	402	JUN 20/93	R01			
102	SEP 20/92	R02	403	JUN 20/93	R01			
80-11-00			404	BLANK				
501	JAN 20/98	R01						
502	JAN 20/98	R01						
503	JAN 20/98	R01						
504	JAN 20/98	R01						
505	JAN 20/98	R01						
506	MAY 28/01	R01						
507	JAN 20/98	R01						
508	JAN 20/98	R01						
509	JAN 20/98	R01						
510	BLANK							
80-11-00								
601	JUN 20/93	R01						
602	JUN 20/93	R01						
80-11-01								
401	JUN 20/93	R01						
402	SEP 20/91	R01						
403	SEP 20/94	R01						
404	SEP 28/04	R01						
405	SEP 28/04	R01						
406	SEP 28/07	R01						
80-11-01								
601	JAN 28/02	R01A						
602	JAN 28/02	R01A						
603	SEP 28/03	R03A						
604	SEP 20/93	R04A						

R = REVISED, A = ADDED OR D = DELETED
F = FOLDOUT PAGE
32
JAN 20/09

D633N132

CHAPTER 80
EFFECTIVE PAGES
R PAGE 1
LAST PAGE

CHAPTER 80 - STARTING

TABLE OF CONTENTS

<u>Subject</u>	<u>Chapter Section Subject</u>	<u>Page</u>	<u>Effectivity</u>
<u>STARTING</u>	80-00-00		
<u>CRANKING</u>	80-10-00		
ENGINE STARTING SYSTEM	80-11-00		
Description and Operation		1	ALL
General		1	
Component Details		1	
Pneumatic Starter		1	
Starter Control Valve		3	
Starter QAD (Quick Attach-Detach) Adapter		3	
Operation		5	
Control		10	
Functional Description		5	
Component Location		101	ALL
Component Index			
Component Location			
Adjustment/Test		501	ALL
Operational Test - Engine		501	
Starting System			
System Test - Engine Starting System		503	
Inspection/Check		601	ALL
ADAPTER - STARTER QAD	80-11-07		
Removal/Installation		401	ALL
FILTER - STARTER CONTROL VALVE	80-11-08		
Maintenance Practices		201	ALL
Clean the Filter		201	
Install the Filter		203	
Remove the Filter		201	
PANEL - ENGINE START/RAT CONTROL	80-11-09		
Removal/Installation		401	ALL
STARTER - PNEUMATIC	80-11-01		
Removal/Installation		401	ALL
Inspection/Check		601	ALL
VALVE - STARTER CONTROL	80-11-02		
Removal/Installation		401	ALL

80-CONTENTS

ENGINE STARTING SYSTEM – DESCRIPTION AND OPERATION

1. General

- A. The engine starting system supplies the input to turn the engine high pressure (HP) compressor rotor to a speed at which engine light-up can occur. The system is used for ground starts, and can also be used for in-flight starts.
- B. The start system includes the engine-mounted components that follow:
 - (1) A pneumatic starter is installed on the forward face of the high-speed (HS) external gearbox.
 - (2) A starter control valve is installed on the lower left side of the low pressure (LP) compressor (fan) case.
 - (3) The related air ducting and electrical wiring.
- C. The HP compressor rotor assembly is turned by the starter through the HS external gearbox. The starter is a pneumatically driven motor, connected by ducts to the bleed air system of the aircraft. Air for the starter can be supplied by a ground supply, the Auxiliary Power Unit (APU) or from the other engine.
- D. The supply of air to the starter is controlled by the start valve which is a pneumatically operated, electrically controlled, butterfly valve. The start valve is electrically connected to the start switches on the pilots overhead instrument panel P5. In the flight compartment, a VALVE position indicator and the Engine Indication and Crew Alerting System (EICAS) show the position of the valve.
- E. All the ducting is designed for high pressures and temperatures, and gimbal joints are used to permit movement. Air leakage is prevented by E-type seals installed between all the mating flanges. The flanges are attached by coupling clamps. Supports attach the ducting to the LP compressor case.

2. Component Details

- A. Pneumatic Starter (Fig. 1)
 - (1) The starter is a pneumatically driven turbine that accelerates the engine HP compressor rotor to the speed that is necessary to start the engine. The unit is mounted on the front face of the HS external gearbox.
 - (2) The starter is a turbine, a reduction gear train, a clutch and an output drive shaft that is contained in a case. It has an air inlet and an exhaust.
 - (3) The single-stage axial flow turbine is connected to the output drive shaft through a reduction gear train and a clutch. Pawls located on the output drive shaft engage with a ratchet ring on the rear face of the gear train hub. Leaf springs hold the pawls down to form a centrifugal clutch. The splined output drive shaft engages with the HS external gearbox which turns the engine HP compressor rotor assembly.
 - (4) The starter case includes a containment ring which will contain a failure of the turbine assembly.



EFFECTIVITY

ALL

80-11-00

R01

Page 1
Dec 20/90



PNEUMATIC STARTER INTERNAL FUNCTION
(ELONGATED FOR CLARITY)

1 ADAPTER INSTALLED ON STARTERS
POST-RR-SB 80-B009

B

Pneumatic Starter
Figure 1

EFFECTIVITY	
ALL	

80-11-00

R01

Page 2
Jan 28/02

- (5) A plug in the starter case permits oil replenishment, and a sight glass allows oil level checking. A drain plug with a magnetic plug lets you do an inspection for signs of bearing failure.
- B. Starter Control Valve (Fig. 2)
- (1) The starter control valve is a pneumatically operated, electrically controlled, shut-off valve located on the lower left side of the LP compressor (fan) case.
 - (2) The start valve controls the air flow from the starter air duct to the starter motor. The start valve is a butterfly type valve that is contained in a cylindrical valve body. It has in-line flanged end connectors, an actuator, a solenoid valve and a pressure controller.
 - (3) The butterfly valve is held in the valve body by a shaft that turns in anti-seize bushings. An interlocking sealing ring is used on the butterfly valve to keep air leakage between the valve and the valve body to a minimum.
 - (4) The end of the valve shaft has a visual position indicator which also operates an electrical position switch.
 - (5) The actuator is two pistons of different areas installed on a common shaft in a cylinder. The assembly is held in the closed position by a spring. Movement of the valve shaft is transmitted through a linkage to the butterfly valve shaft.
 - (6) The solenoid valve is a ball valve, a spring loaded plunger and an electrically operated solenoid. A manually operated override plunger is on the body at the opposite end of the solenoid.
 - (7) The pressure controller is a double-diaphragm piston, spring loaded, with a shaft that connects it to a ball-type servo relief valve.
 - (8) The electrical position switch sends a signal, open or closed, to the start relay circuit. If the position of the valve does not agree with the position of the engine start switch, the starter control VALVE light will come on.
- C. Starter QAD (Quick Attach-Detach) Adapter
- (1) The starter is installed to a quick attach-detach (QAD) adapter with a coupling clamp. The adapter is installed on the gearbox front face. A locating dowel is used to make sure the alignment of the adapter is correct.


EFFECTIVITY

ALL

80-11-00

R01

Page 3
Jun 20/93



51106

Starter Control Valve
Figure 2

EFFECTIVITY	
	ALL

80-11-00

52582

3. Operation

A. Functional Description (Fig. 3)

(1) Engine Start - Auxiliary Power Unit (APU)

- (a) With the APU at a governed speed and the APU bleed air switch open (Ref 49-11-00), bleed air is supplied to pressurize the airplane pneumatic system. The isolation valve must be open, and the pack valve switches must be in the valve closed position (Ref 36-11-00). When the engine start switch is moved to GND, electrical power is supplied to the applicable starter control valve. The solenoid valve on the starter control valve opens. The starter control valve position indicator switch sends a valve open signal to the start relay circuit.
- (b) Air, immediately upstream of the butterfly valve (Fig. 4), is filtered and pushed through an orifice in the solenoid valve. Air is also let in to the smaller piston of the double-acting actuator. When the solenoid is energized, the ball valve opens to let air into the larger piston while it closes the vent port. The air that pushes on the larger piston has more force than the combined force of the upstream air pressure that pushes on the smaller piston and the actuator spring. Movement of the actuator is transmitted through a linkage to turn the butterfly valve to the open position.
- (c) Air, upstream of the pneumatic starter turbine nozzle area, gives the pressure controller a sensing pressure. As the sensed pressure increases to more than the spring load, the ball valve is unseated and lets some of the servo pressure air that pushes on the larger actuator piston vent. This causes the butterfly valve to close a small amount which reduces the pressure at the starter turbine nozzle.
- (d) When the starter control valve opens, compressed air enters the starter. The air goes in through the turbine and goes out of the starter through the air exhaust. The reduction gear train converts the high speed, low torque rotation of the turbine to low speed, high torque rotation of the gear train hub. The ratchet teeth of the gear hub engage the pawls of the output drive shaft to transmit drive to the HS external gearbox. This turns the engine HP compressor rotor assembly.


EFFECTIVITY

ALL


80-11-00

R01

Page 5
Jan 28/02



ELECTRICAL SCHEMATIC



VALVE SHOWN IN CLOSED POSITION

Starter Control Valve Schematic
Figure 4

51107

EFFECTIVITY
ALL

80-11-00

R01

Page 7
Jun 20/93

- (e) When the HP compressor speed is about 25% N3 RPM (minimum), the FUEL CONTROL switch is put to the RUN position to apply ignition and fuel flow.
 - (f) The starter continues to help the engine turn until the dedicated generator control unit removes the power to the engine start switch solenoid. The engine start switch returns to the AUTO position at about 47% N3 rpm. The solenoid valve is de-energized and the start control valve then closes. The air that pushes on the larger piston is then vented to the atmosphere through the vent. Air pressure and the actuator spring pressure that pushes on the smaller piston then closes the butterfly valve. A loss of air pressure will cause the butterfly valve to close because of the actuator spring.
 - (g) If the engine starter is still engaged above the engine RPM at which starter cutout should occur, a L(R) STARTER CUTOUT message will show on the upper EICAS display as a level B message.
 - (h) When the air supply to the starter is stopped, the pawls overrun the teeth on the gear train hub which lets the turbine turn until it stops. The engine HP compressor assembly, the HS external gearbox and the output drive shaft of the starter will continue to turn. When the output drive shaft of the starter gets to a given speed, the centrifugal force is more than the tension of the clutch leaf springs. This lets the pawls retract until they do not touch the teeth on the gear hub which disengages the output drive shaft from the starter turbine.
 - (i) ENGINES PRE SB 31-0035;
A position switch is used on the starter control valve to transmit the position of the valve. If the selected valve mode does not agree with the actual valve mode, an amber VALVE light on the overhead panel P5 will come on. L(R) ENG STARTER will show on the upper EICAS display as a level C message if the starter valve does not open in 6 seconds.
 - (j) ENGINES POST SB 31-0035;
A position switch is used on the starter control valve to transmit the position of the valve. If the selected valve mode does not agree with the actual valve mode, an amber VALVE light on the overhead panel P5 will come on. L(R) ENG STARTER will show on the upper EICAS display as a level C message if the starter valve does not open in 10 seconds.
- (2) Engine Start - Manual

EFFECTIVITY

ALL

80-11-00

R01

Page 8
Jan 28/00

WARNING: WHEN YOU OPERATE THE STARTER CONTROL VALVE MANUALLY, HAND AND ARM COVERS MUST BE USED. HEAT AND HIGH SPEED AIR FROM THE STARTER CAN CAUSE INJURIES TO PERSONS.

CAUTION: IF THE VALVE IS NOT CLOSED WHEN N3 GETS TO 50% RPM, THE STARTER CAN BE DAMAGED.

MANUAL OPERATION OF THE STARTER CONTROL VALVE WITHOUT AIR PRESSURE IN THE INLET DUCT CAN DAMAGE THE VALVE.

- (a) Make sure you have interphone communication between the person on the ramp and the person in the flight compartment.
- (b) Open the access door in the left fan cowl to get access to the starter control valve.
- (c) Do the normal engine start procedure along with these steps:
 - 1) If the starter control valve has an electrical failure to the solenoid, the valve may be opened manually with the manual override knob. When you push the knob in, it unseats the ball valve which lets air flow to the larger piston while it closes the vent.
 - 2) If the starter control valve has a mechanical failure to the actuator, put the start switch for the engine with the inoperative starter control valve in the GND position and tell the ground personnel to open and hold the manual override valve with a 1/2 inch deep socket and wrench.
 - a) When the N3 RPM gets to 50%, tell the ground personnel to close the valve.
 - b) Make sure the start switch moves to the AUTO position.
- (3) Engine Start - External Air Source
 - (a) Ground carts connected to the ground air source are used to run the starters. The procedure to start the engine is the same as when you use the APU as the air source.
- (4) Engine Start - Cross-Bleed Air
 - (a) Use the bleed air from the other engine to start the engine. The air supply pressure regulating and shut-off valve for the air source engine must be in the open position to supply bleed air to the pneumatic distribution system. The switches that control the air supply pressure regulating and shut-off valves are located on the overhead panel P5. The procedure to start the engine is the same as when you use the APU as the air source.
- (5) Engine Motoring
 - (a) The starter can be used to motor the engine. The engine may need to be motored to clear the engine gas path of remaining fuel or for other ground maintenance tasks. To motor an engine, the ignition circuit breakers must be open and the FUEL CONTROL switch put to the CUTOFF position. Put the engine start switch to the GND position.

EFFECTIVITY

ALL

80-11-00

R01

Page 9
Jan 28/00

B. Control

- (1) Make sure the applicable ENGINE START CONTROL and circuit breakers for the ignition system, on the overhead panel P11, are in the closed position.
- (2) Make sure the switch for the applicable isolation valve, on the overhead panel P5, is in the open position.
- (3) Make sure the valve switches for the air conditioning packs, on the overhead panel P5, are in the closed position.
- (4) Put the engine start switch, on the overhead panel P5, to the GND position.
 - (a) Make sure the starter control VALVE light goes on and then goes off.
 - (b) Make sure the N3 tachometer shows that the N3 RPM increases.
- (5) When N3 gets to 25% RPM, put the FUEL CONTROL switch to the RUN position.
- (6) When the N3 gets to 50% RPM make sure the engine start switch goes to the AUTO position.
- (7) Make sure the starter control VALVE light comes on and then goes off.

EFFECTIVITY

ALL

80-11-00


R01

Page 10
Jan 28/00

ENGINE STARTING SYSTEM



COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
ADAPTER - STARTER QAD	--	2	413AL,414AR, LEFT ENGINE FAN COWL, 423AL,424AR, RIGHT ENGINE FAN COWL	80-11-07
FILTER - STARTER CONTROL VALVE	--	2	413AL,414AR, LEFT ENGINE FAN COWL, 423AL,424AR, RIGHT ENGINE FAN COWL	80-11-08
PANEL - ENG START/RAT CONT, M10468		1	FLIGHT COMPARTMENT, P5	*
RELAYS - (31-01-36/101) LEFT ENGINE CONTROLS POWER, K10208 LEFT ENGINE START DISAGREE, K10209 LEFT ENGINE START 2, K10247 LEFT ENGINE START 3, K10248 LEFT ENGINE START TO STOP, K10212				
RELAYS - (31-01-37/101) RIGHT ENGINE CONTROLS POWER, K10220 RIGHT ENGINE START DISAGREE, K10221 RIGHT ENGINE START 2, K10250 RIGHT ENGINE START 3, K10251 RIGHT ENGINE START TO STOP, K10224				
STARTER - PNEUMATIC	--	2	413AL,414AR, LEFT ENGINE FAN COWL, 423AL,424AR, RIGHT ENGINE FAN COWL	80-11-01
SWITCH - LEFT ENGINE START, S3	--	1	FLIGHT COMPARTMENT, P5, ENGINE START/RAT CONTROL PANEL, M10468	*
SWITCH - RIGHT ENGINE START, S4	--	1	FLIGHT COMPARTMENT, P5, ENGINE START/RAT CONTROL PANEL, M10468	*
VALVE - STARTER CONTROL, V10008	--	2	413AL,414AR, LEFT ENGINE FAN COWL, 423AL,424AR, RIGHT ENGINE FAN COWL	80-11-08

* SEE THE WDM EQUIPMENT LIST



 Engine Starting System - Component Index
 Figure 101

80-11-00

R02

 Page 101
 Sep 20/92



FLIGHT COMPARTMENT



ENGINE START/RAT CONTROL PANEL, M10468
(B)

Engine Starting System - Component Location
Figure 102

EFFECTIVITY	ALL
-------------	-----

80-11-00

ENGINE STARTING SYSTEM – ADJUSTMENT/TEST

1. General

- A. An operational test and a system test are given for the engine starting system.
- B. The operational test can be done when there is pneumatic and electrical power on the airplane.

NOTE: It makes sure that the system operates correctly.

- C. The system test makes sure that the fault indication and the manual override is satisfactory.

TASK 80-11-00-715-001-R00

2. Operational Test – Engine Starting System

A. References

- (1) AMM 12-13-02/301, Engine Starter
- (2) AMM 24-22-00/201, Control
- (3) AMM 36-00-00/201, Pneumatic – General

B. Access

- (1) Location Zones
210 Control cabin

C. Prepare for Test

S 615-002-R00

- (1) Do the Engine Starter Oil Servicing procedure (AMM 12-13-02/301).

S 865-003-R00

- (2) Supply the electrical power (AMM 24-22-00/201).

S 865-004-R00

- (3) Supply the pneumatic power (AMM 36-00-00/201).

S 865-005-R00

- (4) For the left engine, make sure this circuit breaker is closed:
 - (a) P11 Overhead Circuit Breaker Panel
 - 1) 11D19, ENGINE START CONT LEFT

EFFECTIVITY

ALL

80-11-00

R01

Page 501
Jan 20/98

S 865-006-R00

- (5) For the right engine, make sure this circuit breaker is closed:
(a) P11 Overhead Circuit Breaker Panel
1) 11D20, ENGINE START CONT RIGHT

S 865-007-R00

- (6) Make sure that the six EICAS circuit breakers on the P11 panel are closed.

D. Test Engine Starting System

S 615-008-R00

WARNING: BEFORE YOU DO THIS TEST, MAKE SURE ALL PERSONS, TOOLS, AND UNWANTED OBJECTS ARE REMOVED FROM THE ENGINE INLET AREA. MAKE A SAFETY AREA AROUND THE ENGINE INLET. IF YOU DO NOT FOLLOW THESE INSTRUCTIONS, YOU CAN CAUSE INJURY TO PERSONS AND DAMAGE TO EQUIPMENT.

- (1) Make sure that the FUEL CONTROL switch is in the CUTOFF position and attach a DO-NOT-OPERATE tag.

S 615-060-R00

- (2) Obey the starter operation limits when starting engine (AMM 71-00-00/201).

S 615-010-R00

CAUTION: DO NOT OPERATE THE STARTER MORE THAN THE STARTER OPERATION LIMITS. THE STARTER CAN BE DAMAGED IF THE STARTER IS OPERATED MORE THAN THE STARTER OPERATION LIMITS.

- (3) Move the ENGINE START switch to the GND position and let the starter turn the engine to approximately 25% N3.

NOTE: The ENGINE START VALVE light should come on momentarily and then go off.

EFFECTIVITY

ALL

80-11-00

R01

Page 502
Jan 20/98

- S 865-062-R00
(4) Move the ENGINE START switch to the AUTO position.

NOTE: The ENGINE START VALVE light should come on momentarily and then go off.

E. Put the Airplane Back to its Usual Condition

- S 865-011-R00
(1) Remove the pneumatic power, if it is not necessary (AMM 36-00-00/201).

- S 865-012-R00
(2) Remove the electrical power if it is not necessary (AMM 24-22-00/201).

TASK 80-11-00-735-013-R00

3. System Test - Engine Starting System

A. Equipment

- (1) Voltmeter/Continuity Indicator capable of reading 28 Vdc (commercially available).

B. References

- (1) AMM 12-13-02/301, Engine Starter
(2) AMM 24-22-00/201, Control
(3) AMM 36-00-00/201, Pneumatic - General
(4) AMM 71-11-04/201, Fan Cowl Panels

C. Access

- (1) Location Zones
210 Control Cabin
413/423 Fan Cowl Panel (left)
- (2) Access Panels
413AL/423AL Fanl cowl panel (left)
413BL/423BL Starter control valve access door

D. Prepare for Test

- S 865-014-R00
(1) Supply the electrical power (AMM 24-22-00/201).

EFFECTIVITY

ALL

80-11-00

R01

Page 503
Jan 20/98


- S 865-015-R00
(2) Make sure that the six EICAS circuit breakers are closed.

- S 865-017-R00
(3) For the left engine, make sure this circuit breaker is closed:
(a) P11 Overhead Circuit Breaker Panel
1) 11D19, ENGINE START CONT LEFT

- S 865-018-R00
(4) For the right engine, make sure this circuit breaker is closed:
(a) P11 Overhead Circuit Breaker Panel
1) 11D20, ENGINE START CONT RIGHT

E. Starter Valve Position Indication System Test

- S 015-019-R00
(1) Open the starter control valve access door.



48931

Starter Control Valve Access
Figure 501

EFFECTIVITY	
	ALL

80-11-00

R01

Page 504
Jan 20/98

- S 735-020-R00
- (2) Disconnect the electrical connector from the starter control valve.
- S 735-021-R00
- (3) Move the ENGINE START switch to the GND position.
- S 735-022-R00
- (4) Make sure that the START VALVE light comes on and stays on.
- S 735-023-R00
- (5) Make sure that the L (R) ENG STARTER message is shown on the upper EICAS display after approximately 5 seconds.
- S 735-024-R00
- (6) Make sure that the voltage between pins 1+ and 2- on the electrical connector for the starter control valve measures 28V dc.
- S 735-025-R00
- (7) Connect pins 4 and 5 on the electrical connector (D1306) for the starter control valve with a jumper wire.
- S 735-026-R00
- (8) Make sure that the START VALVE light goes off and the EICAS message L (R) ENG STARTER is not shown on the EICAS display.
- S 735-027-R00
- (9) Move the ENGINE START switch to the AUTO position.
- S 735-028-R00
- (10) Make sure that the START VALVE light goes on.
- S 735-029-R00
- (11) Make sure that the L (R) ENG STARTER message is shown on the EICAS display after approximately 5 seconds.

EFFECTIVITY

ALL

80-11-00

R01

Page 505
Jan 20/98

S 735-030-R00

- (12) Remove the wire between the pins 4 and 5 on the electrical connector for the starter control valve.

S 735-031-R00

- (13) Make sure that the START VALVE light goes off and the EICAS message L (R) ENG STARTER is not shown on the EICAS display.

S 735-032-R00

- (14) Connect the electrical connector to the starter control valve.

S 415-033-R00

- (15) Close the starter control valve access door.

S 865-034-R00

- (16) For the left engine, open this circuit breaker and attach a DO-NOT-CLOSE tag:

- (a) P11 Overhead Circuit Breaker Panel
1) 11D19, ENGINE START CONT LEFT

S 865-035-R00

- (17) For the right engine, open this circuit breaker and attach a DO-NOT-CLOSE tag:

- (a) P11 Overhead Circuit Breaker Panel
1) 11D20, ENGINE START CONT RIGHT

S 015-057-R00

CAUTION: OBEY THE PRECAUTIONS FOR THE KEVLAR WRAPPING WHEN YOU OPEN THE FAN COWL PANEL. IF THE PRECAUTIONS ARE NOT OBEYED, DAMAGE TO THE KEVLAR WRAPPING CAN OCCUR.

- (18) Open the right fan cowl panel (AMM 71-11-04/201).

S 735-037-R00

- (19) Disconnect the connector from the dedicated generator (Fig. 502).

S 865-038-R00

- (20) For the left engine, remove the DO-NOT-CLOSE tag and close this circuit breaker:

- (a) P11 Overhead Circuit Breaker Panel
1) 11D19, ENGINE START CONT LEFT

S 865-039-R00

- (21) For the right engine, remove the DO-NOT-CLOSE tag and close this circuit breaker:

- (a) P11 Overhead Circuit Breaker Panel
1) 11D20, ENGINE START CONT RIGHT

EFFECTIVITY


ALL

80-11-00

R01

Page 506
May 28/01

- S 735-040-R00
(22) Move the START switch to the GND position and hold.
- S 735-041-R00
(23) Make sure that the START VALVE light comes on and the L (R) ENG STARTER message is shown on EICAS.
- S 735-042-R00
(24) Make sure that the N3 rotor does not turn.
- S 735-043-R00
(25) Move the START switch to the AUTO position.
- S 735-044-R00
(26) Connect the electrical connector to the dedicated generator.



Dedicated Generator Location
Figure 502

EFFECTIVITY	
	ALL

80-11-00

R01

Page 507
Jan 20/98

S 415-058-R00

CAUTION: OBEY THE PRECAUTIONS FOR THE KEVLAR WRAPPING WHEN YOU CLOSE THE FAN COWL PANEL. IF THE PRECAUTIONS ARE NOT OBEYED, DAMAGE TO THE KEVLAR WRAPPING CAN OCCUR.

(27) Close the right fan cowl panel (AMM 71-11-04/201).

F. Starter Control Valve Manual Override Test (Fig. 501)

S 615-046-R00

(1) Do the Engine Starter Oil Servicing procedure (AMM 12-13-02/301).

S 865-047-R00

(2) Supply the pneumatic power (AMM 36-00-00/201).

S 015-048-R00

(3) Open the starter control valve access door.

S 865-049-R00

(4) Make sure that the FUEL CONTROL switch is in the CUTOFF position and attach DO-NOT-OPERATE tag.

S 735-050-R00

WARNING: BEFORE YOU DO THIS TEST, MAKE SURE ALL PERSONS, TOOLS, AND UNWANTED OBJECTS ARE REMOVED FROM THE ENGINE INLET AREA. MAKE A SAFETY AREA AROUND THE ENGINE INLET. IF YOU DO NOT FOLLOW THESE INSTRUCTIONS, YOU CAN CAUSE INJURY TO PERSONS AND DAMAGE TO EQUIPMENT.

(5) Turn the manual override shaft on the starter control valve to the OPEN position and let the engine turn to $20 \pm 2\%$ N3.

S 735-051-R00

(6) Close the engine starter control valve when the engine turns at $20 \pm 2\%$ N3.

EFFECTIVITY
ALL

80-11-00

- S 735-052-R00
- (7) Make sure that the starter control valve closed and that air flow to the engine starter has stopped.
- S 415-053-R00
- (8) Close the starter control valve access door.
- S 865-054-R00
- (9) Remove the DO-NOT-OPERATE tag from the FUEL CONTROL switch.
- S 865-055-R00
- (10) Remove the pneumatic power, if it is not necessary (AMM 36-00-00/201).
- S 865-056-R00
- (11) Remove the electrical power, if it is not necessary (AMM 24-22-00/201).

EFFECTIVITY

ALL

80-11-00

R01

Page 509
Jan 20/98

ENGINE STARTING SYSTEM - INSPECTION/CHECK

TASK 80-11-00-206-001-R00

1. Engine Starting System Inspection

A. References

- (1) AMM 12-13-02/301, Engine Starter-Oil Replenishing
- (2) AMM 71-11-04/201, Fan Cowl Panels

B. Access

(1) Location Zones

- 413 Fan cowl panel (Left)
- 414 Fan cowl panel (Right)
- 423 Fan cowl panel (Left)
- 424 Fan cowl panel (Right)

(2) Access Panels

- 413 Fan cowl panel (Left)
- 414 Fan cowl panel (Right)
- 423 Fan cowl panel (Left)
- 424 Fan cowl panel (Right)

C. Engine Starting System Inspection

S 866-002-R00

- (1) For the left engine, open this circuit breaker and attach a DO-NOT-CLOSE tag:
 - (a) P11 Overhead Circuit Breaker Panel
 - 1) 11D19, ENGINE START CONT LEFT

S 866-003-R00

- (2) For the right engine, open this circuit breaker and attach a DO-NOT-CLOSE tag:
 - (a) P11 Overhead Circuit Breaker Panel
 - 1) 11D20, ENGINE START CONT RIGHT

S 016-004-R00

- (3) Open the fan cowl panels (AMM 71-11-04/201).

S 216-005-R00

- (4) Examine the engine starter duct for cracks, holes or other damage.

S 216-006-R00

- (5) Examine the engine starter duct to make sure it is aligned correctly.

S 216-007-R00

- (6) Examine the engine starter duct coupling clamps to make sure they are tight.

EFFECTIVITY

ALL

80-11-00

R01

Page 601
Jun 20/93

- S 616-008-R00
- (7) Look into the sight glass to see if you need to add oil.
(a) Do the Engine Starter Oil Servicing procedure, if it is necessary (AMM 12-13-02/301).
- S 416-009-R00
- (8) Close the fan cowl panels (AMM 71-11-04/201).
- S 866-010-R00
- (9) For the left engine, remove the DO-NOT-CLOSE tag and close this circuit breaker:
(a) P11 Overhead Circuit Breaker Panel
1) 11D19, ENGINE START CONT LEFT
- S 866-011-R00
- (10) For the right engine, remove the DO-NOT-CLOSE tag and close this circuit breaker:
(a) P11 Overhead Circuit Breaker Panel
1) 11D20, ENGINE START CONT RIGHT

EFFECTIVITY

ALL

80-11-00

R01

Page 602
Jun 20/93

PNEUMATIC STARTER – REMOVAL/INSTALLATION

1. General

- A. Two tasks are given in this procedure. The first is the removal of the pneumatic starter and the second is the installation of the starter.
- B. In this procedure the pneumatic starter will be referred to as the starter.

TASK 80-11-01-024-001-R00

2. Remove the Pneumatic Starter

A. References

- (1) AMM 71-11-04/201, Fan Cowl Panels

B. Access

(1) Location Zone

- 413 Fan Cowl Panel (Left)
- 414 Fan Cowl Panel (Right)
- 423 Fan Cowl Panel (Left)
- 424 Fan Cowl Panel (Right)

(2) Access Zone

- 413AL Fan Cowl Panel (Left)
- 414AR Fan Cowl Panel (Right)
- 423AL Fan Cowl Panel (Left)
- 424AR Fan Cowl Panel (Right)

C. Prepare to Remove the Starter

S 864-002-R00

- (1) For the left engine, open this circuit breaker and attach a DO-NOT-CLOSE tag:
 - (a) P11 Overhead Circuit Breaker Panel
 - 1) 11D19, ENGINE START CONT LEFT

S 864-003-R00

- (2) For the right engine, open this circuit breaker and attach a DO-NOT-CLOSE tag:
 - (a) P11 Overhead Circuit Breaker Panel
 - 1) 11D20, ENGINE START CONT RIGHT

S 014-017-R00

CAUTION: OBEY THE PRECAUTIONS FOR THE KEVLAR WRAPPING WHEN YOU OPEN THE FAN COWL PANEL. IF THE PRECAUTIONS ARE NOT OBEYED, DAMAGE TO THE KEVLAR WRAPPING CAN OCCUR.

- (3) Open the fan cowl panels (AMM 71-11-04/201).

D. Remove the Starter (Fig. 401)


EFFECTIVITY

ALL

80-11-01

R01

Page 401
Jun 20/93



68467A

Pneumatic Starter Installation
Figure 401

EFFECTIVITY	
	ALL

80-11-01

R01

Page 402
Sep 20/91

S 024-005-R00

- (1) Remove the air duct.
 - (a) Remove the nuts (12) and the bolts (11) from each end of the support link (9) and remove the link.
 - (b) Remove the nut (12) and the bolt (11) from the support link (8) at the air duct connection.
 - 1) Move the support link away from the duct.
 - (c) Hold the air duct (10) and remove the coupling clamps (1, 3).

NOTE: E-type seals (2, 7) can be left in their positions.

- (d) Remove the air duct (10).

S 024-022-R00

WARNING: BE CAREFUL WHEN YOU MOVE THE PNEUMATIC STARTER. BECAUSE THE STARTER WEIGHS 38 POUNDS (17.2 KG), INJURY TO YOU CAN OCCUR.

CAUTION: DO NOT LIFT THE STARTER BY THE DRIVESHAFT. INTERNAL DAMAGE TO THE STARTER CAN OCCUR.

- (2) Remove the starter.
 - (a) Release the coupling clamp (5) from the QAD adapter flange.
 - (b) Move the starter (4) forward to disengage the adapter splines and the drive shaft splines for the starter (4).
 - (c) Remove the starter (4).
 - (d) Remove and discard the seal (6) from the driveshaft.
 - (e) Put caps on all open duct ends.

TASK 80-11-01-424-007-R00

3. Install the Pneumatic Starter

A. Parts

EFFECTIVITY

ALL

80-11-01

R01

Page 403
Sep 20/94

AMM		NOMENCLATURE	AIPC		
FIG	ITEM		SUBJECT	FIG	ITEM
401	1	Clamp - Vee	80-11-02	01	45
	2	Gasket			15
	3	Coupling	80-11-53	01	149
	4	Starter - Air	80-11-01	01	5
	5	Coupling Clamp			20
	6	Packing			25
	7	Gasket			180
	8	Support Link	80-11-53	01	255,260, 270,275
	9	Support Link			255,260, 265
	10	Duct Assy - Air Starter Lwr			135
	11	Bolt			90
	12	Nut			95

B. Consumable Material

- (1) Clean Engine Oil, OMat No. 1011

C. References

- (1) AMM 12-13-02/301, Engine Starter - Oil Replenishing
 (2) AMM 71-00-00/201, Power Plant
 (3) AMM 71-11-04/201, Fan Cowl Panels

D. Access

(1) Location Zone

- 413 Fan Cowl Panel (Left)
 414 Fan Cowl Panel (Right)
 423 Fan Cowl Panel (Left)
 424 Fan Cowl Panel (Right)

(2) Access Zone

- 413AL Fan Cowl Panel (Left)
 414AR Fan Cowl Panel (Right)
 423AL Fan Cowl Panel (Left)
 424AR Fan Cowl Panel (Right)

E. Procedure (Fig. 401)

S 434-008-R00

- (1) Remove the caps from the ducts.

S 424-015-R00

- (2) Install the starter.
 (a) Lubricate the new seal ring with clean engine oil
 OMat No. 1011.
 (b) Put the seal ring (6) onto the drive shaft.

EFFECTIVITY

ALL

80-11-01

R01

Page 404
Sep 28/04

- (c) Make sure the flanges of the starter (4) and the QAD adapter are clean and not damaged.
- (d) Put the starter (4) on the QAD adapter.
- (e) Make sure the magnetic drain plug is at bottom center.
- (f) Align the master splines on the starter (4) and the adapter.
- (g) Push the starter (4) to the gearbox until it stops.
- (h) Install the coupling clamp (5), that connects the starter to the QAD adapter.
 - 1) Tighten the clamp to 60-65 pound-inches (6.8-7.3 Newton meters).

S 424-009-R00

- (3) Install the air duct.
 - (a) Examine the E-type seals (2, 7) in the air duct (10) flanges.
 - (b) Engage the flanges and align the yellow marks on the ducts.
 - (c) Install the coupling clamps (1, 3).

S 434-016-R00

- (4) Install the support link assembly.
 - (a) Put the free end of the support link (8) in the forked connection on the air duct.
 - (b) Adjust the link to align the bolt holes.
 - (c) Adjust the support link (9), to align the bolt holes.
 - (d) Install the bolts (11) and the nuts (12).
 - (e) Tighten the nuts (12).
 - (f) Examine the safety holes in the support links (8, 9) to make sure the threads are engaged correctly.
 - (g) Tighten the locknuts for the support link.
- F. Put the airplane back to its usual condition.

S 614-010-R00

- (1) Fill the starter (4) with oil (AMM 12-13-02/301).

S 414-018-R00

CAUTION: OBEY THE PRECAUTIONS FOR THE KEVLAR WRAPPING WHEN YOU CLOSE THE FAN COWL PANEL. IF THE PRECAUTIONS ARE NOT OBEYED, DAMAGE TO THE KEVLAR WRAPPING CAN OCCUR.

- (2) Close the fan cowl panels (AMM 71-11-04/201).

S 864-012-R00

- (3) For the left engine, remove the DO-NOT-CLOSE tag and close this circuit breaker:
 - (a) P11 Overhead Circuit Breaker Panel
 - 1) 11D19, ENGINE START CONT LEFT

EFFECTIVITY

ALL

80-11-01

R01

Page 405
Sep 28/04

S 864-013-R00

(4) For the right engine, remove the DO-NOT-CLOSE tag and close this circuit breaker:

- (a) P11 Overhead Circuit Breaker Panel
 - 1) 11D20, ENGINE START CONT RIGHT

S 714-019-R00

WARNING: USE AMM 71-00-00/201 TO OPERATE THE POWER PLANT. IF YOU DO NOT USE THIS PROCEDURE, YOU CAN CAUSE INJURY TO PERSONS OR DAMAGE TO EQUIPMENT.

(5) Use the Power Plant Dry-Motor procedure to motor the engine (AMM 71-00-00/201).

EFFECTIVITY

ALL

80-11-01

STARTER - INSPECTION/CHECK

1. General

- A. This procedure contains steps to do the visual inspections that follow:
- (1) Visual inspection of the magnetic chip detector for signs of starter damage.
 - (2) Visual inspection for oil leakage from the starter.
 - (3) Visual inspection to make sure that the starter is correctly attached to the engine and the pneumatic duct.

TASK 80-11-01-206-001-R00

2. Pneumatic Starter Inspection

A. References

- (1) AMM 12-13-02/301, Starter Servicing
- (2) AMM 71-11-04/201, Fan Cowl Panels
- (3) AMM 78-31-00/201, Thrust Reverser System
- (4) AMM 80-11-01/401, Pneumatic Starter

B. Access

- (1) Location Zones
 - 410 Left Engine
 - 420 Right Engine

- (2) Access Panels
 - 413AL Fan Cowl Panel (Left)
 - 414AR Fan Cowl Panel (Right)
 - 415AL Thrust Reverser (Left)
 - 416AR Thrust Reverser (Right)
 - 423AL Fan Cowl Panel (Left)
 - 424AR Fan Cowl Panel (Right)
 - 425AL Thrust Reverser (Left)
 - 426AR Thrust Reverser (Right)

C. Prepare for inspection

S 866-002-R00

WARNING: DO THE THRUST REVERSER DEACTIVATION PROCEDURE TO PREVENT THE OPERATION OF THE THRUST REVERSER. ACCIDENTAL OPERATION OF THE THRUST REVERSER CAN CAUSE INJURY TO YOU OR DAMAGE TO EQUIPMENT.

- (1) Do this procedure: Thrust Reverser Deactivation for Ground Maintenance (AMM 78-31-00/201).

EFFECTIVITY

ALL

80-11-01

R01A

Page 601
Jan 28/02

S 016-017-R00

CAUTION: OBEY THE PRECAUTIONS FOR THE KEVLAR WRAPPING WHEN YOU OPEN THE FAN COWL PANEL. IF THE PRECAUTIONS ARE NOT OBEYED, DAMAGE TO THE KEVLAR WRAPPING CAN OCCUR.

(2) Open the fan cowl panels (AMM 71-11-04/201).

D. Magnetic Chip Detector Inspection (Fig. 601)

S 216-004-R00

- (1) Remove and examine the magnetic chip detector as follows:
- (a) Remove the magnetic chip detector from the drain plug in the starter.
 - (b) Examine the magnetic chip detector for an unusually large quantity of metal particles.
 - 1) Also look for large metal pieces such as pins, lockwire, and casting chips.
 - 2) Metal pieces should not be larger than 0.1 inch (2.5 mm) in length.

S 906-005-R00

- (2) If large metal chips or large quantities of metal particles are found, replace the starter (AMM 80-11-01/401).

NOTE: The drain plug has a two part base which permits the magnetic chip detector to be removed without any oil leakage. A spring-loaded seal closes the opening as the magnetic chip detector is removed.

S 436-006-R00

- (3) Install a new O-ring on the magnetic chip detector.

S 436-007-R00

- (4) Install the magnetic chip detector in the starter oil drain plug.
- (a) Tighten the plug to 5-15 inch-pounds (0.56-1.69 newton-meters).
 - (b) Install lockwire to the plug.

E. Starter Oil Leak Inspection

S 216-008-R00

- (1) Examine the starter for oil leakage.

S 906-009-R00

- (2) If an unusual quantity of oil leakage is found around the starter housing, replace the starter (AMM 80-11-01/401).

S 906-010-R00

- (3) If an unusual quantity of oil leakage is found around the fill plug or overfill plug, replace the packing.


EFFECTIVITY

ALL

80-11-01

R01A

Page 602
Jan 28/02




Engine Starter - Oil Change and Chip Detector Inspection
Figure 601 (Sheet 1)

EFFECTIVITY
ENGINES WITH HAMILTON
STANDARD STARTER


80-11-01

R03A

Page 603
Sep 28/03



STARTER
SEE (B)



FWD ←
BOTTOM

STARTER
(B)

A3995

Engine Starter - Oil Change and Chip Detector Inspection
Figure 601 (Sheet 2)

EFFECTIVITY
ENGINES WITH GARRETT STARTER

80-11-01

R04A

Page 604
Sep 20/93

S 906-011-R00

- (4) If an unusual quantity of oil leakage is found around the oil drain plug, do the steps that follow:

WARNING: DO NOT KEEP THE OIL ON YOUR SKIN FOR A LONG TIME. IF YOU DO NOT CLEAN THE OIL OFF, THE OIL CAN CAUSE INJURY. THE OIL CAN ALSO STAIN CLOTHING AND DAMAGE PAINT.

- (a) Remove the fill plug and the drain plug and let the oil drain fully.
- (b) Install a new packing on the drain plug.
- (c) Install the drain plug in the starter.
 - 1) Tighten the drain plug to 10-25 inch-pounds (1.13-2.82 newton-meters).
 - 2) Install lockwire to the plug.

S 616-012-R00

- (5) Do the oil servicing procedure for the engine starter (AMM 12-13-02/301).

S 216-013-R00

- (6) Make sure that the starter is correctly attached to the engine and the pneumatic duct.

F. Put the airplane back to its usual condition

S 416-018-R00

CAUTION: OBEY THE PRECAUTIONS FOR THE KEVLAR WRAPPING WHEN YOU CLOSE THE FAN COWL PANEL. IF THE PRECAUTIONS ARE NOT OBEYED, DAMAGE TO THE KEVLAR WRAPPING CAN OCCUR.

- (1) Close the fan cowl panels (AMM 71-11-04/401).

S 866-015-R00

- (2) Do the activation procedure for the thrust reverser (AMM 78-31-00/201).

EFFECTIVITY

ALL

80-11-01

R02A

Page 605
Sep 28/04

STARTER CONTROL VALVE – REMOVAL/INSTALLATION

TASK 80-11-02-004-008-R00

1. Remove the Starter Control Valve

A. References

- (1) AMM 71-11-04/201, Fan Cowl Panels

B. Access

(1) Location Zones

- 413 Fan cowl panel (left)
- 414 Fan cowl panel (right)
- 423 Fan cowl panel (left)
- 424 Fan cowl panel (right)

(2) Access Panels

- 413AL Fan cowl panel (left)
- 414AR Fan cowl panel (right)
- 423AL Fan cowl panel (left)
- 424AR Fan cowl panel (right)

C. Prepare for the Removal

S 864-001-R00

- (1) For the left engine, open this circuit breaker and attach a DO-NOT-CLOSE tag:
 - (a) P11 Overhead Circuit Breaker Panel
 - 1) 11D19, ENGINE START CONT LEFT

S 864-002-R00

- (2) For the right engine, open this circuit breaker and attach a DO-NOT-CLOSE tag:
 - (a) P11 Overhead Circuit Breaker Panel
 - 1) 11D20, ENGINE START CONT RIGHT

S 864-003-R00

WARNING: MAKE SURE THERE IS NO AIR PRESSURE IN THE STARTER DUCT. PRESSURIZED AIR IN THE STARTER DUCT CAN CAUSE INJURY TO PERSONS WHEN YOU REMOVE THE STARTER CONTROL VALVE.

- (3) Make sure the external air supply is not connected to the bleed air system and the APU is off.

S 014-004-R00

CAUTION: OBEY THE PRECAUTIONS FOR THE KEVLAR WRAPPING WHEN YOU OPEN THE FAN COWL PANEL. IF YOU DO NOT OBEY THE PRECAUTIONS, DAMAGE TO THE KEVLAR WRAPPING CAN OCCUR.

- (4) Open the fan cowl panels (AMM 71-11-04/201).

EFFECTIVITY

ALL

80-11-02

R01

Page 401
Jun 20/93

D. Procedure (Fig. 401)

S 034-018-R00

- (1) Disconnect the electrical connector from the starter control valve (3).

S 034-005-R00

- (2) Do the steps that follow to remove the support links (9, 12) from the starter air duct (6):
- (a) Remove the nuts (11) and the bolts (10) from each end of the support link (12).
 - (b) Remove the support link (12).
 - (c) Remove the nut (11) and the bolt (10) from the support link (9) until you can move the support link away from the duct.

S 034-019-R00

- (3) Do the steps that follow to remove the starter air duct (6):
- (a) Hold the air duct (6) and remove the coupling clamps (5) and (8).
 - (b) Remove the air duct (6).

S 024-006-R00

- (4) Do the steps that follow to remove the starter control valve (3):

WARNING: BE CAREFUL WHEN YOU MOVE THE STARTER CONTROL VALVE. BECAUSE THE VALVE WEIGHS 16 POUNDS (7.2 KG), INJURY TO PERSONS OR DAMAGE TO EQUIPMENT CAN OCCUR.

- (a) Hold the starter control valve (3) and remove the coupling clamp (1).
- (b) Remove the starter control valve (3).
- (c) Remove the E-type seal (4) from the valve outlet.

NOTE: The E-type seals (2, 7) can be left in their position.

- 1) Keep the seal.
- (d) Put dust caps on all the ducts and connectors that are open.

TASK 80-11-02-404-007-R00

2. Install the Starter Control Valve

A. General

- (1) Use the procedure in AMM 70-51-00/201 to tighten the fasteners.




EFFECTIVITY

ALL


80-11-02

R01

Page 402
Jun 20/93



B



68466

Starter Control Valve Installation
Figure 401

EFFECTIVITY

ALL

80-11-02

R01

Page 403
Jun 20/93

216833

- (2) Tighten the fasteners to the torque values in AMM 70-51-00/201 unless a torque value is specified in this procedure.

B. Parts

AMM		NOMENCLATURE	AIPC		
FIG	ITEM		SUBJECT	FIG	ITEM
401	1	Clamp - Vee	80-11-02	01	45
	2	Gasket			15
	3	Valve - Starter Cont	80-11-01	02	150
	4	Gasket	80-11-02		15
	5	Clamp - Vee			45
	6	Duct Assy - Air Starter Lwr	80-11-53	01	135
	7	Gasket	80-11-01	02	180
	8	Coupling	80-11-53	01	149
	9	Support Link			255,260,
	10	Bolt			90
	11	Nut			95
	12	Support Link			255,260,

C. References

- (1) AMM 71-00-00/201, Power Plant
(2) AMM 71-11-04/201, Fan Cowl Panels

D. Access

(1) Location Zones

- 413 Fan cowl panel (left)
414 Fan cowl panel (right)
423 Fan cowl panel (left)
424 Fan cowl panel (right)

(2) Access Panels

- 413AL Fan cowl panel (left)
414AR Fan cowl panel (right)
423AL Fan cowl panel (left)
424AR Fan cowl panel (right)

E. Procedure (Fig. 401)

S 424-009-R00

- (1) Do the steps that follow to install the starter control valve (3):
(a) Remove the dust caps from the ducts and connectors.
(b) Make sure the E-type seal (4) for the valve outlet flange and the E-type seals (2, 7) for the duct flanges are not damaged.
(c) Install the E-type seal (4) in the valve outlet flange (AMM 70-12-02/201).

EFFECTIVITY

ALL

80-11-02

R01

Page 404
May 28/01

- (d) Prepare the coupling clamps (1, 5, 8), the valve inlet and outlet flanges and duct flanges for installation (AMM 70-12-02/201).

WARNING: BE CAREFUL WHEN YOU MOVE THE STARTER CONTROL VALVE. BECAUSE THE VALVE WEIGHS 16 POUNDS (7.2 KG), INJURY TO PERSONS OR DAMAGE TO EQUIPMENT CAN OCCUR.

- (e) Install the starter control valve (3) on the duct.
 - 1) Make sure the arrow on the valve body points in the direction of the airflow.
 - 2) Make sure the alignment marks on valve body are aligned with the alignment marks on the duct.
- (f) Install the top coupling clamp (1).
 - 1) Make sure there is sufficient clearance between the clamp bolt and adjacent structure.
 - 2) Adjust the top coupling clamp (1), if it is necessary.
 - 3) Tighten the coupling clamp (1) (AMM 70-12-02/201).

S 434-010-R00

- (2) Do the steps that follow to install the starter air duct (6):
 - (a) Install the air duct (6).
 - (b) Engage the mating flanges.
 - (c) Make sure the yellow alignment marks on the ducts are aligned.

S 434-011-R00

- (3) Do the steps that follow to install the support links (9, 12) for the starter air duct (6):
 - (a) Put the free end of the support link (9) in the forked connection on the air duct.
 - 1) Adjust the link to align the bolt holes, if it is necessary.
 - 2) Install the bolts (10) and the nuts (11).
 - 3) Tighten the bolts (10) and the nuts (11) (AMM 70-51-00/201).
 - (b) Install the support link (12).
 - 1) Adjust the link to align the bolt holes, if it is necessary.
 - 2) Install the bolts (10) and the nuts (11).
 - 3) Tighten the bolts (10) and the nuts (11) (AMM 70-51-00/201).
 - (c) Look in the safety holes in the support links (9, 12) to make sure the threads are engaged correctly.
 - (d) Tighten the locknuts on the support links (9, 12) (AMM 70-51-00/201).
 - (e) Install the middle coupling clamp (5).
 - 1) Make sure there is sufficient clearance between the clamp bolt and adjacent structure.
 - 2) Adjust the middle coupling clamp (5), if it is necessary.
 - 3) Tighten the middle coupling clamp (5) (AMM 70-12-02/201).

EFFECTIVITY

ALL

80-11-02

R01

Page 405
Jun 20/93

- (f) Install the bottom coupling clamp (8).
 - 1) Make sure there is sufficient clearance between the clamp bolt and adjacent structure.
 - 2) Adjust the bottom coupling clamp (8), if it is necessary.
 - 3) Tighten the bottom coupling clamp (8) (AMM 70-12-02/201).

S 434-012-R00

- (4) Connect the electrical connector to the starter control valve (AMM 70-12-02/201).

S 414-013-R00

CAUTION: OBEY THE PRECAUTION FOR THE KEVLAR WRAPPING WHEN YOU CLOSE THE FAN COWL PANEL. IF YOU DO NOT OBEY THE PRECAUTIONS, DAMAGE TO THE KEVLAR WRAPPING CAN OCCUR.

- (5) Close the fan cowl panels (AMM 71-11-04/401).

S 864-014-R00

- (6) For the left engine, remove the DO-NOT-CLOSE tag and close this circuit breaker:
 - (a) P11 Overhead Circuit Breaker Panel
 - 1) 11D19, ENGINE START CONT LEFT

S 864-015-R00

- (7) For the right engine, remove the DO-NOT-CLOSE tag and close this circuit breaker:
 - (a) P11 Overhead Circuit Breaker Panel
 - 1) 11D20, ENGINE START CONT RIGHT

S 864-017-R00

WARNING: USE AMM 71-00-00/201 TO OPERATE THE POWER PLANT. IF YOU DO NOT USE THIS PROCEDURE, YOU CAN CAUSE INJURY TO PERSONS OR DAMAGE TO EQUIPMENT.

- (8) Use the Power Plant Dry-Motor procedure to motor the engine (AMM 71-00-00/201).

EFFECTIVITY

ALL

80-11-02

R01

Page 406
Jan 28/03

STARTER QAD ADAPTER – REMOVAL/INSTALLATION

1. General

A. The quick attach detach (QAD) adapter for the starter helps to change starters quickly. This section gives the removal and the installation procedures for the QAD adapter. The engine starter must be removed to get access to the QAD adapter.

TASK 80-11-07-024-001-R00

2. Remove the Starter QAD Adapter

A. Equipment

(1) HU34316 – Socket, Rolls-Royce

B. References

- (1) AMM 71-11-04/201, Fan Cowl Panels
- (2) AMM 78-31-00/201, Thrust Reversers
- (3) AMM 80-11-01/401, Pneumatic Starter

C. Access

(1) Location Zones

- 413 Fan Cowl Panel (Left)
- 414 Fan Cowl Panel (Right)

(2) Access Panels

- 423 Fan Cowl Panel (Left)
- 424 Fan Cowl Panel (Right)

D. Procedure

S 044-016-R00

WARNING: DO THE THRUST REVERSER DEACTIVATION PROCEDURE TO PREVENT THE OPERATION OF THE THRUST REVERSER. ACCIDENTAL OPERATION OF THE THRUST REVERSER CAN CAUSE INJURY TO PERSONS OR DAMAGE TO EQUIPMENT.

- (1) Do this procedure: Thrust Reverser Deactivation for Ground Maintenance (AMM 78-31-00/201).

S 014-017-R00

- (2) Open the fan cowl panels (AMM 71-11-04/201).

EFFECTIVITY

ALL

80-11-07

R01

Page 401
Mar 20/94

- S 014-018-R00
(3) Remove the pneumatic starter (AMM 80-11-01/401).

- S 024-015-R00
(4) Do the steps that follow to remove the QAD adapter (Fig. 401):
(a) Remove the nuts (1) from the QAD adapter (2) with the HU34316 socket.
(b) Remove the QAD adapter from the high speed (HS) external gearbox.
(c) Remove the seal ring (3) from the flange of the QAD adapter.
1) Discard the used seal ring.

TASK 80-11-07-424-005-R00

3. Install the Starter QAD Adapter

A. Equipment

- (1) HU34316 - Socket, Rolls-Royce

B. Consumable Materials

- (1) G00535 Jointing Compound
British Spec - DTD.900/4586 Hylomar (Light)
OMat No. - 4/46
(2) B00090 Degreasing fluid
(Inhibited and stabilized 1.1.1. trichloroethane)
British Spec - B.S.4487:1969
American Spec - MIL-T-81533
OMat No. - 1/21

C. References

- (1) AMM 70-02-01/201, Identification, Lubrication and Fitting of Rubber Sealing Rings
(2) AMM 70-51-00/201, Torque Tightening Technique
(3) AMM 71-11-04/201, Fan Cowl Panels
(4) AMM 78-31-00/201, Thrust Reversers
(5) AMM 80-11-01/401, Pneumatic Starter

D. Access

- (1) Location Zones
413 Fan Cowl Panel (Left)
414 Fan Cowl Panel (Right)
(2) Access Panels
423 Fan Cowl Panel (Left)
424 Fan Cowl Panel (Right)

E. Procedure

- S 414-013-R00
(1) Do the steps that follow to install the starter QAD adapter (Fig. 401):



EFFECTIVITY

ALL

80-11-07

R01

Page 402
Mar 20/94



50875

Starter QAD Adapter Installation
Figure 401

EFFECTIVITY	
	ALL

80-11-07

R01

Page 403
Sep 20/93

215432

WARNING: DO NOT GET DEGREASING FLUID IN YOUR MOUTH, OR EYES, OR ON YOUR SKIN. PUT ON A PROTECTIVE SPLASH GOGGLE AND GLOVES WHEN YOU USE DEGREASING FLUID. DO NOT BREATHE THE FUMES. DEGREASING FLUID IS A DANGEROUS SOLVENT WHICH CAN CAUSE INJURY OR DAMAGE.

- (a) Use cold liquid degreasing fluid to clean the mating faces of the QAD adapter and the HS external gearbox.
- (b) Use a brush and apply a thin film of jointing compound to the mating faces of the QAD adapter and the HS external gearbox.
- (c) Let the compound dry for a minimum of 10 minutes.
- (d) Lubricate a new ring seal (3) for the flange of the QAD adapter (AMM 70-02-01/201).
 - 1) Install the seal ring to the flange of the QAD adapter.
 - 2) Put the QAD adapter (2) on the HS external gearbox mating face.
 - 3) Make sure the location dowel is correctly engaged.
 - 4) Make sure the seal ring (3) is installed correctly.
- (e) Install and tighten the nuts (1) that attach the QAD adapter to the gearbox with the HU34316 socket (AMM 70-51-00/201).

S 414-019-R00

- (2) Install the starter (AMM 80-11-01/401).

S 444-020-R00

- (3) Do the activation procedure for the thrust reverser (AMM 78-31-00/201).

S 414-021-R00

- (4) Close the fan cowl panels (AMM 71-11-04/201).

EFFECTIVITY

ALL

80-11-07

R01

Page 404
Mar 20/94

STARTER CONTROL VALVE FILTER – MAINTENANCE PRACTICES

1. General

- A. This procedure gives three tasks. These tasks are a removal, cleaning, and an installation of the filter.
- B. In this procedure the filter for the starter control valve will be referred to as the filter.

TASK 80-11-08-002-001-R00

2. Remove the Filter

- A. References
 - (1) AMM 24-22-00/201, Electrical Power
 - (2) AMM 71-11-04/201, Fan Cowl Panels
- B. Access
 - (1) Location Zones
 - 413 Fan Cowl Panel (Left)
 - 423 Fan Cowl Panel (Left)
 - (2) Access Panels
 - 413AL Fan Cowl Panel (Left)
 - 423AL Fan Cowl Panel (Left)
- C. Procedure (Fig. 201)

S 862-002-R00

- (1) Remove the electrical power (AMM 24-22-00/201).

S 012-003-R00

CAUTION: OBEY THE PRECAUTIONS FOR THE KEVLAR WRAPPING WHEN YOU OPEN THE FAN COWL PANEL. IF YOU DO NOT OBEY THE PRECAUTIONS, DAMAGE TO THE KEVLAR WRAPPING CAN OCCUR.

- (2) Open the left fan cowl panel (AMM 71-11-04/201).

S 022-019-R00

- (3) Do these steps to remove the filter (Fig. 201):
 - (a) Remove the plug (4).
 - (b) Discard the seal ring (3).
 - (c) Remove the filter (1) and the spring (2).

TASK 80-11-08-102-007-R00

3. Clean the Filter

- A. Equipment
 - (1) Compressed air supply
- B. Consumable Materials
 - (1) Turco Liquid Sprayeze

EFFECTIVITY



ALL

80-11-08

R01

Page 201
May 20/98

SEE **A**



- (2) Fine Organics, F02085 or F02085M
- (3) B00148 Solvent - Methyl Ethyl Ketone (MEK), TT-M-261
- C. References
 - (1) AMM 70-42-12/201, Local Surface Protection
- D. Access
 - (1) Location Zones
 - 413 Fan Cowl Panel (Left)
 - 423 Fan Cowl Panel (Left)
 - (2) Access Panels
 - 413AL Fan Cowl Panel (Left)
 - 423AL Fan Cowl Panel (Left)
- E. Procedure

S 022-008-R00

- (1) Do the steps in the procedure to remove the filter element.

S 112-009-R00

WARNING: DO NOT GET METHYLETHYLKETONE (MEK) IN YOUR MOUTH OR EYES, OR ON YOUR SKIN. DO NOT BREATHE THE FUMES FROM MEK. PUT ON PROTECTIVE SPLASH GOGGLES AND GLOVES WHEN YOU USE MEK. KEEP MEK AWAY FROM SPARKS, FLAMES AND HEAT. MEK IS A POISONOUS AND FLAMMABLE SOLVENT WHICH CAN CAUSE INJURY TO PERSONS OR DAMAGE TO EQUIPMENT.

CAUTION: THE SOLVENT CAN CAUSE DAMAGE TO SURFACE PROTECTION. DAMAGED AREAS MUST BE REPAIRED (AMM 70-42-12/201).

- (2) Do these steps to clean the filter element:
 - (a) Clean the filter with the solvent.
 - (b) Dry the filter with low pressure compressed air.
 - (c) Look at the filter for signs of damage or contamination.
 - (d) Replace the filter if you find any damage or contamination.

S 422-010-R00

- (3) Do the steps in the procedure to install the filter.

TASK 80-11-08-402-011-R00

4. Install the Filter

A. Consumable Materials

- (1) Lockwire
 - British Spec./Ref - DTD 189A 22 S.W.G.
 - American Spec./Ref - 21 A.W.G.
 - OMat Item No. - 238

EFFECTIVITY

ALL

80-11-08

R01

Page 203
May 20/98

B. References

- (1) AMM 24-22-00/201, Electrical Power
- (2) AMM 70-02-01/201, Identification, Lubrication and Fitting of Rubber Sealing Rings
- (3) AMM 70-51-00/201, Torque Tightening Technique
- (4) AMM 71-11-04/201, Fan Cowl Panels

C. Access

- (1) Location Zones
 - 413 Fan Cowl Panel (Left)
 - 423 Fan Cowl Panel (Left)
- (2) Access Panels
 - 413AL Fan Cowl Panel (Left)
 - 423AL Fan Cowl Panel (Left)

D. Procedure

S 422-020-R00

- (1) Do these steps to install the filter:
 - (a) Install the filter (1) and the spring (2) with the flanged end of the filter first.
 - (b) Install the new preformed packing (3) on to the plug (4) (AMM 70-02-01/201).
 - (c) Install the plug (4) and make sure the spring (2) and the filter (1) are in the correct position.
 - 1) Tighten the plug (4) to 20-25 pound-inches (2.3-2.8 Newton meters) (AMM 70-51-00/201).
 - (d) Install lockwire to the plug (4).

S 412-017-R00

CAUTION: OBEY THE PRECAUTIONS FOR THE KEVAR WRAPPING WHEN YOU CLOSE THE FAN COWL PANEL. IF YOU DO NOT OBEY THE PRECAUTIONS, DAMAGE TO THE KEVLAR WRAPPING CAN OCCUR.

- (2) Close the left fan cowl panel (AMM 71-11-04/201).

EFFECTIVITY

ALL

80-11-08

R01

Page 204
Jun 20/96

ENGINE START/RAT CONTROL PANEL - REMOVAL/INSTALLATION

1. General

A. The engine start/ram air turbine (RAT) control panel M10468 is located on the pilots' overhead panel P5. This section gives the engine start/RAT control panel removal and installation procedures.

TASK 80-11-09-024-002-R00

2. Remove the Engine Start/RAT Control Panel

A. Access

- (1) Location Zones
210 Control Cabin

B. Procedure

S 864-015-R00

(1) Open these circuit breakers and attach DO-NOT-CLOSE tags:

- (a) P11 Overhead Circuit Breaker Panel
 - 1) 11A33, IND LIGHTS 2
 - 2) 11A35, IND LIGHTS 4
 - 3) 11D7, ENGINES STBY IGN LEFT 1
 - 4) 11D8, ENGINES STBY IGN LEFT 2
 - 5) 11D9, ENGINES STBY IGN RIGHT 1
 - 6) 11D10, ENGINES STBY IGN RIGHT 2
 - 7) 11D19, ENGINE START CONT LEFT
 - 8) 11D20, ENGINE START CONT RIGHT
 - 9) 11D26, HYDRAULICS RAT AUTO CONT
 - 10) 11D27, HYDRAULIC RAT AUTO PWR
 - 11) 11L1, LEFT ENGINE IGN 1
 - 12) 11L28, RIGHT ENGINE IGN 1
 - 13) 11N4, INSTRUMENT & PANEL OVHD
- (b) P6 Circuit Breaker Panel
 - 1) 6C1, FUEL COND CONT L
 - 2) 6C2, FUEL COND CONT R
 - 3) 6F1, RAT MAN

EFFECTIVITY

ALL

80-11-09

R01

Page 401
Jun 20/93

S 024-016-R00

- (2) Remove the control panel from the P5 panel.

TASK 80-11-09-424-005-R00

3. Install the Engine Start/RAT Control Panel

A. References

- (1) AMM 24-22-00/201, Electrical Power - Control
- (2) AMM 33-16-00/501, Master Dim and Test

B. Access

- (1) Location Zones
210 Control Cabin

C. Procedure

S 424-006-R00

- (1) Install the control panel in the P5 panel.

S 864-014-R00

- (2) Remove the DO-NOT-CLOSE tags and close these circuit breakers:

(a) P11 Overhead Circuit Breaker Panel

- 1) 11A33, IND LIGHTS 2
- 2) 11A35, IND LIGHTS 4
- 3) 11D7, ENGINES STBY IGN LEFT 1
- 4) 11D8, ENGINES STBY IGN LEFT 2
- 5) 11D9, ENGINES STBY IGN RIGHT 1
- 6) 11D10, ENGINES STBY IGN RIGHT 2
- 7) 11D19, ENGINE START CONT LEFT
- 8) 11D20, ENGINE START CONT RIGHT
- 9) 11D26, HYDRAULICS RAT AUTO CONT
- 10) 11D27, HYDRAULIC RAT AUTO PWR
- 11) 11L1, LEFT ENGINE IGN 1
- 12) 11L28, RIGHT ENGINE IGN 1
- 13) 11N4, INSTRUMENT & PANEL OVHD

(b) P6 Circuit Breaker Panel

- 1) 6C1, FUEL COND CONT L
- 2) 6C2, FUEL COND CONT R
- 3) 6F1, RAT MAN

EFFECTIVITY

ALL

80-11-09

R01

Page 402
Jun 20/93

- S 864-016-R00
- (3) Supply the electrical power (AMM 24-22-00/201).
- S 714-017-R00
- (4) Do these steps to make sure the control panel installation is correct:
- (a) Push the master dim and test (MD&T) switch on the overhead P5 panel (AMM 33-16-00/501).
 - (b) Make sure the engine start VALVE light on the control panel comes on.
 - (c) Release the MD&T switch on P5 panel to the off position.
- S 864-018-R00
- (5) Remove the electrical power if it is not necessary (AMM 24-22-00/201).

EFFECTIVITY

ALL

80-11-09

R01

Page 403
Jun 20/93