


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

GPA Group plc

PAGE	DATE	CODE	PAGE	DATE	CODE	PAGE	DATE	CODE
CHAPTER 28 TAB			28-FAULT CODE INDEX			28-22-00		
FUEL			CONT.			CONT.		
EFFECTIVE PAGES			7	SEP 20/08	07	105	MAY 28/06	01
SEE LAST PAGE OF LIST FOR			8	SEP 20/08	06	106	SEP 28/06	28
NUMBER OF PAGES			9	SEP 20/08	07	107	SEP 28/06	21
28-CONTENTS			10	SEP 20/08	01	108	SEP 28/06	10
1	MAY 28/06	GUI	28-BITE INDEX			109	SEP 28/06	07
R 2	JAN 20/09	GUI.1	1	SEP 28/99	01	110	SEP 28/06	06
R 3	JAN 20/09	GUI.1	2	SEP 28/99	01	111	SEP 28/06	06
4	JAN 28/00	GUI	3	SEP 28/99	01	112	SEP 28/06	08
5	MAY 28/06	GUI	4	BLANK		113	SEP 28/07	06
6	MAY 20/08	GUI	28-11-00			114	SEP 28/07	05
7	MAY 20/08	GUI	101	SEP 20/90	01	R 115	JAN 20/09	05.1
8	BLANK		102	MAR 20/95	02	116	MAY 28/07	05
28-HOW TO USE THE FIM			103	SEP 20/90	01	R 117	JAN 20/09	04.1
1	SEP 20/98	01	104	BLANK		118	MAY 28/07	04
2	SEP 20/98	01	28-13-00			119	SEP 28/07	04
3	SEP 28/99	01	101	SEP 20/94	01	120	SEP 28/07	GUI
4	SEP 28/06	01	102	SEP 20/94	01	121	MAY 28/07	04
5	SEP 20/98	01	103	SEP 20/94	01	122	MAY 28/07	05
6	SEP 20/98	01	104	JAN 28/02	01	123	MAY 28/07	11
28-INDEX			28-21-00			124	JAN 28/07	26
1	SEP 20/94	02	101	SEP 20/93	01	125	JAN 28/07	27
2	SEP 20/94	02	102	SEP 20/94	09	126	JAN 28/07	27
3	SEP 28/02	01	103	SEP 20/94	01	127	JAN 28/07	27
4	BLANK		104	SEP 20/94	03	128	JAN 28/07	27
28-EICAS MESSAGES			105	SEP 20/94	11	129	JAN 28/07	27
1	SEP 20/90	01	106	SEP 20/94	02	130	JAN 28/07	27
2	SEP 20/90	01	107	SEP 20/94	01	131	JAN 28/07	28
3	MAY 28/05	07	108	SEP 20/94	01	132	JAN 28/07	15
4	BLANK		109	SEP 20/94	01	133	JAN 28/07	04
28-FAULT CODE DIAGRAM			110	SEP 20/94	01	134	SEP 20/08	04
1	JUN 15/86	01	111	SEP 20/94	01	135	JAN 28/07	04
2	DEC 15/83	01	112	SEP 28/07	01	136	JAN 28/07	04
3	JUN 20/90	01	113	SEP 28/07	01	137	JAN 28/07	05
4	JUN 20/96	01	114	MAR 20/97	01	138	JAN 28/07	04
5	JUN 20/96	05	115	SEP 28/07	01	139	SEP 28/07	04
6	JAN 20/98	18	116	SEP 28/07	06	140	SEP 28/07	03
7	JUN 15/87	02	117	SEP 28/07	01	141	SEP 20/08	02
8	DEC 15/83	01	118	SEP 28/07	01	142	BLANK	
9	SEP 20/87	04	119	SEP 28/07	03	28-25-00		
10	MAR 20/93	10	120	SEP 28/07	18	101	DEC 20/90	09
28-FAULT CODE INDEX			121	SEP 28/07	18	102	SEP 28/06	01
1	SEP 20/08	03	122	SEP 28/07	18	103	DEC 20/90	01
2	SEP 20/08	02	123	SEP 28/07	04	104	DEC 20/90	09
3	SEP 20/08	01	124	SEP 28/07	04	105	DEC 20/90	03
4	SEP 20/08	01	125	SEP 28/07	04	106	MAR 20/96	01
5	SEP 20/08	06	126	SEP 28/07	03	107	MAY 28/04	01
6	SEP 20/08	10	127	SEP 28/07	04	108	SEP 28/06	01
			128	SEP 28/07	04	109	MAR 20/93	01
			R 127	JAN 20/09	03.1	110	BLANK	
			R 128	BLANK		28-26-00		
			28-22-00			101	SEP 20/94	01
			101	SEP 28/06	27	102	SEP 20/94	01
			102	SEP 28/06	28	103	SEP 20/98	01
			103	SEP 28/06	18	104	SEP 20/94	03
			104	SEP 28/06	30	105	SEP 20/94	01
						106	SEP 20/94	01

R = REVISED, A = ADDED OR D = DELETED

F = FOLDOUT PAGE

32

JAN 20/09

D633N632

CHAPTER 28

EFFECTIVE PAGES

PAGE 1

CONTINUED



BOEING
757
FAULT ISOLATION/MAINT MANUAL

GPA Group plc

PAGE	DATE	CODE	PAGE	DATE	CODE	PAGE	DATE	CODE
28-41-00	CONFIG 2		28-41-00	CONFIG 2	CONT.	28-41-00	CONFIG 3	CONT.
101	MAY 28/06	20	159	MAY 28/06	20	105	MAY 28/03	03
102	MAY 28/03	16	160	MAY 28/06	20	106	MAY 28/03	03
103	MAY 28/03	16	161	MAY 28/06	20	107	MAY 28/03	03
104	MAY 28/03	16	162	MAY 28/06	20	108	MAY 28/03	03
105	MAY 28/03	16	163	MAY 28/06	20	109	MAY 28/03	03
106	MAY 28/03	13	164	MAY 28/06	20	110	MAY 28/03	03
107	MAY 28/03	16	165	MAY 28/06	20	111	MAY 28/03	03
108	MAY 28/03	16	166	MAY 28/06	20	112	MAY 28/03	03
109	MAY 28/03	16	167	MAY 28/06	20	113	MAY 28/03	03
110	MAY 28/03	16	168	MAY 28/06	20	114	MAY 28/03	03
111	MAY 28/03	16	169	MAY 28/06	20	115	MAY 28/03	03
112	MAY 28/03	16	170	MAY 28/06	20	116	SEP 28/07	03
113	MAY 28/03	16	171	SEP 28/06	20	117	SEP 28/07	03
114	MAY 28/03	13	172	MAY 28/06	20	118	SEP 28/07	03
115	MAY 28/03	16	R 173	JAN 20/09	20.1	119	SEP 28/07	03
116	MAY 28/03	16	174	MAY 28/06	20	120	SEP 28/07	03
117	MAY 28/06	20	175	MAY 28/06	20	121	SEP 28/07	03
118	MAY 28/06	20	176	MAY 28/06	20	122	SEP 28/07	03
119	MAY 28/06	20	177	MAY 28/06	20	123	SEP 28/07	03
120	MAY 28/06	20	178	MAY 28/06	20	124	SEP 28/07	03
121	MAY 28/06	20	179	MAY 28/06	20	125	SEP 28/07	03
122	MAY 28/06	20	180	MAY 28/06	20	126	SEP 28/07	03
123	MAY 28/06	20	180A	MAY 28/06	20	127	SEP 28/07	03
124	MAY 28/06	20	180B	MAY 28/06	20	128	SEP 28/07	03
125	MAY 28/06	20	180C	MAY 28/06	20	129	SEP 28/07	03
126	MAY 28/06	20	180D	MAY 28/06	20	130	SEP 28/07	03
127	MAY 28/06	20	180E	MAY 28/06	20	131	SEP 28/07	03
128	MAY 28/06	20	180F	MAY 28/06	20	132	SEP 28/07	03
129	MAY 28/06	20	180G	MAY 28/06	20	133	SEP 28/07	03
130	MAY 28/06	20	180H	MAY 28/06	20	134	SEP 28/07	03
131	MAY 28/06	20	180I	MAY 28/06	20	135	SEP 28/07	03
132	MAY 28/06	20	180J	MAY 28/06	20	136	SEP 28/07	03
133	MAY 28/06	20	180K	MAY 28/06	20	137	SEP 28/07	03
134	MAY 28/06	20	180L	MAY 28/06	20	138	SEP 28/07	03
135	MAY 28/06	20	180M	MAY 28/06	20	139	SEP 28/07	03
136	MAY 28/06	20	180N	MAY 28/06	20	140	SEP 28/07	03
137	MAY 28/06	20	180O	MAY 28/06	20	141	SEP 28/07	03
138	MAY 28/06	20	180P	MAY 28/06	20	142	SEP 28/07	03
139	MAY 28/06	20	180Q	MAY 28/06	20	143	SEP 28/07	03
140	MAY 28/06	20	180R	MAY 28/06	20	144	SEP 28/07	03
141	MAY 28/06	20	180S	MAY 28/06	20	145	SEP 28/07	03
142	MAY 28/06	20	180T	MAY 28/06	20	146	SEP 28/07	03
143	MAY 28/06	20	180U	MAY 28/06	20	147	SEP 28/07	03
144	MAY 28/06	20	180V	MAY 28/06	20	148	SEP 28/07	03
145	MAY 28/06	20	180W	MAY 28/06	20	149	SEP 28/07	03
146	MAY 28/06	20	180X	MAY 28/06	20	150	SEP 28/07	03
147	SEP 28/07	20	180Y	MAY 28/06	20	151	SEP 28/07	03
148	MAY 28/06	20	180Z	MAY 28/06	20	152	SEP 28/07	03
149	MAY 28/06	20	181	MAY 28/06	20	153	SEP 28/07	03
150	MAY 28/06	20	182	MAY 28/06	20	154	SEP 28/07	03
151	MAY 28/06	20	182A	MAY 28/06	20	155	SEP 28/07	03
152	MAY 28/06	20	182B	MAY 28/06	20	156	SEP 28/07	03
153	MAY 28/06	20				157	SEP 28/07	03
154	MAY 28/06	20	28-41-00	CONFIG 3		158	SEP 28/07	03
155	MAY 28/06	20	101	SEP 28/07	03	159	SEP 28/07	03
156	MAY 28/06	20	102	MAY 28/03	03	160	SEP 28/07	03
157	MAY 28/06	20	103	MAY 28/03	03	161	SEP 28/07	03
158	MAY 28/06	20	104	MAY 28/03	03	162	SEP 28/07	03

R = REVISED, A = ADDED OR D = DELETED

F = FOLDOUT PAGE

32

JAN 20/09

D633N632

CHAPTER 28

EFFECTIVE PAGES

PAGE 2

CONTINUED



BOEING
757
FAULT ISOLATION/MAINT MANUAL

GPA Group plc

PAGE	DATE	CODE	PAGE	DATE	CODE	PAGE	DATE	CODE
28-41-00	CONFIG 3	CONT.	28-43-00		CONT.			
163	SEP 28/07	03	105	DEC 20/95	01A			
164	SEP 28/07	03	106	BLANK				
165	SEP 28/07	03						
166	SEP 28/07	03	28-44-00					
167	SEP 28/07	03	101	SEP 20/90	02			
168	SEP 28/07	03	102	SEP 20/90	02			
169	SEP 28/07	03	103	SEP 20/90	02			
170	SEP 28/07	03	104	SEP 20/90	02			
171	SEP 28/07	03						
172	SEP 28/07	03						
173	SEP 28/07	03						
R 174	JAN 20/09	05.1						
175	SEP 28/07	03						
176	SEP 28/07	03						
177	SEP 28/07	03						
178	SEP 28/07	03						
179	SEP 28/07	03						
180	SEP 28/07	03						
180A	SEP 28/07	03						
180B	SEP 28/07	03						
180C	SEP 28/07	03						
180D	SEP 28/07	03						
180E	SEP 28/07	03						
180F	SEP 28/07	03						
180G	SEP 28/07	03						
180H	SEP 28/07	03						
180I	SEP 28/07	03						
180J	SEP 28/07	03						
180K	SEP 28/07	03						
180L	SEP 28/07	03						
180M	SEP 28/07	03						
180N	SEP 28/07	03						
180O	SEP 28/07	03						
180P	SEP 28/07	03						
180Q	SEP 28/07	03						
180R	SEP 28/07	03						
180S	SEP 28/07	03						
180T	SEP 28/07	03						
180U	SEP 28/07	03						
180V	SEP 28/07	03						
180W	SEP 28/07	03						
180X	SEP 28/07	03						
180Y	SEP 28/07	03						
180Z	SEP 28/07	03						
181	SEP 28/07	03						
182	SEP 28/07	03						
182A	SEP 28/07	03						
182B	SEP 28/07	01						
28-42-00								
101	SEP 20/94	01						
102	SEP 20/94	01						
28-43-00								
101	MAR 20/93	01A						
102	MAR 20/93	01A						
103	SEP 28/99	01A						
104	MAR 20/94	01A						

R = REVISED, A = ADDED OR D = DELETED
 F = FOLDOUT PAGE
 32
 JAN 20/09

D633N632

CHAPTER 28
 EFFECTIVE PAGES
 PAGE 3
 LAST PAGE

CHAPTER 28 - FUEL

TABLE OF CONTENTS

<u>Subject</u>	Chapter Section <u>Subject</u>	<u>Page</u>	<u>Effectivity</u>
HOW TO USE THE FIM	28-HOW TO USE THE FIM	1	ALL
INDEX	28-INDEX	1	ALL
EICAS MESSAGES	28-EICAS MESSAGES	1	ALL
FAULT CODE DIAGRAMS	28-FAULT CODE DIAGRAM	1	ALL
FAULT CODE INDEX	28-FAULT CODE INDEX	1	ALL
BITE INDEX	28-BITE INDEX	1	ALL
<u>FUEL SYSTEM</u>	28-00-00		
<u>STORAGE</u>	28-10-00		
FUEL TANKS	28-11-00		
Component Location		101	ALL
Component Index			
Component Location			
FUEL TANK VENT SYSTEM	28-13-00		
Component Location		101	ALL
Component Index			
Component Location			

28-CONTENTS



BOEING
757
FAULT ISOLATION/MAINT MANUAL

CHAPTER 28 - FUEL

TABLE OF CONTENTS

<u>Subject</u>	Chapter Section <u>Subject</u>	<u>Page</u>	<u>Effectivity</u>
<u>DISTRIBUTION</u>	28-20-00		
PRESSURE FUELING SYSTEM	28-21-00		
Component Location		101	ALL
Component Index			
Component Location			
Fault Isolation			
All Load Select Indicator		107	
Display is Blank with Bat Pwr			
Switch in ON and TEST IND			
Switch Depressed (Fig. 103)			
All Tanks Failed to Stop at		124	
Preselected Quantity During			
Pressure Fueling. Fuel Spill			
at Surge Tank. (Fig. 109)			
Fuel Transferred to the Center		125	
Tank. (Fig. 110)			
Fueling Did Not Stop at		121	
Preselected Quantity or Fuel			
Transfer to Center Tank			
Occurred. (Fig. 108)			
Fueling Panel Light Fails to		116	
Illuminate with Ground Power			
on Airplane (Fig. 106)			
Fueling Stopped, "Push Set"		126	
Displayed on Fueling Control			
Panel, P28 (Fig. 111)			
Fueling Valve Light Fails to		109	
Illuminate with Fueling Valve			
Selected Open (Fig. 104)			
Fueling Valve OPEN Light		114	
Illuminated with Fueling			
Switch in FUEL. Fuel Quantity			
Did Not Increase or Increased			
at a Slow Rate. (Fig. 105)			
Load Select Fuel Indicator		115	
Displays Not All 8's When			
Test Switch is Pressed (Fig.			
105A)			
Load Select Indicator Display		118	
Remained Blank with IND TEST			
Switch Depressed (Fig. 107)			

28-CONTENTS



BOEING
757
FAULT ISOLATION/MAINT MANUAL

CHAPTER 28 - FUEL

TABLE OF CONTENTS

<u>Subject</u>	<u>Chapter Section Subject</u>	<u>Page</u>	<u>Effectivity</u>
Load Select Indicator Flashes at One Second Intervals (Fig. 107A)		120	
Unwanted Fuel Transfer from Center Tank to Main Tank(s) (Fig. 112)		127	
ENGINE FUEL FEED SYSTEM	28-22-00		
Component Location		101	ALL
Component Index			
Component Location			
Fault Isolation			
Boost Pump Low PRESS Light Failed to Illuminate with PUMP Switch/Light in OFF Position (Fig. 110)		133	
CTR FUEL PUMP EICAS Msg Illum and C PUMP PRESS Lt On (Fig. 105)		113	
EICAS Msg FUEL SPAR VAL and SPAR VALVE Lt Illum (Fig. 104)		111	
Forward (Aft) Fuel Crossfeed Valve Lt Fails to Illuminate (Fig. 107A)		125	
Fuel Crossfeed Valve Lt Fails to Extinguish (Fig. 108)		126	
Fuel Crossfeed Valve Lt Fails to Illuminate (Fig. 107)		124	
Fwd (Aft) Fuel Crossfeed Valve Lt Fails to Extinguish (Fig. 108A)		127	
L (R) FUEL SYS PRESS EICAS Msg Displayed (Fig. 109)		129	
L (R) FUEL SYS PRESS EICAS Msg Displayed (Fig. 109A)		131	
L FWD Boost Pump PRESS Light Failed to Illuminate with Pump Switch/Light in OFF Position (Fig. 111)		135	
Main Tank Fuel Boost Pump PRESS Lt and FUEL PUMP EICAS Msg Displayed (Fig. 106)		119	
Not Used		110	

28-CONTENTS



BOEING
757
FAULT ISOLATION/MAINT MANUAL

CHAPTER 28 - FUEL

TABLE OF CONTENTS

<u>Subject</u>	<u>Chapter Section Subject</u>	<u>Page</u>	<u>Effectivity</u>
APU FUEL FEED SYSTEM	28-25-00		
Component Location		101	ALL
Component Index			
Component Location			
Fault Isolation			
APU FAULT Lt and APU FUEL VAL EICAS Msg Displayed (Fig. 104)		107	
EICAS Msg DC FUEL PUMP ON Displayed (Fig. 105)		108	
Left Forward Boost Pump Does Not Come On Automatically When AC Power Is Available (APU at 95% Full Speed) (Fig. 106)		109	
Not Used		106	
DEFUELING	28-26-00		
Component Location		101	ALL
Component Index			
Component Location			
Fault Isolation			
Defueling Valve Light Does Not Indicate Selected Valve Position (Fig. 103)		105	

28-CONTENTS

CHAPTER 28 - FUEL

TABLE OF CONTENTS

<u>Subject</u>	Chapter Section <u>Subject</u>	<u>Page</u>	<u>Effectivity</u>
<u>INDICATING</u>	28-40-00		
FUEL QUANTITY INDICATING SYSTEM (FQIS)	28-41-00		
Component Location		101	CONFIG 2 [*]
Component Index			
Component Location			
Fault Isolation			
Dry Capacitance Test in the Main Equipment Center (No Fuel in the Tank) (Fig. 109)		180E	
EICAS Msg FUEL QTY IND or FUEL QTY CHANNEL Displayed. (Fig. 117)		180W	
Fault Message Reference Chart (Fig. 106)		144	
Fault Messages (Fig. 108)		149	
Fuel Quantity BITE Procedure (Fig. 104) (FQIS BITE Procedure)		119	
Fuel Quantity Indicating Module (FQIM) Does Not Display Correctly. (Fig. 114)		180R	
Fuel Quantity Indicating Module (FQIM), M10054, Shows the Message(s) "-A.-", "-b.-" or "-A.b" in One or All Fuel Quantity Displays (Fig. 119)		182	
Fuel Quantity Indicating System Problems Index (Fig. 103)		118	
FUEL CONFIG Light and EICAS Message FUEL CONFIG are Illuminated (Fig. 111)		180M	
FUEL CONFIG Light and EICAS Msg LOW FUEL Not Displayed during Fuel Qty Test (Fig. 115)		180T	
Intermittent Fault Messages (Fig. 110)		180I	
Left, Center and Right Center Fuel Tank Wiring FQIS Wiring (Fig. 107)		145	

28-CONTENTS



BOEING
757
FAULT ISOLATION/MAINT MANUAL

CHAPTER 28 – FUEL

TABLE OF CONTENTS

<u>Subject</u>	Chapter Section <u>Subject</u>	<u>Page</u>	<u>Effectivity</u>
Load Select Indicator Shows the Message "-A.-", or "-b.-" or "-A.b" in the Display (Fig. 118)		180Z	
Load Select Indicator Shows the Message "I.d" in the Display (Fig. 120)		182B	
Not Used		143	
Not Used		180P	
Not Used		180Q	
Total Fuel Qty Does Not Agree with FMC Calculated Fuel Qty. Fuel Flow Normal. (Fig. 116)		180U	
[*] GUI 001-114, 116-999			
Component Location		101	CONFIG 3 [*]
Component Index			
Component Location			
Fault Isolation			
Dry Capacitance Test in the Main Equipment Center (No Fuel in the Tank) (Fig. 109)		180F	
EICAS Msg FUEL QTY IND or FUEL QTY CHANNEL Displayed. (Fig. 117)		180X	
Fault Message Reference Chart (Fig. 106)		143	
Fault Messages (Fig. 108)		150	
Fuel Quantity BITE Procedure (Fig. 104)		118	
Fuel Quantity Indicating Module (FQIM) Does Not Display Correctly. (Fig. 114)		180S	
Fuel Quantity Indicating Module (FQIM), M10054, Shows the Message(s) "-A.-", "-b.-" or "-A.b" in One or All Fuel Quantity Displays (Fig. 119)		182	
Fuel Quantity Indicating System Problems Index (Fig. 103)		117	
FQIS Wiring (Fig. 107)		144	


28-CONTENTS

CHAPTER 28 - FUEL

TABLE OF CONTENTS

<u>Subject</u>	<u>Chapter Section Subject</u>	<u>Page</u>	<u>Effectivity</u>
FUEL CONFIG Light and EICAS Message FUEL CONFIG are Illuminated (Fig. 111)		180N	
FUEL CONFIG Light and EICAS Msg LOW FUEL Not Displayed during Fuel Qty Test (Fig. 115)		180U	
Intermittent Fault Messages (Fig. 110)		180J	
Load Select Indicator Shows the Message "-A.-", or "-b.-" or "-A.b" in the Display (Fig. 118)		180Z	
Load Select Indicator Shows the Message "I.d" in the Display (Fig. 120)		182B	
Not Used		142	
Not Used		180Q	
Not Used		180R	
Total Fuel Qty Does Not Agree with FMC Calculated Fuel Qty. Fuel Flow Normal (Fig. 116)		180V	
[*] GUI 115			
FUEL PRESSURE INDICATING SYSTEM	28-42-00		
Component Location		101	ALL
Component Index			
Component Location			
FUEL TEMPERATURE INDICATING SYSTEM	28-43-00		
Component Location		101	ALL
Component Index			
Component Location			
Fault Isolation			
Fuel Temperature Indicator Does Not Display Correctly. (Fig. 103)		104	
FUEL MEASURING STICKS	28-44-00		
Component Location		101	ALL
Component Index			
Component Location			

28-CONTENTS



Basic Fault Isolation Process
Figure 1


EFFECTIVITY

ALL

28-HOW TO USE THE FIM

01

Page 1
Sep 20/98



How to Get Fault Information from BITE
Figure 2


EFFECTIVITY

ALL

28-HOW TO USE THE FIM

01

Page 2
Sep 20/98



How to Find the Corrective Action or Fault Isolation Procedure in the FIM

Figure 3

EFFECTIVITY

ALL

28-HOW TO USE THE FIM

01

Page 3
Sep 28/99

ASSUMED CONDITIONS AT START OF TASK

- External electrical power is OFF
- Hydraulic power and pneumatic power are OFF
- Engines are shut down
- Circuit breakers for the system are closed. (If open, do not close the circuit breaker for the fuel boost and fuel override pumps until you correct the problem).
- No equipment in the system is deactivated

PREREQUISITES

- This box gives the steps to get the airplane from the normal shutdown condition to the configuration necessary to do the fault isolation procedure.
- The Prerequisites give procedure references, circuit breakers, and special tools and equipment requirements.

FAULT ISOLATION BLOCKS

- Start the fault isolation procedure at block 1 unless specified differently.
- Do the check to get an answer to the question in the box. Follow the arrow that applies to your answer. This will go to the next check.
- When you get to a box in the column at the right of the page, you have isolated that fault. Do the steps in that box to repair the cause of the fault.
- Make sure that fault is corrected to complete the procedure.

Do the Fault Isolation Procedure
Figure 4


EFFECTIVITY

ALL

28-HOW TO USE THE FIM

01

Page 4
Sep 28/06




Subjects in Each FIM Chapter
Figure 5 (Sheet 1)

EFFECTIVITY	ALL
-------------	-----

28-HOW TO USE THE FIM

01


Page 5
Sep 20/98



Alphabetical list of the EICAS messages. Gives the procedure to repair the cause of the message or a reference to a fault isolation procedure.

Failure analysis diagrams for the airplane systems to find the correct fault code for the fault.


Numerical list of fault codes. Gives the procedure to repair the cause of the fault or a reference to a fault isolation procedure.



Alphabetical list of all the LRUs/systems that have BITE. Gives the chapter/section for the BITE procedure.

Component index, component location, and fault isolation procedures for the systems in the chapter.


Subjects in Each FIM Chapter
Figure 5 (Sheet 2)




28-HOW TO USE THE FIM

<u>TITLE</u>	<u>CHAP/SEC</u>
APU	
FAULT LIGHT.....	2825
FUEL VALVE	2825
RUN LIGHT	CHAPTER 49
SLCTR SWITCH	CHAPTER 49
BOOST PUMP (CTR).....	2822
BOOST PUMP (MAIN).....	2822
CROSSFEED VALVE(S).....	2822
ENGINE VALVE	CHAPTER 71
FUEL	
CONFIG	2841
CONTROL SW	CHAPTER 71
FLOW	CHAPTER 71
LEAK	2841
QTY BITE	2841
QTY IND	2841
QTY IND/CHANNEL MSGs	2841
QTY IND TEST SWITCH.....	2841
QTY (INDICATION VS FMC	
FUEL QTY)	2841
TEMP IND	2843
TRANSFER	2841
USED	CHAPTER 34
LOW FUEL	2841
SPAR VALVE	2822
TOTAL FUEL QTY IND.....	2841

FUEL - INDEX
 Figure 1 (Sheet 1)



28-INDEX




FUEL - INDEX
Figure 1 (Sheet 2)

EFFECTIVITY	ALL
-------------	-----

28-INDEX

BOEING
757
FAULT ISOLATION/MAINT MANUAL



1 UNITS ARE IN LBS OR KGS

<u>TITLE</u>	<u>CHAP/SEC</u>
BAT PWR SWITCH	2821
DEFUELING LIGHT	2826
DEFUELING SWITCH	2826
FUELING VALVE LIGHT	2821
FUELING VALVE SWITCH	2821
LOAD SELECT CONTROL	2841
LOAD SELECT INDICATOR	2841
OVERFILL RESET SWITCH	2821
OVERFILL TEST SWITCH	2821
PANEL LIGHT	2821
SET SWITCH	2821
TEST SWITCH IND	2841
TEST SWITCH SYSTEM	2821

FUEL - INDEX (GROUND)
Figure 2

EFFECTIVITY

ALL

28-INDEX

FUEL - EICAS MESSAGE LIST

1. General

- A. This procedure shows the EICAS message locations and gives a list of procedures to find the solution for each message.
 - (1) EICAS Message Locations (Fig. 1)
 - (a) Figure 1 shows the location of the EICAS display units and the area where the messages show on the display units.
 - (b) Each message level has a different location. The location and color of each message level is also shown.
 - (2) The EICAS MESSAGE LIST gives the message, level, and procedure for each message.
 - (a) The EICAS MESSAGE column lists the messages alphabetically. Messages which start with L, R, or C are put together and alphabetized at L.
 - (b) The LEVEL column gives all levels for each message as follows:
 - A - Warning messages
 - B - Caution messages
 - C - Advisory messages
 - S - Status messages
 - M - Maintenance messages
 - (c) The PROCEDURE column gives the steps that are necessary to remove the message and includes one or more of the procedures that follow:
 - 1) A Fault Isolation Manual procedure reference
 - 2) A Maintenance Manual procedure and reference
 - 3) Wiring checks and a Wiring Diagram Manual reference
 - 4) A reference to an EICAS message list in a different chapter.
 - 5) A reference to a FAULT CODE INDEX and specified fault codes
 - 6) A step to change the airplane configuration

EFFECTIVITY



ALL

28-EICAS MESSAGES


01

Page 1
Sep 20/90


BOEING
757
FAULT ISOLATION/MAINT MANUAL



ENGINE PRIMARY PAGE OR COMPACTED PAGE
(TOP DISPLAY UNIT)




ECS/MSG PAGE
(BOTTOM DISPLAY UNIT)



STATUS PAGE
(BOTTOM DISPLAY UNIT)

LEVEL	COLOR
A-WARNING	RED
B-CAUTION	YELLOW
C-ADVISORY	YELLOW
S-STATUS	WHITE
M-MAINTENANCE	WHITE

EICAS Message Locations
Figure 1



28-EICAS MESSAGES


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

EICAS MESSAGE LIST		
EICAS MESSAGE	LEVEL	PROCEDURE
APU FUEL VAL	C	FIM 28-25-00/101, Fig. 104
CTR (L,R) FUEL PUMP	C	Replace the (L, R) override fuel boost pump switch-light (YQVS6, YQVS7) (AMM 33-13-00/201). FIM 28-22-00/101, Fig. 105
DC FUEL PUMP ON	M	FIM 28-25-00/101, Fig. 105
FUEL CONFIG	C	FIM 28-41-00/101, Fig. 111
FUEL CROSSFEED	C	FIM 28-22-00/101, Fig. 107 FIM 28-22-00/101, Fig. 108
FUEL QTY BITE	S,M	FIM 28-41-00/101, Fig. 104
FUEL QTY CHANNEL	S	FIM 28-41-00/101, Fig. 117
FUEL QTY IND	S	FIM 28-41-00/101, Fig. 117
(L,R) AFT FUEL PUMP	C	FIM 28-22-00/101, Fig. 106
(L,R) FUEL SPAR VAL	C	Go to 28-FAULT CODE INDEX and look at the fault codes: 28 22 01 --, 28 22 06 --, 28 22 07 --, 28 22 09 --.
(L,R) FUEL SYS PRESS	B	FIM 28-22-00/101, Fig. 109
(L,R) FWD FUEL PUMP	C	FIM 28-22-00/101, Fig. 106
LOW FUEL	B	FIM 28-41-00/101, Fig. 104

EFFECTIVITY

ALL

28-EICAS MESSAGES


07

Page 3
May 28/05

BOEING

757

FAULT ISOLATION/MAINT MANUAL



APPLICABLE CIRCUIT BREAKERS

6E5	FUELING CONTROL	34A10	FUEL QTY
6E4	FUELING QTY	34A11	FLNG CONT
6E6	FUELING VALVES	34A9	FLNG VALVES
11C34	FUEL QTY R		
11L19	FUEL QTY L		

PRESSURE FUELING – FAULT CODES (GROUND)

EFFECTIVITY




ALL

28-FAULT CODE DIAGRAM

01

Page 1
Jun 15/86

BOEING
757
FAULT ISOLATION/MAINT MANUAL



FAULT CODE/
LOCATION


R MAIN 01
L MAIN 02
CENTER 03
ALL 04

FUELING START?

FUELING SLOW?

FUELING STOPPED AT
PRESELECTED QTY?

FUEL SPILL AT
SURGE TANK?



APPLICABLE CIRCUIT BREAKERS

6E5	FUELING CONTROL	34A10	FUEL QTY
6E4	FUEL QTY	34A11	FLNG CONT
6E6	FUELING VALVES	34A9	FLNG VALVES
11C34	FUEL QTY R		
11L19	FUEL QTY L		

PRESSURE FUELING - FAULT CODES (GROUND)


EFFECTIVITY
ALL

28-FAULT CODE DIAGRAM

108715

BOEING

757 FAULT ISOLATION/MAINT MANUAL



APPLICABLE CIRCUIT BREAKERS

6F14	L FUEL OVRD PUMP	6H17	R FWD FUEL BOOST PUMP
6F20	R FUEL OVRD PUMP	6H20	R AFT FUEL BOOST PUMP
6H14	L AFT FUEL BOOST PUMP	6H23	L FWD FUEL BOOST PUMP

FUEL BOOST PUMPS – FAULT CODES


EFFECTIVITY

ALL

28-FAULT CODE DIAGRAM

01

Page 3
Jun 20/90



APPLICABLE CIRCUIT BREAKERS AS INSTALLED

6E3	APU FUEL VALVES
6H23	L FWD FUEL BOOST PUMP
11D32	FUEL DISAGREE ENABLE APU
11D32	FUEL DISAGREE ENBL APU


APU FUEL FEED - FAULT CODES

EFFECTIVITY
ALL

28-FAULT CODE DIAGRAM

BOEING

757 FAULT ISOLATION/MAINT MANUAL



**FAULT CODE/
LOCATION**

L 01
R 02
FWD 03
AFT 04
SINGLE 05

NOT APPLY 00

1 AIRPLANES WITH A SINGLE FUEL CROSSFEED VALVE.
2 AIRPLANES W/FWD AND AFT FUEL CROSSFEED VALVES.

APPLICABLE CIRCUIT BREAKERS AS INSTALLED

6E1	L SPAR FUEL VALVES
6E2	R SPAR FUEL VALVES
1 11D36	FUEL CROSSFEED


2 A19	FUEL CROSSFEED VALVE FWD
2 D24	FUEL CROSSFEED VALVE FWD
2 A20	FUEL CROSSFEED VALVE AFT
2 D25	FUEL CROSSFEED VALVE AFT
2 11D36	X FEED IND

FUEL FEED (VALVES) – FAULT CODES

EFFECTIVITY
ALL

28-FAULT CODE DIAGRAM

C30553



APPLICABLE CIRCUIT BREAKERS AS INSTALLED

6E4	FUELING QTY
11C34	FUEL QTY L
11C34	FUEL QTY 1
11L19	FUEL QTY R
11L19	FUEL QTY 2

- 1 DURING TEST OBSERVE:
ALL (8) IN QTY EXCEPT 1 IN FIRST
DIGIT OF TOTAL AND 188 IN TEMP
FUEL CONFIG LGT, EICAS MSG - LOW FUEL
MASTER CAUTION LGTS & AURAL CAUTION (ENG RUNNING)
- 2 IF BLANK WITH FUEL QTY IND MSG DISPLAYED, SEE " FUEL QTY
IND/CHANNEL MSG'S".

FUEL QUANTITY, TEMPERATURE INDICATION AND TEST - FAULT CODES

EFFECTIVITY


ALL

28-FAULT CODE DIAGRAM

BOEING

757

FAULT ISOLATION/MAINT MANUAL



APPLICABLE CIRCUIT BREAKERS

N/A

FUEL TRANSFER/CONFIG - FAULT CODES

EFFECTIVITY


ALL

28-FAULT CODE DIAGRAM

02

Page 7
Jun 15/87

BOEING
757
FAULT ISOLATION/MAINT MANUAL



APPLICABLE CIRCUIT BREAKERS

6E6	DEFUELING VALVES
34A9	DEFUELING VALVES

DEFUELING - FAULT CODES (GROUND)

EFFECTIVITY


ALL

28-FAULT CODE DIAGRAM

BOEING

757

FAULT ISOLATION/MAINT MANUAL



- 1 REPORT FUEL QUANTITY DIFFERENCE THAT EXCEEDS 900 KGS FOR OVER 6 MINUTES AND REACHES 1400 KGS. 6 MINUTE TIME IS CUMULATIVE. SMALLER DIFFERENCES MAY BE NORMAL WITH AIRPLANE ATTITUDE AND SYSTEM TOLERANCES.
- 2 TO CORRECT DIFFERENCE BETWEEN FMC FUEL & TOTALIZER FUEL ON PERF INIT PAGE, MANUALLY ENTER ANY AMOUNT OF FUEL, THEN DELETE FUEL WITH DELETE KEY. FMC SHOULD THEN DISPLAY TOTALIZER FUEL.
- 3 FUEL LEAKS MAY BE CHECKED VISUALLY BY CABIN STAFF OR EVIDENT BY AILERON TRIM, AIRPLANE PERFORMANCE, OR FUEL MANAGEMENT CHECK.

APPLICABLE CIRCUIT BREAKERS

11C34	FUEL QTY 1
11L19	FUEL QTY 2

FUEL QTY (INDICATION VS FMC FUEL QTY) - FAULT CODES

EFFECTIVITY

ALL


28-FAULT CODE DIAGRAM

141282

BOEING

757

FAULT ISOLATION/MAINT MANUAL



FUEL QTY IND/CHANNEL MSG'S - FAULT CODES

EFFECTIVITY

ALL

28-FAULT CODE DIAGRAM

B79076



BOEING
757
FAULT ISOLATION/MAINT MANUAL

FAULT CODE	LOG BOOK REPORT	FAULT ISOLATION REFERENCE
28 21 XA 00	A ground fueling problem was encountered by the ground crew which is not covered in the fault code diagrams.	SSM 28-21-01
28 21 XB --	A (01=R MAIN,02=L MAIN,03=CENTER,04=ALL) fueling problem was encountered by the ground crew which is not covered by fault code diagrams.	SSM 28-21-01
28 22 XA --	A (01=L FWD,02=L AFT,03=R FWD,04=R AFT,05=L CTR,06=R CTR,07=L,08=R,09=L&R) fuel boost pump problem developed which was not covered by fault code diagrams.	SSM 28-22-01
28 22 XB --	A (01=L,02=R) fuel feed problem developed which was not covered by fault code diagrams.	SSM 28-22-01
28 25 XA 00	An APU fuel feed problem developed which was not covered by fault code diagrams.	SSM 28-25-01
28 26 XA --	A (01=RIGHT MAIN,02=LEFT MAIN) defueling problem was encountered by the ground crew which is not covered in the fault code diagrams.	SSM 28-26-01
28 41 XA --	A (01=L MAIN,02=R MAIN,03=C,04=TOTAL) fuel quantity and temperature indicating system problem developed which was not covered by fault code diagrams.	FIM 28-41-00/101, Fig. 104
28 41 XB --	A (01=L,02=R) fuel transfer/configuration problem developed which was not covered by fault code diagrams.	FIM 28-41-00/101, Fig. 104
28 41 XC 00	A fuel quantity indication vs FMC fuel quantity indication problem was encountered by the flight crew which was not covered by fault code diagrams.	SSM 28-41-01 thru SSM 28-41-04

EFFECTIVITY

ALL

28-FAULT CODE INDEX

03

Page 1
Sep 20/08



BOEING
757
FAULT ISOLATION/MAINT MANUAL

FAULT CODE	LOG BOOK REPORT	FAULT ISOLATION REFERENCE
28 41 XD --	A (01=L,02=R,03=C) fuel quantity indication/fuel quantity channel message problem was encountered by the flight crew which was not covered by fault code diagrams.	SSM 28-41-01 thru SSM 28-41-03
28 21 01 --	(01=R MAIN,02=LMAIN,04=ALL,05=R CTR,06=L CTR) Fueling valve lgt fails to come on with fueling valve selected open.	FIM 28-21-00/101, Fig. 104
28 21 02 --	(01=R MAIN,02=L MAIN,03=CENTER,04=ALL) Load select indicator display remained blank with indicator test switch pushed.	(01=R MAIN,02=L MAIN,03=CENTER) Replace load select indicator N92 (left main tank), N10011 (center tank), N93 (right main tank)(AMM 28-41-06). (04=ALL) FIM 28-21-00/101, Fig. 107, Block 1.
28 21 03 --	(01=R MAIN,02=L MAIN,03=CENTER) Load select indicator fails to display 8s when test switch is pushed.	FIM 28-21-00/101, Fig. 105, Block 1
28 21 04 00	Fueling control panel light fails to come on with ground power on airplane.	FIM 28-21-00/101, Fig. 106, Block 1
28 21 05 --	(01=R MAIN,02=L MAIN,05=R CENTER,06=L CENTER) fueling valve light fails to come on with fueling valve selected open and battery power selected.	FIM 28-21-00/101, Fig. 104, Block 1
28 21 06 --	(01=R MAIN,02=L MAIN,03=CENTER) Load select indicators displays remain blank with battery power selected and indicator test switch pushed.	FIM 28-21-00/101, Fig. 103, Block 1
28 21 07 --	(01=R MAIN,02=L MAIN,03=CENTER) Load select indicator fails to display 8s with battery power selected and indicator test switch pushed.	FIM 28-21-00/101, Fig. 105A, Block 1

EFFECTIVITY

ALL

28-FAULT CODE INDEX

02

Page 2
Sep 20/08



BOEING
757
FAULT ISOLATION/MAINT MANUAL

FAULT CODE	LOG BOOK REPORT	FAULT ISOLATION REFERENCE
28 21 08 --	(01=R MAIN,02=L MAIN,03=CENTER,04=ALL) Fueling valve OPEN light on with fueling switch in FUEL. Fuel quantity did not increase.	FIM 28-21-00/101, Fig. 105, Block 1
28 21 09 --	(01=R MAIN,02=L MAIN,03=CENTER,04=ALL) Tank pressure fueling does not stop at preselected quantity. No fuel spill occurs at surge tank.	FIM 28-21-00/101, Fig. 108, Block 1
28 21 10 --	(01=R MAIN,02=L MAIN,03=CENTER,04=ALL) Tank pressure fueling does not stop at preselected quantity. Fuel spill occurs at surge tank.	FIM 28-21-00/101, Fig. 109, Block 1
28 21 11 --	(01=R MAIN,02=L MAIN,03=CENTER,04=ALL) Fueling valve OPEN light on with fueling switch in FUEL. Fuel quantity increased at a slow rate.	FIM 28-21-00/101, Fig. 105, Block 1
28 21 12 --	(01=R MAIN,02=L MAIN,03=CENTER,04=ALL) Load select indicator display remained all 8s when IND TEST switch was depressed and released.	(01=R MAIN,02=L MAIN,03=CENTER) Replace load select indicator N92 (left main tank), N10011 (center tank), N93 (right main tank)(AMM 28-41-06). (04=ALL) Replace IND TEST switch S457 on P28 fueling control panel (WDM 28-21-11).
28 21 13 --	(01=L,02=R) main tank transferred fuel (___ kgs/ ___ lbs) into C tank.	FIM 28-21-00/101, Fig. 108, Block 1
28 22 01 --	(01=L,02=R) SPAR VALVE lgt remained on with Fuel Control sw selected (CUTOFF, RICH, RUN). EICAS msg (L,R) FUEL SPAR VALVE displayed.	FIM 28-22-00/101, Fig. 104, Block 1
28 22 02 --	(07=L CTR,11=R CTR) BOOST PUMP low PRESS light on. EICAS msg CTR (L,R) FUEL PUMP displayed.	FIM 28-22-00/101, Fig. 105, Block 1

EFFECTIVITY

ALL

28-FAULT CODE INDEX

01

Page 3
Sep 20/08


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT CODE	LOG BOOK REPORT	FAULT ISOLATION REFERENCE
28 22 03 --	(05=L FWD,06=L AFT,09=R FWD,10=R AFT) BOOST PUMP low PRESS lgt on with switch on. EICAS msg (L,R) (FWD,AFT) FUEL PUMP displayed.	FIM 28-22-00/101, Fig. 106, Block 1
28 22 04 00	(03=Fwd,04=Aft,05=Single) FUEL CROSSFEED VALVE lgt failed to come on when (open, close) selected. EICAS msg (FWD FUEL CROSSFEED, AFT FUEL CROSSFEED, FUEL CROSSFEED) displayed.	FIM 28-22-00/101, Fig. 107, Block 1
28 22 05 00	(03=Fwd,04=Aft,05=Single) FUEL CROSSFEED VALVE lgt remained on when (open, close) selected. EICAS msg (FWD FUEL CROSSFEED, AFT FUEL CROSSFEED, FUEL CROSSFEED) displayed.	FIM 28-22-00/101, Fig. 108, Block 1
28 22 06 --	(01=L,02=R) ENG VALVE and SPAR VALVE light on and EICAS msg: (L,R) FUEL SPAR VAL and (L,R) ENG FUEL VAL displayed with fuel control sw in (RUN,RICH,CUTOFF). No fuel flow indicated.	FIM 28-22-00/101, Fig. 104, Block 2
28 22 07 --	(01=L,02=R) eng SPAR VALVE light on and EICAS msg: (L,R) FUEL SPAR VAL displayed with fuel control sw in (RUN,RICH). Fuel flow indicated.	FIM 28-22-00/101, Fig. 104, Block 20
28 22 08 --	EICAS msg (01=L,02=R,08=L&R) FUEL SYS PRESS displayed.	FIM 28-22-00/101, Fig. 109, Block 1
28 22 09 --	(01=L,02=R) SPAR VALVE lgt failed to come on with Fuel Control sw selected (CUTOFF, RICH, RUN). EICAS msg (L,R) FUEL SPAR VALVE displayed.	Relamp R(L) spar valve annunciator on fuel control module M73 (AMM 33-16-02). If the problem continues, replace annunciator diode/fuse card (AMM 33-16-02).
28 22 10 --	(07=L CTR,11=R CTR) BOOST PUMP low PRESS lgt on and EICAS message CTR (L,R) FUEL PUMP displayed with sw OFF.	Replace L(R) override fuel boost pump switch/light YQVS6 (YQVS7) (AMM 33-13-00).

EFFECTIVITY

ALL

28-FAULT CODE INDEX

01

Page 4
Sep 20/08



BOEING
757
FAULT ISOLATION/MAINT MANUAL

FAULT CODE	LOG BOOK REPORT	FAULT ISOLATION REFERENCE
28 22 11 --	(05=L FWD,06=L AFT,09=R FWD,10=R AFT) BOOST PUMP low PRESS light failed to come on and EICAS message failed to display with switch OFF.	(01=L FWD) FIM 28-22-00/101, Fig. 111, Block 1. (02=L AFT,03=R FWD,04=R AFT) FIM 28-22-00/101, Fig. 110, Block 1.
28 22 13 --	(05=L FWD,06=L AFT,07=L CTR,09=R FWD,10=R AFT,11=R CTR) fuel boost pump sw (light(s) inop, binds, bar inop, cover broken, etc).	Replace fuel boost pump switch/light: (05=L fwd) YQVS2, (06=L aft) YQVS1, (07=L ctr) YQVS6, (09=R fwd) YQVS5, (10=R aft) YQVS4, (11=R ctr) YQVS7.
28 25 01 00	APU FAULT lgt on and EICAS msg APU FUEL VAL displayed.	FIM 28-25-00/101, Fig. 104, Block 1
28 25 02 00	EICAS msg DC FUEL PUMP ON displayed.	FIM 28-25-00/101, Fig. 105, Block 1
28 25 03 00	EICAS msg L FWD FUEL PUMP displayed and L FWD BOOST PUMP low PRESS lgt on with AC power and APU sw on.	FIM 28-22-00/101, Fig. 106, Block 1
28 26 01 --	(01=R MAIN,02=L MAIN) defueling valve light on with defuel valve sw in CLOSE.	FIM 28-26-00/101, Fig. 103, Block 1
28 26 02 --	(01=R MAIN,02=L MAIN) Defueling valve light off with defuel valve sw in OPEN.	FIM 28-26-00/101, Fig. 103, Block 1
28 41 01 --	(01=L MAIN,02=R MAIN,03=C,04=TOTAL) FUEL QTY ind displays (describe condition: inaccurate, blank, missing segments) during FUEL QTY TEST.	FIM 28-41-00/101, Fig. 114, Block 1
28 41 02 --	(01=L MAIN,02=R MAIN,03=C,04=TOTAL,05=(L or R or C) & TOTAL,06=ALL) FUEL QTY ind displays (describe condition: intermittent, fluctuate, inaccurate, blank, missing segments). FUEL QTY TEST normal.	FIM 28-41-00/101, Fig. 104

EFFECTIVITY

ALL

28-FAULT CODE INDEX

06

Page 5
Sep 20/08



757
FAULT ISOLATION/MAINT MANUAL

FAULT CODE	LOG BOOK REPORT	FAULT ISOLATION REFERENCE
28 41 03 --	(01=L MAIN,02=R MAIN,03=C,04=TOTAL) FUEL QTY ind displays (describe condition: intermittent, fluctuates, inaccurate, blank, missing segments). FUEL QTY TEST normal.	FIM 28-41-00/101, Fig. 114, Block 1
28 41 04 00	EICAS msg FUEL QTY BITE displayed.	FIM 28-41-00/101, Fig. 104
28 41 05 00	FUEL QTY & TEMP display (describe condition: inaccurate, blank, missing segments) during FUEL QTY TEST.	Replace fuel quantity indicator M10054 (AMM 28-41-04/401).
28 41 06 00	FUEL CONFIG lgt & EICAS msg LOW FUEL not displayed during FUEL QTY TEST.	FIM 28-41-00/101, Fig. 115, Block 1
28 41 07 00	FUEL QTY & TEMP system did not test. Operation normal with test sw in normal.	Replace test panel M10398 (S6 faulty) (WDM 28-41-31).
28 41 11 --	(01=L MAIN,02=R MAIN,03=C,04=TOTAL) FUEL QTY displays (describe condition: fluctuates, inaccurate, blank, missing segments). FUEL TEMP ind abnormal. FUEL QTY TEST abnormal.	Replace fuel quantity indicator M10054 (AMM 28-41-04/401).
28 41 12 --	(01=L MAIN,02=R MAIN,03=C,04=TOTAL) FUEL QTY display reads zero. FUEL QTY TEST normal.	FIM 28-41-00/101, Fig. 104
28 41 13 00	FUEL CONFIG lgt remained off and EICAS msg FUEL CONFIG did not display with more than 1200 LBS/500KGS in C tank with C pumps off.	FIM 28-41-00/101, Fig. 104
28 41 14 --	FUEL CONFIG lgt remained off and EICAS msg LOW FUEL did not display with less than 2200 LBS/1000 KGS in (01=L,02=R) main tank.	FIM 28-41-00/101, Fig. 104

EFFECTIVITY

ALL

28-FAULT CODE INDEX

10

Page 6
Sep 20/08



BOEING
757
FAULT ISOLATION/MAINT MANUAL

FAULT CODE	LOG BOOK REPORT	FAULT ISOLATION REFERENCE
28 41 15 --	FUEL CONFIG lgt remained off and EICAS msg FUEL CONFIG did not display with main tanks unbalance of ____ LBS/____ KGS). (01=L,02=R) Fuel tank low.	FIM 28-41-00/101, Fig. 104
28 41 16 00	FUEL CONFIG lgt on and EICAS msg LOW FUEL displayed with more than 2200 LBS/1000 KGS in each main tank.	FIM 28-41-00/101, Fig. 104
28 41 17 00	FUEL CONFIG lgt on and EICAS msg FUEL CONFIG displayed with center qty less than 1000 LBS/400 KGS and main tanks balanced.	FIM 28-41-00/101, Fig. 104
28 41 18 --	Total fuel differs from (12=Capt,13=F/O,14=Capt & F/O) FMC(s) calculated fuel qty. Differences exceeded 2000 lbs/900 kgs for over 6 minutes and peaked above 3000 lbs/1400 kgs. EICAS msg, FMC MESSAGE or FUEL QTY BITE did not display. Fuel flow was norm. Total fuel _____, FMC calculated fuel _____.	FIM 28-41-00/101, Fig. 104
28 41 20 --	Total fuel differs from (12=Capt,13=F/O,14=Capt & F/O) FMC(s) calculated fuel quantity. Total fuel _____, FMC calculated fuel _____. EICAS msg FUEL QTY BITE displayed. Fuel flow was normal.	FIM 28-41-00/101, Fig. 116
28 41 21 00	EICAS msg FUEL QTY CHANNEL displayed. FUEL QTY test not checked.	FIM 28-41-00/101, Fig. 117, Block 1
28 41 22 --	(01=L,02=R,03=C) Fuel tank and total fuel indicators (blank, intermittent). EICAS msg FUEL QTY IND not displayed.	Replace the fuel quantity indicator M10054 (AMM 28-41-04/401).

EFFECTIVITY

ALL

28-FAULT CODE INDEX

07

Page 7
Sep 20/08


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT CODE	LOG BOOK REPORT	FAULT ISOLATION REFERENCE
28 41 23 --	(01=L,02=R,03=C) Fuel tank and total fuel indicators (blank, intermittent). EICAS msg FUEL QTY IND displayed. FUEL QTY test not checked.	FIM 28-41-00/101, Fig. 104
28 41 24 00	EICAS msg FUEL QTY BITE displayed (steady,intermittent). FUEL QTY test not checked.	FIM 28-41-00/101, Fig. 104
28 41 25 --	Total fuel differs from (12=Capt,13=F/O,14=Capt & F/O) FMC(s) calculated fuel qty. Fuel qty ERROR-PROG 2/2 alert msg displayed on CDU and EICAS msgs, FMC MESSAGE and FUEL QTY BITE displayed. Total Fuel Fuel _____, FMC fuel _____.	FIM 28-41-00/101, Fig. 104
28 41 26 00	FUEL CONFIG light on and EICAS msg FUEL CONFIG displayed with C pumps on and main tanks balanced.	FIM 28-41-00/101, Fig. 104
28 41 28 00	All fuel tank qty indicators (blank, intermittent). No EICAS msgs displayed.	Replace fuel quantity indicator M10054 (AMM 28-41-04).
28 41 29 00	All fuel tank qty indicators (blank, intermittent). EICAS msg FUEL QTY CHANNEL displayed.	FIM 28-41-00/101, Fig. 104
28 41 30 00	All fuel tank qty indicators blank. EICAS msgs FUEL QTY BITE and FUEL QTY CHANNEL displayed (steady, intermittent).	FIM 28-41-00/101, Fig. 104
28 41 31 --	(01=L,02=R,03=C) Fuel tank and total fuel qty indicators (blank, intermittent). EICAS msg FUEL QTY CHANNEL displayed.	FIM 28-41-00/101, Fig. 104
28 41 32 00	EICAS msg FUEL QTY CHANNEL displayed. Display returned within 60 sec of FUEL QTY test.	FIM 28-41-00/101, Fig. 117, Block 1

EFFECTIVITY

ALL

28-FAULT CODE INDEX

06

Page 8
Sep 20/08



BOEING
757
FAULT ISOLATION/MAINT MANUAL

FAULT CODE	LOG BOOK REPORT	FAULT ISOLATION REFERENCE
28 41 33 --	(01=L,02=R,03=C) Fuel tank and total fuel qty indicators (blank, intermittent). EICAS msg FUEL QTY IND displayed. Display returned within 60 sec of FUEL QTY test.	FIM 28-41-00/101, Fig. 114, Block 1
28 41 34 --	(01=L,02=R) Eng, side of airplane has evidence of fuel leak. Fuel leak evidence checked (visually, by abnormal aileron trim, fuel management, airplane performance, etc). Total fuel differs from FMC qty with normal fuel flow.	FIM 28-41-00/101, Fig. 116, Block 1
28 41 35 --	(01=L MAIN,02=R MAIN,03=C, 04=TOTAL,05=(L OR R OR C) & TOTAL,06=ALL) FUEL QTY ind displays (-A.-, -b.-, -A.b) during FUEL QTY TEST.	FIM 28-41-00/101, Fig. 119, Block 1
28 41 36 --	EICAS msg FUEL QTY CHANNEL displayed. (01=L,02=R,03=C) Fuel qty ind displays (-A.-, -b.-, -A.b). Display returned within 60 sec of FUEL QTY test.	FIM 28-41-00/101, Fig. 104
28 41 37 --	(01=L,02=R,03=C) Fuel tank and total fuel qty indicators (blank, intermittent). EICAS msg FUEL QTY IND displayed. Fuel qty ind displays (-A.-, -b.-, -A.b). Display returned within 60 sec of FUEL QTY test.	FIM 28-41-00/101, Fig. 104
28 41 38 --	All fuel tank qty indicators (blank, intermittent). (01=L, 02=R,03=C) Fuel qty ind displays (-A.-, -b.-, -A.b). EICAS msg FUEL QTY CHANNEL displayed.	FIM 28-41-00/101, Fig. 104
28 43 01 00	FUEL TEMP ind displays (describe condition: inaccurate, blank, missing segments) during FUEL QTY TEST.	FIM 28-43-00/101, Fig. 103, Block 1

EFFECTIVITY

ALL

28-FAULT CODE INDEX

07

Page 9
Sep 20/08



BOEING
757
FAULT ISOLATION/MAINT MANUAL

FAULT CODE	LOG BOOK REPORT	FAULT ISOLATION REFERENCE
28 43 02 00	FUEL TEMP displays (describe condition: intermittent, inaccurate, blank, missing segments). FUEL QTY TEST normal.	FIM 28-43-00/101, Fig. 103, Block 1
28 43 03 00	FUEL TEMP displays (describe condition: intermittent, inaccurate, blank, missing segments). FUEL QTY TEST abnormal.	FIM 28-43-00/101, Fig. 103, Block 1

EFFECTIVITY

ALL

28-FAULT CODE INDEX

01

Page 10
Sep 20/08


BITE Index

1. General

- A. Use this index to find the BITE procedure for the applicable LRU/System.
- B. The BITE procedure will provide the fault isolation instructions for the fault indications/LRU maintenance messages.

<u>LRU/System Name</u>	<u>Acronym</u>	<u>FIM Reference</u>
Air Data Computer	ADC	34-12
Air Data Inertial Reference Unit	ADIRU	34-26
Air Traffic Control Transponder	ATC	34-53
Airborne Vibration Monitor Signal Conditioner	AVM	77-31
Antiskid/Autobrake Control Unit		32-42
APU Fire Detection System		26-15
Automatic Direction Finder Receiver	ADF	34-57
APU Control Unit	ECU	49-11
Brake Temperature Monitor Unit		32-46
Bus Power Control Unit	BPCU	24-20
Cabin Pressure Controller		21-30
Digital Flight Data Acquisition Unit	DFDAU	31-31
Distance Measuring Equipment Interrogator	DME	34-55
Duct Leak (Wing and Body)		26-18
E/E Cooling Control Card (If cards installed)		21-58
ECS Bleed Configuration Card		36-10
Electronic Engine Control (RR Engines)	EEC	73-21
Electronic Engine Control Monitor Unit (PW Engines)	EECM	71-EPCS Message Index
Electronic Flight Instrument System	EFIS	34-22
Electronic Propulsion Control System (PW Engines)	EPCS	71-EPCS Message Index
Engine Fire/Overheat Detection System		26-11
Engine Indication and Crew Alerting System Computer	EICAS	31-41

Bite Index
Figure 1 (Sheet 1)




28-BITE INDEX


757
FAULT ISOLATION/MAINT MANUAL

<u>LRU/System Name</u>	<u>Acronym</u>	<u>FIM Reference</u>
Engine Turbine Cooling Overheat Detection System (RR Engines)		26-13
Enhanced Ground Proximity Warning Computer	EGPWC	34-46
Flap/Slat Accessory Module	FSAM	27-51
Flap/Slat Electronic Unit	FSEU	27-51
Flight Management Computer	FMC	34-61
Fuel Quantity Indicating System Processor	FQIS	28-41
Ground Proximity Warning Computer	GPWC	34-46
HF (High Frequency) Communication		23-11
Inertial Reference Unit	IRU	34-21
Instrument Comparator Unit	ICU	34-25
Instrument Landing System Receiver	ILS	34-31
Lower Cargo Compartment Smoke Detection System		26-16
Maintenance Control Display Panel	MCDP	22-00
PA (Passenger Address) Amplifier		23-31
Pack Standby Temperature Controller		21-51
Pack Temperature Controller		21-51
Passenger Entertainment System	PES	23-34
Power Supply Module (Control System Electronics Units)	PSM	27-09
Propulsion Discrete Interface Unit (PW Engines)	PDIU	73-21
Proximity Switch Electronics Unit	PSEU	32-09
Radio Altimeter Transmitter/Receiver	RA	34-33
Rudder Ratio Changer Module	RRCM	27-09
Spoiler Control Module	SCM	27-09
Stabilizer Position Module	SPM	27-48
Stabilizer Trim/Elevator Asymmetry Limit Module	SAM	27-09
Stall Warning Computer/Module (in Warning Electronic Unit)	SWC	27-32
Strut Overheat Detection System (RR Engines)		26-12

Bite Index
Figure 1 (Sheet 2)




28-BITE INDEX


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

<u>LRU/System Name</u>	<u>Acronym</u>	<u>FIM Reference</u>
Thrust Management Computer/Autothrottle	TMC	22-00
Traffic Alert and Collision Avoidance Computer	TCAS	34-45
VHF (Very High Frequency) Communication		23-12
VOR/Marker Beacon Receiver	VOR/MKR	34-51
Warning Electronic Unit BITE Module (Stall Warning)	WEU	27-32
Weather Radar Transceiver	WXR	34-43
Wheel Well Fire Detection		26-17
Window Heat Control Unit	WHCU	30-41
Yaw Damper Module	YDM	22-21
Yaw Damper/Stabilizer Trim Module	YSM	27-09
Zone Temperature Controller		21-60

Bite Index
Figure 1 (Sheet 3)



28-BITE INDEX

01


Page 3
Sep 28/99


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FUEL TANKS

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
DOOR - CENTER TANK ACCESS	1	7	134AZ,531AB,531BB,531CB,631AB, 631BB,631CB	28-11-02
DOOR - LEFT MAIN TANK ACCESS	1	16	541AB,541BB,541CB,541DB,541EB, 541FB,541GB,541HB,541JB,541KB, 541LB,541MB,542AB,542BB,542CB, 542DB	28-11-01
DOOR - LEFT SURGE TANK ACCESS	1	3	543AB,543BB,543CB	28-11-03
DOOR - RIGHT MAIN TANK ACCESS	1	16	641AB,641BB,641CB,641DB,641EB, 641FB,641GB,641HB,641JB,641KB, 641LB,641MB,642AB,642BB,642CB, 642DB	28-11-01
DOOR - RIGHT SURGE TANK ACCESS	1	3	643AB,643BB,643CB	28-11-03
PORT - OVERWING FILL	1	2	L & R UPPER WING SURFACE, OUTBD	28-11-04
VALVE - LEFT BAFFLE RIB CHECK	2	11	541AB	28-11-00
VALVE - LEFT CENTER TANK SUMP DRAIN	2	1	194CL, L ECS EQUIPMENT BAY ACCESS DOOR	28-11-05
VALVE - LEFT MAIN TANK SUMP DRAIN	2	1	541AB	28-11-05
VALVE - LEFT SURGE TANK SUMP DRAIN	2	1	543AB	28-11-05
VALVE - RIGHT BAFFLE RIB CHECK	2	11	641AB	28-11-00
VALVE - RIGHT CENTER TANK SUMP DRAIN	2	1	194CR, R ECS EQUIPMENT BAY ACCESS DOOR	28-11-05
VALVE - RIGHT MAIN TANK SUMP DRAIN	2	1	641AB	28-11-05
VALVE - RIGHT SURGE TANK SUMP DRAIN	2	1	643AB	28-11-05

Fuel Tanks - Component Index
Figure 101



28-11-00

01


Page 101
Sep 20/90

97821

BOEING

757

FAULT ISOLATION/MAINT MANUAL




Fuel Tanks - Component Location
Figure 102 (Sheet 1)

EFFECTIVITY	ALL
-------------	-----

28-11-00

E82154

BOEING
757
FAULT ISOLATION/MAINT MANUAL



Fuel Tanks - Component Location
Figure 102 (Sheet 2)

EFFECTIVITY	ALL
-------------	-----

28-11-00

01

Page 103
Sep 20/90



BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FUEL VENT SYSTEM

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
ARRESTOR - SURGE TANK VENT FLAME	2	2	543BB,643BB, WING, OUTBD	28-13-05
HOUSING - SURGE TANK VENT FLAME ARRESTOR	2	2	543BB,643BB, WING, OUTBD	28-13-05
VALVE - FLOAT DRAIN	2	4	134AZ, WING, INBD	28-13-03
VALVE - FLOAT-ACTUATED VENT	1	2	531CB,631CB, WING, INBD	28-13-01
VALVE - FUEL VENT FLOAT	1	2	542DB,642DB, WING, OUTBD	28-13-01
VALVE - SURGE TANK DRAIN CHECK	2	2	541MB,641MB, WING, OUTBD	28-13-08
VALVE - SURGE TANK PRESSURE RELIEF	2	2	543AB,643AB, WING, OUTBD	28-13-04

* SEE THE WDM EQUIPMENT LIST

Fuel Vent System - Component Index
Figure 101




28-13-00

01

Page 101
Sep 20/94


E44546



Fuel Vent System - Component Location
Figure 102 (Sheet 1)


EFFECTIVITY	
	ALL

28-13-00




FLOAT-ACTUATED VENT VALVE

(A)




FUEL VENT FLOAT VALVE

(B)



FLOAT DRAIN VALVE

(C)



PRESSURE RELIEF VALVE OF THE SURGE TANK

(D)

Fuel Vent System - Component Location (Details from Sht 1)
Figure 102 (Sheet 2)


EFFECTIVITY

ALL

28-13-00


01

Page 103
Sep 20/94




DRAIN CHECK VALVE OF THE SURGE TANK

(E) FROM SHT 1



VENT FLAME ARRESTOR OF THE SURGE TANK

(F) FROM SHT 1



Fuel Vent System - Component Location
Figure 102 (Sheet 3)

EFFECTIVITY	ALL

28-13-00

 **BOEING**
757
FAULT ISOLATION/MAINT MANUAL

PRESSURE FUELING

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
ACTUATOR - L CTR TANK FUELING SHUTOFF VALVE, V10001	3	1	LEFT MAIN LANDING GEAR DOOR	28-21-12
ACTUATOR - L TANK FUELING SHUTOFF VALVE, V10003	3	1	551BB, L WING, INBD	28-21-12
ACTUATOR - R CTR TANK FUELING SHUTOFF VALVE, V10064	3	1	RIGHT MAIN LANDING GEAR DOOR	28-21-12
ACTUATOR - R TANK FUELING SHUTOFF VALVE, V10002	3	1	651BB, R WING, INBD	28-21-12
ADAPTER - FUELING	2	2	FUELING PANEL DOOR, 621GB	28-21-01
CARD - SURGE TANK FUEL LEVEL SENSOR CONTROL, M586	4	1	119BL, MAIN EQUIP CTR, P50	28-21-04
CIRCUIT BREAKER - FUELING QTY, C1045	1	1	FLIGHT COMPARTMENT, P6 6E4	*
FUELING CONTROL, C1043	1	1	6E5	*
FUELING VALVES, C1046	1	1	6E6	*
CIRCUIT BREAKER - FUEL QTY R OR 2, C1048	1	1	FLIGHT COMPARTMENT, P11 11C34	*
FUEL QTY L OR 1, C1053	1	1	11L19	*
CIRCUIT BREAKER - FLNG VALVE, C1047	4	1	119BL, MAIN EQUIP CTR, P34 34A9	*
FUEL QTY, C1040	4	1	34A10	*
FLNG CONT, C1041	4	1	34A11	*
CONTROL - LOAD SELECT, M638	2	1	621GB, FUELING CONTROL PANEL, P28	28-41-07
PANEL - FUELING CONTROL, P28	2	1	621GB, R WING, OUTBD	28-21-08
LIGHT - FUELING PANEL DOOR, L243	2	1	621GB, FUELING CONTROL PANEL, P28	*
LIGHT - FUELING PANEL DOOR, L379	2	1	621GB, FUELING CONTROL PANEL, P28	*
LIGHT - L CTR FUELING VALVE OPEN, L402	2	1	621GB, FUELING CONTROL PANEL, P28	*
LIGHT - L MAIN FUELING VALVE OPEN, L83	2	1	621GB, FUELING CONTROL PANEL, P28	*
LIGHT - R CTR FUELING VALVE OPEN, L82	2	1	621GB, FUELING CONTROL PANEL, P28	*
LIGHT - R MAIN FUELING VALVE OPEN, L81	2	1	621GB, FUELING CONTROL PANEL, P28	*
RELAY - (FIM 31-01-33/101) FUEL QUANTITY TRANSFER, K356				
FUELING PANEL DOOR, K179				
FUELING POWER TRANSFER, K357				
L CTR REFUELING VALVE, K10013				
L REFUELING VALVE, K10025				
OVERFILL CONTROL, K181				
OVERFILL SET, K180				
R CTR REFUELING VALVE, K10157				
R REFUELING VALVE, K10024				
SENSOR - L SURGE TANK FUEL LEVEL, TS195	3	1	561AB, L WING	28-21-03
SENSOR - R SURGE TANK FUEL LEVEL, TS196	3	1	661AB, R WING, OUTBD	28-21-03

* SEE THE WDM EQUIPMENT LIST

Pressure Fueling - Component Index
Figure 101 (Sheet 1)

EFFECTIVITY

ALL

28-21-00

01

Page 101
Sep 20/93


56567


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL


COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
SWITCH - BATTERY POWER, S345	2	1	621GB, FUELING CONTROL PANEL, P28	*
SWITCH - CENTER LOAD SELECT SET, S420	2	1	621GB, FUELING CONTROL PANEL, P28	*
SWITCH - CTR FUELING VALVE, S417	2	1	621GB, FUELING CONTROL PANEL, P28	*
SWITCH - FUELING PANEL DOOR, S346	2	1	621GB, FUELING CONTROL PANEL, P28	*
SWITCH - L MAIN FUELING VALVE, S348	2	1	621GB, FUELING CONTROL PANEL, P28	*
SWITCH - LEFT MAIN LOAD SELECT SET, S418	2	1	621GB, FUELING CONTROL PANEL, P28	*
SWITCH - OVERFILL RESET, S347	2	1	621GB, FUELING CONTROL PANEL, P28	*
SWITCH - OVERFILL TEST, S416	2	1	621GB, FUELING CONTROL PANEL, P28	*
SWITCH - R MAIN FUELING VALVE, S349	2	1	621GB, FUELING CONTROL PANEL, P28	*
SWITCH - R MAIN LOAD SELECT SET, S419	2	1	621GB, FUELING CONTROL PANEL, P28	*
SWITCH - TEST INDICATOR, S457	2	1	621GB, FUELING CONTROL PANEL, P28	*
SWITCH - TEST SYSTEM, S421	2	1	621GB, FUELING CONTROL PANEL, P28	*
VALVE - FUELING MANIFOLD DRAIN CHECK	3	2	134AZ	28-21-05
VALVE - FUELING MANIFOLD VENT	3	1	642AB	28-21-09
VALVE - L CTR FUELING SHUTOFF, V10001	3	1	134AZ	28-21-02
VALVE - L MAIN FUELING SHUTOFF, V10003	3	1	541AB	28-21-02
VALVE - R CTR FUELING SHUTOFF, V10064	3	1	134AZ	28-21-02
VALVE - R MAIN FUELING SHUTOFF, V10002	3	1	641AB	28-21-02

* SEE THE WDM EQUIPMENT LIST

Pressure Fueling - Component Index
 Figure 101 (Sheet 2)



28-21-00



FLIGHT COMPARTMENT

Pressure Fueling - Component Location
Figure 102 (Sheet 1)

EFFECTIVITY	
	ALL


28-21-00

01

Page 103
Sep 20/94

BOEING

757 FAULT ISOLATION/MAINT MANUAL



Pressure Fueling - Component Location
Figure 102 (Sheet 2)


EFFECTIVITY

ALL


28-21-00

03


Page 104
Sep 20/94



LEFT OR RIGHT SURGE TANK FUEL LEVEL SENSOR, TS195 OR TS196



DRAIN CHECK VALVE OF THE FUELING MANIFOLD



FUELING SHUTOFF VALVE (EXAMPLE)

Pressure Fueling - Component Location
Figure 102 (Sheet 3)


EFFECTIVITY	ALL
-------------	-----

28-21-00


BOEING

757

FAULT ISOLATION/MAINT MANUAL



MAIN EQUIPMENT CENTER



ELECTRICAL SYSTEM CARD FILE, P50

(G)

Pressure Fueling - Component Location
Figure 102 (Sheet 4)

EFFECTIVITY	
	ALL

28-21-00


ALL LOAD SELECT INDICATOR DISPLAYS BLANK WITH BAT PWR SWITCH IN "ON" AND "TEST IND" SWITCH DEPRESSED

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
6E4,6E5,11L19,11C34

MAKE SURE THESE CIRCUIT BREAKERS ARE OPEN AND ATTACH DO-NOT-CLOSE TAGS:
34A10,34A11


MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:
ELECTRICAL POWER IS ON (MM 24-22-00/201)



All Load Select Indicator Displays Blank with Bat Pwr Switch in ON and TEST IND Switch Depressed
Figure 103 (Sheet 1)

EFFECTIVITY	ALL
-------------	-----

28-21-00



All Load Select Indicator Displays Blank with Bat Pwr Switch in ON and
TEST IND Switch Depressed
Figure 103 (Sheet 2)

EFFECTIVITY	ALL
-------------	-----

28-21-00

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:

11C34, 11L19, 6E4, 6E5, 6E6, 34A9, 34A10, 34A11

MAKE SURE THESE AIRPLANES ARE IN THIS CONFIGURATION:

ELECTRICAL POWER IS ON (AMM 24-22-00/201)

FUELING MANIFOLD IS PRESSURIZED (AMM 12-11-01/301)

EQUIPMENT:

1. FUEL QTY TEST SET - MODEL GTF-2, P/N 361-012-001
GULL AIRBORNE INSTRUMENTS, INC.,
55 ENGINEERS ROAD, SMITHTOWN, NY 11787

OR

2. FUEL QTY TEST SET - MODEL 8000
BARFIELD INSTRUMENT CORP.,
MIAMI, FL 33142

OR

3. FUEL QTY TEST SET - P/N 472090-007, OR
P/N 472090-009, OR 60-2R


NOTE: THE LATEST VERSION OF THE PSD-60-2R IS
REQUIRED (MODEL 6 OR HIGHER) TO DO THE
CONTINUITY CHECKS.

JcAir INC.
400 INDUSTRIAL PARKWAY
INDUSTRIAL AIRPORT, KS 66031

4. EXTENDER CARD - A28009-14

5. BCD M-1 BONDING METER
BCD ELECTRONICS LTD.
VANCOUVER, BC
(604) 433-2447

**FUELING VALVE LIGHT
FAILS TO ILLUMINATE
WITH FUELING VALVE
SELECTED OPEN**



Fueling Valve Light Fails to Illuminate with Fueling Valve Selected Open
Figure 104 (Sheet 1)

EFFECTIVITY

ALL

28-21-00


01

Page 109
Sep 28/07

71561

BOEING
757
FAULT ISOLATION/MAINT MANUAL


FROM SHEET 1
(BLOCK 2)



Fueling Valve Light Fails to Illuminate with Fueling Valve Selected Open
Figure 104 (Sheet 2)

EFFECTIVITY	ALL
-------------	-----

28-21-00



Fueling Valve Light Fails to Illuminate with Fueling Valve Selected Open
Figure 104 (Sheet 3)

EFFECTIVITY	ALL
-------------	-----

28-21-00



757

FAULT ISOLATION/MAINT MANUAL

FROM SHEET 3
(BLOCK 15)

NO

16 REMOVE THE CONTROL CARD OF THE FUEL LEVEL SENSOR, M586, IN THE ELECTRICAL SYSTEMS CARD FILE, P50 (AMM 28-21-04/401). DISCONNECT THE L SURGE TANK FUEL LEVEL SENSOR CONNECTOR, D2510.

INSTALL A JUMPER WIRE BETWEEN PIN A AND PIN B ON THE CONNECTOR, D2510.

USE THE EXTENDER CARD AND THE FUEL QUANTITY TEST SET TO DO A CONTINUITY CHECK ON CONNECTOR D2514, FROM PINS, 5 TO 15 (WDM 28-21-21).

IS THERE CONTINUITY FROM PINS, 5 TO 15?

NOTE: THIS IS NOT A COMPLETE CHECK OF THE OPERATION OF THE FUEL LEVEL SENSOR.

NO

30 REPAIR OR REPLACE THE WIRING FROM THE FUEL LEVEL SENSOR FOR THE LEFT SURGE TANK, TO THE ELECTRICAL SYSTEMS CARD FILE, P50 (WDM 28-21-21).

YES

17 DISCONNECT THE R SURGE TANK FUEL LEVEL SENSOR CONNECTOR, D2456.

INSTALL A JUMPER WIRE BETWEEN PIN A AND PIN B ON THE CONNECTOR, D2456.

USE THE EXTENDED CARD AND THE FUEL QUANTITY TEST SET TO DO A CONTINUITY CHECK ON CONNECTOR, D2456, FROM PINS, 16 TO 17 (WDM 28-21-21).

IS THERE CONTINUITY FROM PINS, 16 TO 17?

NOTE: THIS IS NOT A COMPLETE CHECK OF THE OPERATION OF THE FUEL LEVEL SENSOR.

NO

31 REPAIR OR REPLACE THE WIRING FROM THE FUEL LEVEL SENSOR FOR THE RIGHT SURGE TANK, TO THE ELECTRICAL SYSTEMS CARD FILE P50 (WDM 28-21-21).

YES

32 REPLACE THE CONTROL CARD OF THE FUEL LEVEL SENSOR, M586, IN THE P50 PANEL (AMM 28-21-04/401).

IF THE PROBLEM CONTINUES, REPLACE THE TWO FUEL LEVEL SENSORS (AMM 28-21-03/401).

Fueling Valve Light Fails to Illuminate with Fueling Valve Selected Open
Figure 104 (Sheet 4)

EFFECTIVITY


ALL

28-21-00

01

Page 112
Sep 28/07

264461



Fueling Valve Light Fails to Illuminate with Fueling Valve Selected Open
Figure 104 (Sheet 5)

EFFECTIVITY	ALL
-------------	-----

28-21-00

01


Page 113
Sep 28/07

FUELING VALVE "OPEN" LIGHT ILLUMINATED WITH FUELING SWITCH IN "FUEL". FUEL QUANTITY DID NOT INCREASE OR INCREASED AT A SLOW RATE.

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
6E4, 6E5, 6E6, 11C34, 11L19, 34A9, 34A10, 34A11

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)
FUELING MANIFOLD IS PRESSURIZED (AMM 12-11-01/301)



Fueling Valve OPEN Light Illuminated with Fueling Switch in FUEL.
Fuel Quantity Did Not Increase or Increased at a Slow Rate.
Figure 105

EFFECTIVITY	ALL
-------------	-----


28-21-00

LOAD SELECT FUEL
INDICATOR DISPLAYS
NOT ALL 8'S WHEN TEST
SWITCH IS PRESSED


PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
6E4,6E5,6E6,11L19,11C34,34A9,34A10,34A11

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
28V DC ELECTRICAL POWER IS ON (MM 24-22-00/201)



Load Select Fuel Indicator Displays Not All 8's When Test Switch is Pressed
Figure 105A



28-21-00

06

Page 115
Sep 28/07


B19375

FUELING PANEL LIGHT FAILS TO ILLUMINATE WITH GROUND POWER ON AIRPLANE

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
 6E5,34A11; 1 ▷ 37C4

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
 28V DC ELECTRICAL POWER IS ON (MM 24-22-00/201)




1 ▷ IF INSTALLED


Fueling Panel Light Fails to Illuminate with Ground Power on Airplane
 Figure 106 (Sheet 1)

EFFECTIVITY	ALL
-------------	-----

28-21-00



Fueling Panel Light Fails to Illuminate with Ground Power on Airplane
Figure 106 (Sheet 2)



28-21-00

01

Page 117
Sep 28/07


A38991

LOAD SELECT INDICA-
TOR DISPLAY REMAINED
BLANK WITH "IND
TEST" SWITCH
DEPRESSED

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
11C34,11L19,6E4,6E5,34A10,34A11

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (MM 24-22-00/201)




Load Select Indicator Display Remained Blank with IND TEST Switch Depressed
Figure 107 (Sheet 1)

EFFECTIVITY

ALL

28-21-00



Load Select Indicator Display Remained Blank with IND TEST Switch Depressed
Figure 107 (Sheet 2)

EFFECTIVITY	ALL
-------------	-----


28-21-00

LOAD SELECT
INDICATOR FLASHES
AT ONE SECOND
INTERVALS

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
11M19,34L2,36D2 (IF INSTALLED)

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)



Load Select Indicator Flashes at One Second Intervals
Figure 107A

EFFECTIVITY	ALL
-------------	-----

28-21-00


FUELING DID NOT STOP AT PRESELECTED QUANTITY OR FUEL TRANSFER TO CENTER TANK OCCURRED.

PREREQUISITES

MAKE SURE THIS SYSTEM WILL OPERATE:
DEFUELING (AMM 28-26-00/501)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
6E4,6E5,6E6,11C34,11L19,34A9,34A10,34A11

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)
DEFUELING VALVES ARE IN THE CLOSED POSITION



Fueling Did Not Stop at Preselected Quantity or Fuel Transfer to Center Tank Occurred.
Figure 108 (Sheet 1)

EFFECTIVITY	
	ALL

28-21-00

BOEING
757
FAULT ISOLATION/MAINT MANUAL

FROM SHEET 1
(BLOCK 1)

FROM SHEET 1
(BLOCK 10)

YES

YES

21	INSTALL THE ELECTRICAL CONNECTOR ON THE FUELING SHUT-OFF VALVE (WDM 28-21-23): <ul style="list-style-type: none"> • D2500 LEFT MAIN • D2502 LEFT CENTER • D2446 RIGHT CENTER • D2444 RIGHT MAIN. <p style="text-align: center;">REPLACE THE APPLICABLE FUELING VALVE CONTROL RELAY IN THE P33 PANEL (WDM 28-21-22):</p> <ul style="list-style-type: none"> • K10025 LEFT MAIN • K10013 LEFT CENTER • K10157 RIGHT CENTER • K10024 RIGHT MAIN.
----	---



22	DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE (FIM 28-41-00/101, FIG. 104).
----	---

Fueling Did Not Stop at Preselected Quantity or Fuel Transfer to Center Tank Occurred.
Figure 108 (Sheet 2)

EFFECTIVITY	ALL
-------------	-----

28-21-00

BOEING
757
FAULT ISOLATION/MAINT MANUAL



(A)

Fueling Did Not Stop at Preselected Quantity or Fuel Transfer to Center Tank Occurred.
Figure 108 (Sheet 3)

EFFECTIVITY	
	ALL

H01322

28-21-00

04


Page 123
Sep 28/07

ALL TANKS FAILED TO STOP AT PRESELECTED QUANTITY DURING PRESSURE FUELING. FUEL SPILL AT SURGE TANK.

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
6E5,34A11

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (MM 24-22-00/201)
MAKE SURE THE REFUELING DOOR (621GB) FOR THE REFUEL CONTROL PANEL IS OPEN



1 DO THE FUEL QUANTITY BITE PROCEDURE (28-41-00, FIG. 104)

All Tanks Failed to Stop at Preselected Quantity During Pressure Fueling.
Fuel Spill at Surge Tank.
Figure 109

EFFECTIVITY	ALL
-------------	-----

28-21-00

245631

PREREQUISITES


MAKE SURE THIS SYSTEM WILL OPERATE:
DEFUELING (AMM 28-26-00/501)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
6E4, 6E5, 6E6, 11C34, 11L19, 34A9, 34A10, 34A11

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)
DEFUELING VALVES ARE IN THE CLOSED POSITION
CROSSFEED VALVES ARE IN THE CLOSED POSITION
CENTER TANK REFUEL VALVES ARE IN THE OPEN POSITION
CENTER FUEL TANK MUST BE LESS THAN FULL

WARNING: TO OPERATE ANY OF THE FUEL PUMPS, YOU MUST BE IN THE FLIGHT COMPARTMENT TO CONTINUOUSLY MONITOR THE FUEL QUANTITY AND THE LOW PRESSURE INDICATION IN THE FUEL TANK. IMMEDIATELY SET THE APPLICABLE FUEL PUMP SWITCH TO THE OFF POSITION IF THE LOW PRESSURE LIGHT COMES ON AND STAYS ON. FUEL VAPORS IN THE TANK MAY IGNITE AND CAUSE A FIRE OR EXPLOSION.

FUEL TRANSFER TO CENTER TANK OCCURRED.



Fuel Transfer to Center Tank Occurred.
Figure 110

EFFECTIVITY

ALL

28-21-00

04

Page 125
Sep 28/07


642550

**"PUSH SET" ON LOAD
SELECT INDICATOR
DISPLAYED**

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
6F14,6F20,6H14,6H17,6H20,6H23,11D24,11D25,11D33,
11D34,11D36

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)



PUSH SET on Load Select Indicator Displayed
Figure 111

EFFECTIVITY	ALL
-------------	-----


28-21-00

PREREQUISITES

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)
DEFUELING VALVES ARE IN THE CLOSED POSITION
CROSSFEED VALVES ARE IN THE CLOSED POSITION
FUEL CONTROL SWITCHES ARE IN THE CUTOFF POSITION
FUEL PUMP SWITCHES ARE IN THE OFF POSITION

WARNING: TO OPERATE ANY OF THE FUEL PUMPS, YOU MUST BE IN THE FLIGHT COMPARTMENT TO CONTINUOUSLY MONITOR THE FUEL QUANTITY AND THE LOW PRESSURE INDICATION IN THE FUEL TANK. IMMEDIATELY SET THE APPLICABLE FUEL PUMP SWITCH TO THE OFF POSITION IF THE LOW PRESSURE LIGHT COMES ON AND STAYS ON. FUEL VAPORS IN THE TANK MAY IGNITE AND CAUSE A FIRE OR EXPLOSION.

UNWANTED FUEL TRANSFER FROM CENTER TANK TO MAIN TANK(S)



Unwanted Fuel Transfer From Center Tank to Main Tank(s)
Figure 112

EFFECTIVITY

ALL

28-21-00

03.1

Page 127
Jan 20/09

1733900

BOEING

757

FAULT ISOLATION/MAINT MANUAL

ENGINE FUEL-FEED SYSTEM

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
ACTUATOR - ENGINE FUEL CROSSFEED VALVE, V24	3	1	MAIN LANDING GEAR DOOR	28-22-12
ACTUATOR - ENGINE FUEL SHUTOFF VALVE (SPAR VALVE)	2	2	551BB, 651BB	28-22-11
CIRCUIT BREAKERS -			FLT COMPT, P6	
L AFT FUEL BOOST PUMP, C366		1	6H14	*
L FWD FUEL BOOST PUMP, C372		1	6H23	*
L FUEL OVRD PUMP, C369		1	6F14	*
L SPAR FUEL VALVE, C1061		1	6E1	*
R AFT FUEL BOOST PUMP, C371		1	6H20	*
R FWD FUEL BOOST PUMP, C368		1	6H17	*
R FUEL OVRD PUMP, C370		1	6F20	*
R SPAR FUEL VALVE, C1062		1	6E2	*
CIRCUIT BREAKERS -			FLT COMPT, P11	
FUEL - AUTO S/O OVRD PMP CTR TANK L, C4679		1	11L13	*
FUEL - AUTO S/O OVRD PMP CTR TANK R, C4680		1	11L25	*
FUEL CROSSFEED, C1051		1	11D36	*
L DISAGREE ENBL, C4133		1	11D33	*
R DISAGREE ENBL, C4132		1	11D34	*
LINE - FUEL AND FITTINGS		--	FUEL TANKS	28-22-07
PUMP - AUTOMATIC SUMPING JET	4	4	134AZ, 541AB, 641AB	28-22-06
PUMP - FUEL OVERRIDE	5	2	134AZ	28-22-05
PUMP - SCAVENGE EJECTOR	4	1	531AB	28-22-13
PUMP - FUEL BOOST	5	4	531AB, 631AB	28-22-03
RELAYS - (FIM 31-01-33/101)				
FUEL PANEL DOOR, K179				
FUEL QTY POWER TRANSFER, K356				
L AFT FUEL BOOST PUMP CONTROL, K187				
L CTR OVRD PMP AUTO S/O ENABLE, K10873				
L CTR OVRD PMP AUTO S/O TIME DELAY, K10872				
L OVERRIDE FUEL BOOST PUMP CONTROL, K10011				
L SECONDARY OVRD FUEL BOOST PUMP CONTROL, K10875				
L SPAR VALVE DISAGREE ENBL, K10111				
R FWD FUEL BOOST PUMP CONTROL, K190				
R SPAR VALVE DISAGREE ENBL, K10110				
FUEL CROSSFEED VALVE DISAGREE, K10094				
RELAYS - (FIM 31-01-37/101)				
L FWD FUEL BOOST PUMP CONTROL, K188				
R AFT FUEL BOOST PUMP CONTROL, K189				
R CTR OVRD PMP AUTO S/O ENABLE, K10870				
R CTR OVRD PMP AUTO S/O TIME DELAY, K10871				
R OVERRIDE FUEL BOOST PUMP CONTROL, K10012				
R SECONDARY OVERRIDE FUEL BOOST PUMP CONTROL, K10874				

* SEE THE WDM EQUIPMENT LIST

AIRPLANES WITH OVERRIDE PUMP AUTO SHUTOFF
(POST-SB 28A0081 OR POST-SB 28A0082)



AIRPLANES WITH SECONDARY OVERRIDE FUEL BOOST
PUMP CONTROL RELAYS (POST-SB 28A0105)

Engine Fuel-Feed System - Component Index Figure 101 (Sheet 1)

EFFECTIVITY
GUI 001-008 PRE-SB 28-29

28-22-00


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
SWITCH - L AUTO S/O FUEL TEST, S10712 		1	119BL, MAIN EQUIP CTR, E2	*
SWITCH - R AUTO S/O FUEL TEST, S10711 		1	119BL, MAIN EQUIP CTR, E2	*
VALVE - ENGINE FUEL CROSSFEED, V24	3	1	134AZ	28-22-02
VALVE - ENGINE FUEL SHUTOFF (SPAR VALVE)	2	2	541AB, 641AB	28-22-01
VALVE - FLOAT-OPERATED SHUTOFF	4	1	541AB	28-22-10
VALVE - DISCHARGE CHECK	3	6	531AB, 631AB, 134AZ	28-22-09
VALVE - REMOVAL CHECK	3	6	531AB, 631AB, 134AZ	28-22-08
VALVE - FUEL BOOST PUMP BYPASS	4	2	541AB, 641AB	28-22-04






* SEE THE WDM EQUIPMENT LIST

Engine Fuel-Feed System - Component Index
 Figure 101 (Sheet 2)



EFFECTIVITY
 GUI 001-008 PRE-SB 28-29

28-22-00

 **BOEING**
757
FAULT ISOLATION/MAINT MANUAL

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
ACTUATOR - AFT ENGINE FUEL CROSSFEED VALVE, V10139	3	1	LEFT, MAIN LANDING GEAR DOOR	28-22-12
ACTUATOR - ENGINE FUEL SHUTOFF VALVE (SPAR VALVE)	2	2	551BB, 651BB	28-22-11
ACTUATOR - FWD ENGINE FUEL CROSSFEED VALVE, V10138	3	1	RIGHT, MAIN LANDING GEAR DOOR	28-22-12
CIRCUIT BREAKER -			FLT COMPT, P6	
L AFT FUEL BOOST PUMP, C366		1	6H14	*
L FWD FUEL BOOST PUMP, C372		1	6H23	*
L FUEL OVRD PUMP, C369		1	6F14	*
L SPAR FUEL VALVE, C1061		1	6E1	*
R AFT FUEL BOOST PUMP, C371		1	6H20	*
R FWD FUEL BOOST PUMP, C368		1	6H17	*
R FUEL OVRD PUMP, C370		1	6F20	*
R SPAR FUEL VALVE, C1062		1	6E2	*
CIRCUIT BREAKER -			FLT COMPT, P11	
AFT FUEL CROSSFEED, C4477		1	11D25	*
FUEL - AUTO S/O OVRD PMP CTR TANK L, C4679 		1	11L13	*
FUEL - AUTO S/O OVRD PMP CTR TANK R, C4680 		1	11L25	*
FUEL XFEED IND, C4485		1	11D36	
FWD FUEL CROSSFEED, C4476		1	11D24	*
L DISAGREE ENBL, C4133		1	11D33	*
R DISAGREE ENBL, C4132		1	11D34	*
LINE - FUEL AND FITTINGS		--	FUEL TANKS	28-22-07
PUMP - AUTOMATIC SUMPING JET	4	4	134AZ, 541AB, 641AB	28-22-06
PUMP - FUEL BOOST	5	4	531AB, 631AB	28-22-03
PUMP - FUEL OVERRIDE	5	2	134AZ	28-22-05
PUMP - SCAVENGE EJECTOR	4	1	531AB	28-22-13
RELAY - (FIM 31-01-33/101)				
AFT FUEL CROSSFEED VALVE DISAGREE, K10714				
FUEL PANEL DOOR, K179				
FUEL QTY POWER TRANSFER, K356				
FWD FUEL CROSSFEED VALVE DISAGREE, K10715				
L AFT FUEL BOOST PUMP CONTROL, K187				
L CTR OVRD PMP AUTO S/O ENABLE, K10873 				
L CTR OVRD PMP AUTO S/O TIME DELAY, K10872 				
L OVERRIDE FUEL BOOST PUMP CONTROL, K10011				
L SECONDARY OVRD FUEL BOOST PUMP CONTROL, K10875 				
L SPAR VALVE DISAGREE ENBL, K10111				
R FWD FUEL BOOST PUMP CONTROL, K190				
R SPAR VALVE DISAGREE ENBL, K10110				

* SEE THE WDM EQUIPMENT LIST






-  AIRPLANES WITH OVERRIDE PUMP AUTO SHUTOFF (POST-SB 28A0081 OR POST-SB 28A0082)
-  AIRPLANES WITH SECONDARY OVERRIDE FUEL BOOST PUMP CONTROL RELAYS (POST-SB 28A0105)

Engine Fuel-Feed System - Component Index
Figure 101 (Sheet 3)

EFFECTIVITY
GUI 001-008 POST-SB 28-29;
GUI 009-999

28-22-00


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
RELAY - (FIM 31-01-37/101) L FWD FUEL BOOST PUMP CONTROL, K188 R AFT FUEL BOOST PUMP CONTROL, K189 R CTR OVRD PMP AUTO S/O ENABLE, K10870  R CTR OVRD PMP AUTO S/O TIME DELAY, K10871  R OVERRIDE FUEL BOOST PUMP CONTROL, K10012 R SECONDARY OVRD FUEL BOOST PUMP CONTROL, K10874  SWITCH - L AUTO S/O FUEL TEST, S10712  SWITCH - R AUTO S/O FUEL TEST, S10711  VALVE - AFT ENGINE FUEL CROSSFEED, V10139 VALVE - DISCHARGE CHECK VALVE - ENGINE FUEL SHUTOFF (SPAR VALVE) VALVE - FLOAT-OPERATED SHUTOFF VALVE - FUEL BOOST PUMP BYPASS VALVE - FWD ENGINE FUEL CROSSFEED, V10138 VALVE - REMOVAL CHECK				
		1	119BL, MAIN EQUIP CTR, E2	*
		1	119BL, MAIN EQUIP CTR, E2	*
	3	1	134AZ	28-22-02
	3	6	531AB, 631AB, 134AZ	28-22-09
	2	2	541AB, 641AB	28-22-01
	4	1	541AB	28-22-10
	4	2	541AB, 641AB	28-22-04
	3	1	134AZ	28-22-02
	3	6	531AB, 631AB, 134AZ	28-22-08



* SEE THE WDM EQUIPMENT LIST

Engine Fuel-Feed System - Component Index
Figure 101 (Sheet 4)

EFFECTIVITY
 GUI 001-008 POST-SB 28-29;
 GUI 009-999

28-22-00

BOEING
757
FAULT ISOLATION/MAINT MANUAL



FLIGHT COMPARTMENT

Engine Fuel-Feed System - Component Location
Figure 102 (Sheet 1)

EFFECTIVITY	
	ALL

28-22-00

01


Page 105
May 28/06

55684

BOEING

757



FAULT ISOLATION/MAINT MANUAL



Engine Fuel-Feed System - Component Location
Figure 102 (Sheet 2)

EFFECTIVITY	
	ALL

28-22-00




ENGINE FUEL CROSSFEED VALVE AND ACTUATOR

(B) 1 4


ENGINE FUEL CROSSFEED VALVE AND ACTUATOR

(B) 1 3



FORWARD AND AFT ENGINE FUEL CROSSFEED VALVES AND ACTUATORS

(B) 2 3



FORWARD AND AFT ENGINE FUEL CROSSFEED VALVES AND ACTUATORS

(B) 2 4

NOT USED


(C)

Engine Fuel-Feed System - Component Location (Detail from Sht 2)
Figure 102 (Sheet 3)

EFFECTIVITY


ALL

28-22-00




BYPASS VALVE

D




AUTOMATIC SUMPING JET PUMP

E



FLOAT-OPERATED SHUTOFF VALVE

F



SCAVENGE EJECTOR PUMP

G


Engine Fuel-Feed System - Component Location (Details from Sht 2)
Figure 102 (Sheet 4)

EFFECTIVITY	ALL

28-22-00

NOT USED

(H)



FUEL OVERRIDE PUMP SHOWN
(FUEL BOOST PUMP IS ALMOST THE SAME)

(I)

Engine Fuel-Feed System - Component Location (Detail from Sht 2)
Figure 102 (Sheet 5)

EFFECTIVITY

ALL


28-22-00

07

Page 109
Sep 28/06

B25741

Not Used
Figure 103



28-22-00

06

Page 110
Sep 28/06


178259

EICAS MSG "FUEL SPAR VAL" AND "SPAR VALVE" LT ILLUM

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
6E1, 6E2, 11D33, 11D34

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)




EICAS Msg FUEL SPAR VAL and SPAR VALVE Lt Illum
Figure 104 (Sheet 1)

EFFECTIVITY	ALL
-------------	-----

28-22-00

FROM SHEET 1
(BLOCK 1)



EICAS Msg FUEL SPAR VAL and SPAR VALVE Lt Illum
Figure 104 (Sheet 2)

EFFECTIVITY

ALL

28-22-00

08

Page 112
Sep 28/06

E47962

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:

1 ▷ 11L13, 11L25

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:


ELECTRICAL POWER IS ON (AMM 24-22-00/201)

ENGINES DO NOT OPERATE

WARNING: DO NOT RESET A FUEL PUMP CIRCUIT BREAKER THAT HAS OPENED (TRIPPED) UNTIL YOU CORRECT THE PROBLEM. THIS CONDITION CAN CAUSE A FIRE OR EXPLOSION.

WARNING: TO OPERATE ANY OF THE FUEL PUMPS, YOU MUST BE IN THE FLIGHT COMPARTMENT TO CONTINUOUSLY MONITOR THE FUEL QUANTITY AND THE LOW PRESSURE INDICATION IN THE FUEL TANK. IMMEDIATELY SET THE APPLICABLE FUEL PUMP SWITCH TO THE OFF POSITION IF THE LOW PRESSURE LIGHT COMES ON AND STAYS ON. FUEL VAPORS IN THE TANK MAY IGNITE AND CAUSE A FIRE OR EXPLOSION.

"CTR FUEL PUMP"
EICAS MSG ILLUM
AND "C PUMP PRESS"
LT ON



1 ▷ AIRPLANES WITH OVERRIDE PUMP AUTO SHUTOFF (POST-SB 28A0081 OR POST-SB 28A0082)

2 ▷ CDCCL - REFER TO THE TASK: AIRWORTHINESS LIMITATION PRECAUTIONS (AMM 28-00-00/201), FOR IMPORTANT INFORMATION ON CRITICAL DESIGN CONFIGURATION CONTROL LIMITATIONS (CDCCLs).

3 ▷ AIRPLANES POST-SB 28A0078 OR POST-SB 28A0079

CTR FUEL PUMP EICAS Msg Illum and C PUMP PRESS Lt On
Figure 105 (Sheet 1)

EFFECTIVITY

ALL


28-22-00

06

Page 113
Sep 28/07

216712

BOEING
757
FAULT ISOLATION/MAINT MANUAL



CTR FUEL PUMP EICAS Msg Illum and C PUMP PRESS Lt On
Figure 105 (Sheet 2)

EFFECTIVITY


ALL

28-22-00

05

Page 114
Sep 28/07

F99834



\triangleright AIRPLANES WITH SECONDARY OVERRIDE FUEL BOOST PUMP CONTROL RELAY (POST-SB 28A105)

CTR FUEL PUMP EICAS Msg Illum and C PUMP PRESS Lt On
Figure 105 (Sheet 3)

EFFECTIVITY	ALL
-------------	-----

28-22-00

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:

1 ▷ 11L13, 11L25

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)
ENGINES DO NOT OPERATE

MAKE SURE THE CENTER TANK HAS A MINIMUM OF 40,000
POUNDS (18,000 KILOGRAMS) OF FUEL
(AMM 12-11-01/301, AMM 28-26-00/201).

WARNING: DO NOT RESET A FUEL PUMP CIRCUIT BREAKER THAT HAS OPENED (TRIPPED) UNTIL YOU CORRECT THE PROBLEM. THIS CONDITION CAN CAUSE A FIRE OR EXPLOSION.

TO OPERATE ANY OF THE FUEL PUMPS, YOU MUST BE IN THE FLIGHT COMPARTMENT TO CONTINUOUSLY MONITOR THE FUEL QUANTITY AND LOW PRESSURE INDICATION IN THE FUEL TANK. IMMEDIATELY SET THE APPLICABLE FUEL PUMP SWITCH TO THE OFF POSITION IF THE PRESSURE LIGHT COMES ON AND STAYS ON. FUEL VAPORS IN THE TANK MAY IGNITE AND CAUSE A FIRE OR EXPLOSION.

NOTE: IF YOU MAKE A DECISION TO DISPATCH THE AIRPLANE WITH AN OPEN CIRCUIT BREAKER, DO THE STEPS IN THE MEL TO DEACTIVATE THE (L, R CENTER OVERRIDE PUMP). OPERATE THE AIRPLANE PER THE MEL PROCEDURES.

"CTR FUEL PUMP" EICAS
MSG ILLUM AND "C PUMP
PRESS" LT ON, PUMP
CIRCUIT BREAKER OPEN ▷ 2




- 1 ▷ AIRPLANES WITH OVERRIDE PUMP AUTO SHUTOFF (POST-SB 28A0081 OR POST-SB 28A0082)
- 2 ▷ CDCCL - REFER TO THE TASK: AIRWORTHINESS LIMITATION PRECAUTIONS (AMM 28-00-00/201), FOR IMPORTANT INFORMATION ON CRITICAL DESIGN CONFIGURATION CONTROL LIMITATIONS (CDCCLs)

CTR FUEL PUMP EICAS Msg Illum and C PUMP PRESS Lt On, Pump Circuit Breaker Open
Figure 105A (Sheet 1)

EFFECTIVITY	ALL
-------------	-----

28-22-00



CTR FUEL PUMP EICAS Msg Illum and C PUMP PRESS Lt On, Pump Circuit Breaker Open
Figure 105A (Sheet 2)

EFFECTIVITY

ALL

28-22-00

04.1

Page 117
Jan 20/09

FROM SHEET 2
(BLOCK 4)

YES

5 (OVERRIDE PUMP OPERATIONAL CHECK)
 MAKE SURE THE CENTER TANK HAS A MINIMUM 40,000 POUNDS (18,000 KILOGRAMS) OF FUEL.
 CONNECT THE LEFT (RIGHT) ELECTRICAL CONNECTOR D1766 (D1838).
 CLOSE THE LEFT (RIGHT) CIRCUIT BREAKER 6F14 (6F20).
 PUSH THE LEFT (RIGHT) "OVERRIDE PUMPS" SWITCH-LIGHT ON THE OVERHEAD PANEL, P5 TO THE ON POSITION.
 OPERATE THE LEFT (RIGHT) OVERRIDE PUMP FOR 5 MINUTES.
 DOES THE LEFT (RIGHT) OVERRIDE PUMP CIRCUIT BREAKER 6F14 (6F20) STAY CLOSED?

YES

47 THE CONDITION THAT CAUSED THE CIRCUIT BREAKER TO OPEN IS NOT PRESENT.
 CLOSE THE FUELING STATION DOOR, 621GB.

NO

48 REPLACE THE LEFT (RIGHT) OVERRIDE PUMP, M10016 (M10017) (AMM 28-22-03/401).
 DO A OVERRIDE PUMP OPERATIONAL CHECK. GO TO BLOCK 5.

CTR FUEL PUMP EICAS Msg Illum and C PUMP PRESS Lt On, Pump Circuit Breaker Open
Figure 105A (Sheet 3)

EFFECTIVITY

ALL

28-22-00

04

Page 118
May 28/07

1340612


PREREQUISITES

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)

WARNING: DO NOT RESET A FUEL PUMP CIRCUIT BREAKER THAT HAS OPENED (TRIPPED) UNTIL YOU CORRECT THE PROBLEM. THIS CONDITION CAN CAUSE A FIRE OR EXPLOSION.

WARNING: TO OPERATE ANY OF THE FUEL PUMPS, YOU MUST BE IN THE FLIGHT COMPARTMENT TO CONTINUOUSLY MONITOR THE FUEL QUANTITY AND THE LOW PRESSURE INDICATION IN THE FUEL TANK. IMMEDIATELY SET THE APPLICABLE FUEL PUMP SWITCH TO THE OFF POSITION IF THE LOW PRESSURE LIGHT COMES ON AND STAYS ON. FUEL VAPORS IN THE TANK MAY IGNITE AND CAUSE A FIRE OR EXPLOSION.

MAIN TANK FUEL BOOST PUMP PRESS LT AND "FUEL PUMP" EICAS MSG DISPLAYED



1 CDCCL - REFER TO THE TASK: AIRWORTHINESS LIMITATION PRECAUTIONS (AMM 28-00-00/201), FOR IMPORTANT INFORMATION ON CRITICAL DESIGN CONFIGURATION CONTROL LIMITATIONS (CDCCLs).

2 AIRPLANES POST-SB 28A0078 OR POST-SB 28A0079


Main Tank Fuel Boost Pump PRESS Lt and FUEL PUMP EICAS Msg Displayed
Figure 106 (Sheet 1)

EFFECTIVITY	ALL
-------------	-----


28-22-00

BOEING
757
FAULT ISOLATION/MAINT MANUAL

FROM SHEET 1
(BLOCK 20)



FROM SHEET 1
(BLOCK 3)



Main Tank Fuel Boost Pump PRESS Lt and FUEL PUMP EICAS Msg Displayed
Figure 106 (Sheet 2)

EFFECTIVITY

ALL

28-22-00

PREREQUISITES


MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)


MAKE SURE THE CENTER TANK HAS A MINIMUM OF 40,000
POUNDS (18,000 KILOGRAMS) OF FUEL AND THE NO. 1
(NO. 2) TANK HAS A MINIMUM OF 1000 POUNDS
(450 KILOGRAMS) OF FUEL
(AMM 12-11-01/301, AMM 28-26-00/201).


WARNING: DO NOT RESET FUEL PUMP CIRCUIT BREAKER
THAT HAS OPENED (TRIPPED) UNTIL YOU
CORRECT THE PROBLEM. THIS CONDITION CAN
CAUSE A FIRE OR EXPLOSION.

TO OPERATE ANY OF THE FUEL PUMPS, YOU
MUST BE IN THE FLIGHT COMPARTMENT TO
CONTINUOUSLY MONITOR THE FUEL QUANTITY
AND THE LOW PRESSURE INDICATION IN THE
FUEL TANK. IMMEDIATELY SET THE
APPLICABLE FUEL PUMP SWITCH TO THE OFF
POSITION IF THE LOW PRESSURE LIGHT COMES
ON AND STAYS ON. FUEL VAPORS IN THE TANK
MAY IGNITE AND CAUSE A FIRE OR EXPLOSION.

NOTE: IF YOU MAKE A DECISION TO DISPATCH THE AIRPLANE
WITH AN OPEN CIRCUIT BREAKER, DO THE STEPS IN
THE MEL TO DEACTIVATE THE (AFT, FWD MAIN TANK
BOOST PUMP). OPERATE THE AIRPLANE PER THE MEL
PROCEDURES.

MAIN TANK FUEL BOOST
PUMP PRESS LT AND
"FUEL PUMP" EICAS
MSG DISPLAYED, PUMP
CIRCUIT BREAKER
OPENED 



 CDCCL - REFER TO THE TASK: AIRWORTHINESS LIMITATION PRECAUTIONS (AMM 28-00-00/201), FOR IMPORTANT INFORMATION ON CRITICAL DESIGN CONFIGURATION CONTROL LIMITATIONS (CDCCLs).

Main Tank Fuel Boost Pump PRESS Lt and FUEL PUMP EICAS Msg
Displayed, Pump Circuit Breaker Open
Figure 106A (Sheet 1)

EFFECTIVITY


ALL

28-22-00

04

Page 121
May 28/07

L02487



Main Tank Fuel Boost Pump PRESS Lt and FUEL PUMP EICAS Msg
Displayed, Pump Circuit Breaker Open
Figure 106A (Sheet 2)


EFFECTIVITY

ALL

28-22-00

05

Page 122
May 28/07



Main Tank Fuel Boost Pump PRESS Lt and FUEL PUMP EICAS Msg
 Displayed, Pump Circuit Breaker Open
 Figure 106A (Sheet 3)

EFFECTIVITY	ALL
-------------	-----

28-22-00

FUEL CROSSFEED
VALVE LT FAILS TO
ILLUMINATE

PREREQUISITES NONE



1	REPLACE THE FUEL CROSSFEED VALVE DISAGREE RELAY, K10094 (WDM 28-22-31).
---	---

Fuel Crossfeed Valve Lt Fails to Illuminate
Figure 107

EFFECTIVITY
GUI 001-008 PRE-SB 28-29

28-22-00

FORWARD (AFT)
FUEL CROSSFEED
VALVE LT FAILS TO
ILLUMINATE

PREREQUISITES NONE



1	REPLACE THE FORWARD (AFT) FUEL CROSSFEED VALVE DISAGREE RELAY, K10715 (K10714)(WDM 28-22-31).
---	---

Forward (Aft) Fuel Crossfeed Valve Lt Fails to Illuminate
Figure 107A

EFFECTIVITY
GUI 001-008 POST-SB 28-29;
GUI 009-999


28-22-00

**FUEL CROSSFEED
VALVE LT FAILS TO
EXTINGUISH**

PREREQUISITES

MAKE SURE THIS CIRCUIT BREAKER IS CLOSED:
11D36

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT
FOLLOWS:
ELECTRICAL POWER IS ON (MM 24-22-00/201)



Fuel Crossfeed Valve Lt Fails to Extinguish
Figure 108

EFFECTIVITY
GUI 001-008 PRE-SB 28-29

28-22-00

71150


**FWD (AFT) FUEL
CROSSFEED VALVE LT
FAILS TO EXTINGUISH**

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:

- 11D24, FWD CROSSFEED VALVE
- 11D25, AFT CROSSFEED VALVE
- 11D36, FUEL XFEED IND

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)




Fwd (Aft) Fuel Crossfeed Valve Lt Fails to Extinguish
Figure 108A (Sheet 1)

EFFECTIVITY
GUI 001-008 POST-SB 28-29;
GUI 009-999

28-22-00

FROM SHEET 1
(BLOCK 2)



Fwd (Aft) Fuel Crossfeed Valve Lt Fails to Extinguish
Figure 108A (Sheet 2)

EFFECTIVITY
GUI 001-008 POST-SB 28-29;
GUI 009-999

28-22-00


PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED ¹ :
6F14, 6F20, 6H14, 6H17, 6H20, 6H23, 11D33, 11D34,
11D36; ² > 11L13, 11L25

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)

WARNING: TO OPERATE ANY OF THE FUEL PUMPS, YOU MUST BE IN THE FLIGHT COMPARTMENT TO CONTINUOUSLY MONITOR THE FUEL QUANTITY AND THE LOW PRESSURE INDICATION IN THE FUEL TANK. IMMEDIATELY SET THE APPLICABLE FUEL PUMP SWITCH TO THE OFF POSITION IF THE LOW PRESSURE LIGHT COMES ON AND STAYS ON. FUEL VAPORS IN THE TANK MAY IGNITE AND CAUSE A FIRE OR EXPLOSION.

"L (R) FUEL SYS PRESS" EICAS MSG DISPLAYED



¹ DO NOT CLOSE A FUEL PUMP CIRCUIT BREAKER IF IT IS OPEN (TRIPPED). DO THE FIGURE 105A OR FIGURE 106A PROCEDURE FIRST.


² AIRPLANES WITH OVERRIDE PUMP AUTO SHUTOFF (POST-SB 28A0081 OR POST-SB 28A0082)

L (R) FUEL SYS PRESS EICAS Msg Displayed
Figure 109 (Sheet 1)

EFFECTIVITY
GUI 001-008 PRE-SB 28-29

28-22-00

BOEING
757
FAULT ISOLATION/MAINT MANUAL



L (R) FUEL SYS PRESS EICAS Msg Displayed
Figure 109 (Sheet 2)

EFFECTIVITY
GUI 001-008 PRE-SB 28-29

28-22-00


PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED ¹ :
6F14, 6F20, 6H14, 6H17, 6H20, 6H23, 11D24, 11D25,
11D33, 11D34, 11D36; ² 11L13, 11L25

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)

WARNING: TO OPERATE ANY OF THE FUEL PUMPS, YOU MUST BE IN THE FLIGHT COMPARTMENT TO CONTINUOUSLY MONITOR THE FUEL QUANTITY AND THE LOW PRESSURE INDICATION IN THE FUEL TANK. IMMEDIATELY SET THE APPLICABLE FUEL PUMP SWITCH TO THE OFF POSITION IF THE LOW PRESSURE LIGHT COMES ON AND STAYS ON. FUEL VAPORS IN THE TANK MAY IGNITE AND CAUSE A FIRE OR EXPLOSION.

"L (R) FUEL SYS PRESS" EICAS MSG DISPLAYED



¹ DO NOT CLOSE A FUEL PUMP CIRCUIT BREAKER IF IT IS OPEN (TRIPPED). DO THE FIGURE 105A OR FIGURE 106A PROCEDURE FIRST.


² AIRPLANES WITH OVERRIDE PUMP AUTO SHUTOFF (POST-SB 28A0081 OR POST-SB 28A0082)

L (R) FUEL SYS PRESS EICAS Msg Displayed
Figure 109A (Sheet 1)

EFFECTIVITY
GUI 001-008 POST-SB 28-29;
GUI 009-999

28-22-00

BOEING
757
FAULT ISOLATION/MAINT MANUAL




L (R) FUEL SYS PRESS EICAS Msg Displayed
Figure 109A (Sheet 2)

EFFECTIVITY
GUI 001-008 POST-SB 28-29;
GUI 009-999

28-22-00


PREREQUISITES


MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED  :
6H14, 6H17, 6H20

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)
THE MAIN TANKS CONTAIN MORE THAN 2000 POUNDS
(1000 KILOGRAMS) OF FUEL (AMM 12-11-01/301)

WARNING: TO OPERATE ANY OF THE FUEL PUMPS, YOU MUST BE IN THE FLIGHT COMPARTMENT TO CONTINUOUSLY MONITOR THE FUEL QUANTITY AND THE LOW PRESSURE INDICATION IN THE FUEL TANK. IMMEDIATELY SET THE APPLICABLE FUEL PUMP SWITCH TO THE OFF POSITION IF THE LOW PRESSURE LIGHT COMES ON AND STAYS ON. FUEL VAPORS IN THE TANK MAY IGNITE AND CAUSE A FIRE OR EXPLOSION.

**BOOST PUMP LOW
"PRESS" LIGHT FAILED
TO ILLUMINATE WITH
PUMP SWITCH/LIGHT IN
"OFF" POSITION**



 DO NOT CLOSE A FUEL PUMP CIRCUIT BREAKER IF IT IS OPEN (TRIPPED). DO THE FIGURE 105A OR FIGURE 106A PROCEDURE FIRST.

**Boost Pump Low PRESS Light Failed to Illuminate with
PUMP Switch/Light in OFF Position
Figure 110 (Sheet 1)**

EFFECTIVITY	ALL
-------------	-----

28-22-00

BOEING
757
FAULT ISOLATION/MAINT MANUAL

FROM SHEET 1
(BLOCK 1)

YES

2 REMOVE THE APPLICABLE FUEL BOOST PUMP CONTROL RELAY (WDM 28-22-11):

- L AFT
 - K187 IN THE P33 PANEL
- R FWD
 - K190 IN THE P33 PANEL
- R AFT
 - K189 IN THE P37 PANEL

DO A CHECK FOR 115V AC AT PIN X1 (PIN X2 IS A GROUND) (WDM 28-22-11). **2** DO THE PUMP REVERSAL-OPERATIONAL TEST (AMM 28-22-00/501). IS THERE 115V AC AT PIN X1?

NO

22 REPLACE THE APPLICABLE FUEL BOOST PUMP CONTROL RELAY:

- L AFT
 - K187 IN THE P33 PANEL
- R FWD
 - K190 IN THE P33 PANEL
- R AFT
 - K189 IN THE P37 PANEL

(WDM 28-22-11). **2** DO THE PUMP REVERSAL-OPERATIONAL TEST (AMM 28-22-00/501).

YES

23 REPLACE THE APPLICABLE FUEL BOOST PUMP SWITCH-LIGHT (AMM 33-13-00/201) ON THE FUEL MANAGEMENT CONTROL PANEL, M10055, ON THE P5 PANEL:

- L AFT
 - YQVS1
- R FWD
 - YQVS5
- R AFT
 - YQVS4

OR M10055 (WDM 28-22-11).

2 AIRPLANES POST-SB 28A0078 OR POST-SB 28A0079

Boost Pump Low PRESS Light Failed to Illuminate with
PUMP Switch/Light in OFF Position
Figure 110 (Sheet 2)

EFFECTIVITY

ALL

28-22-00

04

Page 134
Sep 20/08


420906

**L FWD BOOST PUMP
"PRESS" LIGHT FAILED
TO ILLUMINATE WITH
PUMP SWITCH IN "OFF"
POSITION**

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED ¹ :
6H23, 11B34, 11D35

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)
THE MAIN TANKS CONTAIN MORE THAN 2000 POUNDS
(1000 KILOGRAMS) OF FUEL (AMM 12-11-01/301)



¹ DO NOT CLOSE A FUEL PUMP CIRCUIT BREAKER IF IT IS OPEN (TRIPPED). DO THE FIGURE 105A OR FIGURE 106A PROCEDURE FIRST.

**L FWD Boost Pump PRESS Light Failed to Illuminate with
Pump Switch/Light in OFF Position
Figure 111 (Sheet 1)**

EFFECTIVITY

ALL


28-22-00

04

Page 135
Jan 28/07

98051

FROM SHEET 1
(BLOCK 3)



L FWD Boost Pump PRESS Light Failed to Illuminate with
Pump Switch in OFF Position
Figure 111 (Sheet 2)

EFFECTIVITY

ALL

28-22-00

04

Page 136
Jan 28/07

816515



757

FAULT ISOLATION/MAINT MANUAL

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE OPEN:

11D7, 11D8, 11L1, 11D9, 11D10, 11L28

MAKE SURE THESE VALVES ARE CLOSED:

V109, V108

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:

ELECTRICAL POWER IS ON (AMM 24-22-00/201)

THE LEFT (RIGHT) MAIN TANK CONTAINS AT LEAST

4200 LBS (1900 KG) (AMM 12-11-01/301 OR

AMM 28-26-00/201)

THE CENTER TANK CONTAINS 0 LBS (0 KG) OF FUEL

(AMM 28-26-00/201)

APU SWITCH IS IN THE "OFF" POSITION.

WARNING: TO OPERATE ANY OF THE FUEL PUMPS, YOU MUST BE IN THE FLIGHT COMPARTMENT TO CONTINUOUSLY MONITOR THE FUEL QUANTITY AND THE LOW PRESSURE INDICATION IN THE FUEL TANK. IMMEDIATELY SET THE APPLICABLE FUEL PUMP SWITCH TO THE OFF POSITION IF THE LOW PRESSURE LIGHT COMES ON AND STAYS ON. FUEL VAPORS IN THE TANK MAY IGNITE AND CAUSE A FIRE OR EXPLOSION.

Right (Left) Engine Fails the Suction Feed Test
Figure 112 (Sheet 1)

EFFECTIVITY	ALL
-------------	-----

28-22-00

05

Page 137
Jan 28/07

D74346

**RIGHT (LEFT)
ENGINE FAILS THE
SUCTION FEED TEST**

↓

1 OPEN OR REMOVE RIGHT (LEFT) STRUT ACCESS DOORS (AMM 54-53-01/401) AND ENGINE COWLING THAT ARE REQUIRED TO VISUALLY CHECK THE FUEL FEED LINE FROM THE FRONT SPAR TO THE R (L) FUEL PUMP.

MAKE SURE THE FUEL CONTROL SWITCHES ON THE P10 STAND ARE IN THE "CUTOFF" POSITION.

MAKE SURE THE ENG START SWITCHES ON THE P5 PANEL ARE IN THE "OFF" POSITION.

OPEN THESE CIRCUIT BREAKERS (6C1, 6C2) AND ATTACH DO NOT CLOSE TAGS.

PUT THE R (L) FUEL CONTROL SWITCH IN THE "RUN" POSITION.

MAKE SURE THE R (L) SPAR VALVE LIGHT IS OFF.

PUSH THE FUEL CROSSFEED SWITCH-LIGHT(S) ON THE P5 PANEL TO THE "OPEN" POSITION.

MAKE SURE THE CORRESPONDING LIGHT(S) IS OFF.

RECORD THE QUANTITY OF FUEL IN THE LEFT, CENTER, AND RIGHT FUEL TANKS.

PUSH THE L (R) AFT FUEL PUMP SWITCH-LIGHT(S) TO "ON".

CHECK FOR LEAKS IN THE FUEL LINE:
MONITOR THE FUEL QUANTITY IN ALL OF THE TANKS AND MONITOR THE FUEL FEED LINE FROM THE FRONT SPAR TO THE ENGINE DRIVEN FUEL PUMP ON THE R (L) ENGINE FOR FUEL LEAKS.

DOES THE FUEL QUANTITY INCREASE OR IS THERE A LEAK IN THE FUEL FEED LINE FROM THE FRONT SPAR TO THE ENGINE DRIVEN FUEL PUMP ON THE R (L) ENGINE?

NOTE: IF THE CENTER TANK FUEL QUANTITY INCREASES A LEAK EXISTS IN THE FUEL FEED LINE IN THE CENTER TANK BETWEEN THE CROSSFEED VALVE(S) AND THE R (L) MAIN TANK.

IF THE R (L) MAIN TANK FUEL QUANTITY INCREASES A LEAK EXISTS IN THE FUEL FEED LINE IN THE R (L) MAIN TANK.

YES →

21 PUSH THE L (R) AFT FUEL PUMP SWITCH-LIGHT(S) FOR THE MAIN TANK TO THE OFF POSITION.

SET THE R (L) FUEL CONTROL SWITCH ON THE P10 STAND TO THE "CUTOFF" POSITION.

MAKE SURE THE R (L) SPAR VALVE LIGHT IS OFF.

MAKE SURE THE R (L) ENGINE VALVE LIGHT IS OFF.

PUSH THE FUEL CROSSFEED SWITCH-LIGHT(S) ON THE P5 PANEL TO THE CLOSED POSITION.


REPAIR ANY LEAK(S) THAT WERE FOUND (AMM 28-22-07/401).

NOTE: TO PINPOINT THE LEAK YOU MAY NEED TO PRESSURIZE THE FUEL FEED LINE WITH AIR (AMM 28-22-07/601).


DO THE ENGINE FUEL SUCTION FEED OPERATIONAL TEST AGAIN TO MAKE SURE THE TEST RESULTS ARE SATISFACTORY (AMM 28-22-00/501).

NO
↓
SEE SHEET 3
(BLOCK 2)

Right (Left) Engine Fails the Suction Feed Test
Figure 112 (Sheet 2)



28-22-00



Right (Left) Engine Fails the Suction Feed Test
Figure 112 (Sheet 3)

EFFECTIVITY	ALL
-------------	-----

28-22-00

PREREQUISITES

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)
ENGINES DO NOT OPERATE


MAKE SURE THE CENTER TANK HAS A MINIMUM OF 40,000 POUNDS (18,000 KILOGRAMS) OF FUEL AND THE NO. 1 (NO. 2) TANK HAS A MINIMUM OF 1,000 POUNDS (450 KILOGRAMS) OF FUEL (AMM 12-11-01/301, AMM 28-26-00/201).


WARNING: DO NOT RESET THE FUEL PUMP GFI RELAY THAT HAS OPENED (TRIPPED) UNTIL YOU CORRECT THE PROBLEM. THIS CONDITION CAN CAUSE A FIRE OR EXPLOSION.

WARNING: TO OPERATE ANY OF THE FUEL PUMPS, YOU MUST BE IN THE FLIGHT COMPARTMENT TO CONTINUOUSLY MONITOR THE FUEL QUANTITY AND THE LOW PRESSURE INDICATION IN THE FUEL TANK. IMMEDIATELY SET THE APPLICABLE FUEL PUMP SWITCH TO THE OFF POSITION IF THE LOW PRESSURE LIGHT COMES ON AND STAYS ON. FUEL VAPORS IN THE TANK MAY IGNITE AND CAUSE A FIRE OR EXPLOSION.

**FUEL BOOST PUMP
GFI RELAY
OPEN** 




 THE RESET BUTTON LOCATED AT THE TOP EDGE OF THE GFI RELAY MOVES UP, TO EXPOSE A NARROW WHITE BAND WHEN THE GFI CIRCUIT TURNS OFF THE RELAY DUE TO A GROUND FAULT, OR RESULTS WHEN YOU PUSH THE TEST BUTTON LOCATED ON THE TOP SURFACE OF THE RELAY.

 THE GFI RELAY IS A LATCHING RELAY AND CAN NOT BE RESET BY PUSHING THE RESET BUTTON ON THE GFI RELAY. THE APPLICABLE BOOST PUMP SWITCH ON THE P5 OVERHEAD PANEL MUST BE PLACED IN THE OFF POSITION BEFORE THE RESET BUTTON ON THE RELAY IS PUSHED.

Fuel Boost Pump GFI Relay Open
Figure 113 (Sheet 1)

EFFECTIVITY
AIRPLANES POST-SB 28A0078 OR
POST-SB 28A0079

28-22-00



Fuel Boost Pump GFI Relay Open
Figure 113 (Sheet 2)

EFFECTIVITY
AIRPLANES POST-SB 28A0078 OR
POST-SB 28A0079

28-22-00

BOEING
757
FAULT ISOLATION/MAINT MANUAL

APU FUEL-FEED SYSTEM

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
ACTUATOR - APU FUEL SHUTOFF VALVE, V96	1	1	MAIN GEAR DOORS	28-25-11
ARRESTOR - APU FLAME	4	2	MAIN GEAR DOORS	28-25-07
CIRCUIT BREAKERS	1		FLT COMPT, P6	
APU FUEL VALVE, C1063		1	6E3	*
L FWD FUEL BOOST PUMP, C372		1	6H23	*
CIRCUIT BREAKERS	1		FLT COMPT, P11	
APU DC PUMP, C1058		1	11C33	*
APU FUEL DISAGREE ENBL, C4175		1	11D32	*
DC PUMP CONT, C1052			11D35	*
CIRCUIT BREAKERS			119BL, MAIN EQUIP CTR, P37	
APU GND SERVICE PWR SENSE, C4174		1		*
LINE - APU FUEL AND SHROUD	3		AIRPLANE FUSELAGE	28-25-05
PUMP - APU DC FUEL, M336	2	1	134AZ, MAIN GEAR DOORS	28-25-01
RELAYS - (REF 31-01-70, FIG. 101)				
APU FUEL PUMP TRANSFER, K505				
DC FUEL PUMP CONTROL, K191				
GND SERVICE SENSE RELAY, K10159				
L FWD PUMP START, K512				
RELAYS - (REF 31-01-86, FIG. 101)				
APU FUEL CONTROL, K175				
APU SOV DISAGREE, K10160				
APU SOV DISAGREE ENABLE, K10162				
SWITCH - APU DC FUEL PUMP PRESSURE, S74	2	1	MAIN GEAR DOORS	28-25-03
SWITCH - APU FUEL SHUTOFF PRESSURE, S10189	2	1	MAIN GEAR DOORS	*
VALVE - APU CHECK	2	1	134AZ	28-25-06
VALVE - APU FUEL SHUTOFF, V96	1	1	134AZ	28-25-02
VALVE - APU SUMP DRAIN	4	1	MAIN GEAR DOORS	28-25-09

* SEE THE WDM EQUIPMENT LIST

APU Fuel-Feed System - Component Index
Figure 101

EFFECTIVITY

ALL

28-25-00

09


Page 101
Dec 20/90

188448

BOEING

757


FAULT ISOLATION/MAINT MANUAL



APU Fuel-Feed System - Component Location
Figure 102 (Sheet 1)


EFFECTIVITY	
	ALL

28-25-00




APU CHECK VALVE

(B)



APU DC FUEL PUMP, M336 AND PRESSURE SWITCH, S74

(C)




PRESSURE SWITCH FOR APU FUEL SHUTOFF, S10189

(D)

APU Fuel-Feed System - Component Location (Details from Sht 1)
Figure 102 (Sheet 2)

EFFECTIVITY	
	ALL

28-25-00



APU Fuel-Feed System - Component Location
 Figure 102 (Sheet 3)




EFFECTIVITY	
	ALL

28-25-00

09

Page 104
 Dec 20/90

188442




APU Fuel-Feed System - Component Location
Figure 102 (Sheet 4)

EFFECTIVITY	
	ALL

28-25-00

 **BOEING**
757
FAULT ISOLATION/MAINT MANUAL

Not Used
Figure 103



28-25-00

01

Page 106
Mar 20/96


188449

**APU FAULT LT AND
"APU FUEL VAL" EICAS
MSG DISPLAYED**

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
6E3, 11D32, 11D35, 11C33

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)



APU FAULT Lt and APU FUEL VAL EICAS Msg Displayed
Figure 104

EFFECTIVITY

ALL

28-25-00

01

Page 107
May 28/04


70363

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
6E3,6F14,6H14,6H23,11C33,11D32,11D33,11D34,11D35

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (REF 24-22-00/201)
THE APU MASTER CONTROL SWITCH IS IN THE ON POSITION

EICAS MSG "DC FUEL PUMP ON" DISPLAYED



EICAS Msg DC FUEL PUMP ON Displayed
Figure 105

EFFECTIVITY

ALL

28-25-00

01

Page 108
Sep 28/06


70368

LEFT FORWARD BOOST PUMP DOES NOT COME ON AUTOMATICALLY WHEN AC POWER IS AVAILABLE (APU AT 95% FULL SPEED)

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
6E3,6F14,6H23,11C33,11D33,11D34,11D35

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (MM 24-22-00/201)



Left Forward Boost Pump Does Not Come On Automatically
When AC Power Is Available (APU at 95% Full Speed)
Figure 106

EFFECTIVITY	ALL
-------------	-----

28-25-00

B63096


BOEING
757
FAULT ISOLATION/MAINT MANUAL

DEFUELING

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
ACTUATOR - LEFT DEFUELING VALVE, V108	1	1	733, LEFT MLG OLEO DOOR	28-26-02
ACTUATOR - RIGHT DEFUELING VALVE, V109	1	1	743, RIGHT MLG OLEO DOOR	28-26-02
CIRCUIT BREAKER - FUELING VALVE, C1046	1	1	FLT COMPT, P6 6E6	*
CIRCUIT BREAKER - FLNG VALVE, C1047	2	1	119BL, MAIN EQUIP CTR, P34 34A9	*
RELAY - (FIM 31-01-33/101) FUELING PANEL DOOR, K179				
FUELING PWR TRANSFER, K357				
L DEFUEL VALVE CONT, K452				
L DEFUEL VALVE IND, K449				
R DEFUEL VALVE CONT, K453				
R DEFUEL VALVE IND, K450				
SWITCH - LEFT DEFUELING VALVE, S350	2	1	621GB, FUELING CONTROL PANEL, P28	28-26-00
SWITCH - RIGHT DEFUELING VALVE, S351	2	1	621GB, FUELING CONTROL PANEL, P28	28-26-00
VALVE BODY - LEFT DEFUELING, V108	1	1	531CB	28-26-01
VALVE BODY - RIGHT DEFUELING, V109	1	1	631CB	28-26-01

* SEE THE WDM EQUIPMENT LIST

Defueling - Component Index
Figure 101




28-26-00

01


Page 101
Sep 20/94

E44533



FLIGHT COMPARTMENT

Defueling - Component Location
Figure 102 (Sheet 1)



28-26-00



01

Page 102
Sep 20/94



55016

RIGHT CENTER TANK
ACCESS DOOR, 631CB

LEFT CENTER TANK
ACCESS DOOR, 531CB



MAIN EQUIPMENT CENTER





- 1 PREFERRED
- 2 ALTERNATE

Defueling - Component Location
Figure 102 (Sheet 2)

EFFECTIVITY	
	ALL

28-26-00

855566



FUELING CONTROL PANEL, P28

DEFUELING VALVE SWITCH (2 LOCATIONS)

(B)

1 THE UNITS ARE IN LBS OR KGS.

Defueling - Component Location
Figure 102 (Sheet 3)

EFFECTIVITY

ALL

28-26-00

03

Page 104
Sep 20/94

AD8028


**DEFUELING VALVE
LIGHT DOES NOT
INDICATE SELECTED
VALVE POSITION**

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
6E6,34A9

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT
FOLLOWS:

ELECTRICAL POWER IS ON (MM 24-22-00/201)



Defueling Valve Light Does Not Indicate Selected Valve Position
Figure 103 (Sheet 1)

EFFECTIVITY

ALL

28-26-00

01

Page 105
Sep 20/94

BOEING
757
FAULT ISOLATION/MAINT MANUAL

FROM SHEET 1
(BLOCK 3)

NO

13 DISCONNECT THE ELECTRICAL CONNECTOR (D1522,D1524) FROM THE (LEFT,RIGHT) DEFUELING VALVE ACTUATOR. INSTALL THE (LEFT,RIGHT) DEFUELING VALVE ACTUATOR, V108 OR V109 (MM 28-26-02/401).
REMOVE THE (LEFT,RIGHT) DEFUEL VALVE CONTROL RELAY (K452,K453) IN THE MISCELLANEOUS ELECTRICAL POWER PANEL, P33 (WDM 28-26-11).
IF THE (LEFT, RIGHT) DEFUELING VALVE IS IN THE "OPEN" POSITION, DO A CHECK FOR 28V DC AT CONNECTOR (D2716,D2626), PIN X1.
IF THE (LEFT,RIGHT) DEFUELING VALVE IS IN THE "CLOSE" POSITION, DO A CHECK FOR ZERO V DC AT CONNECTOR (D2716,D2626), PIN X1.
IS THE CORRECT VOLTAGE FOUND?

YES

25 REPLACE THE (LEFT,RIGHT) DEFUEL VALVE CONTROL RELAY (K452,K453) IN THE MISCELLANEOUS ELECTRICAL POWER PANEL, P33 (WDM 28-26-11).
MAKE SURE THE "DEFUEL (LH,RH) OPEN" LIGHT AGREES WITH THE "DEFUEL (LH,RH)" SWITCH POSITION.

NO

26 INSTALL THE (LEFT,RIGHT) DEFUEL VALVE CONTROL RELAY (K452,K453) IN THE MISCELLANEOUS ELECTRICAL POWER PANEL, P33 (WDM 28-26-11).
REPLACE THE (LEFT,RIGHT) DEFUELING VALVE SWITCH (S350, S351) ON THE FUELING CONTROL PANEL, P28 (WDM 28-26-11).
MAKE SURE THE "DEFUEL (LH,RH) OPEN" LIGHT AGREES WITH THE "DEFUEL (LH,RH)" SWITCH POSITION.

Defueling Valve Light Does Not Indicate Selected Valve Position
Figure 103 (Sheet 2)

EFFECTIVITY

ALL

28-26-00

01


Page 106
Sep 20/94

8115690



757
 FAULT ISOLATION/MAINT MANUAL

FUEL QUANTITY INDICATING SYSTEM

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
CIRCUIT BREAKER - FUEL QTY, C1040		1	119BL, MAIN EQUIP CTR, P34 34A10	*
CIRCUIT BREAKER - FUEL QTY - L, C1048		1	FLT COMPT, P11 11C34	*
FUEL QTY - R, C1053		1	11L19	*
CIRCUIT BREAKER - FUELING QTY, C1045		1	FLT COMPT, P6 6E4	*
COMPENSATOR - CENTER TANK, TS5010	8	1	631AB, CENTER FUEL TANK	28-41-02
COMPENSATOR - L MAIN TANK, TS108	8	1	541AB, L MAIN FUEL TANK	28-41-02
COMPENSATOR - R MAIN TANK, TS119	8	1	641AB, R MAIN FUEL TANK	28-41-02
COMPUTER - (FIM 31-41-00/101) EICAS L, M10181 EICAS R, M10182				
DENSITOMETER - CENTER TANK, M10903	12	1	631AB, CENTER FUEL TANK	28-41-03
DENSITOMETER - L MAIN TANK, M10901	12	1	541AB, L MAIN FUEL TANK	28-41-03
DENSITOMETER - R MAIN TANK, M10902	12	1	641AB, R MAIN FUEL TANK	28-41-03
HARNESS - CENTER DENSITOMETER TANK WIRING, M10917	13	1	CENTER MAIN FUEL TANK	28-41-09
HARNESS - L CENTER TANK WIRING, M10910 AND M10911	9	1	CENTER FUEL TANK	28-41-09
HARNESS - L MAIN TANK WIRING, M10908 AND M10909	11	1	L MAIN FUEL TANK	28-41-09
HARNESS - LEFT MAIN DENSITOMETER TANK WIRING, M10916	13	1	L MAIN FUEL TANK	28-41-09
HARNESS - R CENTER TANK WIRING, M10912 AND M10913	10	1	CENTER FUEL TANK	28-41-09
HARNESS - R MAIN TANK WIRING, M10914 AND M10915	11	1	R MAIN FUEL TANK	28-41-09
HARNESS - RIGHT MAIN DENSITOMETER TANK WIRING, M10918	13	1	R MAIN FUEL TANK	28-41-09
HOT SHORT PROTECTOR, M11872 	15	1	651, R REAR SPAR	28-41-24
INDICATOR - CENTER TANK LOAD SELECT (LSI), N10039	5	1	FUELING CONTROL PANEL, P28	28-41-06
INDICATOR - L MAIN TANK LOAD SELECT (LSI), N10040	5	1	FUELING CONTROL PANEL, P28	28-41-06
INDICATOR - R MAIN TANK LOAD SELECT (LSI), N10038	5	1	FUELING CONTROL PANEL, P28	28-41-06
MODULE - FUEL QUANTITY INDICATING (FQIM), M10054	3	1	FLT COMPT, P5	28-41-04
RELAY - (FIM 31-01-33/101) FUEL QTY PWR XFR, K356 FUELING PANEL DOOR, K179 FUELING POWER TRANSFER, K357				
RELAY - (FIM 31-01-36/101) SYS 1 AIR/GND, K10691				
RELAY - (FIM 31-01-37/101) SYS 2 AIR/GND, K10203				

* SEE THE WDM EQUIPMENT LIST

 AIRPLANES POST-SB 28A0085

Fuel Quantity Indicating System - Component Index
 Figure 101 (Sheet 1)

EFFECTIVITY
 GUI 001-114, 116-999

28-41-00
 CONFIG 2
 Page 101
 May 28/06


 **BOEING**
757
FAULT ISOLATION/MAINT MANUAL

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
SWITCH - FUEL QUANTITY TEST, S6	3	1	FLT COMPT, P61	*
SWITCH - TEST INDICATOR, S457	5	1	FUELING CONTROL PANEL, P28	*
UNIT - FUEL QUANTITY PROCESSOR (FQPU), M121	4	1	119BL, MAIN EQUIP CTR, E3-4	28-41-08
UNIT - TANK	8	-	LEFT OR RIGHT WING	28-41-01
CENTER TANK NO. 1, TS5011		1	134AZ	
CENTER TANK NO. 2, TS5012		1	531AB	
CENTER TANK NO. 3, TS5013		1	531AB	
CENTER TANK NO. 4, TS5014		1	531BB	
CENTER TANK NO. 5, TS5015		1	531CB	
CENTER TANK NO. 6, TS5016		1	631AB	
CENTER TANK NO. 7, TS5017		1	631AB	
CENTER TANK NO. 8, TS5075		1	631BB	
CENTER TANK NO. 9, TS5076		1	631CB	
L MAIN TANK NO. 1, TS109		1	541AB	
L MAIN TANK NO. 2, TS110		1	541BB	
L MAIN TANK NO. 3, TS111		1	541CB	
L MAIN TANK NO. 4, TS112		1	541DB	
L MAIN TANK NO. 5, TS113		1	541FB	
L MAIN TANK NO. 6, TS114		1	541GB	
L MAIN TANK NO. 7, TS115		1	541HB	
L MAIN TANK NO. 8, TS116		1	541JB	
L MAIN TANK NO. 9, TS117		1	541LB	
L MAIN TANK NO. 10, TS118		1	541MB	
L MAIN TANK NO. 11, TS5196		1	542AB	
L MAIN TANK NO. 12, TS5197		1	542CB	
R MAIN TANK NO. 1, TS146		1	641AB	
R MAIN TANK NO. 2, TS147		1	641BB	
R MAIN TANK NO. 3, TS148		1	641CB	
R MAIN TANK NO. 4, TS149		1	641DB	
R MAIN TANK NO. 5, TS150		1	641FB	
R MAIN TANK NO. 6, TS151		1	641GB	
R MAIN TANK NO. 7, TS152		1	641HB	
R MAIN TANK NO. 8, TS153		1	641JB	
R MAIN TANK NO. 9, TS154		1	641LB	
R MAIN TANK NO. 10, TS155		1	641MB	
R MAIN TANK NO. 11, TS5198		1	642AB	
R MAIN TANK NO. 12, TS5199		1	642CB	

Fuel Quantity Indicating System - Component Index
Figure 101 (Sheet 2)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
CONFIG 2
Page 102
May 28/03




Fuel Quantity Indicating System - Component Location
 Figure 102 (Sheet 1)

EFFECTIVITY
 GUI 001-114, 116-999

28-41-00

CONFIG 2
 Page 103
 May 28/03




Fuel Quantity Indicating System - Component Location
Figure 102 (Sheet 2)

EFFECTIVITY
GUI 001-114, 116-999


28-41-00

CONFIG 2
Page 104
May 28/03

757 FAULT ISOLATION/MAINT MANUAL




FLIGHT COMPARTMENT



**FUEL QUANTITY INDICATING MODULE
(FQIM), M10054**


(A)



**FUEL QUANTITY
TEST SWITCH, S6**

**MISCELLANEOUS TEST PANEL, M10398 (REF)
(EXAMPLE PANEL SHOWN)**

(B)



EICAS MAINTENANCE PANEL

(C)


1 THE UNITS ARE IN KGS OR LBS.

**Fuel Quantity Indicating System - Component Location
Figure 102 (Sheet 3)**


EFFECTIVITY
GUI 001-114, 116-999

28-41-00

CONFIG 2
Page 105
May 28/03



MAIN EQUIPMENT CENTER



FQIS PROCESSOR, M121

(C)

INSTRUCTIONS:

- Press ON to start BITE display
- Press YES or NO in response to questions (?)
- Press to display next result
- Press to display previous result
- Press MENU to return to current menu
- Press OFF to stop BITE display

PRIMARY BITE MENU OPTIONS:

- FAULT HISTORY: Displays past faults by flight leg
- SYSTEM DATA: Displays system/LRU data
- SELF TEST: Tests system/LRUs interfaces
- SYSTEM CONFIG: Displays system configuration
- ERASE FAULT HISTORY:

(D)

**Fuel Quantity Indicating System - Component Location
Figure 102 (Sheet 4)**


EFFECTIVITY
GUI 001-114, 116-999

28-41-00
CONFIG 2
Page 106
May 28/03

BOEING

757

FAULT ISOLATION/MAINT MANUAL



FUELING CONTROL PANEL, P28

(E)


1 THE UNITS ARE IN KGS OR LBS.

Fuel Quantity Indicating System - Component Location
Figure 102 (Sheet 5)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00


CONFIG 2
Page 107
May 28/03



Fuel Quantity Indicating System - Component Location
Figure 102 (Sheet 6)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
CONFIG 2
Page 108
May 28/03



Fuel Quantity Indicating System - Component Location
Figure 102 (Sheet 7)


EFFECTIVITY
GUI 001-114, 116-999

28-41-00
CONFIG 2
Page 109
May 28/03

892366


NOT USED

(F)



TANK UNIT
(EXAMPLE)

(G)



LEFT MAIN TANK COMPENSATOR, TS108
CENTER TANK COMPENSATOR, TS5010
RIGHT MAIN TANK COMPENSATOR, TS119


(H)

Fuel Quantity Indicating System - Component Location
(Details from Shts 6 and 7)
Figure 102 (Sheet 8)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00

CONFIG 2
Page 110
May 28/03




Fuel Quantity Indicating System - Component Location
(Detail from Sht 6)
Figure 102 (Sheet 9)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00

CONFIG 2
Page 111
May 28/03



RIGHT CENTER TANK WIRING HARNESS

J


Fuel Quantity Indicating System - Component Location
(Detail from Sht 7)
Figure 102 (Sheet 10)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00

CONFIG 2
Page 112
May 28/03

BOEING
757
FAULT ISOLATION/MAINT MANUAL




LEFT OR RIGHT MAIN TANK WIRING HARNESS

(K)


Fuel Quantity Indicating System - Component Location
(Detail from Sht 6 and 7)
Figure 102 (Sheet 11)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
CONFIG 2
Page 113
May 28/03



FRONT VIEW



LEFT MAIN, CENTER OR RIGHT MAIN DENSITOMETER, M10901, M10903 OR M10902




Fuel Quantity Indicating System - Component Location
 (Detail from Sht 6 and 7)
 Figure 102 (Sheet 12)

EFFECTIVITY
 GUI 001-114, 116-999

28-41-00

CONFIG 2
 Page 114
 May 28/03



LEFT MAIN, RIGHT MAIN OR CENTER DENSITOMETER TANK WIRING HARNESS,
M10916, M10918, OR M10917




Fuel Quantity Indicating System - Component Location
(Detail from Sht 6 and 7)
Figure 102 (Sheet 13)

EFFECTIVITY
GUI 001-114, 116-999


28-41-00
CONFIG 2
Page 115
May 28/03

BOEING
757
FAULT ISOLATION/MAINT MANUAL



HI-Z/LO-Z CONNECTOR

(N)



DENSITOMETER CONNECTOR


(O)

Fuel Quantity Indicating System - Component Location
(Details from Sht 6 and 7)
Figure 102 (Sheet 14)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00

CONFIG 2
Page 116
May 28/03



Fuel Quantity Indicating System - Component Location
Figure 102 (Sheet 15)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
CONFIG 2
Page 117
May 28/06

TITLE

FUEL QUANTITY BITE PROCEDURE.....	FIGURE 104
FAULT MESSAGE REFERENCE CHART.....	FIGURE 106
FQIS WIRING	FIGURE 107
FAULT MESSAGES	FIGURE 108
DRY CAPACITANCE TEST IN THE MAIN EQUIPMENT CENTER..... (NO FUEL IN THE TANK)	FIGURE 109
INTERMITTENT FAULT MESSAGES.....	FIGURE 110
FUEL QUANTITY INDICATOR DOES NOT DISPLAY CORRECTLY.....	FIGURE 114
FUEL CONFIG LIGHT AND EICAS MSG LOW FUEL NOT DISPLAYED..... DURING FUEL QTY TEST	FIGURE 115
TOTAL FUEL QTY DOES NOT AGREE WITH FMC CALCULATED..... FUEL QTY. FUEL FLOW NORMAL	FIGURE 116
EICAS MSG FUEL QTY IND OR FUEL QTY CHANNEL DISPLAYED.....	FIGURE 117
LOAD SELECT INDICATOR SHOWS "-A.-", "-b.-", OR "-A.b"	FIGURE 118
FUEL QUANTITY INDICATOR SHOWS "-A.-", "-b.-", OR "-A.b"	FIGURE 119
LOAD SELECT INDICATOR SHOWS THE MESSAGE "I.d" IN THE DISPLAY	FIGURE 120

Fuel Quantity Indicating System Problems Index
Figure 103

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
 CONFIG 2
 Page 118
 May 28/06

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
6E4,11C34,11L19,34A10

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)

EQUIPMENT:

JcAIR, INC.

400 INDUSTRIAL PARKWAY

INDUSTRIAL AIRPORT, KS 66031

- A. FUEL QTY TEST SET - P/N 472090-007, OR P/N 472090-009, OR PSD 40-1, OR P/N 472090-007, OR P/N 472090-009, OR PSD 40-1, OR PSD 60-1, OR PSD 60-2, OR PSD 60-2R
- B. FUEL QTY ADAPTER HARNESS -
LEFT/RIGHT MAIN FUEL TANK - PSD 757/767-101
CENTER FUEL TANK - PSD 757/767 - 102
DENSITOMETER - PSD 757/767 - 103
- C. TEST BOX, FQIS - PSD 757/767 - 1

NOTE 1: WHEN AN AIRPLANE EICAS MESSAGE SHOWS, YOU MUST DO A CHECK OF THE PROCESSOR (FQPU) BITE MENU "PRESENT FAULTS?". FOR THE FAULT HISTORY MENU, DO A CHECK FOR FAULT MESSAGES ON THE FLIGHT LEG 00. MAKE AND KEEP A WRITTEN RECORD OF THE FAULTS IN FLIGHT LEG 00 TO HELP IN SUBSEQUENT FAULT ISOLATION.

NOTE 2: THE RECOMMENDED CORRECTIVE ACTION FOR FAULT MESSAGES IS AS FOLLOWS:

- DO A CHECK OF THE "PRESENT FAULTS?" MENU
- IF THERE ARE PRESENT FAULTS SHOWN, DO THE APPLICABLE FAULT ISOLATION PROCEDURE IN FIG. 106.

NOTE: IF NO PRESENT FAULTS SHOW AND THERE ARE FAULT MESSAGES IN "FAULT HISTORY?" FLIGHT LEG 00, MAKE SURE THE FQIS OPERATES CORRECTLY AS FOLLOWS:

1. MAKE SURE THE FUEL QUANTITY DISPLAY DOES NOT GO OFF OR HAVE AN IRREGULAR INDICATION
2. DO A "SELF TEST?" ON THE FQIS PROCESSOR DISPLAY
3. IF NO FAULTS SHOW FROM THE "SELF TEST?" OR IN THE "PRESENT FAULTS?" MENU AND THE FQIS DISPLAY OPERATES CORRECTLY, NO FURTHER MAINTENANCE IS NECESSARY.

NOTE 3: EACH FLIGHT LEG, AS SHOWN BY THE PROCESSOR UNDER THE "FAULT HISTORY?" MENU, STARTS AT AIRPLANE TAKEOFF. THIS FLIGHT LEG WILL BE FLIGHT LEG 00 IN THE FQIS PROCESSOR UNTIL THE NEXT TAKEOFF. AT TAKEOFF THE DATA FROM FLIGHT LEG 00 IS RECORDED IN FLIGHT LEG 01, AND FLIGHT LEG 00 WILL START AGAIN.

Fuel Quantity BITE Procedure
Figure 104 (Sheet 1)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
CONFIG 2
Page 119
May 28/06

NOTE 4: AIRPLANES WITH THE PROCESSOR, PART NO. S345N001-030; IF THE AIRPLANE POWER IS PUT OFF AND ON, AND THERE IS A FAULT MESSAGE IN "FAULT HISTORY?" FLIGHT LEG 0, THE EICAS MESSAGE "FUEL QTY BITE" WILL SHOW. THE EICAS MESSAGE "FUEL QTY BITE" WILL ALSO SHOW IF YOU DO A "SELF TEST?" WHEN THERE IS A FAULT MESSAGE IN FLIGHT LEG 0. TO CORRECT THIS FAULT MESSAGE, SEE NOTE 1.

NOTE 5: THE AIRPLANE WIRING HARNESSSES ARE EXTERNAL TO THE FUEL TANK.

NOTE 6: THE TANK WIRING HARNESSSES ARE INTERNAL TO THE FUEL TANK.

1. BITE CONTROL PANEL - GENERAL

A. THE BITE CONTROL PANEL IS ON THE FRONT OF THE PROCESSOR IN THE MAIN EQUIPMENT CENTER, FIG. 102, SHEET 4. THE PROCESSOR BITE CONTROL PANEL OPERATION BUTTONS ARE AS FOLLOWS:

- OFF/ON: THE "ON/OFF" BUTTON PUTS THE BITE DISPLAY CONTROL ON OR OFF
- MENU: THE "MENU" BUTTON PUTS YOU AT THE MENU LEVEL OF THE MENU YOU ARE IN
- YES: THE "YES" BUTTON PUTS ON THE MENU ITEM SHOWN ON THE DISPLAY FOR MESSAGES THAT END IN A QUESTION MARK (?)
- NO: THE "NO" BUTTON PUTS ON THE NEXT MENU ITEM ON THE DISPLAY FOR MESSAGES THAT END IN A QUESTION MARK (?)
- ↑ (UP): THE "UP" BUTTON SHOWS THE LAST DATA ITEM SHOWN
- ↓ (DOWN): THE "DOWN" BUTTON SHOWS THE NEXT DATA ITEM

2. PROCESSOR MENU - GENERAL

THE TOP LEVEL MENU MESSAGES ARE AS FOLLOWS:
(SEE SHEET 6).

A. PRESENT FAULTS ?

THE PRESENT FAULTS MENU DISPLAY IS SHOWN ON SHEET 8. THE PRESENT FAULTS MENU SHOWS ALL PRESENT SYSTEM FAULTS.

B. FAULT HISTORY ?

THE FAULT HISTORY MENU DISPLAY IS SHOWN ON SHEET 10. THE FAULT HISTORY MENU SHOWS ALL SYSTEM FAULTS FOR THE FLIGHT LEGS 0 THRU 64.

(CONTINUED ON NEXT SHEET)

Fuel Quantity BITE Procedure
Figure 104 (Sheet 2)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
CONFIG 2
Page 120
May 28/06

C. SYSTEM DATA ?

THE SYSTEM DATA MENU DISPLAY IS SHOWN ON SHEET 13. THE SYSTEM DATA MENU SHOWS DATA AS FOLLOWS:

(1) UPLIFT DATA ?

- THE UPLIFT DATA MENU SHOWS AIRPLANE FUEL LOADED DATA AS FOLLOWS:
 - (a) UPLIFT MASS (THE MASS OF THE FUEL ADDED DURING THE REFUEL OPERATION)
 - (b) UPLIFT DENSITY (THE DENSITY OF THE FUEL ADDED DURING THE REFUEL OPERATION)

NOTE 1: YOU CAN CALCULATE THE FUEL UPLIFT VOLUME TO COMPARE IT TO THE FUEL TRUCK VOLUME. IF YOU DIVIDE THE "UPLIFT MASS" BY THE "UPLIFT DENSITY" YOU WILL GET THE AIRPLANE FUEL VOLUME.

NOTE 2: TO SEE THE UPLIFT DATA AFTER THE REFUEL OPERATION, YOU MUST CLOSE THE FUELING STATION DOOR AND THEN WAIT FOR APPROXIMATELY 2 MINUTES FOR THE PROCESSOR TO CALCULATE THE DATA.

(2) MAIN TANKS DATA ?

- THE MAIN TANKS DATA MENU SHOWS LEFT AND RIGHT MAIN TANK FUEL DATA AS FOLLOWS:
 - (a) FUEL MASS
 - (b) FUEL DENSITY
 - (c) FUEL VOLUME
 - (d) HI-Z WIRING, COMPENSATOR AND TANK UNIT CAPACITANCE MEASUREMENTS.

(3) CENTER TANK DATA ?

- THE CENTER TANK DATA MENU SHOWS CENTER TANK FUEL DATA AS FOLLOWS:
 - (a) FUEL MASS
 - (b) FUEL DENSITY
 - (c) FUEL VOLUME
 - (d) HI-Z WIRING, COMPENSATOR AND TANK UNIT CAPACITANCE MEASUREMENTS.

D. SELF-TEST ?

THE SELF-TEST MENU DISPLAYS ARE SHOWN ON SHEET 15. THE SELF-TEST MENU DOES A TEST OF THE FQIS SYSTEM. IF NO FAULTS SHOW, THE "TEST COMPLETE SELF-TEST PASS" MESSAGE IS SHOWN. IF FAULTS OCCUR, THE FAULTS ARE SHOWN ON THE DISPLAY.

NOTE: YOU CAN SEE THE FAULT MESSAGES IN THE SELF-TEST PROCEDURE ONE TIME ONLY. TO SEE THE SELF-TEST FAULT MESSAGES AGAIN, YOU MUST DO THE "SELF-TEST?" PROCEDURE AGAIN. YOU MUST CLOSE THE FUELING STATION DOOR, 621GB, TO DO THIS TEST.

Fuel Quantity BITE Procedure
Figure 104 (Sheet 3)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
CONFIG 2
Page 121
May 28/06

E. SYSTEM CONFIG ?

THE SYSTEM CONFIGURATION MENU DISPLAYS ARE SHOWN ON SHEET 19. THE SYSTEM CONFIGURATION MENU DISPLAYS ARE AS FOLLOWS:

(1) LEFT MAIN CONFIGURATION ?

RIGHT MAIN CONFIGURATION ?

CENTER CONFIGURATION ?

- THE LEFT MAIN CONFIGURATION, RIGHT MAIN CONFIGURATION, AND CENTER CONFIGURATION MENUS SHOW THE DATA AS FOLLOWS:

- (a) SOFTWARE VERSION AND REVISION
- (b) A AND B AIR/GROUND RELAY INDICATION
- (c) LB OR KG INDICATION
- (d) FUELING STATION DOOR (PANEL 28) OPEN/CLOSED INDICATION
- (e) AIRPLANE FUEL TANK INDICATION
- (f) FQIS SELF-TEST STATUS.

(2) ARINC BUS A CONFIGURATION ?

ARINC BUS B CONFIGURATION ?

- THE ARINC BUS A CONFIGURATION, AND ARINC BUS B CONFIGURATION MENUS SHOW THE DATA AS FOLLOWS:

- (a) SOFTWARE VERSION AND REVISION
- (b) A AND B AIR/GROUND RELAY INDICATION
- (c) SPARE TANK STATUS, "ABSENT" SHOWS IF NO SPARE TANK IS USED
- (d) FUELING STATION DOOR (PANEL 28) OPEN/CLOSED INDICATION
- (e) ID STATUS, INDICATION OF THE INPUT/OUTPUT CARD IN USE (CARD 1 OR 2)
- (f) CENTER OVERRIDE PUMPS, ON/OFF INDICATION
- (g) FLIGHT, REFUEL, SYSTEM TEST INDICATION (0 IS OFF, OR 1 IS ON)
- (h) LEFT, RIGHT AND CENTER SET SWITCH INDICATION (0 IS OFF, OR 1 IS ON)
- (i) SELECTED BUS IS FAILED, REPLACE THE APPLICABLE BUS.

Fuel Quantity BITE Procedure
Figure 104 (Sheet 4)

EFFECTIVITY
GUI 001-114, 116-999

864796

28-41-00

CONFIG 2
Page 122
May 28/06

 **BOEING**
757
FAULT ISOLATION/MAINT MANUAL

(3) BDB CONFIGURATION ?

- THE BITE DISPLAY BOARD CONFIGURATION MENU SHOWS DATA AS FOLLOWS:
 - (a) SOFTWARE VERSION AND REVISION
 - (b) FUEL QUANTITY BITE, SHOWS "NO FAULT" OR "FAULT PRESENT" FOR ALL FQIS FAILURES.

F. ERASE HISTORY ?

- THE ERASE FAULT HISTORY MENU DISPLAY IS SHOWN ON SHEET 24. THE ERASE FAULT HISTORY MENU DISPLAYS ARE AS FOLLOWS:
 - (a) ERASE FLIGHT LEG 11-64? LETS YOU ERASE THE AIRPLANE FLIGHT LEGS 11 THRU 64.
 - (b) ARE YOU SURE? LETS YOU ERASE OR NOT ERASE THE FLIGHT LEGS 11 THRU 64.
 - (c) END HISTORY ERASE (ERASE COMPLETE).

(CONTINUED)

Fuel Quantity BITE Procedure
Figure 104 (Sheet 5)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00


CONFIG 2

20

Page 123

May 28/06

MAIN MENU



Fuel Quantity BITE Procedure
Figure 104 (Sheet 6)

EFFECTIVITY
GUI 001-114, 116-999

878408

28-41-00
CONFIG 2
Page 124
May 28/06

3. FUEL QUANTITY BITE PROCEDURE

A. PUSH AND RELEASE THE "ON/OFF" BUTTON TO PUT THE PROCESSOR BITE DISPLAY TO ON.

NOTE: MAKE SURE THE PROCESSOR BITE DISPLAY IS ON. IF THE PROCESSOR BITE DISPLAY IS NOT ON AFTER YOU PUSH THE "ON/OFF" BUTTON MORE THAN ONCE, MAKE SURE POWER IS SUPPLIED TO THE PROCESSOR (WDM 28-21-11).

B. "PRESENT FAULTS ?" WILL SHOW ON THE FQIS PROCESSOR DISPLAY. PUSH AND RELEASE THE "YES" BUTTON TO SEE THE PRESENT FAULTS MENU, OR CONTINUE TO PUSH THE "NO" BUTTON TO SEE THE NEXT MENU ALTERNATIVES (SEE SHEET 6).

C. PRESENT FAULTS ?

(1) MAKE SURE THE PROCESSOR BITE DISPLAY IS ON AND "PRESENT FAULTS ?" SHOWS ON THE MENU DISPLAY.

(A) IF THE PROCESSOR IS NOT ON, GO TO STEP 3.A.

(2) PUSH AND RELEASE THE "YES" BUTTON TO GO TO THE PRESENT FAULT DATA.

(3) MAKE A WRITTEN RECORD OF ALL THE FAULT MESSAGES SHOWN.

(4) CONTINUE TO PUSH AND RELEASE THE "DOWN" BUTTON TO SEE ALL THE FAULT MESSAGES.

NOTE: PUSH AND RELEASE THE "UP" BUTTON TO SEE THE PREVIOUS FAULT MESSAGES.

(5) WHEN THE "END OF PRESENT FAULTS" MESSAGE SHOWS, ALL FAULT MESSAGES ARE SHOWN. PUSH AND RELEASE THE MENU BUTTON.

NOTE: THIS PUTS YOU AT THE TOP OF THE "PRESENT FAULTS ?" MENU.


(6) SEE FIG. 106 FOR CORRECTION OF ALL FAULT MESSAGES.


Fuel Quantity BITE Procedure
Figure 104 (Sheet 7)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
CONFIG 2
Page 125
May 28/06

PRESENT FAULT MENU




 " - " THIS INDICATION SHOWS "A" OR "G" TO INDICATE THAT THE FAULT FIRST OCCURRED IN THE AIR OR GROUND MODE.

Fuel Quantity BITE Procedure
Figure 104 (Sheet 8)

EFFECTIVITY
GUI 001-114, 116-999

878412

28-41-00

CONFIG 2
 Page 126
 May 28/06

D. FAULT HISTORY ?

(1) MAKE SURE THE PROCESSOR BITE DISPLAY IS ON AND "FAULT HISTORY ?" SHOWS ON THE MENU DISPLAY.

(A) IF THE PROCESSOR IS NOT ON, GO TO STEP 3.A.

(2) PUSH AND RELEASE THE "YES" BUTTON TO GO TO THE "FAULT HISTORY LEG ##?" DISPLAY.

NOTE: THE "##" PLACE HOLDER WILL SHOW THE FLIGHT LEG NUMBER FOR THE FLIGHT LEG WITH THE RECORDED FAULTS.

(3) PUSH AND RELEASE THE "YES" BUTTON TO SEE THE FAULT MESSAGES, OR PUSH AND RELEASE THE "NO" BUTTON TO SEE THE NEXT "FLIGHT LEG" WITH FAULT MESSAGES.

NOTE: ONLY THE FLIGHT LEGS WITH FAULTS RECORDED WILL SHOW FAULT MESSAGES ON THE DISPLAY.

(4) MAKE A WRITTEN RECORD OF THE FAULT MESSAGE SHOWN.

(5) CONTINUE TO PUSH AND RELEASE THE "DOWN" BUTTON TO SEE ALL THE FAULT MESSAGES.

(6) WHEN "END OF HISTORY FLIGHT LEG ##" SHOWS, PUSH AND RELEASE THE "DOWN" BUTTON TO SEE THE NEXT FLIGHT LEG'S FAULT MESSAGES.

(7) WHEN THE "END OF FAULT HISTORY" MESSAGE SHOWS, PUSH AND RELEASE THE "MENU" BUTTON.

NOTE: THIS PUTS YOU AT THE TOP OF THE "FAULT HISTORY ?" MENU.

(8) SEE FIG. 106 FOR POSSIBLE CORRECTION OF THE FAULT MESSAGES SHOWN.


NOTE: ONLY THE FLIGHT LEGS WITH FAULTS RECORDED WILL SHOW FAULT MESSAGES ON THE DISPLAY.

Fuel Quantity BITE Procedure
Figure 104 (Sheet 9)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00

CONFIG 2
Page 127
May 28/06



2 " " THIS INDICATION SHOWS "A" OR "G" TO SHOW THAT THE FAULT FIRST OCCURRED IN THE AIR OR ON THE GROUND MODE. THE "##" INDICATION WILL SHOW THE NUMBER OF TIMES THE FAULT OCCURRED IN THE APPLICABLE FLIGHT LEG.

Fuel Quantity BITE Procedure
Figure 104 (Sheet 10)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
CONFIG 2
Page 128
May 28/06

E. SYSTEM DATA ?

(1) MAKE SURE THE PROCESSOR BITE DISPLAY IS ON AND "SYSTEM DATA ?" SHOWS ON THE MENU DISPLAY.

NOTE: IF THE PROCESSOR BITE DISPLAY IS NOT ON, GO TO STEP 3.A.

(2) IF YOU WANT TO SEE SYSTEM DATA, PUSH AND RELEASE THE "YES" BUTTON. THE "UPLIFT DATA ?" MENU WILL SHOW.

(3) IF YOU WANT TO SEE THE UPLIFT DATA, PUSH AND RELEASE THE "YES" BUTTON; OR IF YOU WANT TO SEE THE "MAIN TANKS DATA ?" MENU, PUSH AND RELEASE THE "NO" BUTTON AND GO TO STEP (5).

(A) PUSH AND RELEASE THE "DOWN" BUTTON TO SEE THE UPLIFT DATA AS FOLLOWS:

- 1) UPLIFT MASS (KG OR LB)
- 2) UPLIFT DENSITY (KG/L OR LB/G)
- 3) END OF UPLIFT DATA.

(4) WHEN THE "END OF UPLIFT DATA" MESSAGE SHOWS, PUSH AND RELEASE THE "DOWN" BUTTON TO GO TO THE "MAIN TANKS DATA ?" MENU.

(5) PUSH AND RELEASE THE "YES" BUTTON TO SEE THE MAIN TANKS DATA; OR IF YOU WANT TO SEE THE CENTER TANK DATA, PUSH AND RELEASE THE "NO" BUTTON AND GO TO STEP (7).

(A) CONTINUE TO PUSH AND RELEASE THE "DOWN" BUTTON TO SEE ALL THE MAIN TANKS DATA MESSAGES.

(B) MAKE A WRITTEN RECORD OF ALL THE SYSTEM DATA SHOWN FOR THE LEFT AND RIGHT FUEL TANKS.

(CONTINUED ON NEXT SHEET)

Fuel Quantity BITE Procedure
Figure 104 (Sheet 11)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00

CONFIG 2

Page 129

May 28/06

20

(C) THE MAIN TANKS DATA MENU SHOWS THE LEFT AND RIGHT FUEL TANK DATA AS FOLLOWS (SEE SHEET 13):

- 1) FUEL MASS
- 2) FUEL DENSITY
- 3) FUEL VOLUME
- 4) HI-Z WIRING CAPACITANCE
- 5) COMPENSATOR CAPACITANCE
- 6) TANK UNIT CAPACITANCE
- 7) END OF MAIN TANK DATA.

(6) WHEN THE "END OF MAIN TANK DATA" MESSAGE SHOWS, PUSH AND RELEASE THE "DOWN" BUTTON TO GO TO THE "CENTER TANK DATA ?" MENU.

(7) PUSH AND RELEASE THE "YES" BUTTON TO SEE THE CENTER TANKS DATA.

(A) CONTINUE TO PUSH AND RELEASE THE "DOWN" BUTTON TO SEE ALL OF THE CENTER TANK DATA.

(B) MAKE A WRITTEN RECORD OF ALL THE SYSTEM DATA SHOWN FOR THE CENTER FUEL TANK.

(C) THE CENTER TANK DATA MENU SHOWS THE CENTER FUEL TANK DATA AS FOLLOWS (SEE SHEET 13):

- 1) FUEL MASS
- 2) FUEL DENSITY
- 3) FUEL VOLUME
- 4) HI-Z WIRING CAPACITANCE
- 5) COMPENSATOR CAPACITANCE
- 6) TANK UNIT CAPACITANCE
- 7) END OF CENTER TANK DATA.

(D) PUSH AND RELEASE THE "DOWN" BUTTON TO SHOW THE MESSAGE "END OF SYSTEM DATA".

NOTE: WHEN THIS MESSAGE SHOWS, ALL OF THE SYSTEM DATA HAVE SHOWN.

(E) PUSH AND RELEASE THE MENU BUTTON.

NOTE: THIS PUTS YOU AT THE TOP OF THE "SYSTEM DATA ?" MENU.

(CONTINUED ON SHEET 14)

Fuel Quantity BITE Procedure
Figure 104 (Sheet 12)

EFFECTIVITY
GUI 001-114, 116-999


28-41-00

CONFIG 2

Page 130

May 28/06

20



Fuel Quantity BITE Procedure
Figure 104 (Sheet 13)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00

CONFIG 2

20

Page 131

May 28/06

F. SELF TEST ?

- (1) MAKE SURE THE PROCESSOR BITE DISPLAY IS ON AND "SELF TEST ?" SHOWS ON THE MENU DISPLAY.

NOTE: IF THE PROCESSOR BITE DISPLAY IS NOT ON, DO STEP 3.A.

- (2) IF YOU WANT TO BEGIN THE SELF TEST, PUSH AND RELEASE THE "YES" BUTTON TO GO TO THE "BEGIN SELF TEST ? TEST TIME =90 SEC" DISPLAY (SEE SHEET 16).

NOTE: IF YOU DO NOT WANT TO DO A SELF TEST, PUSH AND RELEASE THE "NO" BUTTON TO GO TO "END OF SELF TEST" WHEN "BEGIN SELF TEST ?" SHOWS.

NOTE: THE FUELING STATION DOOR, 621GB, MUST BE CLOSED FOR THIS TEST.

- (A) PUSH AND RELEASE THE "YES" BUTTON TO START THE SELF TEST.

NOTE: THE DISPLAY "TEST IN PROGRESS" WILL FLASH FOR 90 SECONDS.

- (B) IF THE SELF TEST MESSAGE "TEST COMPLETE SELF TEST PASS" SHOWS, PUSH AND RELEASE THE "DOWN" BUTTON TO GO TO "END OF SELF TEST".

- (C) IF YOU WANT TO SEE THE SYSTEM FAULT MESSAGES WHEN "TEST COMPLETE LIST FAULTS ?" SHOWS, PUSH AND RELEASE THE "YES" BUTTON TO SEE THE SYSTEM FAULT MESSAGES.

1) CONTINUE TO PUSH AND RELEASE THE "DOWN" BUTTON TO SEE ALL OF THE FAULT MESSAGES.

2) MAKE A WRITTEN RECORD OF ALL THE FAULT MESSAGES SHOWN.

3) PUSH AND RELEASE THE "DOWN" BUTTON WHEN THE "END OF SELF TEST FAULTS" MESSAGE SHOWS (ALL OF THE SELF TEST FAULT MESSAGES ARE SHOWN).

NOTE: SEE FIG. 106 FOR CORRECTION OF ALL FAULT MESSAGES.

- (D) IF YOU DO NOT WANT TO SEE THE SYSTEM FAULT MESSAGES WHEN "TEST COMPLETE LIST FAULTS ?" SHOWS, PUSH AND RELEASE THE "NO" BUTTON TO NOT SEE THE SYSTEM FAULTS.

NOTE: WHEN THE "END OF SELF TEST FAULTS" SHOWS, YOU ARE AT THE END OF THE SELF TEST.

- (3) PUSH AND RELEASE THE "MENU" BUTTON.


NOTE: THIS PUTS YOU AT THE TOP OF THE "SELF TEST MENU ?" DISPLAY.

Fuel Quantity BITE Procedure
Figure 104 (Sheet 14)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
CONFIG 2
Page 132
May 28/06

SELF TEST MENU



Fuel Quantity BITE Procedure
Figure 104 (Sheet 15)

EFFECTIVITY
GUI 001-114, 116-999

878437

28-41-00

CONFIG 2
Page 133
May 28/06

G. SYSTEM CONFIGURATION ?

- (1) MAKE SURE THE PROCESSOR BITE DISPLAY IS ON AND "SYSTEM CONFIGURATION ?" SHOWS ON THE MENU DISPLAY.

NOTE: IF THE PROCESSOR IS NOT ON, GO TO STEP 3.A.

- (2) IF YOU WANT TO SEE THE SYSTEM CONFIGURATION DATA, PUSH AND RELEASE THE "YES" BUTTON.
- (3) TO SEE THE LEFT MAIN FUEL TANK CONFIGURATION DATA, GO TO STEP (A) BELOW; TO SEE THE RIGHT MAIN FUEL TANK CONFIGURATION, PUSH AND RELEASE THE "NO" BUTTON AND GO TO STEP (A) BELOW; TO SEE THE CENTER FUEL TANK CONFIGURATION, DATA PUSH AND RELEASE THE "NO" BUTTON TWO TIMES AND GO TO STEP (A) BELOW (SEE SHEET 19).
- (A) PUSH AND RELEASE THE "YES" BUTTON WHEN THE MENU DISPLAY SHOWS THE APPLICABLE MENU: "LEFT MAIN CONFIGURATION ?", "RIGHT MAIN CONFIGURATION ?", "CENTER CONFIGURATION ?"
- (B) CONTINUE TO PUSH AND RELEASE THE "DOWN" BUTTON TO SEE THE APPLICABLE FUEL TANK CONFIGURATION DATA.
- (C) MAKE A WRITTEN RECORD OF ALL THE MESSAGES SHOWN FOR THE APPLICABLE FUEL TANK CONFIGURATION.
- (D) THE FUEL TANK CONFIGURATION DATA MENU SHOWS THE FUEL TANK DATA AS FOLLOWS (SHEET 19):
- 1) SOFTWARE VERSION NUMBER AND REVISION NUMBER
 - 2) "AIR" OR "GROUND" A RELAY INDICATION
 - 3) "AIR" OR "GROUND" B RELAY INDICATION
 - 4) FQIS SYSTEM "LB" OR "KG" CONFIGURATION INDICATION
 - 5) FUELING STATION DOOR "OPEN" OR "CLOSED" INDICATION
 - 6) ID STATUS INDICATION SHOWS THE AIRPLANE FUEL TANK ON THE DISPLAY
 - 7) FQIS SELF TEST STATUS INDICATION SHOWS "NO TEST" OR "TEST".

NOTE: WHEN THE "END LEFT MAIN CONFIGURATION" MESSAGE SHOWS, ALL OF THE LEFT MAIN FUEL TANK CONFIGURATION MESSAGES ARE SHOWN.

- (E) IF YOU WANT TO SEE MORE SYSTEM CONFIGURATION DATA, PUSH AND RELEASE THE "DOWN" BUTTON TO CONTINUE.
- (F) IF YOU WANT TO GO TO THE TOP OF THE SYSTEM DATA MENU, PUSH AND RELEASE THE "MENU" BUTTON.

(CONTINUED ON SHEET 17)

Fuel Quantity BITE Procedure
Figure 104 (Sheet 16)

EFFECTIVITY
GUI 001-114, 116-999

864804

28-41-00
CONFIG 2
Page 134
May 28/06

(4) TO SEE THE CONFIGURATION DATA FOR ONE OF THE TWO ARINC BUSES, PUSH AND RELEASE THE "YES" BUTTON WHEN THE DISPLAY SHOWS THE APPLICABLE MENU: "ARINC BUS A CONFIGURATION ?", "ARINC BUS B CONFIGURATION ?" (SEE SHEET 19).

NOTE: THE MESSAGE "SWITCHING TO SELECTED BUS" WILL SHOW.
IF THE BUS IS BAD, THE MESSAGE "SELECTED BUS IS FAILED" WILL SHOW.

- (A) PUSH AND RELEASE THE "DOWN" BUTTON TO SEE THE ARINC BUS CONFIGURATION DATA.
- (B) CONTINUE TO PUSH AND RELEASE THE "DOWN" BUTTON TO SEE ALL OF THE ARINC DATA.
- (C) MAKE A WRITTEN RECORD OF ALL THE ARINC MESSAGES SHOWN.
- (D) THE ARINC BUS CONFIGURATION DATA MENUS SHOW INPUT/OUTPUT CARD (IOC) 1 DATA AS FOLLOWS (SEE SHEET 19):
 - 1) SOFTWARE VERSION NUMBER AND REVISION NUMBER
 - 2) "AIR" OR "GROUND" A RELAY INDICATION
 - 3) "AIR" OR "GROUND" B RELAY INDICATION
 - 4) SPARE STATUS (THIS INDICATION IS NOT ACTIVE, "ABSENT" SHOWS)
 - 5) "OPEN" OR "CLOSED" FUELING STATION DOOR STATUS
 - 6) ID STATUS INDICATION SHOWS THE INPUT OUTPUT CARD IN USE, "IOC #1" OR "IOC #2"
 - 7) CENTER OVERRIDE PUMP "ON" OR "OFF" INDICATION
 - 8) FLIGHT, REFUEL, SYSTEM TEST INDICATION (0 IS OFF, OR 1 IS ON)
 - 9) SET LEFT, RIGHT, OR CENTER INDICATION (0 IS OFF, OR 1 IS ON).

NOTE: WHEN THE "END OF ARINC CONFIGURATION" MESSAGE SHOWS, ALL THE ARINC CONFIGURATION MESSAGES HAVE SHOWN.

- (E) IF YOU WANT TO SEE MORE SYSTEM CONFIGURATION DATA, PUSH AND RELEASE THE "DOWN" BUTTON TO CONTINUE.
- (F) IF YOU WANT TO GO TO THE TOP OF THE SYSTEM CONFIGURATION MENU, PUSH AND RELEASE THE "MENU" BUTTON.

(CONTINUED ON SHEET 18)

Fuel Quantity BITE Procedure
Figure 104 (Sheet 17)

EFFECTIVITY
GUI 001-114, 116-999


28-41-00
CONFIG 2
Page 135
May 28/06


- (5) IF YOU WANT TO SEE THE DATA FOR THE BITE DISPLAY BOARD, PUSH AND RELEASE THE "YES" BUTTON WHEN THE "BITE DISPLAY BRD CONFIGURATION ?" MENU SHOWS (SEE SHEET 19).
- (A) PUSH AND RELEASE THE "DOWN" BUTTON TO SEE THE BITE DISPLAY BOARD CONFIGURATION DATA.
 - (B) CONTINUE TO PUSH AND RELEASE THE "DOWN" BUTTON WHILE YOU MAKE A WRITTEN RECORD OF ALL THE BDB DATA MESSAGES SHOWN, IF IT IS NECESSARY.
 - (C) THE BITE DISPLAY BOARD CONFIGURATION MENU SHOWS DATA AS FOLLOWS (SEE SHEET 22):
 - 1) SOFTWARE VERSION NUMBER AND REVISION NUMBER SHOW
 - 2) FUEL QUANTITY BITE, SHOWS "NO FAULT" OR "FAULT PRESENT" FOR THE FQIS PROCESSOR DISPLAY BOARD
- NOTE: WHEN THE "END OF BDB CONFIGURATION" MESSAGE SHOWS, ALL OF THE BDB CONFIGURATION MESSAGES ARE SHOWN.
- (D) PUSH AND RELEASE THE "DOWN" BOTTON TO CONTINUE.
- NOTE: THE MESSAGE "END OF SYSTEM CONFIGURATION" WILL SHOW.
- (6) PUSH AND RELEASE THE MENU BUTTON. THIS PUTS YOU AT THE TOP OF THE "SYSTEM CONFIGURATION ?" MENU.

Fuel Quantity BITE Procedure
Figure 104 (Sheet 18)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
CONFIG 2
Page 136
May 28/06


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL
 SYSTEM CONFIGURATION MENU



Fuel Quantity BITE Procedure
Figure 104 (Sheet 19)

EFFECTIVITY
GUI 001-114, 116-999

878439

28-41-00


CONFIG 2

20

Page 137

May 28/06

INDIVIDUAL FUEL QUANTITY CHANNEL CARD (IFQC) DATA




Fuel Quantity BITE Procedure
Figure 104 (Sheet 20)

EFFECTIVITY
GUI 001-114, 116-999

878440

28-41-00
 CONFIG 2
 Page 138
 May 28/06

INPUT/OUTPUT CARD (IOC) DATA



Fuel Quantity BITE Procedure
 Figure 104 (Sheet 21)

EFFECTIVITY
 GUI 001-114, 116-999

878442

28-41-00


CONFIG 2

20

Page 139

May 28/06

BITE DISPLAY BOARD DATA



Fuel Quantity BITE Procedure
Figure 104 (Sheet 22)

EFFECTIVITY
GUI 001-114, 116-999

878444

28-41-00

CONFIG 2
Page 140
May 28/06

H. ERASE HISTORY ?

(1) MAKE SURE THE FQIS PROCESSOR IS ON AND "ERASE FAULT HISTORY ?" SHOWS ON THE MENU DISPLAY (SEE SHEET 24).

NOTE: IF THE FQIS PROCESSOR IS NOT ON, GO TO STEP 3.A.

(2) PUSH AND RELEASE THE "YES" BUTTON TO GO TO THE "ERASE FLIGHT LEG 11-64 ?" DISPLAY.

(3) IF YOU WANT TO STOP THE ERASE PROCEDURE, PUSH AND RELEASE THE "NO" BUTTON GO TO STOP THE "END HISTORY ERASE" MESSAGE.

(4) IF YOU WANT TO ERASE FLIGHT HISTORY, PUSH AND RELEASE THE "YES" BUTTON TO ERASE THE FLIGHT LEGS 11 THRU 64 FAULT MESSAGES.

(5) FOR THE MESSAGE "ARE YOU SURE ?", PUSH AND RELEASE THE "YES" BUTTON TO ERASE THE FLIGHT LEGS 11 THRU 64, OR PUSH AND RELEASE THE "NO" BUTTON TO GO TO THE "END HISTORY ERASE" MESSAGE.

(6) IF YOU DID THE ERASE THE FLIGHT LEGS 11 THRU 64 STEP, THE MESSAGE "ERASE IN PROGRESS" WILL SHOW AND THEN THE MESSAGE "END HISTORY ERASE COMPLETE" WILL SHOW.

(7) WHEN THE "END HISTORY ERASE COMPLETE" MESSAGE SHOWS, PUSH AND RELEASE THE "MENU" BUTTON.

NOTE: THIS PUTS YOU AT THE TOP OF THE "ERASE FAULT HISTORY ?" MENU.

Fuel Quantity BITE Procedure
Figure 104 (Sheet 23)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00


CONFIG 2

Page 141

May 28/06

20

ERASE FAULT HISTORY MENU



Fuel Quantity BITE Procedure
Figure 104 (Sheet 24)

EFFECTIVITY
GUI 001-114, 116-999

878447

28-41-00

CONFIG 2
Page 142
May 28/06

Not Used
Figure 105

EFFECTIVITY
GUI 001-114, 116-999

28-41-00

CONFIG 2
Page 143
May 28/06

20


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL



NO.	FIG.	SHEET	FAULT MESSAGES
1	108	2	** TU ## OPEN LOZ OR HIZ WIRE G##.
2	108	3	** TU ## SHORTED IN TANK G##.
3	108	4	** TU ?? SHORTED IN TANK G##.
4	108	5	** TU ## CONTAMINATED G##.
5	108	6	** TU ## SHORTED TO GROUND G##.
6	108	7	** COMP OPEN LOZ OR HIZ WIRE G##.
7	108	8	** COMP SHORTED IN TANK G##.
8	108	9	** COMPENSATOR CONTAMINATED G##.
9	108	10	** COMP SHORTED TO GROUND G##.
10	108	11	** HIZ WIRE OPEN AT SPAR G##.
11	108	12	** HIZ SHIELD OPEN AT SPAR G##.
12	108	13	** HIZ WIRE OPEN AT PROCESSOR G##.
13	108	14	** HIZ SHIELD OPEN AT PROC G##.
14	108	15	** HIZ WIRE LOW RESISTANCE G##.
15	108	16	** HIZ SHORTED WIRE TO SHLD G##.
16	108	17	** HIZ SHIELD SHORT TO GND G##.
17	108	18	** DENS RESISTOR UNREADABLE G##.
18	108	19	** DENS EXCITA- TION SHORTED G##.
19	108	20	** DENS SENSE WIRE SHORTED G##.
20	108	21	** DENS SENSE OPEN AT SPAR G##.
21	108	22	** DENS SENSE OPEN AT PROC G##.
22	108	23	** DENS CONTAM OR RESISTOR G##.
23	108	24	** DENS SENSOR OR DRIVE WIRE G## (OR) ** DENS SENSOR FAILURE G##.
24	108	25	** IFQC CIRCUIT BOARD FAILED G##.
25	108	26	** IFQC AIR/GND CIRCUIT FAIL G##.
26	108	27	AIR/GROUND INPUT FAILED G##.
27	108	28	LB/KG INPUT WIRE FAILED G##.
28	108	29	** IFQC LB/KG CIRCUIT FAIL G##.
29	108	30	IOC 1 DISCRETE DRIVER FAIL G##.
30	108	30	LOAD SELECT UNIT OR WIRE FAIL G##.
31	108	31	IOC # (1 OR 2) FAILED G##.
32	108	31	VOLUME SHUTOFF OF ** AT 95% G##.
33	108	32	VOLUME SHUTOFF OF ** AT 87% G##.
34	108	33	BITE DISPLAY BOARD FAILED G##.
35	108	34	(THE BITE DISPLAY BOARD IS NOT ON)
36	108	35	ARINC BUS (A OR B) FAILED G##.
37	108	36	** TU ?? SHORTED TO GROUND G##.

Fault Message Reference Chart
Figure 106




EFFECTIVITY
GUI 001-114, 116-999

28-41-00
 CONFIG 2
 Page 144
 May 28/06








 **BOEING**
757
FAULT ISOLATION/MAINT MANUAL

FQIS PROCESSOR CONNECTOR PINS		EE BAY RACK CONNECTOR D42226 PINS		HI-Z/LO-Z CONNECTOR (FRONT SPAR) D6888 PINS		COMPONENT	EQUIPMENT NO.	ACCESS DOOR
D2440B	D2440C	LO-Z	HI-Z	LO-Z	HI-Z			
LO-Z	HI-Z							
								
F10	E6	9	1	9	1	COMPENSATOR	TS5010	631AB
E10	E6	7	1	3	1	TANK UNIT NO. 6	TS5016	631AB
D11	E6	4	1	4	1	TANK UNIT NO. 7	TS5017	631AB
E11	E6	5	1	5	1	TANK UNIT NO. 8	TS5075	631BB
F11	E6	6	1	6	1	TANK UNIT NO. 9	TS5076	631CB

RIGHT CENTER FUEL TANK (WDM 28-41-41)

FQIS PROCESSOR CONNECTOR PINS		EE BAY RACK CONNECTOR D42224 PINS		HI-Z/LO-Z CONNECTOR (FRONT SPAR) D6892 PINS		COMPONENT	EQUIPMENT NO.	ACCESS DOOR
D2440A	D2440C	LO-Z	HI-Z	LO-Z	HI-Z			
LO-Z	HI-Z							
								
D10	B6	8	1	3	1	TANK UNIT NO. 1	TS5011	134AZ
E10	B6	4	1	4	1	TANK UNIT NO. 2	TS5012	531AB
D11	B6	5	1	5	1	TANK UNIT NO. 3	TS5013	531AB
E11	B6	6	1	6	1	TANK UNIT NO. 4	TS5014	531BB
D10		7	1	7	1	TANK UNIT NO. 5	TS5015	531CB

LEFT CENTER FUEL TANK (WDM 28-41-41)



-  THE PIN NUMBER E6 IS FOR THE HI-Z CENTER CONDUCTOR ONLY. THE HI-Z SHIELD PINS ARE D5 AND F7 (WDM 28-41-41).
-  THE PIN NUMBER 1 IS FOR THE HI-Z CENTER CONDUCTOR ONLY. THE HI-Z SHIELD PIN IS C1 (WDM 28-41-41).
-  THE PIN NUMBER 1 IS FOR THE HI-Z CENTER CONDUCTOR ONLY. THE HI-Z SHIELD PIN IS C1 (WDM 28-41-41).
-  THE PIN NUMBER 6B IS FOR THE HI-Z CENTER CONDUCTOR ONLY. THE HI-Z SHIELD PINS ARE A5 AND F7 (WDM 28-41-41).
-  THE PIN NUMBER 1 IS FOR THE HI-Z CENTER CONDUCTOR ONLY. THE HI-Z SHIELD PIN IS C1 (WDM 28-41-41).
-  THE PIN NUMBER 1 IS FOR THE HI-Z CENTER CONDUCTOR ONLY. THE HI-Z SHIELD PIN IS C1 (WDM 28-41-41).
-  THIS PIN (PIN NUMBER D10) IS ON CONNECTOR D2440B.

Left, Center and Right Center Fuel Tank Wiring
FQIS Wiring
Figure 107 (Sheet 1)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
CONFIG 2
Page 145
May 28/06

 **BOEING**
757
FAULT ISOLATION/MAINT MANUAL

FQIS PROCESSOR CONNECTOR D2440A PINS	EE BAY RACK CONNECTOR D41276 PINS	HOT SHORT PROTECTOR CONNECTOR D11720 PINS 	HOT SHORT PROTECTOR CONNECTOR D11718 PINS 	DENSITOMETER CONNECTOR (REAR SPAR) D6890 PINS	COMPONENT	EQUIPMENT NO.	ACCESS DOOR
					DENSITOMETER	M10903	631AB
J9	11	1	1	1	SENSE		
K10	14	3, 8	3, 8	C1	SHIELD		
H10	12	15	15	2	DRIVE (POSITIVE)		
J10	13	11	11	3	DRIVE (NEGATIVE)		
G9	16	12	12	6	KR0		
G10	17	13	13	7	KR1		
G11	18	14	14	8	KR2		
G12	19	5	5	9	KR3		

CENTER TANK DENSITOMETER (WDM 28-41-41, -51)




 AIRPLANES POST-SB 28A0085

Center Tank Densitometer Wiring
FQIS Wiring
Figure 107 (Sheet 2)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
CONFIG 2
Page 146
May 28/06




 **BOEING**
757
FAULT ISOLATION/MAINT MANUAL

FQIS PROCESSOR CONNECTOR PINS		EE BAY RACK CONNECTOR D42226 PINS		HI-Z/LO-Z CONNECTOR (FRONT SPAR) D6884 PINS		COMPONENT	EQUIPMENT NO.	ACCESS DOOR
D2440B	D2440C	LO-Z	HI-Z	LO-Z	HI-Z			
LO-Z	HI-Z 	LO-Z	HI-Z 	LO-Z	HI-Z 			
E4	J2	17	1	17	1	COMPENSATOR	TS119	641AB
C1	J2	3	1	3	1	TANK UNIT NO. 1	TS146	641AB
D1	J2	4	1	4	1	TANK UNIT NO. 2	TS147	641BB
E1	J2	5	1	5	1	TANK UNIT NO. 3	TS148	641CB
F1	J2	6	1	6	1	TANK UNIT NO. 4	TS149	641DB
C2	J2	7	1	7	1	TANK UNIT NO. 5	TS150	641FB
D2	J2	8	1	8	1	TANK UNIT NO. 6	TS151	641GB
E2	J2	9	1	9	1	TANK UNIT NO. 7	TS152	641HB
F2	J2	10	1	10	1	TANK UNIT NO. 8	TS153	641JB
C3	J2	11	1	11	1	TANK UNIT NO. 9	TS154	641LB
D3	J2	12	1	12	1	TANK UNIT NO. 10	TS155	641MB
E3	J2	13	1	13	1	TANK UNIT NO. 11	TS5198	642AB
F3	J2	14	1	14	1	TANK UNIT NO. 12	TS5199	642CB

RIGHT MAIN FUEL FUEL TANK (WDM 28-41-31)

FQIS PROCESSOR CONNECTOR D2440B PINS	EE BAY RACK CONNECTOR D41276 PINS	DENSITO- METER CONNECTOR (REAR SPAR) D6886 PINS	COMPONENT	EQUIPMENT NO.	ACCESS DOOR
			DENSITOMETER	M10902	641AB
D7	1	1	SENSE		
E6	4	C1	SHIELD		
D6	2	2	DRIVE (POSITIVE)		
E5	3	3	DRIVE (NEGATIVE)		
A5	6	6	KR0		
B5	7	7	KR1		
C5	8	8	KR2		
D5	9	9	KR3		

RIGHT MAIN FUEL TANK DENSITOMETER (WDM 28-41-31,-51)

-  THE PIN NUMBER J2 IS FOR THE HI-Z CENTER CONDUCTOR ONLY. THE HI-Z SHIELD PINS ARE H1 AND K3 (WDM 28-41-31).
-  THE PIN NUMBER 1 IS FOR THE HI-Z CENTER CONDUCTOR ONLY. THE HI-Z SHIELD PIN IS C1 (WDM 28-41-31).
-  THE PIN NUMBER 1 IS FOR THE HI-Z CENTER CONDUCTOR ONLY. THE HI-Z SHIELD PIN IS C1 (WDM 28-41-31).

Right Main Fuel Tank Wiring
FQIS Wiring
Figure 107 (Sheet 3)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
CONFIG 2
Page 147
Sep 28/07

 **BOEING**
757
FAULT ISOLATION/MAINT MANUAL

FQIS PROCESSOR CONNECTOR PINS		EE BAY RACK CONNECTOR PINS		HI-Z/LO-Z CONNECTOR (FRONT SPAR) D6880 PINS		COMPONENT	EQUIPMENT NO.	ACCESS DOOR
D2440A	D2440C	D41268	D42220	LO-Z	HI-Z			
L0-Z	HI-Z 11	L0-Z	HI-Z 12	L0-Z	HI-Z 13			
E4	B2	17	1	17	1	COMPENSATOR	TS108	541AB
C1	B2	3	1	3	1	TANK UNIT NO. 1	TS109	541AB
D1	B2	4	1	4	1	TANK UNIT NO. 2	TS110	541BB
E1	B2	5	1	5	1	TANK UNIT NO. 3	TS111	541CB
F1	B2	6	1	6	1	TANK UNIT NO. 4	TS112	541DB
C2	B2	7	1	7	1	TANK UNIT NO. 5	TS113	541FB
D2	B2	8	1	8	1	TANK UNIT NO. 6	TS114	541GB
E2	B2	9	1	9	1	TANK UNIT NO. 7	TS115	541HB
F2	B2	10	1	10	1	TANK UNIT NO. 8	TS116	541JB
C3	B2	11	1	11	1	TANK UNIT NO. 9	TS117	541LB
D3	B2	12	1	12	1	TANK UNIT NO. 10	TS118	541MB
E3	B2	13	1	13	1	TANK UNIT NO. 11	TS5196	542AB
F3	B2	14	1	14	1	TANK UNIT NO. 12	TS5197	542CB

LEFT MAIN FUEL TANK (WDM 28-41-21)

FQIS PROCESSOR CONNECTOR D2440A PINS	EE BAY RACK CONNECTOR D41272 PINS	DENSITO-METER CONNECTOR (REAR SPAR) D6882 PINS	COMPONENT	EQUIPMENT NO.	ACCESS DOOR
			DENSITOMETER	M10901	541AB
B6	1	1	SENSE		
A6	4	C1	SHIELD		
A5	2	2	DRIVE (POSITIVE)		
B5	3	3	DRIVE (NEGATIVE)		
C5	6	6	KR0		
D5	7	7	KR1		
E5	8	8	KR2		
D6	9	9	KR3		

LEFT MAIN FUEL TANK DENSITOMETER (WDM 28-41-21,-51)

- 11 THE PIN NUMBER B2 IS FOR THE HI-Z CENTER CONDUCTOR ONLY. THE HI-Z SHIELD PINS ARE A1 AND C3 (WDM 28-41-21).
- 12 THE PIN NUMBER 1 IS FOR THE HI-Z CENTER CONDUCTOR ONLY. THE HI-Z SHIELD PIN IS C1 (WDM 28-41-21).
- 13 THE PIN NUMBER 1 IS FOR THE HI-Z CENTER CONDUCTOR ONLY. THE HI-Z SHIELD PIN IS C1 (WDM 28-41-21).

Left Main Fuel Tank Wiring
FQIS Wiring
Figure 107 (Sheet 4)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
CONFIG 2
Page 148
May 28/06

** FAULT ## MESSAGE G##.	EXAMPLE
<p>THIS BLOCK SHOWS THE EXACT FAULT MESSAGE THAT SHOWS ON THE FQIS PROCESSOR DISPLAY. THERE ARE ABBREVIATIONS USED IN THE FAULT MESSAGES BECAUSE OF THE LIMITS ON THE DISPLAY. THE FUEL TANK AND COMPONENT INDICATIONS ARE SHOWN AS FOLLOWS:</p> <p>"**" SHOWS THE FUEL TANK THAT THE FAULT MESSAGE IS FOR AS FOLLOWS:</p> <p style="margin-left: 20px;"> ** - "LM" LEFT MAIN FUEL TANK ** - "RM" RIGHT MAIN FUEL TANK ** - "CT" CENTER FUEL TANK </p> <p>"##" THIS PLACE HOLDER SHOWS THE NUMERICAL INDICATION FOR TANK UNIT, OR OTHER NUMERICAL IDENTIFICATION. AN EXAMPLE IS AS FOLLOWS:</p> <p style="margin-left: 20px;"> ## - "1" INDICATION FOR NUMBER 1 TANK UNIT ## - "2" INDICATION FOR NUMBER 2 TANK UNIT ## - "3" INDICATION FOR NUMBER 3 TANK UNIT . . . ## - "12" INDICATION FOR NUMBER 12 TANK UNIT </p> <p>"G##" - THIS PLACE HOLDER INDICATION SHOWS IF THE FIRST APPLICABLE FAULT MESSAGE OCCURRED IN THE GROUND "G" MODE, OR IN THE AIR "A" MODE. THE "###" PLACE HOLDER INDICATION SHOWS HOW MANY TIMES THE FAULT OCCURRED DURING THE APPLICABLE FLIGHT LEG.</p> <p><u>NOTE:</u> THE "###" INDICATION WILL SHOW THE NUMBER OF TIMES THE FAULT OCCURRED AS FOLLOWS:</p> <p style="margin-left: 20px;"> FAULTS 1-9, WILL SHOW AS 1-9 FAULTS 10-18, WILL SHOW AS 9 FAULTS 19-28, WILL SHOW AS 19 FAULTS 29-38, WILL SHOW AS 29 FAULTS 39-48, WILL SHOW AS 39 . . . FAULTS 89-98, WILL SHOW AS 89 FAULT 99, WILL SHOW AS 99 </p>	
FAULT CONDITION	
THIS BLOCK EXPLAINS THE FQIS SYSTEM FAULT CONDITIONS.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
- THIS BLOCK SHOWS THE POSSIBLE FLIGHT COMPARTMENT OR AIRPLANE INDICATIONS THAT WILL OCCUR BECAUSE OF THE FAULT MESSAGE SHOWN ABOVE.	
CORRECTION	
THIS BLOCK SHOWS THE STEPS TO CORRECT THE FAULT MESSAGE SHOWN ABOVE.	

Fault Messages
Figure 108 (Sheet 1)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
 CONFIG 2
 Page 149
 May 28/06


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	1
<p>** TU ## OPEN LOZ OR HIZ WIRE G##.</p>	
FAULT CONDITION	
<p>THIS FAULT MESSAGE SHOWS IF THE APPLICABLE TANK UNIT CAPACITANCE IS LESS THAN THE CAPACITANCE FOR AN EMPTY FUEL TANK, AND THERE ARE NO OTHER FAULTS IN THE SYSTEM.</p>	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - NORMAL IS POSSIBLE, WHEN ONLY ONE "*** TU ## OPEN LOZ OR HIZ WIRE G ##" FAULT MESSAGE SHOWS. WHEN YOU FUEL THE AIRPLANE THE VOLUME TOP-OFF (VTO) MECHANISM CAN STOP FUELING AT 5% LESS THAN FULL (SEE FAULT MESSAGE 32). - THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" SHOWS - THE FUEL QUANTITY INDICATION CAN GO OFF FOR THE APPLICABLE FUEL TANK, AND THE TOTAL FUEL QUANTITY INDICATION CAN GO OFF (FUEL QTY IND, M10054), AND THE EICAS STATUS MESSAGE "FUEL QTY IND" CAN SHOW. - WHILE FUELING, THE FUELING SHUTOFF VALVES CAN CLOSE FOR THE APPLICABLE FUEL TANK. THE "PUSH SET" MESSAGE CAN SHOW ON THE LSI ON THE FUELING CONTROL PANEL, P28, REFER TO AMM 12-11-01/301 TO CONTINUE FUELING. THE FUEL QUANTITY INDICATOR, M10054, WILL ALSO GO OFF. 	
CORRECTION	
<ol style="list-style-type: none"> 1. EXAMINE THE APPLICABLE CONNECTORS AND PINS FOR CORROSION OR DAMAGE TO THE PINS, SEE FIG. 107. 2. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 3. IF THE PROBLEM CONTINUES, FIND THE OPEN WIRE BETWEEN THE FQIS PROCESSOR AND THE FUEL TANK. 4. MEASURE THE CAPACITANCE OF THE APPLICABLE TANK UNIT AT THE TANK WALL (SPAR) CONNECTOR, SEE FIG. 109. 5. IF THE CAPACITANCE OF THE TANK UNIT IS ZERO, THE OPEN WIRE IS ON THE TANK WIRE HARNESS. <ol style="list-style-type: none"> A. GO INTO THE APPLICABLE FUEL TANK AND EXAMINE THE LO-Z/HI-Z CONNECTIONS AT THE TANK UNIT. 6. IF THE MEASURED CAPACITANCE IS OK, THE PROBLEM IS IN THE AIRPLANE WIRE HARNESS. 7. REPLACE OR REPAIR THE APPLICABLE HI-Z/LO-Z WIRE HARNESS (WDM 28-41-21,-31,-41). 8. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
 Figure 108 (Sheet 2)

EFFECTIVITY
 GUI 001-114, 116-999

28-41-00
 CONFIG 2
 Page 150
 May 28/06


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	2
** TU ## SHORTED IN TANK G##.	
FAULT CONDITION	
LESS THAN NORMAL RESISTANCE IS MEASURED FROM THE INNER TUBE OF THE TANK UNIT TO THE OUTER TUBE OF THE TANK UNIT.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" SHOWS. - THE FUEL QUANTITY INDICATION WILL GO OFF FOR THE APPLICABLE FUEL TANK, THE TOTAL FUEL QUANTITY INDICATION WILL GO OFF (FUEL QTY IND, M10054), AND THE EICAS STATUS MESSAGE "FUEL QTY IND" SHOWS. - WHILE FUELING, THE FUELING SHUTOFF VALVE CLOSES FOR THE APPLICABLE FUEL TANK. THE "PUSH SET" MESSAGE WILL SHOW ON THE LSI ON THE FUELING CONTROL PANEL, P28, REFER TO AMM 12-11-01/301 TO CONTINUE FUELING. THE FUEL QUANTITY INDICATOR FOR THE APPLICABLE FUEL TANK, M10054, WILL ALSO GO OFF. 	
CORRECTION	
<ol style="list-style-type: none"> 1. EXAMINE THE APPLICABLE SPAR CONNECTOR FOR CONDUCTIVE MATERIAL BETWEEN THE HI-Z AND LO-Z TERMINALS. 2. IF THE PROBLEM CONTINUES, DEFUEL THE APPLICABLE FUEL TANK (AMM 28-26-00/201). 3. USE THE SUMP TO REMOVE ALL THE REMAINING FUEL FROM THE APPLICABLE FUEL TANK, (AMM 12-11-03/301). 4. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 5. IF THE PROBLEM CONTINUES TO SHOW, GO INTO THE FUEL TANK AND EXAMINE THE APPLICABLE TANK UNIT FOR CONTAMINATION OR CONDUCTIVE MATERIAL IN THE TANK UNIT OR TERMINAL BLOCK (AMM 28-11-00/201). 6. REPLACE THE APPLICABLE TANK UNIT (AMM 28-41-01/401). 7. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
Figure 108 (Sheet 3)

EFFECTIVITY
GUI 001-114, 116-999

896415

20

28-41-00
 CONFIG 2
 Page 151
 May 28/06


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	3
** TU ?? SHORTED IN TANK G##.	
FAULT CONDITION	
THE RESISTANCE MEASURED FROM THE INNER TUBE OF A TANK UNIT OR THE COMPENSATOR TO THE OUTER TUBE OF THE TANK UNIT IS VERY LOW. WITH THIS FAULT THE PROCESSOR CANNOT ISOLATE THE FAILED TANK UNIT OR COMPENSATOR.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" WILL SHOW. - THE FUEL QUANTITY INDICATION WILL GO OFF FOR THE APPLICABLE FUEL TANK, THE TOTAL FUEL QUANTITY INDICATION WILL GO OFF (FUEL QTY IND, M10054), AND THE EICAS STATUS MESSAGE "FUEL QTY IND" SHOWS. - WHILE FUELING, THE FUELING SHUTOFF VALVE CLOSES FOR THE APPLICABLE FUEL TANK. THE "PUSH SET" MESSAGE WILL SHOW ON THE LSI ON THE FUELING CONTROL PANEL, P28, REFER TO AMM 12-11-01/301 TO CONTINUE FUELING. THE FUEL QUANTITY INDICATOR, M10054, WILL ALSO GO OFF FOR THE APPLICABLE FUEL TANK. 	
CORRECTION	
<ol style="list-style-type: none"> 1. GO TO THE "SYSTEM DATA?" MENU AND LOOK AT THE CAPACITANCE VALUES FOR THE TANK UNITS IN THE APPLICABLE FUEL TANK. 2. FIND THE TANK UNIT CAPACITANCE VALUE THAT IS 0.0, OR APPROXIMATELY 0.0 (FIG. 104, FIG. 109). <ol style="list-style-type: none"> A. IF A PROBLEM AT THE TANK UNIT OR SPAR CONNECTOR CANNOT BE FOUND, DO THE TEST: DRY CAPACITANCE TEST IN THE MAIN EQUIPMENT CENTER WITH THE 757/767-1 TEST BOX BOX (FIG. 109). 3. REPLACE THE APPLICABLE TANK UNIT (AMM 28-41-01/401). 4. IF THE PROBLEM CONTINUES, REPLACE THE APPLICABLE TANK WIRING HARNESS (AMM 28-41-04/401). 5. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
Figure 108 (Sheet 4)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
 CONFIG 2
 Page 152
 May 28/06

FAULT MESSAGE	4
** TU ## CONTAMINATED G##.	
FAULT CONDITION	
THERE IS CONTAMINATION BETWEEN THE INNER AND OUTER TUBES OF THE TANK UNIT THAT CAUSES A RESISTANCE LESS THAN THE USUAL RESISTANCE, OR THE CAPACITANCE MEASURED FOR THE TANK UNIT IS A MINIMUM OF 105% OF THE FULL VALUE, OR THERE IS A HI-Z SHIELD OPEN IN THE FUEL TANK. THERE CAN BE MORE THAN ONE TANK UNIT CONTAMINATION MESSAGE.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - NORMAL INDICATION WITH AN INDICATION ERROR FOR FUEL QUANTITY OF $\pm 5\%$ FOR THE APPLICABLE TANK (ONLY ONE TANK UNIT IS FAULTED). - THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" CAN SHOW. - IF THERE IS MORE THAN ONE CONTAMINATED TANK UNIT, OR THE HIGHEST TANK UNIT IN THE FUEL TANK IS CONTAMINATED, THE FUEL QUANTITY INDICATION WILL GO OFF (FUEL QTY IND, M10054), AND THE EICAS STATUS MESSAGE "FUEL QTY IND" SHOWS. - IF THERE IS MORE THAN ONE CONTAMINATED TANK UNIT (OR THE HIGHEST TANK UNIT IN THE FUEL TANK IS CONTAMINATED, WHILE FUELING, THE FUELING SHUTOFF VALVE WILL CLOSE FOR THE APPLICABLE FUEL TANK. THE "PUSH SET" MESSAGE WILL SHOW ON THE LSI ON THE FUELING CONTROL PANEL, P28, REFER TO AMM 12-11-01/301 TO CONTINUE FUELING. THE FUEL QUANTITY INDICATOR FOR THE APPLICABLE TANK, M10054, WILL ALSO GO OFF. 	
CORRECTION	
<ol style="list-style-type: none"> 1. DEFUEL THE APPLICABLE FUEL TANK (AMM 28-26-00/201). 2. DRAIN THE APPLICABLE FUEL TANK SUMP (AMM 12-11-03/301). 3. DO THE DRY CAPACITANCE TEST, FIG. 109. 4. MAKE SURE THE TANK UNIT CAPACITANCE VALUES ARE IN THE LIMITS ON FIG. 109. IF ALL THE TANK UNIT CAPACITANCE VALUES ARE IN THE LIMITS ON FIG. 109, GO TO STEP 8. 5. IF ONE OF THE TANK UNITS IS NOT IN THE LIMITS ON FIG. 109, REPLACE THE APPLICABLE TANK UNIT THAT SHOWS IN THE FAULT MESSAGE ON THE FQIS PROCESSOR DISPLAY (AMM 28-41-01/401). 6. IF MORE THAN ONE OF THE TANKS CAPACITANCE VALUES ARE NOT IN THE LIMITS ON FIG. 109, EXAMINE THE HI-Z SHIELD CONNECTIONS AT THE TANK UNIT AND REPLACE THE APPLICABLE FUEL TANK WIRING HARNESS (AMM 28-41-09/401). 7. IF THE PROBLEM CONTINUES, REPLACE THE APPLICABLE WIRE HARNESS (AMM 28-41-09/401). 8. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
Figure 108 (Sheet 5)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
 CONFIG 2
 Page 153
 May 28/06


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	5
** TU ## SHORTED TO GROUND G##.	
FAULT CONDITION	
THE APPLICABLE TANK UNIT OR LO-Z WIRE IS SHORTED TO GROUND.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - NORMAL OPERATION WITH AN INDICATION ERROR FOR FUEL QUANTITY OF $\pm 5\%$ FOR THE APPLICABLE TANK (ONLY ONE TANK UNIT CAN BE BAD). - THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" CAN SHOW. - IF THERE IS MORE THAN ONE ELECTRICAL SHORT THE FUEL QUANTITY INDICATION WILL GO OFF FOR THE APPLICABLE FUEL TANK, THE TOTAL FUEL QUANTITY INDICATION WILL GO OFF (FUEL QTY IND, M10054), AND THE EICAS STATUS MESSAGE "FUEL QTY IND" SHOWS. - IF THERE IS MORE THAN ONE ELECTRICAL SHORT WHILE FUELING, THE FUELING SHUTOFF VALVE CLOSES FOR THE APPLICABLE FUEL TANK. THE "PUSH SET" MESSAGE WILL SHOW ON THE FUEL QUANTITY INDICATORS ON THE FUELING CONTROL PANEL, P28, REFER TO AMM 12-11-01/301 TO CONTINUE FUELING. THE FUEL QUANTITY INDICATOR, M10054, WILL ALSO GO OFF. 	
CORRECTION	
<ol style="list-style-type: none"> 1. OPEN THE HI-Z/LO-Z CONNECTOR FOR THE APPLICABLE FUEL TANK, SEE FIG. 107. 2. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?" 3. IF THE FAULT MESSAGE CONTINUES TO SHOW WHEN THE HI-Z/LO-Z CONNECTOR IS OPEN, THEN THE PROBLEM IS BETWEEN THE FQIS PROCESSOR AND THE HI-Z/LO-Z CONNECTOR AT THE FRONT SPAR. <ul style="list-style-type: none"> <u>NOTE:</u> THE OTHER TANK UNITS AND COMPENSATOR WILL SHOW THE OPEN LO-Z OR HI-Z FAULT MESSAGE AND THE OPEN HI-Z AT SPAR FAULT MESSAGE WILL SHOW, WHEN THE SPAR CONNECTOR IS OPEN. IGNORE THESE OPEN FAULT MESSAGES. 4. EXAMINE THE WIRING TO FIND THE TANK UNIT LO-Z SHORT TO GROUND AND REPAIR OR REPLACE THE APPLICABLE WIRING (WDM 28-41-21,-31,-41). 5. IF THE PROBLEM GOES AWAY THE SHORTED CIRCUIT IS IN THE FUEL TANK. 6. GO INTO THE APPLICABLE FUEL TANK (AMM 28-11-00/201). <ul style="list-style-type: none"> <u>NOTE:</u> THE OTHER TANK UNITS AND COMPENSATOR WILL SHOW THE OPEN LO-Z OR HI-Z FAULT MESSAGE AND THE OPEN HI-Z AT SPAR FAULT MESSAGE WILL SHOW, WHEN THE SPAR CONNECTOR IS OPEN. IGNORE THESE OPEN FAULT MESSAGES. 7. EXAMINE AND REPLACE THE APPLICABLE TANK UNIT (AMM 28-41-01/401). <ul style="list-style-type: none"> <u>NOTE:</u> MAKE SURE THE TANK UNIT HAS CLEARANCE FROM THE AIRPLANE STRUCTURE. 8. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 9. IF THE PROBLEM CONTINUES, EXAMINE AND REPLACE THE TANK WIRING HARNESS (WDM 28-41-21,-31,-41). 10. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
Figure 108 (Sheet 6)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
 CONFIG 2
 Page 154
 May 28/06


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	6
** COMP OPEN LOZ OR HIZ WIRE G##.	
FAULT CONDITION	
THIS MESSAGE IS SENT IF THE MEASURED CAPACITANCE OF THE APPLICABLE TANK UNIT IS BELOW THE MINIMUM VALUE SEE FIG. 108, AND THERE ARE NO OTHER FAULTS.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - NORMAL OPERATION WITH AN INDICATION ERROR FOR FUEL QUANTITY OF $\pm 5\%$ FOR THE APPLICABLE TANK (ONLY ONE TANK UNIT CAN BE BAD). - THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" CAN SHOW. - THE FUEL OPERATION CAN STOP AT 5% OR 13% LESS THAN THE VOLUMETRIC SHUTOFF (VSO) POINT TO PREVENT A FUEL SPILL. 	
CORRECTION	
<ol style="list-style-type: none"> 1. EXAMINE AND CLEAN THE APPLICABLE CONNECTORS, SEE FIG. 107. 2. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?", TO SEE IF THE FAULT MESSAGES CONTINUES TO SHOW. 3. IF THE PROBLEM CONTINUES, FIND THE OPEN WIRE BETWEEN THE FQIS PROCESSOR AND THE FUEL TANK. 4. MEASURE THE CAPACITANCE OF THE APPLICABLE COMPENSATOR AT THE TANK WALL (SPAR) CONNECTOR, SEE FIG. 107. 5. IF THE CAPACITANCE OF THE COMPENSATOR IS ZERO, THE OPEN WIRE IS ON THE TANK WIRE HARNESS. <ol style="list-style-type: none"> A. GO INTO THE APPLICABLE FUEL TANK AND EXAMINE THE LO-Z/HI-Z CONNECTIONS AT THE COMPENSATOR. 6. IF THE MEASURED CAPACITANCE IS OK, THE PROBLEM IS IN THE AIRPLANE WIRE HARNESS. 7. REPLACE OR REPAIR THE APPLICABLE HI-Z/LO-Z WIRE HARNESS (WDM 28-41-21,-31,-41). 8. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
Figure 108 (Sheet 7)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
 CONFIG 2
 Page 155
 May 28/06


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	7
<p>** COMP SHORTED IN TANK G##.</p>	
FAULT CONDITION	
<p>THERE IS LESS THAN 10,000 OHMS OF RESISTANCE BETWEEN THE INNER AND OUTER TUBES OF THE APPLICABLE TANK UNIT.</p>	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<p>- THE FUEL QUANTITY INDICATION WILL GO OFF FOR THE APPLICABLE FUEL TANK, THE TOTAL FUEL QUANTITY INDICATION WILL GO OFF (FUEL QTY IND, M10054), AND THE EICAS STATUS MESSAGE "FUEL QTY IND" SHOWS.</p> <p>- WHILE FUELING, THE FUELING SHUTOFF VALVE CLOSES FOR THE APPLICABLE FUEL TANK. THE "PUSH SET" MESSAGE WILL SHOW ON THE FUEL QUANTITY INDICATORS ON THE FUELING CONTROL PANEL, P28, REFER TO AMM 12-11-01/301 TO CONTINUE FUELING. THE FUEL QUANTITY INDICATOR, M10054, WILL ALSO GO OFF.</p>	
CORRECTION	
<ol style="list-style-type: none"> 1. DEFUEL THE APPLICABLE FUEL TANK (AMM 28-26-00/201). 2. DRAIN THE APPLICABLE FUEL TANK SUMP (AMM 12-11-03/301). 3. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?" 4. IF THE PROBLEM CONTINUES, EXAMINE THE APPLICABLE COMPENSATOR AND TERMINAL BLOCK FOR CONTAMINATION. <p style="margin-left: 20px;"><u>NOTE:</u> MAKE SURE THE COMPENSATOR HAS CLEARANCE WITH THE AIRPLANE STRUCTURE.</p> <ol style="list-style-type: none"> 5. REPLACE THE APPLICABLE COMPENSATOR IF IT IS NECESSARY (AMM 28-41-02/401). 6. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?" 	

Fault Messages
Figure 108 (Sheet 8)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
 CONFIG 2
 Page 156
 May 28/06


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	8
** COMPENSATOR CONTAMINATED G##.	
FAULT CONDITION	
THE COMPENSATOR OR DENSITOMETER IS BAD; OR BOTH THE COMPENSATOR AND DENSITOMETER ARE BAD.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
- THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" SHOWS.	
CORRECTION	
<ol style="list-style-type: none"> 1. DEFUEL THE APPLICABLE FUEL TANK (AMM 28-26-00/201). 2. DRAIN THE APPLICABLE FUEL TANK SUMP (AMM 12-11-03/301). 3. DO THE DRY CAPACITANCE TEST, FIG. 109. 4. IF THE FAULT CONTINUES TO SHOW, DISCONNECT THE APPLICABLE SPAR CONNECTOR AND EXAMINE IT FOR DAMAGE OR CONTAMINATION. 5. REPAIR OR REPLACE THE WIRE HARNESS IF IT IS NECESSARY (WDM 28-41-21,-31,-41). 6. IF THE PROBLEM CONTINUES, MEASURE THE RESISTANCE BETWEEN THE APPLICABLE HI-Z SHIELD AND AIRPLANE GROUND ON THE AIRPLANE WIRE HARNESS (AMM 28-41-00/501). 7. IF THE MEASURED RESISTANCE IS MORE THAN 7 OHMS, EXAMINE THE HI-Z SHIELD CONNECTIONS BETWEEN THE SPAR AND THE PROCESSOR (SEE FIG. 107). 8. IF THE PROBLEM CONTINUES, YOU MUST GO INTO THE FUEL TANK (AMM 28-11-00/201). 9. EXAMINE THE FUEL TANK FOR WATER, MICROBIAL GROWTH, OR OTHER CONTAMINANTS NEAR THE COMPENSATOR. 10. IF THERE IS NO CONTAMINATION, THEN DO A RESISTANCE TEST TO MAKE SURE THE HI-Z SHIELD RESISTANCE IS LESS THAN 1 OHM BETWEEN THE COMPENSATOR AND THE HI-Z SHIELD CONTACT AT THE SPAR CONNECTOR. 11. IF THE SHIELD RESISTANCE IS OK, REPLACE THE COMPENSATOR (AMM 28-41-02/401). 12. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
Figure 108 (Sheet 9)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
 CONFIG 2
 Page 157
 May 28/06


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	9
** COMP SHORTED TO GROUND G##.	
FAULT CONDITION	
THE APPLICABLE TANK UNIT OUTER TUBE OR LO-Z WIRE IS SHORTED TO GROUND.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - NORMAL OPERATION WITH AN INDICATION ERROR FOR FUEL QUANTITY OF $\pm 5\%$ FOR THE APPLICABLE TANK (ONLY ONE TANK UNIT CAN BE BAD). - THE FUEL OPERATION CAN STOP AT 5% OR 13% LESS THAN THE VOLUMETRIC SHUTOFF (VSO) POINT TO PREVENT A FUEL SPILL. - THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" SHOWS 	
CORRECTION	
<ol style="list-style-type: none"> 1. OPEN THE APPLICABLE HI-Z/LO-Z CONNECTOR (FIG. 107). 2. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?" <u>NOTE:</u> WHEN YOU OPEN THE SPAR CONNECTOR, "OPEN" FAULT MESSAGES WILL SHOW. IGNORE THESE "OPEN" FAULT MESSAGES. 3. IF THE FAULT MESSAGE CONTINUES TO SHOW, FOR THE APPLICABLE COMPENSATOR, THE FAILURE IS BETWEEN THE APPLICABLE HI-Z/LO-Z CONNECTOR AND THE FQIS PROCESSOR (M121), GO TO STEP 5. <u>NOTE:</u> ALL THE TANK UNITS WILL SHOW THE FAULT MESSAGES OPEN LO-Z OR HI-Z WIRE WHEN YOU OPEN THE SPAR CONNECTOR. IGNORE THESE OPEN FAULT MESSAGES. 4. IF THE FAULT MESSAGE DOES NOT SHOW AFTER STEP 2, THE PROBLEM IS IN THE FUEL TANK, GO TO STEP 6. 5. FIND THE SHORTED COMPENSATOR LO-Z WIRE. REPAIR OR REPLACE THE WIRE AS NECESSARY (WDM 28-41-21,-31,-41). 6. EXAMINE AND REPLACE THE APPLICABLE COMPENSATOR (AMM 28-41-02/401). <u>NOTE:</u> MAKE SURE THE COMPENSATOR HAS CLEARANCE FROM THE AIRPLANE STRUCTURE. 7. IF THE PROBLEM CONTINUES, EXAMINE AND REPLACE THE APPLICABLE TANK WIRING HARNESS (WDM 28-41-21,-31,-41). 8. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
Figure 108 (Sheet 10)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
 CONFIG 2
 Page 158
 May 28/06


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	10
<p>** HIZ WIRE OPEN AT SPAR G##.</p>	
FAULT CONDITION	
<p>THIS MESSAGE SHOWS IF THERE IS AN OPEN IN THE CENTER CONDUCTOR OF THE HI-Z WIRE. THE OPEN WIRE IS USUALLY NEAR THE APPLICABLE HI-Z/LO-Z CONNECTOR. THIS INCLUDES THE POINTS BETWEEN A POINT HALF THE DISTANCE BETWEEN THE FQIS PROCESSOR AND THE HI-Z/LO-Z CONNECTOR, AND A POINT HALF THE DISTANCE BETWEEN THE HI-Z/LO-Z CONNECTOR AND THE FIRST TANK SENSOR.</p>	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - THE FUEL QUANTITY INDICATION WILL GO OFF FOR THE APPLICABLE FUEL TANK, THE TOTAL FUEL QUANTITY INDICATION WILL GO OFF (FUEL QTY IND, M10054), AND THE EICAS STATUS MESSAGE "FUEL QTY IND" SHOWS. - WHILE FUELING, THE FUELING SHUTOFF VALVE CLOSES FOR THE APPLICABLE FUEL TANK. THE "PUSH SET" MESSAGE WILL SHOW ON THE FUEL QUANTITY INDICATORS ON THE FUELING CONTROL PANEL, P28, REFER TO AMM 12-11-01/301 TO CONTINUE FUELING. THE FUEL QUANTITY INDICATOR, M10054, WILL ALSO GO OFF. 	
CORRECTION	
<ol style="list-style-type: none"> 1. EXAMINE THE APPLICABLE HI-Z/LO-Z CONNECTOR FOR CONTAMINATION OR DAMAGE, SEE TABLE 102. 2. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104, "SELF TEST ?" TO SEE IF THE FAULT MESSAGE CONTINUES TO SHOW. 3. DO A TEST ON THE APPLICABLE HI-Z WIRE TO FIND THE OPEN WIRE (WDM 28-41-21,-31,-41). <ol style="list-style-type: none"> A. ON THE FRONT PANEL OF THE FQIS PROCESSOR, GO TO THE "SYSTEM DATA?" MENU. FIND THE CAPACITANCE VALUE FOR THE APPLICABLE HI-Z WIRE. IF YOU DIVIDE THIS VALUE BY 50, YOU WILL HAVE THE APPROXIMATE VALUE FOR THE DISTANCE (IN FEET) TO THE OPEN WIRE FROM THE FQIS PROCESSOR. 4. REPAIR OR REPLACE THE APPLICABLE WIRING HARNESS (WDM 28-41-21,-31,-41). 5. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
 Figure 108 (Sheet 11)

EFFECTIVITY
 GUI 001-114, 116-999

28-41-00
 CONFIG 2
 Page 159
 May 28/06


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	11
<p>** HIZ SHIELD OPEN AT SPAR G##.</p>	
FAULT CONDITION	
<p>THIS MESSAGE SHOWS IF THERE IS AN OPEN IN THE HI-Z WIRE. THE OPEN WIRE WILL BE NEAR THE APPLICABLE HI-Z/LO-Z CONNECTOR. THIS INCLUDES THE POINTS BETWEEN A POINT HALF THE DISTANCE BETWEEN THE FQIS PROCESSOR AND THE HI-Z/LO-Z CONNECTOR, AND A POINT HALF THE DISTANCE BETWEEN THE HI-Z/LO-Z CONNECTOR AND THE FIRST TANK UNIT.</p>	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - THE FUEL QUANTITY INDICATION WILL GO OFF FOR THE APPLICABLE FUEL TANK, THE TOTAL FUEL QUANTITY INDICATION WILL GO OFF (FUEL QTY IND, M10054), AND THE EICAS STATUS MESSAGE "FUEL QTY IND" SHOWS. - WHILE FUELING, THE FUELING SHUTOFF VALVE CLOSES FOR THE APPLICABLE FUEL TANK. THE "PUSH SET" MESSAGE WILL SHOW ON THE FUEL QUANTITY INDICATORS ON THE FUELING CONTROL PANEL, P28, REFER TO AMM 12-11-01/301 TO CONTINUE FUELING. THE FUEL QUANTITY INDICATOR, M10054, WILL ALSO GO OFF. 	
CORRECTION	
<ol style="list-style-type: none"> 1. EXAMINE THE APPLICABLE CONNECTORS FOR CONTAMINATION OR DAMAGE, SEE FIG. 107. 2. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?" TO SEE IF THE FAULT MESSAGE CONTINUES TO SHOW. 3. DO A TEST ON THE APPLICABLE HI-Z SHIELD TO FIND THE OPEN SHIELD (WDM 28-41-21,-31,-41). <ol style="list-style-type: none"> A. ON THE FRONT PANEL OF THE FQIS PROCESSOR, GO TO THE "SYSTEM DATA?" MENU. FIND THE CAPACITANCE VALUE FOR THE APPLICABLE HI-Z WIRE. IF YOU DIVIDE THIS VALUE BY 50, YOU WILL HAVE THE APPROXIMATE VALUE FOR THE DISTANCE (IN FEET) TO THE OPEN WIRE FROM THE FQIS PROCESSOR. 4. EXAMINE, REPAIR OR REPLACE THE APPLICABLE HI-Z WIRING HARNESS AS NECESSARY (WDM 28-41-21,-31,-41). 5. DO THIS PROCEDURE: FUEL QTY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
 Figure 108 (Sheet 12)

EFFECTIVITY
 GUI 001-114, 116-999

28-41-00
 CONFIG 2
 Page 160
 May 28/06


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	12
** HIZ WIRE OPEN AT PROCESSOR G##.	
FAULT CONDITION	
THIS MESSAGE SHOWS IF THERE IS AN OPEN IN THE CENTER WIRE OF THE HI-Z CABLE. THE OPEN WIRE WILL BE NEAR THE FQIS PROCESSOR. THIS INCLUDES THE POINTS BETWEEN THE FQIS PROCESSOR CONNECTOR, AND A POINT HALF THEIR DISTANCE BETWEEN THE FQIS PROCESSOR CONNECTOR AND THE HI-Z/LO-Z CONNECTOR.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - THE FUEL QUANTITY INDICATION WILL GO OFF FOR THE APPLICABLE FUEL TANK, THE TOTAL FUEL QUANTITY INDICATION WILL GO OFF (FUEL QTY IND, M10054), AND THE EICAS STATUS MESSAGE "FUEL QTY IND" SHOWS. - WHILE FUELING, THE FUELING SHUTOFF VALVE CLOSES FOR THE APPLICABLE FUEL TANK. THE "PUSH SET" MESSAGE WILL SHOW ON THE FUEL QUANTITY INDICATORS ON THE FUELING CONTROL PANEL, P28, REFER TO AMM 12-11-01/301 TO CONTINUE FUELING. THE FUEL QUANTITY INDICATOR, M10054, WILL ALSO GO OFF. 	
CORRECTION	
<ol style="list-style-type: none"> 1. EXAMINE THE FQIS PROCESSOR CONNECTOR AND THE E/E BAY RACK CONNECTOR FOR CONTAMINATION OR DAMAGE, SEE FIG. 107. <ol style="list-style-type: none"> A. ON THE FRONT PANEL OF THE FQIS PROCESSOR, GO TO THE "SYSTEM DATA?" MENU. FIND THE CAPACITANCE VALUE FOR THE APPLICABLE HI-Z WIRE. IF YOU DIVIDE THIS VALUE BY 50, YOU WILL HAVE THE APPROXIMATE VALUE FOR THE DISTANCE (IN FEET) TO THE OPEN WIRE FROM THE FQIS PROCESSOR. 2. EXAMINE AND REPAIR THE APPLICABLE WIRE CIRCUIT (WDM 28-41-21,-31,-41). 3. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
Figure 108 (Sheet 13)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
 CONFIG 2
 Page 161
 May 28/06


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	13
<p>** HIZ SHIELD OPEN AT PROC G##.</p>	
FAULT CONDITION	
<p>THIS MESSAGE SHOWS IF THERE IS AN OPEN IN THE SHIELD WIRE OF THE HI-Z CABLE. THE OPEN WIRE WILL BE NEAR THE FQIS PROCESSOR. THIS INCLUDES THE POINTS BETWEEN THE FQIS PORCESSOR CONNECTOR, AND A POINT HALF THE DISTANCE BETWEEN THE FQIS PROCESSOR CONNECTOR AND THE HI-Z/LO-Z CONNECTOR.</p>	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - THE FUEL QUANTITY INDICATION WILL GO OFF FOR THE APPLICABLE FUEL TANK, THE TOTAL FUEL QUANTITY INDICATION WILL GO OFF (FUEL QTY IND, M10054), AND THE EICAS STATUS MESSAGE "FUEL QTY IND" SHOWS. - WHILE FUELING, THE FUELING SHUTOFF VALVE CLOSES FOR THE APPLICABLE FUEL TANK. THE "PUSH SET" MESSAGE WILL SHOW ON THE FUEL QUANTITY INDICATORS ON THE FUELING CONTROL PANEL, P28, REFER TO AMM 12-11-01/301 TO CONTINUE FUELING. THE FUEL QUANTITY INDICATOR, M10054, WILL ALSO GO OFF. 	
CORRECTION	
<ol style="list-style-type: none"> 1. EXAMINE THE FQIS PROCESSOR CONNECTOR AND THE E/E BAY RACK CONNECTOR FOR CONTAMINATION OR DAMAGE, SEE FIG. 107. <ol style="list-style-type: none"> A. ON THE FRONT PANEL OF THE FQIS PROCESSOR, GO TO THE "SYSTEM DATA?" MENU. FIND THE CAPACITANCE VALUE FOR THE APPLICABLE HI-Z WIRE. IF YOU DIVIDE THIS VALUE BY 50, YOU WILL HAVE THE APPROXIMATE VALUE FOR THE DISTANCE (IN FEET) TO THE OPEN WIRE FROM THE FQIS PROCESSOR. 2. EXAMINE AND REPAIR THE APPLICABLE WIRE CIRCUIT (WDM 28-41-21,-31,-41). 3. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
 Figure 108 (Sheet 14)

EFFECTIVITY
 GUI 001-114, 116-999

28-41-00
 CONFIG 2
 Page 162
 May 28/06


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	14
** HIZ WIRE LOW RESISTANCE G##.	
FAULT CONDITION	
THIS MESSAGE SHOWS IF LESS THAN 402,000 OHMS OF RESISTANCE IS MEASURED BETWEEN THE HI-Z SHIELD AND THE HI-Z CENTER CONDUCTOR.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
- NORMAL OPERATION - THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" SHOWS.	
CORRECTION	
1. EXAMINE THE APPLICABLE WIRE CONNECTORS FOR CONTAMINATION OR DAMAGE, SEE FIG. 107. CLEAN OR REPAIR THE CONNECTIONS AS NECESSARY. 2. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 3. IF THE PROBLEM CONTINUES, OPEN THE APPLICABLE HI-Z/LO-Z CONNECTOR, SEE FIG. 107, AND THE FUEL QUANTITY BITE PROCEDURE, SEE FIG. 104, SELF-TEST? 4. IF THE FAULT MESSAGE SHOWS THE PROBLEM IS BETWEEN THE FQIS PROCESSOR AND THE HI-Z/LO-Z CONNECTOR AT THE FRONT SPAR. GO TO STEP 6. <u>NOTE:</u> THE OTHER TANK UNITS AND COMPENSATOR WILL SHOW THE OPEN LO-Z OR HI-Z FAULT MESSAGE WHEN THE SPAR CONNECTOR IS OPEN. IGNORE THESE OPEN FAULT MESSAGES. 5. IF THE FAULT MESSAGE DOES NOT SHOW THE PROBLEM IS IN THE APPLICABLE TANK WIRING HARNESS. GO TO STEP 7. 6. REPAIR OR REPLACE THE CIRCUIT BETWEEN THE FQIS PROCESSOR AND THE APPLICABLE HI-Z/LO-Z CONNECTOR (WDM 28-41-21,-31,-41). 7. EXAMINE AND REPLACE THE APPLICABLE TANK WIRING HARNESS (AMM 28-41-09/401). 8. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?".	

Fault Messages
 Figure 108 (Sheet 15)

EFFECTIVITY
 GUI 001-114, 116-999

896436


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	15
** HIZ SHORTED WIRE TO SHLD G##.	
FAULT CONDITION	
THIS MESSAGE SHOWS IF LESS THAN 2,180 OHMS RESISTANCE IS MEASURED BETWEEN THE HI-Z SHIELD AND THE HI-Z CENTER CONDUCTOR.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - THE FUEL QUANTITY INDICATION WILL GO OFF FOR THE APPLICABLE FUEL TANK, THE TOTAL FUEL QUANTITY INDICATION WILL GO OFF (FUEL QTY IND, M10054), AND THE EICAS STATUS MESSAGE "FUEL QTY IND" SHOWS. - WHILE FUELING, THE FUELING SHUTOFF VALVE CLOSES FOR THE APPLICABLE FUEL TANK. THE "PUSH SET" MESSAGE WILL SHOW ON THE FUEL QUANTITY INDICATORS ON THE FUELING CONTROL PANEL, P28, REFER TO AMM 12-11-01/301 TO CONTINUE FUELING. THE FUEL QUANTITY INDICATOR, M10054, WILL ALSO GO OFF. 	
CORRECTION	
<ol style="list-style-type: none"> 1. EXAMINE THE APPLICABLE WIRE CONNECTORS FOR CONTAMINATION OR DAMAGE, SEE FIG. 107. CLEAN OR REPAIR THE CONNECTIONS AS NECESSARY. 2. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 3. IF THE PROBLEM CONTINUES, OPEN THE APPLICABLE HI-Z/LO-Z CONNECTOR, SEE FIG. 107, AND THE FUEL QUANTITY BITE PROCEDURE, FIG. 104, SELF-TEST? 4. IF THE FAULT MESSAGE SHOWS THE PROBLEM IS BETWEEN THE FQIS PROCESSOR AND THE HI-Z/LO-Z CONNECTOR AT THE FRONT SPAR, GO TO STEP 6. <p style="margin-left: 20px;"><u>NOTE:</u> THE OTHER TANK UNITS AND COMPENSATOR WILL SHOW THE OPEN LO-Z OR HI-Z FAULT MESSAGE WHEN THE SPAR CONNECTOR IS OPEN. IGNORE THESE OPEN FAULT MESSAGES.</p> <ol style="list-style-type: none"> 5. IF THE FAULT MESSAGE DOES NOT SHOW, THE PROBLEM IS IN THE APPLICABLE TANK WIRING HARNESS. GO TO STEP 7. 6. REPAIR OR REPLACE THE APPLICABLE AIRPLANE WIRING HARNESS (WDM 28-41-21,-31,-41). 7. EXAMINE AND REPLACE THE APPLICABLE TANK WIRING HARNESS (AMM 28-41-09/401). 8. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
Figure 108 (Sheet 16)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
 CONFIG 2
 Page 164
 May 28/06


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	16
** HIZ SHIELD SHORT TO GND G##.	
FAULT CONDITION	
THIS FAULT MESSAGE SHOWS IF THERE IS A HI-Z SHIELD SHORTED TO A LO-Z WIRE, OR THE HI-Z SHIELD IS SHORTED TO GROUND AT A POINT OTHER THAN AT THE PROCESSOR.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - THE FUEL QUANTITY INDICATION WILL GO OFF FOR THE APPLICABLE FUEL TANK, THE TOTAL FUEL QUANTITY INDICATION WILL GO OFF (FUEL QTY IND, M10054), AND THE EICAS STATUS MESSAGE "FUEL QTY IND" SHOWS. - WHILE FUELING, THE FUELING SHUTOFF VALVE CLOSES FOR THE APPLICABLE FUEL TANK. THE "PUSH SET" MESSAGE WILL SHOW ON THE FUEL QUANTITY INDICATORS ON THE FUELING CONTROL PANEL, P28, REFER TO AMM 12-11-01/301 TO CONTINUE FUELING. THE FUEL QUANTITY INDICATOR, M10054, WILL ALSO GO OFF. 	
CORRECTION	
<ol style="list-style-type: none"> 1. OPEN THE APPLICABLE HI-Z/LO-Z CONNECTOR, SEE FIG. 107. 2. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 3. IF THE FAULT MESSAGE SHOWS THE PROBLEM IS BETWEEN THE FQIS PROCESSOR AND THE HI-Z/LO-Z CONNECTOR AT THE FRONT SPAR, GO TO STEP 5. <p style="margin-left: 20px;"><u>NOTE:</u> THE OTHER TANK UNITS AND COMPENSATOR WILL SHOW THE OPEN LO-Z OR HI-Z FAULT MESSAGE WHEN THE SPAR CONNECTOR IS OPEN. IGNORE THESE OPEN FAULT MESSAGES.</p> 4. IF THE FAULT MESSAGE DOES NOT SHOW, THE PROBLEM IS IN THE APPLICABLE FUEL TANK WIRING HARNESS. GO TO STEP 6. <p style="margin-left: 20px;"><u>NOTE:</u> WHEN THE PROCESSOR IS INSTALLED, THE USUAL HI-Z SHIELD TO AIRPLANE GROUND (OR THE HI-Z SHIELD TO LO-Z WIRE) RESISTANCE IS 4.5 TO 6.5 OHMS. WHEN THE PROCESSOR IS REMOVED, THE SAME RESISTANCE CHECKS WILL SHOW MORE THAN 10 MEGOHMS (AMM 28-41-00/501).</p> 5. EXAMINE AND REPAIR THE CIRCUIT BETWEEN THE FQIS PROCESSOR AND THE APPLICABLE HI-Z/LO-Z CONNECTOR (AMM 28-41-00/501)(WDM 28-41-21, -31, -41). 6. REPAIR OR REPLACE THE APPLICABLE TANK WIRING HARNESS (AMM 28-41-09/401). 7. IF THE PROBLEM CONTINUES, EXAMINE AND REPLACE THE APPLICABLE COMPENSATOR OR TANK UNIT (AMM 28-41-01,-02/401). 8. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
Figure 108 (Sheet 17)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
 CONFIG 2
 Page 165
 May 28/06

 **BOEING**
757
FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE

17

** DENS RESISTOR UNREADABLE G##.

FAULT CONDITION

THIS MESSAGE SHOWS IF ONE OR MORE OF THE CALIBRATION RESISTORS IN THE DENSITOMETER DOES NOT OPERATE CORRECTLY. THE FAULT CONDITIONS ARE AS FOLLOWS:



- (1) DENSITOMETER INSTALLED BACKWARDS
- (2) CALIBRATION WIRE SHORTED TO GROUND
- (3) CALIBRATION RESISTOR FAILED
- (4) CALIBRATION WIRE SHORTED TO ANOTHER CALIBRATION WIRE
- (5) DENSITOMETER DRIVE WIRE OPEN

NOTE: FOR ANY DENSITOMETER FAULT MESSAGE, WHERE THE DENSITOMETER IS STILL IN NORMAL RANGE, THE FAULT MESSAGE COMPENSATOR CONTAMINATED CAN SHOW.

FLIGHT COMPARTMENT OR AIRPLANE INDICATION

- NORMAL OPERATION WITH AN INDICATION ERROR FOR FUEL QUANTITY OF $\pm 5\%$ FOR THE APPLICABLE TANK (ONLY ONE TANK UNIT CAN BE BAD).
- THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" SHOWS.

CORRECTION

1. REMOVE THE FQIS PROCESSOR, M121 (AMM 28-41-08/401).
2. INSTALL THE PSD 757/767-1 TESTER AND DO THE DENSITOMETER TEST.
NOTE: NO OTHER TEST BOX IS NECESSARY TO DO THE DENSITOMETER TEST. READ THE GO-NO-GO (RED/GREEN) LED LIGHT ON THE FRONT OF THE 757/767-1 TEST BOX.
3. MAKE A WRITTEN RECORD OF THE PROBLEM.
4. OPEN THE APPLICABLE DENSITOMETER CONNECTOR AT THE REAR SPAR, FIG. 102.
5. CONNECT THE PSD 757/767-1 TESTER TO THE DENSITOMETER CONNECTOR ON THE REAR SPAR AND DO A TEST.
6. IF A FAILURE INDICATION DOES NOT SHOW, THE PROBLEM IS IN THE HOT SHORT PROTECTOR  OR AIRPLANE WIRE HARNESS.
 - A. REPAIR OR REPLACE THE HOT SHORT PROTECTOR, M11872 (AMM 28-41-24/401)  OR THE APPLICABLE AIRPLANE HARNESS (WDM 28-41-21,-31,-41).
7. IF A FAILURE INDICATION CONTINUES TO SHOW, THE PROBLEM IS IN THE APPLICABLE FUEL TANK.
 - A. YOU MUST GO INTO THE APPLICABLE FUEL TANK (AMM 28-11-00/201).
 - B. EXAMINE THE DENSITOMETER TERMINALS FOR CONTAMINATION, CLEAN OR REPAIR AS NECESSARY.
 - C. IF YOU CANNOT FIND ANY CONTAMINATION, REPLACE THE DENSITOMETER (AMM 28-41-04/401).
8. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?".



 IF INSTALLED, CENTER TANK ONLY (POST-SB 28A0085)

Fault Messages
Figure 108 (Sheet 18)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
CONFIG 2
Page 166
May 28/06


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	18
<p>** DENS EXCITA- TION SHORTED G##.</p>	
FAULT CONDITION	
<p>THIS FAULT MESSAGE SHOWS IF THE DENSITOMETER DRIVE CIRCUIT DOES NOT HAVE SUFFICIENT RESISTANCE BETWEEN THE POSITIVE OR NEGATIVE DRIVE WIRES, AND AIRPLANE GROUND.</p> <p><u>NOTE:</u> FOR ANY DENSITOMETER FAULT MESSAGE, WHERE THE DENSITOMETER IS STILL IN NORMAL RANGE, THE FAULT MESSAGE COMPENSATOR CONTAMINATED CAN SHOW.</p>	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<p>- NORMAL OPERATION WITH AN INDICATION ERROR FOR FUEL QUANTITY OF $\pm 5\%$ FOR THE APPLICABLE TANK (ONLY ONE TANK UNIT CAN BE BAD).</p> <p>- THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" SHOWS.</p>	
CORRECTION	
<ol style="list-style-type: none"> 1. REMOVE THE FQIS PROCESSOR, M121 (AMM 28-41-08/401). 2. INSTALL THE PSD 757/767-1 TESTER AND DO THE DENSITOMETER TEST. <p style="margin-left: 20px;"><u>NOTE:</u> NO OTHER TEST BOX IS NECESSARY TO DO THE DENSITOMETER TEST. READ THE GO-NO-GO (RED/GREEN) LED LIGHT ON THE FRONT OF THE 757/767-1 TEST BOX.</p> 3. MAKE A WRITTEN RECORD OF THE PROBLEM. 4. OPEN THE APPLICABLE DENSITOMETER CONNECTOR AT THE REAR SPAR, FIG. 102. 5. CONNECT THE PSD 757/767-1 TESTER TO THE DENSITOMETER CONNECTOR ON THE REAR SPAR AND DO A TEST. 6. IF A FAILURE INDICATION DOES NOT SHOW, THE PROBLEM IS IN THE HOT SHORT PROTECTOR  OR AIRPLANE WIRE HARNESS. <ol style="list-style-type: none"> A. REPAIR OR REPLACE THE HOT SHORT PROTECTOR, M11872 (AMM 28-41-24/401)  OR THE APPLICABLE AIRPLANE HARNESS (WDM 28-41-21,-31,-41). 7. IF A FAILURE INDICATION CONTINUES TO SHOW, THE PROBLEM IS IN THE APPLICABLE FUEL TANK. <ol style="list-style-type: none"> A. YOU MUST GO INTO THE APPLICABLE FUEL TANK (AMM 28-11-00/201). B. EXAMINE THE DENSITOMETER TERMINALS FOR CONTAMINATION, CLEAN OR REPAIR AS NECESSARY. C. IF YOU CANNOT FIND ANY CONTAMINATION, REPLACE THE DENSITOMETER (MM 28-41-04/401). 8. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 9. IF THE APPLICABLE FAULT MESSAGE CONTINUES TO SHOW, THE PROBLEM IS THE APPLICABLE TANK WIRING HARNESS. REPAIR OR REPLACE THE APPLICABLE TANK WIRING HARNESS (WDM 28-41-21,-31,-41). 10. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

 IF INSTALLED, CENTER TANK ONLY (POST-SB 28A0085)

Fault Messages
Figure 108 (Sheet 19)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
 CONFIG 2
 Page 167
 May 28/06

 **BOEING**
757
FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE

19

** DENS SENSE WIRE SHORTED G##.

FAULT CONDITION

THIS MESSAGE IS AN INDICATION THAT THERE IS LESS THAN 80 OHMS BETWEEN THE CENTER CONDUCTOR OF THE DENSITOMETER SENSE WIRE AND THE SHIELD.


THIS MESSAGE CAN OCCUR AS A NUISANCE MESSAGE IF THE APPLICABLE TANK IS EMPTY.

NOTE: FOR ANY DENSITOMETER FAULT MESSAGE, WHERE THE DENSITOMETER IS STILL IN NORMAL RANGE, THE FAULT MESSAGE COMPENSATOR CONTAMINATED CAN SHOW.

FLIGHT COMPARTMENT OR AIRPLANE INDICATION

- NORMAL OPERATION WITH AN INDICATION ERROR FOR FUEL QUANTITY OF $\pm 5\%$ FOR THE APPLICABLE TANK (ONLY ONE TANK UNIT CAN BE BAD).
- THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" SHOWS.

CORRECTION

1. DO THESE STEPS TO FIND OUT IF THIS IS A NUISANCE FAULT:
 - A. IF THE APPLICABLE TANK IS EMPTY, ADD FUEL UNTIL THE DENSITOMETER IS COVERED (138 U.S. GALLONS FOR THE LEFT OR RIGHT MAIN TANKS, 1002 U.S. GALLONS FOR THE CENTER TANK).
 - B. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE (FIG. 104, "SELF TEST ?").
 - C. IF THE FAULT MESSAGE DOES NOT SHOW, THEN THE SYSTEM IS OK.
 - D. IF THE FAULT MESSAGE CONTINUES TO SHOW, THEN CONTINUE.
2. DISCONNECT THE APPLICABLE DENSITOMETER CONNECTOR (REAR SPAR)(FIG. 107).
3. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE (FIG. 104, "SELF TEST ?").
4. IF THE FAULT CONTINUES TO SHOW, THE PROBLEM IS IN THE HOT SHORT PROTECTOR  OR AIRPLANE WIRING HARNESS. EXAMINE THE WIRING (WDM 28-41-21,-31,-41). REPAIR THE PROBLEMS THAT YOU FIND.

NOTE: WHEN THE REAR SPAR CONNECTOR FOR THE DENSITOMETER IS OPEN OTHER FAULT MESSAGES WILL SHOW. LOOK FOR THE INITIAL FAULT MESSAGE ONLY, IGNORE ALL OTHER FAULT MESSAGES.
5. IF THE FAULT MESSAGE DOES NOT SHOW, THE PROBLEM IS IN THE APPLICABLE DENSITOMETER, TANK WIRING HARNESS OR CONDUCTIVE MATERIAL IS ON THE DENSITOMETER TERMINALS.
6. GO INTO THE APPLICABLE FUEL TANK (AMM 28-11-00/201).
7. EXAMINE AND REPLACE THE DENSITOMETER IF IT IS NECESSARY (AMM 28-41-03/401).
8. EXAMINE AND REPLACE THE DENSITOMETER TANK WIRING HARNESS IF IT IS NECESSARY (AMM 28-41-09/401).
9. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE (FIG. 104, "SELF TEST ?").





 IF INSTALLED, CENTER TANK ONLY (POST-SB 28A0085)

Fault Messages
Figure 108 (Sheet 20)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
CONFIG 2
Page 168
May 28/06


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	20
<p>** DENS SENSE OPEN AT SPAR G##.</p>	
FAULT CONDITION	
<p>THIS MESSAGE IS SENT IF AN OPEN OCCURS IN THE DENSITOMETER SENSE COIL WIRE OR SHIELD. THE OPEN WIRE WILL OCCUR NEAR THE DENSITOMETER CONNECTOR, SEE FIG. 107. THIS INCLUDES THE POINTS BETWEEN, A POINT HALF THE DISTANCE BETWEEN THE PROCESSOR AND THE APPLICABLE DENSITOMETER CONNECTOR, AND A POINT HALF THE DISTANCE BETWEEN THE APPLICABLE DENSITOMETER CONNECTOR AND THE APPLICABLE DENSITOMETER.</p> <p><u>NOTE:</u> FOR ANY DENSITOMETER FAULT MESSAGE, WHERE THE DENSITOMETER IS STILL IN NORMAL RANGE, THE FAULT MESSAGE COMPENSATOR CONTAMINATED CAN SHOW.</p>	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<p>- NORMAL OPERATION WITH AN INDICATION ERROR FOR FUEL QUANTITY OF $\pm 5\%$ FOR THE APPLICABLE TANK (ONLY ONE TANK UNIT CAN BE BAD).</p> <p>- THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" SHOWS.</p>	
CORRECTION	
<ol style="list-style-type: none"> 1. EXAMINE THE APPLICABLE DENSITOMETER CONNECTOR ON THE REAR SPAR FOR DAMAGE OR CONTAMINATION, SEE FIG. 107. EXAMINE AND REPAIR THE DENSITOMETER CONNECTOR IF IT IS NECESSARY. 2. IF THE PROBLEM CONTINUES, REPLACE THE HOT SHORT PROTECTOR, M11872 (AMM 28-41-24/401)  OR HOT SHORT PROTECTOR WIRE HARNESS (AMM 28-41-25/401)  OR EXAMINE THE AIRPLANE WIRING HARNESS FOR THE APPLICABLE DENSITOMETER (WDM 28-41-21,-31,-41). REPAIR THE PROBLEMS THAT YOU FIND. 3. IF THE HOT SHORT PROTECTOR , HOT SHORT PROTECTOR WIRE HARNESS  AND THE APPLICABLE AIRPLANE WIRING HARNESS ARE OK, THE PROBLEM IS IN THE APPLICABLE TANK WIRING HARNESS. 4. GO INTO THE APPLICABLE FUEL TANK (AMM 28-11-00/201). 5. EXAMINE AND REPLACE THE APPLICABLE DENSITOMETER TANK WIRING HARNESS (AMM 28-41-09/401). 6. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

 IF INSTALLED, CENTER TANK ONLY (POST-SB 28A0085)

Fault Messages
Figure 108 (Sheet 21)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
 CONFIG 2
 Page 169
 May 28/06


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	21
<p>** DENS SENSE OPEN AT PROC G##.</p>	
FAULT CONDITION	
<p>THIS MESSAGE IS SENT IF AN OPEN OCCURS IN THE DENSITOMETER SENSE COIL WIRE OR SHIELD. THE OPEN WIRE WILL OCCUR NEAR THE FQIS PROCESSOR. THE BREAK IN THE SENSE WIRE WILL BE A POINT BETWEEN, THE FQIS PROCESSOR AND A POINT HALF THE DISTANCE BETWEEN THE FQIS PROCESSOR AND THE DENSITOMETER CONNECTOR.</p> <p><u>NOTE:</u> FOR ANY DENSITOMETER FAULT MESSAGE, WHERE THE DENSITOMETER IS STILL IN NORMAL RANGE, THE FAULT MESSAGE COMPENSATOR CONTAMINATED CAN SHOW.</p>	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<p>- NORMAL OPERATION WITH AN INDICATION ERROR FOR FUEL QUANTITY OF $\pm 5\%$ FOR THE APPLICABLE TANK (ONLY ONE TANK UNIT CAN BE BAD).</p> <p>- THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" SHOWS.</p>	
CORRECTION	
<ol style="list-style-type: none"> 1. EXAMINE THE APPLICABLE ELECTRONIC EQUIPMENT BAY SHELF CONNECTORS FOR DAMAGE, SEE FIG. 107. 2. IF THE CONNECTORS ARE OK, THE DENSITOMETER SENSE WIRE IS OPEN BETWEEN THE FQIS PROCESSOR AND A POINT HALF THE DISTANCE BETWEEN THE FQIS PROCESSOR AND THE DENSITOMETER CONNECTOR. 3. EXAMINE AND REPAIR THE CIRCUIT, SEE FIG. 107 (WDM 28-41-21,-31,-41). 4. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
Figure 108 (Sheet 22)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
 CONFIG 2
 Page 170
 May 28/06


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	22
** DENS CONTAM OR RESISTOR G##.	
FAULT CONDITION	
IF THE MEASURED DENSITY IS NOT IN THE USUAL LIMITS, OR THE DENSITOMETER AND COMPENSATOR DENSITY VALUES ARE NOT THE SAME, THIS FAULT MESSAGE IS SENT.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
- NORMAL OPERATION WITH AN INDICATION ERROR FOR FUEL QUANTITY OF $\pm 5\%$ FOR THE APPLICABLE TANK (ONLY ONE TANK UNIT CAN BE BAD). - THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" SHOWS.	
CORRECTION	
1. DEFUEL THE APPLICABLE FUEL TANK (AMM 28-26-00/201). 2. DRAIN THE APPLICABLE FUEL TANK SUMP (AMM 12-11-03/301). 3. IF YOU DO NOT FIND CONTAMINATION IN THE SUMP FUEL, GO TO STEP 4, OR IF THERE WAS CONTAMINATION IN THE SUMP FUEL, DO THIS PROCEDURE: FQIS BITE PROCEDURE, FIG. 104 "SELF TEST ?". 4. IF THE FAULT MESSAGE CONTINUES TO SHOW, GO INTO THE APPLICABLE FUEL TANK (AMM 28-11-00/201). 5. EXAMINE THE DENSITOMETER FOR DAMAGE, WATER, MICROBIAL GROWTH, OR OTHER CONTAMINATION MATERIAL. REPLACE THE DENSITOMETER AS NECESSARY (AMM 28-41-03/401). 6. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?".	

Fault Messages
Figure 108 (Sheet 23)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
 CONFIG 2
 Page 171
 Sep 28/06


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL




FAULT MESSAGE	23
<p>** DENS SENSOR OR DRIVE WIRE G## (OR) ** DENS SENSOR FAILURE G**.</p>	
FAULT CONDITION	
<p>THE DENSITOMETER SENSOR DOES NOT OPERATE CORRECTLY.</p> <p><u>NOTE:</u> FOR ANY DENSITOMETER FAULT MESSAGE, WHERE THE DENSITOMETER IS STILL IN ITS USUAL LIMITS, THE FAULT MESSAGE COMPENSATOR CONTAMINATED CAN SHOW.</p>	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<p>- NORMAL OPERATION WITH AN INDICATION ERROR FOR FUEL QUANTITY OF $\pm 5\%$ FOR THE APPLICABLE TANK (ONLY ONE TANK UNIT CAN BE BAD).</p> <p>- THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" SHOWS.</p>	
CORRECTION	
<ol style="list-style-type: none"> 1. REPLACE THE DENSITOMETER FOR THE APPLICABLE FUEL TANK (AMM 28-41-03/401). 2. REFUEL THE APPLICABLE FUEL TANK UNTIL THE FUEL IS ABOVE THE DENSITOMETER (AMM 12-11-01/301). 3. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 4. IF THE PROBLEM CONTINUES, REPLACE THE DENSITOMETER IN TANK WIRING HARNESS FOR THE APPLICABLE FUEL TANK (AMM 28-41-09/401). 5. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
 Figure 108 (Sheet 24)

EFFECTIVITY
 GUI 001-114, 116-999

28-41-00

CONFIG 2
 Page 172
 May 28/06

FAULT MESSAGE	24
** IFQC CIRCUIT BOARD FAILED G##.	
FAULT CONDITION	
THE FQIS BITE SHOWS A PROBLEM WITH THE INDIVIDUAL FUEL QUANTITY CHANNEL (IFQC) CIRCUIT BOARD OR THERE IS A PROBLEM WITH THE DENSITOMETER HOT SHORT PROTECTOR. 	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - NORMAL OPERATION WITH AN INDICATION ERROR FOR FUEL QUANTITY OF $\pm 5\%$ FOR THE APPLICABLE TANK (ONLY ONE TANK UNIT CAN BE BAD). - NORMAL OPERATION, IF FUEL GAGE CIRCUITRY IS NOT BAD. - THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" SHOWS. - THE FUEL QUANTITY INDICATION WILL GO OFF FOR THE APPLICABLE FUEL TANK, THE TOTAL FUEL QUANTITY INDICATION WILL GO OFF (FUEL QTY IND, M10054), AND THE EICAS STATUS MESSAGE "FUEL QTY IND" SHOWS. - WHILE FUELING, THE FUELING SHUTOFF VALVE CLOSES FOR THE APPLICABLE FUEL TANK. THE "PUSH SET" MESSAGE WILL SHOW ON THE FUEL QUANTITY INDICATORS ON THE FUELING CONTROL PANEL, REFER TO AMM 12-11-01/301 TO CONTINUE FUELING. THE FUEL QUANTITY INDICATOR, M10054, WILL ALSO GO OFF. 	
CORRECTION	
<ol style="list-style-type: none"> 1. DO A CHECK FOR THESE CONDITIONS: <ol style="list-style-type: none"> A. FUEL QUANTITY INDICATION FOR THE APPLICABLE TANK IS BLANK. B. FMC TOTALIZER FUEL QUANTITY VALUE IS BLANK. C. FUEL QTY IND EICAS STATUS LEVEL MESSAGE IS SHOWN. D. ON THE PROCESSOR, THE "SYSTEM DATA" MENU FOR THE APPLICABLE TANK SHOWS ZEROES FOR ALL DATA. 2. IF ONE OR MORE OF THESE CONDITIONS IS NOT TRUE, THEN GO TO STEP 4. 3. IF ALL OF THE CONDITIONS IN STEP 1 ARE TRUE, THEN DO THESE STEPS: <ol style="list-style-type: none"> A. CYCLE THE POWER FOR THE PROCESSOR. B. IF THE REFUEL PANEL DOOR IS OPEN, OPEN THESE CIRCUIT BREAKERS AND CLOSE THEM AGAIN: <ol style="list-style-type: none"> (1) 34A10, FUEL QTY-FUEL (2) 6E4, FUELING QTY C. IF THE REFUEL PANEL DOOR IS CLOSED, OPEN THESE CIRCUIT BREAKERS AND CLOSE THEM AGAIN: <ol style="list-style-type: none"> (3) 11C34, FUEL QTY L OR FUEL QTY 1 (4) 11L19, FUEL QTY R OR FUEL QTY 2 D. IF NO FAULT MESSAGES ARE SHOWN IN THE PRESENT FAULTS MENU, THE SYSTEM IS OK. E. IF THE FAULT MESSAGE CONTINUES TO SHOW IN THE "PRESENT FAULTS" MENU, THEN CONTINUE. 4. DO THESE STEPS: <ol style="list-style-type: none"> A. EXAMINE THE WIRING AT THE DENSITOMETER HOT SHORT PROTECTOR WIRE HARNESS CONNECTORS D11718 AND D11720, FOR A SHORT (AMM 28-41-25/401).  <ol style="list-style-type: none"> (1) IF THERE IS A SHORT TO GROUND, REPAIR OR REPLACE THE WIRING (AMM 28-41-25/401). (2) IF THE WIRING IS OK, REPLACE THE DENSITOMETER HOT SHORT PROTECTOR, M11872 (AMM 28-41-24/401).  B. IF THE FAULT MESSAGE CONTINUES TO SHOW IN THE "PRESENT FAULTS" MENU, THEN CONTINUE. C. REPLACE THE PROCESSOR, M121 (AMM 28-41-08/401). D. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104, "SELF TEST?". 	

 IF INSTALLED, CENTER TANK ONLY (POST-SB 28A0085)

Fault Messages
Figure 108 (Sheet 25)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
CONFIG 2
Page 173
Jan 20/09

20.1


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	25
** IFQC AIR/GND CIRCUIT FAIL G##.	
FAULT CONDITION	
THE APPLICABLE INDIVIDUAL FUEL QUANTITY CHANNEL (IFQC) CIRCUIT BOARD CAN NOT FIND IF THE AIRPLANE IS IN THE AIR OR ON THE GROUND.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - THE FQIS SYSTEM IS SET TO THE AIR MODE IF THE FUELING STATION DOOR, 621GB IS CLOSED. - THE FQIS SYSTEM IS SET TO THE GROUND MODE IF THE FUELING STATION DOOR, 621GB, IS OPEN. 	
CORRECTION	
<ol style="list-style-type: none"> 1. REPLACE THE FQIS PROCESSOR, M121 (AMM 28-41-08/401). 2. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 3. IF THE PROBLEM CONTINUES, DO THE CORRECTION FOR THE FAULT MESSAGE "AIR/GROUND_INPUT_FAILED", SEE FIG. 106. 	

Fault Messages
Figure 108 (Sheet 26)

EFFECTIVITY
GUI 001-114, 116-999

896451

20

28-41-00

CONFIG 2
Page 174
May 28/06


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	26
AIR/GROUND INPUT FAILED G##.	
FAULT CONDITION	
THE FQIS AIR/GROUND INPUTS A AND B DO NOT AGREE, OR ONE OF THE INPUTS IS FAILED OPEN, OR THE SYSTEM HAS BEEN OPERATED ON BATTERY POWER. NOTE: IF THE AIRPLANE WAS OPERATED ON BATTERY POWER, THIS FAULT MESSAGE CAN SHOW. THIS IS BECAUSE THE AIR/GROUND INDICATION USUALLY DEFAULTS TO "AIR" AND BATTERY POWER IS USED TO REFUEL THE AIRPLANE.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
- THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" SHOWS.	
CORRECTION	
<ol style="list-style-type: none"> 1. REMOVE THE FQIS PROCESSOR, M121 (AMM 28-41-08/401). 2. WHEN THE AIRPLANE IS IN THE GROUND MODE, MEASURE THE RESISTANCE BETWEEN THE PROCESSOR RACK CONNECTOR GND PIN K7 AND THE AIR/GND COM PIN K8 FOR BOTH CONNECTORS, D2440A AND D2440B. <ol style="list-style-type: none"> A. IF THE RESISTANCE IS MORE THAN 10 OHMS, EXAMINE AND REPAIR THE APPLICABLE CIRCUIT (WDM 28-41-14). 3. WHEN THE AIRPLANE IS IN THE AIR MODE, MEASURE THE RESISTANCE BETWEEN THE PROCESSOR RACK CONNECTOR GND K7 PIN AND THE AIR/GND COM PIN K6 FOR BOTH CONNECTORS, D2440A AND D2440B. <ol style="list-style-type: none"> A. IF THE RESISTANCE IS MORE THAN 10 OHMS, EXAMINE AND REPAIR THE APPLICABLE CIRCUIT (WDM 28-41-14). 4. IF THE RESISTANCE IS LESS THAN 10 OHMS IN STEPS 2 OR 3, REPLACE THE FQIS PROCESSOR, M121 (AMM 28-41-08/401). 5. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
Figure 108 (Sheet 27)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
 CONFIG 2
 Page 175
 May 28/06


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	27
LB/KG INPUT WIRE FAILED G##.	
FAULT CONDITION	
THE POUND/KILOGRAM INPUT JUMPER HAS FAILED OPEN.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
- NORMAL OPERATION, LB/KG STATUS FOUND BY VALUE STORED IN MEMORY. - THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" SHOWS.	
CORRECTION	
1. REMOVE THE FQIS PROCESSOR, M121 (AMM 28-41-08/401). 2. FOR AIRPLANES WITH UNITS IN LBS, MEASURE THE RESISTANCE BETWEEN THE LBS PIN, A9, TO LBS/KGS COM PIN, C9, ON THE PROCESSOR RACK CONNECTOR D2440A (WDM 28-41-11). A. IF THE RESISTANCE IS MORE THAN 10 OHMS, EXAMINE AND REPAIR THE APPLICABLE CIRCUIT (WDM 28-41-11). 3. FOR AIRPLANES WITH UNITS IN KGS, MEASURE THE RESISTANCE BETWEEN THE KGS PIN, E9, TO LBS/KGS COM PIN, C9, ON THE PROCESSOR RACK, CONNECTOR D2440A (WDM 28-41-11). A. IF THE RESISTANCE IS MORE THAN 10 OHMS, EXAMINE AND REPAIR THE APPLICABLE CIRCUIT (WDM 28-41-11). 4. IF THE RESISTANCE IS LESS THAN 10 OHMS IN STEPS 2 OR 3, REPLACE THE FQIS PROCESSOR, M121 (AMM 28-41-08/401). 5. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?".	

Fault Messages
 Figure 108 (Sheet 28)

EFFECTIVITY
 GUI 001-114, 116-999

28-41-00
 CONFIG 2
 Page 176
 May 28/06


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	28
** IFQC LB/KG CIRCUIT FAIL G##.	
FAULT CONDITION	
THE APPLICABLE IFQC CIRCUIT BOARD CANNOT READ THE POUNDS OR KILOGRAMS INPUT.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
- NORMAL OPERATION - POUND OR KILOGRAM STATUS IS COMES FROM DATA IN NONVOLATILE MEMORY	
CORRECTION	
1. REPLACE THE FQIS PROCESSOR, M121 (AMM 28-41-08/401). 2. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 3. IF THE PROBLEM CONTINUES, DO THE CORRECTION FOR THE FAULT MESSAGE "LB/KG_INPUT_FAILED", SEE FIG. 106.	

Fault Messages
Figure 108 (Sheet 29)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
 CONFIG 2
 Page 177
 May 28/06


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	29
IOC 1 DISCRETE DRIVER FAIL G##.	
FAULT CONDITION	
THE INPUTS AIR/GROUND AND LB/KG CANNOT BE READ BY THE FQIS PROCESSOR.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - NORMAL OPERATION - THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" SHOWS. 	
CORRECTION	
<ol style="list-style-type: none"> 1. REPLACE THE FQIS PROCESSOR, M121 (AMM 28-41-08/401). 2. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 3. IF THE FAULT MESSAGE CONTINUES TO SHOW, EXAMINE AND REPAIR THE APPLICABLE AIR/GND OR LB/KG CIRCUIT (WDM 28-41-14). 4. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	
FAULT MESSAGE	30
LOAD SELECT UNIT OR WIRE FAIL G##.	
FAULT CONDITION	
THE FQIS PROCESSOR CANNOT READ THE LOAD SELECT CONTROL UNIT BECAUSE OF A CONTROL UNIT FAILURE OR A WIRING FAULT.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - FUELING MUST BE DONE MANUALLY - IF YOU PUSH THE SET SWITCH FOR THE LOAD SELECT CONTROL, "FAIL" WILL SHOW ON THE LOWER LOAD SELECT INDICATOR DISPLAY. 	
CORRECTION	
<ol style="list-style-type: none"> 1. REPLACE THE LOAD SELECT CONTROL, M638 (AMM 28-41-07/401). 2. IF THE FAULT MESSAGE CONTINUES TO SHOW, DO A CHECK OF THE LOAD SELECT WIRING BETWEEN THE LOAD SELECT CONTROL AND THE FQIS PROCESSOR, M121 (WDM 28-21-22). 3. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
Figure 108 (Sheet 30)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
 CONFIG 2
 Page 178
 May 28/06


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	31
IOC # (1 OR 2) FAILED G##.	
FAULT CONDITION	
THIS FAULT MESSAGE SHOWS A FAILURE OF THE APPLICABLE INPUT/OUTPUT CARD (IOC) OR ARINC BUS FAILURE.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - THE EICAS STATUS MESSAGE "FUEL QTY BITE" SHOWS. - AUTOMATIC REFUELING NOT AVAILABLE - "FAIL" SHOWS ON THE LOAD SELECT INDICATOR DISPLAY IF YOU TRY AUTOMATIC REFUELING. 	
CORRECTION	
<ol style="list-style-type: none"> 1. REPLACE THE FQIS PROCESSOR, M121 (AMM 28-41-08/401). 2. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 3. IF THE FAULT MESSAGE CONTINUES TO SHOW DO A CHECK OF THE WIRING BETWEEN THE FQIS PROCESSOR, M121, AND THE FUEL QUANTITY INDICATORS AS FOLLOWS (WDM 28-41-11): <ol style="list-style-type: none"> A. FLIGHT COMPARTMENT IND M10054 B. FUELING PANEL IND N10038 C. FUELING PANEL IND N10039 D. FUELING PANEL IND N10040. 4. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	
FAULT MESSAGE	32
VOLUME SHUTOFF OF ** AT 95% G##.	
FAULT CONDITION	
THERE IS A SYSTEM FAILURE THAT RESULTS IN FUEL SHUTOFF DURING FUELING AT 95% OF FULL TO PREVENT FUEL SPILLS.	
<u>NOTE:</u> FOR MANUAL OR AUTOMATIC REFUELING THE AFFECTED FUEL TANK CAN BE REFUELED TO 5% LESS THAN FULL.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
- REFUELING WILL STOP AT 5% BELOW THE VOLUMETRIC SHUTOFF (VSO) POINT.	
CORRECTION	
<ol style="list-style-type: none"> 1. DO THE CORRECTIONS FOR THESE FAULT MESSAGES SHOWN IN THE PRESENT FAULTS MENU AND THE FAULT HISTORY MENU, FLIGHT LEG O. 2. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?", TO MAKE SURE THERE ARE NO FAULT MESSAGES SHOWN. <p style="margin-left: 20px;"><u>NOTE:</u> YOU CAN REFUEL MANUALLY (AMM 12-11-01/301).</p> 3. THE REFUEL VALVE CAN BE CLOSED AND "PUSH SET" CAN SHOW ON REFUEL PANEL INDICATOR. IF YOU PUSH THE "SET" SWITCH, THE REFUEL VALVE WILL OPEN, AND YOU CAN CONTROL THE VALVE MANUALLY. <p style="margin-left: 20px;"><u>NOTE:</u> THE FQIS WILL NOT CLOSE THE REFUEL VALVE, AND THE FQIS FUEL QUANTITY INDICATION WILL FLASH ON AND OFF.</p> 	

Fault Messages
Figure 108 (Sheet 31)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
 CONFIG 2
 Page 179
 May 28/06


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	33
VOLUME SHUTOFF OF ** AT 87% G##.	
FAULT CONDITION	
THERE IS A SYSTEM FAILURE THAT RESULTS IN FUEL SHUTOFF DURING FUELING AT 95% OF FULL. <u>NOTE:</u> FOR MANUAL OR AUTOMATIC REFUELING THE AFFECTED FUEL TANK CAN BE REFUELED TO A QUANTITY 13% LESS THAN EXPECTED.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
- THE EICAS STATUS MESSAGE "FUEL QTY BITE" SHOWS. - REFUELING WILL STOP AT 13% BELOW THE VOLUMETRIC SHUTOFF (VSO) POINT.	
CORRECTION	
1. DO THE CORRECTIONS FOR THESE FAULT MESSAGES SHOWN IN THE PRESENT FAULTS MENU AND THE FAULT HISTORY MENU, FLIGHT LEG 0. 2. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?", TO MAKE SURE THERE ARE NO FAULT MESSAGES SHOWN. <u>NOTE:</u> YOU CAN REFUEL MANUALLY, REFER TO AMM 12-11-01/301. 3. THE REFUEL VALVE CAN BE CLOSED AND "PUSH SET" CAN SHOW ON REFUEL PANEL INDICATOR. IF YOU PUSH THE "SET" SWITCH, THE REFUEL VALVE WILL OPEN, AND YOU CAN CONTROL THE VALVE MANUALLY. <u>NOTE:</u> THE FQIS WILL NOT CLOSE THE REFUEL VALVE, AND THE FQIS FUEL QUANTITY INDICATION WILL FLASH ON AND OFF.	

Fault Messages
Figure 108 (Sheet 32)

EFFECTIVITY
GUI 001-114, 116-999

896460

28-41-00
 CONFIG 2
 Page 180
 May 28/06


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	34
BITE DISPLAY BOARD FAILED G##.	
FAULT CONDITION	
THIS MESSAGES SHOWS ON THE FQIS PROCESSOR ONLY. THIS MESSAGE SHOWS THAT THE FQIS BITE DISPLAY BOARD (BDB) IS FAILED.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" CAN SHOW. - SELF-TEST FROM FQIS PROCESSOR MENU BOARD MAY NOT OPERATE - FAULT MESSAGES MAY NOT BE STORED OR SHOWN CORRECTLY - THE EICAS STATUS MESSAGE "FUEL QTY BITE" SHOWS. <p><u>NOTE:</u> IF THIS MESSAGE SHOWS GO TO STEP 3.</p>	
CORRECTION	
<ol style="list-style-type: none"> 1. REPLACE THE FQIS PROCESSOR, M121 (AMM 28-41-08/401). 2. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". <p><u>NOTE:</u> THIS PROBLEM ONLY AFFECTS THE BDB DISPLAY. THE FUEL QUANTITY INFORMATION IS NOT AFFECTED. THE FQIS PROCESSOR REPLACEMENT MAY BE DONE AT A LATER TIME, BUT IF ANOTHER FQIS SYSTEM FAULT OCCURS IT WILL POSSIBLY NOT BE CORRECTLY RECORDED OR SHOWN.</p> <ol style="list-style-type: none"> 3. IF THE PROBLEM CONTINUES, DO A CHECK OF THE WIRING BETWEEN THE FQIS PROCESSOR AND THE EICAS COMPUTERS (WDM 28-41-11). 4. REPAIR OR REPLACE THE APPLICABLE WIRING (WDM 28-41-11). 5. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
Figure 108 (Sheet 33)

EFFECTIVITY
GUI 001-114, 116-999

896461


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	35
(THE BITE DISPLAY BOARD IS OFF).	
FAULT CONDITION	
THE BITE DISPLAY IS OFF.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - NORMAL OPERATION - FAULT MESSAGES WILL NOT BE STORED OR SHOWN - FQIS BITE "SELF TEST ?" WILL NOT OPERATE - LOW FUEL AND FUEL CONFIGURATION INDICATIONS WILL NOT OPERATE CORRECTLY 	
CORRECTION	
<ol style="list-style-type: none"> 1. PUSH AND RELEASE THE "ON/OFF" BUTTON ON THE FQIS PROCESSOR CONTROL PANEL. 2. IF THE FQIS PROCESSOR DISPLAY IS OFF, REMOVE THE FQIS PROCESSOR, M121 (AMM 28-41-08/401). 3. DO A TEST AT THE FQIS CONNECTOR TO MAKE SURE THERE IS 28V DC AT THE CONNECTOR AS FOLLOWS (WDM 28-41-11): <ul style="list-style-type: none"> A. CONNECTOR D2440A, PINS J1 AND K1 B. CONNECTOR D2440B, PINS F6 AND G6, J1 AND K1, H10 AND H11. 4. INSTALL THE FQIS PROCESSOR, M121 (AMM 28-41-08/401). 5. PUSH AND RELEASE THE "ON/OFF" BUTTON ON THE FQIS PROCESSOR CONTROL PANEL. 6. IF THE PROBLEM CONTINUES, REPLACE THE FQIS PROCESSOR, M121 (AMM 28-41-08/401). 7. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
Figure 108 (Sheet 34)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
 CONFIG 2
 Page 180B
 May 28/06


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	36
ARINC BUS (A OR B) FAILED G##.	
FAULT CONDITION	
THE ARINC BUS A OR B WIRES OR THE PROCESSOR ARE BAD.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
- NORMAL OPERATION, ON THE CHANNEL THAT IS GOOD. - THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" CAN SHOW.	
CORRECTION	
1. REPLACE THE FQIS PROCESSOR, M121 (AMM 28-41-08/401). 2. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 3. IF THE FAULT MESSAGE CONTINUES TO SHOW, DO A CONTINUITY CHECK OF THE ARINC WIRES. A. DO A CONTINUITY TEST OF THE WIRES BETWEEN THE PROCESSOR, M121, AND THE LOAD SELECT INDICATORS AND THE FUEL QUANTITY INDICATOR, M10054 (WDM 28-41-11). B. DO A CONTINUITY TEST OF THE WIRES BETWEEN THE PROCESSOR, M121, AND THE LOAD SELECT CONTROL UNIT, M638 (WDM 28-21-22). C. REPLACE OR REPAIR THE WIRES AS NECESSARY. 4. IF THE ARINC WIRES ARE OK, REPLACE THE FUEL QUANTITY INDICATOR, M10054 (AMM 28-41-04/401). 5. IF THE PROBLEM CONTINUES, REPLACE THE LOAD SELECT CONTROL, M638 (AMM 28-41-07/401). 6. IF THE PROBLEM CONTINUES, REPLACE THE LOAD SELECT INDICATORS (AMM 28-41-06/401). 7. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?".	

Fault Messages
Figure 108 (Sheet 35)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
 CONFIG 2
 Page 180C
 May 28/06


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	37
<p>** TU ?? SHORTED TO GROUND G##.</p>	
FAULT CONDITION	
<p>THERE IS MORE THAN 1.7 MILLIAMPS OF CURRENT FLOW IN ONE OR MORE LOW Z CIRCUIT(S), AND THE DRIVE VOLTAGE TO ONE OR MORE TANK UNITS HAS DECREASED ENOUGH TO AFFECT THE MEASURED VALUE OF THE TANK UNIT CAPACITANCE. THIS FAULT PREVENTS FAULT ISOLATION TO ONE TANK UNIT BY THE FQIS PROCESSOR.</p>	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - NORMAL OPERATION WITH AN INDICATION ERROR FOR FUEL QUANTITY OF ±5% FOR THE APPLICABLE TANK (ONLY ONE TANK UNIT CAN BE BAD). - THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" CAN SHOW. - IF THERE IS MORE THAN ONE ELECTRICAL SHORT THE FUEL QUANTITY INDICATION WILL GO OFF FOR THE APPLICABLE FUEL TANK, THE TOTAL FUEL QUANTITY INDICATION WILL GO OFF (FUEL QTY IND, M10054), AND THE EICAS STATUS MESSAGE "FUEL QTY IND" SHOWS. - THE REFUEL OPERATION CAN STOP AT 5% LESS THAN THE VSO. THIS WILL PREVENT ACCIDENTAL FUEL SPILL. - THE REFUEL OPERATION CAN STOP AT 5% LESS THAN THE AUTOMATIC SET VALUE. - IF THERE IS MORE THAN ONE ELECTRICAL SHORT WHILE FUELING, THE FUELING SHUTOFF VALVE CLOSES FOR THE APPLICABLE FUEL TANK. THE "PUSH SET" MESSAGE WILL SHOW ON THE FUEL QUANTITY INDICATORS ON THE FUELING CONTROL PANEL, P28, REFER TO AMM 12-11-01/301 TO CONTINUE FUELING. THE FUEL QUANTITY INDICATOR, M10054, WILL ALSO GO OFF. 	
CORRECTION	
<ol style="list-style-type: none"> 1. OPEN THE HI-Z/LO-Z CONNECTOR FOR THE APPLICABLE FUEL TANK, SEE FIG. 107. 2. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?" 3. IF THE FAULT MESSAGE CONTINUES TO SHOW WHEN THE HI-Z/LO-Z CONNECTOR IS OPEN, THEN THE PROBLEM IS BETWEEN THE FQIS PROCESSOR AND THE HI-Z/LO-Z CONNECTOR AT THE FRONT SPAR. <p style="margin-left: 20px;"><u>NOTE:</u> THE OTHER TANK UNITS AND COMPENSATOR WILL SHOW THE OPEN LO-Z OR HI-Z FAULT MESSAGE AND THE OPEN HI-Z AT SPAR FAULT MESSAGE WILL SHOW, WHEN THE SPAR CONNECTOR IS OPEN. IGNORE THESE OPEN FAULT MESSAGES.</p> 4. EXAMINE THE WIRING TO FIND THE TANK UNIT LO-Z SHORT TO GROUND AND REPAIR OR REPLACE THE APPLICABLE WIRING (WDM 28-41-21,-31,-41). 5. IF THE PROBLEM GOES AWAY THE SHORTED CIRCUIT IS IN THE FUEL TANK. 6. MEASURE THE RESISTANCE OF EACH TANK UNIT AT THE APPLICABLE SPAR CONNECTOR TO FIND THE SHORT (AMM 28-41-00/501). USE THE 757/767-1 TESTER TO MEASURE THE RESISTANCE OF THE LO-Z AND HI-Z WIRES. 7. GO INTO THE APPLICABLE FUEL TANK (AMM 28-11-00/201). 8. EXAMINE AND REPLACE THE APPLICABLE TANK UNIT (AMM 28-41-01/401). <p style="margin-left: 20px;"><u>NOTE:</u> MAKE SURE THE TANK UNIT HAS CLEARANCE FROM THE AIRPLANE STRUCTURE.</p> 9. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 10. IF THE PROBLEM CONTINUES, EXAMINE AND REPLACE THE APPLICABLE TANK WIRING HARNESS (WDM 28-41-21,-31,-41). 11. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
Figure 108 (Sheet 36)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
 CONFIG 2
 Page 180D
 May 28/06

NOTE 1: THE PRIMARY SOURCE OF FAILURE CAN BE DAMAGE TO THE HI-Z/LO-Z PLUG ON THE AIRPLANE WIRING HARNESS. LOOK AT THE HI-Z/LO-Z PLUG BEFORE YOU DO A CHECK OF AN AIRPLANE WIRING HARNESS.

NOTE 2: THE "DRY CAPACITANCE TEST IN THE MAIN EQUIPMENT CENTER (NO FUEL IN THE TANK)" IS A TEST BETWEEN THE FUEL TANK AND THE MAIN EQUIPMENT CENTER.

1. DRY CAPACITANCE TEST IN THE MAIN EQUIPMENT CENTER WITH THE FQPU (NO FUEL IN THE TANK)

- A. DEFUEL THE APPLICABLE FUEL TANK (AMM 28-26-00/201).
- B. DRAIN AND PURGE THE APPLICABLE FUEL TANK (AMM 28-11-00/201).
- C. PUSH THE "ON/OFF" BUTTON ON THE FQIS PROCESSOR, M121.
- D. CONTINUE PUSH AND RELEASE THE "NO" BUTTON UNTIL THE "SYSTEM DATA?" MENU SHOWS.
- E. PUSH AND RELEASE THE "YES" BUTTON TO SEE THE SYSTEM DATA.
- F. PUSH THE "NO" BUTTON WHEN THE "UPLIFT DATA?" MESSAGE SHOWS ON THE DISPLAY.
- G. WHEN THE MESSAGE "MAIN TANKS DATA?" SHOWS PUSH AND RELEASE THE "YES" BUTTON.

NOTE: THIS MENU LIST WILL SHOW THE LEFT AND RIGHT MAIN FUEL TANK CAPACITANCE DATA.

- H. MAKE A WRITTEN RECORD OF THE LEFT AND RIGHT MAIN TANK CAPACITANCE VALUES.
- I. CONTINUE TO PUSH AND RELEASE THE "DOWN" BUTTON UNTIL THE "END OF MAIN TANKS DATA?" SHOWS ON THE DISPLAY.
- J. PUSH AND RELEASE THE "DOWN" BUTTON TO SEE THE CENTER TANK DATA.
- K. WHEN THE MESSAGE "CENTER TANK DATA?" SHOWS PUSH AND RELEASE THE "YES" BUTTON.

NOTE: THIS MENU LIST WILL SHOW THE CENTER FUEL TANK CAPACITANCE DATA.

- L. MAKE A WRITTEN RECORD OF THE CENTER TANK CAPACITANCE VALUES.
- M. CONTINUE TO PUSH AND RELEASE THE "DOWN" BUTTON UNTIL THE "END OF CTR TANK DATA?" SHOWS ON THE DISPLAY.
- N. IF THE CAPACITANCE VALUES ARE NOT IN THE LIMITS SHOWN IN FIG. 109, SHT. 4, DO THE STEPS THAT FOLLOW:
 - (1) REMOVE THE HI-Z/LO-Z PLUG FOR THE APPLICABLE FUEL TANK. EXAMINE THE APPLICABLE CONNECTOR FOR DAMAGE.
 - (a) IF THE CAPACITANCE VALUE CHANGES AFTER YOU INSTALL THE HI-Z/LO-Z PLUG, REPAIR OR REPLACE THE DEFECTIVE PIN ON THE HI-Z/LO-Z PLUG (WDM 28-41-21,-31,-41).
 - (b) IF THE CAPACITANCE VALUE DOES NOT CHANGE AFTER YOU INSTALL THE HI-Z/LO-Z PLUG, DO THE STEPS THAT FOLLOW:
 - 1) LOOK FOR DAMAGE ON THE TANK WIRING HARNESS BETWEEN THE HI-Z/LO-Z RECEPTACLE AND THE TANK UNIT OR COMPENSATOR.
 - 2) DO A CHECK ON THE TANK UNIT OR COMPENSATOR FOR A POSSIBLE SHORT TO GROUND. REPAIR OR REPLACE THE TANK UNIT (AMM 28-41-01/401), OR THE TANK WIRING HARNESS (AMM 28-41-09/401) IF IT IS NECESSARY.
 - (2) DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?".
- O. IF THE CAPACITANCE VALUES ARE IN THE LIMITS SHOWN IN FIG. 109, SHT. 4, THE FQIS IS OK.

Dry Capacitance Test in the Main Equipment Center (No Fuel in the Tank)
Figure 109 (Sheet 1)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
CONFIG 2
Page 180E
May 28/06

 **BOEING**
757
FAULT ISOLATION/MAINT MANUAL

NOTE 1: THE PRIMARY SOURCE OF FAILURE CAN BE DAMAGE TO THE HI-Z/LO-Z PLUG ON THE AIRPLANE WIRING HARNESS. LOOK AT THE HI-Z/LO-Z PLUG BEFORE YOU DO A CHECK OF AN AIRPLANE WIRING HARNESS.

NOTE 2: THE "DRY CAPACITANCE TEST IN THE MAIN EQUIPMENT CENTER (NO FUEL IN THE TANK)" IS A TEST BETWEEN THE FUEL TANK AND THE MAIN EQUIPMENT CENTER.

EQUIPMENT:

JcAIR, INC.
400 INDUSTRIAL PARKWAY
INDUSTRIAL AIRPORT, KS 66031


- A. FUEL QTY TEST SET -
P/N 472090-007, OR P/N 472090-009, OR PSD 40-1, OR PSD 60-1, OR PSD 60-2,
OR PSD 60-2R
- B. FUEL QTY ADAPTER HARNESS -
LEFT/RIGHT MAIN FUEL TANK - PSD 757/767-101
CENTER FUEL TANK - PSD 757/767-102
DENSITOMETER - PSD 757/767-103
- C. TEST BOX, FQIS - PSD 757/767-1

1. DRY CAPACITANCE TEST IN THE MAIN EQUIPMENT CENTER WITH THE PSD 757/767-1 TESTER (NO FUEL IN THE TANK)
- A. DEFUEL THE APPLICABLE FUEL TANK (AMM 28-26-00/201).
 - B. DRAIN AND PURGE THE APPLICABLE FUEL TANK (AMM 28-11-00/201).
 - C. REMOVE THE PROCESSOR (FQPU), M121 (AMM 28-41-08/401).
 - D. INSTALL THE PSD 757/767-1 TESTER AND LOOK AT THE CAPACITANCE VALUES FOR ALL THE TANK UNITS AND THE COMPENSATOR IN THE APPLICABLE TANK.
 - E. MAKE A WRITTEN RECORD OF THE CAPACITANCE VALUES.
 - F. IF THE CAPACITANCE VALUES ARE NOT IN THE LIMITS SHOWN IN FIG. 109, SHT. 4, DO THE STEPS THAT FOLLOW:
 - (1) REMOVE THE HI-Z/LO-Z PLUG FOR THE APPLICABLE FUEL TANK. EXAMINE THE APPLICABLE HI-Z/LO-Z CONNECTOR FOR DAMAGE.
 - (a) IF THE CAPACITANCE VALUE CHANGES WHEN YOU INSTALL THE HI-Z/LO-Z PLUG, REPAIR OR REPLACE THE DEFECTIVE PIN ON THE HI-Z/LO-Z PLUG (WDM 28-41-21,-31,-41).
 - (b) IF THE CAPACITANCE VALUE DOES NOT CHANGE AFTER YOU INSTALL THE HI-Z/LO-Z PLUG, DO THE STEPS THAT FOLLOW:
 - 1) LOOK FOR DAMAGE ON THE TANK WIRING HARNESS BETWEEN THE HI-Z/LO-Z RECEPTACLE AND THE TANK UNIT OR COMPENSATOR.
 - 2) DO A CHECK ON THE TANK UNIT OR COMPENSATOR FOR A POSSIBLE SHORT TO GROUND REPAIR OR REPLACE THE TANK UNIT (AMM 28-41-01/401), OR THE TANK WIRING HARNESS (AMM 28-41-09/401) IF IT IS NECESSARY.
 - (2) REMOVE THE TEST EQUIPMENT AND INSTALL THE FQPU, M121 (AMM 28-41-08/401).
 - (3) DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?".
 - G. IF THE CAPACITANCE VALUES ARE IN THE LIMITS SHOWN IN FIG. 109, SHT. 4, THE FQIS IS OK.

Dry Capacitance Test in the Main Equipment Center (No Fuel in the Tank)
Figure 109 (Sheet 2)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
CONFIG 2
Page 180F
May 28/06



Dry Capacitance Test in the Main Equipment Center (No Fuel in the Tank)
Figure 109 (Sheet 3)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00

CONFIG 2
Page 180G
May 28/06

 **BOEING**
757
FAULT ISOLATION/MAINT MANUAL

TANK UNIT OR COMPENSATOR UNDER TEST	MINIMUM CAPACITANCE (PICOFARADS)	MAXIMUM CAPACITANCE (PICOFARADS)	EQUIP. NO.
CENTER TANK UNIT NO. 1	81.23	82.61	TS5011
CENTER TANK UNIT NO. 2	90.04	91.56	TS5012
CENTER TANK UNIT NO. 3	70.12	71.36	TS5013
CENTER TANK UNIT NO. 4	57.07	58.09	TS5014
CENTER TANK UNIT NO. 5	54.97	55.87	TS5015
CENTER TANK UNIT NO. 6	90.04	91.56	TS5016
CENTER TANK UNIT NO. 7	70.12	71.36	TS5017
CENTER TANK UNIT NO. 8	57.07	58.09	TS5075
CENTER TANK UNIT NO. 9	54.97	55.87	TS5076
COMPENSATOR - CENTER TANK	50.8	51.4	TS5010
COMPENSATOR - LEFT MAIN TANK	50.8	51.4	TS108
COMPENSATOR - RIGHT MAIN TANK	50.8	51.4	TS119
LEFT MAIN TANK UNIT NO. 1	53.47	54.35	TS109
LEFT MAIN TANK UNIT NO. 2	51.42	52.28	TS110
LEFT MAIN TANK UNIT NO. 3	42.86	43.60	TS111
LEFT MAIN TANK UNIT NO. 4	41.16	41.84	TS112
LEFT MAIN TANK UNIT NO. 5	32.68	33.18	TS113
LEFT MAIN TANK UNIT NO. 6	32.62	33.12	TS114
LEFT MAIN TANK UNIT NO. 7	28.91	29.37	TS115
LEFT MAIN TANK UNIT NO. 8	28.20	28.66	TS116
LEFT MAIN TANK UNIT NO. 9	26.81	27.25	TS117
LEFT MAIN TANK UNIT NO. 10	23.52	23.90	TS118
LEFT MAIN TANK UNIT NO. 11	20.35	20.69	TS5196
LEFT MAIN TANK UNIT NO. 12	20.35	20.69	TS5197
RIGHT MAIN TANK UNIT NO. 1	53.47	54.35	TS146
RIGHT MAIN TANK UNIT NO. 2	51.42	52.28	TS147
RIGHT MAIN TANK UNIT NO. 3	42.86	43.60	TS148
RIGHT MAIN TANK UNIT NO. 4	41.16	41.84	TS149
RIGHT MAIN TANK UNIT NO. 5	32.68	33.18	TS150
RIGHT MAIN TANK UNIT NO. 6	32.62	33.12	TS151
RIGHT MAIN TANK UNIT NO. 7	28.91	29.37	TS152
RIGHT MAIN TANK UNIT NO. 8	28.20	28.66	TS153
RIGHT MAIN TANK UNIT NO. 9	26.81	27.25	TS154
RIGHT MAIN TANK UNIT NO. 10	23.52	23.90	TS155
RIGHT MAIN TANK UNIT NO. 11	20.35	20.69	TS5198
RIGHT MAIN TANK UNIT NO. 12	20.35	20.69	TS5199

Dry Capacitance Test in the Main Equipment Center (No Fuel in the Tank)
Figure 109 (Sheet 4)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
CONFIG 2
Page 180H
May 28/06

1. GENERAL
 - A. THE FAULT MESSAGES THAT FOLLOW ARE CONSIDERED INTERMITTENT IF THERE ARE NO FAULT MESSAGES IN THE PRESENT FAULTS MENU AND THERE ARE NO REPORTS THAT THE FQIS TANK INDICATIONS HAVE BLANKED.
 - B. THESE INTERMITTENT MESSAGES CAN SHOW ON THE 757 EICAS:
 1. EICAS MAINTENANCE MESSAGE "FUEL QUANTITY BITE"
 2. EICAS STATUS MESSAGE "FUEL QUANTITY CHAN"THESE MESSAGES CAN BE CAUSED BY INTERMITTENT BUILT-IN-TEST (BIT) FAULT MESSAGES FROM THE FUEL QUANTITY INDICATING SYSTEM (FQIS).
 - C. THIS SERVICE INFORMATION APPLIES TO AIRPLANES WITH THE FQIS PROCESSOR, PART NUMBERS 30071-0101,-0202,-0303 BOEING PART NUMBERS S345N001-030,-031,-032 (MANUFACTURED BY SIMMONDS PRECISION).
 - D. THE 757 FQIS BIT IN THE PROCESSOR CAN SHOW 37 FAULT MESSAGES. ALL OF THESE FAULT MESSAGES WILL CAUSE A "FUEL QTY BITE" MESSAGE ON THE EICAS MAINTENANCE PAGE. THESE FAULT MESSAGES CAN ALSO CAUSE A "FUEL QTY CHAN", "FUEL QTY IND" OR "FUEL QTY BITE" MESSAGE ON THE EICAS STATUS PAGE. TO REMOVE THE EICAS MESSAGES, YOU MUST GO TO THE BITE PANEL ON THE PROCESSOR AND LOOK AT THE FAULT MESSAGES AS FOLLOWS (SEE FIG. 104):
 1. YOU MUST GO TO THE "PRESENT FAULTS ?" MENU AND LOOK AT THE FAULT MESSAGES STORED IN MEMORY. IF THERE ARE FAULT MESSAGES IN THE PRESENT FAULTS MENU, YOU MUST CORRECT THESE FAULTS TO REMOVE THE EICAS MESSAGE(S).
 2. YOU MUST ALSO GO TO THE "FAULT HISTORY ?" MENU ON THE BITE PANEL OF THE PROCESSOR AND LOOK AT THE FAULT MESSAGES STORED IN MEMORY FOR THE FLIGHT LEG 00.
- NOTE:** AIRPLANES WITH PROCESSOR 300 71-0101 (S345N001-030);
POWER INTERRUPT CAN RESET EICAS MESSAGES IF THERE ARE FAULTS IN
FLIGHT LEG 00.

Intermittent Fault Messages
Figure 110 (Sheet 1)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
CONFIG 2
Page 180I
May 28/06


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	FLIGHT DECK INDICATION OR POSSIBLE CAUSE FOR INTERMITTENT FAULT MESSAGE	CORRECTION
LM IFQC CIRCUIT BOARD FAILED	FOR A POWER BUS TRANSFER OR POWER INTERRUPTION, THESE FAULT MESSAGES CAN CAUSE AN EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" TO SHOW. <u>NOTE:</u> ONLY THE "IOC NUMBER 1 (OR 2) FAILED" MESSAGE WILL CAUSE A "FUEL QUANTITY CHAN" STATUS MESSAGE TO SHOW ON EICAS.	GO TO THE FQIS PROCESSOR BITE PANEL AND DO THE STEPS IN STEP 1.C.
RM IFQC CIRCUIT BOARD FAILED		
CT IFQC CIRCUIT BOARD FAILED		
IOC NUMBER 1 FAILED		
IOC NUMBER 2 FAILED		
LOAD SELECT UNIT OR WIRE FAIL		
IOC 1 DISCRETE DRIVE FAIL		
VOLUME SHUTOFF OF LM AT 95%	THESE MESSAGES CAN SHOW IF POWER IS APPLIED TO THE FQIS (POWER-UP) WHEN THE MAIN TANKS ARE EMPTY, OR WHEN THE CENTER TANK IS LESS THAN 17% FULL BEFORE REFUELING.	IF THESE MESSAGES ONLY SHOW ONE TIME, FUEL QUANTITY INDICATION OR REFUELING WILL NOT BE AFFECTED. IGNORE THE FAULT MESSAGE IN THE FAULT HISTORY MENU.
VOLUME SHUTOFF OF RM AT 95%		
VOLUME SHUTOFF OF CT AT 95%		
LM TU (1-12) CONTAMINATED	THESE MESSAGES CAN SHOW IN THE "FAULT HISTORY ?" MENU OF THE FQIS PROCESSOR BIT.	GO TO FIG. 104, SHEET 1, NOTES 1 AND 2 FOR CORRECTIVE ACTION.
RM TU (1-12) CONTAMINATED		
CT TU (1-12) CONTAMINATED		
LM COMPENSATOR CONTAMINATED		
RM COMPENSATOR CONTAMINATED		
CT COMPENSATOR CONTAMINATED		
AIR/GROUND INPUT FAILED	WHEN THE AIRPLANE IS OPERATED ON BATTERY POWER ON THE GROUND, THIS FAULT MESSAGE WILL SHOW.	IF THE AIRPLANE IS OPERATED ON BATTERY POWER (I.E., BATTERY POWERED REFUELING) AND THIS FAULT MESSAGE SHOWS IN THE FAULT HISTORY MENU, IGNORE THE FAULT MESSAGE.

INTERMITTENT FAULT MESSAGES FOR PROCESSOR S345N001-030

Intermittent Fault Messages
Figure 110 (Sheet 2)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
 CONFIG 2
 Page 180J
 May 28/06


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	FLIGHT DECK INDICATION OR POSSIBLE CAUSE FOR INTERMITTENT FAULT MESSAGE	CORRECTION
LM IFQC CIRCUIT BOARD FAILED	FOR A POWER BUS TRANSFER OR POWER INTERRUPTION, THESE FAULT MESSAGES CAN CAUSE AN EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" TO SHOW. <u>NOTE:</u> ONLY THE "IOC NUMBER 1 (OR 2) FAILED" MESSAGE WILL CAUSE A "FUEL QUANTITY CHAN" STATUS MESSAGE TO SHOW ON EICAS.	GO TO THE FQIS PROCESSOR BITE PANEL AND DO THE STEPS IN STEP 1.C.
RM IFQC CIRCUIT BOARD FAILED		
CT IFQC CIRCUIT BOARD FAILED		
IOC NUMBER 1 FAILED		
IOC NUMBER 2 FAILED		
IOC 1 DISCRETE DRIVE FAIL		
LM TU (1-12) CONTAMINATED	THESE MESSAGES CAN SHOW IN THE "FAULT HISTORY ?" MENU OF THE FQIS PROCESSOR BIT.	GO TO FIG. 104, SHEET 1, NOTES 1 AND 2 FOR CORRECTIVE ACTION.
RM TU (1-12) CONTAMINATED		
CT TU (1-12) CONTAMINATED		
LM COMPENSATOR CONTAMINATED		
RM COMPENSATOR CONTAMINATED		
CT COMPENSATOR CONTAMINATED		
AIR/GROUND INPUT FAILED	WHEN THE AIRPLANE IS OPERATED ON BATTERY POWER ON THE GROUND, THIS FAULT MESSAGE WILL SHOW.	IF THE AIRPLANE IS OPERATED ON BATTERY POWER (I.E., BATTERY POWERED REFUELING) AND THIS FAULT MESSAGE SHOWS IN THE FAULT HISTORY MENU, IGNORE THE FAULT MESSAGE.

INTERMITTENT FAULT MESSAGES FOR PROCESSOR S345N001-031

Intermittent Fault Messages
Figure 110 (Sheet 3)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
 CONFIG 2
 Page 180K
 May 28/06


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	FLIGHT DECK INDICATION OR POSSIBLE CAUSE FOR INTERMITTENT FAULT MESSAGE	CORRECTION
LM IFQC CIRCUIT BOARD FAILED	FOR A POWER BUS TRANSFER OR POWER INTERRUPTION, THESE FAULT MESSAGES CAN CAUSE AN EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" TO SHOW. <u>NOTE:</u> ONLY THE "IOC NUMBER 1 (OR 2) FAILED" MESSAGE WILL CAUSE A "FUEL QUANTITY CHAN" STATUS MESSAGE TO SHOW ON EICAS.	GO TO THE FQIS PROCESSOR BITE PANEL AND DO THE STEPS IN STEP 1.C.
RM IFQC CIRCUIT BOARD FAILED		
CT IFQC CIRCUIT BOARD FAILED		
IOC NUMBER 1 FAILED		
IOC NUMBER 2 FAILED		
IOC 1 DISCRETE DRIVE FAIL		
LM TU (1-12) CONTAMINATED	THESE MESSAGES CAN SHOW IN THE "FAULT HISTORY ?" MENU OF THE FQIS PROCESSOR BIT.	GO TO FIG. 104, SHEET 1, NOTES 1 AND 2 FOR CORRECTIVE ACTION.
RM TU (1-12) CONTAMINATED		
CT TU (1-12) CONTAMINATED		
LM COMPENSATOR CONTAMINATED		
RM COMPENSATOR CONTAMINATED		
CT COMPENSATOR CONTAMINATED		

INTERMITTENT FAULT MESSAGES FOR PROCESSOR S345N001-032

Intermittent Fault Messages
Figure 110 (Sheet 4)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
 CONFIG 2
 Page 180L
 May 28/06


PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
6E4, 11C34, 11M19, 34L2

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)

WARNING: TO OPERATE ANY OF THE FUEL PUMPS, YOU MUST BE IN THE FLIGHT COMPARTMENT TO CONTINUOUSLY MONITOR THE FUEL QUANTITY AND THE LOW PRESSURE INDICATION IN THE FUEL TANK. IMMEDIATELY SET THE APPLICABLE FUEL PUMP SWITCH TO THE OFF POSITION IF THE LOW PRESSURE LIGHT COMES ON AND STAYS ON. FUEL VAPORS IN THE TANK MAY IGNITE AND CAUSE A FIRE OR EXPLOSION.


"FUEL CONFIG"
LIGHT AND EICAS
MESSAGE "FUEL CONFIG"
ARE ILLUMINATED



FUEL CONFIG Light and EICAS Message FUEL CONFIG are Illuminated
Figure 111 (Sheet 1)

EFFECTIVITY
GUI 001-114, 116-999


28-41-00
CONFIG 2
Page 180M
May 28/06



FUEL CONFIG Light and EICAS Message FUEL CONFIG are Illuminated
Figure 111 (Sheet 2)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
CONFIG 2
Page 180N
May 28/06



FUEL CONFIG Light and EICAS Message FUEL CONFIG are Illuminated
Figure 111 (Sheet 3)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
 CONFIG 2
 Page 1800
 May 28/06

Not Used
Figure 112

EFFECTIVITY
GUI 001-114, 116-999

28-41-00

CONFIG 2
Page 180P
May 28/06

Not Used
Figure 113

EFFECTIVITY
GUI 001-114, 116-999


28-41-00

CONFIG 2
Page 180Q
May 28/06

**FUEL QUANTITY
INDICATING MODULE
(FQIM) DOES NOT
DISPLAY CORRECTLY.**

PREREQUISITES
MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
6E4,11C34,11L19,34A10
MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)


NOTE: THE DISPLAY IS NOT CORRECT IF IT IS INTERMITTENT, NOT ACCURATE, OR DOES NOT SHOW PART OR ALL OF NUMBERS.



Fuel Quantity Indicating Module (FQIM) Does Not Display Correctly.
Figure 114 (Sheet 1)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
CONFIG 2
Page 180R
May 28/06




Fuel Quantity Indicating Module (FQIM) Does Not Display Correctly.
Figure 114 (Sheet 2)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
 CONFIG 2
 Page 180S
 May 28/06

"FUEL CONFIG" LIGHT
AND EICAS MSG "LOW
FUEL" NOT DISPLAYED
DURING FUEL QTY TEST

PREREQUISITES
 MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
 6E4,11L19,34A10
 MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
 ELECTRICAL POWER IS ON (AMM 24-22-00/201)



FUEL CONFIG Light and EICAS Msg LOW FUEL Not Displayed during Fuel Qty Test
Figure 115

EFFECTIVITY
GUI 001-114, 116-999


28-41-00
 CONFIG 2
 Page 180T
 May 28/06

TOTAL FUEL QTY DOES NOT AGREE WITH FMC CALCULATED FUEL QTY. FUEL FLOW NORMAL.

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
6E4,11L19,34A10

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)




Total Fuel Qty Does Not Agree with FMC Calculated Fuel Qty. Fuel Flow Normal.
Figure 116 (Sheet 1)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
CONFIG 2
Page 180U
May 28/06

FROM SHEET 1
(BLOCK 3)



Total Fuel Qty Does Not Agree with FMC Calculated Fuel Qty. Fuel Flow Normal.
Figure 116 (Sheet 2)

EFFECTIVITY
GUI 001-114, 116-999


28-41-00
CONFIG 2
Page 180V
May 28/06

EICAS MSG "FUEL QTY IND" OR "FUEL QTY CHANNEL" DISPLAYED.

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
6E4,11C34,11L19,34A10


MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)



EICAS Msg FUEL QTY IND or FUEL QTY CHANNEL Displayed.
Figure 117 (Sheet 1)

EFFECTIVITY
GUI 001-114, 116-999


28-41-00
CONFIG 2
Page 180W
May 28/06



EICAS Msg FUEL QTY IND or FUEL QTY CHANNEL Displayed.
Figure 117 (Sheet 2)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
CONFIG 2
Page 180X
May 28/06



EICAS Msg FUEL QTY IND or FUEL QTY CHANNEL Displayed.
Figure 117 (Sheet 3)

EFFECTIVITY
GUI 001-114, 116-999


28-41-00
 CONFIG 2
 Page 180Y
 May 28/06

LOAD SELECT INDICATOR SHOWS THE MESSAGE "-A.-", OR "-b.-" OR "-A.b" IN THE DISPLAY

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
6E4,11C34,11L19,34A10


MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)



Load Select Indicator Shows the Message "-A.-", or "-b.-" or "-A.b" in the Display Figure 118 (Sheet 1)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
CONFIG 2
Page 180Z
May 28/06



Load Select Indicator Shows the Message "-A.-", or "-b.-" or "-A.b" in the Display
Figure 118 (Sheet 2)

EFFECTIVITY
GUI 001-114, 116-999


28-41-00
 CONFIG 2
 Page 181
 May 28/06

FUEL QUANTITY INDICATING MODULE (FQIM), M10054, SHOWS THE MESSAGE(S) "-A.-", "-b.-" OR "-A.b" IN ONE OR ALL FUEL QUANTITY DISPLAYS

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
6E4,11C34,11L19,34A10


MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)



Fuel Quantity Indicating Module (FQIM), M10054, Shows the Message(s) "-A.-", "-b.-" or "-A.b" in One or All Fuel Quantity Displays
Figure 119 (Sheet 1)

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
CONFIG 2
Page 182
May 28/06



Fuel Quantity Indicating Module (FQIM), M10054, Shows the Message(s) "-A.-", "-b.-"
 or "-A.b" in One or All Fuel Quantity Displays
 Figure 119 (Sheet 2)

EFFECTIVITY
 GUI 001-114, 116-999


28-41-00
 CONFIG 2
 Page 182A
 May 28/06

LOAD SELECT INDICATOR
SHOWS THE MESSAGE
"I.d" IN THE DISPLAY

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
6E4,11C34,11L19,34A10

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)



Load Select Indicator Shows the Message "I.d" in the Display
Figure 120

EFFECTIVITY
GUI 001-114, 116-999

28-41-00
CONFIG 2
Page 182B
May 28/06



757

FAULT ISOLATION/MAINT MANUAL

FUEL QUANTITY INDICATING SYSTEM

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
CIRCUIT BREAKER - FUEL QTY, C1040		1	119BL, MAIN EQUIP CTR, P34 34A10	*
CIRCUIT BREAKER - FUEL QTY - L, C1048		1	FLT COMPT, P11 11C34	*
FUEL QTY - R, C1053		1	11L19	*
CIRCUIT BREAKER - FUELING QTY, C1045		1	FLT COMPT, P6 6E4	*
COMPENSATOR - CENTER TANK, TS5010	8	1	631AB, CENTER FUEL TANK	28-41-02
COMPENSATOR - L MAIN TANK, TS108	8	1	541AB, L MAIN FUEL TANK	28-41-02
COMPENSATOR - R MAIN TANK, TS119	8	1	641AB, R MAIN FUEL TANK	28-41-02
COMPUTER - (FIM 31-41-00/101) EICAS L, M10181 EICAS R, M10182				
DENSITOMETER - CENTER TANK, M10903	12	1	631AB, CENTER FUEL TANK	28-41-03
DENSITOMETER - L MAIN TANK, M10901	12	1	541AB, L MAIN FUEL TANK	28-41-03
DENSITOMETER - R MAIN TANK, M10902	12	1	641AB, R MAIN FUEL TANK	28-41-03
HARNESS - CENTER DENSITOMETER TANK WIRING, M10917	13	1	CENTER MAIN FUEL TANK	28-41-09
HARNESS - L CENTER TANK WIRING, M10294	9	1	CENTER FUEL TANK	28-41-09
HARNESS - L MAIN TANK WIRING, M726	11	1	L MAIN FUEL TANK	28-41-09
HARNESS - LEFT MAIN DENSITOMETER TANK WIRING, M10916	13	1	L MAIN FUEL TANK	28-41-09
HARNESS - R CENTER TANK WIRING, M10137	10	1	CENTER FUEL TANK	28-41-09
HARNESS - R MAIN TANK WIRING, M727	11	1	R MAIN FUEL TANK	28-41-09
HARNESS - RIGHT MAIN DENSITOMETER TANK WIRING, M10918	13	1	R MAIN FUEL TANK	28-41-09
HOT SHORT PROTECTOR, M11872 ¹	14	1	651, R REAR SPAR	28-41-24
INDICATOR - CENTER TANK LOAD SELECT (LSI), N10039	5	1	FUELING CONTROL PANEL, P28	28-41-06
INDICATOR - L MAIN TANK LOAD SELECT (LSI), N10040	5	1	FUELING CONTROL PANEL, P28	28-41-06
INDICATOR - R MAIN TANK LOAD SELECT (LSI), N10038	5	1	FUELING CONTROL PANEL, P28	28-41-06
MODULE - FUEL QUANTITY PROCESSOR (FQPU), M10054	3	1	FLT COMPT, P5	28-41-04
RELAY - (FIM 31-01-33/101) FUEL QTY PWR XFR, K356 FUELING PANEL DOOR, K179 FUELING POWER TRANSFER, K357				
RELAY - (FIM 31-01-36/101) SYS 1 AIR/GND, K140				
RELAY - (FIM 31-01-37/101) SYS 2 AIR/GND, K200				

* SEE THE WDM EQUIPMENT LIST

¹ AIRPLANES POST-SB 28A0085

Fuel Quantity Indicating System - Component Index
Figure 101 (Sheet 1)

EFFECTIVITY
GUI 115

28-41-00

CONFIG 3

03

Page 101

Sep 28/07

1421784



757

FAULT ISOLATION/MAINT MANUAL

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
UNIT - TANK	8	-	LEFT OR RIGHT WING	28-41-01
CENTER TANK NO. 1, TS5011		1	134AZ	
CENTER TANK NO. 2, TS5012		1	531AB	
CENTER TANK NO. 3, TS5013		1	531AB	
CENTER TANK NO. 4, TS5014		1	531BB	
CENTER TANK NO. 5, TS5015		1	531CB	
CENTER TANK NO. 6, TS5016		1	631AB	
CENTER TANK NO. 7, TS5017		1	631AB	
CENTER TANK NO. 8, TS5075		1	631BB	
CENTER TANK NO. 9, TS5076		1	631CB	
L MAIN TANK NO. 1, TS109		1	541AB	
L MAIN TANK NO. 2, TS110		1	541BB	
L MAIN TANK NO. 3, TS111		1	541CB	
L MAIN TANK NO. 4, TS112		1	541DB	
L MAIN TANK NO. 5, TS113		1	541FB	
L MAIN TANK NO. 6, TS114		1	541GB	
L MAIN TANK NO. 7, TS115		1	541HB	
L MAIN TANK NO. 8, TS116		1	541JB	
L MAIN TANK NO. 9, TS117		1	541LB	
L MAIN TANK NO. 10, TS118		1	541MB	
L MAIN TANK NO. 11, TS5196		1	542AB	
L MAIN TANK NO. 12, TS5197		1	542CB	
R MAIN TANK NO. 1, TS146		1	641AB	
R MAIN TANK NO. 2, TS147		1	641BB	
R MAIN TANK NO. 3, TS148		1	641CB	
R MAIN TANK NO. 4, TS149		1	641DB	
R MAIN TANK NO. 5, TS150		1	641FB	
R MAIN TANK NO. 6, TS151		1	641GB	
R MAIN TANK NO. 7, TS152		1	641HB	
R MAIN TANK NO. 8, TS153		1	641JB	
R MAIN TANK NO. 9, TS154		1	641LB	
R MAIN TANK NO. 10, TS155		1	641MB	
R MAIN TANK NO. 11, TS5198		1	642AB	
R MAIN TANK NO. 12, TS5199		1	642CB	


Fuel Quantity Indicating System - Component Index
Figure 101 (Sheet 2)

EFFECTIVITY
GUI 115

28-41-00

CONFIG 3
Page 102
May 28/03

03



Fuel Quantity Indicating System - Component Location
 Figure 102 (Sheet 1)

EFFECTIVITY
GUI 115


28-41-00

CONFIG 3

03

Page 103

May 28/03



Fuel Quantity Indicating System - Component Location
 Figure 102 (Sheet 2)

EFFECTIVITY
GUI 115


28-41-00

CONFIG 3


Page 104

May 28/03

03




FLIGHT COMPARTMENT



FUEL QUANTITY INDICATING MODULE (FQIM), M10054


(A)



FUEL QUANTITY TEST SWITCH, S6

MISCELLANEOUS TEST PANEL, M10398 (REF)
(EXAMPLE PANEL SHOWN)

(B)




EICAS MAINTENANCE PANEL


(C)

1 THE UNITS ARE IN KGS OR LBS.

Fuel Quantity Indicating System - Component Location
Figure 102 (Sheet 3)



MAIN EQUIPMENT CENTER



FQIS PROCESSOR, M121

(C)

INSTRUCTIONS:

- Press ON to start BITE display
- Press YES or NO in response to questions (?)
- Press to display next result
- Press to display previous result
- Press MENU to return to current menu
- Press OFF to stop BITE display

PRIMARY BITE MENU OPTIONS:

- FAULT HISTORY: Displays past faults by flight leg
- SYSTEM DATA: Displays system/LRU Data
- SELF TEST: Tests system/LRUs interfaces
- SYSTEM CONFIG: Displays system configuration
- ERASE FAULT HISTORY:

(D)

Fuel Quantity Indicating System - Component Location
Figure 102 (Sheet 4)

EFFECTIVITY
GUI 115

28-41-00

CONFIG 3

03


Page 106

May 28/03

BOEING

757

FAULT ISOLATION/MAINT MANUAL



RIGHT MAIN TANK LOAD SELECT INDICATOR, N10038

CENTER TANK LOAD SELECT INDICATOR, N10039

BATTERY POWER SWITCH, S345 (REF)

LEFT MAIN TANK LOAD SELECT INDICATOR, N10040

FUELING CONTROL PANEL, P28

(E)

1 THE UNITS ARE IN KGS OR LBS.

Fuel Quantity Indicating System - Component Location
Figure 102 (Sheet 5)


EFFECTIVITY
GUI 115

28-41-00

CONFIG 3
Page 107
May 28/03

03

F76609




Fuel Quantity Indicating System - Component Location
Figure 102 (Sheet 6)

EFFECTIVITY
GUI 115

28-41-00

CONFIG 3
Page 108
May 28/03

03



RIGHT WING

Fuel Quantity Indicating System - Component Location
Figure 102 (Sheet 7)

EFFECTIVITY
GUI 115

AD9387


28-41-00

CONFIG 3

Page 109


May 28/03

03




HI-Z BUSSING PLUG OR LO-Z CONNECTOR

F



TANK UNIT
(EXAMPLE)

G



LEFT MAIN TANK COMPENSATOR, TS108
CENTER TANK COMPENSATOR, TS5010
RIGHT MAIN TANK COMPENSATOR, TS119

H

Fuel Quantity Indicating System - Component Location (Details from Sht 6 and 7)
Figure 102 (Sheet 8)

EFFECTIVITY
GUI 115


28-41-00

CONFIG 3

Page 110

May 28/03

03



LEFT CENTER TANK WIRING HARNESS, M10294

I

Fuel Quantity Indicating System - Component Location (Detail from Sht 6)
Figure 102 (Sheet 9)

EFFECTIVITY
GUI 115

A09389


28-41-00

CONFIG 3

03

Page 111

May 28/03



RIGHT CENTER TANK WIRING HARNESS, M10137

J

**Fuel Quantity Indicating System - Component Location (Detail from Sht 7)
Figure 102 (Sheet 10)**


EFFECTIVITY
GUI 115

28-41-00

CONFIG 3
Page 112
May 28/03

03

BOEING
757
FAULT ISOLATION/MAINT MANUAL



(K)

Fuel Quantity Indicating System - Component Location (Detail from Sht 6 and 7)
Figure 102 (Sheet 11)

EFFECTIVITY
GUI 115

28-41-00

CONFIG 3


03

Page 113


May 28/03

AD9590

BOEING
757
FAULT ISOLATION/MAINT MANUAL



FRONT VIEW



LEFT MAIN, CENTER OR RIGHT MAIN DENSITOMETER, M10901, M10903 OR M10902

(L)


Fuel Quantity Indicating System - Component Location (Detail from Sht 6 and 8)
Figure 102 (Sheet 12)

EFFECTIVITY
GUI 115

28-41-00

CONFIG 3
Page 114
May 28/03


03



LEFT MAIN, RIGHT MAIN OR CENTER DENSITOMETER TANK WIRING HARNESS,
 M10916, M10918, OR M10917

(M)


Fuel Quantity Indicating System - Component Location
 (Detail from Sht 6 and 7)
 Figure 102 (Sheet 13)



AD9598

28-41-00
 CONFIG 3
 Page 115
 May 28/03

03



Fuel Quantity Indicating System - Component Location
Figure 102 (Sheet 14)

EFFECTIVITY
GUI 115

28-41-00

CONFIG 3


Page 116

Sep 28/07

03

<u>TITLE</u>	
FUEL QUANTITY BITE PROCEDURE.....	FIGURE 104
FAULT MESSAGE REFERENCE CHART.....	FIGURE 106
FQIS WIRING	FIGURE 107
FAULT MESSAGES	FIGURE 108
DRY CAPACITANCE TEST IN THE MAIN EQUIPMENT CENTER..... (NO FUEL IN THE TANK)	FIGURE 109
INTERMITTENT FAULT MESSAGES.....	FIGURE 110
FUEL QUANTITY INDICATOR DOES NOT DISPLAY CORRECTLY.....	FIGURE 114
FUEL CONFIG LIGHT AND EICAS MSG LOW FUEL NOT DISPLAYED	FIGURE 115
DURING FUEL QTY TEST	
TOTAL FUEL QTY DOES NOT AGREE WITH FMC CALCULATED.....	FIGURE 116
FUEL QTY. FUEL FLOW NORMAL	
EICAS MSG FUEL QTY IND OR FUEL QTY CHANNEL DISPLAYED	FIGURE 117
LOAD SELECT INDICATOR SHOWS "-A.-", "-b.-", OR "-A.b"	FIGURE 118
FUEL QUANTITY INDICATOR SHOWS "-A.-", "-b.-", OR "-A.b"	FIGURE 119
LOAD SELECT INDICATOR SHOWS THE MESSAGE "I.d" IN THE DISPLAY	FIGURE 120

Fuel Quantity Indicating System Problems Index
Figure 103



A09324

03

28-41-00

CONFIG 3
Page 117
Sep 28/07

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
6E4, 11C34, 11L19, 34A10

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)

EQUIPMENT:

1. GULL AIRBORNE INSTRUMENTS INC.,
55 ENGINEERS ROAD, SMITHTOWN, NY 11787
 - A. FUEL QTY TEST SET - MODEL GTF-2, P/N 361-012-001
 - B. FUEL QTY ADAPTER HARNESS - 370-044-001OR
2. BARFIELD INSTRUMENT CORP., MIAMI, FL 33142
 - A. FUEL QTY TEST SET - MODEL 8000
 - B. FUEL QTY ADAPTER HARNESS - 101-00543OR
3. JcAIR, INC.
400 INDUSTRIAL PARKWAY, INDUSTRIAL AIRPORT, KS 66031
 - A. FUEL QTY TEST SET - P/N 472090-007, OR P/N 472090-009, OR PSD 40-1, OR PSD 60-1, OR PSD 60-2, OR PSD 60-2R
 - B. FUEL QTY ADAPTER HARNESS -
LEFT/RIGHT MAIN FUEL TANK - PSD 40-510
CENTER FUEL TANK - PSD 40-511
 - C. TEST BOX, FQIS - PSD 757/767 - 1
 - D. FUEL QTY ADAPTER HARNESS - DENSITOMETER - PS 757/767 - 103
4. TEST BOX, FQIS -
A28007-44 (PART OF A28007-41)

NOTE 1: WHEN AN AIRPLANE EICAS MESSAGE SHOWS, YOU MUST DO A CHECK OF THE PROCESSOR (FQPU) BITE MENU "PRESENT FAULTS?". FOR THE FAULT HISTORY MENU, DO A CHECK FOR FAULT MESSAGES ON THE FLIGHT LEG 00. MAKE AND KEEP A WRITTEN RECORD OF THE FAULTS IN FLIGHT LEG 00 TO HELP IN SUBSEQUENT FAULT ISOLATION.

NOTE 2: THE RECOMMENDED CORRECTIVE ACTION FOR FAULT MESSAGES IS AS FOLLOWS:

- DO A CHECK OF THE "PRESENT FAULTS?" MENU
- IF THERE ARE PRESENT FAULTS SHOWN, DO THE APPLICABLE FAULT ISOLATION PROCEDURE IN FIG. 106.

NOTE: IF NO PRESENT FAULTS SHOW AND THERE ARE FAULT MESSAGES IN "FAULT HISTORY?" FLIGHT LEG 00, MAKE SURE THE FQIS OPERATES CORRECTLY AS FOLLOWS:

1. MAKE SURE THE FUEL QUANTITY DISPLAY DOES NOT GO OFF OR HAVE AN IRREGULAR INDICATION
2. DO A "SELF TEST?" ON THE PROCESSOR DISPLAY
3. IF NO FAULTS SHOW FROM THE "SELF TEST?" OR IN THE "PRESENT FAULTS?" MENU AND THE FQIS DISPLAY OPERATES CORRECTLY, NO FURTHER MAINTENANCE IS NECESSARY.

Fuel Quantity BITE Procedure
Figure 104 (Sheet 1)

EFFECTIVITY
GUI 115

28-41-00
CONFIG 3
Page 118
Sep 28/07

03

 **BOEING**
757
FAULT ISOLATION/MAINT MANUAL

- NOTE 3: EACH FLIGHT LEG, AS SHOWN BY THE PROCESSOR UNDER THE "FAULT HISTORY?" MENU, STARTS AT AIRPLANE TAKEOFF. THIS FLIGHT LEG WILL BE FLIGHT LEG 00 IN THE FQIS PROCESSOR UNTIL THE NEXT TAKEOFF. AT TAKEOFF THE DATA FORM FLIGHT LEG 00 IS RECORDED IN FLIGHT LEG 01, AND FLIGHT LEG 00 WILL START AGAIN.
- NOTE 4: AIRPLANES WITH THE PROCESSOR, PART NO. S345N001-030; IF THE AIRPLANE POWER IS PUT OFF AND ON, AND THERE IS A FAULT MESSAGE IN "FAULT HISTORY?" FLIGHT LEG 0, THE EICAS MESSAGE "FUEL QTY BITE" WILL SHOW. THE EICAS MESSAGE "FUEL QTY BITE" WILL ALSO SHOW IF YOU DO A "SELF TEST?" WHEN THERE IS A FAULT MESSAGE IN FLIGHT LEG 0. TO CORRECT THIS FAULT MESSAGE, SEE NOTE 1.
- NOTE 5: THE AIRPLANE WIRING HARNESSSES ARE EXTERNAL TO THE FUEL TANK.
- NOTE 6: THE TANK WIRING HARNESSSES ARE INTERNAL TO THE FUEL TANK.

1. BITE CONTROL PANEL - GENERAL

A. THE BITE CONTROL PANEL IS ON THE FRONT OF THE PROCESSOR IN THE MAIN EQUIPMENT CENTER, FIG. 102, SHEET 4. THE PROCESSOR BITE CONTROL PANEL OPERATION BUTTONS ARE AS FOLLOWS:

- OFF/ON: THE "ON/OFF" BUTTON PUTS THE BITE DISPLAY CONTROL ON OR OFF
- MENU: THE "MENU" BUTTON PUTS YOU AT THE MENU LEVEL OF THE MENU YOU ARE IN
- YES: THE "YES" BUTTON PUTS ON THE MENU ITEM SHOWN ON THE DISPLAY FOR MESSAGES THAT END IN A QUESTION MARK (?)
- NO: THE "NO" BUTTON PUTS ON THE NEXT MENU ITEM ON THE DISPLAY FOR MESSAGES THAT END IN A QUESTION MARK (?)
- ↑ (UP): THE "UP" BUTTON SHOWS THE LAST DATA ITEM SHOWN
- ↓ (DOWN): THE "DOWN" BUTTON SHOWS THE NEXT DATA ITEM

2. PROCESSOR MENU - GENERAL

THE FQIS TOP LEVEL MENU MESSAGES ARE AS FOLLOWS:
(SEE SHEET 6).

A. PRESENT FAULTS ?

THE PRESENT FAULTS MENU DISPLAY IS SHOWN ON SHEET 8. THE PRESENT FAULTS MENU SHOWS ALL PRESENT SYSTEM FAULTS.

B. FAULT HISTORY ?

THE FAULT HISTORY MENU DISPLAY IS SHOWN ON SHEET 10. THE FAULT HISTORY MENU SHOWS ALL SYSTEM FAULTS FOR THE FLIGHT LEGS 0 THRU 64.

(CONTINUED ON NEXT SHEET)

Fuel Quantity BITE Procedure
Figure 104 (Sheet 2)

EFFECTIVITY
GUI 115

28-41-00

CONFIG 3

03

Page 119

Sep 28/07

C. SYSTEM DATA ?

THE SYSTEM DATA MENU DISPLAY IS SHOWN ON SHEET 13. THE SYSTEM DATA MENU SHOWS DATA AS FOLLOWS:

(1) UPLIFT DATA ?

THE UPLIFT DATA MENU SHOWS AIRPLANE FUEL LOADED DATA AS FOLLOWS:

- (A) FUEL UPLIFT MASS
- (B) FUEL DENSITY.

NOTE: YOU CAN CALCULATE THE FUEL UPLIFT VOLUME TO COMPARE IT TO THE FUEL TRUCK VOLUME. IF YOU DIVIDE THE "FUEL UPLIFT MASS" BY THE "FUEL DENSITY" YOU WILL GET THE AIRPLANE FUEL VOLUME.

(2) MAIN TANKS DATA ?

THE MAIN TANKS DATA MENU SHOWS LEFT AND RIGHT MAIN TANK FUEL DATA AS FOLLOWS:

- (A) FUEL MASS
- (B) FUEL DENSITY
- (C) FUEL VOLUME
- (D) HI-Z WIRING, COMPENSATOR AND TANK UNIT CAPACITANCE MEASUREMENTS.

(3) CENTER TANK DATA ?

THE CENTER TANK DATA MENU SHOWS CENTER TANK FUEL DATA AS FOLLOWS:

- (A) FUEL MASS
- (B) FUEL DENSITY
- (C) FUEL VOLUME
- (D) HI-Z WIRING, COMPENSATOR AND TANK UNIT CAPACITANCE MEASUREMENTS.

D. SELF TEST ?

THE SELF TEST MENU DISPLAYS ARE SHOWN ON SHEET 15. THE SELF TEST MENU DOES A TEST OF THE FQIS SYSTEM. IF NO FAULTS SHOW, THE "TEST COMPLETE SELF TEST PASS" MESSAGE IS SHOWN. IF FAULTS OCCUR, THE FAULTS ARE SHOWN ON THE DISPLAY.

NOTE: YOU CAN SEE THE FAULT MESSAGES IN THE SELF TEST PROCEDURE ONE TIME ONLY. TO SEE THE SELF TEST FAULT MESSAGES AGAIN, YOU MUST DO THE "SELF TEST?" PROCEDURE AGAIN. YOU MUST CLOSE THE FUELING STATION DOOR, 621GB, TO DO THIS TEST.

(CONTINUED ON NEXT SHEET)

Fuel Quantity BITE Procedure
Figure 104 (Sheet 3)

EFFECTIVITY
GUI 115

28-41-00
CONFIG 3
Page 120
Sep 28/07

03

E. SYSTEM CONFIG ?

THE SYSTEM CONFIGURATION MENU DISPLAYS ARE SHOWN ON SHEET 23. THE SYSTEM CONFIGURATION MENU DISPLAYS ARE AS FOLLOWS:

- (1) LEFT MAIN CONFIGURATION ?
RIGHT MAIN CONFIGURATION ?
CENTER CONFIGURATION ?

THE LEFT MAIN CONFIGURATION, RIGHT MAIN CONFIGURATION, AND CENTER CONFIGURATION MENUS SHOW THE DATA AS FOLLOWS:

- (A) SOFTWARE VERSION AND REVISION
- (B) A AND B AIR/GROUND RELAY INDICATION
- (C) LB OR KG INDICATION
- (D) FUELING STATION DOOR (PANEL 28) OPEN/CLOSED INDICATION
- (E) AIRPLANE FUEL TANK INDICATION
- (F) FQIS SELF TEST STATUS.

- (2) ARINC BUS A CONFIGURATION ?
ARINC BUS B CONFIGURATION ?

THE ARINC BUS A CONFIGURATION, AND ARINC BUS B CONFIGURATION MENUS SHOW THE DATA AS FOLLOWS:

- (A) SOFTWARE VERSION AND REVISION
- (B) A AND B AIR/GROUND RELAY INDICATION
- (C) SPARE TANK STATUS, "ABSENT" SHOWS IF NO SPARE TANK IS USED
- (D) FUELING STATION DOOR (PANEL 28) OPEN/CLOSED INDICATION
- (E) ID STATUS, INDICATION OF THE INPUT/OUTPUT CARD IN USE (CARD 1 OR 2)
- (F) CENTER OVERRIDE PUMPS, ON/OFF INDICATION
- (G) FLIGHT, REFUEL, SYSTEM TEST INDICATION (0 IS OFF, OR 1 IS ON)
- (H) LEFT, RIGHT, AND CENTER SET SWITCH INDICATION (0 IS OFF, OR 1 IS ON)
- (I) SELECTED BUS IS FAILED, REPLACE THE APPLICABLE BUS.

(CONTINUED ON NEXT SHEET)

Fuel Quantity BITE Procedure
Figure 104 (Sheet 4)

EFFECTIVITY
GUI 115

28-41-00

CONFIG 3
Page 121
Sep 28/07

03

(3) BDB CONFIGURATION ?

THE BITE DISPLAY BOARD CONFIGURATION MENU SHOWS DATA AS FOLLOWS:

- (A) SOFTWARE VERSION AND REVISION
- (B) FUEL QUANTITY BITE, SHOWS "NO FAULT" OR "FAULT PRESENT" FOR ALL FQIS FAILURES.

F. ERASE HISTORY ?

THE ERASE FAULT HISTORY MENU DISPLAY IS SHOWN ON SHEET 28. THE ERASE FAULT HISTORY MENU DISPLAYS ARE AS FOLLOWS:

- (A) ERASE FLIGHT LEG 11-64? LETS YOU ERASE THE AIRPLANE FLIGHT LEGS 11 THRU 64.
- (B) ARE YOU SURE? LETS YOU ERASE OR NOT ERASE THE FLIGHT LEGS 11 THRU 64.
- (C) END HISTORY ERASE (ERASE COMPLETE).

(CONTINUED ON SHEET 7)

Fuel Quantity BITE Procedure
Figure 104 (Sheet 5)


EFFECTIVITY
GUI 115

AD9329

28-41-00
CONFIG 3
Page 122
Sep 28/07

03

MAIN MENU



Fuel Quantity BITE Procedure
Figure 104 (Sheet 6)

EFFECTIVITY
GUI 115

A09346

03

28-41-00

CONFIG 3
Page 123
Sep 28/07

3. FUEL QUANTITY BITE PROCEDURE

A. PUSH AND RELEASE THE "ON/OFF" BUTTON TO PUT THE PROCESSOR BITE DISPLAY TO ON.

NOTE: MAKE SURE THE PROCESSOR BITE DISPLAY IS ON. IF THE PROCESSOR BITE DISPLAY IS NOT ON AFTER YOU PUSH THE "ON/OFF" BUTTON MORE THAN ONCE, MAKE SURE POWER IS SUPPLIED TO THE FQIS PROCESSOR (FIG. 106, FAULT MESSAGE 36).

B. "PRESENT FAULTS ?" WILL SHOW ON THE FQIS PROCESSOR DISPLAY. PUSH AND RELEASE THE "YES" BUTTON TO SEE THE PRESENT FAULTS MENU, OR CONTINUE TO PUSH THE "NO" BUTTON TO SEE THE NEXT MENU ALTERNATIVES (SEE SHEET 6).

C. PRESENT FAULTS ?

(1) MAKE SURE THE PROCESSOR BITE DISPLAY IS ON AND "PRESENT FAULTS ?" SHOWS ON THE MENU DISPLAY.

(A) IF THE FQIS PROCESSOR IS NOT ON, GO TO STEP 3.A.

(2) PUSH AND RELEASE THE "YES" BUTTON TO GO TO THE PRESENT FAULT DATA.

(3) MAKE A WRITTEN RECORD OF ALL THE FAULT MESSAGES SHOWN.

(4) CONTINUE TO PUSH AND RELEASE THE "DOWN" BUTTON TO SEE ALL THE FAULT MESSAGES.

NOTE: PUSH AND RELEASE THE "UP" BUTTON TO SEE THE PREVIOUS FAULT MESSAGES.

(5) WHEN THE "END OF PRESENT FAULTS" MESSAGE SHOWS, ALL FAULT MESSAGES ARE SHOWN. PUSH AND RELEASE THE MENU BUTTON.

NOTE: THIS PUTS YOU AT THE TOP OF THE "PRESENT FAULTS ?" MENU.

(6) SEE FIG. 106 FOR CORRECTION OF ALL FAULT MESSAGES.

(CONTINUED ON SHEET 9)


Fuel Quantity BITE Procedure
Figure 104 (Sheet 7)


EFFECTIVITY
GUI 115

28-41-00
CONFIG 3
Page 124
Sep 28/07

03

PRESENT FAULT MENU




 "_" THIS INDICATION SHOWS "A" OR "G" TO INDICATE THAT THE FAULT FIRST OCCURRED IN THE AIR OR GROUND MODE.

Fuel Quantity BITE Procedure
Figure 104 (Sheet 8)

EFFECTIVITY
GUI 115

A09347

03

28-41-00

CONFIG 3
 Page 125
 Sep 28/07

D. FAULT HISTORY ?

(1) MAKE SURE THE PROCESSOR BITE DISPLAY IS ON AND "FAULT HISTORY ?" SHOWS ON THE MENU DISPLAY.

(A) IF THE PROCESSOR IS NOT ON, GO TO STEP 3.A.

(2) PUSH AND RELEASE THE "YES" BUTTON TO GO TO THE "FAULT HISTORY LEG ## ?" DISPLAY.

NOTE: THE "##" PLACE HOLDER WILL SHOW THE FLIGHT LEG NUMBER FOR THE FLIGHT LEG WITH THE RECORDED FAULTS.

(3) PUSH AND RELEASE THE "YES" BUTTON TO SEE THE FAULT MESSAGES, OR PUSH AND RELEASE THE "NO" BUTTON TO SEE THE NEXT "FLIGHT LEG" WITH FAULT MESSAGES.

NOTE: ONLY THE FLIGHT LEGS WITH FAULTS RECORDED WILL SHOW FAULT MESSAGES ON THE DISPLAY.

(4) MAKE A WRITTEN RECORD OF THE FAULT MESSAGE SHOWN.

(5) CONTINUE TO PUSH AND RELEASE THE "DOWN" BUTTON TO SEE ALL THE FAULT MESSAGES.

(6) WHEN "END OF HISTORY FLIGHT LEG ##" SHOWS, PUSH AND RELEASE THE "DOWN" BUTTON TO SEE THE NEXT FLIGHT LEG'S FAULT MESSAGES.

(7) WHEN THE "END OF FAULT HISTORY" MESSAGE SHOWS, PUSH AND RELEASE THE "MENU" BUTTON.

NOTE: THIS PUTS YOU AT THE TOP OF THE "FAULT HISTORY ?"

(8) REFER TO TABLE 101 FOR CORRECTION OF ALL FAULT MESSAGES.

NOTE: ONLY THE FLIGHT LEGS WITH FAULTS RECORDED WILL SHOW FAULT MESSAGES ON THE DISPLAY.

(CONTINUED ON SHEET 11)

Fuel Quantity BITE Procedure
Figure 104 (Sheet 9)


EFFECTIVITY
GUI 115

28-41-00

CONFIG 3
Page 126
Sep 28/07

03

FAULT HISTORY MENU



2 " " THIS INDICATION SHOWS "A" OR "G" TO SHOW THAT THE FAULT FIRST OCCURRED IN THE AIR OR ON THE GROUND MODE. THE "##" INDICATION WILL SHOW THE NUMBER OF TIMES THE FAULT OCCURRED IN THE APPLICABLE FLIGHT LEG.

Fuel Quantity BITE Procedure
Figure 104 (Sheet 10)

EFFECTIVITY
GUI 115

A09349

03

28-41-00
CONFIG 3
Page 127
Sep 28/07

E. SYSTEM DATA ?

(1) MAKE SURE THE PROCESSOR BITE DISPLAY IS ON AND "SYSTEM DATA ?" SHOWS ON THE MENU DISPLAY.

NOTE: IF THE PROCESSOR BITE DISPLAY IS NOT ON, GO TO STEP 3.A.

(2) IF YOU WANT TO SEE SYSTEM DATA, PUSH AND RELEASE THE "YES" BUTTON. THE "UPLIFT DATA ?" MENU WILL SHOW.

(3) IF YOU WANT TO SEE THE UPLIFT DATA, PUSH AND RELEASE THE "YES" BUTTON; OR IF YOU WANT TO SEE THE "MAIN TANKS DATA ?" MENU, PUSH AND RELEASE THE "NO" BUTTON AND GO TO STEP (5).

(A) PUSH AND RELEASE THE "DOWN" BUTTON TO SEE THE UPLIFT DATA AS FOLLOWS:

- 1) UPLIFT MASS (KG OR LB)
- 2) UPLIFT DENSITY (KG/L OR LB/G)
- 3) END OF UPLIFT DATA.

(4) WHEN THE "END OF UPLIFT DATA" MESSAGE SHOWS, PUSH AND RELEASE THE "DOWN" BUTTON TO GO TO THE "MAIN TANKS DATA ?" MENU.

(5) PUSH AND RELEASE THE "YES" BUTTON TO SEE THE MAIN TANKS DATA; OR IF YOU WANT TO SEE THE CENTER TANK DATA, PUSH AND RELEASE THE "NO" BUTTON AND GO TO STEP (7).

(A) CONTINUE TO PUSH AND RELEASE THE "DOWN" BUTTON TO SEE ALL THE MAIN TANKS DATA MESSAGES.

(B) MAKE A WRITTEN RECORD OF ALL THE SYSTEM DATA SHOWN FOR THE LEFT AND RIGHT FUEL TANKS.

(CONTINUED ON NEXT SHEET)

Fuel Quantity BITE Procedure
Figure 104 (Sheet 11)

EFFECTIVITY
GUI 115

A09333

28-41-00

CONFIG 3
Page 128
Sep 28/07

03

- (C) THE MAIN TANKS DATA MENU SHOWS THE LEFT AND RIGHT FUEL TANK DATA AS FOLLOWS (SEE SHEET 13):
- 1) FUEL MASS
 - 2) FUEL DENSITY
 - 3) FUEL VOLUME
 - 4) HI-Z WIRING CAPACITANCE
 - 5) COMPENSATOR CAPACITANCE
 - 6) TANK UNIT CAPACITANCE
 - 7) END OF MAIN TANK DATA.
- (6) WHEN THE "END OF MAIN TANK DATA" MESSAGE SHOWS, PUSH AND RELEASE THE "DOWN" BUTTON TO GO TO THE "CENTER TANK DATA ?" MENU.
- (7) PUSH AND RELEASE THE "YES" BUTTON TO SEE THE CENTER TANKS DATA.
- (A) CONTINUE TO PUSH AND RELEASE THE "DOWN" BUTTON TO SEE ALL OF THE CENTER TANK DATA.
- (B) MAKE A WRITTEN RECORD OF ALL THE SYSTEM DATA SHOWN FOR THE CENTER FUEL TANK.
- (C) THE CENTER TANK DATA MENU SHOWS THE CENTER FUEL TANK DATA AS FOLLOWS (SEE SHEET 13):
- 1) FUEL MASS
 - 2) FUEL DENSITY
 - 3) FUEL VOLUME
 - 4) HI-Z WIRING CAPACITANCE
 - 5) COMPENSATOR CAPACITANCE
 - 6) TANK UNIT CAPACITANCE
 - 7) END OF CENTER TANK DATA.
- (D) PUSH AND RELEASE THE "DOWN" BUTTON TO SHOW THE MESSAGE "END OF SYSTEM DATA".
- NOTE: WHEN THIS MESSAGE SHOWS, ALL OF THE SYSTEM DATA HAVE SHOWN.
- (E) PUSH AND RELEASE THE MENU BUTTON.
- NOTE: THIS PUTS YOU AT THE TOP OF THE "SYSTEM DATA ?" MENU.

(CONTINUED ON SHEET 14)


Fuel Quantity BITE Procedure
Figure 104 (Sheet 12)

EFFECTIVITY
GUI 115

28-41-00

CONFIG 3
Page 129
Sep 28/07

03



Fuel Quantity BITE Procedure
Figure 104 (Sheet 13)

EFFECTIVITY
GUI 115

28-41-00

CONFIG 3

Page 130

Sep 28/07

03

F. SELF TEST ?

- (1) MAKE SURE THE PROCESSOR BITE DISPLAY IS ON AND "SELF TEST ?" SHOWS ON THE MENU DISPLAY.

NOTE: IF THE PROCESSOR BITE DISPLAY IS NOT ON, GO TO STEP 3.A.

- (2) IF YOU WANT TO BEGIN THE SELF TEST, PUSH AND RELEASE THE "YES" BUTTON TO GO TO THE "BEGIN SELF TEST ? TEST TIME =90 SEC" DISPLAY (SEE SHEET 16).

NOTE: IF YOU DO NOT WANT TO DO A SELF TEST, PUSH AND RELEASE THE "NO" BUTTON TO GO TO "END OF SELF TEST" WHEN "BEGIN SELF TEST ?" SHOWS.

NOTE: YOU MUST CLOSE THE FUELING STATION DOOR, 621GB, BEFORE YOU DO THIS TEST.

- (A) PUSH AND RELEASE THE "YES" BUTTON TO START THE SELF TEST.

NOTE: THE DISPLAY "TEST IN PROGRESS" WILL FLASH FOR 90 SECONDS.

- (B) IF THE SELF TEST MESSAGE "TEST COMPLETE SELF TEST PASS" SHOWS, PUSH AND RELEASE THE "DOWN" BUTTON TO GO TO "END OF SELF TEST".

- (C) IF YOU WANT TO SEE THE SYSTEM FAULT MESSAGES WHEN "TEST COMPLETE LIST FAULTS ?" SHOWS, PUSH AND RELEASE THE "YES" BUTTON TO SEE THE SYSTEM FAULT MESSAGES.

1) CONTINUE TO PUSH AND RELEASE THE "DOWN" BUTTON TO SEE ALL OF THE FAULT MESSAGES.

2) MAKE A WRITTEN RECORD OF ALL THE FAULT MESSAGES SHOWN.

3) PUSH AND RELEASE THE "DOWN" BUTTON WHEN THE "END OF SELF TEST FAULTS" MESSAGE SHOWS (ALL OF THE SELF TEST FAULT MESSAGES ARE SHOWN).

NOTE: SEE TABLE 101 FOR CORRECTION OF ALL FAULT MESSAGES. WHEN THE "END OF SELF TEST FAULTS" MESSAGE SHOWS, ALL OF THE SELF TEST FAULT MESSAGES ARE SHOWN.

- (D) IF YOU DO NOT WANT TO SEE THE SYSTEM FAULTS WHEN "TEST COMPLETE LIST FAULTS ?" SHOWS, PUSH AND RELEASE THE "NO" BUTTON TO NOT SEE THE SYSTEM FAULTS.

NOTE: WHEN THE "END OF SELF TEST FAULTS" SHOWS, YOU ARE AT THE END OF THE SELF TEST.

- (3) PUSH AND RELEASE THE "MENU" BUTTON.

NOTE: THIS PUTS YOU AT THE TOP OF THE "SELF TEST MENU ?" DISPLAY.

(CONTINUED ON SHEET 16)

Fuel Quantity BITE Procedure
Figure 104 (Sheet 14)

EFFECTIVITY
GUI 115

28-41-00


CONFIG 3

03

Page 131

Sep 28/07

SELF TEST MENU



Fuel Quantity BITE Procedure
Figure 104 (Sheet 15)

EFFECTIVITY
GUI 115

AD9353

28-41-00

CONFIG 3
Page 132
Sep 28/07

03

G. SYSTEM CONFIGURATION ?

- (1) MAKE SURE THE PROCESSOR BITE DISPLAY IS ON AND "SYSTEM CONFIGURATION ?" SHOWS ON THE MENU DISPLAY.

NOTE: IF THE FQIS PROCESSOR IS NOT ON, GO TO STEP 3.A.

- (2) IF YOU WANT TO SEE THE SYSTEM CONFIGURATION DATA, PUSH AND RELEASE THE "YES" BUTTON.
- (3) TO SEE THE LEFT MAIN FUEL TANK CONFIGURATION DATA, GO TO STEP (A) BELOW; TO SEE THE RIGHT MAIN FUEL TANK CONFIGURATION, PUSH AND RELEASE THE "NO" BUTTON AND GO TO STEP (A) BELOW; TO SEE THE CENTER FUEL TANK CONFIGURATION, DATA PUSH AND RELEASE THE "NO" BUTTON TWO TIMES AND GO TO STEP (A) BELOW (SEE SHEET 19):

(A) PUSH AND RELEASE THE "YES" BUTTON WHEN THE MENU DISPLAY SHOWS THE APPLICABLE MENU: "LEFT MAIN CONFIGURATION ?", "RIGHT MAIN CONFIGURATION ?", "CENTER CONFIGURATION ?"

(B) CONTINUE TO PUSH AND RELEASE THE "DOWN" BUTTON TO SEE THE APPLICABLE FUEL TANK CONFIGURATION DATA.

(C) MAKE A WRITTEN RECORD OF ALL THE MESSAGES SHOWN FOR THE APPLICABLE FUEL TANK CONFIGURATION.

(D) THE LEFT MAIN CONFIGURATION DATA MENU SHOWS THE LEFT MAIN FUEL TANK DATA AS FOLLOWS (SHEET 19):

- 1) SOFTWARE VERSION NUMBER AND REVISION NUMBER
- 2) "AIR" OR "GROUND" A RELAY INDICATION
- 3) "AIR" OR "GROUND" B RELAY INDICATION
- 4) FQIS SYSTEM "LB" OR "KG" CONFIGURATION INDICATION
- 5) FUELING STATION DOOR "OPEN" OR "CLOSED" INDICATION
- 6) ID STATUS INDICATION SHOWS THE AIRPLANE FUEL TANK ON THE DISPLAY
- 7) FQIS SELF TEST STATUS INDICATION SHOWS "NO TEST" OR "TEST".

NOTE: WHEN THE "END LEFT MAIN CONFIGURATION" MESSAGE SHOWS, ALL OF THE LEFT MAIN FUEL TANK CONFIGURATION MESSAGES ARE SHOWN.

(E) IF YOU WANT TO SEE MORE SYSTEM CONFIGURATION DATA, PUSH AND RELEASE THE "DOWN" BUTTON TO CONTINUE.

(F) IF YOU WANT TO GO TO THE TOP OF THE SYSTEM DATA MENU, PUSH AND RELEASE THE "MENU" BUTTON.

(CONTINUED ON SHEET 17)

Fuel Quantity BITE Procedure
Figure 104 (Sheet 16)

EFFECTIVITY
GUI 115

28-41-00

CONFIG 3

03

Page 133

Sep 28/07

 **BOEING**
757
FAULT ISOLATION/MAINT MANUAL

(4) TO SEE THE CONFIGURATION DATA FOR ONE OF THE TWO ARINC BUSES, PUSH AND RELEASE THE "YES" BUTTON WHEN THE DISPLAY SHOWS THE APPLICABLE MENU: "ARINC BUS A CONFIGURATION ?", "ARINC BUS B CONFIGURATION ?" (SEE SHEET 19).

NOTE: THE MESSAGE "SWITCHING TO SELECTED BUS" WILL SHOW.
IF THE BUS IS BAD, THE MESSAGE "SELECTED BUS IS FAILED" WILL SHOW.

- (A) PUSH AND RELEASE THE "DOWN" BUTTON TO SEE THE ARINC BUS CONFIGURATION DATA.
- (B) CONTINUE TO PUSH AND RELEASE THE "DOWN" BUTTON TO SEE ALL OF THE ARINC DATA.
- (C) MAKE A WRITTEN RECORD OF ALL THE ARINC MESSAGES SHOWN.
- (D) THE ARINC BUS A CONFIGURATION DATA MENU SHOWS INPUT/OUTPUT CARD (IOC) 1 DATA AS FOLLOWS (SEE SHEET 19):
 - 1) SOFTWARE VERSION NUMBER AND REVISION NUMBER
 - 2) "AIR" OR "GROUND" A RELAY INDICATION
 - 3) "AIR" OR "GROUND" B RELAY INDICATION
 - 4) SPARE STATUS (THIS INDICATION IS NOT ACTIVE, "ABSENT" SHOWS)
 - 5) "OPEN" OR "CLOSED" FUELING STATION DOOR STATUS
 - 6) ID STATUS INDICATION SHOWS THE INPUT OUTPUT CARD IN USE, "IOC #1" OR "IOC #2"
 - 7) CENTER OVERRIDE PUMP "ON" OR "OFF" INDICATION
 - 8) FLIGHT, REFUEL, SYSTEM TEST INDICATION (0 IS OFF, OR 1 IS ON)
 - 9) SET LEFT, RIGHT, OR CENTER INDICATION (0 IS OFF, OR 1 IS ON).

NOTE: WHEN THE "END OF ARINC CONFIGURATION" MESSAGE SHOWS, ALL THE ARINC CONFIGURATION MESSAGES SHOW.

- (E) IF YOU WANT TO SEE MORE SYSTEM CONFIGURATION DATA, PUSH AND RELEASE THE "DOWN" BUTTON TO CONTINUE.
- (F) IF YOU WANT TO GO TO THE TOP OF THE SYSTEM CONFIGURATION MENU, PUSH AND RELEASE THE "MENU" BUTTON.

(CONTINUED ON SHEET 18)

Fuel Quantity BITE Procedure
Figure 104 (Sheet 17)

EFFECTIVITY
GUI 115

28-41-00
CONFIG 3
Page 134
Sep 28/07

03

 **BOEING**
757
FAULT ISOLATION/MAINT MANUAL

- (5) IF YOU WANT TO SEE THE DATA FOR THE BITE DISPLAY BOARD, PUSH AND RELEASE THE "YES" BUTTON WHEN THE "BITE DISPLAY BRD CONFIGURATION ?" MENU SHOWS (SEE SHEET 19).
- (A) PUSH AND RELEASE THE "DOWN" BUTTON TO SEE THE BITE DISPLAY BOARD CONFIGURATION DATA.
- (B) CONTINUE TO PUSH AND RELEASE THE "DOWN" BUTTON WHILE YOU MAKE A WRITTEN RECORD OF ALL THE BDB DATA MESSAGES SHOWN, IF IT IS NECESSARY.
- (C) THE BITE DISPLAY BOARD CONFIGURATION MENU SHOWS DATA AS FOLLOWS (SEE FIGURE 105, SHEET 9):
- 1) SOFTWARE VERSION NUMBER AND REVISION NUMBER SHOW
 - 2) FUEL QUANTITY BITE, SHOWS "NO FAULT" OR "FAULT PRESENT" FOR THE FQIS PROCESSOR DISPLAY BOARD
- NOTE: WHEN THE "END OF BDB CONFIGURATION" MESSAGE SHOWS, ALL OF THE BDB CONFIGURATION MESSAGES ARE SHOWN.
- (D) PUSH AND RELEASE THE "DOWN" BUTTON TO CONTINUE.
- NOTE: THE MESSAGE "END OF SYSTEM CONFIGURATION" WILL SHOW.
- (6) PUSH AND RELEASE THE MENU BUTTON. THIS PUTS YOU AT THE TOP OF THE "SYSTEM CONFIGURATION ?" MENU.

(CONTINUED ON SHEET 23)

Fuel Quantity BITE Procedure
Figure 104 (Sheet 18)


EFFECTIVITY
GUI 115

28-41-00

CONFIG 3
Page 135
Sep 28/07

03

SYSTEM CONFIGURATION MENU



Fuel Quantity BITE Procedure
Figure 104 (Sheet 19)


EFFECTIVITY
GUI 115

28-41-00

CONFIG 3
Page 136
Sep 28/07

03

INDIVIDUAL FUEL QUANTITY CHANNEL CARD (IFQC) DATA



Fuel Quantity BITE Procedure
Figure 104 (Sheet 20)


EFFECTIVITY
GUI 115

A09355

03

28-41-00
 CONFIG 3
 Page 137
 Sep 28/07

INPUT/OUTPUT CARD (IOC) DATA



Fuel Quantity BITE Procedure
Figure 104 (Sheet 21)

EFFECTIVITY
GUI 115


AD9356

28-41-00

CONFIG 3
Page 138
Sep 28/07

03

BITE DISPLAY BOARD DATA



Fuel Quantity BITE Procedure
Figure 104 (Sheet 22)

EFFECTIVITY
GUI 115

A09357

28-41-00

CONFIG 3
Page 139
Sep 28/07

03

H. ERASE HISTORY ?

- (1) MAKE SURE THE FQIS PROCESSOR IS ON AND "ERASE FAULT HISTORY ?" SHOWS ON THE MENU DISPLAY (SEE SHEET 24).
NOTE: IF THE FQIS PROCESSOR IS NOT ON, GO TO STEP 3.A.
- (2) PUSH AND RELEASE THE "YES" BUTTON TO GO TO THE "ERASE FLIGHT LEG 11-64 ?" DISPLAY.
- (3) IF YOU WANT TO STOP THE ERASE PROCEDURE, PUSH AND RELEASE THE "NO" BUTTON GO TO STOP THE "END HISTORY ERASE" MESSAGE.
- (4) IF YOU WANT TO ERASE FLIGHT HISTORY, PUSH AND RELEASE THE "YES" BUTTON TO ERASE THE FLIGHT LEGS 11 THRU 64 FAULT MESSAGES.
- (5) FOR THE MESSAGE "ARE YOU SURE ?", PUSH AND RELEASE THE "YES" BUTTON TO ERASE THE FLIGHT LEGS 11 THRU 64, OR PUSH AND RELEASE THE "NO" BUTTON TO GO TO THE "END HISTORY ERASE" MESSAGE.
- (6) IF YOU DID THE ERASE THE FLIGHT LEGS 11 THRU 64 STEP, THE MESSAGE "ERASE IN PROGRESS" WILL SHOW AND THEN THE MESSAGE "END HISTORY ERASE COMPLETE" WILL SHOW.
- (7) WHEN THE "END HISTORY ERASE COMPLETE" MESSAGE SHOWS, PUSH AND RELEASE THE "MENU" BUTTON.
NOTE: THIS PUTS YOU AT THE TOP OF THE "ERASE FAULT HISTORY ?" MENU.

Fuel Quantity BITE Procedure
Figure 104 (Sheet 23)


EFFECTIVITY
GUI 115

A09345

28-41-00
CONFIG 3
Page 140
Sep 28/07

03

ERASE FAULT HISTORY MENU



Fuel Quantity BITE Procedure
Figure 104 (Sheet 24)

EFFECTIVITY
GUI 115

A09358


28-41-00

CONFIG 3
Page 141
Sep 28/07

03

Not Used
Figure 105

EFFECTIVITY
GUI 115



C75710

03

28-41-00

CONFIG 3

Page 142

Sep 28/07


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

NO.	FIGURE	SHEET	FAULT MESSAGES
1	108	2	** TU ## OPEN LOZ OR HIZ WIRE G##.
2	108	3	** TU ## SHORTED IN TANK G##.
3	108	4	** TU ?? SHORTED IN TANK G##.
4	108	5	** TU ## CONTAMINATED G##.
5	108	6	** TU ## SHORTED TO GROUND G##.
6	108	7	** COMP OPEN LOZ OR HIZ WIRE G##.
7	108	8	** COMP SHORTED IN TANK G##.
8	108	9	** COMPENSATOR CONTAMINATED G##.
9	108	10	** COMP SHORTED TO GROUND G##.
10	108	11	** HIZ WIRE OPEN AT SPAR G##.
11	108	12	** HIZ SHIELD OPEN AT SPAR G##.
12	108	13	** HIZ WIRE OPEN AT PROCESSOR G##.
13	108	14	** HIZ SHIELD OPEN AT PROC G##.
14	108	15	** HIZ WIRE LOW RESISTANCE G##.
15	108	16	** HIZ SHORTED WIRE TO SHLD G##.
16	108	17	** HIZ SHIELD SHORT TO GND G##.
17	108	18	** DENS RESISTOR UNREADABLE G##.
18	108	19	** DENS EXCITA- TION SHORTED G##.
19	108	20	** DENS SENSE WIRE SHORTED G##.
20	108	21	** DENS SENSE OPEN AT SPAR G##.
21	108	22	** DENS SENSE OPEN AT PROC G##.
22	108	23	** DENS CONTAM OR RESISTOR G##.
23	108	24	** DENS SENSOR OR DRIVE WIRE G## (OR) ** DENS SENSOR FAILURE G##
24	108	25	** IFQC CIRCUIT BOARD FAILED G##.
25	108	26	** IFQC AIR/GND CIRCUIT FAIL G##.
26	108	27	AIR/GROUND INPUT FAILED G##.
27	108	28	LB/KG INPUT WIRE FAILED G##.
28	108	29	** IFQC LB/KG CIRCUIT FAIL G##.
29	108	30	IOC 1 DISCRETE DRIVER FAIL G##.
30	108	30	LOAD SELECT UNIT OR WIRE FAIL G##.
31	108	31	IOC # (1 OR 2) FAILED G##.
32	108	31	VOLUME SHUTOFF OF ** AT 95% G##.
33	108	32	VOLUME SHUTOFF OF ** AT 87% G##.
34	108	33	BITE DISPLAY BOARD FAILED G##.
35	108	34	(THE BITE DISPLAY BOARD IS NOT ON)
36	108	35	ARINC BUS (A OR B) FAILED G##.
37	108	36	** TU ?? SHORTED TO GROUND G##.

Fault Message Reference Chart
Figure 106

EFFECTIVITY
GUI 115

28-41-00

CONFIG 3





03

Page 143




Sep 28/07

A09359

EFFECTIVITY
GUT 115





COMPONENT	EQUIP- MENT NUMBER	ACCESS DOOR	FQIS PROCESSOR CONNECTOR PINS		EE RACK CONNECTOR PINS		INTER- MEDIATE CONNECTOR (1)	INTER- MEDIATE CONNECTOR (2)	FRONT SPAR CONNECTOR PINS		
			LO-Z CONNECTOR D2440B	HI-Z CONNECTOR D2440C 	LO-Z CONNECTOR D41620	HI-Z CONNECTOR D42222 	LO-Z CONNECTOR D41198	LO-Z CONNECTOR D41196	LO-Z CONNECTOR D2814	HI-Z  BUSSING PLUG M723	HI-Z  SHIELD BUSSING PLUG M723
COMPENSATOR	TS119	641AB	E4	J2	1	1	1	1	16	16C	16S
TANK UNIT NO. 1	TS146	641AB	C1	J2	2	1	2	2	1	1C	1S
TANK UNIT NO. 2	TS147	641BB	D1	J2	3	1	3	3	2	2C	2S
TANK UNIT NO. 3	TS148	641CB	E1	J2	4	1	4	4	3	3C	3S
TANK UNIT NO. 4	TS149	641DB	F1	J2	5	1	5	5	4	4C	4S
TANK UNIT NO. 5	TS150	641FB	C2	J2	6	1	6	6	5	5C	5S
TANK UNIT NO. 6	TS151	641GB	D2	J2	7	1	7	7	6	6C	6S
TANK UNIT NO. 7	TS152	641HB	E2	J2	8	1	8	8	7	7C	7S
TANK UNIT NO. 8	TS153	641JB	F2	J2	9	1	9	9	8	8C	8S
TANK UNIT NO. 9	TS154	641LB	C3	J2	10	1	10	10	9	9C	9S
TANK UNIT NO. 10	TS155	641MB	D3	J2	11	1	11	11	10	10C	10S
TANK UNIT NO. 11	TS5198	642AB	E3	J2	36	1	12	12	11	11C	11S
TANK UNIT NO. 12	TS5199	642CB	F3	J2	37	1	13	13	12	12C	12S

RIGHT MAIN FUEL TANK

-  THE PIN NUMBER J2 IS FOR THE HI-Z CENTER CONDUCTOR ONLY. THE HI-Z SHIELD PIN IS H1 (WDM 28-41-31).
-  THE PIN NUMBER 1 IS FOR THE HI-Z CENTER CONDUCTOR ONLY. THE HI-Z SHIELD PIN IS C1 (WDM 28-41-31).
-  THE HI-Z BUSSING PLUG PUTS THE HI-Z WIRE THROUGH THE CONNECTOR D2818. THE HI-Z CENTER CONDUCTOR IS PIN 1, AND THE SHIELD PIN IS C1.




FQIS Wiring
Figure 107 (Sheet 1)

EFFECTIVITY
GUI 115





COMPONENT	EQUIP- MENT NUMBER	ACCESS DOOR	FQIS PROCESSOR CONNECTOR PINS		EE RACK CONNECTOR PINS		INTER- MEDIATE CONNECTOR (1)	INTER- MEDIATE CONNECTOR (2)	FRONT SPAR CONNECTOR PINS		
			LO-Z CONNECTOR D2440A	HI-Z CONNECTOR D2440C 	LO-Z CONNECTOR D41636	HI-Z CONNECTOR D42222 	LO-Z CONNECTOR D41394	LO-Z CONNECTOR D41192	LO-Z CONNECTOR D2788	HI-Z  BUS- SING PLUG M722	HI-Z  SHIELD BUS- SING PLUG M722
COMPENSATOR	TS108	541AB	E4	B2	11	1	1	1	16	16C	16S
TANK UNIT NO. 1	TS109	541AB	C1	B2	12	1	2	2	1	1C	1S
TANK UNIT NO. 2	TS110	541BB	D1	B2	13	1	3	3	2	2C	2S
TANK UNIT NO. 3	TS111	541CB	E1	B2	14	1	4	4	3	3C	3S
TANK UNIT NO. 4	TS112	541DB	F1	B2	15	1	5	5	4	4C	4S
TANK UNIT NO. 5	TS113	541FB	C2	B2	16	1	6	6	5	5C	5S
TANK UNIT NO. 6	TS114	541GB	D2	B2	17	1	7	7	6	6C	6S
TANK UNIT NO. 7	TS115	541HB	E2	B2	18	1	8	8	7	7C	7S
TANK UNIT NO. 8	TS116	541JB	F2	B2	19	1	9	9	8	8C	8S
TANK UNIT NO. 9	TS117	541LB	C3	B2	20	1	10	10	9	9C	9S
TANK UNIT NO. 10	TS118	541MB	D3	B2	21	1	11	11	10	10C	10S
TANK UNIT NO. 11	TS5196	542AB	E3	B2	22	1	12	12	11	11C	11S
TANK UNIT NO. 12	TS5197	542CB	F3	B2	25	1	13	13	12	12C	12S

FQIS Wiring
Figure 107 (Sheet 2)




LEFT MAIN FUEL TANK

-  THE PIN NUMBER B2 IS FOR THE HI-Z CENTER CONDUCTOR ONLY. THE HI-Z SHIELD PIN IS A1 (WDM 28-41-21).
-  THE PIN NUMBER 1 IS FOR THE HI-Z CENTER CONDUCTOR ONLY. THE HI-Z SHIELD PIN IS C1 (WDM 28-41-21).
-  THE HI-Z BUS-SING PLUG PUTS THE HI-Z WIRE THROUGH THE CONNECTOR D2792. THE HI-Z CENTER CONDUCTOR IS PIN 1, AND THE SHIELD PIN IS C1.

EFFECTIVITY
GUI 115






COMPONENT	EQUIP- MENT NUMBER	ACCESS DOOR	FQIS PROCESSOR CONNECTOR PINS		EE RACK CONNECTOR PINS		FRONT SPAR CONNECTOR PINS		
			LO-Z CONNECTOR D2440B	HI-Z CONNECTOR D2440C 	LO-Z CONNECTOR D41620	HI-Z CONNECTOR D42226 	LO-Z CONNECTOR D2814	HI-Z  BUSSING PLUG M10139	HI-Z  SHIELD BUSSING PLUG M10139
COMPENSATOR	TS5010	631AB	F10	E6	17	1	5	5C	5S
TANK UNIT NO. 6	TS5016	631AB	E10	E6	12	1	1	1C	1S
TANK UNIT NO. 7	TS5017	631AB	D11	E6	13	1	2	2C	2S
TANK UNIT NO. 8	TS5075	631BB	E11	E6	14	1	3	3C	3S
TANK UNIT NO. 9	TS5076	631CB	F11	E6	16	1	4	4C	4S

RIGHT CENTER FUEL TANK





-  THE PIN NUMBER E6 IS FOR THE HI-Z CENTER CONDUCTOR ONLY. THE HI-Z SHIELD PIN IS D5 (WDM 28-41-41).
-  THE PIN NUMBER 1 IS FOR THE HI-Z CENTER CONDUCTOR ONLY. THE HI-Z SHIELD PIN IS C1 (WDM 28-41-41).
-  THE HI-Z BUSSING PLUG PUTS THE HI-Z WIRE THROUGH THE CONNECTOR D2812. THE HI-Z CENTER CONDUCTOR IS PIN 1, AND THE HI-Z SHIELD IS PIN C1.

FQIS Wiring
Figure 107 (Sheet 3)

EFFECTIVITY
GUI 115

COMPONENT	EQUIP- MENT NUMBER	ACCESS DOOR	FQIS PROCESSOR CONNECTOR PINS		EE RACK CONNECTOR PINS		FRONT SPAR CONNECTOR PINS		
			LO-Z CONNECTOR D2440A	HI-Z CONNECTOR D2440C 	LO-Z CONNECTOR D41636	HI-Z CONNECTOR D42224 	LO-Z CONNECTOR D2784	HI-Z  BUS- SING PLUG M10295	HI-Z  SHIELD BUS- SING PLUG M10295
COMPENSATOR	TS5011	134AZ	D10	B6	26	1	1	1C	1S
TANK UNIT NO. 6	TS5012	531AB	E10	B6	27	1	2	2C	2S
TANK UNIT NO. 7	TS5013	531AB	D11	B6	28	1	3	3C	3S
TANK UNIT NO. 8	TS5014	531BB	E11	B6	29	1	4	4C	4S
TANK UNIT NO. 9	TS5015	531CB	D10 	B6	30	1	5	5C	5S

LEFT CENTER FUEL TANK

-  THE PIN NUMBER 1 IS FOR THE HI-Z CENTER CONDUCTOR ONLY. THE HI-Z SHIELD PIN IS C1 (WDM 28-41-41).
-  THIS PIN D10 IS ON THE CONNECTOR D2440B.
-  THE PIN NUMBER B6 IS FOR THE HI-Z CENTER CONDUCTOR ONLY. THE HI-Z SHIELD PIN IS A5 (WDM 28-41-41).
-  THE HI-Z BUS-
SING
PLUG PUTS THE HI-Z WIRE THROUGH THE CONNECTOR D2786. THE HI-Z CENTER CONDUCTOR IS
PIN 1, AND THE HI-Z SHIELD IS PIN C1.

FQIS Wiring
Figure 107 (Sheet 4)

BOEING
757
FAULT ISOLATION/MAINT MANUAL

FQIS PROCESSOR CONNECTOR D2440B PINS	EE BAY RACK CONNECTOR D41276 PINS	DENSITOMETER CONNECTOR (REAR) (SPAR) D6886 PINS	COMPONENT	EQUIPMENT NO.	ACCESS DOOR
			DENSITOMETER	M10902	641AB
7D	1	1	SENSE		
6E	4	C1	SHIELD		
6D	2	2	DRIVE (POSITIVE)		
5E	3	3	DRIVE (NEGATIVE)		
5A	6	6	KR0		
5B	7	7	KR1		
5C	8	8	KR2		
5D	9	9	KR3		

RIGHT MAIN FUEL TANK DENSITOMETER

FQIS PROCESSOR CONNECTOR D2440A PINS	EE BAY RACK CONNECTOR D41272 PINS	DENSITOMETER CONNECTOR (REAR) (SPAR) D6882 PINS	COMPONENT	EQUIPMENT NO.	ACCESS DOOR
			DENSITOMETER	M10901	541AB
6B	1	1	SENSE		
6A	4	C1	SHIELD		
5A	2	2	DRIVE (POSITIVE)		
5B	3	3	DRIVE (NEGATIVE)		
5C	6	6	KR0		
5D	7	7	KR1		
5E	8	8	KR2		
6D	9	9	KR3		

LEFT MAIN FUEL TANK DENSITOMETER

FQIS Wiring
Figure 107 (Sheet 5)

EFFECTIVITY
GUI 115

28-41-00

CONFIG 3
Page 148
Sep 28/07

03


BOEING
757
FAULT ISOLATION/MAINT MANUAL

FQIS PROCESSOR CONNECTOR D2440A PINS	EE BAY RACK CONNECTOR D41276 PINS	HOT SHORT PROTECTOR CONNECTOR D11720 PINS 13	HOT SHORT PROTECTOR CONNECTOR D11718 PINS 13	DENSITOMETER CONNECTOR (REAR SPAR) D6890 PINS	COMPONENT	EQUIPMENT NO.	ACCESS DOOR
					DENSITOMETER	M10903	631AB
J9	11	1	1	1	SENSE		
K10	14	3, 8	3, 8	C1	SHIELD		
H10	12	15	15	2	DRIVE (POSITIVE)		
J10	13	11	11	3	DRIVE (NEGATIVE)		
G9	16	12	12	6	KR0		
G10	17	13	13	7	KR1		
G11	18	14	14	8	KR2		
G12	19	5	5	9	KR3		

CENTER TANK DENSITOMETER (WDM 28-41-41, -51)

13 AIRPLANES POST-SB 28A0085

FQIS Wiring
Figure 107 (Sheet 6)



1422076

03

28-41-00
CONFIG 3
Page 149
Sep 28/07


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

**** FAULT ## MESSAGE G##.**

EXAMPLE

THIS BLOCK SHOWS THE EXACT FAULT MESSAGE THAT SHOWS ON THE FQIS PROCESSOR DISPLAY. THERE ARE ABBREVIATIONS USED IN THE FAULT MESSAGES BECAUSE OF THE LIMITS ON THE DISPLAY. THE FUEL TANK AND COMPONENT INDICATIONS ARE SHOWN AS FOLLOWS:

"**" SHOWS THE FUEL TANK THAT THE FAULT MESSAGE IS FOR AS FOLLOWS:

- ** - "LM" LEFT MAIN FUEL TANK
- ** - "RM" RIGHT MAIN FUEL TANK
- ** - "CT" CENTER FUEL TANK

"###" THIS PLACE HOLDER SHOWS THE NUMERICAL INDICATION FOR TANK UNIT, OR OTHER NUMERICAL IDENTIFICATION. AN EXAMPLE IS AS FOLLOWS:

- ## - "1" INDICATION FOR NUMBER 1 TANK UNIT
- ## - "2" INDICATION FOR NUMBER 2 TANK UNIT
- ## - "3" INDICATION FOR NUMBER 3 TANK UNIT
- .
- .
- ## - "12" INDICATION FOR NUMBER 12 TANK UNIT

"G##" - THIS PLACE HOLDER INDICATION SHOWS IF THE FIRST APPLICABLE FAULT MESSAGE OCCURRED IN THE GROUND "G" MODE, OR IN THE AIR "A" MODE. THE "###" PLACE HOLDER INDICATION SHOWS HOW MANY TIMES THE FAULT OCCURRED DURING THE APPLICABLE FLIGHT LEG.

NOTE: THE "###" INDICATION WILL SHOW THE NUMBER OF TIMES THE FAULT OCCURRED AS FOLLOWS:

- FAULTS 1-9, WILL SHOW AS 1-9
- FAULTS 10-18, WILL SHOW AS 9
- FAULTS 19-28, WILL SHOW AS 19
- FAULTS 29-38, WILL SHOW AS 29
- FAULTS 39-48, WILL SHOW AS 39
- .
- .
- FAULTS 89-98, WILL SHOW AS 89
- FAULT 99, WILL SHOW AS 99

FAULT CONDITION

THIS BLOCK EXPLAINS THE FQIS SYSTEM FAULT CONDITIONS.

FLIGHT COMPARTMENT OR AIRPLANE INDICATION

- THIS BLOCK SHOWS THE POSSIBLE FLIGHT COMPARTMENT OR AIRPLANE INDICATIONS THAT WILL OCCUR BECAUSE OF THE FAULT MESSAGE SHOWN ABOVE.

CORRECTION

THIS BLOCK SHOWS THE STEPS TO CORRECT THE FAULT MESSAGE SHOWN ABOVE.

Fault Messages
Figure 108 (Sheet 1)

EFFECTIVITY
GUI 115

28-41-00
 CONFIG 3
 Page 150
 Sep 28/07

03


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	1
<p>** TU ## OPEN LOZ OR HIZ WIRE G##.</p>	
FAULT CONDITION	
<p>THIS FAULT MESSAGE SHOWS IF THE APPLICABLE TANK UNIT CAPACITANCE IS LESS THAN THE CAPACITANCE FOR AN EMPTY FUEL TANK, AND THERE ARE NO OTHER FAULTS IN THE SYSTEM.</p>	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - NORMAL IS POSSIBLE, WHEN ONLY ONE "*** TU ## OPEN LOZ OR HIZ WIRE G ##" FAULT MESSAGE SHOWS. WHEN YOU FUEL THE AIRPLANE THE VOLUME TOP-OFF (VTO) MECHANISM CAN STOP FUELING AT 5% LESS THAN FULL (SEE FAULT MESSAGE 32). - THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" SHOWS - THE FUEL QUANTITY INDICATION CAN GO OFF FOR THE APPLICABLE FUEL TANK, AND THE TOTAL FUEL QUANTITY INDICATION CAN GO OFF (FUEL QTY IND, M10054), AND THE EICAS STATUS MESSAGE "FUEL QTY IND" CAN SHOW. - WHILE FUELING, THE FUELING SHUTOFF VALVES CAN CLOSE FOR THE APPLICABLE FUEL TANK. THE "PUSH SET" MESSAGE CAN SHOW ON THE LSI ON THE FUELING CONTROL PANEL, P28, REFER TO AMM 12-11-01/301 TO CONTINUE FUELING. THE FUEL QUANTITY INDICATOR, M10054, WILL ALSO GO OFF. 	
CORRECTION	
<ol style="list-style-type: none"> 1. EXAMINE THE APPLICABLE CONNECTORS AND PINS FOR CORROSION OR DAMAGE TO THE PINS (FIG. 107). 2. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 3. IF THE PROBLEM CONTINUES, FIND THE OPEN WIRE BETWEEN THE FQIS PROCESSOR AND THE FUEL TANK. 4. MEASURE THE CAPACITANCE OF THE APPLICABLE TANK UNIT AT THE TANK WALL (SPAR) CONNECTOR (FIG. 109). 5. IF THE CAPACITANCE OF THE TANK UNIT IS ZERO, THE OPEN WIRE IS ON THE TANK WIRE HARNESS. <ol style="list-style-type: none"> A. GO INTO THE APPLICABLE FUEL TANK AND EXAMINE THE LO-Z/HI-Z CONNECTIONS AT THE TANK UNIT. 6. IF THE MEASURED CAPACITANCE IS OK, THE PROBLEM IS IN THE AIRPLANE WIRE HARNESS. 7. REPLACE OR REPAIR THE APPLICABLE HI-Z/LO-Z WIRE HARNESS (WDM 28-41-21,-31,-41). 8. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
Figure 108 (Sheet 2)

EFFECTIVITY
GUI 115

AD9421

03

28-41-00
 CONFIG 3
 Page 151
 Sep 28/07


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	2
** TU ## SHORTED IN TANK G##.	
FAULT CONDITION	
LESS THAN NORMAL RESISTANCE IS MEASURED FROM THE INNER TUBE OF THE TANK UNIT TO THE OUTER TUBE OF THE TANK UNIT.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" SHOWS. - THE FUEL QUANTITY INDICATION WILL GO OFF FOR THE APPLICABLE FUEL TANK, THE TOTAL FUEL QUANTITY INDICATION WILL GO OFF (FUEL QTY IND, M10054), AND THE EICAS STATUS MESSAGE "FUEL QTY IND" SHOWS. - WHILE FUELING, THE FUELING SHUTOFF VALVE CLOSES FOR THE APPLICABLE FUEL TANK. THE "PUSH SET" MESSAGE WILL SHOW ON THE LSI ON THE FUELING CONTROL PANEL, P28, SEE AMM 12-11-01/301 TO CONTINUE FUELING. THE FUEL QUANTITY INDICATOR FOR THE APPLICABLE FUEL TANK, M10054, WILL ALSO GO OFF. 	
CORRECTION	
<ol style="list-style-type: none"> 1. EXAMINE THE APPLICABLE SPAR CONNECTOR FOR CONDUCTIVE MATERIAL BETWEEN THE HI-Z AND LO-Z TERMINALS. 2. IF THE PROBLEM CONTINUES, DEFUEL THE APPLICABLE FUEL TANK (AMM 28-26-00/201). 3. USE THE SUMP TO REMOVE ALL THE REMAINING FUEL FROM THE APPLICABLE FUEL TANK, (AMM 12-11-03/301). 4. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 5. IF THE PROBLEM CONTINUES TO SHOW, GO INTO THE FUEL TANK AND EXAMINE THE APPLICABLE TANK UNIT FOR CONTAMINATION OR CONDUCTIVE MATERIAL IN THE TANK UNIT OR TERMINAL BLOCK (AMM 28-11-00/201). 6. REPLACE THE APPLICABLE TANK UNIT (AMM 28-41-01/401). 7. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
Figure 108 (Sheet 3)

EFFECTIVITY
GUI 115

28-41-00
 CONFIG 3
 Page 152
 Sep 28/07

03


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	3
** TU ?? SHORTED IN TANK G##.	
FAULT CONDITION	
THE RESISTANCE MEASURED FROM THE INNER TUBE OF A TANK UNIT OR THE COMPENSATOR TO THE OUTER TUBE OF THE TANK UNIT IS VERY LOW. WITH THIS FAULT THE PROCESSOR CANNOT ISOLATE THE FAILED TANK UNIT OR COMPENSATOR.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" WILL SHOW. - THE FUEL QUANTITY INDICATION WILL GO OFF FOR THE APPLICABLE FUEL TANK, THE TOTAL FUEL QUANTITY INDICATION WILL GO OFF (FUEL QTY IND, M10054), AND THE EICAS STATUS MESSAGE "FUEL QTY IND" SHOWS. - WHILE FUELING, THE FUELING SHUTOFF VALVE CLOSES FOR THE APPLICABLE FUEL TANK. THE "PUSH SET" MESSAGE WILL SHOW ON THE LSI ON THE FUELING CONTROL PANEL, P28, REFER TO AMM 12-11-01/301 TO CONTINUE FUELING. THE FUEL QUANTITY INDICATOR, M10054, WILL ALSO GO OFF FOR THE APPLICABLE FUEL TANK. 	
CORRECTION	
<ol style="list-style-type: none"> 1. GO TO THE "SYSTEM DATA?" MENU AND LOOK AT THE CAPACITANCE VALUES FOR THE TANK UNITS IN THE APPLICABLE FUEL TANK. 2. FIND THE TANK UNIT CAPACITANCE VALUE THAT IS 0.0, OR APPROXIMATELY 0.0 (FIG. 104, FIG. 109). <ol style="list-style-type: none"> A. IF A PROBLEM AT THE TANK UNIT OR SPAR CONNECTOR CANNOT BE FOUND, DO THE TEST: DRY CAPACITANCE TEST IN THE MAIN EQUIPMENT CENTER WITH THE 757/767-1 TEST BOX BOX (FIG. 109). 3. REPLACE THE APPLICABLE TANK UNIT (AMM 28-41-01/401). 4. IF THE PROBLEM CONTINUES, REPLACE THE APPLICABLE TANK WIRING HARNESS (AMM 28-41-04/401). 5. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
Figure 108 (Sheet 4)

EFFECTIVITY
GUI 115

28-41-00
 CONFIG 3
 Page 153
 Sep 28/07

03


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	4
** TU ## CONTAMINATED G##.	
FAULT CONDITION	
THERE IS CONTAMINATION BETWEEN THE INNER AND OUTER TUBES OF THE TANK UNIT THAT CAUSES A RESISTANCE LESS THAN THE USUAL RESISTANCE, OR THE CAPACITANCE MEASURED FOR THE TANK UNIT IS A MINIMUM OF 105% OF THE FULL VALUE, OR THERE IS A HI-Z SHIELD OPEN IN THE FUEL TANK. THERE CAN BE MORE THAN ONE TANK UNIT CONTAMINATION MESSAGE.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - NORMAL INDICATION WITH AN INDICATION ERROR FOR FUEL QUANTITY OF $\pm 5\%$ FOR THE APPLICABLE TANK (ONLY ONE TANK UNIT IS FAULTED). - THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" CAN SHOW. - IF THERE IS MORE THAN ONE CONTAMINATED TANK UNIT, OR THE HIGHEST TANK UNIT IN THE FUEL TANK IS CONTAMINATED, THE FUEL QUANTITY INDICATION WILL GO OFF (FUEL QTY IND, M10054), AND THE EICAS STATUS MESSAGE "FUEL QTY IND" SHOWS. - IF THERE IS MORE THAN ONE CONTAMINATED TANK UNIT (OR THE HIGHEST TANK UNIT IN THE FUEL TANK IS CONTAMINATED, WHILE FUELING, THE FUELING SHUTOFF VALVE WILL CLOSE FOR THE APPLICABLE FUEL TANK. THE "PUSH SET" MESSAGE WILL SHOW ON THE LSI ON THE FUELING CONTROL PANEL, P28, REFER TO AMM 12-11-01/301 TO CONTINUE FUELING. THE FUEL QUANTITY INDICATOR FOR THE APPLICABLE TANK, M10054, WILL ALSO GO OFF. 	
CORRECTION	
<ol style="list-style-type: none"> 1. DEFUEL THE APPLICABLE FUEL TANK (AMM 28-26-00/201). 2. DRAIN THE APPLICABLE FUEL TANK SUMP (AMM 12-11-03/301). 3. DO THE DRY CAPACITANCE TEST (FIG. 109). 4. MAKE SURE THE TANK UNIT CAPACITANCE VALUES ARE IN THE LIMITS ON FIG. 109. IF ALL THE TANK UNIT CAPACITANCE VALUES ARE IN THE LIMITS ON FIG. 109, GO TO STEP 8. 5. IF ONE OF THE TANK UNITS IS NOT IN THE LIMITS ON FIG. 109, REPLACE THE APPLICABLE TANK UNIT THAT SHOWS IN THE FAULT MESSAGE ON THE FQIS PROCESSOR DISPLAY (AMM 28-41-01/401). 6. IF MORE THAN ONE OF THE TANKS CAPACITANCE VALUES ARE NOT IN THE LIMITS ON FIG. 109, EXAMINE THE HI-Z SHIELD CONNECTIONS AT THE TANK UNIT AND REPLACE THE APPLICABLE FUEL TANK WIRING HARNESS (AMM 28-41-09/401). 7. IF THE PROBLEM CONTINUES, REPLACE THE APPLICABLE WIRE HARNESS (AMM 28-41-09/401). 8. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
Figure 108 (Sheet 5)

EFFECTIVITY
GUI 115

28-41-00
 CONFIG 3
 Page 154
 Sep 28/07

03

FAULT MESSAGE	5
** TU ## SHORTED TO GROUND G##.	
FAULT CONDITION	
THE APPLICABLE TANK UNIT OR LO-Z WIRE IS SHORTED TO GROUND.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - NORMAL OPERATION WITH AN INDICATION ERROR FOR FUEL QUANTITY OF $\pm 5\%$ FOR THE APPLICABLE TANK (ONLY ONE TANK UNIT CAN BE BAD). - THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" CAN SHOW. - IF THERE IS MORE THAN ONE ELECTRICAL SHORT THE FUEL QUANTITY INDICATION WILL GO OFF FOR THE APPLICABLE FUEL TANK, THE TOTAL FUEL QUANTITY INDICATION WILL GO OFF (FUEL QTY IND, M10054), AND THE EICAS STATUS MESSAGE "FUEL QTY IND" SHOWS. - IF THERE IS MORE THAN ONE ELECTRICAL SHORT WHILE FUELING, THE FUELING SHUTOFF VALVE CLOSES FOR THE APPLICABLE FUEL TANK. THE "PUSH SET" MESSAGE WILL SHOW ON THE FUEL QUANTITY INDICATORS ON THE FUELING CONTROL PANEL, P28, REFER TO AMM 12-11-01/301 TO CONTINUE FUELING. THE FUEL QUANTITY INDICATOR, M10054, WILL ALSO GO OFF. 	
CORRECTION	
<ol style="list-style-type: none"> 1. OPEN THE HI-Z/LO-Z CONNECTOR FOR THE APPLICABLE FUEL TANK (FIG. 107). 2. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?" 3. IF THE FAULT MESSAGE CONTINUES TO SHOW WHEN THE HI-Z/LO-Z CONNECTOR IS OPEN, THEN THE PROBLEM IS BETWEEN THE FQIS PROCESSOR AND THE HI-Z/LO-Z CONNECTOR AT THE FRONT SPAR. <p style="margin-left: 20px;"><u>NOTE:</u> THE OTHER TANK UNITS AND COMPENSATOR WILL SHOW THE OPEN LO-Z OR HI-Z FAULT MESSAGE AND THE OPEN HI-Z AT SPAR FAULT MESSAGE WILL SHOW, WHEN THE SPAR CONNECTOR IS OPEN. IGNORE THESE OPEN FAULT MESSAGES.</p> 4. EXAMINE THE WIRING TO FIND THE TANK UNIT LO-Z SHORT TO GROUND AND REPAIR OR REPLACE THE APPLICABLE WIRING (WDM 28-41-21,-31,-41). 5. IF THE PROBLEM GOES AWAY THE SHORTED CIRCUIT IS IN THE FUEL TANK. 6. GO INTO THE APPLICABLE FUEL TANK (AMM 28-11-00/201). <p style="margin-left: 20px;"><u>NOTE:</u> THE OTHER TANK UNITS AND COMPENSATOR WILL SHOW THE OPEN LO-Z OR HI-Z FAULT MESSAGE AND THE OPEN HI-Z AT SPAR FAULT MESSAGE WILL SHOW, WHEN THE SPAR CONNECTOR IS OPEN. IGNORE THESE OPEN FAULT MESSAGES.</p> 7. EXAMINE AND REPLACE THE APPLICABLE TANK UNIT (AMM 28-41-01/401). <p style="margin-left: 20px;"><u>NOTE:</u> MAKE SURE THE TANK UNIT HAS CLEARANCE FROM THE AIRPLANE STRUCTURE.</p> 8. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 9. IF THE PROBLEM CONTINUES, EXAMINE AND REPLACE THE TANK WIRING HARNESS (WDM 28-41-21,-31,-41). 10. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
Figure 108 (Sheet 6)

EFFECTIVITY
GUI 115

28-41-00
 CONFIG 3
 Page 155
 Sep 28/07

03


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	6
** COMP OPEN LOZ OR HIZ WIRE G##.	
FAULT CONDITION	
THIS MESSAGE IS SENT IF THE MEASURED CAPACITANCE OF THE APPLICABLE TANK UNIT IS BELOW THE MINIMUM VALUE (FIG. 108), AND THERE ARE NO OTHER FAULTS.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - NORMAL OPERATION WITH AN INDICATION ERROR FOR FUEL QUANTITY OF $\pm 5\%$ FOR THE APPLICABLE TANK (ONLY ONE TANK UNIT CAN BE BAD). - THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" CAN SHOW. - THE FUEL OPERATION CAN STOP AT 5% OR 13% LESS THAN THE VOLUMETRIC SHUTOFF (VSO) POINT TO PREVENT A FUEL SPILL. 	
CORRECTION	
<ol style="list-style-type: none"> 1. EXAMINE AND CLEAN THE APPLICABLE CONNECTORS (FIG. 107). 2. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?", TO SEE IF THE FAULT MESSAGES CONTINUE TO SHOW. 3. IF THE PROBLEM CONTINUES, FIND THE OPEN WIRE BETWEEN THE FQIS PROCESSOR AND THE FUEL TANK. 4. MEASURE THE CAPACITANCE OF THE APPLICABLE COMPENSATOR AT THE TANK WALL (SPAR) CONNECTOR (FIG. 107). 5. IF THE CAPACITANCE OF THE COMPENSATOR IS ZERO, THE OPEN WIRE IS ON THE TANK WIRE HARNESS. <ol style="list-style-type: none"> A. GO INTO THE APPLICABLE FUEL TANK AND EXAMINE THE LO-Z/HI-Z CONNECTIONS AT THE COMPENSATOR. 6. IF THE MEASURED CAPACITANCE IS OK, THE PROBLEM IS IN THE AIRPLANE WIRE HARNESS. 7. REPLACE OR REPAIR THE APPLICABLE HI-Z/LO-Z WIRE HARNESS (WDM 28-41-21,-31,-41). 8. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
Figure 108 (Sheet 7)

EFFECTIVITY
GUI 115

28-41-00
 CONFIG 3
 Page 156
 Sep 28/07

03


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	7
** COMP SHORTED IN TANK G##.	
FAULT CONDITION	
THERE IS LESS THAN 10,000 OHMS OF RESISTANCE BETWEEN THE INNER AND OUTER TUBES OF THE APPLICABLE TANK UNIT.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - THE FUEL QUANTITY INDICATION WILL GO OFF FOR THE APPLICABLE FUEL TANK, THE TOTAL FUEL QUANTITY INDICATION WILL GO OFF (FUEL QTY IND, M10054), AND THE EICAS STATUS MESSAGE "FUEL QTY IND" SHOWS. - WHILE FUELING, THE FUELING SHUTOFF VALVE CLOSES FOR THE APPLICABLE FUEL TANK. THE "PUSH SET" MESSAGE WILL SHOW ON THE FUEL QUANTITY INDICATORS ON THE FUELING CONTROL PANEL, P28, REFER TO AMM 12-11-01/301 TO CONTINUE FUELING. THE FUEL QUANTITY INDICATOR, M10054, WILL ALSO GO OFF. 	
CORRECTION	
<ol style="list-style-type: none"> 1. DEFUEL THE APPLICABLE FUEL TANK (AMM 28-26-00/201). 2. DRAIN THE APPLICABLE FUEL TANK SUMP (AMM 12-11-03/301). 3. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?" 4. IF THE PROBLEM CONTINUES, EXAMINE THE APPLICABLE COMPENSATOR AND TERMINAL BLOCK FOR CONTAMINATION. <u>NOTE:</u> MAKE SURE THE COMPENSATOR HAS CLEARANCE WITH THE AIRPLANE STRUCTURE. 5. REPLACE THE APPLICABLE COMPENSATOR IF IT IS NECESSARY (AMM 28-41-02/401). 6. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?" 	

Fault Messages
Figure 108 (Sheet 8)

EFFECTIVITY
GUI 115

28-41-00
 CONFIG 3
 Page 157
 Sep 28/07

03


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	8
** COMPENSATOR CONTAMINATED G##.	
FAULT CONDITION	
THE COMPENSATOR OR DENSITOMETER IS BAD; OR BOTH THE COMPENSATOR AND DENSITOMETER ARE BAD.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
- THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" SHOWS.	
CORRECTION	
<ol style="list-style-type: none"> 1. DEFUEL THE APPLICABLE FUEL TANK (AMM 28-26-00/201). 2. DRAIN THE APPLICABLE FUEL TANK SUMP (AMM 12-11-03/301). 3. DO THE DRY CAPACITANCE TEST (FIG. 109). 4. IF THE FAULT CONTINUES TO SHOW, DISCONNECT THE APPLICABLE SPAR CONNECTOR AND EXAMINE IT FOR DAMAGE OR CONTAMINATION. 5. REPAIR OR REPLACE THE WIRE HARNESS IF IT IS NECESSARY (WDM 28-41-21,-31,-41). 6. IF THE PROBLEM CONTINUES, MEASURE THE RESISTANCE BETWEEN THE APPLICABLE HI-Z SHIELD AND AIRPLANE GROUND ON THE AIRPLANE WIRE HARNESS (AMM 28-41-00/501). 7. IF THE MEASURED RESISTANCE IS MORE THAN 7 OHMS, EXAMINE THE HI-Z SHIELD CONNECTIONS BETWEEN THE SPAR AND THE PROCESSOR (FIG. 107). 8. IF THE PROBLEM CONTINUES, YOU MUST GO INTO THE FUEL TANK (AMM 28-11-00/201). 9. EXAMINE THE FUEL TANK FOR WATER, MICROBIAL GROWTH, OR OTHER CONTAMINANTS NEAR THE COMPENSATOR. 10. IF THERE IS NO CONTAMINATION, THEN DO A RESISTANCE TEST TO MAKE SURE THE HI-Z SHIELD RESISTANCE IS LESS THAN 1 OHM BETWEEN THE COMPENSATOR AND THE HI-Z SHIELD CONTACT AT THE SPAR CONNECTOR. 11. IF THE SHIELD RESISTANCE IS OK, REPLACE THE COMPENSATOR (AMM 28-41-02/401). 12. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
Figure 108 (Sheet 9)

EFFECTIVITY
GUI 115

28-41-00
 CONFIG 3
 Page 158
 Sep 28/07

03


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	9
** COMP SHORTED TO GROUND G##.	
FAULT CONDITION	
THE APPLICABLE TANK UNIT OUTER TUBE OR LO-Z WIRE IS SHORTED TO GROUND.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - NORMAL OPERATION WITH AN INDICATION ERROR FOR FUEL QUANTITY OF $\pm 5\%$ FOR THE APPLICABLE TANK (ONLY ONE TANK UNIT CAN BE BAD). - THE FUEL OPERATION CAN STOP AT 5% OR 13% LESS THAN THE VOLUMETRIC SHUTOFF (VSO) POINT TO PREVENT A FUEL SPILL. - THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" SHOWS 	
CORRECTION	
<ol style="list-style-type: none"> 1. OPEN THE APPLICABLE HI-Z/LO-Z CONNECTOR (FIG. 107). 2. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?" <u>NOTE:</u> WHEN YOU OPEN THE SPAR CONNECTOR, "OPEN" FAULT MESSAGES WILL SHOW. IGNORE THESE "OPEN" FAULT MESSAGES. 3. IF THE FAULT MESSAGE CONTINUES TO SHOW, FOR THE APPLICABLE COMPENSATOR, THE FAILURE IS BETWEEN THE APPLICABLE HI-Z/LO-Z CONNECTOR AND THE FQIS PROCESSOR (M121), GO TO STEP 5. <u>NOTE:</u> ALL THE TANK UNITS WILL SHOW THE FAULT MESSAGES OPEN LO-Z OR HI-Z WIRE WHEN YOU OPEN THE SPAR CONNECTOR. IGNORE THESE OPEN FAULT MESSAGES. 4. IF THE FAULT MESSAGE DOES NOT SHOW AFTER STEP 2, THE PROBLEM IS IN THE FUEL TANK, GO TO STEP 6. 5. FIND THE SHORTED COMPENSATOR LO-Z WIRE. REPAIR OR REPLACE THE WIRE AS NECESSARY (WDM 28-41-21,-31,-41). 6. EXAMINE AND REPLACE THE APPLICABLE COMPENSATOR (AMM 28-41-02/401). <u>NOTE:</u> MAKE SURE THE COMPENSATOR HAS CLEARANCE FROM THE AIRPLANE STRUCTURE. 7. IF THE PROBLEM CONTINUES, EXAMINE AND REPLACE THE APPLICABLE TANK WIRING HARNESS (WDM 28-41-21,-31,-41). 8. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
Figure 108 (Sheet 10)

EFFECTIVITY
GUI 115

A09431

28-41-00
 CONFIG 3
 Page 159
 Sep 28/07

03


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	10
<p>** HIZ WIRE OPEN AT SPAR G##.</p>	
FAULT CONDITION	
<p>THIS MESSAGE SHOWS IF THERE IS AN OPEN IN THE CENTER CONDUCTOR OF THE HI-Z WIRE. THE OPEN WIRE IS USUALLY NEAR THE APPLICABLE HI-Z/LO-Z CONNECTOR. THIS INCLUDES THE POINTS BETWEEN A POINT HALF THE DISTANCE BETWEEN THE FQIS PROCESSOR AND THE HI-Z/LO-Z CONNECTOR, AND A POINT HALF THE DISTANCE BETWEEN THE HI-Z/LO-Z CONNECTOR AND THE FIRST TANK SENSOR.</p>	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - THE FUEL QUANTITY INDICATION WILL GO OFF FOR THE APPLICABLE FUEL TANK, THE TOTAL FUEL QUANTITY INDICATION WILL GO OFF (FUEL QTY IND, M10054), AND THE EICAS STATUS MESSAGE "FUEL QTY IND" SHOWS. - WHILE FUELING, THE FUELING SHUTOFF VALVE CLOSURES FOR THE APPLICABLE FUEL TANK. THE "PUSH SET" MESSAGE WILL SHOW ON THE FUEL QUANTITY INDICATORS ON THE FUELING CONTROL PANEL, P28, REFER TO AMM 12-11-01/301 TO CONTINUE FUELING. THE FUEL QUANTITY INDICATOR, M10054, WILL ALSO GO OFF. 	
CORRECTION	
<ol style="list-style-type: none"> 1. EXAMINE THE APPLICABLE HI-Z/LO-Z CONNECTOR FOR CONTAMINATION OR DAMAGE (FIG. 107). 2. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104, "SELF TEST ?" TO SEE IF THE FAULT MESSAGE CONTINUES TO SHOW. 3. DO A TEST ON THE APPLICABLE HI-Z WIRE TO FIND THE OPEN WIRE (WDM 28-41-21,-31,-41). <ol style="list-style-type: none"> A. ON THE FRONT PANEL OF THE FQIS PROCESSOR, GO TO THE "SYSTEM DATA?" MENU. FIND THE CAPACITANCE VALUE FOR THE APPLICABLE HI-Z WIRE. IF YOU DIVIDE THIS VALUE BY 50, YOU WILL HAVE THE APPROXIMATE VALUE FOR THE DISTANCE (IN FEET) TO THE OPEN WIRE FROM THE FQIS PROCESSOR. 4. REPAIR OR REPLACE THE APPLICABLE WIRING HARNESS (WDM 28-41-21,-31,-41). 5. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
 Figure 108 (Sheet 11)

EFFECTIVITY
GUI 115

28-41-00
 CONFIG 3
 Page 160
 Sep 28/07

03

FAULT MESSAGE	11
<p>** HIZ SHIELD OPEN AT SPAR G##.</p>	
FAULT CONDITION	
<p>THIS MESSAGE SHOWS IF THERE IS AN OPEN IN THE HI-Z WIRE. THE OPEN WIRE WILL BE NEAR THE APPLICABLE HI-Z/LO-Z CONNECTOR. THIS INCLUDES THE POINTS BETWEEN A POINT HALF THE DISTANCE BETWEEN THE FQIS PROCESSOR AND THE HI-Z/LO-Z CONNECTOR, AND A POINT HALF THE DISTANCE BETWEEN THE HI-Z/LO-Z CONNECTOR AND THE FIRST TANK UNIT.</p>	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - THE FUEL QUANTITY INDICATION WILL GO OFF FOR THE APPLICABLE FUEL TANK, THE TOTAL FUEL QUANTITY INDICATION WILL GO OFF (FUEL QTY IND, M10054), AND THE EICAS STATUS MESSAGE "FUEL QTY IND" SHOWS. - WHILE FUELING, THE FUELING SHUTOFF VALVE CLOSES FOR THE APPLICABLE FUEL TANK. THE "PUSH SET" MESSAGE WILL SHOW ON THE FUEL QUANTITY INDICATORS ON THE FUELING CONTROL PANEL, P28, REFER TO AMM 12-11-01/301 TO CONTINUE FUELING. THE FUEL QUANTITY INDICATOR, M10054, WILL ALSO GO OFF. 	
CORRECTION	
<ol style="list-style-type: none"> 1. EXAMINE THE APPLICABLE CONNECTORS FOR CONTAMINATION OR DAMAGE (FIG. 107). 2. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?" TO SEE IF THE FAULT MESSAGE CONTINUES TO SHOW. 3. DO A TEST ON THE APPLICABLE HI-Z SHIELD TO FIND THE OPEN SHIELD (WDM 28-41-21,-31,-41). <ol style="list-style-type: none"> A. ON THE FRONT PANEL OF THE FQIS PROCESSOR, GO TO THE "SYSTEM DATA?" MENU. FIND THE CAPACITANCE VALUE FOR THE APPLICABLE HI-Z WIRE. IF YOU DIVIDE THIS VALUE BY 50, YOU WILL HAVE THE APPROXIMATE VALUE FOR THE DISTANCE (IN FEET) TO THE OPEN WIRE FROM THE FQIS PROCESSOR. 4. EXAMINE, REPAIR OR REPLACE THE APPLICABLE HI-Z WIRING HARNESS AS NECESSARY (WDM 28-41-21,-31,-41). 5. DO THIS PROCEDURE: FUEL QTY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
 Figure 108 (Sheet 12)

EFFECTIVITY
 GUI 115

28-41-00
 CONFIG 3
 Page 161
 Sep 28/07

03


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	12
** HIZ WIRE OPEN AT PROCESSOR G##.	
FAULT CONDITION	
THIS MESSAGE SHOWS IF THERE IS AN OPEN IN THE CENTER WIRE OF THE HI-Z CABLE. THE OPEN WIRE WILL BE NEAR THE FQIS PROCESSOR. THIS INCLUDES THE POINTS BETWEEN THE FQIS PROCESSOR CONNECTOR, AND A POINT HALF THEIR DISTANCE BETWEEN THE FQIS PROCESSOR CONNECTOR AND THE HI-Z/LO-Z CONNECTOR.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - THE FUEL QUANTITY INDICATION WILL GO OFF FOR THE APPLICABLE FUEL TANK, THE TOTAL FUEL QUANTITY INDICATION WILL GO OFF (FUEL QTY IND, M10054), AND THE EICAS STATUS MESSAGE "FUEL QTY IND" SHOWS. - WHILE FUELING, THE FUELING SHUTOFF VALVE CLOSES FOR THE APPLICABLE FUEL TANK. THE "PUSH SET" MESSAGE WILL SHOW ON THE FUEL QUANTITY INDICATORS ON THE FUELING CONTROL PANEL, P28, REFER TO AMM 12-11-01/301 TO CONTINUE FUELING. THE FUEL QUANTITY INDICATOR, M10054, WILL ALSO GO OFF. 	
CORRECTION	
<ol style="list-style-type: none"> 1. EXAMINE THE FQIS PROCESSOR CONNECTOR AND THE E/E BAY RACK CONNECTOR FOR CONTAMINATION OR DAMAGE (FIG. 107). <ol style="list-style-type: none"> A. ON THE FRONT PANEL OF THE FQIS PROCESSOR, GO TO THE "SYSTEM DATA?" MENU. FIND THE CAPACITANCE VALUE FOR THE APPLICABLE HI-Z WIRE. IF YOU DIVIDE THIS VALUE BY 50, YOU WILL HAVE THE APPROXIMATE VALUE FOR THE DISTANCE (IN FEET) TO THE OPEN WIRE FROM THE FQIS PROCESSOR. 2. EXAMINE AND REPAIR THE APPLICABLE WIRE CIRCUIT (WDM 28-41-21,-31,-41). 3. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
Figure 108 (Sheet 13)

EFFECTIVITY
GUI 115

28-41-00
 CONFIG 3
 Page 162
 Sep 28/07

03


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	13
** HIZ SHIELD OPEN AT PROC G##.	
FAULT CONDITION	
THIS MESSAGE SHOWS IF THERE IS AN OPEN IN THE SHIELD WIRE OF THE HI-Z CABLE. THE OPEN WIRE WILL BE NEAR THE FQIS PROCESSOR. THIS INCLUDES THE POINTS BETWEEN THE FQIS PORCESSOR CONNECTOR, AND A POINT HALF THE DISTANCE BETWEEN THE FQIS PROCESSOR CONNECTOR AND THE HI-Z/LO-Z CONNECTOR.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - THE FUEL QUANTITY INDICATION WILL GO OFF FOR THE APPLICABLE FUEL TANK, THE TOTAL FUEL QUANTITY INDICATION WILL GO OFF (FUEL QTY IND, M10054), AND THE EICAS STATUS MESSAGE "FUEL QTY IND" SHOWS. - WHILE FUELING, THE FUELING SHUTOFF VALVE CLOSES FOR THE APPLICABLE FUEL TANK. THE "PUSH SET" MESSAGE WILL SHOW ON THE FUEL QUANTITY INDICATORS ON THE FUELING CONTROL PANEL, P28, REFER TO AMM 12-11-01/301 TO CONTINUE FUELING. THE FUEL QUANTITY INDICATOR, M10054, WILL ALSO GO OFF. 	
CORRECTION	
<ol style="list-style-type: none"> 1. EXAMINE THE FQIS PROCESSOR CONNECTOR AND THE E/E BAY RACK CONNECTOR FOR CONTAMINATION OR DAMAGE (FIG. 107). <ol style="list-style-type: none"> A. ON THE FRONT PANEL OF THE FQIS PROCESSOR, GO TO THE "SYSTEM DATA?" MENU. FIND THE CAPACITANCE VALUE FOR THE APPLICABLE HI-Z WIRE. IF YOU DIVIDE THIS VALUE BY 50, YOU WILL HAVE THE APPROXIMATE VALUE FOR THE DISTANCE (IN FEET) TO THE OPEN WIRE FROM THE FQIS PROCESSOR. 2. EXAMINE AND REPAIR THE APPLICABLE WIRE CIRCUIT (WDM 28-41-21,-31,-41). 3. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
Figure 108 (Sheet 14)

EFFECTIVITY
GUI 115

28-41-00
 CONFIG 3
 Page 163
 Sep 28/07

03


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	14
** HIZ WIRE LOW RESISTANCE G##.	
FAULT CONDITION	
THIS MESSAGE SHOWS IF LESS THAN 402,000 OHMS OF RESISTANCE IS MEASURED BETWEEN THE HI-Z SHIELD AND THE HI-Z CENTER CONDUCTOR.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
- NORMAL OPERATION - THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" SHOWS.	
CORRECTION	
<ol style="list-style-type: none"> 1. EXAMINE THE APPLICABLE WIRE CONNECTORS FOR CONTAMINATION OR DAMAGE (FIG. 107). CLEAN OR REPAIR THE CONNECTIONS AS NECESSARY. 2. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 3. IF THE PROBLEM CONTINUES, OPEN THE APPLICABLE HI-Z/LO-Z CONNECTOR (FIG. 107) AND THE FUEL QUANTITY BITE PROCEDURE, SEE FIG. 104, SELF-TEST? 4. IF THE FAULT MESSAGE SHOWS THE PROBLEM IS BETWEEN THE FQIS PROCESSOR AND THE HI-Z/LO-Z CONNECTOR AT THE FRONT SPAR. GO TO STEP 6. <p style="margin-left: 20px;"><u>NOTE:</u> THE OTHER TANK UNITS AND COMPENSATOR WILL SHOW THE OPEN LO-Z OR HI-Z FAULT MESSAGE WHEN THE SPAR CONNECTOR IS OPEN. IGNORE THESE OPEN FAULT MESSAGES.</p> <ol style="list-style-type: none"> 5. IF THE FAULT MESSAGE DOES NOT SHOW THE PROBLEM IS IN THE APPLICABLE TANK WIRING HARNESS. GO TO STEP 7. 6. REPAIR OR REPLACE THE CIRCUIT BETWEEN THE FQIS PROCESSOR AND THE APPLICABLE HI-Z/LO-Z CONNECTOR (WDM 28-41-21,-31,-41). 7. EXAMINE AND REPLACE THE APPLICABLE TANK WIRING HARNESS (AMM 28-41-09/401). 8. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
Figure 108 (Sheet 15)

EFFECTIVITY
GUI 115

AD9437

28-41-00

CONFIG 3
 Page 164
 Sep 28/07

03


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	15
** HIZ SHORTED WIRE TO SHLD G##.	
FAULT CONDITION	
THIS MESSAGE SHOWS IF LESS THAN 2,180 OHMS RESISTANCE IS MEASURED BETWEEN THE HI-Z SHIELD AND THE HI-Z CENTER CONDUCTOR.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - THE FUEL QUANTITY INDICATION WILL GO OFF FOR THE APPLICABLE FUEL TANK, THE TOTAL FUEL QUANTITY INDICATION WILL GO OFF (FUEL QTY IND, M10054), AND THE EICAS STATUS MESSAGE "FUEL QTY IND" SHOWS. - WHILE FUELING, THE FUELING SHUTOFF VALVE CLOSES FOR THE APPLICABLE FUEL TANK. THE "PUSH SET" MESSAGE WILL SHOW ON THE FUEL QUANTITY INDICATORS ON THE FUELING CONTROL PANEL, P28, REFER TO AMM 12-11-01/301 TO CONTINUE FUELING. THE FUEL QUANTITY INDICATOR, M10054, WILL ALSO GO OFF. 	
CORRECTION	
<ol style="list-style-type: none"> 1. EXAMINE THE APPLICABLE WIRE CONNECTORS FOR CONTAMINATION OR DAMAGE (FIG. 107). CLEAN OR REPAIR THE CONNECTIONS AS NECESSARY. 2. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 3. IF THE PROBLEM CONTINUES, OPEN THE APPLICABLE HI-Z/LO-Z CONNECTOR (FIG. 107), AND THE FUEL QUANTITY BITE PROCEDURE, FIG. 104, SELF-TEST? 4. IF THE FAULT MESSAGE SHOWS THE PROBLEM IS BETWEEN THE FQIS PROCESSOR AND THE HI-Z/LO-Z CONNECTOR AT THE FRONT SPAR, GO TO STEP 6. <u>NOTE:</u> THE OTHER TANK UNITS AND COMPENSATOR WILL SHOW THE OPEN LO-Z OR HI-Z FAULT MESSAGE WHEN THE SPAR CONNECTOR IS OPEN. IGNORE THESE OPEN FAULT MESSAGES. 5. IF THE FAULT MESSAGE DOES NOT SHOW, THE PROBLEM IS IN THE APPLICABLE TANK WIRING HARNESS. GO TO STEP 7. 6. REPAIR OR REPLACE THE APPLICABLE AIRPLANE WIRING HARNESS (WDM 28-41-21,-31,-41). 7. EXAMINE AND REPLACE THE APPLICABLE TANK WIRING HARNESS (AMM 28-41-09/401). 8. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
Figure 108 (Sheet 16)

EFFECTIVITY
GUI 115

28-41-00
 CONFIG 3
 Page 165
 Sep 28/07

03


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL



FAULT MESSAGE	16
<p>** HIZ SHIELD SHORT TO GND G##.</p>	
FAULT CONDITION	
<p>THIS FAULT MESSAGE SHOWS IF THERE IS A HI-Z SHIELD SHORTED TO A LO-Z WIRE, OR THE HI-Z SHIELD IS SHORTED TO GROUND AT A POINT OTHER THAN AT THE PROCESSOR.</p>	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<p>- THE FUEL QUANTITY INDICATION WILL GO OFF FOR THE APPLICABLE FUEL TANK, THE TOTAL FUEL QUANTITY INDICATION WILL GO OFF (FUEL QTY IND, M10054), AND THE EICAS STATUS MESSAGE "FUEL QTY IND" SHOWS.</p> <p>- WHILE FUELING, THE FUELING SHUTOFF VALVE CLOSES FOR THE APPLICABLE FUEL TANK. THE "PUSH SET" MESSAGE WILL SHOW ON THE FUEL QUANTITY INDICATORS ON THE FUELING CONTROL PANEL, P28, REFER TO AMM 12-11-01/301 TO CONTINUE FUELING. THE FUEL QUANTITY INDICATOR, M10054, WILL ALSO GO OFF.</p>	
CORRECTION	
<ol style="list-style-type: none"> 1. OPEN THE APPLICABLE HI-Z/LO-Z CONNECTOR (FIG. 107). 2. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 3. IF THE FAULT MESSAGE SHOWS THE PROBLEM IS BETWEEN THE FQIS PROCESSOR AND THE HI-Z/LO-Z CONNECTOR AT THE FRONT SPAR, GO TO STEP 5. <p style="margin-left: 20px;"><u>NOTE:</u> THE OTHER TANK UNITS AND COMPENSATOR WILL SHOW THE OPEN LO-Z OR HI-Z FAULT MESSAGE WHEN THE SPAR CONNECTOR IS OPEN. IGNORE THESE OPEN FAULT MESSGES.</p> 4. IF THE FAULT MESSAGE DOES NOT SHOW, THE PROBLEM IS IN THE APPLICABLE FUEL TANK WIRING HARNESS. GO TO STEP 6. <p style="margin-left: 20px;"><u>NOTE:</u> WHEN THE PROCESSOR IS INSTALLED, THE USUAL HI-Z SHIELD TO AIRPLANE GROUND (OR THE HI-Z SHIELD TO LO-Z WIRE) RESISTANCE IS 4.5 TO 6.5 OHMS. WHEN THE PROCESSOR IS REMOVED, THE SAME RESISTANCE CHECKS WILL SHOW MORE THAN 10 MEGOHMS (AMM 28-41-00/501).</p> 5. EXAMINE AND REPAIR THE CIRCUIT BETWEEN THE FQIS PROCESSOR AND THE APPLICABLE HI-Z/LO-Z CONNECTOR (AMM 28-41-00/501)(WDM 28-41-21, -31, -41). 6. REPAIR OR REPLACE THE APPLICABLE TANK WIRING HARNESS (AMM 28-41-09/401). 7. IF THE PROBLEM CONTINUES, EXAMINE AND REPLACE THE APPLICABLE COMPENSATOR OR TANK UNIT (AMM 28-41-01,-02/401). 8. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
Figure 108 (Sheet 17)

EFFECTIVITY
GUI 115

28-41-00
 CONFIG 3
 Page 166
 Sep 28/07

03

FAULT MESSAGE	17
<p>** DENS RESISTOR UNREADABLE G##.</p>	
FAULT CONDITION	
<p>THIS MESSAGE SHOWS IF ONE OR MORE OF THE CALIBRATION RESISTORS IN THE DENSITOMETER DOES NOT OPERATE CORRECTLY. THE FAULT CONDITIONS ARE AS FOLLOWS:</p> <ol style="list-style-type: none"> 1. DENSITOMETER INSTALLED BACKWARDS 2. CALIBRATION WIRE SHORTED TO GROUND 3. CALIBRATION RESISTOR FAILED 4. CALIBRATION WIRE SHORTED TO ANOTHER CALIBRATION WIRE 5. DENSITOMETER DRIVE WIRE OPEN <p><u>NOTE:</u> FOR ANY DENSITOMETER FAULT MESSAGE, WHERE THE DENSITOMETER IS STILL IN NORMAL RANGE, THE FAULT MESSAGE COMPENSATOR CONTAMINATED CAN SHOW.</p>	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - NORMAL OPERATION WITH AN INDICATION ERROR FOR FUEL QUANTITY OF $\pm 5\%$ FOR THE APPLICABLE TANK (ONLY ONE TANK UNIT CAN BE BAD). - THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" SHOWS. 	
CORRECTION	
<ol style="list-style-type: none"> 1. REMOVE THE FQIS PROCESSOR, M121 (AMM 28-41-08/401). 2. INSTALL THE PSD 757/767-1 TESTER AND DO THE DENSITOMETER TEST. <p><u>NOTE:</u> NO OTHER TEST BOX IS NECESSARY TO DO THE DENSITOMETER TEST. READ THE GO-NO-GO (RED/GREEN) LED LIGHT ON THE FRONT OF THE 757/767-1 TEST BOX.</p> 3. MAKE A WRITTEN RECORD OF THE PROBLEM. 4. OPEN THE APPLICABLE DENSITOMETER CONNECTOR AT THE REAR SPAR (FIG. 107). 5. CONNECT THE PSD 757/767-1 TESTER TO THE DENSITOMETER CONNECTOR ON THE REAR SPAR AND DO A TEST. 6. IF A FAILURE INDICATION DOES NOT SHOW, THE PROBLEM IS IN THE HOT SHORT PROTECTOR  OR AIRPLANE WIRE HARNESS. <ol style="list-style-type: none"> A. REPAIR OR REPLACE THE HOT SHORT PROTECTOR, M11872 (AMM 28-41-24/401)  OR THE APPLICABLE AIRPLANE HARNESS (WDM 28-41-21, -31, -41). 7. IF A FAILURE INDICATION CONTINUES TO SHOW, THE PROBLEM IS IN THE APPLICABLE FUEL TANK. <ol style="list-style-type: none"> A. YOU MUST GO INTO THE APPLICABLE FUEL TANK (AMM 28-11-00/201). B. EXAMINE THE DENSITOMETER TERMINALS FOR CONTAMINATION, CLEAN OR REPAIR AS NECESSARY. C. IF YOU CANNOT FIND ANY CONTAMINATION, REPLACE THE DENSITOMETER (AMM 28-41-04/401). 8. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

 IF INSTALLED, CENTER TANK ONLY (POST-SB 28A0085)



Fault Messages
Figure 108 (Sheet 18)

EFFECTIVITY
GUI 115

28-41-00
 CONFIG 3
 Page 167
 Sep 28/07

03

 **BOEING**
757
FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	18
** DENS EXCITA- TION SHORTED G##.	
FAULT CONDITION	
THIS FAULT MESSAGE SHOWS IF THE DENSITOMETER DRIVE CIRCUIT DOES NOT HAVE SUFFICIENT RESISTANCE BETWEEN THE POSITIVE OR NEGATIVE DRIVE WIRES, AND AIRPLANE GROUND. <u>NOTE:</u> FOR ANY DENSITOMETER FAULT MESSAGE, WHERE THE DENSITOMETER IS STILL IN NORMAL RANGE, THE FAULT MESSAGE COMPENSATOR CONTAMINATED CAN SHOW.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
- NORMAL OPERATION WITH AN INDICATION ERROR FOR FUEL QUANTITY OF $\pm 5\%$ FOR THE APPLICABLE TANK (ONLY ONE TANK UNIT CAN BE BAD). - THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" SHOWS.	
CORRECTION	
<ol style="list-style-type: none"> 1. REMOVE THE FQIS PROCESSOR, M121 (AMM 28-41-08/401). 2. INSTALL THE PSD 757/767-1 TESTER AND DO THE DENSITOMETER TEST. <u>NOTE:</u> NO OTHER TEST BOX IS NECESSARY TO DO THE DENSITOMETER TEST. READ THE GO-NO-GO (RED/GREEN) LED LIGHT ON THE FRONT OF THE 757/767-1 TEST BOX. 3. MAKE A WRITTEN RECORD OF THE PROBLEM. 4. OPEN THE APPLICABLE DENSITOMETER CONNECTOR AT THE REAR SPAR (FIG. 107). 5. CONNECT THE PSD 757/767-1 TESTER TO THE DENSITOMETER CONNECTOR ON THE REAR SPAR AND DO A TEST. 6. IF A FAILURE INDICATION DOES NOT SHOW, THE PROBLEM IS IN THE HOT SHORT PROTECTOR  OR AIRPLANE WIRE HARNESS. <ol style="list-style-type: none"> A. REPAIR OR REPLACE THE HOT SHORT PROTECTOR, M11872 (AMM 28-41-24/401)  OR THE APPLICABLE AIRPLANE HARNESS (WDM 28-41-21, -31, -41). 7. IF A FAILURE INDICATION CONTINUES TO SHOW, THE PROBLEM IS IN THE APPLICABLE FUEL TANK. <ol style="list-style-type: none"> A. YOU MUST GO INTO THE APPLICABLE FUEL TANK (AMM 28-11-00/201). B. EXAMINE THE DENSITOMETER TERMINALS FOR CONTAMINATION, CLEAN OR REPAIR AS NECESSARY. C. IF YOU CANNOT FIND ANY CONTAMINATION, REPLACE THE DENSITOMETER (AMM 28-41-04/401). 8. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 9. IF THE APPLICABLE FAULT MESSAGE CONTINUES TO SHOW, THE PROBLEM IS THE APPLICABLE TANK WIRING HARNESS. REPAIR OR REPLACE THE APPLICABLE TANK WIRING HARNESS (WDM 28-41-21,-31,-41). 10. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	


 IF INSTALLED, CENTER TANK ONLY (POST-SB 28A0085)

Fault Messages
Figure 108 (Sheet 19)

EFFECTIVITY
GUI 115

28-41-00
CONFIG 3
Page 168
Sep 28/07

03

FAULT MESSAGE	19
** DENS SENSE WIRE SHORTED G##.	
FAULT CONDITION	
THIS MESSAGE IS AN INDICATION THAT THERE IS LESS THAN 80 OHMS BETWEEN THE CENTER CONDUCTOR OF THE DENSITOMETER SENSE WIRE AND THE SHIELD. <u>NOTE:</u> FOR ANY DENSITOMETER FAULT MESSAGE, WHERE THE DENSITOMETER IS STILL IN NORMAL RANGE, THE FAULT MESSAGE COMPENSATOR CONTAMINATED CAN SHOW.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
- NORMAL OPERATION WITH AN INDICATION ERROR FOR FUEL QUANTITY OF $\pm 5\%$ FOR THE APPLICABLE TANK (ONLY ONE TANK UNIT CAN BE BAD). - THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" SHOWS.	
CORRECTION	
<ol style="list-style-type: none"> 1. DISCONNECT THE APPLICABLE DENSITOMETER CONNECTOR (REAR SPAR)(FIG. 107). 2. DO THE FQIS PROCESSOR BITE, FIG. 104 "SELF TEST ?". 3. IF THE FAULT CONTINUES TO SHOW, THE PROBLEM IS IN THE HOT SHORT PROTECTOR  OR THE AIRPLANE WIRING HARNESS. EXAMINE THE WIRING (WDM 28-41-21, -31, -41). <p style="margin-left: 40px;"><u>NOTE:</u> WHEN THE REAR SPAR CONNECTOR FOR THE DENSITOMETER IS OPEN OTHER FAULT MESSAGES WILL SHOW. LOOK FOR THE INITIAL FAULT MESSAGE ONLY, IGNORE ALL OTHER FAULT MESSAGES.</p> <ol style="list-style-type: none"> 4. IF THE FAULT MESSAGE DOES NOT SHOW, THE PROBLEM IS IN THE APPLICABLE DENSITOMETER, TANK WIRING HARNESS OR CONDUCTIVE MATERIAL IS ON THE DENSITOMETER TERMINALS. 5. GO INTO THE APPLICABLE FUEL TANK (AMM 28-11-00/201). 6. EXAMINE AND REPLACE THE DENSITOMETER IF IT IS NECESSARY (AMM 28-41-03/401). 7. EXAMINE AND REPLACE THE DENSITOMETER TANK WIRING HARNESS IF IT IS NECESSARY (AMM 28-41-09/401). 8. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

 IF INSTALLED, CENTER TANK ONLY (POST-SB 28A0085)

Fault Messages
Figure 108 (Sheet 20)

EFFECTIVITY
GUI 115

28-41-00
CONFIG 3
Page 169
Sep 28/07

03

 **BOEING**
757
FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE

20

** DENS SENSE OPEN AT SPAR G##.

FAULT CONDITION





THIS MESSAGE IS SENT IF AN OPEN OCCURS IN THE DENSITOMETER SENSE COIL WIRE OR SHIELD. THE OPEN WIRE WILL OCCUR NEAR THE DENSITOMETER CONNECTOR (FIG. 107). THIS INCLUDES THE POINTS BETWEEN, A POINT HALF THE DISTANCE BETWEEN THE PROCESSOR AND THE APPLICABLE DENSITOMETER CONNECTOR, AND A POINT HALF THE DISTANCE BETWEEN THE APPLICABLE DENSITOMETER CONNECTOR AND THE APPLICABLE DENSITOMETER.

NOTE: FOR ANY DENSITOMETER FAULT MESSAGE, WHERE THE DENSITOMETER IS STILL IN NORMAL RANGE, THE FAULT MESSAGE COMPENSATOR CONTAMINATED CAN SHOW.

FLIGHT COMPARTMENT OR AIRPLANE INDICATION

- NORMAL OPERATION WITH AN INDICATION ERROR FOR FUEL QUANTITY OF $\pm 5\%$ FOR THE APPLICABLE TANK (ONLY ONE TANK UNIT CAN BE BAD).
- THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" SHOWS.

CORRECTION

1. EXAMINE THE APPLICABLE DENSITOMETER CONNECTOR ON THE REAR SPAR FOR DAMAGE OR CONTAMINATION (FIG. 107). EXAMINE AND REPAIR THE DENSITOMETER CONNECTOR IF IT IS NECESSARY.
2. IF THE PROBLEM CONTINUES, REPLACE THE HOT SHORT PROTECTOR, M11872 (AMM 28-41-24/401)  OR HOT SHORT PROTECTOR WIRE HARNESS (AMM 28-41-25/401)  OR EXAMINE THE AIRPLANE WIRING HARNESS FOR THE APPLICABLE DENSITOMETER (WDM 28-41-21, -31, -41). REPAIR THE PROBLEMS THAT YOU FIND.
3. IF THE HOT SHORT PROTECTOR  HOT SHORT PROTECTOR WIRE HARNESS  AND THE APPLICABLE AIRPLANE WIRING HARNESS IS OK, THE PROBLEM IS IN THE APPLICABLE TANK WIRING HARNESS.
4. GO INTO THE APPLICABLE FUEL TANK (AMM 28-11-00/201).
5. EXAMINE AND REPLACE THE APPLICABLE DENSITOMETER TANK WIRING HARNESS (AMM 28-41-09/401).
6. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?".

 IF INSTALLED, CENTER TANK ONLY (POST-SB 28A0085)

Fault Messages
Figure 108 (Sheet 21)

EFFECTIVITY
GUI 115

28-41-00
CONFIG 3
Page 170
Sep 28/07

03


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	21
<p>** DENS SENSE OPEN AT PROC G##.</p>	
FAULT CONDITION	
<p>THIS MESSAGE IS SENT IF AN OPEN OCCURS IN THE DENSITOMETER SENSE COIL WIRE OR SHIELD. THE OPEN WIRE WILL OCCUR NEAR THE FQIS PROCESSOR. THE BREAK IN THE SENSE WIRE WILL BE A POINT BETWEEN, THE FQIS PROCESSOR AND A POINT HALF THE DISTANCE BETWEEN THE FQIS PROCESSOR AND THE DENSITOMETER CONNECTOR.</p> <p><u>NOTE:</u> FOR ANY DENSITOMETER FAULT MESSAGE, WHERE THE DENSITOMETER IS STILL IN NORMAL RANGE, THE FAULT MESSAGE COMPENSATOR CONTAMINATED CAN SHOW.</p>	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - NORMAL OPERATION WITH AN INDICATION ERROR FOR FUEL QUANTITY OF $\pm 5\%$ FOR THE APPLICABLE TANK (ONLY ONE TANK UNIT CAN BE BAD). - THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" SHOWS. 	
CORRECTION	
<ol style="list-style-type: none"> 1. EXAMINE THE APPLICABLE ELECTRONIC EQUIPMENT BAY SHELF CONNECTORS FOR DAMAGE (FIG. 107). 2. IF THE CONNECTORS ARE OK, THE DENSITOMETER SENSE WIRE IS OPEN BETWEEN THE FQIS PROCESSOR AND A POINT HALF THE DISTANCE BETWEEN THE FQIS PROCESSOR AND THE DENSITOMETER CONNECTOR. 3. EXAMINE AND REPAIR THE CIRCUIT (FIG. 107)(WDM 28-41-21,-31,-41). 4. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
Figure 108 (Sheet 22)

EFFECTIVITY
GUI 115

28-41-00
 CONFIG 3
 Page 171
 Sep 28/07

03


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	22
<p>** DENS CONTAM OR RESISTOR G##.</p>	
FAULT CONDITION	
<p>IF THE MEASURED DENSITY IS NOT IN THE USUAL LIMITS, OR THE DENSITOMETER AND COMPENSATOR DENSITY VALUES ARE NOT THE SAME, THIS FAULT MESSAGE IS SENT.</p>	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<p>- NORMAL OPERATION WITH AN INDICATION ERROR FOR FUEL QUANTITY OF $\pm 5\%$ FOR THE APPLICABLE TANK (ONLY ONE TANK UNIT CAN BE BAD).</p> <p>- THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" SHOWS.</p>	
CORRECTION	
<ol style="list-style-type: none"> 1. DEFUEL THE APPLICABLE FUEL TANK (AMM 28-26-00/201). 2. DRAIN THE APPLICABLE FUEL TANK SUMP (AMM 12-11-03/301). 3. IF YOU DO NOT FIND CONTAMINATION IN THE SUMP FUEL, GO TO STEP 4, OR IF THERE WAS CONTAMINATION IN THE SUMP FUEL, DO THE FQIS BITE PROCEDURE, FIG. 104 "SELF TEST ?". 4. IF THE FAULT MESSAGE CONTINUES TO SHOW, GO INTO THE APPLICABLE FUEL TANK (AMM 28-11-00/201). 5. EXAMINE THE DENSITOMETER FOR DAMAGE, WATER, MICROBIAL GROWTH, OR OTHER CONTAMINATION MATERIAL. REPLACE THE DENSITOMETER AS NECESSARY (AMM 28-41-03/401). 6. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
Figure 108 (Sheet 23)

EFFECTIVITY
GUI 115

28-41-00

CONFIG 3
Page 172
Sep 28/07

03


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	23
<p>** DENS SENSOR OR DRIVE WIRE G## (OR) ** DENS SENSOR FAILURE G##.</p>	
FAULT CONDITION	
<p>THE DENSITOMETER SENSOR DOES NOT OPERATE CORRECTLY.</p> <p><u>NOTE:</u> FOR ANY DENSITOMETER FAULT MESSAGE, WHERE THE DENSITOMETER IS STILL IN ITS USUAL LIMITS, THE FAULT MESSAGE COMPENSATOR CONTAMINATED CAN SHOW.</p>	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - NORMAL OPERATION WITH AN INDICATION ERROR FOR FUEL QUANTITY OF $\pm 5\%$ FOR THE APPLICABLE TANK (ONLY ONE TANK UNIT CAN BE BAD). - THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" SHOWS. 	
CORRECTION	
<ol style="list-style-type: none"> 1. REPLACE THE DENSITOMETER FOR THE APPLICABLE FUEL TANK (AMM 28-41-03/401). 2. REFUEL THE APPLICABLE FUEL TANK UNTIL THE FUEL IS ABOVE THE DENSITOMETER (AMM 12-11-01/301). 3. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 4. IF THE PROBLEM CONTINUES, REPLACE THE DENSITOMETER IN TANK WIRING HARNESS FOR THE APPLICABLE FUEL TANK (AMM 28-41-09/401). 5. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
Figure 108 (Sheet 24)

EFFECTIVITY
GUI 115

28-41-00
 CONFIG 3
 Page 173
 Sep 28/07

03


 **BOEING**
757
FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE

24

** IFQC CIRCUIT BOARD FAILED G##.



FAULT CONDITION

THE FQIS BITE SHOWS A PROBLEM WITH THE INDIVIDUAL FUEL QUANTITY CHANNEL (IFQC) CIRCUIT BOARD OR THERE IS A PROBLEM WITH THE DENSITOMETER HOT SHORT PROTECTOR. 

FLIGHT COMPARTMENT OR AIRPLANE INDICATION

- NORMAL OPERATION WITH AN INDICATION ERROR FOR FUEL QUANTITY OF $\pm 5\%$ FOR THE APPLICABLE TANK (ONLY ONE TANK UNIT CAN BE BAD).
- NORMAL OPERATION, IF FUEL GAGE CIRCUITRY IS NOT BAD.
- THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" SHOWS.
- THE FUEL QUANTITY INDICATION WILL GO OFF FOR THE APPLICABLE FUEL TANK, THE TOTAL FUEL QUANTITY INDICATION WILL GO OFF (FUEL QTY IND, M10054), AND THE EICAS STATUS MESSAGE "FUEL QTY IND" SHOWS.
- WHILE FUELING, THE FUELING SHUTOFF VALVE CLOSES FOR THE APPLICABLE FUEL TANK. THE "PUSH SET" MESSAGE WILL SHOW ON THE FUEL QUANTITY INDICATORS ON THE FUELING CONTROL PANEL, REFER TO AMM 12-11-01/301 TO CONTINUE FUELING. THE FUEL QUANTITY INDICATOR, M10054, WILL ALSO GO OFF.

CORRECTION

1. DO A CHECK FOR THESE CONDITIONS:
 - A. FUEL QUANTITY INDICATION FOR THE APPLICABLE TANK IS BLANK.
 - B. FMC TOTALIZER FUEL QUANTITY VALUE IS BLANK.
 - C. FUEL QTY IND EICAS STATUS LEVEL MESSAGE IS SHOWN.
 - D. ON THE PROCESSOR, THE "SYSTEM DATA" MENU FOR THE APPLICABLE TANK SHOWS ZEROES FOR ALL DATA.
2. IF ONE OR MORE OF THESE CONDITIONS IS NOT TRUE, THEN GO TO STEP 4.
3. IF ALL OF THE CONDITIONS IN STEP 1 ARE TRUE, THEN DO THESE STEPS:
 - A. CYCLE THE POWER FOR THE PROCESSOR.
 - B. IF THE REFUEL PANEL DOOR IS OPEN, OPEN THESE CIRCUIT BREAKERS AND CLOSE THEM AGAIN:
 - (1) 34A10, FUEL QTY-FUEL
 - (2) 6E4, FUELING QTY
 - C. IF THE REFUEL PANEL DOOR IS CLOSED, OPEN THESE CIRCUIT BREAKERS AND CLOSE THEM AGAIN:
 - (3) 11C34, FUEL QTY L OR FUEL QTY 1
 - (4) 11L19, FUEL QTY R OR FUEL QTY 2
 - D. IF NO FAULT MESSAGES ARE SHOWN IN THE PRESENT FAULTS MENU, THE SYSTEM IS OK.
 - E. IF THE FAULT MESSAGE CONTINUES TO SHOW IN THE "PRESENT FAULTS" MENU, THEN CONTINUE.
4. DO THESE STEPS:
 - A. EXAMINE THE WIRING AT THE DENSITOMETER HOT SHORT PROTECTOR WIRE HARNESS CONNECTORS D11718 AND D11720, FOR A SHORT (AMM 28-41-25/401). 
 - (1) IF THERE IS A SHORT TO GROUND, REPAIR OR REPLACE THE WIRING (AMM 28-41-25/401).
 - (2) IF THE WIRING IS OK, REPLACE THE DENSITOMETER HOT SHORT PROTECTOR, M11872 (AMM 28-41-24/401). 
 - B. IF THE FAULT MESSAGE CONTINUES TO SHOW IN THE "PRESENT FAULTS" MENU, THEN CONTINUE.
 - C. REPLACE THE PROCESSOR, M121 (AMM 28-41-08/401).
 - D. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104, "SELF TEST?".

 IF INSTALLED, CENTER TANK ONLY (POST-SB 28A0085)

Fault Messages
Figure 108 (Sheet 25)

EFFECTIVITY
GUI 115

28-41-00
CONFIG 3
Page 174
Jan 20/09

05.1


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	25
** IFQC AIR/GND CIRCUIT FAIL G##.	
FAULT CONDITION	
THE APPLICABLE INDIVIDUAL FUEL QUANTITY CHANNEL (IFQC) CIRCUIT BOARD CAN NOT FIND IF THE AIRPLANE IS IN THE AIR OR ON THE GROUND.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - THE FQIS SYSTEM IS SET TO THE AIR MODE IF THE FUELING STATION DOOR, 621GB IS CLOSED. - THE FQIS SYSTEM IS SET TO THE GROUND MODE IF THE FUELING STATION DOOR, 621GB, IS OPEN. 	
CORRECTION	
<ol style="list-style-type: none"> 1. REPLACE THE FQIS PROCESSOR, M121 (AMM 28-41-08/401). 2. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 3. IF THE PROBLEM CONTINUES, DO THE CORRECTION FOR THE FAULT MESSAGE "AIR/GROUND_INPUT_FAILED" (FIG. 106). 	

Fault Messages
Figure 108 (Sheet 26)

EFFECTIVITY
GUI 115

28-41-00
 CONFIG 3
 Page 175
 Sep 28/07

03


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	26
AIR/GROUND INPUT FAILED G##.	
FAULT CONDITION	
THE FQIS AIR/GROUND INPUTS A AND B DO NOT AGREE, OR ONE OF THE INPUTS IS FAILED OPEN, OR THE SYSTEM HAS BEEN OPERATED ON BATTERY POWER. <u>NOTE:</u> IF THE AIRPLANE WAS OPERATED ON BATTERY POWER, THIS FAULT MESSAGE CAN SHOW. THIS IS BECAUSE THE AIR/GROUND INDICATION USUALLY DEFAULTS TO "AIR" AND BATTERY POWER IS USED TO REFUEL THE AIRPLANE.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
- THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" SHOWS.	
CORRECTION	
<ol style="list-style-type: none"> 1. REMOVE THE FQIS PROCESSOR, M121 (AMM 28-41-08/401). 2. WHEN THE AIRPLANE IS IN THE GROUND MODE, MEASURE THE RESISTANCE BETWEEN THE PROCESSOR RACK CONNECTOR GND PIN K7 AND THE AIR/GND COM PIN K8 FOR THE TWO CONNECTORS, D2440A AND D2440B. <ol style="list-style-type: none"> A. IF THE RESISTANCE IS MORE THAN 10 OHMS, EXAMINE AND REPAIR THE APPLICABLE CIRCUIT (WDM 28-41-14). 3. WHEN THE AIRPLANE IS IN THE AIR MODE, MEASURE THE RESISTANCE BETWEEN THE PROCESSOR RACK CONNECTOR GND K7 PIN AND THE AIR/GND COM PIN K6 FOR THE TWO CONNECTORS, D2440A AND D2440B. <ol style="list-style-type: none"> A. IF THE RESISTANCE IS MORE THAN 10 OHMS, EXAMINE AND REPAIR THE APPLICABLE CIRCUIT (WDM 28-41-14). 4. IF THE RESISTANCE IS LESS THAN 10 OHMS IN STEPS 2 OR 3, REPLACE THE FQIS PROCESSOR, M121 (AMM 28-41-08/401). 5. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
 Figure 108 (Sheet 27)

EFFECTIVITY
GUI 115

28-41-00
 CONFIG 3
 Page 176
 Sep 28/07

03


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	27
LB/KG INPUT WIRE FAILED G##.	
FAULT CONDITION	
THE POUND/KILOGRAM INPUT JUMPER HAS FAILED OPEN.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
- NORMAL OPERATION, LB/KG STATUS FOUND BY VALUE STORED IN MEMORY. - THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" SHOWS.	
CORRECTION	
1. REMOVE THE FQIS PROCESSOR, M121 (AMM 28-41-08/401). 2. FOR AIRPLANES WITH UNITS IN LBS, MEASURE THE RESISTANCE BETWEEN THE LBS PIN, A9, TO LBS/KGS COM PIN, C9, ON THE PROCESSOR RACK CONNECTOR D2440A (WDM 28-41-11). A. IF THE RESISTANCE IS MORE THAN 10 OHMS, EXAMINE AND REPAIR THE APPLICABLE CIRCUIT (WDM 28-41-11). 3. FOR AIRPLANES WITH UNITS IN KGS, MEASURE THE RESISTANCE BETWEEN THE KGS PIN, E9, TO LBS/KGS COM PIN, C9, ON THE PROCESSOR RACK CONNECTOR D2440A (WDM 28-41-11). A. IF THE RESISTANCE IS MORE THAN 10 OHMS, EXAMINE AND REPAIR THE APPLICABLE CIRCUIT (WDM 28-41-11). 4. IF THE RESISTANCE IS LESS THAN 10 OHMS IN STEPS 2 OR 3, REPLACE THE FQIS PROCESSOR, M121 (AMM 28-41-08/401). 5. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?".	

Fault Messages
 Figure 108 (Sheet 28)

EFFECTIVITY
 GUI 115

28-41-00
 CONFIG 3
 Page 177
 Sep 28/07

03


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	28
** IFQC LB/KG CIRCUIT FAIL G##.	
FAULT CONDITION	
THE APPLICABLE IFQC CIRCUIT BOARD CANNOT READ THE POUNDS OR KILOGRAMS INPUT.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
- NORMAL OPERATION - POUND OR KILOGRAM STATUS IS COMES FROM DATA IN NONVOLATILE MEMORY	
CORRECTION	
1. REPLACE THE FQIS PROCESSOR, M121 (AMM 28-41-08/401). 2. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 3. IF THE PROBLEM CONTINUES, DO THE CORRECTION FOR THE FAULT MESSAGE "LB/KG_INPUT_FAILED" (FIG. 106).	

Fault Messages
 Figure 108 (Sheet 29)

EFFECTIVITY
GUI 115

AD9457

28-41-00

CONFIG 3
 Page 178
 Sep 28/07

03

 **BOEING**
757
FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	29
IOC 1 DISCRETE DRIVER FAIL G##.	
FAULT CONDITION	
THE INPUTS AIR/GROUND AND LB/KG CANNOT BE READ BY THE FQIS PROCESSOR.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - NORMAL OPERATION - THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" SHOWS. 	
CORRECTION	
<ol style="list-style-type: none"> 1. REPLACE THE FQIS PROCESSOR, M121 (AMM 28-41-08/401). 2. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 3. IF THE FAULT MESSAGE CONTINUES TO SHOW, EXAMINE AND REPAIR THE APPLICABLE AIR/GND OR LB/KG CIRCUIT (WDM 28-41-14). 4. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	
FAULT MESSAGE	30
LOAD SELECT UNIT OR WIRE FAIL G##.	
FAULT CONDITION	
THE FQIS PROCESSOR CANNOT READ THE LOAD SELECT CONTROL UNIT BECAUSE OF A CONTROL UNIT FAILURE OR A WIRING FAULT.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - FUELING MUST BE DONE MANUALLY - IF YOU PUSH THE SET SWITCH FOR THE LOAD SELECT CONTROL, "FAIL" WILL SHOW ON THE LOWER LOAD SELECT INDICATOR DISPLAY. 	
CORRECTION	
<ol style="list-style-type: none"> 1. REPLACE THE LOAD SELECT CONTROL, M638 (AMM 28-41-07/401). 2. IF THE FAULT MESSAGE CONTINUES TO SHOW, DO A CHECK OF THE LOAD SELECT WIRING BETWEEN THE LOAD SELECT CONTROL AND THE FQIS PROCESSOR, M121 (WDM 28-21-22). 3. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
Figure 108 (Sheet 30)

EFFECTIVITY
GUI 115

28-41-00
CONFIG 3
Page 179
Sep 28/07

03


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	31
IOC # (1 OR 2) FAILED G##.	
FAULT CONDITION	
THIS FAULT MESSAGE SHOWS A FAILURE OF THE APPLICABLE INPUT/OUTPUT CARD (IOC) OR ARINC BUS FAILURE.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - THE EICAS STATUS MESSAGE "FUEL QTY BITE" SHOWS. - AUTOMATIC REFUELING NOT AVAILABLE - "FAIL" SHOWS ON THE LOAD SELECT INDICATOR DISPLAY IF YOU TRY AUTOMATIC REFUELING. 	
CORRECTION	
<ol style="list-style-type: none"> 1. REPLACE THE FQIS PROCESSOR, M121 (AMM 28-41-08/401). 2. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 3. IF THE FAULT MESSAGE CONTINUES TO SHOW DO A CHECK OF THE WIRING BETWEEN THE FQIS PROCESSOR, M121, AND THE FUEL QUANTITY INDICATORS AS FOLLOWS (WDM 28-41-11): <ul style="list-style-type: none"> A. FLIGHT COMPARTMENT IND M10054 B. FUELING PANEL IND N10038 C. FUELING PANEL IND N10039 D. FUELING PANEL IND N10040. 4. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	
FAULT MESSAGE	32
VOLUME SHUTOFF OF ** AT 95% G##.	
FAULT CONDITION	
THERE IS A SYSTEM FAILURE THAT RESULTS IN FUEL SHUTOFF DURING FUELING AT 95% OF FULL TO PREVENT FUEL SPILLS.	
<u>NOTE:</u> FOR MANUAL OR AUTOMATIC REFUELING THE AFFECTED FUEL TANK CAN BE REFUELED TO 5% LESS THAN FULL.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
- REFUELING WILL STOP AT 5% BELOW THE VOLUMETRIC SHUTOFF (VSO) POINT.	
CORRECTION	
<ol style="list-style-type: none"> 1. DO THE CORRECTIONS FOR THESE FAULT MESSAGES SHOWN IN THE PRESENT FAULTS MENU AND THE FAULT HISTORY MENU, FLIGHT LEG 0. 2. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?", TO MAKE SURE THERE ARE NO FAULT MESSAGES SHOWN. <ul style="list-style-type: none"> <u>NOTE:</u> YOU CAN REFUEL MANUALLY (AMM 12-11-01/301). 3. THE REFUEL VALVE CAN BE CLOSED AND "PUSH SET" CAN SHOW ON REFUEL PANEL INDICATOR. IF YOU PUSH THE "SET" SWITCH, THE REFUEL VALVE WILL OPEN, AND YOU CAN CONTROL THE VALVE MANUALLY. <ul style="list-style-type: none"> <u>NOTE:</u> THE FQIS WILL NOT CLOSE THE REFUEL VALVE, AND THE FQIS FUEL QUANTITY INDICATION WILL FLASH ON AND OFF. 	

Fault Messages
Figure 108 (Sheet 31)

EFFECTIVITY
GUI 115

28-41-00
 CONFIG 3
 Page 180
 Sep 28/07

03

 **BOEING**
757
FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	33
VOLUME SHUTOFF OF ** AT 87% G##.	
FAULT CONDITION	
THERE IS A SYSTEM FAILURE THAT RESULTS IN FUEL SHUTOFF DURING FUELING AT 95% OF FULL. <u>NOTE:</u> FOR MANUAL OR AUTOMATIC REFUELING THE AFFECTED FUEL TANK CAN BE REFUELED TO A QUANTITY 13% LESS THAN EXPECTED.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
- THE EICAS STATUS MESSAGE "FUEL QTY BITE" SHOWS. - REFUELING WILL STOP AT 13% BELOW THE VOLUMETRIC SHUTOFF (VSO) POINT.	
CORRECTION	
1. DO THE CORRECTIONS FOR THESE FAULT MESSAGES SHOWN IN THE PRESENT FAULTS MENU AND THE FAULT HISTORY MENU, FLIGHT LEG 0. 2. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?", TO MAKE SURE THERE ARE NO FAULT MESSAGES SHOWN. <u>NOTE:</u> YOU CAN REFUEL MANUALLY (AMM 12-11-01/301). 3. THE REFUEL VALVE CAN BE CLOSED AND "PUSH SET" CAN SHOW ON REFUEL PANEL INDICATOR. IF YOU PUSH THE "SET" SWITCH, THE REFUEL VALVE WILL OPEN, AND YOU CAN CONTROL THE VALVE MANUALLY. <u>NOTE:</u> THE FQIS WILL NOT CLOSE THE REFUEL VALVE, AND THE FQIS FUEL QUANTITY INDICATION WILL FLASH ON AND OFF.	

Fault Messages
Figure 108 (Sheet 32)

EFFECTIVITY
GUI 115

28-41-00
CONFIG 3
Page 180A
Sep 28/07

03

A09460


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	34
BITE DISPLAY BOARD FAILED G##.	
FAULT CONDITION	
THIS MESSAGES SHOWS ON THE FQIS PROCESSOR ONLY. THIS MESSAGE SHOWS THAT THE FQIS BITE DISPLAY BOARD (BDB) IS FAILED.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" CAN SHOW. - SELF-TEST FROM FQIS PROCESSOR MENU BOARD MAY NOT OPERATE - FAULT MESSAGES MAY NOT BE STORED OR SHOWN CORRECTLY - THE EICAS STATUS MESSAGE "FUEL QTY BITE" SHOWS. <p><u>NOTE:</u> IF THIS MESSAGE SHOWS GO TO STEP 3.</p>	
CORRECTION	
<ol style="list-style-type: none"> 1. REPLACE THE FQIS PROCESSOR, M121 (AMM 28-41-08/401). 2. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". <u>NOTE:</u> THIS PROBLEM ONLY AFFECTS THE BDB DISPLAY. THE FUEL QUANTITY INFORMATION IS NOT AFFECTED. THE FQIS PROCESSOR REPLACEMENT MAY BE DONE AT A LATER TIME, BUT IF ANOTHER FQIS SYSTEM FAULT OCCURS IT WILL POSSIBLY NOT BE CORRECTLY RECORDED OR SHOWN. 3. IF THE PROBLEM CONTINUES, DO A CHECK OF THE WIRING BETWEEN THE FQIS PROCESSOR AND THE EICAS COMPUTERS (WDM 28-41-11). 4. REPAIR OR REPLACE THE APPLICABLE WIRING (WDM 28-41-11). 5. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
Figure 108 (Sheet 33)

EFFECTIVITY
GUI 115

AD9461

28-41-00

CONFIG 3
Page 180B
Sep 28/07

03


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	35
<p>(THE BITE DISPLAY BOARD IS OFF).</p>	
FAULT CONDITION	
<p>THE BITE DISPLAY IS OFF.</p>	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - NORMAL OPERATION - FAULT MESSAGES WILL NOT BE STORED OR SHOWN - FQIS BITE "SELF TEST ?" WILL NOT OPERATE - LOW FUEL AND FUEL CONFIGURATION INDICATIONS WILL NOT OPERATE CORRECTLY 	
CORRECTION	
<ol style="list-style-type: none"> 1. PUSH AND RELEASE THE "ON/OFF" BUTTON ON THE FQIS PROCESSOR CONTROL PANEL. 2. IF THE FQIS PROCESSOR DISPLAY IS OFF, REMOVE THE FQIS PROCESSOR, M121 (AMM 28-41-08/401). 3. DO A TEST AT THE FQIS CONNECTOR TO MAKE SURE THERE IS 28V DC AT THE CONNECTOR AS FOLLOWS (WDM 28-41-11): <ul style="list-style-type: none"> A. CONNECTOR D2440A, PINS J1 AND K1 B. CONNECTOR D2440B, PINS F6 AND G6, J1 AND K1, H10 AND H11. 4. INSTALL THE FQIS PROCESSOR, M121 (AMM 28-41-08/401). 5. PUSH AND RELEASE THE "ON/OFF" BUTTON ON THE FQIS PROCESSOR CONTROL PANEL. 6. IF THE PROBLEM CONTINUES, REPLACE THE FQIS PROCESSOR, M121 (AMM 28-41-08/401). 7. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
 Figure 108 (Sheet 34)

EFFECTIVITY
 GUI 115

AD9462

28-41-00
 CONFIG 3
 Page 180C
 Sep 28/07

03


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	36
ARINC BUS (A OR B) FAILED G##.	
FAULT CONDITION	
THE ARINC BUS A OR B WIRES OR THE PROCESSOR ARE BAD.	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
- NORMAL OPERATION, ON THE CHANNEL THAT IS GOOD. - THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" CAN SHOW.	
CORRECTION	
<ol style="list-style-type: none"> 1. REPLACE THE FQIS PROCESSOR, M121 (AMM 28-41-08/401). 2. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 3. IF THE FAULT MESSAGE CONTINUES TO SHOW, DO A CONTINUITY CHECK OF THE ARINC WIRES. <ol style="list-style-type: none"> A. DO A CONTINUITY CHECK OF THE WIRES BETWEEN THE PROCESSOR, M121, AND THE LOAD SELECT INDICATORS AND THE FUEL QUANTITY INDICATOR, M10054 (WDM 28-41-11). B. DO A CONTINUITY CHECK OF THE WIRES BETWEEN THE PROCESSOR, M121, AND THE LOAD SELECT CONTROL UNIT, M638 (WDM 28-21-22). C. REPLACE OR REPAIR THE WIRES AS NECESSARY. 4. IF THE ARINC WIRES ARE OK, REPLACE THE FUEL QUANTITY INDICATOR, M10054 (AMM 28-41-04/401). 5. IF THE PROBLEM CONTINUES, REPLACE THE LOAD SELECT CONTROL, M638 (AMM 28-41-07/401). 6. IF THE PROBLEM CONTINUES, REPLACE THE LOAD SELECT INDICATORS (AMM 28-41-06/401). 7. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
Figure 108 (Sheet 35)

EFFECTIVITY
GUI 115

28-41-00

CONFIG 3
 Page 180D
 Sep 28/07

03


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	37
<p>** TU ?? SHORTED TO GROUND G##.</p>	
FAULT CONDITION	
<p>THERE IS MORE THAN 1.7 MILLIAMPS OF CURRENT FLOW IN ONE OR MORE LOW Z CIRCUIT(S), AND THE DRIVE VOLTAGE TO ONE OR MORE TANK UNITS HAS DECREASED ENOUGH TO AFFECT THE MEASURED VALUE OF THE TANK UNIT CAPACITANCE. THIS FAULT PREVENTS FAULT ISOLATION TO ONE TANK UNIT BY THE FQIS PROCESSOR.</p>	
FLIGHT COMPARTMENT OR AIRPLANE INDICATION	
<ul style="list-style-type: none"> - NORMAL OPERATION WITH AN INDICATION ERROR FOR FUEL QUANTITY OF ±5% FOR THE APPLICABLE TANK (ONLY ONE TANK UNIT CAN BE BAD). - THE EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" CAN SHOW. - IF THERE IS MORE THAN ONE ELECTRICAL SHORT THE FUEL QUANTITY INDICATION WILL GO OFF FOR THE APPLICABLE FUEL TANK, THE TOTAL FUEL QUANTITY INDICATION WILL GO OFF (FUEL QTY IND, M10054), AND THE EICAS STATUS MESSAGE "FUEL QTY IND" SHOWS. - THE REFUEL OPERATION CAN STOP AT 5% LESS THAN THE VSO. THIS WILL PREVENT ACCIDENTAL FUEL SPILL. - THE REFUEL OPERATION CAN STOP AT 5% LESS THAN THE AUTOMATIC SET VALUE. - IF THERE IS MORE THAN ONE ELECTRICAL SHORT WHILE FUELING, THE FUELING SHUTOFF VALVE CLOSES FOR THE APPLICABLE FUEL TANK. THE "PUSH SET" MESSAGE WILL SHOW ON THE FUEL QUANTITY INDICATORS ON THE FUELING CONTROL PANEL, P28, REFER TO AMM 12-11-01/301 TO CONTINUE FUELING. THE FUEL QUANTITY INDICATOR, M10054, WILL ALSO GO OFF. 	
CORRECTION	
<ol style="list-style-type: none"> 1. OPEN THE HI-Z/LO-Z CONNECTOR FOR THE APPLICABLE FUEL TANK (FIG. 107). 2. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?" 3. IF THE FAULT MESSAGE CONTINUES TO SHOW WHEN THE HI-Z/LO-Z CONNECTOR IS OPEN, THEN THE PROBLEM IS BETWEEN THE FQIS PROCESSOR AND THE HI-Z/LO-Z CONNECTOR AT THE FRONT SPAR. <p style="margin-left: 20px;"><u>NOTE:</u> THE OTHER TANK UNITS AND COMPENSATOR WILL SHOW THE OPEN LO-Z OR HI-Z FAULT MESSAGE AND THE OPEN HI-Z AT SPAR FAULT MESSAGE WILL SHOW, WHEN THE SPAR CONNECTOR IS OPEN. IGNORE THESE OPEN FAULT MESSAGES.</p> 4. EXAMINE THE WIRING TO FIND THE TANK UNIT LO-Z SHORT TO GROUND AND REPAIR OR REPLACE THE APPLICABLE WIRING (WDM 28-41-21,-31,-41). 5. IF THE PROBLEM GOES AWAY THE SHORTED CIRCUIT IS IN THE FUEL TANK. 6. MEASURE THE RESISTANCE OF EACH TANK UNIT AT THE APPLICABLE SPAR CONNECTOR TO FIND THE SHORT (AMM 28-41-00/501). USE THE A28007-44 OR PSD757-1 TEST BOX TO MEASURE THE RESISTANCE OF THE LO-Z AND HI-Z WIRES. 7. GO INTO THE APPLICABLE FUEL TANK (AMM 28-11-00/201). 8. EXAMINE AND REPLACE THE APPLICABLE TANK UNIT (AMM 28-41-01/401). <p style="margin-left: 20px;"><u>NOTE:</u> MAKE SURE THE TANK UNIT HAS CLEARANCE FROM THE AIRPLANE STRUCTURE.</p> 9. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 10. IF THE PROBLEM CONTINUES, EXAMINE AND REPLACE THE APPLICABLE TANK WIRING HARNESS (WDM 28-41-21,-31,-41). 11. DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?". 	

Fault Messages
Figure 108 (Sheet 36)

EFFECTIVITY
GUI 115

28-41-00
 CONFIG 3
 Page 180E
 Sep 28/07

03

 **BOEING**
757
FAULT ISOLATION/MAINT MANUAL

NOTE 1: THE PRIMARY SOURCE OF FAILURE CAN BE DAMAGE TO THE HI-Z/LO-Z PLUG ON THE AIRPLANE WIRING HARNESS. LOOK AT THE HI-Z/LO-Z PLUG BEFORE YOU DO A CHECK OF AN AIRPLANE WIRING HARNESS.

NOTE 2: THE "DRY CAPACITANCE TEST IN THE MAIN EQUIPMENT CENTER (NO FUEL IN THE TANK)" IS A TEST BETWEEN THE FUEL TANK AND THE MAIN EQUIPMENT CENTER.

1. DRY CAPACITANCE TEST IN THE MAIN EQUIPMENT CENTER WITH THE FQPU (NO FUEL IN THE TANK)

- A. DEFUEL THE APPLICABLE FUEL TANK (AMM 28-26-00/201).
- B. DRAIN AND PURGE THE APPLICABLE FUEL TANK (AMM 28-11-00/201).
- C. PUSH THE "ON/OFF" BUTTON ON THE FQIS PROCESSOR, M121.
- D. CONTINUE PUSH AND RELEASE THE "NO" BUTTON UNTIL THE "SYSTEM DATA?" MENU SHOWS.
- E. PUSH AND RELEASE THE "YES" BUTTON TO SEE THE SYSTEM DATA.
- F. PUSH THE "NO" BUTTON WHEN THE "UPLIFT DATA?" MESSAGE SHOWS ON THE DISPLAY.
- G. WHEN THE MESSAGE "MAIN TANKS DATA?" SHOWS PUSH AND RELEASE THE "YES" BUTTON.
NOTE: THIS MENU LIST WILL SHOW THE LEFT AND RIGHT MAIN FUEL TANK CAPACITANCE DATA.
- H. MAKE A WRITTEN RECORD OF THE LEFT AND RIGHT MAIN TANK CAPACITANCE VALUES.
- I. CONTINUE TO PUSH AND RELEASE THE "DOWN" BUTTON UNTIL THE "END OF MAIN TANKS DATA?" SHOWS ON THE DISPLAY.
- J. PUSH AND RELEASE THE "DOWN" BUTTON TO SEE THE CENTER TANK DATA.
- K. WHEN THE MESSAGE "CENTER TANK DATA?" SHOWS PUSH AND RELEASE THE "YES" BUTTON.
NOTE: THIS MENU LIST WILL SHOW THE CENTER FUEL TANK CAPACITANCE DATA.
- L. MAKE A WRITTEN RECORD OF THE CENTER TANK CAPACITANCE VALUES.
- M. CONTINUE TO PUSH AND RELEASE THE "DOWN" BUTTON UNTIL THE "END OF CTR TANK DATA?" SHOWS ON THE DISPLAY.
- N. IF THE CAPACITANCE VALUES ARE NOT IN THE LIMITS SHOWN IN FIG. 109, SHT. 4, DO THE STEPS THAT FOLLOW:
 - (1) SHAKE THE AIRPLANE WIRING HARNESS AT THE HI-Z/LO-Z PLUG FOR THE APPLICABLE FUEL TANK. LOOK AT THE CAPACITANCE VALUES ON THE FQPU FOR ALL THE TANK UNITS AND THE COMPENSATOR.
 - (a) IF THE CAPACITANCE VALUE CHANGES WHEN YOU SHAKE THE AIRPLANE WIRING HARNESS AT THE HI-Z/LO-Z PLUG, REPAIR OR REPLACE THE DEFECTIVE PIN ON THE HI-Z/LO-Z PLUG (WDM 28-41-21,-31,-41).
 - (b) IF THE CAPACITANCE VALUE DOES NOT CHANGE WHEN YOU SHAKE THE AIRPLANE WIRING HARNESS AT THE HI-Z/LO-Z PLUG, DO THE STEPS THAT FOLLOW:
 - 1) LOOK FOR DAMAGE ON THE TANK WIRING HARNESS BETWEEN THE HI-Z/LO-Z RECEPTACLE AND THE TANK UNIT OR COMPENSATOR.
DO A CHECK ON THE TANK UNIT OR COMPENSATOR FOR A POSSIBLE SHORT TO GROUND. REPAIR OR REPLACE THE TANK UNIT (AMM 28-41-01/401), OR THE TANK WIRING HARNESS (AMM 28-41-09/401) IF IT IS NECESSARY.
 - 2) DO THE FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?".
- O. IF THE CAPACITANCE VALUES ARE IN THE LIMITS SHOWN IN FIG. 109, SHT. 4, THE FQIS IS OK.

Dry Capacitance Test in the Main Equipment Center (No Fuel in the Tank)
Figure 109 (Sheet 1)

EFFECTIVITY
GUI 115

28-41-00
CONFIG 3
Page 180F
Sep 28/07

03

 **BOEING**
757
FAULT ISOLATION/MAINT MANUAL

NOTE 1: THE PRIMARY SOURCE OF FAILURE CAN BE DAMAGE TO THE HI-Z/LO-Z PLUG ON THE AIRPLANE WIRING HARNESS. LOOK AT THE HI-Z/LO-Z PLUG BEFORE YOU DO A CHECK OF AN AIRPLANE WIRING HARNESS.

NOTE 2: THE "DRY CAPACITANCE TEST IN THE MAIN EQUIPMENT CENTER (NO FUEL IN THE TANK)" IS A TEST BETWEEN THE FUEL TANK AND THE MAIN EQUIPMENT CENTER.

EQUIPMENT:

JcAIR, INC.
400 INDUSTRIAL PARKWAY
INDUSTRIAL AIRPORT, KS 66031

- A. FUEL QTY TEST SET -
P/N 472090-007, OR P/N 472090-009, OR PSD 40-1, OR PSD 60-1, OR PSD 60-2,
OR PSD 60-2R
- B. FUEL QTY ADAPTER HARNESS -
LEFT/RIGHT MAIN FUEL TANK - PSD40-510
CENTER FUEL TANK - PSD40-511
DENSITOMETER - PSD757/767-103
- C. TEST BOX, FQIS - PSD757/767-1, (IN MAIN EQUIPMENT CENTER); PSD757-1 OR
A28007-44 (PART OF A28007-41) (AT WING SPAR)


1. DRY CAPACITANCE TEST IN THE MAIN EQUIPMENT CENTER WITH THE PSD 757/767-1 TESTER (NO FUEL IN THE TANK)
- A. DEFUEL THE APPLICABLE FUEL TANK (AMM 28-26-00/201).
 - B. DRAIN AND PURGE THE APPLICABLE FUEL TANK (AMM 28-11-00/201).
 - C. REMOVE THE PROCESSOR (FQPU), M121 (AMM 28-41-08/401).
 - D. INSTALL THE PSD 757/767-1 TESTER AND LOOK AT THE CAPACITANCE VALUES FOR ALL THE TANK UNITS AND THE COMPENSATOR IN THE APPLICABLE TANK.
 - E. MAKE A WRITTEN RECORD OF THE CAPACITANCE VALUES.
 - F. IF THE CAPACITANCE VALUES ARE NOT IN THE LIMITS SHOWN IN FIG. 109, SHT. 4, DO THE STEPS THAT FOLLOW:
 - (1) REMOVE THE HI-Z/LO-Z PLUG FOR THE APPLICABLE FUEL TANK. EXAMINE THE APPLICABLE HI-Z/LO-Z CONNECTOR FOR DAMAGE.
 - (a) IF THE CAPACITANCE VALUE CHANGES WHEN YOU INSTALL THE HI-Z/LO-Z PLUG, REPAIR OR REPLACE THE DEFECTIVE PIN ON THE HI-Z/LO-Z PLUG (WDM 28-41-21,-31,-41).
 - (b) IF THE CAPACITANCE VALUE DOES NOT CHANGE AFTER YOU INSTALL THE HI-Z/LO-Z PLUG, DO THE STEPS THAT FOLLOW:
 - 1) LOOK FOR DAMAGE ON THE TANK WIRING HARNESS BETWEEN THE HI-Z/LO-Z RECEPTACLE AND THE TANK UNIT OR COMPENSATOR.
 - 2) DO A CHECK ON THE TANK UNIT OR COMPENSATOR FOR A POSSIBLE SHORT TO GROUND REPAIR OR REPLACE THE TANK UNIT (AMM 28-41-01/401), OR THE TANK WIRING HARNESS (AMM 28-41-09/401) IF IT IS NECESSARY.
 - (2) REMOVE THE TEST EQUIPMENT AND INSTALL THE FQPU, M121 (AMM 28-41-08/401).
 - (3) DO THIS PROCEDURE: FUEL QUANTITY BITE PROCEDURE, FIG. 104 "SELF TEST ?".
 - G. IF THE CAPACITANCE VALUES ARE IN THE LIMITS SHOWN IN FIG. 109, SHT. 4, THE FQIS IS OK.

Dry Capacitance Test in the Main Equipment Center (No Fuel in the Tank)
Figure 109 (Sheet 2)

EFFECTIVITY
GUI 115

28-41-00
CONFIG 3
Page 180G
Sep 28/07

03



Dry Capacitance Test in the Main Equipment Center (No Fuel in the Tank)
Figure 109 (Sheet 3)

EFFECTIVITY
GUI 115

28-41-00

CONFIG 3
Page 180H
Sep 28/07

03


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

TANK UNIT OR COMPENSATOR UNDER TEST	MINIMUM CAPACITANCE (PICOFARADS)	MAXIMUM CAPACITANCE (PICOFARADS)	EQUIP. NO.
L MAIN TANK UNIT NO. 1	60.55	61.25	TS109
L MAIN TANK UNIT NO. 2	58.25	58.95	TS110
L MAIN TANK UNIT NO. 3	48.70	49.30	TS111
L MAIN TANK UNIT NO. 4	46.80	47.40	TS112
L MAIN TANK UNIT NO. 5	37.20	37.70	TS113
L MAIN TANK UNIT NO. 6	37.20	37.70	TS114
L MAIN TANK UNIT NO. 7	32.95	33.45	TS115
L MAIN TANK UNIT NO. 8	32.15	32.65	TS116
L MAIN TANK UNIT NO. 9	30.65	31.15	TS117
L MAIN TANK UNIT NO. 10	27.00	27.50	TS118
L MAIN TANK UNIT NO. 11	23.35	23.95	TS5196
L MAIN TANK UNIT NO. 12	23.40	23.90	TS5197
CENTER TANK UNIT NO. 1	91.60	92.60	TS5011
CENTER TANK UNIT NO. 2	101.50	102.60	TS5012
CENTER TANK UNIT NO. 3	79.20	80.20	TS5013
CENTER TANK UNIT NO. 4	64.65	65.35	TS5014
CENTER TANK UNIT NO. 5	62.30	63.00	TS5015
CENTER TANK UNIT NO. 6	101.50	102.60	TS5016
CENTER TANK UNIT NO. 7	79.20	80.20	TS5017
CENTER TANK UNIT NO. 8	64.65	65.35	TS5075
CENTER TANK UNIT NO. 9	62.30	63.00	TS5076
R MAIN TANK UNIT NO. 1	60.55	61.25	TS146
R MAIN TANK UNIT NO. 2	58.25	58.95	TS147
R MAIN TANK UNIT NO. 3	48.70	49.30	TS148
R MAIN TANK UNIT NO. 4	46.80	47.40	TS149
R MAIN TANK UNIT NO. 5	37.20	37.70	TS150
R MAIN TANK UNIT NO. 6	37.20	37.70	TS151
R MAIN TANK UNIT NO. 7	32.95	33.45	TS152
R MAIN TANK UNIT NO. 8	32.15	32.65	TS153
R MAIN TANK UNIT NO. 9	30.65	31.15	TS154
R MAIN TANK UNIT NO. 10	27.00	27.50	TS155
R MAIN TANK UNIT NO. 11	23.35	23.95	TS5198
R MAIN TANK UNIT NO. 12	23.40	23.90	TS5199
L MAIN TANK COMPENSATOR	50.20	50.70	TS108
CENTER TANK COMPENSATOR	50.20	50.70	TS5010
R MAIN TANK COMPENSATOR	50.20	50.70	TS119

Dry Capacitance Test in the Main Equipment Center (No Fuel in the Tank)
 Figure 109 (Sheet 4)

EFFECTIVITY
GUI 115

28-41-00

CONFIG 3
 Page 180I
 Sep 28/07

03

1. GENERAL

- A. THE FAULT MESSAGES THAT FOLLOW ARE CONSIDERED INTERMITTENT IF THERE ARE NO FAULT MESSAGES IN THE PRESENT FAULTS MENU AND THERE ARE NO REPORTS THAT THE FQIS TANK INDICATIONS HAVE BLANKED.
- B. THESE INTERMITTENT MESSAGES CAN SHOW ON THE 757 EICAS:
 - 1. EICAS MAINTENANCE MESSAGE "FUEL QUANTITY BITE"
 - 2. EICAS STATUS MESSAGE "FUEL QUANTITY CHAN"THESE MESSAGES CAN BE CAUSED BY INTERMITTENT BUILT-IN-TEST (BIT) FAULT MESSAGES FROM THE FUEL QUANTITY INDICATING SYSTEM (FQIS).
- C. THIS SERVICE INFORMATION APPLIES TO AIRPLANES WITH THE FQIS PROCESSOR, PART NUMBERS 30071-0101,-0202,-0303 BOEING PART NUMBERS S345N001-030,-031,-032 (MANUFACTURED BY SIMMONDS PRECISION).
- D. THE 757 FQIS BIT IN THE PROCESSOR CAN SHOW 37 FAULT MESSAGES. ALL OF THESE FAULT MESSAGES WILL CAUSE A "FUEL QTY BITE" MESSAGE ON THE EICAS MAINTENANCE PAGE. THESE FAULT MESSAGES CAN ALSO CAUSE A "FUEL QTY CHAN", "FUEL QTY IND" OR "FUEL QTY BITE" MESSAGE ON THE EICAS STATUS PAGE. TO REMOVE THE EICAS MESSAGES, YOU MUST GO TO THE BITE PANEL ON THE PROCESSOR AND LOOK AT THE FAULT MESSAGES AS FOLLOWS (FIG. 104):
 - 1. YOU MUST GO TO THE "PRESENT FAULTS ?" MENU AND LOOK AT THE FAULT MESSAGES STORED IN MEMORY. IF THERE ARE FAULT MESSAGES IN THE PRESENT FAULTS MENU, YOU MUST CORRECT THESE FAULTS TO REMOVE THE EICAS MESSAGE(S).
 - 2. YOU MUST ALSO GO TO THE "FAULT HISTORY ?" MENU ON THE BITE PANEL OF THE PROCESSOR AND LOOK AT THE FAULT MESSAGES STORED IN MEMORY FOR THE FLIGHT LEG 00.

NOTE: AIRPLANES WITH PROCESSOR 300 71-0101 (S345N001-030);
POWER INTERRUPT CAN RESET EICAS MESSAGES IF THERE ARE FAULTS IN
FLIGHT LEG 00.

Intermittent Fault Messages
Figure 110 (Sheet 1)

EFFECTIVITY
GUI 115

28-41-00
CONFIG 3
Page 180J
Sep 28/07

03


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	FLIGHT DECK INDICATION OR POSSIBLE CAUSE FOR INTERMITTENT FAULT MESSAGE	CORRECTION
LM IFQC CIRCUIT BOARD FAILED	FOR A POWER BUS TRANSFER OR POWER INTERRUPTION, THESE FAULT MESSAGES CAN CAUSE AN EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" TO SHOW. NOTE: ONLY THE "IOC NUMBER 1 (OR 2) FAILED" MESSAGE WILL CAUSE A "FUEL QUANTITY CHAN" STATUS MESSAGE TO SHOW ON EICAS.	GO TO THE FQIS PROCESSOR BITE PANEL AND DO THE STEPS IN STEP 1.C.
RM IFQC CIRCUIT BOARD FAILED		
CT IFQC CIRCUIT BOARD FAILED		
IOC NUMBER 1 FAILED		
IOC NUMBER 2 FAILED		
LOAD SELECT UNIT OR WIRE FAIL		
IOC 1 DISCRETE DRIVE FAIL		
VOLUME SHUTOFF OF LM AT 95%	THESE MESSAGES CAN SHOW IF POWER IS APPLIED TO THE FQIS (POWER-UP) WHEN THE MAIN TANKS ARE EMPTY, OR WHEN THE CENTER TANK IS LESS THAN 17% FULL BEFORE REFUELING.	IF THESE MESSAGES ONLY SHOW ONE TIME, FUEL QUANTITY INDICATION OR REFUELING WILL NOT BE AFFECTED. IGNORE THE FAULT MESSAGE IN THE FAULT HISTORY MENU.
VOLUME SHUTOFF OF RM AT 95%		
VOLUME SHUTOFF OF CT AT 95%		
LM TU (1-12) CONTAMINATED	THESE MESSAGES CAN SHOW IN THE "FAULT HISTORY ?" MENU OF THE FQIS PROCESSOR BIT.	GO TO FIG. 104, SHEET 1, NOTES 1 AND 2 FOR CORRECTIVE ACTION.
RM TU (1-12) CONTAMINATED		
CT TU (1-12) CONTAMINATED		
LM COMPENSATOR CONTAMINATED		
RM COMPENSATOR CONTAMINATED		
CT COMPENSATOR CONTAMINATED		
AIR/GROUND INPUT FAILED	WHEN THE AIRPLANE IS OPERATED ON BATTERY POWER ON THE GROUND, THIS FAULT MESSAGE WILL SHOW.	IF THE AIRPLANE IS OPERATED ON BATTERY POWER (I.E., BATTERY POWERED REFUELING) AND THIS FAULT MESSAGE SHOWS IN THE FAULT HISTORY MENU, IGNORE THE FAULT MESSAGE.

INTERMITTENT FAULT MESSAGES FOR PROCESSOR S345N001-030

Intermittent Fault Messages
Figure 110 (Sheet 2)

EFFECTIVITY
GUI 115

28-41-00
 CONFIG 3
 Page 180K
 Sep 28/07

03


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	FLIGHT DECK INDICATION OR POSSIBLE CAUSE FOR INTERMITTENT FAULT MESSAGE	CORRECTION
LM IFQC CIRCUIT BOARD FAILED	FOR A POWER BUS TRANSFER OR POWER INTERRUPTION, THESE FAULT MESSAGES CAN CAUSE AN EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" TO SHOW. <u>NOTE:</u> ONLY THE "IOC NUMBER 1 (OR 2) FAILED" MESSAGE WILL CAUSE A "FUEL QUANTITY CHAN" STATUS MESSAGE TO SHOW ON EICAS.	GO TO THE FQIS PROCESSOR BITE PANEL AND DO THE STEPS IN STEP 1.C.
RM IFQC CIRCUIT BOARD FAILED		
CT IFQC CIRCUIT BOARD FAILED		
IOC NUMBER 1 FAILED		
IOC NUMBER 2 FAILED		
IOC 1 DISCRETE DRIVE FAIL		
LM TU (1-12) CONTAMINATED	THESE MESSAGES CAN SHOW IN THE "FAULT HISTORY ?" MENU OF THE FQIS PROCESSOR BIT.	GO TO FIG. 104, SHEET 1, NOTES 1 AND 2 FOR CORRECTIVE ACTION.
RM TU (1-12) CONTAMINATED		
CT TU (1-12) CONTAMINATED		
LM COMPENSATOR CONTAMINATED		
RM COMPENSATOR CONTAMINATED		
CT COMPENSATOR CONTAMINATED		
AIR/GROUND INPUT FAILED	WHEN THE AIRPLANE IS OPERATED ON BATTERY POWER ON THE GROUND, THIS FAULT MESSAGE WILL SHOW.	IF THE AIRPLANE IS OPERATED ON BATTERY POWER (I.E., BATTERY POWERED REFUELING) AND THIS FAULT MESSAGE SHOWS IN THE FAULT HISTORY MENU, IGNORE THE FAULT MESSAGE.

INTERMITTENT FAULT MESSAGES FOR PROCESSOR S345N001-031

Intermittent Fault Messages
Figure 110 (Sheet 3)

EFFECTIVITY
GUI 115

C77006

28-41-00
 CONFIG 3
 Page 180L
 Sep 28/07

03


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FAULT MESSAGE	FLIGHT DECK INDICATION OR POSSIBLE CAUSE FOR INTERMITTENT FAULT MESSAGE	CORRECTION
LM IFQC CIRCUIT BOARD FAILED	FOR A POWER BUS TRANSFER OR POWER INTERRUPTION, THESE FAULT MESSAGES CAN CAUSE AN EICAS MAINTENANCE MESSAGE "FUEL QTY BITE" TO SHOW. <u>NOTE:</u> ONLY THE "IOC NUMBER 1 (OR 2) FAILED" MESSAGE WILL CAUSE A "FUEL QUANTITY CHAN" STATUS MESSAGE TO SHOW ON EICAS.	GO TO THE FQIS PROCESSOR BITE PANEL AND DO THE STEPS IN STEP 1.C.
RM IFQC CIRCUIT BOARD FAILED		
CT IFQC CIRCUIT BOARD FAILED		
IOC NUMBER 1 FAILED		
IOC NUMBER 2 FAILED		
IOC 1 DISCRETE DRIVE FAIL		
LM TU (1-12) CONTAMINATED	THESE MESSAGES CAN SHOW IN THE "FAULT HISTORY ?" MENU OF THE FQIS PROCESSOR BIT.	GO TO FIG. 104, SHEET 1, NOTES 1 AND 2 FOR CORRECTIVE ACTION.
RM TU (1-12) CONTAMINATED		
CT TU (1-12) CONTAMINATED		
LM COMPENSATOR CONTAMINATED		
RM COMPENSATOR CONTAMINATED		
CT COMPENSATOR CONTAMINATED		

INTERMITTENT FAULT MESSAGES FOR PROCESSOR S345N001-032

Intermittent Fault Messages
Figure 110 (Sheet 4)

EFFECTIVITY
GUI 115

C77016

03

28-41-00

CONFIG 3
 Page 180M
 Sep 28/07


PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
6E4, 11C34, 11M19, 34L2

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)

WARNING: TO OPERATE ANY OF THE FUEL PUMPS, YOU MUST BE IN THE FLIGHT COMPARTMENT TO CONTINUOUSLY MONITOR THE FUEL QUANTITY AND THE LOW PRESSURE INDICATION IN THE FUEL TANK. IMMEDIATELY SET THE APPLICABLE FUEL PUMP SWITCH TO THE OFF POSITION IF THE LOW PRESSURE LIGHT COMES ON AND STAYS ON. FUEL VAPORS IN THE TANK MAY IGNITE AND CAUSE A FIRE OR EXPLOSION.

"FUEL CONFIG"
LIGHT AND EICAS
MESSAGE "FUEL CONFIG"
ARE ILLUMINATED




FUEL CONFIG Light and EICAS Message FUEL CONFIG are Illuminated
Figure 111 (Sheet 1)

EFFECTIVITY
GUI 115

28-41-00
CONFIG 3
Page 180N
Sep 28/07

03



FUEL CONFIG Light and EICAS Message FUEL CONFIG are Illuminated
Figure 111 (Sheet 2)


EFFECTIVITY
GUI 115

28-41-00

CONFIG 3

03 Page 1800

Sep 28/07



FUEL CONFIG Light and EICAS Message FUEL CONFIG are Illuminated
Figure 111 (Sheet 3)

EFFECTIVITY
GUI 115

28-41-00
 CONFIG 3
 Page 180P
 Sep 28/07

03

Not Used
Figure 112

EFFECTIVITY
GUI 115

28-41-00


CONFIG 3
Page 180Q
Sep 28/07

03

E64513

Not Used
Figure 113

EFFECTIVITY
GUI 115



E64514

03

28-41-00

CONFIG 3

Page 180R

Sep 28/07


**FUEL QUANTITY
INDICATING MODULE
(FQIM) DOES NOT
DISPLAY CORRECTLY.**

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
6E4,11C34,11L12,11L19,34A10

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)

NOTE: THE DISPLAY IS NOT CORRECT IF IT IS INTERMIT-
TENT, NOT ACCURATE, OR DOES NOT SHOW PART OR
ALL OF NUMBERS.




Fuel Quantity Indicating Module (FQIM) Does Not Display Correctly.
Figure 114 (Sheet 1)

EFFECTIVITY
GUI 115

28-41-00
CONFIG 3
Page 180S
Sep 28/07

03



Fuel Quantity Indicating Module (FQIM) Does Not Display Correctly.
Figure 114 (Sheet 2)

EFFECTIVITY
GUI 115

28-41-00
 CONFIG 3
 Page 180T
 Sep 28/07


03

"FUEL CONFIG" LIGHT
AND EICAS MSG "LOW
FUEL" NOT DISPLAYED
DURING FUEL QTY TEST

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
6E4,11L19,34A10

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)



FUEL CONFIG Light and EICAS Msg LOW FUEL Not Displayed during Fuel Qty Test
Figure 115

EFFECTIVITY
GUI 115

28-41-00
 CONFIG 3
 Page 180U
 Sep 28/07


03

TOTAL FUEL QTY DOES NOT AGREE WITH FMC CALCULATED FUEL QTY. FUEL FLOW NORMAL.

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
6E4,11L19,34A10

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)




Total Fuel Qty Does Not Agree with FMC Calculated Fuel Qty. Fuel Flow Normal.
Figure 116 (Sheet 1)

EFFECTIVITY
GUI 115

28-41-00
CONFIG 3
Page 180V
Sep 28/07

03



Total Fuel Qty Does Not Agree with FMC Calculated Fuel Qty. Fuel Flow Normal.
Figure 116 (Sheet 2)

EFFECTIVITY
GUI 115

28-41-00
 CONFIG 3
 Page 180W
 Sep 28/07


03

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
6E4,11C34,11L19,34A10

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)

EICAS MSG "FUEL QTY IND" OR "FUEL QTY CHANNEL" DISPLAYED.




EICAS Msg FUEL QTY IND or FUEL QTY CHANNEL Displayed.
Figure 117 (Sheet 1)

EFFECTIVITY
GUI 115

28-41-00
 CONFIG 3
 Page 180X
 Sep 28/07

03



EICAS Msg FUEL QTY IND or FUEL QTY CHANNEL Displayed.
Figure 117 (Sheet 2)

EFFECTIVITY
GUI 115

28-41-00
 CONFIG 3
 Page 180Y
 Sep 28/07


03

LOAD SELECT INDICATOR SHOWS THE MESSAGE "-A.-", OR "-b.-" OR "-A.b" IN THE DISPLAY

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
6E4,11C34,11L19,34A10

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)




Load Select Indicator Shows the Message "-A.-", or "-b.-" or "-A.b" in the Display Figure 118 (Sheet 1)

EFFECTIVITY
GUI 115

28-41-00
CONFIG 3
Page 180Z
Sep 28/07

03

AD9482



Load Select Indicator Shows the Message "-A.-", or "-b.-" or "-A.b" in the Display
Figure 118 (Sheet 2)

EFFECTIVITY
GUI 115

28-41-00

CONFIG 3


03

Page 181

Sep 28/07

FUEL QUANTITY INDICATING MODULE (FQIM), M10054, SHOWS THE MESSAGE(S) "-A.-", "-b.-" OR "-A.b" IN ONE OR ALL FUEL QUANTITY DISPLAYS

PREREQUISITES
 MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
 6E4,11C34,11L19,34A10
 MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
 ELECTRICAL POWER IS ON (AMM 24-22-00/201)




Fuel Quantity Indicating Module (FQIM), M10054, Shows the Message(s) "-A.-", "-b.-" or "-A.b" in One or All Fuel Quantity Displays
Figure 119 (Sheet 1)

EFFECTIVITY
GUI 115

28-41-00
CONFIG 3
Page 182
Sep 28/07

03



Fuel Quantity Indicating Module (FQIM), M10054, Shows the Message(s) "-A.-", "-b.-"
 or "-A.b" in One or All Fuel Quantity Displays
 Figure 119 (Sheet 2)

EFFECTIVITY
GUI 115

28-41-00

CONFIG 3

03

Page 182A


Sep 28/07

LOAD SELECT INDICATOR
SHOWS THE MESSAGE
"I.d" IN THE DISPLAY

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
6E4,11C34,11L19,34A10

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)



Load Select Indicator Shows the Message "I.d" in the Display
Figure 120

EFFECTIVITY
GUI 115

28-41-00
 CONFIG 3
 Page 182B
 Sep 28/07

01




757

FAULT ISOLATION/MAINT MANUAL

FUEL PRESSURE INDICATING SYSTEM

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
SWITCH - L AFT FUEL BOOST PUMP PRESSURE, S71	--	1	MAIN LANDING GEAR DOORS	28-42-01
SWITCH - L FUEL OVERRIDE PUMP PRESSURE, S10010	--	1	MAIN LANDING GEAR DOORS	28-42-01
SWITCH - L FWD FUEL BOOST PUMP PRESSURE, S70	--	1	FRONT SPAR	28-42-01
SWITCH - R AFT FUEL BOOST PUMP PRESSURE, S73	--	1	MAIN LANDING GEAR DOORS	28-42-01
SWITCH - R FUEL OVERRIDE PUMP PRESSURE, S10011	--	1	MAIN LANDING GEAR DOORS	28-42-01
SWITCH - R FWD FUEL BOOST PUMP PRESSURE, S72	--	1	FRONT SPAR	28-42-01

Fuel Pressure Indicating System - Component Index
Figure 101




28-42-00

01

Page 101
Sep 20/94

E44535

BOEING
757
FAULT ISOLATION/MAINT MANUAL



PRESSURE SWITCH OF THE LEFT AFT, LEFT FORWARD, RIGHT AFT OR RIGHT FORWARD FUEL BOOST PUMP, S71, S70, S73, OR S72, SHOWN (PRESSURE SWITCH OF THE LEFT AND RIGHT FUEL OVERRIDE PUMP, S10010 AND S10011, ALMOST THE SAME)

(A)

Fuel Pressure Indicating System - Component Location
Figure 102

EFFECTIVITY	
ALL	

28-42-00




757
 FAULT ISOLATION/MAINT MANUAL

FUEL TEMPERATURE INDICATING SYSTEM

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
CIRCUIT BREAKER - FUELING QTY, C1045	--	1	FLT COMPT, P6 6E4	*
CIRCUIT BREAKERS - FUEL QTY 1, C1048	--	1	FLT COMPT, P11 11C34	*
FUEL QTY 2, C1053	--	1	11L19	*
INSTR LTS, C1246	--	1	11B7	*
OVHD INSTR LTS AND PANEL LTS, C1241	--	1	11N4	*
CIRCUIT BREAKER - FUEL QTY, C1040	--	1	FLT COMPT, P34 34AA10	*
SENSOR - FUEL TEMPERATURE, TS5140	1	1	641AB	28-43-01

* SEE THE WDM EQUIPMENT LIST

Fuel Temperature Indicating System - Component Index
 Figure 101





28-43-00

01A

Page 101
 Mar 20/93

B54210



FUEL TEMPERATURE SENSOR, TS5140

(A)


Fuel Temperature Indicating System - Component Location
 Figure 102 (Sheet 1)

EFFECTIVITY	
	ALL


28-43-00

BOEING

757 FAULT ISOLATION/MAINT MANUAL



FLIGHT COMPARTMENT



FUEL QUANTITY INDICATING MODULE (FQIM), M10054

(B)

**MISCELLANEOUS TEST PANEL, M10398
(EXAMPLE PANEL SHOWN)**

(C)

1 THE UNITS ARE IN LBS OR KGS.

**Fuel Temperature Indicating System - Component Location
Figure 102 (Sheet 2)**

EFFECTIVITY

ALL

28-43-00

01A

Page 103
Sep 28/99


PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
6E4,11B7,11C34,11L19,11N4,34AA10

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)

FUEL TEMPERATURE INDICATOR DOES NOT DISPLAY CORRECTLY.

NOTE: AN INCORRECT DISPLAY IS ONE THAT FLUCTUATES OR IS INTERMITTENT OR INACCURATE OR BLANK OR HAS MISSING SEGMENTS.




Fuel Temperature Indicator Does Not Display Correctly.
Figure 103 (Sheet 1)

EFFECTIVITY	ALL
-------------	-----

28-43-00

BOEING
757
FAULT ISOLATION/MAINT MANUAL



Fuel Temperature Indicator Does Not Display Correctly.
Figure 103 (Sheet 2)

EFFECTIVITY

ALL

28-43-00

01A

Page 105
Dec 20/95


C21325


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL


FUEL MEASURING STICK ASSEMBLY

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
L FUEL MEASURING STICK NO. 1	1	1	531AB	28-44-01
L FUEL MEASURING STICK NO. 2	1	1	531CB	28-44-01
L FUEL MEASURING STICK NO. 3	1	1	541AB	28-44-01
L FUEL MEASURING STICK NO. 4	1	1	541EB	28-44-01
L FUEL MEASURING STICK NO. 5	1	1	541JB	28-44-01
L FUEL MEASURING STICK NO. 6	1	1	541MB	28-44-01
L FUEL MEASURING STICK NO. 7	1	1	542BB	28-44-01
R FUEL MEASURING STICK NO. 1	2	1	631AB	28-44-01
R FUEL MEASURING STICK NO. 2	2	1	631CB	28-44-01
R FUEL MEASURING STICK NO. 3	2	1	641AB	28-44-01
R FUEL MEASURING STICK NO. 4	2	1	641EB	28-44-01
R FUEL MEASURING STICK NO. 5	2	1	641JB	28-44-01
R FUEL MEASURING STICK NO. 6	2	1	641MB	28-44-01
R FUEL MEASURING STICK NO. 7	2	1	642BB	28-44-01

Fuel Measuring Stick Assembly - Component Index
Figure 101




28-44-00



Fuel Measuring Stick Assembly - Component Location
Figure 102 (Sheet 1)

EFFECTIVITY	ALL
-------------	-----


28-44-00



Fuel Measuring Stick Assembly - Component Location
Figure 102 (Sheet 2)


EFFECTIVITY	ALL
-------------	-----

28-44-00



LEFT OR RIGHT FUEL MEASURING STICK NO. 1
(INSTALLED ON THE AIRPLANE STRUCTURE)

(A)



LEFT OR RIGHT FUEL MEASURING STICK NO. 2,3,4,5,6,7
(INSTALLED ON THE MAIN OR CENTER TANK ACCESS DOOR)

(B)

Fuel Measuring Stick Assembly - Component Location (Details from Sht 1 and 2)
Figure 102 (Sheet 3)

EFFECTIVITY	ALL
-------------	-----

28-44-00