


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

GPA Group plc

| PAGE | DATE | CODE | PAGE | DATE | CODE | PAGE | DATE | CODE |
|---|-----------|------|---------------|-----------|------|-------------------|-----------|------|
| CHAPTER 52 TAB | | | 52-BITE INDEX | | | 52-34-00 | | |
| DOORS | | | 1 | SEP 28/99 | 01 | 115 | MAY 28/07 | 05 |
| EFFECTIVE PAGES SEE LAST PAGE OF LIST FOR NUMBER OF PAGES | | | 2 | SEP 28/99 | 01 | 116 | MAY 28/07 | 03 |
| 52-CONTENTS | | | 3 | SEP 28/99 | 01 | 117 | SEP 20/94 | 03 |
| 1 | JAN 28/00 | GUI | 4 | BLANK | | 118 | MAY 28/07 | 04 |
| 2 | JAN 28/00 | GUI | 52-11-00 | | | 119 | MAY 28/07 | 03 |
| 3 | JAN 28/00 | GUI | 101 | JUN 20/91 | 02 | 120 | MAY 28/07 | 03 |
| 4 | MAY 28/05 | GUI | 102 | JUN 20/91 | 01 | 121 | MAY 28/07 | 04 |
| 5 | MAY 28/05 | GUI | 103 | JUN 20/91 | 01 | 122 | MAY 28/07 | 03 |
| 6 | MAY 28/05 | GUI | 104 | SEP 28/99 | 01 | 123 | MAY 28/07 | 12 |
| 52-HOW TO USE THE FIM | | | 105 | JUN 20/91 | 02 | 124 | MAY 28/07 | 03 |
| 1 | SEP 20/98 | 01 | 106 | JUN 20/91 | 01 | 125 | MAY 28/07 | 04 |
| 2 | SEP 20/98 | 01 | 107 | JUN 20/91 | 01 | 126 | MAY 28/07 | 04 |
| 3 | SEP 28/99 | 01 | 108 | JUN 20/91 | 01 | 127 | MAY 28/07 | 11 |
| 4 | SEP 20/98 | 01 | 109 | MAY 28/99 | 01 | 128 | MAY 28/07 | 02 |
| 5 | SEP 20/98 | 01 | 110 | JAN 20/99 | 01 | 129 | MAY 28/07 | 02 |
| 6 | SEP 20/98 | 01 | 111 | JAN 20/98 | 01 | 130 | SEP 20/94 | 02 |
| 52-INDEX | | | 112 | JAN 20/98 | 01 | 131 | SEP 20/94 | 02 |
| 1 | MAY 28/05 | 04 | 113 | MAY 28/99 | 01 | 132 | SEP 20/94 | 02 |
| 2 | MAY 28/05 | 04 | 114 | JAN 20/98 | 01 | 133 | SEP 20/94 | 01 |
| 52-EICAS MESSAGES | | | 115 | MAY 28/99 | 01 | 134 | SEP 20/94 | 02 |
| 1 | DEC 20/90 | 01 | 116 | SEP 28/99 | 01 | 52-36-00 | | |
| 2 | DEC 20/90 | 01 | 117 | JAN 20/98 | 01 | 101 | SEP 20/90 | 01 |
| 3 | MAR 20/96 | 02 | 118 | MAY 28/99 | 01 | 102 | SEP 20/90 | 01 |
| 4 | MAR 20/96 | 02 | 119 | MAY 28/99 | 01 | 52-51-00 CONFIG 1 | | |
| 5 | MAR 20/96 | 01 | 120 | JAN 20/98 | 01 | 101 | MAY 28/05 | 11 |
| 6 | BLANK | | 121 | MAY 28/99 | 01 | 102 | MAY 28/05 | 11 |
| 52-FAULT CODE DIAGRAM | | | 122 | MAY 28/99 | 01 | 103 | MAY 28/05 | 11 |
| 1 | MAR 20/88 | 01 | 123 | JAN 20/98 | 01 | 104 | MAY 28/05 | 11 |
| 2 | MAR 15/87 | 01 | 124 | SEP 20/08 | 01 | 105 | MAY 28/05 | 11 |
| 3 | JUN 20/97 | 02 | 125 | JAN 20/98 | 01 | 106 | BLANK | |
| 4 | SEP 20/87 | 01 | 126 | JAN 20/98 | 01 | 52-51-00 CONFIG 2 | | |
| 5 | JUN 20/92 | 07 | 127 | SEP 20/98 | 01 | 101 | MAY 28/05 | 11 |
| 6 | MAY 28/05 | 05 | 128 | JAN 20/98 | 01 | 102 | MAY 28/05 | 11 |
| 7 | MAY 28/05 | 04 | 129 | JAN 20/98 | 01 | 103 | MAY 28/05 | 11 |
| 8 | BLANK | | 130 | BLANK | | 104 | MAY 28/05 | 11 |
| 52-FAULT CODE INDEX | | | 52-21-00 | | | 105 | MAY 28/05 | 11 |
| 1 | SEP 20/08 | 01 | 101 | SEP 20/94 | 01 | 106 | MAY 28/05 | 11 |
| 2 | SEP 20/08 | 01 | 102 | DEC 20/95 | 01 | 107 | MAY 28/05 | 11 |
| 3 | SEP 20/08 | 01 | 103 | SEP 20/94 | 01 | 108 | MAY 28/05 | 11 |
| 4 | SEP 20/08 | 01 | 104 | BLANK | | 109 | MAY 28/05 | 11 |
| 5 | SEP 20/08 | 01 | 52-34-00 | | | 110 | MAY 28/05 | 11 |
| 6 | SEP 20/08 | 01 | 101 | SEP 28/01 | 18 | 111 | MAY 28/05 | 11 |
| 7 | SEP 20/08 | 06 | 102 | DEC 20/95 | 18 | 112 | MAY 28/05 | 11 |
| 8 | BLANK | | 103 | DEC 20/95 | 02 | 52-71-00 | | |
| | | | 104 | DEC 20/95 | 01 | 101 | DEC 20/88 | 02 |
| | | | 105 | DEC 20/95 | 01 | 102 | SEP 15/83 | 01 |
| | | | 106 | MAY 28/07 | 01 | 103 | SEP 15/83 | 01 |
| | | | 107 | MAY 28/07 | 03 | 104 | SEP 15/83 | 01 |
| | | | 108 | MAY 28/07 | 13 | 105 | SEP 15/83 | 01 |
| | | | 109 | MAY 28/07 | 01 | 106 | DEC 20/88 | 02 |
| | | | 110 | MAY 28/07 | 03 | 107 | DEC 20/88 | 02 |
| | | | 111 | MAY 28/07 | 04 | 108 | SEP 20/94 | 02 |
| | | | 112 | MAY 28/07 | 12 | 109 | SEP 20/94 | 04 |
| | | | 113 | MAY 28/07 | 01 | 110 | SEP 20/94 | 03 |
| | | | 114 | SEP 20/94 | 03 | | | |

R = REVISED, A = ADDED OR D = DELETED

F = FOLDOUT PAGE

32

JAN 20/09

D633N632

CHAPTER 52

EFFECTIVE PAGES

PAGE 1

LAST PAGE



BOEING
757
FAULT ISOLATION/MAINT MANUAL

CHAPTER 52 - DOORS

TABLE OF CONTENTS

| <u>Subject</u> | Chapter Section <u>Subject</u> | <u>Page</u> | <u>Effectivity</u> |
|--|--------------------------------------|-------------|--------------------|
| HOW TO USE THE FIM | 52-HOW TO USE THE FIM | 1 | ALL |
| INDEX | 52-INDEX | 1 | ALL |
| EICAS MESSAGES | 52-EICAS MESSAGES | 1 | ALL |
| FAULT CODE DIAGRAMS | 52-FAULT CODE DIAGRAM | 1 | ALL |
| FAULT CODE INDEX | 52-FAULT CODE INDEX | 1 | ALL |
| BITE INDEX | 52-BITE INDEX | 1 | ALL |
| <u>DOORS</u> | 52-00-00 | | |
| <u>PASSENGER/CREW</u> | 52-10-00 | | |
| NO. 1, 2 AND 4 PASSENGER DOORS | 52-11-00 | | |
| Component Location | | 101 | ALL |
| Component Index | | | |
| Component Location | | | |
| Fault Isolation | | | |
| Door is Difficult to Arm/Disarm (Fig. 114) | | 124 | |
| Door is Difficult to Cock (Fig. 110) | | 119 | |
| Door is Difficult to Latch/Unlatch (Fig. 108) | | 115 | |
| Door is Difficult to Open/Close (Fig. 112) | | 121 | |
| Emergency Power Assist System (EPAS) is Difficult to Adjust (Fig. 116) | | 127 | |
| General Guidelines for Door Fault Isolation (Fig. 103) | | 109 | |
| Wear is Found on the Latch Fittings (Fig. 106) | | 113 | |

52-CONTENTS

 **BOEING**
757
FAULT ISOLATION/MAINT MANUAL

CHAPTER 52 - DOORS

TABLE OF CONTENTS

| <u>Subject</u> | Chapter Section <u>Subject</u> | <u>Page</u> | <u>Effectivity</u> |
|---------------------------|--------------------------------------|-------------|--------------------|
| <u>EMERGENCY EXIT</u> | 52-20-00 | | |
| NO. 3 EMERGENCY EXIT DOOR | 52-21-00 | | |
| Component Location | | 101 | ALL |
| Component Index | | | |
| Component Location | | | |

52-CONTENTS



BOEING
757
FAULT ISOLATION/MAINT MANUAL

CHAPTER 52 - DOORS

TABLE OF CONTENTS

| <u>Subject</u> | Chapter Section <u>Subject</u> | <u>Page</u> | <u>Effectivity</u> |
|-------------------------------|--------------------------------------|-------------|--------------------|
| <u>CARGO</u> | 52-30-00 | | |
| NO. 1 AND NO. 2 CARGO DOORS | 52-34-00 | | |
| Component Location | | 101 | ALL |
| Component Index | | | |
| Component Location | | | |
| Fault Isolation | | | |
| No. 1 (Fwd) or No. 2 (Aft) | | 132 | |
| Cargo Door Binding When | | | |
| (Unlocking, Locking, Locking | | | |
| and Unlocking) (Fig. 111) | | | |
| No. 1 (Fwd) Cargo Door Failed | | 114 | |
| to Close Electrically. Manual | | | |
| Operation was Normal. (Fig. | | | |
| 105) | | | |
| No. 1 (Fwd) Cargo Door Failed | | 120 | |
| to Open or Close | | | |
| Electrically. Manual | | | |
| Operation was Normal. (Fig. | | | |
| 107) | | | |
| No. 1 (Fwd) Cargo Door Will | | 106 | |
| Not Open Electrically. Manual | | | |
| Operation Was Normal. (Fig. | | | |
| 103) | | | |
| No. 1 or No. 2 Cargo Door | | 128 | |
| Failed to Open or Close | | | |
| Electrically or Manually. | | | |
| (Fig. 109) | | | |
| No. 1 or No. 2 Cargo Door | | 130 | |
| Opens and Closes too Slowly | | | |
| (Fig. 110) | | | |
| No. 1 or No. 2 Cargo Door | | 134 | |
| Overtravels During Closing | | | |
| (Slams Shut) (Fig. 112) | | | |
| No. 2 (Aft) Cargo Door Failed | | 117 | |
| to Close Electrically. Manual | | | |
| Operation was Normal. (Fig. | | | |
| 106) | | | |
| No. 2 (Aft) Cargo Door Failed | | 124 | |
| to Open or Close | | | |
| Electrically. Manual | | | |
| Operation was Normal. (Fig. | | | |
| 108) | | | |

52-CONTENTS



BOEING
757
FAULT ISOLATION/MAINT MANUAL

CHAPTER 52 - DOORS

TABLE OF CONTENTS

| <u>Subject</u> | Chapter Section <u>Subject</u> | <u>Page</u> | <u>Effectivity</u> |
|--|--------------------------------------|-------------|--------------------|
| No. 2 (Aft) Cargo Door Failed to Open Electrically. Manual Operation Was Normal. (Fig. 104) | | 110 | |
| NO. 3 CARGO DOOR | 52-36-00 | | |
| Component Location | | 101 | [*] |
| Component Index | | | |
| Component Location | | | |
| [*] AIRPLANES WITH NO. 3 CARGO DOOR | | | |

52-CONTENTS



BOEING
757
FAULT ISOLATION/MAINT MANUAL

CHAPTER 52 - DOORS

TABLE OF CONTENTS

| <u>Subject</u> | Chapter Section <u>Subject</u> | <u>Page</u> | <u>Effectivity</u> |
|--|--------------------------------------|-------------|--------------------|
| <u>FIXED INTERIOR</u> | 52-50-00 | | |
| FLIGHT COMPARTMENT DOOR | 52-51-00 | | |
| Component Location | | 101 | CONFIG 1 [*] |
| Component Index | | | |
| Component Location | | | |
| Fault Isolation | | | |
| Flight Deck Door Unlocked | | 104 | |
| Light Did Not Go Off with the | | | |
| Door Locked (Fig. 103) | | | |
| Flight Deck Door Unlocked | | 105 | |
| Switch Will Not Unlock the | | | |
| Door (Fig. 104) | | | |
| [*] GUI 005, 008 PRE-SB 25-271; GUI 007 PRE-SB 25-269; GUI 001-003, 009-999 | | | |
| Component Location | | 101 | CONFIG 2 [*] |
| Component Index | | | |
| Component Location | | | |
| Fault Isolation | | | |
| Flight Deck Door "AUTO UNLK" | | 112 | |
| Light Does Not Come On (Fig. | | | |
| 109) | | | |
| Flight Deck Door "LOCK FAIL" | | 111 | |
| Light Is On (Fig. 108) | | | |
| Flight Deck Door Chime Does | | 110 | |
| Not Sound After Correct Code | | | |
| (Fig. 107) | | | |
| Flight Deck Door Does Not Lock | | 106 | |
| In The "Auto" Mode (Fig. 103) | | | |
| Flight Deck Door Does Not | | 108 | |
| Unlock In "AUTO" Mode (Fig. | | | |
| 105) | | | |
| Flight Deck Door Does Not | | 107 | |
| Unlock In The "Unlock" Mode | | | |
| (Fig. 104) | | | |
| Flight Deck Door Unlocks Or | | 109 | |
| Chimes Sound In "DENY" Mode | | | |
| (Fig. 106) | | | |
| [*] GUI 005, 008 POST-SB 25-271; GUI 007 POST-SB 25-269; GUI 004, 006 | | | |

52-CONTENTS




BOEING
757
FAULT ISOLATION/MAINT MANUAL

CHAPTER 52 - DOORS

TABLE OF CONTENTS

| <u>Subject</u> | Chapter Section <u>Subject</u> | <u>Page</u> | <u>Effectivity</u> |
|---|--------------------------------------|-------------|--------------------|
| <u>DOOR WARNING</u> | 52-70-00 | | |
| DOOR WARNING SYSTEM | 52-71-00 | | |
| Component Location | | 101 | ALL |
| Component Index | | | |
| Component Location | | | |
| Fault Isolation | | | |
| Doors Lgt Illum and EICAS Msg Displayed. Door was Closed. (Fig. 103) | | 108 | |
| EICAS Message Displayed For Entry Door, Emer Door, Cargo Door, or Access Door. Corresponding Annunciator Light Not Illuminated (Fig. 104A) | | 110 | |
| EICAS Msg (L,R) (FWD,CTR,AFT) ENT DOOR Did Not Display with Door Open. (Fig. 104) | | 109 | |

52-CONTENTS



Basic Fault Isolation Process
Figure 1


EFFECTIVITY

ALL

52-HOW TO USE THE FIM

01

Page 1
Sep 20/98



How to Get Fault Information from BITE
Figure 2


EFFECTIVITY

ALL

52-HOW TO USE THE FIM

01

Page 2
Sep 20/98



How to Find the Corrective Action or Fault Isolation Procedure in the FIM

Figure 3

EFFECTIVITY

ALL

52-HOW TO USE THE FIM

01

Page 3
Sep 28/99

ASSUMED CONDITIONS AT START OF TASK

- External electrical power is OFF
- Hydraulic power and pneumatic power are OFF
- Engines are shut down
- Circuit breakers for the system are closed
- No equipment in the system is deactivated

PREREQUISITES

- This box gives the steps to get the airplane from the normal shutdown condition to the configuration necessary to do the fault isolation procedure.
- The Prerequisites give procedure references, circuit breakers, and special tools and equipment requirements.

FAULT ISOLATION BLOCKS

- Start the fault isolation procedure at block 1 unless specified differently.
- Do the check to get an answer to the question in the box. Follow the arrow that applies to your answer. This will go to the next check.
- When you get to a box in the column at the right of the page, you have isolated that fault. Do the steps in that box to repair the cause of the fault.
- Make sure that fault is corrected to complete the procedure.

Do the Fault Isolation Procedure
Figure 4


EFFECTIVITY

ALL

52-HOW TO USE THE FIM

01


Page 4
Sep 20/98



Subjects in Each FIM Chapter
Figure 5 (Sheet 1)

| | |
|------------------------|---|
| EFFECTIVITY ALL | <h1 style="margin: 0;">52-HOW TO USE THE FIM</h1> <p align="right">01 Page 5 Sep 20/98</p> |
|------------------------|---|


H54440



Alphabetical list of the EICAS messages. Gives the procedure to repair the cause of the message or a reference to a fault isolation procedure.

Failure analysis diagrams for the airplane systems to find the correct fault code for the fault.


Numerical list of fault codes. Gives the procedure to repair the cause of the fault or a reference to a fault isolation procedure.



Alphabetical list of all the LRUs/systems that have BITE. Gives the chapter/section for the BITE procedure.

Component index, component location, and fault isolation procedures for the systems in the chapter.


Subjects in Each FIM Chapter
Figure 5 (Sheet 2)




52-HOW TO USE THE FIM

| <u>TITLE</u> | <u>CHAP/SEC</u> |
|---|-----------------|
| CARGO DOORS..... | 5234 |
| DOOR AIR NOISE..... | 5211 |
| DOOR INDICATION..... | 5271 |
| ENTRY/SERVICE/EMERGENCY EXIT DOORS..... | 5211,5221 |
| FLIGHT DECK DOOR | 5251 |
| FLIGHT DECK DOOR CONTROL PANEL | |
| (SEcurity DOOR)..... | 5251 |
| FLIGHT DECK ACCESS PANEL | |
| (SEcurity DOOR)..... | 5251 |
| GIRT BAR ENGAGEMENT INDICATOR | |
| LIGHT (SLIDE/RAFT)..... | CHAPTER 25 |
| LAVATORY DOORS | CHAPTER 25 |
| WINDOW FOGGING | CHAPTER 25 |


DOORS - INDEX




52-INDEX




ENTRY/SERVICE DOORS




5271 OVERHEAD PANEL




OVERHEAD PANEL




EMERGENCY EXIT DOOR




FLIGHT DECK DOOR




FLT DK DOOR



CARGO DOOR CONTROL SWITCH



CARGO COMPT DOOR



LAVATORY DOOR (TYPICAL)

1 AS INSTALLED

DOORS - INDEX

| | |
|-------------|-----|
| EFFECTIVITY | ALL |
|-------------|-----|

52-INDEX

DOORS - EICAS MESSAGE LIST

1. General

- A. This procedure shows the EICAS message locations and gives a list of procedures to find the solution for each message.
 - (1) EICAS Message Locations (Fig. 1)
 - (a) Figure 1 shows the location of the EICAS display units and the area where the messages show on the display units.
 - (b) Each message level has a different location. The location and color of each message level is also shown.
 - (2) The EICAS MESSAGE LIST gives the message, level, and procedure for each message.
 - (a) The EICAS MESSAGE column lists the messages alphabetically. Messages which start with L, R, or C are put together and alphabetized at L.
 - (b) The LEVEL column gives all levels for each message as follows:
 - A - Warning messages
 - B - Caution messages
 - C - Advisory messages
 - S - Status messages
 - M - Maintenance messages
 - (c) The PROCEDURE column gives the steps that are necessary to remove the message and includes one or more of the procedures that follow:
 - 1) A Fault Isolation Manual procedure reference
 - 2) A Maintenance Manual procedure and reference
 - 3) Wiring checks and a Wiring Diagram Manual reference
 - 4) A reference to an EICAS message list in a different chapter.
 - 5) A reference to a FAULT CODE INDEX and specified fault codes
 - 6) A step to change the airplane configuration

EFFECTIVITY



ALL

52-EICAS MESSAGES


01

Page 1
Dec 20/90


BOEING
757
FAULT ISOLATION/MAINT MANUAL



ENGINE PRIMARY PAGE OR COMPACTED PAGE
(TOP DISPLAY UNIT)




ECS/MSG PAGE
(BOTTOM DISPLAY UNIT)



STATUS PAGE
(BOTTOM DISPLAY UNIT)

| LEVEL | COLOR |
|---------------|--------|
| A-WARNING | RED |
| B-CAUTION | YELLOW |
| C-ADVISORY | YELLOW |
| S-STATUS | WHITE |
| M-MAINTENANCE | WHITE |

EICAS Message Locations
Figure 1



52-EICAS MESSAGES



BOEING
757
FAULT ISOLATION/MAINT MANUAL

| EICAS MESSAGE LIST | | |
|--------------------|-------|--|
| EICAS MESSAGE | LEVEL | PROCEDURE |
| ACCESS DOORS | C | Remove the unwanted material or blockages from the forward access door or the Electrical/Electronics access door latch pins and latch fittings. If the problem continues, adjust the access door proximity sensors (AMM 52-71-00/501). |
| AFT CARGO DOOR | C | Remove the unwanted material or blockages from the No. 2 cargo door latch mechanisms. If the problem continues, adjust the No. 2 cargo door proximity sensor, S10088 (AMM 52-71-00/501). |
| AFT CARGO DOOR 1 | C | Remove the unwanted material or blockages from the No. 2 cargo door latch mechanisms. If the problem continues, adjust the No. 2 cargo door proximity sensor, S10088 (AMM 52-71-00/501). |
| AFT CARGO DOOR 2 | C | Remove the unwanted material or blockages from the No. 3 cargo door latch mechanisms. If the problem continues, adjust the No. 3 cargo door proximity sensor, S10089 (AMM 52-71-00/501). |
| CARGO DOORS | C | Remove the unwanted material or blockages from the cargo doors latch mechanisms. If the problem continues, adjust the cargo door locked proximity sensors (AMM 52-71-00/501). |
| E/E ACCESS DOOR | C | Remove the unwanted material or blockages from the Electrical/Electronics access door latch pins and latch fittings. If the problem continues, adjust the proximity sensor (AMM 52-71-00/501). |
| EMER DOORS | C | Remove the unwanted material or blockages from the mechanisms of the emergency doors or hatches. If the problem continues, adjust the proximity sensors (AMM 52-71-00/501). |

EFFECTIVITY

ALL

52-EICAS MESSAGES

02

Page 3
Mar 20/96


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

| EICAS MESSAGE LIST | | |
|--------------------|-------|--|
| EICAS MESSAGE | LEVEL | PROCEDURE |
| FWD ACCESS DOOR | C | Remove the unwanted material or blockages from the forward access door latch pins and latch fittings. If the problem continues, adjust the access door proximity sensors (AMM 52-71-00/501). |
| FWD CARGO DOOR | C | Remove the unwanted material or blockages from the No. 1 cargo door latch mechanisms. If the problem continues, adjust the No. 1 cargo door locked proximity sensor, S10083 (AMM 52-71-00/501). |
| (L,R) AFT ENT DOOR | C | Remove the unwanted material or blockages from the No. 4 passenger door latch cams or upper and lower gates. If the problem continues, adjust the No. 4 passenger door warning proximity sensor, S10097 or S10093 (AMM 52-71-00/501). |
| (L,R) CTR ENT DOOR | C | Remove the unwanted material or blockages from the No. 2 passenger door latch cams or upper and lower gates. If the problem continues, adjust the No. 2 passenger door warning proximity sensor, S10095 or S10091 (AMM 52-71-00/501). |
| (L,R) EMER DOOR | C | Remove the unwanted material or blockages from the No. 3 emergency exit door latch rollers, latch cams, and stop fittings. If the problem continues, adjust the proximity sensor (AMM 52-71-00/501). |
| (L,R) ENTRY DOORS | C | Remove the unwanted material or blockages from the No. 1, 2, and 4 passenger doors latch cams or upper and lower gates. If the problem continues, adjust the No. 1, 2, and 4 passenger doors warning proximity sensors, S10094, S10090, S10095, S10091, S10097, and S10093 (AMM 52-71-00/501). |

EFFECTIVITY

ALL

52-EICAS MESSAGES

02

Page 4
Mar 20/96


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

| EICAS MESSAGE LIST | | |
|-----------------------|-------|---|
| EICAS MESSAGE | LEVEL | PROCEDURE |
| (L,R) FWD ENT DOOR | C | Remove the unwanted material or blockages from the No. 1 passenger door latch cams or upper and lower gates. If the problem continues, adjust the No. 1 passenger door warning proximity sensor, S10094 or S10090 (AMM 52-71-00/501). |

EFFECTIVITY

ALL

52-EICAS MESSAGES

01

Page 5
Mar 20/96


BOEING

757

FAULT ISOLATION/MAINT MANUAL



ENTRY/SERVICE/EMERGENCY EXIT DOORS

FAULT CODE/ LOCATION



DOORS 1

| | |
|---------|----|
| 1L | 01 |
| 2L | 02 |
| 3L EMER | 03 |
| 4L | 04 |
| 1R | 05 |
| 2R | 06 |
| 3R EMER | 07 |
| 4R | 08 |



APPLICABLE CIRCUIT BREAKERS
NONE

ENTRY/SERVICE/EMERGENCY EXIT DOORS - FAULT CODES

EFFECTIVITY

ALL

52-FAULT CODE DIAGRAM

01

Page 1
Mar 20/88


BOEING

757

FAULT ISOLATION/MAINT MANUAL

ENTRY/SERVICE DOORS


EMERGENCY EXIT DOORS



**FAULT CODE/
LOCATION**

| DOORS | | 1 |
|-------|------|----|
| 1L | | 01 |
| 2L | | 02 |
| 3L | EMER | 03 |
| 4L | | 04 |
| 1R | | 05 |
| 2R | | 06 |
| 3R | EMER | 07 |
| 4R | | 08 |


DOES DOOR HAVE EXCESSIVE
NOISE LEVEL DUE TO LEAKAGE?



NOT APPLY 00

NORMAL

REPORT ANY FAULT SYMPTOM OR PATTERN NOT SHOWN ABOVE → 52 11 XB



APPLICABLE CIRCUIT BREAKERS

NONE

DOOR AIR NOISE - FAULT CODES


EFFECTIVITY

ALL

52-FAULT CODE DIAGRAM

01

Page 2
Mar 15/87



1 A KEY MUST BE USED TO OPEN DOOR FROM PASSENGER COMPARTMENT. DOOR WILL UNLOCK WITH LOSS OF ELECTRICAL POWER.

APPLICABLE CIRCUIT BREAKERS AS INSTALLED


| | |
|------|------------------|
| 11R5 | FLT DK DOOR LOCK |
| 11R5 | F/D DOOR LOCK |

FLIGHT DECK DOOR - FAULT CODES

EFFECTIVITY

ALL

52-FAULT CODE DIAGRAM



APPLICABLE CIRCUIT BREAKERS

NONE

CARGO DOORS - FAULT CODES


EFFECTIVITY

ALL

52-FAULT CODE DIAGRAM

BOEING

757 FAULT ISOLATION/MAINT MANUAL



APPLICABLE CIRCUIT BREAKERS

11R33 DOOR IND

DOOR INDICATION - FAULT CODES

EFFECTIVITY

ALL

52-FAULT CODE DIAGRAM

07


Page 5
Jun 20/92

BOEING

757

FAULT ISOLATION/MAINT MANUAL

OVERHEAD PANEL



FAULT CODE/ LOCATION

| | |
|------|----|
| UNLK | 01 |
| AUTO | 02 |
| DENY | 03 |
| ALL | 04 |

WAS FLIGHT DECK DOOR CONTROL PANEL OPERATION NORMAL?

NOT APPLY 00

| | | |
|--|-------------------------------------|-------------|
| <div style="border: 1px solid black; width: 20px; height: 20px; margin: 0 auto; transform: rotate(45deg);"></div> <p>YES</p> | DOOR LOCK FAIL LIGHT ABNORMAL | NORMAL |
| | DOOR AUTO UNLOCK LIGHT ABNORMAL | 52 51 11 00 |
| | DOOR LOCK CONTROL SELECTOR ABNORMAL | 52 51 12 00 |
| | | 52 51 13 -- |

REPORT ANY FAULT SYMPTOM OR PATTERN NOT SHOWN ABOVE → 52 51 XB --

APPLICABLE CIRCUIT BREAKERS

NONE

1 AS INSTALLED

FLIGHT DECK DOOR CONTROL PANEL – FAULT CODES

EFFECTIVITY


ALL

52-FAULT CODE DIAGRAM


05

Page 6
May 28/05

FAULT CODE/
LOCATION



WAS FLIGHT DECK ACCESS PANEL OPERATION NORMAL?



REPORT ANY FAULT SYMPTOM OR PATTERN NOT SHOWN ABOVE → 52 51 XC 00

APPLICABLE CIRCUIT BREAKERS

NONE

1 AS INSTALLED

FLIGHT DECK ACCESS PANEL – FAULT CODES

EFFECTIVITY

ALL

52-FAULT CODE DIAGRAM

04

Page 7
May 28/05



BOEING
757
FAULT ISOLATION/MAINT MANUAL

| FAULT CODE | LOG BOOK REPORT | FAULT ISOLATION REFERENCE |
|-------------|---|---|
| 52 11 XA -- | A (01=1L,02=2L,03=3L EMER,04=4L,05=1R,06=2R,07=3R EMER,08=4R) door problem was encountered which is not covered in the Fault Code Diagrams. | (01=1L,02=2L,04=4L,05=1R,06=2R,08=4R) AMM 52-11-00 (03=3L EMER,07=3R EMER) AMM 52-21-00 |
| 52 11 XB -- | A (01=1L,02=2L,03=3L EMER,04=4L,05=1R,06=2R,07=3R EMER,08=4R) door air noise problem was encountered which is not covered in the Fault Code Diagrams. | (01=1L,02=2L,04=4L,05=1R,06=2R,08=4R) AMM 52-09-01 (03=3L EMER,07=3R EMER) AMM 52-09-06 |
| 52 34 XA -- | A (01=FWD,02=AFT) cargo door problem was encountered which is not covered in the Fault Code Diagrams. | AMM 52-34-00 |
| 52 51 XA 00 | A flight deck door problem was encountered which is not covered in the Fault Code Diagrams. | AMM 52-51-00 |
| 52 51 XB -- | A flight deck door control panel problem was encountered which is not covered in the Fault Code Diagrams. | AMM 52-51-00 |
| 52 51 XC 00 | A flight deck access panel problem was encountered which is not covered in the Fault Code Diagrams. | AMM 52-51-00 |
| 52 71 XA -- | A (01=L,02=R,03=FWD,04=CTR,05=AFT,06=E/E) door warning indication problem was encountered by the flight crew which is not covered in Fault Code Diagrams. | AMM 52-71-00 |
| 52 11 01 -- | (01=1L,02=2L,03=3L EMER,04=4L,05=1R,06=2R,07=3R EMER,08=4R) Door bustle (damaged, loose, etc.). | (01=1L,02=2L,04=4L,05=1R,06=2R,08=4R) Tighten strap through center latch (AMM 25-66-01). If problem continues, replace bustle (AMM 52-21-00). |

EFFECTIVITY

ALL

52-FAULT CODE INDEX

01

Page 1
Sep 20/08



757
FAULT ISOLATION/MAINT MANUAL

| FAULT CODE | LOG BOOK REPORT | FAULT ISOLATION REFERENCE |
|-------------|---|---|
| 52 11 02 -- | (01=1L,02=2L,03=3L EMER,04=4L,05=1R,06=2R,07=3R EMER,08=4R) Door escape slide pressure (below green band, zero). | (01=1L,02=2L,04=4L,05=1R,06=2R,08=4R) Replace passenger door escape slide (AMM 25-66-01). (03=3L EMER,07=3R EMER) Replace emergency exit door escape slide (AMM 25-66-03). |
| 52 11 03 -- | (01=1L,02=2L,04=4L,05=1R,06=2R,08=4R) Door evacuation slide arming lever difficult to position to (ENGAGE,DETACH) position. | FIM 52-11-00/101, Fig. 103, Block 1 |
| 52 11 04 -- | (01=1L,02=2L,04=4L,05=1R,06=2R,08=4R) Door handle difficult to move to open position. | Check door rigging and adjust as required (AMM 52-11-00). If problem continues, repair or replace door (AMM 52-11-01), guide arm (AMM 52-11-04), camplates or lower hinge link (AMM 52-11-09), rotary snubber (AMM 52-11-10), counterbalance (AMM 52-11-11), or other components. |
| 52 11 05 -- | (01=1L,02=2L,03=3L EMER,04=4L,05=1R,06=2R,07=3R EMER,08=4R) Door handle difficult to move to close position. | Check door rigging and adjust as required (AMM 52-11-00). If problem persists, repair or replace door (AMM 52-11-01), guide arm (AMM 52-11-04), camplates or lower hinge link (AMM 52-11-09), rotary snubber (AMM 52-11-10), counterbalance (AMM 52-11-11), or other components. |
| 52 11 06 -- | (01=1L,02=2L,04=4L,05=1R,06=2R,08=4R) Door has excessive noise from air leak (describe location of noise). | Repair or replace passenger door seal (AMM 52-09-01). |
| 52 11 07 -- | (01=1L,02=2L,03=3L EMER,04=4L,05=1R,06=2R,07=3R EMER,08=4R) Door seal (torn, loose, etc.). | (01=1L,02=2L,04=4L,05=1R,06=2R,08=4R) Repair or replace passenger door seal (AMM 52-09-01). (03=3L EMER,07=3R EMER) Repair or replace emergency exit door seal (AMM 52-09-06). |

EFFECTIVITY

ALL

52-FAULT CODE INDEX

01

Page 2
Sep 20/08



BOEING
757
FAULT ISOLATION/MAINT MANUAL

| FAULT CODE | LOG BOOK REPORT | FAULT ISOLATION REFERENCE |
|-------------|--|--|
| 52 11 08 -- | (01=1L,02=2L,04=4L,05=1R,06=2R,08=4R) Door handle difficult to move. | FIM 52-11-00/101, Fig. 104, Block 1 |
| 52 11 09 -- | (01=1L,02=2L,04=4L,05=1R,06=2R,08=4R) Outside door handle will not release. | Adjust exterior handle latch (AMM 52-11-13). |
| 52 11 10 -- | (01=1L,02=2L,04=4L,05=1R,06=2R,08=4R) Door damaged by loading steps, fleet service, etc. | Repair or replace door (AMM 52-11-01). |
| 52 11 11 -- | (01=1L,02=2L,04=4L,05=1R,06=2R,08=4R) Door rollers do not always engage, damaged, etc. | Adjust latch roller cranks (AMM 52-11-00) or, repair or replace damaged rollers. |
| 52 11 12 -- | (01=1L,02=2L,04=4L,05=1R,06=2R,08=4R) Door sweeper seal (damaged, loose, does not interface with floor, etc.). | Repair or replace seal. |
| 52 11 13 -- | (01=1L,02=2L,04=4L,05=1R,06=2R,08=4R) Door hold-open latch binds, broken. | Repair or replace hold-open latch (AMM 52-11-08). |
| 52 11 14 -- | (01=1L,02=2L,04=4L,05=1R,06=2R,08=4R) Door evacuation slide arming lever broken. | Repair or replace door evacuation slide arming lever. |
| 52 11 15 -- | (01=1L,02=2L,04=4L,05=1R,06=2R,08=4R) Door handle too close to slide cover. | Adjust the position of slide and slide cover (AMM 25-66-01). |
| 52 21 01 -- | (03=3L EMER,07=3R EMER) Exit door has excessive noise from air leak (describe location of noise). | Repair or replace emergency exit pressure seal (AMM 52-09-06). |
| 52 34 01 -- | (01=FWD,02=AFT) Cargo door will not open electrically. Manual operation was normal. | FIM 52-34-00/101, Fig. 103 and 104, Block 1 |
| 52 34 02 -- | (01=FWD,02=AFT) Cargo door failed to open electrically or manually. | FIM 52-34-00/101, Fig. 109, Block 1 |

EFFECTIVITY

ALL

52-FAULT CODE INDEX

01

Page 3
Sep 20/08



BOEING
757
FAULT ISOLATION/MAINT MANUAL

| FAULT CODE | LOG BOOK REPORT | FAULT ISOLATION REFERENCE |
|-------------|---|--|
| 52 34 03 -- | (01=FWD,02=AFT) Cargo door failed to close electrically. Manual operation was norm. | (01=FWD) FIM 52-34-00/101, Fig. 105, Block 1 (02=AFT) FIM 52-34-00/101, Fig. 106, Block 1 |
| 52 34 04 -- | (01=FWD,02=AFT) Cargo door failed to close electrically or manually. | FIM 52-34-00/101, Fig. 109, Block 1 |
| 52 34 05 -- | (01=FWD,02=AFT) Cargo door failed to open or close electrically. Manual operation was norm. | (01=FWD) FIM 52-34-00/101, Fig. 107, Block 1 (02=AFT) FIM 52-34-00/101, Fig. 108, Block 1 |
| 52 34 06 -- | (01=FWD,02=AFT) Cargo door failed to open or close electrically or manually. | FIM 52-34-00/101, Fig. 109, Book 1 |
| 52 34 07 -- | (01=FWD,02=AFT) Cargo door (opens and closes too slow, binding during open/close). | FIM 52-34-00/101, Fig. 110, Block 1 |
| 52 34 08 -- | (01=FWD,02=AFT) Cargo door binding when (unlocking, locking, locking and unlocking). | FIM 52-34-00/101, Fig. 111, Block 1 |
| 52 34 09 -- | (01=FWD,02=AFT) Cargo door over travels during closing (slams shut). | FIM 52-34-00/101, Fig. 112, Block 1 |
| 52 34 10 -- | (01=FWD,02=AFT 1) Cargo door motor continues to run after door closed. | FIM 52-34-00/101, Fig. 112, Block 3 |
| C2 34 11 -- | (01=FWD,02=AFT 1) Cargo door locking handle stop missing. | Replace cargo door locking handle stop (AMM 52-34-22). |
| 52 34 12 -- | (01=FWD,02=AFT) Cargo door springs open excessively when unlocked. | Replace and/or adjust door down proximity switch and target (AMM 52-34-35). |
| 52 51 01 00 | FLIGHT DK DOOR UNLOCKED lgt failed to extin with door locked. | FIM 52-51-00/101, Fig. 103, Block 1 |
| 52 51 02 00 | FLIGHT DK DOOR UNLOCKED sw would not unlock door. | FIM 52-51-00/101, Fig. 104, Block 1 |

EFFECTIVITY

ALL

52-FAULT CODE INDEX

01

Page 4
Sep 20/08



BOEING
757
FAULT ISOLATION/MAINT MANUAL

| FAULT CODE | LOG BOOK REPORT | FAULT ISOLATION REFERENCE |
|-------------|--|--|
| 52 51 03 00 | Flight deck door will not latch. | Replace flight deck door lock unit (AMM 52-51-01). |
| 52 51 04 00 | Flight deck door difficult to (open/close). | Replace flight deck door lock unit (AMM 52-51-01). |
| 52 51 05 00 | Flight deck door handle broken. | Repair or replace flight deck door handle as required. |
| 52 51 06 00 | Flight deck door key (broken in lock, missing, etc.). | Remove broken key from lock and/or replace key. |
| 52 51 11 00 | Flight Deck Door LOCK FAIL light (inop, door locked, etc.). | FIM 52-51-00/101 |
| 52 51 12 00 | Flight Deck Door AUTO UNLK light operation abnormal. | FIM 52-51-00/101 |
| 52 51 13 -- | Flight Deck Door Lock Selector operation abnormal. | FIM 52-51-00/101 |
| 52 51 14 00 | Flight Deck Access Panel Keypad (access code, specify key) operation abnormal. | FIM 52-51-00/101 |
| 52 51 15 00 | Flight Deck Access Panel (red, amber, green) LED operation abnormal. | FIM 52-51-00/101 |
| 52 71 01 -- | EICAS msg (01=L,02=R) FWD ENT DOOR displayed steady/intermittent and ENTRY DOORS open lgt on steady/intermittent with door closed. | FIM 52-71-00/101, Fig. 103, Block 1 |
| 52 71 02 -- | EICAS msg (01=L,02=R) EMER DOOR displayed steady/intermittent and EMER DOORS open light on steady/intermittent with door closed. | FIM 52-71-00/101, Fig. 103, Block 1 |
| 52 71 03 00 | EICAS msg FWD CARGO DOOR displayed steady/intermittent and CARGO DOORS open light on steady/intermittent with door closed. | FIM 52-71-00/101, Fig. 103, Block 1 |

EFFECTIVITY

ALL

52-FAULT CODE INDEX

01

Page 5
Sep 20/08



BOEING
757
FAULT ISOLATION/MAINT MANUAL

| FAULT CODE | LOG BOOK REPORT | FAULT ISOLATION REFERENCE |
|-------------|--|-------------------------------------|
| 52 71 04 00 | EICAS msg FWD ACCESS DOOR displayed steady/intermittent and ACCESS DOORS open light on steady/intermittent with door closed. | FIM 52-71-00/101, Fig. 103, Block 1 |
| 52 71 05 -- | EICAS msg (L,R) (03=FWD,04=CTR,05=AFT) ENT DOOR not displayed and ENTRY DOORS open light not on with door open. | FIM 52-71-00/101, Fig. 104, Block 1 |
| 52 71 06 -- | EICAS msg (01=L,02=R) EMER DOOR not displayed and EMER DOORS open light not on with door open. | FIM 32-09-03/101, Fig. 103, Block 1 |
| 52 71 07 -- | EICAS msg (03=FWD,05=AFT) CARGO DOOR not displayed and CARGO DOORS open light not on with door open. | FIM 32-09-03/101, Fig. 103, Block 1 |
| 52 71 08 -- | EICAS msg (03=FWD,06=E/E) ACCESS DOOR not displayed and ACCESS DOORS open light not on with door open. | FIM 32-09-03/101, Fig. 103, Block 1 |
| 52 71 09 -- | EICAS msg (01=L,02=R) CTR ENT DOOR displayed steady/intermittent and ENTRY DOORS open lgt on steady/intermittent with door closed. | FIM 52-71-00/101, Fig. 103, Block 1 |
| 52 71 10 -- | EICAS msg (01=L,02=R) AFT ENT DOOR displayed steady/intermittent and ENTRY DOORS open lgt on steady/intermittent with door closed. | FIM 52-71-00/101, Fig. 103, Block 1 |
| 52 71 11 -- | EICAS msg (01=L,02=R) ENTRY DOORS displayed steady/intermittent and ENTRY DOORS open lgt on steady/intermittent with doors closed. | FIM 52-71-00/101, Fig. 103, Block 1 |
| 52 71 12 00 | EICAS msg displayed steady/intermittent and corresponding DOOR OPEN light not on. | FIM 52-71-00/101, Fig. 104A |

EFFECTIVITY

ALL

52-FAULT CODE INDEX

01

Page 6
Sep 20/08



BOEING
757
FAULT ISOLATION/MAINT MANUAL

| FAULT CODE | LOG BOOK REPORT | FAULT ISOLATION REFERENCE |
|-------------|---|-------------------------------------|
| 52 71 13 00 | EICAS msg EMER DOORS displayed steady/intermittent and EMER DOORS open lgt on steady/intermittent with doors closed. | FIM 52-71-00/101, Fig. 103, Block 1 |
| 52 71 14 -- | EICAS msg AFT CARGO DR (03=1, 04=2) displayed steady/intermittent and CARGO DOORS open lgt on steady/intermittent with door closed. | FIM 52-71-00/101, Fig. 103, Block 1 |
| 52 71 15 00 | EICAS msg CARGO DOORS displayed steady/intermittent and CARGO DOORS open lgt on steady/intermittent with doors closed. | FIM 52-71-00/101, Fig. 103, Block 1 |
| 52 71 16 00 | EICAS msg E/E ACCESS DOOR displayed steady/intermittent and ACCESS DOORS open lgt on steady/intermittent with door closed. | FIM 52-71-00/101, Fig. 103, Block 1 |
| 52 71 17 00 | EICAS msg ACCESS DOORS displayed steady/intermittent and ACCESS DOORS open lgt on steady/intermittent with doors closed. | FIM 52-71-00/101, Fig. 103, Block 1 |

EFFECTIVITY

ALL

52-FAULT CODE INDEX

06

Page 7
Sep 20/08


BITE Index

1. General

- A. Use this index to find the BITE procedure for the applicable LRU/System.
- B. The BITE procedure will provide the fault isolation instructions for the fault indications/LRU maintenance messages.

| <u>LRU/System Name</u> | <u>Acronym</u> | <u>FIM Reference</u> |
|---|----------------|--------------------------|
| Air Data Computer | ADC | 34-12 |
| Air Data Inertial Reference Unit | ADIRU | 34-26 |
| Air Traffic Control Transponder | ATC | 34-53 |
| Airborne Vibration Monitor Signal Conditioner | AVM | 77-31 |
| Antiskid/Autobrake Control Unit | | 32-42 |
| APU Fire Detection System | | 26-15 |
| Automatic Direction Finder Receiver | ADF | 34-57 |
| APU Control Unit | ECU | 49-11 |
| Brake Temperature Monitor Unit | | 32-46 |
| Bus Power Control Unit | BPCU | 24-20 |
| Cabin Pressure Controller | | 21-30 |
| Digital Flight Data Acquisition Unit | DFDAU | 31-31 |
| Distance Measuring Equipment Interrogator | DME | 34-55 |
| Duct Leak (Wing and Body) | | 26-18 |
| E/E Cooling Control Card (If cards installed) | | 21-58 |
| ECS Bleed Configuration Card | | 36-10 |
| Electronic Engine Control (RR Engines) | EEC | 73-21 |
| Electronic Engine Control Monitor Unit (PW Engines) | EECM | 71-EPCS Message Index |
| Electronic Flight Instrument System | EFIS | 34-22 |
| Electronic Propulsion Control System (PW Engines) | EPCS | 71-EPCS Message Index |
| Engine Fire/Overheat Detection System | | 26-11 |
| Engine Indication and Crew Alerting System Computer | EICAS | 31-41 |

Bite Index
Figure 1 (Sheet 1)




52-BITE INDEX


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

| <u>LRU/System Name</u> | <u>Acronym</u> | <u>FIM Reference</u> |
|---|----------------|----------------------|
| Engine Turbine Cooling Overheat Detection System (RR Engines) | | 26-13 |
| Enhanced Ground Proximity Warning Computer | EGPWC | 34-46 |
| Flap/Slat Accessory Module | FSAM | 27-51 |
| Flap/Slat Electronic Unit | FSEU | 27-51 |
| Flight Management Computer | FMC | 34-61 |
| Fuel Quantity Indicating System Processor | FQIS | 28-41 |
| Ground Proximity Warning Computer | GPWC | 34-46 |
| HF (High Frequency) Communication | | 23-11 |
| Inertial Reference Unit | IRU | 34-21 |
| Instrument Comparator Unit | ICU | 34-25 |
| Instrument Landing System Receiver | ILS | 34-31 |
| Lower Cargo Compartment Smoke Detection System | | 26-16 |
| Maintenance Control Display Panel | MCDP | 22-00 |
| PA (Passenger Address) Amplifier | | 23-31 |
| Pack Standby Temperature Controller | | 21-51 |
| Pack Temperature Controller | | 21-51 |
| Passenger Entertainment System | PES | 23-34 |
| Power Supply Module (Control System Electronics Units) | PSM | 27-09 |
| Propulsion Discrete Interface Unit (PW Engines) | PDIU | 73-21 |
| Proximity Switch Electronics Unit | PSEU | 32-09 |
| Radio Altimeter Transmitter/Receiver | RA | 34-33 |
| Rudder Ratio Changer Module | RRCM | 27-09 |
| Spoiler Control Module | SCM | 27-09 |
| Stabilizer Position Module | SPM | 27-48 |
| Stabilizer Trim/Elevator Asymmetry Limit Module | SAM | 27-09 |
| Stall Warning Computer/Module (in Warning Electronic Unit) | SWC | 27-32 |
| Strut Overheat Detection System (RR Engines) | | 26-12 |

Bite Index
Figure 1 (Sheet 2)




52-BITE INDEX


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

| <u>LRU/System Name</u> | <u>Acronym</u> | <u>FIM Reference</u> |
|---|----------------|----------------------|
| Thrust Management Computer/Autothrottle | TMC | 22-00 |
| Traffic Alert and Collision Avoidance Computer | TCAS | 34-45 |
| VHF (Very High Frequency) Communication | | 23-12 |
| VOR/Marker Beacon Receiver | VOR/MKR | 34-51 |
| Warning Electronic Unit BITE Module (Stall Warning) | WEU | 27-32 |
| Weather Radar Transceiver | WXR | 34-43 |
| Wheel Well Fire Detection | | 26-17 |
| Window Heat Control Unit | WHCU | 30-41 |
| Yaw Damper Module | YDM | 22-21 |
| Yaw Damper/Stabilizer Trim Module | YSM | 27-09 |
| Zone Temperature Controller | | 21-60 |

Bite Index
Figure 1 (Sheet 3)



52-BITE INDEX

01

Page 3
Sep 28/99

BOEING
757
FAULT ISOLATION/MAINT MANUAL

PASSENGER DOORS

| COMPONENT | FIG. 102 SHT | QTY | ACCESS/AREA | REFERENCE |
|---|--------------------|-----|---|-----------|
| ACTUATOR - EMERGENCY POWER | 7 | 6 | | |
| DOOR NO. 1 LEFT | | | 221AL | 52-11-31 |
| DOOR NO. 1 RIGHT | | | 222AR | 52-11-31 |
| DOOR NO. 2 LEFT | | | 231AL | 52-11-34 |
| DOOR NO. 2 RIGHT | | | 232AR | 52-11-34 |
| DOOR NO. 4 LEFT | | | 251AL | 52-11-35 |
| DOOR NO. 4 RIGHT | | | 252AR | 52-11-35 |
| ARM - GUIDE | 3,4 | 6 | BOTTOM OF THE BODY HINGE TORQUE TUBES | 52-11-04 |
| ARMS - HINGE | 3,4 | 12 | TOP AND BOTTOM OF THE DOOR HINGE TORQUE TUBES | 52-11-00 |
| CHAIN - EMERGENCY POWER | 4,7 | 6 | EMERGENCY POWER ACTUATOR | |
| DOOR NO. 1 LEFT AND DOOR NO. 1 RIGHT | | | | 52-11-31 |
| DOOR NO. 2 LEFT AND DOOR NO. 2 RIGHT | | | | 52-11-34 |
| DOOR NO. 4 LEFT AND DOOR NO. 4 RIGHT | | | | 52-11-35 |
| COUNTERBALANCE - CAMSHAFT/SPRING CYLINDER | 4 | 6 | BODY HINGE TORQUE TUBE | 52-11-11 |
| DOOR - PASSENGER | 1 | 6 | | 52-11-01 |
| NO. 1 LEFT | | | 831 | |
| NO. 1 RIGHT | | | 841 | |
| NO. 2 LEFT | | | 832 | |
| NO. 2 RIGHT | | | 842 | |
| NO. 4 LEFT | | | 834 | |
| NO. 4 RIGHT | | | 844 | |
| LINING - DOOR | 2 | 6 | ALL PASSENGER DOORS | 52-11-02 |
| LOCK - HOLD OPEN | 4 | 6 | BODY HINGE TORQUE TUBES | 52-11-00 |
| MECHANISM - DOOR EMERGENCY | 5,6 | 6 | ALL PASSENGER DOORS | 52-11-20 |
| MECHANISM - DOOR HANDLE | 5,6 | 6 | ALL PASSENGER DOORS | 52-11-13 |
| MECHANISM - GIRT BAR | 5,6 | 6 | ALL PASSENGER DOORS | 52-11-25 |
| RESERVOIR - EMERGENCY POWER | 7 | 6 | | 52-11-30 |
| DOOR NO. 1 LEFT AND DOOR NO. 1 RIGHT | | | ABOVE ACCESS PANEL IN THE CEILING BETWEEN THE DOORS | |
| DOOR NO. 2 LEFT AND DOOR NO. 2 RIGHT | | | ABOVE PASSENGER SERVICE UNIT | |
| DOOR NO. 4 LEFT AND DOOR NO. 4 RIGHT | | | ABOVE EACH DOOR | |
| | | | ABOVE ACCESS PANEL IN THE CEILING | |
| | | | ABOVE EACH DOOR | |
| SNUBBER - ROTARY | 4 | 6 | BODY HINGE TORQUE TUBE | 52-11-10 |
| SPRING CYLINDER - EMERGENCY POWER | 7 | 6 | EMERGENCY POWER RESERVOIR | 52-11-33 |
| TORQUE TUBE - BODY | 4 | 6 | FUSELAGE STRUCTURE FORWARD OF THE DOOR | 52-11-00 |
| TORQUE TUBE - LATCH | 3 | 12 | TWO ON EACH PASSENGER DOOR | 52-11-00 |
| TORQUE TUBE - DOOR | 3 | 6 | ALL PASSENGER DOORS | 52-11-00 |
| TRIGGER - EMERGENCY POWER | 3 | 6 | BODY HINGE TORQUE TUBE | 52-11-32 |

Passenger Doors - Component Index
Figure 101

EFFECTIVITY



ALL

52-11-00

02

Page 101
Jun 20/91


BOEING
757
FAULT ISOLATION/MAINT MANUAL



Passenger Doors - Component Location
Figure 102 (Sheet 1)


| | |
|-------------|-----|
| EFFECTIVITY | ALL |
|-------------|-----|

52-11-00



NO. 1, 2, OR 4 PASSENGER DOOR
(INTERNAL MECHANISMS)
(EXAMPLE)

(A)



NO. 1, 2 OR 4 PASSENGER DOOR
(INTERNAL VIEW)
(EXAMPLE)

(A)

Passenger Doors - Component Location (Detail from Sht 1)
Figure 102 (Sheet 2)


EFFECTIVITY

ALL

52-11-00

01

Page 103
Jun 20/91




Passenger Doors - Component Location (Details from Sht 2)
Figure 102 (Sheet 3)

| | |
|-------------|-----|
| EFFECTIVITY | |
| | ALL |

52-11-00

BOEING
757
FAULT ISOLATION/MAINT MANUAL




Passenger Doors - Component Location (Detail from Sht 2)
Figure 102 (Sheet 4)

| | |
|-------------|-----|
| EFFECTIVITY | |
| | ALL |


52-11-00

02

Page 105
Jun 20/91




NO. 1 PASSENGER DOOR EMERGENCY MECHANISM (EXAMPLE)





Passenger Doors - Component Location
Figure 102 (Sheet 5)

| | |
|-------------|-----|
| EFFECTIVITY | |
| | ALL |


52-11-00



NO. 4 PASSENGER DOOR EMERGENCY MECHANISM
(EXAMPLE)



NO. 2 PASSENGER DOOR EMERGENCY MECHANISM
(EXAMPLE)




Passenger Doors - Component Location
Figure 102 (Sheet 6)

| | |
|-------------|-----|
| EFFECTIVITY | ALL |
|-------------|-----|

52-11-00

BOEING
757
FAULT ISOLATION/MAINT MANUAL




Passenger Doors - Component Location
Figure 102 (Sheet 7)

| | |
|-------------|-----|
| EFFECTIVITY | |
| | ALL |

52-11-00

**GUIDELINES FOR
GENERAL DOOR FAULT
ISOLATION**

PREREQUISITES:
NONE




General Guidelines for Door Fault Isolation
Figure 103 (Sheet 1)

EFFECTIVITY

| |
|-----|
| ALL |
|-----|


52-11-00



General Guidelines for Door Fault Isolation
Figure 103 (Sheet 2)

EFFECTIVITY _____
ALL

52-11-00



1

Door Adjustments (Example)
Figure 104

| | |
|-------------|-----|
| EFFECTIVITY | |
| | ALL |


52-11-00

01


Page 111
Jan 20/98

H01959


BOEING
757
FAULT ISOLATION/MAINT MANUAL




1. ARMED AND LATCHED




2. DOOR NOT LATCHED - UPPER AND LOWER GATES FOLDED IN - MOTION TO COCK BEGINS



3. DOOR FULLY COCKED - READY TO BE OPENED



4. DOOR NOT FULLY OPEN



5. DOOR FULLY OPEN

1 YOU CAN USE THE ASSIST HANDLE TO PULL THE DOOR TO THE COCKED POSITION.

Passenger Door Cycles
Figure 105

| | |
|-------------|-----|
| EFFECTIVITY | ALL |
|-------------|-----|

52-11-00

01

Page 112
Jan 20/98

HD1869


PREREQUISITES
NONE

WARNING: THIS CHART GIVES GENERAL DATA TO POINT THE USER TO THE PROBLEM DOOR CYCLE. MAKE SURE THAT A COMPONENT IS DEFECTIVE BEFORE YOU REPLACE IT.

NOTE: GREATER THAN NORMAL WORN AREAS SHOW:
 • INCORRECT DOOR RIGGING
 • WORN TORQUE TUBE BEARINGS
 • WORN GUIDE ARM BEARINGS

WEAR IS FOUND ON THE LATCH FITTINGS


NOTE: REPLACEMENT OF WORN PARTS WILL OCCUR IN ANOTHER PROCEDURE.




Wear Is Found on the Latch Fittings
Figure 106

EFFECTIVITY ————
ALL


52-11-00



NO. 1, 2, OR 4 PASSENGER DOOR



LATCH FITTING
(ON FUSELAGE)
(A)



DOOR FRAME

1 WEAR IN THIS AREA INDICATES THAT THE DOOR IS NOT ADJUSTED CORRECTLY

Upper Latch Fitting Wear
Figure 107


| | |
|-------------|-----|
| EFFECTIVITY | ALL |
|-------------|-----|

52-11-00

HO2126

DOOR IS DIFFICULT TO LATCH/UNLATCH

PREREQUISITES
NONE



Door Is Difficult to Latch/Unlatch
Figure 108 (Sheet 1)


EFFECTIVITY

| |
|-----|
| ALL |
|-----|

52-11-00

H03777

FROM SHEET 1
(BLOCK 4)



Door Is Difficult to Latch/Unlatch
Figure 108 (Sheet 2)

EFFECTIVITY


ALL

52-11-00

01

Page 116
Sep 28/99

HD3779



Latch/Unlatch Components
Figure 109 (Sheet 1)


| | |
|-------------|-----|
| EFFECTIVITY | |
| | ALL |

52-11-00

01


Page 117
Jan 20/98

HD1966




- NOTE:** TURN THE ADJUSTMENT NUT TO CHANGE THE LENGTH OF THE GUIDE ARM:
- MAKE THE ARM SHORTER TO MOVE THE AFT EDGE OF THE DOOR INBOARD.
 - MAKE THE ARM LONGER TO MOVE THE AFT EDGE OF THE DOOR OUTBOARD.
 - THE SERRATED PLATE ADJUSTMENTS GIVES THE GREATEST AMOUNT OF ADJUSTMENT.

**DOOR ADJUSTMENT
(TOP VIEW)**




- NOTE:** IF YOU MAKE THE PUSHROD LONGER, YOU WILL MOVE THE DOOR OUTBOARD. THE EXTERNAL HANDLE FORCE INCREASES AS YOU ADJUST THE DOOR OUTBOARD.

**HANDLE ADJUSTMENT
(TOP VIEW)**




Latch/Unlatch Components
Figure 109 (Sheet 2)



52-11-00

DOOR IS DIFFICULT TO COCK

PREREQUISITES
NONE




Door Is Difficult to Cock
Figure 110

EFFECTIVITY

| |
|-----|
| ALL |
|-----|

52-11-00



NO. 1, 2, OR 4 PASSENGER DOOR
(EXAMPLE)


Cocking Components
Figure 111

| | |
|-------------|-----|
| EFFECTIVITY | ALL |
|-------------|-----|

52-11-00

DOOR IS DIFFICULT TO CLOSE/OPEN

PREREQUISITES
NONE



Door Is Difficult to Close/Open
Figure 112 (Sheet 1)

EFFECTIVITY ————
ALL

52-11-00


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FROM SHEET 1
(BLOCK 5)

NO

6 EXAMINE THE DOOR
CLOSE/OPEN MECHANISMS FOR
CORRECT OPERATION.

7 MOVE THE DOOR FULL OPEN.
DOES THE HOLD-OPEN LOCK
FAIL TO HOLD THE DOOR OPEN OR
IS IT DIFFICULT TO RELEASE?

YES

13 LOOK AT THE HOLD-OPEN LOCK
MECHANISM.
IS THE HOLD-OPEN LOCK
HOOK, OR LIFT LEVER AND SHELF
BROKEN?

YES

27 REMOVE AND REPLACE THE
BROKEN PARTS
(AMM 52-11-08/401).

NO

28 LUBRICATE THE HOLD-OPEN
LOCK HOOK SPRING AND SHAFT.

Door Is Difficult to Close/Open
Figure 112 (Sheet 2)

EFFECTIVITY


ALL

52-11-00

01

Page 122
May 28/99

H10260



Close/Open Components
Figure 113

EFFECTIVITY

ALL


52-11-00

01

Page 123
Jan 20/98

DOOR IS DIFFICULT TO ARM/DISARM

PREREQUISITES
NONE




Door Is Difficult to Arm/Disarm
Figure 114


EFFECTIVITY

| |
|-----|
| ALL |
|-----|

52-11-00




**NO. 1 OR 4 PASSENGER DOOR
(LEFT DOOR IS SHOWN, RIGHT DOOR IS OPPOSITE)**



CRANK STOP

(B)




GIRT BAR MECHANISM

(A)

**Arm/Disarm Components
Figure 115 (Sheet 1)**

| | |
|-------------|-----|
| EFFECTIVITY | ALL |
| | |

52-11-00




Arm/Disarm Components
Figure 115 (Sheet 2)

| | |
|-------------|-----|
| EFFECTIVITY | ALL |
|-------------|-----|

52-11-00

EMERGENCY POWER ASSIST SYSTEM (EPAS) IS DIFFICULT TO ADJUST

PREREQUISITES
NONE



Emergency Power Assist System (EPAS) Is Difficult to Adjust
Figure 116 (Sheet 1)

EFFECTIVITY


ALL

52-11-00


01

Page 127
Sep 20/98

HD4006




Emergency Power Assist System (EPAS) Is Difficult to Adjust
Figure 116 (Sheet 2)



52-11-00

BOEING
757
FAULT ISOLATION/MAINT MANUAL



EMERGENCY POWER SYSTEM

1 THE ARROWS SHOW THE DIRECTION OF MOVEMENT DURING EMERGENCY OPERATION.

EPAS Components
Figure 117

| | |
|-------------|-----|
| EFFECTIVITY | ALL |
|-------------|-----|

52-11-00

01

Page 129
Jan 20/98


HO2216


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

NO. 3 EMERGENCY EXIT

| COMPONENT | FIG. 102 SHT | QTY | ACCESS/AREA | AMM REFERENCE |
|-------------------------------|--------------------|-----|--|------------------|
| BUTTON - RELEASE | 2 | 4 | TWO ON EACH EXIT | 52-21-00 |
| DOOR - PRESSURE RELIEF | 2 | 2 | EMERGENCY EXIT | 52-21-00 |
| EXIT - NO. 3 EMERGENCY | 1 | 2 | | 52-21-01 |
| LEFT | | | 835 | |
| RIGHT | | | 845 | |
| FITTING - STOP | 2 | 20 | FORWARD AND AFT EDGES OF EMERGENCY EXIT | 52-21-00 |
| HANDLE - INTERIOR | 1 | 2 | INTERIOR OF EMERGENCY EXIT | 52-21-00 |
| LINING - NO. 3 EMERGENCY EXIT | 1 | 2 | INTERIOR OF EMERGENCY EXIT | 52-21-02 |
| SNUBBER | 2 | 4 | EMERGENCY EXIT HINGES | 52-21-00 |

No. 3 Emergency Exit - Component Index
Figure 101





52-21-00

01

Page 101
Sep 20/94

E44899

BOEING
 757
 FAULT ISOLATION/MAINT MANUAL




INSIDE VIEW OF NO. 3 EMERGENCY EXIT

(A)


No. 3 Emergency Exit - Component Location
 Figure 102 (Sheet 1)

| | |
|-------------|-----|
| EFFECTIVITY | |
| | ALL |

52-21-00



**NO. 3 EMERGENCY EXIT
(SHOWN WITH LINING AND ESCAPE SLIDE REMOVED)**



**Component Location
Figure 102 (Sheet 2)**

| | |
|-------------|-----|
| EFFECTIVITY | |
| | ALL |

52-21-00

01

Page 103
Sep 20/94

54721

BOEING
757
FAULT ISOLATION/MAINT MANUAL

NO. 1 AND 2 CARGO DOORS

| COMPONENT | FIG. 102 SHT | QTY | ACCESS/AREA | REFERENCE |
|--|--------------|-----|-----------------------------------|-----------|
| ACTUATOR - ROTARY, HINGE DRIVE | 2 | 4 | CEILING, ABOVE CARGO DOOR | 52-34-06 |
| ARM - HINGE | 2 | 4 | CARGO DOOR | |
| CIRCUIT BREAKERS | | | 119BL, MAIN EQUIP CTR, P34 | * |
| CARGO DOOR CONT, C1403 | | 1 | 34A5 | * |
| NO. 1 CARGO DOOR, C360 | | 1 | 34A1 | * |
| NO. 2 CARGO DOOR, C361 | | 1 | 34A2 | * |
| DOOR - CARGO, NO. 1 | 1 | 1 | 821 | 52-34-01 |
| DOOR - CARGO, NO. 2 | 1 | 1 | 822 | 52-34-01 |
| GEARBOX - MANUAL DRIVE | 2 | 2 | FUSELAGE, FWD OF CARGO DOOR | 52-34-03 |
| HANDLE MECHANISM | 2 | 2 | CARGO DOOR | 52-34-22 |
| HINGE LINKAGE | 2 | 4 | CARGO DOOR | 52-34-09 |
| POWER UNIT - HINGE DRIVE | 2 | 2 | CEILING, ABOVE CARGO DOOR | 52-34-05 |
| RELAY - (REF 31-01-65, FIG. 101) | | | | |
| PDU RAISE RELAY, K10411 | | | | |
| PDU LOWER RELAY, K10412 | | | | |
| RELAY - (REF 31-01-86, FIG. 101) | | | | |
| PDU RAISE RELAY, K10413 | | | | |
| PDU LOWER RELAY, K10414 | | | | |
| SENSORS - NO. 1 CARGO DOOR, PROXIMITY | | | | |
| OPEN A, S10350 | 1 | 1 | 821, FUSELAGE FRAME AT CARGO DOOR | 52-34-35 |
| DOWN A, S10352 | 1 | 1 | 821, FUSELAGE FRAME AT CARGO DOOR | 52-34-35 |
| SENSORS - NO. 2 CARGO DOOR, PROXIMITY | | | | |
| OPEN A, S10357 | 1 | 1 | 822, FUSELAGE FRAME AT CARGO DOOR | 52-34-35 |
| DOWN A, S10359 | 1 | 1 | 822, FUSELAGE FRAME AT CARGO DOOR | 52-34-35 |
| SWITCH - NO. 1 CARGO DOOR, CONTROL | | | | |
| EXTERIOR, S10183 | 1 | 1 | 122AR, P43, AFT OF CARGO DOOR | 52-34-30 |
| INTERIOR, S10180 | 1 | 1 | 821, P41, FWD CARGO COMPT CEILING | 52-34-30 |
| SWITCH - NO. 2 CARGO DOOR, CONTROL | | | | |
| EXTERIOR, S10182 | 1 | 1 | 154AR, P44, AFT OF CARGO DOOR | 52-34-30 |
| INTERIOR, S10181 | 1 | 1 | 822, P42, AFT CARGO COMPT CEILING | 52-34-30 |
| SWITCH - NO. 1 CARGO DOOR, INTERLOCK, S10561 | 1 | 1 | 821, INSIDE CARGO DOOR | * |
| SWITCH - NO. 2 CARGO DOOR, INTERLOCK, S10562 | 1 | 1 | 822, INSIDE CARGO DOOR | * |
| TRACK - LATCH | 1 | 4 | FUSELAGE FRAME AT CARGO DOOR | 52-34-19 |

* SEE WDM EQUIPMENT LIST

No. 1 and 2 Cargo Doors - Component Index
Figure 101

EFFECTIVITY



ALL

52-34-00

BOEING

757

FAULT ISOLATION/MAINT MANUAL




INTERIOR
NO. 1 OR 2 CARGO
DOOR CONTROL SWITCH,
S10180 OR S10181

EXTERIOR
NO. 1 OR 2 CARGO
DOOR CONTROL SWITCH,
S10182 OR S10183

INTERNAL CARGO DOOR CONTROL
PANEL, P41 OR P42

(B)



EXTERNAL CARGO DOOR CONTROL
PANEL, P43 OR P44


(C)

No. 1 and 2 Cargo Doors - Component Location
Figure 102 (Sheet 1)

EFFECTIVITY


ALL

52-34-00



HINGE LINK

(D)



**NO. 1 OR 2 CARGO DOOR
(CLOSED POSITION)**

(E)

No. 1 and 2 Cargo Doors - Component Location (Details from Sht 1)
Figure 102 (Sheet 2)

EFFECTIVITY



ALL

52-34-00

02

Page 103
Dec 20/95


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL



No. 1 and 2 Cargo Doors - Component Location
Figure 102 (Sheet 3)

| | |
|-------------|-----|
| EFFECTIVITY | ALL |
|-------------|-----|

52-34-00

01

Page 104
Dec 20/95

107768

NO. 1 AND NO. 2 CARGO DOOR – FAULT ISOLATION

1. General

A. This procedure contains the trouble-shooting for the No. 1 and the No. 2 cargo doors. It has figures that contain the trouble-shooting procedures for specific cargo door failures. It also contains a fault isolation tip if a failure in another system affects the cargo doors.

2. Fault Isolation Tip

A. During ground operation it is possible for a protective feature in the ground power system to operate. This will cause the ground power system to fail to supply power to the cargo doors. Any one of these steps will reset the ground power system:

- (1) Remove and re-apply electrical power from the ground power system (AMM 24-22-00/201).
- (2) Depress the ground service switch on the forward flight attendants panel.
- (3) Remove and re-install the ground power plug in the external receptacle.

B. If the problem remains do the bite test of the bus power control unit (BPCU) found in chapter 24-3 of the 757 BITE manual.

EFFECTIVITY

ALL

52-34-00

01


Page 105
Dec 20/95

NO. 1 (FWD) CARGO DOOR WILL NOT OPEN ELECTRICALLY. MANUAL OPERATION WAS NORMAL.

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
34A1, 34A5

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)
DOOR IS CLOSED BUT NOT LATCHED




No. 1 (Fwd) Cargo Door Will Not Open Electrically. Manual Operation Was Normal.
Figure 103 (Sheet 1)

EFFECTIVITY

| |
|-----|
| ALL |
|-----|

52-34-00

 **BOEING**
757
FAULT ISOLATION/MAINT MANUAL



No. 1 (Fwd) Cargo Door Will Not Open Electrically. Manual Operation was Normal.
Figure 103 (Sheet 2)

EFFECTIVITY

ALL


52-34-00

03

Page 107
May 28/07

BOEING
757
FAULT ISOLATION/MAINT MANUAL

FROM SHEET 2
(BLOCK 12)




No. 1 (Fwd) Cargo Door Will Not Open Electrically. Manual Operation was Normal.
Figure 103 (Sheet 3)


EFFECTIVITY

| |
|-----|
| ALL |
|-----|

52-34-00



No. 1 (Fwd) Cargo Door Will Not Open Electrically. Manual Operation was Normal.
Figure 103 (Sheet 4)




52-34-00

**NO. 2 (AFT) CARGO
 DOOR FAILED TO OPEN
 ELECTRICALLY.
 MANUAL OPERATION
 WAS NORMAL.**

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
34A2, 34A5


MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201).
DOOR IS CLOSED BUT NOT LATCHED



No. 2 (Aft) Cargo Door Failed to Open Electrically. Manual Operation Was Normal.
 Figure 104 (Sheet 1)

| | |
|-------------|-----|
| EFFECTIVITY | |
| | ALL |

52-34-00



No. 2 (Aft) Cargo Door Failed to Open Electrically. Manual Operation was Normal.
Figure 104 (Sheet 2)


EFFECTIVITY

ALL

52-34-00

04

Page 111
May 28/07


FROM SHEET 2
(BLOCK 12)


No. 2 (Aft) Cargo Door Failed to Open Electrically. Manual Operation was Normal.
Figure 104 (Sheet 3)


EFFECTIVITY

ALL

52-34-00



No. 2 (Aft) Cargo Door Failed to Open Electrically. Manual Operation was Normal.
Figure 104 (Sheet 4)




52-34-00

**NO. 1 (FWD) CARGO
DOOR FAILED TO CLOSE
ELECTRICALLY.
MANUAL OPERATION
WAS NORMAL.**

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
34A1,34A5

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)
CARGO DOOR IS OPEN



No. 1 (Fwd) Cargo Door Failed to Close Electrically. Manual Operation was Normal.
Figure 105 (Sheet 1)


EFFECTIVITY

ALL

52-34-00

03

Page 114
Sep 20/94



No. 1 (Fwd) Cargo Door Failed to Close Electrically. Manual Operation was Normal.
Figure 105 (Sheet 2)

EFFECTIVITY


| |
|-----|
| ALL |
|-----|

52-34-00

BOEING
757
FAULT ISOLATION/MAINT MANUAL

FROM SHEET 2
(BLOCK 4)

FROM SHEET 2
(BLOCK 13)



No. 1 (Fwd) Cargo Door Failed to Close Electrically. Manual Operation was Normal.
Figure 105 (Sheet 3)

EFFECTIVITY

ALL

52-34-00

03

Page 116
May 28/07


248184

**NO. 2 (AFT) CARGO
DOOR FAILED TO
CLOSE ELECTRICALLY.
MANUAL OPERATION
WAS NORMAL.**

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
34A1,34A5

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)
CARGO DOOR IS OPEN



No. 2 (Aft) Cargo Door Failed to Close Electrically. Manual Operation was Normal.
Figure 106 (Sheet 1)


EFFECTIVITY

ALL

52-34-00

03

Page 117
Sep 20/94



No. 2 (Aft) Cargo Door Failed to Close Electrically. Manual Operation was Normal. Figure 106 (Sheet 2)

EFFECTIVITY


| |
|-----|
| ALL |
|-----|

52-34-00

BOEING
757
FAULT ISOLATION/MAINT MANUAL

FROM SHEET 2
(BLOCK 4)

FROM SHEET 4
(BLOCK 13)



No. 2 (Aft) Cargo Door Failed to Close Electrically. Manual Operation was Normal.
Figure 106 (Sheet 3)

EFFECTIVITY

| |
|-----|
| ALL |
|-----|


52-34-00

NO. 1 (FWD) CARGO DOOR FAILED TO OPEN OR CLOSE ELECTRICALLY. MANUAL OPERATION WAS NORMAL.

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
34A1, 34A5


MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)
DOOR IS CLOSED BUT NOT LATCHED



No. 1 (Fwd) Cargo Door Failed to Open or Close Electrically.
Manual Operation was Normal.
Figure 107 (Sheet 1)

| | |
|-------------|-----|
| EFFECTIVITY | ALL |
|-------------|-----|

52-34-00



No. 1 (Fwd) Cargo Door Failed to Open or Close Electrically.
 Manual Operation was Normal.
 Figure 107 (Sheet 2)

EFFECTIVITY


ALL

52-34-00

04

Page 121
May 28/07

BOEING
757
FAULT ISOLATION/MAINT MANUAL



No. 1 (Fwd) Cargo Door Failed to Open or Close Electrically.
Manual Operation was Normal.
Figure 107 (Sheet 3)

| | |
|-------------|-----|
| EFFECTIVITY | ALL |
|-------------|-----|

52-34-00

BOEING
757
FAULT ISOLATION/MAINT MANUAL

FROM SHEET 2
(BLOCK 6)

FROM SHEET 3
(BLOCK 14)

NO

YES

15 WITH THE INTERIOR CARGO DOOR CONTROL SWITCH, S10180, IN THE "OPEN" POSITION, PUT A JUMPER AND DO A CHECK FOR 28V DC ON CONNECTOR D4806 BETWEEN PIN X1 AND PIN X2 (WDM 52-34-11).
IS THERE 28V DC BETWEEN THE PINS?

YES

29 REPLACE THE HINGE POWER UNIT RAISE RELAY, K10411 (WDM 52-34-11).
INSTALL CONNECTOR D4806 ON THE HINGE POWER UNIT RAISE RELAY, K10411.
MAKE SURE THE CARGO DOOR OPENS AND CLOSES ELECTRICALLY (AMM 52-34-00/201).

NO

30 DO A CHECK AND REPLACE THE CARGO DOOR MOTOR INTERLOCK SWITCH, S10561 (WDM 52-34-11).
IF THE PROBLEM CONTINUES, EXAMINE THE CIRCUIT FROM THE CARGO DOOR MOTOR INTERLOCK SWITCH, S10561, PIN 2, TO THE INTERIOR CARGO DOOR CONTROL SWITCH, S10180, PIN 1 (WDM 52-34-11).
REPAIR THE PROBLEMS THAT YOU FIND.
IF THE PROBLEM CONTINUES, EXAMINE THE CIRCUIT FROM THE CARGO DOOR MOTOR INTERLOCK SWITCH, S10561, PIN 1 TO THE HINGE POWER UNIT RAISE RELAY, K10411, PIN X1 (WDM 52-34-11).
REPAIR THE PROBLEMS THAT YOU FIND.
MAKE SURE THE CARGO DOOR OPENS AND CLOSES ELECTRICALLY (AMM 52-34-00/201).

NO

31 EXAMINE THE CIRCUIT FROM THE HINGE POWER UNIT LOWER RELAY, K10412, PINS A2, B2, C2, TO THE P34 APU/EXTERNAL POWER PANEL, CONNECTOR D40080P, PINS 1, 2, 3 (WDM 52-34-11).
REPAIR THE PROBLEMS THAT YOU FIND.
INSTALL CONNECTOR D4808 ON THE HINGE POWER UNIT LOWER RELAY, K10412.
MAKE SURE THE CARGO DOOR OPENS AND CLOSES ELECTRICALLY (AMM 52-34-00/201).

No. 1 (Fwd) Cargo Door Failed to Open or Close Electrically.
Manual Operation was Normal.
Figure 107 (Sheet 4)

EFFECTIVITY

ALL


52-34-00

**NO. 2 (AFT) CARGO DOOR
FAILED TO OPEN OR
CLOSE ELECTRICALLY.
MANUAL OPERATION WAS
NORMAL.**

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
34A2, 34A5

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)
DOOR IS CLOSED BUT NOT LATCHED



No. 2 (Aft) Cargo Door Failed to Open or Close Electrically.
Manual Operation was Normal.
Figure 108 (Sheet 1)


EFFECTIVITY

ALL

52-34-00

03

Page 124
May 28/07



No. 2 (Aft) Cargo Door Failed to Open or Close Electrically.
Manual Operation was Normal.
Figure 108 (Sheet 2)

EFFECTIVITY


ALL

52-34-00

04

Page 125
May 28/07

BOEING
757
FAULT ISOLATION/MAINT MANUAL



No. 2 (Aft) Cargo Door Failed to Open or Close Electrically.
Manual Operation was Normal.
Figure 108 (Sheet 3)

| | |
|-------------|-----|
| EFFECTIVITY | ALL |
|-------------|-----|

52-34-00

BOEING
757
FAULT ISOLATION/MAINT MANUAL

FROM SHEET 2
(BLOCK 6)

FROM SHEET 3
(BLOCK 14)

NO

YES

15 WITH THE INTERIOR CARGO DOOR CONTROL SWITCH, S10181, IN THE "OPEN" POSITION, PUT A JUMPER AND DO A CHECK FOR 28V DC ON CONNECTOR D4810 BETWEEN PIN X1 AND PIN X2 (WDM 52-35-11).
IS THERE 28V DC BETWEEN THE PINS?

YES

29 REPLACE THE HINGE POWER UNIT RAISE RELAY, K10413 (WDM 52-35-11).
INSTALL CONNECTOR D4810 ON THE HINGE POWER UNIT RAISE RELAY, K10413.
MAKE SURE THE CARGO DOOR OPENS AND CLOSES ELECTRICALLY (AMM 52-34-00/201).

NO

30 DO A CHECK AND REPLACE THE CARGO DOOR MOTOR INTERLOCK SWITCH, S10562 (WDM 52-35-11).
IF THE PROBLEM CONTINUES, EXAMINE THE CIRCUIT FROM THE CARGO DOOR MOTOR INTERLOCK SWITCH, S10562, PIN 2, TO THE INTERIOR CARGO DOOR CONTROL SWITCH, S10181, PIN 1 (WDM 52-35-11).
REPAIR THE PROBLEMS THAT YOU FIND.
IF THE PROBLEM CONTINUES, EXAMINE THE CIRCUIT FROM THE CARGO DOOR MOTOR INTERLOCK SWITCH, S10562, PIN 1, TO THE HINGE POWER UNIT RAISE RELAY, K10413, PIN X1 (WDM 52-35-11).
REPAIR THE PROBLEMS THAT YOU FIND.
MAKE SURE THE CARGO DOOR OPENS AND CLOSES ELECTRICALLY (AMM 52-34-00/201).

31 EXAMINE THE CIRCUIT FROM THE HINGE POWER UNIT LOWER RELAY, K10414, PINS A2, B2, C2, TO THE P34 APU/EXTERNAL POWER PANEL, CONNECTOR D40188P, PINS 4, 7, 10 (WDM 52-35-11).
REPAIR THE PROBLEMS THAT YOU FIND.
INSTALL CONNECTOR D4812 ON THE HINGE POWER UNIT LOWER RELAY, K10414.
MAKE SURE THE CARGO DOOR OPENS AND CLOSES ELECTRICALLY (AMM 52-34-00/201).

No. 2 (Aft) Cargo Door Failed to Open or Close Electrically.
Manual Operation was Normal.
Figure 108 (Sheet 4)

EFFECTIVITY

ALL

52-34-00

11

Page 127
May 28/07

335947

NO. 1 OR NO. 2
 CARGO DOOR FAILED
 TO OPEN OR CLOSE
 ELECTRICALLY OR
 MANUALLY.

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:


- NO. 1 CARGO DOOR, 34A1 AND 34A5
- NO. 2 CARGO DOOR, 34A2 AND 34A5

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:

- NO. 1 OR 2 CARGO DOOR IS NOT LATCHED

EQUIPMENT:


- CARGO DOOR SLING B52016-1



No. 1 or No. 2 Cargo Door Failed to Open or Close
 Electrically or Manually.
 Figure 109 (Sheet 1)

| | |
|-------------|-----|
| EFFECTIVITY | ALL |
|-------------|-----|

52-34-00



No. 1 or No. 2 Cargo Door Failed to Open or Close
 Electrically or Manually.
 Figure 109 (Sheet 2)

EFFECTIVITY

| |
|-----|
| ALL |
|-----|

52-34-00

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:

- NO. 1 CARGO DOOR, 34A1 AND 34A5
- NO. 2 CARGO DOOR, 34A2 AND 34A5


MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:

- NO. 1 OR 2 CARGO DOOR IS NOT LATCHED

EQUIPMENT:

- CARGO DOOR SLING B52016-1

**NO. 1 OR NO. 2
CARGO DOOR OPENS
AND CLOSES TOO
SLOWLY**



No. 1 or No. 2 Cargo Door Opens and Closes too Slowly
Figure 110 (Sheet 1)


EFFECTIVITY

ALL


52-34-00

02

Page 130
Sep 20/94




No. 1 or No. 2 Cargo Door Opens and Closes too Slowly
Figure 110 (Sheet 2)



52-34-00

NO. 1 (FWD) OR NO. 2 (AFT) CARGO DOOR BINDING WHEN (UNLOCKING, LOCKING, LOCKING AND UNLOCKING)


| |
|------------------------------|
| PREREQUISITES NONE |
|------------------------------|



No. 1 (Fwd) or No. 2 (Aft) Cargo Door Binding When (Unlocking, Locking, Locking and Unlocking)
 Figure 111 (Sheet 1)

EFFECTIVITY
 ALL

52-34-00



No. 1 (Fwd) or No. 2 (Aft) Cargo Door Binding When (Unlocking, Locking,
 Locking and Unlocking)
 Figure 111 (Sheet 2)

| | |
|-------------|-----|
| EFFECTIVITY | ALL |
|-------------|-----|

52-34-00

**NO. 1 OR NO. 2 CARGO
DOOR OVERTRAVELS
DURING CLOSING
(SLAMS SHUT)**


PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:

- NO. 1 CARGO DOOR, 34A1 AND 34A5
- NO. 2 CARGO DOOR, 34A2 AND 34A5

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:

- ELECTRICAL POWER IS ON (MM 24-22-00/201)



No. 1 or No. 2 Cargo Door Overtravels During Closing (Slams Shut)
Figure 112

| | |
|-------------|-----|
| EFFECTIVITY | ALL |
|-------------|-----|

52-34-00


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

NO. 3 CARGO DOOR

| COMPONENT | FIG. 102 SHT | QTY | ACCESS/AREA | REFERENCE |
|---|--------------------|-----|----------------------------|-----------|
| ARM - HINGE | --- | 2 | 823, AFT CARGO COMPARTMENT | 52-36-12 |
| DOOR - NO. 3 CARGO | --- | 1 | 823, AFT CARGO COMPARTMENT | 52-36-01 |
| MECHANISM - COUNTERBALANCE | --- | 1 | 823, AFT CARGO COMPARTMENT | 52-36-15 |
| MECHANISM - DOOR LATCHING | --- | 1 | 823, AFT CARGO COMPARTMENT | 52-36-00 |
| SENSOR - PROXIMITY NO. 3 CARGO DOOR WARNING, S10089 (REF 52-71-00, FIG. 101) | --- | 1 | | |
| SNUBBER - DOOR | --- | 1 | 823, AFT CARGO COMPARTMENT | 52-36-13 |



* SEE THE WDM EQUIPMENT LIST

No. 3 Cargo Door - Component Index
Figure 101

EFFECTIVITY
AIRPLANES WITH NO. 3 CARGO DOOR

52-36-00

BOEING
757
FAULT ISOLATION/MAINT MANUAL



No. 3 Cargo Door - Component Location
Figure 102

EFFECTIVITY
AIRPLANES WITH NO. 3 CARGO DOOR

52-36-00

01

Page 102
Sep 20/90

BOEING
757
FAULT ISOLATION/MAINT MANUAL

FLIGHT COMPARTMENT DOOR




| COMPONENT | FIG. 102 SHT | QTY | ACCESS/AREA | AMM REFERENCE |
|--|--------------------|-----|---|------------------|
| CIRCUIT BREAKER - FLT DECK DR LOCK, C1400 | | 1 | FLIGHT COMPARTMENT, P11 11R5 | * |
| DOOR - FLIGHT COMPARTMENT | 1 | 1 | FLIGHT COMPARTMENT | 52-51-01 |
| DOOR LOCK UNIT - FLIGHT COMPARTMENT, M635 | 1 | 1 | FLIGHT COMPARTMENT DOORJAMB | 52-51-01 |
| PANEL - (FIM 33-45-00/101) | | | | |
| RIGHT OVERHEAD LIGHTING CONTROL, M10057 | | | | |
| RELAY - (FIM 31-01-34/101) | | | | |
| FLIGHT DK DR OPEN/CLOSE, K10256 | | | | |
| SWITCH, FLIGHT COMPARTMENT DOOR RELEASE, YCX S1 | 2 | 1 | FLIGHT COMPARTMENT, P5, RIGHT OVERHEAD LIGHTING CONTROL PANEL, M10057 | * |
| SWITCH - FLIGHT DECK DOOR PROXIMITY, S10165 | 1 | 1 | FLIGHT COMPARTMENT DOORJAMB | 52-51-01 |

* SEE THE WDM EQUIPMENT LIST

Flight Compartment Door - Component Index
Figure 101

EFFECTIVITY
GUI 005, 008 PRE-SB 25-271;
GUI 007 PRE-SB 25-269;
GUI 001-003, 009-999

52-51-00
CONFIG 1
Page 101
May 28/05



**FLIGHT COMPARTMENT DOOR
LOCK UNIT, M635
(SHOWN WITH SOLENOID ENERGIZED, DOOR LOCKED)**


(B)

**Flight Compartment Door - Component Location
Figure 102 (Sheet 1)**


EFFECTIVITY
GUI 005, 008 PRE-SB 25-271;
GUI 007 PRE-SB 25-269;
GUI 001-003, 009-999

52-51-00
CONFIG 1
Page 102
May 28/05

BOEING
757
FAULT ISOLATION/MAINT MANUAL



FLIGHT COMPARTMENT



RIGHT OVERHEAD LIGHTING
CONTROL PANEL, M10057 (REF)

(C)


Flight Compartment Door - Component Location
Figure 102 (Sheet 2)

EFFECTIVITY
GUI 005, 008 PRE-SB 25-271;
GUI 007 PRE-SB 25-269;
GUI 001-003, 009-999

52-51-00
CONFIG 1
Page 103
May 28/05

FLIGHT DECK DOOR
UNLOCKED LIGHT DID
NOT GO OFF WITH THE
DOOR LOCKED

PREREQUISITES
NONE




Flight Deck Door Unlocked Light Did Not Go Off with the Door Locked
Figure 103

EFFECTIVITY
GUI 005, 008 PRE-SB 25-271;
GUI 007 PRE-SB 25-269;
GUI 001-003, 009-999

52-51-00
 CONFIG 1
 Page 104
 May 28/05

FLIGHT DECK DOOR
UNLOCKED SWITCH
WILL NOT UNLOCK
THE DOOR

PREREQUISITES
NONE



Flight Deck Door Unlocked Switch Will Not Unlock the Door
Figure 104

EFFECTIVITY
 GUI 005, 008 PRE-SB 25-271;
 GUI 007 PRE-SB 25-269;
 GUI 001-003, 009-999

52-51-00
 CONFIG 1
 Page 105
 May 28/05


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FLIGHT COMPARTMENT DOOR

| COMPONENT | FIG. 102 SHT | QTY | ACCESS/AREA | AMM REFERENCE |
|--|--------------------|-----|---|------------------|
| CHIME MODULE, M11864 | 3 | 1 | FLIGHT COMPARTMENT DOORJAMB | 52-51-20 |
| CIRCUIT BREAKER - F/D DOOR LOCK, C1400 | | 1 | FLIGHT COMPARTMENT, P11 | * |
| DOOR - FLIGHT COMPARTMENT | 1 | 1 | 11R5 | 52-51-01 |
| ELECTRIC STRIKE - FLIGHT COMPARTMENT, M11865 | 1 | 1 | FLIGHT COMPARTMENT | 52-51-03 |
| KEYPAD, M11863 | 2 | 1 | FLIGHT COMPARTMENT DOORJAMB | 52-51-15 |
| PANEL - RIGHT OVERHEAD LIGHTING CONTROL, M10057 | 4 | 1 | FLIGHT COMPARTMENT DOORJAMB | 52-51-30 |
| SWITCH, FLIGHT COMPARTMENT DOOR LOCK, YCX S1 | 4 | 1 | FLIGHT COMPARTMENT, P5, RIGHT OVERHEAD LIGHTING CONTROL PANEL, M10057 | 52-51-30 |


* SEE THE WDM EQUIPMENT LIST

Flight Compartment Door - Component Index
Figure 101

EFFECTIVITY

| | |
|---|--|
| GUI 005, 008 POST-SB 25-271; GUI 007 POST-SB 25-269; GUI 004, 006 | |
|---|--|



52-51-00
 CONFIG 2
 Page 101
 May 28/05



Flight Compartment Door - Component Location
Figure 102 (Sheet 1)

EFFECTIVITY
GUI 005, 008 POST-SB 25-271;
GUI 007 POST-SB 25-269;
GUI 004, 006

52-51-00
CONFIG 2
Page 102
May 28/05



KEYPAD, M11863

(B)

Flight Compartment Door - Component Location
Figure 102 (Sheet 2)

EFFECTIVITY
GUI 005, 008 POST-SB 25-271;
GUI 007 POST-SB 25-269;
GUI 004, 006

52-51-00



CONFIG 2

Page 103

May 28/05

CHIME MODULE, M11864

SEE (C)



CHIME MODULE, M11864

(C)

Flight Compartment Door - Component Location
Figure 102 (Sheet 3)


EFFECTIVITY

GUI 005, 008 POST-SB 25-271;
 GUI 007 POST-SB 25-269;
 GUI 004, 006


52-51-00

CONFIG 2
 Page 104
 May 28/05

BOEING
757
FAULT ISOLATION/MAINT MANUAL



FLIGHT COMPARTMENT



RIGHT OVERHEAD LIGHTING CONTROL PANEL, M10057

(D)

Flight Compartment Door - Component Location
Figure 102 (Sheet 4)

EFFECTIVITY
GUI 005, 008 POST-SB 25-271;
GUI 007 POST-SB 25-269;
GUI 004, 006

52-51-00
CONFIG 2
Page 105
May 28/05

**DOOR DOES NOT LOCK
IN THE "AUTO" MODE**



DESCRIPTION:

THE ELECTRIC STRIKE, M11865 IS DEFECTIVE OR NOT GETTING VOLTAGE OR GROUND.

POSSIBLE CAUSES:


1. CHIME MODULE, M11864
2. ELECTRIC STRIKE, M11865
3. AIRCRAFT WIRING.

FAULT ISOLATION:

PREREQUISITES

MAKE SURE THIS CIRCUIT BREAKER IS CLOSED:
11R5

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)
FLIGHT DECK DOOR IS CLOSED
POWER SWITCH ON THE CHIME MODULE, M10536 IS IN
THE "NORM" POSITION
DEADBOLT ON THE FLIGHT DECK DOOR IS UNLOCKED



Door Does Not Lock in the "AUTO" Mode
Figure 103

EFFECTIVITY

GUI 005, 008 POST-SB 25-271;
GUI 007 POST-SB 25-269;
GUI 004, 006

52-51-00
CONFIG 2
Page 106
May 28/05

DOOR DOES NOT
UNLOCK IN
"UNLOCK" MODE



PREREQUISITES

MAKE SURE THIS CIRCUIT BREAKER IS CLOSED:
11R5

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)
FLIGHT DECK DOOR IS CLOSED
DEADBOLT ON THE FLIGHT DECK DOOR IS UNLOCKED


DESCRIPTION:

THE ELECTRIC STRIKE, M11865, CIRCUIT TO GROUND WILL NOT OPEN.

POSSIBLE CAUSES:

1. CHIME MODULE, M11864
2. RIGHT OVERHEAD LIGHTING CONTROL PANEL, M10057
3. WIRING PROBLEM BETWEEN THE CHIME MODULE, M11864 AND STRUCTURE GROUND (WDM 52-51-11).

FAULT ISOLATION:



Door Does Not UnLock in the "UNLOCK" Mode
Figure 104

EFFECTIVITY
GUI 005, 008 POST-SB 25-271;
GUI 007 POST-SB 25-269;
GUI 004, 006

52-51-00
CONFIG 2
Page 107
May 28/05

DOOR DOES NOT UNLOCK
 IN "AUTO" MODE AFTER
 A CORRECT CODE HAS
 BEEN ENTERED ON THE
 KEYPAD



PREREQUISITES

MAKE SURE THIS CIRCUIT BREAKER IS CLOSED:
 11R5

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
 ELECTRICAL POWER IS ON (AMM 24-22-00/201)
 FLIGHT DECK DOOR IS CLOSED
 DEADBOLT ON THE FLIGHT DECK DOOR IS UNLOCKED


DESCRIPTION:

THE ELECTRIC STRIKE, M11865, CIRCUIT TO GROUND WILL NOT OPEN.

POSSIBLE CAUSES:

1. CHIME MODULE, M11864
2. KEYPAD, M11863
3. WIRING PROBLEM BETWEEN THE CHIME MODULE, M11864 AND STRUCTURE GROUND (WDM 52-51-11).

FAULT ISOLATION:



Door Does Not Unlock in "AUTO" Mode After a Correct
 Code Has Been Entered On the Keypad
 Figure 105

EFFECTIVITY

GUI 005, 008 POST-SB 25-271;
 GUI 007 POST-SB 25-269;
 GUI 004, 006

52-51-00
 CONFIG 2
 Page 108
 May 28/05

DOOR UNLOCKS OR
CHIMES SOUND IN THE
"DENY" MODE



PREREQUISITES

MAKE SURE THIS CIRCUIT BREAKER IS CLOSED:
11R5

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)
FLIGHT DECK DOOR IS CLOSED
POWER SWITCH ON THE CHIME MODULE, M10536 IS IN
THE "NORM" POSITION


DESCRIPTION:

THE CHIME MODULE, M11864 IS DEFECTIVE OR NOT RECEIVING THE CORRECT GROUND SIGNAL.

POSSIBLE CAUSES:

1. RIGHT OVERHEAD LIGHTING CONTROL PANEL, M10057
2. CHIME MODULE, M11864
3. WIRING PROBLEM BETWEEN THE CHIME MODULE, M11864 AND STRUCTURE GROUND (WDM 52-51-11).

FAULT ISOLATION:



Door Unlocks or Chimes Sound in the "DENY" Mode
Figure 106

EFFECTIVITY
GUI 005, 008 POST-SB 25-271;
GUI 007 POST-SB 25-269;
GUI 004, 006

52-51-00
CONFIG 2
Page 109
May 28/05

CHIME DOES NOT SOUND
WHEN A CORRECT CODE
IS ENTERED ON THE
KEYPAD IN "AUTO"
MODE




DESCRIPTION:

THE CHIME MODULE, M11864 IS DEFECTIVE OR THE SYSTEM IS IN DENY MODE.

POSSIBLE CAUSES:

1. CHIME MODULE, M11864

FAULT ISOLATION:



PREREQUISITES

MAKE SURE THIS CIRCUIT BREAKER IS CLOSED:
11R5

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)
FLIGHT DECK DOOR IS CLOSED
POWER SWITCH ON THE CHIME MODULE, M1864 IS IN THE "NORM" POSITION

NOTE: THE CHIME AND KEYPAD CAN BE DISABLED FOR UP TO 30 MINUTES AFTER THE DOOR LOCK SWITCH IS TURNED TO THE "DENY" POSITION. THE DENY MODE CAN BE ENDED BY TURNING THE DOOR LOCK SWITCH TO THE "UNLOCK" POSITION.

Chime Does Not Sound When a Correct Code is Entered on the Keypad in "AUTO" Mode
Figure 107

EFFECTIVITY

| |
|------------------------------|
| GUI 005, 008 POST-SB 25-271; |
| GUI 007 POST-SB 25-269; |
| GUI 004, 006 |

52-51-00
 CONFIG 2
 Page 110
 May 28/05

N85688

**FLIGHT DECK DOOR
"LOCK FAIL" LIGHT
IS ON**



PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
11R5

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)
FLIGHT DECK DOOR IS CLOSED
DEADBOLT ON THE FLIGHTDECK DOOR IS UNLOCKED


DESCRIPTION:

THE DOOR LOCK SOLENOID IS COMMANDED TO THE LOCKED POSITION BUT IS NOT IN THE LOCKED POSITION. THE CHIME MODULE SENSES A CONDITION WHERE POWER IS APPLIED TO THE ELECTRIC STRIKE, M11865 BUT ELECTRICAL CONTACTS IN THE UNIT ARE NOT CLOSED.

POSSIBLE CAUSES:

1. THE ELECTRIC STRIKE, M11865 IS JAMMED OR DEFECTIVE
2. RIGHT OVERHEAD LIGHTING CONTROL PANEL, M10057
3. WIRING PROBLEM BETWEEN THE CHIME MODULE, M11864 AND STRUCTURE GROUND (WDM 52-51-11).

FAULT ISOLATION:



Flight Deck Door "LOCK FAIL" Light is on
Figure 108

EFFECTIVITY
GUI 005, 008 POST-SB 25-271;
GUI 007 POST-SB 25-269;
GUI 004, 006

52-51-00
CONFIG 2
Page 111
May 28/05

FLIGHT DECK DOOR
"AUTO UNLK" LIGHT
DOES NOT COME ON
AFTER A CORRECT
ACCESS CODE HAS
BEEN ENTERED



PREREQUISITES

MAKE SURE THIS CIRCUIT BREAKER IS CLOSED:
11R5

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)
FLIGHT DECK DOOR IS CLOSED

NOTE: A CORRECT ACCESS CODE ENTERED ON THE KEYPAD
WILL MAKE THE "AUTO UNLK" LIGHT COME ON. THE
"AUTO UNLK" LIGHT WILL BLINK WHEN THE CHIME
SOUNDS.


DESCRIPTION:

THE "AUTO UNLK" LIGHT IS COMMANDED TO COME ON FROM THE CHIME MODULE, M11864 WHEN A CORRECT ACCESS CODE IS ENTERED ON THE KEYPAD.

POSSIBLE CAUSES:

1. DEFECTIVE LIGHT BULB
2. CHIME MODULE, M11864
3. WIRING PROBLEM BETWEEN THE CHIME MODULE, M11864 AND "AUTO UNLK" LIGHT

FAULT ISOLATION:




Flight Deck Door "AUTO UNLK" Light Does Not Come On
After a Correct Pass Code Has Been Entered
Figure 109

EFFECTIVITY
GUI 005, 008 POST-SB 25-271;
GUI 007 POST-SB 25-269;
GUI 004, 006


52-51-00
CONFIG 2
Page 112
May 28/05

 **BOEING**
757
FAULT ISOLATION/MAINT MANUAL

DOOR WARNING SYSTEM

| COMPONENT | FIG. 102 SHT | QTY | ACCESS/AREA | REFERENCE |
|---|--------------------|-----|--|-----------|
| CIRCUIT BREAKER DOOR IND, C4144 COMPUTER - (REF 31-41-00, FIG. 101) EICAS L, M10181 EICAS R, M10182 | | 1 | FLT COMPT, P11 11R33 | * |
| LIGHT - ENTRY DOORS WARNING, YNEL001 | 1 | 1 | FLT COMPT, P5, ANNUNCIATOR PANEL M10394 (REF) | * |
| LIGHT - EMERGENCY DOORS WARNING, YNEL002 | 1 | 1 | FLT COMPT, P5, ANNUNCIATOR PANEL M10394 (REF) | * |
| LIGHT - CARGO DOORS WARNING, YNEL003 | 1 | 1 | FLT COMPT, P5, ANNUNCIATOR PANEL M10394 (REF) | * |
| LIGHT - ACCESS DOORS WARNING, YNEL004 | 1 | 1 | FLT COMPT, P5, ANNUNCIATOR PANEL M10394 (REF) | * |
| MODULE - (REF 32-09-03, FIG. 101) PROXIMITY SWITCH ELECTRONICS UNIT (PSEU), M162 | | | | |
| PANEL - (REF 30-31-00, FIG. 101) ANNUNCIATOR, M10394 | | | | |
| SENSOR - FORWARD ACCESS DOOR, S10085 | 4 | 1 | 113AL, DOOR FWD FRAME | 52-71-00 |
| SENSOR - E/E ACCESS DOOR, S10086 | 4 | 1 | 119BL, DOOR R FRAME | 52-71-00 |
| SENSOR - NO. 1 PASSENGER DOOR L, S10094 | 1 | 1 | 831, DOOR AFT FRAME | 52-71-00 |
| SENSOR - NO. 2 PASSENGER DOOR L, S10095 | 1 | 1 | 832, DOOR AFT FRAME | 52-71-00 |
| SENSOR - NO. 3 EMERGENCY EXIT L, S10096 | 3 | 1 | 835, DOOR FWD FRAME | 52-71-00 |
| SENSOR - NO. 4 PASSENGER DOOR L, S10097 | 2 | 1 | 836, DOOR AFT FRAME | 52-71-00 |
| SENSOR - NO. 1 PASSENGER DOOR R, S10090 | 1 | 1 | 841, DOOR FWD FRAME | 52-71-00 |
| SENSOR - NO. 2 PASSENGER DOOR R, S10091 | 1 | 1 | 842, DOOR AFT FRAME | 52-71-00 |
| SENSOR - NO. 3 EMERGENCY EXIT R, S10092 | 3 | 1 | 845, DOOR FWD FRAME | 52-71-00 |
| SENSOR - NO. 4 PASSENGER DOOR R, S10093 | 2 | 1 | 846, DOOR AFT FRAME | 52-71-00 |
| SENSOR - NO. 1 CARGO DOOR, S10083 | 5 | 1 | 821, DOOR UPPER FRAME | 52-71-00 |
| SENSOR - NO. 2 CARGO DOOR, S10088 | 5 | 1 | 822, DOOR UPPER FRAME | 52-71-00 |
| SENSOR - NO. 3 CARGO DOOR, S10089  | 6 | 1 | 823, DOOR FWD FRAME | 52-71-00 |

* SEE WM EQUIPMENT LIST

 AIRPLANES WITH NO. 3 CARGO DOOR

Component Index
Figure 101

EFFECTIVITY

ALL

52-71-00

02


Page 101
Dec 20/88

590758

BOEING



757

FAULT ISOLATION/MAINT MANUAL




| | | | |
|--------------------------------|---------------------------|--------------------------|----------------------------|
| ENTRY DOORS _a | EMER DOORS _a | CARGO DOORS _a | ACCESS DOORS _a |
| CAPT PITOT _a | F/O PITOT _a | L AOA _a | R AOA _a |
| L AUX PITOT _a | R AUX PITOT _a | TAT _a | |
| STAB TRIM _a | SPOILERS _a | AUTO SPDRK _a | MACH SPD TRIM _a |
| UNSCHEB STAB TRIM _a | RUDDER RATIO _a | ANTI-SKID _a | |

ANNUNCIATOR PANEL, M10394 (REF)



(VIEW WITH COVER REMOVED)
A-A




NO. 1/NO. 2 PASSENGER DOOR L & R SENSORS (TYP-4 PLS)

Component Location
Figure 102 (Sheet 1)

| | |
|-------------|-----|
| EFFECTIVITY | ALL |
|-------------|-----|

52-71-00



Component Location
Figure 102 (Sheet 2)



| | |
|-------------|-----|
| EFFECTIVITY | |
| | ALL |

52-71-00

01

Page 103
Sep 15/83

54851



NO. 3 EMERGENCY EXIT DOOR SENSOR

(D)

Component Location
Figure 102 (Sheet 3)

| | |
|-------------|--|
| EFFECTIVITY | |
| ALL | |

52-71-00

01




Page 104
Sep 15/83

BOEING
757
FAULT ISOLATION/MAINT MANUAL

FORWARD ACCESS
DOOR SENSOR S10085
SEE (E)


E/E ACCESS
DOOR SENSOR
S10086
SEE (F)

113AL
119BL



FORWARD ACCESS DOOR SENSOR, S10085

(E)



E/E ACCESS DOOR SENSOR, S10086

(F)

Component Location
Figure 102 (Sheet 4)

EFFECTIVITY


ALL

52-71-00

01

Page 105
Sep 15/83


BOEING
757
FAULT ISOLATION/MAINT MANUAL



Component Location
Figure 102 (Sheet 5)

| | |
|-------------|-----|
| EFFECTIVITY | ALL |
|-------------|-----|

52-71-00



NO. 3 CARGO DOOR SENSOR, S10089

I


Component Location
Figure 102 (Sheet 6)

EFFECTIVITY
AIRPLANES WITH NO. 3 CARGO DOOR

52-71-00

DOORS LGT ILLUM
AND EICAS MSG
DISPLAYED. DOOR
WAS CLOSED.

PREREQUISITES
NONE




Doors Lgt Illum and EICAS Msg Displayed. Door was Closed.
Figure 103

| | |
|-------------|-----|
| EFFECTIVITY | ALL |
|-------------|-----|

52-71-00

EICAS MSG "(L,R)
(FWD,CTR,AFT) ENT
DOOR" DID NOT
DISPLAY WITH DOOR
OPEN.

PREREQUISITES
NONE




EICAS Msg (L,R) (FWD,CTR,AFT) ENT DOOR Did Not Display with Door Open.
Figure 104

| | |
|-------------|-----|
| EFFECTIVITY | ALL |
|-------------|-----|

52-71-00

EICAS MESSAGE DISPLAYED FOR ENTRY DOOR, EMER DOOR, CARGO DOOR, OR ACCESS DOOR.
 CORRESPONDING ANNUNCIATOR LIGHT NOT ILLUMINATED.

PREREQUISITES
 ELECTRICAL POWER (MM 24-22-00)
 CB'S: 11R33



EICAS Message Displayed For Entry Door, Emer Door, Cargo Door, or Access Door. Corresponding Annunciator Light Not Illuminated.

Figure 104A

| | |
|-------------|-----|
| EFFECTIVITY | ALL |
|-------------|-----|

52-71-00