



BOEING
757
FAULT ISOLATION/MAINT MANUAL

GPA Group plc

PAGE	DATE	CODE	PAGE	DATE	CODE	PAGE	DATE	CODE
CHAPTER 52 TAB			52-BITE INDEX			52-34-00		
DOORS			1	SEP 28/99	01	115	MAY 28/07	05
EFFECTIVE PAGES SEE LAST PAGE OF LIST FOR NUMBER OF PAGES			2	SEP 28/99	01	116	MAY 28/07	03
52-CONTENTS			3	SEP 28/99	01	117	SEP 20/94	03
1	JAN 28/00	GUI	4	BLANK		118	MAY 28/07	04
2	JAN 28/00	GUI	52-11-00			119	MAY 28/07	03
3	JAN 28/00	GUI	101	JUN 20/91	02	120	MAY 28/07	03
4	MAY 28/05	GUI	102	JUN 20/91	01	121	MAY 28/07	04
5	MAY 28/05	GUI	103	JUN 20/91	01	122	MAY 28/07	03
6	MAY 28/05	GUI	104	SEP 28/99	01	123	MAY 28/07	12
52-HOW TO USE THE FIM			105	JUN 20/91	02	124	MAY 28/07	03
1	SEP 20/98	01	106	JUN 20/91	01	125	MAY 28/07	04
2	SEP 20/98	01	107	JUN 20/91	01	126	MAY 28/07	04
3	SEP 28/99	01	108	JUN 20/91	01	127	MAY 28/07	11
4	SEP 20/98	01	109	MAY 28/99	01	128	MAY 28/07	02
5	SEP 20/98	01	110	JAN 20/99	01	129	MAY 28/07	02
6	SEP 20/98	01	111	JAN 20/98	01	130	SEP 20/94	02
52-INDEX			112	JAN 20/98	01	131	SEP 20/94	02
1	MAY 28/05	04	113	MAY 28/99	01	132	SEP 20/94	02
2	MAY 28/05	04	114	JAN 20/98	01	133	SEP 20/94	01
52-EICAS MESSAGES			115	MAY 28/99	01	134	SEP 20/94	02
1	DEC 20/90	01	116	SEP 28/99	01	52-36-00		
2	DEC 20/90	01	117	JAN 20/98	01	101	SEP 20/90	01
3	MAR 20/96	02	118	MAY 28/99	01	102	SEP 20/90	01
4	MAR 20/96	02	119	MAY 28/99	01	52-51-00 CONFIG 1		
5	MAR 20/96	01	120	JAN 20/98	01	101	MAY 28/05	11
6	BLANK		121	MAY 28/99	01	102	MAY 28/05	11
52-FAULT CODE DIAGRAM			122	MAY 28/99	01	103	MAY 28/05	11
1	MAR 20/88	01	123	JAN 20/98	01	104	MAY 28/05	11
2	MAR 15/87	01	124	SEP 20/08	01	105	MAY 28/05	11
3	JUN 20/97	02	125	JAN 20/98	01	106	BLANK	
4	SEP 20/87	01	126	JAN 20/98	01	52-51-00 CONFIG 2		
5	JUN 20/92	07	127	SEP 20/98	01	101	MAY 28/05	11
6	MAY 28/05	05	128	JAN 20/98	01	102	MAY 28/05	11
7	MAY 28/05	04	129	JAN 20/98	01	103	MAY 28/05	11
8	BLANK		130	BLANK		104	MAY 28/05	11
52-FAULT CODE INDEX			52-21-00			105	MAY 28/05	11
1	SEP 20/08	01	101	SEP 20/94	01	106	MAY 28/05	11
2	SEP 20/08	01	102	DEC 20/95	01	107	MAY 28/05	11
3	SEP 20/08	01	103	SEP 20/94	01	108	MAY 28/05	11
4	SEP 20/08	01	104	BLANK		109	MAY 28/05	11
5	SEP 20/08	01	52-34-00			110	MAY 28/05	11
6	SEP 20/08	01	101	SEP 28/01	18	111	MAY 28/05	11
7	SEP 20/08	06	102	DEC 20/95	18	112	MAY 28/05	11
8	BLANK		103	DEC 20/95	02	52-71-00		
			104	DEC 20/95	01	101	DEC 20/88	02
			105	DEC 20/95	01	102	SEP 15/83	01
			106	MAY 28/07	01	103	SEP 15/83	01
			107	MAY 28/07	03	104	SEP 15/83	01
			108	MAY 28/07	13	105	SEP 15/83	01
			109	MAY 28/07	01	106	DEC 20/88	02
			110	MAY 28/07	03	107	DEC 20/88	02
			111	MAY 28/07	04	108	SEP 20/94	02
			112	MAY 28/07	12	109	SEP 20/94	04
			113	MAY 28/07	01	110	SEP 20/94	03
			114	SEP 20/94	03			

R = REVISED, A = ADDED OR D = DELETED
F = FOLDOUT PAGE
32
MAY 20/09

D633N632

CHAPTER 52
EFFECTIVE PAGES
PAGE 1
LAST PAGE



BOEING
757
FAULT ISOLATION/MAINT MANUAL

CHAPTER 52 - DOORS

TABLE OF CONTENTS

<u>Subject</u>	Chapter Section <u>Subject</u>	<u>Page</u>	<u>Effectivity</u>
HOW TO USE THE FIM	52-HOW TO USE THE FIM	1	ALL
INDEX	52-INDEX	1	ALL
EICAS MESSAGES	52-EICAS MESSAGES	1	ALL
FAULT CODE DIAGRAMS	52-FAULT CODE DIAGRAM	1	ALL
FAULT CODE INDEX	52-FAULT CODE INDEX	1	ALL
BITE INDEX	52-BITE INDEX	1	ALL
<u>DOORS</u>	52-00-00		
<u>PASSENGER/CREW</u>	52-10-00		
NO. 1, 2 AND 4 PASSENGER DOORS	52-11-00		
Component Location		101	ALL
Component Index			
Component Location			
Fault Isolation			
Door is Difficult to Arm/Disarm (Fig. 114)		124	
Door is Difficult to Cock (Fig. 110)		119	
Door is Difficult to Latch/Unlatch (Fig. 108)		115	
Door is Difficult to Open/Close (Fig. 112)		121	
Emergency Power Assist System (EPAS) is Difficult to Adjust (Fig. 116)		127	
General Guidelines for Door Fault Isolation (Fig. 103)		109	
Wear is Found on the Latch Fittings (Fig. 106)		113	

52-CONTENTS

 **BOEING**
757
FAULT ISOLATION/MAINT MANUAL

CHAPTER 52 - DOORS

TABLE OF CONTENTS

<u>Subject</u>	Chapter Section <u>Subject</u>	<u>Page</u>	<u>Effectivity</u>
<u>EMERGENCY EXIT</u>	52-20-00		
NO. 3 EMERGENCY EXIT DOOR	52-21-00		
Component Location		101	ALL
Component Index			
Component Location			

52-CONTENTS



BOEING
757
FAULT ISOLATION/MAINT MANUAL

CHAPTER 52 - DOORS

TABLE OF CONTENTS

<u>Subject</u>	Chapter Section <u>Subject</u>	<u>Page</u>	<u>Effectivity</u>
<u>CARGO</u>	52-30-00		
NO. 1 AND NO. 2 CARGO DOORS	52-34-00		
Component Location		101	ALL
Component Index			
Component Location			
Fault Isolation			
No. 1 (Fwd) or No. 2 (Aft)		132	
Cargo Door Binding When (Unlocking, Locking, Locking and Unlocking) (Fig. 111)			
No. 1 (Fwd) Cargo Door Failed to Close Electrically. Manual Operation was Normal. (Fig. 105)		114	
No. 1 (Fwd) Cargo Door Failed to Open or Close Electrically. Manual Operation was Normal. (Fig. 107)		120	
No. 1 (Fwd) Cargo Door Will Not Open Electrically. Manual Operation Was Normal. (Fig. 103)		106	
No. 1 or No. 2 Cargo Door Failed to Open or Close Electrically or Manually. (Fig. 109)		128	
No. 1 or No. 2 Cargo Door Opens and Closes too Slowly (Fig. 110)		130	
No. 1 or No. 2 Cargo Door Overtravels During Closing (Slams Shut) (Fig. 112)		134	
No. 2 (Aft) Cargo Door Failed to Close Electrically. Manual Operation was Normal. (Fig. 106)		117	
No. 2 (Aft) Cargo Door Failed to Open or Close Electrically. Manual Operation was Normal. (Fig. 108)		124	

52-CONTENTS

 **BOEING**
757
FAULT ISOLATION/MAINT MANUAL

CHAPTER 52 - DOORS

TABLE OF CONTENTS

<u>Subject</u>	<u>Chapter Section Subject</u>	<u>Page</u>	<u>Effectivity</u>
No. 2 (Aft) Cargo Door Failed to Open Electrically. Manual Operation Was Normal. (Fig. 104)		110	
NO. 3 CARGO DOOR	52-36-00		
Component Location		101	[*]
Component Index			
Component Location			
[*] AIRPLANES WITH NO. 3 CARGO DOOR			

52-CONTENTS

CHAPTER 52 - DOORS

TABLE OF CONTENTS

<u>Subject</u>	Chapter Section <u>Subject</u>	<u>Page</u>	<u>Effectivity</u>
<u>FIXED INTERIOR</u>	52-50-00		
FLIGHT COMPARTMENT DOOR	52-51-00		
Component Location		101	CONFIG 1 [*]
Component Index			
Component Location			
Fault Isolation			
Flight Deck Door Unlocked		104	
Light Did Not Go Off with the			
Door Locked (Fig. 103)			
Flight Deck Door Unlocked		105	
Switch Will Not Unlock the			
Door (Fig. 104)			
[*] GUI 005, 008 PRE-SB 25-271; GUI 007 PRE-SB 25-269; GUI 001-003, 009-999			
Component Location		101	CONFIG 2 [*]
Component Index			
Component Location			
Fault Isolation			
Flight Deck Door "AUTO UNLK"		112	
Light Does Not Come On (Fig.			
109)			
Flight Deck Door "LOCK FAIL"		111	
Light Is On (Fig. 108)			
Flight Deck Door Chime Does		110	
Not Sound After Correct Code			
(Fig. 107)			
Flight Deck Door Does Not Lock		106	
In The "Auto" Mode (Fig. 103)			
Flight Deck Door Does Not		108	
Unlock In "AUTO" Mode (Fig.			
105)			
Flight Deck Door Does Not		107	
Unlock In The "Unlock" Mode			
(Fig. 104)			
Flight Deck Door Unlocks Or		109	
Chimes Sound In "DENY" Mode			
(Fig. 106)			
[*] GUI 005, 008 POST-SB 25-271; GUI 007 POST-SB 25-269; GUI 004, 006			

52-CONTENTS




BOEING
757
FAULT ISOLATION/MAINT MANUAL

CHAPTER 52 - DOORS

TABLE OF CONTENTS

<u>Subject</u>	Chapter Section <u>Subject</u>	<u>Page</u>	<u>Effectivity</u>
<u>DOOR WARNING</u>	52-70-00		
DOOR WARNING SYSTEM	52-71-00		
Component Location		101	ALL
Component Index			
Component Location			
Fault Isolation			
Doors Lgt Illum and EICAS Msg Displayed. Door was Closed. (Fig. 103)		108	
EICAS Message Displayed For Entry Door, Emer Door, Cargo Door, or Access Door. Corresponding Annunciator Light Not Illuminated (Fig. 104A)		110	
EICAS Msg (L,R) (FWD,CTR,AFT) ENT DOOR Did Not Display with Door Open. (Fig. 104)		109	

52-CONTENTS



Basic Fault Isolation Process
Figure 1


EFFECTIVITY

ALL

52-HOW TO USE THE FIM

01

Page 1
Sep 20/98



How to Get Fault Information from BITE
Figure 2

EFFECTIVITY

ALL

52-HOW TO USE THE FIM

01

Page 2
Sep 20/98

IF YOU HAVE:

THEN DO THIS TO FIND THE CORRECTIVE ACTION OR FAULT ISOLATION PROCEDURE IN THE FIM:

FAULT CODE

1. The first two digits of the fault code are the FIM chapter that you need. Go to the Fault Code Index in that chapter and find the fault code.
2. Find the Fault Isolation Reference for the fault code and do the corrective action. If there is a FIM reference, then go to that fault isolation procedure in the FIM and do the steps in the procedure (see Figure 4).

EICAS MESSAGE TEXT
(with no fault code)

1. If you know the chapter of the EICAS message, then go to the EICAS Messages section in that chapter and find the EICAS message.

If you do not know the chapter of the EICAS message, then do these steps:
 - A. Go to FIM EICAS MESSAGE LIST and find the EICAS message in the table.

NOTE: The list follows the INTRODUCTION to the FIM.
 - B. Find the chapter number on the same line as the EICAS message. Go to the EICAS Messages section in that chapter and find the EICAS message.
2. Do the corrective action in the "Procedure" column for the EICAS message. If there is a FIM reference, then go to that fault isolation procedure in the FIM and do the steps in the procedure (see Figure 4).

OBSERVED FAULT DESCRIPTION

1. Go to the Fault Code Diagram for the problem in the applicable chapter.
2. Do the fault analysis on the diagram and find the fault code.
3. The first two digits of the fault code are the FIM chapter that you need. Go to the Fault Code Index in that chapter and find the fault code.
4. Find the Fault Isolation Reference for the fault code and do the corrective action. If there is a FIM reference, then go to that fault isolation procedure in the FIM and do the steps in the procedure (see Figure 4).

How to Find the Corrective Action or Fault Isolation Procedure in the FIM

Figure 3

EFFECTIVITY

ALL

52-HOW TO USE THE FIM

ASSUMED CONDITIONS AT START OF TASK

- External electrical power is OFF
- Hydraulic power and pneumatic power are OFF
- Engines are shut down
- Circuit breakers for the system are closed
- No equipment in the system is deactivated

PREREQUISITES

- This box gives the steps to get the airplane from the normal shutdown condition to the configuration necessary to do the fault isolation procedure.
- The Prerequisites give procedure references, circuit breakers, and special tools and equipment requirements.

FAULT ISOLATION BLOCKS

- Start the fault isolation procedure at block 1 unless specified differently.
- Do the check to get an answer to the question in the box. Follow the arrow that applies to your answer. This will go to the next check.
- When you get to a box in the column at the right of the page, you have isolated that fault. Do the steps in that box to repair the cause of the fault.
- Make sure that fault is corrected to complete the procedure.

Do the Fault Isolation Procedure
Figure 4


EFFECTIVITY

ALL

52-HOW TO USE THE FIM


01

Page 4
Sep 20/98



Subjects in Each FIM Chapter
Figure 5 (Sheet 1)


<p>EFFECTIVITY</p> <hr/> <p align="center">ALL</p>	<p align="center">52-HOW TO USE THE FIM</p> <p align="right">01</p> <p align="right">Page 5 Sep 20/98</p>
--	--




Alphabetical list of the EICAS messages. Gives the procedure to repair the cause of the message or a reference to a fault isolation procedure.




Failure analysis diagrams for the airplane systems to find the correct fault code for the fault.



Numerical list of fault codes. Gives the procedure to repair the cause of the fault or a reference to a fault isolation procedure.




Alphabetical list of all the LRUs/systems that have BITE. Gives the chapter/section for the BITE procedure.



Component index, component location, and fault isolation procedures for the systems in the chapter.




Subjects in Each FIM Chapter
Figure 5 (Sheet 2)




52-HOW TO USE THE FIM

<u>TITLE</u>	<u>CHAP/SEC</u>
CARGO DOORS.....	5234
DOOR AIR NOISE.....	5211
DOOR INDICATION.....	5271
ENTRY/SERVICE/EMERGENCY EXIT DOORS.....	5211,5221
FLIGHT DECK DOOR	5251
FLIGHT DECK DOOR CONTROL PANEL	
(SEcurity DOOR).....	5251
FLIGHT DECK ACCESS PANEL	
(SEcurity DOOR).....	5251
GIRT BAR ENGAGEMENT INDICATOR	
LIGHT (SLIDE/RAFT).....	CHAPTER 25
LAVATORY DOORS	CHAPTER 25
WINDOW FOGGING	CHAPTER 25


DOORS - INDEX




52-INDEX




ENTRY/SERVICE DOORS




5271 OVERHEAD PANEL




OVERHEAD PANEL




EMERGENCY EXIT DOOR




FLIGHT DECK DOOR




FLT DK DOOR



CARGO DOOR CONTROL SWITCH



CARGO COMPT DOOR



LAVATORY DOOR (TYPICAL)

1 AS INSTALLED

DOORS - INDEX

EFFECTIVITY	ALL
-------------	-----

52-INDEX

DOORS - EICAS MESSAGE LIST

1. General

- A. This procedure shows the EICAS message locations and gives a list of procedures to find the solution for each message.
- (1) EICAS Message Locations (Fig. 1)
 - (a) Figure 1 shows the location of the EICAS display units and the area where the messages show on the display units.
 - (b) Each message level has a different location. The location and color of each message level is also shown.
 - (2) The EICAS MESSAGE LIST gives the message, level, and procedure for each message.
 - (a) The EICAS MESSAGE column lists the messages alphabetically. Messages which start with L, R, or C are put together and alphabetized at L.
 - (b) The LEVEL column gives all levels for each message as follows:
 - A - Warning messages
 - B - Caution messages
 - C - Advisory messages
 - S - Status messages
 - M - Maintenance messages
 - (c) The PROCEDURE column gives the steps that are necessary to remove the message and includes one or more of the procedures that follow:
 - 1) A Fault Isolation Manual procedure reference
 - 2) A Maintenance Manual procedure and reference
 - 3) Wiring checks and a Wiring Diagram Manual reference
 - 4) A reference to an EICAS message list in a different chapter.
 - 5) A reference to a FAULT CODE INDEX and specified fault codes
 - 6) A step to change the airplane configuration

EFFECTIVITY



ALL

52-EICAS MESSAGES


01

Page 1
Dec 20/90


BOEING
757
FAULT ISOLATION/MAINT MANUAL



ENGINE PRIMARY PAGE OR COMPACTED PAGE
(TOP DISPLAY UNIT)




ECS/MSG PAGE
(BOTTOM DISPLAY UNIT)



STATUS PAGE
(BOTTOM DISPLAY UNIT)

LEVEL	COLOR
A-WARNING	RED
B-CAUTION	YELLOW
C-ADVISORY	YELLOW
S-STATUS	WHITE
M-MAINTENANCE	WHITE

EICAS Message Locations
Figure 1



52-EICAS MESSAGES



BOEING
757
FAULT ISOLATION/MAINT MANUAL

EICAS MESSAGE LIST		
EICAS MESSAGE	LEVEL	PROCEDURE
ACCESS DOORS	C	Remove the unwanted material or blockages from the forward access door or the Electrical/Electronics access door latch pins and latch fittings. If the problem continues, adjust the access door proximity sensors (AMM 52-71-00/501).
AFT CARGO DOOR	C	Remove the unwanted material or blockages from the No. 2 cargo door latch mechanisms. If the problem continues, adjust the No. 2 cargo door proximity sensor, S10088 (AMM 52-71-00/501).
AFT CARGO DOOR 1	C	Remove the unwanted material or blockages from the No. 2 cargo door latch mechanisms. If the problem continues, adjust the No. 2 cargo door proximity sensor, S10088 (AMM 52-71-00/501).
AFT CARGO DOOR 2	C	Remove the unwanted material or blockages from the No. 3 cargo door latch mechanisms. If the problem continues, adjust the No. 3 cargo door proximity sensor, S10089 (AMM 52-71-00/501).
CARGO DOORS	C	Remove the unwanted material or blockages from the cargo doors latch mechanisms. If the problem continues, adjust the cargo door locked proximity sensors (AMM 52-71-00/501).
E/E ACCESS DOOR	C	Remove the unwanted material or blockages from the Electrical/Electronics access door latch pins and latch fittings. If the problem continues, adjust the proximity sensor (AMM 52-71-00/501).
EMER DOORS	C	Remove the unwanted material or blockages from the mechanisms of the emergency doors or hatches. If the problem continues, adjust the proximity sensors (AMM 52-71-00/501).

EFFECTIVITY

ALL

52-EICAS MESSAGES

02

Page 3
Mar 20/96


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

EICAS MESSAGE LIST		
EICAS MESSAGE	LEVEL	PROCEDURE
FWD ACCESS DOOR	C	Remove the unwanted material or blockages from the forward access door latch pins and latch fittings. If the problem continues, adjust the access door proximity sensors (AMM 52-71-00/501).
FWD CARGO DOOR	C	Remove the unwanted material or blockages from the No. 1 cargo door latch mechanisms. If the problem continues, adjust the No. 1 cargo door locked proximity sensor, S10083 (AMM 52-71-00/501).
(L,R) AFT ENT DOOR	C	Remove the unwanted material or blockages from the No. 4 passenger door latch cams or upper and lower gates. If the problem continues, adjust the No. 4 passenger door warning proximity sensor, S10097 or S10093 (AMM 52-71-00/501).
(L,R) CTR ENT DOOR	C	Remove the unwanted material or blockages from the No. 2 passenger door latch cams or upper and lower gates. If the problem continues, adjust the No. 2 passenger door warning proximity sensor, S10095 or S10091 (AMM 52-71-00/501).
(L,R) EMER DOOR	C	Remove the unwanted material or blockages from the No. 3 emergency exit door latch rollers, latch cams, and stop fittings. If the problem continues, adjust the proximity sensor (AMM 52-71-00/501).
(L,R) ENTRY DOORS	C	Remove the unwanted material or blockages from the No. 1, 2, and 4 passenger doors latch cams or upper and lower gates. If the problem continues, adjust the No. 1, 2, and 4 passenger doors warning proximity sensors, S10094, S10090, S10095, S10091, S10097, and S10093 (AMM 52-71-00/501).

EFFECTIVITY

ALL

52-EICAS MESSAGES

02

Page 4
Mar 20/96


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

EICAS MESSAGE LIST		
EICAS MESSAGE	LEVEL	PROCEDURE
(L,R) FWD ENT DOOR	C	Remove the unwanted material or blockages from the No. 1 passenger door latch cams or upper and lower gates. If the problem continues, adjust the No. 1 passenger door warning proximity sensor, S10094 or S10090 (AMM 52-71-00/501).

EFFECTIVITY _____

ALL

52-EICAS MESSAGES

01

Page 5
Mar 20/96


BOEING

757

FAULT ISOLATION/MAINT MANUAL



ENTRY/SERVICE/EMERGENCY EXIT DOORS

FAULT CODE/ LOCATION



DOORS 1

1L	01
2L	02
3L EMER	03
4L	04
1R	05
2R	06
3R EMER	07
4R	08



APPLICABLE CIRCUIT BREAKERS
NONE

ENTRY/SERVICE/EMERGENCY EXIT DOORS - FAULT CODES

EFFECTIVITY

ALL

52-FAULT CODE DIAGRAM

01

Page 1
Mar 20/88


BOEING

757

FAULT ISOLATION/MAINT MANUAL

ENTRY/SERVICE DOORS


EMERGENCY EXIT DOORS




FAULT CODE/
LOCATION

DOORS		1
1L		01
2L		02
3L	EMER	03
4L		04
1R		05
2R		06
3R	EMER	07
4R		08

DOES DOOR HAVE EXCESSIVE
NOISE LEVEL DUE TO LEAKAGE?



REPORT ANY FAULT SYMPTOM OR PATTERN NOT SHOWN ABOVE → 52 11 XB



APPLICABLE CIRCUIT BREAKERS

NONE

DOOR AIR NOISE - FAULT CODES


EFFECTIVITY

ALL

52-FAULT CODE DIAGRAM

01

Page 2
Mar 15/87



1 A KEY MUST BE USED TO OPEN DOOR FROM PASSENGER COMPARTMENT. DOOR WILL UNLOCK WITH LOSS OF ELECTRICAL POWER.

APPLICABLE CIRCUIT BREAKERS AS INSTALLED


11R5	FLT DK DOOR LOCK
11R5	F/D DOOR LOCK

FLIGHT DECK DOOR – FAULT CODES

EFFECTIVITY

ALL

52-FAULT CODE DIAGRAM



APPLICABLE CIRCUIT BREAKERS

NONE

CARGO DOORS - FAULT CODES

EFFECTIVITY


ALL

52-FAULT CODE DIAGRAM

BOEING

757

FAULT ISOLATION/MAINT MANUAL



APPLICABLE CIRCUIT BREAKERS

11R33 DOOR IND

DOOR INDICATION - FAULT CODES

EFFECTIVITY


ALL

52-FAULT CODE DIAGRAM

07

Page 5
Jun 20/92

OVERHEAD PANEL




FAULT CODE/
LOCATION

UNLK	01
AUTO	02
DENY	03
ALL	04

WAS FLIGHT DECK DOOR CONTROL PANEL OPERATION NORMAL?

NOT APPLY 00



REPORT ANY FAULT SYMPTOM OR PATTERN NOT SHOWN ABOVE → 52 51 XB _ _

APPLICABLE CIRCUIT BREAKERS

NONE

1 AS INSTALLED

FLIGHT DECK DOOR CONTROL PANEL – FAULT CODES

EFFECTIVITY


ALL

52-FAULT CODE DIAGRAM


05

Page 6
May 28/05

FAULT CODE/
LOCATION



WAS FLIGHT DECK ACCESS PANEL OPERATION NORMAL?



REPORT ANY FAULT SYMPTOM OR PATTERN NOT SHOWN ABOVE ▶ 52 51 XC 00

APPLICABLE CIRCUIT BREAKERS

NONE

1 ▶ AS INSTALLED

FLIGHT DECK ACCESS PANEL – FAULT CODES

EFFECTIVITY

ALL

52-FAULT CODE DIAGRAM

04

Page 7
May 28/05



BOEING
757
FAULT ISOLATION/MAINT MANUAL

FAULT CODE	LOG BOOK REPORT	FAULT ISOLATION REFERENCE
52 11 XA --	A (01=1L,02=2L,03=3L EMER,04=4L,05=1R,06=2R,07=3R EMER,08=4R) door problem was encountered which is not covered in the Fault Code Diagrams.	(01=1L,02=2L,04=4L,05=1R,06=2R,08=4R) AMM 52-11-00 (03=3L EMER,07=3R EMER) AMM 52-21-00
52 11 XB --	A (01=1L,02=2L,03=3L EMER,04=4L,05=1R,06=2R,07=3R EMER,08=4R) door air noise problem was encountered which is not covered in the Fault Code Diagrams.	(01=1L,02=2L,04=4L,05=1R,06=2R,08=4R) AMM 52-09-01 (03=3L EMER,07=3R EMER) AMM 52-09-06
52 34 XA --	A (01=FWD,02=AFT) cargo door problem was encountered which is not covered in the Fault Code Diagrams.	AMM 52-34-00
52 51 XA 00	A flight deck door problem was encountered which is not covered in the Fault Code Diagrams.	AMM 52-51-00
52 51 XB --	A flight deck door control panel problem was encountered which is not covered in the Fault Code Diagrams.	AMM 52-51-00
52 51 XC 00	A flight deck access panel problem was encountered which is not covered in the Fault Code Diagrams.	AMM 52-51-00
52 71 XA --	A (01=L,02=R,03=FWD,04=CTR,05=AFT,06=E/E) door warning indication problem was encountered by the flight crew which is not covered in Fault Code Diagrams.	AMM 52-71-00
52 11 01 --	(01=1L,02=2L,03=3L EMER,04=4L,05=1R,06=2R,07=3R EMER,08=4R) Door bustle (damaged, loose, etc.).	(01=1L,02=2L,04=4L,05=1R,06=2R,08=4R) Tighten strap through center latch (AMM 25-66-01). If problem continues, replace bustle (AMM 52-21-00).

EFFECTIVITY

ALL

52-FAULT CODE INDEX

01

Page 1
Sep 20/08



757
FAULT ISOLATION/MAINT MANUAL

FAULT CODE	LOG BOOK REPORT	FAULT ISOLATION REFERENCE
52 11 02 --	(01=1L,02=2L,03=3L EMER,04=4L,05=1R,06=2R,07=3R EMER,08=4R) Door escape slide pressure (below green band, zero).	(01=1L,02=2L,04=4L,05=1R,06=2R,08=4R) Replace passenger door escape slide (AMM 25-66-01). (03=3L EMER,07=3R EMER) Replace emergency exit door escape slide (AMM 25-66-03).
52 11 03 --	(01=1L,02=2L,04=4L,05=1R,06=2R,08=4R) Door evacuation slide arming lever difficult to position to (ENGAGE,DETACH) position.	FIM 52-11-00/101, Fig. 103, Block 1
52 11 04 --	(01=1L,02=2L,04=4L,05=1R,06=2R,08=4R) Door handle difficult to move to open position.	Check door rigging and adjust as required (AMM 52-11-00). If problem continues, repair or replace door (AMM 52-11-01), guide arm (AMM 52-11-04), camplates or lower hinge link (AMM 52-11-09), rotary snubber (AMM 52-11-10), counterbalance (AMM 52-11-11), or other components.
52 11 05 --	(01=1L,02=2L,03=3L EMER,04=4L,05=1R,06=2R,07=3R EMER,08=4R) Door handle difficult to move to close position.	Check door rigging and adjust as required (AMM 52-11-00). If problem persists, repair or replace door (AMM 52-11-01), guide arm (AMM 52-11-04), camplates or lower hinge link (AMM 52-11-09), rotary snubber (AMM 52-11-10), counterbalance (AMM 52-11-11), or other components.
52 11 06 --	(01=1L,02=2L,04=4L,05=1R,06=2R,08=4R) Door has excessive noise from air leak (describe location of noise).	Repair or replace passenger door seal (AMM 52-09-01).
52 11 07 --	(01=1L,02=2L,03=3L EMER,04=4L,05=1R,06=2R,07=3R EMER,08=4R) Door seal (torn, loose, etc.).	(01=1L,02=2L,04=4L,05=1R,06=2R,08=4R) Repair or replace passenger door seal (AMM 52-09-01). (03=3L EMER,07=3R EMER) Repair or replace emergency exit door seal (AMM 52-09-06).

EFFECTIVITY

ALL

52-FAULT CODE INDEX

01

Page 2
Sep 20/08



BOEING
757
FAULT ISOLATION/MAINT MANUAL

FAULT CODE	LOG BOOK REPORT	FAULT ISOLATION REFERENCE
52 11 08 --	(01=1L,02=2L,04=4L,05=1R,06=2R,08=4R) Door handle difficult to move.	FIM 52-11-00/101, Fig. 104, Block 1
52 11 09 --	(01=1L,02=2L,04=4L,05=1R,06=2R,08=4R) Outside door handle will not release.	Adjust exterior handle latch (AMM 52-11-13).
52 11 10 --	(01=1L,02=2L,04=4L,05=1R,06=2R,08=4R) Door damaged by loading steps, fleet service, etc.	Repair or replace door (AMM 52-11-01).
52 11 11 --	(01=1L,02=2L,04=4L,05=1R,06=2R,08=4R) Door rollers do not always engage, damaged, etc.	Adjust latch roller cranks (AMM 52-11-00) or, repair or replace damaged rollers.
52 11 12 --	(01=1L,02=2L,04=4L,05=1R,06=2R,08=4R) Door sweeper seal (damaged, loose, does not interface with floor, etc.).	Repair or replace seal.
52 11 13 --	(01=1L,02=2L,04=4L,05=1R,06=2R,08=4R) Door hold-open latch binds, broken.	Repair or replace hold-open latch (AMM 52-11-08).
52 11 14 --	(01=1L,02=2L,04=4L,05=1R,06=2R,08=4R) Door evacuation slide arming lever broken.	Repair or replace door evacuation slide arming lever.
52 11 15 --	(01=1L,02=2L,04=4L,05=1R,06=2R,08=4R) Door handle too close to slide cover.	Adjust the position of slide and slide cover (AMM 25-66-01).
52 21 01 --	(03=3L EMER,07=3R EMER) Exit door has excessive noise from air leak (describe location of noise).	Repair or replace emergency exit pressure seal (AMM 52-09-06).
52 34 01 --	(01=FWD,02=AFT) Cargo door will not open electrically. Manual operation was normal.	FIM 52-34-00/101, Fig. 103 and 104, Block 1
52 34 02 --	(01=FWD,02=AFT) Cargo door failed to open electrically or manually.	FIM 52-34-00/101, Fig. 109, Block 1

EFFECTIVITY

ALL

52-FAULT CODE INDEX

01

Page 3
Sep 20/08



BOEING
757
FAULT ISOLATION/MAINT MANUAL

FAULT CODE	LOG BOOK REPORT	FAULT ISOLATION REFERENCE
52 34 03 --	(01=FWD,02=AFT) Cargo door failed to close electrically. Manual operation was norm.	(01=FWD) FIM 52-34-00/101, Fig. 105, Block 1 (02=AFT) FIM 52-34-00/101, Fig. 106, Block 1
52 34 04 --	(01=FWD,02=AFT) Cargo door failed to close electrically or manually.	FIM 52-34-00/101, Fig. 109, Block 1
52 34 05 --	(01=FWD,02=AFT) Cargo door failed to open or close electrically. Manual operation was norm.	(01=FWD) FIM 52-34-00/101, Fig. 107, Block 1 (02=AFT) FIM 52-34-00/101, Fig. 108, Block 1
52 34 06 --	(01=FWD,02=AFT) Cargo door failed to open or close electrically or manually.	FIM 52-34-00/101, Fig. 109, Book 1
52 34 07 --	(01=FWD,02=AFT) Cargo door (opens and closes too slow, binding during open/close).	FIM 52-34-00/101, Fig. 110, Block 1
52 34 08 --	(01=FWD,02=AFT) Cargo door binding when (unlocking, locking, locking and unlocking).	FIM 52-34-00/101, Fig. 111, Block 1
52 34 09 --	(01=FWD,02=AFT) Cargo door over travels during closing (slams shut).	FIM 52-34-00/101, Fig. 112, Block 1
52 34 10 --	(01=FWD,02=AFT 1) Cargo door motor continues to run after door closed.	FIM 52-34-00/101, Fig. 112, Block 3
C2 34 11 --	(01=FWD,02=AFT 1) Cargo door locking handle stop missing.	Replace cargo door locking handle stop (AMM 52-34-22).
52 34 12 --	(01=FWD,02=AFT) Cargo door springs open excessively when unlocked.	Replace and/or adjust door down proximity switch and target (AMM 52-34-35).
52 51 01 00	FLIGHT DK DOOR UNLOCKED lgt failed to extin with door locked.	FIM 52-51-00/101, Fig. 103, Block 1
52 51 02 00	FLIGHT DK DOOR UNLOCKED sw would not unlock door.	FIM 52-51-00/101, Fig. 104, Block 1

EFFECTIVITY

ALL

52-FAULT CODE INDEX

01

Page 4
Sep 20/08



BOEING
757
FAULT ISOLATION/MAINT MANUAL

FAULT CODE	LOG BOOK REPORT	FAULT ISOLATION REFERENCE
52 51 03 00	Flight deck door will not latch.	Replace flight deck door lock unit (AMM 52-51-01).
52 51 04 00	Flight deck door difficult to (open/close).	Replace flight deck door lock unit (AMM 52-51-01).
52 51 05 00	Flight deck door handle broken.	Repair or replace flight deck door handle as required.
52 51 06 00	Flight deck door key (broken in lock, missing, etc.).	Remove broken key from lock and/or replace key.
52 51 11 00	Flight Deck Door LOCK FAIL light (inop, door locked, etc.).	FIM 52-51-00/101
52 51 12 00	Flight Deck Door AUTO UNLK light operation abnormal.	FIM 52-51-00/101
52 51 13 --	Flight Deck Door Lock Selector operation abnormal.	FIM 52-51-00/101
52 51 14 00	Flight Deck Access Panel Keypad (access code, specify key) operation abnormal.	FIM 52-51-00/101
52 51 15 00	Flight Deck Access Panel (red, amber, green) LED operation abnormal.	FIM 52-51-00/101
52 71 01 --	EICAS msg (01=L,02=R) FWD ENT DOOR displayed steady/intermittent and ENTRY DOORS open lgt on steady/intermittent with door closed.	FIM 52-71-00/101, Fig. 103, Block 1
52 71 02 --	EICAS msg (01=L,02=R) EMER DOOR displayed steady/intermittent and EMER DOORS open light on steady/intermittent with door closed.	FIM 52-71-00/101, Fig. 103, Block 1
52 71 03 00	EICAS msg FWD CARGO DOOR displayed steady/intermittent and CARGO DOORS open light on steady/intermittent with door closed.	FIM 52-71-00/101, Fig. 103, Block 1

EFFECTIVITY

ALL

52-FAULT CODE INDEX

01

Page 5
Sep 20/08



BOEING
757
FAULT ISOLATION/MAINT MANUAL

FAULT CODE	LOG BOOK REPORT	FAULT ISOLATION REFERENCE
52 71 04 00	EICAS msg FWD ACCESS DOOR displayed steady/intermittent and ACCESS DOORS open light on steady/intermittent with door closed.	FIM 52-71-00/101, Fig. 103, Block 1
52 71 05 --	EICAS msg (L,R) (03=FWD,04=CTR,05=AFT) ENT DOOR not displayed and ENTRY DOORS open light not on with door open.	FIM 52-71-00/101, Fig. 104, Block 1
52 71 06 --	EICAS msg (01=L,02=R) EMER DOOR not displayed and EMER DOORS open light not on with door open.	FIM 32-09-03/101, Fig. 103, Block 1
52 71 07 --	EICAS msg (03=FWD,05=AFT) CARGO DOOR not displayed and CARGO DOORS open light not on with door open.	FIM 32-09-03/101, Fig. 103, Block 1
52 71 08 --	EICAS msg (03=FWD,06=E/E) ACCESS DOOR not displayed and ACCESS DOORS open light not on with door open.	FIM 32-09-03/101, Fig. 103, Block 1
52 71 09 --	EICAS msg (01=L,02=R) CTR ENT DOOR displayed steady/intermittent and ENTRY DOORS open lgt on steady/intermittent with door closed.	FIM 52-71-00/101, Fig. 103, Block 1
52 71 10 --	EICAS msg (01=L,02=R) AFT ENT DOOR displayed steady/intermittent and ENTRY DOORS open lgt on steady/intermittent with door closed.	FIM 52-71-00/101, Fig. 103, Block 1
52 71 11 --	EICAS msg (01=L,02=R) ENTRY DOORS displayed steady/intermittent and ENTRY DOORS open lgt on steady/intermittent with doors closed.	FIM 52-71-00/101, Fig. 103, Block 1
52 71 12 00	EICAS msg displayed steady/intermittent and corresponding DOOR OPEN light not on.	FIM 52-71-00/101, Fig. 104A

EFFECTIVITY

ALL

52-FAULT CODE INDEX

01

Page 6
Sep 20/08



BOEING
757
FAULT ISOLATION/MAINT MANUAL

FAULT CODE	LOG BOOK REPORT	FAULT ISOLATION REFERENCE
52 71 13 00	EICAS msg EMER DOORS displayed steady/intermittent and EMER DOORS open lgt on steady/intermittent with doors closed.	FIM 52-71-00/101, Fig. 103, Block 1
52 71 14 --	EICAS msg AFT CARGO DR (03=1, 04=2) displayed steady/intermittent and CARGO DOORS open lgt on steady/intermittent with door closed.	FIM 52-71-00/101, Fig. 103, Block 1
52 71 15 00	EICAS msg CARGO DOORS displayed steady/intermittent and CARGO DOORS open lgt on steady/intermittent with doors closed.	FIM 52-71-00/101, Fig. 103, Block 1
52 71 16 00	EICAS msg E/E ACCESS DOOR displayed steady/intermittent and ACCESS DOORS open lgt on steady/intermittent with door closed.	FIM 52-71-00/101, Fig. 103, Block 1
52 71 17 00	EICAS msg ACCESS DOORS displayed steady/intermittent and ACCESS DOORS open lgt on steady/intermittent with doors closed.	FIM 52-71-00/101, Fig. 103, Block 1

EFFECTIVITY

ALL

52-FAULT CODE INDEX

06

Page 7
Sep 20/08

BOEING
757
FAULT ISOLATION/MAINT MANUAL


BITE Index

1. General

- A. Use this index to find the BITE procedure for the applicable LRU/System.
- B. The BITE procedure will provide the fault isolation instructions for the fault indications/LRU maintenance messages.

<u>LRU/System Name</u>	<u>Acronym</u>	<u>FIM Reference</u>
Air Data Computer	ADC	34-12
Air Data Inertial Reference Unit	ADIRU	34-26
Air Traffic Control Transponder	ATC	34-53
Airborne Vibration Monitor Signal Conditioner	AVM	77-31
Antiskid/Autobrake Control Unit		32-42
APU Fire Detection System		26-15
Automatic Direction Finder Receiver	ADF	34-57
APU Control Unit	ECU	49-11
Brake Temperature Monitor Unit		32-46
Bus Power Control Unit	BPCU	24-20
Cabin Pressure Controller		21-30
Digital Flight Data Acquisition Unit	DFDAU	31-31
Distance Measuring Equipment Interrogator	DME	34-55
Duct Leak (Wing and Body)		26-18
E/E Cooling Control Card (If cards installed)		21-58
ECS Bleed Configuration Card		36-10
Electronic Engine Control (RR Engines)	EEC	73-21
Electronic Engine Control Monitor Unit (PW Engines)	EECM	71-EPCS Message Index
Electronic Flight Instrument System	EFIS	34-22
Electronic Propulsion Control System (PW Engines)	EPCS	71-EPCS Message Index
Engine Fire/Overheat Detection System		26-11
Engine Indication and Crew Alerting System Computer	EICAS	31-41

Bite Index
Figure 1 (Sheet 1)



52-BITE INDEX


01

Page 1
Sep 28/99


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

<u>LRU/System Name</u>	<u>Acronym</u>	<u>FIM Reference</u>
Engine Turbine Cooling Overheat Detection System (RR Engines)		26-13
Enhanced Ground Proximity Warning Computer	EGPWC	34-46
Flap/Slat Accessory Module	FSAM	27-51
Flap/Slat Electronic Unit	FSEU	27-51
Flight Management Computer	FMC	34-61
Fuel Quantity Indicating System Processor	FQIS	28-41
Ground Proximity Warning Computer	GPWC	34-46
HF (High Frequency) Communication		23-11
Inertial Reference Unit	IRU	34-21
Instrument Comparator Unit	ICU	34-25
Instrument Landing System Receiver	ILS	34-31
Lower Cargo Compartment Smoke Detection System		26-16
Maintenance Control Display Panel	MCDP	22-00
PA (Passenger Address) Amplifier		23-31
Pack Standby Temperature Controller		21-51
Pack Temperature Controller		21-51
Passenger Entertainment System	PES	23-34
Power Supply Module (Control System Electronics Units)	PSM	27-09
Propulsion Discrete Interface Unit (PW Engines)	PDIU	73-21
Proximity Switch Electronics Unit	PSEU	32-09
Radio Altimeter Transmitter/Receiver	RA	34-33
Rudder Ratio Changer Module	RRCM	27-09
Spoiler Control Module	SCM	27-09
Stabilizer Position Module	SPM	27-48
Stabilizer Trim/Elevator Asymmetry Limit Module	SAM	27-09
Stall Warning Computer/Module (in Warning Electronic Unit)	SWC	27-32
Strut Overheat Detection System (RR Engines)		26-12

Bite Index
Figure 1 (Sheet 2)




52-BITE INDEX


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

<u>LRU/System Name</u>	<u>Acronym</u>	<u>FIM Reference</u>
Thrust Management Computer/Autothrottle	TMC	22-00
Traffic Alert and Collision Avoidance Computer	TCAS	34-45
VHF (Very High Frequency) Communication		23-12
VOR/Marker Beacon Receiver	VOR/MKR	34-51
Warning Electronic Unit BITE Module (Stall Warning)	WEU	27-32
Weather Radar Transceiver	WXR	34-43
Wheel Well Fire Detection		26-17
Window Heat Control Unit	WHCU	30-41
Yaw Damper Module	YDM	22-21
Yaw Damper/Stabilizer Trim Module	YSM	27-09
Zone Temperature Controller		21-60

Bite Index
Figure 1 (Sheet 3)



52-BITE INDEX

01

Page 3
Sep 28/99

 **BOEING**
757
FAULT ISOLATION/MAINT MANUAL

PASSENGER DOORS

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
ACTUATOR - EMERGENCY POWER	7	6		
DOOR NO. 1 LEFT			221AL	52-11-31
DOOR NO. 1 RIGHT			222AR	52-11-31
DOOR NO. 2 LEFT			231AL	52-11-34
DOOR NO. 2 RIGHT			232AR	52-11-34
DOOR NO. 4 LEFT			251AL	52-11-35
DOOR NO. 4 RIGHT			252AR	52-11-35
ARM - GUIDE	3,4	6	BOTTOM OF THE BODY HINGE TORQUE TUBES	52-11-04
ARMS - HINGE	3,4	12	TOP AND BOTTOM OF THE DOOR HINGE TORQUE TUBES	52-11-00
CHAIN - EMERGENCY POWER	4,7	6	EMERGENCY POWER ACTUATOR	
DOOR NO. 1 LEFT AND DOOR NO. 1 RIGHT				52-11-31
DOOR NO. 2 LEFT AND DOOR NO. 2 RIGHT				52-11-34
DOOR NO. 4 LEFT AND DOOR NO. 4 RIGHT				52-11-35
COUNTERBALANCE - CAMSHAFT/SPRING CYLINDER	4	6	BODY HINGE TORQUE TUBE	52-11-11
DOOR - PASSENGER	1	6		52-11-01
NO. 1 LEFT			831	
NO. 1 RIGHT			841	
NO. 2 LEFT			832	
NO. 2 RIGHT			842	
NO. 4 LEFT			834	
NO. 4 RIGHT			844	
LINING - DOOR	2	6	ALL PASSENGER DOORS	52-11-02
LOCK - HOLD OPEN	4	6	BODY HINGE TORQUE TUBES	52-11-00
MECHANISM - DOOR EMERGENCY	5,6	6	ALL PASSENGER DOORS	52-11-20
MECHANISM - DOOR HANDLE	5,6	6	ALL PASSENGER DOORS	52-11-13
MECHANISM - GIRT BAR	5,6	6	ALL PASSENGER DOORS	52-11-25
RESERVOIR - EMERGENCY POWER	7	6		52-11-30
DOOR NO. 1 LEFT AND DOOR NO. 1 RIGHT			ABOVE ACCESS PANEL IN THE CEILING BETWEEN THE DOORS	
DOOR NO. 2 LEFT AND DOOR NO. 2 RIGHT			ABOVE PASSENGER SERVICE UNIT	
DOOR NO. 4 LEFT AND DOOR NO. 4 RIGHT			ABOVE EACH DOOR	
			ABOVE ACCESS PANEL IN THE CEILING	
			ABOVE EACH DOOR	
SNUBBER - ROTARY	4	6	BODY HINGE TORQUE TUBE	52-11-10
SPRING CYLINDER - EMERGENCY POWER	7	6	EMERGENCY POWER RESERVOIR	52-11-33
TORQUE TUBE - BODY	4	6	FUSELAGE STRUCTURE FORWARD OF THE DOOR	52-11-00
TORQUE TUBE - LATCH	3	12	TWO ON EACH PASSENGER DOOR	52-11-00
TORQUE TUBE - DOOR	3	6	ALL PASSENGER DOORS	52-11-00
TRIGGER - EMERGENCY POWER	3	6	BODY HINGE TORQUE TUBE	52-11-32

Passenger Doors - Component Index
Figure 101

EFFECTIVITY



ALL

52-11-00

02

Page 101
Jun 20/91


BOEING
757
FAULT ISOLATION/MAINT MANUAL



Passenger Doors - Component Location
Figure 102 (Sheet 1)


EFFECTIVITY	ALL
-------------	-----

52-11-00



NO. 1, 2, OR 4 PASSENGER DOOR
(INTERNAL MECHANISMS)
(EXAMPLE)

(A)



NO. 1, 2 OR 4 PASSENGER DOOR
(INTERNAL VIEW)
(EXAMPLE)

(A)

Passenger Doors - Component Location (Detail from Sht 1)
Figure 102 (Sheet 2)


EFFECTIVITY

ALL

52-11-00

01

Page 103
Jun 20/91




Passenger Doors - Component Location (Details from Sht 2)
Figure 102 (Sheet 3)

EFFECTIVITY	
	ALL

52-11-00

BOEING
757
FAULT ISOLATION/MAINT MANUAL




Passenger Doors - Component Location (Detail from Sht 2)
Figure 102 (Sheet 4)

EFFECTIVITY	
	ALL


52-11-00

02

Page 105
Jun 20/91




NO. 1 PASSENGER DOOR EMERGENCY MECHANISM (EXAMPLE)





Passenger Doors - Component Location
Figure 102 (Sheet 5)

EFFECTIVITY	
	ALL


52-11-00



NO. 4 PASSENGER DOOR EMERGENCY MECHANISM
(EXAMPLE)



NO. 2 PASSENGER DOOR EMERGENCY MECHANISM
(EXAMPLE)




Passenger Doors - Component Location
Figure 102 (Sheet 6)

EFFECTIVITY	
	ALL

52-11-00

BOEING
757
FAULT ISOLATION/MAINT MANUAL




Passenger Doors - Component Location
Figure 102 (Sheet 7)

EFFECTIVITY	
	ALL

52-11-00

**GUIDELINES FOR
GENERAL DOOR FAULT
ISOLATION**

PREREQUISITES:
NONE




General Guidelines for Door Fault Isolation
Figure 103 (Sheet 1)

EFFECTIVITY

ALL

52-11-00




General Guidelines for Door Fault Isolation
Figure 103 (Sheet 2)

EFFECTIVITY

ALL

52-11-00



1

Door Adjustments (Example)
Figure 104

EFFECTIVITY	
	ALL


52-11-00

01


Page 111
Jan 20/98

H01959


BOEING
757
FAULT ISOLATION/MAINT MANUAL




1. ARMED AND LATCHED




2. DOOR NOT LATCHED - UPPER AND LOWER GATES FOLDED IN - MOTION TO COCK BEGINS



3. DOOR FULLY COCKED - READY TO BE OPENED



4. DOOR NOT FULLY OPEN



5. DOOR FULLY OPEN

1 YOU CAN USE THE ASSIST HANDLE TO PULL THE DOOR TO THE COCKED POSITION.

Passenger Door Cycles
Figure 105

EFFECTIVITY	ALL
-------------	-----

52-11-00


PREREQUISITES
NONE

WARNING: THIS CHART GIVES GENERAL DATA TO POINT THE USER TO THE PROBLEM DOOR CYCLE. MAKE SURE THAT A COMPONENT IS DEFECTIVE BEFORE YOU REPLACE IT.

NOTE: GREATER THAN NORMAL WORN AREAS SHOW:
 • INCORRECT DOOR RIGGING
 • WORN TORQUE TUBE BEARINGS
 • WORN GUIDE ARM BEARINGS

WEAR IS FOUND ON THE LATCH FITTINGS


NOTE: REPLACEMENT OF WORN PARTS WILL OCCUR IN ANOTHER PROCEDURE.




Wear Is Found on the Latch Fittings
Figure 106

EFFECTIVITY ————
ALL


52-11-00



NO. 1, 2, OR 4 PASSENGER DOOR



LATCH FITTING
(ON FUSELAGE)
(A)



DOOR FRAME

1 WEAR IN THIS AREA INDICATES THAT THE DOOR IS NOT ADJUSTED CORRECTLY

Upper Latch Fitting Wear
Figure 107


EFFECTIVITY	ALL
-------------	-----

52-11-00

HO2126

DOOR IS DIFFICULT TO LATCH/UNLATCH

PREREQUISITES
NONE




Door Is Difficult to Latch/Unlatch
Figure 108 (Sheet 1)

EFFECTIVITY ————
ALL

52-11-00

H03777

FROM SHEET 1
(BLOCK 4)



Door Is Difficult to Latch/Unlatch
Figure 108 (Sheet 2)

EFFECTIVITY


ALL

52-11-00

01

Page 116
Sep 28/99

HD3779



Latch/Unlatch Components
Figure 109 (Sheet 1)


EFFECTIVITY	
	ALL

52-11-00

01


Page 117
Jan 20/98

HD1966




- NOTE:** TURN THE ADJUSTMENT NUT TO CHANGE THE LENGTH OF THE GUIDE ARM:
- MAKE THE ARM SHORTER TO MOVE THE AFT EDGE OF THE DOOR INBOARD.
 - MAKE THE ARM LONGER TO MOVE THE AFT EDGE OF THE DOOR OUTBOARD.
 - THE SERRATED PLATE ADJUSTMENTS GIVES THE GREATEST AMOUNT OF ADJUSTMENT.

**DOOR ADJUSTMENT
(TOP VIEW)**




- NOTE:** IF YOU MAKE THE PUSHROD LONGER, YOU WILL MOVE THE DOOR OUTBOARD. THE EXTERNAL HANDLE FORCE INCREASES AS YOU ADJUST THE DOOR OUTBOARD.

**HANDLE ADJUSTMENT
(TOP VIEW)**




Latch/Unlatch Components
Figure 109 (Sheet 2)



52-11-00

DOOR IS DIFFICULT TO COCK

PREREQUISITES
NONE




Door Is Difficult to Cock
Figure 110

EFFECTIVITY

ALL

52-11-00



NO. 1, 2, OR 4 PASSENGER DOOR
(EXAMPLE)

Cocking Components
Figure 111

EFFECTIVITY	
	ALL


52-11-00

01

Page 120
Jan 20/98

DOOR IS DIFFICULT TO CLOSE/OPEN

PREREQUISITES
NONE



Door Is Difficult to Close/Open
Figure 112 (Sheet 1)

EFFECTIVITY ————
ALL

52-11-00


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FROM SHEET 1
(BLOCK 5)

NO

6 EXAMINE THE DOOR
CLOSE/OPEN MECHANISMS FOR
CORRECT OPERATION.

7 MOVE THE DOOR FULL OPEN.
DOES THE HOLD-OPEN LOCK
FAIL TO HOLD THE DOOR OPEN OR
IS IT DIFFICULT TO RELEASE?

YES

13 LOOK AT THE HOLD-OPEN LOCK
MECHANISM.
IS THE HOLD-OPEN LOCK
HOOK, OR LIFT LEVER AND SHELF
BROKEN?

YES

27 REMOVE AND REPLACE THE
BROKEN PARTS
(AMM 52-11-08/401).

NO

28 LUBRICATE THE HOLD-OPEN
LOCK HOOK SPRING AND SHAFT.

Door Is Difficult to Close/Open
Figure 112 (Sheet 2)

EFFECTIVITY


ALL

52-11-00

01

Page 122
May 28/99

H10260



Close/Open Components
Figure 113

EFFECTIVITY

ALL


52-11-00

01

Page 123
Jan 20/98

DOOR IS DIFFICULT TO ARM/DISARM

PREREQUISITES
NONE




Door Is Difficult to Arm/Disarm
Figure 114


EFFECTIVITY

ALL

52-11-00




NO. 1 OR 4 PASSENGER DOOR
(LEFT DOOR IS SHOWN, RIGHT DOOR IS OPPOSITE)



CRANK STOP

(B)



GIRT BAR MECHANISM

(A)

Arm/Disarm Components
Figure 115 (Sheet 1)

EFFECTIVITY


ALL

52-11-00

01

Page 125
Jan 20/98

HO2179




Arm/Disarm Components
Figure 115 (Sheet 2)

EFFECTIVITY	
	ALL

52-11-00

EMERGENCY POWER ASSIST SYSTEM (EPAS) IS DIFFICULT TO ADJUST

PREREQUISITES
NONE



Emergency Power Assist System (EPAS) Is Difficult to Adjust
Figure 116 (Sheet 1)

EFFECTIVITY


ALL

52-11-00


01

Page 127
Sep 20/98

HD4006




Emergency Power Assist System (EPAS) Is Difficult to Adjust
Figure 116 (Sheet 2)



52-11-00

BOEING
757
FAULT ISOLATION/MAINT MANUAL



EMERGENCY POWER SYSTEM

1 THE ARROWS SHOW THE DIRECTION OF MOVEMENT DURING EMERGENCY OPERATION.

EPAS Components
Figure 117

EFFECTIVITY	ALL
-------------	-----


52-11-00


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

NO. 3 EMERGENCY EXIT

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
BUTTON - RELEASE	2	4	TWO ON EACH EXIT	52-21-00
DOOR - PRESSURE RELIEF	2	2	EMERGENCY EXIT	52-21-00
EXIT - NO. 3 EMERGENCY	1	2		52-21-01
LEFT			835	
RIGHT			845	
FITTING - STOP	2	20	FORWARD AND AFT EDGES OF EMERGENCY EXIT	52-21-00
HANDLE - INTERIOR	1	2	INTERIOR OF EMERGENCY EXIT	52-21-00
LINING - NO. 3 EMERGENCY EXIT	1	2	INTERIOR OF EMERGENCY EXIT	52-21-02
SNUBBER	2	4	EMERGENCY EXIT HINGES	52-21-00

No. 3 Emergency Exit - Component Index
Figure 101





52-21-00

01

Page 101
Sep 20/94

E44899

BOEING
 757
 FAULT ISOLATION/MAINT MANUAL




INSIDE VIEW OF NO. 3 EMERGENCY EXIT

(A)


No. 3 Emergency Exit - Component Location
 Figure 102 (Sheet 1)

EFFECTIVITY	
	ALL

52-21-00



**NO. 3 EMERGENCY EXIT
(SHOWN WITH LINING AND ESCAPE SLIDE REMOVED)**



**Component Location
Figure 102 (Sheet 2)**

EFFECTIVITY	
	ALL

52-21-00

01

Page 103
Sep 20/94

54721

BOEING
757
FAULT ISOLATION/MAINT MANUAL

NO. 1 AND 2 CARGO DOORS

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
ACTUATOR - ROTARY, HINGE DRIVE	2	4	CEILING, ABOVE CARGO DOOR	52-34-06
ARM - HINGE	2	4	CARGO DOOR	
CIRCUIT BREAKERS			119BL, MAIN EQUIP CTR, P34	*
CARGO DOOR CONT, C1403		1	34A5	*
NO. 1 CARGO DOOR, C360		1	34A1	*
NO. 2 CARGO DOOR, C361		1	34A2	*
DOOR - CARGO, NO. 1	1	1	821	52-34-01
DOOR - CARGO, NO. 2	1	1	822	52-34-01
GEARBOX - MANUAL DRIVE	2	2	FUSELAGE, FWD OF CARGO DOOR	52-34-03
HANDLE MECHANISM	2	2	CARGO DOOR	52-34-22
HINGE LINKAGE	2	4	CARGO DOOR	52-34-09
POWER UNIT - HINGE DRIVE	2	2	CEILING, ABOVE CARGO DOOR	52-34-05
RELAY - (REF 31-01-65, FIG. 101)				
PDU RAISE RELAY, K10411				
PDU LOWER RELAY, K10412				
RELAY - (REF 31-01-86, FIG. 101)				
PDU RAISE RELAY, K10413				
PDU LOWER RELAY, K10414				
SENSORS - NO. 1 CARGO DOOR, PROXIMITY				
OPEN A, S10350	1	1	821, FUSELAGE FRAME AT CARGO DOOR	52-34-35
DOWN A, S10352	1	1	821, FUSELAGE FRAME AT CARGO DOOR	52-34-35
SENSORS - NO. 2 CARGO DOOR, PROXIMITY				
OPEN A, S10357	1	1	822, FUSELAGE FRAME AT CARGO DOOR	52-34-35
DOWN A, S10359	1	1	822, FUSELAGE FRAME AT CARGO DOOR	52-34-35
SWITCH - NO. 1 CARGO DOOR, CONTROL				
EXTERIOR, S10183	1	1	122AR, P43, AFT OF CARGO DOOR	52-34-30
INTERIOR, S10180	1	1	821, P41, FWD CARGO COMPT CEILING	52-34-30
SWITCH - NO. 2 CARGO DOOR, CONTROL				
EXTERIOR, S10182	1	1	154AR, P44, AFT OF CARGO DOOR	52-34-30
INTERIOR, S10181	1	1	822, P42, AFT CARGO COMPT CEILING	52-34-30
SWITCH - NO. 1 CARGO DOOR, INTERLOCK, S10561	1	1	821, INSIDE CARGO DOOR	*
SWITCH - NO. 2 CARGO DOOR, INTERLOCK, S10562	1	1	822, INSIDE CARGO DOOR	*
TRACK - LATCH	1	4	FUSELAGE FRAME AT CARGO DOOR	52-34-19

* SEE WDM EQUIPMENT LIST

No. 1 and 2 Cargo Doors - Component Index
Figure 101

EFFECTIVITY



ALL

52-34-00

BOEING

757

FAULT ISOLATION/MAINT MANUAL



INTERIOR
NO. 1 OR 2 CARGO
DOOR CONTROL SWITCH,
S10180 OR S10181


EXTERIOR
NO. 1 OR 2 CARGO
DOOR CONTROL SWITCH,
S10182 OR S10183

INTERNAL CARGO DOOR CONTROL
PANEL, P41 OR P42

(B)

NO. 1 OR 2 CARGO DOOR

(A)



EXTERNAL CARGO DOOR CONTROL
PANEL, P43 OR P44


(C)

No. 1 and 2 Cargo Doors - Component Location
Figure 102 (Sheet 1)

EFFECTIVITY


ALL

52-34-00



HINGE LINK

(D)



**NO. 1 OR 2 CARGO DOOR
(CLOSED POSITION)**

(E)

No. 1 and 2 Cargo Doors - Component Location (Details from Sht 1)
Figure 102 (Sheet 2)

EFFECTIVITY



ALL

52-34-00

02

Page 103
Dec 20/95


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL



No. 1 and 2 Cargo Doors - Component Location
Figure 102 (Sheet 3)

EFFECTIVITY	ALL
-------------	-----

52-34-00

01

Page 104
Dec 20/95

107768

NO. 1 AND NO. 2 CARGO DOOR – FAULT ISOLATION

1. General

A. This procedure contains the trouble-shooting for the No. 1 and the No. 2 cargo doors. It has figures that contain the trouble-shooting procedures for specific cargo door failures. It also contains a fault isolation tip if a failure in another system affects the cargo doors.

2. Fault Isolation Tip

A. During ground operation it is possible for a protective feature in the ground power system to operate. This will cause the ground power system to fail to supply power to the cargo doors. Any one of these steps will reset the ground power system:

- (1) Remove and re-apply electrical power from the ground power system (AMM 24-22-00/201).
- (2) Depress the ground service switch on the forward flight attendants panel.
- (3) Remove and re-install the ground power plug in the external receptacle.

B. If the problem remains do the bite test of the bus power control unit (BPCU) found in chapter 24-3 of the 757 BITE manual.

EFFECTIVITY

ALL

52-34-00

01


Page 105
Dec 20/95

NO. 1 (FWD) CARGO DOOR WILL NOT OPEN ELECTRICALLY. MANUAL OPERATION WAS NORMAL.

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
34A1, 34A5

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)
DOOR IS CLOSED BUT NOT LATCHED



No. 1 (Fwd) Cargo Door Will Not Open Electrically. Manual Operation Was Normal. Figure 103 (Sheet 1)

EFFECTIVITY


ALL

52-34-00

01

Page 106
May 28/07

 **BOEING**
757
FAULT ISOLATION/MAINT MANUAL



No. 1 (Fwd) Cargo Door Will Not Open Electrically. Manual Operation was Normal.
Figure 103 (Sheet 2)

EFFECTIVITY


ALL

52-34-00

03

Page 107
May 28/07

BOEING
757
FAULT ISOLATION/MAINT MANUAL




No. 1 (Fwd) Cargo Door Will Not Open Electrically. Manual Operation was Normal.
Figure 103 (Sheet 3)

EFFECTIVITY

ALL

52-34-00



No. 1 (Fwd) Cargo Door Will Not Open Electrically. Manual Operation was Normal.
Figure 103 (Sheet 4)

EFFECTIVITY ————
ALL

52-34-00


E47557

NO. 2 (AFT) CARGO DOOR FAILED TO OPEN ELECTRICALLY. MANUAL OPERATION WAS NORMAL.

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
34A2, 34A5


MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201).
DOOR IS CLOSED BUT NOT LATCHED



No. 2 (Aft) Cargo Door Failed to Open Electrically. Manual Operation Was Normal. Figure 104 (Sheet 1)

EFFECTIVITY	
	ALL

52-34-00



No. 2 (Aft) Cargo Door Failed to Open Electrically. Manual Operation was Normal.
Figure 104 (Sheet 2)

EFFECTIVITY

ALL

52-34-00

04


Page 111
May 28/07



757

FAULT ISOLATION/MAINT MANUAL


FROM SHEET 2 (BLOCK 12)




No. 2 (Aft) Cargo Door Failed to Open Electrically. Manual Operation was Normal. Figure 104 (Sheet 3)

EFFECTIVITY	ALL
-------------	-----

52-34-00



No. 2 (Aft) Cargo Door Failed to Open Electrically. Manual Operation was Normal.
Figure 104 (Sheet 4)




52-34-00

**NO. 1 (FWD) CARGO
 DOOR FAILED TO CLOSE
 ELECTRICALLY.
 MANUAL OPERATION
 WAS NORMAL.**

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
34A1,34A5


MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)
CARGO DOOR IS OPEN



No. 1 (Fwd) Cargo Door Failed to Close Electrically. Manual Operation was Normal. Figure 105 (Sheet 1)

EFFECTIVITY	
	ALL

52-34-00



No. 1 (Fwd) Cargo Door Failed to Close Electrically. Manual Operation was Normal.
Figure 105 (Sheet 2)

EFFECTIVITY

ALL

52-34-00


05

Page 115
May 28/07

BOEING
757
FAULT ISOLATION/MAINT MANUAL

FROM SHEET 2
(BLOCK 4)

FROM SHEET 2
(BLOCK 13)



No. 1 (Fwd) Cargo Door Failed to Close Electrically. Manual Operation was Normal.
Figure 105 (Sheet 3)

EFFECTIVITY

ALL

52-34-00

03

Page 116
May 28/07


248184

**NO. 2 (AFT) CARGO
DOOR FAILED TO
CLOSE ELECTRICALLY.
MANUAL OPERATION
WAS NORMAL.**

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
34A1,34A5

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)
CARGO DOOR IS OPEN



No. 2 (Aft) Cargo Door Failed to Close Electrically. Manual Operation was Normal. Figure 106 (Sheet 1)


EFFECTIVITY

ALL

52-34-00

03

Page 117
Sep 20/94



No. 2 (Aft) Cargo Door Failed to Close Electrically. Manual Operation was Normal. Figure 106 (Sheet 2)

EFFECTIVITY

ALL

52-34-00


04

Page 118
May 28/07

BOEING
757
FAULT ISOLATION/MAINT MANUAL

FROM SHEET 2
(BLOCK 4)

FROM SHEET 4
(BLOCK 13)



No. 2 (Aft) Cargo Door Failed to Close Electrically. Manual Operation was Normal.
Figure 106 (Sheet 3)

EFFECTIVITY _____
ALL


52-34-00

**NO. 1 (FWD) CARGO
DOOR FAILED TO OPEN
OR CLOSE ELECTRICALLY.
MANUAL OPERATION WAS
NORMAL.**

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
34A1, 34A5


MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)
DOOR IS CLOSED BUT NOT LATCHED



No. 1 (Fwd) Cargo Door Failed to Open or Close Electrically.
Manual Operation was Normal.
Figure 107 (Sheet 1)

EFFECTIVITY	ALL
-------------	-----

52-34-00



No. 1 (Fwd) Cargo Door Failed to Open or Close Electrically.
Manual Operation was Normal.
Figure 107 (Sheet 2)

EFFECTIVITY


ALL

52-34-00

04

Page 121
May 28/07

BOEING
757
FAULT ISOLATION/MAINT MANUAL



No. 1 (Fwd) Cargo Door Failed to Open or Close Electrically.
Manual Operation was Normal.
Figure 107 (Sheet 3)

EFFECTIVITY	ALL
-------------	-----

52-34-00

BOEING
757
FAULT ISOLATION/MAINT MANUAL

FROM SHEET 2
(BLOCK 6)

FROM SHEET 3
(BLOCK 14)

NO

YES

15 WITH THE INTERIOR CARGO DOOR CONTROL SWITCH, S10180, IN THE "OPEN" POSITION, PUT A JUMPER AND DO A CHECK FOR 28V DC ON CONNECTOR D4806 BETWEEN PIN X1 AND PIN X2 (WDM 52-34-11).
IS THERE 28V DC BETWEEN THE PINS?

YES

29 REPLACE THE HINGE POWER UNIT RAISE RELAY, K10411 (WDM 52-34-11).
INSTALL CONNECTOR D4806 ON THE HINGE POWER UNIT RAISE RELAY, K10411.
MAKE SURE THE CARGO DOOR OPENS AND CLOSES ELECTRICALLY (AMM 52-34-00/201).

NO

30 DO A CHECK AND REPLACE THE CARGO DOOR MOTOR INTERLOCK SWITCH, S10561 (WDM 52-34-11).
IF THE PROBLEM CONTINUES, EXAMINE THE CIRCUIT FROM THE CARGO DOOR MOTOR INTERLOCK SWITCH, S10561, PIN 2, TO THE INTERIOR CARGO DOOR CONTROL SWITCH, S10180, PIN 1 (WDM 52-34-11).
REPAIR THE PROBLEMS THAT YOU FIND.
IF THE PROBLEM CONTINUES, EXAMINE THE CIRCUIT FROM THE CARGO DOOR MOTOR INTERLOCK SWITCH, S10561, PIN 1 TO THE HINGE POWER UNIT RAISE RELAY, K10411, PIN X1 (WDM 52-34-11).
REPAIR THE PROBLEMS THAT YOU FIND.
MAKE SURE THE CARGO DOOR OPENS AND CLOSES ELECTRICALLY (AMM 52-34-00/201).

31 EXAMINE THE CIRCUIT FROM THE HINGE POWER UNIT LOWER RELAY, K10412, PINS A2, B2, C2, TO THE P34 APU/EXTERNAL POWER PANEL, CONNECTOR D40080P, PINS 1, 2, 3 (WDM 52-34-11).
REPAIR THE PROBLEMS THAT YOU FIND.
INSTALL CONNECTOR D4808 ON THE HINGE POWER UNIT LOWER RELAY, K10412.
MAKE SURE THE CARGO DOOR OPENS AND CLOSES ELECTRICALLY (AMM 52-34-00/201).

No. 1 (Fwd) Cargo Door Failed to Open or Close Electrically.
Manual Operation was Normal.
Figure 107 (Sheet 4)

EFFECTIVITY

ALL

52-34-00

12

Page 123
May 28/07


335940

**NO. 2 (AFT) CARGO DOOR
FAILED TO OPEN OR
CLOSE ELECTRICALLY.
MANUAL OPERATION WAS
NORMAL.**

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
34A2, 34A5

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)
DOOR IS CLOSED BUT NOT LATCHED



No. 2 (Aft) Cargo Door Failed to Open or Close Electrically.
Manual Operation was Normal.
Figure 108 (Sheet 1)


EFFECTIVITY

ALL

52-34-00

03

Page 124
May 28/07



No. 2 (Aft) Cargo Door Failed to Open or Close Electrically.
Manual Operation was Normal.
Figure 108 (Sheet 2)

EFFECTIVITY


ALL

52-34-00

04

Page 125
May 28/07

BOEING
757
FAULT ISOLATION/MAINT MANUAL



No. 2 (Aft) Cargo Door Failed to Open or Close Electrically.
Manual Operation was Normal.
Figure 108 (Sheet 3)

EFFECTIVITY	ALL
-------------	-----

52-34-00

BOEING
757
FAULT ISOLATION/MAINT MANUAL

FROM SHEET 2
(BLOCK 6)

FROM SHEET 3
(BLOCK 14)

NO

YES

15 WITH THE INTERIOR CARGO DOOR CONTROL SWITCH, S10181, IN THE "OPEN" POSITION, PUT A JUMPER AND DO A CHECK FOR 28V DC ON CONNECTOR D4810 BETWEEN PIN X1 AND PIN X2 (WDM 52-35-11).
IS THERE 28V DC BETWEEN THE PINS?

YES

29 REPLACE THE HINGE POWER UNIT RAISE RELAY, K10413 (WDM 52-35-11).
INSTALL CONNECTOR D4810 ON THE HINGE POWER UNIT RAISE RELAY, K10413.
MAKE SURE THE CARGO DOOR OPENS AND CLOSES ELECTRICALLY (AMM 52-34-00/201).

NO

30 DO A CHECK AND REPLACE THE CARGO DOOR MOTOR INTERLOCK SWITCH, S10562 (WDM 52-35-11).
IF THE PROBLEM CONTINUES, EXAMINE THE CIRCUIT FROM THE CARGO DOOR MOTOR INTERLOCK SWITCH, S10562, PIN 2, TO THE INTERIOR CARGO DOOR CONTROL SWITCH, S10181, PIN 1 (WDM 52-35-11).
REPAIR THE PROBLEMS THAT YOU FIND.
IF THE PROBLEM CONTINUES, EXAMINE THE CIRCUIT FROM THE CARGO DOOR MOTOR INTERLOCK SWITCH, S10562, PIN 1, TO THE HINGE POWER UNIT RAISE RELAY, K10413, PIN X1 (WDM 52-35-11).
REPAIR THE PROBLEMS THAT YOU FIND.
MAKE SURE THE CARGO DOOR OPENS AND CLOSES ELECTRICALLY (AMM 52-34-00/201).

31 EXAMINE THE CIRCUIT FROM THE HINGE POWER UNIT LOWER RELAY, K10414, PINS A2, B2, C2, TO THE P34 APU/EXTERNAL POWER PANEL, CONNECTOR D40188P, PINS 4, 7, 10 (WDM 52-35-11).
REPAIR THE PROBLEMS THAT YOU FIND.
INSTALL CONNECTOR D4812 ON THE HINGE POWER UNIT LOWER RELAY, K10414.
MAKE SURE THE CARGO DOOR OPENS AND CLOSES ELECTRICALLY (AMM 52-34-00/201).

No. 2 (Aft) Cargo Door Failed to Open or Close Electrically.
Manual Operation was Normal.
Figure 108 (Sheet 4)

EFFECTIVITY

ALL

52-34-00

11

Page 127
May 28/07

335947

NO. 1 OR NO. 2
 CARGO DOOR FAILED
 TO OPEN OR CLOSE
 ELECTRICALLY OR
 MANUALLY.

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:


- NO. 1 CARGO DOOR, 34A1 AND 34A5
- NO. 2 CARGO DOOR, 34A2 AND 34A5

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:

- NO. 1 OR 2 CARGO DOOR IS NOT LATCHED

EQUIPMENT:


- CARGO DOOR SLING B52016-1



No. 1 or No. 2 Cargo Door Failed to Open or Close
 Electrically or Manually.
 Figure 109 (Sheet 1)

EFFECTIVITY	ALL
-------------	-----

52-34-00



No. 1 or No. 2 Cargo Door Failed to Open or Close
 Electrically or Manually.
 Figure 109 (Sheet 2)

EFFECTIVITY

ALL

52-34-00

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:

- NO. 1 CARGO DOOR, 34A1 AND 34A5
- NO. 2 CARGO DOOR, 34A2 AND 34A5


MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:

- NO. 1 OR 2 CARGO DOOR IS NOT LATCHED

EQUIPMENT:

- CARGO DOOR SLING B52016-1

**NO. 1 OR NO. 2
CARGO DOOR OPENS
AND CLOSES TOO
SLOWLY**



No. 1 or No. 2 Cargo Door Opens and Closes too Slowly
Figure 110 (Sheet 1)


EFFECTIVITY

ALL


52-34-00

02

Page 130
Sep 20/94




No. 1 or No. 2 Cargo Door Opens and Closes too Slowly
Figure 110 (Sheet 2)



52-34-00

NO. 1 (FWD) OR NO. 2 (AFT) CARGO DOOR BINDING WHEN (UNLOCKING, LOCKING, LOCKING AND UNLOCKING)


PREREQUISITES
 NONE



No. 1 (Fwd) or No. 2 (Aft) Cargo Door Binding When (Unlocking, Locking, Locking and Unlocking)
 Figure 111 (Sheet 1)

EFFECTIVITY
 ALL

52-34-00



No. 1 (Fwd) or No. 2 (Aft) Cargo Door Binding When (Unlocking, Locking,
 Locking and Unlocking)
 Figure 111 (Sheet 2)

EFFECTIVITY	ALL
-------------	-----

52-34-00

**NO. 1 OR NO. 2 CARGO
DOOR OVERTRAVELS
DURING CLOSING
(SLAMS SHUT)**


PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:

- NO. 1 CARGO DOOR, 34A1 AND 34A5
- NO. 2 CARGO DOOR, 34A2 AND 34A5

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:

ELECTRICAL POWER IS ON (MM 24-22-00/201)



No. 1 or No. 2 Cargo Door Overtravels During Closing (Slams Shut)
Figure 112

EFFECTIVITY	ALL
-------------	-----

52-34-00


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

NO. 3 CARGO DOOR

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
ARM - HINGE	---	2	823, AFT CARGO COMPARTMENT	52-36-12
DOOR - NO. 3 CARGO	---	1	823, AFT CARGO COMPARTMENT	52-36-01
MECHANISM - COUNTERBALANCE	---	1	823, AFT CARGO COMPARTMENT	52-36-15
MECHANISM - DOOR LATCHING	---	1	823, AFT CARGO COMPARTMENT	52-36-00
SENSOR - PROXIMITY NO. 3 CARGO DOOR WARNING, S10089 (REF 52-71-00, FIG. 101)	---	1		
SNUBBER - DOOR	---	1	823, AFT CARGO COMPARTMENT	52-36-13

* SEE THE WDM EQUIPMENT LIST

No. 3 Cargo Door - Component Index
Figure 101

EFFECTIVITY
AIRPLANES WITH NO. 3 CARGO DOOR



52-36-00

01

Page 101
Sep 20/90

107090

BOEING
757
FAULT ISOLATION/MAINT MANUAL



No. 3 Cargo Door - Component Location
Figure 102

EFFECTIVITY
AIRPLANES WITH NO. 3 CARGO DOOR

52-36-00

BOEING
757
FAULT ISOLATION/MAINT MANUAL

FLIGHT COMPARTMENT DOOR




COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
CIRCUIT BREAKER - FLT DECK DR LOCK, C1400		1	FLIGHT COMPARTMENT, P11 11R5	*
DOOR - FLIGHT COMPARTMENT	1	1	FLIGHT COMPARTMENT	52-51-01
DOOR LOCK UNIT - FLIGHT COMPARTMENT, M635	1	1	FLIGHT COMPARTMENT DOORJAMB	52-51-01
PANEL - (FIM 33-45-00/101)				
RIGHT OVERHEAD LIGHTING CONTROL, M10057				
RELAY - (FIM 31-01-34/101)				
FLIGHT DK DR OPEN/CLOSE, K10256				
SWITCH, FLIGHT COMPARTMENT DOOR RELEASE, YCX S1	2	1	FLIGHT COMPARTMENT, P5, RIGHT OVERHEAD LIGHTING CONTROL PANEL, M10057	*
SWITCH - FLIGHT DECK DOOR PROXIMITY, S10165	1	1	FLIGHT COMPARTMENT DOORJAMB	52-51-01

* SEE THE WDM EQUIPMENT LIST

Flight Compartment Door - Component Index
Figure 101

EFFECTIVITY
GUI 005, 008 PRE-SB 25-271;
GUI 007 PRE-SB 25-269;
GUI 001-003, 009-999

52-51-00
CONFIG 1
Page 101
May 28/05



**FLIGHT COMPARTMENT DOOR
LOCK UNIT, M635
(SHOWN WITH SOLENOID ENERGIZED, DOOR LOCKED)**


(B)

Flight Compartment Door - Component Location
Figure 102 (Sheet 1)


EFFECTIVITY
GUI 005, 008 PRE-SB 25-271;
GUI 007 PRE-SB 25-269;
GUI 001-003, 009-999

52-51-00
CONFIG 1
Page 102
May 28/05

BOEING
757
FAULT ISOLATION/MAINT MANUAL



FLIGHT COMPARTMENT



RIGHT OVERHEAD LIGHTING
CONTROL PANEL, M10057 (REF)

(C)


Flight Compartment Door - Component Location
Figure 102 (Sheet 2)

EFFECTIVITY
GUI 005, 008 PRE-SB 25-271;
GUI 007 PRE-SB 25-269;
GUI 001-003, 009-999

52-51-00
CONFIG 1
Page 103
May 28/05

FLIGHT DECK DOOR
UNLOCKED LIGHT DID
NOT GO OFF WITH THE
DOOR LOCKED

PREREQUISITES
NONE




Flight Deck Door Unlocked Light Did Not Go Off with the Door Locked
Figure 103

EFFECTIVITY
GUI 005, 008 PRE-SB 25-271;
GUI 007 PRE-SB 25-269;
GUI 001-003, 009-999

52-51-00
 CONFIG 1
 Page 104
 May 28/05

FLIGHT DECK DOOR
UNLOCKED SWITCH
WILL NOT UNLOCK
THE DOOR

PREREQUISITES
NONE



Flight Deck Door Unlocked Switch Will Not Unlock the Door
Figure 104

EFFECTIVITY
 GUI 005, 008 PRE-SB 25-271;
 GUI 007 PRE-SB 25-269;
 GUI 001-003, 009-999

52-51-00
 CONFIG 1
 Page 105
 May 28/05


BOEING
 757
 FAULT ISOLATION/MAINT MANUAL

FLIGHT COMPARTMENT DOOR


COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
CHIME MODULE, M11864	3	1	FLIGHT COMPARTMENT DOORJAMB	52-51-20
CIRCUIT BREAKER - F/D DOOR LOCK, C1400		1	FLIGHT COMPARTMENT, P11	*
DOOR - FLIGHT COMPARTMENT	1	1	11R5	52-51-01
ELECTRIC STRIKE - FLIGHT COMPARTMENT, M11865	1	1	FLIGHT COMPARTMENT	52-51-03
KEYPAD, M11863	2	1	FLIGHT COMPARTMENT DOORJAMB	52-51-15
PANEL - RIGHT OVERHEAD LIGHTING CONTROL, M10057	4	1	FLIGHT COMPARTMENT DOORJAMB	52-51-30
SWITCH, FLIGHT COMPARTMENT DOOR LOCK, YCX S1	4	1	FLIGHT COMPARTMENT, P5, RIGHT OVERHEAD LIGHTING CONTROL PANEL, M10057	52-51-30

* SEE THE WDM EQUIPMENT LIST

Flight Compartment Door - Component Index
Figure 101

EFFECTIVITY
 GUI 005, 008 POST-SB 25-271;
 GUI 007 POST-SB 25-269;
 GUI 004, 006



52-51-00
 CONFIG 2
 Page 101
 May 28/05



Flight Compartment Door - Component Location
 Figure 102 (Sheet 1)

EFFECTIVITY
 GUI 005, 008 POST-SB 25-271;
 GUI 007 POST-SB 25-269;
 GUI 004, 006

52-51-00
 CONFIG 2
 Page 102
 May 28/05



KEYPAD, M11863

(B)

Flight Compartment Door - Component Location
Figure 102 (Sheet 2)

EFFECTIVITY
GUI 005, 008 POST-SB 25-271;
GUI 007 POST-SB 25-269;
GUI 004, 006

52-51-00



CONFIG 2

Page 103

May 28/05

CHIME MODULE, M11864

SEE (C)



CHIME MODULE, M11864

(C)

Flight Compartment Door - Component Location
Figure 102 (Sheet 3)

EFFECTIVITY

GUI 005, 008 POST-SB 25-271;
 GUI 007 POST-SB 25-269;
 GUI 004, 006


52-51-00

CONFIG 2


Page 104

May 28/05

BOEING
757
FAULT ISOLATION/MAINT MANUAL



FLIGHT COMPARTMENT



RIGHT OVERHEAD LIGHTING CONTROL PANEL, M10057

(D)

Flight Compartment Door - Component Location
Figure 102 (Sheet 4)

EFFECTIVITY
GUI 005, 008 POST-SB 25-271;
GUI 007 POST-SB 25-269;
GUI 004, 006

52-51-00
CONFIG 2
Page 105
May 28/05

**DOOR DOES NOT LOCK
IN THE "AUTO" MODE**



DESCRIPTION:

THE ELECTRIC STRIKE, M11865 IS DEFECTIVE OR NOT GETTING VOLTAGE OR GROUND.

POSSIBLE CAUSES:


1. CHIME MODULE, M11864
2. ELECTRIC STRIKE, M11865
3. AIRCRAFT WIRING.

FAULT ISOLATION:

PREREQUISITES

MAKE SURE THIS CIRCUIT BREAKER IS CLOSED:
11R5

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)
FLIGHT DECK DOOR IS CLOSED
POWER SWITCH ON THE CHIME MODULE, M10536 IS IN
THE "NORM" POSITION
DEADBOLT ON THE FLIGHT DECK DOOR IS UNLOCKED



Door Does Not Lock in the "AUTO" Mode
Figure 103

EFFECTIVITY

GUI 005, 008 POST-SB 25-271;
GUI 007 POST-SB 25-269;
GUI 004, 006

52-51-00
CONFIG 2
Page 106
May 28/05

DOOR DOES NOT
UNLOCK IN
"UNLOCK" MODE



PREREQUISITES

MAKE SURE THIS CIRCUIT BREAKER IS CLOSED:
11R5

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)
FLIGHT DECK DOOR IS CLOSED
DEADBOLT ON THE FLIGHT DECK DOOR IS UNLOCKED


DESCRIPTION:

THE ELECTRIC STRIKE, M11865, CIRCUIT TO GROUND WILL NOT OPEN.

POSSIBLE CAUSES:

1. CHIME MODULE, M11864
2. RIGHT OVERHEAD LIGHTING CONTROL PANEL, M10057
3. WIRING PROBLEM BETWEEN THE CHIME MODULE, M11864 AND STRUCTURE GROUND (WDM 52-51-11).

FAULT ISOLATION:



Door Does Not UnLock in the "UNLOCK" Mode
Figure 104

EFFECTIVITY
GUI 005, 008 POST-SB 25-271;
GUI 007 POST-SB 25-269;
GUI 004, 006

52-51-00
CONFIG 2
Page 107
May 28/05

DOOR DOES NOT UNLOCK
IN "AUTO" MODE AFTER
A CORRECT CODE HAS
BEEN ENTERED ON THE
KEYPAD



PREREQUISITES

MAKE SURE THIS CIRCUIT BREAKER IS CLOSED:
11R5

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)
FLIGHT DECK DOOR IS CLOSED
DEADBOLT ON THE FLIGHT DECK DOOR IS UNLOCKED


DESCRIPTION:

THE ELECTRIC STRIKE, M11865, CIRCUIT TO GROUND WILL NOT OPEN.

POSSIBLE CAUSES:

1. CHIME MODULE, M11864
2. KEYPAD, M11863
3. WIRING PROBLEM BETWEEN THE CHIME MODULE, M11864 AND STRUCTURE GROUND (WDM 52-51-11).

FAULT ISOLATION:



Door Does Not Unlock in "AUTO" Mode After a Correct
Code Has Been Entered On the Keypad
Figure 105

EFFECTIVITY

GUI 005, 008 POST-SB 25-271;
GUI 007 POST-SB 25-269;
GUI 004, 006

52-51-00
CONFIG 2
Page 108
May 28/05

DOOR UNLOCKS OR
CHIMES SOUND IN THE
"DENY" MODE



PREREQUISITES

MAKE SURE THIS CIRCUIT BREAKER IS CLOSED:
11R5

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)
FLIGHT DECK DOOR IS CLOSED
POWER SWITCH ON THE CHIME MODULE, M10536 IS IN
THE "NORM" POSITION


DESCRIPTION:

THE CHIME MODULE, M11864 IS DEFECTIVE OR NOT RECEIVING THE CORRECT GROUND SIGNAL.

POSSIBLE CAUSES:

1. RIGHT OVERHEAD LIGHTING CONTROL PANEL, M10057
2. CHIME MODULE, M11864
3. WIRING PROBLEM BETWEEN THE CHIME MODULE, M11864 AND STRUCTURE GROUND (WDM 52-51-11).

FAULT ISOLATION:



Door Unlocks or Chimes Sound in the "DENY" Mode
Figure 106

EFFECTIVITY
GUI 005, 008 POST-SB 25-271;
GUI 007 POST-SB 25-269;
GUI 004, 006

52-51-00
CONFIG 2
Page 109
May 28/05

CHIME DOES NOT SOUND
WHEN A CORRECT CODE
IS ENTERED ON THE
KEYPAD IN "AUTO"
MODE




DESCRIPTION:

THE CHIME MODULE, M11864 IS DEFECTIVE OR THE SYSTEM IS IN DENY MODE.

POSSIBLE CAUSES:

1. CHIME MODULE, M11864

FAULT ISOLATION:



PREREQUISITES

MAKE SURE THIS CIRCUIT BREAKER IS CLOSED:
11R5

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)
FLIGHT DECK DOOR IS CLOSED
POWER SWITCH ON THE CHIME MODULE, M1864 IS IN THE "NORM" POSITION

NOTE: THE CHIME AND KEYPAD CAN BE DISABLED FOR UP TO 30 MINUTES AFTER THE DOOR LOCK SWITCH IS TURNED TO THE "DENY" POSITION. THE DENY MODE CAN BE ENDED BY TURNING THE DOOR LOCK SWITCH TO THE "UNLOCK" POSITION.

Chime Does Not Sound When a Correct Code is Entered on the Keypad in "AUTO" Mode
Figure 107

EFFECTIVITY

GUI 005, 008 POST-SB 25-271;
GUI 007 POST-SB 25-269;
GUI 004, 006

52-51-00
 CONFIG 2
 Page 110
 May 28/05

N85688

**FLIGHT DECK DOOR
"LOCK FAIL" LIGHT
IS ON**



PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
11R5

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)
FLIGHT DECK DOOR IS CLOSED
DEADBOLT ON THE FLIGHTDECK DOOR IS UNLOCKED


DESCRIPTION:

THE DOOR LOCK SOLENOID IS COMMANDED TO THE LOCKED POSITION BUT IS NOT IN THE LOCKED POSITION. THE CHIME MODULE SENSES A CONDITION WHERE POWER IS APPLIED TO THE ELECTRIC STRIKE, M11865 BUT ELECTRICAL CONTACTS IN THE UNIT ARE NOT CLOSED.

POSSIBLE CAUSES:

1. THE ELECTRIC STRIKE, M11865 IS JAMMED OR DEFECTIVE
2. RIGHT OVERHEAD LIGHTING CONTROL PANEL, M10057
3. WIRING PROBLEM BETWEEN THE CHIME MODULE, M11864 AND STRUCTURE GROUND (WDM 52-51-11).

FAULT ISOLATION:



Flight Deck Door "LOCK FAIL" Light is on
Figure 108

EFFECTIVITY
GUI 005, 008 POST-SB 25-271;
GUI 007 POST-SB 25-269;
GUI 004, 006

52-51-00
CONFIG 2
Page 111
May 28/05

FLIGHT DECK DOOR
"AUTO UNLK" LIGHT
DOES NOT COME ON
AFTER A CORRECT
ACCESS CODE HAS
BEEN ENTERED



PREREQUISITES

MAKE SURE THIS CIRCUIT BREAKER IS CLOSED:
11R5

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)
FLIGHT DECK DOOR IS CLOSED

NOTE: A CORRECT ACCESS CODE ENTERED ON THE KEYPAD WILL MAKE THE "AUTO UNLK" LIGHT COME ON. THE "AUTO UNLK" LIGHT WILL BLINK WHEN THE CHIME SOUNDS.


DESCRIPTION:

THE "AUTO UNLK" LIGHT IS COMMANDED TO COME ON FROM THE CHIME MODULE, M11864 WHEN A CORRECT ACCESS CODE IS ENTERED ON THE KEYPAD.

POSSIBLE CAUSES:

1. DEFECTIVE LIGHT BULB
2. CHIME MODULE, M11864
3. WIRING PROBLEM BETWEEN THE CHIME MODULE, M11864 AND "AUTO UNLK" LIGHT

FAULT ISOLATION:



Flight Deck Door "AUTO UNLK" Light Does Not Come On
After a Correct Pass Code Has Been Entered
Figure 109


EFFECTIVITY

GUI 005, 008 POST-SB 25-271;
GUI 007 POST-SB 25-269;
GUI 004, 006


52-51-00
CONFIG 2
Page 112
May 28/05

 **BOEING**
757
FAULT ISOLATION/MAINT MANUAL

DOOR WARNING SYSTEM

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
CIRCUIT BREAKER DOOR IND, C4144 COMPUTER - (REF 31-41-00, FIG. 101) EICAS L, M10181 EICAS R, M10182		1	FLT COMPT, P11 11R33	*
LIGHT - ENTRY DOORS WARNING, YNEL001	1	1	FLT COMPT, P5, ANNUNCIATOR PANEL M10394 (REF)	*
LIGHT - EMERGENCY DOORS WARNING, YNEL002	1	1	FLT COMPT, P5, ANNUNCIATOR PANEL M10394 (REF)	*
LIGHT - CARGO DOORS WARNING, YNEL003	1	1	FLT COMPT, P5, ANNUNCIATOR PANEL M10394 (REF)	*
LIGHT - ACCESS DOORS WARNING, YNEL004	1	1	FLT COMPT, P5, ANNUNCIATOR PANEL M10394 (REF)	*
MODULE - (REF 32-09-03, FIG. 101) PROXIMITY SWITCH ELECTRONICS UNIT (PSEU), M162				
PANEL - (REF 30-31-00, FIG. 101) ANNUNCIATOR, M10394				
SENSOR - FORWARD ACCESS DOOR, S10085	4	1	113AL, DOOR FWD FRAME	52-71-00
SENSOR - E/E ACCESS DOOR, S10086	4	1	119BL, DOOR R FRAME	52-71-00
SENSOR - NO. 1 PASSENGER DOOR L, S10094	1	1	831, DOOR AFT FRAME	52-71-00
SENSOR - NO. 2 PASSENGER DOOR L, S10095	1	1	832, DOOR AFT FRAME	52-71-00
SENSOR - NO. 3 EMERGENCY EXIT L, S10096	3	1	835, DOOR FWD FRAME	52-71-00
SENSOR - NO. 4 PASSENGER DOOR L, S10097	2	1	836, DOOR AFT FRAME	52-71-00
SENSOR - NO. 1 PASSENGER DOOR R, S10090	1	1	841, DOOR FWD FRAME	52-71-00
SENSOR - NO. 2 PASSENGER DOOR R, S10091	1	1	842, DOOR AFT FRAME	52-71-00
SENSOR - NO. 3 EMERGENCY EXIT R, S10092	3	1	845, DOOR FWD FRAME	52-71-00
SENSOR - NO. 4 PASSENGER DOOR R, S10093	2	1	846, DOOR AFT FRAME	52-71-00
SENSOR - NO. 1 CARGO DOOR, S10083	5	1	821, DOOR UPPER FRAME	52-71-00
SENSOR - NO. 2 CARGO DOOR, S10088	5	1	822, DOOR UPPER FRAME	52-71-00
SENSOR - NO. 3 CARGO DOOR, S10089 	6	1	823, DOOR FWD FRAME	52-71-00

* SEE WM EQUIPMENT LIST

 AIRPLANES WITH NO. 3 CARGO DOOR

Component Index
Figure 101

EFFECTIVITY

ALL

52-71-00

02


Page 101
Dec 20/88

590758

BOEING



757

FAULT ISOLATION/MAINT MANUAL




ENTRY DOORS _a	EMER DOORS _a	CARGO DOORS _a	ACCESS DOORS _a
CAPT PITOT _a	F/O PITOT _a	L AOA _a	R AOA _a
L AUX PITOT _a	R AUX PITOT _a	TAT _a	
STAB TRIM _a	SPOILERS _a	AUTO SPDRK _a	MACH SPD TRIM _a
UNSCHEB STAB TRIM _a	RUDDER RATIO _a	ANTIISKID _a	

ANNUNCIATOR PANEL, M10394 (REF)



(VIEW WITH COVER REMOVED)
A-A




NO. 1/NO. 2 PASSENGER DOOR L & R SENSORS (TYP-4 PLS)

Component Location
Figure 102 (Sheet 1)

EFFECTIVITY	ALL
-------------	-----

52-71-00





Component Location
Figure 102 (Sheet 2)

EFFECTIVITY	
	ALL

52-71-00

01

Page 103
Sep 15/83



NO. 3 EMERGENCY EXIT DOOR SENSOR

(D)

Component Location
Figure 102 (Sheet 3)

EFFECTIVITY	ALL
-------------	-----

52-71-00

01

Page 104
Sep 15/83




54852

BOEING
757
FAULT ISOLATION/MAINT MANUAL

FORWARD ACCESS
DOOR SENSOR S10085
SEE (E)


E/E ACCESS
DOOR SENSOR
S10086
SEE (F)

113AL
119BL



FORWARD ACCESS DOOR SENSOR, S10085

(E)



E/E ACCESS DOOR SENSOR, S10086

(F)

Component Location
Figure 102 (Sheet 4)

EFFECTIVITY


ALL

52-71-00

01

Page 105
Sep 15/83

BOEING
757
FAULT ISOLATION/MAINT MANUAL




Component Location
Figure 102 (Sheet 5)

EFFECTIVITY	ALL
-------------	-----

52-71-00

590113



NO. 3 CARGO DOOR SENSOR, S10089

I


Component Location
Figure 102 (Sheet 6)

EFFECTIVITY
AIRPLANES WITH NO. 3 CARGO DOOR

52-71-00

DOORS LGT ILLUM
AND EICAS MSG
DISPLAYED. DOOR
WAS CLOSED.

PREREQUISITES
NONE




Doors Lgt Illum and EICAS Msg Displayed. Door was Closed.
Figure 103

EFFECTIVITY	ALL
-------------	-----

52-71-00

EICAS MSG "(L,R)
(FWD,CTR,AFT) ENT
DOOR" DID NOT
DISPLAY WITH DOOR
OPEN.

PREREQUISITES
NONE




EICAS Msg (L,R) (FWD,CTR,AFT) ENT DOOR Did Not Display with Door Open.
Figure 104

EFFECTIVITY	ALL
-------------	-----

52-71-00

EICAS MESSAGE DISPLAYED FOR ENTRY DOOR, EMER DOOR, CARGO DOOR, OR ACCESS DOOR.
CORRESPONDING ANNUNCIATOR LIGHT NOT ILLUMINATED.

PREREQUISITES
ELECTRICAL POWER (MM 24-22-00)
CB'S: 11R33



EICAS Message Displayed For Entry Door, Emer Door, Cargo Door, or Access Door. Corresponding Annunciator Light Not Illuminated.

Figure 104A

EFFECTIVITY	ALL
-------------	-----

52-71-00