

 **BOEING**
COMPONENT
MAINTENANCE MANUAL

TO: ALL HOLDERS OF ELEVATOR CONTROL TORQUE TUBE ASSEMBLY COMPONENT MAINTENANCE
MANUAL 27-31-37

REVISION NO. 12 DATED MAR 01/00

HIGHLIGHTS

Pages which have been added or revised are outlined below together with the highlights of the revision. Remove and insert the affected pages as listed and enter Revision No. and date on the Record of Revision Sheet.

CHAPTER/SECTION

AND PAGE NO.

DESCRIPTION OF CHANGE

TITLE PAGE

Incorporated PRR 13204 which added new top assemblies

1

253T2127-21 and -22 that use new force transducer

TR & SB RECORD

assemblies 253T2311-9 and -10.

1

DESCRIPTION & OPERATION

1

301-302

501

REPAIR-GEN

601

REPAIR 1-1

601-602

REPAIR 1-2

601-602

REPAIR 6-3

601-603

REPAIR 6-4

601-603

REPAIR 7-2

601-604

REPAIR 8-2

601-604

REPAIR 11-1

602

702-710

1002-1003,1005-1012,

1014,1017-1030,

1032-1039,1041

27-31-37

HIGHLIGHTS

01.1

Page 1

Mar 01/00

 **BOEING**
COMPONENT
MAINTENANCE MANUAL

<u>CHAPTER/SECTION AND PAGE NO.</u>	<u>DESCRIPTION OF CHANGE</u>
CONTENTS	Edited text.
1	
REPAIR 2-1 602	
401	Clarified text for Chapter 20 references.
501	
REPAIR 2-1 601	
REPAIR 3-1 601	
REPAIR 4-1 601	
REPAIR 5-1 601	
REPAIR 6-1 601	
REPAIR 7-1 601	
REPAIR 8-1 601	
REPAIR 9-1 601	
REPAIR 10-1 601	
701-703	
REPAIR-GEN 603	Updated true position dimensioning symbols.
701-703 901	Removed tool fixture A27082-1.

27-31-37

HIGHLIGHTS

01.1

Page 2

Mar 01/00

ELEVATOR CONTROL TORQUE TUBE ASSEMBLY

PART NUMBER 253T2127-5 THRU -19,
-21,-22

COMPONENT MAINTENANCE MANUAL
WITH
ILLUSTRATED PARTS LIST

27-31-37

TITLE PAGE

Page 1

Mar 01/00

01.1



REVISION RECORD

- Retain this record in front of manual. On receipt of revision, insert revised pages in the manual, and enter revision number, date inserted and initial.

REVISION NUMBER	REVISION DATE	DATE FILED	BY	REVISION NUMBER	REVISION DATE	DATE FILED	BY

27-31-37

REVISION RECORD

01 Page 1

Jul 10/83



TEMPORARY REVISION AND SERVICE BULLETIN RECORD

BOEING SERVICE BULLETIN	BOEING TEMPORARY REVISION	OTHER DIRECTIVE	DATE OF INCORPORATION INTO MANUAL
767-27-0121		PRR B10479 PRR B11720 PRR 13204	APR 10/82 JAN 01/89 JUN 01/95 MAR 01/00

27-31-37

TR & SB RECORD

01.1

Page 1

Mar 01/00


BOEING
 COMPONENT
 MAINTENANCE MANUAL

PAGE	DATE	CODE	PAGE	DATE	CODE
27-31-37			CHECK		
			*501	MAR 01/00	01.1
			502	BLANK	
TITLE PAGE			REPAIR-GENERAL		
*1	MAR 01/00	01.1	*601	MAR 01/00	01.1
2	BLANK		602	JUL 10/83	01
REVISION RECORD			*603	MAR 01/00	01.1
1	JUL 10/83	01	604	BLANK	
2	BLANK		REPAIR 1-1		
TR & SB RECORD			*601	MAR 01/00	01.1
*1	MAR 01/00	01.1	*602	MAR 01/00	01.1
2	BLANK		REPAIR 1-2		
LIST OF EFFECTIVE PAGES			*601	MAR 01/00	01.1
*1	MAR 01/00	01	*602	MAR 01/00	01.1
THRU LAST PAGE			REPAIR 2-1		
CONTENTS			*601	MAR 01/00	01.1
*1	MAR 01/00	01.1	*602	MAR 01/00	01.1
2	BLANK		REPAIR 3-1		
INTRODUCTION			*601	MAR 01/00	01.1
1	APR 10/84	01.1	602	JUL 10/84	01.1
2	BLANK		REPAIR 4-1		
DESCRIPTION & OPERATION			*601	MAR 01/00	01.1
*1	MAR 01/00	01.1	602	JUL 10/84	01.1
2	BLANK		REPAIR 5-1		
DISASSEMBLY			*601	MAR 01/00	01.1
*301	MAR 01/00	01.1	602	JUL 10/84	01.1
*302	MAR 01/00	01.1	REPAIR 6-1		
*303	MAR 01/00	01.101	*601	MAR 01/00	01.1
*304	BLANK		602	JUN 01/95	01.1
CLEANING			REPAIR 6-2		
*401	MAR 01/00	01.1	601	JUL 10/84	01.1
402	BLANK		602	JUN 01/95	01.1

* = REVISED, ADDED OR DELETED

27-31-37EFFECTIVE PAGES
CONTINUED Page 1
01 Mar 01/00

PAGE	DATE	CODE	PAGE	DATE	CODE
REPAIR 6-3			REPAIR 11-1		
*601	MAR 01/00	01.1	601	DEC 01/96	01.1
*602	MAR 01/00	01.1	*602	MAR 01/00	01.1
*603	MAR 01/00	01.1			
*604	BLANK		REPAIR 12-1		
REPAIR 6-4			601	DEC 01/96	01.1
*601	MAR 01/00	01.1	602	DEC 01/96	01.1
*602	MAR 01/00	01.1	ASSEMBLY		
*603	MAR 01/00	01.1	*701	MAR 01/00	01.1
*604	BLANK		*702	MAR 01/00	01.1
REPAIR 7-1			*703	MAR 01/00	01.1
*601	MAR 01/00	01.1	*704	MAR 01/00	01.1
602	JUL 10/84	01.1	*705	MAR 01/00	01.1
REPAIR 7-2			*706	MAR 01/00	01.1
*601	MAR 01/00	01.1	*707	MAR 01/00	01.1
*602	MAR 01/00	01.1	*708	MAR 01/00	01.1
*603	MAR 01/00	01.1	*709	MAR 01/00	01.1
*604	MAR 01/00	01.1	*710	MAR 01/00	01.1
REPAIR 8-1			FITS AND CLEARANCES		
*601	MAR 01/00	01.1	801	APR 10/84	01.1
602	JUL 10/84	01.1	802	APR 10/84	01.1
REPAIR 8-2			803	APR 10/84	01.1
*601	MAR 01/00	01.1	804	APR 10/84	01.1
*602	MAR 01/00	01.1	805	APR 10/84	01.1
*603	MAR 01/00	01.1	806	JUN 01/95	01.1
*604	MAR 01/00	01.1	807	JUN 01/95	01.1
REPAIR 9-1			808	APR 10/84	01.1
*601	MAR 01/00	01.1	SPECIAL TOOLS		
602	JUL 01/89	01.1	*901	MAR 01/00	01.1
REPAIR 10-1			902	BLANK	
*601	MAR 01/00	01.1	ILLUSTRATED PARTS LIST		
602	JUL 01/89	01.1	1001	JUL 10/83	01
			*1002	MAR 01/00	01.1
			*1003	MAR 01/00	01.1
			*1004	MAR 01/00	01.1
			*1005	MAR 01/00	01.1
			*1006	MAR 01/00	01.1
			*1007	MAR 01/00	01.1
			*1008	MAR 01/00	01.1

* = REVISED, ADDED OR DELETED

27-31-37

EFFECTIVE PAGES
CONTINUED Page 2
01 Mar 01/00


BOEING
 COMPONENT
 MAINTENANCE MANUAL

PAGE	DATE	CODE	PAGE	DATE	CODE
ILLUSTRATED PARTS LIST		CONT.			
*1009	MAR 01/00	01.1			
*1010	MAR 01/00	01.1			
*1011	MAR 01/00	01.1			
*1012	MAR 01/00	01.1			
*1013	BLANK				
*1014	MAR 01/00	01.1			
*1015	MAR 01/00	01.1			
*1016	MAR 01/00	01.1			
*1017	MAR 01/00	01.1			
*1018	MAR 01/00	01.1			
*1019	MAR 01/00	01.1			
*1020	MAR 01/00	01.1			
*1021	MAR 01/00	01.1			
*1022	MAR 01/00	01.1			
*1023	MAR 01/00	01.1			
*1024	MAR 01/00	01.1			
*1025	MAR 01/00	01.1			
*1026	MAR 01/00	01.1			
*1027	MAR 01/00	01.1			
*1028	MAR 01/00	01.1			
*1029	MAR 01/00	01.1			
*1030	MAR 01/00	01.1			
*1031	BLANK				
*1032	MAR 01/00	01.1			
*1033	MAR 01/00	01.1			
*1034	MAR 01/00	01.1			
*1035	MAR 01/00	01.1			
*1036	MAR 01/00	01.1			
*1037	MAR 01/00	01.1			
*1038	MAR 01/00	01.1			
*1039	MAR 01/00	01.1			
*1040	MAR 01/00	01.1			
*1041	MAR 01/00	01.1			
*1042	BLANK				

* = REVISED, ADDED OR DELETED

27-31-37

EFFECTIVE PAGES
 LAST PAGE Page 3
 01 Mar 01/00



TABLE OF CONTENTS

<u>Paragraph Title</u>	<u>Page</u>
Description and Operation.	1
Testing and Fault Isolation (not applicable)	
Disassembly.	301
Cleaning	401
Check.	501
Repair	601
Assembly	701
Fits and Clearances.	801
Special Tools.	901
Illustrated Parts List	1001

27-31-37

CONTENTS

01.1

Page 1

Mar 01/00



INTRODUCTION

The instructions in this manual provide the information necessary to perform maintenance functions ranging from simple checks and replacement to complete shop-type repair.

This manual is divided into separate sections:

- | | |
|--|------------------------------|
| 1. Title Page | 4. List of Effective Pages |
| 2. Record of Revisions | 5. Table of Contents |
| 3. Temporary Revision &
Service Bulletin Record | 6. Introduction |
| | 7. Procedures & IPL Sections |

Refer to the Table of Contents for the page location of applicable sections. An asterisked flagnote *[] in place of the page number indicates that no special instructions are provided since the function can be performed using standard industry practices.

The beginning of the REPAIR section includes a list of the separate repairs, a list of applicable standard Boeing practices, and an explanation of the True Position Dimensioning symbols used.

An explanation of the use of the Illustrated Parts List is provided in the Introduction to that section.

All weights and measurements used in the manual are in English units, unless otherwise stated. When metric equivalents are given they will be in parentheses following the English units.

Design changes, optional parts, configuration differences and Service Bulletin modifications create alternate part numbers. These are identified in the Illustrated Parts List (IPL) by adding an alphabetical character to the basic item number. The resulting item number is called an alpha-variant. Throughout the manual, IPL basic item number references also apply to alpha-variants unless otherwise indicated.

Verification:

Disassembly	JAN 21/83
Assembly	JAN 21/83

27-31-37

INTRODUCTION

01.1

Page 1

Apr 10/84

ELEVATOR CONTROL TORQUE TUBE ASSEMBLYDESCRIPTION AND OPERATION

1. The elevator control torque tube assembly consists of a follower assembly, support with a stick shaker, support fitting, transducer assembly, torque tube and two arm assemblies. The torque tube assembly is connected to the control column and its rotational output is sent to the tension regulators. The regulators, in turn, send the output to the elevator control aft quadrant assemblies.

2. Leading Particulars (Approximate)

| A. 253T2127-5, -7, -9, -11, -13, -15, -17, -19, -21 Assemblies

Diameter -- 12 inches

Length -- 51 inches

Weight -- 21 pounds

| B. 253T2127-6, -8, -10, -12, -14, -16, -18, -22 Assemblies

Diameter -- 12 inches

Length -- 22 inches

Weight -- 14 pounds

27-31-37

DESCRIPTION & OPERATION

01.1

Page 1

Mar 01/00

DISASSEMBLY

NOTE: Disassemble this component only as necessary to complete fault isolation, determine the serviceability of parts, perform required repairs, and restore the unit to serviceable condition.

1. Disassembly of 253T2127-5, -7, -9, -11, -13, -15, -17, -18, -19, -21
 (IPL Fig. 1)

- A. On 253T2127-5, -7, -11, -13, -15, -18, -19, -21 remove rivets (10) and transducer assembly (5) from torque tube (255).
 On 253T2127-9, -17, remove rivets (10) and crank assembly (7) from torque tube (255).

NOTE: Refer to par. 3 for disassembly of transducer assembly (253T2311-1, -3, -5, -7, -9).

- B. Remove rivets (20) and support fitting (15) from torque tube (255).

- C. Remove bolts (30), washers (35), nuts (40) and stick shaker (25A) from support (45B or 45C or 45D).

- D. Remove rivets (50) and support (45B or 45C or 45D) from torque tube (255).

WARNING: USE EXTREME CARE DURING SPRING REMOVAL. SPRINGS ARE HEAVILY LOADED.

CAUTION: DO NOT USE TOOLS THAT MAY CAUSE DAMAGE TO SPRING.

- E. Remove springs (55) from arm assemblies (115, 135) and follower assembly (170).

- F. On 253T2127-21, remove rivets (58) and remove crank (57) from torque tube (255).

- G. Remove bolts (60, 65), spacer (70), washers (75), nuts (90), and bushings (95, 100) from arm assemblies (115, 135).

- H. Remove rivets (120) and arm assembly (115) from torque tube (255).

NOTE: Do not remove bushings (105, 125) from arm (130) unless necessary for repair or replacement.

- I. Remove rivets (140) and arm assembly (135) from torque tube (255).

NOTE: Do not remove bushings (105, 145) from arm (150) unless necessary for repair or replacement.

27-31-37

DISASSEMBLY

01.1

Page 301

Mar 01/00

- J. Remove bolts (80), washers (85), nuts (90), plain bushing (110) and follower assembly (170).

NOTE: Do not disassemble follower assembly (170) unless necessary for repair or replacement.

- K. Remove screws (155), nuts (160), and fittings (165) from follower assembly (170).

2. Disassembly of 253T2127-6, -8, -10, -12, -14, -16, -22 (IPL Fig. 2)

- A. Remove bolts (15), washers (20), nuts (25) and cam (10) from override crank assembly (30).

- B. Remove rivets (35) and override crank assembly (30) from torque tube (110).

NOTE: Do not remove bushings (5, 40A) from crank assembly (30).

- C. Remove rivets (55) and fitting (50) from torque tube (110).

- D. On 253T2127-22, remove rivets (58) and remove crank (57) from torque tube (100).

- E. Remove bolts (65), washers (70), nuts (75) and stick shaker (60A) from support (80B or 80C or 80D).

- F. Remove rivets (85) and support (80B or 80C or 80D) from torque tube (110).

- G. On 253T2127-6, -8, -12, -14, -16, -22, remove rivets (95) and transducer assembly (90) from torque tube (110).
On 253T2127-10, remove rivets (95) and crank assembly (92) from torque tube (110).

NOTE: Refer to par. 3., for disassembly of transducer assembly (90).

- H. Remove rivets (105) and stop (100) from torque tube (110).

3. Disassembly of Transducer Assembly (IPL Fig. 3)

NOTE: Do not remove flanged bushings unless necessary for repair or replacement.

- A. Remove bolts (10), washers (15), nuts (20) and transducer (25).

- B. Remove bolts (30, 50, 52), washers (35, 55, 57), plain bushings (45, 65), nuts (40, 60), collar (62), and arm assembly (70) from crank assembly (95 or 100).

27-31-37

DISASSEMBLY

01.1

Page 302

Mar 01/00



C. Remove spacer (150) and bearing (145) from crank assembly (95 or 100).

NOTE: Do not remove bearing (105) from crank assembly (95 or 100) unless necessary for repair or replacement.

27-31-37

DISASSEMBLY

01.101

Page 303

Mar 01/00



CLEANING

- | 1. Clean all parts but not the bearings shown in 20-30-03.
- | 2. Clean teflon-sealed bearings (210, IPL Fig. 1 and 105, 145, IPL Fig. 3) as shown in manufacturer's suggested procedures.

27-31-37

01.1
CLEANING
Page 401
Mar 01/00

CHECK

- | 1. Check all parts for defects in accordance with standard industry practices.
2. Check spring (55, IPL Fig. 1).
 - A. Extend spring to 7.10–7.16 inches and check that load is 11.15–13.65 lbs.
 - B. Extend spring to 10.26–10.32 inches and check that load is 46.17–56.43 lbs.
 - C. Visually check springs for nicks, scratches or other damage. Replace spring if damage is found.
- | 3. Check Detail Parts for 253T2127-5, -7, -9, -11, -13, -15, -17, -18, -19, -21 (IPL Fig. 1)
 - A. Magnetic particle check as shown in 20-20-01 -- Spring (55), fitting (165) and retainer (205).
 - B. Penetrant check as shown in 20-20-02 -- Fitting (15), support (45B, 45C, 45D), crank (57), spacer (70), arm (130, 150), follower (215) and tube (255).
- | 4. Check Detail Parts for 253T2127-6, -8, -10, -12, -14, -16, -22 (IPL Fig. 2)
 - A. Magnetic particle check as shown in 20-20-01 -- Cam (10).
 - B. Penetrant check as shown in 20-20-02 -- Crank (45, 57), fitting (50), support (80B, 80C), stop (100), and tube (110).
- | 5. Check Detail Parts for 253T2311-1 thru -10 (IPL Fig. 3)
 - A. Penetrant check as shown in 20-20-02 -- Arm (90) and crank (125, 130)

27-31-37

CHECK

01.1

Page 501

Mar 01/00

REPAIR – GENERAL1. Content

- A. Repair, refinish and replacement procedures are included in separate repair sections as follows:

<u>P/N</u>	<u>NAME</u>	<u>REPAIR</u>
253T2126	SUPPORT	1-1, 1-2
253T2130	FOLLOWER	2-1
253T2131	ARM	3-1
253T2134	ARM	4-1
253T2146	CRANK, OVERRIDE	5-1
253T2312	ARM	6-1, 6-2, 6-3, 6-4
253T2313	CRANK	7-1, 7-2
253T2314	CRANK	8-1, 8-2
253T2316	CRANK	9-1
253T2317	CRANK	10-1
- -	MISC PARTS REFINISH	11-1
253T2152	TORQUE TUBE	12-1

2. Standard Procedures

- A. Refer to the following standard practices as applicable, for details of procedures in individual repairs.

20-30-01 Cleaning and Relubricating Antifriction Bearing
 20-30-02 Stripping of Protective Finishes
 20-30-03 General Cleaning Procedure
 20-41-01 Decoding Table for Boeing Finish Codes
 20-42-05 Bright Cadmium Plating
 20-43-01 Chromic Acid Anodizing
 20-50-01 Bolt and Nut Installation
 20-50-03 Bearing Installation and Retention
 20-50-12 Application of Adhesives

27-31-37

REPAIR-GENERAL

01.1

Page 601

Mar 01/00

3. Materials

NOTE: Equivalent substitutes may be used.

A. Primer -- BMS 10-11, type 1 (Ref 20-60-02)

B. Sealant -- BMS 5-95 (Ref 20-60-04)

C. Adhesive -- Type 44 (Ref 20-50-12)

27-31-37

REPAIR-GENERAL

01

Page 602

Jul 10/83

BOEING

COMPONENT MAINTENANCE MANUAL

- STRAIGHTNESS
- ▭ FLATNESS
- ⊥ PERPENDICULARITY (OR SQUARENESS)
- // PARALLELISM
- ROUNDNESS
- ⊙ CYLINDRICITY
- ⌒ PROFILE OF A LINE
- △ PROFILE OF A SURFACE
- ◎ CONCENTRICITY
- ≡ SYMMETRY
- ∠ ANGULARITY
- ↗ RUNOUT
- ↗ TOTAL RUNOUT
- ⊏ COUNTERBORE OR SPOTFACE
- ∇ COUNTERSINK

- ⊕ THEORETICAL EXACT POSITION OF A FEATURE (TRUE POSITION)
- ∅ DIAMETER
- S ∅ SPHERICAL DIAMETER
- R RADIUS
- SR SPHERICAL RADIUS
- () REFERENCE
- BASIC (BSC) OR DIM A THEORETICALLY EXACT DIMENSION USED TO DESCRIBE SIZE, SHAPE OR LOCATION OF A FEATURE FROM WHICH PERMISSIBLE VARIATIONS ARE ESTABLISHED BY TOLERANCES ON OTHER DIMENSIONS OR NOTES.
- A- DATUM
- Ⓜ MAXIMUM MATERIAL CONDITION (MMC)
- Ⓛ LEAST MATERIAL CONDITION (LMC)
- Ⓢ REGARDLESS OF FEATURE SIZE (RFS)
- Ⓟ PROJECTED TOLERANCE ZONE
- FIM FULL INDICATOR MOVEMENT

EXAMPLES

<p>— 0.002 STRAIGHT WITHIN 0.002</p> <p>⊥ 0.002 B PERPENDICULAR TO B WITHIN 0.002</p> <p>// 0.002 A PARALLEL TO A WITHIN 0.002</p> <p>○ 0.002 ROUND WITHIN 0.002</p> <p>⊙ 0.010 CYLINDRICAL SURFACE MUST LIE BETWEEN TWO CONCENTRIC CYLINDERS, ONE OF WHICH HAS A RADIUS 0.010 INCH GREATER THAN THE OTHER</p> <p>⌒ 0.006 A EACH LINE ELEMENT OF THE SURFACE AT ANY CROSS SECTION MUST LIE BETWEEN TWO PROFILE BOUNDARIES 0.006 INCH APART RELATIVE TO DATUM PLANE A</p> <p>△ 0.020 A SURFACES MUST LIE WITHIN PARALLEL BOUNDARIES 0.02 INCH APART AND EQUALLY DISPOSED ABOUT TRUE PROFILE</p>	<p>◎ ∅ 0.0005 C CONCENTRIC TO C WITHIN 0.0005 DIAMETER</p> <p>≡ 0.010 A SYMMETRICAL WITH A WITHIN 0.010</p> <p>∠ 0.005 A ANGULAR TOLERANCE 0.005 WITH A</p> <p>⊕ ∅ 0.002 Ⓢ B LOCATED AT TRUE POSITION WITHIN 0.002 DIA RELATIVE TO DATUM B, REGARDLESS OF FEATURE SIZE</p> <p>⊥ ∅ 0.010 Ⓜ A 0.510 Ⓟ AXIS IS TOTALLY WITHIN A CYLINDER OF 0.010-INCH DIAMETER, PERPENDICULAR TO, AND EXTENDING 0.510-INCH ABOVE, DATUM A, MAXIMUM MATERIAL CONDITION</p> <p>2.000 THEORETICALLY EXACT DIMENSION IS 2.000 OR 2.000 BSC</p> <p>0.020 A A 0.020</p>
<p>NOTE: DATUM MAY APPEAR AT EITHER SIDE OF TOLERANCE FRAME</p>	

True Position Dimensioning Symbols
Figure 601

27-31-37

REPAIR-GENERAL

01.1

Page 603

Mar 01/00



SUPPORT – REPAIR 1-1

253T2126-4, -5

|1. Plating Repair (IPL Fig. 1; 45B, IPL Fig. 2; 80B, Fig. 601)

NOTE: Repair consists of restoration of original finish. Refer to Refinish instructions, Fig. 601, and to REPAIR-GEN for list of applicable standard practices.


27-31-37

REPAIR 1-1


01.1

Page 601

Mar 01/00



REFINISH

CHROMIC ACID ANODIZE (F-17.05) ALL OVER. APPLY A COAT OF PRIMER, BMS 10-11, TYPE I (F-20.02) BUT NOT WHEN NOTED 

MATERIAL: AL ALLOY
 ALL DIMENSIONS ARE IN INCHES

 OMIT PRIMER

253T2126-4,-5
 Support - Plating Repair
 Figure 601

27-31-37

REPAIR 1-1

01.1

Page 602

Mar 01/00

SUPPORT – REPAIR 1-2

253T2126-6

1. Refinish Repair (IPL Fig. 1; 45D, IPL Fig. 2; 80D, Fig. 601)

NOTE: Repair consists of restoration of original finish. Refer to Refinish instructions, Fig. 601, and to REPAIR-GEN for list of applicable standard practices.

27-31-37


REPAIR 1-2

01.1


Page 601

Mar 01/00

→ A



→ A



REFINISH

BORIC ACID - SULFURIC ACID ANODIZE (F-17.31) CLASS I OR 5, OR CHROMIC ACID ANODIZE ATT 22 VOLTS AS SHOWN IN SOPM 20-43-01, CLASS 3 OR 5. APPLY TWO LAYERS OF BMS 10-11, TYPE 1 PRIMER (F.20.03) BUT NOT WHEN IDENTIFIED BY 1

1 OMIT PRIMER

MATERIAL: AL ALLOY
 ALL DIMENSIONS ARE IN INCHES

253T2126-6
 Support - Refinish/Repair
 Figure 601

27-31-37

REPAIR 1-2

01.1

Page 602

Mar 01/00

FOLLOWER ASSEMBLY – REPAIR 2-1

253T2130-1

1. Bearing Replacement (IPL Fig. 1, Fig. 601)

NOTE: Refer to REPAIR-GEN for list of applicable standard practices.

A. Remove bolts (190), washers (195), nuts (200), and retainers (205).
Remove bearings (210).

B. Install new bearings (210) as shown in 20-50-03.

C. Install retainers (205) and secure with bolts (190), washers (195), and nuts (200).

2. Roller Replacement (IPL Fig. 1, Fig. 601)

A. Remove nut (185), washer (180), and roller (175) from follower (215).

B. Install roller (175), washer (180) and nut (185) on follower (215).

3. Bearing Seat Repair (IPL Fig. 1, Fig. 601)

A. Machine bearing seat as required, within repair limit shown, to remove defects.

B. Chrome plate build up repaired surface and grind to dimension shown.



27-31-37

REPAIR 2-1

01.1

Page 601

Mar 01/00



REPAIR

1 CHROME PLATE BUILDUP AND GRIND TO DIMENSION AND FINISH SHOWN. CHROME PLATE RUNOUT 0.00-0.08. STOP CHROME PLATE 0.00-0.02 FROM FILLET RADIUS OR EDGE

ITEM NUMBERS REFER TO IPL FIG. 1

253T2130-1
 Follower Assembly - Bearing/Roller Replacement
 Figure 601

27-31-37

REPAIR 2-1

01.1

Page 602

Mar 01/00

ARM ASSEMBLY – REPAIR 3-1

253T2131-1

NOTE: Refer to REPAIR-GEN for list of applicable standard practices. For repair of surfaces which may only require stripping and restoration of original finish, refer to Refinish instructions, Fig. 601.

1. Bushing Replacement (IPL Fig. 1, Fig. 601)

- A. Remove bushings (105, 145).
- B. Install new bushings (145) as shown in 20-50-03.
- C. Install new bushings (105) as shown in 20-50-03 but use BMS 5-95 wet sealant.
- D. Machine to dimension shown.
- E. Fillet seal bushing (105) flanges with BMS 5-95 sealant.

2. Bushing Seat Replacement (IPL Fig. 1, Fig. 601)

- A. Machine bushing seat as required, within repair limits shown, to remove defects.
- B. Chrome plate build up repaired surface and grind to dimension shown.

3. Fastener Hole Repair

- A. Refer to Torque Tube Repair 12-1 for oversize hole repair instructions of the Arm Assembly.

27-31-37

REPAIR 3-1



01.1

Page 601

Mar 01/00

**COMPONENT
MAINTENANCE MANUAL**

NOTE: BUSHINGS (105) ARE NOT PART OF ARM ASSEMBLY. REPLACEMENT OF BUSHINGS (105) IS SHOWN HERE TO FACILITATE ASSEMBLY.



A-A

REFINISH

ARM (150) -- ANODIZE (F-17.05) ALL OVER.
 APPLY ONE COAT OF PRIMER, BMS 10-11, TYPE I
 (F-20.02) EXCEPT AS NOTED

- 1 OMIT PRIMER
- 2 BUILD UP WITH CHROME PLATE AND GRIND TO DIMENSION AND FINISH SHOWN. CHROME PLATE RUNOUT 0.00-0.08. STOP CHROME PLATE 0.00-0.02 FROM FILLET RADIUS OR EDGE

REPAIR

REF 2

MATERIAL: AL ALLOY

ITEM NUMBERS REFER TO IPL FIG. 1

ALL DIMENSIONS ARE IN INCHES

253T2131-1
 Arm Assembly - Bushing Replacement and Refinish
 Figure 601

27-31-37

REPAIR 3-1

Page 602

Jul 10/84

01.1

ARM ASSEMBLY – REPAIR 4-1

253T2134-1

NOTE: Refer to REPAIR-GEN for list of applicable standard practices. For repair of surfaces which may only require stripping and restoration of original finish, refer to Refinish instructions, Fig. 601.

1. Bushing Replacement (IPL Fig. 1, Fig. 601)

- A. Remove bushings (105, 125).
- B. Install new bushing (125) as shown in 20-50-03.
- C. Install new bushing (105) as shown in 20-50-03 but use BMS 5-95 wet sealant.
- D. Machine bushings to dimension shown.
- E. Fillet seal bushing (105) flange with BMS 5-95 sealant.

2. Bushing Seat Replacement (IPL Fig. 1, Fig. 601)

- A. Machine bushing seat as required, within repair limit shown, to remove defects.
- B. Chrome plate build up repaired surface and grind to dimension and finish shown.

3. Fastener Hole Repair

- A. Refer to Torque Tube Repair 12-1 for oversize hole repair instructions of the Arm Assembly.


27-31-37

REPAIR 4-1


01.1

Page 601

Mar 01/00



NOTE: BUSHING (105) IS NOT PART OF ARM ASSEMBLY. REPLACEMENT OF BUSHING (105) IS SHOWN HERE TO FACILITATE ASSEMBLY.



REFINISH

ARM (130) -- ANODIZE (F-17.05) ALL OVER. APPLY ONE COAT OF PRIMER, BMS 10-11, TYPE I (F-20.02) EXCEPT AS NOTED

- 1 OMIT PRIMER
- 2 BUILD UP WITH CHROME PLATE AND GRIND TO DIMENSION AND FINISH SHOWN. CHROME PLATE RUNOUT 0.00-0.08. STOP CHROME PLATE 0.00-0.02 FROM FILLET RADIUS OR EDGE

REPAIR

REF 2

MATERIAL: AL ALLOY

ITEM NUMBERS REFER TO IPL FIG. 1

ALL DIMENSIONS ARE IN INCHES

253T2134-1
 Arm - Bushing Replacement and Refinish
 Figure 601

27-31-37

REPAIR 4-1

Page 602

Jul 10/84

01.1

OVERRIDE CRANK ASSEMBLY – REPAIR 5-1

253T2146-1

NOTE: Refer to REPAIR-GEN for list of applicable standard practices. For repair of surfaces which may only require stripping and restoration of original finish, refer to Refinish instructions, Fig. 601.

1. Bushing Replacement (IPL Fig. 2, Fig. 601)

A. Remove bushings (5, 40).

B. Install new bushing (40) as shown in 20-50-03.

C. Install new bushing (5) as shown in 20-50-03 but use BMS 5-95 wet sealant.

D. Machine bushings to dimension shown.

E. Fillet seal bushing (5) flange with BMS 5-95 sealant.

2. Bushing Seat Replacement (IPL Fig. 1, Fig. 601)

A. Machine bushing seat as required, within repair limit shown, to remove defects.

B. Chrome plate build up repaired surface and grind to dimension and finish shown.

3. Fastener Hole Repair

A. Refer to Torque Tube Repair 12-1 for oversize hole repair instructions of the Override Crank Assembly.


27-31-37

REPAIR 5-1

01.1

Page 601

Mar 01/00



NOTE: BUSHING (5) IS NOT PART OF CRANK ASSEMBLY. REPLACEMENT OF BUSHING (5) IS SHOWN HERE TO FACILITATE ASSEMBLY.

REFINISH

CRANK (45) -- ANODIZE (F-17.05) ALL OVER.
 APPLY ONE COAT OF PRIMER, BMS 10-11, TYPE I (F-20.02) EXCEPT AS NOTED

- 1 OMIT PRIMER
- 2 BUILD UP WITH CHROME PLATE AND GRIND TO DIMENSION SHOWN. CHROME PLATE RUNOUT 0.00-0.08. STOP CHROME PLATE 0.00-0.02 FROM FILLET RADIUS OR EDGE

REPAIR

REF 2

MATERIAL: AL ALLOY

ITEM NUMBERS REFER TO IPL FIG. 2

ALL DIMENSIONS ARE IN INCHES

253T2146-1
 Override Crank Assembly - Bushing Replacement and Refinish
 Figure 601

27-31-37

REPAIR 5-1

01.1

Page 602

Jul 10/84

ARM ASSEMBLY – REPAIR 6-1

253T2312-1

NOTE: Refer to REPAIR-GEN for list of applicable standard practices.

1. Bushing Replacement (IPL Fig. 3, 601)
 - A. Remove bushings (75, 80, 85, 135, 140, 155).
 - B. Install new bushings (75, 80, 85) as shown in 20-50-03.
 - C. Install new bushings (135, 140, 155) as shown in 20-50-03 but use BMS 5-95 wet sealant.
 - D. Machine bushings (75, 80, 135, 140) to dimension shown.
 - E. Fillet seal bushing (135, 140, 155) flanges with BMS 5-95 wet sealant.



27-31-37

REPAIR 6-1

01.1

Page 601

Mar 01/00



A-A

- 1 DIMENSIONS APPLY AFTER INSTALLATION OF BUSHINGS
- 2 ORIGINAL PRODUCTION CONFIGURATION OF 253T2312-1 AND CONFIGURATION OF 253T2312-1 BEFORE INCORPORATION OF SB 767-27-0121.
- 3 NEW PRODUCTION CONFIGURATION OF 253T2312-1 AND CONFIGURATION OF 253T2312-1 AFTER INCORPORATION OF SB 767-27-0121.

NOTE: BUSHINGS (135,140,155) ARE NOT PART OF ARM ASSEMBLY. REPLACEMENT OF BUSHINGS (135,140,155) IS SHOWN HERE TO FACILITATE ASSEMBLY.

ITEM NUMBER REFERS TO IPL FIG. 3

ALL DIMENSIONS ARE IN INCHES

253T2312-1
 Bushing Replacement
 Figure 601

27-31-37

REPAIR 6-1

Page 602

Jun 01/95

01.1

ARM - REPAIR 6-2

253T2312-2

NOTE: Refer to REPAIR-GEN for list of applicable standard practices. For repair of surfaces which may only require restoration of original finish, refer to Refinish instructions, Fig. 601.

1. Repair (Fig. 601)

- A. Machine bearing seat as required, within repair limit shown to remove defects.
- B. Chrome plate build up repaired surface and grind to dimension and finish shown.


27-31-37

REPAIR 6-2

01.1

Page 601

Jul 10/84



REFINISH

ANODIZE (F-17.05) ALL OVER. APPLY ONE COAT OF BMS 10-11, TYPE 1 PRIMER (F-20.02) EXCEPT OMIT PRIMER ON ALL ID'S

REPAIR

REF 1

MATERIAL: AL ALLOY

ALL DIMENSIONS ARE IN INCHES

- 1 BUILD UP WITH CHROME PLATE AND GRIND TO DIMENSION SHOWN. CHROME PLATE RUNOUT 0.00-0.08. STOP CHROME PLATE 0.00-0.02 FROM FILLET RADIUS OR EDGE.
- 2 ORIGINAL PRODUCTION CONFIGURATION OF 253T2312-2 AND CONFIGURATION OF 253T2312-2 BEFORE INCORPORATION OF SB 767-27-0121.
- 3 NEW PRODUCTION CONFIGURATION OF 253T2312-2 AND CONFIGURATION OF 253T2312-2 AFTER INCORPORATION OF SB 767-27-0121.

253T2312-2
 Arm - Plating Repair
 Figure 601

27-31-37

REPAIR 6-2

Page 602

Jun 01/95

01.1

ARM ASSEMBLY – REPAIR 6-3

253T2312-4

NOTE: Refer to REPAIR-GEN for list of applicable standard practices.

1. Bushing Replacement (IPL Fig. 3, Fig. 601)

- A. Remove bushings (75A, 80A, 85) from arm (90A).
- B. Install new bushings (75A, 80A, 85) into arm (90A) by shrink-fit procedure as shown in SOPM 20-50-03.


27-31-37

REPAIR 6-3

01.1

Page 601

Mar 01/00



253T2312-4
Arm Assembly Repair
Figure 601 (Sheet 1)



27-31-37

REPAIR 6-3
Page 602
Mar 01/00

01.1

L07251

BOEING
COMPONENT
MAINTENANCE MANUAL



- 1 INSTALL THIS BUSHING BY SHRINK-FIT PROCEDURE AS SHOWN IN SOPM 20-50-03.
- 2 DO NOT PUT PROMER IN THIS SURFACE

ITEM NUMBERS REFER TO IPL FIG. 3
 ALL DIMENSIONS ARE IN INCHES

253T2312-4
 Arm Assembly Repair
 Figure 601 (Sheet 2)

27-31-37
 REPAIR 6-3
 Page 603
 Mar 01/00

01.1

ARM - REPAIR 6-4

253T2312-5

NOTE: Refer to REPAIR-GEN for list of applicable standard practices. For repair of surfaces, which may only require restoration of original finish, refer to Refinish instructions, Fig. 601.

1. Arm Refinish (IPL Fig. 3, Fig. 601)

- A. Machine as required, within repair limits shown in Fig. 601 to remove defects.
- B. Boric acid-sulfuric acid anodize, class 1 or chromic acid anodize at 22 volts, class 3 (F-17.35) all surfaces as shown in SOPM 20-43-03.
- C. Apply two layers of BMS 10-11, type 1 primer (F-20.03) to all outside surfaces as shown in SOPM 20-41-02, but not in holes identified by flagnote 1 in Fig. 601.


27-31-37

REPAIR 6-4

01.1

Page 601

Mar 01/00




253T2312-5
 Arm Repair
 Figure 601 (Sheet 1)

27-31-37

REPAIR 6-4
 Page 602
 Mar 01/00

01.1

BOEING
COMPONENT
MAINTENANCE MANUAL



1 DO NOT PUT PROMER IN THIS SURFACE

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY
 BREAK ALL SHARP EDGES
 ITEM NUMBERS REFER TO IPL FIG. 3
 ALL DIMENSIONS ARE IN INCHES

253T2312-5
 Arm Repair
 Figure 601 (Sheet 2)

27-31-37

REPAIR 6-4

01.1

Page 603

Mar 01/00

CRANK ASSEMBLY – REPAIR 7-1

253T2313-1

NOTE: Refer to REPAIR-GEN for list of applicable standard practices. For repair of surfaces which may only require restoration of original finish, refer to Refinish instructions, Fig. 601.

1. Bushing Replacement (IPL Fig. 3, Fig. 601)

A. Remove bushings.

B. Install new bushings (110, 115, 120) as shown in 20-50-03.

C. Install new bushings (155, 160) as shown in 20-50-03 but use BMS 5-95 wet sealant.

D. Machine bushings (115, 160) to dimension shown.

E. Fillet seal bushing (155, 160) flanges with BMS 5-95 sealant.

2. Bearing Replacement (IPL Fig. 3, Fig. 601)

A. Remove bearing.

B. Install and roller swage new bearing (105) as shown in 20-50-03 but use BMS 10-11, type 1, wet primer.

3. Bearing and Bushing Seat Repair (IPL Fig. 3, Fig. 601)

A. Machine bearing or bushing seat as required, within repair limit shown, to remove defects.

B. Chrome plate build up repaired surface and grind to dimension shown.

4. Fastener Hole Repair

A. Refer to Torque Tube Repair 12-1 for oversize hole repair instructions of the Crank Assembly.


27-31-37

REPAIR 7-1

01.1

Page 601

Mar 01/00

**COMPONENT
MAINTENANCE MANUAL**

REFINISH

ANODIZE (F-17.05) ALL OVER. APPLY ONE COAT OF BMS 10-11, TYPE 1 PRIMER (F-20.02) EXCEPT OMIT PRIMER ON ALL ID'S

1 BUILD UP WITH CHROME PLATE AND GRIND TO DIMENSION SHOWN. CHROME PLATE RUNOUT 0.00-0.08. STOP CHROME PLATE 0.00-0.02 FROM FILLET RADIUS OR EDGE

REPAIR

REF 1

ALL DIMENSIONS ARE IN INCHES

253T2313-1
Crank Assembly - Repair
Figure 601

27-31-37

REPAIR 7-1

01.1

Page 602

Jul 10/84

CRANK ASSEMBLY – REPAIR 7-2

253T2313-4

NOTE: Refer to REPAIR-GEN for list of applicable standard practices. For repair of surface, which may only require restoration of original finish, refer to Refinish instructions.

1. Bushing Replacement (IPL Fig. 3, Fig. 601)

- A. Remove bushings (115A, 120) from crank (130A).
- B. Install new bushings (115A, 120) into crank (130A) by shrink-fit procedure as shown in SOPM 20-50-03.
- C. Machine bushings (115A, 120) to dimension shown.

2. Bearing Replacement (IPL Fig. 3, Fig. 601)

- A. Remove bearing (105A) from crank (130A).
- B. Install and roller swage new bearing (105A) into crank (130A) as shown in SOPM 20-50-03 but use BMS 10-11, type 1 wet primer.

3. Bearing and Bushing Seat Repair (IPL Fig. 3, Fig. 601)

- A. Machine bearing or bushing seat as required, within repair limit shown, to remove defects.
- B. Chrome plate build up repaired surface and grind to dimension shown.

4. Fastener Hole Repair

- A. Refer to Torque Tube Repair 12-1 for oversize hole repair instructions of the Crank Assembly.


27-31-37

REPAIR 7-2

01.1

Page 601

Mar 01/00



253T2313-4
Crank Assembly Repair
Figure 601 (Sheet 1)


27-31-37

REPAIR 7-2

Page 602

Mar 01/00

01.1



A-A

253T2313-4
 Crank Assembly Repair
 Figure 601 (Sheet 2)

27-31-37



REPAIR 7-2

Page 603

Mar 01/00

01.1

L07398



REFINISH

BORIC - SULFURIC ACID ANODIZE (F-17.35).
 APPLY BMS 10-11, TYPE 1 PRIMER (F-20.03).
 DO NOT PUT PRIMER TO ALL INSIDE DIAMETERS.

1 BUILD UP WITH CHROME PLATE AND GRIND TO DIMENSION SHOWN. CHROME PLATE RUNOUT 0.00-0.08. STOP CHROME PLATE 0.00-0.02 FROM FILLET RADIUS OR EDGE.

REPAIR

REF 1

ALL DIMENSIONS ARE IN INCHES

253T2313-4
 Crank Assembly Repair
 Figure 601 (Sheet 3)

27-31-37

REPAIR 7-2

Page 604

Mar 01/00

01.1

CRANK ASSEMBLY – REPAIR 8-1

253T2314-1

NOTE: Refer to REPAIR-GEN for list of applicable standard practices. For repair of surfaces which may only require restoration of original finish, refer to Refinish instructions, Fig. 601.

1. Bushing Replacement (IPL Fig. 3, Fig. 601)

A. Remove bushings.

B. Install new bushings (110, 115, 120) as shown in 20-50-03.

C. Install new bushings (155, 160) as shown in 20-50-03 but use BMS 5-95 wet sealant.

D. Machine bushings (115, 160) to dimension shown.

E. Fillet seal bushing (155, 160) flanges with BMS 5-95 sealant.

2. Bearing Replacement (IPL Fig. 3, Fig. 601)

A. Remove bearing.

B. Install and roller swage new bearing (105) as shown in 20-50-03 but use BMS 10-11, type 1, wet primer.

3. Bearing and Bushing Seat Repair (IPL Fig. 3, Fig. 601)

A. Machine bearing or bushing seat as required, within repair limit shown, to remove defects.

B. Chrome plate build up repaired surface and grind to dimension shown.

4. Fastener Hole Repair

A. Refer to Torque Tube Repair 12-1 for oversize hole repair instructions of the Crank Assembly.


27-31-37

REPAIR 8-1

01.1

Page 601

Mar 01/00

**COMPONENT
MAINTENANCE MANUAL**

 253T2314-1
 Crank Assembly - Repair
 Figure 601

27-31-37

REPAIR 8-1

01.1

Page 602

Jul 10/84

CRANK ASSEMBLY – REPAIR 8-2

253T2314-4

NOTE: Refer to REPAIR-GEN for list of applicable standard practices. For repair of surfaces, which may only require restoration of original finish, refer to Refinish instructions, (Fig. 601).

1. Bushing Replacement (IPL Fig. 3, Fig. 601)

- A. Remove bushings (115A, 120) from crank (125A).
- B. Install new bushings (115A, 120) into crank (125A) by shrink-fit procedure as shown in SOPM 20-50-03.
- C. Machine bushings (115A, 120) to dimension shown.

2. Bearing Replacement (IPL Fig. 3, Fig. 601)

- A. Remove bearing (105A) from crank (125A).
- B. Install and roller swage new bearing (105A) into crank (125A) as shown in SOPM 20-50-03 but use BMS 10-11, type 1 wet primer.

3. Bearing and Bushing Seat Repair (IPL Fig. 3, Fig. 601)

- A. Machine bearing or bushing seat as required, within repair limit shown, to remove defects.
- B. Chrome plate build up repaired surface and grind to dimension shown.

4. Fastener Hole Repair

- A. Refer to Torque Tube Repair 12-1 for oversize hole repair instructions of the Crank Assembly.


27-31-37

REPAIR 8-2

01.1

Page 601

Mar 01/00




253T2314-4
Crank Assembly Repair
Figure 601 (Sheet 1)

27-31-37

REPAIR 8-2
Page 602
Mar 01/00

01.1





253T2314-4
 Crank Assembly Repair
 Figure 601 (Sheet 2)

27-31-37

REPAIR 8-2
 Page 603
 Mar 01/00

01.1

L07563



REFINISH

BORIC - SULFURIC ACID ANODIZE (F-17.35).
 APPLY BMS 10-11, TYPE 1 PRIMER (F-20.03).
 DO NOT PUT PRIMER TO ALL INSIDE DIAMETERS.

1 BUILD UP WITH CHROME PLATE AND GRIND TO DIMENSION SHOWN. CHROME PLATE RUNOUT 0.00-0.08. STOP CHROME PLATE 0.00-0.02 FROM FILLET RADIUS OR EDGE.

REPAIR

REF 1

ALL DIMENSIONS ARE IN INCHES

253T2314-4
 Crank Assembly Repair
 Figure 601 (Sheet 3)

27-31-37

REPAIR 8-2

Page 604

Mar 01/00

01.1

CRANK ASSEMBLY – REPAIR 9-1

253T2316-1

NOTE: Refer to REPAIR-GEN for list of applicable standard practices. For repair of surfaces which may only require restoration of original finish, refer to Refinish instructions, Fig. 601.

1. Bushing Replacement (IPL Fig. 2, Fig. 601)

- A. Remove bushings.
- B. Install new bushings (96 thru 99) as shown in 20-50-03 but use BMS 5-95 wet sealant.
- C. Machine bushings (96, 97) to dimension shown.
- D. Fillet seal bushing (96) flanges with BMS 5-95 sealant.

2. Bushing Seat Replacement (IPL Fig. 2, Fig. 601)

- A. Machine bushing seat as required, within repair limit shown, to remove defects.
- B. Chrome plate buildup repaired surface and grind to dimension shown.

3. Fastener Hole Repair

- A. Refer to Torque Tube Repair 12-1 for oversize hole repair instructions of the Crank Assembly.


27-31-37

REPAIR 9-1

01.1

Page 601

Mar 01/00

**COMPONENT
MAINTENANCE MANUAL**

REFINISH

ANODIZE (F-17.05) ALL OVER. APPLY ONE COAT OF BMS 10-11, TYPE 1 PRIMER (F-20.02) EXCEPT OMIT PRIMER ON ALL ID'S

1 BUILD UP WITH CHROME PLATE AND GRIND TO DIMENSION SHOWN. CHROME PLATE RUNOUT 0.00-0.08. STOP CHROME PLATE 0.00-0.02 FROM FILLET RADIUS OR EDGE

REPAIR

REF 1

MATERIAL: AL ALLOY

ALL DIMENSIONS ARE IN INCHES

ITEM NUMBERS REFER TO IPL FIG. 2

253T2316-1
Crank Assembly - Repair
Figure 601

27-31-37

REPAIR 9-1

Page 602

Jul 01/89

01.1

CRANK ASSEMBLY – REPAIR 10-1

253T2317-1

NOTE: Refer to REPAIR-GEN for list of applicable standard practices. For repair of surfaces which may only require restoration of original finish, refer to Refinish instructions, Fig. 601.

1. Bushing Replacement (IPL Fig. 1, Fig. 601)

- A. Remove bushings.
- B. Install new bushings (11 thru 14) as shown in 20-50-03 but use BMS 5-95 wet sealant.
- C. Machine bushings (11, 12) to dimension shown.
- D. Fillet seal bushing (11) flanges with BMS 5-95 sealant.

2. Bushing Seat Replacement (IPL Fig. 1, Fig. 601)

- A. Machine bushing seat as required, within repair limit shown, to remove defects.
- B. Chrome plate buildup repaired surface and grind to dimension shown.

3. Fastener Hole Repair

- A. Refer to Torque Tube Repair 12-1 for oversize hole repair instructions of the Crank Assembly.


27-31-37

REPAIR 10-1

01.1

Page 601

Mar 01/00

**COMPONENT
MAINTENANCE MANUAL**

REFINISH

ANODIZE (F-17.05) ALL OVER. APPLY ONE COAT OF BMS 10-11, TYPE 1 PRIMER (F-20.02) EXCEPT OMIT PRIMER ON ALL ID'S

1 BUILD UP WITH CHROME PLATE AND GRIND TO DIMENSION SHOWN. CHROME PLATE RUNOUT 0.00-0.08. STOP CHROME PLATE 0.00-0.02 FROM FILLET RADIUS OR EDGE

REPAIR

REF 1

MATERIAL: AL ALLOY

ALL DIMENSIONS ARE IN INCHES

ITEM NUMBERS REFER TO IPL FIG. 1

253T2317-1
Crank Assembly - Repair
Figure 601

27-31-37

REPAIR 10-1

Page 602

Jul 01/89

01.1

MISC PARTS REFINISH - REPAIR 11-1

1. Repair of parts listed in Fig. 601 consists of restoration of the original finish.

IPL FIG. & ITEM	MATERIAL	FINISH
<u>Fig. 1</u>		
Spacer (70)	Al alloy	Chromic acid anodize and apply one coat of primer, BMS 10-11, type 1 (F-18.13).
Support Fitting (15)	Al alloy	Anodize (F-17.05) all over. Apply one coat of primer, BMS 10-11, Type 1 (F-20.02) except omit primer on OD of 0.998-0.999 inch diameter shank and ID of 2.966-2.968 inch hole.
Fitting (165)	15-5PH CRES, 150-170 ksi	Passivate (F-17.09).
Follower (215)	Al alloy	Anodize (F-17.05) all over. Apply one coat of primer, BMS 10-11, type 1 (F-20.02) except omit primer on ID of 0.375-0.379 and 0.7488-0.7493 inch dia holes.
Retainer (205)	4130 Steel, normalized	Cadmium plate and apply one coat of primer, BMS 10-11, type 1 (F-16.01).
Tube (255)	Al alloy	Anodize (F-17.05) all over. Apply one coat of primer, BMS 10-11, type 1 (F-20.02) except omit primer on 2.962-2.964-inch faying surface.

Refinish Details
 Figure 601 (Sheet 1)

27-31-37

REPAIR 11-1

01.1

Page 601

Dec 01/96

IPL FIG. & ITEM	MATERIAL	FINISH
<u>Fig. 2</u>		
Cam (10)	17-4PH CRES, 180 ksi min	Passivate (F-17.09) all over. Cadmium plate and apply one coat of primer, BMS 10-11, type 1 (F-16.01) on 6.25-inch radius faying surface only.
Support Fitting (50)	Al alloy	Anodize (F-17.05) all over. Apply one coat of primer, BMS 10-11, type 1 (F-20.02) except omit primer on OD of 0.998-0.999 inch diameter shank shank and ID of 2.966-2.968-inch hole.
Crank (57)	Al alloy	Boric acid-sulfuric acid anodized (F-17.35). Apply BMS 10-11, type 1 primer (F-20.03) but do not put primer in the inside diameter.
Tube (110)	Al alloy	Anodize (F-17.05) all over. Apply one coat of primer, BMS 10-11, type 1 (F-20.02) except omit primer on OD of 2.962-2.964 inch faying surfaces.
Stop (100)	Al alloy	Anodize (F-17.05) all over. Apply one coat of primer, BMS 10-11, type 1 (F-20.02) except omit primer on ID of 2.966-2.968 inch hole.

Refinish Details
Figure 601 (Sheet 2)

27-31-37

REPAIR 11-1

01.1

Page 602

Mar 01/00

TORQUE TUBE - REPAIR 12-1

253T2152-1, -2

NOTE: Refer to REPAIR-GENERAL for list of applicable standard practices. For repair of surfaces which may only require restoration of original finish, refer to Repair 11-1 for finish instructions.

1. 0.260-0.263 Diameter Hole Repair for Torque Tube 253T2152-1 (255, Fig. 1)

NOTES: (1) Item numbers refer to IPL Fig. 1 unless specified differently.

(2) Assembly Fig. 701 identifies the hole locations.

A. Repair the worn or corroded 0.260-0.263 diameter holes in the torque tube (255) and the related holes in the transducer assy (5), crank assembly (7), support fitting (15) or arm assembly (115, 135) parts as follows:

- (1) Machine the holes to 0.276-0.279 inch. All of the parts are aluminum alloy. Break sharp edges. The surface roughness must be 125 microinch or better.
- (2) Do a penetrant check of the machined areas as specified in 20-20-02.
- (3) Touch up finish the parts. Refer to the following for the finishes:
 - (a) For the transducer assembly (5), the finish for the crank assembly (95, Fig. 3) is identified in Repair 8-1.
 - (b) For the crank assembly (7), the finish is identified in Repair 10-1.
 - (c) For the support fitting (15), and the torque tube (255), the finish is identified in Repair 11-1.
 - (d) For the arm assembly (115), the finish is identified in Repair 4-1.
 - (e) For the arm assembly (135), the finish is identified in Repair 3-1.
- (4) Use the applicable steps specified in Assembly par. 4 to assemble the parts to the torque tube (255), but replace the rivets with the following oversized bolts:
 - (a) Attach arm assembly (115, 135) with BACB30VH08-05 bolts.
 - (b) Attach support fitting (15) with BACB30VH08-06 bolts.
 - (c) Attach transducer assembly (5) and crank assembly (7) with BACB30VH08-07 bolts.

27-31-37

REPAIR 12-1

01.1

Page 601

Dec 01/96

2. 0.260-0.263 Diameter Hole Repair for Torque Tube 253T2152-2 (110, Fig. 2)

NOTES: (1) Item numbers refer to IPL Fig. 2 unless specified differently.

(2) Assembly Fig. 702 identifies the hole locations.

A. Repair the worn or corroded 0.260-0.263 diameter holes in the torque tube (110) and the related holes in the crank assy (30, 92), support fitting (50), transducer assy (90) or stop (100) as follows:

- (1) Machine the holes to 0.276-0.279 inch. All of the parts are aluminum alloy. Break sharp edges. The surface roughness must be 125 microinch or better.
- (2) Do a penetrant check of the machined areas as specified in 20-20-02.
- (3) Touch up finish the parts as necessary. Refer to the following for the finishes:
 - (a) For the crank assembly (30), the finish is identified in Repair 5-1.
 - (b) For the support fitting (50), stop (100) and the torque tube (110), the finish is identified in Repair 11-1.
 - (c) For the transducer assembly (90), the finish for the crank assembly (100, Fig. 3) is identified in Repair 7-1.
 - (d) For the crank assembly (92), the finish is identified in Repair 9-1.
- (4) Use the applicable steps specified in Assembly par. 6 to assemble the parts to the torque tube (110), but replace the rivets with the following oversized bolts:
 - (a) Attach crank assembly (30) with BACB30VH08-05 bolts.
 - (b) Attach support fitting (50) with BACB30VH08-06 bolts.
 - (c) Attach transducer assembly (90), crank assembly (92) and stop (100) with BACB30VH08-07 bolts.

27-31-37

REPAIR 12-1

01.1

Page 602

Dec 01/96

ASSEMBLY1. Materials

NOTE: Equivalent substitutes may be used.

- A. Primer -- BMS 10-11, type 1 (Ref 20-60-02)
- B. Sealant -- BMS 5-95 (Ref 20-60-04)
- C. Adhesive -- Type 44 (Ref 20-50-12)
- D. Grease -- MIL-G-23827 (Ref 20-60-03)
- E. Lockwire -- MS20995C32

2. Equipment

NOTE: Equivalent substitutes may be used.

- A. Deleted
- B. Force Transducer Rigging Set -- A27025-1

3. Assemble Transducer Assembly (IPL Fig. 3)

- A. Coat all surfaces of spacer (150) with grease. Install spacer (150). Install bearing (145) on crank assembly (95 or 100) as shown in 20-50-03 but use primer.
- B. Install arm assembly (70) on crank assembly with bolt (50, 52), washers (55, 57), bushings (65, 140) and nut (60, 62). Install rigging bushing A27025-3 in crank assembly (95 or 100) in place of bushing (45).

CAUTION: DO NOT APPLY ANY EXTERNAL LOAD TO TRANSDUCER ASSEMBLY WHILE RIGGING TRANSDUCER (25).

- C. Loosen jamnut of transducer (25). Install transducer (25) on arm assembly (70) and crank assembly (95 or 100) with bolts (10), washers (15), bushings (85, 155) and nuts (20).
- D. Adjust length of transducer (25) so that rigging rod A27025-2 can be passed thru arm assembly (70) and the above rigging bushing without loading transducer (25).

27-31-37ASSEMBLY
Page 701
Mar 01/00

01.1

- E. Lock adjustment with adjustment screw and locknuts of transducer (25) and recheck for no load on transducer (25). Lockwire adjustment screw and locknuts as shown in 20-50-02.
- F. Remove rigging set. Coat all surfaces of bushing (45) with grease. Install bushing (45), bolt (30), washers (35) and nut (40).
- G. Coil and protect wire bundle of transducer (25).

4. Assembly of 253T2127-5, -7, -9, -11, -13, -15, -17, -18, -19, -21
(IPL Fig. 1, 701)

NOTE: Install all rivets with wet BMS 5-95 sealant.

NOTE: See Repair 12-1 for oversized bolt information. Oversized bolts replace rivets after torque tube (255) holes are repaired as specified in Repair 12-1.

- A. If a new torque tube (255) is being installed, drill rivet holes thru tube (255) per Fig. 701 using existing holes of assemblies (5, 15, 45B, 45C, 115, 135).
- B. If a new part (5, 15, 45B or 45C or 45D, 115 or 135) is being installed, spotface to dimension shown.

NOTE: New torque tube (255) installation as shown in par. A is recommended.

- C. Apply adhesive on all faying surfaces of tube (255).
- D. On 253T2127-5, -7, -11, -13, -15, -18, -19, -21, install transducer assembly (5) on tube (255) with rivets (10).
On 253T2127-9, -17, install crank assembly (14J) on tube (255) with rivets (10).
- E. Install support fitting (15) on tube (255) with rivets (20).
- F. Install support (45B or 45C) on tube (255) with rivets (50).

27-31-37

ASSEMBLY
Page 702
Mar 01/00

01.1


BOEING
 COMPONENT
 MAINTENANCE MANUAL

- G. On 253T2127-21, bond crank (57) onto tube (255) with type 44 adhesive. Install rivets (58) onto crank (57) with BMS 5-95 sealant.
- H. Secure stick shaker (25A) on support (45B or 45C) with fasteners (30, 35, 40).
- I. Install arm assembly (115) on tube (255) with rivets (120).
- J. Install arm assembly (135) on tube (255) with rivets (140).
- K. Install fittings (165) on follower assembly (170) and secure with screws (155) and nuts (160).
- L. Align IDs of bearings (210) of follower assembly (170) between IDs of bushings (105, 125, 145) in arm assemblies (115, 135). Slide plain bushings (110) against inner race of bearings (210). Secure with bolts (80), washers (85) and nuts (90).
- M. Install spacer (70), bushing (100), bolt (65), washer (75) and nut (90) on arm assembly (135).
- N. Install bushing (95), bolts (60), washers (75), nuts (90) on arm assembly (115).

WARNING: USE EXTREME CARE WHEN INSTALLING SPRINGS. SPRINGS ARE HEAVILY LOADED.

CAUTION: DO NOT USE TOOLS THAT MAY CAUSE DAMAGE TO SPRING.

- O. Install springs (55).
- 5. Prepare and store component in accordance with standard industry practices.
- 6. Assembly of 253T2127-6, -8, -10, -12, -14, -16, -22 (IPL Fig. 2, 702)

NOTE: Install all rivets with wet BMS 5-95 sealant.

NOTE: See Repair 12-1 for oversized bolt information. Oversized bolts replace rivets after torque tube (110) holes are repaired as specified in Repair 12-1.

- A. If a new torque tube (110) is being installed, drill rivet holes thru tube (110) as shown in Fig. 702 using holes of assemblies (30, 50, 80B or 80C or 80D, 90, 100).
- B. If a new part (30, 50, 80B or 80C or 80D, 90 or 100) is being installed, spotface to dimension shown.

NOTE: New torque tube (110) installation per par. A is recommended.

- C. Apply adhesive on all faying surfaces of torque tube (110).

27-31-37



ASSEMBLY
 Page 703
 Mar 01/00

01.1

- D. Secure cam (10) on override crank assembly (30) with fasteners (15, 20, 25).
 - E. Install override crank assembly (30) on tube (110) with rivets (35).
 - F. Install fitting (50) on tube (110) with rivets (55).
 - G. Bond crank (57) onto tube (110) with type 44 adhesive. Install rivets (58) onto crank (57) with BMS 5-95 sealant.
 - H. Secure stick shaker (60A) on support (80B or 80C or 80D) with fasteners (65, 70, 75).
 - I. Install support (80B or 80C or 80D) on tube (110) with rivets (85).
 - J. On 253T2127-6, -8, -12, -14, -16, -22, install transducer assembly (90) on tube (110) with rivets (95).
On 253T2127-10, install crank assembly (99J) on tube (110) with rivets (95).
 - K. Install stop (100) on tube (110) with rivets (105).
7. Prepare and store component in accordance with standard industry practices.

27-31-37ASSEMBLY
Page 704
Mar 01/00

01.1



Torque Tube Assembly
 Figure 701 (Sheet 1)


27-31-37

ASSEMBLY
 Page 705
 Mar 01/00


01.1

**COMPONENT
MAINTENANCE MANUAL**

∠ A 0.030



B-B




C-C

**Torque Tube Assembly
Figure 701 (Sheet 2)**

27-31-37

ASSEMBLY
Page 706
Mar 01/00

01.1



1 BOND PER SOPM 20-50-12 WITH TYPE 44 ADHESIVE

2 INSTALL WITH WET SEALANT, BMS 5-95

3 FOR 253T2127-21

ITEM NUMBERS REFER TO IPL FIG. 1

ALL DIMENSIONS ARE IN INCHES


Torque Tube Assembly
 Figure 701 (Sheet 3)

27-31-37

ASSEMBLY
 Page 707
 Mar 01/00

01.1

COMPONENT
MAINTENANCE MANUAL



Torque Tube Assembly
Figure 702 (Sheet 1)


27-31-37

ASSEMBLY
Page 708
Mar 01/00


01.1

RIVET (85) 2
 0.202
 0.299 DIA HOLE

SPOTFACE 0.531-0.551 DIA
 DEPTH 0.060-0.080
 FILLET R 0.062-0.090
 (4 LOCATIONS)



C-C



D-D



RIVET (55) 2
 0.263
 0.260 DIA HOLE
 SPOTFACE 0.625-0.645 DIA
 DEPTH 0.060-0.080
 FILLET R 0.062-0.090
 (3 LOCATIONS)

Torque Tube Assembly
 Figure 702 (Sheet 2)

27-31-37

ASSEMBLY
 Page 709
 Mar 01/00

01.1



1 BOND PER SOPM 20-50-12 WITH TYPE 44 ADHESIVE

2 INSTALL WITH WET SEALANT, BMS 5-95

ITEM NUMBERS REFER TO IPL FIG. 2

ALL DIMENSIONS ARE IN INCHES



Torque Tube Assembly
 Figure 702 (Sheet 3)

27-31-37

ASSEMBLY
 Page 710
 Mar 01/00

01.1

BOEING
COMPONENT
MAINTENANCE MANUAL
FITS AND CLEARANCES




ITEM NUMBERS REFER TO IPL FIG. 1

Fits and Clearances
Figure 801 (Sheet 1)

27-31-37

FITS AND CLEARANCES
01.1 Page 801
Apr 10/84



ITEM NUMBERS REFER TO IPL FIG. 3

**Fits and Clearances
 Figure 801 (Sheet 2)**

27-31-37


BOEING
 COMPONENT
 MAINTENANCE MANUAL

Ref Letter Fig.801	Mating Item No. IPL Fig.1	Design Dimension				Service Wear Limit		
		Dimension		Assembly *[1] Clearance		Dimension		*[1] Maximum Clearance
		Min	Max	Min	Max	Min	Max	
A	ID 130	0.3750	0.3756	-0.0015	-0.0003	0.3759	0.3758	-0.0001
	OD 125	0.3759	0.3765					
B	ID 150	0.3750	0.3756	-0.0015	-0.0003	0.3759	0.3758	-0.0001
	OD 145	0.3759	0.3765					
C	ID 215	0.7489	0.7493	-0.0012	-0.0002	0.7495	0.7494	-0.0001
	OD 210	0.7495	0.7500					
D	ID 150	0.5000	0.5006	-0.0016	-0.0004	0.5010	0.5009	-0.0001
	OD 105	0.5010	0.5016					
E	ID 130	0.5000	0.5006	-0.0016	-0.0004	0.5010	0.5009	-0.0001
	OD 105	0.5010	0.5016					
F	ID 105	0.366	0.359	-0.008	-0.0155			
	OD 110	0.3745	0.3740					
G	ID 130	0.3750	0.3790	0.001	0.005			
	OD 95	0.3740	0.3745					
H	ID 150	0.3750	0.3790	0.001	0.005			
	OD 100	0.3740	0.3745					


*[1] NEGATIVE VALUES DENOTE INTERFERENCE FIT

ALL DIMENSIONS ARE IN INCHES

Fits and Clearances
 Figure 801 (Sheet 3)

27-31-37

FITS AND CLEARANCES
 01.1 Page 803
 Apr 10/84



ITEM NUMBERS REFER TO IPL FIG. 2


Ref Letter Fig.802	Mating Item No. IPL Fig.2	Design Dimension				Service Wear Limit		
		Dimension		Assembly *[1] Clearance		Dimension		*[1] Maximum Clearance
		Min	Max	Min	Max	Min	Max	
A	ID 30	0.3750	0.3756	-0.0015	-0.0003	0.3759	0.3758	-0.0001
	OD 40	0.3759	0.3765					
B	ID 30	0.5000	0.5006	-0.0016	-0.0004	0.5010	0.5009	-0.0001
	OD 5	0.5010	0.5016					

*[1] NEGATIVE VALUES DENOTE INTERFERENCE FIT

ALL DIMENSIONS ARE IN INCHES

Fits and Clearances
 Figure 802

27-31-37




TRANSDUCER ASSEMBLY

ITEM NUMBERS REFER TO IPL FIG. 3

Fits and Clearances
Figure 803 (Sheet 1)


27-31-37

FITS AND CLEARANCES
01.1 Page 805
Apr 10/84



A-A

B-B



C-C

D-D

Fits and Clearances
 Figure 803 (Sheet 2)

27-31-37


BOEING
 COMPONENT
 MAINTENANCE MANUAL

REF LETTER	REF IPL	DESIGN DIMENSION*				SERVICE WEAR LIMIT*		
	FIG. 3, MATING ITEM NO.	DIMENSION		ASSEMBLY CLEARANCE		DIMENSION		MAXIMUM CLEARANCE
		MIN	MAX	MIN	MAX	MIN	MAX	
A	ID 125,130	0.3750	0.3756	-0.0015	-0.0003	0.3759	0.3758	-0.0001
	OD 115	0.3759	0.3765				0.3759	
B	ID 125,130	0.5000	0.5006	-0.0016	-0.0004	0.5010	0.5009	-0.0001
	OD 160	0.5010	0.5016				0.5010	
C	ID 125,130	0.3125	0.3131	-0.0011	0.000	0.3131	0.3131	0.000
	OD 120	0.3131	0.3136				0.3131	
D	ID 125,130	0.3125	0.3131	-0.0011	0.000	0.3131	0.3131	0.000
	OD 155	0.3131	0.3136				0.3131	
E	ID 90	0.3125	0.3131	-0.0011	0.000	0.3131	0.3131	0.000
	OD 85	0.3131	0.3136				0.3131	
F	ID 90	0.3125	0.3131	-0.0011	0.000	0.3131	0.3131	0.000
	OD 155	0.3131	0.3136				0.3131	
G	ID 105,145	0.2495	0.2500	0.0000	0.0015	0.2480	0.2500	0.0020
	OD 50	0.2495	0.2495				0.2480	
G	ID 105,145	0.2495	0.2500	0.0000	0.0019			
	OD 52	0.2481	0.2495					
H	ID 75	0.2495	0.2505	0.0000	0.0020	0.2480	0.2505	0.0025
	OD 50	0.2485	0.2495				0.2480	
H	ID 75	0.2495	0.2505	0.0000	0.0024			
	OD 52	0.2481	0.2495					
I	ID 65	0.2500	0.2505	0.0005	0.0020	0.2480	0.2505	0.0025
	OD 50	0.2485	0.2495				0.2480	
I	ID 65	0.2500	0.2505	0.0005	0.0024			
	OD 52	0.2481	0.2495					
J	ID 90	0.5000	0.5006	-0.0016	-0.0004	0.5010	0.5009	-0.0001
	OD 140	0.5010	0.5016				0.5010	
K	ID 90	0.5625	0.5631	-0.0017	-0.0005	0.5636	0.5635	-0.0001
	OD 135	0.5636	0.5642				0.5636	
L	ID 90	0.4375	0.4381	-0.0015	-0.0003	0.4384	0.4383	-0.0001
	OD 80	0.4384	0.4390				0.4384	
M	ID 125,130	0.6250	0.6256	-0.0015	-0.0001	0.6257	0.6256	-0.0001
	OD 110	0.6257	0.6265				0.6257	

* ALL DIMENSIONS ARE IN INCHES

Fits and Clearances
 Figure 803 (Sheet 3)

27-31-37

FITS AND CLEARANCES
 01.1 Page 807
 Jun 01/95

Ref Letter Fig.803	Mating Item No. IPL Fig.3	Design Dimension				Service Wear Limit		
		Dimension		Assembly *[1] Clearance		Dimension		*[1] Maximum Clearance
		Min	Max	Min	Max	Min	Max	
N	ID 125,130	0.7488	0.7493	-0.0012	-0.0002	0.7495	0.7494	-0.0001
	OD 105	0.7495	0.7500					
O	ID 125,130	0.7488	0.7493	-0.0012	-0.0002	0.7495	0.7494	-0.0001
	OD 145	0.7495	0.7500					

*[1] NEGATIVE VALUES DENOTE INTERFERENCE FIT
 ALL DIMENSIONS ARE IN INCHES

Fits and Clearances
 Figure 803 (Sheet 4)

27-31-37

FITS AND CLEARANCES
 01.1 Page 808
 Apr 10/84

SPECIAL TOOLS

NOTE: Equivalent substitutes may be used.

1. Deleted
2. Force Transducer Rigging Set -- A27025-1

27-31-37

SPECIAL TOOLS

01.1

Page 901

Mar 01/00



ILLUSTRATED PARTS LIST

1. This section lists and illustrates replaceable or repairable component parts. The Illustrated Parts Catalog contains a complete explanation of the Boeing part numbering system.

2. Indentures show parts relationships as follows:

Assembly

Detail Parts for Assembly

Subassembly

Attaching Parts for Subassembly

Detail Parts for Subassembly

Detail Installation Parts (Included only if installation parts may be returned to shop as part of assembly)

3. One use code letter (A, B, C, etc.) is assigned in the EFF CODE column for each variation of top assembly. All listed parts are used on all top assemblies except when limitations are shown by use code letter opposite individual part entries.

4. Letter suffixes (alpha-variants) are added to item numbers for optional parts, Service Bulletin modification parts, configuration differences (except left- and right-hand parts), product improvement parts, and parts added between two sequential item numbers. The alpha-variant is not shown on illustrations when appearance and location of all variants of the part is the same.

5. Service Bulletin modifications are shown by the notations PRE SB XXXX and POST SB XXXX.

A. When a new top assembly part number is assigned by Service Bulletin, the notations appear at the top assembly level only. The configuration differences at detail part level are then shown by use code letter.

B. When the top assembly part number is not changed by the Service Bulletin, the notations appear at the detail part level.

6. Parts Interchangeability

Optional
(OPT)

The parts are optional to and interchangeable with other parts having the same item number.

Supersedes, Superseded By
(SUPSDS, SUPSD BY)

The part supersedes and is not interchangeable with the original part.

Replaces, Replaced By
(REPLS, REPLD BY)

The part replaces and is interchangeable with, or is an alternate to, the original part.

27-31-37

ILLUSTRATED PARTS LIST

01

Page 1001

Jul 10/83

VENDORS

K8455 RHP BEARINGS PLC RHP AEROSPACE
OLDENDS LANE
STONEHOUSE GL10 3RM UK

OPTK6 SPS TECHNOLOGIES INC AEROSPACE PRODUCTS DIV
5195 W 4700 SPO BOX 18459
KEARNS, UTAH 84118

06725 AIR INDUSTRIES CORPORATION
12570 KNOTT STREET
GARDEN GROVE, CALIFORNIA 92641-3932

07484 ACCURATE BUSHING CO INC
443 NORTH AVENUE
GARWOOD, NEW JERSEY 07027-1014

15653 KAYNAR TECHNOLOGY KAYNAR DIV
800 SOUTH STATE COLLEGE BLVD PO BOX 3001
FULLERTON, CALIFORNIA 92634-3001

21335 TORRINGTON CO FAFNIR BEARING DIV
59 FIELD STREET
TORRINGTON, CONNECTICUT 06790-4942

22863 KAVLICO CORP INC
14501 LOS ANGELES AVENUE
MOORPARK, CALIFORNIA 93021

30163 VALENTEC DAYRON INC
333 MAGUIRE BLVD PO BOX 140394
ORLANDO, FLORIDA 32814-0394

38443 MRC BEARINGS
402 CHANDLER STREET
JAMESTOWN, NEW YORK 14701-3802

27-31-37

ILLUSTRATED PARTS LIST
01.1 Page 1002
Mar 01/00

**BOEING**
COMPONENT
MAINTENANCE MANUALVENDORS

40920 MPB MINIATURE PRECISION BEARING DIV
PRECISION PARK PO BOX 547
KEENE, NEW HAMPSHIRE 03431

43991 FAG BEARING INCORPORATED
118 HAMILTON AVENUE
STAMFORD, CONNECTICUT 06904

5M902 FAIRCHILD IND INC FAIRCHILD AEROSPACE FASTENER DIV
3016 W LOMITA BLVD
TORRANCE, CALIFORNIA 90505-5103

52828 REPUBLIC FASTENER MFG CORP
1300 RANCHO CONEJO BLVD
NEWBURY PARK, CALIFORNIA 91320-1405

56878 SPS TECHNOLOGIES INC AEROSPACE AND INDUSTRIAL PRODUCTS DIV
HIGHLAND AVENUE
JENKINTOWN, PENNSYLVANIA 19046

60380 TORRINGTON CO BEARINGS DIV SUBSIDIARY OF INGERSOLL-RAND CORP
59 FIELD STREET PO BOX 1008
TORRINGTON, CONNECTICUT 06790-4942

62554 SIMMONDS MECAERO FASTENERS INC
1734 SEQUOIA AVENUE
ORANGE, CALIFORNIA 92668

71087 BOOTS ACFT NUT DIV TOWNSEND CO SEE TEXTRON INC CHERRY
FASTENER TOWNSEND DIV V11815

72962 HARVARD INDUSTRIES INC
3 WERNER WAY SUITE 210
LEBANON, NEW JERSEY 08833

27-31-37ILLUSTRATED PARTS LIST
01.1 Page 1003
Mar 01/00

VENDORS

73197 HI-SHEAR TECHNOLOGY CORP
2600 SKYPARK DRIVE
TORRANCE, CALIFORNIA 90509

80539 SPS TECHNOLOGIES INC AEROSPACE PRODUCTS DIV
2701 SOUTH HARBOR BOULEVARD PO BOX 1259
SANTA ANA, CALIFORNIA 92702-1259

83086 NEW HAMPSHIRE BALL BEARINGS, INCORPORATED
ROUTE 202
PETERBOROUGH, NEW HAMPSHIRE 03458

83326 SAFE FLIGHT INSTRUMENT CORPORATION
NEW KING STREET PO BOX 550
WHITE PLAINS, NEW YORK 10602

92215 FAIRCHILD IND INC FAIRCHILD AEROSPACE FASTENER DIV
3010 W LOMITA BLVD
TORRANCE, CALIFORNIA 90505-5102

92563 MCGILL MFG CO INC BEARINGS DIV
909 LAFAYETTE STREET
VALPARAISO, INDIANA 46383-4210

27-31-37

ILLUSTRATED PARTS LIST
01.1 Page 1004
Mar 01/00


BOEING
 COMPONENT
 MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NO.	FIG.	ITEM	TTL REQ
AN316-5R		1	160	6
AN960D10		3	15	4
AN960D416		3	35	1
		3	37	1
		3	55	1
		3	57	1
AN960PD10		1	35	2
		2	70	2
AN960PD416		1	85	2
		2	20	4
AN960PD416L		1	75	3
AN960PD616		1	180	1
AN960PD8L		1	195	8
BACB10AC3		80	10	2
BACB10AF6F26HS		1	175	1
BACB10BX4		1	210	2
		3	105	1
		3	145	1
BACB10FS04J		3	105A	1
BACB28AK04-017		1	100	1
BACB28AK04-030		1	110	2
BACB28AK04-035		3	65	1
BACB28AK04-049		1	95	2
BACB28AM06B014A		1	105	3
BACB28AM06B015A		2	5	1
BACB28AM06B017A		3	140	1
BACB28AM06B020A		1	11	1
		2	96	1
		3	160	1
BACB28AM07B018A		3	135	1
BACB28AM07B020A		1	13	1
		2	98	1
BACB28AP04-011		1	125	1
		1	145	2
BACB28AP04-012		2	40A	1
BACB28AP04-017		3	75	1
BACB28AP04-020		3	115	1
BACB28AP04P017		3	75A	1
BACB28AP04P020		1	12	1
		3	115A	1
BACB28AP05-018		3	80	1
BACB28AP05P020		1	14	1
		2	99	1
BACB28AT06B014C		1	105A	3
BACB28AT06B015C		2	5A	1

27-31-37

 ILLUSTRATED PARTS LIST
 01.1 Page 1005
 Mar 01/00

PART NUMBER	AIRLINE PART NO.	FIG.	ITEM	TTL REQ
BACB28AT06B017C		3	140A	1
BACB28AT07B018C		3	135A	1
BACB28X3C010		3	85	1
BACB28X3C011		3	120	1
BACB28X3C024		3	120A	1
		3	155	2
BACB28Y4C104		3	45	1
BACB28Y8C084		3	110	1
BACB30NF3-13		3	10	2
BACB30NM3K13		3	10A	2
BACB30NM3K16		1	30A	2
		2	65A	2
BACB30NR4K10		1	60	2
BACB30NR4K12		1	80	2
BACB30NR4K14		1	65	1
BACB30NR4K24		3	30	1
BACB30NR4K25		3	50	1
BACB30NR4K4		2	15A	2
BACB30NR4K6		2	15	2
BACB30VH08-05		1	120A	4
		1	140A	4
		2	35A	3
BACB30VH08-06		1	20A	8
		2	55A	8
BACB30VH08-07		1	10A	6
		2	95A	6
		2	105A	3
BACB30VT8K28		3	52	1
BACC30BL8		3	62	1
BACC45FT12C12P		80	5	3
BACN10JC08		1	200	4
BACN10JC3		1	40	2
		2	75	2
		3	20	2
BACN10JC4		1	90	5
		2	25	2
		3	40	1
		3	60	1
BACN10JC6		1	185	1
BACN10YR3CD		1	40A	2
		2	75A	2
		3	20A	2
BACN10YR4CD		1	90A	5
BACN10YR4CD		2	25A	2
		3	40A	1

27-31-37

 ILLUSTRATED PARTS LIST
 01.1 Page 1006
 Mar 01/00


BOEING
 COMPONENT
 MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NO.	FIG.	ITEM	TTL REQ
BACS12CK5-20		1	155	3
BACW10BN4AC		3	35B	1
		3	55B	1
BACW10CT8CU		3	55A	1
BRH10A08		1	200	4
BRH10A3		1	40	2
		2	75	2
		3	20	2
CS204E		1	210	2
		3	105	1
		3	145	1
C07202-3		1	25A	1
		2	60A	1
GM10242		3	25D	1
		80	1	RF
HHKSP3		80	10	2
HRS4CFR26		1	175	1
HRS4CFR6		1	175	1
HST10AG8-28		3	52	1
HST79-8		3	62	1
HST79CY8		3	62	1
H10-08BAC		1	200	4
H10-3BAC		1	40	2
		2	75	2
		3	20	2
H52732-3CD		1	40A	2
		2	75A	2
		3	20A	2
H52732-4CD		1	90A	5
		2	25A	2
		3	40A	1
KP4A		1	210	2
		3	105	1
		3	145	1

27-31-37

 ILLUSTRATED PARTS LIST
 01.1 Page 1007
 Mar 01/00

PART NUMBER	AIRLINE PART NO.	FIG.	ITEM	TTL REQ
KP4AFS428		1	210	2
		3	105	1
		3	145	1
KP4AG27		1	210	2
		3	105	1
		3	145	1
KP4ALY196		1	210	2
		3	105	1
		3	145	1
KP4ASD610		1	210	2
		3	105	1
		3	145	1
KP4A2TS		1	210	2
		3	105	1
		3	145	1
KSP3		80	10	2
LLKP4A		1	210	2
		3	105	1
		3	145	1
MS90354-0605		1	50	4
		2	85	4
MS90354-0805		1	120	4
		1	140	4
		2	35	3
MS90354-0806		1	20	8
		2	55	8
MS90354-0807		1	10	6
		2	95	6
		2	105	3
MS90354U0504		1	58	3
		2	58	4
MS90354U0605		1	50A	4
		2	85A	4
MS90354U0805		1	120B	4
		1	140B	4
		2	35B	3

27-31-37

 ILLUSTRATED PARTS LIST
 01.1 Page 1008
 Mar 01/00


BOEING
 COMPONENT
 MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NO.	FIG.	ITEM	TTL REQ
MS90354U0806		1	20B	8
		2	55B	8
MS90354U0807		1	10B	6
		2	105B	3
NAS1149D0363J		1	35A	2
		2	70A	2
NAS1149D0363J		3	15A	4
NAS1149D0416J		1	75A	3
		2	20A	4
NAS1149D0463J		1	85A	2
		3	37A	1
		3	57B	1
NAS1190E5P20		1	155A	3
NAS43DD4-24		3	150	1
NAS43DD4-24FC		3	150A	1
NAS602-9		1	190	4
NAS6603-16		1	30	2
		2	65	2
NS202101-02		1	40	2
		2	75	2
		3	20	2
NS202101-82		1	200	4
PLH53CD		1	40A	2
		2	75A	2
		3	20A	2
PLH54CD		1	90A	5
		2	25A	2
		3	40A	1
RMLH9075-3W		1	40	2
		2	75	2
		3	20	2

27-31-37

 ILLUSTRATED PARTS LIST
 01.1 Page 1009
 Mar 01/00

PART NUMBER	AIRLINE PART NO.	FIG.	ITEM	TTL REQ
RMLH9075-82W		1	200	4
S253T401-1		3	25	1
		80	1	RF
S253T401-3		3	25D	1
T6S1032J		1	40	2
		2	75	2
		3	20	2
T6S832J		1	200	4
VN303A02		1	40	2
		2	75	2
		3	20	2
VN303A82		1	200	4
10-61072-3		3	25C	1
10-61072-4		3	25B	1
253T2126-4		1	45B	1
		2	80B	1
253T2126-5		1	45C	1
		2	80C	1
253T2126-6		1	45D	1
		2	80D	1
253T2127-10		1	1J	RF
		2	1D	RF
253T2127-11		1	1K	RF
		2	1E	RF
253T2127-13		1	1M	RF
		2	1F	RF
253T2127-15		1	1P	RF
		2	1G	RF
253T2127-17		1	1R	RF
		2	1H	RF
253T2127-5		1	1D	RF
		2	1B	RF
253T2127-7		1	1F	RF
		2	1C	RF
253T2127-9		1	1H	RF
253T2128-1		1	15	1
		2	50	1
253T2129-1		2	10	1
253T2130-1		1	170	1
253T2131-1		1	135	1
253T2131-2		1	150	1
253T2132-1		1	55	3
253T2132-2		1	55A	3
253T2133-1		1	215	1
253T2134-1		1	115	1

27-31-37

 ILLUSTRATED PARTS LIST
 01.1 Page 1010
 Mar 01/00


BOEING
 COMPONENT
 MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NO.	FIG.	ITEM	TTL REQ
253T2134-2		1	130	1
253T2135-1		1	205	4
253T2145-1		2	100	1
253T2146-1		2	30	1
253T2146-2		2	45	1
253T2152-1		1	255	1
253T2152-2		2	110	1
253T2154-1		1	70	1
253T2155-1		1	165	3
253T2311-1		1	5	1
		3	1	RF
253T2311-10		2	90D	1
		3	5D	RF
253T2311-2		2	90	1
		3	5	RF
253T2311-3		1	5A	1
		3	1A	RF
253T2311-4		2	90A	1
		3	5A	RF
253T2311-5		1	5B	1
		3	1B	RF
253T2311-6		2	90B	1
		3	5B	RF
253T2311-7		1	5C	1
		3	1C	RF
253T2311-8		2	90C	1
		3	5C	RF
253T2311-9		3	1D	RF
253T2312-1		3	70	1
253T2312-2		3	90	1
253T2312-4		3	70A	1
253T2312-5		3	90A	1
253T2313-1		3	100	1


27-31-37

 ILLUSTRATED PARTS LIST
 01.1 Page 1011
 Mar 01/00

PART NUMBER	AIRLINE PART NO.	FIG.	ITEM	TTL REQ
253T2313-2		3	130	1
253T2313-4		3	100A	1
253T2313-5		3	130A	1
253T2314-1		3	95	1
253T2314-2		3	125	1
253T2314-4		3	95A	1
253T2314-5		3	125A	1
253T2316-1		2	92	1
253T2316-2		2	99J	1
253T2317-1		1	7	1
253T2317-2		1	14J	1
253T4013-2		1	57	1
		2	57	1
96-02		1	40	2
		2	75	2
		3	20	2
96-82		1	200	4

27-31-37


 ILLUSTRATED PARTS LIST
 01.1 Page 1012
 Mar 01/00



Elevator Control Torque Tube Assembly
 Figure 1 (Sheet 1)

27-31-37


ILLUSTRATED PARTS LIST
 01.1 Page 1014
 Mar 01/00



Elevator Control Torque Tube Assembly
 Figure 1 (Sheet 2)

27-31-37

ILLUSTRATED PARTS LIST
 01.1 Page 1015
 Mar 01/00



Elevator Control Torque Tube Assembly
 Figure 1 (Sheet 3)

27-31-37

ILLUSTRATED PARTS LIST
 01.1 Page 1016
 Mar 01/00


BOEING
 COMPONENT
 MAINTENANCE MANUAL

FIG. & ITEM	PART NO.	AIRLINE PART NUMBER	NOMENCLATURE 1234567	EFF CODE	QTY PER ASSY
01-					
-1	253T2127-1		DELETED		
-1A	253T2127-2		DELETED		
-1B	253T2127-3		DELETED		
-1C	253T2127-4		DELETED		
-1D	253T2127-5		TUBE ASSY-ELEV CONT TORQUE	A	RF
-1E	253T2127-6		TUBE ASSY-ELEV CONT TORQUE (FOR DETAILS SEE FIG. 2)	B	RF
-1F	253T2127-7		TUBE ASSY-ELEV CONT TORQUE	C	RF
-1G	253T2127-8		TUBE ASSY-ELEV CONT TORQUE (FOR DETAILS SEE FIG. 2)	D	RF
-1H	253T2127-9		TUBE ASSY-ELEV CONT TORQUE	E	RF
-1J	253T2127-10		TUBE ASSY-ELEV CONT TORQUE (FOR DETAILS SEE FIG. 2)	F	RF
-1K	253T2127-11		TUBE ASSY-ELEV CONT TORQUE	G	RF
-1L	253T2127-12		TUBE ASSY-ELEV CONT TORQUE (FOR DETAILS SEE FIG. 2)	H	RF
-1M	253T2127-13		TUBE ASSY-ELEV CONT TORQUE	J	RF
-1N	253T2127-14		TUBE ASSY-ELEV CONT TORQUE (FOR DETAILS SEE FIG. 2)	K	RF
-1P	253T2127-15		TUBE ASSY-ELEV CONT TORQUE	L	RF
-1Q	253T2127-16		TUBE ASSY-ELEV CONT TORQUE (FOR DETAILS SEE FIG. 2)	M	RF
-1R	253T2127-17		TUBE ASSY-ELEV CONT TORQUE	N	RF
-1S	253T2127-18		TUBE ASSY-ELEV CONT TORQUE	P	RF
-1T	253T2127-19		TUBE ASSY-ELEV CONT TORQUE	Q	RF
R -1U	253T2127-21		TUBE ASSY-ELEV CONT TORQUE	R	RF
R -1V	253T2127-22		TUBE ASSY-ELEV CONT TORQUE (FOR DETAILS SEE FIG. 2)	S	RF
5	253T2311-1		.TRANSDUCER ASSY- (FOR DETAILS SEE FIG. 3)	A,C	1
-5A	253T2311-3		.TRANSDUCER ASSY- (FOR DETAILS SEE FIG. 3)	G	1
-5B	253T2311-5		.TRANSDUCER ASSY- (FOR DETAILS SEE FIG. 3)	J,P	1
-5C	253T2311-7		.TRANSDUCER ASSY- (FOR DETAILS SEE FIG. 3)	L,Q	1
7	253T2317-1		.CRANK ASSY	E,N	1
10	MS90354-0807		ATTACHING PARTS .RIVET	A,C,E ,G,J, L,N,P ,Q	6
			-----*-----		

27-31-37

 ILLUSTRATED PARTS LIST
 01.1 Page 1017
 Mar 01/00

FIG. & ITEM	PART NO.	AIRLINE PART NUMBER	NOMENCLATURE 1234567	EFF CODE	QTY PER ASSY
R 01-10A	BACB30VH08-07		.BOLT-(OVERSIZE- (FOR REPAIR ONLY)	A,C,E ,G,J, L,N, P-R	6
R -10B	MS90354U0807		ATTACHING PARTS .RIVET -----*	R	6
11	BACB28AM06B020A		..BUSHING	E,N	1
12	BACB28AP04P020		..BUSHING	E,N	1
13	BACB28AM07B020A		..BUSHING	E,N	1
14	BACB28AP05P020		..BUSHING	E,N	1
14J	253T2317-2		..CRANK	E,N	1
15	253T2128-1		.FITTING-SPRT	A,C,E ,G,J, L,N-R	1
20	MS90354-0806		ATTACHING PARTS .RIVET -----*	A,C,E ,G,J, L,N,P ,Q	8
R -20A	BACB30VH08-06		.BOLT-(OVERSIZE- FOR REPAIR ONLY)	A,C,E ,G,J, L,N, P-R	8
R -20B	MS90354U0806		ATTACHING PARTS .RIVET -----*	R	8
25	C07202-2		DELETED		
25A	C07202-3		.SHAKER-STICK (V83326)	A,C,E ,G,J, L,N-R	1
			ATTACHING PARTS		

27-31-37

 ILLUSTRATED PARTS LIST
 01.1 Page 1018
 Mar 01/00


BOEING
 COMPONENT
 MAINTENANCE MANUAL

FIG. & ITEM	PART NO.	AIRLINE PART NUMBER	NOMENCLATURE 1234567	EFF CODE	QTY PER ASSY
01-30	NAS6603-16		.BOLT	A,C,E ,G,J, L,N,P ,Q	2
R -30A	BACB30NM3K16		.BOLT	R	2
35	AN960PD10		.WASHER	A,C,E ,G,J, L	2
-35A	NAS1149D0363J		.WASHER	N-R	2
40	H10-3BAC		.NUT- (V15653) (SPEC BACN10JC3) (OPT NS202101-02 (V80539)) (OPT RMLH9075-3W (V72962)) (OPT T6S1032J (V71087)) (OPT VN303A02 (V92215)) (OPT 96-02 (V80539)) (OPT BRH10A3 (V52828))	A,C,E ,G,J, L,N,P ,Q	2
R -40A	H52732-3CD		.NUT- (V15653) (SPEC BACN10YR3CD) (OPT PLH53CD (V62554)) -----*	R	2

27-31-37

 ILLUSTRATED PARTS LIST
 01.1 Page 1019
 Mar 01/00

FIG. & ITEM	PART NO.	AIRLINE PART NUMBER	NOMENCLATURE 1234567	EFF CODE	QTY PER ASSY
01-45	253T2126-1		DELETED		
-45A	253T2126-3		DELETED		
45B	253T2126-4		. SUPPORT	A	1
-45C	253T2126-5		. SUPPORT	C, E, G J, L N, P, Q	1
R -45D	253T2126-6		. SUPPORT ATTACHING PARTS	R	1
50	MS90354-0605		. RIVET	A, C, E G, J L, N, P Q	4
R -50A	MS90354U0605		. RIVET -----*	R	4
55	253T2132-1		. SPRING	A, C, E G, J L	3
55A	253T2132-2		. SPRING	N-R	3
R 57	253T4013-2		. CRANK ATTACHING PARTS	R	1
R 58	MS90354U0504		. RIVET -----*	R	3
60	BACB30NR4K10		. BOLT	A, C, E G, J L, N-R	2
65	BACB30NR4K14		. BOLT	A, C, E G, J L, N-R	1
70	253T2154-1		. SPACER	A, C, E G, J L, N-R	1
75	AN960PD416L		. WASHER	A, C, E G, J L	3

27-31-37

 ILLUSTRATED PARTS LIST
 01.1 Page 1020
 Mar 01/00

BOEING
 COMPONENT
 MAINTENANCE MANUAL

FIG. & ITEM	PART NO.	AIRLINE PART NUMBER	NOMENCLATURE 1234567	EFF CODE	QTY PER ASSY
01-					
-75A	NAS1149D0416J		.WASHER	N-R	3
80	BACB30NR4K12		.BOLT	A,C,E ,G,J, L,N-R	2
85	AN960PD416		.WASHER	A,C,E ,G,J, L	2
-85A	NAS1149D0463J		.WASHER	N-R	2
90	BACN10JC4		.NUT	A,C,E ,G,J, L,N,P ,Q	5
R -90A	H52732-4CD		.NUT- (V15653) (SPEC BACN10YR4CD) (OPT PLH54CD (V62554))	R	5
95	BACB28AK04-049		.BUSHING	A,C,E ,G,J, L,N-R	2
100	BACB28AK04-017		.BUSHING	A,C,E ,G,J, L,N-R	1
105	BACB28AM06B014A		.BUSHING	A,C,E ,G,J, L,N,P ,Q	3
R -105A	BACB28AT06B014C		.BUSHING	R	3
110	BACB28AK04-030		.BUSHING	A,C,E ,G,J, L,N-R	2
115	253T2134-1		.ARM ASSY	A,C,E ,G,J, L,N-R	1
120	MS90354-0805		ATTACHING PARTS .RIVET	A,C,E ,G,J, L,N,P ,Q	4
			-----*		

27-31-37

ILLUSTRATED PARTS LIST
 01.1 Page 1021
 Mar 01/00

FIG. & ITEM	PART NO.	AIRLINE PART NUMBER	NOMENCLATURE 1234567	EFF CODE	QTY PER ASSY
R 01- -120A	BACB30VH08-05		.BOLT-(OVERSIZE- FOR REPAIR ONLY)	A,C,E ,G,J, L,N, P-R	4
R -120B	MS90354U0805		ATTACHING PARTS .RIVET -----*-----	R	4
125	BACB28AP04-011		..BUSHING	A,C,E ,G,J, L,N-R	1
130	253T2134-2		..ARM	A,C,E ,G,J, L,N-R	1
135	253T2131-1		.ARM ASSY	A,C,E ,G,J, L,N-R	1
140	MS90354-0805		ATTACHING PARTS .RIVET -----*-----	A,C,E ,G,J, L,N,P ,Q	4
R -140A	BACB30VH08-05		.BOLT-(OVERSIZE- FOR REPAIR ONLY)	A,C,E ,G,J, L,N, P-R	4
R -140B	MS90354U0805		ATTACHING PARTS .RIVET -----*-----	R	4

27-31-37

 ILLUSTRATED PARTS LIST
 01.1 Page 1022
 Mar 01/00


BOEING
 COMPONENT
 MAINTENANCE MANUAL

FIG. & ITEM	PART NO.	AIRLINE PART NUMBER	NOMENCLATURE 1234567	EFF CODE	QTY PER ASSY
01-145	BACB28AP04-011		..BUSHING	A,C,E ,G,J, L,N-R	2
150	253T2131-2		..ARM	A,C,E ,G,J, L,N-R	1
155	BACS12CK5-20		.SCREW- (OPT ITEM 155A)	A,C,E ,G,J, L,N-R	3
-155A	NAS1190E5P20		.SCREW- (OPT ITEM 155)	A,C,E ,G,J, L,N-R	3
160	AN316-5R		.NUT	A,C,E ,G,J, L,N-R	6
165	253T2155-1		.FITTING	A,C,E ,G,J, L,N-R	3
170	253T2130-1		.FOLLOWER ASSY	A,C,E ,G,J, L,N-R	1
175	HRS4CFR6		..ROLLER- (V60380) (SPEC BACB10AF6F26HS) (OPT HRS4CFR26 (V07484)) (OPT HRS4CFR26 (V92563))	A,C,E ,G,J, L,N-R	1
180	AN960PD616		..WASHER	A,C,E ,G,J, L,N-R	1
185	BACN10JC6		..NUT	A,C,E ,G,J, L,N-R	1

27-31-37

 ILLUSTRATED PARTS LIST
 01.1 Page 1023
 Mar 01/00

FIG. & ITEM	PART NO.	AIRLINE PART NUMBER	NOMENCLATURE 1234567	EFF CODE	QTY PER ASSY
01-190	NAS602-9		..BOLT	A,C,E G,J L,N-R	4
195	AN960PD8L		..WASHER	A,C,E G,J L,N-R	8
200	H10-08BAC		..NUT- (V15653) (SPEC BACN10JC08) (OPT NS202101-82 (V80539)) (OPT RMLH9075-82W (V72962)) (OPT T6S832J (V71087)) (OPT VN303A82 (V92215)) (OPT 96-82 (V80539)) (OPT BRH10A08 (V52828))	A,C,E G,J L,N-R	4
205	253T2135-1		..RETAINER	A,C,E G,J L,N-R	4
210	KP4AFS428		..BEARING- (V21335) (SPEC BACB10BX4) (OPT KP4A2TS (V43991)) (OPT LLKP4A (V38443)) (OPT KP4AG27 (V30163)) (OPT KP4A (V38443)) (OPT KP4ALY196 (V40920)) (OPT KP4ASD610 (V83086)) (OPT CS204E (VK8455))	A,C,E G,J L,N-R	2

27-31-37

ILLUSTRATED PARTS LIST

01.1 Page 1024

Mar 01/00


BOEING
 COMPONENT
 MAINTENANCE MANUAL

FIG. & ITEM	PART NO.	AIRLINE PART NUMBER	NOMENCLATURE 1234567	EFF CODE	QTY PER ASSY
01- 215	253T2133-1		. . FOLLOWER	A,C,E ,G,J, L,N-R	1
255	253T2152-1		. TORQUE TUBE	A,C,E ,G,J, L,N-R	1

- Item Not Illustrated


27-31-37

ILLUSTRATED PARTS LIST

01.1

Page 1025

Mar 01/00



Elevator Control Torque Tube Assembly
 Figure 2

27-31-37

ILLUSTRATED PARTS LIST
 01.1 Page 1026
 Mar 01/00


BOEING
 COMPONENT
 MAINTENANCE MANUAL

FIG. & ITEM	PART NO.	AIRLINE PART NUMBER	NOMENCLATURE 1234567	EFF CODE	QTY PER ASSY
02-					
-1	253T2127-2		DELETED		
-1A	253T2127-4		DELETED		
-1B	253T2127-6		TUBE ASSY-ELEV CONT TORQUE	B	RF
-1C	253T2127-8		TUBE ASSY-ELEV CONT TORQUE	D	RF
-1D	253T2127-10		TUBE ASSY-ELEV CONT TORQUE	F	RF
-1E	253T2127-12		TUBE ASSY-ELEV CONT TORQUE	H	RF
-1F	253T2127-14		TUBE ASSY-ELEV CONT TORQUE	K	RF
-1G	253T2127-16		TUBE ASSY-ELEV CONT TORQUE	M	RF
R -1H	253T2127-22		TUBE ASSY-ELEV CONT TORQUE	S	RF
5	BACB28AM06B015A		.BUSHING	B,D,F ,H,K, M	1
R -5A	BACB28AT06B015C		.BUSHING	R	1
10	253T2129-1		.CAM	B,D,F ,H,K, M,S	1
15	BACB30NR4K6		ATTACHING PARTS .BOLT	B,D,F ,H,K, M	2
R -15A	BACB30NR4K4		.BOLT	S	2
20	AN960PD416		.WASHER	B,D,F ,H,K, M	4
R -20A	NAS1149D0416J		.WASHER	S	4
25	BACN10JC4		.NUT	B,D,F ,H,K, M	2
R -25A	H52732-4CD		.NUT- (V15653) (SPEC BACN10YR4CD) (OPT PLH54CD (V62554)) -----*	S	2
30	253T2146-1		.CRANK ASSY-OVERRIDE	B,D,F ,H,K, M,S	1
35	MS90354-0805		ATTACHING PARTS .RIVET	B,D,F ,H,K, M	3
R -35A	BACB30VH08-05		-----* .BOLT-(OVERSIZE- FOR REPAIR ONLY)	B,D,F ,H,K, M,S	3

27-31-37

 ILLUSTRATED PARTS LIST
 01.1 Page 1027
 Mar 01/00

FIG. & ITEM	PART NO.	AIRLINE PART NUMBER	NOMENCLATURE 1234567	EFF CODE	QTY PER ASSY
02-					
R -35B	MS90354U0805		ATTACHING PARTS .RIVET -----*-----	S	3
40	BACB28AP04-12		DELETED		
40A	BACB28AP04-012		..BUSHING	B,D,F ,H,K, M,S	1
45	253T2146-2		..CRANK	B,D,F ,H,K, M,S	1
50	253T2128-1		.FITTING	B,D,F ,H,K, M,S	1
55	MS90354-0806		ATTACHING PARTS .RIVET -----*-----	B,D,F ,H,K, M	8
R 55A	BACB30VH08-06		.BOLT-(OVERSIZE- FOR REPAIR ONLY)	B,D,F ,H,K, M,S	8
R -55B	MS90354U0806		ATTACHING PARTS .RIVET -----*-----	S	8
R 57	253T4013-2		.CRANK	S	1
R 58	MS90354U0504		ATTACHING PARTS .RIVET -----*-----	S	3
60	C07202-2		DELETED		
60A	C07202-3		.SHAKER-STICK (V83326)	B,D,F ,H,K, M,S	1
65	NAS6603-16		ATTACHING PARTS .BOLT	B,D,F ,H,K, M	2
R -65A	BACB30NM3K16		.BOLT	S	2
70	AN960PD10		.WASHER	B,D,F ,H,K, M	2
R -70A	NAS1149D0363J		.WASHER	S	2

27-31-37

 ILLUSTRATED PARTS LIST
 01.1 Page 1028
 Mar 01/00


BOEING
 COMPONENT
 MAINTENANCE MANUAL

FIG. & ITEM	PART NO.	AIRLINE PART NUMBER	NOMENCLATURE 1234567	EFF CODE	QTY PER ASSY
02-75	H10-3BAC		.NUT- (V15653) (SPEC BACN10JC3) (OPT NS202101-02 (V80539)) (OPT RMLH9075-3W (V72962)) (OPT T6S1032J (V71087)) (OPT VN303A02 (V92215)) (OPT 96-02 (V80539)) (OPT BRH10A3 (V52828))	B,D,F ,H,K, M	2
R -75A	H52732-3CD		.NUT- (V15653) (SPEC BACN10YR3CD) (OPT PLH53CD (V62554)) -----*	S	2
80	253T2126-1		DELETED		
-80A	253T2126-1		DELETED		
80B	253T2126-4		.SUPPORT	B	1
-80C	253T2126-5		.SUPPORT	D,F,H ,K,M	1
R -80D	253T2126-6		.SUPPORT ATTACHING PARTS	S	1
85	MS90354-0605		.RIVET	B,D,F ,H,K, M	4
R -85A	MS90354U0605		.RIVET -----*	S	4
90	253T2311-2		.TRANSDUCER ASSY- (FOR DETAILS SEE FIG. 3)	B,D	1
-90A	253T2311-4		.TRANSDUCER ASSY- (FOR DETAILS SEE FIG. 3)	H	1
-90B	253T2311-6		.TRANSDUCER ASSY- (FOR DETAILS SEE FIG. 3)	K	1
-90C	253T2311-8		.TRANSDUCER ASSY- (FOR DETAILS SEE FIG. 3)	M	1
R -90D	253T2311-10		.TRANSDUCER ASSY- (FOR DETAILS SEE FIG. 3)	S	1
92	253T2316-1		.CRANK ASSY	F	1
93	253T2146-1		DELETED		

27-31-37


 ILLUSTRATED PARTS LIST
 01.1 Page 1029
 Mar 01/00

FIG. & ITEM	PART NO.	AIRLINE PART NUMBER	NOMENCLATURE 1234567	EFF CODE	QTY PER ASSY
02-					
95	MS90354-0807		ATTACHING PARTS .RIVET	B,D,F ,H,K, M	6
			-----*-----		
R -95A	BACB30VH08-07		.BOLT-(OVERSIZE- FOR REPAIR ONLY)	B,D,F ,H,K, M,S	6
96	BACB28AM06B020A		..BUSHING	F	1
97	BACB28AP04P020		..BUSHING	F	1
97J	BACB28AP04-012		DELETED		
98	BACB28AM07B020A		..BUSHING	F	1
99	BACB28AP05P020		..BUSHING	F	1
99J	253T2316-2		..CRANK	F	1
99N	253T2146-2		DELETED		
100	253T2145-1		.STOP	B,D,F ,H,K, M,S	1
			ATTACHING PARTS .RIVET	B,D,F ,H,K, M,S	3
			-----*-----		
R -105A	BACB30VH08-07		.BOLT-(OVERSIZE FOR REPAIR ONLY)	B,D,F ,H,K, M,S	3
			ATTACHING PARTS .RIVET	S	3
R -105B	MS90354U0807		-----*-----		
110	253T2152-2		.TUBE	B,D,F ,H,K, M,S	1

- Item Not Illustrated

27-31-37

 ILLUSTRATED PARTS LIST
 01.1 Page 1030
 Mar 01/00



Elevator Control Force Transducer Assembly
 Figure 3

27-31-37

ILLUSTRATED PARTS LIST
 01.1 Page 1032
 Mar 01/00


BOEING
 COMPONENT
 MAINTENANCE MANUAL

FIG. & ITEM	PART NO.	AIRLINE PART NUMBER	NOMENCLATURE 1234567	EFF CODE	QTY PER ASSY
03- -1	253T2311-1		TRANSDUCER ASSY-ELEV CONT FORCE	A,C	RF
-1A	253T2311-3		TRANSDUCER ASSY-ELEV CONT FORCE	G	RF
-1B	253T2311-5		TRANSDUCER ASSY-ELEV CONT FORCE	J,P	RF
-1C	253T2311-7		TRANSDUCER ASSY-ELEV CONT FORCE	L,Q	RF
R -1D	253T2311-9		TRANSDUCER ASSY-ELEV CONT FORCE	R	RF
-5	253T2311-2		TRANSDUCER ASSY-ELEV CONT FORCE	B,D	RF
-5A	253T2311-4		TRANSDUCER ASSY-ELEV CONT FORCE	H	RF
-5B	253T2311-6		TRANSDUCER ASSY-ELEV CONT FORCE	K	RF
-5C	253T2311-8		TRANSDUCER ASSY-ELEV CONT FORCE	M	RF
R -5D	253T2311-10		TRANSDUCER ASSY-ELEV CONT FORCE	S	RF
10	BACB30NF3-13		.BOLT	A-D, G-M,P ,Q	2
R -10A	BACB30NM3K13		.BOLT	R,S	2
15	AN960D10		.WASHER	A-D, G-M,P ,Q	4
R -15A	NAS1149D0363J		.WASHER	R,S	4
20	H10-3BAC		.NUT- (V15653) (SPEC BACN10JC3) (OPT NS202101-02 (V80539)) (OPT RMLH9075-3W (V72962)) (OPT T6S1032J (V71087)) (OPT VN303A02 (V92215)) (OPT 96-02 (V80539)) (OPT BRH10A3 (V52828))	A-D, G-M,P ,Q	2

27-31-37

 ILLUSTRATED PARTS LIST
 01.1 Page 1033
 Mar 01/00

FIG. & ITEM	PART NO.	AIRLINE PART NUMBER	NOMENCLATURE 1234567	EFF CODE	QTY PER ASSY
R 03- -20A	H52732-3CD		.NUT- (V15653) (SPEC BACN10YR3CD) (OPT PLH53CD (V62554))	R,S	2
25	GM6931		.TRANSDUCER ASSY-FORCE (V22863) (SPEC S253T401-1) (FOR DETAILS SEE FIG. 80)	A-D,J ,K,P	1
-25A	10-61072-3		DELETED		
-25B	GM5341-4		.TRANSDUCER ASSY-FORCE (V22863) (SPEC 10-61072-4) (OPT ITEM 25C)	G,H,L ,M,Q	1
-25C	GM5341-1		.TRANSDUCER ASSY-FORCE (V22863) (SPEC 10-61072-3) (OPT ITEM 25B)	G,H,L ,M,Q	1
R -25D	GM10242		.TRANSDUCER ASSY-FORCE (V22863) (SPEC S253T401-3)	R,S	1
30	BACB30NR4K24		.BOLT	A-D, G-M, P-S	1
R 35	AN960D416		.WASHER	A-D, G-M,P ,Q	1
R -35A	BACWBN4AC		DELETED		
R -35B	BACW10BN4AC		.WASHER	R,S	1
R 37	AN960D416		.WASHER	A-D, G-M,P ,Q	1

27-31-37

 ILLUSTRATED PARTS LIST
 01.1 Page 1034
 Mar 01/00


BOEING
 COMPONENT
 MAINTENANCE MANUAL

FIG. & ITEM	PART NO.	AIRLINE PART NUMBER	NOMENCLATURE 1234567	EFF CODE	QTY PER ASSY
R 03-					
-37A	NAS1149D0463J		.WASHER	R,S	1
40	BACN10JC4		.NUT	A-D, G-M,P Q	1
R -40A	H52732-4CD		.NUT- (V15653) (SPEC BACN10YR4CD) (OPT PLH54CD (V62554))	R,S	1
45	BACB28Y4C104		.BUSHING	A-D, G-M, P-S	1
50	BACB30NR4K25		.BOLT	A-D,G H	1
52	HST10AG8-28		.BOLT- (VOPTK6) (SPEC BACB30VT8K28) (OPT HST10AG8-28 (V06725)) (OPT HST10AG8-28 (V56878)) (OPT HST10AG8-28 (V73197))	J-M, P-S	1
55	AN960D416		.WASHER	A-D,G H	1
-55A	BACW10CT8CU		.WASHER	J-M,P Q	1
R -55B	BACW10BN4AC		.WASHER	R,S	1
57	AN960D416		.WASHER	A-D,G H	1
-57A	AN960JD416		.WASHER	J-M,P Q	1
R -57B	NAS1149D0463J		.WASHER	R,S	1

27-31-37

 ILLUSTRATED PARTS LIST
 01.1 Page 1035
 Mar 01/00

FIG. & ITEM	PART NO.	AIRLINE PART NUMBER	NOMENCLATURE 1234567	EFF CODE	QTY PER ASSY
03-60	BACN10JC4		.NUT	A-D,G	1
R 62	HST79CY8		.COLLAR- (V73197) (SPEC BACC30BL8) (OPT HST79-8 (V56878)) (OPT HST79-8 (V92215)) (OPT HST79-8 (V5M902))	,H J-M, P-S	1
65	BACB28AK04-035		.BUSHING	A-D, G-M, P-S	1
70	253T2312-1		.ARM ASSY	A-D, G-M,P	1
R -70A	253T2312-4		.ARM ASSY	,Q R,S	1
75	BACB28AP04-017		..BUSHING	A-D, G-M,P	1
R -75A	BACB28AP04P017		..BUSHING	,Q R,S	1
80	BACB28AP05-018		..BUSHING	A-D, G-M,P	1
R -80A	BACB28AP05P018		..BUSHING	,Q R,S	1
85	BACB28X3C010		..BUSHING	A-D, G-M, P-S	1
90	253T2312-2		..ARM	A-D, G-M,P	1
R -90A	253T2312-5		..ARM	,Q R,S	1
95	253T2314-1		.CRANK ASSY	A,C,G ,J,L, P,Q	1
R -95A	253T2314-4		.CRANK ASSY	R	1

27-31-37

 ILLUSTRATED PARTS LIST
 01.1 Page 1036
 Mar 01/00


BOEING
 COMPONENT
 MAINTENANCE MANUAL

FIG. & ITEM	PART NO.	AIRLINE PART NUMBER	NOMENCLATURE 1234567	EFF CODE	QTY PER ASSY
	03- -100	253T2313-1	.CRANK ASSY	B,D,H ,K,M	1
R	-100A 105	253T2313-4 KP4AFS428	.CRANK ASSY ..BEARING- (V21335) (SPEC BACB10BX4) (OPT KP4A2TS (V43991)) (OPT LLKP4A (V38443)) (OPT KP4AG27 (V30163)) (OPT KP4A (V38443)) (OPT KP4ALY196 (V40920)) (OPT KP4ASD610 (V83086)) (OPT CS204E (VK8455))	S A-D, G-M,P ,Q	1 1
R	-105A 110	BACB10FS04J BACB28Y8C084	..BEARING ..BUSHING	R,S A-D, G-M,P ,Q	1 1
	115	BACB28AP04-020	..BUSHING	A-D, G-M,P ,Q	1
R	-115A 120	BACB28AP04P020 BACB28X3C011	..BUSHING ..BUSHING	R,S A-D, G-M,P ,Q	1 1
R	-120A 125	BACB28X3C024 253T2314-2	..BUSHING ..CRANK	R,S A,C,G ,J,L, P,Q	1 1
R	-125A -130	253T2314-5 253T2313-2	..CRANK ..CRANK	R B,D,H ,K,M	1 1
R	-130A 135	253T2313-5 BACB28AM07B018A	..CRANK ..BUSHING	S A-D, G-M,P ,Q	1 1

27-31-37

ILLUSTRATED PARTS LIST

01.1

Page 1037

Mar 01/00

FIG. & ITEM	PART NO.	AIRLINE PART NUMBER	NOMENCLATURE 1234567	EFF CODE	QTY PER ASSY
R 03- -135A 140	BACB28AT07B018C BACB28AM06B017A		.BUSHING .BUSHING	R,S A-D, G-M,P ,Q	1 1
R -140A 145	BACB28AT06B017C KP4AFS428		.BUSHING .BEARING- (V21335) (SPEC BACB10BX4) (OPT KP4A2TS (V43991)) (OPT LLKP4A (V38443)) (OPT KP4AG27 (V30163)) (OPT KP4A (V38443)) (OPT KP4ALY196 (V40920)) (OPT KP4ASD610 (V83086)) (OPT CS204E (VK8455))	R,S A-D, G-M, P-S	1 1
150	NAS43DD4-24		.SPACER	A-D, G-M,P ,Q	1
R -150A 155	NAS43DD4-24FC BACB28X3C024		.SPACER .BUSHING	R,S A-D, G-M,P ,Q	1 2

27-31-37

 ILLUSTRATED PARTS LIST
 01.1 Page 1038
 Mar 01/00


BOEING
 COMPONENT
 MAINTENANCE MANUAL

FIG. & ITEM	PART NO.	AIRLINE PART NUMBER	NOMENCLATURE 1234567	EFF CODE	QTY PER ASSY
03- 160	BACB28AM06B020A		.BUSHING	A-D, G-M, P-S	1


- Item Not Illustrated

27-31-37

ILLUSTRATED PARTS LIST

01.1 Page 1039

Mar 01/00



Force Transducer Assembly
Figure 80

27-31-37

ILLUSTRATED PARTS LIST
01.1 Page 1040
Mar 01/00


BOEING
 COMPONENT
 MAINTENANCE MANUAL

FIG. & ITEM	PART NO.	AIRLINE PART NUMBER	NOMENCLATURE 1234567	EFF CODE	QTY PER ASSY
80- -1	GM6931		TRANSDUCER ASSY-FORCE (V22863) (SPEC S253T401-1)	A-D, J K, P	RF
5	BACC45FT12C12P		.CONNECTOR	A-D, J K, P	3
10	KSP3		.BEARING- (V38443) (SPEC BACB10AC3) (OPT KSP3-2TS (V43991)) (OPT KSP3E9440A (V21335)) (OPT KSP3FS428 (V21335)) (OPT HHKSP3 (V38443)) (OPT KSP3G27 (V30163))	A-D, J K, P	2

- Item Not Illustrated

27-31-37

ILLUSTRATED PARTS LIST
 01.1 Page 1041
 Mar 01/00