

 **BOEING**  
COMPONENT  
MAINTENANCE MANUAL

TO: ALL HOLDERS OF MAIN LANDING GEAR BRAKE, WHEEL AND TIRE, INAXLE, HUB CAP  
INSTALLATIONS COMPONENT MAINTENANCE MANUAL 32-11-27.

REVISION NO. 2 DATED NOV 01/02

HIGHLIGHTS

Pages which have been added or revised are outlined below together with the highlights of the revision. Remove and insert the affected pages as listed and enter Revision No. and date on the Record of Revision Sheet.

CHAPTER/SECTION

AND PAGE NO.

DESCRIPTION OF CHANGE

TITLE PAGE

Added 165T0002-2, -3.

1

TR & SB RECORD

1

DESCRIPTION & OPERATION Added clarifications and updated callouts.

1

301-302

401

501

REPAIR-GEN

601

REPAIR 1-1

601-602

REPAIR 2-1

601-602

REPAIR 2-2

601-602,604

REPAIR 3-1

601-602

REPAIR 3-2

601-604

**32-11-27**

HIGHLIGHTS

01.1

Page 1

Nov 01/02

 **BOEING**  
COMPONENT  
MAINTENANCE MANUAL

CHAPTER/SECTION  
AND PAGE NO.

REPAIR 4-1  
601  
REPAIR 5-1  
601  
701-709

DESCRIPTION OF CHANGE

HIGHLIGHT CONTINUED FROM PREVIOUS PAGE

**32-11-27**

HIGHLIGHTS

01.1

Page 2

Nov 01/02

# MAIN LANDING GEAR BRAKE, WHEEL AND TIRE, IN AXLE, HUB CAP INSTALLATIONS

PART NUMBERS 165T0001-1  
165T0002-1,-2,-3  
165T0003-1  
165T0004-1

COMPONENT MAINTENANCE MANUAL  
WITH  
ILLUSTRATED PARTS LIST

**32-11-27**

TITLE PAGE

Page 1

Nov 01/02

01.1

165T0001  
165T0002  
165T0003  
165T0004



REVISION RECORD

- Retain this record in front of manual. On receipt of revision, insert revised pages in the manual, and enter revision number, date inserted and initial.

REVISION NUMBER	REVISION DATE	DATE FILED	BY	REVISION NUMBER	REVISION DATE	DATE FILED	BY

32-11-27

REVISION RECORD

01

Page 1

Mar 01/00

K93439

165T0001  
165T0002  
165T0003  
165T0004

 **BOEING**  
COMPONENT  
MAINTENANCE MANUAL

TEMPORARY REVISION AND SERVICE BULLETIN RECORD

BOEING SERVICE BULLETIN	BOEING TEMPORARY REVISION	OTHER DIRECTIVE	DATE OF INCORPORATION INTO MANUAL
		MC 3245MP6099M	NOV 01/00

**32-11-27**

TR & SB RECORD

01.1

Page 1

Nov 01/02

165T0001  
 165T0002  
 165T0003  
 165T0004

 **BOEING**  
 COMPONENT  
 MAINTENANCE MANUAL

PAGE	DATE	CODE	PAGE	DATE	CODE
32-11-27			REPAIR-GENERAL		
			*601	NOV 01/02	01.1
			*602	BLANK	
TITLE PAGE			REPAIR 1-1		
*1	NOV 01/02	01.1	*601	NOV 01/02	01.1
2	BLANK		*602	NOV 01/02	01.1
REVISION RECORD			REPAIR 2-1		
1	MAR 01/00	01	*601	NOV 01/02	01.1
2	BLANK		*602	NOV 01/02	01.1
TR & SB RECORD			REPAIR 2-2		
*1	NOV 01/02	01.1	*601	NOV 01/02	01.1
2	BLANK		*602	NOV 01/02	01.1
LIST OF EFFECTIVE PAGES			603	MAR 01/00	01
*1	NOV 01/02	01	*604	NOV 01/02	01.1
THRU LAST PAGE			REPAIR 3-1		
CONTENTS			*601	NOV 01/02	01.1
1	MAR 01/00	01	*602	NOV 01/02	01.1
2	BLANK		REPAIR 3-2		
INTRODUCTION			*601	NOV 01/02	01.1
1	MAR 01/00	01	*602	NOV 01/02	01.1
2	BLANK		*603	NOV 01/02	01.1
DESCRIPTION & OPERATION			*604	NOV 01/02	01.1
*1	NOV 01/02	01.1	REPAIR 4-1		
2	BLANK		*601	NOV 01/02	01.1
DISASSEMBLY			*602	NOV 01/02	01.101
*301	NOV 01/02	01.1	*603	NOV 01/02	01.101
*302	NOV 01/02	01.1	*604	BLANK	
CLEANING			REPAIR 5-1		
*401	NOV 01/02	01.1	*601	NOV 01/02	01.1
402	BLANK		*602	NOV 01/02	01.101
CHECK			*603	NOV 01/02	01.101
*501	NOV 01/02	01.1	*604	BLANK	
502	BLANK				

\* = REVISED, ADDED OR DELETED

**32-11-27**

EFFECTIVE PAGES  
 CONTINUED Page 1  
 01 Nov 01/02

PAGE	DATE	CODE	PAGE	DATE	CODE
ASSEMBLY					
*701	NOV 01/02	01.1			
*702	NOV 01/02	01.1			
*703	NOV 01/02	01.1			
*704	NOV 01/02	01.1			
*705	NOV 01/02	01.1			
*706	NOV 01/02	01.1			
*707	NOV 01/02	01.1			
*708	NOV 01/02	01.1			
*709	NOV 01/02	01.1			
710	BLANK				
ILLUSTRATED PARTS LIST					
1001	MAR 01/00	01			
1002	NOV 01/00	01.1			
1003	NOV 01/00	01.1			
1004	NOV 01/00	01.1			
1005	NOV 01/00	01.1			
1006	NOV 01/00	01.1			
1007	NOV 01/00	01.1			
1008	NOV 01/00	01.1			
1009	NOV 01/00	01.1			
1010	NOV 01/00	01.1			
1011	BLANK				
1012	NOV 01/00	01.1			
1013	NOV 01/00	01.1			
1014	NOV 01/00	01.1			
1015	BLANK				
1016	NOV 01/00	01.1			
1017	NOV 01/00	01.1			
1018	NOV 01/00	01.1			
1019	BLANK				
1020	NOV 01/00	01.1			
1021	NOV 01/00	01.1			
1022	BLANK				

\* = REVISED, ADDED OR DELETED

**32-11-27**

EFFECTIVE PAGES  
 LAST PAGE Page 2  
 01 Nov 01/02

165T0001  
165T0002  
165T0003  
165T0004



TABLE OF CONTENTS

<u>Paragraph Title</u>	<u>Page</u>
Description and Operation . . . . .	1
Testing and Fault Isolation . . . . .*[1]	
Disassembly . . . . .	301
Cleaning. . . . .	401
Check . . . . .	501
Repair. . . . .	601
Assembly. . . . .	701
Special Tools . . . . .*[1]	
Illustrated Parts List. . . . .	1001

\*[1] Not Applicable.

**32-11-27**

01  
CONTENTS  
Page 1  
Mar 01/00



INTRODUCTION

The instructions in this manual provide the information necessary to perform maintenance functions ranging from simple checks and replacement to complete shop-type repair.

This manual is divided into separate sections:

- |  |                              |
|--|------------------------------|
| 1. Title Page                                      | 4. List of Effective Pages   |
| 2. Record of Revisions                             | 5. Table of Contents         |
| 3. Temporary Revision &<br>Service Bulletin Record | 6. Introduction              |
|  | 7. Procedures & IPL Sections |

Refer to the Table of Contents for the page location of applicable sections.

The beginning of the REPAIR section includes a list of the separate repairs, a list of applicable standard Boeing practices, and an explanation of the True Position Dimensioning symbols used.

An explanation of the use of the Illustrated Parts List is provided in the Introduction to that section.

All weights and measurements used in the manual are in English units, unless otherwise stated. When metric equivalents are given they will be in parentheses following the English units.

Design changes, optional parts, configuration differences and Service Bulletin modifications create alternate part numbers. These are identified in the Illustrated Parts List (IPL) by adding an alphabetical character to the basic item number. The resulting item number is called an alpha-variant. Throughout the manual, IPL basic item number references also apply to alpha-variants unless otherwise indicated.

Verification:

**32-11-27**

INTRODUCTION

01

Page 1

Mar 01/00

MAIN LANDING GEAR BRAKE, WHEEL AND TIRE,  
IN-AXLE, HUB CAP INSTALLATIONS

DESCRIPTION AND OPERATION

1. Description

A. The main landing gear wheels/brakes/equipment installation components include hubcap installations, in-axle installations, wheel and tire assemblies, and brake installations. Because the wheel and tire assemblies and the brake assemblies are made by vendors, the repair procedures for these assemblies are covered by the vendor component maintenance manuals.

2. Operation

A. The wheel and tire assemblies, the in-axle installations, and the brake assemblies support the airplane main landing gear during taxi, takeoff, and landing.

3. Leading Particulars (Approximate)

A. Weight of each wheel/tire assembly -- 426 pounds

**32-11-27**

DESCRIPTION & OPERATION

01.1

Page 1

Nov 01/02

DISASSEMBLY

1. General

- A. This procedure has the data necessary to disassemble the main landing gear brake, wheel and tire, in-axle, and hub cap installation components.
- B. Disassemble this component sufficiently to isolate the defects, do the necessary repairs, and put the component back to a serviceable condition.
- C. Refer to IPL Fig. 1 thru 4 for item numbers.

2. Disassembly

A. Procedure

- (1) Use standard industry procedures and these steps.
- (2) Remove the hub cap assembly (15, IPL Fig. 4) from the wheel and tire assembly (5, IPL Fig. 2).
  - (a) Remove V-clamp (Fig. 4, 5), spacer (Fig. 4, 10), and hub cap assembly (Fig. 4, 15).
  - (b) Remove bolts (Fig. 4, 20), washers (Fig. 4, 25), and hub cap assembly (Fig. 4, 30).
  - (c) Remove screw (Fig. 4, 45), washer (Fig. 4, 50), and driver (Fig. 4, 60) from coupling assembly (Fig. 4, 65).
- (3) Remove the wheel and tire assemblies from each axle of the main landing gear.
- (4) Remove in-axle assembly (Fig. 3, 20) from the axle.
  - (a) Remove bolts (Fig. 3, 5), washers (Fig. 3, 10), nuts (Fig. 3, 15).

**32-11-27**

DISASSEMBLY

01.1

Page 301

Nov 01/02

- (b) Pull out the in-axle assembly and disconnect it from the electrical lines.
  - (c) Remove screws (Fig. 3, 25), nuts (Fig. 3, 30), connector (Fig. 3, 32), screws (Fig. 3, 35) and plate (Fig. 3, 40).
  - (d) Remove nut-retainer (Fig. 3, 90), and antiskid assembly (Fig. 3, 65).
  - (e) Remove bolts (Fig. 3, 70), washers (Fig. 3, 75), transducer (Fig. 3, 85).
- (5) Remove lockwire, bolts (Fig. 1, 20), washers (Fig. 1, 25), sensor (Fig. 1, 30) and brake assembly.
- (6) Disconnect the hose half quick disconnect (QD) (Fig. 1, 35), remove bolts (Fig. 1, 45), washers (Fig. 1, 50), brake disconnect (Fig. 1, 55), brake assembly (Fig. 1, 60), backup ring (Fig. 1, 65), packing (Fig. 1, 70).

**32-11-27**

DISASSEMBLY

01.1

Page 302

Nov 01/02

CLEANING

1. General

- A. This procedure has the data necessary to clean main landing gear wheels/brakes/hub cap/in-axle components.
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for details of the SOPM subjects identified in this procedure.

2. Cleaning

A. Reference

- (1) SOPM 20-30-03, General Cleaning Procedures

B. Procedure

- (1) Clean all parts by standard industry practices and the instructions in SOPM 20-30-03.

**32-11-27**

CLEANING  
Page 401  
Nov 01/02

01.1

CHECK

1. General

- A. This procedure has the data necessary to find defects in the material of the specified parts.
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for details of the SOPM subjects identified in this procedure.

2. Check

A. References

- (1) SOPM 20-20-01, Magnetic Particle Inspection
- (2) SOPM 20-20-02, Penetrant Methods of Inspection

B. Procedure

- (1) Use standard industry practices to do a visual check of all the parts for defects. Do the penetrant or magnetic particle check if the visual check shows possible defects on the parts listed below:
  - (a) Dog (85, IPL Fig. 3)
- (2) Do a magnetic particle check (SOPM 20-20-01) of these parts:
  - (a) Adapter (60, 60A, IPL Fig. 3)
- (3) Do a penetrant check (SOPM 20-20-02) of these parts:
  - (a) Adapter (60, 60A, IPL Fig. 3)

32-11-27

CHECK

01.1

Page 501

Nov 01/02

REPAIR – GENERAL

1. General

- A. Instructions for repair, refinish, and replacement of the specified subassembly parts are included in each REPAIR when applicable:

<u>PART NUMBER</u>	<u>NAME</u>	<u>REPAIR</u>
---	REFINISH OF OTHER PARTS	1-1
163U6003-1,-6	HUB CAP ASSEMBLY	2-1, 2-2
294W5142-1	HUB CAP ASSEMBLY	3-1, 3-2
294W5131-2	ADAPTER	4-1
294W5131-4	ADAPTER	5-1

2. Dimensioning Symbols

- | A. Standard True Position Dimensioning Symbols used in the applicable repair procedures are shown in SOPM 20-00-00.

**32-11-27**

REPAIR-GENERAL

01.1

Page 601

Nov 01/02

REFINISH OF OTHER PARTS – REPAIR 1-1

1. General

- A. This procedure has the data necessary to refinish the parts which are not given in the specified repairs.
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for details of the SOPM subjects identified in this procedure.

2. Refinish of Other Parts

A. General

- (1) Instructions for the repair of the parts listed in Table 601 are for repair of the initial finish.

B. Consumable Materials

NOTE: Equivalent material can be used.

- (1) A00359 Sealant -- BMS 5-95 (SOPM 20-60-04)

C. References

- (1) SOPM 20-30-02, Stripping of Protective Finishes
- (2) SOPM 20-30-03, General Cleaning Procedures
- (3) SOPM 20-41-01, Decoding Table for Boeing Finish Codes
- (4) SOPM 20-41-02, Application of Chemical and Solvent Resistant Finishes
- (5) SOPM 20-60-02, Finishing Materials

**32-11-27**

REPAIR 1-1

01.1

Page 601

Nov 01/02



D. Procedure

IPL FIG. & ITEM	MATERIAL	FINISH
<u>IPL Fig. 3</u>		
Washer (70)	15-5PH CRES	Passivate (F-17.25, which replaces F-17.09).
Dog (80, 80A)	15-5PH CRES	Passivate (F-17.25, which replaces F-17.09).
<u>IPL Fig. 4</u>		
Washer (25, 50)	15-5PH CRES	Passivate (F-17.25, which replaces F-17.09).

Refinish Details  
 Table 601

**32-11-27**

REPAIR 1-1

01.1

Page 602

Nov 01/02

HUB CAP ASSEMBLY – REPAIR 2-1

163U6003-1, -6

1. General

- A. This procedure has the data necessary to replace the parts of the hub cap assembly (30, 30A).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for details of the SOPM subjects identified in this procedure.
- C. Refer to IPL Fig. 4 for item numbers.
- D. References
  - (1) SOPM 20-41-01, Decoding Table for Boeing Finish Codes
  - (2) SOPM 20-50-03, Bearing and Bushing Replacement
- E. Procedure
  - (1) Remove the locator pin (35) from the hub cap.
  - (2) If you find defects on hub cap surfaces, refer to REPAIR 2-2 for repair instructions.
  - (3) Install a replacement locator pin (35) in the hub cap by the shrink-fit method (SOPM 20-50-03).


**32-11-27**

REPAIR 2-1

01.1

Page 601

Nov 01/02



1 INSTALL BY SHRINK FIT METHOD

ITEM NUMBERS REFER TO IPL FIG. 4

163U6003-1,-6  
 Hubcap Assembly Parts Replacement  
 Figure 601

**32-11-27**

REPAIR 2-1  
 Page 602  
 Nov 01/02

01.1

HUB CAP - REPAIR 2-2

163T6003-3, -7

1. General

- A. This procedure has the data necessary to repair and refinish the hub cap (40, 40A).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for details of the SOPM subjects identified in this procedure.
- C. Refer to IPL Fig. 4 for item numbers.
- D. General repair details:

(1) Material: Aluminum alloy

2. Hub Refinish

A. Consumable Materials

NOTE: Equivalent material can be used.

- (1) C00432 Primer -- BMS 10-11, Type 1 (SOPM 20-60-02)
- (2) C00033 Enamel -- BMS 10-60, Type 1 (SOPM 20-60-02)

B. References

- (1) SOPM 20-20-02, Penetrant Methods of Inspection
- (2) SOPM 20-30-02, Stripping of Protective Finishes
- (3) SOPM 20-30-03, General Cleaning Procedures
- (4) SOPM 20-41-01, Decoding Table For Boeing Finish Codes
- (5) SOPM 20-60-02, Finishing Materials

**32-11-27**

REPAIR 2-2

01.1

Page 601

Nov 01/02

C. Procedure (Fig. 601)

- (1) Chromic acid anodize and apply primer BMS 10-11, Type 1 (F-18.13).
- (2) Apply BMS 10-60, Type 1, gloss enamel (F-14.9813, which replaces SRF-14.9813).

**32-11-27**

REPAIR 2-2


01.1

Page 602

Nov 01/02

165T0001  
 165T0002  
 165T0003  
 165T0004

**BOEING**  
 COMPONENT  
 MAINTENANCE MANUAL



163U6003-3,-7  
 Hubcap Repair  
 Figure 601 (Sheet 1)

**32-11-27**

REPAIR 2-2  
 Page 603  
 Mar 01/00

01

SPOTFACE


0.20 DIA X 0.02  
 0.18 DIA X 0.01

0.126 DIA  
 0.125 DIA

$\oplus$	0.005	$\textcircled{M}$	D	E
----------	-------	-------------------	---	---


FILLET R

0.10 R  
 0.08 R




(A)

HUBCAP (40)



7.790 DIA (REF)  
 7.785

C-C



1 NO ENAMEL IN THIS AREA AND ALL INTERIOR SURFACES

2 ALLOWED MISMATCH IN THIS AREA  $\pm 0.010$

125 ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ITEM NUMBERS REFER TO IPL FIG. 4

ALL DIMENSIONS ARE IN INCHES

163U6003-3,-7  
 Hubcap Repair  
 Figure 601 (Sheet 2)

**32-11-27**

REPAIR 2-2

Page 604

Nov 01/02

01.1

HUB CAP ASSEMBLY – REPAIR 3-1

294W5142-1

1. General

- A. This procedure has the data necessary to replace the parts of the hub cap assembly (30).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for details of the SOPM subjects identified in this procedure.
- C. Refer to IPL Fig. 4 for item numbers.
- D. References
  - (1) SOPM 20-41-01, Decoding Table for Boeing Finish Codes
  - (2) SOPM 20-50-03, Bearing and Bushing Replacement
- E. Procedure
  - (1) Remove the old locator pin (35) from the hub cap.
  - (2) If you find defects on the hub cap, refer to REPAIR 3-2 for repair instructions.
  - (3) Install a replacement locator pin (35) in the hub cap by the shrink-fit method (SOPM 20-50-03).

**32-11-27**


REPAIR 3-1

01.1

Page 601

Nov 01/02





1 INSTALL THE PIN BY THE SHRINK FIT  
PROCEDURE (SOPM 20-50-03) WITH  
BMS 5-95 SEALANT

ITEM NUMBERS REFER TO IPL FIG. 4

294W5142-1  
Hub Assembly Repair  
Figure 601

**32-11-27**

REPAIR 3-1  
Page 602  
Nov 01/02

01.1

HUB CAP - REPAIR 3-2

294W5142-2

1. General

- A. This procedure has the data necessary to repair and refinish the hub cap (40).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for details of the SOPM subjects identified in this procedure.
- C. Refer to IPL Fig. 4 for item numbers.
- D. General repair details:

(1) Material: Aluminum alloy

2. Hub Refinish

A. Consumable Materials

NOTE: Equivalent material can be used.

- (1) C00175 Coating -- BMS 10-79, Type 3 Primer (SOPM 20-60-02)
- (2) C00033 Enamel -- BMS 10-60, Type 2, Color 707 (SOPM 20-60-02)

B. References

- (1) SOPM 20-20-02, Penetrant Methods of Inspection
- (2) SOPM 20-30-02, Stripping of Protective Finishes
- (3) SOPM 20-30-03, General Cleaning Procedures
- (4) SOPM 20-41-01, Decoding Table For Boeing Finish Codes
- (5) SOPM 20-60-02, Finishing Materials

**32-11-27**

REPAIR 3-2

01.1

Page 601

Nov 01/02

C. Procedure (Fig. 601)

- (1) Boric acid-sulfuric acid anodize (F-17.31).
- (2) Apply BMS 10-79, Type 3, primer (F-19.47) and BMS 10-60, Type 2, gloss Enamel (F-19.39-707).

**32-11-27**


REPAIR 3-2

Page 602

Nov 01/02

01.1

165T0001  
 165T0002  
 165T0003  
 165T0004




294W5142-2  
 Hubcap Repair  
 Figure 601 (Sheet 1)

**32-11-27**

REPAIR 3-2  
 Page 603  
 Nov 01/02

01.1

K76272



- 1 DIMENSION MUST STAY WITHIN THESE LIMITS WITH THE PART IN UNRESTRAINED CONDITION
- 2 NO ENAMEL IN THIS AREA AND ALL INTERIOR SURFACES
- 3 RUNOUT CAN BE MEASURED WITH DATUM FEATURES HELD IN RESTRAINED POSITION

- 125 ✓ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY
- BREAK ALL SHARP EDGES
- ITEM NUMBERS REFER TO IPL FIG. 4
- ALL DIMENSIONS ARE IN INCHES

294W5142-2  
 Hubcap Repair  
 Figure 601 (Sheet 2)

ADAPTER – REPAIR 4-1

294W5131-2

1. General

- A. This procedure has the data necessary to refinish adapter (60).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for details of the SOPM subjects identified in this procedure.
- C. Refer to IPL Fig. 3 for item numbers.
- D. General repair details:
  - (1) Material: Aluminum alloy

2. Support Transducer Refinish

A. Consumable Materials

NOTE: Equivalent material can be used.

- (1) C00259 Primer -- BMS 10-11, Type (SOPM 20-60-02)

B. References

- (1) SOPM 20-30-02, Stripping of Protective Finishes
- (2) SOPM 20-41-01, Decoding Table for Boeing Finish Codes
- (3) SOPM 20-41-02, Application of Solvent and Chemical Resistant Finishes
- (4) SOPM 20-43-01, Chromic Acid Anodizing

C. Procedure (Fig. 601)

- (1) Chromic acid anodize (F-17.05).
- (2) Apply BMS 10-11, Type 1 primer (F-20.03) unless shown differently.



**32-11-27**

REPAIR 4-1

01.1

Page 601

Nov 01/02




SPOTFACE  
 0.729 DIA X 0.090  
 0.709 DIA X 0.062 FILLET R

0.277 DIA  
 0.267 DIA

⊕	∅	0.010	M	A	M	B
---	---	-------	---	---	---	---

(10 LOCATIONS)

A-A



0.190 DIA 1  
 0.170 DIA 1

⊕	∅	0.010	M	C	S	B
---	---	-------	---	---	---	---

-D-

0.1245 DIA 1  
 0.1235 DIA 1

⊕	∅	0.010	M	C	S	D	M
---	---	-------	---	---	---	---	---

SPOTFACE  
 0.635 DIA X 0.090  
 0.615 DIA X 0.062 FILLET R

0.229 DIA  
 0.218 DIA

⊕	∅	0.010	M	C	S	B	D	M
---	---	-------	---	---	---	---	---	---

(3 LOCATIONS)

294W5131-2  
 Adapter Repair  
 Figure 601 (Sheet 1)

**32-11-27**


REPAIR 4-1

01.101

Page 602

Nov 01/02

165T0001  
165T0002  
165T0003  
165T0004



DO NOT PRIME THIS SURFACE

ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ALL DIMENSIONS ARE IN INCHES

294W5131-2  
Adapter Repair  
Figure 601 (Sheet 2)

**32-11-27**

REPAIR 4-1

01.101

Page 603

Nov 01/02

K76890



ADAPTER – REPAIR 5-1

294W5131-4

1. General

- A. This procedure has the data necessary to refinish adapter (60).
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for details of the SOPM subjects identified in this procedure.
- C. Refer to IPL Fig. 3 for item numbers.
- D. General repair details:
  - (1) Material: Aluminum alloy

2. Support Transducer Refinish

A. Consumable Materials

NOTE: Equivalent material can be used.

- (1) C00259 Primer -- BMS 10-11, Type 1 (SOPM 20-60-02)

B. References

- (1) SOPM 20-30-02, Stripping of Protective Finishes
- (2) SOPM 20-41-01, Decoding Table for Boeing Finish Codes
- (3) SOPM 20-41-02, Application of Solvent and Chemical Resistant Finishes
- (4) SOPM 20-43-01, Chromic Acid Anodizing

C. Procedure (Fig. 601)

- (1) Chromic acid anodize (F-17.05).
- (2) Apply BMS 10-11, Type 1 primer (F-20.03) unless shown differently.



**32-11-27**

REPAIR 5-1

01.1

Page 601


Nov 01/02



SPOTFACE  
 0.729 DIA X 0.090  
 0.709 DIA X 0.062 FILLET R

0.277 DIA  
 0.267 DIA

$\text{⊕}$   $\text{⊗}$  0.010 (M) A (M) B  
 (10 LOCATIONS)  
 A-A



0.190 DIA  
 0.170 DIA 1

$\text{⊕}$   $\text{⊗}$  0.010 (M) C (S) B D (S)

SPOTFACE  
 0.635 DIA X 0.090  
 0.615 DIA X 0.062 FILLET R

0.229 DIA  
 0.218 DIA

$\text{⊕}$   $\text{⊗}$  0.005 (M) C (S) B D (S)  
 (3 LOCATIONS)

294W5131-4  
 Adapter Repair  
 Figure 601 (Sheet 1)

**32-11-27**


REPAIR 5-1

01.101

Page 602

Nov 01/02

165T0001  
 165T0002  
 165T0003  
 165T0004



1 DO NOT PRIME THIS SURFACE

125 ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

BREAK ALL SHARP EDGES

ALL DIMENSIONS ARE IN INCHES

294W5131-4  
 ADAI Adapter Repair  
 Figure 601 (Sheet 2)

**32-11-27**

REPAIR 5-1

01.101

Page 603

Nov 01/02

K76909

ASSEMBLY

1. General

- A. This procedure has the data necessary to assemble the main landing gear brake, wheel and tire, in-axle, and hub cap installation components.
- B. Refer to the Standard Overhaul Practices Manual (SOPM) for details of the SOPM subjects identified in this procedure.
- C. Refer to IPL Fig. 1 thru 4 for item numbers.

2. Assembly

A. Consumable Materials

NOTE: Equivalent material can be used.

- (1) A00359 Sealant -- BMS 5-95 (SOPM 20-60-04)
- (2) D00378 Grease -- Aeroshell 22 or Mobil 28 (SOPM 20-60-03)
- (3) G01505 Wire -- MS20995N32 Lockwire (SOPM 20-60-04)
- (4) G01395 Compound -- BMS 3-27 Corrosion Inhibiting (SOPM 20-60-02)

B. References

- (1) SOPM 20-50-01, Bolt and Nut Installation
- (2) SOPM 20-50-02, Installation of Safetying Devices
- (3) SOPM 20-60-04, Miscellaneous Materials

C. Procedure

- (1) Use standard industry procedures and these steps.
- (2) Assemble the brake assembly (Fig. 701).

**32-11-27**

ASSEMBLY  
Page 701  
Nov 01/02

01.1

**WARNING:** BMS 3-27 CORROSION INHIBITING COMPOUND CONTAINS SOLVENTS, CHROMATES, AND A SMALL AMOUNT OF BOUND ASBESTOS. REFER TO THE APPLICABLE SAFETY STANDARDS FOR PRECAUTIONS.

**CAUTION:** BMS 3-27 COMPOUND IS USED ONLY IN STATIC JOINTS WHERE GREASE CANNOT BE APPLIED. BMS 3-27 COMPOUND IN DYNAMIC JOINTS WILL NOT LET THEM MOVE FREELY.

(a) Apply BMS 3-27 corrosion inhibiting compound on bolts (20), and washers (25).

(b) Install bolts, washers (25), sensor (30) to the brake assembly (60).

(c) Install lockwire on bolts (20) by the double-twist procedure.

**WARNING:** BMS 3-27 CORROSION INHIBITING COMPOUND CONTAINS SOLVENTS, CHROMATES, AND A SMALL AMOUNT OF BOUND ASBESTOS. REFER TO THE APPLICABLE SAFETY STANDARDS FOR PRECAUTIONS.

**CAUTION:** BMS 3-27 COMPOUND IS USED ONLY IN STATIC JOINTS WHERE GREASE CANNOT BE APPLIED. BMS 3-27 COMPOUND IN DYNAMIC JOINTS WILL NOT LET THEM MOVE FREELY.

(d) Apply BMS 3-27 corrosion inhibiting compound on bolts (45), and washers (50).

(e) Lubricate the packing (70) with BMS 3-11 hydraulic fluid. Install backup ring (65), packing (70), brake half and quick disconnect (QD) (55) on the brake assembly (60).

(f) Align the hole in the bulkhead half with the pin on the brake assembly and install bolts (45), washers (50).

(g) Install lockwire on bolts (45) by the double-twist procedure.

(3) Assemble in-axle assembly (Fig. 702).

(a) Install dog (80), washer (75), and bolt (70) on transducer (85).

**32-11-27**

ASSEMBLY  
Page 702  
Nov 01/02



01.1

- (b) Install lockwire on bolt (70) and dog (80) by the double-twist procedure.
  - (c) Install antiskid assembly (65), adapter (60), and retainer nut (90). Tighten the nut to 480-720 pound-inches.
  - (d) Install lockwire on retainer nut (90) and to adapter (60) by the double-twist procedure.
  - (e) Install plate (40), and screws (35) to adapter assembly (45).
  - (f) Install connector (32) on plate (40) with screws (25) and nuts (30).
- (4) Assemble the wheel and tire assembly (Fig. 703).
- (a) Install coupling assembly (65), cup (55), washer (50), and screw (45). Tighten the screws (45) to 15-20 pound-inches. Do not lockwire.
  - (b) Install coupling assembly (65), driver (60) on hubcap assembly (30) with washers (25), and bolts (20) (Fig. 704). Tighten bolts (20) to 30-35 pound-inches. Install lockwire by the double-twist procedure.
- (5) Install the wheel and assembly on the landing gear.
- (6) Install hub cap assembly (15) on main landing gear with V-clamp (5) and spacer (10) (IPL Fig. 4).

**32-11-27**

ASSEMBLY  
Page 703  
Nov 01/02

01.1



294W5120-3012  
 Main Landing Gear Brake Assembly  
 Figure 701 (Sheet 1)


**32-11-27**

ASSEMBLY  
 Page 704  
 Nov 01/02

01.1

165T0001  
165T0002  
165T0003  
165T0004

**BOEING**  
COMPONENT  
MAINTENANCE MANUAL



ITEM NUMBERS REFER TO IPL FIG. 1

294W5120-3012  
Main Landing Gear Brake Assembly  
Figure 701 (Sheet 2)




**32-11-27**

ASSEMBLY  
Page 705  
Nov 01/02

01.1

K77291





ITEM NUMBERS REFER TO IPL FIG. 3


294W5130-14  
 Main Landing Gear In-Axle Assembly  
 Figure 702

**32-11-27**

ASSEMBLY  
 Page 706  
 Nov 01/02

01.1

165T0001  
165T0002  
165T0003  
165T0004




294W5110-374,-375,-376  
Main Landing Gear Wheel and Tire Assembly  
Figure 703 (Sheet 1)

**32-11-27**


ASSEMBLY  
Page 707  
Nov 01/02

01.1

K77297



A-A



B-B

ITEM NUMBERS REFER TO IPL FIG. 2

294W5110-374,-375,-376  
Main Landing Gear Wheel and Tire Assembly  
Figure 703 (Sheet 2)


**32-11-27**

ASSEMBLY  
Page 708  
Nov 01/02

01.1

165T0001  
 165T0002  
 165T0003  
 165T0004

**BOEING**  
 COMPONENT  
 MAINTENANCE MANUAL



- 1 INSTALL DRIVER WITH ITS DRIVE LUG NEAREST TO THE SLOT IN THE HUB CAP
- 2 APPLY BMS 5-95 SEALANT TO FAYING SURFACE (SOPM 20-50-19)

ITEM NUMBERS REFER TO IPL FIG. 4

294W5140-12  
 Main Landing Gear Hub Cap Assembly  
 Figure 704

**32-11-27**

ASSEMBLY  
 Page 709  
 Nov 01/02

01.1

ILLUSTRATED PARTS LIST

1. This section lists and illustrates replaceable or repairable component parts. The Illustrated Parts Catalog contains a complete explanation of the Boeing part numbering system.

2. Indentures show parts relationships as follows:

Assembly

Detail Parts for Assembly

Subassembly

Attaching Parts for Subassembly

Detail Parts for Subassembly

Detail Installation Parts (Included only if installation parts may be returned to shop as part of assembly)

3. One use code letter (A, B, C, etc.) is assigned in the EFF CODE column for each variation of top assembly. All listed parts are used on all top assemblies except when limitations are shown by use code letter opposite individual part entries.

4. Letter suffixes (alpha-variants) are added to item numbers for optional parts, Service Bulletin modification parts, configuration differences (Except left- and right-hand parts), product improvement parts, and parts added between two sequential item numbers. The alpha-variant is not shown on illustrations when appearance and location of all variants of the part is the same.

5. Service Bulletin modifications are shown by the notations PRE SB XXXX and POST SB XXXX.

A. When a new top assembly part number is assigned by Service Bulletin, the notations appear at the top assembly level only. The configuration differences at detail part level are then shown by use code letter.

B. When the top assembly part number is not changed by the Service Bulletin, the notations appear at the detail part level.

6. Parts Interchangeability

Optional  
(OPT)

The parts are optional to and interchangeable with other parts having the same item number.

Supersedes, Superseded By  
(SUPSDS, SUPSD BY)

The part supersedes and is not interchangeable with the original part.

Replaces, Replaced By  
(REPLS, REPLD BY)

The part replaces and is interchangeable with, or is an alternate to, the original part.

**32-11-27**

ILLUSTRATED PARTS LIST

01 Page 1001

Mar 01/00

VENDORS

F0217 LABINAL SA  
5 AV NEWTON  
78051 ST QUENTIN EN YVELINES, FRANCE  
FORMERLY PRECISION MECANIQUE LABINAL IN CEDEX, FRANCE

S4233 BRIDGESTONE TIRE CO LTD  
1 KYOBASHI 1-CHROME  
CHUO-KU, TOKYO 104 JAPAN

0A1K8 MICHELIN AIRCRAFT TIRE CORP  
1305 PERIMETER RD  
GREENVILLE, SOUTH CAROLINA 29605  
FORMERLY IN AKRON, OH; IN CHARLOTTE, NC

02107 FLOUROCARBON CO OHIO DIV  
DOVER, OHIO 44622  
CANCELLED NO REPLACEMENT  
FORMERLY SPARTA MANUFACTURING CO

07128 TETRAFLUOR INC  
2051 EAST MAPLE AVENUE  
EL SEGUNDO, CALIFORNIA 90245-5009  
FORMERLY ROYAL IND TETRAFLUOR DIV V0667B ENGLEWOOD CALIF

07649 SENIOR FLEXONICS METAL BELLOWS DIV  
1075 PROVIDENCE HWY  
SHARON, MASSACHUSETTS 02067  
METAL BELLOWS SEE PARKER-HANNIFIN V92003

11362 PARKER-HANIFFIN CORP STRATOFLEX DIV  
3353 OLD CONEJO ROAD  
NEWBURY PARK, CALIFORNIA 91320-2162  
FORMERLY SYMETRICS INC.

14242 VOSS INDUSTRIES INC  
2168 WEST 25TH STREET  
CLEVELAND, OHIO 44113-4115

15653 KAYNAR TECHNOLOGY KAYNAR DIV  
800 SOUTH STATE COLLEGE BLVD PO BOX 3001  
FULLERTON, CALIFORNIA 92831-3001  
FORMERLY MICRODOT AEROSP LTD VK6405

22337 BRIDGESTONE/FIRESTONE INC GOV'T CONTRACTS 1  
BRIDGESTONE PK  
NASHVILLE, TENNESSEE 37214  
FORMERLY FIRESTONE TIRE AND RUBBER CO GOVT CONTRACTS DIV  
FORMERLY IN AKRON, OHIO

32-11-27

ILLUSTRATED PARTS LIST  
01.1 Page 1002  
Nov 01/00

165T0001  
165T0002  
165T0003  
165T0004

 **BOEING**  
COMPONENT  
MAINTENANCE MANUAL

VENDORS

26303 GREENE TWEED IND INC ADVANTEC DIV  
7101 PATTERSON DRIVE PO BOX 5037  
GARDEN GROVE, CALIFORNIA 92645-5037  
FORMERLY OHIO AIRCRAFT SUPPLIES INC IN INGLEWOOD, CALIFORNIA  
FORMERLY ADVANTEC DIV OF IFP INC, LOS ANGELES, CA V5P801

26879 CORONADO MFG INC  
11069 PENROSE AVENUE  
SUN VALLEY, CALIFORNIA 90352-2722  
FORMERLY CORONADO PLASTICS INC IN BURBANK, CALIFORNIA

27238 BRISTOL INDUSTRIES  
630 EAST LAMBERT ROAD PO BOX 630  
BREA, CALIFORNIA 92621-4119

35918 LEWIS ENGINEERING CO  
238 WATER STREET  
NAUGATUCK, CONNECTICUT 06770-2803  
FORMERLY LEWIS ENGINEERING COMPANY V52778  
FORMERLY LEWIS ELECTRONIC INSTRUMENTATION DIV OF COLT IND

62554 SIMMONDS MECAERO FASTENERS INC  
1734 SEQUOIA AVENUE  
ORANGE, CALIFORNIA 92668

8W928 AEROQUIP CORP AEROSPACE DIV TOCCOA PLANT  
MEADOWBROOK INDUSTRIAL PK PO BOX 819  
TOCCOA, GEORGIA 30577-0819

81982 CRANE COMPANY HYDRO-AIRE DIV  
3000 WINONA AVENUE PO BOX 7722  
BURBANK, CALIFORNIA 91510  
FORMERLY HYDRO-AIRE DIV CRANE CO AND ADEL VALVE V00502

91816 CIRCLE SEAL CONTROLS INC A WATTS INDUSTRIES INC CO  
2301 WARDLOW CIRCLE PO BOX 3300  
CORONA, CALIFORNIA 91718  
FORMERLY BRUNSWICK CORP CIRCLE SEAL DIV BRUNSWICK VALVE &  
CONTROL; FORMERLY CIRCLE SEAL DIV BRUNSWICK VALVE & CONTROL  
FORMERLY ZEVCO INC V62701

94878 RAYBESTOS-MANHATTAN INC PACIFIC COAST DIV  
FULLERTON, CALIFORNIA 92631  
BUSINESS DISCONTINUED

97153 GOODRICH BF ENGINEERED PRODUCTS GROUP  
PO BOX 340 WACO STREET  
TROY, OHIO 45373-3835

32-11-27

ILLUSTRATED PARTS LIST  
01.1 Page 1003  
Nov 01/00

VENDORS

97820 BUSAK AND SHAMBAN INC BEARING DIV  
711 MITCHELL ROAD PO BOX 665  
NEWBURY PARK, CALIFORNIA 91320-2214  
FORMERLY IN CULVER CITY, CALIF; FORMERLY SHAMBAN W S & CO

**32-11-27**

ILLUSTRATED PARTS LIST  
01.1 Page 1004  
Nov 01/00



165T0001  
 165T0002  
 165T0003  
 165T0004

 **BOEING**  
 COMPONENT  
 MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NO.	FIG.	ITEM	TTL REQ
APR07621		2	10	8
APR07626		2	10B	8
BACB30MR4HK2		1	20	16
		1	45	32
BACB30NR4K10		3	5	16
BACC10KG936WA		4	5	8
BACN10YR04CD		3	30	32
BACN10YR4CM		3	15A	16
BACN11AG3		2	50	16
BACR12BM211		1	65	16
BACS12ER04K5		3	25	32
BACW10BP3CD		4	25	16
BACW10BP4ACU		1	25	16
		1	50	32
BH00312-04		3	30	32
C11236-211B		1	65	16
H52732-04CD		3	30	32
H52732-4CM		3	15A	16
MS21209C0415P		3	50	32
MS21209F1-10P		3	55	8
M12301IND02		2	10A	8
M83723-61-110A		3	32	8
NAS1149C0332R		2	45	16
NAS1149C0463R		3	10	16
NAS1352N04-4P		3	35	32
NAS1352N08H10		4	45	16
NAS1611-211		1	70A	8
NAS1611-211A		1	70	8
NAS6603-8		2	40	16
NAS6603H2		3	70	8
NAS6703H44		4	20	16
NE103306-0930		4	5A	8
NH1008479-20		4	5	8
PLH54CM		3	15A	16
RMR12BM211		1	65	16
SPEC294W502-663		2	10A	8
STF800-211		1	65	16
S161T102-5		4	65	8
S274A102-13		1	55	8
S274A102-32		1	35	8
S283T001-10		3	85A	8
S283T001-15		3	85	8
S283T015-1		1	30	8
S294W502-6635		2	10	8
S294W511-310		1	60	8

**32-11-27**

ILLUSTRATED PARTS LIST  
 01.1 Page 1005  
 Nov 01/00

PART NUMBER	AIRLINE PART NO.	FIG.	ITEM	TTL REQ
S294W511-370		2	15	8
S30294-211-1		1	65	16
TF450-211A		1	65	16
VC1296-930		4	5B	8
10-44		2	20	8
140-025-1		3	85A	8
140-025-2		3	85	8
161T1207-1		4	35	8
161T1209-1		3	90	8
161T1220-1		4	55	8
161T1221-1		3	80A	8
161T1221-3		3	80	8
161T1222-1		3	75	8
161T1223-1		4	50	8
163U6003-1		4	30	8
163U6003-3		4	40	8
163U6003-6		4	30A	8
163U6003-7		4	40A	8
163U6008-2		4	60	8
165T0001-1		1	1A	RF
165T0002-1		1	5	RF
		2	1	RF
165T0002-2		1	5A	RF
		2	1A	RF
165T0002-3		1	5B	RF
		2	1B	RF
165T0003-1		1	10	RF
		3	1	RF
165T0004-1		1	15	RF
		4	1	RF
165T0101-102		3	65	8
2-1566		1	60	8
2100-211		1	65	16
294W5110-374		2	5	8
294W5110-375		2	5A	8
294W5110-376		2	5B	8
294W5120-3012		1	40	8
294W5130-14		3	20	8
294W5131-2		3	60A	8
294W5131-3		3	45	8
294W5131-4		3	60	8
294W5132-1		3	40	8
294W5140-12		4	15	8
294W5141-1		4	10	8
294W5142-1		4	30B	8
294W5142-2		4	40B	8

# 32-11-27

 ILLUSTRATED PARTS LIST  
 01.1 Page 1006  
 Nov 01/00


165T0001  
165T0002  
165T0003  
165T0004

 **BOEING**  
COMPONENT  
MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NO.	FIG.	ITEM	TTL REQ
3-1540		2	15	8
3100152		1	30	8
4305901160		2	25A	8
4305910630		2	30A	8
49-319		2	25	8
591300-13		1	55	8
591300-32		1	35	8
60B10055-4		2	20	8
68-1313		2	30	8
84490-1		4	65	8
97-151		2	35	8

**32-11-27**

ILLUSTRATED PARTS LIST  
01.1 Page 1007  
Nov 01/00



Main Landing Gear Brake Assembly  
 Figure 1

**32-11-27**

ILLUSTRATED PARTS LIST  
 01.1 Page 1008  
 Nov 01/00

165T0001  
 165T0002  
 165T0003  
 165T0004

 **BOEING**  
 COMPONENT  
 MAINTENANCE MANUAL

FIG. & ITEM	PART NO.	AIRLINE PART NUMBER	NOMENCLATURE 1234567	EFF CODE	QTY PER ASSY
01-			MAIN LANDING GEAR BRAKE, WHEEL AND TIRE, IN-AXLE, HUB CAP INSTL		
-1A	165T0001-1		BRAKE INSTL	A	RF
-5	165T0002-1		WHEEL AND TIRE INSTL-BFG R32, BS R32 NON-TPIS, SM BORE GAUGE, BFG HGW WHEEL (FOR DETAILS SEE FIG. 2)	B	RF
-5A	165T0002-2		WHEEL AND TIRE INSTL-BFG R32, MI R32 BFE TIRE, NON-TPIS, SM BORE FILL VALVE/GAUGE (FOR DETAILS SEE FIG. 2)	E	RF
-5B	165T0002-3		WHEEL AND TIRE INSTL-BFG R32, MI R32 BFE TIRE, W/TPIS SENSOR HOLDER, SM BORE FILL VALVE/GAUGE (FOR DETAILS SEE FIG. 2)	F	RF
-10	165T0003-1		IN AXLE INSTL- (NON TPIS) (FOR DETAILS SEE FIG. 3)	C	RF
-15	165T0004-1		HUB CAP INSTL- (FOR DETAILS SEE FIG. 4)	D	RF
20	BACB30MR4HK2		.BOLT	A	16
25	BACW10BP4ACU		.WASHER	A	16
30	3100152		.SENSOR-BTMS (V35918) (SPEC S283T015-1)	A	8
35	591300-32		.QD-HOSE HALF (V11362) (SPEC S274A102-32)	A	8
40	294W5120-3012		.BRAKE ASSY-BFG	A	8
45	BACB30MR4HK2		..BOLT	A	4
50	BACW10BP4ACU		..WASHER	A	4
55	591300-13		..QD-BRAKE HALF (V11362) (SPEC S274A102-13)	A	1
60	2-1566		..BRAKE ASSY-BFG (V97153) (SPEC S294W511-310)	A	1

**32-11-27**


ILLUSTRATED PARTS LIST  
 01.1 Page 1009  
 Nov 01/00

FIG. & ITEM	PART NO.	AIRLINE PART NUMBER	NOMENCLATURE 1234567	EFF CODE	QTY PER ASSY
01-65	C11236-211B		..RING-BACKUP (V26879) (SPEC BACR12BM211) (OPT RMR12BM211 (V94878)) (OPT STF800-211 (V02107)) (OPT S30294-211-1 (V97820)) (OPT TF450-211A (V07128)) (OPT 2100-211 (V26303))	A	2
70	NAS1611-211A		..PACKING- (OPT ITEM 70A)	A	1
-70A	NAS1611-211		..PACKING- (OPT ITEM 70)	A	1

- Item Not Illustrated

# 32-11-27

 ILLUSTRATED PARTS LIST  
 01.1 Page 1010  
 Nov 01/00



Main Landing Gear Wheel and Tire Assembly  
 Figure 2

**32-11-27**

ILLUSTRATED PARTS LIST  
 01.1 Page 1012  
 Nov 01/00

165T0001  
 165T0002  
 165T0003  
 165T0004

 **BOEING**  
 COMPONENT  
 MAINTENANCE MANUAL

FIG. & ITEM	PART NO.	AIRLINE PART NUMBER	NOMENCLATURE 1234567	EFF CODE	QTY PER ASSY
02- -1	165T0002-1		WHEEL AND TIRE INSTL-BFG R32, BS R32 NON-TPIS, SM BORE GAUGE, BFG HGW WHEEL	B	RF
-1A	165T0002-2		WHEEL AND TIRE INSTL-BFG R32, MI R32 BFE TIRE, NON-TPIS, SM BORE FILL VALVE/GAUGE	E	RF
-1B	165T0002-3		WHEEL AND TIRE INSTL-BFG R32, MI R32 BFE TIRE, W/TPIS SENSOR HOLDER, SM BORE FILL VALVE/GAUGE	F	RF
5	294W5110-374		.WHEEL AND TIRE ASSY	B	8
-5A	294W5110-375		.WHEEL AND TIRE ASSY	E	8
-5B	294W5110-376		.WHEEL AND TIRE ASSY	F	8
10	APR07621		..TIRE-RADIAL 32PR 50X20 R22 BRIDGESTONE (VS4233)	B	1
-10A	M12301IND02		..TIRE-RADIAL 32PR 50X20 R22 MICHELIN (VOA1K8) (SPEC S294W502-6635)	E,F	1
-10B	APR07626		..TIRE-RADIAL 32PR 50X20 R22 BRIDGESTONE (V22337) (SPEC S294W502-6635) (OPT APR07621 (VS4233))	B	1
15	3-1540		..WHEEL ASSY-RADICAL 32 BFG (V97153) (SPEC S294W511-370)	B,E,F	1
20	10-44		..VALVE ASSY-FILL/GAUGE SMALL BORE GSE INTERFACE (V91816) (SPEC 60B10055-4)	B,E,F	1

**32-11-27**

ILLUSTRATED PARTS LIST  
 01.1 Page 1013  
 Nov 01/00




FIG. & ITEM	PART NO.	AIRLINE PART NUMBER	NOMENCLATURE 1234567	EFF CODE	QTY PER ASSY
02-25	49-319		..PLUG-TPIS PORT (V97153)	B,E	1
-25A	4305901160		..HOLDER-PRESSURE (VF0217)	F	1
30	68-1313		..PACKING-TPIS PORT (V97153)	B,E	1
30A	4305910630		..CAP-PRESSURE SEAL (VF0217)	F	1
35	97-151		..WEIGHT-BAL FILL PORT (V97153)	B,E,F	1
40	NAS6603-8		..BOLT	F	2
45	NAS1149C0332R		..WASHER	F	2
50	BACN11AG3		..NUT	F	2

- Item Not Illustrated

**32-11-27**

ILLUSTRATED PARTS LIST  
 01.1 Page 1014  
 Nov 01/00



Main Landing Gear In-Axle Assembly  
 Figure 3

**32-11-27**

ILLUSTRATED PARTS LIST  
 01.1 Page 1016  
 Nov 01/00

165T0001  
 165T0002  
 165T0003  
 165T0004

 **BOEING**  
 COMPONENT  
 MAINTENANCE MANUAL

FIG. & ITEM	PART NO.	AIRLINE PART NUMBER	NOMENCLATURE 1234567	EFF CODE	QTY PER ASSY
03-					
-1	165T0003-1		IN AXLE INSTL-NON TPIS	C	RF
5	BACB30NR4K10		.BOLT	C	16
10	NAS1149C0463R		.WASHER	C	16
15	BACN10YR4CH		DELETED		
15A	H52732-4CM		.NUT- (V15653) (SPEC BACN10YR4CM) (OPT PLH54CM (V62554))	C	16
20	294W5130-14		.IN AXLE ASSY	C	8
25	BACS12ER04K5		..SCREW	C	4
30	H52732-04CD		..NUT- (V15653) (SPEC BACN10YR04CD) (OPT BH00312-04 (V27238))	C	4
32	M83723-61-110A		..CONNECTOR-DUMMY	C	1
35	NAS1352N04-4P		..SCREW	C	4
40	294W5132-1		..PLATE	C	1
45	294W5131-3		..ADAPTER ASSY	C	1
50	MS21209C0415P		...INSERT	C	4
55	MS21209F1-10P		...INSERT	C	1
60	294W5131-4		...ADAPTER- (OPT ITEM 60A)	C	1
-60A	294W5131-2		...ADAPTER- (OPT ITEM 60)	C	1
65	165T0101-102		..ANTISKID ASSY	C	1
70	NAS6603H2		...BOLT	C	1
R 75	161T1222-1		...WASHER	C	1
R 80	161T1221-3		...DOG- (OPT ITEM 80A)	C	1

**32-11-27**


ILLUSTRATED PARTS LIST  
 01.1 Page 1017  
 Nov 01/00

FIG. & ITEM	PART NO.	AIRLINE PART NUMBER	NOMENCLATURE 1234567	EFF CODE	QTY PER ASSY
R 03-80A	161T1221-1		...DOG- (OPT ITEM 80)	C	1
85	140-025-2		...TRANSDUCER-ANTI-SKID (V81982) (SPEC S283T001-15) (OPT ITEM 085A)	C	1
-85A	140-025-1		...TRANSDUCER-ANTI SKID (V81982) (SPEC S283T001-10) (OPT ITEM 085)	C	1
R 90	161T1209-1		..RETAINER	C	1

- Item Not Illustrated

# 32-11-27

 ILLUSTRATED PARTS LIST  
 01.1 Page 1018  
 Nov 01/00



Main Landing Gear Hub Cap Assembly  
 Figure 4

**32-11-27**

ILLUSTRATED PARTS LIST  
 01.1 Page 1020  
 Nov 01/00

165T0001  
 165T0002  
 165T0003  
 165T0004

**BOEING**  
 COMPONENT  
 MAINTENANCE MANUAL

FIG. & ITEM	PART NO.	AIRLINE PART NUMBER	NOMENCLATURE 1234567	EFF CODE	QTY PER ASSY
04-1	165T0004-1		HUB CAP INSTL	D	RF
5	NH1008479-20		.CLAMP-V (V8W928) (SPEC BACC10KG936WA) (OPT ITEMS 5A, 5B)	D	8
-5A	NE103306-0930		.CLAMP-V (OPT ITEMS 5, 5B)	D	8
-5B	VC1296-930		.CLAMP-V (V14242) (OPT ITEMS 5, 5A)	D	8
10	294W5141-1		.SPACER-LONG	D	8
15	294W5140-12		.HUB CAP ASSY	D	8
20	NAS6703H44		..BOLT	D	2
25	BACW10BP3CD		..WASHER	D	2
30	163U6003-1		..HUB ASSY- (OPT ITEMS 30A, 30B)	D	1
-30A	163U6003-6		..HUB ASSY- (OPT ITEMS 30, 30B)	D	1
-30B	294W5142-1		..HUB ASSY- (OPT ITEMS 30, 30A)	D	8
35	161T1207-1		...PIN-LOCATOR	D	1
40	163U6003-3		...HUB- (USED ON ITEM 30)	D	1
-40A	163U6003-7		...HUB- (USED ON ITEM 30A)	D	1
-40B	294W5142-2		...HUB- (USED ON ITEM 30B)	D	1
45	NAS1352N08H10		..SCREW	D	2
R 50	161T1223-1		..WASHER	D	1
R 55	161T1220-1		..CUP	D	1
60	163U6008-2		..DRIVER	D	1
65	84490-1		..COUPLING ASSY- (V07649) (SPEC S161T102-5)	D	1

- Item Not Illustrated

**32-11-27**

ILLUSTRATED PARTS LIST  
 01.1 Page 1021  
 Nov 01/00