



MAIN GEAR DOOR OPERATED SEQUENCE VALVE BUNGEE ASSEMBLY

PART NUMBER 273T4531-1

COMPONENT MAINTENANCE MANUAL
WITH
ILLUSTRATED PARTS LIST

32-32-50

TITLE PAGE

Page 1

Oct 01/87

01



REVISION RECORD

- Retain this record in front of manual. On receipt of revision, insert revised pages in the manual, and enter revision number, date inserted and initial.

REVISION NUMBER	REVISION DATE	DATE FILED	BY	REVISION NUMBER	REVISION DATE	DATE FILED	BY



TEMPORARY REVISION AND SERVICE BULLETIN RECORD

BOEING SERVICE BULLETIN	BOEING TEMPORARY REVISION	OTHER DIRECTIVE	DATE OF INCORPORATION INTO MANUAL
		PRR B10031	APR 10/83

32-32-50

TR & SB RECORD

01

Page 1

Oct 01/87


BOEING
 COMPONENT
 MAINTENANCE MANUAL

PAGE	DATE	CODE	PAGE	DATE	CODE
32-32-50			REPAIR-GENERAL		
			601	OCT 01/87	01
			602	BLANK	
TITLE PAGE			REPAIR 1-1		
1	OCT 01/87	01	601	OCT 01/87	01
2	BLANK		602	OCT 01/87	01
REVISION RECORD			REPAIR 2-1		
1	OCT 01/87	01	601	OCT 01/87	01
2	BLANK		602	OCT 01/87	01
TR & SB RECORD			REPAIR 3-1		
1	OCT 01/87	01	601	OCT 01/87	01
2	BLANK		602	BLANK	
LIST OF EFFECTIVE PAGES			ASSEMBLY		
1	OCT 01/87	01	701	OCT 01/87	01
THRU LAST PAGE			702	OCT 01/87	01
CONTENTS			ILLUSTRATED PARTS LIST		
1	OCT 01/87	01	1001	OCT 01/87	01
2	BLANK		1002	OCT 01/87	01
INTRODUCTION			1003	OCT 01/87	01
1	OCT 01/87	01	1004	BLANK	
2	BLANK				
DESCRIPTION & OPERATION					
1	OCT 01/87	01			
2	BLANK				
DISASSEMBLY					
301	OCT 01/87	01			
302	BLANK				
CLEANING					
401	OCT 01/87	01			
402	BLANK				
CHECK					
501	OCT 01/87	01			
502	BLANK				

* = REVISED, ADDED OR DELETED

32-32-50
 EFFECTIVE PAGES
 LAST PAGE Page 1
 01 Oct 01/87



TABLE OF CONTENTS

<u>Paragraph Title</u>	<u>Page</u>
Description and Operation.	1
Testing/Trouble Shooting (not applicable)	
Disassembly.	301
Cleaning	401
Check.	501
Repair	601
Assembly	701
Fits and Clearances (not applicable)	
Special Tools (not applicable)	
Illustrated Parts List	1001

32-32-50

CONTENTS

01

Page 1

Oct 01/87



INTRODUCTION

The instructions in this manual provide the information necessary to perform maintenance functions ranging from simple checks and replacement to complete shop-type repair.

This manual is divided into separate sections:

- | | |
|--|------------------------------|
| 1. Title Page | 4. List of Effective Pages |
| 2. Record of Revisions | 5. Table of Contents |
| 3. Temporary Revision &
Service Bulletin Record | 6. Introduction |
| | 7. Procedures & IPL Sections |

Refer to the Table of Contents for the page location of applicable sections. An asterisked flagnote *[] in place of the page number indicates that no special instructions are provided since the function can be performed using standard industry practices.

The beginning of the REPAIR section includes a list of the separate repairs, a list of applicable standard Boeing practices, and an explanation of the True Position Dimensioning symbols used.

An explanation of the use of the Illustrated Parts List is provided in the Introduction to that section.

All weights and measurements used in the manual are in English units, unless otherwise stated. When metric equivalents are given they will be in parentheses following the English units.

Design changes, optional parts, configuration differences and Service Bulletin modifications create alternate part numbers. These are identified in the Illustrated Parts List (IPL) by adding an alphabetical character to the basic item number. The resulting item number is called an alpha-variant. Throughout the manual, IPL basic item number references also apply to alpha-variants unless otherwise indicated.

Verification:

Disassembly -- OCT 21/86
Assembly -- OCT 21/86

32-32-50

INTRODUCTION

01

Page 1

Oct 01/87



MAIN GEAR DOOR OPERATED SEQUENCE VALVE BUNGEE ASSEMBLY

DESCRIPTION AND OPERATION

1. The main gear door operated sequence valve bungee assembly consists of cylinder, rod, piston, spring, collar, bushing, and rod ends.
2. The bungee assembly is a backup system to the lever connecting the main landing gear door to the sequencing valve. If the lever fails, the bungee pulls the valve into the gear down position so that the gear can still be extended.

3. Leading Particulars (Approximate)

Length (compressed) -- 11 inches

Length (extended) -- 16 inches

Diameter (largest) -- 1 inch

Weight -- 1 pound

32-32-50

DESCRIPTION & OPERATION

01

Page 1

Oct 01/87



DISASSEMBLY

1. Remove rivets (5, 8), rod end bearings (10, 15) and collar (20) from cylinder.
2. Slide out (50,) with piston (30) attached, washers (35) and spring (45).
3. Do not remove piston (30) from rod (50), or bushing (40) from cylinder (25), unless necessary for repair or replacement.

32-32-50

DISASSEMBLY

01

Page 301

Oct 01/87



CLEANING

1. Clean all parts except bearings (10, 15, IPL Fig. 1) using standard industry practices and the information contained in 20-30-03.

CAUTION: BEARINGS (10, 15) ARE TEFLON LINED. CLEAN ONLY BY SPECIAL METHOD GIVEN IN 20-30-01.

2. Clean rod end bearings (10, 15) only by special method for teflon lined bearings in 20-30-01.

32-32-50

01
CLEANING
Page 401
Oct 01/87



CHECK

1. Check all parts for obvious defects in accordance with standard industry practices.
2. Magnetic particle check cylinder (25), spring (45) and rod (50) per 20-20-01.
3. Spring Check
 - A. Compress spring (45) to 3.0 inches and check that load is 26-30 lbs.

32-32-50

01
CHECK
Page 501
Oct 01/87

REPAIR – GENERAL1. Content

- A. Repair, refinish and replacement procedures are included in separate repair sections as follows:

<u>P/N</u>	<u>NAME</u>	<u>REPAIR</u>
273T4536	ROD	1-1
273T4534	CYLINDER	2-1
- -	MISCELLANEOUS PARTS REFINISH	3-1

2. Standard Practices

- A. Refer to the following standard practices as applicable, for details of procedures in individual repairs.

20-30-02 Stripping of Protective Finishes
 20-41-01 Decoding Table for Boeing Finish Codes

3. Materials

NOTE: Equivalent substitutes may be used.

- A. Sealant -- BMS 5-95 (Ref 20-60-04)
 B. Primer -- BMS 10-11, Type 1 (Ref 20-60-02)
 C. Enamel -- BMS 10-60, Color 707 Gray Gloss Enamel (Ref 20-60-02)

32-32-50

REPAIR-GENERAL

01

Page 601

Oct 01/87

ROD - REPAIR 1-1

273T4536-1

1. Piston Replacement (Fig. 601)

NOTE: Refer to REPAIR-GENERAL for list of applicable standard practices.

- A. Machine OD of piston (30) until sufficient amount of wire (33) is exposed to enable gripping with pliers. Pull wire out and remove remaining portion of piston from rod (50). If wire cannot be pulled out or breaks, carefully cut piston to split it into pieces to free it from rod.
- B. Cut a piece of wire (33) approximately 1.60 inches long. Smooth and round one end to remove burrs and sharp edges.
- C. Insert replacement piston (30) on rod at grooved end and position with outer face flush with end of rod.
- D. Clamp piston (30) in vise so hole in OD is accessible.
- E. Insert prepared end of wire (33) in hole in piston OD. With a small hammer, tap exposed end of wire to drive it into piston (3). Wire will curl around inside circumferential groove between piston and rod, locking the two together.
- F. Continue driving wire into piston until entire length is installed. Use a pin punch to drive outer end of wire flush with piston OD.
- G. Stake around hole to retain wire in piston. Remove upset material projecting from piston OD and smooth surface to 16 microinch surface.


32-32-50

REPAIR 1-1

01

Page 601

Oct 01/87



Piston Replacement on Rod
Figure 601

4-107

32-32-50

REPAIR 1-1

Page 602

Oct 01/87

01

CYLINDER – REPAIR 2-1

273T4534-1

1. Bushing Replacement (Fig. 601)

NOTE: Refer to REPAIR-GENERAL for list of applicable standard practices.

- A. Machine out ID of bushing (40) until wire (43) is exposed. Pry loose wire (43) and remaining portion of bushing from cylinder (25).
- B. Cut a piece of wire (43), approximately 2.15 inches long. Smooth and round one end to remove burrs and sharp edges.
- C. Insert replacement bushing (40) in cylinder bore at ground end and position with outer face flush with end face of cylinder.
- D. Clamp cylinder in vise so hole in OD is accessible.
- E. Insert prepared end of wire (43) in hole in cylinder OD. With a small hammer, tap exposed end of wire to drive it into cylinder (25). Wire will curl around inside circumferential groove between bushing and cylinder, locking the two together.
- F. Continue driving wire into cylinder until entire length is installed. Use a pin punch to drive outer end of wire flush with cylinder OD.
- G. Dimple around hole to retain wire in cylinder.


32-32-50

REPAIR 2-1

01

Page 601

Oct 01/87



Bushing Replacement in Cylinder
Figure 601

4-108

32-32-50

REPAIR 2-1

Page 602

Oct 01/87

01

MISCELLANEOUS PARTS REFINISH – REPAIR 3-1

1. Repair of the parts listed in Fig. 601 consists of restoration of the original finish. Refer to REPAIR-GEN for list of applicable standard practices.

IPL FIG. & ITEM	MATERIAL	FINISH
<u>Fig. 1</u>		
Rod (50), Collar (20), Cylinder (25)	17-4PH CRES, 180-200 ksi	Passivate (F-17.09) all over.
Spring (45)	17-7PH CRES per AMS5673 Optional - AMS5678 HT TR to CH900	Passivate (F-17.09) all over.
Bungee assy (1)		Apply one coat BMS 10-11, type 1 primer (F-20.02) and BMS 10-60 gray gloss enamel (SRF-14.9813) all over except on bearings, in longitudinal slots in cylinder wall and inside cylinder.
Washer (35)	AISI 301 CRES	Passivate (F-17.09) all over.

Refinish Details
Figure 601

32-32-50

REPAIR 3-1

01

Page 601

Oct 01/87

ASSEMBLY1. Materials

NOTE: Equivalent substitutes may be used.

A. Sealant -- BMS 5-95 (BMS 5-79 Optional) (Ref 20-60-04)

2. Assembly (IPL Fig. 1) (Fig. 701)

CAUTION: KEYWAY OF ROD END BEARING (10) IS TO SERVE AS DRAINAGE CHANNEL AND SHALL NOT BE OBSTRUCTED BY RIVET OR SEALANT.

A. If rod end bearing (10, 15), collar (20) or cylinder (25) are replaced, drill new holes for rivets (5, 8) as necessary. Maintain center-to-center distance shown. Locate holes in rod end bearing (10) at 90-degree spacing, not to pass thru keyway.

B. Slide one washer (35), spring (45) and remaining washer (35) over rod (50). Insert rod, threaded bore end first, thru cylinder (25) from end without bushing (40).

CAUTION: KEYWAY OF ROD END BEARING (10) IS TO SERVE AS DRAINAGE CHANNEL AND SHALL NOT BE OBSTRUCTED BY RIVET OR SEALANT.




C. To keep sealant from blocking keyway, temporarily position a length of wire, such as lockwire, in keyway of rod end bearing (10). Then install rod end bearing in collar (20) with wet sealant, threading parts together until holes for rivets (5) align.

D. Insert collar (20) into cylinder (25). Install rivets (5) with wet sealant.

E. Install rod end bearing (15) in rod, with wet sealant. Install rivet (8) with wet sealant.

F. Remove wire, temporarily installed in step C. above, after sealant is cured sufficiently to allow keyway to remain open as drainage channel.

32-32-5001 ASSEMBLY
Page 701
Oct 01/87



- 1 INSTALL WITH WET SEALANT
- 2 KEYWAY TO SERVE AS DRAINAGE CHANNEL. DO NOT OBSTRUCT WITH RIVET OR SEALANT

ALL DIMENSIONS ARE IN INCHES

Assembly Details
 Figure 701

32-32-50

ASSEMBLY
 Page 702
 Oct 01/87

01

ILLUSTRATED PARTS LIST

1. This section lists and illustrates replaceable or repairable component parts. The Illustrated Parts Catalog contains a complete explanation of the Boeing part numbering system.
2. Indentures show parts relationships as follows:

Assembly

Detail Parts for Assembly

Subassembly

Attaching Parts for Subassembly

Detail Parts for Subassembly

Detail Installation Parts (Included only if installation parts may be returned to shop as part of assembly)

3. One use code letter (A, B, C, etc.) is assigned in the EFF CODE column for each variation of top assembly. All listed parts are used on all top assemblies except when limitations are shown by use code letter opposite individual part entries.
4. Letter suffixes (alpha-variants) are added to item numbers for optional parts, Service Bulletin modification parts, configuration differences (except left- and right-hand parts), product improvement parts, and parts added between two sequential item numbers. The alpha-variant is not shown on illustrations when appearance and location of all variants of the part is the same.
5. Service Bulletin modifications are shown by the notations PRE SB XXXX and POST SB XXXX.
 - A. When a new top assembly part number is assigned by Service Bulletin, the notations appear at the top assembly level only. The configuration differences at detail part level are then shown by use code letter.
 - B. When the top assembly part number is not changed by the Service Bulletin, the notations appear at the detail part level.

6. Parts Interchangeability

Optional
(OPT)

The parts are optional to and interchangeable with other parts having the same item number.

Supersedes, Superseded By
(SUPSDS, SUPSD BY)

The part supersedes and is not interchangeable with the original part.

Replaces, Replaced By
(REPLS, REPLD BY)

The part replaces and is interchangeable with, or is an alternate to, the original part.


32-32-50

ILLUSTRATED PARTS LIST

01

Page 1001

Oct 01/87



Main Gear Door Operated Sequence Valve Bungee Assembly
 Figure 1

32-32-50

ILLUSTRATED PARTS LIST
 01 Page 1002
 Oct 01/87


BOEING
 COMPONENT
 MAINTENANCE MANUAL

FIG. & ITEM	PART NO.	AIRLINE PART NUMBER	NOMENCLATURE 1234567	EFF CODE	QTY PER ASSY
01- -1	273T4531-1		BUNGEE ASSY-MG DOOR OPERATED SEQ VALVE		RF
5	MS20615-4M18		.RIVET		2
8	MS20615-4M11		.RIVET		2
10	M81935-1-3		.BEARING, ROD END		1
15	M81935-1-4K		.BEARING, ROD END		1
20	273T4532-1		.COLLAR		1
25	273T4534-1		.CYLINDER		1
30	273T4533-1		.PISTON		1
33	273T4531-2		.WIRE		1
35	273T4547-1		.WASHER		2
40	273T4535-1		.BUSHING		1
43	273T4531-3		.WIRE		1
45	273T4537-1		.SPRING		1
50	273T4536-1		.ROD		1

32-32-50

ILLUSTRATED PARTS LIST

01

Page 1003

Oct 01/87