

 **BOEING**
COMPONENT
MAINTENANCE MANUAL

TO: ALL HOLDERS OF ALTERNATE EXTEND TORQUE SHAFT ASSEMBLY COMPONENT
MAINTENANCE MANUAL 32-35-70

REVISION NO. 2 DATED NOV 01/02

HIGHLIGHTS

Pages which have been added or revised are outlined below together with the highlights of the revision. Remove and insert the affected pages as listed and enter Revision No. and date on the Record of Revision Sheet.

CHAPTER/SECTION

AND PAGE NO.

DESCRIPTION OF CHANGE

TITLE PAGE

Added shaft assemblies 257T3501-3, -4, -5 with changed quadrant details.

1

REPAIR 2-1

601-602

REPAIR 4-1

601,603

1002-1004,1009-1012

TITLE PAGE

Added clarifications and updated callouts.

1

401

501

REPAIR-GEN

601-602

REPAIR 1-1

601

REPAIR 2-1

601-602

REPAIR 3-1

601-602

REPAIR 4-1

601-604

REPAIR 5-1

601-604

REPAIR 6-1

601-602

32-35-70

HIGHLIGHTS

01.1

Page 1

Nov 01/02

 **BOEING**
COMPONENT
MAINTENANCE MANUAL

CHAPTER/SECTION
AND PAGE NO.

REPAIR 7-1

601

701

1001

DESCRIPTION OF CHANGE

HIGHLIGHT CONTINUED FROM PREVIOUS PAGE

32-35-70

HIGHLIGHTS

01.1

Page 2

Nov 01/02

ALTERNATE EXTEND TORQUE SHAFT ASSEMBLY

PART NUMBERS 257T3501-1 THRU -5

COMPONENT MAINTENANCE MANUAL
WITH
ILLUSTRATED PARTS LIST

32-35-70

TITLE PAGE

Page 1

Nov 01/02

01.1



REVISION RECORD

- Retain this record in front of manual. On receipt of revision, insert revised pages in the manual, and enter revision number, date inserted and initial.

REVISION NUMBER	REVISION DATE	DATE FILED	BY	REVISION NUMBER	REVISION DATE	DATE FILED	BY



TEMPORARY REVISION AND SERVICE BULLETIN RECORD

BOEING SERVICE BULLETIN	BOEING TEMPORARY REVISION	OTHER DIRECTIVE	DATE OF INCORPORATION INTO MANUAL

32-35-70

TR & SB RECORD

01

Page 1

Jan 01/91


BOEING
 COMPONENT
 MAINTENANCE MANUAL

PAGE	DATE	CODE	PAGE	DATE	CODE
32-35-70			REPAIR-GENERAL		
			*601	NOV 01/02	01.1
			*602	NOV 01/02	01.1
TITLE PAGE			REPAIR 1-1		
*1	NOV 01/02	01.1	*601	NOV 01/02	01.1
2	BLANK		602	JAN 01/91	01
REVISION RECORD			603	JAN 01/91	01
1	JAN 01/91	01	604	JAN 01/91	01
2	BLANK		605	JAN 01/91	01
TR & SB RECORD			606	JAN 01/91	01
1	JAN 01/91	01	REPAIR 2-1		
2	BLANK		*601	NOV 01/02	01.1
LIST OF EFFECTIVE PAGES			*602	NOV 01/02	01.1
*1	NOV 01/02	01	REPAIR 3-1		
THRU LAST PAGE			*601	NOV 01/02	01.1
CONTENTS			*602	NOV 01/02	01.1
1	JAN 01/91	01	REPAIR 4-1		
2	BLANK		*601	NOV 01/02	01.1
INTRODUCTION			*602	NOV 01/02	01.1
1	JAN 01/91	01	*603	NOV 01/02	01.1
2	BLANK		*604	NOV 01/02	01.1
DESCRIPTION & OPERATION			REPAIR 5-1		
1	JUL 01/91	01.1	*601	NOV 01/02	01.1
2	BLANK		*602	NOV 01/02	01.1
DISASSEMBLY			*603	NOV 01/02	01.1
301	JAN 01/91	01	*604	NOV 01/02	01.1
302	BLANK		REPAIR 6-1		
CLEANING			*601	NOV 01/02	01.1
*401	NOV 01/02	01.1	*602	NOV 01/02	01.1
402	BLANK		REPAIR 7-1		
CHECK			*601	NOV 01/02	01.1
*501	NOV 01/02	01.1	602	BLANK	
502	BLANK				

* = REVISED, ADDED OR DELETED

32-35-70
 EFFECTIVE PAGES
 CONTINUED Page 1
 01 Nov 01/02

PAGE	DATE	CODE	PAGE	DATE	CODE
ASSEMBLY					
*701	NOV 01/02	01.1			
702	JAN 01/91	01			
FITS AND CLEARANCES					
801	JAN 01/91	01			
802	BLANK				
ILLUSTRATED PARTS LIST					
*1001	NOV 01/02	01.1			
*1002	NOV 01/02	01.1			
*1003	NOV 01/02	01.1			
*1004	NOV 01/02	01.1			
*1005	NOV 01/02	01.1			
*1006	NOV 01/02	01.1			
*1007	NOV 01/02	01.1			
*1008	NOV 01/02	01.1			
*1009	NOV 01/02	01.1			
*1010	NOV 01/02	01.1			
*1011	NOV 01/02	01.1			
*1012	NOV 01/02	01.1			

* = REVISED, ADDED OR DELETED

32-35-70

EFFECTIVE PAGES
 LAST PAGE Page 2
 01 Nov 01/02



TABLE OF CONTENTS

<u>Paragraph Title</u>	<u>Page</u>
Description and Operation	1
Disassembly	301
Cleaning.	401
Check	501
Repair.	601
Assembly.	701
Fits and Clearances	801
Illustrated Parts List.	1001

32-35-70

CONTENTS

01

Page 1

Jan 01/91



INTRODUCTION

The instructions in this manual provide the information necessary to perform maintenance functions ranging from simple checks and replacement to complete shop-type repair.

This manual is divided into separate sections:

- | | |
|--|------------------------------|
| 1. Title Page | 4. List of Effective Pages |
| 2. Record of Revisions | 5. Table of Contents |
| 3. Temporary Revision &
Service Bulletin Record | 6. Introduction |
| | 7. Procedures & IPL Sections |

Refer to the Table of Contents for the page location of applicable sections. An asterisked flagnote *[] in place of the page number indicates that no special instructions are provided since the function can be performed using standard industry practices.

The beginning of the REPAIR section includes a list of the separate repairs, a list of applicable standard Boeing practices, and an explanation of the True Position Dimensioning symbols used.

An explanation of the use of the Illustrated Parts List is provided in the Introduction to that section.

All weights and measurements used in the manual are in English units, unless otherwise stated. When metric equivalents are given they will be in parentheses following the English units.

Design changes, optional parts, configuration differences and Service Bulletin modifications create alternate part numbers. These are identified in the Illustrated Parts List (IPL) by adding an alphabetical character to the basic item number. The resulting item number is called an alpha-variant. Throughout the manual, IPL basic item number references also apply to alpha-variants unless otherwise indicated.

Verification:

Disassembly
Assembly

32-35-70

INTRODUCTION

01

Page 1

Jan 01/91



ALTERNATE EXTEND TORQUE SHAFT ASSEMBLY

DESCRIPTION AND OPERATION

1. The primary components of the alternate extend torque shaft assembly are two quadrant assemblies, a crank assembly and a common torque shaft.
2. During hydraulic system failure, an electric actuator can turn the torque shaft. This turns the quadrants and the crank assembly. Turning the quadrants moves two control cables that release the right and left main gear doors. This permits the main gear to free fall to the down and locked position. Turning the crank assembly releases the front gear doors, permitting the front gear to free fall to the down and locked position.
3. Leading Particulars (approximate)

Length -- 17 inches
Height -- 12 inches
Width -- 13 inches

32-35-70

DESCRIPTION & OPERATION

01.1

Page 1

Jul 01/91



DISASSEMBLY

1. Disassembly (IPL Fig. 1)

A. Remove support assembly (60).

- (1) Remove the nut (55) from the stub shaft (90).
- (2) Slide the support assembly (60) from the stub shaft.

NOTE: Refer to the Repair sections for more disassemble procedures.

B. Disassemble the Support assembly (60).

- (1) Remove the bolts (5), washers (10) and nuts (15) to remove the actuator (20), switch (25), and the switch plate (30).

32-35-70

DISASSEMBLY

01

Page 301

Jan 01/91



CLEANING

1. Clean all parts by standard industry practices and the instructions in SOPM 20-30-03.

32-35-70

CLEANING
Page 401
Nov 01/02

01.1



CHECK

- |1. Examine all parts for defects by standard industry practices.
- |2. Magnetic particle examine (SOPM 20-20-01) -- stub shaft (90).
- |3. Penetrant examine (SOPM 20-20-02) -- crank (195, 195A), flanged hub (125,185), quadrant (130,160,165), stop crank (85,85A) and support (75).

32-35-70

CHECK

01.1

Page 501

Nov 01/02

REPAIR – GENERAL1. Content

- A. Repair, refinish and replacement procedures are included in separate repair sections as follows:

<u>P/N</u>	<u>NAME</u>	<u>REPAIR</u>
257T3519	TORQUE SHAFT	1-1
257T3511	ACTUATOR SUPPORT ASSY	2-1
257T3512	STOP CRANK	3-1
257T3513	QUADRANT ASSY	4-1
257T3514	CRANK ASSY	5-1
257T3520	STUB SHAFT	6-1
- - -	MISCELLANEOUS PARTS	7-1
- - -	REFINISH	

2. Standard Practices

- A. Refer to the subsequent approved practices, as applicable, for details of the procedures in each repair.

20-00-00 Introduction
 20-20-02 Penetrant Methods and Inspections
 20-30-02 Stripping of Protective Finishes
 20-41-01 Decoding Table for Boeing Finish Codes
 20-41-02 Application of Chemical and Solvent Resistant Finishes
 20-50-03 Bearing Installation and Retention

3. Materials

NOTE: Equivalent substitutes can be used.

- A. Enamel -- BMS 10-11, Type 2, Color 702 (SOPM 20-60-02)
 B. Sealant -- BMS 5-95 (SOPM 20-60-04)
 C. Primer -- BMS 10-11, Type 1 (SOPM 20-60-02)
 D. Grease -- BMS 3-33 or BMS 3-24 (SOPM 20-60-03)

32-35-70

REPAIR-GENERAL

01.1

Page 601

Nov 01/02

4. Dimensioning Symbols

- A. Standard True Position Dimensioning Symbols used in applicable repair procedures are shown in SOPM 20-00-00.

32-35-70

REPAIR-GENERAL

01.1

Page 602

Nov 01/02

TORQUE SHAFT – REPAIR 1-1

257T3519-1

1. Disassembly (Fig. 601 and IPL Fig. 1)
 - A. Remove the rivets (80) from the stop crank (85) and the stub shaft (90).
 - B. Remove the stop crank (85) and the stub shaft (90) from the torque shaft (220).
 - C. Remove the rivets (105, 145) from the quadrant assembly (100, 135).
 - D. Remove the quadrant (100, 135) from the torque shaft (220).
 - E. Remove the rivets (200, 205) from the crank assembly (170, 200).
 - F. Remove the crank assembly (170, 200) from the torque shaft (220).
 - G. Remove the rivets (105, 145) from the quadrant assembly (100, 140).
 - H. Remove the quadrant assembly (100, 140) from the torque shaft (220).
2. Torque Shaft Repair

NOTE: Refer to REPAIR-GEN for a list of applicable standard practices. Instructions given in Fig. 602 are to repair the finishes of the items.
3. Assembly (Refer to Fig. 601 and IPL Fig. 1)
 - A. Attach the quadrant assembly (100, 135) to the torque shaft (220) with new rivets (105, 145).
 - B. Attach the crank assembly (170, 175) to the torque shaft (220) with new rivets (200, 205).
 - C. Attach the other quadrant assembly (100, 140) to the torque shaft (220) with new rivets (105, 145).
 - D. Attach the stop crank (85) and the stub shaft (90) to the torque shaft (220) with new rivets (80).


32-35-70

REPAIR 1-1

01.1

Page 601

Nov 01/02



(257T3501-1 ASSEMBLY)

- 1 ASSEMBLE WITH WET PRIMER, BMS 10-11, TYPE 1 (F-20.06).
- 2 DO NOT USE PRIMER ON THIS SURFACE.
- 3 LIMIT THE TORQUE TO 500-600 INCH-POUNDS.

Torque Shaft Repair
 Figure 601 (Sheet 1)


32-35-70

REPAIR 1-1

Page 602

Jan 01/91

01



Torque Shaft Repair
 Figure 601 (Sheet 2)


32-35-70

REPAIR 1-1

01

Page 603

Jan 01/91



(257T3501-2 ASSEMBLY)

- 1 ASSEMBLE WITH WET PRIMER, BMS 10-11, TYPE 1 (F-20.06).
- 2 DO NOT USE PRIMER ON THIS SURFACE.
- 3 LIMIT THE TORQUE TO 500-600 INCH-ROUNDS.

Torque Shaft Repair
 Figure 601 (Sheet 3)


32-35-70

REPAIR 1-1

Page 604

Jan 01/91

01



1 ASSEMBLE WITH WET BMS 10-11,
 TYPE 1 PRIMER (F-20.06).

Torque Shaft Repair
 Figure 601 (Sheet 4)


32-35-70

REPAIR 1-1

01

Page 605

Jan 01/91



REPAIR

CHROMIC ACID ANODIZE, TYPE 1, AND
 APPLY ONE COAT OF BMS 10-11,
 TYPE 1 PRIMER (F-18.13).

125/ ON ALL MACHINED SURFACES,
 UNLESS SHOWN DIFFERENTLY

MATERIAL: AL ALLOY

ALL DIMENSIONS ARE IN INCHES

1 OMIT PRIMER ON THESE SURFACES

257T3519-1
 Torque Shaft Repair
 Figure 602

32-35-70

REPAIR 1-1

Page 606

Jan 01/91

01

ACTUATOR SUPPORT ASSEMBLY – REPAIR 2-1

257T3511-1, -4

NOTE: Refer to REPAIR-GEN for a list of applicable standard practices.

1. Bearing Replacement (Fig. 601)

- A. Remove the old bearing (65) from the actuator support assembly (60).
- B. Install a replacement bearing with BMS 5-95 wet sealant and roller swage the housing (SOPM 20-50-03).

2. Bushing Replacement (Fig. 601)

- A. Remove the old bushings from the actuator support assembly (60).
- B. Install replacement bushings by the press-fit method (SOPM 20-50-03).
- C. Make a check of the dimensions and machine them as necessary to the dimensions shown.

32-35-70


REPAIR 2-1

01.1

Page 601

Nov 01/02

COMPONENT
MAINTENANCE MANUAL



REFINISH

CHEMICAL TREAT AND APPLY BMS 10-11, TYPE 1
YELLOW PRIMER AND BMS 10-11, TYPE 2 WHITE
GLOSS ENAMEL (F-21.12).

ITEM NUMBERS REFER TO IPL FIG. 1
ALL DIMENSIONS ARE IN INCHES

257T3511-1,-4
Actuator Support Repair
Figure 601

32-35-70

REPAIR 2-1

01.1

Page 602

Nov 01/02



STOP CRANK – REPAIR 3-1

257T3512-1,-3

|NOTE: Refer to REPAIR-GEN for a list of applicable standard practices.

|1. Coating Repair (Fig. 601)

| A. Repair is only replacement of the original finish.


32-35-70

REPAIR 3-1

01.1

Page 601

Nov 01/02



REFINISH

CHROMIC ACID ANODIZE AND APPLY BMS 10-11, TYPE 1 PRIMER (F-18.13). APPLY BMS 10-11, TYPE 2, COLOR 702 WHITE GLOSS ENAMEL (F-21.03).

REPAIR

(SAME AS REFINISH)

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

MATERIAL: AL ALLOY

ALL DIMENSIONS ARE IN INCHES

1 NO PRIMER OR ENAMEL

257T3512-1,-3
 Stop Crank Repair
 Figure 601

32-35-70

REPAIR 3-1

01.1

Page 602

Nov 01/02

QUADRANT ASSY - REPAIR 4-1

257T3513-1, -5, -6, -11, -12

NOTE: Refer to REPAIR-GEN for a list of applicable standard practices. Refer to IPL Fig. 1 for item numbers.

1. Parts Replacement (Fig. 601)

- A. On quadrant assembly 257T3513-1, remove rivets (120) and flanged hub (125) from quadrant assembly (100).
- B. Remove rivets (110) and cable guards (115).
- C. Repair, refinish or replace parts as necessary.
- D. On quadrant assembly 257T3513-1, attach flanged hub (125) to quadrant assembly (100) with new rivets (120).
- E. Attach cable guards (115) to quadrant assembly (100, 135, 140) with new rivets (110).


32-35-70

REPAIR 4-1

01.1

Page 601

Nov 01/02



REFINISH

CHROMIC ACID ANODIZE (F-17.04). APPLY BMS 10-11, TYPE 1 PRIMER (F-20.02). APPLY BMS 10-11, TYPE 2, COLOR 702 WHITE GLOSS ENAMEL (F-21.03).

REPAIR

(SAME AS REFINISH)

125 ✓ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

MATERIAL: AL ALLOY

ALL DIMENSIONS ARE IN INCHES

1 NO PRIMER OR ENAMEL

257T3513-1
 Quadrant Assembly Repair
 Figure 601 (Sheet 1)


32-35-70

REPAIR 4-1

Page 602

Nov 01/02

01.1



REFINISH

CHROMIC ACID OR SULFURIC ACID ANODIZE (F-17.05).
 APPLY BMS 10-11, TYPE 1 PRIMER (F-20.02). APPLY
 BMS 10-11, TYPE 2, COLOR 702 WHITE GLOSS ENAMEL
 (F-21.15), 0.0005-0.0010 THICK.

1 NO PRIMER OR ENAMEL

REPAIR

(SAME AS REFINISH)

125/ ALL MACHINED SURFACES UNLESS SHOWN
 DIFFERENTLY

MATERIAL: AL ALLOY

ALL DIMENSIONS ARE IN INCHES

257T3513-5,-6
 Quadrant Assembly Repair
 Figure 601 (Sheet 2)



32-35-70

REPAIR 4-1

Page 603

Nov 01/02

01.1



REFINISH

CHROMIC ACID ANODIZE AND APPLY BMS 10-11, TYPE 1 PRIMER (F-18.13). APPLY BMS 10-11, TYPE 2, COLOR 702 WHITE GLOSS ENAMEL (F-21.03).

- 1 NO ENAMEL IN THE BORE
- 2 ENAMEL OPTIONAL ON CHAMFER

REPAIR

(SAME AS REFINISH)

125 ✓ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

MATERIAL: AL ALLOY

ALL DIMENSIONS ARE IN INCHES

257T3525-1
 Flanged Hub Repair
 Figure 602

32-35-70

REPAIR 4-1

Page 604

Nov 01/02

01.1

CRANK ASSEMBLY - REPAIR 5-1

257T3514-1, -5

NOTE: Refer to REPAIR-GEN for a list of applicable standard practices. Refer to IPL Fig. 1 for item numbers. For repair of surfaces which is only replacement of the original finish, refer to Refinish instructions.

1. Repair (Fig. 601)

A. On crank assembly 257T3514-1, remove rivets (180) and flanged hub (185).

B. Replace parts as necessary.

CAUTION: USE BACR15BB8B26 RIVET ONLY. DO NOT USE SUBSTITUTES.

C. On crank assembly 257T3514-1, attach flanged hub (185) to crank (195) with new rivets (180).

D. Assemble with grease on the faying surfaces.



32-35-70

REPAIR 5-1

01.1


Page 601

Nov 01/02



257T3514-1
 SHOWN WITH 257T3514-2
 FOR 257T3514-4 DIFFERENCES SEE (A)

257T3514-4
 (A)



257T3514-1,-5
 Crank Assembly Repair
 Figure 601 (Sheet 1)


32-35-70

REPAIR 5-1

Page 602

Nov 01/02

01.1



257T3514-5

B-B

REFINISH

CHROMIC ACID ANODIZE AND APPLY BMS 10-11, TYPE 1 PRIMER (F-18.13). APPLY BMS 10-11, TYPE 2 ENAMEL, COLOR 702 WHITE GLOSS (F-21.03).

REPAIR

(SAME AS REFINISH)

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

MATERIAL: AL ALLOY

ALL DIMENSIONS ARE IN INCHES

1 NO PRIMER OR ENAMEL

257T3514-1,-5
 Crank Assembly Repair
 Figure 601 (Sheet 2)


32-35-70

REPAIR 5-1


01.1

Page 603

Nov 01/02



257T3525-2



A-A

REFINISH

CHROMIC ACID ANODIZE AND APPLY BMS 10-11, TYPE 1 PRIMER (F-18.13). APPLY BMS 10-11, TYPE 2 ENAMEL, COLOR 702 WHITE GLOSS (F-21.03).

REPAIR

(SAME AS REFINISH)

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

MATERIAL: AL ALLOY

ALL DIMENSIONS ARE IN INCHES

- 1 NO ENAMEL IN THE BORE.
- 2 ENAMEL OPTIONAL ON CHAMFER.

257T3525-2
 Flanged Hub Repair
 Figure 602

| STUB SHAFT – REPAIR 6-1

| 257T3520-1

1. Repair

- | A. Repair is only replacement of the original finish. Refer to Refinish instructions in Fig. 601. Refer to REPAIR-GENERAL for applicable standard practices.


32-35-70

REPAIR 6-1

01.1

Page 601

Nov 01/02



REFINISH

CADMIUM PLATE (F-15.06) APPLY BMS 10-11, TYPE 1 PRIMER (F-20.02).

REPAIR

(SAME AS REFINISH)

125/ ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY

MATERIAL: 4340 STEEL, 180-200 KSI

ALL DIMENSIONS ARE IN INCHES

1 WIPE WITH PRIMER (F-19.45)

257T3520-1
 Stub Shaft Repair
 Figure 601

32-35-70

REPAIR 6-1

Page 602

Nov 01/02

01.1


BOEING
 COMPONENT
 MAINTENANCE MANUAL

MISCELLANEOUS PARTS REFINISH – REPAIR 7-1

1. Refinish of these parts is only replacement of the original finish. Refer to REPAIR-GENERAL for a list of applicable standard practices.

IPL FIG. & ITEM	MATERIAL	FINISH
<u>Fig. 1</u> Switch plate (30) Cable Guard (155)	Al alloy	Chemical treat and apply BMS 10-11, type 1 primer (F-18.06). Apply BMS 10-11 type 2 enamel (F-21.03).
Spacers (95)	Al alloy	Chromic acid anodize and apply BMS 10-11 type 1 primer (F-18.13)

Refinish Details
 Figure 601

32-35-70

REPAIR 7-1

01.1

Page 601

Nov 01/02

ASSEMBLY1. Assembly (IPL Fig. 1)

- A. Install the switch plate (30), switch (25) and the actuator (20) with bolts (5), washers (10) and nuts (15).
- B. Slide the support assembly (60) on the stub shaft (90).
- C. Install the nut (55) on the stub shaft (90) and tighten the nut to 500-600 in. lb.


2. Switch Adjustment (Fig. 701)

- A. Loosen the nuts (15) at each end of the switch plate (30).
- B. Put two 0.0875-0.0885 inch diameter pins, as shown, on each side of travel.
- C. Adjust the switches to touch the stop crank (85) when it is turned between its limits of travel.
- D. Tighten the nuts (15).
- E. Put two 0.0655-0.0665 inch diameter pins as shown.
- F. Turn the stop crank and make sure it touches and operates the switch before it touches the pins.
- G. Put two 0.1095-0.1105 inch diameter pins as shown.
- H. Turn the stop crank and make sure it touches the pins before it touches the switches. Make sure the switches do not operate.

NOTE: You can measure the electrical continuity through the common (C) and normally open (N.O.) terminals to see if the switches operate.


32-35-70ASSEMBLY
Page 701
Nov 01/02

01.1



NOTE: THE QUADRANTS ARE NOT SHOWN.

Shaft Assembly Adjustment
Figure 701



REF LETTER FIG. 801	MATING ITEM NO. IPL FIG.1	DESIGN DIMENSION				SERVICE WEAR LIMIT		
		DIMENSION		ASSEMBLY CLEARANCE		DIMENSION		MAXIMUM CLEARANCE
		MIN	MAX	MIN	MAX	MIN	MAX	
A	ID 65	1.8120	1.8130	0.0000	0.0020	1.8080	1.8160	0.0040
	OD 90	1.8110	1.8120					
B	ID 75	2.7500	2.7510	0.0000	0.0020	2.7460	2.7540	0.0040
	OD 65	2.7490	2.7500					

Fits and Clearances
 Figure 801

32-35-70

FITS AND CLEARANCES
 01 Page 801
 Jan 01/91

ILLUSTRATED PARTS LIST

1. This section lists and illustrates replaceable or repairable component parts. The Illustrated Parts Catalog contains a complete explanation of the Boeing part numbering system.

2. Indentures show parts relationships as follows:

Assembly

Detail Parts for Assembly

Subassembly

Attaching Parts for Subassembly

Detail Parts for Subassembly

Detail Installation Parts (Included only if installation parts may be returned to shop as part of assembly)

3. One use code letter (A, B, C, etc.) is assigned in the EFF CODE column for each variation of top assembly. All listed parts are used on all top assemblies except when limitations are shown by use code letter opposite individual part entries.

4. Letter suffixes (alpha-variants) are added to item numbers for optional parts, Service Bulletin modification parts, configuration differences (except left- and right-hand parts), product improvement parts, and parts added between two sequential item numbers. The alpha-variant is not shown on illustrations when appearance and location of all variants of the part is the same.

5. Service Bulletin modifications are shown by the notations PRE SB XXXX and POST SB XXXX.

A. When a new top assembly part number is assigned by Service Bulletin, the notations appear at the top assembly level only. The configuration differences at detail part level are then shown by use code letter.

B. When the top assembly part number is not changed by the Service Bulletin, the notations appear at the detail part level.

6. Parts Interchangeability

Optional
(OPT)

The parts are optional to and interchangeable with other parts having the same item number.

Supersedes, Superseded By
(SUBSDS, SUPSD BY)

The part supersedes and is not interchangeable with the original part.

Replaces, Replaced By
(REPLS, REPLD BY)

The part replaces and is interchangeable with, or is an alternate to, the original part.

32-35-70

ILLUSTRATED PARTS LIST

01.1

Page 1001

Nov 01/02

VENDORS

06144 INDUSTRIAL TECTONICS BEARING CORP
18301 SOUTH SANTA FE AVENUE
RANCO DOMINQUEZ, CALIFORNIA 90221
FORMERLY IN COMPTON, CALIFORNIA

21335 TORRINGTON CO FAFNIR BEARING DIV
59 FIELD STREET
TORRINGTON, CONNECTICUT 06790-1008
FORMERLY FAFNIR BRG AND TEXTRON INC FAFNIR DIV IN
NEW BRITAIN, CONNECTICUT

38443 MRC BEARINGS
402 CHANDLER STREET
JAMESTOWN, NEW YORK 14701-3802
FORMERLY MARLIN-ROCKWELL CORP DIV TRW AND TRW INC

40920 MPB MINIATURE PRECISION BEARING DIV
PRECISION PARK PO BOX 547
KEENE, NEW HAMPSHIRE 03431
FORMERLY MPB CORP AND MINIATURE BRG DIV MPB CORP

56878 SPS TECHNOLOGIES INC AEROSPACE AND INDUSTRIAL PRODUCTS DIV
HIGHLAND AVENUE
JENKINTOWN, PENNSYLVANIA 19046
FORMERLY STANDARD PRESSED STEEL

72962 HARVARD INDUSTRIES INC
3 WERNER WAY SUITE 210
LEBANON, NEW JERSEY 08833
FORMERLY AMERACE CORP ESNA DIV
FORMERLY ELASTIC STOP NUT IN UNION, NJ

83086 NEW HAMPSHIRE BALL BEARINGS, INCORPORATED
ROUTE 202
PETERBOROUGH, NEW HAMPSHIRE 03458

91929 HONEYWELL INC MICRO SWITCH DIV
11 WEST SPRING STREET
FREEPORT, ILLINOIS 61032
FORMERLY MICRO SWITCH A DIV OF HONEYWELL
FORMERLY V74059 AND V40228

97393 SHUR-LOK CORPORATION
2541 WHITE ROAD PO BOX 19584
IRVINE, CALIFORNIA 92713
FORMERLY SHUR LOK CORP VB0060
FORMERLY IN SANTA ANA, CALIFORNIA 92714

32-35-70

ILLUSTRATED PARTS LIST
01.1 Page 1002
Nov 01/02


BOEING
 COMPONENT
 MAINTENANCE MANUAL

PART NUMBER	AIRLINE PART NO.	FIG.	ITEM	TTL REQ
ADH3721R2		1	20	2
AN960JD416L		1	10A	8
		1	40A	1
AN960KD416L		1	10	8
		1	40	1
BACA12D2		1	20	2
BACB10EX29		1	65	1
BACN10JC4		1	15	4
		1	45	1
BACN10RF28		1	55	1
BACR15BB5AD		1	110	8
		1	150	8
BACR15BB8B18		1	120	4
BACR15BB8B26		1	180	3
BR9080-2812		1	55	1
KP29BS		1	65	1
KP29BSFS428		1	65	1
KP29BSLY196		1	65	1
KP29BSNJC		1	65	1
KP29BSSD610		1	65	1
KP29BS2		1	65	1
MS21042L4		1	15A	4
		1	45A	1
MS25011-2		1	25	2
MS27648-29		1	65A	1
MS90354U0807		1	80A	6
MS90354U0808		1	205A	5
MS90354-0805		1	105	8
		1	175	6
MS90354-0807		1	80	6
MS90354-0808		1	205	5
MS90354-0814		1	145	8
NAS43HT4-138		1	50	1
NAS6604-38		1	35	1
NAS6604-7		1	5	4
NAS77-4-24		1	190	1
		1	210	1
NAS77-5-42		1	70	3
SL2822-28		1	55	1
257T3501-1		1	1	RF
257T3501-2		1	1A	RF
257T3501-3		1	1B	RF
257T3501-4		1	1C	RF
257T3501-5		1	1D	RF
257T3511-1		1	60	1


32-35-70

 ILLUSTRATED PARTS LIST
 01.1 Page 1003
 Nov 01/02

PART NUMBER	AIRLINE PART NO.	FIG.	ITEM	TTL REQ
257T3511-2		1	75	1
257T3511-4		1	60A	1
257T3511-5		1	75A	1
257T3512-1		1	85	1
257T3512-3		1	85A	1
257T3513-1		1	100	2
257T3513-11		1	135A	1
257T3513-12		1	140B	1
257T3513-2		1	130	2
257T3513-5		1	135	1
257T3513-6		1	140	1
257T3513-7		1	160	1
257T3513-8		1	165	1
257T3514-1		1	170	1
257T3514-2		1	195	1
257T3514-4		1	195A	1
257T3514-5		1	200	1
257T3514-6		1	215	1
257T3516-1		1	115	4
		1	155	4
257T3516-2		1	155A	4
257T3517-1		1	95	1
257T3519-1		1	220	1
257T3520-1		1	90	1
257T3525-1		1	125	2
257T3525-2		1	185	1
257T3526-1		1	30	2
82631-2812		1	55	1

32-35-70



 ILLUSTRATED PARTS LIST
 01.1 Page 1004
 Nov 01/02



Torque Shaft Assembly
Figure 1 (Sheet 1)

32-35-70


ILLUSTRATED PARTS LIST
01.1 Page 1005
Nov 01/02



**Torque Shaft Assembly
 Figure 1 (Sheet 2)**

32-35-70

ILLUSTRATED PARTS LIST
 01.1 Page 1006
 Nov 01/02





(D)

Torque Shaft Assembly
Figure 1 (Sheet 3)

32-35-70

ILLUSTRATED PARTS LIST
01.1 Page 1007
Nov 01/02



Torque Shaft Assembly
 Figure 1 (Sheet 4)

32-35-70

ILLUSTRATED PARTS LIST
 01.1 Page 1008
 Nov 01/02


BOEING
 COMPONENT
 MAINTENANCE MANUAL

FIG. & ITEM	PART NO.	AIRLINE PART NUMBER	NOMENCLATURE 1234567	EFF CODE	QTY PER ASSY
01- -1	257T3501-1		SHAFT ASSY-LG ALTERNATE EXTEND TORQUE	A	RF
-1A	257T3501-2		SHAFT ASSY-LG ALTERNATE EXTEND TORQUE	B	RF
R -1B	257T3501-3		SHAFT ASSY-LG ALTERNATE EXTEND TORQUE	C	RF
R -1C	257T3501-4		SHAFT ASSY-LG ALTERNATE EXTEND TORQUE	D	RF
R -1D	257T3501-5		SHAFT ASSY-LG ALTERNATE EXTEND TORQUE	E	RF
5	NAS6604-7		.BOLT		4
10	AN960KD416L		.WASHER	A	8
-10A	AN960JD416L		.WASHER	B-E	8
15	BACN10JC4		.NUT	A	4
-15A	MS21042L4		.NUT	B-E	4
20	ADH3721R2		.ACTUATOR- (V91929) (SPEC BACA12D2)		2
25	MS25011-2		.SWITCH		2
30	257T3526-1		.PLATE-SWITCH		2
35	NAS6604-38		.BOLT		1
40	AN960KD416L		.WASHER	A	1
-40A	AN960JD416L		.WASHER	B-E	1
45	BACN10JC4		.NUT	A	1
-45A	MS21042L4		.NUT	B-E	1
50	NAS43HT4-138		.SPACER		1
55	SL2822-28		.NUT- (V97393) (SPEC BACN10RF28) (OPT 82631-2812 (V56878)) (OPT BR9080-2812 (V72962))		1
60	257T3511-1		.SUPPORT ASSY-ACTR	A-C	1
R -60A	257T3511-4		.SUPPORT ASSY-ACTR	DE	1

32-35-70

ILLUSTRATED PARTS LIST

01.1

Page 1009

Nov 01/02

FIG. & ITEM	PART NO.	AIRLINE PART NUMBER	NOMENCLATURE 1234567	EFF CODE	QTY PER ASSY
01-65	KP29BSLY196		..BEARING- (V40920) (SPEC BACB10EX29) (OPT KP29BSSD610 (V83086)) (OPT KP29BS (V06144)) (OPT KP29BSFS428 (V21335)) (OPT KP29BS2 (V38443)) (OPT KP29BSNJC (V06144)) (OPT ITEM 65A)		1
R -65A	MS27648-29		..BEARING- (OPT ITEM 65)		1
70	NAS77-5-42		..BUSHING		3
75	257T3511-2		..SUPPORT (USED ON ITEM 60)		1
R -75A	257T3511-5		..SUPPORT (USED ON ITEM 60A)		1
80	MS90354-0807		.RIVET	A-D	6
R -80A	MS90354U0807		.RIVET	E	6
85	257T3512-1		.CRANK-STOP (OPT ITEM 85A)		1
-85A	257T3512-3		.CRANK-STOP (OPT ITEM 85)		1
90	257T3520-1		.SHAFT-STUB		1
95	257T3517-1		.SPACER		1
100	257T3513-1		.QUADRANT ASSY ATTACHING PARTS	A	2
105	MS90354-0805		.RIVET -----*-----	A	8
110	BACR15BB5AD		..RIVET- (SIZE DETERMINE ON INST)		4
115	257T3516-1		..GUARD-CABLE		2
120	BACR15BB8B18		..RIVET		2
125	257T3525-1		..HUB		1
130	257T3513-2		..QUADRANT		1
135	257T3513-5		.QUADRANT ASSY	B	1
R -135A	257T3513-11		.QUADRANT ASSY	CDE	1
140	257T3513-6		.QUADRANT ASSY	B	1
R -140A	257T3513-6		.QUADRANT ASSY- (LIMITED) (OPT ITEM 140B)	CD	1

32-35-70

 ILLUSTRATED PARTS LIST
 01.1 Page 1010
 Nov 01/02


BOEING
 COMPONENT
 MAINTENANCE MANUAL

FIG. & ITEM	PART NO.	AIRLINE PART NUMBER	NOMENCLATURE 1234567	EFF CODE	QTY PER ASSY
R 01-140B	257T3513-12		.QUADRANT ASSY- (OPT ITEM 140A)	CD	1
R -140C	257T3513-12		.QUADRANT ASSY ATTACHING PARTS	E	1
145	MS90354-0814		.RIVET -----*-----	B-E	8
150	BACR15BB5AD		..RIVET- (SIZE DETERMINE ON INST)		4
155	257T3516-1		..GUARD-CABLE (USED ON ITEM 140A)		2
R -155A	257T3516-2		..GUARD-CABLE (USED ON ITEMS 135A, 140B)		2
160	257T3513-7		..QUADRANT- (USED ON ITEMS 135, 135A)		1
165	257T3513-8		..QUADRANT- (USED ON ITEMS 140, 140A,140B,140C)		1
170	257T3514-1		.CRANK ASSY ATTACHING PARTS	A	1
175	MS90354-0805		.RIVET -----*-----	A	6
180	BACR15BB8B26		..RIVET		3
185	257T3525-2		..HUB		1
190	NAS77-4-24		..BUSHING		1
195	257T3514-2		..CRANK- (OPT ITEM 195A)		1
-195A	257T3514-4		..CRANK- (OPT ITEM 195)		1

32-35-70

ILLUSTRATED PARTS LIST

01.1

Page 1011

Nov 01/02

FIG. & ITEM	PART NO.	AIRLINE PART NUMBER	NOMENCLATURE	EFF CODE	QTY PER ASSY
			1234567		
01- 200	257T3514-5		.CRANK ASSY ATTACHING PARTS	B-E	1
R -205A	MS90354-0808		.RIVET	B-D	5
	MS90354U0808		.RIVET -----*-----	E	5
210	NAS77-4-24		..BUSHING		1
215	257T3514-6		..CRANK		1
220	257T3519-1		.SHAFT		1

- Item Not Illustrated

32-35-70

ILLUSTRATED PARTS LIST
 01.1 Page 1012
 Nov 01/02