

 **BOEING**
COMPONENT
MAINTENANCE MANUAL

TO: ALL HOLDERS OF MAIN LANDING GEAR BRAKE QUADRANT ASSEMBLY COMPONENT
MAINTENANCE MANUAL 32-41-23.

REVISION NO. 1 DATED SEP 01/94

HIGHLIGHTS

Pages which have been added or revised are outlined below together with the highlights of the revision. Remove and insert the affected pages as listed and enter Revision No. and date on the Record of Revision Sheet.

CHAPTER/SECTION

AND PAGE NO.

DESCRIPTION OF CHANGE

REPAIR-GEN
601

Added reference to 32-00-05 for standard repair of high-strength steel parts.

REPAIR-GEN
602-603

Changed the standard location of the datum letters.

REPAIR 4-1
601

Changed a diameter callout on bearing shaft 69B81260-1.

32-41-23

HIGHLIGHTS

01.1

Page 1

Sep 01/94



MAIN LANDING GEAR BRAKE QUADRANT ASSEMBLY

PART NUMBER 253T3526-1,-2

COMPONENT MAINTENANCE MANUAL
WITH
ILLUSTRATED PARTS LIST

32-41-23

TITLE PAGE

Page 1

Apr 10/86

01

209512



REVISION RECORD

- Retain this record in front of manual. On receipt of revision, insert revised pages in the manual, and enter revision number, date inserted and initial.

REVISION NUMBER	REVISION DATE	DATE FILED	BY	REVISION NUMBER	REVISION DATE	DATE FILED	BY

TEMPORARY REVISION AND SERVICE BULLETIN RECORD

BOEING SERVICE BULLETIN	BOEING TEMPORARY REVISION	OTHER DIRECTIVE	DATE OF INCORPORATION INTO MANUAL
		PRR B11452	APR 10/86

32-41-23

TR & SB RECORD

01

Page 1

Apr 10/86


BOEING
 COMPONENT
 MAINTENANCE MANUAL

PAGE	DATE	CODE	PAGE	DATE	CODE
32-41-23			REPAIR-GENERAL		CONT.
			*604	BLANK	
TITLE PAGE			REPAIR 1-1		
1	APR 10/86	01	601	APR 10/86	01
2	BLANK		602	APR 10/86	01
REVISION RECORD			REPAIR 2-1		
1	APR 10/86	01	601	APR 10/86	01
2	BLANK		602	APR 10/86	01
TR & SB RECORD			REPAIR 3-1		
1	APR 10/86	01	601	APR 10/86	01
2	BLANK		602	BLANK	
LIST OF EFFECTIVE PAGES			REPAIR 3-2		
*1	SEP 01/94	01	601	APR 10/86	01
THRU LAST PAGE			602	APR 10/86	01
			603	APR 10/86	01
CONTENTS			604	BLANK	
1	APR 10/86	01	REPAIR 4-1		
2	BLANK		*601	SEP 01/94	01.1
INTRODUCTION			602	BLANK	
1	APR 10/86	01	REPAIR 5-1		
2	BLANK		601	APR 10/86	01
DESCRIPTION & OPERATION			602	BLANK	
1	APR 10/86	01	ASSEMBLY		
2	BLANK		701	APR 10/86	01
DISASSEMBLY			702	APR 10/86	01
301	APR 10/86	01	703	APR 10/86	01
302	BLANK		704	BLANK	
CHECK			ILLUSTRATED PARTS LIST		
501	APR 10/86	01	1001	APR 10/86	01
502	BLANK		1002	APR 10/86	01
REPAIR-GENERAL			1003	APR 10/86	01
*601	SEP 01/94	01.1	1004	BLANK	
*602	SEP 01/94	01.1	1005	APR 10/86	01
*603	SEP 01/94	01.1	1006	APR 10/86	01
			1007	APR 10/86	01

* = REVISED, ADDED OR DELETED

32-41-23
 EFFECTIVE PAGES
 CONTINUED Page 1
 01 Sep 01/94

PAGE	DATE	CODE	PAGE	DATE	CODE
ILLUSTRATED PARTS LIST					
1008	APR 10/86	01			
		CONT.			

* = REVISED, ADDED OR DELETED

32-41-23

EFFECTIVE PAGES
 LAST PAGE Page 2
 01 Sep 01/94



TABLE OF CONTENTS

<u>Paragraph Title</u>	<u>Page</u>
Description and Operation	1
Testing/Trouble Shooting (not applicable)	
Disassembly.	301
Cleaning*[1]	
Check.	501
Repair	601
Assembly	701
Fits and Clearances (not applicable)	
Special Tools (not applicable)	
Illustrated Parts List	1001

*[1] Special instructions not required. Use standard industry practices.

32-41-23

01

CONTENTS
Page 1
Apr 10/86



INTRODUCTION

The instructions in this manual provide the information necessary to perform maintenance functions ranging from simple checks and replacement to complete shop-type repair.

This manual is divided into separate sections:

- | | |
|---|------------------------------|
| 1. Title Page | 4. List of Effective Pages |
| 2. Record of Revisions | 5. Table of Contents |
| 3. Temporary Revisions &
Service Bulletin Record | 6. Introduction |
| | 7. Procedures & IPL Sections |

Refer to the Table of Contents for the page location of applicable sections. An asterisked flagnote *[] in place of the page number indicates that no special instructions are provided since the function can be performed using standard industry practices.

The beginning of the REPAIR section includes a list of the separate repairs, a list of applicable standard Boeing practices, and an explanation of the True Position Dimensioning symbols used.

An explanation of the use of the Illustrated Parts List is provided in the Introduction to that section.

All weights and measurements used in the manual are in English units, unless otherwise stated. When metric equivalents are given they will be in parentheses following the English units.

Design changes, optional parts, configuration differences and Service Bulletin modifications create alternate part numbers. These are identified in the Illustrated Parts List (IPL) by adding an alphabetical character to the basic item number. The resulting item number is called an alpha-variant. Throughout the manual, IPL basic item number references also apply to alpha-variants unless otherwise indicated.

Verification:

Disassembly
Assembly

32-41-23

INTRODUCTION

01

Page 1

Apr 10/86



MAIN LANDING GEAR BRAKE QUADRANT ASSEMBLY

DESCRIPTION AND OPERATION

1. The main landing gear brake quadrant assembly consists of cranks and quadrant mounted on a shaft. Bearing shafts provide turning surfaces. Inputs transmitted from the brake system rotate the quadrant to operate the brakes by cables.

2. Leading Particulars (Approximate)

Length -- 8 inches

Width -- 8 inches

Height -- 6 inches

Weight -- 5 pounds

32-41-23

DESCRIPTION & OPERATION

01

Page 1

Apr 10/86



DISASSEMBLY

NOTE: Disassemble this component only as necessary to complete fault isolation, determine the serviceability of parts, perform required repairs and restore the unit to serviceable condition. Refer to IPL Fig. 1 for item numbers.

1. Left-Hand Quadrant

- A. Remove bolt (10), washer (15) and nut (20) from crank (25).
- B. Remove crank (25) and nut (30) from shaft (85).
- C. Remove crank (40), spacers (55, 60), and bearing (35) from shaft. Do not remove bearing (45) from crank (50) unless necessary for repair or replacement.
- D. Remove parts (75, 70, 65) and quadrant (80) from shaft (85).
- E. Remove spring pin (170) and separate bearing shaft (175) from shaft (85).

2. Right-Hand Quadrant

- A. Remove nut (90) from outer shaft (165). Remove crank (95), bearing (115), and spacer (110) from shaft. Do not remove bearing (100) from crank (105) unless necessary for repair or replacement.
- B. Remove bolt (125), washer (130), and nut (135) from crank (140); then remove crank (140) from shaft (165).
- C. Remove parts (155, 150, 145) and quadrant (160) from shaft (165).
- D. Remove spring pin (170) and separate bearing shaft (175) from shaft (165).

32-41-23

DISASSEMBLY

01

Page 301

Apr 10/86



CHECK

1. Check all parts for obvious defects in accordance with standard industry practices.
2. Penetrant check per 20-20-02:
 - A. Cranks (25, 30 or 90, 50 or 105)
 - B. Spacers (55 or 110, 60, 120)
 - C. Quadrant (80 or 160)
 - D. Shaft (85 or 165)
3. Magnetic particle check per 20-20-01:
 - A. Bearing shaft (175)

32-41-23

01
CHECK
Page 501
Apr 10/86

REPAIR – GENERAL1. Content

- A. Repair, refinish and replacement procedures are included in separate repair sections as follows:

<u>P/N</u>	<u>NAME</u>	<u>REPAIR</u>
253T3527	SHAFT	1-1
253T3528	QUADRANT	2-1
253T3529	CRANK	3-1
69B81260	BEARING SHAFT	4-1
- - -	MISCELLANEOUS PARTS REFINISH	5-1

2. Standard Practices

- A. Refer to the following standard practices, as applicable, for details of procedures in individual repairs.

20-30-02	Stripping of Protective Finishes
20-41-01	Decoding Table for Boeing Finish Codes
20-42-05	Bright Cadmium Plating
20-43-01	Chromic Acid Anodizing
20-50-02	Installation of Safetying Devices
20-50-03	Bearing Installation and Retention
32-00-05	Repair of High Strength Steel Landing Gear Parts

3. Materials

NOTE: Equivalent substitutes can be used.

- A. Primer -- BMS 10-11, Type 1 (Ref 20-60-02)

32-41-23

REPAIR-GENERAL

01.1

Page 601

Sep 01/94

4. Dimensioning Symbols

- A. Standard True Position Dimensioning Symbols used in applicable repair procedures are shown in Fig. 601.

32-41-23

REPAIR-GENERAL

01.1

Page 602

Sep 01/94

BOEING

COMPONENT MAINTENANCE MANUAL

- STRAIGHTNESS
- ▭ FLATNESS
- ⊥ PERPENDICULARITY (OR SQUARENESS)
- // PARALLELISM
- ROUNDNESS
- ⊙ CYLINDRICITY
- ⌒ PROFILE OF A LINE
- △ PROFILE OF A SURFACE
- ◎ CONCENTRICITY
- ≡ SYMMETRY
- ∠ ANGULARITY
- ↗ RUNOUT
- ↗ TOTAL RUNOUT
- ⊏ COUNTERBORE OR SPOTFACE
- ∇ COUNTERSINK

- ⊕ THEORETICAL EXACT POSITION OF A FEATURE (TRUE POSITION)
- ∅ DIAMETER
- S ∅ SPHERICAL DIAMETER
- R RADIUS
- SR SPHERICAL RADIUS
- () REFERENCE
- BASIC (BSC) OR DIM A THEORETICALLY EXACT DIMENSION USED TO DESCRIBE SIZE, SHAPE OR LOCATION OF A FEATURE FROM WHICH PERMISSIBLE VARIATIONS ARE ESTABLISHED BY TOLERANCES ON OTHER DIMENSIONS OR NOTES.
- A- DATUM
- Ⓜ MAXIMUM MATERIAL CONDITION (MMC)
- Ⓛ LEAST MATERIAL CONDITION (LMC)
- Ⓢ REGARDLESS OF FEATURE SIZE (RFS)
- Ⓟ PROJECTED TOLERANCE ZONE
- FIM FULL INDICATOR MOVEMENT

EXAMPLES

<p>— 0.002 STRAIGHT WITHIN 0.002</p> <p>⊥ 0.002 B PERPENDICULAR TO B WITHIN 0.002</p> <p>// 0.002 A PARALLEL TO A WITHIN 0.002</p> <p>○ 0.002 ROUND WITHIN 0.002</p> <p>⊙ 0.010 CYLINDRICAL SURFACE MUST LIE BETWEEN TWO CONCENTRIC CYLINDERS, ONE OF WHICH HAS A RADIUS 0.010 INCH GREATER THAN THE OTHER</p> <p>⌒ 0.006 A EACH LINE ELEMENT OF THE SURFACE AT ANY CROSS SECTION MUST LIE BETWEEN TWO PROFILE BOUNDARIES 0.006 INCH APART RELATIVE TO DATUM PLANE A</p> <p>△ 0.020 A SURFACES MUST LIE WITHIN PARALLEL BOUNDARIES 0.02 INCH APART AND EQUALLY DISPOSED ABOUT TRUE PROFILE</p>	<p>◎ ∅ 0.0005 C CONCENTRIC TO C WITHIN 0.0005 DIAMETER</p> <p>≡ 0.010 A SYMMETRICAL WITH A WITHIN 0.010</p> <p>∠ 0.005 A ANGULAR TOLERANCE 0.005 WITH A</p> <p>⊕ ∅ 0.002 Ⓢ B LOCATED AT TRUE POSITION WITHIN 0.002 DIA RELATIVE TO DATUM B, REGARDLESS OF FEATURE SIZE</p> <p>⊥ ∅ 0.010 Ⓜ A 0.510 Ⓟ AXIS IS TOTALLY WITHIN A CYLINDER OF 0.010-INCH DIAMETER, PERPENDICULAR TO, AND EXTENDING 0.510-INCH ABOVE, DATUM A, MAXIMUM MATERIAL CONDITION</p> <p>2.000 THEORETICALLY EXACT DIMENSION IS 2.000 OR 2.000 BSC</p> <p>0.020 A A 0.020</p>
<p>NOTE: DATUM MAY APPEAR AT EITHER SIDE OF TOLERANCE FRAME</p>	

True Position Dimensioning Symbols
Figure 601

32-41-23

REPAIR-GENERAL

01.1

Page 603

Sep 01/94



SHAFT - REPAIR 1-1

253T3527-1, -2

1. Plating Repair

NOTE: Repair consists of restoration of original finish. Refer to Refinish instructions, Fig. 601 and to REPAIR-GEN for list of applicable standard practices.




32-41-23

REPAIR 1-1

01

Page 601

Apr 10/86



	1	2	3	4	5	6 1	6 2	7	8 1	8 2
DESIGN DIM	0.3752 0.3747	0.252 0.247	0.44 0.42	1.0618 1.0608	0.9197 0.9097	0.906 0.905	0.90 0.88	0.4415 0.4405	2.802 2.792	4.779 4.769

REFINISH

CHROMIC ACID ANODIZE (F-17.02) ALL OVER

1 253T3527-1

2 253T3527-2

REPAIR

(SAME AS REFINISH)

125 MACHINE FINISH EXCEPT AS NOTED

MATERIAL: AL ALLOY

ALL DIMENSIONS ARE IN INCHES

253T3527-1,-2
Shaft Repair and Refinish
Figure 601

32-41-23

REPAIR 1-1

Page 602

Apr 10/86

01



QUADRANT ASSEMBLY - REPAIR 2-1

253T3528-1, -2

1. Coating Repair

NOTE: Repair consists of restoration of original finish. Refer to Refinish instructions, Fig. 601 and to REPAIR-GEN for list of applicable standard practices.


32-41-23

REPAIR 2-1

01

Page 601

Apr 10/86



	①	②	③	④	⑤
DESIGN DIM	0.805 0.795	1.0635 1.0620	0.224 0.221	8.381 8.371	0.083 0.073

REFINISH

ANODIZE (F-17.05) AND APPLY PRIMER,
 BMS 10-11, TYPE 1 (F-20.02) EXCEPT AS NOTED.

① OMIT PRIMER THIS AREA

REPAIR

(SAME AS REFINISH)
 125/ MACHINE FINISH EXCEPT AS NOTED
 (250/ FINISH ON FORGED SURFACES)

MATERIAL: AL ALLOY

ALL DIMENSIONS ARE IN INCHES

253T3528-1,-2
 Quadrant Details
 Figure 601

32-41-23

REPAIR 2-1
 Page 602
 Apr 10/86

01


CRANK ASSEMBLY - REPAIR 3-1

253T3529-1

NOTE: Refer to REPAIR-GEN for list of applicable standard practices. Refer to IPL Fig. 1 for item numbers. For repair of surfaces which may require only restoration of original finish, refer to Refinish instructions, REPAIR 3-2.

1. Bearing Replacement (Fig. 601)

- A. Remove bearing (45 or 100) from crank (50 or 105).
- B. Install and roller swage new bearing with wet BMS 10-11, type 1 primer per 20-50-03.



1 ROLLER SWAGE HOUSING OVER BEARING PER 20-50-03, USING WET PRIMER BMS 10-11, TYPE 1 INSTEAD OF GREASE.

253T3529-1

Bearing Replacement
 Figure 601

209926

32-41-23

REPAIR 3-1

01

Page 601

Apr 10/86



CRANK - REPAIR 3-2

253T3529-2, -3, -4

1. Coating Repair

NOTE: Repair consists of restoration of original finish. Refer to Refinish instructions, Fig. 601 and to REPAIR-GEN for list of applicable standard practices.


32-41-23

REPAIR 3-2

01

Page 601

Apr 10/86



253T3529-2,-3,-4
 Crank Repair and Refinish
 Figure 601 (Sheet 1)

32-41-23


REPAIR 3-2

Page 602

Apr 10/86

01

BOEING
COMPONENT
MAINTENANCE MANUAL



	1	2	3	4	5	6	7	8	9
DESIGN DIM	0.3781 0.3766	0.15 0.13	0.615 0.605	0.20 0.18	0.2505 0.2495	0.3781 0.3766	0.17 0.15	0.615 0.605	0.2505 0.2495
REPAIR LIMIT	---	---	---	---	---	---	---	---	---

	10	11	12	13	14	15	16
DESIGN DIM	1.501 1.500	1.36 1.34	0.11 0.09	0.265 0.250	1.501 1.500	0.9077 0.9062	1.0635 1.0620
REPAIR LIMIT	---	---	---	---	---	---	---

REFINISH

ANODIZE (F-17.05) ALL OVER. APPLY PRIMER, BMS 10-11, TYPE 1 (F-20.02) EXCEPT OMIT PRIMER IN ALL HOLES.

REPAIR

(SAME AS REFINISH)
 125 / MACHINE FINISH EXCEPT AS NOTED
 MATERIAL: AL ALLOY
 ALL DIMENSIONS ARE IN INCHES

253T3529-2,-3,-4
 Crank Repair and Refinish
 Figure 601 (Sheet 2)

32-41-23

REPAIR 3-2

01

Page 603


Apr 10/86

SHAFT - REPAIR 4-1

69B81260-1

1. Plating Repair

- A. Repair is only replacement of the original finish. Refer to Refinish instructions, Fig. 601 and to REPAIR-GEN for a list of applicable standard practices.



REFINISH

CADMIUM PLATE (F-15.02) AREAS SHOWN BY .
 PASSIVATE (F-17.09) ALL OTHER AREAS

REPAIR

(SAME AS REFINISH)
 125 ALL MACHINED SURFACES UNLESS SHOWN DIFFERENTLY
 MATERIAL: 17-4PH CRES, 180-200 KSI
 ALL DIMENSIONS ARE IN INCHES

69B81260-1
 Bearing Shaft Repair and Refinish
 Figure 601

209515

32-41-23

REPAIR 4-1

01.1

Page 601

Sep 01/94


BOEING
 COMPONENT
 MAINTENANCE MANUAL

MISCELLANEOUS PARTS REFINISH – REPAIR 5-1

1. Repair of parts listed in Fig. 601 consists of restoration of the original finish.

IPL FIG. & ITEM	MATERIAL	FINISH
<u>Fig. 1</u> Spacers (55 or 110, 60, 120)	Al alloy	Treat interior and exterior surfaces per MIL-C-5541 and apply one coat BMS 10-11, type 1 primer (F-18.07) except omit primer on interior surface.

Refinish Details
 Figure 601

32-41-23

REPAIR 5-1

01

Page 601

Apr 10/86

ASSEMBLY1. Materials

NOTE: Equivalent substitutes may be used.

A. Grease -- BMS 3-24 (Ref 20-60-03)


2. Left-Hand Quadrant (IPL Fig. 1) (Fig. 701)

- A. Coat bearing shaft (175) with grease and install in shaft (85). Install pin (170) in shaft (85) and peen over shaft material for positive retention at both ends of pin.
- B. Coat mating surfaces of quadrant (80) and shaft (85) with grease; then install quadrant on shaft. Install parts (65, 70, 75).
- C. Install spacer (55) and bearing (35) per 20-50-03 in crank (40).
- D. Install spacer (60), crank (40), and nut (30) on shaft (85). With nut thread and locking insert fully engaged with the shaft thread, measure the max torque to rotate nut. Tighten nut with an additional torque of 100-200 lb-in.
- E. Coat mating surfaces of crank (25) and shaft (85) with grease; then install crank on shaft. Install bolt (10), washer (15) and nut (20).

3. Right hand quadrant (Fig. 702)

- A. Coat bearing shaft (175) with grease and install in shaft (165). Install pin (170) in shaft (165) and peen over shaft material for positive retention at both ends of pin.
- B. Coat mating surfaces of quadrant (160) and shaft (165) with grease; then install quadrant on shaft. Install parts (145, 150, 155).
- C. Coat mating surfaces of crank (140) and shaft (165) with grease; then install crank on shaft. Install bolt (125), washer (130), and nut (135).
- D. Install spacer (110) and bearing (115) per 20-50-03 in crank (95).
- E. Install spacer (120), crank (95), and nut (90) on shaft (165). With nut thread and locking insert fully engaged with the shaft thread, measure the max torque to rotate nut. Tighten nut with an additional torque of 100-200 lb-in.

32-41-2301 ASSEMBLY
Page 701
Apr 10/86




253T3526-2 (LH)

Assembly Details
 Figure 701

32-41-23

ASSEMBLY
 Page 702
 Apr 10/86

01



253T3526-2 (RH)

Assembly Details
 Figure 702

32-41-23

ASSEMBLY
 Page 703
 Apr 10/86

01

209975



ILLUSTRATED PARTS LIST

1. This section lists and illustrates replaceable or repairable component parts. The Illustrated Parts Catalog contains a complete explanation of the Boeing part numbering system.

2. Indentures show parts relationships as follows:

Assembly

Detail Parts for Assembly

Subassembly

Attaching Parts for Subassembly

Detail Parts for Subassembly

Detail Installation Parts (Included only if installation parts may be returned to shop as part of assembly)

3. One use code letter (A, B, C, etc.) is assigned in the EFF CODE column for each variation of top assembly. All listed parts are used on all top assemblies except when limitations are shown by use code letter opposite individual part entries.

4. Letter suffixes (alpha-variants) are added to item numbers for optional parts, Service Bulletin modification parts, configuration differences (except left- and right-hand parts), product improvement parts, and parts added between two sequential item numbers. The alpha-variant is not shown on illustrations when appearance and location of all variants of the part are the same.

5. Service Bulletin modifications are shown by the notations PRE SB XXXX and POST SB XXXX.

A. When a new top assembly part number is assigned by Service Bulletin, the notations appear at the top assembly level only. The configuration differences at detail part level are then shown by use code letter.

B. When the top assembly part number is not changed by the Service Bulletin, the notations appear at the detail part level.

6. Parts Interchangeability

Optional
(OPT)

The parts are optional to and interchangeable with other parts having the same item number.

Supersedes, Superseded By
(SUPSDS, SUPSD BY)

The part supersedes and is not interchangeable with the original part.

Replaces, Replaced By
(REPLS, REPLD BY)

The part replaces and is interchangeable with, or is an alternate to, the original part.

32-41-23

ILLUSTRATED PARTS LIST

01 Page 1001

Apr 10/86

VENDORS

06710 VALLEY-TODECO INCORPORATED
12975 BRADLEY AVENUE
SYLMAR, CALIFORNIA 91342

06725 AIR INDUSTRIES CORPORATION
12570 KNOTT STREET
GARDEN GROVE, CALIFORNIA 92641

06950 VSI CORP SCREWCORP DIV
13001 EAST TEMPLE AVENUE
CITY OF INDUSTRY, CALIFORNIA 91746

08524 DEUTSCH FASTENER CORPORATION
PO BOX 92925 7001 WEST IMPERIAL HIGHWAY
LOS ANGELES, CALIFORNIA 90045

15653 KAYNAR MICRODOT FASTENING SYSTEMS HIGH-TECH DIV
PO BOX 3001 800 SOUTH STATE COLLEGE BLVD
FULLERTON, CALIFORNIA 92634

17943 FEDERAL MANUFACTURING CORPORATION
6910 FARMDALE AVENUE
NORTH HOLLYWOOD, CALIFORNIA 91605

27624 PAUL R BRILES INC P.B. FASTENER DIV
1700 WEST 132ND STREET PO BOX 1157
GARDENA, CALIFORNIA 90249

52828 REPUBLIC FASTENER MFG CORP
1300 RANCHO CONEJO BLVD
NEWBURY PARK, CALIFORNIA 91320

56878 SPS TECHNOLOGIES INC
HIGHLAND AVENUE
JENKINTOWN, PENNSYLVANIA 19046

72962 AMERACE CORP ESNA DIV
2330 VAUXHALL ROAD
UNION, NEW JERSEY 07083

80539 SPS TECHNOLOGIES INC AEROSPACE PRODUCTS DIV
2701 SOUTH HARBOR BOULEVARD PO BOX 1259
SANTA ANA, CALIFORNIA 92702

32-41-23

ILLUSTRATED PARTS LIST
01 Page 1002
Apr 10/86



VENDORS

92215 VOI-SHAN DIV OF VSI CORP SUB OF FAIRCHILD INDUSTRIAL INC
8463 HIGUERA STREET
CULVER CITY, CALIFORNIA 90230


97928 LITTON FASTENING SYSTEMS DIV OF LITTON SYSTEMS INC
3969 PARAMONT BOULEVARD
LAKEWOOD, CALIFORNIA 90712

32-41-23

ILLUSTRATED PARTS LIST

01 Page 1003

Apr 10/86



LH ASSEMBLY

253T3526-1

Main Landing Gear Brake Quadrant Assembly
 Figure 1 (Sheet 1)


32-41-23

ILLUSTRATED PARTS LIST

01

Page 1005

Apr 10/86



RH ASSEMBLY

253T3526-2

Main Landing Gear Brake Quadrant Assembly
 Figure 1 (Sheet 2)

32-41-23

ILLUSTRATED PARTS LIST
 01 Page 1006
 Apr 10/86


BOEING
 COMPONENT
 MAINTENANCE MANUAL

FIG. & ITEM	PART NO.	AIRLINE PART NUMBER	NOMENCLATURE 1234567	EFF CODE	QTY PER ASSY
01- -1	253T3526-1		QUADRANT ASSY - MLG BRAKE (LH)	A	RF
-5	253T3526-2		QUADRANT ASSY - MLG BRAKE (RH)	B	RF
10	BACB30NF4-28		.BOLT- (V06710) (SPEC BACB30NF4-28) (OPT BACB30NF4-28) (V06725,V06950,V08524, V17943,V27624,V56878, V80539,V92215,V97928)	A	1
15	AN960JD416		.WASHER	A	1
20	BRH10C4MD		.NUT- (V52828) (SPEC BACN10JC4CD) (OPT H51650-4BAC (V15653)) (OPT 1022H9075-4W (V72962))	A	1
25	253T3529-3		.CRANK	A	1
30	BACN10RF242		.NUT	A	1
35	MS27646-41G		.BEARING	A	1
40	253T3529-1		.CRANK ASSY	A	1
45	MS27646-41G		..BEARING	A	1
50	253T3529-2		..CRANK	A	1
55	253T3520-6		.SPACER	A	1
60	253T3520-4		.SPACER	A	1
65	BACB30NF4-27		.BOLT- (V06710) (SPEC BACB30NF4-27) (FOR OPTIONAL VENDORS REFER TO ITEM 10)	A	1
70	AN960JD416		.WASHER	A	1
75	BRH10C4MD		.NUT- (V52828) (SPEC BACN10JC4CD) (FOR OPTIONAL PARTS REFER TO ITEM 20)	A	1

32-41-23

ILLUSTRATED PARTS LIST

01

Page 1007

Apr 10/86

**COMPONENT
MAINTENANCE MANUAL**

FIG. & ITEM	PART NO.	AIRLINE PART NUMBER	NOMENCLATURE 1234567	EFF CODE	QTY PER ASSY
01-					
80	253T3528-1		.QUADRANT	A	1
-80A	253T3528-2		.QUADRANT (OPT)	A	1
85	253T3527-1		.SHAFT	A	1
90	BACN10RF242		.NUT	B	1
95	253T3529-1		.CRANK ASSY	B	1
100	MS27646-41G		..BEARING	B	1
105	253T3529-2		..CRANK	B	1
110	253T3520-6		.SPACER	B	1
115	MS27646-41G		.BEARING	B	1
120	253T3520-5		.SPACER	B	1
125	BACB30NF4-28		.BOLT- (V06710) (SPEC BACB30NF4-28) (FOR OPTIONAL PARTS REFER TO ITEM 10)	B	1
130	AN960JD416		.WASHER	B	1
135	BRH10C4MD		.NUT- (V52828) (SPEC BACN10JC4CD) (FOR OPTIONAL PARTS REFER TO ITEM 20)	B	1
140	253T3529-4		.CRANK	B	1
145	BACB30NF4-27		.BOLT- (V06710) (SPEC BACB30NF4-27) (FOR OPTIONAL VENDORS REFER TO ITEM 10)	B	1
150	AN960JD416		.WASHER	B	1
155	BRH10C4MD		.NUT- (V52828) (SPEC BACN10JC4CD) (FOR OPTIONAL PARTS REFER TO ITEM 20)	B	1
160	253T3528-1		.QUADRANT	B	1
160A	253T3528-2		.QUADRANT (OPT)	B	1
165	253T3527-2		.SHAFT	B	1
170	MS39086-150		.PIN, SPRING		1
175	69B81260-1		.SHAFT, BEARING		1

32-41-23

ILLUSTRATED PARTS LIST

01

Page 1008

Apr 10/86