


**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

## Scandinavian Airlines System

PAGE	DATE	CODE	PAGE	DATE	CODE	PAGE	DATE	CODE
CHAPTER 32 TAB			32-FAULT CODE INDEX			32-09-03		
LANDING GEAR			1	MAY 10/96	04	115	DEC 10/98	CONT.
EFFECTIVE PAGES			2	APR 22/99	12	116	NOV 10/96	02
SEE LAST PAGE OF LIST FOR			3	APR 22/99	02	117	AUG 22/00	19
NUMBER OF PAGES			4	MAY 10/96	08	118	MAY 10/95	18
32-CONTENTS			5	APR 22/99	02	119	MAY 10/95	02
1	DEC 22/99	SAS	6	APR 22/99	04	120	AUG 22/07	03
2	DEC 22/99	SAS	7	APR 22/99	04	121	AUG 22/07	01
3	DEC 22/99	SAS	8	DEC 22/01	14	122	NOV 10/95	03
R 4	AUG 22/09	SAS.101	9	APR 22/99	19	123	NOV 10/95	02
5	DEC 22/99	SAS	10	AUG 22/99	17	124	AUG 10/95	01
6	DEC 22/99	SAS	11	APR 22/99	35	125	NOV 10/95	01
7	APR 22/06	SAS	12	AUG 22/02	19	126	NOV 10/95	02
8	APR 22/02	SAS	13	AUG 22/01	19	127	AUG 22/06	03
R 9	AUG 22/09	SAS.1	14	MAY 10/96	18	128	MAY 10/97	02
10	BLANK		32-BITE INDEX			129	APR 22/01	01
32-HOW TO USE THE FIM			1	AUG 22/99	01	130	BLANK	
1	AUG 22/99	01	2	AUG 22/99	01	32-10-00		
2	AUG 22/99	01	3	AUG 22/99	01	101	FEB 10/91	01
3	AUG 22/99	01	4	BLANK		102	FEB 10/91	01
4	AUG 22/99	01	32-09-00			103	FEB 10/91	01
5	AUG 22/99	01	101	AUG 10/96	03	104	BLANK	
6	AUG 22/99	01	102	DEC 22/06	03	32-20-00		
32-INDEX			103	NOV 10/95	02	101	MAY 10/94	01
1	DEC 22/99	09	104	DEC 22/06	02	102	MAY 10/94	01
2	AUG 22/00	17	105	APR 22/06	03	103	MAY 10/94	01
3	AUG 22/00	09	106	APR 22/06	01	104	BLANK	
4	BLANK		107	APR 22/06	01	32-30-00		
32-EICAS MESSAGES			108	NOV 10/95	02	101	DEC 22/04	01
1	FEB 10/91	01	109	APR 10/98	01	102	DEC 22/04	01
2	MAY 10/91	01	110	APR 10/98	01	103	DEC 22/04	01
3	APR 22/03	01	111	APR 22/99	01	104	DEC 22/04	03
4	APR 22/03	01	112	NOV 10/95	02	105	DEC 22/04	01
5	APR 22/03	01	113	AUG 10/96	03	106	DEC 22/04	01
6	DEC 22/00	06	114	AUG 10/96	03	107	DEC 22/04	01
32-FAULT CODE DIAGRAM			115	AUG 10/95	02	108	DEC 22/04	01
1	DEC 22/99	01	116	AUG 22/03	01	109	DEC 22/04	01
2	FEB 10/97	01	117	DEC 10/98	02	110	DEC 22/04	01
3	AUG 22/00	01	118	NOV 10/95	01	111	DEC 22/01	15
4	AUG 10/98	01	119	DEC 22/05	01	112	DEC 22/04	01
5	AUG 22/00	01	120	BLANK		113	DEC 22/04	01
6	AUG 22/00	01	32-09-03			114	NOV 01/83	01
7	AUG 22/00	04	101	APR 22/99	01	115	AUG 22/01	01
8	APR 22/01	01	102	DEC 10/98	01	116	AUG 22/01	01
9	AUG 10/98	01	103	NOV 10/95	02	117	AUG 22/01	01
10	AUG 22/00	03	104	NOV 10/92	01	118	AUG 22/01	01
11	AUG 10/98	02	105	MAY 10/97	04	119	FEB 10/91	01
12	AUG 22/00	04	106	NOV 10/94	01	120	AUG 22/01	01
13	AUG 22/00	05	107	AUG 10/93	01	121	AUG 22/01	01
14	AUG 22/00	05	108	NOV 10/93	01	122	AUG 22/01	01
			109	MAY 10/97	02	123	AUG 22/01	01
			110	DEC 10/98	01	124	AUG 22/01	01
			111	FEB 10/94	03	125	AUG 22/01	02
			112	FEB 10/97	01	126	AUG 22/01	02
			113	AUG 22/08	03	127	AUG 22/01	02
			114	MAY 10/95	04	128	AUG 22/01	02

R = REVISED, A = ADDED OR D = DELETED

F = FOLDOUT PAGE

33

AUG 22/09

# D633T633

CHAPTER 32

EFFECTIVE PAGES

PAGE 1

CONTINUED

 **BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

Scandinavian Airlines System

PAGE	DATE	CODE	PAGE	DATE	CODE	PAGE	DATE	CODE
32-30-00		CONT.	32-42-00		CONT.	32-51-00		CONT.
129	AUG 22/01	02	123	NOV 10/96	07	113	FEB 10/91	02
130	AUG 22/01	02	124	NOV 10/96	01	114	AUG 10/95	02
131	AUG 22/01	02	125	NOV 10/96	01	115	NOV 10/92	02
132	AUG 22/01	02	126	NOV 10/96	01	116	APR 22/00	02
133	AUG 22/01	02	127	NOV 10/96	05	117	FEB 10/91	01
134	AUG 22/01	02	128	AUG 10/98	12	118	BLANK	
135	AUG 22/01	02	129	NOV 10/96	12			
136	AUG 22/01	02	130	APR 22/06	07	32-61-00		
137	AUG 22/01	02	131	NOV 10/96	08	101	NOV 10/95	02
138	AUG 22/01	02	132	NOV 10/96	01	102	APR 22/05	02
139	AUG 22/01	02				103	DEC 22/06	01
140	AUG 22/01	02	32-44-00			104	DEC 22/06	01
141	AUG 22/01	02	101	FEB 10/91	01	105	DEC 22/06	01
142	AUG 22/01	02	102	FEB 10/91	15	106	NOV 10/95	01
143	AUG 22/01	02	103	FEB 10/91	01	107	NOV 10/95	01
144	AUG 22/01	02	104	FEB 10/91	04	108	NOV 10/95	01
145	AUG 22/01	02	105	AUG 22/99	01	109	DEC 22/06	01
146	AUG 22/01	02	106	FEB 10/91	01	110	NOV 10/95	02
147	AUG 22/01	02	107	AUG 22/06	01	111	NOV 10/95	02
148	AUG 10/98	02	108	FEB 10/91	01	112	NOV 10/95	02
			109	AUG 22/99	01	113	DEC 22/02	07
32-41-00			110	AUG 22/99	07	114	APR 22/03	01
101	AUG 10/87	08	111	AUG 22/99	08	R 115	AUG 22/09	11.1
102	AUG 10/87	06	112	APR 22/03	01	116	NOV 10/95	01
103	AUG 01/83	01	113	DEC 22/01	01	117	APR 22/03	01
104	NOV 01/84	02	114	AUG 22/99	01	118	APR 22/03	01
105	MAY 01/84	01				119	APR 22/03	03
106	APR 22/99	01	32-45-00			120	APR 22/03	12
107	APR 22/99	01	101	FEB 10/93	01	121	APR 22/03	10
108	APR 22/99	01	102	AUG 10/97	01	122	BLANK	
109	APR 22/99	01	103	FEB 10/93	02			
110	APR 22/99	03	104	FEB 10/93	02	32-71-00		
111	APR 22/99	01	105	AUG 10/98	SAS	101	NOV 10/93	01
112	APR 22/99	01	106	AUG 10/98	01	102	NOV 01/86	01
			107	AUG 10/98	01	103	AUG 01/86	01
32-42-00			108	BLANK		104	AUG 01/86	01
101	APR 22/05	11				105	AUG 10/91	01
102	APR 22/05	02	32-46-00			106	AUG 10/91	01
103	APR 22/05	01	101	APR 22/02	01	107	AUG 10/95	01
104	FEB 01/87	03	102	APR 22/02	01	108	AUG 10/95	01
105	NOV 10/96	14	103	APR 22/02	01	109	NOV 10/92	01
106	NOV 10/96	02	104	DEC 22/08	02	110	NOV 10/92	01
107	NOV 10/96	02	105	APR 22/02	01			
108	NOV 10/96	01	106	APR 22/02	01			
109	NOV 10/96	03						
110	NOV 10/96	02	32-51-00					
111	NOV 10/96	03	101	APR 22/99	02			
112	NOV 10/96	04	102	DEC 10/98	02			
113	NOV 10/96	02	103	AUG 22/04	02			
114	NOV 10/96	04	104	AUG 22/04	05			
115	NOV 10/96	04	105	APR 22/99	02			
116	NOV 10/96	02	106	FEB 10/91	02			
117	NOV 10/96	02	107	AUG 22/04	02			
118	AUG 10/98	02	108	AUG 22/04	02			
119	AUG 22/06	01	109	FEB 10/91	02			
120	APR 22/05	03	110	FEB 10/91	02			
121	NOV 10/96	11	111	MAY 10/97	02			
122	NOV 10/96	10	112	FEB 10/91	02			

R = REVISED, A = ADDED OR D = DELETED

F = FOLDOUT PAGE

33

AUG 22/09

D633T633

CHAPTER 32

EFFECTIVE PAGES

PAGE 2

LAST PAGE



**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

CHAPTER 32 - LANDING GEAR

TABLE OF CONTENTS

<u>Subject</u>	Chapter Section <u>Subject</u>	<u>Page</u>	<u>Effectivity</u>
HOW TO USE THE FIM	32-HOW TO USE THE FIM	1	ALL
INDEX	32-INDEX	1	ALL
EICAS MESSAGES	32-EICAS MESSAGES	1	ALL
FAULT CODE DIAGRAMS	32-FAULT CODE DIAGRAM	1	ALL
FAULT CODE INDEX	32-FAULT CODE INDEX	1	ALL
BITE INDEX	32-BITE INDEX	1	ALL
<u>LANDING GEAR</u>	32-00-00		
LANDING GEAR MULTIPLE USE SYSTEMS/COMPONENTS	32-09-00		
Component Location		101	ALL
Component Index			
Component Location			
Fault Isolation			
Air/Ground Relay Problem, No AIR/GND DISAGREE or NOSE A/G DISAGREE EICAS Message Display (Fig. 103)		108	
EICAS Msg AIR/GND DISAGREE or AIR/GND SYS Displayed on Gnd (Fig. 103B)		117	
EICAS Msg AIR/GND DISAGREE Displayed Inflt (Fig. 103A)		115	
EICAS Msg NOSE A/G DISAGREE or NOSE A/G SYS Displayed on Gnd (Fig. 103D)		119	
EICAS Msg NOSE A/G DISAGREE Displayed Inflt (Fig. 103C)		118	

32-CONTENTS

SAS

Page 1  
Dec 22/99



**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

CHAPTER 32 - LANDING GEAR

TABLE OF CONTENTS

<u>Subject</u>	Chapter Section <u>Subject</u>	<u>Page</u>	<u>Effectivity</u>
PROXIMITY SWITCH SYSTEM	32-09-03		
Component Location		101	ALL
Component Index			
Component Location			
Fault Isolation			
BITE Procedure for the Proximity Switch electronics Unit (PSEU) (Fig. 103)		105	
BITE Procedure for the PSEU Sensor Target Test (Fig. 104)		114	
EICAS Message PSEU Card Fault Isolation Procedure (Fig. 107)		125	
Proximity Sensor/Wiring Resistance Check (Fig. 105)		120	
Undefined PSEU BITE Codes Appear (Fig. 106)		122	
<u>MAIN LANDING GEAR AND DOORS</u>	32-10-00		
Component Location		101	ALL
Component Index			
Component Location			
<u>NOSE LANDING GEAR AND DOORS</u>	32-20-00		
Component Location		101	ALL
Component Index			
Component Location			



**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

CHAPTER 32 - LANDING GEAR

TABLE OF CONTENTS

<u>Subject</u>	<u>Chapter Section Subject</u>	<u>Page</u>	<u>Effectivity</u>
<u>EXTENSION AND RETRACTION</u>	32-30-00		
Component Location		101	ALL
Component Index			
Component Location			
Fault Isolation			
"Nose" Gear Green DN Lgt Failed to Illum with Gear Handle "DN". Amber "Gear" Lgt is Illum. EICAS Msg "Gear Disagree" Displayed. (Airplane on Ground)		148	
Amber GEAR LGT Illuminated with Landing Gear Control Lever in Down Position. Gear Green Lgts Illuminated (Fig. 111A)		127	
EICAS Msg GEAR DISAGREE Displayed with Gear Handle UP. NOSE Green Dn Lgt Failed to Extin. DOORS Amber Lgt was Extin and GEAR Lgt Illum. (Fig. 115)		133	
EICAS Msg GEAR DOORS and GEAR DISAGREE Displayed with Gear Handle UP. DOORS and Gear Amber Lgts Illum. Gear Green Dn Lgts all Extin. (Fig. 114)		130	
EICAS Msg GEAR DOORS Displayed and DOORS Amber Lgt Illum With Gear Dn (Fig. 105)		117	
EICAS Msg GEAR DOORS Displayed and DOORS Amber Lgt Slow to Extin After Gear Extension (Fig. 105A)		119	
EICAS Msg GEAR DOORS Displayed with Gear UP. DOORS Amber Lgt was Illum and GEAR Lgt Extin. (Fig. 113)		129	
Gear Green Dn Lgt Failed to Extin with Gear Handle UP. EICAS Msg GEAR DISAGREE Displayed. DOORS Amber Lgt was Extin & GEAR Lgt Illum. (Fig. 116)		135	

32-CONTENTS

SAS

Page 3  
Dec 22/99



**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

CHAPTER 32 - LANDING GEAR

TABLE OF CONTENTS

<u>Subject</u>	<u>Chapter Section Subject</u>	<u>Page</u>	<u>Effectivity</u>
Gear Green Dn Lgt Failed to Extin with Gear Handle UP. EICAS Msg GEAR DISAGREE Displayed. DOORS Amber Lgt and GEAR Lgt Illum. (Fig. 116A)		141	
Gear Green Dn Lgt Failed to Illum with Gear Handle DN. EICAS Msg GEAR DISAGREE Displayed. DOORS Amber Lgt was Extin and GEAR Lgt Illum. Alt Gear Ext was Attempted. (Fig. 112)		128	
Gear Green Dn Lgt Failed to Illum with Gear Handle DN. EICAS Msg GEAR DOORS and GEAR DISAGREE Displayed. DOORS and GEAR Amber Lgt Illum. Alt Gear Ext was Attempted. (Fig. 108)		122	
Gear Green Dn Lgt Failed to Illum with Gear Handle DN. EICAS Msg GEAR DISAGREE Displayed. DOORS Amber Lgt was Extin and GEAR Lgt Illum. Indications Norm After Alt Gear Ext. (Fig. 111)		126	
Gear Green Dn Lgt Failed to Illum with Gear Handle DN. EICAS Msg DRAG BRACE Displayed. GEAR Amber Lgt was Illum. (Fig. 109)		124	
Gear Green Dn Lgt Failed to Illum with Gear Handle DN. EICAS Msg SIDE BRACE Displayed. GEAR Amber Lgt was Illum. (Fig. 110)		125	
Gear Lever Would not Move to UP Pos Inflt. Was Free to Move to UP Pos when LOCK OVRD Pushed. (Fig. 104)		115	



**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

CHAPTER 32 - LANDING GEAR

TABLE OF CONTENTS

<u>Subject</u>	<u>Chapter Section Subject</u>	<u>Page</u>	<u>Effectivity</u>
NOSE Gear Green Dn Lgt Failed to Illum with Gear Handle DN. EICAS Msg GEAR DISAGREE Displayed. DOORS Amber Lgt was Extin and GEAR Lgt was Illum. Indications were Norm after Alt Gear Ext. (Fig. 106)		120	
NOSE Gear Green Dn Lgt Failed to Illum with Gear Handle DN. EICAS Msg GEAR DISAGREE Displayed. DOORS Amber Lgt was Illum. Alt Gear Ext was Attempted. (Fig. 107)		121	
<u>WHEELS AND BRAKES</u>	32-40-00		
HYDRAULIC BRAKE SYSTEM	32-41-00		
Component Location		101	ALL
Component Index			
Component Location			
Fault Isolation			
Brake Pressure Bleeds Off with Parking Brake Set, R and C Hyd Sys are Depressurized (Fig. 107)		109	
Brake Pressure Bleeds Off With R and C Hyd Sys Depressurized. (Fig. 108)		110	
Brake Pressure Indicates (Low, Zero) with (R,C,R and C) Hyd Sys Pressurized and BRAKE SOURCE Lgt Extinguished (Fig. 109)		111	
Brake Pressure Indication High, Inop, Sticks, Intermittent, Etc. (Fig. 110)		112	
Brake Pressure Precharge Low (Fig. 105)		107	
BRAKE SOURCE Lgt Fails to Illuminate with No Hyd Pressure from any Source (Fig. 103)		105	

32-CONTENTS

SAS

Page 5  
Dec 22/99



**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

CHAPTER 32 - LANDING GEAR

TABLE OF CONTENTS

<u>Subject</u>	Chapter Section <u>Subject</u>	<u>Page</u>	<u>Effectivity</u>
ANTISKID/AUTOBRAKE SYSTEM	32-42-00		
Component Location		101	ALL
Component Index			
Component Location			
Fault Isolation			
A/G SW Failure Message		123	
Indicated on Display With BIT (Memory Recall) Selected (Antiskid/Autobrake Control Unit BITE Procedure) (Fig. 105)			
Antiskid/Autobrake Control Unit BITE Procedure (Fig. 103)		115	
Autobrake Selector Will Not Latch in RT0 Position with No Fault Indications (Fig. 107)		126	
Autobrake Selector Will Not Latch into Position(s). Antiskid Lgt was Not Illum. (Fig. 106)		125	
Autobrakes Disarmed on Landing Roll (Fig. 111A)		131	
EICAS Msg ALTN ANTISKID Displayed (Fig. 110)		129	
EICAS Msg ANTISKID/AUTOBRK Displayed (Fig. 111)		130	
EICAS Msg NORM ANTISKID Displayed (Fig. 109)		128	
THIS PAGE INTENTIONALLY LEFT BLANK (Fig. 108)		127	
THR SW Failure Message		122	
Indicated on Display With BIT (Memory Recall) Selected (Antiskid/Autobrake Control Unit BITE Procedure) (Fig. 104)			





**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

CHAPTER 32 - LANDING GEAR

TABLE OF CONTENTS

<u>Subject</u>	<u>Chapter Section Subject</u>	<u>Page</u>	<u>Effectivity</u>
PARKING BRAKE SYSTEM	32-44-00		
Component Location		101	ALL
Component Index			
Component Location			
Fault Isolation			
Brake accumulator pressure bleed down rate is too high when the 30 minute brake bleed down test is performed (parking brake released). (Fig. 107)		110	
Brake Accumulator Pressure Bleed Down Rate is Too High When the 30 Minute Brake Bleed Down Test is performed (Parking Brake Set) (Fig. 108)		112	
Parking Brake Cannot Be Set (Fig. 106)		108	
Parking Brake Handle (Loose, Binds, or Hard to Set) (Fig. 103)		105	
Parking Brake Handle Must be Pushed Down to Release Brakes and Extinguish Light (Fig. 106A)		109	
With Park Brake Released, PARK BRAKE Light Remains Illuminated (Fig. 105)		107	
With Park Brake Set, PARK BRAKE Light Remains Extinguished (Fig. 104)		106	
TIRES AND WHEELS	32-45-00		
Component Location		101	[*]
Component Index			
Component Location			
Fault Isolation			
[*] SAS 050-149, 155-999; MTH ALL AIRPLANES			



**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

CHAPTER 32 - LANDING GEAR

TABLE OF CONTENTS

<u>Subject</u>	Chapter Section <u>Subject</u>	<u>Page</u>	<u>Effectivity</u>
BRAKE TEMPERATURE MONITORING SYSTEM	32-46-00		
Component Location		101	[*]
Component Index			
Component Location			
Fault Isolation			
Brake Temp Indications Blank, Intermittent, or Zero, or High with BRAKE TEMP Light Illuminated. (Fig. 103)		104	
Brake Temperature Monitoring System BITE Procedure (Fig. 104)		105	
[*] AIRPLANES WITH BRAKE TEMPERATURE MONITORING SYSTEM			
<u>STEERING</u>	32-50-00		
NOSE WHEEL STEERING SYSTEM	32-51-00		
Component Location		101	ALL
Component Index			
Component Location			
Fault Isolation			
Airplane Pulls L/R During Taxi (Fig. 109A)		116	
Nose Wheel Not Centered With Tiller Indicator Centered (Fig. 109)		115	
Nose Wheel Vibrates On (Takeoff/Landing) (Fig. 104)		107	
Tiller Steering Forces High (Fig. 108)		114	
Tiller Steering Inop (Fig. 105)		109	
Tiller Steering Response Sluggish (Fig. 107)		113	
Tiller Steers Left or Right Direction Only (Fig. 106)		112	




**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

CHAPTER 32 - LANDING GEAR

TABLE OF CONTENTS

<u>Subject</u>	<u>Chapter Section Subject</u>	<u>Page</u>	<u>Effectivity</u>
<u>POSITION AND WARNING</u>	32-60-00		
LANDING GEAR POSITION INDICATING AND WARNING SYSTEM	32-61-00		
Component Location		101	ALL
Component Index			
Component Location			
Fault Isolation			
EICAS Msg LDG GEAR MONITOR Displayed (Fig. 104)		113	
Gear Green Dn Lgt Failed to Extin with Gear handle UP. DOORS and GEAR Amber Lgts Extin. EICAS Msg Not Displayed (Fig. 105)		119	
GEAR Amber Light Failed to Illum During Gear Extension or Retraction (Fig. 103)		112	
LEFT, RIGHT, NOSE Gear Green Dn Light Flickers After Gear Retraction (Fig. 105A)		120	
<u>SUPPLEMENTARY GEAR</u>	32-70-00		
TAIL SKID SYSTEM	32-71-00		
Component Location		101	[*]
Component Index			
Component Location			
Fault Isolation			
TAIL SKID Displayed on EICAS, and TAIL SKID Light Illuminated (Fig. 103)		105	
[*] 767-300 AIRPLANES			



Basic Fault Isolation Process  
Figure 1


EFFECTIVITY

ALL

## 32-HOW TO USE THE FIM

01

Page 1  
Aug 22/99



How to Get Fault Information from BITE  
Figure 2


EFFECTIVITY

ALL

## 32-HOW TO USE THE FIM

01

Page 2  
Aug 22/99



How to Find the Corrective Action or Fault Isolation Procedure in the FIM

Figure 3

EFFECTIVITY

ALL

## 32-HOW TO USE THE FIM

01

Page 3  
Aug 22/99

 **BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

ASSUMED CONDITIONS AT START OF TASK

- External electrical power is OFF
- Hydraulic power and pneumatic power are OFF
- Engines are shut down
- Circuit breakers for the system are closed
- No equipment in the system is deactivated

PREREQUISITES

- This box gives the steps to get the airplane from the normal shutdown condition to the configuration necessary to do the fault isolation procedure.
- The Prerequisites give procedure references, circuit breakers, and special tools and equipment requirements.

FAULT ISOLATION BLOCKS

- Start the fault isolation procedure at block 1 unless specified differently.
- Do the check to get an answer to the question in the box. Follow the arrow that applies to your answer. This will go to the next check.
- When you get to a box in the column at the right of the page, you have isolated that fault. Do the steps in that box to repair the cause of the fault.
- Make sure that fault is corrected to complete the procedure.

Do the Fault Isolation Procedure  
Figure 4


EFFECTIVITY

ALL

**32-HOW TO USE THE FIM**

01

Page 4  
Aug 22/99




Subjects in Each FIM Chapter  
Figure 5 (Sheet 1)

EFFECTIVITY  ALL	<h1 style="margin: 0;">32-HOW TO USE THE FIM</h1> <p align="right">01      Page 5 Aug 22/99</p>
------------------------	---

K37686






Alphabetical list of the EICAS messages. Gives the procedure to repair the cause of the message or a reference to a fault isolation procedure.

Failure analysis diagrams for the airplane systems to find the correct fault code for the fault.


Numerical list of fault codes. Gives the procedure to repair the cause of the fault or a reference to a fault isolation procedure.



Alphabetical list of all the LRUs/systems that have BITE. Gives the chapter/section for the BITE procedure.

Component index, component location, and fault isolation procedures for the systems in the chapter.

Subjects in Each FIM Chapter  
Figure 5 (Sheet 2)



# 32-HOW TO USE THE FIM




**LANDING GEAR**

<u>EICAS MESSAGES</u>	<u>CHAP/SEC</u>
AIR/GRD DISAGREE .....	3209
AIR/GRD SYS .....	3209
ANTISKID .....	3242, 3244
(ALTN, NORM) ANTISKID .....	3242
AUTOBRAKES .....	3242
BRAKE SOURCE .....	3241
(L, R) DRAG BRACE .....	3230
GEAR DISAGREE .....	3230
GEAR DOORS .....	3230
GEAR NOT DOWN .....	3151
LDG GEAR MONITOR .....	3230, 3261
NOSE A/G DISAGREE .....	3209
NOSE A/G SYS .....	3209
PARKING BRAKE .....	3244
RSV BRAKE VAL .....	2911
(L, R) SIDE BRACE .....	3230
TAILSKID .....	3271
TIRE PRESSURE .....	3245


**LANDING GEAR – CONTENTS**

EFFECTIVITY	ALL
-------------	-----


32-INDEX



CAPT'S PANEL




OVERHEAD PANEL





PILOTS' CENTER PANEL





ACCESSORY PANEL 2911




F/O'S PANEL




PILOTS' CENTER PANEL




CAPTAIN'S/FO'S SIDEWALL



CONTROL STAND




EICAS STATUS



RUDDER PEDALS

1 AS INSTALLED


**LANDING GEAR - INDEX**



**32-INDEX**

<u>TITLE</u>	<u>CHAP/SEC</u>
AIR/GRD RELAY.....	3209
ANTISKID.....	3242
AUTO BRAKES.....	3242
BRAKE PRESSURE SOURCE.....	3241
BRAKING/BRAKE TEMPERATURE.....	3241,3246
GEAR EXTENSION.....	3230
GEAR RETRACTION.....	3230
LEVER LATCH.....	3230
LIGHT BULBS.....	LIGHTS
NOSE WHEEL AND STEERING.....	3251
PARKING BRAKE.....	3244
TAIL SKID.....	3271
TIRE PRESSURE.....	3245
UNCOMMANDED MAIN LANDING GEAR EXTENSION.....	3230

LANDING GEAR – INDEX



**32-INDEX**

LANDING GEAR – EICAS MESSAGE LIST

1. General

- A. This procedure shows the EICAS message locations and gives a list of procedures to find the solution for each message.
- (1) EICAS Message Locations (Fig. 1)
    - (a) Figure 1 shows the location of the EICAS display units and the area where the messages show on the display units.
    - (b) Each message level has a different location. The location and color of each message level is also shown.
  - (2) The EICAS MESSAGE LIST gives the message, level, and procedure for each message.
    - (a) The EICAS MESSAGE column lists the messages alphabetically. Messages which start with L, R, or C are put together and alphabetized at L.
    - (b) The LEVEL column gives all levels for each message as follows:
      - A – Warning messages
      - B – Caution messages
      - C – Advisory messages
      - S – Status messages
      - M – Maintenance messages
    - (c) The PROCEDURE column gives the steps that are necessary to remove the message and includes one or more of the procedures that follow:
      - 1) A Fault Isolation Manual procedure reference
      - 2) A Maintenance Manual procedure and reference
      - 3) Wiring checks and a Wiring Diagram Manual reference
      - 4) A reference to an EICAS message list in a different chapter.
      - 5) A reference to a FAULT CODE INDEX and specified fault codes
      - 6) A step to change the airplane configuration

EFFECTIVITY



ALL

## 32-EICAS MESSAGES


01

Page 1  
Feb 10/91


**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL



ENGINE PRIMARY PAGE OR COMPACTED PAGE  
(TOP DISPLAY UNIT)




ECS/MSG PAGE  
(BOTTOM DISPLAY UNIT)



STATUS PAGE  
(BOTTOM DISPLAY UNIT)

LEVEL	COLOR
A-WARNING	RED
B-CAUTION	YELLOW
C-ADVISORY	YELLOW
S-STATUS	WHITE
M-MAINTENANCE	WHITE

EICAS Message Locations  
Figure 1



# 32-EICAS MESSAGES


**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

EICAS MESSAGE LIST		
EICAS MESSAGE	LEVEL	PROCEDURE
AIR/GND DISAGREE	S,M	FIM 32-09-00/101, Fig. 103A (Displayed in flight) or FIM 32-09-00/101, Fig. 103B (Displayed on the ground).
AIR/GND SYS	C	FIM 32-09-00/101, Fig. 103B
ALL GEAR DOWN	M	FIM 32-09-03/101, Fig. 103, FIM 32-61-00/101, Fig. 104, as applicable.
ALT ANTISKID	S,M	FIM 32-42-00/101, Fig. 110
ANTISKID	C	The ANTISKID EICAS message is always shown with one of the messages that follow: ALT ANTISKID (S,M) NORM ANTISKID (S,M) ANTISKID/AUTOBRK (M) PARKING BRAKE (C) Find the related message and do the procedure for that message.
ANTISKID/AUTOBRK	M	FIM 32-42-00/101, Fig. 111
ANTISKID OFF	C	AIRPLANES WITH ANTISKID ON/OFF SWITCH; make sure the switch (Yaw Damper Panel, P5) is in the "ON" position.  ALL AIRPLANES; if the EICAS message stays on, do the procedure in FIM 32-42-00/101, Fig. 103.
AUTOBRAKES	C	FIM 32-42-00/101, Fig. 103, FIM 32-42-00/101, Fig. 111A as applicable

EFFECTIVITY

ALL

## 32-EICAS MESSAGES

01

Page 3  
Apr 22/03


**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

EICAS MESSAGE LIST		
EICAS MESSAGE	LEVEL	PROCEDURE
BRAKE SOURCE	C	FIM 32-41-00/101, Fig. 103, FIM 32-41-00/101, Fig. 104 FIM 32-41-00/101, Fig. 105 FIM 32-41-00/101, Fig. 106 FIM 32-41-00/101, Fig. 107 FIM 32-41-00/101, Fig. 108 FIM 32-41-00/101, Fig. 109 as applicable.
GEAR DISAGREE (Without GEAR DOORS Msg.)	B	FIM 32-30-00/101, Fig. 106 or 107 FIM 32-30-00/101, Fig. 111 or 112 FIM 32-30-00/101, Fig. 115 FIM 32-30-00/101, Fig. 116 or FIM 32-30-00/101, Fig. 116A as applicable FIM 32-30-00/101, Fig. 117
GEAR DISAGREE	M	FIM 32-09-03/101, Fig. 103, FIM 32-61-00/101, Fig. 104, as applicable.
GEAR DOORS (With GEAR DISAGREE B-Level Msg.)	C	FIM 32-30-00/101, Fig. 108 FIM 32-30-00/101, Fig. 114 as applicable
GEAR DOORS (Without GEAR DISAGREE B-Level Msg.)	C	With the control lever for the landing gear DN: FIM 32-30-00/101, Fig. 105 or FIM 32-30-00/101, Fig. 105A FIM 32-30-00/101, Fig. 113 as applicable

EFFECTIVITY

ALL

## 32-EICAS MESSAGES

01

Page 4  
Apr 22/03





**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

EICAS MESSAGE LIST		
EICAS MESSAGE	LEVEL	PROCEDURE
GEAR DOORS	M	FIM 32-61-00/101, Fig. 104.
(L,R) DRAG BRACE	B	FIM 32-30-00/101, Fig. 109
(L,R) DRAG BRACE	M	FIM 32-09-03/101, Fig. 104 for the drag brace down sensors S237 (S241) and S259 (S263), FIM 32-61-00/101, Fig. 104
LDG GEAR MONITOR	S	FIM 32-61-00/101, Fig. 104
(L,R) SIDE BRACE	B	FIM 32-30-00/101, Fig. 110
(L,R) SIDE BRACE	M	FIM 32-09-03/101, Fig. 104 for the side brace down sensors S236 (S240) and S258 (S262), FIM 32-61-00/101, Fig. 104, as applicable.
NORM ANTISKID	S,M	FIM 32-42-00/101, Fig. 109
NOSE A/G DISAGREE	S,M	FIM 32-09-00/101, Fig. 103C (displayed in flight) or FIM 32-09-00/101, Fig. 103D (displayed on the ground).
NOSE A/G SYS	C	FIM 32-09-00/101, Fig. 103D
NOSE GEAR DOWN	M	FIM 32-09-03/101, Fig. 104 for the nose gear down sensors S232 and S254, FIM 32-61-00/101, Fig. 104, FIM 32-61-00/101, Fig. 104A as applicable.
NOSE GEAR DOWN	M	FIM 32-09-03/101, Fig. 104 for the nose gear down sensors S232 and S254, FIM 32-61-00/101, Fig. 104.
NOSE GEAR LOCKED	M	FIM 32-09-03/101, Fig. 104 for the nose gear locked sensors S233 and S255, FIM 32-61-00/101, Fig. 104.

EFFECTIVITY

ALL

## 32-EICAS MESSAGES

01

Page 5  
Apr 22/03



**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

EICAS MESSAGE LIST		
EICAS MESSAGE	LEVEL	PROCEDURE
PARK BRAKE	C	FIM 32-44-00/101, Fig. 104 or FIM 32-44-00/101, Fig. 105 as applicable.
TAIL SKID	C	FIM 32-71-00/101, Fig. 103
TIRE PRESSURE	S	<p>If all tire pressures indicate normal, do a system test of the indication system for pressure: AMM 32-45-00/501</p> <p>If tire pressure indicating system synoptic display shows low pressure for any of the tires, 1 thru 10, do the tire servicing for the tire(s) that have low pressure: AMM 12-15-03/301</p>
TIRE PRESS SYS	M (NVM)	<p>If all tire pressures indicate normal, do a system test of the indication system for pressure: AMM 32-45-00/501</p>

EFFECTIVITY

ALL
-----

## 32-EICAS MESSAGES



APPLICABLE CIRCUIT BREAKERS AS INSTALLED



11C30	POSITION AIR/GND SYS 1
11T36	TEST PROX SW
11T36	PROX SW TEST
11U15	AIR/GND SYS 1
11U23	POSITION AIR/GND SYS 2
11U24	POSITION AIR/GND SYS 2

AIR/GROUND RELAY – FAULT CODES

EFFECTIVITY	ALL
-------------	-----

# 32-FAULT CODE DIAGRAM

## PILOTS' CENTER PANEL


 FAULT CODE/  
LOCATION


## APPLICABLE CIRCUIT BREAKERS AS INSTALLED

11C30	POSITION AIR/GND SYS 1
11T36	TEST PROX SW
11U15	AIR/GND SYS 1

11U20	LEVER LOCK
11U23	POSITION AIR/GND SYS 2
11U24	POSITION AIR/GND SYS 2

## LEVER LATCH - FAULT CODES

EFFECTIVITY

ALL

**32-FAULT CODE DIAGRAM**


01

 Page 2  
Feb 10/97

# BOEING

## 767

### FAULT ISOLATION/MAINT MANUAL



**APPLICABLE CIRCUIT BREAKERS AS INSTALLED**

6F6	ALTN EXT MOTOR		
6F7	ALTN EXT MOTOR	11U23	POSITION AIR/GND SYS 2
11C30	POSITION AIR/GND SYS 1	11U24	POSITION AIR/GND SYS 2

**GEAR EXTENSION - FAULT CODES**

EFFECTIVITY

ALL

## 32-FAULT CODE DIAGRAM


01

Page 3  
Aug 22/00

# BOEING

## 767

### FAULT ISOLATION/MAINT MANUAL



1 IF LGT BULB INOP, SEE "LIGHTS" CHAPTER.

APPLICABLE CIRCUIT BREAKERS AS INSTALLED

11C30	POSITION AIR/GND SYS 1
11U23	POSITION AIR/GND SYS 2
11U24	POSITION AIR/GND SYS 2

### LANDING GEAR EXT/RET - FAULT CODES (GROUND)


EFFECTIVITY

ALL

## 32-FAULT CODE DIAGRAM

01

Page 4  
Aug 10/98



1 GEAR SHOULD RETRACT AND DOORS CLOSE WITHIN 14 SEC. IF INOP ADP IS CAUSE OF SLOW RETRACTION, SEE HYDRAULIC CHAPTER "ADP (AIR DRIVEN PUMP)" FAULT CODES.

**APPLICABLE CIRCUIT BREAKERS**

11C30 POSITION AIR/GND SYS 1  
11U23 POSITION AIR/GND SYS 2

11U24 POSITION AIR/GND SYS 2

**GEAR RETRACTION – FAULT CODES**

EFFECTIVITY

ALL

**32-FAULT CODE DIAGRAM**

01


Page 5  
Aug 22/00



767

FAULT ISOLATION/MAINT MANUAL


PILOTS' CENTER PANEL



FAULT CODE/ LOCATION

LEFT	01
RIGHT	02
BOTH	03

WITH GEAR LEVER OFF, DID GEAR DOWN LIGHT(S) ILLUM?




REPORT ANY FAULT SYMPTOM OR PATTERN NOT SHOWN ABOVE → 32 30 XD --

APPLICABLE CIRCUIT BREAKERS

11C30	POSITION AIR/GND SYS 1
11U23	POSITION AIR/GND SYS 2
11U24	POSITION AIR/GND SYS 2

UNCOMMANDED MAIN LANDING GEAR EXTENSION - FAULT CODES




32-FAULT CODE DIAGRAM

01

Page 6  
Aug 22/00





APPLICABLE CIRCUIT BREAKERS

6F4	PARKING BRAKE VLV	11U18	ANTISKID 1 - 5
11C31	ANTISKID 2 - 6	11U27	ANTISKID 4 - 8
11C32	ANTISKID 3 - 7		

ANTISKID - FAULT CODES

EFFECTIVITY


ALL

## 32-FAULT CODE DIAGRAM

04

Page 7  
Aug 22/00

**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL



**AUTO BRAKES - FAULT CODES**


EFFECTIVITY

ALL

# 32-FAULT CODE DIAGRAM

01

Page 8  
Apr 22/01



APPLICABLE CIRCUIT BREAKERS AS INSTALLED

6F4 PARKING BRAKE VLV

**PARKING BRAKE - FAULT CODES**

EFFECTIVITY

ALL

**32-FAULT CODE DIAGRAM**


01

Page 9  
Aug 10/98

# BOEING

## 767

### FAULT ISOLATION/MAINT MANUAL



APPLICABLE CIRCUIT BREAKERS AS INSTALLED

6F4	PARKING BRAKE VLV	11L15	ELEC PUMP CTR 1	11U22	BRAKE PRESS
		11L15	ELEC PUMP C1		

### BRAKE PRESSURE SOURCE - FAULT CODES

EFFECTIVITY


ALL

## 32-FAULT CODE DIAGRAM

03

Page 10  
Aug 22/00

**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL



APPLICABLE CIRCUIT BREAKERS

NONE

**NOSE WHEEL AND STEERING – FAULT CODES**

EFFECTIVITY

ALL

# 32-FAULT CODE DIAGRAM


02

Page 11  
Aug 10/98

# BOEING

## 767

### FAULT ISOLATION/MAINT MANUAL



NOTE: BRAKE LOCATION

L	R
<input type="checkbox"/>	<input type="checkbox"/>
1 2	3 4
<input type="checkbox"/>	<input type="checkbox"/>
5 6	7 8

APPLICABLE CIRCUIT BREAKERS

11U16

### BRAKING AND BRAKE TEMPERATURE - FAULT CODES


EFFECTIVITY

ALL

## 32-FAULT CODE DIAGRAM

04

Page 12  
Aug 22/00



APPLICABLE CIRCUIT BREAKERS

11U26 TAIL SKID CONT


TAIL SKID - FAULT CODES

EFFECTIVITY

---

ALL


## 32-FAULT CODE DIAGRAM



**APPLICABLE CIRCUIT BREAKERS**

11U17 TIRE PRESS IND 1

**TIRE POSITIONS**



**TIRE PRESSURE – FAULT CODES**

EFFECTIVITY  
AIRPLANES WITH TIRE PRESSURE INDICATION

**32-FAULT CODE DIAGRAM**

L41990





**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
32 09 XA 00	1. The flight crew found a problem with an air ground relay which is not included in the fault code diagrams. (Ref Fault Code Diagram for the flight crew procedures.) 2. SSM 32-09-02
32 30 XA --	1. A (01=LEFT, 02=RIGHT) gear extension problem occurred which is not included in the fault code diagrams. (Ref Fault Code Diagram for the flight crew procedures.) 2. SSM 32-30-01
32 30 XB --	1. A (01=LEFT, 02=RIGHT, 03=NOSE) gear retraction problem occurred which is not included in the fault code diagrams. (Ref Fault Code Diagram for the flight crew procedures.) 2. SSM 32-30-01
32 30 XC 00	1. The flight crew found a problem with the lever latch which is not included in the fault code diagrams. (Ref Fault Code Diagram for the flight crew procedures.) 2. SSM 32-30-01
32 30 XD --	1. A (01=LEFT, 02=RIGHT, 03=BOTH) main gear uncommanded extension problem occurred that is not included in the fault code diagrams. (Ref Fault Code Diagram for the flight crew procedures.) 2. SSM 32-30-01
32 41 XA 00	1. The flight crew found a problem with the brake pressure source which is not included in the fault code diagrams. (Ref Fault Code Diagram for the flight crew procedures.) 2. SSM 32-41-01
32 42 XA 00	1. The flight crew found an antiskid problem which is not included in the fault code diagrams. (Ref Fault Code Diagram for the flight crew procedures.) 2. SSM 32-42-01 (left) or SSM 32-42-02 (right)
32 42 XB --	1. An (01=1, 02=2, 03=3, 04=4, 05=MAX AUTO) auto brake problem occurred which is not included in the fault code diagrams. (Ref Fault Code Diagram for the flight crew procedures.) 2. SSM 32-42-03
32 44 XA 00	1. The flight crew found a problem with the parking brake which is not included in the fault code diagrams. (Ref Fault Code Diagram for the flight crew procedures.) 2. SSM 32-41-01

EFFECTIVITY

ALL

## 32-FAULT CODE INDEX

04

Page 1  
May 10/96


**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
32 45 XA --	1. Tire pressure symptoms/patterns (01=1, 02=2, 03=3, 04=4, 05=5, 06=6, 07=7, 08=8, 09=L NOSE, 10=R NOSE) occurred again. 2. Make an analysis of the symptoms/patterns and do the procedure to correct the problem, if it is necessary.
32 46 XA --	1. A (01=1, 02=2, 03=3, 04=4, 05=5, 06=6, 07=7, 08=8, 09=L, 10=R) brake temperature problem occurred which is not included in the fault code diagrams. (Ref Fault Code Diagram for the flight crew procedures.) 2. SSM 32-46-01
32 51 XA --	1. A (04=Capt, 05=F/O, 06=Capt & F/O) nose wheel steering problem occurred which is not included in the fault code diagrams. (Ref Fault Code Diagram for the flight crew procedures.) 2. SSM 32-51-01
32 71 XA 00	1. The flight crew found a problem with the tail skid which is not included in the fault code diagrams. (Ref Fault Code Diagram for the flight crew procedures.) 2. SSM 32-71-01
32 09 01 00	1. EICAS msg AIR/GND DISAGREE displayed inflt. 2. FIM 32-09-00/101, Fig. 103A, Block 1
32 09 02 00	1. EICAS msg AIR/GND DISAGREE displayed on gnd. 2. FIM 32-09-00/101, Fig. 103B, Block 1
32 09 03 00	1. EICAS msg NOSE A/G DISAGREE displayed inflt. 2. FIM 32-09-00/101, Fig. 103C, Block 1
32 09 04 00	1. EICAS msg NOSE A/G DISAGREE displayed on gnd. 2. FIM 32-09-00/101, Fig. 103D, Block 1

EFFECTIVITY

ALL

## 32-FAULT CODE INDEX



**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
32 09 05 00	1. EICAS msg AIR/GND SYS displayed. 2. FIM 32-09-00/101, Fig. 103B, Block 1
32 09 06 00	1. EICAS msg NOSE A/G SYS displayed. 2. FIM 32-09-00/101, Fig. 103D, Block 1
32 30 01 00	1. EICAS msg GEAR DOORS displayed & DOORS amber lgt illum with gear dn. Msg and light remain illuminated after landing. 2. FIM 32-30-00/101, Fig. 105, Block 1
32 30 02 00	1. NOSE gear green dn lgt failed to illum with gear handle DN. EICAS msg GEAR DISAGREE displayed. DOORS amber lgt was extin & GEAR lgt was illum. Indications were norm after altn gear extension. 2. FIM 32-30-00/101, Fig. 106, Block 1
32 30 03 00	1. NOSE gear green dn lgt failed to illum with gear handle DN. EICAS msg GEAR DISAGREE displayed. DOORS amber lgt was extin & GEAR lgt was illum. Altn gear extension was attempted. 2. FIM 32-30-00/101, Fig. 107, Block 1
32 30 04 --	1. (01=LEFT, 02=RIGHT) gear green dn lgt failed to illum with gear handle DN. EICAS msg GEAR DOORS & GEAR DISAGREE displayed. DOORS & GEAR amber lgts illum. Altn gear extension was attempted. 2. FIM 32-30-00/101, Fig. 108, Block 1
32 30 05 --	1. (01=LEFT, 02=RIGHT) gear green dn lgt failed to illum with gear handle DN. EICAS msg DRAG BRACE displayed. GEAR amber lgt was illum. 2. FIM 32-30-00/101, Fig. 109, Block 1
32 30 06 --	1. (01=LEFT, 02=RIGHT) gear green dn lgt failed to illum with gear handle DN. EICAS msg SIDE BRACE displayed. GEAR amber lgt was illum. 2. FIM 32-30-00/101, Fig. 110, Block 1
32 30 07 --	1. (01=LEFT, 02=RIGHT) gear green dn lgt failed to illum with gear handle DN. EICAS msg GEAR DISAGREE displayed. DOORS amber lgt was extin & GEAR lgt illum. Indications norm after altn gear extension. 2. FIM 32-30-00/101, Fig. 111, Block 1

EFFECTIVITY

ALL

## 32-FAULT CODE INDEX

02

Page 3  
Apr 22/99


**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
32 30 08 --	1. (O1=LEFT, O2=RIGHT) gear green dn lgt failed to illum with gear handle DN. EICAS msg GEAR DISAGREE displayed. DOORS amber lgt was extin & GEAR lgt illum. Altn gear extension was attempted. 2. FIM 32-30-00/101, Fig. 112, Block 1
32 30 09 00	1. EICAS msg GEAR DOORS displayed with gear handle UP. DOORS amber lgt was illum & GEAR lgt extin. 2. FIM 32-30-00/101, Fig. 113, Block 1
32 30 10 00	1. EICAS msg GEAR DOORS & GEAR DISAGREE displayed with gear handle UP. DOORS & GEAR amber lgts illum. Gear green dn lgts all extin. 2. FIM 32-30-00/101, Fig. 114, Block 1
32 30 11 00	1. EICAS msg GEAR DISAGREE displayed with gear handle UP. NOSE green dn lgt failed to extin. DOORS amber lgt was extin & GEAR lgt illum. 2. FIM 32-30-00/101, Fig. 115, Block 1
32 30 12 --	1. (O1=LEFT, O2=RIGHT) gear green dn lgt failed to extin with gear handle UP. EICAS msg GEAR DISAGREE displayed. DOORS amber lgt was extin & GEAR lgt illum. 2. FIM 32-30-00/101, Fig. 116, Block 1
32 30 13 00	1. EICAS msg GEAR DISAGREE displayed and GEAR amber lgt illum with gear green down lgts illum. 2. Make sure the control lever for the landing gear is fully in the DN detent. If EICAS message and the amber light stay on, replace the control lever module, M937 (AMM 32-31-01/401).
32 30 14 00	1. Landing gear slow, took ____ sec (over 14 sec) to retract. 2. Make sure the door-operated sequence valve for the (L, R) main landing gear is adjusted correctly. If the adjustment is correct, replace the retract actuator for the (L, R) main landing gear or nose landing gear if it is necessary (AMM 32-32-01/401 or AMM 32-34-01/401).
32 30 15 00	1. Landing gear doors slow to close on gear retraction. 2. Make sure the gear-operated sequence valve for the (L, R) main landing gear is adjusted correctly. If the adjustment is correct, replace the door actuator for the (L, R) main landing gear (AMM 32-32-12/401).

EFFECTIVITY

ALL

## 32-FAULT CODE INDEX

08

Page 4  
May 10/96



**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
32 30 16 00	<ol style="list-style-type: none"> <li>EICAS msg GEAR D00R displayed and D00RS amber lgt illum with gear dn. Msg and lgt extinguish after landing.</li> <li>Examine the sensors and targets for the nose and main landing gear doors to make sure they are tight. Tighten or replace them if it is necessary. Clean the target and the surface of the sensor (AMM 32-61-02/201 and AMM 32-61-03/201).</li> </ol>
32 30 17 00	<ol style="list-style-type: none"> <li>EICAS msg GEAR D00RS displayed and D00RS amber lgt slow to extinguish after gear extension.</li> <li>FIM 32-30-00/101, Fig. 105A, Block 1</li> </ol>
32 30 18 00	<ol style="list-style-type: none"> <li>Gear lever would not move to UP pos inflt. Was free to move to UP pos when LOCK OVRD pushed.</li> <li>FIM 32-30-00/101, Fig. 104, Block 1</li> </ol>
32 30 19 --	<ol style="list-style-type: none"> <li>(O1=L, O2=R) gear green dn lgt failed to extin with gear handle UP. EICAS msg GEAR DISAGREE displayed. D00RS amber lgt and GEAR lgt illum.</li> <li>FIM 32-30-00/101, Fig. 116A, Block 1</li> </ol>
32 30 20 --	<ol style="list-style-type: none"> <li>(O1=L, O2=R) main landing gear extended with gear lever OFF, gear down lights illum.</li> <li>Do a check of the adjustment of the main landing gear doors and latch hook (AMM 32-12-00/501). Make sure the clearance between the bottom of the roller and the bottom of the hook is approximately the same for the left and right main landing gear doors. Do a check of the adjustment and operation of the selector valves (AMM 32-31-00/501). Examine filters and fuses for the center hydraulic system for possible contamination or debris. Do a check of the adjustment of the door-operated and the gear-operated sequence valves (AMM 32-32-00/501) and make sure the cam box installation is correct. Do the PSEU BITE procedure (FIM 32-09-03/101, Fig. 103, Block 1).</li> </ol>
32 30 21 00	<ol style="list-style-type: none"> <li>Nose Gear green dn lgt failed to Illum with gear handle DN. GEAR amber lgt illum. EICAS msg GEAR DISAGREE displayed. (Airplane on ground)</li> <li>FIM 32-30-00/101, Fig. 117, Block 1</li> </ol>
32 41 01 00	Not Used
32 41 02 00	Not Used

EFFECTIVITY

ALL

## 32-FAULT CODE INDEX

02

Page 5  
Apr 22/99


**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
32 41 03 00	1. BRAKE SOURCE lgt fails to illuminate with no hyd pressure from any source. 2. FIM 32-41-00/101, Fig. 103, Block 1
32 41 04 00	1. BRAKE SOURCE lgt remains illuminated with right hyd sys pressurizing brakes. 2. FIM 32-41-00/101, Fig. 104, Block 1
32 41 05 00	1. BRAKE SOURCE light illuminated with center hyd sys pressurizing brakes. 2. FIM 32-41-00/101, Fig. 104, Block 1
32 41 06 00	1. Brake pressure precharge low _____ PSI. 2. FIM 32-41-00/101, Fig. 105, Block 1
32 41 07 00	1. Brake pressure bleeds off with C hyd sys pressurized and R sys off. 2. FIM 32-41-00/101, Fig. 106, Block 1
32 41 08 00	1. Brake pressure bleeds off with parking brake set. Hyd sys R and C were depressurized. 2. FIM 32-41-00/101, Fig. 107, Block 1
32 41 09 00	1. Brake press bleeds off with R and C hyd sys depressurized. Parking brake was rel. 2. FIM 32-41-00/101, Fig. 108, Block 1
32 41 10 00	1. Brake press indicates (low, zero) with (R, C, R and C) hyd sys pressurized and BRAKE SOURCE lgt extin. 2. FIM 32-41-00/101, Fig. 109, Block 1
32 41 11 --	1. Brakes grabbing. No. (07=1, 08=2, 09=3, 10=4, 11=5, 12=6, 13=7, 14=8) brake temp high, _____. (Max level) 2. Replace the brake that has the high temperature indication (AMM 32-41-08/401).
32 41 12 --	1. Brakes grabbing. (01=L, 02=R) brake temps high, _____. (Max level) 2. Bleed the hydraulic system for the brake to remove all the air caught in the lines (AMM 32-41-00/201). If the problem continues, do a test of the brake system (AMM 32-41-00/501).

EFFECTIVITY

ALL

## 32-FAULT CODE INDEX

04

Page 6  
Apr 22/99


**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
32 41 13 --	1. (01=L, 02=R) brakes grabbing. Brake temp normal. 2. Do the operational test of the brake system (AMM 32-41-00/501).  <u>NOTE:</u> At low speeds, the correct system sensitivity can cause the brakes to not engage smoothly.
32 41 14 --	1. Brakes (drag/locked), No. (07=1, 08=2, 09=3, 10=4, 11=5, 12=6, 13=7, 14=8) brake temp high, _____. (Max level) 2. Examine the brake that has the high temperature indication. See if it can move freely or if there is damage or adjuster assemblies that are not there (AMM 32-41-08/401).
32 41 15 --	1. Brakes (drag/locked), (01=L, 02=R) brake temp high, _____. (Max level) 2. Do the test on the brake system. Make sure the control system moves freely (AMM 32-41-00/501). If the brakes do not release fully, make sure there is no back pressure in the system caused by incorrect adjustment or a defective brake metering valve (AMM 32-41-03/401).
32 41 16 --	1. Airplane pulls to (R/L) during braking. No. (01=1, 02=2, 03=3, 04=4, 05=5, 06=6, 07=7, -8=8) brake temp high, _____. (Max level) 2. Replace the brake that has the high temperature indication (AMM 32-41-08/401).
32 41 17 --	1. Airplane pulls to (01=L, 02=R) during braking. Brake temp high _____. (Max level) 2. Do a check of the brake system adjustment (AMM 32-41-00/501).  <u>NOTE:</u> A difference between the travel of the left and right brake pedal can cause braking that is not even.
32 41 18 --	1. Airplane pulls to (01=L, 02=R) during braking. Brake temps norm. 2. Make sure the tires for the landing gear have the correct inflation pressures (AMM 12-15-03/301).
32 41 19 00	1. Brake pressure indication (inop, sticks, intermittent, high, etc). 2. FIM 32-41-00/101, Fig. 110, Block 1
32 41 20 --	1. (01=L, 02=R) braking is over-sensitive. 2. Bleed the brakes (AMM 32-41-00/201).

EFFECTIVITY

ALL

## 32-FAULT CODE INDEX

04

Page 7  
Apr 22/99


**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
32 42 01 00	1. EICAS msg NORM ANTISKID displayed & amber ANTI-SKID lgt illum. 2. FIM 32-42-00/101, Fig. 109, Block 1
32 42 02 00	1. EICAS msg ALTN ANTISKID displayed & amber ANTI-SKID lgt illum. 2. FIM 32-42-00/101, Fig. 110, Block 1
32 42 03 00	1. Brakes grab briefly after touchdown (airplanes with S283T001-25 antiskid/autobrake control unit). 2. Replace the autobrake valve (AMM 32-42-09/401). Do a test of the valve that was removed to see if the valve is within calibration limits Ref Textron Component Maintenance Manual P/N 20101420, CMM 32-40-04, pages 101-112. See also Boeing 767 Maintenance Tip 767 MT 32-017, dated December 23, 1993.
32 42 04 00	Not Used.
32 42 05 00	1. Auto brake deceleration more than normal with no faults indicated. Level selected was ____. 2. FIM 32-42-00/101, Fig. 103, Block 6
32 42 06 00	1. Auto brake deceleration less than normal with no faults indicated. Level selected was ____. 2. FIM 32-42-00/101, Fig. 103, Block 6
32 42 07 00	1. Auto brake system inoperative with no fault indications. Level selected was ____. 2. FIM 32-42-00/101, Fig. 103, Block 3
32 42 08 00	1. Auto brake selector (will not latch into, disarmed from) position ____ . ANTISKID lgt was not illum. 2. FIM 32-42-00/101, Fig. 106, Block 1
32 42 09 00	1. Auto brake selector (will not latch into, disarmed from) position(s) ____ . AUTOBRAKES & ANTISKID lgt was illum. 2. FIM 32-42-00/101, Fig. 103, Block 1
32 42 10 00	1. Auto brake selector will not latch in RT0 position with no fault indications. 2. FIM 32-42-00/101, Fig. 107, Block 1
32 42 11 00	1. Auto brake selector will not latch in RT0 position with ANTISKID lgt illum. 2. FIM 32-42-00/101, Fig. 103, Block 3

EFFECTIVITY

ALL

## 32-FAULT CODE INDEX




**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
32 42 12 00	1. Auto brake selector will not latch in RT0 position with AUTO BRAKES lgt illum. 2. FIM 32-42-00/101, Fig. 103, Block 3
32 42 13 00	1. AUTO BRAKES lgt is illum with auto brake selector in RT0 position. 2. FIM 32-42-00/101, Fig. 103, Block 3
32 42 14 00	1. AUTO BRAKES lgt is illum with auto brake selector in OFF position. 2. Replace the pressure switch on the autobrake solenoid valve (AMM 32-42-09/401).
32 42 15 00 thru 32-42-18 00	Not Used
32 42 19 00 thru 32-42-21 00	Not Used
32 42 22 00	1. EICAS msgs NORM ANTISKID & ALTN ANTISKID displayed. Amber ANTISKID lgt illum. 2. FIM 32-42-00/101, Fig. 103, Block 1. After you correct the failure, push the ECS/MSG switch on the right side panel, P61. If the EICAS message NORM ANTISKID shows on the bottom display, go to FIM 32-42-00/101, Fig. 109, Block 1. If the EICAS message ALTN ANTISKID shows on the bottom display, go to FIM 32-42-00/101, Fig. 110, Block 1.
32 42 23 00	1. Autobrakes disarmed on landing roll. 2. FIM 32-42-00/101, Fig. 111A, Block 1
32 42 24 --	1. Autobrake selector will not latch in (07=1, 08=2, 09=3, 10=4, 15= MAX AUTO) pos. 2. Manually hold the selector in the position and refer to FIM 32-42-00/101, Fig. 103, Block 2
32 42 25 00	1. EICAS msgs AUTOBRAKES & ANTISKID displayed and AUTOBRAKE lgt illum with autobrake selector off. 2. Replace the pressure switch on the autobrake solenoid valve, YAAS2 (AMM 32-42-09/401).
32 42 26 00	1. Airplane brakes immediately after selecting RT0 during taxi. 2. Replace the antiskid/autobrake control unit, M102 (AMM 32-42-01/401).

EFFECTIVITY

ALL

## 32-FAULT CODE INDEX


**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
32 42 27 00	1. Auto brake selector will not move. 2. Replace the selector switch for autobrakes, S24 on the captain's instrument panel, P1 (WDM 32-42-12).
32 44 01 00	1. With PARK BRAKE set, PARK BRAKE lgt remains extin. 2. FIM 32-44-00/101, Fig. 104, Block 1
32 44 02 00	1. With PARK BRAKE released, PARK BRAKE lgt remains illum. 2. FIM 32-44-00/101, Fig. 105, Block 1
32 44 03 00	1. Parking brake cannot be set. 2. FIM 32-44-00/101, Fig. 106, Block 1
32 44 04 00	1. EICAS msgs ANTISKID OFF & PARKING BRAKE displayed. PARK BRAKE lgt illum with parking brake released. 2. FIM 32-44-00/101, Fig. 105, Block 1. After you correct the failure, push the ECS/MSG switch on the right side panel, P61. Make sure the EICAS messages ANTISKID OFF & PARKING BRAKE do not show on the top display.
32 44 05 00	1. Parking brake handle (loose, binds, or hard to set). 2. FIM 32-44-00/101, Fig. 103, Block 1
32 44 06 00	1. Parking brake handle must be pushed down to release brakes and extinguish PARK BRAKE lgt. 2. FIM 32-44-00/101, Fig. 106A, Block 1
32 45 01 00	1. EICAS msg TIRE PRESS SYS displayed. 2. Do a system test of the indication system for tire pressure (AMM 32-45-00/501).
32 45 02 00	1. EICAS msg TIRE PRESSURE displayed. All tire pressures indicate normal. 2. Do a system test of the indication system for tire pressure (AMM 32-45-00/501).
32 45 03 --	1. EICAS msg TIRE PRESSURE displayed. (01=1, 02=2, 03=3, 04=4, 05=5, 06=6, 07=7, 08=8, 09=L nose, 10=R nose) tire indicates low pressure. 2. Do the servicing or fill the tires (AMM 12-15-03/301).

EFFECTIVITY

ALL

## 32-FAULT CODE INDEX



**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
32 45 04 --	1. EICAS msg TIRE PRESSURE not displayed. (01=1, 02=2, 03=3, 04=4, 05=5, 06=6, 07=7, 08=8, 09=L nose, 10=R nose) tire indicates low pressure. 2. Do a system test of the indication system for tire pressure (AMM 32-45-00/501). Do the servicing or fill the tire(s) if it is necessary (AMM 12-15-03/301).
32 46 01 --	1. No. (07=1, 08=2, 09=3, 10=4, 11=5, 12=6, 13=7, 14=8) brake temp indicates (blank, inaccurate, zero, or intermittent) 2. FIM 32-46-00/101, Fig. 103, Block 1
32 46 02 00	1. All brake temps indicate (blank, inaccurate, zero, or intermittent) 2. FIM 32-46-00/101, Fig. 104, Block 2
32 46 03 --	1. No. (07=1, 08=2, 09=3, 10=4, 11=5, 12=6, 13=7, 14=8) brake temp high, ____ level higher than others. 2. FIM 32-46-00/101, Fig. 104, Block 2
32 46 04 --	1. (01=L, 02=R) brake temp high, ____ level higher than other side. 2. FIM 32-46-00/101, Fig. 104, Block 2
32 46 05 --	1. No. (07=1, 08=2, 09=3, 10=4, 11=5, 12=6, 13=7, 14=8) brake temp low, ____ level lower than others. 2. FIM 32-46-00/101, Fig. 104, Block 2
32 46 06 --	1. (01=L, 02=R) brake temp low, ____ level lower than other side. 2. FIM 32-46-00/101, Fig. 104, Block 2
32 46 07 --	1. BRAKE TEMP lgt illum. No. (07=1, 08=2, 09=3, 10=4, 11=5, 12=6, 13=7, 14=8) brake temp high. _____, max level. 2. FIM 32-46-00/101, Fig. 103, Block 1
32 46 08 --	1. BRAKE TEMP lgt illum. (01=L, 02=R) brake temp high. _____, max level. 2. FIM 32-46-00/101, Fig. 103, Block 1
32 46 09 00	1. BRAKE TEMP lgt illum. All brake temps high. _____, max level. 2. FIM 32-46-00/101, Fig. 103, Block 1
32 51 01 00	1. Nose wheel (vibrates/shimmies) on (takeoff/landing). 2. FIM 32-51-00/101, Fig. 104, Block 1

EFFECTIVITY

ALL

## 32-FAULT CODE INDEX

35

Page 11  
Apr 22/99


**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
32 51 02 00	1. Nose wheel vibrates at gear retraction. 2. FIM 32-51-00/101, Fig. 104, Block 1
32 51 03 00	1. Rudder pedal steering (describe problem). Tiller steering ok. 2. Repair or replace the centering and rudder interconnect mechanism for the nose wheel steering (AMM 32-51-02/401).
32 51 04 --	1. Tiller steering inop from (04=Capt, 05=F/0, 06=Capt & F/0) side. 2. FIM 32-51-00/101, Fig. 105, Block 1
32 51 05 --	1. Tiller steers left direction only from (04=Capt, 05=F/0, 06=Capt & F/0) side. 2. FIM 32-51-00/101, Fig. 106, Block 1
32 51 06 --	1. Tiller steering response sluggish from (04=Capt, 05=F/0, 06=Capt & F/0) side. 2. FIM 32-51-00/101, Fig. 107, Block 1
32 51 07 --	1. Tiller steering forces high from (04=Capt, 05=F/0, 06=Capt & F/0) side. 2. FIM 32-51-00/101, Fig. 108, Block 1
32 51 08 --	1. Nose wheel not centered with tiller indicator centered on (04=Capt, 05=F/0, 06=Capt & F/0) side. 2. FIM 32-51-00/101, Fig. 109, Block 1
32 51 09 --	1. Tiller steers right direction only from (04=Capt, 05=F/0, 06=Capt & F/0) side. 2. FIM 32-51-00/101, Fig. 106, Block 1
32 51 10 00	1. Nose wheel makes loud noise in wheel well. 2. Examine the spin brake for the nose wheel to see if it is worn. Replace the spin brake pad or spring arm if it is worn or damaged (AMM 32-45-05/201).
32 51 11 00	1. Nose wheel strut bottoms during taxi. 2. Examine the shock strut for the nose landing gear for the correct servicing. Do the servicing if it is necessary (AMM 12-15-02/301). If the failure continues, examine the active dynamic seal on the shock strut to see if there is leakage. Replace the seal if there is damage (AMM 32-21-25/401).

EFFECTIVITY

ALL

## 32-FAULT CODE INDEX


**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
32 51 12 00	1. Airplane pulls (L,R) during taxi. 2. FIM 32-51-00/101, Fig. 109A, Block 1
32 61 01 00	1. EICAS msg LDG GEAR MONITOR displayed with ldg gear down & locked. 2. FIM 32-09-03/101, Fig. 103, Block 1
32 61 02 00 thru 32 61 18 00	Not Used.
32 61 19 00	1. EICAS msg LDG GEAR MONITOR displayed with ldg gear up & locked. 2. FIM 32-09-03/101, Fig. 103, Block 1
32 61 20 00 thru 32 61 27 00	Not Used.
32 61 28 00 32 61 29 00	Not Used. 1. EICAS message LDG GEAR MONITOR displayed (Ref Chapter 31 for fault code diagram). 2. FIM 32-61-00/101, Fig. 104, Block 1
32 61 30 --	1. (01=L, 02=R, 03=NOSE) gear green dn lgt failed to extin with gear handle UP. DOORS & GEAR amber lgts extin. EICAS msg not displayed. 2. FIM 32-61-00/101, Fig. 105, Block 1
32 61 31 00	1. EICAS msg GEAR DOORS displayed and DOORS amber lgt flickers with gear green down lgts illum. 2. Examine and repair the circuit between pin 8, of connector D10338, on the relay for the landing gear doors, K652, and pin 2 of the DOORS light, L658 (WDM 32-61-14).
32 61 32 00	1. EICAS msg GEAR DOORS displayed and DOORS amber lgt flickers after gear retraction. 2. Examine and repair the circuit between pin 8, of connector D10338, on the relay for the landing gear doors, K652, and pin 2 of the DOORS light, L658 (WDM 32-61-14).

EFFECTIVITY

ALL

## 32-FAULT CODE INDEX


**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
32 61 33 --	1. (01=LEFT, 02=RIGHT, 03=NOSE) gear green dn lgt flickers after gear retraction. 2. FIM 32-61-00/101, Fig. 105A, Block 1
32 61 34 --	1. EICAS msg GEAR DISAGREE displayed and (01=LEFT, 02=RIGHT, 03=NOSE) gear green dn lgt flickers after gear retraction. 2. FIM 32-09-03/101, Fig. 103, Block 1. If you cannot identify the failure, do the procedure in FIM 32-61-00/101, Fig. 105A, Block 1
32 61 35 00	1. EICAS msg LDG GEAR MONITOR displayed and D00RS lgt illum after gear ext. 2. FIM 32-09-03/101, Fig. 103, Block 1
32 61 36 00 thru 32 61 44 00	Not Used.
32 61 45 00	1. GEAR amber light failed to illuminate during gear extension. 2. FIM 32-61-00/101, Fig. 103, Block 1
32 61 46 00	1. GEAR amber light failed to illuminate during gear retraction. 2. FIM 32-61-00/101, Fig. 103, Block 1
32 71 01 00	1. EICAS msg TAILSKID displayed and TAIL SKID lgt illuminated with gear lever up/neutral. 2. FIM 32-71-00/101, Fig. 103, Block 2
32 71 02 00	1. EICAS msg TAILSKID displayed and TAIL SKID lgt illuminated with gear lever down. 2. FIM 32-71-00/101, Fig. 103, Block 1
32 71 03 00	1. EICAS msg TAILSKID displayed and TAIL SKID lgt illuminated with gear lever up/neutral or down. 2. FIM 32-71-00/101, Fig. 103, Block 1

EFFECTIVITY

ALL

## 32-FAULT CODE INDEX


BITE Index

1. General

- A. Use this index to find the BITE procedure for the applicable LRU/System.
- B. The BITE procedure will provide the fault isolation instructions for the fault indications/LRU maintenance messages.

<u>LRU/System Name</u>	<u>Acronym</u>	<u>FIM Reference</u>
ACARS Management Unit		23-22
Air Data Computer	ADC	34-12
Air Data Inertial Reference Unit	ADIRU	34-26
Air Supply Control and Test Unit	ASCTU	36-20
Air Traffic Control Transponder	ATC	34-53
Airborne Vibration Monitor Signal Conditioner	AVM	77-31
Antiskid/Autobrake Control Unit	AACU	32-42
APU Fire Detection System		26-15
Automatic Direction Finder Receiver	ADF	34-57
APU Control Unit (or Electronic Control Unit)	ECU	49-11
Autopilot/Flight Director	AFDS	22-00
Auxiliary Zone Temperature Controller	AZTC	2160/21-61
Brake Temperature Monitor Unit	BTMU	32-46
Bus Power Control Unit	BPCU	24-20
Cabin Pressure Controller	CPC	21-30/21-31
Cabin Temperature Controller	CTC	21-61
Digital Flight Data Acquisition Unit	DFDAU	31-31
Distance Measuring Equipment Interrogator	DME	34-55
Duct Leak (Wing and Body)		26-18
E/E Cooling Control Card (If cards installed)		21-58
ECS Bleed Configuration Card		36-10
Electronic Control Unit	ECU	49-11
Electronic Engine Control Monitor Unit (Non-FADEC Engines)	EECM	71-EECM Message Index
Electronic Flight Instrument System	EFIS	34-22

Bite Index  
Figure 1 (Sheet 1)




## 32-BITE INDEX

  
**767**  
**FAULT ISOLATION/MAINT MANUAL**

<u>LRU/System Name</u>	<u>Acronym</u>	<u>FIM Reference</u>
Engine Fire/Overheat Detection System		26-11
Engine Indication and Crew Alerting System Computer	EICAS	31-41
Enhanced Ground Proximity Warning Computer	EGPWC	34-46
Equipment Cooling System Controller		21-58
Equipment Cooling Temperature Controller		21-58
Flap/Slat Electronic Unit	FSEU	27-51
Flap/Stabilizer Position Module	FSPM	27-58
Flight Management Computer	FMC	34-61
Fuel Quantity Indicating System Processor	FQIS	28-41
Ground Proximity Warning Computer	GPWC	34-46
HF (High Frequency) Communication		23-11
In-Flight Entertainment Equipment Cooling Card		21-58
Inertial Reference Unit	IRU	34-21
Instrument Comparator Unit	ICU	34-25
Instrument Landing System Receiver	ILS	34-31
Large Format Display System	LFDS	31-63
Lower Cargo Compartment Smoke Detection System		26-16
Maintenance Control Display Panel	MCDP	22-00
Multi-Mode Receiver	MMR	34-31
PA (Passenger Address) Amplifier		23-31
Pack Standby Temperature Controller	PSTC	21-51
Pack Temperature Controller	PTC	21-51
Passenger Entertainment System	PES	23-34
Power Supply Module (Control System Electronics Units)	PSM	27-09
Propulsion Interface and Monitor Unit (FADEC Engines)	PIMU	71-PIMU Message Index
Proximity Switch Electronics Unit	PSEU	32-09

Bite Index  
Figure 1 (Sheet 2)




## 32-BITE INDEX



  
**767**  
**FAULT ISOLATION/MAINT MANUAL**

<u>LRU/System Name</u>	<u>Acronym</u>	<u>FIM Reference</u>
Radio Altimeter Transmitter/Receiver	RA	34-33
Rudder Ratio Changer Module	RRCM	27-09
Satellite Data Unit	SDU	23-25
Spoiler Control Module	SCM	27-09
Stabilizer Trim/Elevator Asymmetry Limit Module	SAM	27-09
Stall Warning Computer/Module (in Warning Electronic Unit)	SWC	27-32
Strut Overheat Detection System (RR Engines)		26-12
Thrust Management Computer/Autothrottle	TMC	22-00
Traffic Alert and Collision Avoidance Computer	TCAS	34-45
VHF (Very High Frequency) Communication		23-12
VOR/Marker Beacon Receiver	VOR/MKR	34-51
Warning Electronic Unit BITE Module (Stall Warning)	WEU	27-32
Weather Radar Transceiver	WXR	34-43
Wheel Well Fire Detection		26-17
Window Heat Control Unit	WHCU	30-41
Yaw Damper Module	YDM	22-21
Yaw Damper/Stabilizer Trim Module	YSM	27-09
Zone Temperature Controller	ZTC	21-60/21-61

Bite Index  
Figure 1 (Sheet 3)



## 32-BITE INDEX

01

Page 3  
Aug 22/99



767  
 FAULT ISOLATION/MAINT MANUAL

LANDING GEAR MULTIPLE USE SYSTEMS/COMPONENTS

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
CIRCUIT BREAKER - AIR/GND SYS 1, C1182 POSITION AIR/GND SYS 1, C1175 POSITION AIR/GND SYS 2, C1170 POSITION AIR/GND SYS 2 ALTN, C1575 COMPUTER - (FIM 31-41-00/101) LEFT EICAS, M10181 RIGHT EICAS, M10182 MODULE - (FIM 31-01-36/101) TIME DELAY, AIR/GROUND RELAY SYSTEM 1, M1161,M1162 MODULE - (FIM 31-01-37/101) TIME DELAY, AIR/GROUND RELAY SYSTEM 2, M1163,M1164 MODULE - (FIM 32-09-03/101) PROXIMITY SWITCH ELECTRONICS UNIT (PSEU) RELAY -	1	1 1 1 1 1	FLIGHT COMPARTMENT, P11 11U15 11C30 11U23 OR 11U24 11C29	
LEFT PROBE HEAT TEST, K643 RIGHT PROBE HEAT TEST, K645 SYSTEM 1 AIR/GROUND, K514 SYSTEM 1 AIR/GROUND, K515 SYSTEM 1 AIR/GROUND, K516 SYSTEM 1 AIR/GROUND, K552 SYSTEM 2 AIR/GROUND, K517 SYSTEM 2 AIR/GROUND, K518 SYSTEM 2 AIR/GROUND, K520 SYSTEM 2 AIR/GROUND, K522 SYSTEM 2 AIR/GROUND, K528	3	3	119AL, MAIN EQUIPMENT CENTER, P33 PANEL	*
RELAY -  SYSTEM 1 AIR/GROUND, K124 SYSTEM 1 AIR/GROUND, K135 SYSTEM 1 AIR/GROUND, K140 SYSTEM 1 AIR/GROUND, K141 SYSTEM 1 AIR/GROUND, K142 SYSTEM 1 AIR/GROUND, K143 SYSTEM 1 AIR/GROUND, K144 SYSTEM 1 AIR/GROUND, K145 SYSTEM 1 AIR/GROUND, K146 SYSTEM 1 AIR/GROUND, K147 SYSTEM 1 AIR/GROUND, K148 SYSTEM 1 AIR/GROUND, K149 SYSTEM 1 AIR/GROUND, K167 SYSTEM 1 AIR/GROUND, K170 SYSTEM 1 AIR/GROUND, K177 SYSTEM 1 AIR/GROUND, K178 SYSTEM 1 AIR/GROUND, K199 SYSTEM 1 AIR/GROUND, K529 SYSTEM 1 AIR/GROUND, K716 SYSTEM 1 AIR/GROUND, K895 SYSTEM 1 AIR/GROUND, K896	4		119AL, MAIN EQUIPMENT CENTER, P36 PANEL	*

\* SEE THE WDM EQUIPMENT LIST

Landing Gear Multiple Use Systems/Components - Component Index  
 Figure 101 (Sheet 1)

EFFECTIVITY

ALL

32-09-00

03

Page 101  
 Aug 10/96

F96472

**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
RELAY - SYSTEM 1 AIR/GROUND, K1043 SYSTEM 1 AIR/GROUND, K1142 SYSTEM 1 AIR/GROUND, K1219 SYSTEM 1 AIR/GROUND, K2154 SYSTEM 1 AIR/GROUND, K2155 SYSTEM 1 AIR/GROUND, K2156 SYSTEM 1 AIR/GROUND, K2168 SYSTEM 1 AIR/GROUND, K2175 RELAY - SYSTEM 2 AIR/GROUND, K200 SYSTEM 2 AIR/GROUND, K201 SYSTEM 2 AIR/GROUND, K202 SYSTEM 2 AIR/GROUND, K203 SYSTEM 2 AIR/GROUND, K204 SYSTEM 2 AIR/GROUND, K205 SYSTEM 2 AIR/GROUND, K206 SYSTEM 2 AIR/GROUND, K207 SYSTEM 2 AIR/GROUND, K209 SYSTEM 2 AIR/GROUND, K210 SYSTEM 2 AIR/GROUND, K211 SYSTEM 2 AIR/GROUND, K213 SYSTEM 2 AIR/GROUND, K214 SYSTEM 2 AIR/GROUND, K215 SYSTEM 2 AIR/GROUND, K219 SYSTEM 2 AIR/GROUND, K293 SYSTEM 2 AIR/GROUND, K721 SYSTEM 2 AIR/GROUND, K1064 SYSTEM 2 AIR/GROUND, K1220 SYSTEM 2 AIR/GROUND, K2157 SYSTEM 2 AIR/GROUND, K2170 SENSOR - RIGHT MAIN GEAR TRUCK AUTO-SPEEDBRAKE, S10598	5		119AL, MAIN EQUIPMENT CENTER, P37 PANEL	*
SENSOR - SYSTEM 1 LEFT GEAR TILT, S245	2	1	LEFT MAIN GEAR TRUCK BEAM	32-09-07
SENSOR - SYSTEM 1 NOSE GEAR NOT COMPRESSED, S244	2	1	NOSE GEAR STRUT, LEFT SIDE	32-09-08
SENSOR - SYSTEM 1 RIGHT GEAR TILT, S246	2	1	RIGHT MAIN GEAR TRUCK BEAM	32-09-07
SENSOR - SYSTEM 2 LEFT GEAR TILT, S267	2	1	LEFT MAIN GEAR TRUCK BEAM	32-09-07
SENSOR - SYSTEM 2 NOSE GEAR NOT COMPRESSED, S266	2	1	NOSE GEAR STRUT, RIGHT SIDE	32-09-08
SENSOR - SYSTEM 2 RIGHT GEAR TILT, S268	2	1	RIGHT MAIN GEAR TRUCK BEAM	32-09-07

\* SEE THE WDM EQUIPMENT LIST

AIRPLANES WITH AUTO SPEED BRAKE TRUCK TILT  
SENSOR (POST-SB 27A0160 OR PRR 12900-086)

Landing Gear Multiple Use Systems/Components - Component Location  
Figure 101 (Sheet 2)

EFFECTIVITY

ALL



32-09-00

03

Page 102  
Dec 22/06

F96467

**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL



MAIN EQUIPMENT CENTER

(A)

Landing Gear Multiple Use Systems/Components - Component Location  
Figure 102 (Sheet 1)


EFFECTIVITY	ALL
-------------	-----

32-09-00

02

Page 103  
Nov 10/95


38590



**TILT SENSORS FOR THE MAIN LANDING GEAR  
(LEFT MAIN LANDING GEAR IS SHOWN)**

SENSOR NUMBER	SYSTEM	GEAR	LOCATION
S244	1	NOSE	LEFT
S266	2	NOSE	RIGHT
S245	1	L	FWD
S246	1	R	FWD
S267	2	L	AFT
S268	2	R	AFT
S10598	N/A	R	UPR

- 1
- 2
- 3
- SENSOR AND ASSOCIATED PARTS INSTALLED ON RIGHT GEAR ONLY
- AIRPLANES WITH AUTO SPEED BRAKE TRUCK TILT SENSOR (POST-SB 27A0160 OR PRR 12900-086)




**NOT COMPRESSED SENSORS FOR THE  
NOSE LANDING GEAR**

**Landing Gear Multiple Use Systems/Components - Component Location  
Figure 102 (Sheet 2)**

EFFECTIVITY	ALL
-------------	-----

**32-09-00**



FRONT VIEW OF THE P33 PANEL WITH THE DOOR OPEN

**NOTE:** THIS IS AN EXAMPLE INSTALLATION. RELAYS MAY BE SHOWN THAT ARE NOT IN ALL AIRPLANES.

Landing Gear Multiple Use Systems/Components - Component Location  
Figure 102 (Sheet 3)

EFFECTIVITY	ALL
-------------	-----

**32-09-00**

03


Page 105  
Apr 22/06

F97202

# BOEING

## 767

### FAULT ISOLATION/MAINT MANUAL



**NOTE:** THIS IS AN EXAMPLE INSTALLATION. RELAYS MAY BE SHOWN THAT ARE NOT IN ALL AIRPLANES.


1 THIS RELAY CAN BE LOCATED IN A DIFFERENT PART OF THE P36 PANEL

Landing Gear Multiple Use Systems/Components - Component Location  
Figure 102 (Sheet 4)

EFFECTIVITY	ALL
-------------	-----

## 32-09-00

F97218



**NOTE:** THIS IS AN EXAMPLE INSTALLATION. RELAYS MAY BE SHOWN THAT ARE NOT IN ALL AIRPLANES.

1 THIS RELAY CAN BE LOCATED IN A DIFFERENT PART OF THE P36 PANEL


**Landing Gear Multiple Use Systems/Components - Component Location  
Figure 102 (Sheet 5)**

EFFECTIVITY	ALL
-------------	-----

**32-09-00**



**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
11C30,11U15;  11U23 OR 11U24

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
THE SPOILERS ARE RETRACTED (AMM 27-61-00/201)  
THE AUTO SPEEDBRAKE IS IN THE DOWN-AND-LOCKED  
POSITION

EQUIPMENT:  
PROXIMITY SENSOR ACTUATOR/DEACTUATOR SET - A27092-61  
RELAY BREAKOUT BOX - A32074-1

**WARNING:** REFER TO AMM 27-61-00/201 TO DO THE  
DEACTIVATION PROCEDURE FOR THE SPOILERS OR  
MOVE ALL PERSONS AND EQUIPMENT AWAY FROM THE  
SPOILERS. THE SPOILERS CAN RETRACT QUICKLY  
AND CAN CAUSE INJURIES TO PERSONS OR DAMAGE  
TO EQUIPMENT.

**NOTE:** THIS PROCEDURE IS USED TO EXAMINE EACH AIR/  
GROUND RELAY. USE IT WHEN THERE IS A PROBLEM  
WITH A RELAY IN A DIFFERENT SYSTEM AND THERE IS  
NO "AIR/GROUND DISAGREE" MESSAGE SHOWN.

 THE "POSITION AIR/GND SYS 2" CIRCUIT BREAKER, C1170, CAN BE AT ONE OF THESE TWO LOCATIONS.

Air/Ground Relay Problem, No AIR/GND DISAGREE or NOSE A/G DISAGREE  
EICAS Message Display  
Figure 103 (Sheet 1)

EFFECTIVITY


ALL

32-09-00

02

Page 108  
Nov 10/95

AIR/GROUND RELAY  
 PROBLEM, NO "AIR/  
 GND DISAGREE" OR  
 "NOSE A/G DISAGREE"  
 EICAS MESSAGE  
 DISPLAY




Air/Ground Relay Problem, No AIR/GND DISAGREE or NOSE A/G DISAGREE  
 EICAS Message Display  
 Figure 103 (Sheet 2)

EFFECTIVITY	ALL
-------------	-----

**32-09-00**


C46315



Air/Ground Relay Problem, No AIR/GND DISAGREE or NOSE A/G DISAGREE  
 EICAS Message Display  
 Figure 103 (Sheet 3)

EFFECTIVITY	
ALL	

32-09-00



Air/Ground Relay Problem, No AIR/GND DISAGREE or NOSE A/G DISAGREE  
 EICAS Message Display  
 Figure 103 (Sheet 4)

EFFECTIVITY

---

ALL

32-09-00


01

Page 111  
Apr 22/99

# BOEING

## 767

### FAULT ISOLATION/MAINT MANUAL

RELAY NO.	RELAY STATUS 		CONN NO.	CONTINUITY BETWEEN THESE PINS:	
	GND	AIR		GROUND	AIR
K124	D	E	D598	1-13,5-3,7-14,11-9	1-2,5-4,7-8,11-10
K135	E	D	D3532	1-2,5-4,7-8,11-10	1-13,5-3,7-14,11-9
K140	E	D	D3610	1-2,5-4,7-8,11-10	1-13,5-3,7-14,11-9
K141	E	D	D3612	1-2,5-4,7-8,11-10	1-13,5-3,7-14,11-9
K142	E	D	D3614	1-2,5-4,7-8,11-10	1-13,5-3,7-14,11-9
K143	E	D	D3554	1-2,5-4,7-8,11-10	1-13,5-3,7-14,11-9
K144	E	D	D1736	A2-A1,B2-B1,C2-C1,D2-D1	A2-A3,B2-B3,C2-C3,D2-D3
K145	D	E	D1612	A2-A3,B2-B3,C2-C3,D2-D3	A2-A3,B2-B1,C2-C1,D2-D1
K146	E	D	D2886	A2-A1,B2-B1,C2-C1,D2-D1	A2-A3,B2-B3,C2-C3,D2-D3
K147	D	E	D3512	A2-A3,B2-B3,C2-C3,D2-D3	A2-A3,B2-B1,C2-C1,D2-D1
K148	D	E	D3514	1-13,5-3,7-14,11-9	1-2,5-4,7-8,11-10
K149	E	D	D3516	1-2,5-4,7-8,11-10	1-13,5-3,7-14,11-9
K167	D	E	D2910	A2-A3,B2-B3,C2-C3,D2-D3	A2-A1,B2-B1,C2-C1,D2-D1
K170	E	D	D2914	1-2,5-4,7-8,11-10	1-13,5-3,7-14,11-9
K177	E	D	D3534	1-2,5-4,7-8,11-10	1-13,5-3,7-14,11-9
K178	E	D	D3536	A2-A1,B2-B1,C2-C1,D2-D1	A2-A3,B2-B3,C2-C3,D2-D3
K199	D	E	D2912	1-13,5-3,7-14,11-9	1-2,5-4,7-8,11-10
K200	E	D	D3684	1-2,5-4,7-8,11-10	1-13,5-3,7-14,11-9
K201	E	D	D3686	1-2,5-4,7-8,11-10	1-13,5-3,7-14,11-9
K202	E	D	D3688	1-2,5-4,7-8,11-10	1-13,5-3,7-14,11-9
K203	D	E	D640	1-13,5-3,7-14,11-9	1-2,5-4,7-8,11-10
K204	E	D	D3728	A2-A1,B2-B1,C2-C1,D2-D1	A2-A3,B2-B3,C2-C3,D2-D3
K205	D	E	D3730	A2-A3,B2-B3,C2-C3,D2-D3	A2-A1,B2-B1,C2-C1,D2-D1
K206	E	D	D3690	1-2,5-4,7-8,11-10	1-13,5-3,7-14,11-9
K207	E	D	D3692	1-2,5-4,7-8,11-10	1-13,5-3,7-14,11-9
K209	D	E	D3712	A2-A3,B2-B3,C2-C3,D2-D3	A2-A1,B2-B1,C2-C1,D2-D1
K210	E	D	D3694	1-2,5-4,7-8,11-10	1-13,5-3,7-14,11-9
K211	E	D	D3696	1-2,5-4,7-8,11-10	1-13,5-3,7-14,11-9
K213	E	D	D3714	A2-A1,B2-B1,C2-C1,D2-D1	A2-A3,B2-B3,C2-C3,D2-D3
K214	E	D	D3700	1-2,5-4,7-8,11-10	1-13,5-3,7-14,11-9
K215	E	D	D2270	1-2,5-4,7-8,11-10	1-13,5-3,7-14,11-9
K219	D	E	D2904	1-13,5-3,7-14,11-9	1-2,5-4,7-8,11-10
K293	D	E	D3698	1-13,5-3,7-14,11-9	1-2,5-4,7-8,11-10
K514	E	D	D546	A2-A1,B2-B1,C2-C1,D2-D1	A2-A3,B2-B3,C2-C3,D2-D3
K515	E	D	D542	A2-A1,B2-B1,C2-C1,D2-D1	A2-A3,B2-B3,C2-C3,D2-D3
K516	E	D	D3510	A2-A1,B2-B1,C2-C1,D2-D1	A2-A3,B2-B3,C2-C3,D2-D3
K517	E	D	D628	A2-A1,B2-B1,C2-C1,D2-D1	A2-A3,B2-B3,C2-C3,D2-D3
K518	E	D	D630	A2-A1,B2-B1,C2-C1,D2-D1	A2-A3,B2-B3,C2-C3,D2-D3
K520	E	D	D660	A2-A1,B2-B1,C2-C1,D2-D1	A2-A3,B2-B3,C2-C3,D2-D3
K522	E	D	D624	A2-A1,B2-B1,C2-C1,D2-D1	A2-A3,B2-B3,C2-C3,D2-D3
K528	E	D	D1396	A2-A1,B2-B1,C2-C1,D2-D1	A2-A3,B2-B3,C2-C3,D2-D3
K529	E	D	D1388	A2-A1,B2-B1,C2-C1,D2-D1	A2-A3,B2-B3,C2-C3,D2-D3
K552	E	D	D1268	A2-A1,B2-B1,C2-C1,D2-D1	A2-A3,B2-B3,C2-C3,D2-D3
K716	E	D	D10342	1-2,5-4,7-8,11-10	1-13,5-3,7-14,11-9
K721	E	D	D10478	A2-A1,B2-B1,C2-C1,D2-D1	A2-A3,B2-B3,C2-C3,D2-D3
K895	E	D	D10950	A2-A1,B2-B1,C2-C1,D2-D1	A2-A3,B2-B3,C2-C3,D2-D3
K896	E	D	D10954	A2-A1,B2-B1,C2-C1,D2-D1	A2-A3,B2-B3,C2-C3,D2-D3
K1043	E	D	D13176	1-2,5-4,7-8,11-10	1-13,5-3,7-14,11-9
K1064	E	D	D13021	A2-A1,B2-B1,C2-C1,D2-D1	A2-A3,B2-B3,C2-C3,D2-D3
K1142	E	D	D13176	1-2,5-4,7-8,11-10	1-13,5-3,7-14,11-9

**AIR/GROUND RELAY  
TABLE 101**

**NOTE:** BEFORE YOU DO THE CONTINUITY TEST FOR A RELAY, MAKE SURE THE POWER IS REMOVED FROM THE USER SYSTEMS CONNECTED TO THE RELAY. THE RELAY BREAKOUT BOX CAN BE USED TO MAKE THE CONTINUITY TEST EASIER.



E = ENERGIZED  
D = DE-ENERGIZED


Air/Ground Relay Problem, No AIR/GND DISAGREE or NOSE A/G DISAGREE  
EICAS Message Display  
Figure 103 (Sheet 5)

EFFECTIVITY

ALL

# 32-09-00



**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

RELAY NO.	RELAY STATUS 		CONN NO.	CONTINUITY BETWEEN THESE PINS:	
	GND	AIR		GROUND	AIR
K1219	E	D	D13396	1-2,5-4,7-8,11-10	1-13,5-3,7-14,11-9
K1220	E	D	D13398	1-2,5-4,7-8,11-10	1-13,5-3,7-14,11-9
K2154	E	D	D20090	A2-A1,B2-B1,C2-C1,D2-D1	A2-A3,B2-B3,C2-C3,D2-D3
K2155	E	D	D20092	A2-A1,B2-B1,C2-C1,D2-D1	A2-A3,B2-B3,C2-C3,D2-D3
K2156	D	E	D20138	1-13,5-3,7-14,11-9	1-2,5-4,7-8,11-10
K2157	E	D	D20100	A2-A1,B2-B1,C2-C1,D2-D1	A2-A3,B2-B3,C2-C3,D2-D3
K2168	D	E	D20144	A2-A3,B2-B3,C2-C3,D2-D3	A2-A1,B2-B1,C2-C1,D2-D1
K2170	E	D	D20150	A2-A1,B2-B1,C2-C1,D2-D1	A2-A3,B2-B3,C2-C3,D2-D3
K2175	E	D	D20166	A2-A1,B2-B1,C2-C1,D2-D1	A2-A3,B2-B3,C2-C3,D2-D3

AIR/GROUND RELAY  
TABLE 101

**NOTE:** REFERENCE WDM 32-09-11,-12,-13  
(SEE TABLE 103)

Air/Ground Relay Problem, No AIR/GND DISAGREE or NOSE A/G DISAGREE  
EICAS Message Display  
Figure 103 (Sheet 6)



**32-09-00**

03

Page 113  
Aug 10/96

F96517


**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

AIR/GROUND RELAY NO.	MASTER RELAY NO.	EXAMINE FOR 28V DC		WDM REFERENCES
		MASTER RELAY CONNECTOR NO.	PIN NO.	
K124 K213 K141 K215 K144 K219 K145 K293 K147 K518 K148 K520 K167 K529 K170 K552 K199 K895 K201 K896 K202 K1043 K203 K1142 K204 K2156 K205 K2168 K209 K2175	NONE	----	----	32-09-11 32-09-12 32-09-13
K135 K177 K140 K178 K142 K716 K143 K2154 K146 K2155 K149	K144	D1736	6 OR X1 TO GROUND	32-09-11
K200 K214 K206 K721 K207 K2157 K210 K2170 K211	K204	D3728	6 OR X1 TO GROUND	32-09-12
K514 K515 K516	K552	D1268	X1 TO GROUND	32-09-13
K517 K522 K528	K518	D630	X1 TO GROUND	32-09-13

CONTROL RELAY VOLTAGE CHECK  
TABLE 103

Air/Ground Relay Problem, No AIR/GND DISAGREE or NOSE A/G DISAGREE  
 EICAS Message Display  
 Figure 103 (Sheet 7)

EFFECTIVITY

ALL

32-09-00

03

Page 114  
Aug 10/96

F96539

**EICAS MSG "AIR/GND  
DISAGREE" DISPLAYED  
INFLT**


**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
11C30,11T36,11U15; **A** 11U23 OR 11U24

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)

**EQUIPMENT:**

PROXIMITY SENSOR ACTUATOR SET - A32102-1  
(1 RECTANGULAR SENSOR ACTUATOR IS NECESSARY,  
4 ACTUATORS WILL MAKE THE TEST EASIER)



**1** REMOVE THE SENSOR ACTUATORS FROM ALL THE TILT SENSORS OF THE MAIN LANDING GEAR. PUSH THE RESET SWITCH ON THE PSEU TO ERASE THE MEMORY OF THE INFLIGHT BITE. ERASE THE "AIR/GND DISAGREE" EICAS MESSAGE (FIM 31-41-00/101, FIG. 109).

**A** THE "POSITION AIR/GND SYS 2" CIRCUIT BREAKER, C1170, CAN BE AT ONE OF THESE TWO LOCATIONS.

**EICAS Msg AIR/GND DISAGREE Displayed Inflt  
Figure 103A (Sheet 1)**

EFFECTIVITY

ALL


**32-09-00**

02

Page 115  
Aug 10/95



FROM SHEET 1  
(BLOCK 5)



EICAS Msg AIR/GND DISAGREE Displayed Inflt  
Figure 103A (Sheet 2)

EFFECTIVITY

ALL
-----


**32-09-00**

EICAS MSG "AIR/GND DISAGREE" OR "AIR/GND SYS" DISPLAYED ON GND

**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
11C30,11T36,11U15; **A** 11U23 OR 11U24

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)



**A** THE "POSITION AIR/GND SYS 2" CIRCUIT BREAKER, C1170, CAN BE AT ONE OF THESE TWO LOCATIONS.

**1** ERASE THE "AIR/GND DISAGREE" OR "AIR/GND SYS" EICAS MESSAGE (FIM 31-41-00/101, FIG. 109).

EICAS Msg AIR/GND DISAGREE or AIR/GND SYS Displayed on Gnd  
Figure 103B

EFFECTIVITY

ALL

**32-09-00**

02

Page 117  
Dec 10/98


189044

EICAS MSG "NOSE A/G DISAGREE" DISPLAYED INFLT

**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
11C30,11T36,11U15; **A** 11U23 OR 11U24

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
PROXIMITY SENSOR ACTUATOR SET - A32102-1  
(1 RECTANGULAR SENSOR ACTUATOR IS NECESSARY,  
2 ACTUATORS WILL MAKE THE TEST EASIER)



- A** THE "POSITION AIR/GND SYS 2" CIRCUIT BREAKER, C1170, CAN BE AT ONE OF THESE TWO LOCATIONS.
- 1** ERASE THE "NOSE A/G DISAGREE" EICAS MESSAGE (FIM 31-41-00/101, FIG. 109).

EICAS Msg NOSE A/G DISAGREE Displayed Inflt  
Figure 103C

EFFECTIVITY	ALL


**32-09-00**

EICAS MSG "NOSE A/G DISAGREE" OR "NOSE A/G SYS" DISPLAYED ON GND

**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
11C30, 11T36, 11U15; <sup>2</sup> 11U23 OR 11U24

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)



- <sup>1</sup> ERASE THE "NOSE A/G DISAGREE" OR "NOSE A/G" EICAS MESSAGES (FIM 31-41-00/101, FIG. 109).
- <sup>2</sup> THE "POSITION AIR/GND SYS 2" CIRCUIT BREAKER, C1170, CAN BE AT ONE OF THESE TWO LOCATIONS.

EICAS Msg NOSE A/G DISAGREE or NOSE A/G SYS Displayed On Gnd  
Figure 103D

EFFECTIVITY

ALL

**32-09-00**


01

Page 119  
Dec 22/05


825096

 **BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

PROXIMITY SWITCH SYSTEM

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
CARDS - PSEU PRINTED CIRCUIT 			119AL, MAIN EQUIPMENT CENTER, E1-2, PSEU M162	32-09-06
BITE CARD MODULE, YCRM008	2	1		
DRIVER CARD, YCRM006, YCRM007, YCRM010	2	3		
DRIVER CARD AUX, YCRM012	2	1		
LOGIC CARD 1, YCRM011	2	1		
LOGIC CARD 2, YCRM009	2	1		
LOGIC CARD 3, YCRM005	2	1		
PROX CARD, YCRM001-YCRM004, YCRM013-YCRM016	2	8		
CIRCUIT BREAKER -	1		FLIGHT COMPARTMENT, P11	
DOOR IND, C1406		1		*
DOORS L FWD ENTRY CONT, C1402		1		*
FLIGHT CONTROLS SLAT POS IND, C1001		1		*
LANDING GEAR POSITION AIR/GND SYS 1, C1175		1		*
LANDING GEAR POSITION AIR/GND SYS 2, C1170		1		*
LANDING GEAR POSITION AIR/GND SYS 2 ALTN, C1575		1		*
LEFT ENGINE T/R CONT, C1482		1		*
LEFT ENGINE T/R IND, C1480		1		*
PROX SW TEST, C1178		1		*
RIGHT ENGINE T/R CONT, C1483		1		*
RIGHT ENGINE T/R IND ALT, C1479		1		*
RIGHT ENGINE T/R IND, C1481		1		*
RIGHT ENGINE T/R IND ALT, C1478		1		*
CIRCUIT BREAKER -	1		119AL, MAIN EQUIPMENT CENTER, P34	
CONT DOOR CARGO, C1403		1		*
CONT DOOR FWD ENTRY, C1408		1		*
MODULE - PROXIMITY SWITCH ELECTRONICS UNIT (PSEU), M162	1	1	119AL, MAIN EQUIPMENT CENTER, E1-2	32-09-04

\* SEE THE WDM EQUIPMENT LIST

 THE DRIVER CARDS ARE INTERCHANGEABLE.  
THE LOGIC CARDS ARE NOT INTERCHANGEABLE.  
THE PROX CARDS ARE INTERCHANGEABLE.

Proximity Switch System - Component Index  
Figure 101 (Sheet 1)

EFFECTIVITY

ALL

**32-09-03**

01


Page 101  
Apr 22/99

223484




**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
SENSOR - CARGO DOOR CONTROL SYSTEM PROXIMITY (FIM 52-34-00/101) S150-S161 SENSOR - DOOR SYSTEM PROXIMITY (FIM 52-71-00/101) S192-S219 S221-S230 SENSOR - ENTRY DOOR SYSTEM PROXIMITY (FIM 52-11-00/101) S184-S191,S220 SENSOR - LANDING GEAR SYSTEM PROXIMITY (FIM 32-09-00/101) S244-S246 S266-S268 SENSOR - LANDING GEAR SYSTEM PROXIMITY (FIM 32-61-00/101) S232-S242 S247-S264 SENSOR - LEADING EDGE SLAT SYSTEM PROXIMITY (FIM 27-88-00/101) S276-S305 SENSOR - THRUST REVERSER SYSTEM PROXIMITY (FIM 78-34-00/101) S176-S177 S1604-S1605 SENSOR - THRUST REVERSER SYSTEM PROXIMITY (FIM 78-36-00/101) S164-S167 S1607-S1610				

Proximity Switch System - Component Index  
Figure 101 (Sheet 2)



32-09-03




**BITE MODULE, MO08**

(B)

**Proximity Switch System - Component Location  
Figure 102 (Sheet 1)**

EFFECTIVITY	ALL
-------------	-----

**32-09-03**



PROXIMITY SWITCH ELECTRONICS UNIT, M162

(C)

Proximity Switch System - Component Location (Detail from Sht 1)  
Figure 102 (Sheet 2)


EFFECTIVITY	
	ALL

**32-09-03**



**PREREQUISITES**

MAKE SURE THIS SYSTEM WILL OPERATE:  
EICAS (AMM 31-41-00/201)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
11C10,11C30,11D13,11D14,11L32,11L33,11T6,11T33,  
11T36,34J4,34J5;  11U23 OR 11U24

MAKE SURE THIS CIRCUIT BREAKER IS OPEN AND ATTACH A  
DO-NOT-CLOSE TAG:  
11G11


MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
ON THE GROUND WITH THE LANDING GEAR DOWN AND LOCKED  
THRUST REVERSERS ARE RETRACTED  
SPOILERS ARE RETRACTED (AMM 27-61-00/201)  
LEVER FOR THE SPEEDBRAKE IS IN THE DOWN AND LOCKED  
POSITION  
LANDING GEAR CONTROL LEVER IS IN THE DN DETENT  
LEFT OR RIGHT FIRE HANDLES ON THE PILOTS' CONTROL  
STAND (P8) ARE NOT PULLED  
THE LEADING EDGE SLATS ARE RETRACTED (AMM 27-81-00/  
201)  
THE TRAILING EDGE FLAPS ARE RETRACTED  
(AMM 27-51-00/201)

**WARNING:** DO THE DEACTIVATION PROCEDURE FOR THE  
SPOILERS OR MOVE ALL PERSONS AND EQUIPMENT  
AWAY FROM THE SPOILERS (AMM 27-61-00/201).  
THE SPOILERS CAN RETRACT QUICKLY AND CAN  
CAUSE INJURIES TO PERSONS OR DAMAGE TO  
EQUIPMENT.

**NOTE:** AFTER YOU DO THE ALTERNATE GEAR EXTENSION, SOME  
OF THE BITE CODES FOR THE LANDING GEAR INDICA-  
TION SYSTEM CAN BE INCORRECT (BLOCK 14 AND  
BLOCK 23).

THE BITE DOES A TEST OF THE PSEU MODULE. THE  
TEST INCLUDES THE PROXIMITY CARDS AND DRIVER  
CARDS AND THE RELATED LIGHTS.

**NOTE:** IF YOU HAVE INTERMITTENT OR NUISANCE FAULTS,  
DO THIS PROCEDURE: PROXIMITY SENSOR/WIRING  
RESISTANCE CHECK (FIG. 105).

 THE "POSITION AIR/GND SYS 2" CIRCUIT BREAKER, C1170, CAN BE IN  
ONE OF THESE TWO LOCATIONS.

BITE Procedure for the Proximity Switch Electronics Unit (PSEU)  
Figure 103 (Sheet 1)

EFFECTIVITY


ALL

**32-09-03**

04

Page 105  
May 10/97

**BITE PROCEDURE FOR  
THE PROXIMITY  
SWITCH ELECTRONICS  
UNIT (PSEU)**



1 REMOVE THE DO-NOT-CLOSE TAG AND CLOSE THE CIRCUIT BREAKER THAT WAS OPENED IN THE PREREQUISITES BLOCK.

BITE Procedure for the Proximity Switch Electronics Unit (PSEU)  
Figure 103 (Sheet 2)


EFFECTIVITY

ALL

**32-09-03**

01

Page 106  
Nov 10/94



BITE Procedure for the Proximity Switch Electronics Unit (PSEU)  
Figure 103 (Sheet 3)


EFFECTIVITY

ALL

32-09-03

01

Page 107  
Aug 10/93



BITE Procedure for the Proximity Switch Electronics Unit (PSEU)  
Figure 103 (Sheet 4)

EFFECTIVITY


ALL

**32-09-03**

01

Page 108  
Nov 10/93

825708



A THE CODES 500 THRU 507 CAN BE USED TO TEST THE INDIVIDUAL SYSTEMS (SEE TABLE 104).

BITE Procedure for the Proximity Switch Electronics Unit (PSEU)  
Figure 103 (Sheet 5)

EFFECTIVITY


ALL

**32-09-03**

02

Page 109  
May 10/97

**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL



BITE Procedure for the Proximity Switch Electronics Unit (PSEU)  
Figure 103 (Sheet 6)

EFFECTIVITY	ALL
-------------	-----

32-09-03


**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

SENSOR NO.	FAULT DISPLAY	AMM REF	SENSOR NO.	FAULT DISPLAY	AMM REF
S150	150	52-34-43	S213	213	52-71-01
S151	151	52-34-43	S214*	214	52-71-01
S152	152	52-34-43	S215	215	52-71-01
S153	153	52-34-43	S216	216	52-71-01
S154	154	52-34-43	S217	217	52-71-01
S157	157	52-34-43	S218	218	52-71-01
S158	158	52-34-43	S219	219	52-71-01
S159	159	52-34-43	S220	220	52-11-47
S160	160	52-34-43	S221	221	52-71-01
S161	161	52-34-43	S222	222	52-71-01
S1607* (L)	164	78-36-01	S223	223	52-71-01
S1607* (R)	170	78-36-01	S224	224	52-71-01
S1608* (L)	165	78-36-01	S225	225	52-71-01
S1608* (R)	171	78-36-01	S226	226	52-71-01
S1609* (L)	166	78-36-01	S227	227	52-71-01
S1609* (R)	172	78-36-01	S228	228	52-71-01
S1610* (L)	167	78-36-01	S229	229	52-71-01
S1610* (R)	173	78-36-01	S230	230	52-71-01
S1604* (L)	176	78-36-01	S232	232	32-61-03
S1604* (R)	180	78-36-01	S233*	233	32-61-03
S1605* (L)	177	78-36-01	S234	234	32-61-03
S1605* (R)	181	78-36-01	S235	235	32-61-03
S184	184	52-11-47	S236*	236	32-61-02
S185	185	52-11-47	S237	237	32-61-02
S186	186	52-11-47	S238	238	32-61-02
S187	187	52-11-47	S240*	240	32-61-02
S192	192	52-71-01	S241	241	32-61-02
S193	193	52-71-01	S242	242	32-61-02
S194	194	52-71-01	S244	244	32-09-08
S195*	195	52-71-01	S245	245	32-09-07
S196	196	52-71-01	S246	246	32-09-07
S197*	197	52-71-01	S247	247	32-61-04
S198	198	52-71-01	S248	248	32-61-04
S199	199	52-71-01	S254	254	32-61-03
S200	200	52-71-01	S255*	255	32-61-03
S201	201	52-71-01	S256	256	32-61-03
S202	202	52-71-01	S257	257	32-61-03
S203	203	52-71-01	S258*	258	32-61-02
S204	204	52-71-01	S259	259	32-61-02
S205*	205	52-71-01	S260	260	32-61-02
S206	206	52-71-01	S262*	262	32-61-02
S207*	207	52-71-01	S263	263	32-61-02
S208*	208	52-71-01	S264	264	32-61-02
S209	209	52-71-01	S266	266	32-09-08
S211	211	52-71-01	S267	267	32-09-07
S212	212	52-71-01	S268	268	32-09-07

TABLE 101

ALL THE SENSORS ARE RECTANGULAR TYPE EXCEPT THOSE NOTED BY \*

(L) - INSTALLED ON THE LEFT ENGINE  
 (R) - INSTALLED ON THE RIGHT ENGINE

BITE Procedure for the Proximity Switch Electronics Unit (PSEU)  
 Figure 103 (Sheet 7)

EFFECTIVITY

ALL

32-09-03

03

Page 111  
 Feb 10/94

D10573


**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

SENSOR NO.	FAULT DISPLAY	AMM REF
S276	276	27-88-01
S277	277	27-88-01
S278	278	27-88-01
S279	279	27-88-01
S280	280	27-88-01
S281	281	27-88-01
S282	282	27-88-01
S283	283	27-88-01
S284	284	27-88-01
S285	285	27-88-01
S286	286	27-88-01
S287	287	27-88-01
S294	294	27-88-01
S295	295	27-88-01
S296	296	27-88-01
S297	297	27-88-01
S298	298	27-88-01
S299	299	27-88-01
S300	300	27-88-01
S301	301	27-88-01
S302	302	27-88-01
S303	303	27-88-01
S304	304	27-88-01
S305	305	27-88-01

TABLE 101 CONTINUED

BITE Procedure for the Proximity Switch Electronics Unit (PSEU)  
 Figure 103 (Sheet 8)

EFFECTIVITY	ALL
-------------	-----

32-09-03




**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

SUBSYSTEM INPUT POWER FAILURE CODE	EXAMINE FOR 28V DC AT THE PIN LISTED BELOW TO THE GROUND				
	CIRCUIT BREAKER	CONNECTOR	PIN	GROUND PIN	WDM REF
400	C1403 (34J4)	D2166D	C3	D3	52-34-12
401	C1480 (11D13)	D2166A	G4	H4	78-36-11
402	C1481 (11L32)	D2166E	A14	B14	78-36-21
403	C1482 (11D14)	D2166A	J5	K5	78-34-11
404	C1483 (11L33)	D2166E	C15	D15	78-34-21
405	C1402 (11T6) OR C1408 (34J5)	D2166E	C3	D3	52-11-12
406	C1406 (11T33)	D2166D	J11	K11	52-71-11
407	C1175 (11C30)	D2166A	C15	D15	32-09-11
408	C1170 (11U23) OR (11U24)	D2166E	J15	K15	32-09-12
409	C1001 (11C10)	D2166B	J15	K15	27-88-11

TABLE 102

FAILURE CODE	DISCRETE INPUT	AMM REF
421	LDG GR LVR DOWN 1	32-31-01/401
422	LDG GR LVR DOWN 2	32-31-01/401
423	SLAT CMD TO RET 1*	27-51-26/401
434	SLAT CMD TO RET 2*	27-51-26/401
425	SLAT CMD TO T/O 1*	27-51-26/401
426	SLAT CMD TO T/O 2*	27-51-26/401
427	SLAT CMD TO LDG 1*	27-51-26/401
428	SLAT CMD TO LDG 2*	27-51-26/401

\* FROM FSEU M545

TABLE 103

TEST CODE	SYSTEM TESTED
500	CARGO DOOR CONTROL
501	ALL T/R SYSTEMS
502	ENTRY DOOR CONTROL
503	DOOR SYSTEM
504	LG SYSTEM #1
505	LG SYSTEM #2
506	LE SLATS
507	ALL SYSTEMS (NO MEMORY TEST)
ALL OTHER CODES	ALL SYSTEMS PLUS MEMORY TEST

TABLE 104

BITE Procedure for the Proximity Switch Electronics Unit (PSEU)  
 Figure 103 (Sheet 9)

EFFECTIVITY

ALL

32-09-03


03

Page 113  
Aug 22/08

295120

**PREREQUISITES**

MAKE SURE THIS SYSTEM WILL OPERATE:  
 EICAS (AMM 31-41-00/201)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
 11C10,11C30,11D13,11D14,11L32,11L33,11T6,11T33,  
 11T36,34J4,34J5;  11U23 OR 11U24

MAKE SURE THIS CIRCUIT BREAKER IS OPEN AND ATTACH A  
 DO-NOT-CLOSE TAG:  
 11G11


MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
 ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
 ON THE GROUND WITH THE LANDING GEAR DOWN AND LOCKED  
 THRUST REVERSERS ARE RETRACTED  
 SPOILERS ARE RETRACTED (AMM 27-61-00/201)  
 LEVER FOR THE SPEEDBRAKE IS IN THE DOWN AND LOCKED  
 POSITION

EQUIPMENT:  
 A32102-1 - PROXIMITY SENSOR ACTUATOR TEST SET  
 OR  
 KHT8-758-01 - PROXIMITY SENSOR ACTUATOR TEST SET  
 WHICH CONSISTS OF:  
 • KHT8-750-01 (RECTANGULAR) ACTUATOR  
 • KHT8-752-01 (ROUND) ACTUATOR  
 TEST GAUGE, ELDEC CORPORATION, AIRCRAFT SYSTEMS  
 DIVISION, P.O. BOX 3002, BOTHELL, WA 98041-3002

**WARNING:** DO THE DEACTIVATION PROCEDURE FOR THE SPOILERS OR MOVE ALL PERSONS AND EQUIPMENT AWAY FROM THE SPOILERS (AMM 27-61-00/201). THE SPOILERS CAN RETRACT QUICKLY AND CAN CAUSE INJURIES TO PERSONS OR DAMAGE TO EQUIPMENT.

**NOTE:** METAL STRUCTURE (SIDE METAL) NEAR THE SENSOR FACE CAN CHANGE THE EFFECTIVE ACTUATION GAP OF THE SENSOR (SIDE METAL EFFECT). ALUMINUM SIDE METAL WILL CAUSE AN APPARENT GAP REDUCTION. STEEL SIDE METAL WILL CAUSE AN APPARENT GAP INCREASE. IF A SENSOR FAILS THE "TARGET NEAR" TEST WHEN AN ACTUATOR IS USED FOR THE TEST AND THE INSTALLATION CAN BE AFFECTED BY THE SIDE METAL EFFECT, DO THESE STEPS:

1. REMOVE THE SENSOR FROM ITS MOUNTING BRACKET WITH THE WIRING INSTALLED/CONNECTED
2. MOVE THE SENSOR AWAY FROM THE METAL STRUCTURE AND DO A TARGET TEST OF THE SENSOR WITH THE ACTUATOR AGAIN.

 THE "POSITION AIR/GND SYS 2" CIRCUIT BREAKER, C1170, CAN BE IN ONE OF THESE TWO LOCATIONS.

IF THE SENSOR ACTUATES CORRECTLY (TARGET NEAR), IT OPERATES CORRECTLY AND SENSOR REPLACEMENT IS NOT NECESSARY.


BITE Procedure for the PSEU Sensor Target Test  
 Figure 104 (Sheet 1)

EFFECTIVITY	ALL
-------------	-----

**32-09-03**

**NOTE:** THIS PROCEDURE CAN BE USED TO DO TWO TESTS. WHEN YOU USE THE ACTUATOR TEST EQUIPMENT, THE SENSOR PERFORMANCE WILL BE TESTED. THIS CAN HELP FIND DAMAGE INSIDE THE SENSOR. WHEN YOU DO THE TEST WITH THE AIRPLANE SYSTEM TARGETS, YOU CAN TEST THE SENSOR AND TARGET RELATIONSHIP.

**BITE PROCEDURE FOR THE PSEU SENSOR TARGET TEST**




BITE Procedure for the PSEU Sensor Target Test  
Figure 104 (Sheet 2)

EFFECTIVITY

ALL
-----

32-09-03



BITE Procedure for the PSEU Sensor Target Test  
Figure 104 (Sheet 3)

EFFECTIVITY	ALL
-------------	-----

32-09-03


  
**767**
  
**FAULT ISOLATION/MAINT MANUAL**

SENSOR NUMBER	PSEU CODE	SYSTEM/MODE	TARGET		AMM REF	WDM REF
			NEAR	FAR		
S150 S151 S152 S153 S154	150 151 152 153 154	FORWARD CARGO DOOR CONTROL SYSTEM MODE: DOORS OPEN	X X	 X X X	52-33-00	52-34-13 52-34-13 52-34-13 52-34-13 52-34-13
S157 S158 S159 S160 S161	157 158 159 160 161	AFT CARGO DOOR CONTROL SYSTEM MODE: DOORS OPEN	X X	 X X X	52-35-00	52-35-13 52-35-13 52-35-13 52-35-13 52-35-13
S1607 *(L) S1607 *(R) S1608 *(L) S1608 *(R) S1609 *(L) S1609 *(R) S1610 *(L) S1610 *(R) S1604 (L) S1604 (R) S1605 (L) S1605 (R)	164 170 165 171 166 172 167 173 176 180 177 181	THRUST REVERSER SYSTEM MODE: THRUST REVERSERS STOWED	X X X X  X X X X	   X X X X	78-36-01	78-36-11 78-36-11 78-36-11 78-36-11 78-36-11 78-36-11 78-36-11 78-36-11 78-34-11 78-34-11 78-34-11 78-34-11
S184 S185 S186 S187	184 185 186 187	ENTRY DOOR CONTROL SYSTEM MODE: DOORS OPEN	 X X	  X	52-11-47	52-11-13 52-11-13 52-11-13 52-11-13
S192 S193 S194 S195 * S196 S197 * S198 S199	192 193 194 195 196 197 198 199	DOOR SYSTEM MODE: DOORS OPEN		X X X X X X X	52-71-01	52-71-12 52-71-12 52-71-11 52-71-11 52-71-11 52-71-11 52-71-12 52-71-12

TABLE 105

ALL THE SENSORS ARE RECTANGULAR TYPE EXCEPT THOSE NOTED BY \*

(L) - INSTALLED ON THE LEFT ENGINE  
(R) - INSTALLED ON THE RIGHT ENGINE

BITE Procedure for the PSEU Sensor Target Test  
Figure 104 (Sheet 4)

EFFECTIVITY

ALL

32-09-03

 **BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL





SENSOR NUMBER	PSEU CODE	SYSTEM/MODE	TARGET		AMM REF	WDM REF
			NEAR	FAR		
S200	200	DOOR SYSTEM		X	52-71-01	52-71-14
S201	201	MODE: DOORS OPEN		X		52-71-14
S202	202			X		52-71-11
S203	203			X		
S204	204			X		
S205 *	205			X		
S206	206			X		
S207 *	207			X		
S208 *	208			X		
S209	209	DOOR SYSTEM		X	52-71-01	52-71-13
S211	211	MODE: DOORS OPEN		X		
S212	212			X		52-71-11
S213	213			X		52-71-11
S214 *	214			X		52-71-13
S215	215			X		52-71-13
S216 	216			X		52-71-12
S217 	217			X		
S218	218			X		
S219	219			X		
S232	232	LANDING GEAR SYSTEM NO. 1	X		32-61-03	32-61-13
S233 *	233	(POSITION INDICATION)	X			
S234	234	MODE: NOSE GEAR EXTENDED,		X		
S235	235	FWD NOSE GEAR DOORS CLOSED		X		
S236 *	236	LANDING GEAR SYSTEM NO. 1	X		32-61-02	32-61-11
S237	237	(POSITION INDICATION)	X			
S238	238	MODE: MAIN GEAR EXTENDED,	X			
S240 *	240	MAIN GEAR DOORS CLOSED	X			32-61-12
S241	241		X			32-61-12
S242	242		X			32-61-11
S244	244	LANDING GEAR SYSTEM NO. 1		X	32-09-08	32-09-11
S245	245	(AIR/GROUND)		X	32-09-07	
S246	246	MODE: ON GROUND		X		
S247 	247	LANDING GEAR SYSTEM NO. 1	X		32-61-04	32-71-11
S248 	248	(TAIL SKID) MODE: TAIL SKID EXTENDED		X		
S254	254	LANDING GEAR SYSTEM NO. 2	X		32-61-03	32-61-13
S255 *	255	(POSITION INDICATION)	X			
S256	256	MODE: NOSE GEAR EXTENDED,	X			
S257	257	FWD NOSE GEAR DOORS CLOSED	X			
S258 *	258	LANDING GEAR SYSTEM NO. 2	X		32-61-02	32-61-11
S259	259	(POSITION INDICATION)	X			
S260	260	MODE: MAIN GEAR EXTENDED,	X			
S262 *	262	MAIN GEAR DOORS CLOSED	X			32-61-12
S263	263		X			32-61-12
S264	264		X			32-61-11
S266	266	LANDING GEAR SYSTEM NO. 2		X	32-09-08	32-09-12
S267	267	(AIR/GROUND)		X	32-09-07	
S268	268	MODE: ON GROUND		X		

TABLE 105

ALL THE SENSORS ARE RECTANGULAR TYPE EXCEPT THOSE NOTED BY \*

 THE DOOR DOES NOT CLOSE FULLY WHEN THE NOSE GEAR IS EXTENDED.

BITE Procedure for the PSEU Sensor Target Test  
Figure 104 (Sheet 5)

EFFECTIVITY

ALL
-----

32-09-03


**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

SENSOR NUMBER	PSEU CODE	SYSTEM/MODE	TARGET		AMM REF	WDM REF
			NEAR	FAR		
S276	276	LEADING EDGE SLAT SYSTEM MODE: X1 = SLATS FULLY RETRACTED X2 = SLATS TAKEOFF (FLAP LEVER 1-20) X3 = SLATS FULLY EXTENDED (FLAP LEVER 25-30)	X1,X3	X2	27-88-01	27-88-12
S277	277		X1,X3	X2		
S278	278		X1,X3	X2		
S279	279		X1,X3	X2		
S280	280		X1,X3	X2		
S281	281		X1,X3	X2		
S282	282		X1,X2	X3		
S283	283		X1,X2	X3		
S284	284		X1,X2	X3		
S285	285		X1,X2	X3		
S286	286		X1,X2	X3		
S287	287		X1,X2	X3		
S294	294		X1,X3	X2		
S295	295		X1,X3	X2		
S296	296		X1,X3	X2		
S297	297		X1,X3	X2		
S298	298		X1,X3	X2		
S299	299		X1,X3	X2		
S300	300		X1,X2	X3		
S301	301		X1,X2	X3		
S302	302	X1,X2	X3			
S303	303	X1,X2	X3			
S304	304	X1,X2	X3			
S305	305	X1,X2	X3			

TABLE 105

ALL THE SENSORS ARE RECTANGULAR TYPE EXCEPT THOSE NOTED BY \*

BITE Procedure for the PSEU Sensor Target Test  
Figure 104 (Sheet 6)



**32-09-03**

02

Page 119  
May 10/95

192253


**PREREQUISITES**

EQUIPMENT OHMMETER 0-50 OHM RANGE

**NOTE:** USE THIS PROCEDURE IF YOU HAVE AN INTERMITTENT PSEU/SENSOR FAULT AND/OR THE PROBLEM CANNOT BE FOUND WITH THE OTHER FIM PROCEDURES.

**NOTE:** THERE IS AN INDUCTANCE TEST IN FIG. 108 AS WELL FOR SENSOR FAULTS PROTECTION.

**PROXIMITY SENSOR/  
WIRING RESISTANCE  
CHECK**



1 DO THIS CHECK FOR THE FAULTED SENSOR(S) OR THE SENSORS FROM THE SUSPECTED BAD SUBSYSTEM OR CARD.

2 USE TABLE A TO VERIFY THE RESISTANCE VALUES IN RELATION TO A GIVEN SENSOR PART NUMBER

Proximity Sensor/Wiring Resistance Check  
Figure 105 (Sheet 1)

EFFECTIVITY

ALL


**32-09-03**

03

Page 120  
Aug 22/07





**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL



SENSOR	TARGET NEAR	TARGET FAR	RESISTANCE (TARGET FAR)
8-344-01, -02	5.2mh TO 9mh	4.7mh TO 4.92mh	6 TO 11 ohms
8-344-03	5.2mh TO 9mh	4.7mh TO 4.92mh	12 TO 16 ohms
8-345-03	5.2mh TO 9mh	4.7mh TO 4.92mh	12 TO 16 ohms
8-518-01	5.2mh TO 9mh	4.7mh TO 4.92mh	12 TO 16 ohms
8-935-01	5.2mh TO 10mh	4.72mh TO 4.92mh	16 TO 21 ohms
80-161-01	5.2mh TO 12mh	4.72mh TO 4.92mh	16 TO 21 ohms

TABLE A  
FUNCTIONAL LIMITS

Proximity Sensor/Wiring Resistance Check  
Figure 105 (Sheet 2)



32-09-03

01

Page 121  
Aug 22/07


651930

**PREREQUISITES**

MAKE SURE THIS CIRCUIT BREAKER IS OPEN AND ATTACH A DO-NOT-CLOSE TAG:  
11G11

**WARNING:** DO THE DEACTIVATION PROCEDURE FOR THE SPOILER OR MOVE ALL PERSONS AND EQUIPMENT AWAY FROM THE SPOILERS (AMM 27-61-00/201). THE SPOILERS CAN RETRACT QUICKLY AND CAN CAUSE INJURIES TO PERSONS OR DAMAGE TO EQUIPMENT.

**UNDEFINED PSEU BITE CODES APPEAR**




1 REMOVE THE DO-NOT-CLOSE TAG AND CLOSE THE CIRCUIT BREAKER THAT WAS OPENED IN THE PREREQUISITE BLOCK.


Undefined PSEU BITE Codes Appear  
Figure 106 (Sheet 1)

EFFECTIVITY	ALL
-------------	-----

**32-09-03**



Undefined PSEU BITE Codes Appear  
Figure 106 (Sheet 2)



32-09-03



**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

UNDEFINED PSEU BITE CODES	
FROM	TO
17	24
306	3FF
412	420
429	4FF
509	878
902	998
99A	AA9
AAB	CCB
CCD	DDC
DDE	EED
EEF	FFF

**TABLE 107**

NOTE: ALL OTHER CODES ARE DEFINED

Undefined PSEU BITE Codes Appear  
Figure 106 (Sheet 3)



32-09-03

01

Page 124  
Aug 10/95

F20943

**PREREQUISITES**

MAKE SURE THIS SYSTEM WILL OPERATE:  
EICAS (AMM 31-41-00/201)

MAKE SURE THIS CIRCUIT BREAKER IS OPEN AND ATTACH A  
DO-NOT-CLOSE TAG:  
11G11


MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
AIRPLANE IS ON THE GROUND WITH THE LANDING GEAR  
DOWN AND LOCKED  
SPOILERS ARE RETRACTED (AMM 27-61-00/201)  
THRUST REVERSERS ARE RETRACTED  
AUTO SPEEDBRAKE LEVER IS IN THE DOWN-AND-LOCKED  
POSITION

NOTE: USE THIS PROCEDURE IF YOU HAVE RUN THE BITE  
AND ARE INSTRUCTED TO REPLACE THE PSEU OR  
CANNOT ELIMINATE THE PROBLEM BY REPLACING  
OTHER COMPONENTS.

NOTE: FOR EACH EICAS MESSAGE LISTED IN THE FOLLOWING  
TABLE, THERE IS AN ASSOCIATED PROXIMITY CARD,  
LOGIC CARD AND DRIVER CARD. THE DRIVER CARDS  
ARE INTERCHANGEABLE AND CAN BE SWAPPED BETWEEN  
CARD SLOT LOCATIONS FOR FAULT ISOLATION. THE  
PROXIMITY CARDS ARE INTERCHANGEABLE AND CAN BE  
SWAPPED BETWEEN CARD SLOT LOCATIONS. THE  
LOGIC CARDS ARE NOT INTERCHANGEABLE.

**EICAS MESSAGE  
PSEU CARD FAULT  
ISOLATION PROCEDURE**



1. IF YOU HAVE RECORDED OR CURRENTLY SEE AN EICAS MESSAGE LISTED IN THE FOLLOWING TABLE, REPLACE A CARD.
  - A. REPLACE THE ASSOCIATED LOGIC CARD WITH A NEW CARD.
  - B. REPLACE THE ASSOCIATED PROXIMITY AND DRIVER CARD WITH CARDS FROM ANOTHER PSEU SLOT OR A NEW CARD.
  - C. REPLACE THE CARDS BY USING THE PSEU CARD REPLACEMENT PROCEDURE (AMM 32-09-06/401).
2. ERASE THE EICAS MESSAGE (AMM 31-41-00, FIG. 109).
3. CHECK TO SEE IF THE EICAS MESSAGE RETURNS AND FOLLOWS THE SUSPECT CARD.
4. IF THE MESSAGE RETURNS IN THE SAME CARD LOCATION OR WITH THE SAME EICAS MESSAGE, REPLACE THE PSEU (AMM 32-09-04/401).
  - A. IF THE FAULT FOLLOWS THE CARD, REPLACE THE CARD (AMM 32-09-06/401). 

-  REMOVE ANY DO-NOT-CLOSE TAG AND CLOSE THE CIRCUIT BREAKER THAT WAS OPENED IN THE PREREQUISITE BLOCK.

EICAS Message PSEU Card Fault Isolation Procedure  
Figure 107 (Sheet 1)

EFFECTIVITY	ALL
-------------	-----


32-09-03

**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

EICAS MESSAGE	DRIVER/LOGIC/PROX CARD SLOT	WDM REFERENCE OF EICAS OUTPUT
AFT CARGO DOOR	6/11/1	52-71-11
E/E ACCESS COOR	7/5/3 OR 4	52-71-11
FWD ACCESS DOOR	7/5/3 OR 4	52-71-11
FWD CARGO DOOR	7/11/1	52-71-11
L AFT ENT DOOR	6/5/3 OR 4	52-71-11
L CTR ENT DOOR	6/5/3 OR 4	52-71-11
L EMER DOOR	6/5/3 OR 4	52-71-12
L ENTRY DOORS	6/11/16	52-71-11
L FWD EMER DOOR	6/5/3 OR 4	52-71-12
L FWD ENT DOOR	7/5/3 OR 4	52-71-11
L WING SLIDE	7/5/3 OR 4	52-71-12
R AFT EMER DOOR	12/5/3 OR 4	52-71-12
R AFT ENT DOOR	6/5/3 OR 4	52-71-11
R CTR ENT DOOR	10 OR 12/5/3 OR 4	52-71-11
R EMER DOOR	6/5/3 OR 4	52-71-12
R ENTRY DOORS	7/11/16	52-71-11
R FWD ENT DOOR	7/5/3 OR 4	52-71-11
R WING SLIDE	7/5/3 OR 4	52-71-12
L REV ISLN VAL	12/11/13 OR 16	78-36-11,-21
L T/R IN TRANSIT	10/11/13 OR 16	78-36-11,-21
L THR REVERSER	10/11/13 OR 16	78-36-11,-21
R REV ISLN VAL	7/5/2 OR 3	78-36-11,-21
R T/R IN TRANSIT	6/5/2 OR 3	78-36-11,-21
R THR REVERSER	6/5/2 OR 3	78-36-11,-21
ALL GEAR DOWN	10 OR 6/11 OR 5/15 OR 2	32-61-14
GEAR DOORS	10 OR 6/11 OR 5/15 OR 2	32-61-14
GEAR DISAGREE	12 OR 6/11 OR 5/15 OR 2	32-61-14
L DRAG BRACE	10 OR 6/11 OR 5/15 OR 2	32-61-14
L SIDE BRACE	10 OR 6/11 OR 5/15 OR 2	32-61-14
NOSE GEAR DOWN	10 OR 6/11 OR 5/15 OR 2	32-61-14
NOSE GEAR LOCKED	10 OR 7/11 OR 5/15 OR 2	32-61-14
R DRAG BRACE	10 OR 6/11 OR 5/15 OR 2	32-61-14
R SIDE BRACE	10 OR 6/11 OR 5/15 OR 2	32-61-14
TAIL SKID	12/11 OR 5/15 OR 2	32-61-14

EICAS MESSAGE TO PSEU CARD REFERENCE

EICAS Message PSEU Card Fault Isolation Procedure  
Figure 107 (Sheet 2)



32-09-03


**PREREQUISITES**

- EQUIPMENT:**
1. OHMMETER 0-1 MEG OHM
  2. INDUCTANCE METER WITH AN EXCITATION FREQUENCY OF 1000 Hz

**NOTE:** YOU MAY USE THIS PROCEDURE IF YOU HAVE AN INTERMITTENT PSEU/SENSOR FAULT OR THE PROBLEM CANNOT BE FOUND WITH THE OTHER FIM PROCEDURES.

**NOTE:** DO NOT USE A DEACTUATOR TO SIMULATE THE "TARGET FAR" POSITION FOR SENSOR INDUCTANCE TROUBLESHOOTING. YOU COULD GET FALSE INDICATIONS.

**PROXIMITY SENSOR/  
INDUCTANCE AND  
RESISTANCE CHECK**



Proximity Sensor/Inductance and Resistance Check  
Figure 108 (Sheet 1)


EFFECTIVITY

ALL

**32-09-03**

03

Page 127  
Aug 22/06




Proximity Sensor/Inductance and Resistance Check  
Figure 108 (Sheet 2)

EFFECTIVITY	ALL
-------------	-----

32-09-03





Proximity Sensor/Inductance and Resistance Check  
Figure 108 (Sheet 3)

EFFECTIVITY

---

ALL

32-09-03

01

Page 129  
Apr 22/01

651919

 **BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

MAIN LANDING GEAR AND DOORS

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
BRACE - LOWER DRAG	1	2	MAIN WHEEL WELL (L,R), DRAG BRACE ASSEMBLY	32-11-12
BRACE - LOWER SIDE	2	2	MAIN WHEEL WELL (L,R), SIDE BRACE ASSEMBLY	32-11-05
BRACE - UPPER DRAG	1	2	MAIN WHEEL WELL (L,R), DRAG BRACE ASSEMBLY	32-11-11
BRACE - UPPER SIDE	2	2	MAIN WHEEL WELL (L,R), SIDE BRACE ASSEMBLY	32-11-04
BRACE ASSEMBLY - DRAG	1	2	MAIN WHEEL WELL (L,R)	32-11-10
BRACE ASSEMBLY - SIDE	2	2	MAIN WHEEL WELL (L,R)	32-11-03
DOOR - DRAG BRACE	1	2	MAIN WHEEL WELL (L,R)	32-12-08
DOOR - MAIN LANDING GEAR	1	2	732,742, MAIN WHEEL WELL (L,R)	32-12-01
DOOR - POP-UP	1	2	551ET, 651ET, TOP OF WING (L,R)	32-12-13
DOOR - SHOCK STRUT	1	2	734,744, MAIN WHEEL WELL (L,R)	32-12-06
DOOR - TRUNNION	1	2	735,745, MAIN WHEEL WELL (L,R)	32-12-11
LINK - LOWER TORSION	2	2	MAIN GEAR (L,R)	32-11-22
LINK - SIDE BRACE LOCK	2	2	MAIN WHEEL WELL (L,R), SIDE BRACE ASSEMBLY	32-11-08
LINK - UPPER TORSION	2	2	MAIN GEAR (L,R)	32-11-22
ROD - BRAKE	1	8	MAIN GEAR (L,R)	32-11-20
SEALS - SHOCK STRUT	2	12	MAIN GEAR SHOCK STRUT (L,R)	32-11-25
SPINDLE - DRAG BRACE LOWER	1	2	MAIN WHEEL WELL (L,R) DRAG BRACE ASSEMBLY	32-11-13
SPINDLE - DRAG BRACE UPPER	1	2	MAIN WHEEL WELL (L,R) DRAG BRACE ASSEMBLY	32-11-13
SPINDLE - JURY STRUT	1	2	MAIN WHEEL WELL (L,R) DRAG BRACE ASSEMBLY	32-11-16
SPINDLE - SIDE BRACE LOCK LINK	2	2	MAIN WHEEL WELL (L,R), SIDE BRACE ASSEMBLY	32-11-09
SPINDLE - SIDE BRACE LOWER	2	2	MAIN WHEEL WELL (L,R), SIDE BRACE ASSEMBLY	32-11-06
SPINDLE - SIDE BRACE UPPER	2	2	MAIN WHEEL WELL (L,R), SIDE BRACE ASSEMBLY	32-11-06
SPRING - JURY STRUT	1	6	MAIN WHEEL WELL (L,R), DRAG BRACE ASSEMBLY	32-32-05
SPRING - SIDE BRACE LOCK	2	4	MAIN WHEEL WELL (L,R), SIDE BRACE ASSEMBLY	32-32-03
STRUT - SHOCK	1	2	MAIN GEAR (L,R)	32-11-02
STRUT ASSEMBLY - JURY	1	2	MAIN WHEEL WELL (L,R). DRAG BRACE ASSEMBLY	32-11-15
TRUCK ASSEMBLY	1	2	MAIN GEAR (L,R)	32-11-18
WHEEL/TIRE ASSEMBLY	1	8	MAIN GEAR (L,R)	32-45-01

Main Landing Gear and Doors - Component Index  
Figure 101


EFFECTIVITY

ALL

**32-10-00**

01


Page 101  
Feb 10/91



Main Landing Gear and Doors - Component Location  
Figure 102 (Sheet 1)


EFFECTIVITY	
ALL	

**32-10-00**




SIDE BRACE ASSEMBLY

(D)



TORSION LINK

(E)



SHOCK STRUT SEALS

A-A

Main Landing Gear and Doors - Component Location  
Figure 102 (Sheet 2)

EFFECTIVITY	
	ALL

32-10-00

01


Page 103  
Feb 10/91


**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

NOSE LANDING GEAR AND DOORS

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
BEAM - ACTUATOR SUPPORT	2	1	NOSE WHEEL WELL	32-21-04
DOOR - AFT	1	2	715,716, NOSE WHEEL WELL	32-22-04
DOOR - FORWARD	1	2	713,714, NOSE WHEEL WELL	32-22-01
FITTING - AFT TOW	2	1	NOSE GEAR	32-21-12
FITTING - FORWARD TOW	2	1	NOSE GEAR	32-21-12
LINK - AFT LOCK	2	1	NOSE WHEEL WELL	32-21-07
LINK - FORWARD LOCK	2	1	NOSE WHEEL WELL	32-21-07
LINK - LOWER TORSION	2	1	NOSE GEAR	32-21-11
LINK - SUPPORT	2	1	NOSE WHEEL WELL	32-21-00
LINK - UPPER TORSION	2	1	NOSE GEAR	32-21-11
MECHANISM - FORWARD DOOR OPERATING	1	2	NOSE WHEEL WELL	32-22-02
SEAL - SHOCK STRUT	2	6	NOSE GEAR SHOCK STRUT	32-21-25
SPRING - LOCK	2	2	NOSE WHEEL WELL	32-21-09
STRUT - LOWER DRAG	2	1	NOSE WHEEL WELL	32-21-05
STRUT - SHOCK	2	1	NOSE WHEEL WELL	32-21-00
STRUT - UPPER DRAG	2	1	NOSE WHEEL WELL	32-21-05
WHEEL/TIRE ASSEMBLY	2	2	NOSE GEAR	32-45-02

Nose Landing Gear and Doors - Component Index  
Figure 101





32-20-00

01

Page 101  
May 10/94

E14483



NOSE LANDING GEAR DOORS


(A)

Nose Landing Gear and Doors - Component Location  
Figure 102 (Sheet 1)


EFFECTIVITY	
	ALL

**32-20-00**

**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL



(B)



**SHOCK STRUT SEALS**

(C)

**Nose Landing Gear and Doors - Component Location  
Figure 102 (Sheet 2)**

EFFECTIVITY	
	ALL

94646

**32-20-00**

01

Page 103  
May 10/94

 **BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

LANDING GEAR EXTENSION AND RETRACTION

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
ACTUATOR - LANDING GEAR ALTERNATE EXTEND, M1104	9	1	119AL, MAIN EQUIP CTR	32-35-12
ACTUATOR - MAIN GEAR DOOR	2	2	LEFT & RIGHT MAIN WHEEL WELLS	32-32-12
ACTUATOR - MAIN GEAR DOOR ARMING LOCKOUT	3	2	LEFT & RIGHT MAIN WHEEL WELLS	32-35-11
ACTUATOR - MAIN GEAR DOOR LATCH	3	2	LEFT & RIGHT MAIN WHEEL WELLS, DOOR UPLOCK RELEASE MECHANISM HOUSING	32-32-13
ACTUATOR - MAIN GEAR DRAG BRACE LOCK	5	2	LEFT & RIGHT MAIN GEAR	32-32-02
ACTUATOR - MAIN GEAR RETRACT	6	2	551TB,651TB, WING ACCESS PANELS	32-32-01
ACTUATOR - MAIN GEAR SIDE BRACE LOCK	5	2	LEFT & RIGHT MAIN GEAR	32-32-02
ACTUATOR - NOSE GEAR LOCK	7	1	NOSE WHEEL WELL	32-34-02
ACTUATOR - NOSE GEAR RETRACT	8	1	NOSE WHEEL WELL	32-34-01
CABLES - LANDING GEAR EXTENSION AND RETRACTION	11	8	113AL, FWD EQUIP BAY TO SELECTOR VALVES IN RIGHT MAIN WHEEL WELL	32-00-25
CABLES - MAIN GEAR ALTERNATE EXTENSION	11	10	119AL, MAIN EQUIP CTR TO DOOR UPLOCK RELEASE QUADRANT ABOVE MAIN WHEEL WELLS	32-00-25
CABLES - MAIN GEAR DOOR GROUND RELEASE	11	4	197BL,198BR, MLG DOOR GROUND RELEASE LEVER ACCESS DOOR FORWARD AND UP TO DOOR UPLOCK RELEASE GROUND QUADRANT IN MAIN WHEEL WELL	32-00-25
CAM BOX - MAIN GEAR GEAR-OPERATED SEQUENCE VALVE	3	2	LEFT & RIGHT MAIN WHEEL WELLS	32-32-09
CARTRIDGE - NOSE WHEEL STEERING SPRING	8	1	NOSE WHEEL WELL	32-34-06
CIRCUIT BREAKERS	1		FLT COMPT, P6,P11	
LANDING GEAR ALTN EXT LATCH RST, C1177		1	11U14	*
LANDING GEAR ALTN EXT MOTOR, C4248		1	6F6	*
LANDING GEAR LEVER LOCK, C1174		1	11U20	*
CRANK - MAIN GEAR ALTERNATE EXTEND UPLOCK RELEASE	3	2	LEFT & RIGHT MAIN WHEEL WELLS	32-35-03
CYLINDER - MAIN GEAR TRANSFER	6	2	552CB,652CB, WING ACCESS PANELS	32-32-10
CYLINDER - NOSE GEAR TRANSFER	7	1	NOSE WHEEL WELL	32-34-04
DRUM AND LOCKOUT - NOSE WHEEL STEERING	8	1	NOSE WHEEL WELL	32-34-05
FUSE - MAIN GEAR TRUCK POSITIONER	6	4	552CB,652CB, WING ACCESS PANELS	32-32-19
HOOK - MAIN GEAR DOOR UPLOCK	3	2	LEFT & RIGHT MAIN WHEEL WELLS	32-32-14
LEVER - MAIN GEAR DOOR GROUND RELEASE	10	2	197BL,198BR, MLG DOOR GROUND RELEASE LEVER ACCESS DOOR	32-35-05
LOAD LIMITER - MAIN GEAR ALTERNATE EXTEND	9	2	119AL, MAIN EQUIP CTR	32-35-14
LOAD LIMITER - NOSE GEAR ALTERNATE EXTEND	9	1	119AL, MAIN EQUIP CTR	32-35-15
MODULE - LANDING GEAR CONTROL LEVER, M937	1	1	FLT COMPT, P3	32-31-01
POSITIONER - MAIN GEAR TRUCK	5	2	MAIN GEAR	32-32-18
QUADRANT - LANDING GEAR ALTERNATE EXTEND	9	2	119AL, MAIN EQUIP CTR	32-35-13
QUADRANT - LANDING GEAR CONTROL LEVER	1	1	FLT COMPT, P3, BEHIND CONTROL LEVER MODULE M937	32-31-00
QUADRANT - LANDING GEAR SELECTOR VALVE	4	1	ON TOP OF RIGHT MAIN WHEEL WELL DIRECTLY ABOVE LANDING GEAR SELECTOR VALVES	32-31-03
QUADRANT - MAIN GEAR ALTERNATE EXTEND UPLOCK RELEASE GROUND	3	2	LEFT & RIGHT MAIN WHEEL WELLS	32-35-07
QUADRANT - MAIN GEAR DOOR GROUND RELEASE	10	2	197BL,198BR, MLG DOOR GROUND RELEASE LEVER ACCESS DOOR	32-35-05

\* SEE WM EQUIPMENT LIST

Component Index  
Figure 101 (Sheet 1)

EFFECTIVITY

ALL

32-30-00

01

Page 101  
Dec 22/04

38807




**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL




COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
RELAY - (REF 32-09-00, FIG. 101) SYS NO. 1 AIR/GND, K147 SYS NO. 2 AIR/GND, K209 SOLENOID - LANDING GEAR LEVER LOCK, YGBM1	1	1	FLT COMPT, P3, CONTROL LEVER MODULE M937	*
SWITCH - (REF 27-62-00, FIG. 101) GEAR TILT PRESSURE, S452,S453	1	1	FLT COMPT, P3	*
SWITCH - LANDING GEAR ALTERNATE EXTENSION SELECT, S605	9	2	119AL, MAIN EQUIP CTR, ALTERNATE EXTEND ACTUATOR M1104	*
SWITCH - LDG GR ALTN RETN, S606,S607	1	2	FLT COMPT, P3, CONTROL LEVER MODULE, M937	*
SWITCH - LANDING GEAR LEVER POSITION, DOWN, YBGS3,YBGS4	1	2	FLT COMPT, P3, CONTROL LEVER MODULE, M937	*
SWITCH - LANDING GEAR LEVER POSITION, OFF, YBGS2,YBGS6	1	2	FLT COMPT, P3, CONTROL LEVER MODULE, M937	*
SWITCH - LANDING GEAR LEVER POSITION, UP, YBGS1,YBGS5	1	2	FLT COMPT, P3, CONTROL LEVER MODULE, M937	*
VALVE - MAIN GEAR DOOR SAFETY	3	2	LEFT & RIGHT MAIN WHEEL WELLS, DOOR UPLOCK RELEASE MECHANISM HOUSING	32-35-10
VALVE - MAIN GEAR DOOR-OPERATED SEQUENCE	2	2	LEFT & RIGHT MAIN WHEEL WELLS	32-32-06
VALVE - MAIN GEAR GEAR-OPERATED SEQUENCE	3	2	LEFT & RIGHT MAIN WHEEL WELLS	32-32-08
VALVE - NOSE GEAR PRIORITY	7	1	NOSE WHEEL WELL	32-34-00
VALVES - LANDING GEAR SELECTOR	4	2	RIGHT MAIN WHEEL WELL	32-31-02

\* SEE WM EQUIPMENT LIST


Component Index  
Figure 101 (Sheet 2)



**32-30-00**



**LANDING GEAR LEVER POSITION SWITCHES**  
A-A




**Landing Gear Extension and Retraction - Component Location**  
Figure 102 (Sheet 1)


EFFECTIVITY	
	ALL

**32-30-00**

**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL




**LEFT MAIN WHEEL WELL  
(RIGHT MAIN WHEEL WELL IS EQUIVALENT)**



Landing Gear Extension and Retraction - Component Location  
Figure 102 (Sheet 2)

EFFECTIVITY	
	ALL


**32-30-00**



LEFT OR RIGHT MAIN GEAR  
DOOR UPLOCK MECHANISM  
SEE (G)

LEFT MAIN WHEEL WELL OUTBOARD WALL  
(RIGHT MAIN WHEEL WELL OUTBOARD WALL  
IS EQUIVALENT)


(F) FROM SHT 2



LEFT OR RIGHT MAIN GEAR DOOR  
ARMING LOCKOUT ACTUATOR

(H)

LEFT OR RIGHT MAIN GEAR GEAR-OPERATED  
SEQUENCE VALVE AND CAM BOX  
SEE (I) SHT 4



LEFT OR RIGHT MAIN GEAR  
DOOR ARMING LOCKOUT  
ACTUATOR  
SEE (H)

LEFT OR RIGHT  
MAIN GEAR  
ALTERNATE EXTEND  
UPLOCK RELEASE  
GROUND QUADRANT

LEFT OR RIGHT MAIN  
GEAR ALTERNATE  
EXTEND UPLOCK  
RELEASE CRANK

LEFT OR RIGHT  
MAIN GEAR DOOR  
LATCH ACUATOR

LEFT OR RIGHT  
MAIN GEAR  
DOOR SAFETY  
VALVE

LEFT OR RIGHT  
MAIN GEAR DOOR  
UPLOCK HOOK

LEFT OR RIGHT MAIN GEAR DOOR UPLOCK RELEASE MECHANISM

(G)

Landing Gear Extension and Retraction - Component Location  
Figure 102 (Sheet 3)


EFFECTIVITY

ALL

32-30-00

01


Page 105  
Dec 22/04



Landing Gear Extension and Retraction - Component Location  
Figure 102 (Sheet 4)


EFFECTIVITY	
	ALL

32-30-00



LEFT OR RIGHT MAIN GEAR LOCK ACTUATORS

(L)



LEFT OR RIGHT MAIN GEAR TRUCK POSITIONER

(M)

Landing Gear Extension and Retraction - Component Location  
Figure 102 (Sheet 5)

EFFECTIVITY

ALL


32-30-00

01

Page 107  
Dec 22/04

38811


**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL



Landing Gear Extension and Retraction - Component Location  
Figure 102 (Sheet 6)

EFFECTIVITY	
	ALL

32-30-00




Landing Gear Extension and Retraction – Component Location  
Figure 102 (Sheet 7)

EFFECTIVITY	
	ALL

**32-30-00**




NOSE GEAR ACTUATOR  
SUPPORT BEAM (REF)



ACTUATOR

NOSE GEAR RETRACT ACTUATOR

(V)



NOSE WHEEL STEERING  
DRUM AND LOCKOUT


SEE (W)

NOSE GEAR  
RETRACT ACTUATOR  
SEE (V)

NOSE WHEEL  
STEERING  
SPRING  
CARTRIDGE

SEE (X)

COVER  
(REF)



SPRING  
CARTRIDGE  
(REF)

SHOCK  
STRUT  
(REF)

NOSE WHEEL STEERING DRUM AND LOCKOUT

(W)

NOSE GEAR  
AFT LOCK LINK (REF)

NOSE WHEEL  
STEERING DRUM  
AND LOCKOUT  
(REF)

SPRING  
CARTRIDGE

NOSE WHEEL STEERING SPRING CARTRIDGE

(X)

FWD

Landing Gear Extension and Retraction – Component Location  
Figure 102 (Sheet 8)

EFFECTIVITY

ALL

32-30-00


01

Page 110  
Dec 22/04

# BOEING

## 767

### FAULT ISOLATION/MAINT MANUAL




Landing Gear Extension and Retraction - Component Location  
Figure 102 (Sheet 9)


EFFECTIVITY	ALL
-------------	-----

32-30-00

**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL



AFT WING/BODY FAIRING  
SEE (AB)




MLG DOOR GROUND CONTROL HANDLE ACCESS DOOR, 197BL (LEFT), 198BR (RIGHT)

LEFT OR RIGHT MAIN GEAR DOOR GROUND RELEASE LEVER  
SEE (AC)

AFT LEFT WING/BODY FAIRING  
(AFT RIGHT WING/BODY FAIRING IS EQUIVALENT)

(AB)




LEFT OR RIGHT MAIN GEAR DOOR GROUND RELEASE LEVER

(AC)


Landing Gear Extension and Retraction - Component Location  
Figure 102 (Sheet 10)

EFFECTIVITY	ALL
-------------	-----

**32-30-00**



**LANDING GEAR EXTENSION  
AND RETRACTION CONTROL CABLES**



**MAIN GEAR ALTERNATE EXTENSION  
AND DOOR GROUND RELEASE CONTROL CABLES**

**Landing Gear Extension and Retraction – Component Location  
Figure 102 (Sheet 11)**

EFFECTIVITY	
	ALL


**32-30-00**

01

Page 113  
Dec 22/04

105052

Not Used  
Figure 103



**32-30-00**

01

Page 114  
Nov 01/83

102108


GEAR LEVER WOULD NOT MOVE TO "UP" POS INFLT. WAS FREE TO MOVE TO "UP" POS WHEN "LOCK OVRD" PUSHED.

**PREREQUISITES**

MAKE SURE THIS CIRCUIT BREAKER IS CLOSED:  
11U20

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:

- ELECTRICAL POWER IS ON (AMM 24-22-00/201)
- CENTER HYDRAULIC SYSTEM IS PRESSURIZED (AMM 29-11-00/201)
- DOOR LOCKS ARE INSTALLED (AMM 32-00-15/201)
- DOWNLOCKS ARE INSTALLED ON LANDING GEAR (AMM 32-00-20/201)




Gear Lever Would not Move to UP Pos Inflt. Was Free to Move to UP Pos when LOCK OVRD Pushed.  
Figure 104 (Sheet 1)

EFFECTIVITY	ALL
-------------	-----

**32-30-00**

FROM SHEET 1  
(BLOCK 4)



Gear Lever Would not Move to UP Pos Inflt. Was Free to Move to UP Pos when  
LOCK OVRD Pushed.  
Figure 104 (Sheet 2)

EFFECTIVITY

ALL

**32-30-00**

01


Page 116  
Aug 22/01

EICAS MSG "GEAR DOORS" DISPLAYED AND "DOORS" AMBER LGT ILLUM WITH GEAR DN

**PREREQUISITES**

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:

- ELECTRICAL POWER IS ON (AMM 24-22-00/201)
- CENTER HYDRAULIC SYSTEM IS PRESSURIZED (AMM 29-11-00/201)
- DOWNLOCKS ARE INSTALLED ON LANDING GEAR (AMM 32-00-20/201)




EICAS Msg GEAR DOORS Displayed and DOORS Amber Lgt Illum With Gear Dn  
Figure 105 (Sheet 1)

EFFECTIVITY	ALL
-------------	-----

**32-30-00**





EICAS Msg GEAR DOORS Displayed and DOORS Amber Lgt Illum With Gear Dn  
Figure 105 (Sheet 2)

EFFECTIVITY	ALL
-------------	-----


32-30-00

EICAS MSG "GEAR  
DOORS" DISPLAYED AND  
"DOORS" AMBER LGT  
SLOW TO EXTN AFTER  
GEAR EXTENSION

**PREREQUISITES**

MAKE SURE THIS SYSTEM WILL OPERATE:  
EICAS (AMM 31-41-00/201)

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
CENTER HYDRAULIC SYSTEM IS PRESSURIZED  
(AMM 29-11-00/201)  
DOORLOCKS ARE INSTALLED (AMM 32-00-15/201)



EICAS Msg GEAR DOORS Displayed and DOORS Amber Lgt Slow to Extn After  
Gear Extension  
Figure 105A

EFFECTIVITY

ALL

**32-30-00**


01

Page 119  
Feb 10/91

224058

"NOSE" GEAR GREEN DN LGT FAILED TO ILLUM WITH GEAR HANDLE "DN". EICAS MSG "GEAR DISAGREE" DISPLAYED. "DOORS" AMBER LGT WAS EXTIN AND "GEAR" LGT WAS ILLUM. INDICATIONS WERE NORM AFTER ALT GEAR EXT.

**PREREQUISITES**  
NONE



NOSE Gear Green Dn Lgt Failed to Illum with Gear Handle DN. EICAS Msg GEAR DISAGREE Displayed. DOORS Amber Lgt was Extin and GEAR Lgt was Illum. Indications were Norm after Alt Gear Ext.

Figure 106


EFFECTIVITY

ALL
-----

32-30-00

PREREQUISITES  
NONE

"NOSE" GEAR GREEN  
DN LGT FAILED TO  
ILLUM WITH GEAR  
HANDLE "DN". EICAS  
MSG "GEAR DISAGREE"  
DISPLAYED. "DOORS"  
AMBER LGT WAS EXTIN  
AND "GEAR" LGT WAS  
ILLUM. ALT GEAR  
EXT WAS ATTEMPTED.



NOSE Gear Green Dn Lgt Failed to Illum with Gear Handle DN. EICAS Msg GEAR  
DISAGREE Displayed. DOORS Amber Lgt was Extin and GEAR Lgt was Illum.  
Alt Gear Ext was Attempted.

Figure 107

EFFECTIVITY

ALL
-----


32-30-00

GEAR GREEN DN LGT  
FAILED TO ILLUM  
WITH GEAR HANDLE  
"DN". EICAS MSG  
"GEAR DOORS" AND  
"GEAR DISAGREE"  
DISPLAYED. "DOORS"  
AND "GEAR" AMBER  
LGT ILLUM. ALT GEAR  
EXT WAS ATTEMPTED.

**PREREQUISITES**

MAKE SURE THIS SYSTEM WILL OPERATE:  
CENTER HYDRAULIC SYSTEM (AMM 29-11-00/201)

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT  
FOLLOWS:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
DOOR LOCKS ARE INSTALLED (AMM 32-00-15/201)




Gear Green Dn Lgt Failed to Illum with Gear Handle DN.  
EICAS Msg GEAR DOORS and GEAR DISAGREE Displayed. DOORS and GEAR Amber Lgt Illum.  
Alt Gear Ext was Attempted.  
Figure 108 (Sheet 1)

EFFECTIVITY	ALL
-------------	-----

**32-30-00**


**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL



Gear Green Dn Lgt Failed to Illum with Gear Handle DN.  
 EICAS Msg GEAR DOORS and GEAR DISAGREE Displayed. DOORS and GEAR Amber Lgt Illum.  
 Alt Gear Ext was Attempted.  
 Figure 108 (Sheet 2)

EFFECTIVITY

---

ALL

32-30-00

01


Page 123  
Aug 22/01

GEAR GREEN DN LGT  
 FAILED TO ILLUM  
 WITH GEAR HANDLE  
 "DN". EICAS MSG  
 "DRAG BRACE"  
 DISPLAYED. "GEAR"  
 AMBER LGT WAS  
 ILLUM.

**PREREQUISITES**

MAKE SURE THIS SYSTEM WILL OPERATE:  
 CENTER HYDRAULIC SYSTEM (AMM 29-11-00/201)

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT  
 FOLLOWS:  
 ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
 DOWNLOCKS ARE INSTALLED (AMM 32-00-20/201)



Gear Green Dn Lgt Failed to Illum with Gear Handle DN.  
 EICAS Msg DRAG BRACE Displayed. GEAR Amber Lgt was Illum.  
 Figure 109


EFFECTIVITY	ALL
-------------	-----

**32-30-00**

GEAR GREEN DN LGT  
FAILED TO ILLUM  
WITH GEAR HANDLE  
"DN". EICAS MSG  
"SIDE BRACE"  
DISPLAYED. "GEAR"  
AMBER LGT WAS  
ILLUM.

**PREREQUISITES**

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT  
FOLLOWS:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
DOWNLOCKS ARE INSTALLED (AMM 32-00-20/201)



Gear Green Dn Lgt Failed to Illum with Gear Handle DN.  
EICAS Msg SIDE BRACE Displayed. GEAR Amber Lgt was Illum.  
Figure 110

EFFECTIVITY

ALL
-----

32-30-00




GEAR GREEN DN LGT  
FAILED TO ILLUM  
WITH GEAR HANDLE  
"DN". EICAS MSG  
"GEAR DISAGREE"  
DISPLAYED. "DOORS"  
AMBER LGT WAS EXTN  
AND "GEAR" LGT  
ILLUM. INDICATIONS  
NORM AFTER ALT GEAR  
EXT.

**PREREQUISITES**

MAKE SURE THIS SYSTEM WILL OPERATE:  
CENTER HYDRAULIC SYSTEM (AMM 29-11-00/201)

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT  
FOLLOWS:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
DOWNLOCKS ARE INSTALLED (AMM 32-00-20/201)  
DOOR LOCKS ARE INSTALLED (AMM 32-00-15/201)



Gear Green Dn Lgt Failed to Illum with Gear Handle DN.  
EICAS Msg GEAR DISAGREE Displayed. DOORS Amber Lgt was Extn and GEAR  
Lgt Illum. Indications Norm After Alt Gear Ext.

Figure 111

EFFECTIVITY

ALL

**32-30-00**


02

Page 126  
Aug 22/01

AMBER "GEAR" LGT  
ILLUMINATED WITH  
LANDING GEAR  
CONTROL LEVER IN  
DOWN POSITION.  
GEAR GREEN LGTS  
ILLUMINATED.


**PREREQUISITES**

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT  
FOLLOWS:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)



Amber GEAR LGT Illuminated with Landing Gear Control Lever in Down Position.  
Gear Green Lgts Illuminated.


Figure 111A



**32-30-00**

PREREQUISITES  
NONE

GEAR GREEN DN LGT  
FAILED TO ILLUM  
WITH GEAR HANDLE  
"DN". EICAS MSG  
"GEAR DISAGREE"  
DISPLAYED. "DOORS"  
AMBER LGT WAS EXTIN  
AND "GEAR" LGT  
ILLUM. ALT GEAR  
EXT WAS ATTEMPTED.



Gear Green Dn Lgt Failed to Illum with Gear Handle DN.  
EICAS Msg GEAR DISAGREE Displayed. DOORS Amber Lgt was Extin and GEAR  
Lgt Illum. Alt Gear Ext was Attempted.

Figure 112

EFFECTIVITY

ALL
-----

32-30-00


EICAS MSG "GEAR DOORS" DISPLAYED WITH GEAR UP. "DOORS" AMBER LGT WAS ILLUM AND "GEAR" LGT EXTIN.

**PREREQUISITES**

MAKE SURE THIS CIRCUIT BREAKER IS CLOSED:  
11U20

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:

- ELECTRICAL POWER IS ON (AMM 24-22-00/201)
- CENTER HYDRAULIC SYSTEM IS PRESSURIZED (AMM 29-11-00/201)
- DOWNLOCKS ARE INSTALLED (AMM 32-00-20/201)



EICAS Msg GEAR DOORS Displayed with Gear UP. DOORS Amber Lgt was Illum and GEAR Lgt Extin.

Figure 113

EFFECTIVITY

ALL


**32-30-00**

EICAS MSG "GEAR DOORS" AND "GEAR DISAGREE" DISPLAYED WITH GEAR HANDLE "UP". "DOORS" AND "GEAR" AMBER LGTS ILLUM. GEAR GREEN DN LGTS ALL EXTIN.

**PREREQUISITES**

MAKE SURE THIS CIRCUIT BREAKER IS CLOSED:  
11U20

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
CENTER HYDRAULIC SYSTEM IS PRESSURIZED (AMM 29-11-00/201)  
DOWNLOCKS ARE INSTALLED (AMM 32-00-20/201)




EICAS Msg GEAR DOORS and GEAR DISAGREE Displayed with Gear Handle UP.  
DOORS and GEAR Amber Lgts Illum. Gear Green Dn Lgts all Extin.  
Figure 114 (Sheet 1)

EFFECTIVITY	ALL
-------------	-----

32-30-00

94554



**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL



EICAS Msg GEAR DOORS and GEAR DISAGREE Displayed with Gear Handle UP.  
 DOORS and GEAR Amber Lgts Illum. Gear Green Dn Lgts all Extin.  
 Figure 114 (Sheet 2)

EFFECTIVITY	_____
ALL	

32-30-00



EICAS Msg GEAR DOORS and GEAR DISAGREE Displayed with Gear Handle UP.  
 DOORS and GEAR Amber Lgts Illum. Gear Green Dn Lgts all Extin.  
 Figure 114 (Sheet 3)

EFFECTIVITY	ALL
-------------	-----


32-30-00

EICAS MSG "GEAR DISAGREE" DISPLAYED WITH GEAR HANDLE "UP". "NOSE" GREEN DN LGT FAILED TO EXTIN. "DOORS" AMBER LGT WAS EXTIN AND "GEAR" LGT ILLUM.

**PREREQUISITES**

MAKE SURE THIS SYSTEM WILL OPERATE:  
CENTER HYDRAULIC SYSTEM (AMM 29-11-00/201)

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
DOWNLOCKS ARE INSTALLED (AMM 32-00-20/201)



EICAS Msg GEAR DISAGREE Displayed with Gear Handle UP. NOSE Green Dn Lgt Failed to Extin. DOORS Amber Lgt was Extin and GEAR Lgt Illum.  
Figure 115 (Sheet 1)


EFFECTIVITY

ALL
-----

32-30-00



FROM SHEET 1  
(BLOCK 2)



EICAS Msg GEAR DISAGREE Displayed with Gear Handle UP. NOSE Green Dn  
 Lgt Failed to Extin. DOORS Amber Lgt was Extin and GEAR Lgt Illum.  
 Figure 115 (Sheet 2)

EFFECTIVITY	ALL
-------------	-----


32-30-00

GEAR GREEN DN LGT  
FAILED TO EXTIN  
WITH GEAR HANDLE  
"UP". EICAS MSG  
"GEAR DISAGREE"  
DISPLAYED. "DOORS"  
AMBER LGT WAS EXTIN  
& "GEAR" LGT ILLUM.

**PREREQUISITES**

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:

- ELECTRICAL POWER IS ON (AMM 24-22-00/201)
- CENTER HYDRAULIC SYSTEM IS PRESSURIZED (AMM 29-11-00/201)
- DOWNLOCKS ARE INSTALLED (AMM 32-00-20/201)



Gear Green Dn Lgt Failed to Extin with Gear Handle UP.  
EICAS Msg GEAR DISAGREE Displayed. DOORS Amber Lgt was Extin & GEAR Lgt Illum.  
Figure 116 (Sheet 1)

EFFECTIVITY


ALL

**32-30-00**

02

Page 135  
Aug 22/01


FROM SHEET 1  
(BLOCK 2)



Gear Green Dn Lgt Failed to Extin with Gear Handle UP.  
 EICAS Msg GEAR DISAGREE Displayed. DOORS Amber Lgt was Extin & GEAR Lgt Illum.  
 Figure 116 (Sheet 2)

EFFECTIVITY	ALL
-------------	-----

**32-30-00**



Gear Green Dn Lgt Failed to Extin with Gear Handle UP.  
EICAS Msg GEAR DISAGREE Displayed. DOORS Amber Lgt was Extin & GEAR Lgt Illum.  
Figure 116 (Sheet 3)

EFFECTIVITY

ALL

**32-30-00**

02

Page 137  
Aug 22/01

FROM SHEET 3  
(BLOCK 5)

YES

6 **WARNING**

MAKE SURE THAT PERSONS AND EQUIPMENT ARE CLEAR OF THE AREA AROUND THE MAIN LANDING GEAR AND DOORS. INJURIES TO PERSONS OR DAMAGE TO EQUIPMENT CAN OCCUR WHEN THE LANDING GEAR AND THE DOORS MOVE.

PUT THE CONTROL LEVER IN THE "DN" POSITION. AFTER THE LANDING GEAR IS EXTENDED, PUT THE CONTROL LEVER TO THE "OFF" POSITION.

**WARNING**

USE THE PROCEDURE IN AMM 32-00-15 TO REMOVE THE DOOR LOCKS. THE DOORS OPEN AND CLOSE QUICKLY AND CAN CAUSE INJURIES TO PERSONS OR DAMAGE TO EQUIPMENT.

REMOVE THE DOOR LOCKS ON THE MAIN LANDING GEAR (AMM 32-00-15/201).

**WARNING**

MAKE SURE THAT PERSONS AND EQUIPMENT ARE CLEAR OF THE AREA AROUND THE MAIN LANDING GEAR AND DOORS. INJURIES TO PERSONS OR DAMAGE TO EQUIPMENT CAN OCCUR WHEN THE LANDING GEAR AND THE DOORS MOVE.

PUT THE CONTROL LEVER IN THE "UP" POSITION.

DID THE LANDING GEAR RETRACT CORRECTLY AND THE DOORS CLOSE AND LATCH?

NO

38 ADJUST THE DOORS FOR THE MAIN LANDING GEAR (AMM 32-12-00/501).

YES

7 PUT THE CONTROL LEVER TO THE "DN" POSITION.

AFTER THE LANDING GEAR IS EXTENDED, INSTALL THE DOWN-LOCKS ON THE NOSE AND MAIN LANDING GEAR (AMM 32-00-20/201).

REMOVE THE AIRPLANE FROM JACKS (AMM 07-11-01).

THE SYSTEM IS OK.

Gear Green Dn Lgt Failed to Extin with Gear Handle UP.  
 EICAS Msg GEAR DISAGREE Displayed. DOORS Amber Lgt was Extin & GEAR Lgt Illum.  
 Figure 116 (Sheet 4)

EFFECTIVITY

ALL


**32-30-00**

02

Page 138  
Aug 22/01

**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

FROM SHEET 3  
(BLOCK 5)




Gear Green Dn Lgt Failed to Extin with Gear Handle UP.  
EICAS Msg GEAR DISAGREE Displayed. DOORS Amber Lgt was Extin & GEAR Lgt Illum.  
Figure 116 (Sheet 5)

EFFECTIVITY	ALL
-------------	-----

32-30-00

**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

FROM SHEET 5  
(BLOCK 21)



Gear Green Dn Lgt Failed to Extin with Gear Handle UP.  
EICAS Msg GEAR DISAGREE Displayed. DOORS Amber Lgt was Extin & GEAR Lgt Illum.  
Figure 116 (Sheet 6)


EFFECTIVITY	ALL
-------------	-----

32-30-00

GEAR GREEN DN LGT  
FAILED TO EXTIN  
WITH GEAR HANDLE  
"UP". EICAS MSG  
"GEAR DISAGREE"  
DISPLAYED. "DOORS"  
AMBER LGT & "GEAR"  
LGT ILLUM.

**PREREQUISITES**

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
CENTER HYDRAULIC SYSTEM IS PRESSURIZED  
(AMM 29-11-00/201)  
DOWNLOCKS ARE INSTALLED (AMM 32-00-20/201)



Gear Green Dn Lgt Failed to Extin with Gear Handle UP.  
EICAS Msg GEAR DISAGREE Displayed. DOORS Amber Lgt & GEAR Lgt Illum.  
Figure 116A (Sheet 1)

EFFECTIVITY

ALL


**32-30-00**

02

Page 141  
Aug 22/01



FROM SHEET 1  
(BLOCK 2)



Gear Green Dn Lgt Failed to Extin with Gear Handle UP.  
 EICAS Msg GEAR DISAGREE Displayed. DOORS Amber Lgt & GEAR Lgt Illum.  
 Figure 116A (Sheet 2)


EFFECTIVITY

ALL


**32-30-00**

02

Page 142  
Aug 22/01




Gear Green Dn Lgt Failed to Extin with Gear Handle UP.  
 EICAS Msg GEAR DISAGREE Displayed. DOORS Amber Lgt & GEAR Lgt Illum.  
 Figure 116A (Sheet 3)



32-30-00

FROM SHEET 3  
(BLOCK 4)



Gear Green Dn Lgt Failed to Extin with Gear Handle UP.  
 EICAS Msg GEAR DISAGREE Displayed. DOORS Amber Lgt & GEAR Lgt Illum.  
 Figure 116A (Sheet 4)

EFFECTIVITY

ALL

**32-30-00**

02

Page 144  
Aug 22/01

FROM SHEET 4  
(BLOCK 6)

NO

7 PUT THE CONTROL LEVER FOR THE LANDING GEAR IN THE "OFF" POSITION.

WARNING

BEFORE YOU DO THE CHECK, MAKE SURE THAT BLOCK 4 WAS COMPLETED. IF YOU DID NOT MANUALLY PULL ON THE ACTUATOR ROD END THE ROD END CAN MOVE APART FROM THE ACTUATOR WHEN HYDRAULIC PRESSURE IS APPLIED.

WARNING

THE ACTUATOR CAN MOVE SUDDENLY AND/OR EXTEND WHEN HYDRAULIC PRESSURE IS APPLIED. IT CAN CAUSE INJURIES TO PERSONS AND/OR DAMAGE TO EQUIPMENT.

MAKE SURE THE ACTUATOR IS HELD SO THAT THE ROD END IS CLEAR OF THE LANDING GEAR AND OTHER BLOCKAGES.

PRESSURIZE THE CENTER HYDRAULIC SYSTEM (AMM 29-11-00/201).

WARNING

MAKE SURE THE DOWNLOCKS ARE INSTALLED ON THE NOSE AND MAIN LANDING GEAR BEFORE YOU MOVE THE CONTROL LEVER FOR THE LANDING GEAR. IF THE CONTROL LEVER IS MOVED WITHOUT THE DOWNLOCKS INSTALLED, THE LANDING GEAR CAN RETRACT AND CAUSE INJURIES TO PERSONS OR DAMAGE TO EQUIPMENT.

MAKE SURE THE DOWNLOCKS ARE INSTALLED ON THE NOSE AND MAIN LANDING GEAR (AMM 32-00-20/201).

PUT THE CONTROL LEVER IN THE "UP" POSITION.

DOES THE ACTUATOR RETRACT CORRECTLY?

NO

36 REPLACE THE ACTUATOR FOR THE L (R) SIDE BRACE (AMM 32-32-02/401).

YES

SEE SHEET 6  
(BLOCK 8)

Gear Green Dn Lgt Failed to Extin with Gear Handle UP.  
 EICAS Msg GEAR DISAGREE Displayed. DOORS Amber Lgt & GEAR Lgt Illum.  
 Figure 116A (Sheet 5)

EFFECTIVITY

ALL

**32-30-00**

02

Page 145  
Aug 22/01

822342

FROM SHEET 5  
(BLOCK 7)

YES

8 PUT THE CONTROL LEVER FOR THE LANDING GEAR IN THE "DN" POSITION TO EXTEND THE ACTUATOR.

PUT THE CONTROL LEVER IN THE "OFF" POSITION.

REMOVE THE PRESSURE FROM THE CENTER HYDRAULIC SYSTEM (AMM 29-11-00/201).

INSTALL THE ROD END OF THE ACTUATOR FOR THE L (R) SIDE BRACE TO THE SIDE BRACE (AMM 32-32-02/401).

DISCONNECT THE ROD END OF THE ACTUATOR FOR THE L (R) DRAG BRACE FROM THE DRAG BRACE (AMM 32-32-02/401).

WARNING

THE ACTUATOR CAN MOVE SUDDENLY AND/OR EXTEND WHEN HYDRAULIC PRESSURE IS APPLIED. IT CAN CAUSE INJURIES TO PERSONS AND/OR DAMAGE TO EQUIPMENT.

MAKE SURE THE ACTUATOR IS HELD SO THAT THE ROD END IS CLEAR OF THE LANDING GEAR AND OTHER BLOCKAGES.

PRESSURIZE THE CENTER HYDRAULIC SYSTEM (AMM 29-11-00/201).

WARNING

MAKE SURE THE DOWNLOCKS ARE INSTALLED ON THE NOSE AND MAIN LANDING GEAR BEFORE YOU MOVE THE CONTROL LEVER FOR THE LANDING GEAR. THE CONTROL LEVER IS MOVED WITHOUT THE DOWNLOCKS INSTALLED, THE LANDING GEAR CAN RETRACT AND CAUSE INJURIES TO PERSONS OR DAMAGE TO EQUIPMENT.

MAKE SURE THE DOWNLOCKS ARE INSTALLED ON THE NOSE AND MAIN LANDING GEAR (AMM 32-00-20/201).

PUT THE CONTROL LEVER IN THE "UP" POSITION.

DOES THE ACTUATOR RETRACT CORRECTLY?

NO

37 REPLACE THE ACTUATOR FOR THE L (R) DRAG BRACE (AMM 32-32-02/401).

YES

SEE SHEET 7  
(BLOCK 9)

Gear Green Dn Lgt Failed to Extin with Gear Handle UP.  
 EICAS Msg GEAR DISAGREE Displayed. DOORS Amber Lgt & GEAR Lgt Illum.  
 Figure 116A (Sheet 6)

EFFECTIVITY


ALL

**32-30-00**

02

Page 146  
Aug 22/01

FROM SHEET 6  
(BLOCK 8)



Gear Green Dn Lgt Failed to Extin with Gear Handle UP.  
EICAS Msg GEAR DISAGREE Displayed. DOORS Amber Lgt & GEAR Lgt Illum.  
Figure 116A (Sheet 7)

EFFECTIVITY

ALL

**32-30-00**


02

Page 147  
Aug 22/01

THE AIRPLANE IS ON THE GROUND, "NOSE" GEAR GREEN DN LGT FAILED TO ILLUM WITH GEAR HANDLE "DN. AMBER "GEAR" LGT IS ILLUM. EICAS MSG "GEAR DISAGREE" DISPLAYED.

**PREREQUISITES**  
NONE

**WARNING:** DO NOT LET YOURSELF OR ANOTHER PERSON BE UNDER THE AIRPLANE UNTIL YOU ARE SURE THE NOSE GEAR DOWNLOCK OR AIRPLANE JACK IS INSTALLED. INJURY OR DEATH TO PERSONS AND DAMAGE TO EQUIPMENT CAN RESULT.



NOSE Gear Green Dn Lgt Failed to Illum with Gear Handle DN. Amber Gear Lgt Is Illum. EICAS Msg GEAR DISAGREE Displayed. (Airplane on Ground)  
Figure 117

EFFECTIVITY	ALL
-------------	-----

32-30-00

H34342

**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

HYDRAULIC BRAKE SYSTEM

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
ACCUMULATOR - BRAKE HYDRAULIC SURGE ACCUMULATOR - (REF 32-44-00, FIG. 101) PARKING BRAKE	3	1	552CB, 652CB, INBOARD WING TE	32-41-11
ASSEMBLY - BRAKE METERING VALVE	1	2	RIGHT & LEFT WHEEL WELL	
BLEEDER - HYDRAULIC BRAKE	3	8	MAIN LANDING GEAR	32-41-00
BRAKE - HYDRAULIC	3	8	MAIN LANDING GEAR	32-41-08
CABLES - BRAKE CONTROL	1	8	FWD CARGO COMPT CEILING AREA	32-00-25
CHECK VALVE - ACCUMULATOR ISOLATION	2	1	RIGHT WHEEL WELL	32-41-00
CIRCUIT BREAKERS	1		FLT COMPT, P6, P11	
BRAKE PRESS, C1180		1	11U22	*
IND LIGHTS 1, C1306		1	11A33	*
HYDRAULIC ELEC PUMP C1, C1085		1	11L15	*
LANDING GEAR PARKING BRAKE VLV, C1179		1	6F4	*
DISCONNECT - BRAKE	3	8	MAIN LANDING GEAR	32-41-06
GAGE - BRAKE PRESS INDICATOR, N10	1	1	FLT COMPT, P3	*
GAGE - (REF 32-44-00, FIG. 101) PARKING BRAKE ACCUMULATOR PRESSURE				
GAGE - SURGE ACCUMULATOR PRESSURE	3	2	552CB, 652CB, INBOARD WING TE	32-41-00
LIGHT - BRAKE SOURCE INDICATOR, L605	1	1	FLT COMPT, P1	*
MECHANISM - BRAKE PEDAL BUS	1	2	113AL, FWD EQUIP COMPT	32-41-01
MODULE - (REF 32-42-00, FIG. 101) ALTERNATE ANTISKID VALVE ANTISKID SHUTTLE VALVE AUTOBRAKE SHUTTLE VALVE AUTOBRAKE VALVE NORMAL ANTISKID VALVE				
PEDALS - BRAKE, CAPTAIN'S AND FIRST OFFICER'S	1	1	FLT COMPT	32-41-00
SWITCH - ALTN VALVE SELECT PRESS, S415	2	1	LEFT WHEEL WELL	*
SWITCH - (REF 29-11-00, FIG. 101) RESERVE BRAKES AND STEERING SELECT, S547 SYS R ACMP CONTROL PRESSURE, S32				
TRANSDUCER - HYDRAULIC BRAKE PRESSURE, TS90	2	1	RIGHT WHEEL WELL	*
VALVE - ACCUMULATOR ISOLATION	2	1	RIGHT WHEEL WELL	32-41-05
VALVE - ALTERNATE BRAKE SELECTOR	2	1	LEFT WHEEL WELL	32-41-05
VALVE - SURGE ACCUMULATOR CHARGING	3	2	551XBX, 651XBX, INBOARD WING TE	32-41-11
VALVE - (REF 32-44-00, FIG. 101) PARKING BRAKE PARKING BRAKE ACCUMULATOR CHARGING				

\* SEE WM EQUIPMENT LIST

Component Index  
Figure 101

EFFECTIVITY

ALL

**32-41-00**

08

Page 101  
Aug 10/87



269915




# BOEING

## 767


### FAULT ISOLATION/MAINT MANUAL




**BRAKE METERING VALVE ASSEMBLY  
(RIGHT SIDE INSTALLATION SHOWN)**




**BRAKE PEDAL BUS MECHANISM**



**FLT COMPT**



**BRAKE PRESS INDICATOR GAGE, N10**





**BRAKE SOURCE LIGHT, L605**

**Component Location  
Figure 102 (Sheet 1)**


EFFECTIVITY	
	ALL

**32-41-00**


**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL



ALTERNATE BRAKE SELECTOR VALVE (LEFT WHEEL WELL)  
(E)



HYDRAULIC BRAKE PRESSURE TRANSDUCER, TS90 (RIGHT WHEEL ONLY)  
(F)



ACCUMULATOR ISOLATION (SHUTOFF) VALVE (RIGHT WHEEL WELL)  
(G)

Component Location  
Figure 102 (Sheet 2)

EFFECTIVITY	
	ALL



32-41-00

95057

# BOEING


## 767

### FAULT ISOLATION/MAINT MANUAL




**SURGE ACCUMULATOR CHARGING VALVE AND PRESSURE GAGE**

(I)




**BRAKE HYDRAULIC SURGE ACCUMULATOR**

(H)



**BRAKE (TYPICAL-8-PLACES)**

(J)




Component Location  
Figure 102 (Sheet 3)

EFFECTIVITY	
	ALL

32-41-00

"BRAKE SOURCE" LGT  
FAILS TO ILLUMINATE  
WITH NO HYD PRESSURE  
FROM ANY SOURCE

**PREREQUISITES**  
HYDRAULIC POWER (MM 29-11-00)  
ELECTRICAL POWER (MM 24-22-00)  
CB'S: 6F4,11A33,11U22



BRAKE SOURCE Lgt Fails to Illuminate with No Hyd Pressure  
from any Source  
Figure 103

EFFECTIVITY

ALL
-----


32-41-00

"BRAKE SOURCE" LGT  
REMAINS ILLUMINATED  
WITH RIGHT OR CENTER  
HYD SYS PRESSURIZING  
BRAKES

**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
6F4, 11A33, 11U22

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
RIGHT AND CENTER HYDRAULIC SYSTEM PRESSURE IS ON  
(AMM 29-11-00/201)



BRAKE SOURCE Lgt Remains Illuminated with Right or Center  
Hyd Sys Pressurizing Brakes  
Figure 104


EFFECTIVITY	ALL
-------------	-----

**32-41-00**

<b>PREREQUISITES</b> NONE
------------------------------

**BRAKE PRESSURE  
PRECHARGE LOW**

**NOTE:** PRECHARGE PRESSURE OF ACCUMULATOR SHOULD BE APPROXIMATELY 1000 PSI AT 68°F WITH RIGHT AND CENTER HYDRAULIC SYSTEMS DEPRESSURIZED.



Brake Pressure Precharge Low  
Figure 105

EFFECTIVITY ————

ALL
-----

**32-41-00**

01

Page 107  
Apr 22/99

48412


**BRAKE PRESSURE  
 BLEEDS OFF WITH C  
 HYD SYS PRESSURIZED  
 AND R HYD SYS OFF**

**PREREQUISITES**

MAKE SURE THIS CIRCUIT BREAKERS IS CLOSED:  
 11U22

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
 ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
 CENTER HYDRAULIC SYSTEM PRESSURE IS ON  
 (AMM 29-11-00/201)

**NOTE:** THE ACCUMULATOR IS PRESSURIZED BY PRESSURIZING  
 THE RIGHT HYDRAULIC SYSTEM.



Brake Pressure Bleeds Off with C Hyd Sys Pressurized and R Hyd Sys Off  
 Figure 106

EFFECTIVITY	ALL
-------------	-----

**32-41-00**

K16536


**BRAKE PRESSURE  
BLEEDS OFF WITH  
PARKING BRAKE SET,  
R AND C HYD SYS  
ARE DEPRESSURIZED**

**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
6F4, 11U22

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)

NOTE: THE ACCUMULATOR IS PRESSURIZED BY PRESSURIZING  
THE RIGHT HYDRAULIC SYSTEM.



Brake Pressure Bleeds Off with Parking Brake Set, R and C Hyd Sys are Depressurized  
Figure 107

EFFECTIVITY

ALL

**32-41-00**

01

Page 109  
Apr 22/99




**BRAKE PRESSURE  
BLEEDS OFF WITH R  
AND C HYD SYS  
DEPRESSURIZED.  
PARKING BRAKE WAS  
RELEASED.**

**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
6F4,11U22

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (MM 24-22-00/201)  
THERE IS NO PRESSURE IN THE RIGHT AND CENTER  
HYDRAULIC SYSTEMS (29-11-00/201)  
THE PARKING BRAKE IS RELEASED

NOTE: THE ACCUMULATOR IS PRESSURIZED BY PRESSURIZING  
THE RIGHT HYDRAULIC SYSTEM.



Brake Pressure Bleeds Off With R and C Hyd Sys Depressurized.  
Parking Brake was Released.  
Figure 108


EFFECTIVITY	ALL
-------------	-----

**32-41-00**

BRAKE PRESSURE INDICATES (LOW, ZERO) WITH (R,C,R AND C) HYD SYS PRESSURIZED AND "BRAKE SOURCE" LGT EXTINGUISHED

**PREREQUISITES**  
CENTER AND RIGHT HYDRAULIC SYSTEM POWER (MM 29-11-00)  
ELECTRICAL POWER (MM 24-22-00)  
CB'S: 11U22,6F4

NOTE: THE BRAKE PRESS GAGE READS RIGHT HYD SYS AND/OR ACCUMULATOR PRESSURE ONLY.



Brake Pressure Indicates (Low, Zero) with (R,C,R and C) Hyd Sys Pressurized and BRAKE SOURCE Lgt Extinguished  
Figure 109

EFFECTIVITY \_\_\_\_\_  
ALL


**32-41-00**

**BRAKE PRESSURE  
INDICATION HIGH,  
INOP, INTERMITTENT,  
STICKS, ETC.**

**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
6F4,11U22

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (MM 24-22-00/201)  
RIGHT AND CENTER HYDRAULIC SYSTEM PRESSURE IS ON  
(AMM 29-11-00/201)  
THE PARKING BRAKE IS RELEASED



Brake Pressure Indication High, Inop, Intermittent, Sticks, Etc.  
Figure 110

EFFECTIVITY	ALL
-------------	-----

**32-41-00**

 **BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

ANTISKID/AUTOBRAKE SYSTEM

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
ASSEMBLY - ANTISKID/BRAKE COOLING XDCR MOTOR TS358 FOR WHEEL 1 TS359 FOR WHEEL 2 TS362 FOR WHEEL 3 TS363 FOR WHEEL 4 TS360 FOR WHEEL 5 TS361 FOR WHEEL 6 TS364 FOR WHEEL 7 TS365 FOR WHEEL 8	5	8	HUBCAP, MAIN WHL AXLE L FWD OUTBD WHL L FWD INBD WHL R FWD INBD WHL R FWD OUTBD WHL L AFT OUTBD WHL L AFT INBD WHL R AFT INBD WHL R AFT OUTBD WHL	32-42-06
ASSEMBLY - AUTOBRAKE SHUTTLE VALVE	4	2	MAIN WHEEL WELL, TRANSVERSE BEAM	32-42-10
CARD - AUTOBRAKE CIRCUIT	6	1	119AL, MAIN EQUIP CTR, E1-1, ANTISKID/AUTOBRAKE CONTROL UNIT, M102	32-42-01
CARD - BITE CIRCUIT	6	1	119AL, MAIN EQUIP CTR, E1-1, ANTISKID/AUTOBRAKE CONTROL UNIT, M102	32-42-01
CARD - INTERFACE/DISPLAY CIRCUIT	6	1	119AL, MAIN EQUIP CTR, E1-1, ANTISKID/AUTOBRAKE CONTROL UNIT, M102	32-42-01
CARD - MAIN WHEEL CIRCUIT	6	4	119AL, MAIN EQUIP CTR, E1-1, ANTISKID/AUTOBRAKE CONTROL UNIT, M102	32-42-01
CIRCUIT BREAKERS: LANDING GEAR PARKING BRAKE VLV, C1179 R PLT A/B, C108	1	1	FLT COMPT, P6 6F4	*
CIRCUIT BREAKERS: AIR/GND SYS 1, C1182 ANTISKID 1-5, C1171 ANTISKID 2-6, C1183 ANTISKID 3-7, C1184 ANTISKID 4-8, C1172 AUTOBRKS/ANTISKID TEST/IND 2, C1173 AUTOBRKS/ANTISKID TEST/IND 1, C1176 IND LIGHTS 3, C1200 LANDING GEAR POSITION AIR/GND SYS 1, C1175 POSITION AIR/GND SYS 2, C1170 R IND LTS 2, C1274	1	1	FLT COMPT, P11 6K28	*
DIODE - R33,R62,R63,R64 DIODE - (REF 31-01-36, FIG. 101) R129,R130	6	2	119AL, MAIN EQUIP CTR, E1-1	*
DIODE - R217,R218,R609	1	2	FLT COMPT, P61	*
DRIVE - ANTISKID TRANSDUCER	5	8	MAIN WHEEL HUBCAP	32-42-04
FILTER - ALTERNATE ANTISKID MODULE INLET	2	2	552CB/L WING, 652CB/R WING	32-42-03
FILTER - ALTERNATE ANTISKID MODULE SCREEN	2	2	552CB/L WING, 652CB/R WING	32-42-03
FILTER - ANTISKID SHUTTLE VALVE MODULE	3	8	551TB/L WING, 651TB/R WING	32-42-07
FILTER - NORMAL ANTISKID MODULE INLET	3	2	551TB/L WING, 651TB/R WING	32-42-03
FILTER - NORMAL ANTISKID MODULE SCREEN	3	2	551TB/L WING, 651TB/R WING	32-42-03
FUSE - ALTERNATE ANTISKID MODULE	2	4	552CB/L WING, 652CB/R WING	32-42-03
FUSE - NORMAL ANTISKID MODULE	3	8	551TB/L WING, 651TB/R WING	32-42-03

\* SEE WM EQUIPMENT LIST

Antiskid/Autobrake System - Component Index  
Figure 101 (Sheet 1)

EFFECTIVITY

ALL

32-42-00

**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
LIGHT - ANTISKID, YDLL19	1	1	FLT COMPT, P5, ANNUNCIATOR PANEL, M10394	*
LIGHT - AUTOBRAKE, L119	1	1	FLT COMPT, P1	*
MODULE - AUTOBRAKE, M239	4	1	R MAIN WHEEL WELL, KEEL BEAM FWD	32-42-09
MODULE - LEFT ANTISKID SHUTTLE VALVE	3	1	551TB, L WING LWR SURFACE TE	32-42-07
MODULE - LEFT ANTISKID (ALTERNATE)	2	1	552CB, L WING LWR SURFACE TE	32-42-02
MODULE - LEFT ANTISKID (NORMAL)	3	1	551TB, L WING LWR SURFACE TE	32-42-02
MODULE - RIGHT ANTISKID SHUTTLE VALVE	3	1	651TB, R WING LWR SURFACE TE	32-42-07
MODULE - RIGHT ANTISKID (ALTERNATE)	2	1	652CB, R WING LWR SURFACE TE	32-42-02
MODULE - RIGHT ANTISKID (NORMAL)	3	1	651TB, R WING LWR SURFACE TE	32-42-02
PACK - (FIM 22-32-00/101) AUTOTHROTTLE MICROSWITCH, M966				
PANEL - (FIM 30-31-00/101) ANNUNCIATOR, M10394				
PANEL - (FIM 22-21-00/101) YAW DAMPER, M10250				
PLUG - FLIGHT DISPATCH DISCONNECT	3	1	551TB, L WING, 651TB, R WING, ANTISKID SHUTTLE VALVE	32-42-00
RELAY - (FIM 31-01-36/101) AIR/GROUND SYS 1, K199 ANTISKID 1 & 5 FAIL, K10229 ANTISKID 4 & 8 FAIL, K10230 ANTISKID 2 & 6 FAIL, K10231 ANTISKID 3 & 7 FAIL, K10232 ANTISKID ALTERNATE FAIL, K10233 EDP R PRESS SENSE, K127 LEFT IRS SELECT, K511 PARK BRAKE CLOSE SENSE, K419				
RELAY - (FIM 31-01-37/101) AIR/GROUND SYS 2, K293 RIGHT IRS SELECT, K510				
SWITCH - (FIM 32-41-00/101) ALTERNATE VALVE SEL PRESS, S415				
SWITCH - AUTOBRAKE SELECTOR, S24	1	1	FLT COMPT, P1-3	*
SWITCH - AUTOBRAKE SERVO VALVE PRESSURE, YAAS1	4	1	R MAIN WHEEL WELL, AUTOBRAKE MODULE, M239	32-42-09
SWITCH - AUTOBRAKE SOLENOID VALVE PRESS, YAAS2	4	1	R MAIN WHEEL WELL, AUTOBRAKE MODULE, M239	32-42-09
SWITCH - (FIM 34-22-00/101) L IRS INSTR SOURCE SEL, S4 R IRS INSTR SOURCE SEL, S12				

\* SEE THE WDM EQUIPMENT LIST

Antiskid/Autobrake System - Component Index  
Figure 101 (Sheet 2)

EFFECTIVITY

ALL

**32-42-00**

02

Page 102  
Apr 22/05


**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
SWITCH - LEFT METERED PRESSURE, S82	4	1	L MAIN WHEEL WELL, TRANSVERSE BEAM, AUTOBRAKE SHUTTLE VALVE ASSY	32-42-10
SWITCH - RIGHT METERED PRESSURE, S83	4	1	R MAIN WHEEL WELL, TRANSVERSE BEAM, AUTOBRAKE SHUTTLE VALVE ASSY	32-42-10
SWITCH - (FIM 31-51-00/101) SPEED BRAKE POSITION, S493				
SWITCH - THRUST LEVER POSITION, L NO. 1 (L AUTOBRAKE/AUTOBRAKE RTO), S2	7	1	113AL, AUTOTHROTTLE MICROSWITCH PACK, M966	22-32-04
SWITCH - THRUST LEVER POSITION, L NO. 2 (L AUTOBRAKE/AUTOBRAKE RTO), S3	7	1	113AL, AUTOTHROTTLE MICROSWITCH PACK, M966	22-32-04
SWITCH - THRUST LEVER POSITION, R NO. 1 (R AUTOBRAKE/AUTOBRAKE RTO), S6	7	1	113AL, AUTOTHROTTLE MICROSWITCH PACK, M966	22-32-04
SWITCH - THRUST LEVER POSITION, R NO. 2 (R AUTOBRAKE/AUTOBRAKE RTO), S7	7	1	113AL, AUTOTHROTTLE MICROSWITCH PACK, M966	22-32-04
UNIT - ANTISKID/AUTOBRAKE CONTROL, M102 UNIT - (FIM 34-21-00/101) CENTER INERTIAL REFERENCE, M160 LEFT INERTIAL REFERENCE, M159 RIGHT INERTIAL REFERENCE, M161	6	1	119AL, MAIN EQUIP CTR, E1-1	32-42-01
VALVE - ANTISKID SHUTOFF	3	2	551TB/L WING, 651TB/R WING, NORMAL ANTISKID MODULE	32-42-03
VALVE - ANTISKID SHUTTLE	3	8	551TB/L WING, 651TB/R WING, SHUTTLE VALVE MODULE	32-42-07
VALVE - AUTOBRAKE SERVO, YAAV2	4	1	R MAIN WHEEL WELL, AUTOBRAKE MODULE, M239	32-42-09
VALVE - AUTOBRAKE SOLENOID (SHUTOFF), YAAV1	4	1	R MAIN WHEEL WELL, AUTOBRAKE MODULE, M239	32-42-09
VALVE - L ALT ANTISKID, V37, V38	2	2	552CB, L WING, LOWER SURFACE TE, ALT ANTISKID MODULE	32-42-03
VALVE - L NORM ANTISKID, V29, V30, V31, V32	3	4	551TB, L WING, LOWER SURFACE TE, NORM ANTISKID MODULE	32-42-03
VALVE - R ALT ANTISKID, V39, V40	2	2	652CB, R WING, LOWER SURFACE TE, ALT ANTISKID MODULE	32-42-03
VALVE - R NORM ANTISKID, V33, V34, V35, V36	3	4	651TB, R WING, LOWER SURFACE TE, NORM ANTISKID MODULE	32-42-03

Antiskid/Autobrake System - Component Index  
Figure 101 (Sheet 3)

EFFECTIVITY

ALL


**32-42-00**

01


Page 103  
Apr 22/05

94295

**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL




**FLIGHT COMPARTMENT**



**ANNUNCIATOR PANEL, M10394 (REF)**

(A)



**AUTOBRAKE SELECTOR SWITCH, S24**


(B)

Component Location  
Figure 102 (Sheet 1)

EFFECTIVITY	ALL
-------------	-----

**32-42-00**

**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL



**NOTE:** VIEW INDICATORS (C) AND (D) NOT USED.



**NOTE:** SEE FIG. 102 (SHTS 10 AND 11) FOR SCHEMATIC OF FLOW PATHS FROM ANTISKID VALVES TO ANTISKID SHUTTLE VALVES TO BRAKES.

Antiskid/Auto Brake System - Component Location  
Figure 102 (Sheet 2)

EFFECTIVITY	ALL
-------------	-----

**32-42-00**





**NOTE:** SEE FIG. 102 (SHTS 10 AND 11) FOR SCHEMATIC OF FLOW PATHS FROM ANTISKID VALVES TO ANTISKID SHUTTLE VALVES TO BRAKES.

NOMENCLATURE OF VALVE PORT DECALS  
 NORMALLY STORED IN LANDING GEAR DOWNLOCK PIN BOX AS PART OF FLYAWAY EQUIPMENT WHEN NOT USED

**Antiskid/Auto Brake System - Component Location**  
Figure 102 (Sheet 3)

EFFECTIVITY	ALL
-------------	-----



### 32-42-00

G08516

# BOEING

## 767

### FAULT ISOLATION/MAINT MANUAL



**NOTE:** SEE FIG. 102 (SHTS 10 AND 11) FOR SCHEMATIC OF FLOW PATHS FROM ANTISKID VALVES TO ANTISKID SHUTTLE VALVES TO BRAKES.


1 NOMENCLATURE OF VALVE PORT DECALS  
 1A NORMALLY STORED IN LANDING GEAR DOWNLOCK PIN BOX AS PART OF FLYAWAY EQUIPMENT WHEN NOT USED

**Antiskid/Auto Brake System - Component Location**  
**Figure 102 (Sheet 4)**

EFFECTIVITY	ALL
-------------	-----

32-42-00

**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL



Antiskid/Auto Brake System - Component Location  
Figure 102 (Sheet 5)


EFFECTIVITY

ALL

**32-42-00**

01

Page 108  
Nov 10/96



ANTISKID TRANSDUCER DRIVE AND ANTISKID TRANSDUCER ASSEMBLY

(M)

- 1 ▽ TRANSDUCER DRIVE COMPONENT
- 2 ▽ TRANSDUCER ASSEMBLY COMPONENT


Antiskid/Auto Brake System - Component Location  
Figure 102 (Sheet 6)

EFFECTIVITY  
SAS 150-154  
MTH 275-276 WITHOUT SB 32-85

**32-42-00**

03

Page 109  
Nov 10/96




ANTISKID TRANSDUCER DRIVE AND ANTISKID TRANSDUCER ASSEMBLY

(M)

Antiskid/Auto Brake System - Component Location  
Figure 102 (Sheet 7)

EFFECTIVITY  
SAS 050-149, 155-999  
MTH 275-276 WITH SB 32-85




32-42-00



Antiskid/Auto Brake System - Component Location  
Figure 102 (Sheet 8)

EFFECTIVITY	ALL
-------------	-----


32-42-00



Antiskid/Auto Brake System - Component Location  
Figure 102 (Sheet 9)

EFFECTIVITY	
	ALL

32-42-00



**LEGEND**


- ELECTRICAL
- ▨ HYDRAULIC
- ○ ○ RETURN

Antiskid/Auto Brake System - Component Location  
Figure 102 (Sheet 10)

EFFECTIVITY	ALL
-------------	-----

**32-42-00**





**LEGEND**

- ELECTRICAL
- ▨ HYDRAULIC
- ○ ○ RETURN

Antiskid/Auto Brake System - Component Location  
Figure 102 (Sheet 11)

EFFECTIVITY

ALL
-----

**32-42-00**


**ANTISKID/AUTOBRAKE  
CONTROL UNIT BITE  
PROCEDURE**

**PREREQUISITES**

MAKE SURE THIS SYSTEM WILL OPERATE:  
EICAS (AMM 31-41-00/201)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
6F4, 6K28, 11A35, 11C30, 11C31, 11C32, 11R29, 11U12, 11U15,  
11U18, 11U21, 11U23, 11U27

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
RIGHT AND CENTER SYSTEMS HYDRAULIC POWER  
(AMM 29-11-00/201)  
WHEELS CHOCKED, THRUST LEVERS IN IDLE, LG LEVER  
DOWN, SPOILERS STOWED



1 ERASE "ANTISKID/AUTOBRAKE" EICAS MESSAGE  
(FIM 31-41-00/101, FIG. 109) IF IT APPEARS  
ON EICAS DISPLAY AT P2 PANEL.

Antiskid/Autobrake Control Unit BITE Procedure  
Figure 103 (Sheet 1)

EFFECTIVITY

ALL

**32-42-00**

04

Page 115  
Nov 10/96

FROM SHEET 1  
(BLOCK 1)

YES


2 PLACE THE PRESS/TEST-BIT SWITCH TO BIT POSITION AND THEN RELEASE TO RECALL INFLIGHT FAULT.  
IS FAULT INDICATED ON DISPLAY?

**NOTE:** WHEN THE BIT POSITION IS SELECTED AND RELEASED, THE FIRST FAILURE WILL BE DISPLAYED. SUBSEQUENT BIT SELECTIONS WILL DISPLAY ANY REMAINING FAULTS UNTIL TEST END IS DISPLAYED, INDICATING NO REMAINING FAULTS.

YES

43 RECORD COMPONENT NAME INDICATED AS FAULTY. CONTINUE TO SELECT BIT, AND RECORD EACH FAULT UNTIL ALL STORED FAULTS ARE DISPLAYED.  
REFER TO TABLE 101 FOR CORRECTIVE ACTION FOR ANY OF THE FOLLOWING FAILURES INDICATED ON DISPLAY.

VLV (1 THRU 8)  
VLV (1-2,3-4,5-6,7-8)  
XDCR (1 THRU 8)  
BOX (1-5,2-6,3-7,4-8)  
BOX BITE  
BOX A/B  
A/B CNTL  
A/B SOL  
A/B SEL  
PARK BRK  
IRS (L, R)  
A/G SW  
THR SW  
MEM FULL


AFTER CORRECTING THE FAULT, PRESS THE RESET BUTTON ON UNIT TO CLEAR FAULT STORED IN MEMORY. 

**NOTE:** UNIT DISPLAY WILL READ MEM CLR FOR ABOUT 5 SECONDS.


NO

SEE SHEET 3  
(BLOCK 3)

Antiskid/Autobrake Control Unit BITE Procedure  
Figure 103 (Sheet 2)



32-42-00



Antiskid/Autobrake Control Unit BITE Procedure  
Figure 103 (Sheet 3)


EFFECTIVITY

ALL

**32-42-00**

02

Page 117  
Nov 10/96



Antiskid/Autobrake Control Unit BITE Procedure  
Figure 103 (Sheet 4)

EFFECTIVITY

ALL

**32-42-00**

02

Page 118  
Aug 10/98

121922


**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

MESSAGE DISPLAYED	CORRECTIVE ACTION
VLV 1 OR 2, 3, 4, 5, 6, 7, 8, 1-2, 3-4, 5-6, 7-8	REMOVE CONNECTOR ON THE AFFECTED VALVE. CHECK THAT RESISTANCE BETWEEN PINS 1 AND 2 OF VALVE IS 185 ±50 OHMS. IF NOT OK, REPLACE VALVE (AMM 32-42-03/401). IF OK, REMOVE ANTISKID/AUTOBRAKE CONTROL UNIT, M102 (AMM 32-42-01/401), EXAMINE THE CIRCUIT FROM THE CONTROL UNIT FOR OPEN OR SHORT TO GROUND AND SHORT BETWEEN WIRES (WDM 32-42-11). REPAIR THE PROBLEMS THAT YOU FIND. INSTALL UNIT M102.
XDCR 1 OR 2,3,4,5,6,7,8	REMOVE CONNECTOR ON THE AFFECTED TRANSDUCER. CHECK THAT RESISTANCE BETWEEN PINS 1 AND 3 ON TRANSDUCER (WDM 32-42-11) IS GREATER THAN 545 OHMS. CHECK THAT INDUCTANCE BETWEEN PINS 1 AND 3 IS GREATER THAN 0.75 HENRY, USING 1 KHZ INDUCTANCE. IF NOT OK, REPLACE TRANSDUCER (AMM 32-42-06/401). IF OK, REMOVE ANTISKID/AUTOBRAKE CONTROL UNIT, M102 (AMM 32-42-01/401). EXAMINE THE CIRCUIT FROM THE CONTROL UNIT FOR AN OPEN WIRE, ONE WIRE SHORTED TO GROUND OR BOTH WIRES SHORTED TOGETHER (WDM 32-42-11). REPAIR THE PROBLEMS THAT YOU FIND. INSTALL UNIT M102.
BOX 1-5 OR 2-6, 3-7, 4-8	<p>REPLACE APPROPRIATE WHEEL CARD OR THE ANTISKID/AUTOBRAKE CONTROL UNIT, M102 (AMM 32-42-01/401). IF NOT OK, REPLACE TRANSDUCER 1 OR 5, 2 OR 6, 3 OR 7, 4 OR 8 (AMM 32-42-06/401).</p> <p><b>NOTE:</b> THE FAULT MESSAGE 1-5, 2-6, 3-7, OR 4-8 COULD BE CAUSED BY A TRANSDUCER INDUCTIVE FAILURE. USE DISABLE SWITCH ON ANTISKID/AUTOBRAKE CONTROL UNIT TO ISOLATE BAD TRANSDUCER. IF THERE IS A BAD TRANSDUCER AT A SELECTED DISABLE POSITION, THE FAULT INDICATION WILL CLEAR.</p> <p>IF NOT OK, THIS FAULT MAY HAVE BEEN CAUSED BY A NORMAL OR ALTERNATE ANTISKID VALVE THAT IS OUT OF TOLERANCE. DO THE CORRECTIVE ACTION AS DETAILED IN THE NORMAL ANTISKID VLV 1 OR 2, 3, 4, 5, 6, 7 OR 8 FAULT OR IN THE ALTERNATE ANTISKID VLV 1-2, 3-4, 5-6, 7-8 FAULT.</p> <p><b>NOTE:</b> BOX 1-5 CORRESPONDS WITH ANTISKID VALVES 1 AND 5, BOX 2-6 CORRESPONDS WITH ANTISKID VALVES 2 AND 6, BOX 3-7 CORRESPONDS WITH ANTISKID VALVES 3 AND 7, BOX 4-8 CORRESPONDS WITH ANTISKID VALVES 4 AND 8.</p> <p>THE BOX 1-5, 2-6, 3-7, 4-8 FAULTS MAY BE CAUSED WHEN THE ANTISKID VALVE IS BETWEEN THE UPPER TOLERANCE LIMIT OF 235 OHMS AND 3500 OHMS. THE VLV 1, 2, 3, 4, 5, 6, 7 OR 8 FAULTS ARE CAUSED WHEN THE ANTISKID VALVE RESISTANCE IS GREATER THAN 3500 OHMS.</p>
BOX BITE	REPLACE BITE CARD OR THE ANTISKID/AUTOBRAKE CONTROL UNIT, M102 (AMM 32-42-01/401).
BOX A/B	PUSH RESET BUTTON ON CONTROL UNIT TO CLEAR FAULT INDICATION(S). GO TO BLOCK 3. IF "BOX A/B" FAULT REPEATS DURING THIS TEST, REPLACE ANTISKID/AUTOBRAKE CONTROL UNIT, M102 (AMM 32-42-01/401). AACU P/N S283T001-11: IF NO FAULTS ARE INDICATED, CONTROL UNIT IS SATISFACTORY (NUISANCE FAULT).
A/B CNTL	PUSH RESET BUTTON ON CONTROL UNIT TO CLEAR FAULT INDICATIONS. GO TO BLOCK 3. ENSURE THAT NO OTHER SYSTEM OR TESTS ARE PUTTING A DEMAND ON THE RIGHT HYDRAULIC SYSTEM WHILE THE TEST IS RUNNING. IF "A/B CNTL" FAULT REPEATS, REMOVE THE AUTOBRAKE CONTROL (SERVO) VALVE, CONNECTOR D2198. CHECK THAT RESISTANCE BETWEEN PINS 1 AND 2 ON VALVE (WDM 32-42-12) IS 500 ±50 OHMS. IF NOT OK, REPLACE CONTROL VALVE, YAAV2 (AMM 32-42-09/401). IF OK, RECONNECT CONNECTOR D2198, AND REPLACE CONTROL VALVE PRESSURE SWITCH, YAAS1 (AMM 32-42-09/401). RECONNECT CONNECTOR D2200. REPEAT BLOCK 3. IF "A/B CTRL" FAULT REPEATS, REPLACE AUTOBRAKE VALVE MODULE (AMM 32-42-09/401).
A/B SOL	REMOVE THE AUTOBRAKE SOLENOID VALVE, CONNECTOR D2196, CHECK THAT RESISTANCE BETWEEN PINS 1 AND 2 ON VALVE (WDM 32-42-12) IS A MINIMUM OF 65 OHMS, BUT DOES NOT EXCEED 500 OHMS. IF NOT OK, REPLACE SOLENOID VALVE, YAAV1 (AMM 32-42-09/401). IF OK, RECONNECT CONNECTOR D2196, AND REPLACE SOLENOID VALVE PRESSURE SWITCH, YAAS2 (AMM 32-42-09/401). RECONNECT CONNECTOR D2202.

TABLE 101

Antiskid/Autobrake Control Unit BITE Procedure  
 Figure 103 (Sheet 5)

EFFECTIVITY

ALL

32-42-00

01

Page 119  
Aug 22/06


45639


**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

MESSAGE DISPLAYED	CORRECTIVE ACTION
A/B SEL	REPLACE AUTOBRAKES SELECTOR SWITCH, S24 (WDM 32-42-12).
PARK BRK	REFER TO FIM 32-44-00/101, FIG. 105.
A/G SW	REFER TO FIG. 105.
THR SW	REFER TO FIG. 104.
IRS L, OR IRS R	REFER TO FIM 34-21-00/101, FIG. 107. IF THE PROBLEM CONTINUES, REPLACE RELAY, K511, IN P36 PANEL FOR IRS L AND RELAY, K510, IN P37 PANEL FOR IRS R (WDM 32-42-11).
GEAR SW 1 OR GEAR SW 2	CHECK THAT LANDING GEAR IS DOWN AND LOCKED. IF OK, REPLACE LANDING GEAR CONTROL LEVER MODULE (AMM 32-31-01/401).
PRES L	CHECK THAT MANUAL BRAKING IS NOT BEING APPLIED AND THAT PARKING BRAKE IS NOT SET. IF OK, REPLACE LEFT METERED PRESSURE SWITCH ON THE AUTO-BRAKE SHUTTLE VALVE ASSEMBLY (AMM 32-42-10/401).
PRES R	CHECK THAT MANUAL BRAKING IS NOT BEING APPLIED AND THAT PARKING BRAKE IS NOT SET. IF OK, REPLACE RIGHT METERED PRESSURE SWITCH ON THE AUTO-BRAKE SHUTTLE VALVE ASSEMBLY (AMM 32-42-10/401).
THR L1 OR L2, R1, R2	CHECK THAT THRUST LEVERS ARE NOT ADVANCED. IF OK, REPLACE APPROPRIATE THRUST LEVER SWITCH (AMM 22-32-04/201).
SPLR HDL	RESTOW SPOILER HANDLE.
A/G 1	REPLACE AIR/GROUND RELAY, K199, IN P36 PANEL (AMM 32-09-02/401).
A/G 2	REPLACE AIR/GROUND RELAY, K293, IN P37 PANEL (AMM 32-09-02/401).
PRES ACC	PROVIDE RIGHT AND CENTER HYDRAULIC POWER (AMM 29-11-00/201).
PWR A/B, OR 1-5, 2-6, 3-7, 4-8, BITE	CHECK THAT 28V DC POWER IS AT THE APPROPRIATE CIRCUIT BREAKERS C1173 (11U21), C1171 (11U18), C1183 (11C31), C1184 (11C32), C1172 (11U27), C1176 (11U12) (WDM 32-42-11, -12).
SOL PSW	REPLACE SOLENOID VALVE PRESSURE SWITCH (AMM 32-42-09/401).
CNTL PSW	REPLACE CONTROL VALVE PRESSURE SWITCH (AMM 32-42-09/401).
MEM FULL	REPLACE ANTISKID/AUTOBRAKE CONTROL UNIT.

TABLE 101

Antiskid/Autobrake Control Unit BITE Procedure  
 Figure 103 (Sheet 6)



32-42-00


**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL


BRAKE TEST SWITCH POSITION	MESSAGE DISPLAY DURING BRAKE CYCLE	NORMAL ANTISKID SYSTEM	ALTERNATE ANTISKID SYSTEM
		WHEEL NO.	WHEEL NO.
BRAKE TEST 1	BRK 1	1	1-2
BRAKE TEST 5	BRK 5	5	5-6
BRAKE TEST 2	BRK 2	2	1-2
BRAKE TEST 6	BRK 6	6	5-6
BRAKE TEST 3	BRK 3	3	3-4
BRAKE TEST 7	BRK 7	7	7-8
BRAKE TEST 4	BRK 4	4	3-4
BRAKE TEST 8	BRK 8	8	7-8

TABLE 102

AUTOBRAKE SEL POSITION	DISPLAY MESSAGE	BRAKE PRESSURE (PSI)
1	BRK A/B 1	1290 ±200 FOR ABOUT 10 SEC, RETURN TO 300 ±100 FOR ABOUT 5 SEC, THEN TO ZERO
2	BRK A/B 2	1500 ±200 FOR ABOUT 10 SEC, RETURN TO 300 ±100 FOR ABOUT 5 SEC, THEN TO ZERO
3	BRK A/B 3	1750 ±200 FOR ABOUT 10 SEC, RETURN TO 300 ±100 FOR ABOUT 5 SEC, THEN TO ZERO
4	BRK A/B 4	2050 ±200 FOR ABOUT 10 SEC, RETURN TO 300 ±100 FOR ABOUT 5 SEC, THEN TO ZERO
MAX AUTO	BRK A/B 5	3000 ±200 FOR ABOUT 10 SEC, RETURN TO 300 ±100 FOR ABOUT 5 SEC, THEN TO ZERO
RTO	BRK RTO	2900 ±100 FOR ABOUT 15 SEC, RETURN TO LESS THAN 100, THEN TO ZERO

TABLE 103

Antiskid/Autobrake Control Unit BITE Procedure  
Figure 103 (Sheet 7)



32-42-00



**"THR SW" FAILURE MESSAGE INDICATED ON DISPLAY WITH BIT (MEMORY RECALL) SELECTED (ANTISKID/AUTOBRAKE CONTROL UNIT BITE PROCEDURE)**

**PREREQUISITES**

ELECTRICAL POWER (MM 24-22-00)  
RIGHT SYSTEM HYDRAULIC POWER (MM 29-11-00)  
EICAS (MM 31-41-00)  
WHEEL CHOCKED, THRUST LEVERS IN IDLE, LG LEVER DOWN, SPOILERS STOWED  
CB'S: 6F4,6K28,11A35,11C30,11C31,11C32,11R29,11U12,11U15,11U18,11U21,11U23,11U27

**1** RELEASE PARKING BRAKE. PLACE IRU IN NAV MODE (MM 34-21-00).  
PLACE THE ANTISKID/AUTOBRAKE CONTROL UNIT'S BRAKE ROTARY SWITCH AT NORM. PLACE THE AUTOBRAKES SELECTOR SWITCH S24 ON P1-3 PANEL IN MAX AUTO POSITION AND HOLD THRU BLOCK 2 ACTION. PLACE THE RIGHT THRUST LEVER IN THE ADVANCED POSITION.  
**NOTE:** AUTOBRAKES LIGHT ON P1-3 WILL ILLUMINATE AND MESSAGE AUTOBRAKES WILL APPEAR ON EICAS.  
PRESS UNIT'S ENABLE/VERIFY SWITCH AND HOLD, THEN PRESS THE VERIFY SWITCH AND RELEASE BOTH. THE DISPLAY WILL READ THR R1.  
PRESS THE VERIFY SWITCH AGAIN, THE DISPLAY WILL READ THR R2.  
DOES THE DISPLAY READ AS DESCRIBED?

NO

**10** IS THE MESSAGE "THR R1" ABSENT ON DISPLAY?

YES

**20** REPLACE THRUST LEVER POSITION SWITCH S6 (MM 22-32-04). PERFORM BLOCK 2 ACTION.

NO

**21** REPLACE THRUST LEVER POSITION SWITCH S7 (MM 22-32-04). PERFORM BLOCK 2 ACTION.

YES

**2** RETURN THE RIGHT THRUST LEVER TO IDLE. PLACE THE LEFT THRUST LEVER IN THE ADVANCED POSITION.  
PRESS THE ENABLE/VERIFY SWITCH AND HOLD, THEN PRESS THE VERIFY SWITCH AND RELEASE BOTH. THE DISPLAY WILL READ THR L1.  
PRESS THE VERIFY SWITCH AGAIN. THE DISPLAY WILL READ THR L2.  
DOES THE DISPLAY READ AS DESCRIBED?

NO

**11** IS THE MESSAGE "THR L1" ABSENT ON DISPLAY?

YES

**22** REPLACE THRUST LEVER POSITION SWITCH S2 (MM 22-32-04). PERFORM BLOCK 3 ACTION.

NO

**23** REPLACE THRUST LEVER POSITION SWITCH S3 (MM 22-32-04). PERFORM BLOCK 3 ACTION.

YES

**3** RETURN THE AUTOBRAKES SELECTOR SWITCH TO OFF AND THE LEFT THRUST LEVER TO IDLE. SYSTEM IS OK.



ERASE "ANTISKID/AUTOBRK" EICAS MESSAGE (31-41-00, FIG. 109) IF IT APPEARS ON EICAS DISPLAY AT P2 PANEL

THR SW Failure Message Indicated on Display With BIT (Memory Recall) Selected (Antiskid/Autobrake Control Unit BITE Procedure)  
Figure 104


EFFECTIVITY

ALL

**32-42-00**

"A/G SW" FAILURE MESSAGE INDICATED ON DISPLAY WITH BIT (MEMORY RECALL) SELECTED (ANTISKID/AUTOBRAKE CONTROL UNIT BITE PROCEDURE)

**PREREQUISITES**  
ELECTRICAL POWER (MM 24-22-00)  
RIGHT SYSTEM HYDRAULIC POWER (MM 29-11-00)  
EICAS (MM 31-41-00)  
PROXIMITY SWITCH ACTUATOR/DEACTUATOR SET - A27092-25 (2 ACTUATORS FOR RECTANGULAR SENSORS REQUIRED)  
CB'S: 6F4,6K28,11A35,11C30,11C31,11C32,11R29,11T36,11U12,11U15,11U18,11U21,11U23,11U27




A/G SW Failure Message Indicated on Display With BIT (Memory Recall) Selected (Antiskid/Autobrake Control Unit BITE Procedure)  
Figure 105 (Sheet 1)

EFFECTIVITY	ALL
-------------	-----

32-42-00

294612




A/G SW Failure Message Indicated on Display With BIT (Memory Recall)  
 Selected (Antiskid/Autobrake Control Unit BITE Procedure)  
 Figure 105 (Sheet 2)

EFFECTIVITY	ALL
-------------	-----

32-42-00

AUTOBRAKE SELECTOR  
WILL NOT LATCH INTO  
POSITION(S). ANTI-  
SKID LGT WAS NOT  
ILLUM.

**PREREQUISITES**  
ELECTRICAL POWER (MM 24-22-00)  
CB'S: 11C31,11C32,11U12,11U18,11U21,11U27




Autobrake Selector Will Not Latch into Position(s).  
Antiskid Lgt was Not Illum.  
Figure 106

EFFECTIVITY	ALL
-------------	-----

32-42-00

**AUTOBRAKE  
SELECTOR WILL NOT  
LATCH IN "RTO" POSI-  
TION WITH NO FAULT  
INDICATIONS**

**PREREQUISITES**  
 ELECTRICAL POWER (MM 24-22-00)  
 CB'S: 11C31,11C32,11U12,11U18,11U21,11U27




Autobrake Selector Will Not Latch in RTO Position with No Fault Indications  
Figure 107

EFFECTIVITY	ALL
-------------	-----

**32-42-00**

Not Used  
Figure 108



**32-42-00**

05

Page 127  
Nov 10/96

48419

**EICAS MSG "NORM ANTISKID" DISPLAYED**

**PREREQUISITES**

MAKE SURE THIS SYSTEM WILL OPERATE:  
EICAS (AMM 31-41-00/201)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
6F4,6K28,11A35,11C30,11C31,11C32,11R29,11U12,11U15,11U18,11U21,11U23,11U27

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
RIGHT AND CENTER SYSTEMS HYDRAULIC POWER (AMM 29-11-00/201)  
THRUST LEVERS IN IDLE, LG LEVER DOWN, SPOILERS STOWED

1 ALIGN L,R, AND C IRU IN NAV MODE (AMM 34-21-00/401). MAKE SURE THE WHEEL CHOCKS ARE IN POSITION. RELEASE THE PARKING BRAKE.  
DOES THE DISPLAY SHOW "NORM ANTISKID" AFTER PREREQUISITES ARE COMPLETED?

11 DO THIS PROCEDURE: ANTI-SKID/AUTOBRAKE CONTROL UNIT BITE PROCEDURE CONTROL TEST (FIG. 103, BLOCK 3).  
DID THE BITE SHOW ONE OR MORE FAILURES?

20 DO ALL OF THE PROCEDURES NECESSARY TO CORRECT THE FAILURES. 1

12 REMOVE ANTISKID 1-5 FAIL RELAY, K10229, IN P36 PANEL (WDM 32-42-11).  
DOES THE ANTISKID LIGHT ON THE P5 PANEL GO OFF?

21 REPLACE THE ANTISKID 1-5 FAIL RELAY, K10229, IN THE P36 PANEL (WDM 32-42-11). 1

13 INSTALL RELAY K10229. REMOVE ANTISKID 4-8 FAIL RELAY, K10230, IN P36 PANEL (WDM 32-42-11).  
DOES THE ANTISKID LIGHT ON THE P5 PANEL GO OFF?

22 REPLACE THE ANTISKID 4-8 FAIL RELAY, K10230, IN THE P36 PANEL (WDM 32-42-11). 1

14 INSTALL RELAY K10230. REMOVE ANTISKID 2-6 FAIL RELAY, K10231, IN P36 PANEL (WDM 32-42-11).  
DOES THE ANTISKID LIGHT ON THE P5 PANEL GO OFF?

23 REPLACE THE ANTISKID 2-6 FAIL RELAY, K10231, IN THE P36 PANEL (WDM 32-42-11). 1

24 INSTALL RELAY K10231. REPLACE THE ANTISKID 3-7 FAIL RELAY, K10232, IN THE P36 PANEL (WDM 32-42-11). 1

2 DO THIS PROCEDURE: ANTI-SKID/AUTOBRAKE CONTROL UNIT BITE PROCEDURE - INFLIGHT MEMORY RECALL (FIG. 103, BLOCK 2).  
DID THE DISPLAY SHOW ONE OR MORE FAILURES?

25 DO ALL OF THE PROCEDURES NECESSARY TO CORRECT THE FAILURES. 1

3 THE SYSTEM IS OK. 1

1 SET THE PARKING BRAKE. PUT L,R, AND C IRUS TO OFF.

EICAS Msg NORM ANTISKID Displayed  
Figure 109

EFFECTIVITY	ALL
-------------	-----


**32-42-00**

294614

**EICAS MSG "ALTN  
ANTISKID" DISPLAYED**

**PREREQUISITES**

ELECTRICAL POWER (MM 24-22-00)  
 RIGHT AND CENTER SYSTEMS HYDRAULIC POWER (MM 29-11-00)  
 EICAS (MM 31-41-00)  
 THRUST LEVERS IN IDLE, LG LEVER DOWN, SPOILERS STOWED  
 CB'S: 6F4,6K28,11A35,11C30,11C31,11C32,11R29,11U12,  
 11U15,11U18,11U21,11U23,11U27



1 SET THE PARKING BRAKE.  
 PUT L,R, & C IRU'S TO OFF.

EICAS Msg ALTN ANTISKID Displayed  
Figure 110

EFFECTIVITY	ALL
-------------	-----

**32-42-00**



**EICAS MSG  
"ANTISKID/AUTOBRK"  
DISPLAYED**



**1** OPEN MAIN EQUIP CTR ACCESS DOOR, 119AL AND LOCATE ANTISKID/AUTOBRAKE CONTROL UNIT, M102 ON E1 RACK.  
PLACE THE PRESS/TEST-BIT SWITCH TO BIT POSITION AND THEN RELEASE TO RECALL INFIGHT FAULT(S).

**NOTE:** WHEN THE BIT POSITION IS SELECTED AND RELEASED, THE FIRST FAILURE WILL BE DISPLAYED. SUBSEQUENT BIT SELECTIONS WILL DISPLAY ANY REMAINING FAULTS UNTIL "TESTEND" IS DISPLAYED, INDICATING THE LAST STORED FAULT.

RECORD ANY INDICATED FAULTS.

**NOTE:** MESSAGE "BOX A/B" FAULT IS NORMALLY ASSOCIATED WITH THE "ANTISKID/AUTOBRK" EICAS MESSAGE.

PRESS THE REST BUTTON ON UNIT TO CLEAR FAULT(S) STORED IN MEMORY.

**NOTE:** UNIT DISPLAY WILL READ "MEM CLR" FOR ABOUT 5 SECONDS.

RELEASE PARKING BRAKE.  
PLACE IRU IN NAV MODE (AMM 34-21-00/201).  
POSITION AUTOBRAKE SELECTOR SWITCH ON P1 PANEL TO POSITION 1.  
WITH ROTARY SWITCH ON UNIT AT NORM, PRESS AND HOLD THE ENABLE/VERIFY SWITCH, THEN PRESS VERIFY SWITCH AND RELEASE BOTH.

**NOTE:** THE DISPLAY WILL FLASH "WAIT" WHILE TEST IS RUNNING.

IS "BOX A/B" FAULT INDICATION DISPLAYED ON UNIT?


**NOTE:** IF ANY FAULT IS INDICATED, PRESS VERIFY SWITCH UNTIL "TEST END" IS DISPLAYED.

**PREREQUISITES**

MAKE SURE THIS SYSTEM WILL OPERATE:  
EICAS (AMM 31-41-00/201)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
6F4, 6K28, 11A35, 11C30, 11C31, 11C32, 11R29, 11U12, 11U15, 11U18, 11U21, 11U23, 11U27

MAKE SURE THE AIRPLANE IS IN THESE CONFIGURATIONS:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
RIGHT AND CENTER SYSTEMS HYDRAULIC POWER (AMM 29-11-00/201)  
WHEELS CHOCKED, THRUST LEVERS IN IDLE, LG LEVER DOWN, SPOILERS STOWED



- 1 ▷ ERASE "ANTISKID/AUTOBRK" EICAS MESSAGE (FIM 31-41-00/101, FIG. 109).
- 2 ▷ AN "ANTISKID/AUTOBRAKE" NUISANCE MESSAGE CAN OCCUR DURING GROUND OPERATION ON AIRPLANES EQUIPPED WITH S283T001-25 ANTISKID/AUTOBRAKE CONTROL UNITS. THIS CAN OCCUR IF THE AIRPLANE IS MOVING AT VERY LOW SPEED (BELOW 3 KNOTS) WITH NEITHER THE RIGHT OR CENTER HYDRAULIC SYSTEM OPERATING AND THE BRAKE ACCUMULATOR THE ONLY HYDRAULIC SOURCE FOR THE BRAKE SYSTEM. THE MESSAGE "VLV 3-4" TYPICALLY APPEARS ON THE CONTROL UNIT DISPLAY WHEN THE ANTISKID/AUTOBRAKE EICAS MESSAGE IS DISPLAYED. PRESS THE MEMORY RESET ON THE CONTROL UNIT. IF THE MESSAGE GOES OFF, NO FURTHER ACTION IS NECESSARY.

EICAS Msg ANTISKID/AUTOBRK Displayed  
Figure 111

EFFECTIVITY

---


ALL

**32-42-00**

**AUTOBRAKES  
DISARMED ON  
LANDING ROLL**

**PREREQUISITES**

ELECTRICAL POWER (MM 24-22-00)  
RIGHT AND CENTER SYSTEMS HYDRAULIC POWER (MM 29-11-00)  
EICAS (MM 31-41-00)  
WHEELS CHOCKED, THRUST LEVERS IN IDLE, LG LEVER DOWN,  
SPOILERS STOWED  
CB'S: 6F4,6K28,11A35,11C30,11C31,11C32,11R29,11U12,  
11U15,11U18,11U21,11U23,11U27



Autobrakes Disarmed on Landing Roll  
Figure 111A (Sheet 1)

EFFECTIVITY

ALL

**32-42-00**

08

Page 131  
Nov 10/96

FROM SHEET 1  
(BLOCK 2)

NO

**3** DISCONNECT ELECTRICAL CONNECTORS D1404 AND D1364 AT AUTOTHROTTLE MICROSWITCH PACK M966 (WM 32-42-12).  
 CHECK FOR OPEN CIRCUIT BETWEEN CONNECTOR D2372B PINS A2, D6 AND CONNECTOR D1404 PINS 5, 2, ALSO BETWEEN CONNECTOR D2372B PINS A7, A4 AND CONNECTOR D1364 PINS 15, 12 (WM 32-42-12).  
 DOES OPEN CIRCUIT EXIST?

**NOTE:** AUTOBRAKES WILL DISARM IF ANY THRUST LEVER SWITCH INDICATES ADVANCED ON GROUND FOR MORE THAN 3 SECONDS.

YES

**32** CHECK AND REPAIR CIRCUIT FROM D2372B PINS A2, D6 TO D1404 PINS 5, 2, AND FROM D2372B PINS A7, A4 TO D1364 PINS 15, 12 (WM 32-42-12).  
 INSTALL ANTISKID/AUTOBRAKE CONTROL UNIT M102 (MM 32-42-01).  
 INSTALL CONNECTORS D1404 AND D1364 ON AUTOTHROTTLE MICROSWITCH PACK M966.

NO

**33** CHECK AND REPAIR OPEN CIRCUIT FROM CB C1176 (11U12) TO D2372B PIN A11 (WM 32-42-11).  
 INSTALL ANTISKID/AUTOBRAKE CONTROL UNIT M102 (MM 32-42-01).  
 INSTALL CONNECTORS D1404 AND D1364 ON AUTOTHROTTLE MICROSWITCH PACK M966.

**NOTE:** AUTOBRAKES WILL DISARM IF 28 VOLT DC POWER TO ANTISKID/AUTOBRAKE CONTROL UNIT M102 IS LOST.

Autobrakes Disarmed on Landing Roll  
Figure 111A (Sheet 2)

EFFECTIVITY

ALL

**32-42-00**

01

Page 132  
Nov 10/96

**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

PARKING BRAKE SYSTEM

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
ACCUMULATOR - PARKING BRAKE	2	1	RIGHT MAIN LANDING GEAR WHEEL WELL	32-44-06
BRAKES - (REF 32-41-00, FIG. 101) HYDRAULIC				
CABLES - (REF 32-41-00, FIG. 101) BRAKE				
CHECK VALVE - (REF 32-41-00, FIG. 101) ACCUMULATOR ISOLATION				
CIRCUIT BREAKERS	3		FLIGHT COMPARTMENT, P6, P11	
BRAKE PRESS., C1180		1	11U22	*
LANDING GEAR PARKING BRAKE VLV, C1179		1	6F4	*
GAGE - ACCUMULATOR PRESSURE	2	1	RIGHT MAIN LANDING GEAR WHEEL WELL	32-44-00
GAGE - (REF 32-41-00, FIG. 101) BRAKE PRESSURE, N10				
HANDLE/CABLE - PARKING BRAKE	3	1	FLIGHT COMPARTMENT, P10 AND 113AL, FORWARD EQUIPMENT CENTER	32-44-01
LIGHT - PARK BRAKE INDICATION, L592	3	1	FLIGHT COMPARTMENT, P10	*
MECHANISM - PARKING BRAKE	1	1	113AL, FORWARD EQUIPMENT CENTER, BRAKE PEDAL BUS MECHANISM	32-44-02
MODULE - (REF 32-41-00, FIG. 101) (NORMAL/ALTERNATE) METERING VALVE				
OVERRIDE LEVER - MANUAL	1	1	RIGHT MAIN LANDING GEAR WHEEL WELL	32-44-00
PEDALS - (REF 32-41-00, FIG. 101) BRAKE, CAPTAIN'S AND FIRST OFFICER'S		4		
RELAY - (REF 31-01-36, FIG. 101) CLOSE SENSE, K419		1	119AL, MAIN EQUIPMENT CENTER, P36	*
SWITCH - PARKING BRAKE, S459	1	1	113AL, FORWARD EQUIPMENT CENTER	32-44-08
TRANSDUCER - (REF 32-41-00, FIG. 101) BRAKE PRESSURE				
VALVE - (REF 32-41-00, FIG. 101) ACCUMULATOR ISOLATION				
VALVE AND MOTOR - PARKING BRAKE, V41	2	1	RIGHT MAIN LANDING GEAR WHEEL WELL	32-44-04
VALVE - ACCUMULATOR CHARGING	2	1	RIGHT MAIN LANDING GEAR WHEEL WELL	32-44-07

\* SEE THE WDM EQUIPMENT LIST

Parking Brake System - Component Index  
Figure 101


EFFECTIVITY

ALL

**32-44-00**

01


Page 101  
Feb 10/91



Parking Brake System - Component Location  
Figure 102 (Sheet 1)

EFFECTIVITY	
	ALL

32-44-00




Parking Brake System - Component Location  
Figure 102 (Sheet 2)


EFFECTIVITY	
	ALL

**32-44-00**

**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL



FLIGHT COMPARTMENT



QUADRANT STAND PANEL, P10

(G)

Parking Brake System - Component Location  
Figure 102 (Sheet 3)

EFFECTIVITY	
ALL	

32-44-00


**PREREQUISITES**

MAKE SURE THIS SYSTEM WILL OPERATE:  
EICAS (AMM 31-41-00/201)

MAKE SURE THIS CIRCUIT BREAKER IS CLOSED:  
6F4

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)

**PARKING BRAKE HANDLE  
(LOOSE, BINDS, OR  
HARD TO SET)**



Parking Brake Handle (Loose, Binds, or Hard to Set)  
Figure 103


EFFECTIVITY	ALL
-------------	-----

**32-44-00**



**WITH PARK BRAKE SET, "PARK BRAKE" LIGHT REMAINS EXTINGUISHED**

**PREREQUISITES**  
MAKE SURE THIS SYSTEM WILL OPERATE:  
EICAS (MM 31-41-00/201)  
MAKE SURE THIS CIRCUIT BREAKER IS CLOSED:  
6F4  
MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:  
ELECTRICAL POWER IS ON (MM 24-22-00/201)



**1** **WARNING:** USE THE PROCEDURE IN MM 32-00-15/201 TO REMOVE THE DOOR LOCKS. THE DOORS OPEN AND CLOSE QUICKLY AND CAN CAUSE INJURIES TO PERSONS OR DAMAGE TO EQUIPMENT.  
REMOVE THE DOOR LOCKS FROM THE MAIN LANDING GEAR AND CLOSE THE DOORS (MM 32-00-15/201).

With Park Brake Set, PARK BRAKE Light Remains Extinguished  
Figure 104


EFFECTIVITY  
ALL

**32-44-00**

213484

**WITH PARK BRAKE RELEASED, "PARK BRAKE" LIGHT REMAINS ILLUMINATED**

**PREREQUISITES**  
 MAKE SURE THIS CIRCUIT BREAKER IS CLOSED:  
 6F4  
 MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
 ELECTRICAL POWER IS ON (AMM 24-22-00/201)



**1** **WARNING:** USE THE PROCEDURE IN AMM 32-00-15/201 TO REMOVE THE DOOR LOCKS. THE DOORS OPEN AND CLOSE QUICKLY AND CAN CAUSE INJURY TO PERSONS OR DAMAGE TO EQUIPMENT.

REMOVE THE DOOR LOCKS FROM THE MAIN LANDING GEAR AND CLOSE THE DOORS (AMM 32-00-15/201).


With Park Brake Released, PARK BRAKE Light Remains Illuminated  
Figure 105

EFFECTIVITY	ALL
-------------	-----

32-44-00

**PREREQUISITES**  
 MAKE SURE THIS SYSTEM WILL OPERATE:  
 EICAS (MM 31-41-00/201)  
 MAKE SURE THIS CIRCUIT BREAKER IS CLOSED:  
 6F4  
 MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:  
 ELECTRICAL POWER IS ON (MM 24-22-00/201)

**PARKING BRAKE CANNOT BE SET**



Parking Brake Cannot Be Set  
Figure 106

EFFECTIVITY

ALL

**32-44-00**

01

Page 108  
Feb 10/91

48659


PARKING BRAKE HANDLE  
MUST BE PUSHED DOWN  
TO RELEASE BRAKES  
AND EXTINGUISH  
"PARK BRAKE" LIGHT

**PREREQUISITES**

MAKE SURE THIS SYSTEM WILL OPERATE:  
EICAS (AMM 31-41-00/201)

MAKE SURE THIS CIRCUIT BREAKER IS CLOSED:  
6F4

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT  
FOLLOWS:  
ELECTRICAL POWER IS ON (AMM 22-24-00/201)




Parking Brake Handle Must be Pushed Down to Release Brakes  
and Extinguish PARK BRAKE Light  
Figure 106A

EFFECTIVITY	ALL
-------------	-----

32-44-00

**BRAKE ACCUMULATOR PRESSURE BLEED DOWN RATE IS TOO HIGH WHEN THE 30 MINUTE BRAKE BLEED DOWN TEST IS PERFORMED (PARKING BRAKE RELEASED).**


**PREREQUISITES**  
 MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
 6F4,11U2  
 MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
 ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
 RIGHT AND CENTER HYDRAULIC SYSTEM PRESSURE IS OFF (AMM 29-11-00/201)  
 THE PARKING BRAKE IS RELEASED



Brake Accumulator Pressure Bleed Down Rate Is Too High When the 30 Minute Brake Bleed Down Test Is Performed (Parking Brake Released).  
Figure 107 (Sheet 1)

EFFECTIVITY	ALL
-------------	-----

32-44-00



Brake Accumulator Pressure Bleed Down Rate Is Too High When  
the 30 Minute Brake Bleed Down Test Is Performed (Parking Brake Released).  
Figure 107 (Sheet 2)

EFFECTIVITY

ALL
-----


32-44-00

08

Page 111  
Aug 22/99

**BRAKE ACCUMULATOR  
 PRESSURE BLEED DOWN  
 RATE IS TOO HIGH  
 WHEN THE 30 MINUTE  
 BRAKE BLEED DOWN  
 TEST IS PERFORMED  
 (PARKING BRAKE  
 SET).**

**PREREQUISITES**  
 MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
 6F4,11U2  
 MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
 ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
 RIGHT AND CENTER HYDRAULIC SYSTEM PRESSURE IS OFF  
 (AMM 29-11-00/201)  
 THE PARKING BRAKE IS SET




Brake Accumulator Pressure Bleed Down Rate Is Too High When  
 the 30 Minute Brake Bleed Down Test Is Performed (Parking Brake Set).  
 Figure 108 (Sheet 1)

EFFECTIVITY	ALL
-------------	-----

**32-44-00**

611004



Brake Accumulator Pressure Bleed Down Rate Is Too High When  
 the 30 Minute Brake Bleed Down Test Is Performed (Parking Brake Set).  
 Figure 108 (Sheet 2)

EFFECTIVITY

ALL

**32-44-00**


01

Page 113  
Dec 22/01

611005



FROM SHEET 2  
(BLOCK 7)



Brake Accumulator Pressure Bleed Down Rate Is Too High When  
the 30 Minute Brake Bleed Down Test Is Performed (Parking Brake Set).  
Figure 108 (Sheet 3)

EFFECTIVITY

ALL

**32-44-00**

01

Page 114  
Aug 22/99

G11002

 **BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

WHEELS AND TIRES

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
ASSEMBLY - MAIN GEAR TIRE & WHEEL	2	8	MAIN LANDING GEAR	32-45-01
ASSEMBLY - NOSE GEAR TIRE & WHEEL	2	2	NOSE LANDING GEAR	32-45-02
CIRCUIT BREAKER - TIRE PRESSURE IND 1, C1186	1	1	FLT COMPT, P11 11U17	*
CIRCUIT BREAKER - TIRE PRESSURE IND 2, C1187	1	1	APU EXTERNAL PWR PNL, P34 34M11	*
COMPUTER - (REF 31-41-00, FIG. 101) L EICAS, M10181 R EICAS, M10182				
RELAYS - (REF 31-01-36, FIG. 101) TIRE PRESS PWR XFER, K1225				
SENSOR - TIRE PRESSURE 1, TS505	2	1	L MAIN GEAR, L FWD AXLE	32-45-11
SENSOR - TIRE PRESSURE 2, TS506	2	1	L MAIN GEAR, R FWD AXLE	32-45-11
SENSOR - TIRE PRESSURE 3, TS507	2	1	R MAIN GEAR, L FWD AXLE	32-45-11
SENSOR - TIRE PRESSURE 4, TS508	2	1	R MAIN GEAR, R FWD AXLE	32-45-11
SENSOR - TIRE PRESSURE 5, TS509	2	1	L MAIN GEAR, L AFT AXLE	32-45-11
SENSOR - TIRE PRESSURE 6, TS510	2	1	L MAIN GEAR, R AFT AXLE	32-45-11
SENSOR - TIRE PRESSURE 7, TS511	2	1	R MAIN GEAR, L AFT AXLE	32-45-11
SENSOR - TIRE PRESSURE 8, TS512	2	1	R MAIN GEAR, R AFT AXLE	32-45-11
SENSOR - TIRE PRESSURE 9, TS513	2	1	NOSE GEAR, L AXLE	32-45-12
SENSOR - TIRE PRESSURE 10, TS514	2	1	NOSE GEAR, R AXLE	32-45-12
SPIN BRAKE - NOSE GEAR TIRE	2	2	NOSE WHEEL WELL, CEILING	32-45-05
UNIT - TIRE PRESSURE MONITOR, M1602	1	1	119AL, MAIN EQUIP CTR E2-6	32-45-10
UNIT - WHEEL INTERFACE 1, M1629	2	1	L MAIN GEAR, L FWD AXLE	32-45-13
UNIT - WHEEL INTERFACE 2, M1628	2	1	L MAIN GEAR, R FWD AXLE	32-45-13
UNIT - WHEEL INTERFACE 3, M1627	2	1	R MAIN GEAR, L FWD AXLE	32-45-13
UNIT - WHEEL INTERFACE 4, M1626	2	1	R MAIN GEAR, R FWD AXLE	32-45-13
UNIT - WHEEL INTERFACE 5, M1625	2	1	L MAIN GEAR, L AFT AXLE	32-45-13
UNIT - WHEEL INTERFACE 6, M1624	2	1	L MAIN GEAR, R AFT AXLE	32-45-13
UNIT - WHEEL INTERFACE 7, M1623	2	1	R MAIN GEAR, L AFT AXLE	32-45-13
UNIT - WHEEL INTERFACE 8, M1622	2	1	R MAIN GEAR, R AFT AXLE	32-45-13
UNIT - WHEEL INTERFACE 9, M1621	2	1	NOSE GEAR, L AXLE	32-45-14
UNIT - WHEEL INTERFACE 10, M1620	2	1	NOSE GEAR, R AXLE	32-45-14
VALVE - TIRE INFLATION/PRESSURE SENSOR HOLDER	2	10	MAIN & NOSE LANDING GEAR	32-45-08




\* SEE WDM EQUIPMENT LIST

Component Index  
Figure 101

EFFECTIVITY  
SAS 050-149, 155-999;  
MTH ALL AIRPLANES

**32-45-00**

**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL




TIRE PRESSURE MONITOR UNIT, M1602

(B)

Tires and Wheels - Component Locations  
Figure 102 (Sheet 1)

EFFECTIVITY  
SAS 050-149, 155-999;  
MTH ALL AIRPLANES

**32-45-00**




MAIN WHEEL  
INTERFACE UNIT,  
M1629 (LH MG LF AXLE)  
M1628 (LH MG RF AXLE)  
M1627 (RH MG LF AXLE)  
M1626 (RH MG RF AXLE)  
M1625 (LH MG LA AXLE)  
M1624 (LH MG RA AXLE)  
M1623 (RH MG LA AXLE)  
M1622 (RH MG RA AXLE)

TIRE PRESSURE  
SENSOR,  
TS505 (LH MG LF AXLE)  
TS506 (LH MG RF AXLE)  
TS507 (RH MG LF AXLE)  
TS508 (RH MG RF AXLE)  
TS509 (LH MG LA AXLE)  
TS510 (LH MG RA AXLE)  
TS511 (RH MG LA AXLE)  
TS512 (RH MG RA AXLE)

NOSE WHEEL  
INTERFACE UNIT,  
M1621 (LH NOSE GEAR)  
M1620 (RH NOSE GEAR)


TIRE PRESSURE  
SENSOR,  
TS513 (LH NOSE GEAR)  
TS514 (RH NOSE GEAR)



Tires and Wheels - Component Location  
Figure 102 (Sheet 2)

EFFECTIVITY  
SAS 050-149, 155-999;  
MTH ALL AIRPLANES

**32-45-00**



Tires and Wheels - Component Location  
Figure 102 (Sheet 3)

EFFECTIVITY  
SAS 050-149, 155-999;  
MTH ALL AIRPLANES


32-45-00

**TIRE PRESSURE  
MONITOR UNIT BITE  
TEST PROCEDURE**

**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
11D15, 11D16, 11J02, 11J03, 11J26, 11J30, 11J32, 11J34,  
11U17, 34M11

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
RIGHT AND CENTER HYDRAULIC SYSTEM PRESSURE IS OFF  
(AMM 29-11-00/201)




Tire Pressure Monitor Unit Bite Test  
Figure 103 (Sheet 1)

EFFECTIVITY  
SAS 050-149, 155-999;  
MTH ALL AIRPLANES

**32-45-00**


FROM SHEET 1  
(BLOCK 2)



Tire Pressure Monitor Unit Bite Test  
Figure 103 (Sheet 2)

EFFECTIVITY  
SAS 050-149, 155-999;  
MTH ALL AIRPLANES

32-45-00



Tire Pressure Monitor Unit Bite Test  
Figure 103 (Sheet 3)

EFFECTIVITY  
SAS 050-149, 155-999;  
MTH ALL AIRPLANES

32-45-00



**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

BRAKE TEMPERATURE MONITORING SYSTEM

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
BRAKES (REF 32-41-00, FIG. 101) CIRCUIT BREAKER BRAKE TEMP, C1181 COMPUTER - EICAS L, M10181 (REF 31-41-00, FIG. 101) COMPUTER - EICAS R, M10182 (REF 31-41-00, FIG. 101)		1	FLT COMPT, P11 11U16	*
LIGHT - BRAKE TEMP INDICATOR, L663 PANEL - EICAS, DISPLAY SELECT, M10195 (REF 31-41-00, FIG. 101)	1	1	P3, FLT COMPT	*
SENSORS - BRAKE TEMPERATURE (TS91 THRU TS98)	1	8	MAIN LANDING GEAR	32-46-01
UNIT - BRAKE TEMPERATURE MONITOR, M115	2	1	119AL, MAIN EQUIP CTR, E2	32-46-03
UNIT - EICAS LOWER DISPLAY, N10014 (REF 31-41-00, FIG. 101)				

\* SEE WM EQUIPMENT LIST

Component Index  
Figure 101

EFFECTIVITY  
AIRPLANES WITH BRAKE TEMPERATURE  
MONITORING SYSTEM

**32-46-00**


01

Page 101  
Apr 22/02


# BOEING

## 767 FAULT ISOLATION/MAINT MANUAL

BRAKE TEMP INDICATOR LIGHT, L663  
SEE (A)




FLT COMPT




BRAKE TEMPERATURE SENSORS,  
TS91 THRU TS98  
SEE (B)

MAIN LANDING GEAR



BRAKE TEMP INDICATION LIGHT, L663

(A)



BRAKE TEMPERATURE SENSORS, TS91 THRU TS98

(B)


Component Location  
Figure 102 (Sheet 1)

EFFECTIVITY  
AIRPLANES WITH BRAKE TEMPERATURE  
MONITORING SYSTEM



32-46-00

01

Page 102  
Apr 22/02



MAIN EQUIPMENT CENTER  
ACCESS DOOR, 119AL  
SEE (C)



BRAKE TEMPERATURE MONITOR UNIT  
(D)

Component Location  
Figure 102 (Sheet 2)

EFFECTIVITY  
AIRPLANES WITH BRAKE TEMPERATURE  
MONITORING SYSTEM


**32-46-00**

38604

BRAKE TEMP  
 INDICATIONS BLANK,  
 INTERMITTENT, OR  
 ZERO, OR HIGH WITH  
 "BRAKE TEMP" LIGHT  
 ILLUMINATED.

**PREREQUISITES**

MAKE SURE THESE SYSTEMS WILL OPERATE:  
 EICAS (AMM 31-41-00/501)  
 MASTER DIM AND TEST LIGHTS (AMM 33-16-00/501)  
 MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
 11U16  
 MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
 ELECTRICAL POWER IS ON (AMM 24-22-00/201)



Brake Temp Indications Blank, Intermittent, or Zero, or High with  
 BRAKE TEMP Light Illuminated.  
 Figure 103


EFFECTIVITY  
 AIRPLANES WITH BRAKE TEMPERATURE  
 MONITORING SYSTEM

**32-46-00**

**BRAKE TEMPERATURE  
MONITORING SYSTEM  
"BITE" PROCEDURE**

**PREREQUISITES**


MASTER DIM AND TEST SYSTEM (MM 33-16-00)  
ELECTRICAL POWER (MM 24-22-00)  
EICAS (MM 31-41-00)  
CB'S: 11U16



Brake Temperature Monitoring System BITE Procedure  
Figure 104 (Sheet 1)

EFFECTIVITY  
AIRPLANES WITH BRAKE TEMPERATURE  
MONITORING SYSTEM

**32-46-00**



Brake Temperature Monitoring System BITE Procedure  
Figure 104 (Sheet 2)

EFFECTIVITY  
AIRPLANES WITH BRAKE TEMPERATURE  
MONITORING SYSTEM

**32-46-00**

**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

NOSE WHEEL STEERING SYSTEM

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
ACTUATOR - STEERING ASSEMBLY - RUDDER FWD QUADRANT AND JACKSHAFT (FIM 27-21-00/101)	1	2	NOSE LANDING GEAR	32-51-03
CABLES - STEERING	1	1	113AL, FWD EQUIP COMPT; NOSE LANDING GEAR	32-00-25
CARTRIDGE - SPRING (FIM 32-30-00/101) CENTERING CAM AND CAM ROLLER (FIM 32-30-00/101)				
COLLAR - STEERING	1	1	NOSE LANDING GEAR	32-51-05
COMPENSATOR - CABLE	1	1	119AL, MAIN EQUIP CTR	32-51-06
DRUM - NOSE WHEEL STEERING TRUNNION (FIM 32-30-00/101)				
LINKS - PIVOT	1	1	NOSE WHEEL WELL, AFT BULKHEAD	32-51-07
MECHANISM - CENTERING AND RUDDER INTERCONNECT	2	1	113AL, FWD EQUIP COMPT	32-51-02
MECHANISM - SUMMING	1	1	NOSE LANDING GEAR	32-51-00
MODULE - METERING VALVE	1	1	NOSE LANDING GEAR	32-51-04
MODULE - CHECK VALVE	2	1	NOSE WHEEL WELL, AFT LEFT SIDE	32-51-08
PEDALS - CAPTAIN'S AND FIRST OFFICER'S RUDDER (FIM 27-21-00/101)				
QUADRANT - FORWARD	3	1	113AL, FWD EQUIP COMPT	32-51-10
TILLER AND GEARBOX	3	2	FLT COMPT, P13 AND P14	32-51-01
VALVE - NOSE GEAR SELECTOR (FIM 32-30-00/101)				

Nose Wheel Steering System - Component Index  
Figure 101

EFFECTIVITY  
AIRPLANES WITH FIRST OFFICER'S TILLER

**32-51-00**

 **BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

NOSE WHEEL STEERING SYSTEM


COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
ACTUATOR - STEERING ASSEMBLY - (REF 27-21-00, FIG. 101) RUDDER FWD QUADRANT AND JACKSHAFT CABLES - STEERING	1	2	NOSE LANDING GEAR	32-51-03
CARTRIDGE - (REF 32-30-00, FIG. 101) SPRING CENTERING CAM AND CAM ROLLER - (REF 32-30-00, FIG. 101)	1	1	113AL, FWD EQUIP COMPT; NOSE LANDING GEAR	32-00-25
COLLAR - STEERING COMPENSATOR - CABLE	1 1	1 1	NOSE LANDING GEAR 119AL, MAIN EQUIP CTR	32-51-05 32-51-06
DRUM - (REF 32-30-00, FIG. 101) NOSE WHEEL STEERING TRUNNION	1	1	NOSE WHEEL WELL, AFT BULKHEAD	32-51-07
LINKS - PIVOT	1	1	113AL, FWD EQUIP COMPT	32-51-02
MECHANISM - CENTERING AND RUDDER INTERCONNECT	2	1	NOSE LANDING GEAR	32-51-00
MECHANISM - SUMMING	1	1	NOSE LANDING GEAR	32-51-04
MODULE - METERING VALVE	1	1	NOSE WHEEL WELL, AFT LEFT SIDE	32-51-08
MODULE - CHECK VALVE	2	1		
PEDALS - (REF 27-21-00, FIG. 101) CAPTAIN'S AND FIRST OFFICER'S QUADRANT - FORWARD	3	1	113AL, FWD EQUIP COMPT	32-51-10
TILLER AND GEARBOX VALVE - (REF 32-30-00, FIG. 101) NOSE GEAR SELECTOR	3	1	FLT COMPT, P13	32-51-01

Nose Wheel Steering System - Component Index  
Figure 101A


EFFECTIVITY  
AIRPLANES WITHOUT FIRST OFFICER'S TILLER

**32-51-00**





METERING VALVE MODULE AND SUMMING MECHANISM  
(WITH COVER REMOVED)




CABLE COMPENSATOR AND PIVOT LINKS

Nose Wheel Steering System - Component Location  
Figure 102 (Sheet 1)


EFFECTIVITY	
	ALL

32-51-00



CENTERING AND RUDDER INTERCONNECT MECHANISM

(C)




CHECK VALVE MODULE

(D)


Nose Wheel Steering System - Component Location  
Figure 102 (Sheet 2)

EFFECTIVITY	
	ALL

32-51-00



**FLIGHT COMPARTMENT**



1 AIRPLANES WITH CAPTAIN'S AND FIRST OFFICER'S TILLER.


**Nose Wheel Steering System - Component Location  
Figure 102 (Sheet 3)**

EFFECTIVITY	ALL
-------------	-----

**32-51-00**

 **BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

Not Used  
Figure 103



**32-51-00**

02


Page 106  
Feb 10/91

**PREREQUISITES**

NONE

**NOTE:** IF THE AIRPLANE HAS BEEN PARKED (LOADED) FOR A LONG TIME, THE TIRES CAN HAVE A TEMPORARY FLAT SPOT THAT CAN CAUSE VIBRATION. THIS CONDITION IS SATISFACTORY.

**NOSE WHEEL VIBRATES ON (TAKEOFF/LANDING)**



Nose Wheel Vibrates On (Takeoff/Landing)  
Figure 104 (Sheet 1)

EFFECTIVITY


ALL

**32-51-00**

02

Page 107  
Aug 22/04

FROM SHEET 1  
(BLOCK 5)



Nose Wheel Vibrates On (Takeoff/Landing)  
Figure 104 (Sheet 2)

EFFECTIVITY

---

ALL


32-51-00

**PREREQUISITES**

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:

- ELECTRICAL POWER IS ON (MM 24-22-00/201)
- CENTER HYDRAULIC SYSTEM IS PRESSURIZED (MM 29-11-00/201)

**TILLER STEERING  
INOP**



Tiller Steering Inop  
Figure 105 (Sheet 1)

EFFECTIVITY

ALL


**32-51-00**

02

Page 109  
Feb 10/91

**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

FROM SHEET 1  
(BLOCK 2)



SEE SHEET 3  
(BLOCK 39)

Tiller Steering Inop  
Figure 105 (Sheet 2)

EFFECTIVITY

ALL

32-51-00


02

Page 110  
Feb 10/91

48492



**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL




Tiller Steering Inop  
Figure 105 (Sheet 3)

EFFECTIVITY	ALL
-------------	-----

**32-51-00**

TILLER STEERS  
LEFT OR RIGHT  
DIRECTION ONLY

**PREREQUISITES**  
NONE



Tiller Steers Left or Right Direction Only  
Figure 106

EFFECTIVITY	ALL
-------------	-----


**32-51-00**

**TILLER STEERING  
RESPONSE SLUGGISH**


**PREREQUISITES**

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:

- ELECTRICAL POWER IS ON (MM 24-22-00/201)
- CENTER HYDRAULIC SYSTEM IS PRESSURIZED (MM 29-11-00/201)




Tiller Steering Response Sluggish  
Figure 107



**32-51-00**

**TILLER STEERING FORCES HIGH**

**PREREQUISITES**  
NONE




Tiller Steering Forces High  
Figure 108

EFFECTIVITY ————  
ALL

**32-51-00**

**NOSE WHEEL NOT  
CENTERED WITH TILLER  
INDICATOR CENTERED**

**PREREQUISITES**  
MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (MM 24-22-00/201)  
CENTER HYDRAULIC SYSTEM IS PRESSURIZED  
(MM 29-11-00/201)



Nose Wheel Not Centered With Tiller Indicator Centered  
Figure 109


EFFECTIVITY

ALL
-----

32-51-00

**AIRPLANE PULLS L/R DURING TAXI**


**PREREQUISITES**  
 MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
 ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
 CENTER HYDRAULIC SYSTEM IS PRESSURIZED (AMM 29-11-00/201)



Airplane Pulls L/R During Taxi  
 Figure 109A (Sheet 1)

EFFECTIVITY	ALL
-------------	-----

**32-51-00**



Airplane Pulls L/R During Taxi  
Figure 109A (Sheet 2)




EFFECTIVITY

ALL
-----


32-51-00


 **BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL


LANDING GEAR POSITION INDICATING AND WARNING SYSTEM

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
CIRCUIT BREAKER -	9		FLT COMPT, P11	
LANDING GEAR POSITION AIR/GND SYS 1, C1175		1	11C30	*
LANDING GEAR POSITION AIR/GND SYS 2 ALTN, C1575		1	 11C29 OR 11E19	*
POSITION AIR/GND SYS 2, C1170		1	 11U23 OR 11U24	*
PROX SW TEST, C1178		1	11T36	*
COMPUTER - (FIM 31-41-00/101)				
EICAS L, M10181				
EICAS R, M10182				
DIODE - SYS 1, R33,R120,R122,R123,R124,R125, R183	10	7	119AL, MAIN EQUIP CTR, E1-2	*
DIODE - SYS 2, R64,R121,R179,R180,R181,R182, R184	10	7	119AL, MAIN EQUIP CTR, E1-2	*
LIGHT - INDICATOR				
DOORS, L658	9	1	FLT COMPT, P3	*
GEAR, L657	9	1	FLT COMPT, P3	*
LEFT, L652	9	1	FLT COMPT, P3	*
NOSE, L654	9	1	FLT COMPT, P3	*
RIGHT, L653	9	1	FLT COMPT, P3	*
TAIL SKID, L804 	9	1	FLT COMPT, P3	*
MODULE - (FIM 32-09-03/101)				
PROXIMITY SWITCH ELECTRONICS UNIT (PSEU), M162				
MODULE - (FIM 32-30-00/101)				
LANDING GEAR CONTROL LEVER, M937				
RELAY - DRAG BRACE, K718	10	1	119AL, MAIN EQUIP CTR, E1-2	*
RELAY - DRAG BRACE, K719	10	1	119AL, MAIN EQUIP CTR, E1-2	*
RELAY - GEAR DISAGREE, K651	10	1	119AL, MAIN EQUIP CTR, E1-2	*
RELAY - GEAR DOORS, K652	10	1	119AL, MAIN EQUIP CTR, E1-2	*
RELAY - SIDE BRACE, K874	10	1	119AL, MAIN EQUIP CTR, E1-2	*
RELAY - SIDE BRACE, K875	10	1	119AL, MAIN EQUIP CTR, E1-2	*
SENSOR - LEFT DRAG BRACE DOWN, SYS 1, S237	2	1	MAIN GEAR, JURY STRUT	32-61-02
SENSOR - LEFT DRAG BRACE DOWN, SYS 2, S259	2	1	MAIN GEAR, JURY STRUT	32-61-02
SENSOR - LEFT LATCH LOCKED, SYS 1, S238	3	1	MAIN WHEEL WELL, DOOR LATCH	32-61-02
SENSOR - LEFT LATCH LOCKED, SYS 2, S260	3	1	MAIN WHEEL WELL, DOOR LATCH	32-61-02
SENSOR - LEFT SIDE BRACE DOWN, SYS 1, S236	1	1	MAIN GEAR, LOCK LINK	32-61-02
SENSOR - LEFT SIDE BRACE DOWN, SYS 2, S258	1	1	MAIN GEAR, LOCK LINK	32-61-02
SENSOR - RIGHT DRAG BRACE DOWN, SYS 1, S241	2	1	MAIN GEAR, JURY STRUT	32-61-02
SENSOR - RIGHT DRAG BRACE DOWN, SYS 2, S263	2	1	MAIN GEAR, JURY STRUT	32-61-02
SENSOR - RIGHT LATCH LOCKED, SYS 1, S242	3	1	MAIN WHEEL WELL, DOOR LATCH	32-61-02
SENSOR - RIGHT LATCH LOCKED, SYS 2, S264	3	1	MAIN WHEEL WELL, DOOR LATCH	32-61-02
SENSOR - RIGHT SIDE BRACE DOWN, SYS 1, S240	1	1	MAIN GEAR, LOCK LINK	32-61-02
SENSOR - RIGHT SIDE BRACE DOWN, SYS 2, S262	1	1	MAIN GEAR, LOCK LINK	32-61-02

\* SEE THE WDM EQUIPMENT LIST

 THE "LANDING GEAR POSITION AIR/GND SYS 2 ALTN" CIRCUIT BREAKER, C1575, CAN BE IN ONE OF THESE TWO LOCATIONS.

 THE "POSITION AIR/GND SYS 2" CIRCUIT BREAKER, C1170, CAN BE IN ONE OF THESE TWO LOCATIONS.

 767-300 AIRPLANES

Landing Gear Position Indicating and Warning System - Component Index  
Figure 101 (Sheet 1)

EFFECTIVITY

ALL



32-61-00

02


Page 101  
Nov 10/95




**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL



COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
SENSOR - LEFT NOSE DOOR CLOSED, SYS 1, S234	6	1	NOSE WHEEL WELL, LEFT BULKHD	32-61-03
SENSOR - LEFT NOSE DOOR CLOSED, SYS 2, S256	7	1	NOSE WHEEL WELL, LEFT BULKHD	32-61-03
SENSOR - NOSE GEAR LOCKED, SYS 1, S233	5	1	NOSE GEAR, LOCK LINK	32-61-03
SENSOR - NOSE GEAR LOCKED, SYS 2, S255	5	1	NOSE GEAR, LOCK LINK	32-61-03
SENSOR - NOSE GEAR DOWN, SYS 1, S232	4	1	NOSE WHEEL WELL, AFT BULKHD	32-61-03
SENSOR - NOSE GEAR DOWN, SYS 2, S254	4	1	NOSE WHEEL WELL, AFT BULKHD	32-61-03
SENSOR - RIGHT NOSE GEAR DOOR CLOSED, SYS 1, S235	6	1	NOSE WHEEL WELL, FWD BULKHD	32-61-03
SENSOR - RIGHT NOSE GEAR DOOR CLOSED, SYS 2, S257	7	1	NOSE WHEEL WELL, FWD BULKHD	32-61-03
SENSOR - TAIL SKID EXTENDED, S247 	8	1	312AR, STABILIZER/TRIM JACKSCREW COMPT	32-61-04
SENSOR TAIL SKID RETRACTED, S248 	8	1	312AR, STABILIZER/TRIM JACKSCREW COMPT	32-61-04
SWITCH - (FIM 32-30-00/101) LANDING GEAR LEVER POSITION, DOWN YGBS3,YGBS4				

Landing Gear Position Indicating and Warning System - Component Index  
Figure 101 (Sheet 2)




32-61-00

**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL



**MAIN GEAR LOCK LINK SENSORS  
(LEFT MAIN GEAR SIDE BRACE DOWN SENSORS ARE SHOWN,  
RIGHT MAIN GEAR SIDE BRACE DOWN SENSORS ARE EQUIVALENT)**

A



**Landing Gear Position Indicating and Warning System - Component Location  
Figure 102 (Sheet 1)**

EFFECTIVITY	ALL
-------------	-----



**32-61-00**

01

Page 103  
Dec 22/06

38698

**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL




**MAIN GEAR JURY STRUT SENSORS**  
(LEFT MAIN GEAR DRAG BRACE DOWN SENSORS ARE SHOWN,  
RIGHT MAIN GEAR DRAG BRACE DOWN SENSORS ARE EQUIVALENT)

B

Landing Gear Position Indicating and Warning System - Component Location  
Figure 102 (Sheet 2)

EFFECTIVITY	
	ALL

**32-61-00**



**MAIN GEAR DOOR UPLOCK SENSORS**  
(LEFT MAIN GEAR LATCH LOCKED SENSORS ARE SHOWN,  
RIGHT MAIN GEAR LATCH LOCKED SENSORS ARE EQUIVALENT)

(C)

Landing Gear Position Indicating and Warning System - Component Location  
Figure 102 (Sheet 3)


EFFECTIVITY	
	ALL

**32-61-00**

01

Page 105  
Dec 22/06


38708




Landing Gear Position Indicating and Warning System - Component Location  
Figure 102 (Sheet 4)

EFFECTIVITY	ALL
-------------	-----

32-61-00



NOSE GEAR LOCKED SENSORS



NOSE GEAR LOCK LINK SENSORS

(E)


Landing Gear Position Indicating and Warning System - Component Location  
Figure 102 (Sheet 5)

EFFECTIVITY	
	ALL

32-61-00

01


Page 107  
Nov 10/95



Landing Gear Position Indicating and Warning System - Component Location  
Figure 102 (Sheet 6)


EFFECTIVITY	ALL

**32-61-00**



NOSE GEAR DOOR CLOSED SENSORS (SYSTEM 2)

G



Landing Gear Position Indicating and Warning System - Component Location  
Figure 102 (Sheet 7)

EFFECTIVITY	ALL
-------------	-----

32-61-00


01

Page 109  
Dec 22/06




38728



**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL



FLIGHT COMPARTMENT



MAIN EQUIPMENT CENTER




(I)

1 767-300 AIRPLANES

Landing Gear Position Indicating and Warning System - Component Location  
Figure 102 (Sheet 8)

EFFECTIVITY	ALL
-------------	-----

32-61-00



Landing Gear Position Indicating and Warning System - Component Location  
Figure 102 (Sheet 9)

EFFECTIVITY  
767-300

32-61-00

225042


**"GEAR" AMBER LIGHT  
FAILED TO ILLUM  
DURING GEAR  
EXTENSION OR  
RETRACTION**

**PREREQUISITES**

MAKE SURE THIS SYSTEM WILL OPERATE:  
MASTER DIM AND TEST SYSTEM (AMM 33-16-00/501)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
11C30,11T36; 2 11U23 OR 11U24

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)



1 **WARNING:** USE THE PROCEDURE IN AMM 32-00-15 TO REMOVE THE DOOR LOCKS. THE DOORS OPEN AND CLOSE QUICKLY AND CAN CAUSE INJURIES TO PERSONS OR DAMAGE TO EQUIPMENT.

REMOVE THE DOOR LOCKS FROM THE DOORS FOR THE MAIN LANDING GEAR AND CLOSE THE DOORS (AMM 32-00-15/201).

2 THE "POSITION AIR/GND SYS 2" CIRCUIT BREAKER, C1170, CAN BE IN ONE OF THESE TWO LOCATIONS.

**GEAR Amber Light Failed to Illum During Gear Extension or Retraction  
Figure 103**

EFFECTIVITY

ALL

**32-61-00**

02

Page 112  
Nov 10/95

**EICAS MSG "LDG GEAR MONITOR" DISPLAYED**

**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
11C30, 11T36; **A** 11U23 OR 11U24

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
PRESSURE IS REMOVED FROM THE CENTER HYDRAULIC SYSTEM (AMM 29-11-00/201)  
EICAS IS ON (AMM 31-41-00/201)

**NOTE:** IF YOU HAVE THIS EICAS MESSAGE WITHOUT A RELATED PSEU FAULT, JUMPER WIRES IN THE PSEU WIRING CAN BE NECESSARY. REFER TO SB 767-32-115.


**1** MAKE SURE THE DOWNLOCKS ARE INSTALLED ON THE NOSE AND MAIN LANDING GEAR (AMM 32-00-20/201).  
MAKE SURE THAT ALL THE LANDING GEAR DOORS ARE CLOSED.

**NOTE**  
IF THE EICAS MESSAGE "LDG GEAR MONITOR" SHOWED ON THE LOWER DISPLAY AFTER LANDING GEAR RETRACTION, EXAMINE THE AFT HINGES ON THE FORWARD DOORS OF THE NOSE LANDING GEAR. THE EICAS MESSAGE COULD BE CAUSED BY VERTICAL MOVEMENT OF THE HINGES. USE THE PROCEDURE IN AMM 32-22-01/401 TO EXAMINE THE HINGES AND REPAIR THEM IF IT IS NECESSARY. EXAMINE THE NOSE LANDING GEAR DOOR STRUTS FOR WEAR. REPAIR THEM IF IT IS NECESSARY.

MAKE SURE THE CONTROL LEVER FOR THE LANDING GEAR ON THE P3 PANEL IS FULLY ENGAGED IN THE "DN" DETENT.  
PUSH THE ECS/MSG SWITCH ON THE EICAS MAINTENANCE PANEL TO EXAMINE THE EICAS MAINTENANCE MESSAGES. IF ANY OF THESE MESSAGES ARE DISPLAYED, PLEASE WRITE THEM FOR REFERENCE AS AN INTERMITTENT FAILURE:

NOSE GEAR DOWN  
NOSE GEAR LOCKED  
GEAR DISAGREE  
ALL GEAR DOWN  
L(R) DRAG BRACE  
L(R) SIDE BRACE

DO THIS PROCEDURE: EICAS STATUS/MAINTENANCE MESSAGE ERASE PROCEDURE (FIM 31-41-00/101, FIG. 109).  
DOES THE EICAS MESSAGE "LDG GEAR MONITOR" SHOW ON THE STATUS PAGE?



**A** THE "POSITION AIR/GND SYS 2" CIRCUIT BREAKER, C1170, CAN BE IN ONE OF THESE TWO LOCATIONS.

**1** DO THIS PROCEDURE: EICAS STATUS/MAINTENANCE MESSAGE ERASE PROCEDURE (FIM 31-41-00/101, FIG. 109).

EICAS Msg LDG GEAR MONITOR Displayed  
Figure 104 (Sheet 1)

EFFECTIVITY


ALL

**32-61-00**


07

Page 113  
Dec 22/02


C62432



EICAS Msg LDG GEAR MONITOR Displayed  
Figure 104 (Sheet 2)



32-61-00



EICAS Msg LDG GEAR MONITOR Displayed  
Figure 104 (Sheet 3)

EFFECTIVITY


ALL

**32-61-00**

11.1

Page 115  
Aug 22/09

1870858



EICAS Msg LDG GEAR MONITOR Displayed  
Figure 104 (Sheet 4)

EFFECTIVITY

ALL
-----


32-61-00

**PREREQUISITES**

EQUIPMENT OHMMETER 0-50 OHM RANGE

**NOTE:** USE THIS PROCEDURE IF YOU HAVE AN INTERMITTENT PSEU/SENSOR FAULT AND/OR THE PROBLEM CANNOT BE FOUND WITH THE OTHER FIM PROCEDURES.

**PROXIMITY SENSOR/  
WIRING RESISTANCE  
CHECK**



1 DO THIS CHECK FOR THE FAULTED SENSOR(S) OR THE SENSORS FROM THE SUSPECTED BAD SUBSYSTEM OR CARD.

Proximity Sensor/Wiring Resistance Check  
Figure 104A (Sheet 1)

EFFECTIVITY

ALL

**32-61-00**

01


Page 117  
Apr 22/03

N97358




**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

FROM SHEET 1  
(BLOCK 2)



Proximity Sensor/Wiring Resistance Check  
Figure 104A (Sheet 2)

EFFECTIVITY	ALL
-------------	-----


**32-61-00**

GEAR GREEN DN LGT  
FAILED TO EXTIN  
WITH GEAR HANDLE  
"UP". "DOORS" AND  
"GEAR" AMBER LGTS  
EXTIN. EICAS MSG  
NOT DISPLAYED

**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
11C29,11C30,11T36; 1 11U23 OR 11U24

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)



1 THE "POSITION AIR/GND SYS 2" CIRCUIT BREAKER, C1170, CAN BE IN ONE OF THESE TWO LOCATIONS.

Gear Green Dn Lgt Failed to Extin with Gear Handle UP. DOORS and GEAR  
Amber Lgts Extin. EICAS Msg Not Displayed

Figure 105

EFFECTIVITY

ALL

**32-61-00**

03


Page 119  
Apr 22/03

223454

"LEFT", "RIGHT",  
 "NOSE" GEAR GREEN  
 DN LIGHT FLICKERS  
 AFTER GEAR RETRACTION

**PREREQUISITES**

MAKE SURE THIS SYSTEM WILL OPERATE:  
 MASTER DIM AND TEST SYSTEM (AMM 33-16-00/501)  
 MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
 11C30, 11T36; <sup>1</sup> 11U23 OR 11U24  
 MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
 ELECTRICAL POWER IS ON (AMM 24-22-00/201)




<sup>1</sup> THE "POSITION AIR/GND SYS 2" CIRCUIT BREAKER, C1170, CAN BE IN ONE OF THESE TWO LOCATIONS.

LEFT, RIGHT, NOSE Gear Green Dn Light Flickers After Gear Retraction  
 Figure 105A (Sheet 1)

EFFECTIVITY	ALL
-------------	-----

**32-61-00**



LEFT, RIGHT, NOSE Gear Green Dn Light Flickers After Gear Retraction  
Figure 105A (Sheet 2)

EFFECTIVITY	ALL
-------------	-----

32-61-00

**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

TAIL SKID SYSTEM

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
CIRCUIT BREAKER - LANDING GEAR POSITION AIR/GND SYS 1, C1175 POSITION AIR/GND SYS 2, C1170 PROX SW TEST, C1178 TAIL SKID CONT, C1185	3	1 1 1 1	FLT COMPT, P11 11C30 11U23 11T36 11U26	* * * *
COMPUTER - (FIM 31-41-00/101) L EICAS, M10181 R EICAS, M10182 CYLINDER - TRANSFER	1	1	312AR, STABILIZER/TRIM JACKSCREW COMPARTMENT, L SIDE	32-71-02
DIODE - ISOLATION, R63,R188	3	1	119AL, MAIN EQUIP CTR, E1-2	*
FUSE - TAIL SKID HYDRAULIC	1	1	312AR, STABILIZER/TRIM JACKSCREW COMPARTMENT, L SIDE	32-71-04
INDICATOR - LOW PRESSURE	2	1	SHOCK STRUT/ACTUATOR, TAIL SKID FIXED FAIRING	32-71-05
LEVER - TAIL SKID LIGHT - (FIM 32-61-00/101) TAIL SKID, L804	2	1	TAIL SKID FIXED FAIRING	32-71-06
MODULE - (FIM 32-30-00/101) LANDING GEAR CONTROL LEVER, M937 MODULE - TAIL SKID CONTROL	1	1	312AR, STABILIZER/TRIM JACKSCREW COMPARTMENT, L SIDE	32-71-01
RELAY - (FIM 31-01-36/101) DOWN SENSE LANDING GEAR, K904 SENSOR - (FIM 32-61-00/101) TAIL SKID EXTENDED, S247 TAIL SKID RETRACTED, S248	2	1	312AR, STABILIZER/TRIM JACKSCREW COMPARTMENT	32-71-05
STRUT/ACTUATOR - TAIL SKID SHOCK	2	1	312AR, STABILIZER/TRIM JACKSCREW COMPARTMENT	32-71-05
SWITCH - (FIM 32-30-00/101) LANDING GEAR LEVER POSITION DOWN, YBGS3 UNIT - (FIM 32-09-03/101) PROXIMITY SWITCH ELECTRONIC (PSEU), M162	2	1	SHOCK STRUT/ACTUATOR, TAIL SKID FIXED FAIRING	32-71-05
VALVE - TAIL SKID AIR	2	1	312AR, STABILIZER/TRIM JACKSCREW COMPARTMENT, SHOCK STRUT/ ACTUATOR	32-71-03
VALVE - TAIL SKID, BLOCKING	2	1	312AR, STABILIZER/TRIM JACKSCREW COMPARTMENT, TAIL SKID CONTROL MODULE	32-71-01
VALVE - TAIL SKID CONTROL, V124	1	1	312AR, STABILIZER/TRIM JACKSCREW COMPARTMENT, TAIL SKID CONTROL MODULE	32-71-01

\* SEE THE WDM EQUIPMENT LIST



Tail Skid System - Component Index  
Figure 101

EFFECTIVITY  
767-300 AIRPLANES

**32-71-00**


01

Page 101  
Nov 10/93




STABLIZER/TRIM JACKSCREW COMPARTMENT

(A)



TAIL SKID CONTROL MODULE

(B)



HYDRAULIC FUSE (LOOKING FWD)


(C)

Component Location (Details From Sht 1)  
Figure 102 (Sheet 1)

EFFECTIVITY  
767-300 AIRPLANES

32-71-00

**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL



Component Location  
Figure 102 (Sheet 2)


EFFECTIVITY  
767-300 AIRPLANES

32-71-00


01

Page 103  
Aug 01/86

**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL



MAIN EQUIP  
 CTR ACCESS, 119AL  
 SEE (G)




R63 AND R288  
 (ON BACK OF E1-2)

FWD

119AL

MAIN EQUIP CTR

(G)



P11 PANEL

FLT COMPT

Component Location  
 Figure 102 (Sheet 3)

EFFECTIVITY  
 767-300 AIRPLANES

32-71-00

01

Page 104  
 Aug 01/86



**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
11C30,11T36,11U23,11U26

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:


- ELECTRICAL POWER IS ON (MM 24-22-00/201)
- CENTER HYDRAULIC SYSTEM IS PRESSURIZED (MM 29-11-00/201)
- EICAS IS ON (MM 31-41-00/201)
- DOOR LOCKS ARE INSTALLED (MM 32-00-15/201)

**EQUIPMENT:**

PROXIMITY SENSORS ACTUATOR/DEACTUATOR SET - P/N AZ7092-61 (2 RECTANGULAR ACTUATORS, 2 CYLINDRICAL DEACTUATORS AND 3 RECTANGULAR DEACTUATORS REQUIRED).

"TAIL SKID" DISPLAYED ON EICAS, AND "TAIL SKID" LIGHT ILLUMINATED

**WARNING:** USE THE PROCEDURE IN 32-00-15 TO INSTALL THE DOOR LOCKS. THE DOORS OPEN AND CLOSE QUICKLY AND CAN CAUSE INJURIES TO PERSONS OR DAMAGE TO EQUIPMENT.




TAIL SKID Displayed on EICAS, and TAIL SKID Light Illuminated  
Figure 103 (Sheet 1)

EFFECTIVITY  
767-300 AIRPLANES

**32-71-00**


**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL



TAIL SKID Displayed on EICAS, and TAIL SKID Light Illuminated  
Figure 103 (Sheet 2)

EFFECTIVITY  
767-300 AIRPLANES

**32-71-00**




TAIL SKID Displayed on EICAS, and TAIL SKID Light Illuminated  
Figure 103 (Sheet 3)

EFFECTIVITY  
767-300 AIRPLANES

**32-71-00**



FROM SHEET 3  
(BLOCK 3)



TAIL SKID Displayed on EICAS, and TAIL SKID Light Illuminated  
Figure 103 (Sheet 4)

EFFECTIVITY  
767-300 AIRPLANES

32-71-00




TAIL SKID Displayed on EICAS, and TAIL SKID Light Illuminated  
Figure 103 (Sheet 5)

EFFECTIVITY  
767-300 AIRPLANES

32-71-00

**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL



TAIL SKID Displayed on EICAS, and TAIL SKID Light Illuminated  
Figure 103 (Sheet 6)

EFFECTIVITY  
767-300 AIRPLANES

**32-71-00**