

PAGE	DATE	CODE	PAGE	DATE	CODE	PAGE	DATE	CODE
CHARTER 7	7/ TAD			CODE DIAGRAM	CONT.		CODE DIAGRAM	CONT.
CHAPTER 3	4 IAB		7 8	AUG 01/86 APR 10/98	02 03	65 66	AUG 22/02 AUG 22/02	05 05
NAVIGATIO	ANI		9	AUG 22/07	04	67	AUG 22/02 AUG 22/02	05
INAVIGATIO	'IN		10	NOV 10/96	02	68	AUG 22/02	05
EFFECTIVE	DAGES		11	NOV 10/96	04	69	AUG 22/02	09
	PAGE OF LIST	FOR	12	NOV 10/96	02	70	AUG 22/02	11
NUMBER OF		1 010	1 13	NOV 10/96	02	71	AUG 22/02	Ö5 İ
			14	NOV 10/96	05	72	AUG 22/02	09
1			15	NOV 10/96	02	73	AUG 22/02	06
34-CONTEN	ITS		16	NOV 10/96	03	74	BLANK	
1	APR 22/03	SAS	17	APR 22/03	02			
2	DEC 22/03	SAS	18	AUG 22/01	03	34-FAULT	CODE INDEX	
R 3	AUG 22/09	SAS.101	19	AUG 22/01	06	1	MAY 10/96	07
4	APR 22/09	SAS	20	APR 22/03	06	2	APR 22/02	03
5	APR 22/02	SAS	21	DEC 22/02	08	3	APR 22/02	06
6 R 7	APR 22/09 AUG 22/09	SAS	22 23	AUG 22/01 NOV 10/96	03 02	4 5	DEC 22/00 FEB 10/97	12 08
8	AUG 22/09 AUG 22/05	SAS.1 SAS	24	NOV 10/96	02	6	FEB 10/97	05
9	APR 22/06	SAS	25	AUG 10/97	02	7	FEB 10/97	05
10	APR 22/07	SAS	26	AUG 22/02	03	8	APR 10/98	18
1 11	APR 22/07	SAS	27	AUG 22/02	03	9	APR 22/02	02
12	BLANK		28	AUG 22/02	05	10	APR 22/01	15
İ			29	AUG 22/02	03	11	MAY 10/96	19
34-HOW TO	USE THE FIM		30	AUG 22/02	14	12	APR 22/01	17
] 1	AUG 22/99	01	31	AUG 22/02	03	13	APR 22/01	18
2	AUG 22/99	01	32	AUG 22/02	07	14	FEB 10/97	16
3	AUG 22/99	01	33	AUG 22/02	10	15	APR 22/01	13
4	AUG 22/99	01	34	AUG 22/02	09	16	MAY 10/96	14
5	AUG 22/99 AUG 22/99	01 01	35 36	AUG 22/02 AUG 22/02	03 06	17 18	APR 22/03 DEC 22/02	24 15
"	AUG 22/99	UI	37	AUG 22/02 AUG 22/02	07	19	FEB 10/97	15
34-INDEX			38	AUG 22/02	08	20	APR 22/03	17
1 1	AUG 22/02	10	39	AUG 22/02	02	21	APR 22/03	17
2	AUG 10/95	26	40	AUG 22/02	06	22	AUG 10/96	16
3	FEB 10/91	18	41	AUG 22/02	80	23	MAY 10/96	03
4	APR 10/98	28	42	AUG 22/02	02	24	FEB 10/97	07
5	APR 10/98	09	43	AUG 22/02	02	25	AUG 22/01	08
6	AUG 22/02	03	44	AUG 22/02	11	26	AUG 22/01	05
7	DEC 10/98	03	45	AUG 22/02	16	27	AUG 22/07	06
8	BLANK		46	DEC 22/03	18	28	APR 22/03	06
34-EICAS	MESSAGES		47 48	AUG 22/02 AUG 22/02	06 15	29 30	AUG 22/01 AUG 22/03	06 19
1 1	AUG 22/99	01	49	AUG 22/02 AUG 22/02	17	31	AUG 22/03 AUG 22/01	06
2	AUG 22/99	01	50	AUG 22/02	06	32	AUG 22/00	06
3	AUG 22/06	04	51	AUG 22/02	05	33	AUG 22/00	06
4	DEC 22/06	15	52	AUG 22/02	06	34	AUG 22/00	06
4 5	AUG 22/03	04	53	AUG 22/02	05	35	APR 22/01	18
6	DEC 22/06	05	54	AUG 22/02	05	36	AUG 22/01	04
7	AUG 22/06	06	55	AUG 22/02	05	37	AUG 22/01	20
8	DEC 22/05	05	56	AUG 22/02	05	38	AUG 22/01	19
Z/_EALU T	CODE DIACRAM		57	AUG 22/02	05 04	39 40	DEC 22/02	24
1	CODE DIAGRAM	0.3	58 59	AUG 22/02 AUG 22/02	06 05	40 71	AUG 22/00 AUG 22/00	04
1 2	AUG 22/02 NOV 10/96	03 03	60	AUG 22/02 AUG 22/02	05 05	41 42	AUG 22/00 AUG 22/08	20 20
3	NOV 10/96	06	61	AUG 22/02 AUG 22/02	05 05	42	APR 22/02	16
4	NOV 10/96	02	62	AUG 22/02	05	44	APR 22/02	23
5	NOV 10/96	05	63	AUG 22/02	05	45	APR 22/02	13
6	NOV 10/96	04	64	AUG 22/02	05	46	DEC 22/01	19
L			l					

R = REVISED, A = ADDED OR D = DELETED F = FOLDOUT PAGE 33 AUG 22/09 D633T633

CHAPTER 34 **EFFECTIVE PAGES** PAGE CONTINUED



PAGE	DATE	CODE	PAGE	DATE	CODE	PAGE	DATE	CODE
34-FAULT	CODE INDEX	CONT.	34-12-00		CONT.	34-22-00		
47	DEC 22/03	28	115	NOV 10/95	12	101	FEB 10/97	21
48	APR 22/09	14	116	AUG 22/04	12	102	MAY 10/93	10
49	APR 22/02	28 29 43 29 28 24 25	117	AUG 10/98	11	103	MAY 10/93	12
50	AUG 22/01	29	118	AUG 10/98	21	104	FEB 10/97	22
51	DEC 22/00	43	119	AUG 22/04	19	105	AUG 10/90	03
52	DEC 22/02	29	120	AUG 10/98	16	106	APR 22/02	01
53	AUG 22/02	28	121	AUG 10/98	16	107	DEC 22/02	04
54	DEC 22/02	24	122	AUG 10/98		108	DEC 22/02	05
55	AUG 22/02	25	123	AUG 10/98	14	109	NOV 10/96	04
56	AUG 22/02		124	BLANK		110	DEC 22/03	04
57	AUG 22/02	27	34-13-00			111	DEC 22/03	05
58	AUG 22/02			NOV 10 /01	07	112	NOV 10/96	04
59	AUG 22/08	24 22	101 102	NOV 10/91		113	DEC 22/06 DEC 22/06	10 05
60	APR 22/01 APR 22/01	27	102	NOV 10/91 FEB 10/96	10 02	114 115	DEC 22/06	06
62	AUG 22/00	23 20 23	103	BLANK	UZ	116	DEC 22/06	06
63	APR 22/01	23	104	DLAIN		117	DEC 22/06	02
64	APR 22/01	20	34-16-00			118	DEC 22/06	01
65	APR 22/01	22	101	AUG 10/98	13	119	DEC 22/06	14
66	DEC 22/03	21	102	MAY 10/91	03	120	DEC 22/06	14
67	APR 22/02	19	103	AUG 10/98	13	121	DEC 22/06	14
68	DEC 22/02	22	104	MAY 10/91	04	122	APR 22/08	16
69	APR 22/02	18	105	AUG 22/99	03	123	DEC 22/06	03
70	AUG 22/01	16	106	BLANK		124	DEC 22/06	03
71	AUG 22/00	25				125	DEC 22/06	03
72	MAY 10/96	10	34-21-00			126	DEC 22/06	03 l
İ			101	MAY 10/92	02	127	DEC 22/06	03
34-BITE			102	MAY 10/97	02	128	DEC 22/06	02
] 1	AUG 22/99	01	103	AUG 10/90	01	129	DEC 22/06	02
2	AUG 22/99	01	104	MAY 10/97	08	130	APR 22/05	03
3	AUG 22/99	01	105	MAY 10/94	02	131	APR 22/05	03
4	BLANK		106	MAY 10/94	02	132	APR 22/05	02
7/ 44 00			107	NOV 10/95	04	133	APR 22/05	02
34-11-00	FFD 40/04	00	108	MAY 10/94	02	134	APR 22/05	01
101	FEB 10/91	02	109 110	MAY 10/94	02	135 136	APR 22/05	01
102 103	FEB 10/91 DEC 22/01	02 01	1111	MAY 10/94 AUG 10/98	02 02	136	BLANK	
103	APR 22/05	02	112	MAY 10/94	02	34-23-00		ŀ
105	FEB 10/91	02	113	MAY 10/97		101	NOV 10/94	01
106	FEB 10/91	01	114	MAY 10/96	06	102	AUG 22/03	01
107	FEB 10/91	02	115	MAY 10/96	05	103	AUG 22/03	01
108	BLANK		116	MAY 10/94	04	104	BLANK	
i			117	AUG 22/00	05	İ		ľ
34-12-00			118	MAY 10/94	04	34-24-00		1
101	FEB 10/95	10	119	APR 22/06	02	101	APR 22/03	01
102	FEB 10/91	02	120	APR 22/06	02	102	FEB 10/97	SAS
103	FEB 10/97	09	121	APR 22/06	02	103	APR 22/03	01
104	AUG 10/95	01	122	APR 22/06	02	104	BLANK	
105	DEC 22/00	01	123	APR 22/06	02	7, 74 65		
106	AUG 22/07	03		APR 22/06		34-31-00	NOV 40/0/	04
107	FEB 10/95	16	125	APR 22/09	10	101	NOV 10/96	01
108	NOV 10/95	06	126	APR 22/09	03	102	AUG 10/90	11
109 110	NOV 10/95 NOV 10/95	08 12	127	APR 22/09 APR 22/09	10 08	103	NOV 10/96 MAY 10/92	01
1110	NOV 10/95 NOV 10/95	17	128 129	APR 22/09 APR 22/06	08 06	104 105	MAY 10/92 MAY 10/92	01 02
1112	NOV 10/95 NOV 10/95	13	130	APR 22/06 APR 22/06	06 05	105	AUG 10/92	02
113	APR 22/09	08	131	APR 22/06	05	107	AUG 10/90	01
114	NOV 10/95	16	132	BLANK	0,5	108	MAY 10/92	01
	1101 10777		132	DEAM			10/ /L	٠,

R = REVISED, A = ADDED OR D = DELETED F = FOLDOUT PAGE 33 AUG 22/09 D633T633

CHAPTER 34 **EFFECTIVE PAGES** PAGE 2 CONTINUED



PAGE	DATE	CODE	PAGE	DATE	CODE	PAGE	DATE	CODE
34-31-00		CONT.	34-45-00		CONT.	34-51-00		
109	MAY 10/92	01	105	FEB 10/94	04H	101	NOV 10/95	02
110	MAY 10/92	01	106	FEB 10/94	04H	102	NOV 10/95	01
111	NOV 10/95	01	107	MAY 10/96	05H	103	NOV 10/95	11 i
112	NOV 10/95	01	108	FEB 10/94	04H	104	NOV 10/95	03
113	NOV 10/96	04	109	MAY 10/96	05H	105	NOV 10/95	03
114	AUG 22/99	01	110	NOV 10/96	04H	106	NOV 10/95	03
115	AUG 22/99	01	111	NOV 10/96	04H	107	NOV 10/95	10
116	NOV 10/96	01	112	BLANK		108	NOV 10/95	02
117	NOV 10/96	01	İ			109	NOV 10/95	02
118	BLANK		34-46-00	CONFIG 1		110	AUG 22/03	02
İ			101	APR 22/02	01B	111	FEB 10/96	02
34-32-00			102	APR 22/02	01B	112	FEB 10/97	01
101	MAY 10/96	01	103	APR 22/02	01B	113	NOV 10/96	01
102	APR 22/02	04	104	DEC 22/02	01B	114	NOV 10/96	04
103	APR 22/02	06	105	DEC 22/02	01B			
104	BLANK		106	DEC 22/02	01B	34-53-00		
I			107	DEC 22/02	01B	101	MAY 10/96	02
34-33-00			108	DEC 22/02	01B	102	FEB 10/94	01
101	AUG 10/97	01	109	DEC 22/02	01B	103	DEC 22/06	17
102	NOV 10/90	07	110	DEC 22/02	01B	104	NOV 10/93	05
103	MAY 10/93	01	111	APR 22/02	01B	105	FEB 10/94	03
104	DEC 22/00	10	112	DEC 22/02	01B	106	FEB 10/94	04
105	DEC 22/00	07	113	APR 22/02	01B	107	FEB 10/94	04
106	AUG 10/91	01	114	APR 22/02	01B	108	FEB 10/94	03
107	NOV 10/96	01	115	APR 22/02	01B	109	FEB 10/94	03
108	NOV 10/96	05	116	APR 22/02	01B	110	FEB 10/94	03
I			117	APR 22/02	01B	111	DEC 22/03	03
34-43-00			118	DEC 22/02		112	FEB 10/94	
101	NOV 10/90	22	119	APR 22/02	01B	113	NOV 10/96	01
102	APR 22/02	06	120	APR 22/02	01B	114	BLANK	
103	APR 22/02	08	121	APR 22/02	01B	_,		
104	APR 22/02	04	122	APR 22/02	01B	34-55-00		
105	DEC 22/99	09	123	APR 22/02 APR 22/02 APR 22/02 APR 22/02 APR 22/02	01B	101	AUG 10/90	03
106	DEC 22/99	07	124	APR 22/U2	SAS B	102	AUG 10/90	01
107	DEC 22/99	08	125	APR 22/U2	01B	103	FEB 10/91	02
108	APR 22/03	11	126	BLANK		104	AUG 10/90	01
109	APR 22/03	11 22 20 18 18 18	7, ,, ,,	0011570 0		105	AUG 10/98	04
110	APR 22/03	20	34-46-00	CONFIG 2	CACD	106	AUG 22/99	02
111	APR 22/03	10	101	DEC 22/01	SAS B	107	AUG 10/90	02
112 113	APR 22/03	18 18	102 103	DEC 22/01	SAS B	108 109	AUG 10/95 NOV 10/95	01 02
113	APR 22/03 APR 22/03	15	103	DEC 22/01 DEC 22/01	SAS B SAS B	1109	NOV 10/95	02 02
114	APR 22/03 APR 22/03	ر ا 1،	104	DEC 22/01		110	NOV 10/95	02 04
116	APR 22/03 APR 22/03	14 12 11 10 13	105	DEC 22/01	SAS B SAS B	111	NOV 10/95	03
117	APR 22/03 APR 22/03	1 <u>/</u> 1 1	106	DEC 22/01	SAS B	112	NOV 10/95 NOV 10/96	03
117	AFR 22/U3	10	107	DEC 22/03	SAS B	113	NOV 10/96 NOV 10/96	02 07
110	APR 22/03 APR 22/09	10	108	DEC 22/01 DEC 22/01	SAS B SAS B	''4	NOV 10/70	01
120	APR 22/09 APR 22/09	13	1109	DEC 22/01	SAS B	34-57-00		
120	APR 22/09 APR 22/09	10	111	DEC 22/01	SAS B	101	FEB 10/94	10
122	APR 22/09 APR 22/09	09		DEC 22/01	SAS B	107	FEB 10/94	
123	APR 22/09 APR 22/09	09	113	DEC 22/01	SAS B	102	FEB 10/94 FEB 10/94	15
124	BLANK	07	114	DEC 22/01	SAS B	103	FEB 10/94	11
124	DEAIN		115	DEC 22/01	SAS B	105	FEB 10/94	13
34-45-00			116	DEC 22/01	SAS B	106	NOV 10/95	06
101	MAY 10/95	05н	117	DEC 22/01	SAS B	107	NOV 10/95	02
102	FEB 10/94	04H	118	AUG 22/05	SAS B	107	NOV 10/96	05
103	APR 22/02	06H	119	DEC 22/01	SAS B	109	NOV 10/96	02
104	FEB 10/94	04H	120	AUG 22/08	01B	110	NOV 10/96	08
L	. 25 .0777			,,,,,,	J.D	<u> </u>		

R = REVISED, A = ADDED OR D = DELETED F = FOLDOUT PAGE 33 AUG 22/09 D633T633

CHAPTER 34 **EFFECTIVE PAGES** PAGE CONTINUED



PAGE	DATE	CODE	PAGE	DATE	CODE	PAGE	DATE	CODE
PAGE 34-61-00 101 102 103 104 105 106 107 108 109 110 111 112 113 114 115 116 117 118 119 120 121 122 123 124 125 126 127 128 129 130 131 132 133 134 135 136	MAY 10/96 AUG 10/90 MAY 10/97 AUG 10/90 FEB 10/94 AUG 10/98 AUG 10/98 AUG 10/98 AUG 10/90 AUG 22/00 AUG 22/00 AUG 22/00 AUG 22/00 AUG 22/03 AUG 22/03 AUG 22/03 AUG 22/06 AUG 22/06 AUG 22/06 AUG 22/06 AUG 22/06 AUG 22/06 AUG 22/06 AUG 22/07 APR 22/07	12 06 23 05 01 01 01 02 06 17 15 02 01 01 01 01 02 12 02 16 01 02 21 22 18	PAGE	DATE	CODE	PAGE	DATE	CODE

R = REVISED, A = ADDED OR D = DELETED F = FOLDOUT PAGE 33 AUG 22/09 D633T633

CHAPTER 34 **EFFECTIVE PAGES** PAGE 4 LAST PAGE



TABLE OF CONTENTS

<u>Subject</u>	Chapter Section <u>Subject</u>	<u>Page</u>	<u>Effectivity</u>
HOW TO USE THE FIM	34-HOW TO USE THE FI	1 M	ALL
INDEX	34-INDEX	1	ALL
EICAS MESSAGES	34-EICAS MESSAGES	1	ALL
FAULT CODE DIAGRAMS	34-FAULT CODE DIAGR	1 A M	ALL
FAULT CODE INDEX	34-FAULT CODE INDEX	1	ALL
BITE INDEX	34-BITE INDEX	1	ALL
NAVIGATION - GENERAL	34-00-00		
FLIGHT ENVIRONMENT DATA PITOT-STATIC SYSTEM Component Location Component Index Component Location	34-10-00 34-11-00	101	ALL
Fault Isolation Alternate Static System		105	
Problem (Fig. 105) Aux-1 (Aux-2) Static System		107	
Problem (Fig. 107) Capt (F/O) Static System		104	
Problem (Fig. 104) Capt (F/O, Aux-1, Aux-2) Pitot		106	
System Problem (Fig. 106) Not Used (Fig. 103)		103	



TABLE OF CONTENTS

	Chapter Section		
Subject	Subject	<u>Page</u>	Effectivity
AIR DATA COMPUTING SYSTEM	34-12-00		
Component Location		101	ALL
Component Index Component Location			
Fault Isolation			
(NOT USED) (Fig. 103)		104	
(NOT USED) (Fig. 106)		107	
Capt's (F/O) Altimeter is Corrected with ALTN Air Data		105	
Selected (Fig. 104)			
L (R) ADC BITE Procedure (Fig.		110	
109)			
L (R) EADI Airspeed and/or Mach Indications in Error.		115	
Selecting Alth Air Data			
Corrects Fault. (Fig. 110)			
Off Flag in View on Capt's		106	
(F/O's) Altimeter (Fig. 105)		400	
SPD Flag in View on L (R) EADI (Fig. 108)		109	
TAS/SAT and Mach Are In Error		108	
(Fig. 107)			
AIR DATA INSTRUMENTS	34-13-00		
Component Location		101	ALL
Component Index Component Location			
Fault Isolation			
Standby Airspeed Error (Fig.		103	
103)	7/ 4/ 00		
ALTITUDE ALERT SYSTEM Component Location	34–16–00	101	ALL
Component Index		101	7,22
Component Location			
Fault Isolation		407	
Altitude Alert System Fault Isolation (Fig. 103)		103	
150 Cation (119. 103)			



TABLE OF CONTENTS

Chapter Section Subject Subject <u>Page</u> **Effectivity** 34-20-00 ATTITUDE AND DIRECTION INERTIAL REFERENCE SYSTEM 34-21-00 Component Location 101 ALL Component Index Component Location Fault Isolation Align Failed to Extin After 10 111 Min (Nav Sel) (Fig. 105D) ARINC Data Bus Charts 121 Capt (F/O) RDMI HDG Flag In 103 View. Altn IRS Corrects. (Fig. 103) Capt (F/O) VSI Off Flag In 105 View. Altn Air Data Corrects (Fig. 104A) Capt (F/O) VSI Off Flag In 104 View. Altn Air Data Doesn't Correct (Fig. 104) Entry INOP to All IRSs (Align 110 Flashes After Second Entry). (Fig. 105C) Entry INOP to Single IRS 109 (Align Flashes After Second Entry). Position Entry from FMC-CDU Successful. (Fig. 105B) Entry INOP to Single IRS 108 (Align Flashes After Second Entry). Position Entry from FMC-CDU Unsuccessful. (Fig. 105A) IRS BITE Test (Fig. 107) 113 IRS Indicates IRS on DC (Fig. 112 106) IRS Indicates IRS DC Fail 107 (Fig. 105)

IRS Removal Checks (Fig. 107A)

IRU Radial Position Error

(Fig. 107B)

34-CONTENTS

116

118



TABLE OF CONTENTS

	Chapter Section		
Subject	<u>Subject</u>	<u>Page</u>	Effectivity
IRU Removal Checks		129	
Radial Position Error Check Residual Groundspeed Error		130 129	
Check		127	
ELECTRONIC FLIGHT INSTRUMENT	34-22-00		
SYSTEM			
Component Location		101	ALL
Component Index			
Component Location			
Fault Isolation		440	
Attitude Comparator Problems (Fig. 109)		119	
Brightness Control Problems on		109	
Capt (F/O) EADI (Fig. 105)		440	
Brightness Control Problems on Capt (F/O) EHSI (Fig. 107)		112	
Display Problems on Capt (F/O)		107	
EADI (Fig. 104)		440	
Display Problems on Capt (F/O) EHSI (Fig. 106)		110	
EFIS BITE Procedure (Fig. 108)		113	
Not Used (Fig. 103)		106	
STANDBY MAGNETIC COMPASS	34-23-00		
Component Location		101	ALL
Component Index			
Component Location	7/ 2/ 00		
STANDBY ATTITUDE REFERENCE SYSTEM	34-24-00	101	A1 1
Component Location		101	ALL
Component Index Component Location			
Fault Isolation			
Standby Attitude Indication		103	
Problems (Fig. 103)		103	
Trobtems trigs 1007			



TABLE OF CONTENTS

Subject	Chapter Section Subject	<u>Page</u>	<u>Effectivity</u>
LANDING AND TAXIING AIDS INSTRUMENT LANDING SYSTEM Component Location	34-30-00 34-31-00	101	ALL
Component Index Component Location Fault Isolation			
Abnormal ILS Test Response on Capt (F/O) EADI & EHSI (Fig. 104)		106	
EHSI and EADI - Both G/S and LOC Dev Pointers Missing (NCD) (Fig. 106)		108	
Faulty Standby Attitude Indicator Operation (Fig.		109	
107) G/S - False or Late Capture (Fig. 111A)		114	
G/S and LOC Flags in View on Capt (F/O) EHSI & EADI (Fig. 105)		107	
G/S Dev Pointer Not Displayed (Fig. 111)		113	
<pre>ILS BITE Procedure (Fig. 103) Loc (G/S) Dev Pointer Missing on Stby Att Ind (Fig. 109)</pre>		104 111	
Loc Dev Pointer Not Displayed (Fig. 110)		112	
<pre>Stby Att - Both Dev Pointers Missing (NCD) (Fig. 108)</pre>		110	
MARKER BEACON SYSTEM Component Location Component Index Component Location Fault Isolation	34-32-00	101	ALL
Marker Beacon Lights and/or Audio Problems (Fig. 103)		103	



TABLE OF CONTENTS

Subject	Chapter Section Subject	<u>Page</u>	<u>Effectivity</u>
RADIO ALTIMETER (RA) SYSTEM Component Location Component Index Component Location	34-33-00	101	ALL
Fault Isolation Radio Altitude Height on the Capt (F/O) EADI Is Inaccurate (Fig. 103)		103	
RA BITE Procedure (Fig. 104A) RA Flag Displayed on Capt (F/O) EADI (Fig. 104)		105 104	
INDEPENDENT POSITION DETERMINING	34-40-00		
WEATHER RADAR SYSTEM Component Location Component Index Component Location Fault Isolation	34-43-00	101	ALL
Visual Check Weather Radar BITE Procedure for External Faults (With "Antenna Tilt" Fault Messages) (Fig. 105)		119 110	
WXR BITE Procedure (Fig. 103) WXR Range Disagree Problems (Fig. 104)		105 108	
WXR Tilt Code Fault Isolation (Fig. 106)		112	
TRAFFIC ALERT AND COLLISION AVOIDANCE SYSTEM (TCAS)	34-45-00		
Component Location Component Index Component Location Fault Isolation		101	ALL
TCAS BITE Procedure (Fig. 103) TCAS Voice Advisory Alert Problem (Fig. 104)		104 109	



TABLE OF CONTENTS

<u>S</u>	<u>Subject</u>	Chapter Section <u>Subject</u>	<u>Page</u>	<u>Effectivity</u>
	GROUND PROXIMITY WARNING SYSTEM Component Location Component Index Component Location Fault Isolation	34-46-00	101	CONFIG 1 [*]
•	Ground Proximity Warning Computer BITE Procedure (Fig. 103)		104	
	Ground Proximity Warning System Self-Test (Fig. 104) [*] SAS, MARTINAIR WITHOUT EGPWS		118	
	Fault Isolation		101	CONFIG 2 [*]
	General		101	
	EGPWC Self Test Levels		103	
	EGPWS BITE		101	
	Operation of Self-Test Level		104	
	0verview		101	
	Prepare for Troubleshooting		102	
	Recommended Maintenance Response to Terrain INOP Light		119	
	Recommended Maintenance Response To Status LED's		118	
;	Self Test Function [*] SAS, MARTINAIR WITH EGPWS		103	

SAS SAS



TABLE OF CONTENTS

Subject	Chapter Section <u>Subject</u>	<u>Page</u>	Effectivity

<u>Subject</u>	<u>Subject</u>	<u>Page</u>	<u>Effectivity</u>
DEPENDENT POSITION DETERMINING	34-50-00		
VHF OMNIDIRECTIONAL RANGE (VOR)	34-51-00		
SYSTEM			
Component Location		101	ALL
Component Index			
Component Location			
Fault Isolation			
Autotune - VOR Flag in View On		107	
RDMIs, Manual Operation			
Normal (Fig. 105)			
Brg Flag on RDMIs, Lateral Dev		111	
Bar Missing on EHSI in VOR			
Mode, VORCP Freq Select OK			
(Fig. 109)			
VOR BITE Procedure (Fig. 103)		104	
VOR Display Problems on L (R)		109	
RDMI and EHSI (Fig. 107)			
VOR Flag on EHSI, RDMI		108	
Displays Are Normal (Fig.			
106)			
VOR Flag on RDMIs, No Flag on		106	
EHSI, VORCP Display Inop			
(Fig. 104)			
VOR Indications Normal, Freq		110	
Display on VORCP Abnormal			
(Fig. 108)	7/ 57 00		
AIR TRAFFIC CONTROL SYSTEM	34-53-00	404	
Component Location		101	ALL
Component Index			
Component Location			
Fault Isolation		100	
Alt Rptg Inop with Left		109	
(Right) Txpdr Selected (Fig. 104)			
ATC System BITE Procedure		105	
(Fig. 103)		לטו	
ATC Transmission Problems		111	
(Fig. 105)		111	
City. 1007			



TABLE OF CONTENTS

<u>Subject</u>	Chapter Section <u>Subject</u>	<u>Page</u>	<u>Effectivity</u>
DISTANCE MEASURING EQUIPMENT (DME) SYSTEM	34-55-00		
Component Location Component Index Component Location Fault Isolation		101	ALL
Autotune Mode – DME Displays Show Dashes (Fig. 108)		111	
Blank DME Display on EHSI - Otherwise Normal (Fig. 106)		109	
DME EHSI and RDMI Displays Blank (Fig. 107)		110	
DME Ident Signal Missing - Displays Normal (Fig. 109)		112	
DME System BITE Procedure (Fig. 103)		103	
ILS Mode - DME Displays Dashes, ILS Ident Normal (Fig. 105)		107	
VOR Mode - DME Displays Dashes, VOR Ident Normal (Fig. 104)		106	
AUTOMATIC DIRECTION FINDER (ADF) SYSTEM	34-57-00		
Component Location Component Index Component Location Fault Isolation		101	ALL
ADF Audio Problems (Fig. 103) Left (Right) ADF Bearing Problems on Both RDMIs (Fig. 104)		104 105	



TABLE OF CONTENTS

Chapter Section

Subject	Subject	<u>Page</u>	<u>Effectivity</u>
FLIGHT MANAGEMENT COMPUTING FLIGHT MANAGEMENT COMPUTER SYSTEM Component Location Component Index Component Location	34-60-00 34-61-00	101	ALL
Fault Isolation Action Performed on Left (Right) CDU Keyboard Is Not Effective (Fig. 104)		107	
Data Incorrect on Left (Right) CDU Display (Fig. 105)		109	
Data Loader Fault Isolation Procedure		130	
Data Loading Procedure Problems and Corrective Actions (Fig. 113)		132	
Erroneous Display of ".ATC" and ".FMC" messages on EICAS Display (Fig. 109B)		120	
Flight Management Computer System BITE Procedure (Fig. 111)		125	
Fuel Error on CDU Display (Fig. 106)		111	
FMC fails to erase ATS datalink messages from previous flights (Fig. 109C)		121	
FMC CDU lockup with message STANDBY ONE displayed		122	
FMC CDU Messages (Fig. 106A) FMC Failure Caused by VOR/DME Data Error (Fig. 110A)		113 124	
FMC Light Fails to Illuminate with CDU Alert (Fig. 108)		116	
FMC Navigation Data Base or Program Incorrect (Fig. 107)		115	
FMC NAV Data Crossloading Problems (Fig. 103A)		105	
L (R) FMC FAIL message shows on EICAS (Fig. 108A)		117	



Chapter

133

CHAPTER 34 - NAVIGATION

TABLE OF CONTENTS

Section Subject Subject **Effectivity** <u>Page</u> LRU Removal/Installation 131 Maintenance Manual References (Fig. 112) 118 MAP RANGE DISAGREE Message Displayed on Left (Right) EHSI (Fig. 109) The VOL:<LABEL>,<FILENAME>N% 134 and the INSERT DISK #1 Show Again and Again in Sequence While the Disk is in the Data Loader (Fig. 115)

Unable to Remotely Tune VOR

from Left (Right) CDU (Fig.
110)

VNAV Path, Altitude,

Transition, LNAV Path,

Heading, Transition Error

(Fig. 109A)

VOL:<LABEL> Shows for More

Than 3 Minutes after You Put

the Disk into the Data Loader

TRANSFER FAIL Shows on the

Data Loader (Fig. 114)

(Fig. 116)

These are the possible types of faults: YOU FIND A FAULT WITH 1. EICAS Message AN AIRPLANE SYSTEM 2. Observed Fault Use the EICAS message, fault code, or fault description to find the corrective action or fault isolation procedure in the FIM. DO THE CORRECTIVE For details, see Figure 3 -ACTION OR GO TO THE FAULT ISOLATION PROCEDURE IN THE FIM If you do not have a fault code or an EICAS message and if the system has BITE, then you can use the system BITE to get more information: Use the BITE Index to find if the system has BITE and to find the BITE procedures in the FIM. For details, see Figure 2 -The fault isolation procedure

> Basic Fault Isolation Process Figure 1

EFFECTIVITY-

ALL

FOLLOW THE STEPS IN

THE FAULT ISOLATION

PROCEDURE

34-HOW TO USE THE FIM

explains how to find and repair the


For details, see Figure 4 —

the cause of the fault.

01

Page 1 Aug 22/99





How to Get Fault Information from BITE Figure 2


ALL ALL

34-HOW TO USE THE FIM

01

Page 2 Aug 22/99 IF YOU HAVE:

THEN DO THIS TO FIND THE CORRECTIVE ACTION OR FAULT ISOLATION PROCEDURE IN THE FIM:



- The first two digits of the fault code are the FIM chapter that you need. Go to the Fault Code Index in that chapter and find the fault code.
- 2. Find the Fault Isolation Reference for the fault code and do the corrective action. If there is a FIM reference, then go to that fault isolation procedure in the FIM and do the steps in the procedure (see Figure 4).



1. If you know the chapter of the EICAS message, then go to the EICAS Messages section in that chapter and find the EICAS message.

If you do not know the chapter of the EICAS message, then do these steps:

A. Go to FIM EICAS MESSAGE LIST and find the EICAS message in the table.

 $\underline{\text{NOTE}}$: The list follows the INTRODUCTION to the FIM.

- B. Find the chapter number on the same line as the EICAS message. Go to the EICAS Messages section in that chapter and find the EICAS message.
- 2. Do the corrective action in the "Procedure" column for the EICAS message. If there is a FIM reference, then go to that fault isolation procedure in the FIM and do the steps in the procedure (see Figure 4).



- 1. Go to the Fault Code Diagram for the problem in the applicable chapter.
- 2. Do the fault analysis on the diagram and find the fault code.
- 3. The first two digits of the fault code are the FIM chapter that you need. Go to the Fault Code Index in that chapter and find the fault code.
- 4. Find the Fault Isolation Reference for the fault code and do the corrective action. If there is a FIM reference, then go to that fault isolation procedure in the FIM and do the steps in the procedure (see Figure 4).

How to Find the Corrective Action or Fault Isolation
Procedure in the FIM
Figure 3

EFFECTIVITY-

34-HOW TO USE THE FIM

01

ALL

Page 3 Aug 22/99



ASSUMED CONDITIONS AT START OF TASK

- External electrical power is OFF
- Hydraulic power and pneumatic power are OFF
- Engines are shut down
- Circuit breakers for the system are closed
- No equipment in the system is deactivated

PREREQUISITES

- This box gives the steps to get the airplane from the normal shutdown condition to the configuration necessary to do the fault isolation procedure.
- The Prerequisites give procedure references, circuit breakers, and special tools and equipment requirements.

FAULT ISOLATION BLOCKS

- Start the fault isolation procedure at block 1 unless specified differently.
- Do the check to get an answer to the question in the box. Follow the arrow that applies to your answer. This will go to the next check.
- When you get to a box in the column at the right of the page, you have isolated that fault. Do the steps in that box to repair the cause of the fault.
- Make sure that fault is corrected to complete the procedure.

Do the Fault Isolation Procedure Figure 4


EFFECTIVITY-

34-HOW TO USE THE FIM

ALL

Page 4 Aug 22/99






Subjects in Each FIM Chapter Figure 5 (Sheet 1)

ALL

O1 Page 5
Aug 22/99

BOEING PROPRIETARY - Copyright (C) - Unpublished Work - See title page for details.



Subjects in Each FIM Chapter Figure 5 (Sheet 2)

EFFECTIVITY-

34-HOW TO USE THE FIM

01

ALL

Page 6 Aug 22/99



NAVIGATION

EICAS MESSAGES	CHAP/SEC
AILERON LOCKOUT ALT DISAGREE ATC FAULT (L, R) FMC FAIL (L, R) GPS FMC MESSAGE GND PROX BITE GPS IAS DISAGREE INSTR SWITCH (CAPT, F/O) INSTR XFER (L, C, R) IRS DC FAIL (L, C, R) IRS ON DC OVERSPEED UNABLE RNP	3412 3453 3461 3458 3461 3458 3412 3422 3421 3421 3421
FMC MESSAGES	CHAP/SEC
FUEL (QTY ERROR, DISAGREE) - PROG 2/2 IRS NAV ONLY	
MISCELLANEOUS MESSAGES	CHAP/SEC
SG FATI	3422

NAVIGATION - INDEX


34-INDEX


10

Page 1 Aug 22/02



FAULT ISOLATION/MAINT MANUAL





NAVIGATION - INDEX


EFFECTIVITY-ALL

256508

34-INDEX

18


Page 3 Feb 10/91




1 AS INSTALLED







NAVIGATION - INDEX





FAULT ISOLATION/MAINT MANUAL

<u>TITLE</u>	<u>CHAP/SEC</u>	<u>TITLE</u>	CHAP/SEC
CHART		COMPASS (STANDBY)	
ALTIMETER TOLERANCE	S	CDU	3461
(CHART 1)	3413	DH	3433
AIRSPEED TOLERANCES		DME	3455
(CHART 2)	3413	EFI SW (ALTN)	3422
CHECK		FLIGHT DIRECTOR .	2211
IRS ACCURACY CHECK	3421	FMC SW (ALTN)	3461
ADF		FMCS	
CONTROL		AIRSPEED BUG (V	NAV MODE) 2211
MODE(S) (AUDIO & FL	_AGS) 3457	ALERT & ADVISOR	Y MESSAGES 3461
RDMI/RMI		CDU BRIGHTNESS.	3461
ADI		CDU FAIL	3461
ATTITUDE		CDU KEYS	3461
DISPLAY		DISPLAY	3461
STANDBY		FIX PAGE	3461
AIR DATA COMPUTER		FMC FAIL	3461
TEST, SW (ALTN)			& MODE SELECT, 3461
AIRSPEED (ELECTRIC)			3461
AIRSPEED (STANDBY)		LNAV GUIDANCE	3461
ALTIMETER (ELECTRIC)			3461
ALTIMETER (STANDBY)		MAP GENERAL	3461
ALTITUDE ALERT			V MODE)2232
ATC TRANSPONDER			T 3461
AUTOPILOT	CHAPTER 22		3461
		RESYNC	
		VNAV GUIDANCE	3/.61

NAVIGATION - INDEX

EFFECTIVITY-

34-INDEX

ALL

03

Page 6 Aug 22/02

63889



FAULT ISOLATION/MAINT MANUAL

TITLE	<u>PAGE</u>	<u>TITLE</u>	<u>PAGE</u>
GLIDESLOPE	3431	MACH (ELEC)	3412
GROUND PROXIMITY WARN		MARKER BEACON	3432
INHIBIT	3446	RADIO ALTIMETER	3433
OPERATION	3446	RDMI HEADING	3421
OVERRIDE	3446	STANDBY	
TEST	3446	AIRSPEED	3413
GROUND SPEED (ADI)	3421	ALTIMETER	3413
HEADING REF	3421	ATTITUDE INDICATOR	3424
HSI		COMPASS	3423
DISPLAY	3422	TCAS	3445
HEADING	3421	TEMPERATURE (SAT, TAT)	3412
TRACK	3421	TRUE AIRSPEED (TAS)	3412
TREND VECTOR	3421	VERTICAL SPEED INDICATOR	3421
ILS		VOR	
ADI DISPLAY	3431	BRG FLAG MAP MODE	3451
CONTROLS	3431	CONT & DISPLAY	3451
HSI DISPLAY	3431	IDENT	3451
HSI FAULTS	3431	WEATHER RADAR	
IDENT	3431	CONTROLS	3443
STANDBY ATTITUDE DISP	LAY 3431	DISPLAY QUANTITY	3443
TEST	3431	FAULTS (HSI)	3443
IRS ACCURACY FAULTS	3421	WINDSHEAR	3446
IRS ALIGN FAULTS	3421		
IRS DATA ENTRY & DISPLA	Y 3421		
IRS SW (ALTN)	3421		
LIGHTNING STRIKE	3490		

NAVIGATION - INDEX

ALL

34-INDEX

03

Page 7 Dec 10/98



NAVIGATION - EICAS MESSAGE LIST

1. General

- A. This procedure shows the EICAS message locations and gives a list of procedures to find the solution for each message.
 - (1) EICAS Message Locations (Fig. 1)
 - (a) Figure 1 shows the location of the EICAS display units and the area where the messages show on the display units.
 - (b) Each message level has a different location. The location and color of each message level is also shown.
 - (2) The EICAS MESSAGE LIST gives the message, level, and procedure for each message.
 - (a) The EICAS MESSAGE column lists the messages alphabetically. Messages which start with L, R, or C are put together and alphabetized at L.
 - (b) The LEVEL column gives all levels for each message as follows:
 - A Warning messages
 - B Caution messages
 - C Advisory messages
 - E Communication messages medium
 - F Communication messages low
 - S Status messages
 - M Maintenance messages
 - (c) The PROCEDURE column gives the steps that are necessary to remove the message and includes one or more of the procedures that follow:
 - 1) A Fault Isolation Manual procedure reference
 - 2) A Maintenance Manual procedure and reference
 - 3) Wiring checks and a Wiring Diagram Manual reference
 - 4) A reference to an EICAS message list in a different chapter.
 - 5) A reference to a FAULT CODE INDEX and specified fault codes
 - 6) A step to change the airplane configuration


EFFECTIVITY-


34-EICAS MESSAGES

01




FAULT ISOLATION/MAINT MANUAL






ENGINE PRIMARY PAGE OR COMPACTED PAGE (TOP DISPLAY UNIT)



ECS/MSG PAGE
(BOTTOM DISPLAY UNIT)



STATUS PAGE
(BOTTOM DISPLAY UNIT)

LEVEL	COLOR
A-WARNING B-CAUTION C-ADVISORY E-COMMUNICATION MEDIUM F-COMMUNICATION LOW S-STATUS	RED YELLOW YELLOW WHITE WHITE WHITE
M-MAINTENANCE	WHITE

EICAS Message Locations Figure 1

EFFECTIVITY-

34-EICAS MESSAGES

01

ALL

Page 2 Aug 22/99



EICAS MESSAGE LIST		
EICAS MESSAGE	LEVEL	PROCEDURE
ALT DISAGREE	B	FIM 34-12-00/101, Fig. 104
ALTITUDE ALERT	В	Replace the altitude alert module, M617 (AMM 34-16-01/401).
ATC FAULT	С	FIM 34-53-00/101, Fig. 103
ATT DISAGREE	В	FIM 34-21-00/101, Fig. 107
ATT FAIL	С	EICAS OPS S/W -01 THRU -03; Do a check for a nuisance EICAS message: Put the EICAS computer select switch to an alternative position. If the message does not show, open and then close the circuit breaker for the EICAS computer that shows the nuisance message. If the problem continues, replace the EICAS computer that shows the nuisance message.
COMPARATOR BITE	S,M NVM	FIM 34-22-00/101, Fig. 109
F/O PVD	С	EICAS OPS S/W -01 THRU -03; Do a check for a nuisance EICAS message: Put the EICAS computer select switch to an alternative position. If the message does not show, open and then close the circuit breaker for the EICAS computer that shows the nuisance message. If the problem continues, replace the EICAS computer that shows the nuisance message.

34-EICAS MESSAGES

04



EICAS MESSAGE LIST		
EICAS MESSAGE	LEVEL	PROCEDURE
FAST/SLOW FAIL	С	EICAS OPS S/W -01 THRU -03; Do a check for a nuisance EICAS message: Put the EICAS computer select switch to an alternative position. If the message does not show, open and then close the circuit breaker for the EICAS computer that shows the nuisance message. If the problem continues, replace the EICAS computer that shows the nuisance message.
FMC MESSAGE	С	FIM 34-61-00/101, Fig. 111
GND PROX BITE	S,M	FIM 34-46-00/101, Fig. 103
GND PROX SYS	С	FIM 34-46-00/101, Fig. 103
GND PROX SYS	S,M	FIM 34-46-00/101, Fig. 103
G/S DISAGREE	С	EICAS OPS S/W -01 THRU -03; Do a check for a nuisance EICAS message: Put the EICAS computer select switch to an alternative position. If the message does not show, open and then close the circuit breaker for the EICAS computer that shows the nuisance message. If the problem continues, replace the EICAS computer that shows the nuisance message.
G/S FAIL	С	EICAS OPS S/W -01 THRU -03; Do a check for a nuisance EICAS message: Put the EICAS computer select switch to an alternative position. If the message does not show, open and then close the circuit breaker for the EICAS computer that shows the nuisance message. If the problem continues, replace the EICAS computer that shows the nuisance message. If this message is not a nuisance message, see FIM 34-31-00/101, Fig. 104.

34-EICAS MESSAGES

ALL

15 Page 4 Dec 22/06



EICAS MESSAGE LIST		
EICAS MESSAGE	LEVEL	PROCEDURE
HDG DISAGREE	С	EICAS OPS S/W -01 THRU -03; Do a check for a nuisance EICAS message: Put the EICAS computer select switch to an alternative position. If the message does not show, open and then close the circuit breaker for the EICAS computer that shows the nuisance message. If the problem continues, replace the EICAS computer that shows the nuisance message.
HDG FAIL	С	EICAS OPS S/W -01 THRU -03; Do a check for a nuisance EICAS message: Put the EICAS computer select switch to an alternative position. If the message does not show, open and then close the circuit breaker for the EICAS computer that shows the nuisance message. If the problem continues, replace the EICAS computer that shows the nuisance message.
IAS DISAGREE	В	FIM 34-12-00/101, Fig. 104
INSTR SWITCH	В	If "INSTR SWITCH" shows when only one of the two EFI switches are in the ALTN position, replace the L (R) EFI source select switch, S3 (S11) (AMM 33-13-00/201). If the problem continues, examine and repair the applicable circuits (WDM 34-22-17, WDM 34-22-27).
L(R) FMC FAIL	С	FIM 34-61-00/101, Fig. 108A

34-EICAS MESSAGES

EICAS MESSAGE LIST		
EICAS MESSAGE	LEVEL	PROCEDURE
L(R,C) IRS DC FAIL	С	Restore AC and DC power (AMM 24-22-00/201). If the problem continues, refer to FIM 34-21-00/101, Fig. 105.
L(R,C) IRS FAULT	С	FIM 34-21-00/101, Fig. 107
L(R,C) IRS ON DC	С	Restore AC power (AMM 24-22-00/201). If the problem continues, refer to FIM 34-21-00/101, Fig. 106.
LOC DISAGREE	С	EICAS OPS S/W -01 THRU -03; Do a check for a nuisance EICAS message: Put the EICAS computer select switch to an alternative position. If the message does not show, open and then close the circuit breaker for the EICAS computer that shows the nuisance message. If the problem continues, replace the EICAS computer that shows the nuisance message.
LOC FAIL	С	EICAS OPS S/W -01 THRU -03; Do a check for a nuisance EICAS message: Put the EICAS computer select switch to an alternative position. If the message does not show, open and then close the circuit breaker for the EICAS computer that shows the nuisance message. If the problem continues, replace the EICAS computer that shows the nuisance message. If the message is not a nuisance message, see FIM 34-31-00/101, Fig. 104.
OVERSPEED	A	 Visually examine the airplane structure (AMM 05-51-04/201). Do the Air Data System - Operational/Test (AMM 34-12-00/501). If an Air Data Computer fails, replace the applicable Air Data Computer (AMM 34-12-01/401).

34-EICAS MESSAGES

ALL

Page 6 Dec 22/06



	EICAS MESSAGE LIST		
EICAS MESSAGE	LEVEL	PROCEDURE	
PILOT RESPONSE	A,B,C	No activity has been detected on the MCP, EFIS/EICAS, Radio Control Panel, MCDU, or HF/VHF radios. Do a check for a nuisance EICAS message: Put the EICAS computer select switch to an alternative position. If the message does not show, open and then close the circuit breaker for the EICAS computer that shows the nuisance message. If the problem continues, replace the EICAS computer that shows the nuisance message.	
RA DISAGREE	С	EICAS OPS S/W -01 THRU -03; Do a check for a nuisance EICAS message: Put the EICAS computer select switch to an alternative position. If the message does not show, open and then close the circuit breaker for the EICAS computer that shows the nuisance message. If the problem continues, replace the EICAS computer that shows the nuisance message.	
SNGL SOURCE ILS	С	767-400 Airplanes with Rockwell Collins MultiMode Receiver (MMR);	
		If this EICAS Message with no correlated maintenance message, then no maintenance action is necessary.	
TCAS	С	FIM 34-45-00/101, Fig. 103	
TCAS FAIL	С	FIM 34-45-00/101, Fig. 103	
TCAS OFF	С	TCAS is in TA or TA/RA mode. No maintenance action is necessary.	
TRACK FAIL	С	EICAS OPS S/W -01 THRU -03; Do a check for a nuisance EICAS message: Put the EICAS computer select switch to an alternative position. If the message does not show, open and then close the circuit breaker for the EICAS computer that shows the nuisance message. If the problem continues, replace the EICAS computer that shows the nuisance message.	

34-EICAS MESSAGES

ALL

Page 7 Aug 22/06



EICAS MESSAGE LIST		
EICAS MESSAGE	LEVEL	PROCEDURE


ALL ALL

34-EICAS MESSAGES

05

Page 8 Dec 22/05





1 >> SEE "ALTIMETER TOLERANCES" CHART TO CORRECT STANDBY ALTIMETER READING BEFORE COMPARING TO CAPT AND F/O ALTIMETER.

APPLICABLE CIRCUIT BREAKERS AS INSTALLED

11A10	AIR DATA CMPTR L	11E23	ALTM (R)
11A11	AIR DATA AOA SENSOR L	11E23	RIGHT ALTM
11A12	AIR DATA BARO CORRECT L	11F30	(RIGHT) AIR DATA CMPTR (R)
11E2	LEFT ALTM	11F31	(RIGHT) AIR DATA AOA SENSOR (R)
11E2	ALTM (L)	11F32	(RIGHT) AIR DATA BARO CORRECT (R)

ELECTRIC ALTIMETER - FAULT CODES

EFFECTIVITY-ALL


34-FAULT CODE DIAGRAM

03

Page 1 Aug 22/02

174572





TAS, SAT AND TAT - FAULT CODES


ALL

34-FAULT CODE DIAGRAM

03

Page 2 Nov 10/96





MACH, AIRSPEED & ALTN AIR DATA (SHEET 1) - FAULT CODES

34-


34-FAULT CODE DIAGRAM

06

Page 3 Nov 10/96

256606





ELECTRIC MACH, AIRSPEED & ALTN AIR DATA (SHEET 2) - FAULT CODES

ALL


34-FAULT CODE DIAGRAM

02

Page 4 Nov 10/96

133531





AIR DATA COMPUTER TEST (SHEET 1) - FAULT CODES

ALL


256610

34-FAULT CODE DIAGRAM

05

Page 5 Nov 10/96






AIR DATA COMPUTER TEST (SHEET 2) - FAULT CODES

34-FAULT CODE DIAGRAM

04

Page 6 Nov 10/96





LIGHTNING STRIKE - FAULT CODES


ALL

34-FAULT CODE DIAGRAM

02

Page 7 Aug 01/86

223131



STANDBY AIRSPEED AND ALTIMETER - FAULT CODES

EFFECTIVITY-ALL

34-FAULT CODE DIAGRAM

03

Page 8 Apr 10/98



CHART 1 ALTIMETER TOLERANCES - GROUND

AL TITUDE	MAX DIFFERENCE					
ALTITUDE FEET	CAPT & F/O	CAPT OR F/O STANDBY				
SEA LEVEL	40	35				
5,000'	40	50				
10,000'	45	60				

ALTIMETER TOLERANCES - FLIGHT

AL TITUDE		MAX. DIFFERENCE				
ALTITUDE FEET	IAS/MACH	CAPT & F/O	CAPT OR F/O & STANDBY			
		CAPI & F/U	-200	-300		
SEA LEVEL	V _{REF}		20-80	10-90		
3,000'	M.32		3,010-3,150	3,020-3,160		
10,000'	250 KTS	60	9,975-10,195	10,005-10,225		
20,000'	300 KTS	115	19,995-20,295	20,105-20,405		
25,000'	M.80	130	24,950-25,470	25,155-25,675		
30,000'	M.80	135	29,935-30,435	30,115-30,615		
35,000'	M.80	145	34,975-35,465	35,155-35,645		
40,000'	M.80	160	40,040-40,540	40,215-40,715		

CHART 2

AIRSPEED TOLERANCES

OTIVILE L	AIKSI	LLD TOLLKANCES		
		MAX. DIFFERENCE		
AIRSPEED KNOTS	04DT 0 5/0	CAPT OR F/O & STANDBY		
KNOTS	CAPT & F/O	-200	-300	
140	± 3	138-146	138.5-146.5	
200	± 3	198.5-206.5	199-207	
250	1 7	(35,000	& BELOW)	
250	± 3	248-258	249-259	
		(35,	000')	
300	± 3	297-307	300-310	
300	Ι 3	(30,000 & BELOW)		
		298.5-308.5	300.5-310.5	
MACH			1 > LANDING FLAPS	
.4060	± .010M			
.6080	± .009M]	
.80 & ABOVE	± .008M			


CHARTS

 34-FAULT CODE DIAGRAM

04

Page 9 Aug 22/07





6D3	L IRS	11F1	(LEFT) IRS (L)
6D4	C IRS	11F21	(CENTER) IRS (C)
6D5	R IRS	11F22	(RIGHT) IRS (R)
11A6	RDMI L	11F25	(RIGHT) RDMI (R)

RDMI HEADING - FAULT CODES


ALL

34-FAULT CODE DIAGRAM

02

Page 10 Nov 10/96





VERTICAL SPEED INDICATOR - FAULT CODES

ALL


O4 Page 11

Nov 10/96

BOEING PROPRIETARY - Copyright (C) - Unpublished Work - See title page for details.



FAULT ISOLATION/MAINT MANUAL



6D3	L IRS	11E6	(LEFT) HSI (L)	11F9	EFIS SYM GEN (C, CTR)
6D4	C IRS	11E25	(RIGHT) EFIS CONT PNL (R)	11F21	(CENTER) IRS (C)
6D5	R IRS	11E27	(RIGHT) HSI (R)	11F22	(RIGHT) IRS (R)
11A6	RDMI L	11F1	(LEFT) IRS (L)	11F24	(RIGHT) EFIS DSPL SW (R)
11A7	EFIS DSPL SW L	11F3	EFIS DSPL SW L	11F25	(RIGHT) RDMI (R)
11E4	(LEFT) EFIS CONT PNL (L)	11F8	EFIS SYM GEN L	11F29	(RIGHT) EFIS SYM GEN (R)

HSI TRACK - FAULT CODES


EFFECTIVITY-ALL

34-FAULT CODE DIAGRAM

02

Page 12 Nov 10/96





MAP MODE SHOWN. FAULTS RECOGNIZED IN VOR/ILS MODES CAN USE THE SAME FAULT CODES. IN VOR/ILS MODES "NO HEADING BUG" WILL BE REPLACED BY HDG FLAG.

APPLICABLE CIRCUIT BREAKERS AS INSTALLED

6D3	L IRS	11E6	(LEFT) HSI (L)	11F9	EFIS SYM GEN (C, CTR)
6D4	C IRS	11E25	(RIGHT) EFIS CONT PNL (R)	11F21	(CENTER) IRS (C)
6D5	R IRS	11E27	(RIGHT) HSI (R)	11F22	(RIGHT) IRS (R)
11A6	RDMI L	11F1	(LEFT) IRS (L)	11F24	(RIGHT) EFIS DSPL SW (R)
11A7	EFIS DSPL SW L	11F3	EFIS DSPL SW L	11F25	(RIGHT) RDMI (R)
11E4	(LEFT) EFIS CONT PNL (L)	11F8	EFIS SYM GEN L	11F29	(RIGHT) EFIS SYM GEN (R)

HSI HEADING, TREND VECTOR, & ALTN IRS - FAULT CODES


ALL ALL

34-FAULT CODE DIAGRAM

02

Page 13 Nov 10/96





6D3	L IRS	11E6	(LEFT) HSI (L)	11F9	EFIS SYM GEN (C, CTR)
6D4	C IRS	11E25	(RIGHT) EFIS CONT PNL (R)	11F21	(CENTER) IRS (C)
6D5	R IRS	11E27	(RIGHT) HSI (R)	11F22	(RIGHT) IRS (R)
11A6	RDMI L	11F1	(LEFT) IRS (L)	11F24	(RIGHT) EFIS DSPL SW (R)
11A7	EFIS DSPL SW L	11F3	EFIS DSPL SW L	11F25	(RIGHT) RDMI (R)
11E4	(LEFT) EFIS CONT PNL (L)	11F8	EFIS SYM GEN L	11F29	(RIGHT) EFIS SYM GEN (R)

ADI ATTITUDE AND GROUND SPEED - FAULT CODES


ALL

34-FAULT CODE DIAGRAM

05

Page 14 Nov 10/96





1>> NOTE: THE FOLLOWING WILL CAUSE ALIGN TO FLASH:

- 1. ENTERED LONG FAILS TO MATCH LAST POS OF IRS.
- 2. ENTERED LAT FAILS TO MATCH IRS CALCULATED LAT.
- 3. FAILS TO INITIALIZE AFTER INITIALIZATION PROCEDURE COMPLETE.

APPLICABLE CIRCUIT BREAKERS AS INSTALLED

6D3	L IRS	6D5	R IRS		11F21	(CENTER) IRS (C)
6D4	C IRS	11F1	(LEFT)	IRS (L)	11F22	(RIGHT) IRS (R)


IRS ALIGN FAULTS - FAULT CODES

ALL ALL

34-FAULT CODE DIAGRAM

02

Page 15 Nov 10/96



IRS DATA ENTRY AND DISPLAY - FAULT CODES

EFFECTIVITY-ALL

34-FAULT CODE DIAGRAM

03

Page 16 Nov 10/96

295188



RESIDUAL GROUNDSPEED ERROR CHECK

THE FMC-CDU POS REF PAGE 2/2 (4/4 PEGASUS EQUIPPED AIRPLANES) DISPLAYS RESIDUAL GROUNDSPEED FOR FMC AND EACH IRS AT THE END OF THE FLIGHT. USE THE FOLLOWING PROCEDURE TO DETERMINE EXCESSIVE RESIDUAL GROUNDSPEED ERROR.

NOTE: THE IRS'S AND FMC'S MUST NOT BE SHUTOFF PRIOR TO COMPLETING THIS PROCEDURE.

- 1 SELECT POS REF PAGE 2/2 (4/4 PEGASUS EQUIPPED AIRPLANES) AND CHECK EACH IRS RESIDUAL GROUNDSPEED ERROR.
- 2 IF THE IRS RESIDUAL GROUNDSPEED ERROR IS 21 KNOTS OR GREATER AFTER COMPLETION OF ANY ONE CHECK (FLIGHT) OR 15 KNOTS OR GREATER AFTER EACH OF TWO CONSECUTIVE CHECKS (FLIGHTS), MAINTENANCE ACTION IS REQUIRED.

RADIAL POSITION ERROR CHECK

THE FMC-CDU POS REF PAGE 2/2 (4/4 PEGASUS EQUIPPED AIRPLANES) DISPLAYS CURRENT POSITION FOR EACH IRS AND AN ACTUAL POSITION ERROR CHECK IS PERFORMED USING THE RTE 1 OR RTE 2 LEGS PAGE. THIS IS DONE BY ENTERING THE ACTUAL (PARKING) AND IRS POSITIONS AS WAYPOINTS AND COMPARING THEIR DIFFERENCE IN NAUTICAL MILES TO A DEVIATION CRITERIA. USE THE FOLLOWING PROCEDURE TO DETERMINE EXCESSIVE RADIAL POSITION ERROR.

NOTE: THE IRS'S AND FMC'S MUST NOT BE SHUTOFF PRIOR TO COMPLETING THIS PROCEDURE. IF IRS'S HAVE BEEN SHUTOFF, USE "INERTIAL NAVIGATION SYSTEMS" DATA RECORDED BY FLIGHT CREW IN AIRCRAFT LOGBOOK.

- 1 SELECT THE POS REF 2/2 (4/4 PEGASUS EQUIPPED AIRPLANES) PAGE AND RECORD THE DISPLAYED LATITUDE AND LONGITUDE FOR EACH IRS.
- 2 SELECT THE RTE 1 OR RTE 2 LEGS PAGE AND ENTER ACTUAL LATITUDE AND LONGITUDE (GATE, RAMP, ETC) AS A WAYPOINT. (SEE AVERAGE GATE LATITUDE/LONGITUDE COORDINATES PAGE).
- 3 ENTER DISPLAYED LATITUDE AND LONGITUDE OF IRS AS NEXT WAYPOINT ON RTE 1 OR RTE 2 LEGS PAGE. ENTER MANUALLY RECORDED DATA FROM (1) OR LINE SELECT FROM POS REF PAGE.
- 4 RADIAL POSITION ERROR IS THE DISTANCE BETWEEN THE TWO ENTERED WAYPOINTS OR THE COMPUTED LEG LENGTH.
- 5 COMPARE THE DISTANCE ALONG WITH THE TIME IN NAV MODE TO THE ACCEPT/REJECT LIMITS ON THE FOLLOWING IRS PERFORMANCE CRITERIA CHART. USE "USE AFTER RNP-10 EFFECTIVE DATE" CHART AFTER RNP-10 EFFECTIVE DATE.
- 6 IF THE IRS RADIAL POSITION ERROR FALLS UPON THE SHADED AREA FOR TWO CONSECUTIVE FLIGHTS OR ABOVE THE SHADED AREA FOR ONE FLIGHT, MAINTENANCE ACTION IS REQUIRED.


IRS ACCURACY CHECKS

EFFECTIVITY-

34-FAULT CODE DIAGRAM



IRS PERFORMANCE CRITERIA CHART



TIME IN NAV POS (HOURS)

IRS ACCURACY CHARTS


 34-FAULT CODE DIAGRAM

0.3

Page 18 Aug 22/01



IRS PERFORMANCE CRITERIA CHART




IRS ACCURACY CHECKS

AIRPLANES WITH FANS

34-FAULT CODE DIAGRAM

06

Page 19 Aug 22/01



FMC "FREEZE" CAN CAUSE FMC-CDU TO DISPLAY EXCESSIVE GROUND SPEED.
VERIFY RESIDUAL GROUND SPEED USING IRMP.

3 AS INSTALLED

APPLICABLE CIRCUIT BREAKERS

NONE

IRS ACCURACY - FAULT CODES


ALL ALL

34-FAULT CODE DIAGRAM

06

Page 20 Apr 22/03






ADI DISPLAY - FAULT CODES

EFFECTIVITY-34-FAULT CODE DIAGRAM

ALL





HSI DISPLAY - FAULT CODES


EFFECTIVITY-

34-FAULT CODE DIAGRAM

ALL

Page 22 Aug 22/01





ALTN EFI, ADI AND HSI - FAULT CODES

EFIS SYM GEN L

ALL ALL

11F8

(RIGHT) ADI (R)

34-FAULT CODE DIAGRAM


11F29

02

Page 23 Nov 10/96

(RIGHT) EFIS SYM GEN (R)

11E24



FMC-HSI RANGE, MAP AND MODE SELECT - FAULT CODES


ALL

34-FAULT CODE DIAGRAM

02

Page 24 Nov 10/96





- IF AFDS IS IN HDG SEL, WILL CHANGE TO HDG HOLD.

WITH SW IN NORM AND ABOVE 73°N OR BELOW 60°S:

- SAME AS ABOVE EXCEPT RDMI HDG FLAG IN VIEW.

APPLICABLE CIRCUIT BREAKERS AS INSTALLED

6D3	L IRS	11E6	(LEFT) HSI (L)	11F21	(CENTER) IRS (C)
6D4	C IRS	11E25	(RIGHT) EFIS CONT PNL (R)	11F22	(RIGHT) IRS (R)
6D5	R IRS	11E27	(RIGHT) HSI (R)	11F24	(RIGHT) EFIS DSPL SW (R)
11A1	VOR/MKR L	11E33	(RIGHT) VOR (R)	11F25	(RIGHT) RDMI (R)
11A6	RDMI L	11F1	(LEFT) IRS (L)	11F29	(RIGHT) EFIS SYM GEN (R)
11A7	EFIS DSPL SW L	11F8	EFIS SYM GEN L		
11E4	(LEFT) EFIS CONT PNL (L)	11F9	EFIS SYM GEN (C, CTR)		

HEADING REFERENCE - FAULT CODES

EFFECTIVITY-ALL

34-FAULT CODE DIAGRAM

02

Page 25 Aug 10/97



NOT USED Figure 19


EFFECTIVITY-

34-FAULT CODE DIAGRAM

ALL

Page 26 Aug 22/02





APPLICABLE CIRCUIT BREAKERS

LIGHTS STBY INSTR 11B7

STANDBY COMPASS - FAULT CODES

EFFECTIVITY-ALL


34623

34-FAULT CODE DIAGRAM

03

Page 27 Aug 22/02





APPLICABLE CIRCUIT BREAKERS

11A5 STBY ATT IND
11B7 LIGHTS STBY INSTR

STANDBY ATTITUDE INDICATOR - FAULT CODES


ALL

34-FAULT CODE DIAGRAM

05

Page 28 Aug 22/02






ILS TEST - FAULT CODES

ALL ALL

34-FAULT CODE DIAGRAM

03

Page 29 Aug 22/02



IF 2 DOT LOC SCALE IS DISPLAYED WHEN IN 4 DOT RANGE, SYSTEM MAY HAVE BEEN SHUTDOWN IN 2 DOT RANGE. SYSTEM WILL RESET WHEN WITHIN RADIO ALT RANGE. ALTN EFI WILL DISPLAY C ILS.

11A2 ILS (C, CTR) 11E10 (LEFT) ILS (L) 11E31 (RIGHT) ILS (R)

ILS ADI/HSI DISPLAYS AND IDENT - FAULT CODES

EFFECTIVITY-

34-FAULT CODE DIAGRAM


14

ALL

Page 30 Aug 22/02

ABNORMAL LOC DEVIATION MAY BE CAUSED BY FREQ/BEARING INCONSISTANCY OF 3 ILS'S, OR WX RADAR INTERFERENCE IF ILS IS TUNED TO FREQ NOT IN USE OR ILS SIGNAL GOES OFF THE AIR. IF FREQ ABNORMAL SEE SEE "HSI FAULTS IN ILS MODE" FAULT CODES.





11E10 (LEFT) ILS (L) 11E31 (RIGHT) ILS (R)

HSI FAULTS IN ILS MODE - FAULT CODES


ALL

34-FAULT CODE DIAGRAM

03

Page 31 Aug 22/02





11A2 ILS (C, CTR)
11A9 STBY ILS (IND)


ILS STANDBY ATTITUDE DISPLAY AND ILS CONTROLS - FAULT CODES

34-FAULT CODE DIAGRAM

07

Page 32 Aug 22/02





APPLICABLE CIRCUIT BREAKERS

11A1 VOR/MKR L


MARKER BEACON - FAULT CODES

34-FAULT CODE DIAGRAM

10

Page 33 Aug 22/02





RADIO ALTIMETER & DH (ADI) - FAULT CODES

EFFECTIVITY

34-FAULT CODE DIAGRAM

09

Page 34 Aug 22/02



NOT USED Figure 28


EFFECTIVITY-

34-FAULT CODE DIAGRAM

03

Page 35 Aug 22/02





11E12	WX	RADAR	IND
11F2	WX	RADAR	(L)
11F23	WX	RADAR	(R)

WEATHER RADAR FAULTS (HSI) - FAULT CODES


ALL ALL

34-FAULT CODE DIAGRAM

06

Page 36 Aug 22/02





WEATHER RADAR CONTROLS - FAULT CODES

ALL ALL

WX RADAR (R)


11F23

34-FAULT CODE DIAGRAM

07

Page 37 Aug 22/02





APPLICABLE CIRCUIT BREAKERS AS INSTALLED

11E12	WX	RADAR	IND
11F2	WX	RADAR	(L)
11F23	WX	RADAR	(R)

WEATHER RADAR DISPLAY QUALITY - FAULT CODES

ALL ALL

34-FAULT CODE DIAGRAM

80

Page 38 Aug 22/02




EFFECTIVITY

34-FAULT CODE DIAGRAM

02

Page 39 Aug 22/02



GND PROX BITE WILL BE DISPLAYED IF L-IRU IS NOT ALIGNED, OR EITHER L-ADC, L-RA OR L-ILS ARE NOT ON. VERIFY THESE ARE OK BEFORE REPORTING THIS CODE.

2> SEE "RADIO ALTIMETER & DH (ADI)" FAULT CODES.

APPLICABLE CIRCUIT BREAKERS

11F4 GND PROX

295342

GROUND PROXIMITY & WINDSHEAR WARNING TEST AND OPERATION — FAULT CODES


EFFECTIVITY

34-FAULT CODE DIAGRAM

06

Page 40 Aug 22/02





APPLICABLE CIRCUIT BREAKERS

11F4 GND PROX

GROUND PROXIMITY WARNING, INHIBIT AND OVERRIDE - FAULT CODES


ALL ALL

34-FAULT CODE DIAGRAM

80

Page 41 Aug 22/02





APPLICABLE CIRCUIT BREAKERS AS INSTALLED

11A1 (RIGHT) VOR (R) VOR MKR L 11E33 11A6 RDMI L 11F25 (RIGHT) RDMI (R)

VOR - CONTROL AND DISPLAY - FAULT CODES


EFFECTIVITY-

34-FAULT CODE DIAGRAM

02

Page 42 Aug 22/02





VERIFY VOR IS OK WITH HSI IN VOR MODE BEFORE SELECTING THIS CODE. IF NOT SELECT CODE FROM "VOR - CONTROL AND DISPLAY" PAGE.

APPLICABLE CIRCUIT BREAKERS AS INSTALLED

11A1	VOR MKR L	11E33	(RIGHT) VOR (R)
11A6	RDMI L	11F25	(RIGHT) RDMI (R)

VOR - HSI IN MAP MODE - FAULT CODES


ALL ALL

34-FAULT CODE DIAGRAM

02

Page 43 Aug 22/02





APPLICABLE CIRCUIT BREAKERS AS INSTALLED

11A1 | VOR/MKR L | 11E33 | (RIGHT) VOR (R)

VOR IDENT - FAULT CODES


ALL

34-FAULT CODE DIAGRAM

11

Page 44 Aug 22/02





APPLICABLE CIRCUIT BREAKERS AS INSTALLED

11F7 (LEFT) ATC (L)
11F28 (RIGHT) ATC (R)

ATC TRANSPONDER - FAULT CODES


ALL

34-FAULT CODE DIAGRAM

16

Page 45 Aug 22/02





VERTICAL SPEED INDICATOR TCAS - FAULT CODES

ALL


11E26 RIGHT VSI

34-FAULT CODE DIAGRAM

18

Page 46 Dec 22/03





DASHES ON THE RDMI AND HSI DME ARE NORMAL WHEN NO DME SIGNAL IS AVAILABLE. USE THESE CODES ONLY WHEN YOU KNOW DME SIGNAL IS AVAILABLE.

APPLICABLE CIRCUIT BREAKERS AS INSTALLED

11A1	VOR/MKR L	11E32	(RIGHT)	DME	(R)
11E11	(LEFT) DME (L	11E33	(RIGHT)	VOR	(R)

DME - FAULT CODES

ALL


34-FAULT CODE DIAGRAM

06

Page 47 Aug 22/02

VERIFY DME IS OK WITH HSI IN VOR OR ILS MODE BEFORE SELECTING THESE CODES. IF NOT OK SELECT CODE FROM VOR OR ILS BRANCH.





ADF CONTROL PANEL/RDMI - FAULT CODES


ALL

34-FAULT CODE DIAGRAM

15

Page 48 Aug 22/02





ADF RECEIVER MAY LOCK UP DURING ELEC POWER TRANSFER. BRG POINTER FLAG WILL DISPLAY ON RDMI. ADF MAY BE RESTORED BY CYCLING ADF CIRCUIT BREAKER.

APPLICABLE CIRCUIT BREAKERS AS INSTALLED

11A3 ADF (L, R) 11F6 (LEFT) ADF (L) 11F27 ADF R

11A6 RDMI L 11F25 (RIGHT) RDMI (R)

ADF (ADF, ANT MODE) - FAULT CODES

ALL

34-FAULT CODE DIAGRAM

17

Page 49 Aug 22/02



EICAS		AULT CODE/ OCATION
WAS MSG DISPLAYED?	NO	T APPLY 0
NO	-	NORMAL
GPS	 	34 58 01 00
UNABLE RNP	 	34 63 36 00
ALT DISAGREE		34 12 91 00
IAS DISAGREE		34 12 92 00
L GPS		34 58 02 00
R GPS	 	34 58 03 00
REPORT ANY FAULT SYMPTOM OR PATTERN NOT SHOWN ABOVE	-	34 21 XA OC

EICAS MESSAGE - FAULT CODES


EFFECTIVITY ALL

34-FAULT CODE DIAGRAM

06

Page 50 Aug 22/02





APPLICABLE CIRCUIT BREAKERS AS INSTALLED

11E8	(LEFT) FMCS CDU (L)	11E29	(RIGHT) FMCS CDU (R)
11E9	(LEFT) FMCS CMPTR (L)	11E30	(RIGHT) FMCS CMPTR (R)

FMC-CDU KEYS & ALTN FMC - FAULT CODES

EFFECTIVITY-ALL

34-FAULT CODE DIAGRAM


05

Page 51 Aug 22/02

E42678



FAULT ISOLATION/MAINT MANUAL



APPLICABLE CIRCUIT BREAKERS AS INSTALLED

11E8	(LEFT) FMCS CDU (L)	11E29	(RIGHT)	FMCS CDU (R)	
11E9	(LEFT) FMCS CMPTR (L)	11E30	(RIGHT)	FMCS CMPTR (R)

CDU FAIL, FMC FAIL AND RESYNC - FAULT CODES


EFFECTIVITY-ALL

34-FAULT CODE DIAGRAM

06

Page 52 Aug 22/02





APPLICABLE CIRCUIT BREAKERS

11E8	LEFT FMCS CDU
11E9	LEFT FMCS CMPTR
11E29	RIGHT FMCS CDU
11E30	RIGHT FMCS CMPTR

FMC-CDU BRIGHTNESS - FAULT CODES

EFFECTIVITY-ALL


174781

34-FAULT CODE DIAGRAM

05

Page 53 Aug 22/02





FMC-CDU IDENT PAGE - FAULT CODES

EFFECTIVITY-


ALL

34-FAULT CODE DIAGRAM

05

Page 54 Aug 22/02





RECORD TIME IRS WAS IN OPERATION, ACTUAL AND INDICATED LATITUDE AND LONGITUDE. ADD ADDITIONAL NOTE TO LOG BOOK REPORT IF ERROR IS EXCESSIVE FOR 2 CONSECUTIVE FLIGHTS. (SEE RADIAL POSITION ERROR CHECK)

APPLICABLE CIRCUIT BREAKERS AS INSTALLED

174783

6D3	L IRS	11E8	(LEFT) FMCS CDU (L)	11F1	(LEFT) IRS (L)
6D4	C IRS	11E9	(LEFT) FMCS CMPTR (L)	11F21	(CENTER) IRS (C)
6D5	R IRS	11E29	(RIGHT) FMCS CDU (R)	11F22	(RIGHT) IRS (R)
		11E30	(RIGHT) FMCS CMPTR (R)		

FMC-CDU POS INIT/REF PAGE - FAULT CODES


05

Page 55 Aug 22/02

34-FAULT CODE DIAGRAM



FAULT ISOLATION/MAINT MANUAL



FMC-CDU PERFORMANCE INITIALIZATION PAGE - FAULT CODES

EFFECTIVITY-34-FAULT CODE DIAGRAM ALL 05 Page 56 Aug 22/02



EFFECTIVITY-

34-FAULT CODE DIAGRAM

ALL

Page 57 Aug 22/02



EFFECTIVITY-

ALL

34-FAULT CODE DIAGRAM

06

Page 58 Aug 22/02



EFFECTIVITY-

ALL

34-FAULT CODE DIAGRAM

05

Page 59 Aug 22/02



EFFECTIVITY-


ALL

34-FAULT CODE DIAGRAM

05

Page 60 Aug 22/02





FMC - CDU FIX INFO PAGE - FAULT CODES

ALL ALL

34-FAULT CODE DIAGRAM

05

Page 61 Aug 22/02



EFFECTIVITY-

ALL

34-FAULT CODE DIAGRAM

05

Page 62 Aug 22/02



EFFECTIVITY

34-FAULT CODE DIAGRAM

05

Page 63 Aug 22/02



EFFECTIVITY-

ALL

34-FAULT CODE DIAGRAM

05

Page 64 Aug 22/02



EFFECTIVITY

34-FAULT CODE DIAGRAM

05

Page 65 Aug 22/02



EFFECTIVITY-


ALL

34-FAULT CODE DIAGRAM

05

Page 66 Aug 22/02





FMC-CDU PROGRESS PAGE - FAULT CODES


EFFECTIVITY-ALL

34-FAULT CODE DIAGRAM

05

Page 67 Aug 22/02





FMC-CDU ALERT AND ADVISORY MESSAGES - FAULT CODES


ALL

34-FAULT CODE DIAGRAM

05

Page 68 Aug 22/02






FMC-HSI MAP GENERAL - FAULT CODES

34-FAULT CODE DIAGRAM

09 Page 69

Aug 22/02





FMC-HSI MAP DATA - FAULT CODES

ALL

34-FAULT CODE DIAGRAM

11

Page 70 Aug 22/02




EFFECTIVITY-

34-FAULT CODE DIAGRAM

05

Page 71 Aug 22/02






FMC-VNAV MODE EPR AND AIRSPEED BUGS - FAULT CODES

34-FAULT CODE DIAGRAM

Page 72 Aug 22/02

09





APPLICABLE CIRCUIT BREAKERS AS INSTALLED

11E8	(LEFT) FMCS CDU (L)	11E21 (CENTER) FLT CONT CMPTR SERVO (C)
11E9	(LEFT) FMCS CMPTR (L)	11E29 (RIGHT) FMCS CDU (R)
11E16	MODE CONT PNL L	11E30 (RIGHT) FMCS CMPTR (R)
11E17	FLT CONT CMPTR PWR L	11E34 MODE CONT PNL R
11E18	FLT CONT CMPTR SERVO L	11E35 (RIGHT) FLT CONT CMPTR PWR (R)
11E20	(CENTER) FLT CONT CMPTR PWR (C)	11E36 (RIGHT) FLT CONT CMPTR SERVO (R)

FMC-LNAV AND VNAV GUIDANCE - FAULT CODES

ALL ALL

34-FAULT CODE DIAGRAM

06

Page 73 Aug 22/02

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 12 XA	 (01=Capt, 02=F/0) An electric altimeter problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions.) SSM 34-12-01, SSM 34-12-02
34 12 XB 00	 A TAS, SAT, Or TAT problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions.) SSM 34-12-01, SSM 34-12-02
34 12 XC	 (01=Capt, 02=F/0) A mach, airspeed problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions.) SSM 34-12-01, SSM 34-12-02
34 12 XD	 (01=Capt, 02=F/0) An air data computer test problem was encountered by the flight crew which is not covered in the fault code diagrams (Ref fault code diagram for flight crew actions.) SSM 34-12-01, SSM 34-12-02
34 12 XE	 (01=Capt, 02=F/0) An air data computer test problem was encountered by the flight crew which is not covered in the fault code diagrams (Ref fault code diagram for flight crew actions.) SSM 34-12-01, SSM 34-12-02
34 12 XF	 (01=Capt, 02=F/0) A mach, airspeed, ALTN AIR DATA problem was encountered by the flight crew which is not covered in the fault code diagrams (Ref fault code diagram for flight crew actions). SSM 34-12-01, SSM 34-12-02
34 13 XA 00	 A standby airspeed and altimeter problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions.) SSM 34-13-01
34 16 XA	 (01=Capt, 02=F/0, 03=Both) An altitude alert problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref Chapter 22 fault code diagram for flight crew actions.) SSM 34-16-01

34-FAULT CODE INDEX

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 21 XA	 (01=Capt, 02=F/0) An RDMI heading problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions.) SSM 34-21-01, SSM 34-21-02, SSM 34-21-03
34 21 XA 00	 An EICAS message was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions.) Refer to 34-EICAS MESSAGES list.
34 21 XB	 (01=Capt, 02=F/0) A vertical speed indicator problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions.) SSM 34-21-01, SSM 34-21-02, SSM 34-21-03
34 21 XC	 (01=Capt, 02=F/0) An EHSI track and wind problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions.) SSM 34-21-01, SSM 34-21-02, SSM 34-21-03
34 21 XD	 (01=Capt, 02=F/0) An EHSI heading, trend vector, and Altn IRS problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions.) SSM 34-21-01, SSM 34-21-02, SSM 34-21-03
34 21 XE	 (01=Capt, 02=F/0, 03=L, 04=C, 05=R) An EADI attitude and ground speed problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions.) SSM 34-21-01, SSM 34-21-02, SSM 34-21-03
34 21 XF 00	 An IRS accuracy problem was encountered by the flight crew that was not covered in the fault code diagram. (Ref fault code diagram for flight crew actions.) AMM 34-21-00/501.
34 21 XF	 (01=L, 02=C, 03=R, 07=ALL) An IRS ALIGN FAULT panel problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions.) SSM 34-21-01, SSM 34-21-02, SSM 34-21-03

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 21 XG	 (01=L, 02=C, 03=R, 04=ALL) An IRS data entry and display problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions.) SSM 34-21-01, SSM 34-21-02, SSM 34-21-03
34 22 XA	 (01=Capt, 02=F/0) An EADI problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions.) SSM 34-22-08
34 22 XB	 (01=Capt, 02=F/0) An EHSI problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions.) SSM 34-22-07
34 22 XC	 (01=Capt, 02=F/0) An EHSI and EADI problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions.) SSM 34-22-07, SSM 34-22-08
34 22 XD	 (01=Capt, 02=F/0) An EHSI traffic, range, map and mode select problem encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions.) SSM 34-22-07
34 22 XE	Not used.
34 22 XF	Not used.
34 22 XG	 A heading reference problem was encountered by the flight crew which was not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions.) SSM 34-22-07

ALL

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 23 XA 00	 A standby magnetic compass problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions.) Perform standby compass swing operation (AMM 34-23-00/201)
34 24 XA 00	 A standby attitude reference system problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions.) SSM 34-24-01
34 31 XA	 (O1=Capt EHSI and EADI, O2=F/O EADI and EHSI, O3=STBY ATT IND) An ILS TEST problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions.) SSM 34-31-01, SSM 34-31-02, SSM 34-31-03
34 31 XB	 (01=L, 02=R, 03=C, 04=Capt, 05=F/O) An ILS ADI/HSI problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions.) SSM 34-31-01, SSM 34-31-02, SSM 34-31-03
34 31 XC	 (01=Capt, 02=F/0) An ILS/EHSI problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions.) SSM 34-31-01, SSM 34-31-02, SSM 34-31-03
34 31 XD 00	 An ILS controls and STBY ATT IND problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions.) SSM 34-31-01, SSM 34-41-02, SSM 34-41-03



FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 32 XA	 A marker beacon problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions.) SSM 34-32-01
34 33 XA	 (01=Capt, 02=F/0) A radio altitude and DH (EADI) problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions.) SSM 34-33-01, SSM 34-33-02, SSM 34-33-03
34 43 XA	 (01=SYS L, 02=SYS R, 03=Capt, 04=F/0, 05=Both) A WXR display (HSI) problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions.) SSM 34-33-01 thru SSM 34-33-03



FAULT 1. LOG BOOK REPORT
CODE 2. FAULT ISOLATION REFERENCE

34 43 XB --

 (01=SYS L, 02=SYS R) A WXR control problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions.)

2. SSM 34-43-01

EFFECTIVITY-

34-FAULT CODE INDEX

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 43 XC	 A (01=L, 02=R) system WXR display quality problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions.) SSM 34-43-01
34 46 XA 00	 A ground proximity and windshear warning problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions.) SSM 34-46-01
34 46 XB 00	 A ground proximity warning, inhibit and override problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions.) SSM 34-46-01
34 51 XA	 (01=Capt, 02=F/0) A VOR frequency select problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions.) SSM 34-51-01, SSM 34-51-02
34 51 XB	 (01=Capt, 02=F/0, 03=L, 04=R) A VOR display problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions.) SSM 34-51-01, SSM 34-51-02
34 51 XC	 (01=Capt, 02=F/0) A VOR course problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions.) SSM 34-51-01, SSM 34-51-02

34-FAULT CODE INDEX

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 53 XA	 (01=L, 02=R, 03=L & R) An ATC transponder problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions.) SSM 34-53-01, SSM 34-53-02
34 55 XA	 (01=Capt, 02=F/0, 03=L, 04=R) A DME problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions.) SSM 34-55-01, SSM 34-55-02
34 57 XA	 (01=Capt, 02=F/0, 03=L, 04=R) An ADF control panel/RDMI problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions.) SSM 34-57-01, SSM 34-57-02
34 57 XB	 An ADF (ADF, ANT mode) problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions.) SSM 34-57-01, SSM 34-57-02
34 61 XA	 (01=Capt, 02=F/0, 03=Both) An FMC CDU keys problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions). SSM 34-60-01, SSM 34-60-02, SSM 34-61-01 thru SSM 34-61-04
34 61 XB	 (01=Capt, 02=F/0) A CDU fail, FMC fail, or resync problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions). SSM 34-60-01, SSM 34-61-02, SSM 34-61-01 thru SSM 34-61-04

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 61 XC	 (01=Capt, 02=F/0) A CDU brightness problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions). SSM 34-60-01, SSM 34-60-02, SSM 34-61-01 thru SSM 34-61-04
34 61 XD	 (01=Capt, 02=F/0, 03=Both) A CDU IDENT page problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions). SSM 34-60-01, SSM 34-60-02, SSM 34-61-01 thru SSM 34-61-04
34 61 XE	 (01=Capt, 02=F/0, 03=Both) A CDU POS INIT/REF page problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions). SSM 34-60-01, SSM 34-60-02, SSM 34-61-01 thru SSM 34-61-04
34 61 XF	 (01=Capt, 02=F/0, 03=Both) A CDU performance initialization page problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions). SSM 34-60-01, SSM 34-60-02, SSM 34-61-01 thru SSM 34-61-04 NOTE: RESERVES and TRANS ALT not applicable to FMCs with LNAV/VNAV configuration.
34 61 XG	34 61 XG thru 34 61 XJ Not used.
34 61 XK	 (01=Capt, 02=F/0, 03=Both) A CDU FIX INFO page problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions). SSM 34-60-01, SSM 34-60-02, SSM 34-61-01 thru SSM 34-61-04
	<u>NOTE</u> : ETA and ALT not applicable to FMCs with LNAV/VNAV configuration.

34-FAULT CODE INDEX

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 61 XL 34 61 XQ	 34 61 XL thru 34 61 XP Not used. 1. (01=Capt, 02=F/0, 03=Both) A CDU PROGRESS page problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions) 2. SSM 34-60-01, SSM 34-60-02, SSM 34-61-01 thru SSM 34-61-04
	NOTE: Forecast FUEL, forecast ETAs for intermediate waypoints, TO T/C predictions not applicable to FMCs with LNAV/VNAV configuration.
34 61 XR	 (01=Capt, 02=F/0, 03=Both) A CDU alert and advisory message problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions). SSM 34-60-01, SSM 34-60-02, SSM 34-61-01 thru SSM 34-61-04
34 61 XS	 (01=Capt, 02=F/0, 03=Both) An EHSI map general problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions). SSM 34-60-01, SSM 34-60-02, SSM 34-61-01 thru SSM 34-61-04
34 61 XT	 (01=Capt, 02=F/0, 03=Both) An EHSI map data problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions). SSM 34-60-01, SSM 34-60-02, SSM 34-61-01 thru SSM 34-61-04
34 61 XU	Not used.

	FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34	61 XV	 (01=Capt, 02=F/0, 03=No. 1, 04=No. 2, 05=Both) A VNAV mode EPR and airspeed bug problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions). SSM 34-60-01, SSM 34-60-02, SSM 34-61-01 thru SSM 34-61-04
34	61 XW	 (01=Capt, 02=F/0, 03=No. 1, 04=No. 2, 05=Both) An FMC-V NAV Mode N1/EPR and airspeed bug problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions.) SSM 34-60-01,SSM 34-60 -02, SSM 34-61-01 thru SSM 34-61-04
34	61 XX	Not used.
34	61 XY	 (01=Capt, 02=F/0, 03=Both) An FMC LNAV and VNAV problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref fault code diagram for flight crew actions). SSM 34-60-01, SSM 34-60-02, SSM 34-61-01 thru SSM 34-61-04
34	90 XA 00	 A lightning strike occurred which was not covered in the fault code diagrams (Ref fault code diagrams for flight crew action). Make an inspection of the airplane for lightning strike or severe static discharge (AMM 05-51-19/201).
34	11 04 00	 Standby altimeter and standby airspeed (report the problem, low, high, fluctuates, etc.). FIM 34-11-00/101, Fig. 105, Block 1
34	12 01 01	 BARO SET INOP on captain's altimeter. Replace the captain's altimeter, N8 (AMM 34-13-01/401).
34	12 02 01	 Capt altimeter in error. It reads F/O altimeter reads Selecting ALTN AIR DATA corrects the fault. FIM 34-12-00/101, Fig. 104, Block 1
34	12 03 01	1. Capt altimeter in error with both normal and ALTN AIR DATA selected. It reads F/O altimeter reads Stby altimeter reads 2. Replace the captain's altimeter. N8 (AMM 34-13-01/401).

		1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34	12 04 02	 BARO SET INOP on F/O's altimeter. Replace the F/O's altimeter, N48 (AMM 34-13-01/401)
34	12 05 02	 F/O altimeter in error. It reads Capt altimeter reads Stby altimeter reads Selecting ALTN AIR DATA corrects the fault. FIM 34-12-00/101, Fig. 104, Block 1
34	12 06 02	 F/O altimeter in error with both normal and ALTN AIR DATA selected. It reads Capt altimeter reads Stby altimeter reads Replace the F/O's altimeter, N48 (AMM 34-13-01/401).
34	12 07	 (01=Capt, 02=F/0) Altimeter sticking. Replace the applicable altimeter, N8 (captain) or N48 (F/0) (AMM 34-13-01/401).
34	12 08	 OFF flag in view on (01=Capt, 02=F/0) altimeter. Selecting ALTN air data corrects the fault. FIM 34-12-00/101, Fig. 105, Block 1
34	12 09	 Off flag in view on (O1=Capt, O2=F/O) altimeter with both NORMAL and ALTN AIR DATA selected. Replace the applicable altimeter, N8 (captain) or N48 (F/O) (AMM 34-13-01/401).
34	12 10 00	 TAT indicator blank. TAS and SAT normal. Replace the TAT probe (AMM 34-12-02/401).
34	12 11 00	34 12 11 00 thru 34 12 13 00 Not used.
34	12 14 00	 TAS in error. Reads, should be SAT normal. FIM 34-12-00/101, Fig. 109, Block 1
34	12 15 00	 TAS and SAT in error. TAS reads, should be SAT reads, should be Mach and TAT norm. Replace the applicable air data computer, M100 (left) or M101 (right) (AMM 34-12-01/401).
34	12 16 00	1. TAS, SAT and Mach in error. TAS reads, SAT reads

34-FAULT CODE INDEX

ALL

	2. FAULT ISOLATION REFERENCE
34 12 17 34 12 21	34 12 17 thru 34 12 20 Not used. 1. (01=Capt, 02=F/0) AS in error. Capt's AS reads F/0
J. 12 2.	AS reads Stby AS reads ALTN AIR DATA selection corrects the fault. 2. FIM 34-12-00/101, Fig. 110, Block 1
34 12 22	 (01=Capt, 02=F/0) AS in error. Capt's AS reads F/0's AS reads Stby AS reads ALTN AIR DATA selection fails to correct fault. FIM 34-22-00/101, Fig. 104, Block 1
34 12 23	 (01=Capt, 02=F/0) Mach indication in error. Capt's Mach reads F/0 Mach reads ALTN AIR DATA selection corrects the fault. FIM 34-12-00/101, Fig. 110, Block 1
34 12 24	 (01=Capt, 02=F/0) Mach indication in error. Capt's Mach reads F/0 Mach reads ALTN AIR DATA selection fails to correct fault. FIM 34-22-00/101, Fig. 104, Block 1
34 12 25	34 12 25 thru 34 12 26 Not used.
34 12 27	1. (O1=Capt, O2=F/O) AS and Mach in error. Readings are: Capt AS, F/O AS, Stby AS, Capt Mach, F/O Mach ALTN AIR DATA corrects the fault. 2. FIM 34-12-00/101, Fig. 110, Block 1
34 12 28	 (01=Capt, 02=F/0) AS and Mach in error. Readings are: Capt AS, F/0 AS, Stby AS, Capt Mach, F/0 Mach ALTN AIR DATA fails to correct the fault. FIM 34-22-00/101, Fig. 104, Block 1
34 12 29	 (01=Capt, 02=F/O) SPD flag in view. ALTN AIR DATA selection corrects the fault. FIM 34-12-00/101, Fig. 108, Block 1

34-FAULT CODE INDEX

ALL

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 12 30	 (01=Capt, 02=F/0) SPD flag in view. ALTN AIR DATA selection fails to correct fault. FIM 34-22-00/101, Fig. 108, Block 1
34 12 31	 (01=Capt, 02=F/0) MACH flag in view. ALTN AIR DATA selection corrects the fault. Replace the applicable air data computer, M100 (left) or M101 (right) (AMM 34-12-01/401).
34 12 32	 (01=Capt, 02=F/0) MACH flag in view. ALTN AIR DATA selection fails to correct fault. FIM 34-12-00/101, Fig. 109, Block 1
34 12 33 thru 34 12 37	Not used.
34 12 38	 (01=Capt, 02=F/0) Altm fails to read 10,000 ft during ADC test. Test OK with ALTN AIR DATA selected. Replace the applicable air data computer, M100 (left) or M101 (right) (AMM 34-12-01/401).
34 12 39	 (01=Capt, 02=F/0) Altn fails to read 10,000 ft during ADC test with normal or ALTN AIR DATA selected. Replace the applicable altimeter, N8 (captain) or N48 (F/0) (AMM 34-13-01/401).
34 12 40	 (01=Capt, 02=F/0) Alth OFF flag fails to appear during ADC test. Test OK with ALTN AIR DATA selected. Replace the applicable air data computer, M100 (left) or M101 (right) (AMM 34-12-01/401).
34 12 41	 (01=Capt, 02=F/0) Alth OFF flag fails to appear during ADC computer test with normal or ALTN AIR DATA selected. Replace the applicable altimeter, N8 (captain) or N48 (F/0) (AMM 34-13-01/401).
34 12 42	 (01=Capt, 02=F/0) Alth OFF flag fails to appear and alth fails to read 10,000 ft during test. Test OK with ALTN AIR DATA selected. Replace the applicable air data computer, M100 (left) or M101 (right) (AMM 34-12-01/401).



FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 12 43	 (01=Capt, 02=F/0) Alth OFF flag fails to appear and alth fails to read 10,000 ft during test with normal or ALTN AIR DATA selected. Replace the applicable altimeter, N8 (captain) or N48 (F/0) (AMM 34-13-01/401).
34 12 44	 (01=Capt, 02=F/0) Airspeed fails to read 137 KIAS during ADC test. Test OK with ALTN AIR DATA selected. Replace the applicable air data computer, M100 (left) or M101 (right) (AMM 34-12-01/401).
34 12 45	 (01=Capt, 02=F/0) Airspeed fails to read 137 KIAS during ADC test with normal or ALTN AIR DATA selected. FIM 34-22-00/101, Fig. 104, Block 1
34 12 46	34 12 46 thru 34 12 61 Not used.
34 12 62 00	 No response received to ADC test. Replace the applicable air data computer, M100 (left) or M101 (right) (AMM 34-12-01/401).
34 12 63 00	1. TAS, SAT and TAT indications are blank. 2. FIM 34-12-00/101, Fig. 109, Block 1
34 12 64 00	 TAS, SAT, and TAT in error. TAS reads, SAT reads, TAT reads FIM 34-12-00/101, Fig. 109, Block 1
34 12 65	34 12 65 thru 34 12 67 Not used.

34-FAULT CODE INDEX

	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
	2. FAULT ISOLATION REFERENCE
34 12 68 00	 ADC Test of TAT +35C on EICAS (did not display, was blank, etc). FIM 34-12-00/101, Fig. 109, Block 1
34 12 69 00	Not used.
34 12 70	 (01=Capt, 02=F/0) altimeter fluctuates. Altimeter normal with ALTN AIR DATA selected. FIM 34-12-00/101, Fig. 104, Block 1
34 12 71	 (01=Capt, 02=F/0) altimeter fluctuates with normal or ALTN AIR DATA selected. Replace the applicable altimeter, N8 (captain) or N48 (F/0) (AMM 34-13-01/401).
34 12 72	 (01=Capt, 02=F/0) Altimeter baro indicator has uncommanded movement. Replace the applicable altimeter, N8 (captain) or N48 (F/0) (AMM 34-13-01/401).
34 12 73 00	 SAT indication blank. TAS and TAT normal. Replace the applicable air data computer, M100 (left) or M101 (right) (AMM 34-12-01/401).
34 12 74 00	 TAS indication blank. SAT and TAT normal. Replace the applicable air data computer, M100 (left) or M101 (right) (AMM 34-12-01/401).
34 12 75 00	 EICAS msg OVERSPEED displayed and OVSP lgt illum. Air-speed below limit. Replace the applicable air data computer, M100 (left) or M101 (right) (AMM 34-12-01/401).
34 12 76	 Selecting (01=Capt, 02=F/0) ALTN AIR DATA not norm. (Describe) Replace the applicable air data computer, M100 (left) or M101 (right) (AMM 34-12-01/401).

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 12 77	 (01=Capt, 02=F/O) EADI speed tape (fluctuates, inop, etc.) ALTN AIR DATA selection corrects the fault. Replace the applicable air data computer, M100 (left) or M101 (right) (AMM 34-12-01/401).
34 12 78	 (01=Capt, 02=F/0) EADI speed tape (fluctuates, inop, etc.) ALTN AIR DATA selection fails to correct the fault. FIM 34-22-00/101, Fig. 104, Block 1
34 12 79	Not used.
34 12 80 00	 EICAS message AILERON LOCKOUT did not display and AIL LOCK light did not illum during ADC test. FIM 27-09-00/101, Fig. 106, Block 1.
34 12 81	 (01=Capt, 02=F/0, 03=Capt & F/0) VSI did not display flag(s) during ADC test. Test OK with ALTN AIR DATA selected. Replace the applicable air data computer, M100 (left) or M101 (right) (AMM 34-12-01/401).
34 12 82	 (01=Capt, 02=F/0, 03=Capt & F/0) VSI did not display flag(s) during ADC test with norm or ALTN AIR DATA selected. Replace the applicable vertical speed indicator, N9 (captain) or N49 (F/0) (AMM 34-22-06/401).
34 12 82	 (01=Capt, 02=F/0, 03=Capt & F/0) VSI did not display flag(s) during ADC test with norm or ALTN AIR DATA selected. Replace the applicable vertical speed indicator, N9 (captain) or N49 (F/0) (AMM 34-22-09/401).
34 12 83	 (01=Capt, 02=F/0) SPD and MACH flags fail to appear during ADO test. Test ok with ALTN AIR DATA selected. Replace the applicable air data computer, M100 (left) or M101 (right) (AMM 34-12-01/401).
34 12 84	 (01=Capt, 02=F/0) SPD and MACH flags fail to appear during ADO test with normal or ALTN AIR DATA selected. FIM 34-22-00/101, Fig. 104, Block 1
34 12 85	 (01=Capt, 02=F/0) SPD, MACH and ALTM off flags fail to appear during ADC test. Replace the applicable air data computer, M100 (left) or M101 (right) (AMM 34-12-01/401).

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 12 86	 (01=Capt, 02=F/0) EADI speed tape faulty (describe) with normal or ALTN EFI selected. FIM 34-12-00/101, Fig. 109, Block 1, if the problem continues, perform FIM 34-22-00/101, Fig. 108, Block 1
34 12 87	 (01=Capt, 02=F/O) SPD flag and Altm OFF flag in view. ALTN AIR DATA selection corrects fault. FIM 34-12-00/101, Fig. 108, Block 1
34 12 91 00	 The EICAS message ALT DISAGREE (caution) is displayed. FIM 34-12-00/101, Fig. 104
34 12 92 00	 The EICAS message IAS DISAGREE (caution) is displayed. FIM 34-12-00/101, Fig. 104
34 13 01 00	 Standby Altimeter (Report the problem, low, high, sticks, fluctuates, vibrates, INOP, etc.). Replace the standby altimeter, N23 (AMM 34-13-06/401).
34 13 02 00	 Standby airspeed (Report the problem, low, high, sticks, fluctuates, etc.). FIM 34-13-00/101, Fig. 103, Block 1
34 16 01 00	34 16 01 00 thru 34 16 06 00 Not used.
34 16 07 04	 No master CAUTION Lgt on Capt's side when ALT ALERT lgt illum. Other alt alert indications norm (Ref Chapter 22 fault code diagrams). Examine and repair the circuit from burndy terminal TB241, pin YC3 to the captain's master CAUTION switch, pin 16 (WDM 34-16-11).
34 16 07 05	 No master CAUTION Lgt on F/O's side when ALT ALERT lgt illum. Other alt alert indications norm (Ref Chapter 22 fault code diagrams). Examine and repair the circuit from burndy terminal TB241, pin YC3 to the F/O's master CAUTION switch, pin 16 (WDM 34-16-11).



FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 16 07 06	 No master CAUTION Lgt on Capt's or F/O's side when ALT ALERT lgt illum. Other alt alert indications norm (Ref Chapter 22 fault code diagrams). FIM 31-51-00/101, Fig. 104, Block 1
34 16 08	 No caution aural warning from (04=Capt, 05=F/0, 06=both Capt & F/0) speakers when ALT ALERT lgt illum. Other alt alert indication norm (Ref Chapter 22 fault code diagrams). Replace the left siren/owl aural warning module, M999 (AMM 31-51-04/401).
34 16 09 00	 No master CAUTION lgts or aural warning when ALT ALERT lgt illum. Other alt alert indications norm (Ref Chapter 22 fault code diagrams). Replace the altitude alert module, M617 (AMM 34-16-01/401).
34 16 10 00	 No ALT ALERT lgt or ALTITUDE ALERT EICAS msg when apl deviates more than 300' from alt selected on MCP (Ref Chapter 22 fault code diagrams). FIM 34-16-00/101, Fig. 103, Block 1
34 16 11 00	 No ALTITUDE ALERT EICAS msg when airplane deviates more than 300' from selected alt on MCP. Other alt alert indications norm (Ref Chapter 22 fault code diagrams). FIM 34-16-00/101, Fig. 103, Block 1
34 16 12 00	 No ALT ALERT lgt when apl deviates more than 300' from selected alt on MCP. ALTITUDE ALERT EICAS msg displayed (Ref Chapter 22 fault code diagrams). FIM 34-16-00/101, Fig. 103, Block 1

	FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34	16 13 00	1. Capt & F/O altimeters ALT alert lgt (illum, extin) at wrong alt (note alt) (Ref Chapter 22 fault code diagrams). 2. FIM 34-16-00/101, Fig. 103, Block 1
34	16 14	 (04=Capt, 05=F/0, 06=Both Capt and F/O) altimeter ALT lgt failed to illum in alert range (Ref Chapter 22 fault code diagrams). FIM 34-16-00/101, Fig. 103, Block 1
34	21 01	 (01=Capt, 02=F/0) RDMI heading card sticks. Replace the applicable RDMI, N3 (captain) or N43 (F/0) (AMM 34-22-05/401).
34	21 02	 (01=Capt, 02=F/0) RDMI and opposite EHSI heading in error. Capt's RDMI reads, F/0's RDMI reads, standby compass reads OK on ALTN IRS. Replace the applicable IRU, M159 (left) or M161 (right) (AMM 34-21-01/401).
34	21 03	 (01=Capt, 02=F/0) RDMI heading in error. Capt reads
34	21 04	 (01=Capt, 02=F/0) RDMI heading flag in view. No IRS fault indication. Replace the applicable RDMI, N3 (captain) or N43 (F/0) (AMM 34-22-05/401).
34	21 05	 (01=Capt, 02=F/0) RDMI VOR and HDG flags in view. DIST (DME) normal. (L, R) IRS fault is indicated. 0k on ALTN IRS. Replace the applicable IRU, M159 (left) or M161 (right) (AMM 34-21-01/401)

34-FAULT CODE INDEX

ALL

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 21 06	 (01=Capt, O2=F/O) RDMI VOR and HDG flags in view. DIST (DME) normal. Ok on ALTN IRS. FIM 34-21-00/101, Fig. 103, Block 1
34 21 07	 (01=Capt, 02=F/0) RDMI VOR and HDG flags in view. DIST (DME) is blank. Replace the applicable RDMI, N3 (captain) or N43 (F/0) (AMM 34-22-05/401).
34 21 08	 (01=Capt, 02=F/0) Vertical speed sticks. Replace the applicable vertical speed indicator, N9 (left) or N49 (right) (AMM 34-22-06/401).
34 21 08	 (01=Capt, 02=F/0) Vertical speed sticks. Replace the applicable vertical speed indicator, N9 (left) or N49 (right) (AMM 34-22-09/401).
34 21 09	 (01=Capt, 02=F/0) Vertical speed incorrect. 0k on ALTN IRS. Replace the applicable IRU, M159 (left) or M161 (right) (AMM 34-21-01/401).
34 21 10	 (01=Capt, 02=F/0) Vertical speed incorrect. ALTN IRS doesn't correct. ALTN AIR DATA corrects. FIM 34-21-00/101, Fig. 104A, Block 1
34 21 11	 (01=Capt, 02=F/0) Vertical speed OFF flag (VSI FAIL) in view. (L, R) IRS fault indicated. Ok on ALTN IRS. Replace the applicable IRU, M159 (left) or M161 (right) (AMM 34-21-01/401).
34 21 11	 (01=Capt, 02=F/0) Vertical speed OFF flag (VSI FAIL) displayed. (L, R) IRS fault indicated. Ok on ALTN IRS. Replace the applicable IRU, M159 (left) or M161 (right) (AMM 34-21-01/401).
34 21 12	 (01=Capt, 02=F/0) Vertical speed OFF flag (VSI FAIL) displayed. ALTN AIR DATA corrects. FIM 34-21-00/101, Fig. 104A, Block 1

	FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34	21 13	 (01=Capt, 02=F/0) EHSI track in error. Capt track, F/0 track Ok on ALTN IRS. Replace the applicable IRU M159 (left) or M161 (right) (AMM 34-21-01/401).
		<u>NOTE</u> : Track error can be cause by marginal performance of the DME, FMC, or IRU systems.
34	21 14	 (01=Capt, 02=F/0) EHSI track in error. Capt track, F/0 track ALTN IRS doesn't correct. Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).
		<u>NOTE</u> : Track error can be cause by marginal performance of the DME, FMC, or IRU systems.
34	21 15	 (01=Capt, 02=F/0) EHSI track flag in view. IRS fault indicated. Ok on ALTN IRS. Replace applicable IRU, M159 (left) or M161 (right) (AMM 34-21-01/401).
34	21 16	 (01=Capt, 02=F/0) EHSI track flag in view. Ok on ALTN IRS. Replace applicable IRU, M159 (left) or M161 (right) (AMM 34-21-01/401).
34	21 17	 (01=Capt, 02=F/0) EHSI heading bug in error. Capt EHSI heading, F/O RDMI heading, standby compass heading OK on ALTN IRS. Replace the applicable IRU, M159 (left) or M161 (right) (AMM 34-21-01/401).
34	21 18	 (01=Capt, 02=F/0) EHSI curved trend vector missing. IRS fault illum. OK on ALTN IRS. Replace the applicable IRU, M159 (left) or M161 (right) (AMM 34-21-01/401).
34	21 19	 (01=Capt, 02=F/0) EHSI curved trend vector missing. Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 21 20	 (01=Capt, 02=F/0) EHSI heading bug missing. Opposite RDMI HDG normal. Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).
34 21 21	 (01=Capt, 02=F/0) EHSI heading bug missing. HDG and VOR flags in view on opposite RDMI. IRS fault illum. Ok on ALTN IRS. Replace the applicable IRU, M159 (left) or M161 (right) (AMM 34-21-01/401).
34 21 22	 (01=Capt, 02=F/0) EHSI heading bug missing. HDG and VOR flags in view on opposite RDMI. Replace the applicable IRU, M159 (left) or M161 (right) (AMM 34-21-01/401).
34 21 23	 (01=Capt, 02=F/0) EADI ground speed in error. Capt ground speed reads Ok on ALTN IRS. Replace the applicable IRU, M159 (left) or M161 (right) (AMM 34-21-01/401).
34 21 24	 (01=Capt, 02=F/0) EADI ground speed in error. ALTN IRS doesn't correct. Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).
34 21 25	 (01=Capt, 02=F/0) EADI ground speed blank. (L,R) IRS fault indicated. Ok on ALTN IRS. Replace the applicable IRU, M159 (left) or M161 (right) (AMM 34-21-01/401).
34 21 26	 (01=Capt, 02=F/0) EADI ground speed blank. Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).
34 21 27	 (01=Capt, 02=F/0) EADI pitch (describe problem: indicates excessive pitch, oscillates, drifts, etc). Ok on ALTN IRS. Replace the applicable IRU, M159 (left) or M161 (right) (AMM 34-21-01/401).

34-FAULT CODE INDEX

CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 21 28	 (01=Capt, 02=F/O) EADI pitch (describe problem: indicates excessive pitch, oscillates, drifts, etc). ALTN IRS doesn't correct. Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).
34 21 29	 (O1=Capt, O2=F/O) EADI bank (describe problem: indicates excessive bank, oscillates, drifts, etc). Ok on ALTN IRS. Replace the applicable IRU, M159 (left) or M161 (right) (AMM 34-21-01/401).
34 21 30	 (01=Capt, 02=F/0) EADI bank (describe problem: indicates excessive bank, oscillates, drifts, etc). ALTN IRS doesn't correct. Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).
34 21 31	 (01=Capt, 02=F/O) EADI ATT flag in view. (L, R) IRS fault indicated. Ok on ALTN IRS. Replace the applicable IRU, M159 (left) or M161 (right) (AMM 34-21-01/401).
34 21 32	 (01=Capt, 02=F/0) EADI ATT flag in view. Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).
34 21 33	 (O1=Capt, O2=F/O) EADI ATT flag in view and ground speed blank. (L, R) IRS fault indicated. Ok on ALTN IRS. Replace the applicable IRU, M159 (left) or M161 (right) (AMM 34-21-01/401).
34 21 34	 (01=Capt, 02=F/0) EADI ATT flag in view and ground speed blank. Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).
34 21 35	 (O1=Capt, O2=F/O) EADI ATT flag in view and ground speed blank. RDMI HDG flag, HSI TRK flag, and vert speed OFF flag also in view. (L, R) IRS fault indicated. Ok on ALTN IRS. Replace the applicable IRU, M159 (left) or M161 (right) (AMM 34-21-01/401).
34 21 36	Not Used.

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 21 37	1. (01=L, 02=C, 03=R, 07=ALL) IRS indicate(s) IRS DC FAIL. 2. FIM 34-21-00/101, Fig. 105, Block 1.
34 21 38	 (01=L, 02=C, 03=R, 07=ALL) IRS indicate(s) IRS ON DC. FIM 34-21-00/101, Fig. 106, Block 1
34 21 39	 During alignment (01=L, 02=C, 03=R) IRS indicated IRS FAULT. Selecting ATT extinguished FAULT. Replace the applicable IRU, M159 (left), M160 (center) or M161 (right) (AMM 34-21-01/401).
34 21 40	 During alignment (01=L, 02=C, 03=R) IRS indicated IRS FAULT. FAULT remained illum with ATT selected. Replace the applicable IRU, M159 (left), M160 (center) or M161 (right) (AMM 34-21-01/401).
34 21 41	34 21 41 thru 34 21 42 Not used.
34 21 43	 After alignment (01=L, 02=C, 03=R) IRS indicated IRS FAULT. Selecting ATT extinguished FAULT. Replace the applicable IRU, M159 (left), M160 (center) or M161 (right) (AMM 34-21-01/401).
34 21 44	 After alignment (O1=L, O2=C, O3=R) IRS indicated IRS FAULT. FAULT remained illum with ATT selected. Replace the applicable IRU, M159 (left), M160 (center) or M161 (right) (AMM 34-21-01/401).
34 21 45	 (01=L, 02=C, 03=R, 04=L&C, 05=R&C, 06=L&R, 07=ALL) ALIGN flashed when pos entered and re-entered. FIM 34-21-00/101, Fig. 105A, Block 1.

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 21 46	 (01=L, 02=C, 03=R, 04=L&C, 05=R&C, 06=L&R, 07=ALL) ALIGN flashed approx 10 min after align mode entered. IRS FAULT remained extin. FIM 34-21-00/101, Fig. 105D, Block 1.
34 21 47	 (01=L, 02=C, 03=R, 04=L&C, 05=R&C, 06=L&R, 07=ALL) ALIGN flashed approx 10 min after align entered. IRS FAULT illuminated when latitude was re-entered. Replace the applicable IRU, M159 (left), M160 (center) or M161 (right) (AMM 34-21-01/401).
34 21 48	Not used.
34 21 49	 ON DC failed to illum then extin on (O1=L, O2=C, O3=R) IRS(s) when align initiated. Replace the applicable IRU, M159 (left), M160 (center) or M161 (right) (AMM 34-21-O1/401).
34 21 50	 ALIGN failed to illum on (01=L, 02=R, 03=R) IRS(s) when align initiated. Replace the applicable IRU, M159 (left), M160 (center) or M161 (right) (AMM 34-21-01/401).
34 21 51	 ALIGN failed to extin on (01=L, 02=C, 03=R) IRS when NAV entered. NAV selected when turned on. FIM 34-21-00/101, Fig. 105D, Block 1
34 21 52	 ALIGN failed to illum then extin on (01=L, 02=C, 03=R) IRS when switched from NAV to ALIGN to NAV. Replace the applicable IRU, M159 (left), M160 (center) or M161 (right) (AMM 34-21-01/401).

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 21 53	 TK/GS display on IRS panel is inop from (01=L, 02=C, 03=R, 04=ALL) IRS system(s). Replace the IRS panel, M59 (AMM 34-21-02/201).
34 21 54	 PPOS display on IRS panel is inop from (01=L, 02=C, 03=R, 04=ALL) IRS system(s). Replace the IRS panel, M59 (AMM 34-21-02/201).
34 21 55	 WIND display on IRS panel is inop from (01=L, 02=C, 03=R, 04=ALL) IRS system(s). Replace the IRS panel, M59 (AMM 34-21-02/201).
34 21 56	 If Wind display(s) is blank on ground, then there is no fault. HDG display on IRS panel is inop from (O1=L, O2=C, O3=R, O4=ALL) IRS system(s). Replace the IRS panel, M59 (AMM 34-21-02/201).
34 21 57 00	 The number in (describe position) is (describe problem: segment missing, blank, cycling, etc) on IRS panel. Replace the applicable incandescent display lamp(s) (AMM 34-21-02/201). If the problem continues, replace the IRS panel, M59 (AMM 34-21-02/201). If the problem is a floating decimal point, replace the applicable IRU, M159 (left), M160 (center) or M161 (right) (AMM 34-21-01/401).
34 21 57	 (01=L, 02=R, 03=C) IRS residual position error excessive, (indicate NM error, time in nav & No. of flights). Replace the L (C, R) IRU, M159 (M160, M161) (AMM 34-21-01/401).
34 21 58	 All displays on IRS panel are inop from (01=L, 02=C, 03=R) IRS system(s). Replace the applicable IRU, M159 (left), M160 (center) or M161 (right) (AMM 34-21-01/401).

	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 21 58 04	 All displays on IRS panel are inop from (04=ALL) IRS system(s). Replace the IRS panel, M59 (AMM 34-21-02/201). If the problem continues, examine and repair the interface circuit from the IRU (left: connector D367B, pins C10 and C11. center: connector D369B, pins C10 and C11. or right: connector D371B, pins C10 and C11) and the IRMP (left: connector D739, pins 24 and 25. center: connector D743, pins 24 and 25. or right: connector D741, pins 24 and 25) (WDM 34-21-11, (WDM 34-21-21, WDM 34-21-31).
34 21 59 00	1. (Describe key: 1, 2, 3, etc) key is inop on IRS panel. 2. Replace the IRS panel, M59 (AMM 34-21-02/201).
34 21 59	 (01=L, 02=R, 03=C) IRS residual groundspeed error excessive, (indicate G.S. error, No. of flights). Do the residual groundspeed error check (FIM 34-21-00/101). Replace the L (C, R) IRU, M159 (M160, M161) (AMM 34-21-01/401).
34 21 60 00	1. All keys are inop on IRS panel. 2. Replace the IRS panel, M59 (AMM 34-21-02/201).
34 21 61 00	 Align light flashes on all IRU annunciators, after second position was entered on IRS panel. FIM 34-21-00/101, Fig. 105C, Block 1
34 21 62	 (01=Capt, 02=F/0) RDMI, VOR and HDG flags in view. DIST normal. ALTN IRS doesn't correct. Replace the applicable RDMI, N3 (captain) or N43 (F/0) (AMM 34-22-05/401).

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 21 63	 (01=Capt, 02=F/0) EHSI heading bug in error. Capt EHSI heading F/0 RDMI heading Standby compass heading ALTN IRS doesn't correct. Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).
34 21 64	 (01=Capt, 02=F/0) EHSI track flag in view. ALTN IRS doesn't correct. Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).
34 21 65	 Align light flashes on (01=L, 02=C, 03=R) IRS panel after second position entry from IRS panel. IRS pos entry from FMC-CDU ok. FIM 34-21-00/101, Fig. 105B, Block 1
34 21 66	 Align light flashes on (01=L, 02=C, 03=R) IRS panel after second position entry from IRS panel. IRS pos. entry from FMC-CDU unsuccessful. FIM 34-21-00/101, Fig. 105A, Block 1
34 21 67	 (01=Capt, 02=F/0) RDMI HDG flag in view. (L, R) IRS FAULT is indicated. Replace the applicable IRU, M159 (left) or M161 (right) (AMM 34-21-01/401).
34 21 68	 (O1=Capt, O2=F/O) vertical speed incorrect. ALTN IRS doesn't correct. ALTN AIR DATA doesn't correct. Replace the applicable vertical speed indicator, N9 (left) or N49 (right) (AMM 34-22-06/401).

34-FAULT CODE INDEX

ALL

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 21 68	 (01=Capt, 02=F/0) vertical speed incorrect. ALTN IRS doesn't correct. ALTN AIR DATA doesn't correct. Replace the applicable vertical speed indicator, N9 (left) or N49 (right) (AMM 34-22-09/401).
34 21 69	 (01=Capt, 02=F/0) Vertical speed OFF flag (VSI FAIL) displayed. ALTN AIR DATA doesn't correct. FIM 34-21-00/101, Fig. 104, Block 1
34 21 70	 After flight residual GS on (01=L, 02=C, 03=R) IRU is too high for two consecutive flights (record GS error per flight). Replace the applicable IRU, M159 (left), M160 (center) or M161 (right) (AMM 34-21-01/401).
34 21 71	 After flight PPOS on (01=L, 02=C, 03=R) IRU is in error, (record time IRS was in nav mode, actual and indicated latitude and longitude). Add note if IRS error was excessive for two consecutive flights. FIM 34-21-00/101, Fig. 107A, Block 1
34 21 72	 Selecting (01=Capt, 02=F/0) ALTN IRS not norm. (Describe). Replace the applicable IRU, M159 (left), M160 (center) or M161 (right) (AMM 34-21-01/401).
34 21 73	34 21 73 thru 34 21 76
34 21 77	Not used. 1. (01=L, 02=C, 03=R) IRS inoperative. 2. Replace the applicable IRU, M159 (left), M160 (center) or M161 (right) (AMM 34-21-01/401).
34 21 78 00	 ATT DISAGREE message displayed on EICAS. FIM 34-21-00/101, Fig. 107, Block 1
34 21 79	 RA off flag in view. Replace the applicable vertical speed indicator, N9 (left) or N49 (right) (AMM 34-22-09/401).
34 22 01	 (01=Capt, 02=F/0) EADI is blank. Selecting ALTN EFI corrects the fault. FIM 34-22-00/101, Fig. 108, Block 1

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 22 02	 (01=Capt, 02=F/O) EADI is (blank, intermittent). Selecting ALTN EFI does not correct fault. FIM 34-22-00/101, Fig. 104, Block 1
34 22 03	1. (01=Capt, 02=F/0) EADI is out of focus. 2. FIM 34-22-00/101, Fig. 104, Block 1
34 22 04	 (01=Capt, 02=F/0) EADI sky/ground circle goes black intermittently. FIM 34-22-00/101, Fig. 104, Block 1
34 22 05	 (01=Capt, 02=F/0) EADI sky/ground boundary is incorrect. Selecting ALTN EFI corrects the fault. Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).
34 22 06	 (01=Capt, 02=F/O) EADI white horizon line is not aligned with the sky/ground line. Selecting ALTN EFI corrects the fault. Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).
34 22 07	 (01=Capt, 02=F/O) EADI is distorted. Selecting ALTN EFI corrects the fault. Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).
34 22 08	 (01=Capt, 02=F/0) EADI is distorted. Selecting ALTN EFI does not correct the fault. FIM 34-22-00/101, Fig. 104, Block 1
34 22 09	 (01=Capt, 02=F/O) EADI sky and ground colors are offset. Selecting ALTN EFI corrects the faults. Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).
34 22 10	 (01=Capt, 02=F/0) EADI (width, height) is incorrect. Selecting ALTN EFI corrects fault. Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 22 11	 (01=Capt, 02=F/0) EADI (width, height) is incorrect. Selecting ALTN EFI does not correct fault. FIM 34-22-00/101, Fig. 104, Block 1
34 22 12	 (01=Capt, 02=F/0) EADI size and (linearity, brightness) changed. Selecting ALTN EFI corrects the fault. Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).
34 22 13	 (01=Capt, 02=F/0) EADI size and (linearity, brightness) changed. Selecting ALTN EFI does not correct the fault. FIM 34-22-00/101, Fig. 104, Block 1
34 22 14	 (01=Capt, 02=F/0) EADI is only one color. Selecting ALTN EFI corrects fault. Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).
34 22 15	 (01=Capt, 02=F/0) EADI is only one color. Selecting ALTN EFI does not correct fault. FIM 34-22-00/101, Fig. 104, Block 1
34 22 16	 (01=Capt, 02=F/0) EADI is wrong (color, intensity). Selecting ALTN EFI corrects the fault. Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).
34 22 17	 (01=Capt, 02=F/0) EADI is wrong (color, intensity). Selecting ALTN EFI does not correct fault. FIM 34-22-00/101, Fig. 104, Block 1
34 22 18	 (01=Capt, 02=F/0) EADI has a colored fringe on the display. Replace the applicable EADI, N4 (captain) or N44 (F/0) (AMM 34-22-03/401).
34 22 19	1. (01=Capt, 02=F/0) EADI color shade is off. 2. FIM 34-22-00/101, Fig. 104, Block 1
34 22 20	 (01=Capt, 02=F/0) EADI manual brightness adjust is inop. FIM 34-22-00/101, Fig. 105, Block 1
34 22 21	 (01=Capt, 02=F/0) EADI manual and auto brightness adjust are inop. FIM 34-22-00/101, Fig. 105, Block 1

34-FAULT CODE INDEX

Page 32

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 22 22	 (01=Capt, 02=F/0) EHSI is (blank, intermittent). Selecting ALTN EFI corrects the fault. FIM 34-22-00/101, Fig. 108, Block 1
34 22 23	 (01=Capt, 02=F/0) EHSI is (blank, intermittent). Selecting ALTN EFI does not correct fault. FIM 34-22-00/101, Fig. 106, Block 1
34 22 24	1. (01=Capt, 02=F/0) EHSI is out of focus. 2. FIM 34-22-00/101, Fig. 106, Block 1
34 22 25	Not used.
34 22 26	 (01=Capt, 02=F/0) EHSI is distorted. Selecting ALTN EFI corrects the fault. Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).
34 22 27	 (01=Capt, 02=F/0) EHSI is distorted. Selecting ALTN EFI does not correct the fault. FIM 34-22-00/101, Fig. 106, Block 1
34 22 28	 (01=Capt, 02=F/0) EHSI (width, height) is incorrect. Selecting ALTN EFI corrects the fault. Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).
34 22 29	 (01=Capt, 02=F/0) EHSI (width, height) is incorrect. Selecting ALTN EFI does not correct fault. FIM 34-22-00/101, Fig. 106, Block 1
34 22 30	 (01=Capt, 02=F/0) EHSI size and (linearity, brightness) changed. Selecting ALTN EFI corrects the fault. Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).
34 22 31	 (01=Capt, 02=F/0) EHSI size and (linearity, brightness) changed. Selecting ALTN EFI does not correct the fault. FIM 34-22-00/101, Fig. 106, Block 1
34 22 32	 (01=Capt, 02=F/0) EHSI is only one color. Selecting ALTN EFI corrects fault. Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 22 33	 (01=Capt, 02=F/0) EHSI is only one color. Selecting ALTN EFI does not correct fault. FIM 34-22-00/101, Fig. 106, Block 1
34 22 34	 (01=Capt, 02=F/0) EHSI is wrong (color, intensity). Selecting ALTN EFI corrects the faults. Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).
34 22 35	 (01=Capt, 02=F/0) EHSI is wrong (color, intensity). Selecting ALTN EFI does not correct the fault. FIM 34-22-00/101, Fig. 106, Block 1
34 22 36	 (01=Capt, 02=F/0) EHSI has a colored fringe on the display. Replace the applicable EHSI, N5 (captain) or N45 (F/0) (AMM 34-22-04/401).
34 22 37	1. (01=Capt, 02=F/0) EHSI color shade is off. 2. FIM 34-22-00/101, Fig. 106, Block 1
34 22 38	1. (01=Capt, 02=F/0) EHSI manual brightness adjust is inop.2. FIM 34-22-00/101, Fig. 107, Block 1
34 22 39	 (01=Capt, 02=F/0) EHSI manual and auto brightness adjust are inop. FIM 34-22-00/101, Fig. 107, Block 1
34 22 40	 (01=Capt, 02=F/0) EADI and EHSI are blank. Selecting ALTN EFI corrects fault. FIM 34-22-00/101, Fig. 108, Block 1
34 22 41	 (01=Capt, 02=F/0) EADI and EHSI displays are unintelligable. Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).
34 22 42	 (01=Capt, 02=F/0) EADI and EHSI have no lines on the displays. Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).
34 22 43	 (01=Capt, 02=F/0) EADI and EHSI lines are offset. Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 22 44	 (01=Capt, 02=F/0) EHSI mode selector position doesn't correspond to HSI display. ILS mode displayed. DH and WX RADAR FAIL displayed. Replace the applicable EFIS control panel, M94 (left) or M93 (right) (AMM 34-22-02/201).
34 22 45	 (01=Capt, 02=F/0) EHSI (NAV AID, APRT, RTE DATA, WPT) MAP feature switch(es) (describe fault). Replace the applicable EFIS control panel, M94 (left) or M93 (right) (AMM 34-22-02/201).
34 22 46	 (01=Capt, 02=F/0) HSI RANGE selector (describe fault). Replace the applicable EFIS control panel, M94 (left) or M93 (right) (AMM 34-22-02/201).
34 22 47	 (01=Capt, 02=F/0) sky/ground circle on EADI and WXR on EHSI go black. FIM 34-22-00/101, Fig. 108, Block 1
34 22 48	 Command bug(s) on (01=Capt, 02=F/0, 03=both) EADI speed tape(s) disagree(s) with (MCP, FMS CDU). Bugs normal using ALTN EFI. Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).
34 22 49	 Command Airspeed bug(s) (not normal, missing, etc) on (01=Capt, 02=F/0) EADI speed tape(s). ALTN EFI selection corrects fault. Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).
34 22 50	 V1, VR bug(s) (not normal, missing, etc) on (01=Capt, 02=F/0, 03=both) EADI speed tape(s). ALTN EFI selection corrects fault. Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).
34 22 51	 (01=Capt, 02=F/0) EADI speed tape faulty (describe) ALTN EFI selection corrects fault. Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).
34 22 52	34 22 52 thru 34 22 69 Not used.

34-FAULT CODE INDEX

18

ALL

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 22 70	 (01=Capt, 02=F/0) EADI sky/ground boundry is incorrect. Selecting ALTN EFI doesn't correct fault. FIM 34-22-00/101, Fig. 104, Block 1
34 22 71	 (01=Capt, 02=F/0) EADI white horizon is off the sky ground line. Selecting ALTN EFI does not correct fault. FIM 34-22-00/101, Fig. 104, Block 1
34 22 72	 (01=Capt, 02=F/0) EADI sky and ground colors are offset. Selecting ALTN EFI does not correct fault. FIM 34-22-00/101, Fig. 104, Block 1
34 22 73	 (01=Capt, 02=F/0) EADI and EHSI are blank. Selecting ALTN EFI does not correct fault. FIM 34-22-00/101, Fig. 108, Block 1
34 22 74	1. (01=Capt, 02=F/0) EADI auto brightness inop 2. FIM 34-22-00/101, Fig. 105, Block 1
34 22 75 00	 No F/D initialization indicators displayed on captain's EADI with F/D source selector positioned to L. Condition remains same with selector at C; however, operation normal with alternate EFI selected. Replace the left EFIS symbol generator, N148 (AMM 34-22-01/401).
34 22 76 00	 No F/D initialization indications displayed on first officer's EADI with F/D source selector positioned to R. Condition remains same with selector at C; however, operation normal with alternate EFI selected. Replace the right EFIS symbol generator, N150 (AMM 34-22-01/401).
34 22 77	1. (01=Capt, 02=F/0) EHSI auto brightness inop. 2. FIM 34-22-00/101, Fig. 107, Block 1
34 22 78	34 22 78 thru 34 22 79 Not used.

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 22 86	 (01=Capt, 02=F/0) slip indicator not centered. Adjust the EADI inclinometer (AMM 34-22-00/201).
34 22 87	 (01=Capt, 02=F/0, 3=Capt & F/0) HSI and (opposite side, both) RDMI failed to indicate change to true heading when (above 73°N, below 60°S). System normal with HDG REF SW in TRUE. Replace the applicable IRU, M159 (left), M160 (center) or M161 (right) (AMM 34-21-01/401).
34 22 88	 (O1=Capt, O2=F/O, O3=Capt and F/O) HSI and (opposite side, both) RDMI failed to indicate change to true heading with HDG REF SW in TRUE. Examine and repair or replace the HDG REF SW and related circuits (WDM 34-61-24).
34 22 89	 Selecting (01=Capt., 02=F/O) ALTN EFI not norm. (Describe). Examine and repair the applicable ALTN EFI switch and related circuits (WDM 34-22-17, WDM 34-22-27).
	NOTE: If there is an intermittent delay when you push the ALTN EFI switch, replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).
34 22 90	1. DH flag displayed on the (01=Capt, 02=F/0) EADI. 2. FIM 34-22-00/101, Fig. 108, Block 1
34 22 91	 Selecting (01=Capt., 02=F/O) ALTN FMC not norm. (Describe). Examine and repair the applicable ALTN FMC switch and related circuits (WDM 34-22-17, WDM 34-22-27).

	FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34	22 92	 (01=Capt., 02=F/0) EADI and EHSI are blank with SG FAIL message displayed in both indicators. Selecting ALTN EFI corrects fault. FIM 34-22-00/101, Fig. 108, Block 1. If the problem continues, replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).
34	22 93	 Selecting (01=Capt, 02=F/0) ALTN IRS not norm. Examine and repair the applicable ALTN IRS switch and related circuits (WDM 34-22-17, WDM 34-22-27)
34	22 94	 (01=Capt, 02=F/0) EADI and EHSI displays intermittent. Displays normal on ALTN EFI. Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401). If the problem continues, examine and repair the circuit between the integrated drive generator G19, terminal N and ground (WDM 24-21-11, WDM 24-21-21).
34	22 95	 (01=Capt, 02=F/0) EADI and EHSI displays intermittent. Condition same on ALTN EFI. FIM 34-22-00/101, Fig. 108, Block 1
34	23 01 00	 Standby compass light inoperative. Replace the bulb.
34	23 02 00	 Standby compass heading incorrect. Reads, should read Do the standby compass calibration procedure (AMM 34-23-00/201).

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 24 01 00	 Standby attitude indicator lights inoperative. Replace the standby attitude indicator, M20(AMM 34-24-01/201)
34 24 02 00	 Standby attitude indicator attitude display abnormal (pitch, roll, etc.) and GYRO flag is out of view. FIM 34-24-00/101, Fig. 103, Block 1
34 24 03 00	 Standby attitude indicator GYRO flag is in view. FIM 34-24-00/101, Fig. 103, Block 1
34 24 04 00	Not used.
34 24 05 00	 Selection of ILS OFF does not retract ILS pointers. FIM 34-31-00/101, Fig. 103, Block 1
34 25 01 00	 COMPARATOR BITE message is displayed on EICAS. FIM 34-22-00/101, Fig. 109, Block 1
34 31 01	 ILS test response abnormal on (01=Capt EADI & EHSI, 02=F/0 EADI & EHSI, 03=STBY ATT IND). Identify those test indications which were abnormal. FIM 34-31-00/101, Fig. 104, Block 1
34 31 02	34 31 02 thru 34 31 31
34 31 32	 Not used. 1. (L, R, C) ILS ident not received at (04=Capt, 05=F/0, 06=1st 0bs) crew position. Deviation pointer display normal. 2. Replace the applicable audio selector panel, M70 (captain), M71 (F/0) or M98 (1st obs) (AMM 23-51-01/401).
34 31 33	 (01=L, 02=R, 03=C) ILS ident not received at any crew position. Deviation pointer normal. Replace the applicable ILS receiver, M156 (left), M157 (center) or M158 (right) (AMM 34-31-01/401).

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 31 34	 G/S flag in view on the (04=Capt, 05=F/O) EADI & EHSI. Replace the applicable ILS receiver, M156 (left) or M158 (right) (AMM 34-31-01/401).
34 31 35	 LOC flag in view on the (04=Capt, 05=F/O) EADI and EHSI. Replace the applicable ILS receiver, M156 (left) or M158 (right) (AMM 34-31-01/401).
34 31 36	 G/S and LOC flags in view on the (04=Capt, 05=F/O) EADI and EHSI. FIM 34-31-00/101, Fig. 105, Block 1
34 31 37	 Loc pointer or COURSE indicator not displayed on the (04=Capt, 05=F/0) EADI & EHSI. ILS ident not received. FIM 34-31-00/101, Fig. 110, Block 1
34 31 38	 G/S pointer not displayed on the (04=Capt, 05=F/O) EADI & EHSI. FIM 34-31-00/101, Fig. 111, Block 1
34 31 39	 G/S & Loc pointers or COURSE indicator not displayed on the (04=Capt, 05=F/O) EADI and EHSI. ILS ident not received. Replace the ILS control panel, M87 (AMM 34-31-02/401).
34 31 40 07	 G/S and LOC pointers not displayed on Capt or F/O's EADI and EHSI. Replace the ILS control panel, M87 (AMM 34-31-02/401).
34 31 41	 The deviation scales and COURSE bar(s) are missing on (04=Capt's, 05=F/0's, 07=Capt & F/0) EADI's. The pointers are not displayed on the corresponding EHSI. ILS ident received. Replace the ILS control panel, M87 (AMM 34-31-02/401).
34 31 42	 The deviation scales and COURSE bar(s) are missing on (04=Capt, 05=F/0, 07=Capt & F/0) EADI. The pointers are not displayed on the corresponding HSI. ILS ident not received. Replace the ILS control panel, M87 (AMM 34-31-02/401).
34 31 43	 (04=CAPT, 05=F/0) EADI and EHSI LOC pointer and COURSE indicator (Intermittent has reverse HDG, etc). Replace the ILS control panel, M87 (AMM 34-31-02/401).
34 31 44	 (01=L, 02=R, 03=C) ILS reception is weak. Replace the applicable ILS receiver, M156 (left), M158 (center) or M157 (right) (AMM 34-31-01/401).

CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 31 45	 LOC pointer or COURSE ind not displayed on the (04=Capt, 05=F/0) EADI and EHSI. Displays were norm with ALTN EFI selected. FIM 34-31-00/101, Fig. 103, Block 1
34 31 46	Not used.
34 31 47	 ILS frequency displayed on the (01=Capt, 02=F/0) EHSI disagrees with the frequency indicator. HSI reads Control reads Replace the ILS control panel, M87 (AMM 34-31-02/401).
34 31 48	 Selected course pointer display on the (01=Capt, 02=F/0) EHSI disagrees with the course indicator. Replace the ILS control panel, M87 (AMM 34-31-02/401).
34 31 49 00	 F. CRS indicator does not respond to selector movement. Replace the ILS control panel, M87 (AMM 34-31-02/401).
34 31 50 00	 ILS FREQ indicator does not respond to selector movement. Replace the ILS control panel, M87 (AMM 34-31-02/401).
34 31 51 00	 G/S flag in view in the standby attitude indicator. FIM 34-31-00/101, Fig. 107, Block 1
34 31 52 00	1. LOC flag in view in the standby attitude indicator. 2. FIM 34-31-00/101, Fig. 107, Block 1
34 31 53 00	1. G/S & LOC flags in view in the standby attitude indicator. 2. FIM 34-31-00/101, Fig. 107, Block 1
34 31 54 00	 Localizer deviation pointer not displayed in the standby attitude indicator. ILS ident not received on center receiver. Replace the right/center dual localizer antenna, M249 (AMM 34-31-04/401).
34 31 55 00	 Glideslope deviation pointer never displayed in the standby attitude indicator. FIM 34-31-00/101, Fig. 109, Block 1
34 31 56 00	 Neither G/S nor LOC pointers displayed in the standby attitude indicator. FIM 34-31-00/101, Fig. 108, Block 1

34-FAULT CODE INDEX

ALL

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 31 57 00	 The (glideslope, localizer) deviation pointer of the standby attitude indicator (fluctuates, sticks, etc). Replace the standby attitude indicator, M20 (AMM 34-24-01/201).
34 31 58 00	 ILS front CRS indicator has missing segment. Replace the ILS control panel, M87 (AMM 34-31-02/401).
34 31 59 00	 ILS FREQ. indicator has missing segment. Replace the ILS control panel, M87 (AMM 34-31-02/401).
34 31 60 00	 G/S has (false, late) capture. FIM 34-31-00/101, FIG. 111A, Block 1.
34 32 01 00	34 32 01 00 thru 34 32 03 00 Not used.
34 32 04 00	 Both MIDDLE marker lights fail to illuminate. FIM 34-32-00/101, Fig. 103, Block 1
34 32 05 00	 Both OUTER marker lights fail to illuminate. FIM 34-32-00/101, Fig. 103, Block 1
34 32 06 00	 All marker beacon lights fail to illuminate. Ident received. FIM 34-32-00/101, Fig. 103, Block 1
34 32 07 00	 All marker beacon lights fail to illuminate. Ident not received. FIM 34-32-00/101, Fig. 103, Block 1
34 32 08	 Marker beacon ident not received at (01=Capt, 02=F/0, 03=1st 0bs) station. All other crew stations OK. Marker lgts OK. Replace the applicable audio selector panel, M70 (captain), M71 (F/0) or M98 (1st observer) (AMM 23-51-01/401).
34 32 09 00	 Marker beacon ident not received at any crew station. Marker lights are OK. FIM 34-32-00/101, Fig. 103, Block 1
34 32 10 00	 Both INNER/AIRWAYS marker lights fail to illuminate. FIM 34-32-00/101, Fig. 103, Block 1

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 32 11 00	 All marker beacon lgts illum intermittently. Ident not received. FIM 34-32-00/101, Fig. 103, Block 1
34 33 01	 (01=Capt, 02=F/0) Decision height reference indicator does not respond to selector movement. Replace the applicable EFIS control panel, M94 (left), or M93 (right) (AMM 34-22-02/201).
34 33 02	 (01=Capt, 02=F/0) DH reset SW does not reset decision height on the display. Operation normal with ALTN EFI selected. Replace the applicable EFIS control panel, M94 (left), or M93 (right) (AMM 34-22-02/201).
34 33 03	 (01=Capt, 02=F/0) DH reset SW does not reset decision height on the display. Condition remains the same with ALTN EFI selected. Replace the applicable EFIS control panel, M94 (left), or M93 (right) (AMM 34-22-02/201).
34 33 04	Not used.
34 33 05	Not used.
34 33 06	 Decision height alert altitude on (01=Capt, 02=F/0) EADI disagrees with decision height reference indicator. Operation normal with alternate EFI selected. Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401, EFIS).
34 33 07	 Decision height alert altitude on (01=Capt, 02=F/0) EADI disagrees with decision height reference indicator. Condition remains the same with alternate EFI selected. Replace the applicable EFIS control panel, M94 (left) or M93 (right) (AMM 34-22-02/201).
34 33 08	 Rad alt on the (O1=Capt, O2=F/O) EADI is blank below 2500 feet AGL. Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 33 09	 (Selected decision height not displayed, "DH" not displayed, display color incorrect, etc) on (01=Capt, 02=F/0) EADI for radio alt between DH and 999 ft. Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).
34 33 10	 Display did not (flash/change color, etc) on (01=Capt, 02=F/0) EADI at decision height. Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).
34 33 11	 Radio altitude height on the (01=Capt, 02=F/0) EADI is inaccurate. (State amount of inaccuracy, if known.) FIM 34-33-00/101, Fig. 103, Block 1
34 33 12	 Decision height display on the (O1=Capt, O2=F/O) ADI did not reset (automatically, etc). Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).
34 33 13	 RA flag displayed (steady, intermittent) on the (01=Capt, 02=F/0) EADI. FIM 34-33-00/101, Fig. 104, Block 1
34 33 14	34 33 14 thru 34 33 25
34 33 22	 Not used. 1. Radio alt display incorrect on (O1=Capt, O2=F/O) EADI for rad alt above 999 ft. (Describe problem). 2. Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).
34 33 23	 Radio alt display on (01=Capt, 02=F/0) EADI did not change at 999 ft. Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).
34 33 24 00	 DH alert tone sounded 1 beep at DH +50. Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 33 25	 Radio alt display on (01=Capt, 02=F/0) EADI incorrect for rad alt below 999 ft. (Describe problem). Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).
34 33 26	 (01=Capt, 02=F/O) radio alt intermittent on the EADI. Cond normal with ALTN EFI selected. Replace the applicable EFIS symbol generator, M148 (left) or M150 (right) (AMM 34-22-01/401).
34 33 27	 (01=Capt, 02=F/0) radio alt intermittent on the EADI. Cond same with ALTN EFI selected. FIM 34-33-00/101, Fig. 103, Block
34 43 01	 WXR FAIL displayed on HSI with (01= L, 02= R, 05= B0TH) system(s) selected. WXR test displays WXR FAIL WEAK on HSI. FIM 34-43-00/101, Fig. 103, Block 1
34 43 02	 WXR FAIL displayed on HSI with (01= L, 02= R, 05=B0TH) system(s) selected. WXR test displays WXR FAIL STAB on HSI. FIM 34-43-00/101, Fig. 103, Block 1
34 43 03	 WXR FAIL displayed on HSI with (01= L, 02= R) system selected. WXR test not attempted. FIM 34-43-00/101, Fig. 103, Block 1
34 43 04 00	Not used.
34 43 05	 WXR FAIL displayed on HSIs with (01=L, 02=R) system selected. WXR test displays WXR FAIL RT on HSI. FIM 34-43-00/101, Fig. 103, Block 1
34 43 06	 WXR FAIL displayed on HSI with (O1=L, O2=R, O5=Both) system(s) selected. WXR test displays WXR FAIL ANT on HSI. FIM 34-43-00/101, Fig. 103, Block 1
34 43 07	 WXR FAIL displayed on HSI with (01= L, 02= R, 05=B0TH) system(s) selected. WXR test displays WXR FAIL CONT on HSI. FIM 34-43-00/101, Fig. 103, Block 1

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 43 08	 WXR RANGE DISAGREE displayed on (03=CAPT, 04=F/0, 05=B0TH) HSI(s). FIM 34-43-00/101, Fig. 103, Block 1
34 43 09	 WXR/MAP RANGE DISAGREE displayed on (03=CAPT, 04=F/0, 05=B0TH) HSI(s). Replace the applicable EFIS control panel, M94 (captain) or M93 (F/0) (AMM 34-22-02/201).
34 43 10	 WXR DSPY displayed on (03=CAPT, 04=F/0, 05=B0TH) HSI(s). FIM 34-22-00/101, Fig. 106, Block 1 (EFIS).
34 43 11	 (03=CAPT, 04=F/0, 05=B0TH) weather radar switch does not (activate, deactivate) radar. FIM 34-43-00/101, Fig. 103, Block 1
34 43 12 00	 WXR ON switch does not (activate, deactivate) radar with either system selected. Examine and repair the circuit from the captain's EFIS control panel M94, connector D469, pins 14 and 16; F/O's EFIS control panel M93, connector D471, pins 14 and 16; to the WXR control panel M75, connectors D395, pin G and D495, pin G (WDM 34-43-11, WDM 34-43-12, WDM 34-43-21, WDM 34-43-22).
34 43 13	 Antenna tilt (describe Fault: inoperative, etc) with (01=L, 02=R, 03=Both) system(s) selected. FIM 34-43-00/101, Fig. 103, Block 1
34 43 14 00	 Antenna tilt operation is (Describe fault; inop, etc.) with either system selected. Replace the weather radar control panel, M75 (AMM 34-43-02/401).
34 43 15 00	Not used.
34 43 16 00	Not used.
34 43 17	 WX radar mode switch (describe fault: inoperative, etc.) with (01=L, 02=R, 03=Both) system(s) selected. FIM 34-43-00/101, Fig. 103, Block 1

FAULT	1. LOG BOOK REPORT
CODE	2. FAULT ISOLATION REFERENCE
34 43 18 00	 WXR mode switch (describe fault: INOP, etc) with either system selected.
	2. Replace the weather radar control panel, M75
	(AMM 34-43-02/401).
34 43 19	1. WXR gain control inoperative in mode with
	(01=L, 02=R, 03=Both) system(s) selected. 2. FIM 34-43-00/101, Fig. 103, Block 1
	, ,
34 43 20 00	 GAIN control (describe fault: INOP, etc) with either system selected.
	2. Replace the weather radar control panel, M75
	(AMM 34-43-02/401).
34 43 21	1. WXR ATT displayed on EHSI with (O1=SYS L, O2=SYS R) selected.
	WXR test displays WXR FAIL ATT. 2. FIM 34-43-00/101, Fig. 103, Block 1
34 43 22	34 43 22 thru 34 43 35 Not used.
34 43 25 00	 WXR indicator range control (Describe fault: inop, etc).
	2. FIM 34-43-00/101, Fig. 103, Block 1
34 43 26 00	1. WXR indicator brightness control (describe fault: inop, etc).
	2. FIM 34-43-00/101, Fig. 103, Block 1
34 43 36 00	1. Weather radar system select switch (describe fault: INOP,
	etc). 2. Replace the weather radar control panel, M75
	(AMM 34-43-02/401). If the problem continues, replace the RF
	relay (switch) assembly, S36 (WDM 34-43-22).
34 43 37 00	Not used.
34 43 38 00	1. Fault msg COOL displayed on WXR indicator.
	2. FIM 34-43-00/101, Fig. 103, Block 5

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 43 39	 WXR FAIL displayed on HSI with (01= L, 02= R) system selected. WXR test inoperative. Replace the weather radar control panel, M75 (AMM 34-43-02/401).
34 43 40 00	34 43 40 00 thru 34 43 44 00 Not used.
34 43 46 00	 WXR FAIL displayed on EHSI with either system selected. WXR test INOP on both systems. Replace the weather radar control panel, M75 (AMM 34-43-02/401).
34 43 47	 Spoking present on HSI WXR display with (01= L, 02= R, 03=B0TH) system(s) selected. FIM 34-43-00/101, Fig. 103, Block 1
34 43 48 00	 Spoking present on EHSI WXR display with either system selected. FIM 34-22-00/101, Fig. 106, Block 1
34 43 49	 Sweep (describe fault: missing, sticks, etc) on HSI WXR display with (01= L, 02= R, 03=B0TH) system(s) selected. FIM 34-43-00/101, Fig. 103, Block 1
34 43 50 00	 Sweep (describe fault: missing, sticks, etc) on EHSI WXR display with either system selected. FIM 34-22-00/101, Fig. 106, Block 1
34 43 51	 Returns (describe fault: fixed, noisy, false, etc) on HSI WXR display with (01= L, 02= R, 03=B0TH) system(s) selected. FIM 34-43-00/101, Fig. 103, Block 1
34 43 52 00	 Returns (describe fault: fixed, noisy, false, etc) on EHSI WXR display with either system selected. FIM 34-22-00/101, Fig. 106, Block 1
34 43 53	 Precip intensity too (strong, weak) on HSI WXR display with (01= L, 02= R, 03=B0TH) system(s) selected. FIM 34-43-00/101, Fig. 103, Block 1
34 43 54 00	 Precip intensity too (strong, weak) on EHSI WXR display with either system selected. FIM 34-22-00/101, Fig. 106, Block 1

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 43 55	 WXR display on HSI is missing with (01= L, 02= R,03=B0TH) system(s) selected. FIM 34-22-00/101, Fig. 106, Block 1
34 43 56 00	 WXR display on EHSI is missing with either system selected. FIM 34-43-00/101, Fig. 103, Block 1
34 43 57 00 34 43 65	34 43 57 00 thru 34 43 64 00 Not used. 1. (01=L, 02=R) WXR system failed to test. WXR TEST did not display on HSI. 2. FIM 34-43-00/101, Fig. 103, Block 1
34 43 66	 WXR FAIL displayed on HSI with (01=L, 02=R, 05=both) system(s) selected. WXR test displays WXR FAIL ATT on HSI. FIM 34-43-00/101, Fig. 103, Block 1
34 43 67	1. WXR WEAK displayed on HSI with (01=L, 02=R) system selected. 2. FIM 34-43-00/101, Fig. 103, Block 1
34 43 71	1. WXR STAB displayed on HSI with (01=L, 02=R) system selected. 2. FIM 34-43-00/101, Fig. 103, Block 1
34 43 74	1. WXR ATT displayed on HSI with (01=L, 02=R) system selected. 2. FIM 34-43-00/101, Fig. 103, Block 1
34 43 76	 (03=Capt, 04=F/0, 05=Both) weather radar switch doesn't activate radar. WXR DSPY message is on HSI. FIM 34-43-00/101, Fig. 103, Block 1
34 43 77 00	 L or R WXR system failed to test. WXR TEST did not display on HSI. FIM 34-43-00/101, Fig. 103, Block 1
34 43 78 00	 WXR WEAK displayed on EHSI with either system selected. FIM 34-43-00/101, Fig. 103, Block 1
34 43 79 00	 WXR STAB displayed on EHSI with either system selected. FIM 34-43-00/101, Fig. 103, Block 1
34 43 80 00	 WXR ATT displayed on EHSI with either system selected. FIM 34-43-00/101, Fig. 103, Block 1
34 43 87 00	 R/T FAULT displayed on wxr indicator during test. Replace the applicable weather radar transceiver, M213 (left) or M214 (right) (AMM 34-43-01/401).

34-FAULT CODE INDEX

ALL

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 43 88 00	 ANT FAULT displayed on wxr indicator during test. Replace the applicable weather radar transceiver, M213 (left)
34 43 89 00	or M214 (right) (AMM 34-43-01/401). 1. CON FAULT displayed on wxr indicator during test.
34 43 90 00	 Replace the WXR control panel, M75 (AMM 34-43-02/401). ATT FAULT displayed on wxr indicator during test. Replace the applicable weather radar transceiver, M213 (left)
34 43 91 00	or M214 (right) (AMM 34-43-01/401). 1. IND FAULT displayed on wxr indicator during test.
34 43 92 00	 Replace the weather radar indicator, N110 (AMM 34-43-06/201). COOL FAULT displayed on wxr indicator during test. FIM 34-22-00/101.
34 45 07	1. (01=Capt, 02=F/0) resolution advisories abnormal. 2. FIM 34-45-00/101, Fig. 103, Block 1
34 45 08	 (01=Capt, 02=F/0) TA FAIL displayed. FIM 34-45-00/101, Fig. 103, Block 1
34 45 09	1. (01=Capt, 02=F/0) RA FAIL displayed. 2. FIM 34-45-00/101, Fig. 103, Block 1
34 46 01 00	34 46 01 00 thru 34 46 20 00
34 46 21 00	Not used. 1. GND PROX BITE status message displayed on EICAS. 2. FIM 34-46-00/101, Fig. 103, Block 1
34 46 22 00	 The (PULL UP, GND PROX, WINDSHEAR) light did not illuminate when (specify alert condition) existed. FIM 34-46-00/101, Fig. 104, Block 1
34 46 23 00	 The aural message for (specify alert condition) was not announced. FIM 34-46-00/101, Fig. 104, Block 1
34 46 24 00	 A GND PROX alert was received with no alert condition (state sink rate, radio altitude, landing or ascending, gear and flap state if known). FIM 34-46-00/101, Fig. 103, Block 1
34 46 25 00	 A PULL UP alert was received with no alert condition (state sink rate, radio altitude, landing or ascending, gear and flap state, if known). Radio Altimeter indication was normal. FIM 34-46-00/101, Fig. 103, Block 1

	FAULT CODE	LOG BOOK REPORT FAULT ISOLATION REFERENCE
34	46 26 00	A WINDSHEAR alert was received with no alert condition. If the windshear light stays on, examine and repair the circuit from the GPWC M147, connector D4358, pin A12 to the windshear light L890, pin 2. If the light does not stay on, the alert was a nuisance indication.
34	46 27 00	GND PROX BITE was not displayed on EICAS status page during GND PROX test. FIM 34-46-00/101, Fig. 104, Block 1
34	46 28 00	PULL UP light did not illuminate during GND PROX test. FIM 34-46-00/101, Fig. 104, Block 1
34	46 29 00	GND PROX light did not illuminate during GND PROX test. FIM 34-46-00/101, Fig. 104, Block 1
34	46 30 00	The (sink rate, whoop-whoop pull up, terrain, don't sink, too low gear, too low flaps, too low terrain, glideslope, minimum windshear) aural message(s) was not announced during test. (State whether test switch was momentarily positioned to GND PROX or held there for more than 5 seconds.) FIM 34-46-00/101, Fig. 104, Block 1
34	46 31 00	The ground proximity warning system failed to test. FIM 34-46-00/101, Fig. 103, Block 1
34	46 32 00	The GND PROX/CONFIG GEAR OVRD SW didn't inhibit (TOO LOW TERRAIN, TOO LOW GEAR) ground prox alert. FIM 34-46-00/101, Fig. 103, Block 1. If the problem continues, examine the circuit from the terminal block TB119, pin G17, through the GND PROX/CONFIG GEAR OVRD switch, S604, to ground (WDM 34-46-12).
34	46 33 00	The GND PROX FLAP OVRD SW did not inhibit (TOO LOW TERRAIN, TOO LOW FLAP) ground prox alert. FIM 34-46-00/101, Fig. 103, Block 1 If the problem continues, examine the circuit from the terminal block TB119, pin G19, through the GND PROX/CONFIG GEAR OVRD switch, S604, to ground (WDM 34-46-12).
34	46 34 00	The G/S INHB sw did not inhibit G/S alert. FIM 34-46-00/101, Fig. 103, Block 1

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 46 35 00 34 46 37 00	 34 46 35 00 thru 34 46 36 00 Not used. 1. EICAS msg GND PROX BITE displayed (Ref Chapter 31 for Fault Code Diagram). 2. FIM 34-46-00/101, Fig. 103, Block 1
34 46 38 00	 A (GND PROX, PULL UP) alert was not received when (specify alert condition) existed. FIM 34-46-00/101, Fig. 103, Block 1
34 46 39 00	 WINDSHEAR lgt did not illum or ADI msg display during gnd prox test. FIM 34-46-00/101, Fig. 104, Block 1
34 46 40 00	 Voice altitude callouts too loud. FIM 34-46-00/101, Fig. 104, Block 1
34 51 01 34 51 21	 34 51 01 thru 34 51 20 Not used. 1. (03=L, 04=R) VOR course indicator on glareshield does not respond properly to selector operation. 2. Replace the applicable VOR control panel, M91 (left) or M92 (right) (AMM 34-51-02/201).
34 51 22	 (03=L, 04=R) VOR FREQ display does not respond properly to selector operation. FIM 34-51-00/101, Fig. 108, Block 1
34 51 23	 (01=Capt, 02=F/0) EHSI has VOR flag in view. RDMI VOR bearing needles are normal. FIM 34-51-00/101, Fig. 106, Block 1
34 51 24	 (01=Capt, 02=F/0) EHSI has course pointer, line and dev bar missing. RDMI VOR bearing needles are normal. Replace the applicable VOR control panel, M91 (left) or M92 (right) (AMM 34-51-02/201).

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 51 25	 Unable to select (L, R) VOR with VOR/ADF selector on (O1=Capt, O2=F/O) RDMI. Replace the applicable RDMI, N3 (left) or N43 (right) (AMM 34-22-05/401).
34 51 26	 (L, R) Brg flag in view on (01=Capt, 02=F/0) RDMI. The associated HSI VOR indications are normal. HSI is in VOR mode. Replace the applicable RDMI, N3 (left) or N43 (right) (AMM 34-22-05/401).
34 51 27	 (03=L, 04=R) Brg flag in view on both RDMI's. The associated EHSI has VOR flag in view when the EHSI is in VOR mode. FIM 34-51-00/101, Fig. 107, Block 1
34 51 28	 (03=L, 04=R) Brg flag in view on both RDMI's. The associated EHSI has the lateral dev bar missing when the EHSI is in VOR mode. The freq display on the VOR is normal. FIM 34-51-00/101, Fig. 109, Block 1
34 51 29	 (03=L, 04=R) Brg flag in view on both RDMI's. The associated EHSI has the lateral dev bar missing when the EHSI is in VOR mode. The freq display on the VOR is inop. FIM 34-51-00/101, Fig. 104, Block 1
34 51 30	 (03=L, 04=R) Brg flag in view on both RDMI's. The associated EHSI has course pointer, line and dev bar missing. Replace the applicable VOR control panel, M91 (left) or M92 (right) (AMM 34-51-02/201).
34 51 31	 VOR radial not displayed on (O1=Capt, O2=F/O, O5=Both) EHSI's with EHSI in map and manual turning selected. Replace the applicable VOR control panel, M91 (left) or M92 (right) (AMM 34-51-O2/201).
34 51 32	 (01=Capt, 02=F/0) VOR AUTO/MAN select sw (stuck in (Auto,Man) position, will not stay in, etc). Replace the applicable VOR control panel, M91 (left) or M92 (right) (AMM 34-51-02/201).
34 51 33	 (03=L, 04=R, 05=Both) Brg flags in view on both RDMI's with EHSI's in MAP. VOR's are normal with HSI's in VOR mode. FIM 34-51-00/101, Fig. 105, Block 1

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 51 34	 (L, R) VOR ident not received at (01=Capt, 02=F/0, 03=1st Obs) station. Other crew stations OK. Replace the applicable audio selector panel, M70 (captain), M71 (F/O) or M98 (1st observer) (AMM 23-51-01/401).
34 51 35	 (04=L, 05=R) VOR ident not received at any crew station. Replace the applicable VOR receiver, M186 (left) or M187 (right) (AMM 34-51-01/401).
34 51 36	 (L, R) VOR bearing points on (01=Capt, 02=F/0) RDMI (describe fault, sticks, inop, etc.) Replace the applicable RDMI, N3 (left) or N43 (right) (AMM 34-22-05/401).
34 51 37	 (01=Capt, 02=F/0) VOR Auto/Man select sw light (inop, always dim, etc). Replace the applicable VOR Auto/Man select switch lamps (AMM 34-51-02/201). If the problem continues, replace the applicable VOR control panel, M91 (left) or M92 (right) (AMM 34-51-02/201).
34 51 38	34 51 38 thru 34 51 39
34 51 40	Not used. 1. (03=L, 04=R, 05=Both) VOR(S) will not autotune. 2. Replace the applicable VOR control panel, M91 (left) or M92 (right) (AMM 34-51-02/201).
34 51 41	 (03=L, 04=R) VOR CRS indicator on glareshield has missing segment. Replace the applicable VOR control panel, M91 (left) or M92 (right) (AMM 34-51-02/201).
34 51 42	 (03=L, 04=R) VOR FREQ indicator on glareshield has missing segment. Replace the applicable VOR control panel, M91 (left) or M92 (right) (AMM 34-51-02/201).
34 53 01 00	 ATC code indicator does not respond to selector movement. Replace the dual ATC control panel, M81 (AMM 34-53-02/401).
34 53 02	 ATC altitude reporting inop with the (01=L, 02=R, 03=either L or R) transponder selected. FIM 34-53-00/101, Fig. 104, Block 1.

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 53 03	 ATC transmission (weak, intermittent, etc) with the (01=L, 02=R, 03=either L or R) transponder selected. FIM 34-53-00/101, Fig. 105, Block 1.
34 53 04	 Reported no ATC transmission with the (O1=L, O2=R, O3=either L or R) transponder selected. FIM 34-53-00/101, Fig. 105, Block 1.
34 53 05 00	 Reported no ATC transmission with either transponder selected. Replace the dual ATC control panel, M81 (AMM 34-53-02/401).
34 53 06 00	 Reported transmitted code disagrees with the ATC code indicator with either transponder selected. Replace the dual ATC control panel, M81 (AMM 34-53-02/401).
34 53 07	 EICAS msg ATC FAULT displayed and ATC FAIL light illuminated (steady, intermittent) with the (01=L, 02=R, 03=either L or R) transponder selected. Transponder reported inop. FIM 34-53-00/101, Fig. 103, Block 1
34 53 07	 EICAS msg ATC FAULT displayed and (ATC FAIL, XPDR FAULT light illuminated) with the (O1=L or 1, O2=R or 2, O3=both L and R) transponder selected. Transponder reported inop. FIM 34-53-00/101, Fig. 103, Block 1
34 53 08	 ATC identification inop with (01=L, 02=R, 03=either L or R) transponder selected. Replace the dual ATC control panel, M81 (AMM 34-53-02/401).
34 53 09	 EICAS msg ATC FAULT displayed and ATC FAULT lgt illuminated with (01=L, 02=R, 03=either L or R) transponder selected. Transponder reported normal. FIM 34-53-00/101, Fig. 103
34 53 10 00	 ATC code indicator has missing segment. Replace the dual ATC control panel, M81 (AMM 34-53-02/401).
34 53 11	 (01=L, 02=R) ATC code indicator is blank and was reported as inop. Replace the dual ATC control panel, M81 (AMM 34-53-02/401).
34 55 01	34 55 01 thru 34 55 10 Not used.

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 55 11	 DME ident not received on the (03=L, 04=R) receiver. The corresponding DME displays are normal. (VOR, ILS) ident is also normal. FIM 34-55-00/101, Fig. 109, Block 1
34 55 12	 (01=Capt, 02=F/0) (L, R) RDMI DME display is blank. The EHSI DME display is 0K. Replace the applicable RDMI, N3 (left) or N43 (right) (AMM 34-22-05/401).
34 55 13	 (01=Capt, 02=F/0) (L, R) EHSI DME display is blank. The RDMI DME display is OK. FIM 34-55-00/101, Fig. 106, Block 1.
34 55 14	 The RDMI and EHSI DME displays are blank for the (03=L, 04=R) DME. FIM 34-55-00/101, Fig. 107, Block 1
34 55 15	 The RDMI and EHSI DME displays are dashes for the (03=L, 04=R) DME. VOR ident is OK. FIM 34-55-00/101, Fig. 104, Block 1
34 55 16	 The RDMI and EHSI DME displays are dashes for the (03=L, 04=R) DME. ILS ident received. A usable DME signal is present. FIM 34-55-00/101, Fig. 105, Block 1
34 55 17	 The RDMI and EHSI DME displays are dashes for the (03=L, 04=R) DME. (ILS, VOR) ident not received. A usable DME signal is present. FIM 34-55-00/101, Fig. 103, Block 1
34 55 18	 The RDMI DME display for the (03=L, 04=R, 05=Both) DME(s) is dashes with the EHSI in MAP or PLAN mode. FIM 34-55-00/101, Fig. 108, Block 1
34 55 19	 The RDMI and EHSI DME distance is incorrect on the (01=Capt, 02=F/0) side with the HSI in the ILS mode. FIM 34-55-00/101, Fig. 103, Block 1
34 55 20	 (01=Capt, O2=F/O) (L,R) RDMI DME has missing (number segment). Replace the applicable RDMI, N3 (left) or N43 (right) (AMM 34-22-05/401).

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 57 01	 Unable to select ADF with the (L, R) RDMI ADF/VOR selector on the (O1=Capt, O2=F/O) RMDI. Warning flags are retracted. VOR operation normal. Replace the applicable RDMI, N3 (left) or N43 (right) (AMM 34-22-05/401).
34 57 02 00	Not used.
34 57 03	 ADF tone SW inoperative in (03=L, 04=R) position. FIM 34-57-00/101, Fig. 103, Block 1
34 57 04	Not used.
34 57 05	 (03=L, 04=R) ADF frequency indicator does not respond properly to selector operation. (Identify digits) Replace the ADF control panel, M1046 (AMM 34-57-02/401).
34 57 06	 ADF audio (describe fault) at either station using (04=L, 05=R) receiver with mode selector positioned to ADF. RDMI bearing pointer operation normal. FIM 34-57-00/101, Fig. 103, Block 1
34 57 07	 During ADF operation, (L, R) bearing pointer failure flag in view in the (O1=Capt, O2=F/O) RDMI with mode selector positioned to ADF. Operation of the other RDMI is normal. Identification signal reception also normal. Replace the applicable RDMI, N3 (left) or N43 (right) (AMM 34-22-05/401).
34 57 08	 During ADF operation both (04=L, 05=R) bearing pointer failure flags continuously in view with mode selector positioned to ADF. FIM 34-57-00/101, Fig. 104, Block 1
34 57 09	 ADF audio (describe fault) at either crew station using (04=L, 05=R) receiver with mode selector positioned to ANT. RDMI bearing pointer operation normal. FIM 34-57-00/101, Fig. 103, Block 1
34 57 10	 During ADF operation, (L, R) bearing pointer failure flag retracted in the (01=Capt, 02=F/0) RDMI with mode selector positioned to ANT. Operation of the other RDMI is normal. Identification signal reception also normal. Replace the applicable RDMI, N3 (left) or N43 (right) (AMM 34-22-05/401).

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 57 11	 During ADF operation both (04=L, 05=R) bearing pointer failure flags retracted with mode selector positioned to ANT. Identification signal reception normal. Replace the ADF control panel, M85 (AMM 34-57-02/401).
34 57 12	 (L, R) ADF audio (describe fault) at (01=Capt, 02=F/0, 03-1st 0bs) crew station with mode selector positioned to ADF. FIM 34-57-00/101, Fig. 103, Block 1
34 57 13	 (L, R) ADF audio (describe fault) at (01=Capt, 02=F/0, 03=1st 0bs) crew station with mode selector positioned to ANT. FIM 34-57-00/101, Fig. 103, Block 1
34 57 14 00	34 57 14 00 thru 34 57 15 00
34 57 16	Not Used. 1. (03=L, 04=R) ADF frequency indicator has segment missing. 2. Replace the ADF control panel, M1046 (AMM 34-57-02/401).
34 57 17	1. (03=L, 04=R) ADF fails test. (Describe) 2. Replace the ADF control panel, M1046 (AMM 34-57-02/401).
34 57 18	 (04=L, 05=R) ADF pointer (erratic, does not point properly, inop, etc). Audio is normal. Replace the applicable RDMI, N3 (left) or N43 (right) (AMM 34-22-05/401).
34 57 19	 (04=L, 05=R) ADF pointer (erratic, does not point properly, inop, etc). Audio is (describe fault). FIM 34-57-00/101, Fig. 103, Block 1 for an audio problem. FIM 34-57-00/101, Fig. 104, Block 1 for an ADF pointer problem.
34 57 20 00	Not used.
34 57 21	 (01=Capt, 02=F/0) (wide, narrow) RDMI pointer is (inop, stuck, etc) in ADF and VOR position. Replace the applicable RDMI, N3 (left) or N43 (right) (AMM 34-22-05/401).
34 58 01 00	 The EICAS message GPS (advisory) is displayed. Replace the L MMR, M11249, and R MMR, M11250, (AMM 34-31-01/401).
34 58 02 00	 The EICAS message L GPS (advisory) is displayed.
34 58 03 00	 Replace the L MMR, M11249, (AMM 34-31-01/401). The EICAS message R GPS (advisory) is displayed. Replace the R MMR, M11250, (AMM 34-31-01/401).

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 61 01	34 61 01 thru 34 61 14 Not used.
34 61 15	 (01=Capt, 02=F/0) CDU display is (describe fault, e.g., out of focus, blinking, small, etc). Replace the applicable FMC CDU, M76 (left) or M77 (right) (AMM 34-61-02/201).
34 61 16	 (01=Capt, 02=F/0) CDU display blank. Selecting alternate FMC source did not correct the fault. Replace the applicable FMC CDU, M76 (left) or M77 (right) (AMM 34-61-02/201).
34 61 17	1. EICAS msg (03=L, 04=R) FMC FAIL displayed. 2. FIM 34-61-00/101, Fig. 108A
34 61 18	 EICAS msg (03=L 04=R) FMC FAIL displayed. Other CDU displays RESYNCING SINGLE FMC msg. FIM 34-61-00/101, Fig. 108A
34 61 19	34 61 19 thru 34 61 20 Not used.
34 61 21	 Manual brightness control is INOP on (01=Capt, 02=F/0) CDU. Replace the applicable FMC CDU, M76 (left) or M77 (right) (AMM 34-61-02/201).
34 61 22	 Automatic brightness control is INOP on (01=Capt, 02=F/0) CDU. Replace the applicable FMC CDU, M76 (left) or M77 (right) (AMM 34-61-02/201).
34 61 23	 Manual and automatic brightness control are INOP on (01=Capt, 02=F/0) CDU. Replace the applicable FMC CDU, M76 (left) or M77 (right) (AMM 34-61-02/201).
34 61 24 34 61 27	34 61 24 thru 34 61 26 Not used. 1. Nav data incorrect on (01=Capt, 02=F/0, 03=both) CDU IDENT page(s). 2. FIM 34-61-00/101, Fig. 107, Block 1

34-FAULT CODE INDEX

24

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 61 28	 (State data, e.g., drag factor, F-F factor, op program, etc) is incorrect on (01=Capt, 02=F/0, 03=both) CDU IDENT page(s). FIM 34-61-00/101, Fig. 107, Block 1
34 61 29	34 61 29 thru 34 61 31 Not used.
34 61 32	 IRS position entry from (01=Capt, 02=F/0) CDU results in REENTER IRS POS on scratch pad. Message would not clear after POS re-entered. FIM 34-61-00/101, Fig. 105, Block 1
34 61 33	34 61 33 thru 34 61 36 Not used.
34 61 37	 FMC MESSAGE on EICAS and PERF/VNAV UNAVAILABLE displayed on (01=Capt, 02=F/0, 03=Both) CDU(s) when VNAV button pressed. Data was entered in all boxes on perf init page. FIM 34-61-00/101, Fig. 104, Block 1
34 61 38	34 61 38 thru 34 61 71 Not used.
34 61 72	 BRG/DIS FR incorrect on (01=Capt, 02=F/0, 03=both) FIX INFO page(s). FIM 34-61-00/101, Fig. 105, Block 1
34 61 73	 PL/BRG/DIS incorrect on (01=Capt, 02=F/0, 03=both) FIX INFO page(s). FIM 34-61-00/101, Fig. 105, Block 1
34 61 74	 ABEAM incorrect on (01=Capt, 02=F/0, 03=both) FIX INFO page(s). FIM 34-61-00/101, Fig. 105, Block 1
34 61 75	1. DTG incorrect on (01=Capt, 02=F/0, 03=both) FIX INFO page(s). 2. FIM 34-61-00/101, Fig. 105, Block 1

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 61 76	 ETA incorrect on (01=Capt, 02=F/0, 03=both) FIX INFO page(s). FIM 34-61-00/101, Fig. 105, Block 1 NOTE: Code not applicable to FMCs with LNAV/VNAV configuration.
34 61 77	 ETA and DTG incorrect on (01=Capt, 02=F/0, 03=both) FIX INFO page(s). FIM 34-61-00/101, Fig. 105, Block 1 (*[1] go to the last page of the index)
34 61 78	 GS field blank on (01=Capt, 02=F/0, 03=Both) CDU POS REF page. Close the applicable IRU circuit breaker. Open and then close the FMC circuit breaker. If the problem continues, FIM 34-21-00/101, Fig. 107, Block 1
34 61 79	34 61 79 thru 34 61 99 Not used.
34 62 01	34 62 01 thru 34 62 11 Not used.
34 62 12	1. Wind components in error on PROGRESS page 2 on (01=Capt, 02=F/0, 03=both) CDU(s). 2. FIM 34-61-00/101, Fig. 105, Block 1
34 62 13	 FUEL USED (in error, blank) on PROGRESS page 2 on (01=Capt, 02=F/0, 03=both) CDU(s). FIM 34-61-00/101, Fig. 106, Block 1
34 62 14	 FUEL (QTY ERROR, DISAGREE)-PROG 2/2 alert message is displayed on CDU. TOTALIZER differs from CALCULATED on progress page 2 of (O1=Capt, O2=F/O, O3=both) CDU(s). FIM 34-61-00/101, Fig. 106, Block 1
34 62 15	 FMC will not enter the IRS (3) DME DME mode. PROGRESS page 2 indicates (IRS (2) DME DME, IRS (3) DME VOR, etc) on the (01=Capt, 02=F/0, 03=both) CDU(s). FIM 34-61-00/101, Fig. 105, Block 1
34 62 16	 DTG in error on PROGRESS page 1 of (01=Capt, 02=F/0, 03=both) CDU(s). FIM 34-61-00/101, Fig. 105, Block 1

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 62 17	 ETA in error on PROGRESS page 1 of (01=Capt, 02=F/0, 03=both) CDU(s). FIM 34-61-00/101, Fig. 105, Block 1
34 62 18	 Waypoint FUEL in error on PROGRESS page 1 of (01=Capt, 02=F/0, 03=Both) CDU(s). FIM 34-61-00/101, Fig. 106, Block 1 NOTE: Code not applicable to FMCs with LNAV/VNAV configuration.
34 62 19	 Wind in error on PROGRESS page 1 of (01=Capt, 02=F/0, 03=both) CDU(s). FIM 34-61-00/101, Fig. 105, Block 1
34 62 20	Not used.
34 62 21	 MSG light fails to illuminate with CDU advisory on (01=Capt, 02=F/0, 03=both) CDU(s). Replace the applicable FMC CDU, M76 (left) or M77 (right) (AMM 34-61-02/201).
34 62 22 00	 (NOT IN DATA BASE, REENTER IRS POSITION, MAX ALT FLXXX, etc) advisory message displayed when the advisory condition does not exist. Replace the applicable FMC, M134 (left) or M135 (right) (AMM 34-61-01/401).
34 62 23 00	 The following advisory condition exists and no advisory message was received (describe advisory condition). Replace the applicable FMC, M134 (left) or M135 (right) (AMM 34-61-01/401).
34 62 24	 The FMC light fails to illuminate with CDU alert on (01=Capt, 02=F/0, 03=both) CDU. FIM 34-61-00/101, Fig. 108, Block 1
34 62 25	 The FMC light and MSG light fail to illuminate with CDU alerts on (O1=Capt, O2=F/O, O3=both) CDU(s). Replace the applicable FMC, M134 (left) or M135 (right) (AMM 34-61-01/401).

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 62 26 00	 (END OF ROUTE, DISCONTINUITY, NO ACTIVE ROUTE, etc) alert messages displayed when the alert condition does not exist. Replace the applicable FMC, M134 (left) or M135 (right) (AMM 34-61-01/401).
34 62 27 00	 The following alert condition exists and no alert message was received: (describe alert condition). Replace the applicable FMC, M134 (left) or M135 (right) (AMM 34-61-01/401).
34 62 28	 VTK flag is in view on (01=Capt, 02=F/0) HSI. Selecting ALTN FMC corrects the fault. Replace the applicable FMC, M134 (left) or M135 (right) (AMM 34-61-01/401) or the applicable CDU, M76 (left) or M77 (right) (AMM 34-61-02/201).
34 62 29	Not used.
34 62 30	 Map display is offset on (01=Capt, 02=F/0) HSI. Selecting ALTN FMC corrects the fault. Replace the applicable FMC, M134 (left) or M135 (right) (AMM 34-61-01/401) or the applicable CDU, M76 (left) or M77 (right) (AMM 34-61-02/201).
34 62 31	 Map is missing on (01=Capt, 02=F/0) HSI. Selecting ALTN FMC corrects the fault. Replace the applicable FMC, M134 (left) or M135 (right) (AMM 34-61-01/401) or the applicable CDU, M76 (left) or M77 (right) (AMM 34-61-02/201).
34 62 32	 (01=Capt, 02=F/0) HSI displays MAP RANGE DISAGREE. Selecting ALTN FMC corrects the fault. FIM 34-61-00/101, Fig. 109, Block 1.
34 62 33	 (01=Capt, 02=F/0) HSI(s) display (MAP, MAP FAIL). Selecting ALTN FMC corrects the fault. Replace the applicable FMC, M134 (left) or M135 (right) (AMM 34-61-01/401) or the applicable CDU, M76 (left) or M77 (right) (AMM 34-61-02/201).
34 62 34	34 62 34 thru 34 62 37 Not used.

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 62 38	 Distance to go and ETA are missing from (O1=Capt, O2=F/O) HSI. Selecting ALTN FMC corrects the fault. Replace the applicable FMC, M134 (left) or M135 (right) (AMM 34-61-01/401) or the applicable CDU, M76 (left) or M77 (right) (AMM 34-61-02/201).
34 62 39	34 62 39 thru 34 62 42 Not used.
34 62 43	 The airplane (describe problem: EPR, speed or path in error, loses fuel weight) in VNAV DESCENT mode. Fault occurs with (01=L, 02=C, 03=R, 04=any) A/P engaged. For EPR, speed or path in error; FIM 34-61-00/101, Fig. 109A Block A.
34 62 44	3. For loses fuel weight; FIM 34-61-00/101, Fig. 106, Block 1. Not Used.
34 62 45	Not used.
34 62 46	 The airplane (describe problem: EPR, speed or path in error, loses fuel weight) in VNAV CRUISE mode. Fault occurs with (01=Left, 02=Center, 03=Right, 04=Any) A/P engaged. For EPR, speed or path in error; FIM 34-61-00/101, Fig. 109A Block A. For loses fuel weight; FIM 34-61-00/101, Fig. 106, Block 1.
34 62 47	Not used.
34 62 48	Not Used.
34 62 49	 The airplane (describe problem: EPR, speed or path in error, loses fuel weight) in VNAV CLIMB mode. Fault occurs with (01=Left, 02=Center, 03=Right, 04=Any) A/P engaged. For EPR, speed or path in error; FIM 34-61-00/101, Fig. 109A Block A. For loses fuel weight; FIM 34-61-00/101, Fig. 106, Block 1.
34 62 50	34 62 50 thru 34 62 59 Not used.

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 62 60	 VTK flag is in view on (01=Capt, 02=F/0, 03=Both) HSI(s). Selecting ALTN FMC does not correct the fault. Replace the applicable EFIS symbol generator, M148 (left), M149 (center) or M150 (right) (AMM 34-22-01/401).
34 62 61	Not used.
34 62 62	 Map display is offset on (01=Capt, 02=F/0, 03=Both) HSI(s). Selecting ALTN FMC does not correct the fault. Replace the applicable EFIS symbol generator, M148 (left), M149 (center) or M150 (right) (AMM 34-22-01/401).
34 62 63	 Map is missing on (O1=Capt, O2=F/O, O3=Both) HSI(s). Selecting ALTN FMC does not correct the fault. Replace the applicable EFIS symbol generator, M148 (left), M149 (center) or M150 (right) (AMM 34-22-01/401).
34 62 64	 (01=Capt, 02=F/0, 03=Both) HSI(s) display MAP RANGE DISAGREE. Selecting ALTN FMC does not correct the fault. FIM 34-61-00/101, Fig. 109, Block 1
34 62 65	 (01=Capt, 02=F/0, 03=Both) HSI(s) display (MAP, MAP FAIL). Selecting ALTN FMC does not correct the fault. Replace the applicable EFIS symbol generator, M148 (left), M149 (center) or M150 (right) (AMM 34-22-01/401).
34 62 66	34 62 66 thru 34 62 68
34 62 69	Not used. 1. Wind vector and speed are missing from (O1=Capt, O2=F/O, O3=Both) HSI(s). Selecting ALTN FMC does not correct the fault. 2. Replace the applicable EFIS symbol generator, M148 (left),
	M149 (center) or M150 (right) (AMM 34-22-01/401).
34 62 70	 Distance to go and ETA are missing from (O1=Capt, O2=F/O, O3=Both) HSI(s). Selecting ALTN FMC does not correct the fault. Replace the applicable EFIS symbol generator, M148 (left),
	M149 (center) or M150 (right) (AMM 34-22-01/401).
34 62 71	34 62 71 thru 34 62 74 Not used.

	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 62 75	 (Specify key) Key on (01=Capt, 02=F/0) CDU gives multiple response. Replace the applicable FMC CDU, M76 (left) or M77 (right) (AMM 34-61-02/201).
34 62 76	 (Specify key) Key on (01=Capt, 02=F/O) CDU feel is abnormal. Replace the applicable FMC CDU, M76 (left) or M77 (right) (AMM 34-61-02/201).
34 62 77	 All keys on (01=Capt, 02=F/0) CDU inop. Switching FMC source corrects the fault. Replace the applicable FMC, M134 (left) or M135 (right) (AMM 34-61-01/401).
34 62 78	 All keys on (01=Capt, 02=F/O) CDU inop on with normal and ALTN FMC selected. Replace the applicable FMC CDU, M76 (left) or M77 (right) (AMM 34-61-01/401).
34 62 79	34 62 79 thru 34 62 82
34 62 83	Not used. 1. EICAS msg (03=L, 04=R) FMC FAIL displayed. Other CDU displays SINGLE FMC OPERATION msg. 2. FIM 34-61-00/101, Fig. 108A
34 62 84 03	 Both CDUs are locked up on IDENT page. Open the L and R FMCS CMPTR circuit breakers. Stop for 15 seconds. Close the L and R FMC CMPTR circuit breakers. If the problem continues, replace the applicable FMC, M134 (left) or M135 (right) (AMM 34-61-01/401).
34 62 85	 IRS NAV ONLY alert message is displayed on (01=Capt, 02=F/0, 03=both) CDU(s). FIM 34-61-00/101, Fig. 105, Block 1
34 62 86	 (01=Capt, 02=F/0) CDU display is (describe fault, e.g., partially complete or containing garbage characters). Replace the applicable FMC CDU, M76 (left) or M77 (right) (AMM 34-61-02/201).

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 62 87	 (Record number of resyncs) resyncs experienced in (record time period) in (01=Capt, 02=F/0) CDU. Open the applicable FMCS CMPTR circuit breaker. Stop for 15 seconds. Close the applicable FMCS CMPTR circuit breaker. If the problem continues, replace the applicable FMC, M134 (left) or M135 (right) (AMM 34-61-01/401).
34 62 88	 (01=Capt, 02=F/0) CDU display blank. Selecting alternate FMC source corrects the fault. FIM 34-61-00/101, Fig. 111, Block 1
34 62 89	 (Specify key) key on (01=Capt, 02=F/0) CDU gives incorrect response. Switching FMC source corrects the fault. Replace the applicable FMC, M134 (left) or M135 (right) (AMM 34-61-01/401).
34 62 90	 (Specify key) key on (O1=Capt, O2=F/O) CDU gives incorrect response with normal and alternate FMC selected. Replace the applicable FMC CDU, M76 (left) or M77 (right) (AMM 34-61-02/201).
34 62 91	 (Specify key) on (O1=Capt, O2=F/O) CDU inop on all pages. Switching FMC source corrects the fault. Replace the applicable FMC, M134 (left) or M135 (right) (AMM 34-61-01/401).
34 62 92	 (Specify key) on (01=Capt, 02=F/0) CDU inop on all pages with normal and alternate FMC selected. Replace the applicable FMC CDU, M76 (left) or M77 (right) (AMM 34-61-02/201).
34 62 93	1. EXEC key on (01=Capt, 02=F/0, 03=Both) CDU(s) fails to illum. 2. FIM 34-61-00/101, Fig. 104, Block 1
34 62 94	 FMC resync takes longer than 30 seconds in (01=Capt, 02=F/0) CDU. Open the applicable FMCS CMPTR circuit breaker. Stop for 15 seconds. Close the applicable FMCS CMPTR circuit breaker. If the problem continues, replace the applicable FMC, M134 (left) or M135 (right) (AMM 34-61-01/401).
34 62 95	 Incorrect engine type displayed on (01=Capt, 02=F/0, 03=Both) CDU IDENT page(s). Replace the applicable FMC, M134 (left) or M135 (right) (AMM 34-61-01/401).

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 62 96 00	 FMC POS on CDU POS REF page 2/2 is in error (record error). FIM 34-21-00/101, Fig. 107, Block 1
34 62 97	 (04=L, 05=C, 06=R) IRS position on CDU POS REF page 2/2 is in error. (Record time IRS was in operation, actual and indicated latitude and longitude). Add note if IRS error was excessive for two consecutive flights. FIM 34-21-00/101, Fig. 107A, Block 1
34 62 98	 No boxes are displayed for position initialization on (01=Capt, 02=F/0, 03-Both) CDU(s). FIM 34-61-00/101, Fig. 105, Block 1
34 62 99	 The fuel weight is (incorrect, missing) from the performance initialization page on the (01=Capt, 02=F/0, 03=Both) CDU(s). FIM 34-61-00/101, Fig. 106, Block 1
34 63 01	 Tuned navaid data blank on PROGRESS page of (01=Capt, 02=F/0, 03=Both) CDU(s). FIM 34-61-00/101, Fig. 105, Block 1
34 63 02	 Tuned nav aid data constantly changing on PROGRESS page of (01=Capt, 02=F/0, 03=Both) CDU(s). FIM 34-61-00/101, Fig. 105, Block 1
34 63 03 00	 Wind vector on Capt HSI differs from F/O HSI. Selecting ALTN FMC corrects the fault. Replace the applicable FMC, M134 (left) or M135 (right) (AMM 34-61-01/401).
34 63 04 00	 Wind vector on Capt HSI differs from F/O HSI with both normal and ALTN FMC selected. Replace the applicable EFIS symbol generator, M148 (left), M149 (center) or M150 (right) (AMM 34-22-01/401).
34 63 05	 Distance to go and ETA display dashes on (01=Capt, 02=F/0, 03=Both) HSI(s). Selecting ALTN FMC corrects the fault. Replace the applicable FMC, M134 (left) or M135 (right) (AMM 34-61-01/401) or the applicable CDU, M76 (left) or M77 (right) (AMM 34-61-02/201).
34 63 06	 Distance to go and ETA display dashes on (01=Capt, 02=F/0, 03=Both) HSI(s) with normal and ALTN FMC. Replace the applicable EFIS symbol generator, M148 (left), M149 (center) or M150 (right) (AMM 34-22-01/401).

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 63 07	 LNAV remains white (armed) on ADI with (01=L, 02=C, 03=R, 04=Any) A/P engaged. FIM 34-61-00/101, Fig. 110, Block 1
34 63 08	 LNAV annunciation on ADI has a line through it with (01=L, 02=C, 03=R, 04=Any) A/P engaged. FIM 34-61-00/101, Fig. 110, Block 1
34 63 09	 Airplane (describe error in path: track, heading, transition, etc) with (01=L, 02=C, 03=R, 04-Any) A/P engaged. FIM 34-61-00/101, Fig. 110, Block 1
34 63 10	 VNAV will not engage with (01=L, 02=C, 03=R, 04=Any) A/P engaged. FIM 34-61-00/101, Fig. 110, Block 1
34 63 11	 VNAV annunciation on ADI has a line through it with (O1=L, O2=C, O3=R, O4=Any) A/P engaged. FIM 34-61-00/101, Fig. 110, Block 1
34 63 12	 FAIL is illum and screen displays FMC on (01=CAPT, 02=F/0) CDU. No FMC FAIL message is displayed on EICAS. FIM 34-61-00/101, Fig. 111, Block 1
34 63 14	 FAIL is illum and screen displays FMC on (01=Capt, 02=F/0) CDU. Selecting ALTN FMC corrects the fault. FIM 34-61-00/101, Fig. 111, Block 1
34 63 15	 FAIL is illum and screen displays FMC on (01=Capt, 02=F/0) CDU. Selecting ALTN FMC doesn't correct the fault. FIM 34-61-00/101, Fig. 111, Block 1
34 63 16	 FUEL USED and CALCULATED FUEL display blank on (01=Capt, 02=F/0, 03=Both) CDU(S). FIM 34-61-00/101, Fig. 106, Block 1
34 63 17	 Waypoint display (moves, wavers, etc.) on (01=Capt, 02=F/0, 03=Both) HSI(s). Selecting ALTN FMC does not correct fault. FIM 34-61-00/101, Fig. 111, Block 5

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 63 18	 (01=Capt, 02=F/0) Leg sequencing is incorrect in CDU. Do these steps with the CDU IDENT page shown on the CDU (AMM 34-61-00/201): Push the third line select key on the right side. Push the second line select key on the right side. Push the third line select key on the right side again. Push the second line select key on the right side again.
	<u>NOTE</u> : These steps will make the data base with the current date active.
34 63 19	 (01=Capt, 02=F/0) HSI displays leg sequencing incorrectly. Do these steps with the CDU IDENT page shown on the CDU (AMM 34-61-00/201): Push the third line select key on the right side. Push the second line select key on the right side. Push the third line select key on the right side again. Push the second line select key on the right side again.
	<u>NOTE</u> : These steps will make the data base with the current date active.
34 63 20	 Total fuel differs from (12=CAPT, 13=F/0, 14=CAPT & F/0) FMCS calculated fuel qty. Fuel qty ERROR-PROG 2/2 alert message displayed on CDU and EICAS message FMC MESSAGE displayed. Fuel flow was normal. Total fuel, FMC calculated fuel No Evidence of fuel leak. (Ref Chapter 28 fault code diagram). Do these steps with the CDU IDENT page shown on the CDU
	(AMM 34-61-00/201):
	<u>NOTE</u> : These steps will make the data base with the current date active.
	A. Push the third line select key on the right side. B. Push the second line select key on the right side. C. Push the third line select key on the right side again.

34-FAULT CODE INDEX

D. Push the second line select key on the right side again.

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
34 63 21 00	 CDU's do not drop waypoints. Do these steps with the CDU IDENT page shown on the CDU (AMM 34-61-00/201): Push the third line select key on the right side. Push the second line select key on the right side. Push the third line select key on the right side again. Push the second line select key on the right side again.
	<u>NOTE</u> : These steps will make the data base with the current date active.
34 63 22	 V1 INOP displayed on (01=Capt, 02=F/O) ADI. Make sure the V1 speed was put in at the TAKEOFF REF page on the CDU before the airplane left the gate. If the problem continues, FIM 34-61-00/101, Fig. 111, Block 1.
34 63 23	 V1, VR bug(s) (not normal, missing etc) on (01=Capt, 02=F/0, 03=both) ADI speed tape(s) with normal or ALTN EFI selected. FIM 34-61-00/101, Fig. 111, Block 1
34 63 24	 Command airspeed on (01=Capt, 02=F/0, 03=both) ADI speed tape(s) read(s) 100 Kts with VNAV selected, speed mode active. FIM 34-61-00/101, Fig. 111, Block 1
34 63 36 00	 The EICAS message UNABLE RNP displayed. This message is not a failure. This is a response to navigation processing when actual nav performance (ANP) does not meet required nav performance (RNP).
34 90 01 00	 Lightning strike occurred on the nose radome. Inspect the airplane for a lightning strike or static discharge (AMM 05-51-19/201).
34 90 02 00	 Lightning strike occurred on the nacelle(s). Inspect the airplane for a lightning strike or static discharge (AMM 05-51-19/201).
34 90 03 00	 Lightning strike occurred on the wingtip(s). Inspect the airplane for a lightning strike or static discharge (AMM 05-51-19/201).
34 90 04 00	 Lightning strike occurred on leading edge flaps. Inspect the airplane for a lightning strike or static discharge (AMM 05-51-19/201).



FAULT	1. LOG BOOK REPORT
CODE	2. FAULT ISOLATION REFERENCE

34 90 05 00

- 1. Lightning strike occurred on an unknown area.
- 2. Inspect the airplane for a lightning strike or static discharge (AMM 05-51-19/201).

EFFECTIVITY-

34-FAULT CODE INDEX



BITE Index

1. General

- A. Use this index to find the BITE procedure for the applicable LRU/System.
- B. The BITE procedure will provide the fault isolation instructions for the fault indications/LRU maintenance messages.

<u>LRU/System Name</u>	<u>Acronym</u>	FIM Reference
ACARS Management Unit		23-22
Air Data Computer	ADC	34-12
Air Data Inertial Reference Unit	ADIRU	34-26
Air Supply Control and Test Unit	ASCTU	36-20
Air Traffic Control Transponder	ATC	34-53
Airborne Vibration Monitor Signal Conditioner	AVM	77–31
Antiskid/Autobrake Control Unit	AACU	32-42
APU Fire Detection System		26-15
Automatic Direction Finder Receiver	ADF	34-57
APU Control Unit (or Electronic Control Unit)	ECU	49-11
Autopilot/Flight Director	AFDS	22-00
Auxiliary Zone Temperature Controller	AZTC	2160/21-61
Brake Temperature Monitor Unit	BTMU	32-46
Bus Power Control Unit	BPCU	24-20
Cabin Pressure Controller	CPC	21-30/21-31
Cabin Temperature Controller	СТС	21-61
Digital Flight Data Acquisition Unit	DFDAU	31-31
Distance Measuring Equipment Interrogator	DME	34-55
Duct Leak (Wing and Body)		26-18
E/E Cooling Control Card (If cards installed)		21-58
ECS Bleed Configuration Card		36-10
Electronic Control Unit	ECU	49-11
Electronic Engine Control Monitor Unit (Non-FADEC Engines)	EECM	71-EECM Message Index
Electronic Flight Instrument System	EFIS	34-22

Bite Index Figure 1 (Sheet 1)

EFFECTIVITY-

34-BITE INDEX



LRU/System Name	<u>Acronym</u>	FIM Reference
Engine Fire/Overheat Detection System		26-11
Engine Indication and Crew Alerting System Computer	EICAS	31-41
Enhanced Ground Proximity Warning Computer	EGPWC	34-46
Equipment Cooling Systen Controller		21-58
Equipment Cooling Temperature Controller		21-58
Flap/Slat Electronic Unit	FSEU	27-51
Flap/Stabilizer Position Module	FSPM	27-58
Flight Management Computer	FMC	34-61
Fuel Quantity Indicating System Processor	FQIS	28-41
Ground Proximity Warning Computer	GPWC	34-46
HF (High Frequency) Communication		23-11
In-Flight Entertainment Equipment Cooling Card		21-58
Inertial Reference Unit	IRU	34-21
Instrument Comparator Unit	ICU	34-25
Instrument Landing System Receiver	ILS	34-31
Large Format Display System	LFDS	31-63
Lower Cargo Compartment Smoke Detection System		26-16
Maintenance Control Display Panel	MCDP	22-00
Multi-Mode Receiver	MMR	34-31
PA (Passenger Address) Amplifier		23-31
Pack Standby Temperature Controller	PSTC	21-51
Pack Temperature Controller	PTC	21-51
Passenger Entertainment System	PES	23-34
Power Supply Module (Control System Electronics Units)	PSM	27-09
Propulsion Interface and Monitor Unit (FADEC Engines)	PIMU	71-PIMU Message Index
Proximity Switch Electronics Unit	PSEU	32-09

Bite Index Figure 1 (Sheet 2)

EFFECTIVITY-

34-BITE INDEX

01

ALL

Page 2 Aug 22/99



<u>LRU/System Name</u>	<u>Acronym</u>	FIM Reference
Radio Altimeter Transmitter/Receiver	RA	34-33
Rudder Ratio Changer Module	RRCM	27-09
Satellite Data Unit	SDU	23-25
Spoiler Control Module	SCM	27-09
Stabilizer Trim/Elevator Asymmetry Limit Module	SAM	27-09
Stall Warning Computer/Module (in Warning Electronic Unit) SWC	27-32
Strut Overheat Detection System (RR Engines)		26-12
Thrust Management Computer/Autothrottle	TMC	22-00
Traffic Alert and Collision Avoidance Computer	TCAS	34-45
VHF (Very High Frequency) Communication		23-12
VOR/Marker Beacon Receiver	VOR/MKR	34-51
Warning Electronic Unit BITE Module (Stall Warning)	WEU	27-32
Weather Radar Transceiver	WXR	34-43
Wheel Well Fire Detection		26-17
Window Heat Control Unit	WHCU	30-41
Yaw Damper Module	YDM	22-21
Yaw Damper/Stabilizer Trim Module	YSM	27-09
Zone Temperature Controller	ZTC	21-60/21-61

Bite Index Figure 1 (Sheet 3)

EFFECTIVITY-

34-BITE INDEX

ALL

01 Page 3 Aug 22/99



PITOT-STATIC SYSTEM

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
ALTIMETER - (FIM 34-13-00/101) STANDBY, N23 INDICATOR - (FIM 34-13-00/101) STANDBY AIRSPEED, N22 PORT - ALTERNATE STATIC PROBE - CAPTAIN'S PITOT STATIC, B26 PROBE - FIRST OFFICER'S PITOT STATIC, B28 PROBE - LEFT AUXILIARY PITOT STATIC, B29 PROBE - RIGHT AUXILIARY PITOT STATIC, B27 SENSOR - (FIM 21-30-00/101) DIFFERENTIAL PRESSURE, TS5072 SWITCH - (FIM 29-21-00/101) RAT AIRSPEED, S614	 	2 1 1 1 1	FORWARD FUSELAGE NOSE SECT, LEFT UPPER PROBE NOSE SECT, RIGHT UPPER PROBE NOSE SECT, LEFT LOWER PROBE NOSE SECT, RIGHT LOWER PROBE	34-11-03 34-11-01 34-11-01 34-11-01 34-11-01


Pitot-Static System - Component Index Figure 101


EFFECTIVITY-


34-11-00


48267











ALTERNATE STATIC PORT
(EXAMPLE)

Pitot-Static System - Component Location Figure 102

ALL

34-11-00

02

Page 102 Feb 10/91



Not Used Figure 103


ALL

34-11-00

01


Page 103 Dec 22/01





Capt (F/O) Static System Problem Figure 104







Alternate Static System Problem Figure 105



CAPT (F/O, AUX-1, AUX-2) PITOT SYSTEM PROBLEM PREREQUISITES
NONE



Capt (F/O, Aux-1, Aux-2) Pitot System Problem Figure 106






AUX-1 (AUX-2) STATIC SYSTEM PROBLEM

773834

PREREQUISITES
NONE



Aux-1 (Aux-2) Static System Problem Figure 107

ALL

O2 Page 107
Feb 10/91

BOEING PROPRIETARY - Copyright (C) - Unpublished Work - See title page for details.



AIR DATA COMPUTING (ADC) SYSTEM

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
ALTIMETER - (REF 34-13-00, FIG. 101) CAPT, N8 F/O, N48 CIRCUIT BREAKERS	1	1	FLIGHT COMPARTMENT, P11	*
AIR DATA AOA SENSOR LEFT, C1 AIR DATA AOA SENSOR RIGHT, C3 AIR DATA BARO CORRECT LEFT, C2 AIR DATA BARO CORRECT RIGHT, C4 AIR DATA COMPTR LEFT, C625		1 1 1 1	11A11 11F31 11A12 11F32 11A10	* * * *
AIR DATA COMPTR RIGHT, C626 COMPUTER - AIR DATA LEFT, M100 COMPUTER - AIR DATA RIGHT, M101 COMPUTER - (REF 31-41-00, FIG. 101)	2 2	1 1 1	11F30 11F3D 119AL, MAIN EQUIP CENTER, E1-3 119AL, MAIN EQUIP CENTER, E2-3	* 34-12-01 34-12-01
EICAS LEFT, M10181 EICAS RIGHT, M10182 INDICATOR - (REF 34-22-00, FIG. 101) ELEX ATTITUDE DIRECTION LEFT, N4 ELEX ATTITUDE DIRECTION RIGHT, N44 MODULE - DISCRETE WARNING DISPLAY, M779	1	1	FLIGHT COMPARTMENT, P1-3	*
PANEL - (REF 28-43-00, FIG. 101) MISC TEST, M10398 PROBE - TOTAL AIR TEMPERATURE, TS161 RELAY - (REF 31-01-33, FIG. 101) A0A PROBE CURRENT SENSING LEFT, K400 A0A PROBE CURRENT SENSING RIGHT, K401 AUX PITOT STATIC CURRENT SENSING LEFT, K312	2	1	LEFT SIDE FORWARD FUSELAGE	34-12-02
AUX PITOT STATIC CURRENT SENSING RIGHT, K243 PITOT STATIC CURRENT SENSING CAPT, K241 PITOT STATIC CURRENT SENSING F/O, K310 TAT PROBE CURRENT SENSING LEFT, K411 RELAY - (REF 31-01-36, FIG. 101) SYS 1 AIR/GND, K149				
RELAY - (REF 31-01-37, FIG. 101) SYS 2 AIR/GND, K207 SENSOR - ANGLE OF ATTACK LEFT, TS12 SENSOR - ANGLE OF ATTACK RIGHT, TS13 SWITCH - ALTERNATE VMO/MMO SELECT, S591 SWITCH - CAPT ADC INSTR SOURCE SELECT, S482 SWITCH - F/O ADC INSTR SOURCE SELECT, S483 TRANSFORMER - (REF 31-01-36, FIG. 101) AIR DATA COMPUTER LEFT, T139 TRANSFORMER - (REF 31-01-37, FIG. 101) AIR DATA COMPUTER RIGHT, T140	2 2 2 1 1	1 1 1 1 1	LEFT SIDE FUSELAGE NOSE RIGHT SIDE FUSELAGE NOSE 119AL, MAIN EQUIP CENTER FLIGHT COMPARTMENT, P1-1 FLIGHT COMPARTMENT, P3-3	34-12-03 34-12-03 * * *

^{*} SEE THE WDM EQUIPMENT LIST


1 ALL MTH AIRPLANES


Air Data Computing (ADC) System - Component Index Figure 101


EFFECTIVITY-

672045









MISCELLANEOUS TEST PANEL, M10398 (REF)

(C)

Air Data Computing (ADC) System - Component Location Figure 102 (Sheet 1)


ALL

O2 Page 102
Feb 10/91

BOEING PROPRIETARY - Copyright (C) - Unpublished Work - See title page for details.



FAULT ISOLATION/MAINT MANUAL



Air Data Computing (ADC) System - Component Location Figure 102 (Sheet 2)



Not Used Figure 103

ALL ALL

233924

34-12-00

01

Page 104 Aug 10/95




CAPT (F/O) ALTIMETER ERROR IS CORRECTED WITH ALTN AIR DATA SELECTED, OR EICAS MSG "ALT DISAGREE" OR "IAS DISAGREE"

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11A10, 11A11, 11A12, 11E2, 11E25, 11F30, 11F31, 11F32

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201) PITOT-STATIC SYSTEM AT AMBIENT (AMM 34-11-00/501)



Capt (F/O) Altimeter is Corrected with ALTN Air Data Selected, or EICAS Msg "ALT DISAGREE" Or "IAS DISAGREE" Figure 104

34-12-00

01


Page 105 Dec 22/00



MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11A7, 11A10, 11A11, 11A12, 11E2, 11E3, 11E4, 11E23, 11E24, 11E25, 11F8, 11F9, 11F24, 11F29, 11F30, 11F31, 11F32

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201) PITOT - STATIC SYSTEM AT AMBIENT (AMM 34-11-00/501)

OFF FLAG IN VIEW ON CAPT'S (F/O'S) ALTIMETER



Off Flag in View on Capt's (F/O's) Altimeter Figure 105

ALL

O3

Page 106

Aug 22/07

BOEING PROPRIETARY - Copyright (C) - Unpublished Work - See title page for details.



Not Used Figure 106

E79620

34-12-00

16

Page 107 Feb 10/95



MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
11A7,11A10,11A11,11A12,11E2,11E3,11E4,11E8,11E9,
11E23,11E24,11E25,11E29,11E30,11F8,11F9,11F24,
11F29,11F30,11F31,11F32

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201) PITOT-STATIC SYSTEM AT AMBIENT (AMM 34-11-00/501)

CAPT (F/O) TAS/SAT AND MACH ARE IN ERROR

NO SET THE LEFT (RIGHT) ADC 11 REPLACE THE LEFT (RIGHT) ADC, M100 (M101)(AMM 34-12-01/ TEST SWITCH, ON THE P61 TEST PANEL, TO THE "AIR DATA COMPT" 401). POSITION. DOES THE LEFT (RIGHT) EADI AIRSPEED TAPE SHOW 137 KTS AFTER 7 SECONDS? YES 13 DO THIS PROCEDURE: CAPT (F/O) STATIC SYSTEM (FIM 34-11-00/101, FIG. 104). IF THE PROBLEM CONTINUES, DO THIS PROCEDURE: CAPT (F/O), AUX-1, AUX-2) PITOT SYSTEM PROBLEM (FIM 34-11-00/ 101, FIG. 106).

TAS/SAT and Mach Are In Error Figure 107

ALL




MAKE SURE THIS SYSTEM WILL OPERATE: EFIS (MM 34-22-00/501)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11A7,11A10,11A11,11A12,11E2,11E3,11E4,11E23, 11E24,11E25,11F8,11F9,11F24,11F29,11F30,11F31, 11F32

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:

PITOT-STATIC SYSTEM AT AMBIENT (MM 34-11-00/501) ALL INSTRUMENT SOURCE SELECT SWITCHES IN THE NORM POSITION.

SPD FLAG IN VIEW ON L (R) EADI



SPD Flag in View on L (R) EADI Figure 108

ALL

O8
Page 109
Nov 10/95

BOEING PROPRIETARY - Copyright (C) - Unpublished Work - See title page for details.

MAKE SURE THESE SYSTEMS WILL OPERATE: EICAS (MM 31-41-00/501) WARNING SYSTEM (MM 31-51-00/501) INERTIAL REFERENCE SYSTEM (34-21-00/501)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11A7,11A10,11A11,11A12,11E2,11E3,11E4,11E23,11E24 11E25,11F8,11F9,11F24,11F29,11F30,11F31,11F32


MAKE SURE THESE CIRCUIT BREAKERS ARE OPEN AND ATTACH DO-NOT-CLOSE TAGS:

11A17,11F14,11F15,11F16

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:

ELECTRICAL POWER IS ON (MM 24-22-00/201)
PITOT-STATIC SYSTEM AT AMBIENT (MM 34-11-00/501)

L (R) ADC BITE PROCEDURE




L (R) ADC BITE Procedure Figure 109 (Sheet 1)

34-12-00


12

Page 110 Nov 10/95




L (R) ADC BITE Procedure Figure 109 (Sheet 2)





L (R) ADC BITE Procedure Figure 109 (Sheet 3)





THIS PAGE INTENTIONALLY LEFT BLANK

L (R) ADC BITE Procedure Figure 109 (Sheet 4)


EFFECTIVITY-

34-12-00

ALL

Page 113 Apr 22/09





L (R) ADC BITE Procedure Figure 109 (Sheet 5)




L (R) EADI AIRSPEED AND/OR MACH INDICA-TIONS IN ERROR. SELECTING ALTN AIR DATA CORRECTS FAULT

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11A7,11A10,11A11,11A12,11E3,11E4,11E24,11E25,11F8, 11F9,11F24,11F29,11F30,11F31,11F32

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:

ELECTRICAL POWER IS ON (MM 24-22-00/201) PITOT-STATIC SYSTEM AT AMBIENT (MM 34-11-00/501)



L (R) EADI Airspeed and/or Mach Indications in Error. Selecting Altn Air Data Corrects Fault. Figure 110

EFFECTIVITY-ALL



1. ARINC Data Bus Charts

A. General

<u>CAUTION</u>: DO NOT DIRECTLY TOUCH THE CONNECTORS. USE A BREAKOUT BOX OR YOU CAN CAUSE DAMAGE TO THE CONNECTOR.

(1) ARINC 429 data bus gives data necessary to make analysis of ARINC 429 transmitters, receivers, and data buses. For the test, use a breakout box at the available terminals or at the LRU unit.

B. Equipment

- (1) Standard multi-meter
- (2) 429EBP Data Bus Analyzer (recommended) JcAIR Instrumentation 400 Industrial Parkway Industrial Airport, KS 66031

429-2 Data Bus Analyzer (alternative) Interface Technology 150 E. Arrow Highway San Dimas, CA 91773

(3) A34011-1 Breakout Box (recommended) A34011-112 Breakout Box (alternative)

NOTE: Octal labels 034, 035, 246, 251, and 252 are multiple function labels and will not display correctly in engineering units on the data bus analyzer unless the hex equipment ID = 06 is selected. For analyzers not capable of having ID selected, display the label in hexadecimal format and record the value. Set the data bus analyzer to transmit a label in hex format as listed below.

RECEIVED LABEL	TRANSMIT LABEL
034	234 or 236
035	235 or 237
251	204 or 220
252	204 or 220
_	246

NOTE: Insert the hexadecimal value recorded for the received label. Then select engineering format to display the correct engineering value.

EFFECTIVITY-



ADC								
DIGITAL OUTPUT BUS CHART								
	BUS NAME					BUS	ВІТ	
	SOURCE	TYPE	BUS	CON	PINS	FORMAT	I ·	DATA BUS
ADC	(LCR)	Α	1	В	A02 B02	429	LO	ADC APFDS BUS
ADC	(LCR)	Α	2	В	A04 B04	429	LO	ADC INSTR BUS
ADC	(LCR)	Α	3	В	A06 B06	429	LO	ADC ENG CONT BUS
ADC	(LCR)	Α	4	В	A08 B08	429	LO	ADC GEN PRPS BUS

ALL



ADC ID = 06									
OCTAL LABELS CHART									
SIGNAL	TYPE	LABEL	FORMAT		SDI SDI	BINARY RANGE	POSITIVE SENSE	UNITS	
BARO COR NO.3(MB)	Α	034	BCD	8	хх	± 9999.9	ALWAYS POS	МВ	
BARO COR NO.3(IN)	Α	035	BCD	8	XX	± 99.999	ALWAYS POS	IN HG	
ALTITUDE (29.92)	А	203	BNR	16	хх	± 131,072	ABOVE SEA LEV	FEET	
ALTITUDE (BARO #1)	А	204	BNR	16	XX	± 131,072	ABOVE SEA LEV	FEET	
MACH	Α	205	BNR	8	XX	± 4.096	ALWAYS POS	MACH	
COMPUTED AIRSPEED	Α	206	BNR	8	XX	± 1024	ALWAYS POS	KNOTS	
MAX OPRTG SCHEDULE	Α	207	BNR	8	XX	± 1024	ALWAYS POS	KNOTS	
TRUE AIRSPEED	Α	210	BNR	8	XX	± 2048	ALWAYS POS	KNOTS	
TOTAL AIR TEMP	Α	211	BNR	2	XX	± 512	ABOVE FREEZ	DEG C	
ALTITUDE RATE	Α	212	BNR	16	XX	± 32,768	CLIMB UP	FT/MIN	
STATIC AIR TEMP	Α	213	BNR	2	XX	± 512	ABOVE FREEZ	DEG C	
IMPACT PRESSURE	Α	215	BNR	8	хх	± 512	ALWAYS POS	МВ	
ALTITUDE (BARO #2)	Α	220	BNR	16	XX	± 131,072	ABOVE SEA	FEET	
INDICATED AOA	Α	221	BNR	16	XX	± 180	NOSE UP	DEG	
ANGLE OF ATTACK-L	Α	222	BNR	16	ХХ	± 180	NOSE UP	DEG	
ANGLE OF ATTACK-R	Α	223	BNR	16	хх	± 180	NOSE UP	DEG	
TRUE AIRSPEED-D	Α	230	BCD	2	хх	± 799	ALWAYS POS	KNOTS	
TOTAL AIR TEMP-D	Α	231	BCD	2	хх	± 99	ABOVE FREEZ	DEG C	
STATIC AIR TEMP-D	Α	233	BCD	2	хх	± 99	ABOVE FREEZ	DEG C	
BARO COR NO.1(MB)	Α	234	BCD	8	XX	± 9999.9	ALWAYS POS	MB	



ADC ID = 06									
OCTAL LABELS CHART									
SIGNAL	TYPE	LABEL	FORMAT	MIN UPDATE RATE	SDI SDI	BINARY RANGE	POSITIVE SENSE	UNITS	
BARO COR NO.1(IN)	Α	235	BCD	8	хх	± 99.999	ALWAYS POS	INS HG	
BARO COR NO.2(MB)	Α	236	BCD	8	хх	± 9999.9	ALWAYS POS	МВ	
BARO COR NO.2(IN)	Α	237	BCD	8	хх	± 99.999	ALWAYS POS	INS HG	
CORRECTED AOA	Α	241	BNR	16	хх	± 180	NOSE UP	DEG	
TOTAL PRESSURE	Α	242	BNR	8	хх	± 2048	ALWAYS POS	МВ	
STATIC PRESSURE	Α	246	BNR	8	хх	± 2048	ALWAYS POS	МВ	
ALTITUDE (BARO #3)	Α	251	BNR	16	хх	± 131,072	ABOVE SEA LEV	FEET	
ALTITUDE (BARO #4)	Α	252	BNR	16	хх	± 131,072	ABOVE SEA LEV	FEET	
ADC DISCRETES #1	Α	270	DIS	2	хх	N/A	N/A	N/A	
ADC DISCRETES #2	Α	271	DIS	2	хх	N/A	N/A	N/A	
MAINTENANCE WD 1	Α	350	DIS	2	хх	N/A	N/A	N/A	
MAINTENANCE WD 2	Α	351	DIS	2	хх	N/A	N/A	N/A	
MAINTENANCE WD 3	Α	352	DIS	2	хх	N/A	N/A	N/A	
MAINTENANCE WD 4	Α	353	BCD	2	хх	N/A	N/A	N/A	
MAINTENANCE WD 5	Α	354	BNR	2	хх	± 63.999	ALWAYS POS	INS HG	

ALL

19



ADC				
	DISCRE	TE OCT	AL LABELS/BIT CHAR	T
SIGNAL	OCTAL LABEL	BIT	ONE-STATE	ZERO-STATE
SENSOR #1 HEAT ON	270	11	#1 HTR ON	#1 HTR OFF
SENSOR #2 HEAT ON	270	12	#2 HTR ON	#2 HTR OFF
ADC INVALID	270	13	ADC FAIL	ADC OK
PIT/STAT HEAT ON L	270	14	L P/S ON	L P/S OFF
PIT/STAT HEAT ON R	270	15	R P/S ON	R P/S OFF
TAT PROBE HEAT ON	270	16	TAT HTR ON	HTR OFF
L AOA HEAT ON	270	17	L AOA ON	L AOA OFF
R AOA HEAT ON	270	18	R AOA ON	R AOA OFF
OVERSPEED	270	19	OVERSPEED	NOT OVRSPD
ONSIDE AOA FAIL	270	20	ONSIDE FL	ONSIDE OK
AOA UNIQUE	270	21	UNIQUE	AVERAGE
VMO ALTERNATE #1	270	22	VMO=ALT #1	VMO NOT #1
VMO ALTERNATE #2	270	23	VMO=ALT #2	VMO NOT #2
VMO ALTERNATE #3	270	24	VMO=ALT #3	VMO NOT #3
VMO ALTERNATE #4	270	25	VMO=ALT #4	VMO NOT #4
SSEC ALTERNATE	270	26	ALTERNATE	NORMAL
AOAC ALTERNATE	270	27	ALTERNATE	NORMAL
BARO PORT "A"	270	28	BARO "A"	BARO "B"
ZERO SSEC (MACH)	270	29	NO MACH	MACH
ZERO SSEC (AOA)	271	11	NO AOA	AOA
EXT AOA MON (FAIL)	271	12	PRI AOA FL	PRI AOA OK



ADC									
	DISCRETE OCTAL LABELS/BIT CHART								
SIGNAL	OCTAL LABEL	BIT	ONE-STATE	ZERO-STATE					
#4 BARO ALT=#1	271	16	#4 ALT=#1	#4 NOT #1					
#4 BARO ALT=#2	271	17	#4 ALT=#2	#4 NOT #2					
#4 BARO ALT=#3	271	18	#4 ALT=#3	#4 NOT #3					
AOA ROT REF	271	19	#1=#2	#1=-#2					
SDI PAR SET	271	20	SET	NOT SET					
L AOA VANE TEST	350	11	L AOA FAIL	L AOA OK					
R AOA VANE TEST	350	12	R AOA FAIL	R AOA OK					
TAT INPUT TEST	350	15	TAT FAIL	TAT OK					
BARO #1 TEST	350	16	BARO #1 FL	BARO #1 OK					
BARO #2 TEST	350	17	BARO #2 FL	BARO #2 OK					
BARO #3 TEST	350	18	BARO #3 FL	BARO #3 OK					
A/C TYPE PROG TEST	350	19	PROG FAIL	PROG OK					
A/C TYPE CONST TST	350	20	CONST FAIL	CONST OK					
OSPD HDWR TEST	350	21	OSPD FAIL	OSPD OK					
A TO D TEST	350	22	A TO D FL	A TO D OK					
PROCESSOR TEST	350	23	PROC FAIL	PROC OK					
RAM TEST	350	24	RAM FAIL	RAM OK					
PROG MEM TEST	350	25	PROM FAIL	PROM OK					
PS SENS PER TEST	350	26	SENSOR FL	SENSOR OK					
PS SENS TEMP TEST	350	27	SENSOR FL	SENSOR OK					
PS CALIB TEST	350	28	CALIB FAIL	CALIB OK					
F/D CONVERSION TST	350	29	CONV FAIL	CONV OK					



ADC	1						
DISCRETE OCTAL LABELS/BIT CHART							
SIGNAL	OCTAL LABEL	BIT	ONE-STATE	ZERO-STATE			
PT SENS PER TEST	351	11	SENSOR FL	SENSOR OK			
PT SENS TEMP TEST	351	12	SENSOR FL	SENSOR OK			
PT CALIB TEST	351	13	CALIB FAIL	CALIB OK			
ARINC XMTR TEST	351	14	XMTR FAIL	XMTR OK			
ARINC XMTR TEST	351	15	XMTR FAIL	XMTR OK			
ARINC XMTR TEST	351	16	XMTR FAIL	XMTR OK			
POWER SUPPLY TEST	351	17	PWR SUP FL	PWR SUP OK			
AOA COMPARE TEST	351	18	COMP FAIL	COMP OK			
PS=PT	351	19	PS NOT PT	PS=PT			
AVERAGE AOA TEST	351	20	INVALID	AOA OK			
TEMP PS=TEMP PT	351	21	PS NOT PT	PS=PT			
PROG SEQ TEST	351	22	SEQ FAIL	SEQ OK			
PS PLL	351	23	PS PLL FL	PS PLL OK			
PT PLL	351	24	PT PLL FL	PT PLL OK			
EAROM TEST	351	25	EAROM FL	EAROM OK			
BARO #4 TEST	351	26	#4=NCD	#4=PRG PIN			
VMO TEST	351	27	>1 VMO	<2 VMO			
SDI PARITY	351	28	PAR FAIL	PAR OK			
CKSUM CHIP1	352	11	#1 FAIL	#1 0K			
CKSUM CHIP2	352	12	#2 FAIL #2 OK				
CKSUM CHIP3	352	13	#3 FAIL #3 OK				
CKSUM CHIP4	352	14	#4 FAIL	#4 OK			



ADC							
DISCRETE OCTAL LABELS/BIT CHART							
SIGNAL	OCTAL LABEL	BIT	ONE-STATE	ZERO-STATE			
PS MEM CHECK	352	15	PS MEM FL	PS MEM OK			
PT MEM CHECK	352	16	PT MEM FL	PT MEM OK			
A/C TYPE MEM CHECK	352	17	MEM FAIL	MEM OK			
A/C TYPE LSB	352	24	LSB=0	LSB=1			
A/C TYPE LSB+1	352	25	LSB+1=0	LSB+1=1			
A/C TYPE LSB+2	352	26	LSB+2=0	LSB+2=1			
A/C TYPE LSB+3	352	27	LSB+3=0	LSB+3=1			
A/C TYPE MSB	352	28	MSB=0	MSB=1			
A/C TYPE PARITY	352	29	PRTY ODD	PRTY EVEN			

ALL



AIR DATA INSTRUMENTS

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
ALTIMETER - CAPTAIN, N8		1	FLT COMPT, P1	34-13-01
ALTIMETER - FIRST OFFICER, N48		1	FLT COMPT, P3	34-13-01
ALTIMETER - STANDBY, N23		1	FLT COMPT, P1	34-13-06
CIRCUIT BREAKERS -			FLT COMPT, P11	*
ALTM LEFT, C584		1	11E2	*
ALTM RIGHT, C585		1	11E23	*
STBY ALTM VIB, C591		1	11A8	*
COMPUTERS - (34-12-00/101)				
AIR DATA LEFT, M100				
AIR DATA RIGHT, M101				
INDICATOR - STANDBY AIRSPEED, N22		1		34-13-05
MODULE - (34-16-00/101)				
ALTITUDE ALERT, M617			FLT COMPT, P1	
PANEL - (22-11-00/101)				
AFCS MODE CONTROL, M90				
SWITCHES - (34-12-00/101)				
CAPTAIN ADC INSTRUMENT SOURCE SELECT, S482				
FIRST OFFICER ADC INSTRUMENT SOURCE SELECT,				
\$483				

^{*} SEE THE WDM EQUIPMENT LIST


Air Data Instruments - Component Index Figure 101

ALL


34-13-00




FAULT ISOLATION/MAINT MANUAL



FLIGHT COMPARTMENT




ALTIMETER (WITH OFF FLAG)



STANDBY AIRSPEED INDICATOR

(B)



STANDBY ALTIMETER

(c)

Air Data Instruments - Component Location Figure 102

ALL

34-13-00

10

Page 102 Nov 10/91



MAKE SURE THIS SYSTEM WILL OPERATE: EICAS (AMM 31-41-00/201)

MAKE SURE THIS CIRCUIT BREAKER IS CLOSED: 11A8

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)

STANDBY AIRSPEED INDICATOR ERROR

1 PUSH THE STATUS SWITCH ON 20 REPLACE THE STANDBY AIR-THE EICAS DISPLAY SELECT SPEED INDICATOR, N22 (AMM 34-13-05/401). PANEL. DOES THE EICAS MESSAGE "ELEVATOR FEEL" SHOW ON THE **BOTTOM DISPLAY UNIT?** YES 21 DO THIS PROCEDURE: FOR (FIM 34-11-00/101, FIG. 106) FOR AUX PITOT SYSTEM.

> Standby Airspeed Indicator Error Figure 103

EFFECTIVITY-ALL

34-13-00



ALTITUDE ALERT SYSTEM

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
ALTIMETER - (FIM 34-13-00/101) CAPTAIN, N8 FIRST OFFICER, N48 CIRCUIT BREAKER - AURAL WARN SPKR LEFT, C567 AURAL WARN SPKR RIGHT, C568 WARN ELEX A, C565 WARN ELEX B, C566 LIGHT - ALTITUDE ADVISORY LIGHT - ALTITUDE ALERT, L136 MODULE - ALTITUDE ALERT, M617 MODULE - (FIM 32-09-03/101) PSEU, M162 SWITCH - (FIM 34-12-00/101) ALTERNATE VMO/MMO SELECT, S591 CAPTAIN ADC SOURCE SELECT, S482 SWITCH - (FIM 32-44-00/101) PARKING BRAKE, S459 UNIT (FIM 31-31-00/101) DIGITAL FLIGHT DATA ACQUISITION, M138		1 1 1 1 2 1 1	FLT COMPT, P11 11B16 11H35 11J34 11B18 FLT COMPT, P1, P3, ALTIMETER N8, N48 FLT COMPT, P1 119AL, MAIN EQUIP CTR, P51	* * * * * 34–16–01

^{*} SEE THE WDM EQUIPMENT LIST

1>> sas 275-999


Altitude Alert System - Component Index Figure 101

ALL

34-16-00



FAULT ISOLATION/MAINT MANUAL



Altitude Alert System - Component Location Figure 102

ALL

34-16-00

03

Page 102 May 10/91

296442




MAKE SURE THESE SYSTEMS WILL OPERATE:
AUTOPILOT SYSTEM (AMM 22-10-00/501)
ADC SYSTEM (AMM 34-12-00/501)
EICAS (AMM 34-41-00/501)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11B16,11B18,11H35,11J34

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)

EQUIPMENT: PROXIMITY SENSOR ACTUATOR/DEACTUATOR SET A27092-61 (TWO DEACTUATORS)

ALTITUDE ALERT SYSTEM FAULT ISOLATION




Altitude Alert System Fault Isolation Figure 103 (Sheet 1)


34-16-00

13

Page 103 Aug 10/98



Altitude Alert System Fault Isolation Figure 103 (Sheet 2)



Altitude Alert System Fault Isolation Figure 103 (Sheet 3)



INERTIAL REFERENCE SYSTEM

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
CIRCUIT BREAKERS IRS CENTER, C613 IRS LEFT, C611 IRS RIGHT, C612 CIRCUIT BREAKERS IRS C, C621 IRS L, C614 IRS R, C620 COMPUTER - (REF 34-12-00, FIG. 101) AIR DATA L, M100 AIR DATA R, M101			FLIGHT COMPARTMENT, P11 11F21 11F1 11F22 FLIGHT COMPARTMENT, P6 6D4 6D3 6D5	* * * * * * * * *
PANEL - INERTIAL REFERENCE MODE, M59 RELAY - (REF 31-01-06, FIG. 101) CENTER BUS ISOLATION, K123 IRS DC POWER DISCONNECT, K137 SWITCH - (REF 34-12-00, FIG. 101) CAPT ADC INSTR SOURCE SELECT, S482 F/O ADC INSTR SOURCE SELECT, S483 SWITCH - (REF 34-22-00, FIG. 101) R IRS INSTR SOURCE SELECT, S12 UNIT - CENTER INERTIAL REFERENCE, M160 UNIT - LEFT INERTIAL REFERENCE, M159 UNIT - RIGHT INERTIAL REFERENCE, M161	 	1 1 1 1	119AL, MAIN EQUIP CTR, E1-6 119AL, MAIN EQUIP CTR, E1-6 119AL, MAIN EQUIP CTR, E1-6 119AL, MAIN EQUIP CTR, E1-6	34-21-02 34-21-01 34-21-01 34-21-01


^{*} SEE THE WDM EQUIPMENT LIST


Inertial Reference System - Component Index Figure 101


EFFECTIVITY-

34-21-00

169858








119AL LEFT INERTIAL REFERENCE UNIT, M159 F1-6 SEE (B) RIGHT INERTIAL CENTER INERTIAL REFERENCE UNIT, M160 REFERENCE UNIT, M161 SEE (B) SEE (B MAIN EQUIPMENT CENTER

AIRPLANES WITH -110 IRU'S AND SUBSEQUENT;

THE CHASSIS INDICATOR HOLE CONTAINS A PLUG.

NO FAULTBALL INTICATOR IS INSTALLED.

INERTIAL REFERENCE MODE PANEL, M59



LEFT, RIGHT, OR CENTER INERTIAL REFERENCE UNIT, M159, M161, M160

Inertial Reference System - Component Location Figure 102

EFFECTIVITY-ALL

47775

34-21-00

02

Page 102 May 10/97



ELECTRICAL POWER (MM 24-22-00/201)
F/O (CAPT) IRS INSTR SOURCE SELECT SW IN THE USUAL POSITION

CB'S: 11A6,11F25,11F1,11F21,11F22,6D3,6D4,6D5

CAPT (F/O) RDMI HDG FLAG IN VIEW. ALTN IRS CORRECTS.



REMOVE THE R (L) IRU M161 (M159) (MM 34-21-01/401). REMOVE THE L (R) RDMI N3 (N43)(MM 34-22-05/401). EXAMINE AND REPAIR THE DATA BUS CIRCUIT FROM THE R (L) IRU, M161 (M159), TO THE L (R) RDMI, N3 (N43); CONNECTOR D371B (D367B), PINS C10,C11, TO CONNECTOR D645 (D647), PINS 41,42 (WDM 34-21-21,-11; 34-22-81,-91).

INSTALL THE IRU AND THE RDMI.

Capt (F/O) RDMI HDG Flag In View. Alth IRS Corrects. Figure 103

ALL

34-21-00


01

Page 103 Aug 10/90

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 6D3,6D4,6D5,11A10,11A11,11A12,11E5,11E26,11F1, 11F21,11F22,11F30,11F31,11F32

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)
F/O (CAPT) IRS INSTR SOURCE SELECT SW IN THE USUAL POSITION

CAPT (F/O) VSI OFF FLAG IN VIEW. ALTN AIR DATA DOESN'T CORRECT




Capt (F/O) VSI Off Flag in View. Alth Air Data Doesn't Correct Figure 104




CAPT (F/O) VSI OFF FLAG IN VIEW. ALTN AIR DATA CORRECTS ELECTRICAL POWER (MM 24-22-00/201)
CAPT (F/O) IRS AND ADC INSTR SOURCE SELECT SWITCHES
IN THE USUAL POSITIONS


CB'S: 11E5,11E26,11F1,11F21,11F22,6D3,6D4,6D5,11A10, 11A11,11A12,11F30,11F31,11F32




Capt (F/O) VSI Off Flag In View. Alth Air Data Corrects
Figure 104A (Sheet 1)







Capt (F/O) VSI OFF Flag In View. Alth Air Data Corrects Figure 104A (Sheet 2)





MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11F1,11F21,11F22,6D3,6D4,6D5

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)

IRS INDICATES IRS DC FAIL

oxed REMOVE THE L, R, OR C IRU, 10 WAS THE CONTINUITY CHECK 20 REPAIR THE CIRCUIT FROM M159,M161 OR M160 BETWEEN THE IRS R CIRCUIT THE IRS R CIRCUIT BREAKER BREAKER (6D5) AND THE R IRU (AMM 34-21-01/401). (6D4) TO THE R IRU CONNECTOR DO A CONTINUITY CHECK CONNECTOR D371C, PIN 7, DONE? D371C, PIN 7 (WDM 34-21-21). BETWEEN THE IRS L, R, OR C INSTALL THE IRU NO CIRCUIT BREAKERS (6D3,6D4, (AMM 34-21-01/401). 6D5), AS APPLICABLE, AND THE L, R, OR C IRU CONNECTOR D367C,D371C, OR D369C, PIN 7. 21 REPLACE THE IRS DC POWER IS THERE CONTINUITY? DISCONNECT RELAY, K137 (WDM 34-21-11,-31). YES IF THE PROBLEM CONTINUES, EXAMINE THE CIRCUIT BETWEEN THE IRS L OR C CIRCUIT BREAKERS (6D3,6D5), AS APPLICABLE, AND THE L OR C IRU CONNECTOR D367C OR D369C, PIN 7 (WDM 34-21-11,-31). INSTALL THE IRU (AMM 34-21-01/401). 22 DO A TEST ON THE IRU CON-NECTOR D367C (LEFT), D371C (RIGHT), OR D369C (CENTER), PIN 8, FOR A GROUND. REPAIR THE CIRCUIT IF IT IS NECESSARY (WDM 34-21-11,-21,-31).INSTALL THE IRU (AMM 34-21-01/401).

> IRS Indicates IRS DC Fail Figure 105

EFFECTIVITY-ALL

182018



ENTRY INOP TO SINGLE IRS (ALIGN FLASHES AFTER SECOND ENTRY). POSITION ENTRY FROM FMC-CDU UNSUCCESSFUL.

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 6D3,6D4,6D5,11F1,11F21,11F22

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)



Entry INOP to Single IRS (Align Flashes After Second Entry). Position Entry from FMC-CDU Unsuccessful. Figure 105A

EFFECTIVITY-ALL

E20343




ENTRY INOP TO SINGLE IRS (ALIGN FLASHES AFTER SECOND ENTRY). POSITION ENTRY FROM FMC-CDU SUCCESSFUL.

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 6D3,6D4,6D5,11F1,11F21,11F22

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)



Entry INOP to Single IRS (Align Flashes After Second Entry).

Position Entry from FMC-CDU Successful.

Figure 105B



ENTRY INOP TO ALL IRS'S ALIGN FLASHES AFTER SECOND ENTRY

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 6D3,6D4,6D5,11F1,11F21,11F22

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)

1 SET ALL THE MODE SELECT
SWITCHES TO OFF. AFTER
30 SECONDS, SET ALL THE
SWITCHES TO NAV. PUT IN THE
ALIGNMENT DATA AGAIN.
DO ALL THE ALIGN LIGHTS
FLASH?

20 REPLACE THE IRMP, M59
(AMM 34-21-02/401).

2 THE IRS SYSTEM IS OK.

Entry INOP to All IRS's (Align Flashes After Second Entry). Figure 105C

ALL ALL

E20359




ALIGN FAILED TO EXTIN AFTER 10 MIN (NAV SEL)


PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 6D3,6D4,6D5,11E8,11E9,11E29,11E30,11F1,11F21,11F22

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)



Align Failed to Extin after 10 Min (Nav Sel) Figure 105D





IRS INDICATES IRS ON DC

PREREQUISITES

ELECTRICAL POWER (MM 24-22-00/201)

CB'S: 11F1,11F21,11F22,6D3,6D4,6D5



REMOVE THE L, R, OR C IRU, M159,M161, OR M160 (MM 34-21-01/401). EXAMINE AND REPAIR THE APPLICABLE CIRCUIT FROM THE IRS L, R, OR C CIRCUIT BREAKERS (11F1,11F21,11F22) ON PANEL P11, TO THE L, R, OR C IRU CONNECTOR D367C,D371C, OR D369C.

IF THE PROBLEM CONTINUES, DO A TEST ON THE APPLICABLE IRU CONNECTOR D367C (L), D371C (R), OR D369C (C), PIN 5, FOR A GROUND. REPAIR THE CIRCUIT IF IT IS NECESSARY (WDM 34-21-11,-21,-31). INSTALL THE IRU.

IRS Indicates IRS on DC Figure 106


ALL ALL



MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
6D3,6D4,6D5,11A6,11A7,11E4,11E5,11E6,11E8,11E9,
11E25,11E26,11E27,11E29,11E30,11F1,11F8,11F9,
11F21,11F22,11F24,11F25,11F29

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)

IRS BITE TEST



IRS BITE Test Figure 107 (Sheet 1)

ALL


ALL


11 Page 113


May 10/97


BOEING PROPRIETARY - Copyright (C) - Unpublished Work - See title page for details.












IRS BITE Test Figure 107 (Sheet 3)






PREREQUISITES
NONE


NOTE: MAKE SURE THAT THE IRUS AND THE FMCs STAY ON UNTIL YOU DO THIS CHECK.

IRS REMOVAL CHECKS



1> TO CALCULATE THIS VALUE, DO THE IRU REMOVAL CHECKS.

IRS Removal Checks Figure 107A (Sheet 1)







PREREQUISITES NONE

NOTE: MAKE SURE THAT THE IRUS AND THE FMCs STAY ON UNTIL YOU DO THIS CHECK.


IRS REMOVAL CHECKS




IRS Removal Checks Figure 107A (Sheet 2)



TITLE THE MANY HODE (HOOKO)





MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
6D3,6D4,6D5,11A10,11A11,11A12,11E5,11E26,11F1,
11F21,11F22,11F30,11F31,11F32

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:
ELECTRICAL POWER IS ON (AMM 24-22-00/201)
F/O (CAPT) IRS INSTR SOURCE SELECT SW IN THE USUAL
POSITION

IRU "FAULT"
ILLUMINATED ON THE
INERTIAL REFERENCE
MODE PANEL (IRMP)

ON THE IRMP, TURN THE FAULTED IRU OFF. WAIT 30 SECONDS UNTIL THE IRMP "ALIGN" ENUNCIATOR EXTINGUISHES; PLACE EACH IRMP MODE SELECT SWITCH TO THE "NAV" POSITION. PUSH THE "INIT REF" PUSH BUTTON ON THE LEFT FMC-CDU. USE THE "PREV PAGE" OR "NEXT PAGE" SWITCH TO FIND THE "POS INIT" PAGE. PUT IN THE LOCAL LATITUDE AND LONGITUDE DATA INTO THE SCRATCH PATCH. PUSH THE LINE 4R SWITCH TO MOVE THE DATA TO LINE 4. MAKE SURE THE DATA SHOWS ON LINE 4. WAIT 10 MINUTES UNTIL THE IRMP "ALIGN" ENUNCIATOR EXTINGUISHES AND THE IRU IS FULLY IN THE "NAV" MODE. DOES THE IRMP "FAULT" **ENUNCIATOR EXTINGUISH AFTER** TRANSITION TO THE "NAV" MODE? NO REPLACE THE LEFT (RIGHT) IRU, M519 (M161) (AMM 34-21-01

/401).

21 THEN THE IRU IS OK.

IRU "FAULT" Illuminated on the Inertial Reference Mode Panel (IRMP)
Figure 108 (Sheet 1)

AIRPLANE WITH IRMP S242T101-201, -202;

IRU "FAULT" ILLUMINATED ON THE INERTIAL REFERENCE MODE PANEL (IRMP)

PREREQUISITES

ELECTRICAL POWER (MM 24-22-00/201)

CAPT (F/O) IRS AND ADC INSTR SOURCE SELECT SWITCHES

IN THE USUAL POSITIONS

CB'S: 11E5,11E26,11F1,11F21,11F22,6D3,6D4,6D5,11A10,

(IRMP) 11A11,11A12,11F30,11F31,11F32

ON THE IRMP, PLACE THE 21 REPLACE THE APPLICABLE IRU "SYS DSPL" KNOB TO THE "L" OR (AMM 34-21-01/401). "C" OR "R" CORRESPONDING TO THE IRU THAT HAS THE FAULT. ON THE IRMP, PLACE THE "DSPL SYS" KNOB TO THE "HDG" POSITION. PRESS "O" THEN "1" ON THE KEYBOARD WITHIN 5 SECONDS IS THE FAULT CODE 15 DISPLAYED? YES YES 2 ON THE IRMP, TURN THE 22 THEN THE IRU IS OK. FAULTED IRU OFF. WAIT 30 SECONDS UNTIL THE IRMP "ALIGN" ENUNCIATOR EXTINGUISHES; PLACE EACH IRMP MODE SELECT SWITCH TO THE "NAV" POSITION. PUSH THE "INIT REF" PUSH BUTTON ON THE LEFT FMC-CDU. USE THE "PREV PAGE" OR "NEXT PAGE" SWITCH TO FIND THE "POS INIT" PAGE. PUT IN THE LOCAL LATITUDE AND LONGITUDE DATA INTO THE SCRATCH PATCH. PUSH THE LINE 4R SWITCH TO MOVE THE DATA TO LINE 4. MAKE SURE THE DATA SHOWS ON LINE 4. WAIT 10 MINUTES UNTIL THE IRMP "ALIGN" ENUNCIATOR EXTINGUISHES AND THE IRU IS FULLY IN THE "NAV" MODE. DOES THE IRMP "FAULT" **ENUNCIATOR EXTINGUISH AFTER** TRANSITION TO THE "NAV" MODE? NO REPLACE THE LEFT (RIGHT) IRU, M519 (M161) (AMM 34-21-01 /401).



1. ARINC Data Bus Charts

A. General

<u>CAUTION</u>: DO NOT DIRECTLY TOUCH THE CONNECTORS. USE A BREAKOUT BOX OR YOU CAN CAUSE DAMAGE TO THE CONNECTORS.

(1) The ARINC 429 data bus charts give data necessary to make an analysis of ARINC 429 transmitters, receivers, and data buses. For the test, use a breakout box at the available terminal or at the LRU connector.

B. Equipment

- (1) Standard multi-meter
- (2) 429 EBP Data Bus Analyzer (recommended) JCAIR Instrumentation 400 Industrial Parkway Industrial Airport, KS 66031

429-2 Data Bus Analyzer (alternative) Interface Technology 150 E. Arrow Highway San Dimas, CA 91773

(3) A34011-1 Breakout Box (recommended) A34011-112 Breakout Box (alternative)

NOTE: Octal label 315 is a multiple function label. It does not show correctly in engineering units on the data bus analyzer unless you set the hexadecimal equipment ID = 04. For analyzers that cannot have the ID set, show the label in hexadecimal format and make a record of the value. Set the data bus analyzer to send label 015 in hex format and use the value you made a record of for label 315. Change the label 015 format to engineering to show the correct engineering units.

IRMP DIGITAL OUTPUT BUS CHART								
BUS NAME					BUS	ВІТ		
SOURCE	TYPE	BUS	CON	PINS	FORMAT		DATA BUS	
IRMP	Α	1	С	26 27	429	LO	IRMP BUS OUT IRU-C	
IRMP	Α	1	L	26 27	429	LO	IRMP BUS OUT IRU-L	
IRMP	Α	1	R	26 27	429	L0	IRMP BUS OUT IRU-R	

ALL

34-21-00

BOEING PROPRIETARY - Copyright (C) - Unpublished Work - See title page for details.



IRMP(ID=0A4) OCTAL LABELS CHART										
SIGNAL	TYPE	LABEL	FORMAT	MIN UPDATE RATE	SDI	BINARY RANGE	POSITIVE SENSE	UNITS		
SET LATITUDE	А	041	BCD	2		90s-90N	NORTH	DEG:MIN		
SET LONGITUDE	Α	042	BCD	2		180E-180W	EAST	DEG:MIN		
SET MAGNETIC HDG	Α	043	BCD	2		0-359	CW FRM NORTH	DEG		

	IRU DIGITAL OUTPUT BUS CHART								
BUS NAME						BUS	ВІТ		
	SOURCE	TYPE	BUS	CON	PINS	FORMAT		DATA BUS	
IRU	(LCR)	Α	1	В	G07 G08	429	HI	IRU #1	
IRU	(LCR)	Α	2	В	E05 E06	429	HI	IRU #2	
IRU	(LCR)	Α	3	В	C10 C11	429	ні	IRU #3	

ALL ALL

34-21-00

02



	IRU(ID=004) OCTAL LABELS CHART										
SIGNAL	TYPE	LABEL	FORMAT	MIN UPDATE RATE	SDI	BINARY RANGE	POSITIVE SENSE	UNITS			
PRESENT POS LAT-D	Α	010	BCD	2	00	90s-90N	NORTH FROM O	DEG:MIN			
PRESENT POS LONG-D	Α	011	BCD	2	00	180E-180W	EAST FROM O	DEG:MIN			
GROUND SPEED-D	Α	012	BCD	2	00	0-2000	ALWAYS POS	KNOTS			
TRACK ANGLE TRUE-D	Α	013	BCD	2	00	0-359.9	CW FROM NORTH	DEG			
MAGNETIC HEADING-D	Α	014	BCD	2	00	0-359.9	CW FROM NORTH	DEG			
WIND SPEED-D	Α	015	BCD	2	00	0-256	ALWAYS POS	KNOTS			
WIND DIRECT TRUE-D	Α	016	BCD	2	00	0-359	CW FROM NORTH	DEG			
TRUE HEADING-D	Α	044	BCD	2	00	0-359.9	CW FROM NORTH	DEG			
IRS DISCRETES	Α	270	DIS	2	00	N/A	N/A	N/A			
IRS TEST	Α	277	DIS	2	00	N/A	N/A	N/A			
PRESENT POS-LAT	Α	310	BNR	5	N/A	± 180	NORTH FROM O	DEG			
PRESENT POS-LONG	Α	311	BNR	5	N/A	± 180	EAST FROM O	DEG			
GROUND SPEED	Α	312	BNR	10	00	0-4096	ALWAYS POS	KNOTS			
TRACK ANGLE TRUE	Α	313	BNR	20	00	± 180	CW FROM NORTH	DEG			
TRUE HEADING	Α	314	BNR	20	00	± 180	CW FROM NORTH	DEG			
WIND SPEED	Α	315	BNR	10	00	0-256	ALWAYS POS	KNOTS			
WIND DIRECT TRUE	Α	316	BNR	10	00	± 180	CW FROM NORTH	DEG			
TRACK ANGLE-MAG	Α	317	BNR	20	00	± 180	CW FROM NORTH	DEG			
MAGNETIC HEADING	Α	320	BNR	20	00	± 180	CW FROM NORTH	DEG			
DRIFT ANGLE	Α	321	BNR	20	00	± 180	RIGHT	DEG			

EFFECTIVITY-

ALL



	IRU(ID=004) OCTAL LABELS CHART										
SIGNAL	TYPE	LABEL	FORMAT	MIN UPDATE RATE	SDI	BINARY RANGE	POSITIVE SENSE	UNITS			
FLIGHT PATH ANGLE	Α	322	BNR	20	00	± 180	UP	DEG			
FLIGHT PATH ACCEL	Α	323	BNR	50	00	± 4	FORWARD	G'S			
PITCH ANGLE	Α	324	BNR	50	00	± 180	UP	DEG			
ROLL ANGLE	Α	325	BNR	50	00	± 180	RIGHT WING DO	DEG			
BODY PITCH RATE	Α	326	BNR	50	00	± 128	UP	DEG/SEC			
BODY ROLL RATE	Α	327	BNR	50	00	± 128	RIGHT WING DO	DEG/SEC			
BODY YAW RATE	Α	330	BNR	50	00	± 128	NOSE RIGHT	DEG/SEC			
BODY LONGIT ACCEL	Α	331	BNR	50	00	± 4	FORWARD	G'S			
BODY LATERAL ACCEL	Α	332	BNR	50	00	± 4	RIGHT	G'S			
BODY NORMAL ACCEL	Α	333	BNR	50	00	± 4	UP	G'S			
PLATFORM HEADING	Α	334	BNR	10	00	± 180	CW FROM ZERO	DEG			
TRACK ANGLE RATE	Α	335	BNR	50	00	± 32	CW	DEG/SEC			
PITCH ATT RATE	Α	336	BNR	50	00	± 128	UP	DEG/SEC			
ROLL ATT RATE	Α	337	BNR	50	00	± 128	RIGHT WING DO	DEG/SEC			
IRS MAINT DISCRETE	Α	350	DIS	2	00	N/A	N/A	N/A			
IRMP BITE DSPL*[1]	Α	351	DIS	2		N/A	N/A	N/A			
GPS MAINT DIS *[2]	Α	353	DIS	1	00	N/A	N/A	N/A			
POTENTIAL VERT SPD	Α	360	BNR	50	00	± 32,768	UP	FT/MIN			

ALL



IRU(ID=004) OCTAL LABELS CHART									
SIGNAL	TYPE	LABEL	FORMAT	MIN UPDATE RATE	SDI	BINARY RANGE	POSITIVE SENSE	UNITS	
INERTIAL ALTITUDE	Α	361	BNR	25	N/A	± 131,072	UP	FEET	
ALONG TK HRZ ACCEL	А	362	BNR	50	00	± 4	FORWARD	G'S	
CROSS TK HRZ ACCEL	А	363	BNR	50	00	± 4	RIGHT	G'S	
VERTICAL ACCEL	А	364	BNR	50	00	± 4	UP	G'S	
INERTIAL VERT SPD	Α	365	BNR	50	00	± 32,768	UP	FT/MIN	
N-S VELOCITY	Α	366	BNR	10	00	± 4096	NORTH	KNOTS	
E-W VELOCITY	Α	367	BNR	10	00	± 4096	EAST	KNOTS	

^{*[1] -103} IRUs AND ON

EFFECTIVITY-

^{*[2] -107} IRUS AND ON



IRU	IRU DISCRETE OCTAL LABELS/BIT CHART									
SIGNAL	OCTAL LABEL	BIT	ONE-STATE	ZERO-STATE						
ALIGN MODE/NR	270	11	ALIGN MODE	NOT ALIGN						
REV ATTITUDE MODE	270	12	REV ATT	NO REV ATT						
NAV MODE	270	13	NAV	NO NAV						
SET HEADING	270	14	SET HDG	NO SET HDG						
ATTITUDE INVALID	270	15	ATT INVAL	ATT VALID						
DC FAIL	270	16	DC FAIL	DC OK						
ON DC	270	17	ON DC	OFF DC						
ADC FAULT	270	18	ADC FAULT	NO FAULT						
IRU FAULT	270	19	IRU FAULT	NO FAULT						
DC FAIL ON DC	270	20	DC FAIL	NO FAULT						
ALIGN FAULT	270	21	ALIGN FLT	NO FAULT						
NO IRS INITIAL	270	22	NO INITIAL	INITAL						
EXCESS MOTION ERR	270	23	EXC MOTION	NO ERROR						
ADC/IRU FAULT	270	24	FAULT	NO FAULT						
REENTER POS *[2]	270	25	ENTER POS	NO ACTION						
ALIGN STATUS *[1]	270	26	1 MIN	0						
ALIGN STATUS *[1]	270	27	2 MIN	0						
ALIGN STATUS *[1]	270	28	4 MIN	0						
CYCLE IRS *[2]	270	29	CYCLE IRS	NO ACTION						
POWER SUPPLY	350	11	FAULT	NO FAULT						

ALL



IRU	DISCRI	ETE OCT	AL LABELS/BIT CHART	
SIGNAL	OCTAL LABEL	BIT	ONE-STATE	ZERO-STATE
DIGITAL INPUT	350	12	FAULT	NO FAULT
SENSOR LSIC	350	13	FAULT	NO FAULT
MEMORY (RAM)	350	14	FAULT	NO FAULT
MEMORY (PROM)	350	15	FAULT	NO FAULT
PITCH RATE	350	16	FAULT	NO FAULT
GYRO	350	17	FAULT	NO FAULT
TEMP SENSOR	350	19	FAULT	NO FAULT
SYSTEM TESTS	350	20	FAULT	NO FAULT
DISCRETE I/O	350	21	FAULT	NO FAULT
WDT	350	22	FAULT	NO FAULT
СРИ	350	23	FAULT	NO FAULT
A/D OR MUX	350	24	FAULT	NO FAULT
GPS RESERVED *[3]	350	25	TBD	TBD
GPS RESERVED *[3]	350	26	TBD	TBD
GPS RESERVED *[3]	350	27	TBD	TBD
GPS RESERVED *[3]	350	28	TBD	TBD
PWR SUPP CRITICAL *[1]	351	11	FAULT	NO FAULT
DIG I/O WRAPROUND *[1]	351	12	FAULT	NO FAULT
RAM/NVM/PROM MMRY *[1]	351	13	FAULT	NO FAULT
LSIC *[1]	351	14	FAULT	NO FAULT
DISCRETE INPUT *[1]	351	15	FAULT	NO FAULT

ALL



	IRU	DISCRE	ETE OCT	AL LABELS/BIT CHART	
SIGNAL		OCTAL LABEL	BIT	ONE-STATE	ZERO-STATE
PROCESSOR	*[1]	351	16	FAULT	NO FAULT
GYRO	*[1]	351	17	FAULT	NO FAULT
ALIGN/SYSTEM	*[1]	351	18	FAULT	NO FAULT
A/D MUX DATA TRAN	*[1]	351	19	FAULT	NO FAULT
POWER SUPPLY	* [1]	351	20	FAULT	NO FAULT
ADC/DSCRTOUT WRAP	* [1]	351	21	FAULT	NO FAULT
SPARE	* [1]	351	22	NOT USED	NOT USED
CALIBRATION PROM	* [1]	351	23	FAULT	NO FAULT
INA/OTA	* [1]	351	24	FAULT	NO FAULT
ANALOG PITCH RATE	* [1]	351	25	FAULT	NO FAULT
GYRO	* [1]	351	26	FAULT	NO FAULT
GYRO CONFIG	* [1]	351	27	FAULT	NO FAULT
TEMP SENSOR	*[1]	351	28	FAULT	NO FAULT
SPARE	*[1]	351	29	NOT USED	NOT USED
GPS FAULT	*[3]	351	29	FAULT	NO FAULT
NO GPS FNCTN INSTI	_*[4]	353	27	NOT INSTALLED	INSTALLED

^{*[1] -103} IRUs AND ON

EFFECTIVITY-

^{*[2] -105} IRUs AND ON

^{*[3] -107} IRUS AND ON (ALWAYS ZERO STATE)

^{*[4] -107} IRUS AND ON (ALWAYS ONE STATE)



2. IRU Removal Checks (Fig. 107A and 107B)

- A. Two checks are used to make a decision if an IRU is recommended to be replaced. The checks are the residual groundspeed error and the radial position error measurements.
 - (1) Residual groundspeed is the groundspeed of the airplane when the airplane is parked. The POS REF (position reference) page 2/2 on the FMC CDU shows the residual groundspeed for the FMC and the IRUs at the end of the flight.
 - (2) Radial position error is the distance between present position and computed IRU position. The POS REF page 2/2 on the FMC CDU shows the present position for the IRUs. The radial position error check uses the FMC CDU RTE (route) 1 or RTE 2 legs page to calculate the IRS radial position error. The actual and calculated IRS positions are input as waypoints. Their difference, in nautical miles, is compared to the deviation criteria to make a decision if the IRU is recommended to be replaced.
- B. Residual Groundspeed Error Check

NOTE: The IRUs and FMCs must not be shut down before the groundspeed error check is complete.

- (1) Push the INIT REF key on the CDU.
- (2) Push the line select key (LSK) adjacent to <INDEX.
 - (a) Make sure the INIT REF INDEX page is shown.
- (3) Push the LSK adjacent to <POS.
 - (a) Make sure the POS INIT page 1/2 is shown.
- (4) Push the NEXT PAGE or PREV PAGE key to show the POS REF page.
 - (a) Make sure the POS REF page is shown.
- (5) Record the residual groundspeed error shown on the POS REF page for each IRU.

<u>NOTE</u>: FMC freeze can cause FMC-CDU to display excessive groundspeed. Verify IRU residue using IRMP.

- (a) Open the applicable circuit breakers:
 - L FMC, OR
 - R FMC
- (b) Wait 15 seconds then close the applicable circuit breakers: L FMC, OR
 - R FMC
- (c) Observe the IRU groundspeed for 20 minutes to confirm the maximum error.

EFFECTIVITY-

(6) AIRPLANES WITH IRMP P/N S242T101-202 THRU -999; Do these steps:

NOTE: The groundspeed will not change on the FMC when an IRU is replaced. This procedure must be performed after completion of a flight before IRU is switched out of the NAV mode. This value should be recorded before power shutdown.

- (a) Rotate IRMP "SYS DSPL" switch to L, C, or R position, as appropriate.
- (b) Rotate IRMP "DSPL SEL" switch to TK/GS position.
- (c) Read residual speed on the IRMP upper right display window.
- (d) Repeat for each IRU position.
- (7) Replace the IRU (AMM 34-21-01/401) if one of these conditions occur:
 - (a) The residual groundspeed error is 15 knots or larger after each of two consecutive checks.
 - (b) The residual groundspeed error is 21 knots or larger at the end of one check.
- C. Radial Position Error Check

<u>NOTE</u>: The IRUs and FMCs must not be shut down before the radial position error check is complete.

- (1) Push the INIT REF key on the CDU.
- (2) Push the line select key (LSK) adjacent to <INDEX.
 - (a) Make sure the INIT REF INDEX page is shown.
- (3) Push the LSK key adjacent to <POS.
 - (a) Make sure the POS INIT page 1/2 is shown.
- (4) Push the NEXT PAGE or PREV PAGE key to show the POS REF page.
 - (a) Make sure the POS REF page is shown.
- (5) Record the latitude and longitude shown for each IRU.
- (6) Push the LEGS mode key.
 - (a) Make sure the RTE 1 LEGS or RTE 2 LEGS page is shown.
- (7) Input the present position latitude and longitude (gate, ramp, etc.) as a waypoint.
- (8) Input the latitude and longitude of the left IRU as the next waypoint on the RTE 1 or RTE 2 LEGS page.

NOTE: This can be done manually or by line selection from the POS REF page.

(9) Record the computed leg length between the present position waypoint and the left IRU waypoint.

NOTE: This is the radial position error of the left IRU.

(10) Input the latitude and longitude of the center IRU after the present position waypoint, either manually or by line selection from the POS REF page.

EFFECTIVITY-



(11) Record the computed leg length between the present position waypoint and the center IRU waypoint.

NOTE: This is the radial position error of the center IRU.

- (12) Input the latitude and longitude of the right IRU after the present position waypoint, either manually or by line selection from the POS REF page.
- (13) Record the computed leg length between the present position waypoint and the right IRU waypoint.

NOTE: This is the radial position error of the right IRU.

(14) Compare these radial position errors for a given navigation time to the accept/reject limits on Fig. 107B.

NOTE: Navigation time is the time since an IRU last entered NAV mode after a full 10 minute alignment was completed. Flight time is permitted if navigation time is not available.

- (15) Replace the IRU (AMM 34-21-01/401) if one of these conditions occur:
 - (a) The radial position error of the IRU for a given navigation time falls in the "REPLACE AFTER 1 FLIGHT" area of Fig. 107B.
 - (b) The radial position error of the IRU for a given navigation time falls in the "REPLACE AFTER 2 CONSECUTIVE FLIGHTS" area of Fig. 107B for two consecutive flights.

EFFECTIVITY-

34-21-00

ALL



ELECTRONIC FLIGHT INSTRUMENT SYSTEM (EFIS)

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
CIRCUIT BREAKER -	1		FLT COMPT, P11	
ADI LEFT, C593		1	11E3	*
ADI RIGHT, C594		1 1	11E24	*
EFIS CONT PNL LEFT, C633		1	11E4	*
EFIS CONT PNL RIGHT, C634		1 1	11E25	*
EFIS DSPL SW L, C622		1 1	11A7	
EFIS DSPL SW RIGHT, C623		1 1	11F24	*
EFIS SYM GEN L, C637		1	11F8	*
EFIS SYM GEN RÍGHT, C638		1	11F29	*
EFIS SYM GEN C, C639		1	11F9	*
HSI LEFT, C588		1	11E6	*
HSI RIGHT, C589		1	11E27	*
RDMI L, C635		1	11A6	*
RDMI RIGHT, C636		1	11F25	*
VSI LEFT, C586		1	11E5	*
VSI RIGHT, C587		1	11E26	*
GENERATOR - CENTER EFIS SYMBOL, M149	1	1	119AL, MAIN EQUIP CTR, E1-4	34-22-01
GENERATOR - LEFT EFIS SYMBOL, M148	1	1	119AL, MAIN EQUIP CTR, E1-2	34-22-01
GENERATOR - RIGHT EFIS SYMBOL, M150	1	1	119AL, MAIN EQUIP CTR, E1-5	34-22-01
INDICATOR - LEFT ELECTRONIC ATTITUDE	2	1	FLT COMPT, P1-1	34-22-03
DIRECTOR, N4				
INDICATOR - LEFT ELECTRONIC HORIZONTAL	2	1	FLT COMPT, P1-1	34-22-04
SITUATION, N5				
INDICATOR - LEFT RADIO DISTANCE MAGNETIC, N3	2	1	FLT COMPT, P1-1	34-22-05
INDICATOR - LEFT RESOLUTION ADVISORY/	2	1	FLT COMPT, P1-3	34-22-09
VERTICAL SPEED, N9 2				7, 22 24
INDICATOR - LEFT VERTICAL SPEED, N9 1	2	1	FLT COMPT, P1-3	34-22-06
INDICATOR - RIGHT ELECTRONIC ATTITUDE	2	1	FLT COMPT, P3-3	34-22-03
DIRECTOR, N44		4	5. T. 00MDT	7/ 22 0/
INDICATOR - RIGHT ELECTRONIC HORIZONTAL	2	1	FLT COMPT, P3-3	34-22-04
SITUATION, N45			5. T. 00MDT	7/ 22 05
INDICATOR - RIGHT RADIO DISTANCE MAGNETIC,	2	1	FLT COMPT, P3-3	34-22-05
N43	2	1	FLT COMPT D7 7	34-22-09
INDICATOR - RIGHT RESOLUTION ADVISORY/	-	'	FLT COMPT, P3-3	34-22-09
VERTICAL SPEED, N49 2 INDICATOR - RIGHT VERTICAL SPEED, N49 1	2	1	FLT COMPT, P3-3	34-22-06
PANEL - (FIM 34-51-00/101)	-	' '	FET COMPT, PS-5	34-22-00
LEFT VOR/DME CONTROL, M91				
RIGHT VOR/DME CONTROL, M92				
PANEL - LEFT EFIS CONTROL, M94	2	1	FLT COMPT, P10	34-22-02
PANEL - RIGHT EFIS CONTROL, M93	2	1	FLT COMPT, P10	34-22-02
RELAY - (FIM 31-01-37/101)	-	'	121 3311 17 110	J- LL 0L
EFIS/EICAS ATT COMP, K1297 [2>				
FLIGHT RECORDER I/P SWITCHING, K15				
	H	1		1

^{*} SEE THE WDM EQUIPMENT LIST

1 SAS 050-280 2 SAS 281-999

F21357

Electronic Flight Instrument System (EFIS) - Component Index Figure 101 (Sheet 1)

EFFECTIVITY-

34-22-00

21

Page 101 Feb 10/97



ELECTRONIC FLIGHT INSTRUMENT SYSTEM (EFIS)

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
SENSOR - LEFT EFIS REMOTE LIGHT, TS187		1	FLT COMPT, P7	34-22-07
SENSOR - RIGHT EFIS REMOTE LIGHT, TS188		1	FLT COMPT, P7	34-22-07
SWITCH - HEADING REFERENCE, S616	2	1	FLT COMPT, P3-1	*
SWITCH - LEFT EFI, S3	1	1	FLT COMPT, P1-1	33-13-00
SWITCH - LEFT F/D, S1	1	1	FLT COMPT, P1-1	33-13-00
SWITCH - LEFT IRS, S4	1	1	FLT COMPT, P1-1	33-13-00
SWITCH - LEFT NAV, S2	1	1	FLT COMPT, P1-1	33-13-00
SWITCH - RIGHT EFI, S11	1	1	FLT COMPT, P3-3	33-13-00
SWITCH - RIGHT F/D, S9	1	1	FLT COMPT, P3-3	33-13-00
SWITCH - RIGHT IRS, S12	1	1	FLT COMPT, P3-3	33-13-00
SWITCH - RIGHT NAV, S10	1	1	FLT COMPT, P3-3	33–13–00

^{*} SEE THE WDM EQUIPMENT LIST

Electronic Flight Instrument System (EFIS) - Component Index Figure 101 (Sheet 2)

ALL


34-22-00


10

Page 102 May 10/93




FAULT ISOLATION/MAINT MANUAL






LEFT OR RIGHT EADI, N4 OR N44




LEFT OR RIGHT EHSI, N5 OR N45






LEFT OR RIGHT VERTICAL SPEED INDICATOR, N9 OR N49





LEFT OR RIGHT RESOLUTION ADVISORY/ VERTICAL SPEED INDICATOR, N9 OR N49





LEFT OR RIGHT EFIS CONTROL PANEL, M94 OR M93

G

1 SAS 050-280 2 SAS 281-999

EFIS - Component Location (Details from Sht 1) Figure 102 (Sheet 2)


ALL ALL

34-22-00


22

Page 104 Feb 10/97






MAIN EQUIPMENT CENTER



EFIS SYMBOL GENERATOR



EFIS - Component Location Figure 102 (Sheet 3)





Not Used Figure 103

34-22-00

01

Page 106 Apr 22/02




PREREQUISITES

MAKE SURE THIS SYSTEM WILL OPERATE: EFIS (AMM 34-22-00/501)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11A7, 11E3, 11E4, 11E6, 11E24, 11E25, 11E27, 11F8, 11F9, 11F24, 11F29

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)




Display Problems on Capt (F/O) EADI Figure 104 (Sheet 1)

DISPLAY PROBLEMS

ON CAPT (F/O)

EADI



ON THE AVIONICS COOLING MONITOR ON THE P61 PANEL;
MAKE SURE THE INDICATING BALL SHOWS IN THE WINDOW BEFORE YOU
REMOVE THE UNIT. IF THE BALL DOES NOT SHOW AND THE PROBLEM
CONTINUES AFTER YOU EXAMINE AND CLEAN THE INLET SCREEN,
EXAMINE AND REPAIR DAMAGE OR DISCONNECTIONS OF THE COOLING
AIR DUCTS.

EXAMINE THE INLET SCREEN ON THE BACK OF THE OTHER EADI, THE TWO EHSIS (AMM 34-22-04/401), AND THE TWO EICAS DISPLAY UNITS (AMM 31-41-01/401). REPAIR THE PROBLEMS THAT YOU FIND.

Display Problems on Capt (F/O) EADI Figure 104 (Sheet 2)

ALL 05 Page 108
Dec 22/02




PREREQUISITES

MAKE SURE THIS SYSTEM WILL OPERATE: EFIS (AMM 34-22-00/501)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11A7,11E3,11E4,11E6,11E24,11E25,11E27,11F8,11F9 11F24,11F29

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)



1> FOR LIGHT CONDITIONS, PUT A COVER ON THE SENSOR. FOR NO LIGHT CONDITIONS, POINT A LIGHT SOURCE AT THE SENSOR.

BRIGHTNESS CONTROL PROBLEM ON CAPT

Brightness Control Problems on Capt (F/O) EADI Figure 105

EFFECTIVITY-34-22-00 ALL 04 Page 109 Nov 10/96 BOEING PROPRIETARY - Copyright (C) - Unpublished Work - See title page for details.




PREREQUISITES

MAKE SURE THIS SYSTEM WILL OPERATE: EFIS (AMM 34-22-00/501)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11A7,11E3,11E4,11E6,11E24,11E25,11E27,11F8, 11F9,11F24,11F29

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)

DISPLAY PROBLEMS ON CAPT (F/O) EHSI




Display Problems on Capt (F/O) EHSI Figure 106 (Sheet 1)

ALL

O4 Page 110

Dec 22/03

BOEING PROPRIETARY - Copyright (C) - Unpublished Work - See title page for details.



ON THE AVIONICS COOLING MONITOR ON THE P61 PANEL,
MAKE SURE THE INDICATING BALL SHOWS IN THE WINDOW BEFORE YOU
REMOVE THE UNIT. IF THE BALL DOES NOT SHOW AND THE PROBLEM
CONTINUES AFTER YOU EXAMINE AND CLEAN THE INLET SCREEN,
EXAMINE AND REPAIR DAMAGE OR DISCONNECTIONS OF THE COOLING
AIR DUCTS.

EXAMINE THE INLET SCREEN ON THE BACK OF THE OTHER EHSI, THE TWO EADIS (AMM 34-22-03/401), AND THE TWO EICAS DISPLAY UNITS (AMM 31-41-01/401).

Display Problems on Capt (F/O) EHSI Figure 106 (Sheet 2)

34-22-00

05

Page 111 Dec 22/03


PREREQUISITES

MAKE SURE THIS SYSTEM WILL OPERATE: EFIS (AMM 34-22-00/501)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11A7,11E3,11E4,11E6,11E24,11E25,11E27,11F8,11F9, 11F24,11F29


MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)

BRIGHTNESS CONTROL PROBLEM ON CAPT (F/O) EHSI



FOR LIGHT CONDITIONS, PUT A COVER ON THE SENSOR.
FOR NO LIGHT CONDITIONS, POINT A LIGHT SOURCE AT THE SENSOR.

Brightness Control Problems on Capt (F/O) EHSI Figure 107





PREREQUISITES

MAKE SURE THIS SYSTEM WILL OPERATE: EFIS (AMM 34-22-00/501)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11A7, 11E3, 11E4, 11E6, 11E24, 11E25, 11E27, 11F8, 11F9, 11F24, 11F29

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)

EFIS BITE PROCEDURE

NO ON THE LEFT AND RIGHT EFIS CONTROL PANELS, SET THE WXR SWITCH TO THE ON POSITION, ALL THE MAP DATA SWITCHES TO THE ON POSITION 2, THE MODE SWITCH TO THE PLAN POSITION, THE DH REF TO 50, AND ALL THE BRT CONTROLS FULLY CLOCKWISE. ON THE LEFT AND RIGHT INSTRUMENT SOURCE SELECT PANELS, SET THE EFI SWITCH TO THE ALT POSITION AND BACK TO THE NORMAL POSITION. ON THE LEFT AND RIGHT EFIS SYMBOL GENERATORS, PUSH THE RESET SWITCH. ON THE OVERHEAD LIGHTING CONTROL PANEL, PUSH AND HOLD THE TEST SWITCH. SET THE MODE SWITCHES ON THE EFIS CONTROL PANELS TO EACH MODE FOR 15 SECONDS. IS THE MESSAGE, "SG FAIL", SHOWN ON THE LEFT (RIGHT) EADI OR EHSI? YES SEE SHEET 2 (BLOCK 2)

41 THE MESSAGE IS AN INTERMITTENT MESSAGE.
NO ACTION IS REQUIRED.

DISENGAGE THE TEST SWITCH ON THE OVERHEAD LIGHTING CONTROL PANEL.

DO NOT PUSH THE INOP SWITCH ON THE EFIS CONTROL PANEL. IF YOU DO, INCORRECT DISPLAY WILL OCCUR.


ON THE AVIONICS COOLING MONITOR ON THE P61 PANEL, MAKE SURE THE INDICATING BALL SHOWS IN THE WINDOW BEFORE YOU REMOVE THE UNIT. IF THE BALL DOES NOT SHOW AND THE PROBLEM CONTINUES AFTER YOU EXAMINE AND CLEAN THE INLET SCREEN, EXAMINE AND REPAIR DAMAGE OR DISCONNECTIONS OF THE COOLING AIR DUCTS.

EFIS BITE Procedure Figure 108 (Sheet 1)

 34-22-00

10

Page 113 Dec 22/06



EFIS BITE Procedure Figure 108 (Sheet 2)


1331153

34-22-00


05

Page 114 Dec 22/06







EFIS BITE Procedure Figure 108 (Sheet 3)












EFIS BITE Procedure Figure 108 (Sheet 5)

ALL

O2 Page 117

Dec 22/06

BOEING PROPRIETARY - Copyright (C) - Unpublished Work - See title page for details.



EFIS BITE Procedure Figure 108 (Sheet 6)

F00261




PREREQUISITES

MAKE SURE THESE SYSTEMS WILL OPERATE: EICAS (AMM 31-41-00/201) IRS (AMM 34-21-00/501) EFIS (AMM 34-22-00/501)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11A7, 11E3, 11E4, 11E6, 11E24, 11E25, 11E27, 11F8, 11F9, 11F24, 11F29


ATTITUDE COMPARATOR PROBLEMS

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)



Attitude Comparator Problems Figure 109 (Sheet 1)


SAS 281-999



Attitude Comparator Problems Figure 109 (Sheet 2)

EFFECTIVITY-SAS 281-999

854478




Attitude Comparator Problems Figure 109 (Sheet 3)

EFFECTIVITY SAS 281-999

34-22-00

14

Page 121 Dec 22/06



Attitude Comparator Problems Figure 109 (Sheet 4)

EFFECTIVITY
SAS 281-999

16 Page 122
Apr 22/08

BOEING PROPRIETARY - Copyright (C) - Unpublished Work - See title page for details.



1. ARINC Data Bus Charts

A. General

<u>CAUTION</u>: DO NOT DIRECTLY TOUCH THE CONNECTORS. USE A BREAKOUT BOX OR YOU CAN CAUSE DAMAGE TO THE CONNECTORS.

(1) The ARINC 429 data bus charts give data necessary to make an analysis of ARINC 429 transmitters, receivers, and data buses. For the test, use a breakout box at the available terminal or at the LRU connectors.

B. Equipment

- (1) Standard multi-meter
- (2) 429EBP Data Bus Analyzer (recommended) JcAIR Instrumentation 400 Industrial Parkway Industrial Airport, KS 66031

429-2 Data Bus Analyzer (alternative) Interface Technology 150 E. Arrow Highway San Dimas, CA 91773

(3) A34011-1 Breakout Box (recommended)
A34011-112 Breakout Box (alternative)

EFIS CP								
DIGITAL OUTPUT BUS CHART								
BUS NAME					BUS	ВІТ		
SOURCE	TYPE	BUS	CON	PINS	FORMAT	ı	DATA BUS	
EFISCP (L R)	Α	1		36 35	429	LO	OUTPUT BUS	

EFFECTIVITY-



EFIS CP ID=C5											
OCTAL LABELS CHART											
SIGNAL	TYPE	LABEL	FORMAT	MIN UPDATE RATE	SDI	BINARY RANGE	POSITIVE SENSE	UNITS			
WXR RANGE	А	271	DIS	10	00	N/A	ALWAYS POSITIVE	N/A			
EFIS DISCRETES #1	Α	272	DIS	5	00	N/A	N/A	N/A			
EFIS DISCRETES #2	Α	273	DIS	5	00	N/A	N/A	N/A			
DH SELECTED-D	Α	170	BCD	5	00	-20,+2500	ABOVE GRND	FEET			
DH SELECTED	Α	370	BNR	5	00	± 16,384	ABOVE GRND	FEET			

EFFECTIVITY-



EFIS CP									
DISCRETE OCTAL LABELS/BIT CHART									
SIGNAL	OCTAL LABEL	BIT	ONE-STATE	ZERO-STATE					
SPARE	271	11	TBD						
SPARE	271	12	TBD						
SPARE	271	13	TBD						
SPARE	271	14	TBD						
SPARE	271	15	TBD						
SPARE	271	16	TBD						
SPARE	271	17	TBD						
SPARE	271	18	TBD						
SPARE	271	19	TBD						
SPARE	271	20	TBD						
SPARE	271	21	TBD						
SPARE	271	22	TBD						
SPARE	271	23	TBD						
10 MI RANGE SEL	271	29-24	000010						
160 MI RANGE SEL	271	29-24	100000						
20 MI RANGE SEL	271	29-24	000100						
320 MI RANGE SEL	271	29-24	000000						
40 MI RANGE SEL	271	29-24	001000						
5 MI RANGE SEL	271	29-24	000001						
80 MI RANGE SEL	271	29-24	010000						

ALL



EFIS CP									
DISCRETE OCTAL LABELS/BIT CHART									
SIGNAL	OCTAL LABEL	BIT	ONE-STATE	ZERO-STATE					
INVALID DATA	271	31–30	01						
SLAVE	271	31–30	11						
TEST	271	31–30	10						
VALID DATA	271	31–30	00						
ILS (MOD) MODE SEL	272	16-11	000100						
MAP MODE SELECTED	272	16-11	000001						
PLAN MODE SELECTED	272	16-11	001000						
ILS (STD) MODE SEL	272	16-11	100000						
VOR (STD) MODE SEL	272	16-11	010000						
VOR (MOD) MODE SEL	272	16-11	000010						
SUM CHECK	272	17	NOT OK	ок					
SPARE	272	18	1	0					
AIRPORTS	272	23–19	10000						
NAV AIDS	272	23-19	00010						
RTE DATA	272	23–19	01000						
SPARE	272	23–19	00001						
WPT	272	23–19	00100						
MAP ORIENT	272	24	TRACK	HDG					

ALL ALL



EFIS CP									
DISCRETE OCTAL LABELS/BIT CHART									
SIGNAL	OCTAL LABEL		ONE-STATE	ZERO-STATE					
VOR/ILS ORIENT	272	25	TRACK	HDG					
APPROACH MODE	272	9–27	001						
FULL COMPASS ROSE	272	29-27	010						
RSV TEST	272	29-27	100						
DEG PITCHREF S/B	273	19–11	NEG	POS 0.100					
DEG PITCHREF	273	19–11	000000001						
0.200 DEG PITCHREF	273	19–11	000000010						
0.400 DEG PITCHREF	273	19–11	000000100						
0.800 DEG PITCHREF	273	19–11	000001000						
RA ALERT RESET	272	26	RESET	NOT RESET					
1.600 DEG PITCHREF	273	19–11	000010000						
12.80 DEG PITCHREF	273	19–11	010000000						
3.200 DEG PITCHREF	273	19–11	000100000						
6.400 DEG PITCHREF	273	19–11	001000000						
FLT PATH DATA	273	20	ON	OFF					
SPARE	273	21	1	0					
SPARE	273	22	1	0					
WXR DATA	273	23	WXR SEL	NOT SEL					
10 MI RANGE SEL	273	29-24	000010						
160 MI RANGE SEL	273	29-24	100000						

ALL



EFIS CP									
DISCRETE OCTAL LABELS/BIT CHART									
SIGNAL	OCTAL LABEL	BIT	ONE-STATE	ZERO-STATE					
20 MI RANGE SEL	273	29-24	000100						
320 MI RANGE SEL	273	29-24	000000						
40 MI RANGE SEL	273	29-24	001000						
5 MI RANGE SEL	273	29-24	000001						
80 MI RANGE SEL	273	29-24	010000						

EFIS SG								
DIGITAL OUTPUT BUS CHART								
BUS NAME					BUS	ВІТ		
SOURCE	TYPE	BUS	CON	PINS	FORMAT	l .	DATA BUS	
EFISSG (L C R)	Α	1	Ε	A13 B13	429	LO	OUTPUT BUS	

ALL ALL



EFIS SG ID=25										
OCTAL LABELS CHART										
SIGNAL	TYPE	LABEL	FORMAT	MIN UPDATE RATE	SDI	BINARY RANGE	POSITIVE SENSE	UNITS		
GROUND SPEED	Α	012	BCD	4	00	0-2000	ALWAYS POS	KNOTS		
FLT DIR-ROLL	Α	140	BNR	4	00	± 180	RIGHT	DEG		
FLT DIR-PITCH	Α	141	BNR	4	00	± 180	UP	DEG		
A/T FAST SLOW CMD	Α	142	BNR	4	00	± 32	OVERSPEED	KNOTS		
RADIO HEIGHT	Α	164	BNR	4	00	± 8192	ABOVE TOUCDN	FEET		
LOCALIZER DEV	Α	173	BNR	4	00	± -4	FLY RIGHT	DDM		
GLIDESLOPE DEV	Α	174	BNR	4	00	± .8	ABOVE BEAM	DDM		
MODE DISCRETES #2	Α	270	DIS	4	00	N/A	N/A	N/A		
AFDS MODE STATUS-3	Α	274	BNR	4	00	N/A	N/A	N/A		
AFDS MODE STATUS-4	Α	275	BNR	4	00	N/A	N/A	N/A		
TRACK ANGLE TRUE	Α	313	BNR	4	00	± 180	CW FROM NOR	DEG		
TRUE HEADING	Α	314	BNR	4	00	± 180	CW FROM NOR	DEG		
TRACK ANGLE-MAG	Α	317	BNR	4	00	± 180	CW FROM NOR	DEG		
MAGNETIC HEADING	Α	320	BNR	4	00	± 180	CW FROM NOR	DEG		
PITCH ANGLE	Α	324	BNR	4	00	± 180	UP	DEG		
ROLL ANGLE	Α	325	BNR	4	00	± 180	RT WING DN	DEG		
EFISSG MAINT WORD	Α	350	DIS	4	00	N/A	N/A	N/A		
CP & DU MAINT WORD	Α	351	DIS	4	00	N/A	N/A	N/A		
SENS STAT MAINT WD	Α	352	DIS	4	00	N/A	N/A	N/A		
MODE DISCRETES #1	Α	353	DIS	4	00	N/A	N/A	N/A		

EFFECTIVITY-

ALL



EFIS SG									
DISCRETE OCTAL LABELS/BIT CHART									
SIGNAL	OCTAL LABEL	BIT	ONE-STATE	ZERO-STATE					
SPARE	270	11	1	0					
SPARE	270	12	1	0					
SPARE	270	13	1	0					
DH ALERT	270	14	ALERT	ок					
DH+DELTA (H) ALERT	270	15	ALERT	ок					
H ALERT	270	16	ALERT	ок					
FMC/IRS GROUND SPD	270	17	FMC	IRS					
FMC/IRS TRACK DATA	270	18	FMC	IRS					
MAG/TRUE DATA	270	19	TRUE	MAG					
SPARE	270	20	1	0					
SPARE	270	21	1	0					
SPARE	270	22	1	0					
SPARE	270	23	1	0					
SPARE	270	24	1	0					

EFFECTIVITY-

ALL



EFIS SG									
DISCRETE OCTAL LABELS/BIT CHART									
SIGNAL	OCTAL LABEL	BIT	ONE-STATE	ZERO-STATE					
SPARE	270	25	1	0					
SPARE	270	26	1	0					
SPARE	270	27	1	0					
SPARE	270	28	1	0					
SPARE	270	29	1	0					
SG OVERTEMP	350	11	FAULT	ОК					
SG MAIN PROCESSOR	350	12	FAULT	ОК					
SG MAIN MEMORY	350	13	FAULT	ОК					
SG DISPLAY DRIVE	350	14	FAULT	ОК					
SG DSPLY SEQUENCER	350	15	FAULT	ОК					
SG CONTROLLER	350	16	FAULT	ОК					
SG DIGTAL OUTPUT	350	17	FAULT	ОК					
SG I/O PROC NO.1	350	18	FAULT	ОК					
SG I/O PROC NO.2	350	19	FAULT	ок					
SG I/O PROC NO.3	350	20	FAULT	ОК					
SPARE	350	21	1	0					



EFIS SG					
DISCRETE OCTAL LABELS/BIT CHART					
SIGNAL	OCTAL LABEL	BIT	ONE-STATE	ZERO-STATE	
SPARE	350	22	1	0	
SPARE	350	23	1	0	
SPARE	350	24	1	0	
SPARE	350	25	1	0	
SPARE	350	26	1	0	
SPARE	350	27	1	0	
SPARE	350	28	1	0	
SPARE	350	29	1	0	
SPARE	351	11	1	0	
L-EADI ANOMALIES	351	12	FAULT	ок	
L-EADI BEAM FAIL	351	13	FAULT	ок	
L-EADI OVERTEMP	351	14	FAULT	ок	
R-EADI ANOMALIES	351	15	FAULT	ок	
R-EADI BEAM FAIL	351	16	FAULT	ок	

EFFECTIVITY-

ALL

34-22-00

02



EFIS SG				
DISCRETE OCTAL LABELS/BIT CHART				
SIGNAL	OCTAL LABEL	BIT	ONE-STATE	ZERO-STATE
R-EADI OVERTEMP	351	17	FAULT	ок
L-EHSI ANOMALIES	351	18	FAULT	ок
L-EHSI BEAM FAIL	351	19	FAULT	ок
L-EHSI OVERTEMP	351	20	FAULT	ок
R-EHSI ANOMALIES	351	21	FAULT	ок
R-EHSI BEAM FAIL	351	22	FAULT	ок
R-EHSI OVERTEMP	351	23	FAULT	ок
L-CP FAULT	351	24	FAULT	ок
R-CP FAULT	351	25	FAULT	ок
SPARE	351	26	1	0
SPARE	351	27	1	0
SPARE	351	28	1	0
SPARE	351	29	1	0
L-FCC DATA FAULT	352	11	FAULT	ок
C-FCC DATA FAULT	352	12	FAULT	ок
R-FCC DATA FAULT	352	13	FAULT	ок
L-FMC DATA FAULT	352	14	FAULT	ок
R-FMC DATA FAULT	352	15	FAULT	ок
TMC DATA FAULT	352	16	FAULT	ок
L-IRS DATA FAULT	352	17	FAULT	ок
C-IRS DATA FAULT	352	18	FAULT	ок
R-IRS DATA FAULT	352	19	FAULT	ок

EFFECTIVITY-



EFIS SG				
DISCRETE OCTAL LABELS/BIT CHART				
SIGNAL	OCTAL LABEL	BIT	ONE-STATE	ZERO-STATE
L-ADC DATA FAULT	352	20	FAULT	ок
R-ADC DATA FAULT	352	21	FAULT	ок
L-VOR DATA FAULT	352	22	FAULT	ок
R-VOR DATA FAULT	352	23	FAULT	ок
L-DME DATA FAULT	352	24	FAULT	ок
R-DME DATA FAULT	352	25	FAULT	ок
RA DATA FAULT	352	26	FAULT	ок
ILS DATA FAULT	352	27	FAULT	ок
MLS DATA FAULT	352	28	FAULT	ок
WXR DATA FAULT	352	29	FAULT	ок
R EADI FAULT	353	12	FAULT	ок
SPARE	353	13	1	0
R CP FAULT	353	15	FAULT	ок
R EHSI FAULT	353	17	FAULT	ок
SG FAULT	353	18	FAULT	ок
SPARE	353	19	1	0
SPARE	353	20	1	0
SPARE	353	21	1	0
SPARE	353	22	1	0
SPARE	353	23	1	0
SPARE	353	24	1	0

ALL



EFIS SG					
DISCRETE OCTAL LABELS/BIT CHART					
SIGNAL	OCTAL LABEL	BIT	ONE-STATE	ZERO-STATE	
SPARE	353	25	1	0	
SPARE	353	26	1	0	
SPARE	353	27	1	0	
SPARE	353	28	1	0	
SPARE	353	29	1	0	

EFFECTIVITY-



STANDBY MAGNETIC COMPASS

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
COMPASS - STANDBY MAGNETIC, N99		1	FLT COMPT, P5	34-23-01

Standby Magnetic Compass - Component Index Figure 101


34-23-00

01


Page 101 Nov 10/94

E58231





FLIGHT COMPARTMENT



STANDBY MAGNETIC COMPASS, N99

Standby Magnetic Compass - Component Location Figure 102 (Sheet 1)

EFFECTIVITY ALL


33653

34-23-00


01

Page 102 Aug 22/03





FLIGHT COMPARTMENT



STANDBY MAGNETIC COMPASS, N99

Standby Magnetic Compass - Component Location Figure 102 (Sheet 2)

34-23-00

01

Page 103 Aug 22/03



STANDBY ATTITUDE REFERENCE SYSTEM

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
CHARGER - ISFD DEDICATED BATTERY, M11331		1	MAIN EQUIPMENT CTR, E1-4 FLT COMPT, P11	34-24-01
ISFD, C2023 2		1	FLT COMPT, P1-3	*
STBY ATT IND, C619 1		1	11A5	*
STBY ILS IND, C604		1	11A9	*
DISPLAY - INTEGRATD STANDBY FLIGHT DISPLAY,		1	FLT COMPT, P1-3	34-24-01
INDICATOR - STANDBY ATTITUDE ILS, N20		1	FLT COMPT, P1	34-24-01
UNIT - STATIC INV/ILS PRCS, M917		1	119AL, MAIN EQUIP CTR, E1-4	34-24-02

^{*} SEE THE WDM EQUIPMENT LIST




Standby Attitude Reference System - Component Index Figure 101


ALL

34-24-00


01

Page 101 Apr 22/03






MAIN EQUIPMENT CENTER



FLIGHT COMPARTMENT



STANDBY ATTITUDE ILS INDICATOR, N20

SAS 1 MTH 275-299: B/CRS (INSTEAD OF INOP)

SAS

Standby Attitude Reference System - Component Location Figure 102

34-24-00

SAS

Page 102 Feb 10/97



MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11A2,11A5,11A9,11B7

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:

ELECTRICAL POWER IS ON (MM 24-22-00/201)

STANDBY ATTITUDE INDICATION PROBLEMS



REPLACE THE STANDBY ATTITUDE INDICATOR, N2O (MM 34-24-01/201).

IF THE PROBLEM CONTINUES, REPLACE THE STATIC INVERTER/ILS PROCESSOR, M917 (MM 34-24-01/201).

Standby Attitude Indication Problems Figure 103

EFFECTIVITY

AIRPLANES WITH STANDBY

ATTITUDE INDICATOR

34-24-00



INSTRUMENT LANDING SYSTEM (ILS)

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
ANTENNA - L DUAL G/S, M250	1	1	111A1, NOSE RADOME	34-31-03
ANTENNA - L DUAL LOC, M248	1	1	111A1, NOSE RADOME	34-31-04
ANTENNA - R/C DUAL G/S, M251	1	1	111A1, NOSE RADOME	34-31-03
ANTENNA - R/C DUAL LOC, M249		1	111A1, NOSE RADOME	34-31-04
CIRCUIT BREAKER -			FLT COMPT, P11	
ILS CENTER, C606		1	11A2	*
ILS LEFT, C603		1	11E10	*
ILS RIGHT, C605		1	11E31	*
INDICATOR - (FIM 34-22-00/101)				
LEFT ELECTRONIC ATTITUDE DIRECTOR, N4				
LEFT ELECTRONIC HORIZ SITUATION, N5				
RIGHT ELECTRONIC ATTITUDE DIRECTOR, N44				
RIGHT ELECTRONIC HORIZ SITUATION, N45				
INDICATOR - (FIM 34-24-00/101)				
STBY ATTITUDE ILS, N20				
PANEL - (FIM 23-51-00/101)				
CAPTAIN AUDIO SELECTOR, M70				
F/O AUDIO SELECTOR, M71				
FIRST OBSERVER AUDIO SELECTOR, M98 PANEL - (FIM 34-22-00/101)				
LEFT EFIS CONTROL, M94				
RIGHT EFIS CONTROL, M93				
PANEL - ILS CONTROL, M87	2	1	FLT COMPT, P8	34-31-02
SYMBOL GENERATOR - (FIM 34-22-00/101)	-	'	TET COM T, TO	34 31 02
CENTER ELECTRONIC FLT INST SYS, M149				
LEFT ELECTRONIC FLT INST SYS, M148				
RIGHT ELECTRONIC FLT INST SYS, M150				
RECEIVER - CENTER ILS, M157	1	1	119AL, MAIN EQUIP CTR, E1-4	34-31-01
RECEIVER - LEFT ILS, M156	1	1	119AL, MAIN EQUIP CTR, E1-3	34-31-01
RECEIVER - RIGHT ILS, M158	1	1	119AL, MAIN EQUIP CTR, E1-5	34-31-01
RELAY - (FIM 31-01-36/101)				
SYS NO. 1 AIR/GND, K124				
RELAY - (FIM 31-01-37/101)				
SYS NO. 2 AIR/GND, K214				
SYS NO. 2 AIR/GND, K293				
UNIT - (FIM 34-24-00/101)				
STATIC INV/ILS PROCESS, M917				

^{*} SEE THE WDM EQUIPMENT LIST

Instrument Landing System (ILS) - Component Index Figure 101

EFFECTIVITY-


34-31-00

01


Page 101 Nov 10/96




FAULT ISOLATION/MAINT MANUAL




GLIDE SLOPE/ LOCALIZER ANTENNAS AND NOSE RADOME, 111AL





ILS CONTROL PANEL, M87



MAIN EQUIPMENT CENTER

B

LEFT, CENTER OR RIGHT ILS RECEIVER, M156, M157, OR M158

ILS AIR TRANSPORT AUTONICS

DATA IN

 \otimes

⊗

 \otimes

TEST

 \otimes

⊗

 \otimes

0

(0)

0

ILS - Component Location
Figure 102 (Sheet 1)


ALL ALL

34-31-00

11


Page 102 Aug 10/90





NOSE RADOME - OPEN





ILS - Component Location (Detatils from Sht 1) Figure 102 (Sheet 2)

EFFECTIVITY-ALL

34-31-00

01


Page 103 Nov 10/96

MAKE SURE THESE SYSTEMS WILL OPERATE: EFIS (MM 34-22-00/501) IRS (MM 34-21-00/501)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11A2,11A9,11E4,11E6,11E10,11E25,11E27,11E31,11F8, 11F9,11F29

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (MM 24-22-00/201)


ILS BITE PROCEDURE



ILS BITE Procedure Figure 103 (Sheet 1)

34-31-00

224702




ILS BITE Procedure Figure 103 (Sheet 2)




ABNORMAL ILS TEST RESPONSE ON CAPT (F/O) EADI & EHSI ELECTRICAL POWER (MM 24-22-00/201)
IRS INITIALIZED (MM 34-21-00/501)
EFIS (MM 34-22-00/501)

CB'S: 11E10,11E31




Abnormal ILS Test Response on Capt (F/O) EADI & EHSI Figure 104





G/S AND LOC FLAGS IN VIEW ON CAPT (F/O) EHSI & EADI ELECTRICAL POWER (MM 24-22-00/201) IRS INITIALIZED (MM 34-21-00/501) EFIS (MM 34-22-00/501)

CB'S: 11E10,11E31



G/S and LOC Flags in View on Capt (F/O) EHSI & EADI Figure 105

EFFECTIVITY-ALL



MAKE SURE THIS SYSTEM WILL OPERATE: EFIS (MM 34-22-00/501)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11E10,11E31

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:

ELECTRICAL POWER IS ON (MM 24-22-00/201) IRS IS ALIGNED (34-21-00/501)

EHSI AND EADI -BOTH G/S AND LOC **DEV POINTERS** MISSING (NCD)

1 REPLACE THE ILS CONTROL PANEL, M87 (MM 34-31-02/401). IF THE PROBLEM CONTINUES, REMOVE THE ILS CONTROL PANEL. REMOVE THE L (R) ILS RECEIVER, M156 (M158) (MM 34-31-01/401). EXAMINE AND REPAIR THE DATA BUS CIRCUIT FROM THE ILS CONTROL PANEL, CONNECTOR D155 (D601), PINS 14 AND 13 TO THE L (R) ILS RECEIVER, CONNECTOR D429B (D377B), PINS B13 AND C13 (WDM 34-31-11,-21).

INSTALL THE ILS CONTROL PANEL AND THE ILS RECEIVER.

EHSI and EADI - Both G/S and LOC Dev Pointers Missing (NCD) Figure 106

EFFECTIVITY-



MAKE SURE THIS SYSTEM WILL OPERATE:
STANDBY ATTITUDE REFERENCE SYSTEM (MM 34-24-00/501)

MAKE SURE THIS CIRCUIT BREAKER IS CLOSED: 11A2

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (MM 24-22-00/201)

FAULTY STANDBY ATTITUDE INDICATOR OPERATION

NO 1 PUSH AND HOLD THE TEST 11 REPLACE THE C ILS SWITCH ON THE CENTER ILS RECEIVER, M157 (MM 34-31-01/ RECEIVER. 401). DOES THE GREEN "ILS" LIGHT COME ON AT THE END OF THE TEST? YES YES REMOVE THE STATIC 12 REPLACE THE STATIC INVERTER/PRCS, M917 INVERTER/ILS PRCS, M917 (MM 34-24-02/401). (MM 34-24-02/401).IF THE PROBLEM CONTINUES, MAKE SURE THE DATA BUS CIRCUIT FROM THE CENTER ILS REPLACE THE STANDBY ATTITUDE RECEIVER IS ACTIVE AT THE INDICATOR, M20 STATIC INVERTER/ILS PRCS CON-(MM 34-24-01/201). NECTOR, D137A, PINS A1 AND B1 (WDM 34-24-11).IS THE BUS ACTIVE? NO 13 REMOVE THE C ILS RECEIVER,

M157 (MM 34-31-01/401).

EXAMINE AND REPAIR THE
DATA BUS CIRCUIT FROM THE
C ILS RECEIVER CONNECTOR,
D417B, PINS C11 AND B11, TO
THE STATIC INVERTER/ILS PRCS
CONNECTOR, D137A, PINS A1 AND
B1 (WDM 34-24-11).

INSTALL THE ILS RECEIVER.
INSTALL THE STATIC INVERTER/
ILS PRCS.

Faulty Standby Attitude Indicator Operation Figure 107



MAKE SURE THIS SYSTEM WILL OPERATE: STANDBY ATTITUDE REFERENCE SYSTEM (MM 34-24-00/501)

MAKE SURE THIS CIRCUIT BREAKER IS CLOSED: 11A2

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (MM 24-22-00/201)

STBY ATT - BOTH DEV POINTERS MISSING (NCD)

REPLACE THE ILS CONTROL PANEL, M87 (MM 34-31-02/401).

IF THE PROBLEM CONTINUES, REMOVE THE ILS CONTROL PANEL. REMOVE THE ILS RECEIVER, M157

(MM 34-31-01/401). REPAIR THE DATA BUS CIRCUIT AS NECESSARY FROM THE ILS CONTROL PANEL CONNECTOR, D603, PINS 13 AND 14, TO THE C ILS RECEIVER CONNECTOR, D417B, PINS B13 AND C13 (WDM 34-31-31).

INSTALL THE ILS CONTROL PANEL. INSTALL THE ILS RECEIVER.

Stby Att - Both Dev Pointers Missing (NCD) Figure 108



MAKE SURE THIS SYSTEM WILL OPERATE:
STANDBY ATTITUDE REFERENCE SYSTEM (AMM 34-24-00/501)

MAKE SURE THIS CIRCUIT BREAKER IS CLOSED: 11A2

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)

LOC (G/S) DEV POINTER MISSING ON STBY ATT IND

REMOVE THE C ILS RECEIVER, 2 INSTALL THE C ILS M157 (AMM 34-31-01/201). RECEIVER, M157 (AMM 34-31-01/ DO THE ANTENNA CABLE CHECK 401). PROCEDURE (AMM 20-10-32/201) REPLACE THE R/C DUAL LOC (G/S) ANTENNA, M249 (M251) AT THE C ILS RECEIVER CONNEC-TOR, D417C, PINS 1 AND C1 (AMM 34-31-03/401; 34-31-04/ (PINS 5 AND C5)(WDM 34-31-31). 401). IS THE ANTENNA CIRCUIT OK? NO 3 REPLACE THE LOC (G/S) ANTENNA CIRCUIT FROM THE C ILS RECEIVER CONNECTOR, D417C, PINS 1 AND C1 (PINS 5 AND C5), TO THE R/C DUAL LOC (G/S) ANTENNA CONNECTOR, D15 (D19), PINS A1 AND C1 (WDM 34-31-31). INSTALL THE C ILS RECEIVER, M157 (AMM 34-31-05/ 401).

> Loc (G/S) Dev Pointer Missing on Stby Att Ind Figure 109

ALL




MAKE SURE THESE SYSTEMS WILL OPERATE: IRS (AMM 34-21-00/501) EFIS (AMM 34-22-00/501)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11E10,11E31

LOC DEV POINTER NOT DISPLAYED

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)



Loc Dev Pointer Not Displayed Figure 110

ALL ALL




MAKE SURE THESE SYSTEMS WILL OPERATE: IRS (AMM 34-21-00/501) EFIS (AMM 34-22-00/501)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11E10,11E31

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)

G/S DEV POINTER NOT DISPLAYED

NOTE: THE GLIDESLOPE DEVIATION POINTER IS REMOVED FROM VIEW ON THE EADI AND EHSI (ILS MODE) WHEN THE DIFFERENCE BETWEEN THE AIRPLANE TRACK ANGLE AND THE SET RUNWAY HEADING IS MORE THAN 90° OR



G/S Dev Pointer Not Displayed Figure 111

ALL

34-31-00

04

Page 113 Nov 10/96

MAKE SURE THESE SYSTEMS WILL OPERATE: EFIS (AMM 34-22-00/501) ILS (AMM 34-31-00/501)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11A2,11E10,11E31

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201) IRS INITIALIZED (AMM 34-21-00/501)

G/S - FALSE OR LATE CAPTURE

YES 1 OPEN THE NOSE RADOME 30 REPLACE THE G/S DIRECTOR (AMM 53-12-01/201). ELEMENT (AMM 53-12-05/401). DO A CHECK ON THE G/S DIRECTOR ELEMENT (AMM 34-31-03/401).IS THE G/S DIRECTOR ELE-MENT LOOSE OR DAMAGED? NO YES 31 REPLACE THE INDICATED DO A CHECK ON THE MCDP 10 DO THE ANTENNA CABLE CHECK FLIGHT FAULTS PROCEDURE (AMM 20-10-32/201) L (C,R) DUAL G/S ANTENNA (AMM 22-00-02/101 FIG. 101). FOR THE APPLICABLE L (C,R) ILS (M248, LEFT)(M251, RIGHT OR IS THE MCDP MESSAGE, "ILS RECEIVER, CONNECTOR D429C CENTER)(AMM 34-31-03/401). G/S NCD" SHOWN? (D417C,D377C), PINS 5, AND C5. IS THE ANTENNA CABLE OK? NO NO 32 REMOVE THE L (C,R) ILS RECEIVER, M156 (M157,M158) (AMM 34-31-01/401).EXAMINE THE CIRCUIT FROM THE APPLICABLE L (C,R) ILS RECEIVER, CONNECTOR D429C (D417C,D377C), PINS 5,C5, TO DUAL G/S ANTENNA, CONNECTOR D17 (D19,D21)(WDM 34-31-11, -21,-31). REPAIR THE PROBLEMS THAT YOU FIND. INSTALL THE ILS RECEIVER. YES 3 IS ONE OF THESE MCDP 33 REPLACE THE APPLICABLE MESSAGES SHOWN? L (C,R) ILS RECEIVER, M156 (M157,M158)(AMM 34-31-01/401). ILS L ILS C ILS R NO SEE SHEET 2 (BLOCK 4)

> G/S - False or Late Capture Figure 111A (Sheet 1)


ALL

O1 Page 114

Aug 22/99

BOEING PROPRIETARY - Copyright (C) - Unpublished Work - See title page for details.





G/S - False or Late Capture Figure 111A (Sheet 2)



1. ARINC Data Bus Charts

A. General

CAUTION: DO NOT DIRECTLY TOUCH THE CONNECTORS. USE A BREAKOUT BOX OR DAMAGE TO THE CONNECTORS CAN OCCUR.

- (1) ARINC 429 data bus charts give the necessary data to analyze ARINC 429 transmitters, receivers, and data buses. To do the test, use terminal blocks, or at the LRU connectors use a breakout box.
- B. Equipment
 - (1) Standard multi-meter
 - (2) Data Bus Analyzer 429EBP; JcAIR Instrumentation (preferred)
 400 Industrial Parkway,
 Industrial Airport, KS 66031
 - 429EBP; Interface Technology (optional) 150 E. Arrow Highway, San Dimas, CA 91773
 - (3) Breakout box A34011-1 (preferred)
 A34011-112 (optional)

ILS												
DIGITAL OUTPUT BUS CHART												
BUS NAME					BUS	ВІТ	DATA					
SOURCE	TYPE	BUS	CON	PINS	FORMAT		BUS					
ILS (L C R)	Α	1	В	в07 с07	429	L0	ILS OUTPUT #1					
ILS (L C R)	Α	2	В	B11 C11	429	LO	ILS OUTPUT #2					

ILS ID = 010													
OCTAL LABELS CHART													
SIGNAL	TYPE	LABEL	FORMAT	MIN UPDATE RATE	SDI	BINARY RANGE	POSITIVE SENSE	UNITS					
SEL RUNWAY HDG-D	Α	017	BCD	5	00	0-359	ALWAYS POS	DEC					
ILS FREQUENCY	Α	033	BCD	5	00	108-111.95	ALWAYS POS	MHZ					
LOCALIZER DEV	Α	173	BNR	16	00	+4	FLY RIGHT	DDM					
GLIDESLOPE DEV	Α	174	BNR	16	00	+8	FLY DOWN	DDM					



ILS											
DISCRETE OCTAL LABELS/BIT CHART											
SIGNAL	OCTAL LABEL	BIT	ONE-STATE	ZERO-STATE							
TUNE INHIBIT	173	11	INHIBIT	NORMAL							
TUNE INHIBIT	174	11	INHIBIT	NORMAL							

ILS CF	ILS CP												
	DIGITAL OUTPUT BUS CHART												
						BUS	ВІТ	DATA					
SOURCE			TYPE	BUS	CON	PINS		FORMAT		BUS			
ILSCP	(С)	Α	1		14	13	429	LO	ILS FREQ-L		
ILSCP	(С)	Α	2		14	13	429	LO	ILS FREQ-R		
ILSCP	(С)	Α	3		14	13	429	LO	ILS FREQ-C		

ILS CP ID=0B0													
OCTAL LABELS CHART													
SIGNAL TYPE LABEL FORMAT RATE SDI BINARY POSITIV													
SEL RUNWAY HDG-D	Α	017	BCD	5	00	0-359	CW FROM N	DEC					
ILS FREQUENCY	Α	033	BCD	5	00	108-111.95	ALWAYS POS	MHZ					
DME FREQUENCY	Α	035	BCD	5	00	108-135.95	ALWAYS POS	MHZ					

EFFECTIVITY-

ALL



MARKER BEACON SYSTEM

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
ANTENNA - MARKER BEACON, M243		1	BOTTOM FWD FUSELAGE	34-32-01
CIRCUIT BREAKER			FLT COMPT, P11	*
VOR/MKR L, C595		1	11A1	*
LIGHT - CAPT INNER MARKER BEACON LIGHT, L585		1	FLT COMPT, P1	*
LIGHT - CAPT MIDDLE MARKER BEACON LIGHT, L586		1	FLT COMPT, P1	*
LIGHT - CAPT OUTER MARKER BEACON LIGHT, L587		1	FLT COMPT, P1	*
LIGHT - F/O INNER MARKER BEACON LIGHT, L588		1	FLT COMPT, P3	*
LIGHT - F/O MIDDLE MARKER BEACON LIGHT, L589		1	FLT COMPT, P3	*
LIGHT - F/O OUTER MARKER BEACON LIGHT, L590		1	FLT COMPT, P3	*
PANEL - (REF 23-51-00, FIG. 101)				
CAPTAIN AUDIO SELECTOR, M70				
F/O AUDIO SELECTOR, M71				
FIRST OBSERVER AUDIO SELECTOR, M98				
RECEIVER - LEFT VOR/MKR, M186		1	119AL, MAIN EQUIP CTR, E2-2	34-51-01

^{*} SEE THE WDM EQUIPMENT LIST

Marker Beacon System - Component Index Figure 101

EFFECTIVITY-

ALL


34-32-00

01

Page 101 May 10/96



FAULT ISOLATION/MAINT MANUAL



Component Location Figure 102

34-32-00

04

Page 102 Apr 22/02

183122



MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11A1, 11C25, 11C26, 11G29, 11G30, 11R3

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)

MARKER BEACON PROBLEM

YES PUSH AND HOLD THE TEST 21 REPLACE THE LEFT VOR/MKR RECEIVER, M186 (AMM 34-51-01/ SWITCH ON THE FRONT PANEL OF THE LEFT VOR/MKR RECEIVER. 401). DOES THE RED "MKR" TEST LIGHT STAY ON AT THE END OF THE TEST? NO DO ALL THE MARKER BEACON 11 DOES THE FAILURE OCCUR ON 22 REPLACE THE LEFT VOR/MKR LIGHTS, ON THE CAPT'S AND THE CAPT'S AND F/O'S MARKER RECEIVER, M186 (AMM 34-51-01/ F/O'S INSTRUMENT PANELS, COME BEACON LIGHTS? 401). ON WHILE THE TEST SWITCH IS HELD? 23 REPLACE THE APPLICABLE YES CAPT (F/O) MARKER BEACON LIGHT ASSY, L585, L586, L587 (L588, L589,L590)(AMM 33-16-02/201). YES 24 INSTALL THE LEFT VOR/MKR 12 REMOVE THE LEFT VOR/MKR RECEIVER, M186 (AMM 34-51-01/ RECEIVER, M186 (AMM 34-51-01/ 401). 401). DO THE ANTENNA CABLE CHECK REPLACE THE MARKER BEACON PROCEDURE (AMM 20-10-32/201) ANTENNA, M243 (AMM 34-32-01/ AT THE LEFT VOR/MKR RECEIVER, 401). CONNECTOR D329C, PINS 5 AND C5 (WDM 34-32-11).IS THE MARKER BEACON ANTENNA CABLE OK? NO 25 REPLACE THE MARKER BEACON ANTENNA CABLE CIRCUIT FROM THE LEFT VOR/MKR RECEIVER, CONNEC-TOR D329C, PINS 5 AND C5, TO THE MARKER BEACON ANTENNA, CONNECTOR D83, PINS A1 AND C1 (WDM 34-32-11).INSTALL THE LEFT VOR/MKR RECEIVER, M186 (AMM 34-51-01/

Marker Beacon Problem Figure 103

34-32-00



RADIO ALTIMETER SYSTEM

	FIG. 102			
COMPONENT	SHT	QTY	ACCESS/AREA	REFERENCE
ANTENNA - RADIO ALTIMETER RECEIVER, M253, M255,M257		3	BOTTOM FORWARD FUSELAGE	34-33-02
ANTENNA - RADIO ALTIMETER TRANSMITTER, M252,M254,M256		3	BOTTOM FORWARD FUSELAGE	34-33-02
CIRCUIT BREAKERS -			FLIGHT COMPARTMENT, P11	
RAD ALTM CENTER, C602		1	11F20	*
RAD ALTM DIGUT		1	11F5	*
RAD ALTM RIGHT, C601 COMPUTER - (REF 34-41-00, FIG. 101) LEFT EICAS, M10181 RIGHT EICAS, M10182		1	11F26	*
INDICATOR - (REF 34-22-00, FIG. 101) LEFT ELECTRONIC ATTITUDE DIRECTOR, N4 RIGHT ELECTRONIC ATTITUDE DIRECTOR, N44				
RELAY - (REF 31-01-36, FIG. 101) SYS NO. 1 AIR/GND, K124				
SYS NO. 2 AIR/GND, K214 SYS NO. 2 AIR/GND, K293				
SYMBOL GENERATOR - (REF 34-22-00, FIG. 101) CENTER EFIS, M149				
LEFT EFIS, M148 RIGHT EFIS, M150 TRANSMITTER (DECEMBER CONTER DAD ALTM M20/		1	924 FUD CARCO COMPT FE 4	7/ 77 02
TRANSMITTER/RECEIVER - CENTER RAD ALTM, M204 TRANSMITTER/RECEIVER - LEFT RAD ALTM, M202	==	1 1	821, FWD CARGO COMPT, E5-1 821, FWD CARGO COMPT, E5-1	34-33-02 34-33-02
TRANSMITTER/RECEIVER - RIGHT RAD ALTM, M203		1	821, FWD CARGO COMPT, E5-1	34-33-02

^{*} SEE THE WDM EQUIPMENT LIST

Radio Altimeter System - Component Index Figure 101


EFFECTIVITY-

34-33-00


01

Page 101 Aug 10/97





LEFT, RIGHT OR CENTER RADIO ALTIMETER ANTENNA, M252,M253,M254,M255,M256,M257 (EXAMPLE)



LEFT, RIGHT OR CENTER RADIO ALTIMETER RECEIVER/TRANSMITTER, M202,M203 OR M204

Radio Altimeter System - Component Location Figure 102

EFFECTIVITY-ALL

34-33-00

07

Page 102 Nov 10/90




MAKE SURE THIS SYSTEM WILL OPERATE: EFIS (AMM 34-22-00/501)

RADIO ALTITUDE
HEIGHT ON THE CAPT
(F/O) EADI IS
INACCURATE

35125

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11F5,11F20,11F26

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)



Radio Altitude Height on the Capt (F/O) EADI Is Inaccurate Figure 103

ALL

O1 Page 103

May 10/93


BOEING PROPRIETARY - Copyright (C) - Unpublished Work - See title page for details.



MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11A7,11E3,11E4,11E24,11E25,11F5,11F8,11F9,11F20, 11F24,11F26,11F29

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)

RA FLAG DISPLAYED ON CAPT (F/O) EADI



RA Flag Displayed on Capt (F/O) EADI Figure 104


ALL 34-33-00
ALL 10 Page 104
Dec 22/00



MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11A7, 11E3, 11E4, 11E24, 11E25, 11F5, 11F8, 11F9, 11F20, 11F24, 11F26, 11F29

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)

RA BITE PROCEDURE




RA BITE Procedure Figure 104A (Sheet 1)


34-33-00

07

Page 105 Dec 22/00



RA BITE Procedure Figure 104A (Sheet 2)





1. ARINC Data Bus Charts

A. General

<u>CAUTION</u>: DO NOT DIRECTLY TOUCH THE CONNECTORS. USE A BREAKOUT BOX OR YOU CAN CAUSE DAMAGE TO THE CONNECTORS.

(1) The ARINC 429 data bus gives data necessary to make analysis of ARINC 429 transmitters, receivers, and data buses. For the test, use a breakout box at the available terminals or at the LRU connector.

B. Equipment

- (1) Standard multi-meter
- (2) 429EBP Data Bus Analyzer (recommended) JcAIR Instrumentation 400 Industrial Parkway Industrial Airport, KS 66031

429-2 Data Bus Analyzer (alternative) Interface Technology 150 E. Arrow Highway San Dimas, CA 91773

(3) A34011-1 Breakout Box (recommended)
A34011-112 Breakout Box (alternative)

RA													
	DIGITAL OUTPUT BUS CHART												
	BUS NAME					BUS	ВІТ						
	SOURCE	TYPE	BUS	CON	PINS	FORMAT		DATA BUS					
RA	(L C R)	Α	1	В	в02 в03	429	LO	ALTITUDE #1					
RA	(L C R)	Α	2	В	G02 G03	429	LO	ALTITUDE #2					

RA ID = 07												
OCTAL LABELS CHART												
SIGNAL	TYPE	LABEL	FORMAT	MIN UPDATE RATE	SDI		BINARY RANGE	POSITIVE SENSE	UNITS			
RADIO HEIGHT	Α	164	BNR	20	XX	±	8192	ABOVE TOUCHDN	FEET			
RADIO HEIGHT-D	Α	165	BCD	5	XX	±	7999.9	ABOVE TOUCHDN	FEET			

EFFECTIVITY-

34-33-00



RA							
DISCRETE OCTAL LABELS/BIT CHART							
SIGNAL	OCTAL LABEL	BIT	ONE-STATE	ZERO-STATE			
TEST INHIBITED	164	11	INHIBIT	NOT INHIBIT			

 34-33-00

05

Page 108 Nov 10/96



WEATHER RADAR SYSTEM

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
ANTENNA - WEATHER RADAR, M269	2	1	111AL, NOSE RADOME	34-43-05
ASSEMBLY - WAVEGUIDE	2	1	113AL, FORWARD BULKHEAD	34-43-04
CIRCUIT BREAKERS	1		FLIGHT COMPARTMENT, P11	
WX RADAR L, C615		1	11F2	*
WX RADAR R, C599		1	11F23	*
PANEL - (REF 34-22-00, FIG. 101)				
LEFT EFIS CONTROL, M94				
RIGHT EFIS CONTROL, M93				
PANEL - WEATHER RADAR CONTROL, M75	1	1	FLIGHT COMPARTMENT, P8	34-43-02
SWITCH - WAVEGUIDE, S36	2	1	113AL, FORWARD BULKHEAD	34-43-04
SWITCH - (REF 34-22-00, FIG. 101)				
LEFT IRS, S4				
RIGHT IRS, S12				
TRANSCEIVER - WEATHER RADAR, M213,M214	2	2	113AL, FWD EQUIP CTR	34-43-01

^{*} SEE THE WDM EQUIPMENT LIST


Weather Radar System - Component Index Figure 101


EFFECTIVITY-

750135

34-43-00







WEATHER RADAR ANTENNA AND WAVEGUIDE, M269



1> IF INSTALLED

Weather Radar System - Component Location Figure 102A (Sheet 1)

BOEING PROPRIETARY - Copyright (C) - Unpublished Work - See title page for details.


ALL ALL

34-43-00

06

Page 102 Apr 22/02





Weather Radar System - Component Location Figure 102A (Sheet 2)

ALL


O8

Page 103

Apr 22/02

BOEING PROPRIETARY - Copyright (C) - Unpublished Work - See title page for details.





WEATHER RADAR TRANSCEIVER, M213, M214 (ALLIEDSIGNAL RDR-4A)



Weather Radar System - Component Location Figure 102A (Sheet 3)

EFFECTIVITY-ALL

34-43-00

04

Page 104 Apr 22/02



PREREQUISITES

MAKE SURE THESE SYSTEMS WILL OPERATE: IRS (MM 34-21-00/501) EFIS (MM 34-22-00/501) WXR (MM 34-43-00/501)

FMCS (MM 34-61-00/501)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11F2,11F23


MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:

ELECTRICAL POWER IS ON (MM 24-22-00/201)

WARNING: WHEN YOU DO THE BITE TEST, MAKE SURE YOU SET THE WXR CONTROL TO A NON-RADIATING TEST MODE OR OBEY THE PRECAUTIONS FOR WXR OPERATION IN A RADIATION MODE. IF YOU DO NOT DO ONE OF THESE ALTERNATIVES, INJURY TO PERSONS CAN OCCUR.


WXR BITE PROCEDURE

76032



WXR BITE Procedure Figure 103 (Sheet 1)

EFFECTIVITY-34-43-00 ALL 09 Page 105



WXR BITE Procedure Figure 103 (Sheet 2)


EFFECTIVITY-ALL

76079

34-43-00

07

Page 106 Dec 22/99



WXR BITE Procedure Figure 103 (Sheet 3)

ALL

O8
Page 107
Dec 22/99

BOEING PROPRIETARY - Copyright (C) - Unpublished Work - See title page for details.



PREREQUISITES

MAKE SURE THESE SYSTEMS WILL OPERATE:
IRS (AMM 34-21-00/501)
EFIS (AMM 34-22-00/501)
WXR (AMM 34-43-00/501)
FMCS (AMM 34-61-00/501)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11F2

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)

WARNING:

DO NOT OPERATE WEATHER RADAR WHILE FUEL IS ADDED OR REMOVED FROM THE AIRPLANE. DO NOT TRANSMIT RF ENERGY WHILE FUEL IS ADDED OR REMOVED IN AN AREA 300 FEET OR LESS OR THE ANTENNA. THIS CAN CAUSE AN EXPLOSION.

MAKE SURE NO PERSONS ARE IN THE AREA 15 FEET OR LESS FROM THE ANTENNA WHEN IT TRANSMITS RF ENERGY. RF ENERGY CAN CAUSE INJURY TO PERSONS.

WXR Range Disagree Problems Figure 104 (Sheet 1)

EFFECTIVITY-

34-43-00


ALL

11

Page 108 Apr 22/03



WXR RANGE DISAGREE PROBLEMS



WXR Range Disagree Problems Figure 104 (Sheet 2)

ALL 22 Page 109
Apr 22/03

BOEING PROPRIETARY - Copyright (C) - Unpublished Work - See title page for details.

PREREQUISITES

MAKE SURE THESE SYSTEMS WILL OPERATE:
 ADC (AMM 34-12-00/501)
 IRS (AMM 34-21-00/501)
 EFIS (AMM 34-22-00/501)
 RA (AMM 34-33-00/501)
 TCAS (AMM 34-43-00/501)
 TCAS (AMM 34-45-00/501)
 ATC (AMM 34-53-00/501)
 ATC (AMM 34-53-00/501)
 FMCS (AMM 34-61-00/501)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:
 11F2

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:

ELECTRICAL POWER IS ON (AMM 24-22-00/201)

WEATHER RADAR
BITE PROCEDURE FOR
EXTERNAL FAULTS
(WITH "ANTENNA TILT"
FAULT MESSAGES)



1 AIRPLANES WITH OPERATIONAL PREDICTIVE WINDSHEAR SYSTEM (PWS)

Weather Radar Bite Procedure for External Faults
(With "Antenna Tilt" Fault Messages)
Figure 105 (Sheet 1)

34-43-00

20

Page 110 Apr 22/03



EXTERNAL FAULTS	WXR ANTENNA TILT CODE MESSAGES 1
ATTITUDE - LEFT	-1
ATTITUDE - RIGHT	+1
RADIO ALTITUDE - LEFT	-2
RADIO ALTITUDE - RIGHT	+2
DADC - LEFT	-3
DADC - RIGHT	+3
EFIS - LEFT	-4
EFIS - RIGHT	+4
DISCRETE QUALIFIER INPUTS	-5
PITCH/ROLL INPUTS OR AIR GROUND DISCRETE INPUT	-6
AIR GROUND DISCRETE INPUT	-7
WINDSHEAR INHIBIT INPUT	-8

ANTENNA TILT CODES FOR RADAR EXTERNAL FAULTS

1 WINDSHEAR POP-UP MODE WILL IMMEDIATELY EXIT THE SELF-TEST SEQUENCE.

Weather Radar Bite Procedure for External Faults
(With "Antenna Tilt" Fault Messages)
Figure 105 (Sheet 2)

EFFECTIVITY-




PREREQUISITES

MAKE SURE THESE SYSTEMS ARE OPERATIONAL: ADC (AMM 34-12-00/501) IRS (AMM 34-21-00/501) EFIS (AMM 34-22-00/501) RA (AMM 34-33-00/501) WXR (AMM 34-43-00/501) EGPWS (AMM 34-46-00/501)


WXR TILT CODE FAULT **ISOLATION**

WHEN YOU DO THE BITE TEST, MAKE SURE THAT WARNING: YOU OBEY THE PRECAUTIONS FOR WEATHER RADAR OPERATION IN THE RADIATION MODE. INJURY




WXR Tilt Code Fault Isolation Figure 106 (Sheet 1)

EFFECTIVITY-ALL



WXR Tilt Code Fault Isolation Figure 106 (Sheet 2)

EFFECTIVITY-ALL




WXR Tilt Code Fault Isolation Figure 106 (Sheet 3)

EFFECTIVITY-ALL

34-43-00

15

Page 114 Apr 22/03




WXR Tilt Code Fault Isolation Figure 106 (Sheet 4)

EFFECTIVITY-ALL

34-43-00

14

Page 115 Apr 22/03




WXR Tilt Code Fault Isolation Figure 106 (Sheet 5)

34-43-00


12

Page 116 Apr 22/03



WXR Tilt Code Fault Isolation Figure 106 (Sheet 6)

EFFECTIVITY-ALL



WXR Tilt Code Fault Isolation Figure 106 (Sheet 7)

ALL ALL

34-43-00

10

Page 118 Apr 22/03



1. <u>Visual Check</u>

A. Procedure

- (1) Do a visual check of the weather radar LRUs below and make sure that the LRUs have no damage or missing hardware and that the mount screws are tight.
 - (a) R/T mount
 - (b) Antenna drive assembly
 - (c) Antenna planar array
 - (d) Antenna
 - (e) Control Panel
- (2) Make sure the R/T hold-down screws are tight.
- (3) Make sure the system electrical connectors are connected correctly.
- (4) Make sure the waveguide connection to the antenna drive assembly is attached correctly.
- (5) Make sure there are no dirt or foreign objects in the waveguide drain hole.

NOTE: The drain hole may be checked when there is a suspected problem with R/T sensitivity or the weather radar display is blank.

EFFECTIVITY-

34-43-00

ALL



2. ARINC 429 Data Bus

A. <u>General</u>

(1) The ARINC 429 data bus gives data necessary to make an analysis of ARINC 429 transmitters, receivers, and data buses. For the test, use a breakout box at the available terminals of the LRU unit.

CAUTION: DO NOT DIRECTLY TOUCH THE CONNECTORS. USE A BREAKOUT BOX. IF YOU TOUCH THE CONNECTORS, DAMAGE TO EQUIPMENT CAN OCCUR.

B. <u>Equipment</u>

- (1) Standard multi-meter
- (2) Data Bus Analyzer 429EBP
 - JcAIR Instrumentation (recommended) 400 Industrial Parkway, Industrial Airport, KS 66031
 - Interface Technology (alternative) (b) 150 E. Arrow Highway, San Dimas, CA 91773
- (3) Breakout box
 - (a) A34011-1 (recommended)
 - (b) A34011-112 (alternative)

EFFECTIVITY-

34-43-00

ALL

13



WXR CP										
DIGITAL OUTPUT BUS CHART										
BUS NAME					DUC	ВІТ				
SOURCE	TYPE	BUS	CON	PINS	BUS FORMAT		DATA BUS			
WXR CP(L)	А	1	D395	UF	429	L0	OUTPUT BUS L			
WXR CP(L)	A	2	D395	HJ	429	LO	OUTPUT BUS R			
WXR CP(R)	A	1	D495	UF	429	LO	OUTPUT BUS L			
WXR CP(R)	А	2	D495	нЈ	429	L0	OUTPUT BUS R			



WXR CP ID = 23										
OCTAL LABELS CHART										
SIGNAL TYPE LABEL FORMAT RATE SDI RANGE SENSE UNI								UNITS		
GAIN	Α	270	BNR	10	00	N/A	N/A	dB		
TILT	Α	270	BNR	10	00	± 15	UP	DEG		

ALL



WXR CP										
DISCRETE OCTAL LABELS/BIT CHART										
SIGNAL	OCTAL LABEL	ВІТ	ONE-STATE	ZERO-STATE						
STABILIZATION ON	270	13	CODED 1							
MAP	270	16-14	CODED 010							
TEST	270	16-14	CODED 100							
WEATHER	270	16-14	CODED 001							



TRAFFIC ALERT AND COLLISION AVOIDANCE SYSTEM (TCAS)

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
ANTENNA - BOTTOM TCAS, M1707	1	1	BOTTOM OF FUSELAGE	34-45-02
ANTENNA - TOP TCAS, M1706	1	1	TOP OF FUSELAGE	34-45-02
CIRCUIT BREAKER -			FLIGHT COMPARTMENT, P11	
TCAS, C628		1	11F12	*
COMPUTER - (FIM 31-41-00/101)				
EICAS LEFT, M10181 EICAS RIGHT, M10182				
COMPUTER - (FIM 34-46-00/101)				
GROUND PROXIMITY, M147				
COMPUTER - TCAS, M1705	2	1	119BL, MAIN EQUIP CENTER, E1-3	34-45-01
INDICATOR - (FIM 34-22-00/101)				
LEFT ELECTRONIC HORIZONTAL SITUATION, N5				
LEFT VERTICAL SPEED, N9				
RIGHT ELECTRONIC HORIZONTAL SITUATION, N44				
RIGHT VERTICAL SPEED, N49				
INTERROGATOR - (FIM 34-55-00/101)				
LEFT DME, M123 RIGHT DME, M124				
MODULE - (FIM 31-51-00/101)				
LEFT SIREN/OWL (AURAL WARNING), M999				
RIGHT SIREN/OWL (AURAL WARNING), M619				
MODULE - (FIM 32-30-00/101)				
LANDING GEAR LEVER, M937				
PANEL - ATC CONTROL, M81	2	1	FLIGHT COMPARTMENT, P8	34-53-02
RELAY (FIM 31-01-36/101)				
SYS NO. 1 AIR/GND, K143				
RELAY (FIM 31-01-37/101) SYS NO. 2 AIR/GND, K201				
SWITCH - (FIM 34-12-00/101)				
LEFT ADC, S482				
RIGHT ADC, S483				
SWITCH - (FIM 34-21-00/101)				
IRS SOURCE SELECT, S12				
SYMBOL GENERATOR - (FIM 34-22-00/101)				
CENTER EFIS, M149				
LEFT EFIS, M148 RIGHT EFIS, M150				
TRANSPONDER - (FIM 34-53-00/101)				
LEFT ATC, M112				
RIGHT ATC, M113				
UNIT - (FIM 31-31-00/101)				
FLT DATA ACQUISITION, M138				

^{*} SEE THE WDM EQUIPMENT LIST

Traffic Alert and Collision Avoidance System (TCAS) - Component Index Figure 101


EFFECTIVITY-


34-45-00

05H

Page 101 May 10/95







BOTTOM OR TOP TCAS DIRECTIONAL ANTENNA, M1707 OR M1706



Traffic Alert and Collision Avoidance System (TCAS) - Component Location Figure 102 (Sheet 1)


B50200

34-45-00


04H

Page 102 Feb 10/94







FLIGHT COMPARTMENT



MAIN EQUIPMENT CENTER



TCAS/ATC CONTROL PANEL, M81



TCAS COMPUTER, M1705

Traffic Alert and Collision Avoidance System (TCAS) - Component Location Figure 102 (Sheet 2)

34-45-00

06H

Page 103 Apr 22/02


PREREQUISITES

MAKE SURE THESE SYSTEMS WILL OPERATE:
ATC SYSTEM (AMM 34-53-00/501)
EFIS SYSTEM (AMM 34-22-00/501)
IRS SYSTEM (AMM 34-21-00/501)
RA SYSTEM (AMM 34-33-00/501)

MAKE SURE THIS CIRCUIT BREAKER IS CLOSED: 11F12, TCAS

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201) ALIGN IRS (AMM 34-21-00/201)

TCAS BITE PROCEDURE




TCAS BITE Procedure Figure 103 (Sheet 1)

34-45-00

04H

Page 104 Feb 10/94




TCAS BITE Procedure Figure 103 (Sheet 2)

34-45-00

04H

Page 105 Feb 10/94




TCAS BITE Procedure Figure 103 (Sheet 3)

EFFECTIVITY-ALL

34-45-00






TCAS BITE Procedure Figure 103 (Sheet 4)

ALL

O5H Page 107

May 10/96

BOEING PROPRIETARY - Copyright (C) - Unpublished Work - See title page for details.



TCAS BITE Procedure Figure 103 (Sheet 5)

ALL ALL

34-45-00

04H

Page 108 Feb 10/94



PREREQUISITES

MAKE SURE THESE SYSTEMS WILL OPERATE: ATC SYSTEM (AMM 34-53-00/501)

WEU SYSTEM (AMM 31-51-00/501)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:

11B16, WARN SPKR L

11B18, WARN ELEX B

11E5, VSI LEFT

11E26, VSI RIGHT

11F12, TCAS

11H35, WARN SPKR R

11J34, WARN ELEX A

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201) ALIGN IRS (AMM 34-21-00/201)

TCAS VOICE ADVISORY ALERT PROBLEM

1 HOLD THE MOLD SWITCH ON
THE ATC CONTROL PANEL TO THE
TEST POSITION FOR ABOUT
2 SECONDS.
DOES THE COCKPIT SPEAKERS
OR HEADSET SOUND "TCAS TEST
PASS"?

YES

2 THE TCAS VOICE ADVISORY
ALERT IS OK.

20 REPLACE THE TCAS COMPUTER,
M1705 (AMM 34-45-01/401).
IF THE PROBLEM CONTINUES,
REPLACE THE LEFT AURAL WARNING
SIREN/OWL MODULE, M999.
EXAMINE THE CIRCUIT FROM
THE TCAS COMPUTER, CONNECTOR
D2463E, PINS F3 AND G3, TO THE
LEFT AURAL WARNING SIREN/OWL
MODULE, CONNECTOR D811,
PINS 62 AND 63.
REPAIR THE PROBLEMS THAT
YOU FIND.

TCAS Voice Advisory Alert Problem Figure 104

34-45-00

05H

Page 109 May 10/96



1. ARINC Data Bus Charts

A. General

<u>CAUTION</u>: DO NOT DIRECTLY TOUCH THE CONNECTORS. USE A BREAKOUT BOX OR CAN CAUSE DAMAGE TO THE CONNECTORS.

- (1) The ARINC 429 data bus charts give data necessary to make an analysis of ARINC 429 transmitters, receivers, and data buses. For the test, use a breakout box at the available terminal or at the LRU connectors.
- B. Equipment
 - (1) Standard multimeter
 - (2) 429EBP Data Bus Analyzer (recommended) JcAIR Instrumentation 400 Industrial Parkway Industrial Airport, KS 66031

429EBP Data Bus Analyzer (alternative) Interface Technology 150 E. Arrow Highway, San Dimas, CA 91773

(3) A34011-1 Breakout Box (recommended)
A34011-112 Breakout Box (alternative)

EFFECTIVITY-

34-45-00

04H



TCAS COMPUTER										
DIGITAL OUTPUT BUS CHART										
BUS NAME				BUS	ВІТ					
SOURCE	TYPE	BUS	CON	PINS	FORMAT	:	DATA BUS			
TCAS	Α	1	RMP	15J 15K	429	ні	COORDINATION DATA			
TCAS	Α	2	RMP	14A 14B	429	ні	COORDINATION DATA			
TCAS	Α	1	RMP	7C 7D	429	ні	TA/RA DISPLAY #1			
TCAS	А	2	RMP	7G 7H	429	ні	TA/RA DISPLAY #2			

TCAS COMPUTER ID=035										
OCTAL LABELS CHART										
SIGNAL TYPE LABEL FORMAT RATE SDI RANGE SENSE UNI								UNITS		
INTRUDER ALTITUDE	Α	131	BCD	2	00	± 12,700	N/A	FEET		
INTRUDER BEARING	Α	132	BCD	2	00	± 180	N/A	DEGREES		
INTRUDER RANGE	Α	130	BCD	2	00	128	N/A	NM		
OWN AIRCRAFT ALT	Α	203	BCD	2	00	131,072	N/A	FEET		

34-45-00

ALL

Page 111 04H Nov 10/96



GROUND PROXIMITY WARNING SYSTEM

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
CIRCUIT BREAKER -	2		FLT COMPT, P11	
GND PROX, C592		1	11F4	*
COMPUTER - GROUND PROXIMITY WARNING, M147	1	1	119AL, MAIN EQUIP CTR, E1-5	34-46-01
LIGHT - PULL UP	2	1	FLT COMPT, P1, DISCRETE WARNING DISPLAY MODULE, M779 (REF)	*
LIGHT - WINDSHEAR, L890	2	1	FLT COMPT, P1-3	
MODULE - (FIM 33-16-00/101)				
DISCRETE WARNING DISPLAY, M779				
MODULE - (FIM 32-30-00/101)				
LANDING GEAR CONTROL LEVER, M937				
MODULE - (FIM 27-58-00/101)				
LEFT FLAP/STAB POSITION, M838				
PANEL - (FIM 28-43-00/101)				
MISCELLANEOUS TEST, M10398				
RELAY - (FIM 31-01-36/101)				
SYSTEM 1 AIR/GROUND, K149	_	١.		
SWITCH - GND PROX TEST, YEIS4	2	1	FLT COMPT, P61, MISC TEST PANEL, M10398 (REF)	*
SWITCH-LIGHT - GND PROX/CONFIG GEAR OVRD, S604	2	1	FLT COMPT, P3-1	*
SWITCH-LIGHT - GND PROX FLAP OVRD, S603	2	1	FLT COMPT, P3-1	*
SWITCH-LIGHT - GND PROX G/S INHBT, S16	2	1	FLT COMPT, P1-3	*

^{*} SEE THE WDM EQUIPMENT LIST


Ground Proximity Warning System - Component Index Figure 101

34-46-00 CONFIG 1

01B

Page 101 Apr 22/02





Ground Proximity Warning System - Component Location Figure 102 (Sheet 1)


34-46-00 tonfig 1

01B


Page 102 Apr 22/02



_T ISOLATION/MAINT MANUAL




FLIGHT COMPARTMENT





GND PROX-G/S INHB SWITCH-LIGHT, S16





GND PROX FLAP AND CONFIG GEAR OVRD SWITCHES, S603, S604

TEST GND PROX GND PROX TEST SWITCH, YEIS4

TEST PANEL MODULE, M10398 (REF)

Ground Proximity Warning System - Component Location Figure 102 (Sheet 2)

EFFECTIVITY-SAS, MARTINAIR WITHOUT EGPWS

34-46-00

01B

CONFIG Page 103 Apr 22/02

PREREQUISITES

MAKE SURE THESE SYSTEMS WILL OPERATE: ENGINE INDICATING AND CREW ALERTING SYSTEM (AMM 31-41-00/201)WARNING SYSTEM (AMM 31-51-00/501) AIR DATA COMPUTING SYSTEM (AMM 34-12-00/501) INERTIAL REFERENCE SYSTEM (AMM 34-21-00/501) ELECTRONIC FLIGHT INSTRUMENT SYSTEM (EFIS) (AMM 34-22-00/501)

ILS (AMM 34-31-00/501)

RADIO ALTIMETER SYSTEM (AMM 34-33-00/501) FLIGHT MANAGEMENT SYSTEM (AMM 34-61-00/501)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11B16, 11B18, 11F4, 11H35, 11J34

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)

GROUND PROXIMITY WARNING COMPUTER **BITE PROCEDURE**

1 ENERGIZE AND ALIGN THE LEFT IRU (AMM 34-21-00/201). MAKE SURE THE "OVRD" LIGHT IS OFF IN THESE SWITCHES ON THE P3-1 PANEL:

- "GND PROX/CONFIG GEAR OVRD" SWITCH
- "GND PROX/FLAP OVRD" SWITCH.

MOMENTARILY SET THE STATUS/HISTORY SWITCH ON THE GPWC TO THE "PRESENT STATUS" POSITION.

LOOK FOR THESE INDICATIONS ON THE GPWC BITE DISPLAY:

X X X X X X X X X

IN TEST

AIRCRAFT TYPE 767-"XXX"

FMC SELECTED

SYSTEM OK

SOFTWARE VERSION IS "XXX",

"DD-MMM-YY"

DATABASE VERSION IS "XXX",

"DD-MMM-YY" 1*XXXXXX

2*XXXXX*

3*XXXXXX

END TEST

DID SOME OF THESE GPWC INDICATIONS OCCUR?

YES 31 REMOVE THE GPWC, M147 71 REPLACE THE GPWC, M147 (AMM 34-46-01/401). (AMM 34-46-01/401). IS THERE 115V AC AT THE GPWC, CONNECTOR D435C, PIN 2, AND A GROUND AT THE GPWC, CONNECTOR D435C, PIN 3 (WDM 34-46-11)? NO 72 EXAMINE THE CIRCUIT FROM THE GPWC, CONNECTOR D435C, PIN 2, TO CIRCUIT BREAKER C592, (11F4) AND FROM THE GPWC, CONNECTOR D435C, PIN 3, TO GROUND (WDM 34-46-11). REPAIR THE PROBLEMS THAT YOU FIND. INSTALL THE GPWC, M147 (AMM 34-46-01/401).

> SOMETIMES THE EICAS MESSAGE, "GND PROX SYS", CAN SHOW AFTER THE FAULT IS CORRECTED. MOMENTARILY SET THE STATUS/HISTORY SWITCH ON THE GPWC TO THE "HISTORY" POSITION TO ERASE THE EICAS MESSAGE "GND PROX SYS".

- SEE SHEET 2

(BLOCK 2)

Ground Proximity Warning Computer BITE Procedure Figure 103 (Sheet 1)


EFFECTIVITY-SAS, MARTINAIR WITHOUT EGPWS 34-46-00

01B

Page 104 Dec 22/02

CONFIG






Ground Proximity Warning Computer BITE Procedure Figure 103 (Sheet 2)

EFFECTIVITY-SAS, MARTINAIR WITHOUT EGPWS

34-46-00 CONFIG Page 105



Ground Proximity Warning Computer BITE Procedure Figure 103 (Sheet 3)


SAS, MARTINAIR WITHOUT EGPWS

34-46-00

CONFIG 1

Page 106

Dec 22/02




Ground Proximity Warning Computer BITE Procedure
Figure 103 (Sheet 4)

EFFECTIVITY—SAS, MARTINAIR WITHOUT EGPWS

CONFIG 1
Page 107
Dec 22/02

BOEING PROPRIETARY - Copyright (C) - Unpublished Work - See title page for details.



3 THE ISOLATION DIODES ARE LOCATED BETWEEN CONNECTORS D5277 AND D2672. MAKE SURE THE DIODES' POLARITY IS CORRECT.

> Ground Proximity Warning Computer BITE Procedure Figure 103 (Sheet 5)

EFFECTIVITY-SAS, MARTINAIR WITHOUT EGPWS

34-46-00 CONFIG Page 108



FAILURE INDICATION	REFER TO SHT-BLOCK
AIRCRAFT TYPE INVALID	13-23
AIR DATA INACTIVE	7-8
AIR/GROUND INVALID	13-21
AUDIO SELECT INVALID	13-22
BARO ALTITUDE INVALID	7-9
BARORATE INVALID	7-9
BODY PITCH RATE INVALID	10-16
CALLOUTS OPTION INVALID	14-24
COMPUTED AIRSPEED INVALID	7-9
CORRECTED BARO ALTITUDE INVALID	7-9
CORRECTED AOA #1 INVALID	11-18
CORRECTED AOA #2 INVALID	11-18
DSW #1 DATA INACTIVE	11-17
DSW #2 DATA INACTIVE	11-17
EFS DATA INACTIVE	7-9A
FLAP ANGLE #1 INVALID	11-18
FLAP ANGLE #2 INVALID	11-18
FLAPS INVALID	3-38
FLIGHT PATH ACCEL INVALID	10-16
FMC DATA INACTIVE	8-10
FMC LATITUDE INVALID	8-11
FMC LONGITUDE INVALID	8-11
FMC MAG TRACK INVALID	8-11
GEAR INVALID	3-37
GLIDESLOPE CANCEL INVALID	9–14
GLIDESLOPE INVALID	9–13
GPWS FAILED	7–7
ILS DATA INACTIVE	9–12
INDICATED AOA #1 INVALID	11–18
INDICATED AOA #2 INVALID	11–18
INERTIAL ALTITUDE INVALID	10–16
INERTIAL VERTICAL SPEED INVALID	10–16
IRS DATA INACTIVE	10–15
IRS LATITUDE INVALID	10–16
IRS LONGITUDE INVALID	10–16
IRS MAG TRACK INVALID	10–16
IRS MODE INVALID	10–16
LOCALIZER INVALID	9–13
PITCH ANGLE INVALID	10–16
QFE SELECTED	14-25
RADIO ALTIMETER DATA INACTIVE	12-19
RADIO ALTITUDE INVALID	13-20
ROLL ANGLE INVALID	10–16
RUNWAY HEADING INVALID	9–13
STICK SHAKER AGA #1 INVALID	11-18
STICK SHAKER AOA #2 INVALID	11–18
TRUE AIRSPEED INVALID	7–9


TABLE A

Ground Proximity Warning Computer BITE Procedure Figure 103 (Sheet 6)


34-46-00

01B


Page 109 Dec 22/02



Ground Proximity Warning Computer BITE Procedure Figure 103 (Sheet 7)









Ground Proximity Warning Computer BITE Procedure Figure 103 (Sheet 8)

EFFECTIVITY-SAS, MARTINAIR WITHOUT EGPWS


34-46-00 CONFIG Page 111 Apr 22/02



Ground Proximity Warning Computer BITE Procedure Figure 103 (Sheet 9)







Ground Proximity Warning Computer BITE Procedure Figure 103 (Sheet 10)

SAS, MARTINAIR WITHOUT EGPWS

34-46-00


CONFIG 1

Page 113

Apr 22/02

BOEING PROPRIETARY - Copyright (C) - Unpublished Work - See title page for details.





Ground Proximity Warning Computer BITE Procedure Figure 103 (Sheet 11)


EFFECTIVITY—SAS, MARTINAIR WITHOUT EGPWS

CONFIG 1

O1B Page 114

Apr 22/02

BOEING PROPRIETARY - Copyright (C) - Unpublished Work - See title page for details.




Ground Proximity Warning Computer BITE Procedure Figure 103 (Sheet 12)

SAS, MARTINAIR WITHOUT EGPWS

34-46-00 CONFIG 1

01B

Page 115 Apr 22/02



Ground Proximity Warning Computer BITE Procedure Figure 103 (Sheet 13)


EFFECTIVITY
SAS, MARTINAIR WITHOUT EGPWS

CONFIG 1

O1B Page 116

Apr 22/02

BOEING PROPRIETARY - Copyright (C) - Unpublished Work - See title page for details.



Ground Proximity Warning Computer BITE Procedure Figure 103 (Sheet 14)

EFFECTIVITY-SAS, MARTINAIR WITHOUT EGPWS

34-46-00 CONFIG Page 117

PREREQUISITES

MAKE SURE THESE SYSTEMS WILL OPERATE: STALL WARNING COMPUTER (AMM 27-32-00/501) ENGINE INDICATING AND CREW ALERTING SYSTEM (AMM 31-41-00/501) WARNING SYSTEM (AMM 31-51-00/501)

AIR DATA COMPUTING SYSTEM (AMM 34-12-00/501)
INERTIAL REFERENCE SYSTEM (AMM 34-21-00/501)
ELECTRONIC FLIGHT INSTRUMENT SYSTEM (EFIS)


(AMM 34-22-00/501) ILS (AMM 34-31-00/501

RADIO ALTIMETER SYSTEM (AMM 34-33-00/501) FLIGHT MANAGEMENT SYSTEM (AMM 34-61-00/501)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11B16, 11B18, 11F4, 11H35, 11J34

MAKE SURE THE AIRPLANE IS IN THIS CONFIGUTRATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)

GROUND PROXIMITY WARNING SYSTEM SELF-TEST




Ground Proximity Warning System Self-Test Figure 104 (Sheet 1)

34-46-00

01B


CONFIG 1 Page 118 Dec 22/02



Ground Proximity Warning System Self-Test Figure 104 (Sheet 2)

EFFECTIVITY-SAS, MARTINAIR WITHOUT EGPWS

34-46-00 CONFIG Page 119




Ground Proximity Warning System Self-Test Figure 104 (Sheet 3)

EFFECTIVITY-SAS, MARTINAIR WITHOUT EGPWS

34-46-00 CONFIG

01B


Page 120 Apr 22/02



Ground Proximity Warning System Self-Test Figure 104 (Sheet 4)

EFFECTIVITY-SAS, MARTINAIR WITHOUT EGPWS

34-46-00 CONFIG Page 121




Ground Proximity Warning System Self-Test Figure 104 (Sheet 5)

34-46-00 config 1

01B

Page 122 Apr 22/02

M34585



Ground Proximity Warning System Self-Test Figure 104 (Sheet 6)

SAS, MARTINAIR WITHOUT EGPWS

34-46-00

01B

CONFIG 1 Page 123 Apr 22/02



1. ARINC Data Bus Charts

A. General

<u>CAUTION</u>: DO NOT DIRECTLY TOUCH THE CONNECTORS. USE A BREAKOUT BOX OR YOU CAN CAUSE DAMAGE TO THE CONNECTORS.

- (1) The ARINC 429 data bus charts give data necessary to make an analysis of ARINC 429 transmitters, receivers, and data buses. For the test, use a breakout box at the available terminal or at the LRU connectors.
- (2) The SAS data was changed to show only the -207 GPWC and subsequent per SAS COC No. PR 34-01-96, dated September 20, 1996.
- B. Equipment

SAS

SAS

- (1) Standard multi-meter
- (2) 429EBP Data Bus Analyzer (recommended) JcAIR Instrumentation 400 Industrial Parkway Industrial Airport, KS 66031

429-2 Data Bus Analyzer (alternative) Interface Technology 150 E. Arrow Highway San Dimas, CA 91773

(3) A34011-1 Breakout Box (recommended)
A34011-112 Breakout Box (alternative)

	GPWC	DIG	[TAL (OUTPUT BUS	CHART		
BUS NAME SOURCE	TYPE	BUS	CON	PINS	BUS FORMAT	BIT RATE	DATA BUS
GPWC	Α	1	В	CO1 DO1	429	L0	WARN MODE & MAINT

	GPV	VC(ID =	= 23) 0(CTAL LAE	BELS	CHART		
SIGNAL	TYPE	LABEL	FORMAT	MIN UPDATE RATE	SDI	BINARY RANGE	POSITIVE SENSE	UNITS
WARNING MODE+MAINT	Α	270	DIS	12.5	00	N/A	N/A	N/A

34-46-00

CONFIG

SAS B

Page 124 Apr 22/02



G	PWC DIS	CRETE (OCTAL LABELS/BIT CHART	r
SIGNAL	OCTAL LABEL	BIT	ONE-STATE	ZERO-STATE
SINK RATE	270	11	TRUE	NOT TRUE
PULL UP	270	12	TRUE	NOT TRUE
TERRAIN	270	13	TRUE	NOT TRUE
DON'T SINK	270	14	TRUE	NOT TRUE
TOO LOW GEAR	270	15	TRUE	NOT TRUE
TOO LOW FLAP	270	16	TRUE	NOT TRUE
TOO LOW TERRAIN	270	17	TRUE	NOT TRUE
GLIDESLOPE	270	18	TRUE	NOT TRUE
MINIMUMS	270	19	TRUE	NOT TRUE
TERRAIN PULL UP	270	20	TRUE	NOT TRUE
TOO LOW TERRAIN	270	22	TRUE	NOT TRUE
WIND SHEAR	270	23	TRUE	NOT TRUE

EFFECTIVITY-SAS, MARTINAIR WITHOUT EGPWS



ENHANCED GROUND PROXIMITY WARNING SYSTEM - TROUBLE SHOOTING

SAS SAS 1. <u>General</u>

SAS

SAS

SAS

SAS

SAS

SAS

SAS

SAS

SAS SAS

SAS SAS

SAS

SAS

SAS SAS

SAS

SAS

SAS

SAS SAS

SAS SAS

SAS

SAS SAS

SAS

SAS

SAS SAS

SAS

SAS

SAS SAS

SAS SAS

SAS SAS

SAS SAS

SAS

A. Overview

(1) The EGPWC contains extensive Built In Test or BIT capability. The BIT functions provide high confidence that the Warning Computer and interface signal sources are operating properly and that the EGPWS will perform its intended function. Detected failures are indicated via the GND PROX SYS EICAS message and Terrain INOP lights and by the ARINC 429 output. Failures detected during flight are saved in the flight history and are annunciated during Level 4 of the cockpit self test. BIT status is also available through the RS-232 port by use of a PC, terminal or during ATP.

B. EGPWS BITE

- (1) The EGPWC BITE is comprised of three types of functions: Operation Monitoring, Operational Tests, and Restricted Tests.
 - (a) Operation Monitoring
 - 1) Operation Monitoring consists of software checks that are performed as part of the normal Warning Computer processing. Operational Monitoring includes checks of data values and program flow control variables used for the warning computations to ensure they are within expected ranges. The status of various EGPWC hardware sub-systems is continuously verified and includes core processor checks, voice generator circuitry checks and ARINC 429 wrap-around tests. Operational Monitoring also includes extensive testing of the input signals to ensure the EGPWC is using proper data for its calculations.
 - (b) Operation Tests
 - 1) Operation Tests are run during normal operation and do not disrupt the EGPWC warning calculations or annunciations. Operations Tests include CPU instruction set tests, A/D tolerance tests, ROM check-sum verification tests and non-destructive RAM tests. Operation Tests are scheduled by the operating system to be performed between the routines required for normal operation.
 - (c) Restricted Tests
 - 1) Restricted Tests destroy data or take an excessive amount of time to complete and cannot be used during normal system operation. These tests are usually run during system power up or during a cockpit initiated self test. These tests primarily consist of more thorough hardware checks that would disrupt normal operation if continuously run.

34-46-00 config 2

SAS	(d)	EGPWC Front Pane
SAS		1) To aid in tr

SAS

SAS

SAS

SAS

SAS

SAS

SAS

SAS

SAS

SAS

SAS SAS

SAS

SAS

SAS SAS

SAS

SAS SAS

SAS

SAS

SAS SAS

SAS

SAS SAS

SAS

SAS

SAS

SAS SAS

SAS

SAS SAS

SAS SAS

SAS

SAS

SAS

SAS SAS

SAS

SAS

To aid in troubleshooting the EGPWC, the front panel of the Warning Computer contains EGPWS Status LED's, a Self Test interface, a PCMCIA interface, and a test plug.

EGPWS Status LED's (e)

- The EGPWC front panel Status LED's consist of three LED's a yellow External Fault LED, a green Computer OK LED and a red Computer Fail LED. The yellow External Fault LED indicates that a fault external to the EGPWC exists. external faults should be fixed prior to removing and replacing the EGPWC. The green Computer OK LED indicates that the EGPWC is operating correctly with no internal faults. The red Computer Fail LED indicates that the EGPWC has an internal fault.
- (f) Self Test Interface
 - The EGPWC front panel self test interface consists of a self test switch and a headphone jack which can be used to activate all of the self test features. The front panel audio jack is a standard 600Ω monophonic audio output compatible with standard 2-connector audio plug headphones.
- (q) Front Panel PCMCIA Interface
 - The EGPWC front panel PCMCIA interface allows data upload and download capabilities. Instructions on the use of the PCMCIA interface will be supplied in the Service Bulletin accompanying the software update.
- Front Panel Test Plug (RS-232 Port) (h)
 - The EGPWC front panel test plug (RS-232 port) provides various communications support capabilities, discretes used for file downloading and power outputs for a portable data loader. This port serves as access to signal monitoring, flight history, initiating BITE tests, updating databases and other functions. The interface is full duplex and is intended for human interaction, but can also be used for custom interface programs such as the Honeywell WinVIEWS utility.
- The procedures that follow assume that all the wiring is OK.
 - If the corrective action does not correct the failure, use the appropriate wiring diagram to make sure all wiring and connections are correct.
- C. Prepare for Troubleshooting
 - Supply electrical power (AMM 24-22-00/201).
 - Make sure these circuit breakers on the P11 Panel are closed:
 - (a) 11F4, GND PROX
 - 11F3, TERR DSPL (b)
 - (c) 11F5, Left RAD ALTM
- 11F20, Center RAD ALTM (d) SAS

SAS (e) 11F26, Right RAD ALTM 11A10, Left AIR DATA CMPTR SAS (f) SAS (p) 11E10, Left ILS 11E9, Left FMCS CMPTR (h) SAS 11J34, WARN ELEX A SAS (i) (i) 11B18, WARN ELEX B SAS SAS (k) 11F8, Left EFIS SYM GEN 11F9, Center EFIS SYM GEN SAS (1) (m) 11F29, Right EFIS SYM GEN SAS SAS (n) 11E4, Left EFIS CONT PNL 11E25, Right EFIS CONT PNL SAS (o) SAS (p) 11E6, Left HSI SAS

- (q) 11E27, Right HSI
 - Make sure the Left and Right IRU are in the NAV mode and aligned (AMM 34-21-00/201).
 - Make sure that the flaps are up, and that the landing gear lever is in the OFF or DN position.
 - Set a valid ILS frequency on both ILS's and then make sure that the GS flag on captain's EADI is out of view.
- D. Self Test Function

SAS

SAS

SAS

SAS SAS

SAS

SAS SAS

SAS

SAS

SAS SAS

SAS

SAS

SAS

SAS

SAS

SAS

SAS

SAS

SAS

SAS SAS

SAS SAS

SAS SAS

SAS

SAS

SAS

SAS

- (1) The EGPWC support a cockpit operated self test sequence that indicates the operational status of the system. The self test aural annunciate the status of the major functions of the system: Glideslope, GPWS, Bank Angle, Altitude Callouts, Windshear Detection and Terrain Awareness and activates the outputs (lights and displays) for visual verification. The EGPWC self test also provides maintenance information detailing the cause of detected faults, historical information of faults and warnings occurring during flight, and EGPWC and installation configuration information. The self test aural will be heard in the cockpit and through the headphone jack on the EGPWC front panel.
- E. The EGPWC self test is divided into six levels:
 - (1) Level 1 Enunciates the current status of each of the major functions of the EGPWS. This is the normal pre-takeoff test performed by the flight crew. This level can be initiated both on the ground and during flight above 1000 feet of radio altitude. There is a short and a long Level 1 test. The short test is intended to provide a go/no go confidence test. The long test enunciates all configured and activated warning, caution and altitude callout voices. The long Level 1 test can be only initiated on ground.
- Level 2 Identifies all failures current within the system. Level (2) 2 is accessed by maintenance personnel to help resolve INOP conditions. Level 2 can only be accessed on the ground.

EFFECTIVITY-SAS, MARTINAIR WITH EGPWS 34-46-00 CONFIG

- Level 3 Identifies the configuration status of the Warning SAS Computer and the installation. Level 3 can only be accessed on the SAS SAS ground. SAS
 - (4) Level 4 Enunciates faults that have occurred during past flights. This information can be used to resolve system problems reported by the flight crews. Level 4 can only be accessed on the ground.
 - (5) Level 5 Enunciates warnings that have occurred during past flights. This information can be used to resolve system problems reported by the flight crews. Level 5 can only be accessed on the ground.
 - Level 6 Enunciates state changes in the input discretes. This information can be used to verify the installation and operation of the discrete inputs. Level 6 can only be accessed on the ground.
 - The following sections detail the operation of each self test level.
 - In the following sections, reference is made to a "short NOTE: cancel" and a "long cancel". A "short cancel" is defined as depressing the self test switch (either in the cockpit or on the EGPWC front panel) for less than 2 seconds. A "long cancel" is defined as depressing the self test switch for more than 2 seconds.
 - (1) Self Test Level 1

SAS

SAS

SAS

SAS

SAS SAS

SAS

SAS

SAS SAS

SAS

SAS

SAS SAS

SAS

SAS SAS

SAS

SAS

SAS SAS

SAS

SAS SAS

SAS

SAS

SAS

SAS SAS

SAS

SAS SAS

SAS SAS

- (a) Level 1 testing enunciates the current status of each of the major functions of the EGPWS: Descent below glideslope, GPWS, bank angle protection, altitude callouts, windshear detection, and terrain awareness.
- The Level 1 self test is comprised of three parts: preamble, (b) short test and long test.
- The preamble and short test portion of the Level 1 test is initiated by momentarily pressing the GND PROX test switch.
- The long test portion is initiated by depressing the GND PROX test switch for a period between 2 and 5 seconds.
- The Level 1 test can only be initiated when the aircraft is on the ground or if radio altitude is greater than 1000 feet radio altitude.
- (f) All interfacing systems should be powered on and operating prior to conducting a Level 1 self test.

SAS	(g)	The	Terrain Display must be placed in a mode, which will allow
SAS		the	terrain display to be shown (e.g. Map mode) prior to
SAS		star	ting the test in order to see the Terrain Display test
SAS		patt	ern, requiring the selection of "WXR/TERR" prior to
SAS			ting the test. The WXR should be placed in TEST mode.
SAS			Preamble — The preamble checks the program pin connections
SAS			and the internal memory prior to starting the self test.
SAS			If any faults are detected, the self test will ennunciate
SAS			the detected fault and terminate the self test process.
SAS		2)	Short Test — The short self test is initiated holding the
SAS		_,	GND PROX test switch in Test position for less than 2
SAS			seconds. The normal Level 1 short self test sequence is as
SAS			follows:
SAS			a) GND PROX SYS EICAS message and Terrain INOP light turn
SAS			on
SAS			b) GND PROX light turn on
SAS			c) Voice: "GLIDESLOPE"
SAS			d) GND PROX light turn off
SAS			e) GPWS PULL UP light turns on
SAS			f) Voice: "PULL UP"
SAS			g) GPWS PULL UP light turn off
SAS			h) WINDSHEAR light turns on and red WINDSHEAR annunciation
SAS			is displayed on the Captain's and F/O's EADI's
SAS			i) Voice: (SIREN) "WINDSHEAR, WINDSHEAR, WINDSHEAR"
SAS			j) WINDSHEAR light and EADI WINDSHEAR annunciations turn
SAS			off
SAS			k) Amber WINDSHEAR annunciation is displayed on the EADI's
SAS			l) Amber WINDSHEAR annunciations turn off
SAS			m) GPWS PULL UP light turns on
SAS			n) Voice: "TERRAIN TERRAIN PULL UP"
SAS			o) GPWS PULL UP light turn off
SAS			p) Captain's and F/O's TERR select switch ON legend is
SAS			illuminated
SAS			q) Terrain Displays show terrain test pattern
SAS			r) GND PROX light turn on
SAS			s) GND PROX light turn off
SAS			t) Terrain Displays return to normal
SAS			u) ALL INOP lights and EICAS messages turn off
SAS			Long Test
		37	
SAS			
SAS			voices, including warning, caution and altitude callout
SAS			voices.
SAS			b) The long self test is initiated by holding the GND PROX
SAS			test switch in Test position for more than 2 seconds.
SAS			 GND PROX SYS EICAS message and Terrain INOP light
SAS			turn on

FAULT ISOLATION/MAINT MANUAL

SAS	<u>2</u> .	GND PROX light turn on
SAS	<u>3</u> .	Voice: "GLIDESLOPE"
SAS	<u>4</u> . <u>5</u> .	GND PROX light turn off
SAS	5.	GPWS PULL UP light turns on
SAS	- 6.	Voice: "PULL UP"
SAS	<u>6</u> . <u>7</u> .	GPWS PULL UP light turn off
SAS	<u></u> 8.	WINDSHEAR light turns on and red WINDSHEAR
SAS	⊻.	annunciation is displayed on the Captain's and
SAS		F/O's EADI's
SAS	9.	Voice: (SIREN) "WINDSHEAR, WINDSHEAR"
SAS		WINDSHEAR light and EADI WINDSHEAR annunciations
	<u>10</u> .	
SAS	11	turn off
SAS	<u>11</u> .	Amber WINDSHEAR annunciation is displayed on the
SAS	40	EADI's
SAS	<u> 12</u> .	Amber WINDSHEAR annunciations turn off
SAS	<u>13</u> .	GPWS PULL UP light turns on
SAS	14.	Voice: "TERRAIN TERRAIN PULL UP"
SAS	<u>15</u> .	GPWS PULL UP light turn off
SAS	<u> 16</u> .	Captain's and F/O's TERR select switch ON legend is
SAS		illuminated
SAS	<u> 17</u> .	Terrain Displays show terrain test pattern
SAS	<u> 18</u> .	GND PROX light turn on
SAS	<u> 19</u> .	GND PROX light turn off
SAS	20.	Voice: "SINKRATE"
SAS	21.	Voice: "PULL UP"
SAS	22.	Voice: "TERRAIN"
SAS	23 .	Voice: "PULL UP"
SAS	24.	Voice: "DON'T SINK DON'T SINK"
SAS	25.	Voice: "TOO LOW TERRAIN"
SAS	<u>26</u> .	Voice: "TOO LOW GEAR"
SAS	<u>27</u> .	Voice: "TOO LOW FLAPS"
SAS	<u>28</u> .	Voice: "TOO LOW TERRAIN"
SAS	<u>29</u> .	Voice: "GLIDESLOPE"
SAS	<u>30</u> .	Voice: "BANK ANGLE BANK ANGLE"
SAS	<u>30</u> .	Voice: "PLUS HUNDRED"
	<u>31</u> .	
SAS	<u>32</u> .	
SAS		Voice: "TWENTY FIVE HUNDRED"
SAS	<u>34</u> .	Voice: "ONE THOUSAND"
SAS	<u>35</u> .	Voice: "FIVE HUNDRED"
SAS	<u>36</u> .	Voice: "FIFTY"
SAS	<u>37</u> .	Voice: "FORTY"
SAS	<u>38</u> .	Voice: "THIRTY"
SAS	<u>39</u> .	Voice: "TWENTY"
SAS	<u>40</u> .	Voice: "TEN"
SAS	<u>41</u> .	Voice: (SIREN) "WINDSHEAR WINDSHEAR"
SAS	<u>42</u> .	Voice: "TOO LOW TERRAIN"



SAS	43. Voice: "CAUTION TERRAIN CAUTION TERRAIN"
SAS	<u>44</u> . Voice: "TERRAIN TERRAIN PULL UP"
SAS	45. Voice: "CAUTION OBSTACLE CAUTION OBSTACLE"
SAS	46. Voice: "OBSTACLE OBSTACLE PULL UP"
SAS	<u>47</u> . Terrain Displays return to normal
SAS	48. All INOP lights, switch legends and EICAS messages
SAS	turn off
SAS	4) Voice Messages
SAS	 a) The Level 1 Self Test will detect and annunciate any
SAS	current failure conditions, which affect the operation
SAS	of the major EGPWS functions. The following table
SAS	identifies the response for the faults annunciated
SAS	during the test.



VOICE MESSAGE	RESPONSE
	Probable error in writing for the program pins. Verify the program pins are wired correctly and configure the parity pin fo
Aircraft Configuration Data Base CRC Failed	Remove and replace EGPWC.
Aircraft Configuration Data Base Failed	Remove and replace EGPWC.
	Probable error in aircraft type program p Verify the aircraft type program pin connection.
	Perform a Level 2 self test to troubleshorthe problem.
ı	Perform a Level 2 self test to troubleshoothe problem.
9	Perform a Level 2 self test to troubleshorthe problem.
	Perform a Level 2 self test to troubleshoothe problem.
	Perform a Level 2 self test to troubleshoothe problem.
	Perform a Level 2 self test to troubleshoothe problem.
5 5	Position information not available from G See par. G.(1) for troubleshooting.
	Indicates that the "Terrain Awareness an TCF Inhibit" input to the EGPWC is select

(2) Self Test Level 2

(a) A Level 2 self test tells the maintenance crew if there are any faults currently in the system.

SAS SAS

SAS

34-46-00

SAS E

CONFIG 2 Page 108 Dec 22/01



SAS		
SAS		
SAS		
SAS		
SAS		
SAS		
SAS		
SAS		
SAS		
SAS		
SAS		
SAS		
SAS		
SAS		
SAS		
SAS		
SAS		
SAS		
SAS		
SAS		
SAS		
SAS		
SAS		

SAS

- (b) Level 2 is accessed while the aircraft is on the ground by pressing the GND PROX test switch within 3 seconds of the end of the Level 1 test or a short cancel during a Level 1 self test. The message "CURRENT FAULTS" will be enunciated when Level 2 starts. The Level 2 test is not accessible while airborne.
- (c) During the Level 2 self test, a short or a long cancel terminates the self test and "PRESS TO CONTINUE" is enunciated for proceeding to Level 3 self test.
- (d) If no faults currently exist, the message "NO FAULTS" will be enunciated.
- (e) If a fault is detected, it will be classified as either an internal or external fault. Internal faults are defined as those faults that originate within the EGPWC. Internal faults will turn on the red COMPUTER FAIL LED on the EGPWC front panel. External faults are defined as those faults that originate from sources outside the EGPWC. External faults will turn on the amber EXTERNAL FAULT LED on the EGPWC front panel.
 - 1) Internal Faults
 - a) An internal fault indicates a problem with the Warning Computer. The system should be checked and the Warning Computer should be removed and replaced if required. The following figure lists the internal fault messages and the probable maintenance response.

1	····
Annunciation	ROM FAILED
	RAM FAILED
	NVM RAM FAILED
	NVM FAILED
	WATCHDOG TIMER FAILED
	EXCESSIVE WATCHDOG TIMEOUTS FAILURE
	ANALOG CONVERTER FAILED
	VOICE GENERATOR FAILED
	ARINC 429 TRANSMITTER FAILED
	ARINC 429 RECEIVER FAILED
	APPLICATION DATABASE FAILED
	APPLICATION DATABASE CRC FAILED
	TERRAIN DATABASE FAILED
	ENVELOPE MODULATION DATABASE FAILED
	CONFIGURATION DATABASE FAILED
	SYSTEM OR MODE TASK FAILED
	SUPPORT TASK FAILED
	INTERNAL GPS FAILED
Probable Cause	EGPWC failure
Action	Remove and replace the EGPWC.
2) Exte	ernal Faults
a)	ARINC 429 bus activity, ARINC 429 signal faults, inpu
	discrete monitoring, analog input wire monitoring and
	analog signal faults are categorized as external
	analog signal faults are categorized as external faults. The following figure lists the types of
	analog signal faults are categorized as external faults. The following figure lists the types of messages and the probable maintenance response requir
	analog signal faults are categorized as external faults. The following figure lists the types of messages and the probable maintenance response requir for an external fault. For example, if the computer
	analog signal faults are categorized as external faults. The following figure lists the types of messages and the probable maintenance response requir for an external fault. For example, if the computer airspeed on air data computer 1 is failed (SSM=Fail
	analog signal faults are categorized as external faults. The following figure lists the types of messages and the probable maintenance response requir for an external fault. For example, if the computer
	analog signal faults are categorized as external faults. The following figure lists the types of messages and the probable maintenance response requir for an external fault. For example, if the computer airspeed on air data computer 1 is failed (SSM=Fail
	analog signal faults are categorized as external faults. The following figure lists the types of messages and the probable maintenance response requir for an external fault. For example, if the computer airspeed on air data computer 1 is failed (SSM=Fail Warning) the following messages will be annunciated:
	analog signal faults are categorized as external faults. The following figure lists the types of messages and the probable maintenance response requir for an external fault. For example, if the computer airspeed on air data computer 1 is failed (SSM=Fail Warning) the following messages will be annunciated: "CURRENT FAULTS"
	analog signal faults are categorized as external faults. The following figure lists the types of messages and the probable maintenance response requir for an external fault. For example, if the computer airspeed on air data computer 1 is failed (SSM=Fail Warning) the following messages will be annunciated: "CURRENT FAULTS" "EGPWC OK"
	analog signal faults are categorized as external faults. The following figure lists the types of messages and the probable maintenance response requir for an external fault. For example, if the computer airspeed on air data computer 1 is failed (SSM=Fail Warning) the following messages will be annunciated: "CURRENT FAULTS" "EGPWC OK" "EXTERNAL FAULTS"
	analog signal faults are categorized as external faults. The following figure lists the types of messages and the probable maintenance response requir for an external fault. For example, if the computer airspeed on air data computer 1 is failed (SSM=Fail Warning) the following messages will be annunciated: "CURRENT FAULTS" "EGPWC OK"

LEVEL 2 SELF TEST ANNUNCIATION - EXTERNAL FAULTS (EXAMPLES)

EFFECTIVITY-SAS, MARTINAIR WITH EGPWS

SAS

CONFIG 2 Page 110 Dec 22/01



Annunciation	<bus> Inactive</bus>
Example	ILS BUS 1 Inactive
Probable Cause	Input source is not powered or a wiring problem exists between the source LRU and the Warning Computer.
Action	Verify input source LRU is powered. Verify wiring from source to LRU.
Annunciation	<bus> <signal> FAULT</signal></bus>
Example	ILS BUS 1 GLIDESLOPE FAULT
Probable Cause	<pre>Input signal SSM = Fail Warning, or Input signal is not being transmitted (incorrect update rate</pre>
Action	Repair input signal.
	
Annunciation	<bus> WIRING FAULT</bus>
	RADIO ALTIMETER 1 WIRING FAULT
Example	
Example 	Open wire monitor has detected no connection from the SOURCE LRU.
<u> </u>	
Probable Cause	SOURCE LRU.
Probable Cause	SOURCE LRU.
Probable Cause	SOURCE LRU. Verify wiring from the LRU.

 34 - 46 - 00 CONFIG



Annunciation	GEAR SWITCH FAULT	
Probable Cause	Electrical short at the gear discrete input.	
Action	Verify wiring from the gear override switch and/or gea input discretes.	
	-	
Annunciation	GLIDESLOPE CANCEL INVALID	
Probable Cause	Electrical short at the glideslope cancel input.	
Action	Verify wiring from the glideslope cancel input.	
Annunciation	FLAP ANGLE UNREASONABLE	
Probable Cause	Electrical short at the flap discrete input(s).	
Action	Verify wiring from the flap input discrete(s).	
	_F	
Annunciation	SELF TEST INVALID	
Probable Cause	Electrical short at the self test input.	
Action	Verify wiring from the self test discrete.	
Annunciation	MOMENTARY TERRAIN SELECT 1 (OR 2) INVALID	
Probable Cause	Electrical short at the Terrain Select input(s).	
Action	Verify wiring from the terrain "ON" switches.	

34-46-00

SAS B

CONFIG 2 Page 112 Dec 22/01



Annunciation	PROGRAM PIN READ ERROR		
Probable Cause	Wiring error to the program pins.		
Action	Verify wiring to each program pin.		
	····		
Annunciation	PROGRAM PIN PARITY ERROR		
Probable Cause	Wiring error to the program pins.		
Action	Verify wiring to each program pin. Verify ODD parity selected.		
Annunciation	AIRCRAFT TYPE INVALID		
Probable Cause	Wiring error to the Aircraft Type program pins.		
Action	Verify wiring to the Aircraft Type program pins.		
	-		
Annunciation	CALLOUTS OPTION INVALID		
Probable Cause	Wiring error to the Callouts Options program pins.		
Action	Verify wiring to the Callout Options program pins.		
	····p·······		
Annunciation	AUDIO MENU INVAID		
Probable Cause	e Cause Wiring error to the Audio Menu program pins.		
Action	Verify wiring to the Audio Menu program pins.		

 34 - 46 - 00 CONFIG



SAS			
	Annunciation	PROGRAM PIN <xx> INVALID (where XX is a number)</xx>	
SAS	Probable Cause	Invalid option selected.	
SAS	Action	Verify wiring to all program pins.	
SAS SAS SAS	Probable Cause	Invalid option selected.	

(3) Self Test Level 3

SAS

SAS

SAS

SAS SAS

SAS SAS

SAS

SAS

SAS SAS

SAS

SAS

SAS

SAS SAS

SAS

- A Level 3 self test enunciates Warning Computer configuration information. This information is determined by the wiring of the program pins, from data stored in the computer ROM and by identification resistors on each of the internal circuit boards.
- (b) Level 3 is accessed while the aircraft is on the ground by pressing the GND PROX test switch within 3 seconds of the "PRESS TO CONTINUE" message at the end of the Level 2 test. The message "SYSTEM CONFIGURATION" will be enunciated when Level 3 starts.
- (c) During a Level 3 self test a short cancel bumps the enunciation to the next Level 3 item (e.g. from terrain database information to envelope modulation database information). A long cancel terminates the self test level and "PRESS TO CONTINUE" is enunciated for proceding to Level 4 self test.
- The following information is given in the Level 3 self test: (d)



INFORMATION	VERIFICATION
EGPWC Part Number	See IPC or other approved source
EGPWC Serial Number	See identification label on unit
Application Software Number	Any number accepted
Configuration Software Version	Any number accepted
Envelope Modulation Database Version	Any number accepted
Aircraft Type	222
Altitude Callout Menu	97
EGPWC Mod Status	Any number accepted
Terrain Database Version	See IPC or other approved source
Boot Code Version	Any number accepted
Audio Menu	0
Internal GPS Selected	_
Triple Radio Altimeter Selected	_
Bank Angle Selected	-
Peaks Enabled	-
Mode 6 Low Volume Selected	-

(4) Self Test Level 4

SAS

SAS SAS

SAS

SAS

SAS SAS

SAS

SAS

SAS

SAS

- (a) A Level 4 self test enunciates the faults recorded over the last 10 flight legs.
- (b) A Level 4 self test can only be accessed on the ground by pressing the GND PROX test switch within 3 seconds of the "PRESS TO CONTINUE" message at the end of Level 3. The message "Fault History" is enunciated when Level 4 starts.
- (c) During a Level 4 self test, a short cancel bumps to the next flight leg with faults (if any). A long cancel will terminate the self test level and "PRESS TO CONTINUE" will be enunciated for proceeding to Level 5 self test.

SAS		(d)	If no faults occured within the previous 10 flight legs the
SAS			message "NO FAULTS" will be given. If a fault did occur within
SAS			the previous 10 flight legs, the aural messages enunciated
SAS			would be the same as given in Level 2 with the added
SAS			information of which flight leg the fault occurred. For
SAS			example, if radio altimeter bus 1 failed 4 flights earlier the
SAS			messages would be:
SAS			·
SAS			"FLIGHT 4"
SAS			"EGPWC OK"
SAS			"EXTERNAL FAULTS"
SAS			"RADIO ALTIMETER BUS 1 INACTIVE"
SAS			"PRESS TO CONTINUE"
SAS			TRESS TO CONTINGE
SAS			NOTE: Flight 1 was the most recent flight.
SAS			NOTE. I CIGITO I was the most recent religion.
SAS	(5)	Self	Test Level 5
SAS		(a)	
SAS		(4)	warnings) recorded over the last 10 flight legs.
SAS		(b)	A Level 5 self test can only be accessed on the ground by
SAS		(0)	pressing the GND PROX test switch within 3 seconds of the
			· ·
SAS			"PRESS TO CONTINUE" message at the end of Level 4. The message
SAS			"WARNING HISTORY" is enunciated when Level 5 starts.
SAS		(c)	During a Level 5 self test performing a short cancel bumps to
SAS			the next flight leg with warnings (if any). A long cancel will
SAS			terminate the self test level and "PRESS TO CONTINUE" will be
SAS			enunciated for proceeding to Level 6 self test.
SAS		(d)	If no alerts were issued within the previous 10 flight legs the
SAS			message "NO WARNINGS" will be enunciated. If an alert was
SAS			given with the last 10 flight legs the flight leg and alert
SAS			message will be enunciated. For example, if a glideslope alert
SAS			was given 7 flight legs earlier the messages would be:
SAS			
SAS			"WARNING HISTORY"
SAS			"FLIGHT 7"
SAS			"GLIDESLOPE"
SAS			"PRESS TO CONTINUE"
SAS	(6)	Self	Test Level 6
SAS		(a)	
SAS		-	discrete inputs for the selected aircraft type. This feature
SAS			is provided for production aircraft testing of the discrete
0.4.0			in provided and it intended to make the maintaining of

SAS

SAS

input wiring and is intended to match the maintenance display

feature provided on the MK V front panel display.



SAS	(b)	A Level 6 self test can only be accessed on the ground by
SAS		pressing the GND PROX test switch within 3 seconds of the
SAS		"PRESS TO CONTINUE" message at the end of Level 5. The message
SAS		"DISCRETE INPUT TEST, PRESS TO CANCEL" is enunciated when Level
SAS		6 starts and will be repeated approximately every 60 seconds
SAS		until the test is terminated.
SAS	(c)	A short or long cancel will terminate the self test level and
SAS		the message "END OF SELF TEST" will be enunciated.
SAS	(d)	The Level 6 self test monitors each input discrete for a state
SAS		change. If a state change occurs, the EGPWC will enunciate the
SAS		functional name of the discrete followed by its new state. For
SAS		example if the Glideslope Cancel discrete input is defined as
SAS		GND = CANCEL, and the discrete transitions from OPEN to GND,
SAS		the message "GLIDESLOPE CANCELLED" will be issued. If the
SAS		input is reset (transitions from GND to OPEN), the message
SAS		"GLIDESLOPE ENABLED" will be issued.
SAS	(e)	The following table defines the audio phrase for each input
SAS		discrete. Note that not all of the discretes are used on all
SAS		aircraft. The self test discrete cannot be tested in a Level 6
SAS		self test.



SAS		r	T
SAS SAS	NAME	STATE ==>	AUDIO PHRASE
SAS	Capt TERR Switch *)	True =>	Display Discrete 1 True
SAS		False =>	Display Discrete 1 False
SAS	F/O TERR Switch *)	True =>	Display Discrete 2 True
SAS		False =>	Display Discrete 2 False
SAS	Capt WXR Switch *)	True =>	Weather Discrete 1 True
SAS		False =>	Weather Discrete 1 False
SAS	F/O WXR Switch *)	True =>	Weather Discrete 1 True
SAS		False =>	Weather Discrete 2 False
SAS SAS SAS	Landing Flaps Discrete or Flap Override	Selected => Not Selected =>	Landing Flaps Not Landing Flaps
SAS SAS SAS	Landing Gear Discrete or Gear Override **)	Selected => Not Selected =>	Landing Gear Down Landing Gear Up
SAS	Air/Ground Discrete	In Air =>	Not On Ground
SAS		On Ground =>	On Ground
SAS SAS SAS	Glideslope Cancel Discrete	Cancel => Normal =>	Glideslope Cancelled Glideslope Enabled
SAS	Terrain Awareness and TCF Inhibit	Disabled =>	Terrain Off
SAS		Normal =>	Terrain On

- One "True" ennunciation and one "False" enunciation is given for each activation of the switch.
- **) Landing Gear Handle must be pulled or in OFF position to toggle the discrete with the Gear Override Switch.
 - G. Recommended Maintenance Response To Status LED's
 - In general, if the GND PROX SYS message appears on EICAS, the EGPWC front panel LED's should be checked. The following table shows the recommended maintenance action in response to the front panel LED's.

SAS SAS

SAS

SAS



SAS SAS SAS	EXTERNAL FAULT	COMPUTER OK	COMPUTER FAIL	CORRECTIVE ACTION				
SAS SAS SAS SAS	OFF	OFF	OFF	Ensure that the EGPWC is installed in the rack correctly and power to the EGPWC is turned on.				
SAS SAS	OFF	OFF	RED	Troubleshoot internal faults using the Level 2 self test, if possible. Remove and replace the EGPWC, if required.				
SAS	OFF	GREEN	OFF	Normal operation.				
SAS	OFF	GREEN	RED	Remove and replace the EGPWC.				
SAS	YELLOW	OFF	OFF	Remove and replace the EGPWC.				
SAS SAS SAS	YELLOW	OFF	RED	Troubleshoot internal faults using the Level 2 self test, if possible. Remove and replace the EGPWC, if required.				
SAS SAS	YELLOW	GREEN	OFF	Troubleshoot external faults using the Level 2 self test.				
SAS SAS SAS	YELLOW	GREEN	RED	Remove and replace the EGPWC.				

- Н. Recommended Maintenance Response to Terrain INOP Light
 - A Terrain INOP light may not always imply an external or internal failure of the EGPWC. The Terrain INOP light may turn on if the required accuracy of the position information is not being received from the GPS (e.g. weak GPS signal in the hangar), IRS or the FMC. Therefore, if the Terrain INOP light is reported to be on or was on, perform a Level 2 self test and a Level 4 check to consult the fault history. If GPS faults are present, use a Time Domain Reflectometer (TDR) to check the coax cable and antenna. A normal antenna will draw a slow descending line from the antenna position. A relative sharp descending/ascending line show a short/open in the antenna or antenna coax plug. Replace or repair as necessary.

EFFECTIVITY-SAS, MARTINAIR WITH EGPWS

SAS

SAS

SAS

SAS

SAS

SAS

SAS

SAS SAS

SAS SAS

SAS

34-46-00 CONFIG



THIS PAGE INTENTIONALLY LEFT BLANK

Not Used Figure 101

34-46-00 config 2

01B

Page 120 Aug 22/08

18



VOR SYSTEM


COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
ANTENNA - DUAL VOR, M262 CIRCUIT BREAKER - VOR/MKR LEFT, C595 VOR RIGHT, C596 INDICATOR - (FIM 34-22-00/101) LEFT RADIO DISTANCE MAGNETIC, N3 RIGHT RADIO DISTANCE MAGNETIC, N43 PANEL - (FIM 34-22-00/101) LEFT EFIS CONTROL, M94 RIGHT EFIS CONTROL, M93 PANEL - LEFT VOR CONTROL M91 PANEL - RIGHT VOR CONTROL, M92 RECEIVER - LEFT VOR/MARKER, M186 RECEIVER - RIGHT VOR/MARKER, M187 RELAY - (FIM 31-01-36/101) LEFT FMC TUNING, K757 SYS NO. 1 AIR/GND, K124 RELAY - (FIM 31-01-37/101) RIGHT FMC TUNING, K758 SYS NO. 2 AIR/GND, K214	2 2 2 2 2 2	1 1 1 1 1 1	326A, VERTICAL STABILIZER FLT COMPT, P11 11A1 11E33 FLT COMPT, P55 FLT COMPT, P55 119AL, MAIN EQUIP CTR, E2-2 119AL, MAIN EQUIP CTR, E2-3	34-51-02 * * 34-51-02 34-51-01 34-51-01


^{*} SEE THE WDM EQUIPMENT LIST

VOR System - Component Index Figure 101

 34-51-00







VOR System - Component Location Figure 102 (Sheet 1)

33794


34-51-00

01

Page 102 Nov 10/95



FAULT ISOLATION/MAINT MANUAL



VOR System - Component Location Figure 102 (Sheet 2)

FROM SHT 1

EFFECTIVITY-ALL

191123

34-51-00

11

Page 103 Nov 10/95



ELECTRICAL POWER (MM 24-22-00/201)
IRS INITIALIZED (MM 34-21-00/501)
EFIS (MM 34-22-00/501)

CB'S: 11A1,11A6,11E4,11E25,11E33,11F25

VOR BITE PROCEDURE


ENERGIZE AND ALIGN THE 10 DO THE TWO RDMIs SHOW 20 REPLACE THE L (R) RDMI, N3 IRS. SET THE MODE SWITCH ON INCORRECTLY? (N43)(MM 34-22-05/401). THE EFIS CONTROL PANEL TO THE IF THE PROBLEM CONTINUES, YES VOR-EXP POSITION. TURN THE REMOVE THE L (R) RDMI, N3 LEFT AND RIGHT BEARING SOURCE (N43). FOR A L VOR PROBLEM, SWITCHES ON EACH RDMI TO THE EXAMINE AND REPAIR THE CIRCUIT VOR POSITION. PUSH AND HOLD FROM THE L (R) RDMI, CONNECTOR THE TEST SWITCH ON THE L (R) D645 (D647), PINS 38 AND 39 TO TB130, PINS G12 AND G13. FOR A VOR RECEIVER. DOES THIS SEQUENCE OCCUR R VOR PROBLEM, EXAMINE AND ON THE RDMIs: REPAIR THE CIRCUIT FROM THE L (R) RDMI, CONNECTOR D645 THE L (R) BEARING FLAGS (D647), PINS 48 AND 49 TO SHOW FOR ABOUT 6 SECONDS TB243, PINS YA9 AND YA10 THE BEARING FLAGS DO NOT (WDM 34-22-81,-91). SHOW WHILE THE THIN INSTALL THE L (R) RDMI. BEARING POINTERS SHOW 180 ±2 DEGREES UNTIL THE END OF THE TEST? 21 REPLACE THE L (R) VOR/MKR RECEIVER, M186 (M187) YES (MM 34-51-01/401). IF THE PROBLEM CONTINUES, SEE SHEET 2 REMOVE THE L (R) VOR/MKR (BLOCK 2) RECEIVER, M186 (M187). FOR A L VOR PROBLEM, REMOVE THE L (R) RDMI, N3 (N43). EXAMINE AND REPAIR THE CIRCUIT FROM THE L VOR/MKR RECEIVER, CON-NECTOR D329B, PINS B13 AND C13 TO THE L (R) RDMI, CONNECTOR D645 (D647), PINS 38 AND 39. FOR THE R VOR PROBLEM, EXAMINE AND REPAIR THE CIRCUIT FROM THE R VOR/MKR RECEIVER, CON-NECTOR D357B, PINS B13 AND C13 TO TB243, PINS YA9 AND YA10 (WDM 34-51-11,-21). INSTALL THE L (R) VOR/MKR RECEIVER. INSTALL THE L (R) RDMI.

VOR BITE Procedure Figure 103 (Sheet 1)

EFFECTIVITY ALL

34-51-00





VOR BITE Procedure Figure 103 (Sheet 2)

34-51-00




ELECTRICAL POWER (MM 24-22-00/201)
IRS INITIALIZED (MM 34-21-00/501)
EFIS (MM 34-22-00/501)


FMCS (MM 34-61-00/501)

CB'S: 11A1,11A6,11E33,11F25

VOR FLAG ON RDMIS, NO FLAG ON EHSI VORCP DISPLAY INOP



VOR Flag on RDMIs, No Flag on EHSI, VORCP Display Inop Figure 104






AUTOTUNE - VOR FLAG IN VIEW ON RDMIS, MANUAL OPERATION NORMAL

PREREQUISITES

ELECTRICAL POWER (MM 24-22-00/201)
IRS INITIALIZED (MM 34-21-00/501)
EFIS (MM 34-22-00/501)
FMCS (MM 34-61-00/501)

CB'S: 11A1,11A6,11E33,11F25



Autotune - VOR Flag In View On RDMIs, Manual Operation Normal Figure 105

721133

34-51-00

10

Page 107 Nov 10/95



MAKE SURE THIS SYSTEM WILL OPERATE: EFIS (AMM 34-22-00/501)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11A1,11A6,11E33,11F25

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201) IRS IS ALIGNED (AMM 34-21-00/501)

NOTE: AIRPLANES WITH THE -411 EFIS SYMBOL GENERATOR AND ON;

IF YOU PUSH THE "INOP" SWITCH ON THE EFIS CONTROL PANEL WHEN IN THE MAP MODE, A VOR FLAG WILL SHOW ON THE EHSI. MAKE SURE THE "INOP"

SWITCH IS NOT SET.

VOR FLAG ON EHSI, RDMI DISPLAYS ARE NORMAL

TREMOVE THE LEFT (RIGHT)

EFIS SG, M148 (M150)

(AMM 34-22-01/401).

MAKE SURE THE INPUT BUS

FROM THE LEFT (RIGHT) VOR

RECEIVER, CONNECTOR D329B

(D357B), PINS B13 AND C13, IS

ACTIVE AT THE LEFT (RIGHT)

EFIS SG, CONNECTOR D425A

(D373D), PINS J3 AND K3

(WDM 34-51-11,-21).

IS THE BUS ACTIVE?

21 REPLACE THE LEFT (RIGHT)
EFIS SYMBOL GENERATOR, M148
(M150)(AMM 34-22-01/401).

NO

YES

22 EXAMINE THE DATA BUS
CIRCUIT FROM TB130 (TB119),
PINS G12 AND G13, TO THE LEFT
(RIGHT) EFIS SG, CONNECTOR
D425A (D373D), PINS J3 AND K3
(WDM 34-51-11,-21).
REPAIR THE PROBLEMS THAT
YOU FIND.
INSTALL THE EFIS SYMBOL
GENERATOR.

VOR Flag on EHSI, RDMI Displays Are Normal Figure 106

EFFECTIVITY-

34-51-00

02

Page 108 Nov 10/95



MAKE SURE THIS SYSTEM WILL OPERATE: EFIS (AMM 34-22-00/501)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11A1,11A6,11E33,11F25

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201) IRS INITIALIZED (AMM 34-21-00/501)

VOR DISPLAY
PROBLEMS ON L (R)
RDMI AND EHSI

1 PUSH AND HOLD THE TEST
SWITCH ON THE L (R) VOR
RECEIVER.
DOES THE RED "VOR" LIGHT
COME BACK ON AT THE END OF THE
TEST?

NO

21 REPLACE THE L (R) VOR
RECEIVER, M186 (M187)
(AMM 34-51-01/401).

22 DO THIS PROCEDURE: "VOR
FLAG ON THE EHSI, RDMI
DISPLAYS ARE NORMAL"
(FIM 34-51-00/101, FIG. 106).

VOR Display Problems on L (R) RDMI and EHSI Figure 107

ALL


34-51-00

MAKE SURE THESE SYSTEMS WILL OPERATE: IRS INITIALIZED (AMM 34-21-00/501) EFIS (AMM 34-22-00/501) FMCS (AMM 34-61-00/501)

VOR INDICATIONS
NORMAL, FREQ
DISPLAY ON VORCP
ABNORMAL

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11A1, 11A6, 11E33, 11F25

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)



VOR Indications Normal, Freq Display on VORCP Abnormal Figure 108

201086

34-51-00

02

Page 110 Aug 22/03



MAKE SURE THIS SYSTEM WILL OPERATE: EFIS (AMM 34-22-00/501)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11A1,11A6,11E33,11F25

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)

BRG FLAG ON RDMIS, LATERAL DEV BAR MISSING ON EHSI IN VOR MODE, VORCP FREQ SELECT OK

NOTE: THE VOR FLAG IS SHOWN ON THE RDMI AND THE LATERAL DEVIATION BAR IS NOT SHOWN ON THE EHSI WHEN THE VOR SIGNAL IS NOT AVAILABLE.

1 REMOVE THE L (R) VOR/
MARKER RECEIVER, M186 (M187)
(AMM 34-51-01/401).
DO THE ANTENNA CABLE CHECK
PROCEDURE (AMM 20-10-32/201)
AT THE L (R) VOR/MARKER
RECEIVER, CONNECTOR D329C
(D357B), PINS 1 AND C1
(WDM 34-51-11,-21).
IS THE VOR ANTENNA CABLE
OK?

YES

AZO INSTALL THE L (R) VOR/
MARKER RECEIVER, M186 (M187)
(AMM 34-51-01/401).
REPLACE THE VOR ANTENNA,
M262 (AMM 34-51-03/401).

NO

21 REPLACE THE VOR ANTENNA
CABLE CIRCUIT FROM THE L (R)
VOR/MARKER RECEIVER, CONNECTOR
D329C (D357B), PINS 1 AND C1,
TO THE VOR ANTENNA, CONNECTOR
D35 (D37)(WDM 34-51-11,-21).
INSTALL THE L (R) VOR/
MARKER RECEIVER, M186 (M187)
(AMM 34-51-01/401).

Brg Flag on RDMIs, Lateral Dev Bar Missing on EHSI in VOR Mode,
VORCP Freq Select OK
Figure 109

EFFECTIVITY-

34-51-00

ALL

02

Page 111 Feb 10/96



1. ARINC Data Bus Charts

A. General

<u>CAUTION</u>: DO NOT DIRECTLY TOUCH THE CONNECTORS. USE A BREAKOUT BOX OR YOU CAN CAUSE DAMAGE TO THE CONNECTORS.

(1) The ARINC 429 data bus charts give data necessary to make an analysis of ARINC 429 transmitters, receivers, and data buses. For the test, use a breakout box at the available terminal or at the LRU connector.

B. Equipment

- (1) Standard multi-meter
- (2) 429EBP Data Bus Analyzer (recommended) JcAIR Instrumentation 400 Industrial Parkway, Industrial Airport, KS 66031

429-2 Data Bus Analyzer (alternative) Interface Technology 150 E. Arrow Highway, San Dimas, CA 91773

(3) A34011-1 Breakout Box (recommended) A34011-112 Breakout Box (alternative)

VOR										
DIGITAL OUTPUT BUS CHART										
	В	JS	NAME					BUS	ВІТ	
	SOURC	E		TYPE	BUS	CON	PINS	FORMAT		DATA BUS
VOR	(L	R)	Α	1	В	A04 B04	429	LO	OMNIBEARING #1
VOR	(L	R)	Α	2	В	B13 C13	429	LO	OMNIBEARING #2

VOR ID=11											
OCTAL LABELS CHART											
SIGNAL	TYPE	LABEL	FORMAT	MIN UPDATE RATE	SDI	BINARY RANGE	POSITIVE SENSE	UNITS			
SELECTED COURSE #1	Α	024	BCD	5	00	0-359	CW FROM NORTH	DEG			
VOR FREQUENCY	Α	034	BCD	5	00	108-117.95	ALWAYS POSITI	MHZ			
VOR OMNIBEARING	Α	222	BNR	16	00	± 180	CW FROM NORTH	DEG			

F	F	F	F١	$^{\circ}$	ГΊ	T۱	Ί	т	٧
_			_	·			-	•	



VOR										
DISCRETE OCTAL LABELS/BIT CHART										
SIGNAL	OCTAL LABEL	ВІТ	ONE-STATE	ZERO-STATE						
400 HZ MKR BEACON	222	11	PRESENT	NOT PRES						
1300 HZ MKR BEACON	222	12	PRESENT	NOT PRES						
4000 HZ MKR BEACON	222	13	PRESENT	NOT PRES						

VOR CP											
	DIGITAL OUTPUT BUS CHART										
	В	US NAME						BUS	ВІТ		
•	SOURC	E	TYPE	BUS	CON	ΡI	NS	FORMAT			DATA BUS
VORCP	(L	R)	А	1		18	31	429	LO	VOR	FREQUENCY
VORCP	(L	R)	Α	2		16	29	429	L0	DME	FREQUENCY

VOR CP ID=B1											
OCTAL LABELS CHART											
SIGNAL	TYPE	LABEL	FORMAT	MIN UPDATE RATE	SDI	BINARY RANGE	POSITIVE SENSE	UNITS			
SEL RUNWAY HDG-D	Α	017	BCD	5	00	0-359	CW FROM NORTH	DEG			
SELECTED COURSE #1	Α	024	BCD	5	00	0-359	CW FROM NORTH	DEG			
ILS FREQUENCY	Α	033	BCD	5	00	108-111.95	ALWAYS POSITI	MHZ			
VOR FREQUENCY	Α	034	BCD	5	00	108-117.95	ALWAYS POSITI	MHZ			
DME FREQUENCY	Α	035	BCD	5	00	108-135.95	ALWAYS POSITI	MHZ			

EFFECTIVITY-

ALL

34-51-00



VOR CP										
DISCRETE OCTAL LABELS/BIT CHART										
SIGNAL	OCTAL LABEL	BIT	ONE-STATE	ZERO-STATE						
VOR/ILS FREQ	034	14	ILS	VOR						
DME MODE 1	035	11	CODED							
DME MODE 2	035	12	CODED							
DME MODE 3	035	13	CODED							
ILS/VOR FREQ	035	14	ILS	VOR						

ALL

34-51-00



AIR TRAFFIC CONTROL (ATC) SYSTEM

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
ANTENNA - BOTTOM ATC, M259 ANTENNA - TOP ATC, M261 CIRCUIT BREAKER - ATC ANT SWITCH, C4423 ATC LEFT, C616 ATC RIGHT, C617 COMPUTER - (FIM 31-41-00/101) EICAS LEFT, M10181 EICAS RIGHT, M10182 COMPUTER - (FIM 34-45-00/101)	1 1 2	1 1 1 1	BOTTOM OF FUSELAGE TOP OF FUSELAGE FLIGHT COMPARTMENT, P11 11F11 11F7 11F28	34-53-03 34-53-03 * * *
TCAS, M1705 1 PANEL - ATC CONTROL, M81 RELAY - (FIM 31-01-36/101) SYS NO. 1 AIR/GND, K143 RELAY - (FIM 31-01-37/101) SYS NO. 2 AIR/GND, K200 SWITCH - (FIM 34-12-00/101) LEFT ADC, S482 RIGHT ADC, S483	2	1	FLIGHT COMPARTMENT, P8	34-53-02
SWITCH - BOTTOM ATC ANT, S10564	3	1	119AL, MAIN EQUIP CENTER, E2-2	34-53-04
SWITCH - TOP ATC ANT, S10563	3	1	119AL, MAIN EQUIP CENTER, E2-3	34-53-04
TRANSPONDER - LEFT ATC, M112 TRANSPONDER - RIGHT ATC, M113	2 2	1 1	119AL, MAIN EQUIP CENTER, E2-2 119AL, MAIN EQUIP CENTER, E2-3	34-53-01 34-53-01

^{*} SEE THE WDM EQUIPMENT LIST

1 AIRPLANES WITH TCAS

Air Traffic Control (ATC) System - Component Index Figure 101

EFFECTIVITY-


D18233


34-53-00

02

Page 101 May 10/96







BOTTOM OR TOP ATC ANTENNA, M259 OR M261

Air Traffic Control (ATC) System - Component Location Figure 102 (Sheet 1)

ALL ALL


34-53-00


01

Page 102 Feb 10/94




FAULT ISOLATION/MAINT MANUAL





LEFT OR RIGHT ATC TRANSPONDER, M112 OR M113





LEFT OR RIGHT ATC TRANSPONDER, M112 OR M113



> AIRPLANES WITH ROCKWELL COLLINS MODE-S TRANSFORMER

AIRPLANES WITH ACSS MODE-S TRANSFORMER

Air Traffic Control (ATC) System - Component Location Figure 102 (Sheet 2)


EFFECTIVITY-ALL

34-53-00

17

Page 103 Dec 22/06





TOP OR BOTTOM ATC ANTENNA SWITCH, \$10563 OR \$10564



Air Traffic Control (ATC) System - Component Location (Detail from Sht 2) Figure 102 (Sheet 3)

C52732

34-53-00

05

Page 104 Nov 10/93



MAKE SURE THIS SYSTEM WILL OPERATE: ADC SYSTEM (MM 34-12-00/501)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11F7,11F11,11F28

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:


ELECTRICAL POWER IS ON (MM 24-22-00/201)

ATC SYSTEM "BITE" PROCEDURE

YES SET THE TRANSPONDER SELECT 20 REPLACE THE L (R) ATC SWITCH ON THE ATC CONTROL TRANSPONDER, M112 (M113) (MM 34-53-01/401). PANEL TO THE "L (R)" POSITION. SET THE L (R) ADC SWITCH ON THE INSTRUMENT SOURCE SELECT PANEL TO THE "NORM" POSITION. PUSH AND HOLD THE TEST SWITCH ON THE L (R) ATC TRANSPONDER. DOES THE RED "TPR-FAIL" LIGHT COME ON AT THE END OF THE TEST? NO DOES THE RED "LOWER ANT" 10 SET THE TRANSPONDER SELECT 21 REPLACE THE BOTTOM LIGHT COME ON AT THE END OF SWITCH ON THE ATC CONTROL ANTENNA, M259 (MM 34-53-03/ PANEL TO THE "R (L)" POSITION. THE TEST? 401). PUSH AND HOLD THE TEST SWITCH IF THE PROBLEM CONTINUES, NO ON THE R (L) ATC TRANSPONDER. REPLACE THE BOTTOM ATC ANT DOES THE RED "LOWER ANT" SWITCH, S10564 (MM 34-53-04/ SEE SHEET 2 LIGHT COME ON AT THE END OF 401). THE TEST? IF THE PROBLEM CONTINUES, (BLOCK 3) REPLACE THE ANTENNA CIRCUIT NO FROM THE BOTTOM ANT SWITCH, CONNECTOR D2199, PINS A1 AND C1, TO THE BOTTOM ATC ANTENNA, CONNECTOR D41, PINS A1 AND C1 (WDM 34-53-13). 22 REPLACE THE ANTENNA CIR-CUIT FROM THE L (R) ATC TRANS-PONDER, CONNECTOR D331B (D359B), PINS 71 AND C71, TO THE BOTTOM ATC ANT SWITCH, CONNECTOR D2197 (D1441), PINS A1 AND C1 (WDM 34-53-13).


ATC System BITE Procedure Figure 103 (Sheet 1)

34-53-00



ATC System BITE Procedure Figure 103 (Sheet 2)






ATC System BITE Procedure Figure 103 (Sheet 3)

ALL

34-53-00

04

Page 107 Feb 10/94




THE GREEN "TPR-PASS" LIGHT WILL STAY ON OR FLICKER AT THE END OF THE TEST IF THE TRANSPONDER IS REPLYING TO A SIGNAL.

ATC System BITE Procedure Figure 103 (Sheet 4)




PREREQUISITES MAKE SURE THIS SYSTEM WILL OPERATE: ADC SYSTEM (MM 34-12-00/501) MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11F7,11F11,11F28 ALT RPTG INOP WITH LEFT (RIGHT) TXPDR SELECTED PREREQUISITES MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11F7,11F11,11F28 MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS: ELECTRICAL POWER IS ON (MM 24-22-00/201)



Alt Rptg Inop with Left (Right) Txpdr Selected Figure 104 (Sheet 1)

34-53-00
ALL
03 Page 109
Feb 10/94



Alt Rptg Inop with Left (Right) Txpdr Selected Figure 104 (Sheet 2)




MAKE SURE THIS SYSTEM WILL OPERATE: ADC SYSTEM (MM 34-12-00/501)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11F7,11F11,11F28

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:

ELECTRICAL POWER IS ON (MM 24-22-00/201)




ATC Transmission Problems Figure 105 (Sheet 1)

EFFECTIVITY-ALL

695377

ATC TRANSMISSION

34-53-00



THE GREEN "TPR-PASS" LIGHT WILL STAY ON OR FLICKER AT THE END OF THE TEST IF THE TRANSPONDER IS REPLYING TO A SIGNAL.

ATC Transmission Problems Figure 105 (Sheet 2)



1. ARINC Data Bus Charts

A. General

<u>CAUTION</u>: DO NOT DIRECTLY TOUCH THE CONNECTORS. USE A BREAKOUT BOX OR YOU CAN CAUSE DAMAGE TO THE CONNECTORS.

(1) The ARINC 429 data bus charts give data necessary to make an analysis of ARINC 429 transmitters, receivers, and data buses. For the test, use a breakout box at the available terminal or at the LRU connectors.

B. Equipment

- (1) Standard multi-meter
- (2) 429EBP Data Bus Analyzer (recommended) JcAIR Instrumentation 400 Industrial Parkway, Industrial Airport, KS 66031

429EBP Data Bus Analyzer (alternative) 150 E. Arrow Highway, San Dimas, CA 91773

(3) A34011-1 Breakout Box (recommended)
A34011-112 Breakout Box (alternative)

ATC PNL								
DIGITAL OUTPUT BUS CHART								
BUS NAME	SUS NAME				BUS	ВІТ		
SOURCE	TYPE	BUS	CON	PINS	FORMAT		DATA BUS	
TCPNL (L)	Α	1	P1	22 23	429	LO	CONTROL DATA OUT L	
TCPNL (R)	Α	2	P2	22 23	429	LO	CONTROL DATA OUT R	

ATC PNL ID = B8									
OCTAL LABELS CHART									
SIGNAL	TYPE	LABEL	FORMAT	MIN UPDATE RATE	SDI	BINARY RANGE	POSITIVE SENSE	UNITS	
XPONDER CODE	Α	031	BCD	5	00	N/A	N/A	N/A	

 34-53-00



DISTANCE MEASURING EQUIPMENT (DME) SYSTEM

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
ANTENNA - L DME, M263		1	BOTTOM FUSELAGE	34-55-02
ANTENNA - R DME, M264		1	BOTTOM FUSELAGE	34-55-02
CIRCUIT BREAKERS -			FLT COMPT, P11	
DME LEFT, C582		1	11E11	*
DME RIGHT, C583		1	11E32	*
INDICATOR - (REF 34-22-00, FIG. 101)				
L RADIO DISTANCE MAGNETIC, N3		1		
R RADIO DISTANCE MAGNETIC, N43		1		
INTERROGATOR - L DME, M123		1	119AL, MAIN EQUIP CTR, E2-2	34-55-01
INTERROGATOR - R DME, M124		1	119AL, MAIN EQUIP CTR, E2-3	34-55-01
PANEL - (REF 34-22-00, FIG. 101)				
L EFIS CONTROL, M94				
R EFIS CONTROL, M93 PANEL - (REF 34-51-00, FIG. 101)				
L VOR CONTROL, M91				
R VOR CONTROL, M92				
RELAY - (REF 31-01-36, FIG. 101)				
SYS NO. 1 AIR/GND, K124				
SYS NO. 2 AIR/GND, K214				
UNIT - (REF 31-31-00, FIG. 101)				
DIGITAL FLIGHT DATA ACQUISITION, M138				

^{*} SEE THE WDM EQUIPMENT LIST

Distance Measuring Equipment (DME) System - Component Index Figure 101

ALL


34-55-00

03

Page 101 Aug 10/90



FAULT ISOLATION/MAINT MANUAL



Distance Measuring Equipment (DME) System - Component Location Figure 102

ALL

O1 Page 102
Aug 10/90


BOEING PROPRIETARY - Copyright (C) - Unpublished Work - See title page for details.



ELECTRICAL POWER (MM 24-22-00/201) EFIS (MM 34-22-00/501) VOR (MM 34-51-00/501) ILS (MM 34-31-00/501)

DME SYSTEM BITE PROCEDURE

CB'S: 11A1,11E11,11E32,11E33




DME System BITE Procedure Figure 103 (Sheet 1)


ALL

O2 Page 103
Feb 10/91

BOEING PROPRIETARY - Copyright (C) - Unpublished Work - See title page for details.



DME System BITE Procedure Figure 103 (Sheet 2)



DME System BITE Procedure Figure 103 (Sheet 3)

ALL

34-55-00

04


Page 105 Aug 10/98

VOR MODE - DME DISPLAYS DASHES, VOR IDENT NORMAL

PREREQUISITES

ELECTRICAL POWER (MM 24-22-00/201) EFIS (MM 34-22-00/501)

11A1,11E11,11E32,11E33



VOR Mode - DME Displays Dashes, VOR Ident Normal Figure 104


EFFECTIVITY-ALL

34-55-00



ILS MODE - DME DISPLAYS DASHES, ILS IDENT NORMAL ELECTRICAL POWER (MM 24-22-00/201) EFIS (MM 34-22-00/501) ILS (MM 34-31-00/501)


CB'S: 11A1,11E11,11E32,11E33



ILS Mode - DME Displays Dashes, ILS Ident Normal Figure 105 (Sheet 1)

EFFECTIVITY-ALL

34-55-00





MAKE SURE THIS SYSTEM WILL OPERATE: EFIS (AMM 34-22-00/501)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11A1,11E11,11E32,11E33

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)

BLANK DME DISPLAY ON EHSI - OTHERWISE NORMAL

I REMOVE THE L (R) DME
INTERROGATOR, M123 (M124)
(AMM 34-55-01/401).
REMOVE THE L (R) EFIS SG,
M148 (M150)(AMM 34-22-01/401).
MAKE SURE THERE IS DATA ON
THE 429 INPUT BUS FROM THE
L (R) DME INTERROGATOR AT THE
L (R) EFIS SG, CONNECTOR D425A
(D373D), PINS G2 AND H2

(WDM 34-22-19,29).

IS THERE DATA ON THE BUS?

YES

20 INSTALL THE L (R) DME
INTERROGATOR, M123 (M124)
(AMM 34-55-01/401) AND REPLACE
THE L (R) EFIS SG, M148 (M150)
(AMM 34-22-01/401).

NO

21 EXAMINE THE DATA BUS
CIRCUIT FROM THE L (R) DME
INTERROGATOR, CONNECTOR D333B
(D361B), PINS G3 AND H3, T0
THE L (R) EFIS SG, CONNECTOR
D425A (D373D), PINS G2 AND H2
(WDM 34-22-19,-29).
REPAIR THE PROBLEMS THAT
YOU FIND.
INSTALL THE L (R) DME
INTERROGATOR, M123 (M124)
(AMM 34-55-01/401).
INSTALL THE L (R) EFIS SG,
M148 (M150)(AMM 34-22-01/401).

Blank DME Display on EHSI - Otherwise Normal Figure 106

EFFECTIVITY-

ALL

34-55-00

02

Page 109 Nov 10/95



MAKE SURE THIS SYSTEM WILL OPERATE: EFIS (AMM 34-22-00/501)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11A1,11E11,11E32,11E33

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)

DME EHSI AND RDMI DISPLAYS BLANK

PUSH AND HOLD THE TEST
SWITCH ON THE L (R) DME INTERROGATOR.
DOES THE RED LRU STATUSFAIL LIGHT COME ON AT THE END

OF THE TEST (AFTER 6 SECONDS)?

21 REPLACE THE L (R) DME
INTERROGATOR, M123 (M124)
(AMM 34-55-01/401).

NO

Z2 REMOVE THE L (R) DME
INTERROGATOR, M123 (M124)
(AMM 34-55-01/401).
REMOVE THE L (R) EFIS SG,
M148 (M150)(AMM 34-22-01/401).
EXAMINE THE DATA BUS
CIRCUIT FROM THE L (R) DME
INTERROGATOR, CONNECTOR D333B
(D361B), PINS G3 AND H3, T0
THE L (R) EFIS SG, CONNECTOR
D425A (D373D), PINS G2 AND H2
(WDM 34-22-19,-29).
REPAIR THE PROBLEMS THAT
YOU FIND.
INSTALL THE DME INTERROGATOR AND THE EFIS SG.

DME EHSI and RDMI Displays Blank Figure 107

34-55-00

02


Page 110 Nov 10/95



AUTOTUNE MODE DME DISPLAYS SHOW DASHES

ELECTRICAL POWER (MM 24-22-00/201) EFIS (MM 34-22-00/501) FMC (MM 34-61-00/501)

CB'S: 11A1,11E11,11E32,11E33



Autotune Mode - DME Displays Show Dashes Figure 108

ALL

O4 Page 111

Nov 10/95

BOEING PROPRIETARY - Copyright (C) - Unpublished Work - See title page for details.



DME IDENT SIGNAL
MISSING - DISPLAYS
NORMAL

ELECTRICAL POWER (MM 24-22-00/201) VOR (MM 34-22-00/501)

CB'S: 11A1,11E11,11E32,11E33



REPLACE THE L (R) DME INTERROGATOR, M123 (M124)(MM 34-55-01/401). IF THE PROBLEM CONTINUES, REPLACE THE L (R) VOR CONTROL PANEL, M91 (M92)(MM 34-51-02/201).

DME Ident Signal Missing - Displays Normal Figure 109

 34-55-00



1. ARINC Data Bus Charts

A. General

<u>CAUTION</u>: DO NOT DIRECTLY TOUCH THE CONNECTORS. USE A BREAKOUT BOX OR YOU CAN CAUSE DAMAGE TO THE CONNECTORS.

(1) The ARINC 429 data bus charts give data necessary to make an analysis of ARINC 429 transmitters, receivers, and data buses. For the test, use a breakout box at the available terminal or at the LRU connector.

B. Equipment

- (1) Standard multi-meter
- (2) 429EBP Data Bus Analyzer (recommended) JcAIR Instrumentation 400 Industrial Parkway Industrial Airport, KS 66031

429EBP Data Bus Analyzer (alternative) Interface Technology 150 E. Arrow Highway San Dimas, CA 91773

(3) A34011-1 Breakout Box (recommended) A34011-112 Breakout Box (alternative)

DME												
DIGITAL OUTPUT BUS CHART												
BUS NAME							BUS	ВІТ				
	SOURC	E		TYPE	BUS	CON	PINS	FORMAT			DATA	BUS
DME	(L	R)	Α	1	В	G01 H01	429	L0	DME	DATA	OUTPT#1
DME	(L	R)	Α	2	В	G03 H03	429	L0	DME	DATA	OUTPT#2

EFFECTIVITY-

34-55-00



DME	ID=09											
OCTAL LABELS CHART												
	SIGNAL	TYPE	LABEL	FORMAT	MIN UPDATE RATE	SDI	BINARY RANGE	POSITIVE SENSE	UNITS			
DME	FREQUENCY	Α	035	BCD	5	00	108-135.95	ALWAYS POS	MHZ			
DME	DISTANCE-D	Α	201	BCD	6	00	-1T0399 . 99	ALWAYS POS	NM			
DME	DISTANCE	Α	202	BNR	6	00	0-512	ALWAYS POS	NM			

DME											
DISCRETE OCTAL LABELS/BIT CHART											
SIGNAL	OCTAL LABEL	ВІТ	ONE-STATE	ZERO-STATE							
VEL MEMORY MODE	202	11	MEM MODE	NORM MODE							

EFFECTIVITY-

34-55-00

07



AUTOMATIC DIRECTION FINDER (ADF) SYSTEM

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
ANTENNA - LEFT ADF, M265 ANTENNA - RIGHT ADF, M266 CIRCUIT BREAKER - ADF LEFT, C607 ADF RIGHT, C632 INDICATOR - (FIM 34-22-00/101) LEFT RDMI, N3 RIGHT RDMI, N43 PANEL - ADF CONTROL, M1046	1 1 2 2	1 1 1 1	TOP OF FUSELAGE TOP OF FUSELAGE FLIGHT COMPARTMENT, P11 11F6 11A3 FLIGHT COMPARTMENT, P8	34-57-03 34-57-03 * *
RECEIVER - LEFT ADF, M215 RECEIVER - RIGHT ADF, M216 RELAY - (FIM 31-01-36/101) SYS NO. 1 AIR/GND, K124 SYS NO. 2 AIR/GND, K214	2 2	1 1	821, MID EQUIPMENT CENTER, E5-1 821, MID EQUIPMENT CENTER, E5-1	34-57-01 34-57-01

^{*} SEE THE WDM EQUIPMENT LIST

Automatic Direction Finder (ADF) System - Component Index Figure 101


ALL


34-57-00

10

Page 101 Feb 10/94







LEFT OR RIGHT ADF ANTENNA, M265 OR M266


Automatic Direction Finder (ADF) System - Component Location Figure 102 (Sheet 1)

34-57-00

03

Page 102 Feb 10/94







L TONE R HEBBO

FLIGHT COMPARTMENT

ADF CONTROL PANEL, M1046





LEFT OR RIGHT ADF RECEIVER, M215 OR M216

(0)

Automatic Direction Finder (ADF) System - Component Location Figure 102 (Sheet 2)

34-57-00

15

Page 103 Feb 10/94




MAKE SURE THIS SYSTEM WILL OPERATE: FLIGHT INTERPHONE SYSTEM (MM 23-51-00/501)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11A3,11A6,11F6,11F25

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:

ELECTRICAL POWER IS ON (MM 24-22-00/201)

ADF AUDIO PROBLEMS



ADF Audio Problems Figure 103

34-57-00

11


Page 104 Feb 10/94



MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11A3,11A6,11F6,11F25

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)


LEFT (RIGHT) ADF **BEARING PROBLEMS** ON BOTH RDMIs



Left (Right) ADF Bearing Problems on Both RDMIs Figure 104 (Sheet 1)

EFFECTIVITY-ALL

213136



Left (Right) ADF Bearing Problems on Both RDMIs Figure 104 (Sheet 2)

ALL

O6 Page 106
Nov 10/95



1. ARINC Data Bus Charts

A. General

<u>CAUTION</u>: DO NOT DIRECTLY TOUCH THE CONNECTORS. USE A BREAKOUT BOX OR YOU CAN CAUSE DAMAGE TO THE CONNECTORS.

(1) The ARINC 429 data bus charts give data necessary to make an analysis of ARINC 429 transmitters, receivers, and data buses. For the test, use a breakout box at the available terminal or at the LRU connector.

B. Equipment

- (1) Standard multi-meter
- (2) 429EBP Data Bus Analyzer (recommended) JcAIR Instrumentation 400 Industrial Parkway, Industrial Airport, KS 66031

429-2 Data Bus Analyzer (alternative) Interface Technology 150 E. Arrow Highway, San Dimas, CA 91773

(3) A34011-1 Breakout Box (recommended) A34011-112 Breakout Box (alternative)

NOTE: Octal label 222 is a multiple function label and will not display correctly in engineering units on the data bus analyzer unless hexadecimal equipment ID=11 is selected. For analyzers not capable of having ID selected, display the label in hexadecimal format and record the value. Set the data bus analyzer to transmit label 162 in hex format and insert the value recorded for label 222. Change label 162 format to engineering to display the correct engineering units.

EFFECTIVITY-



ADF	ADF												
	DIGITAL OUTPUT BUS CHART												
BUS NAME						BUS	ВІТ						
	SOURCE TYPE BUS			сои	PINS	FORMAT		DATA BUS					
ADF	(L)	Α	1	В	B10 B11	429	LO	BEARING OUTPUT NO. 1					

ADF ID = 12												
OCTAL LABELS CHART												
SIGNAL	TYPE	LABEL	FORMAT	MIN UPDATE RATE	SDI	BINARY RANGE	POSITIVE SENSE	UNITS				
DF BEARING	Α	162	BNR	16	00	± 180	CW FROM HDG	DEG				

ALL ALL



ADF PNL											
DIGITAL OUTPUT BUS CHART											
BUS NAME			BUS	ВІТ							
SOURCE	TYPE	BUS	CON	PINS	FORMAT		DATA BUS				
ADF PNL (L)	А	1	29	12 13	429	L0	FREQ/FUNC - L				
ADF PNL (L)	Α	2	31	12 13	429	LO	FREQ/FUNC - R				

ADF PNL ID = B2											
OCTAL LABELS CHART											
SIGNAL	TYPE	LABEL	FORMAT	MIN UPDATE RATE	SDI	BINARY RANGE	POSITIVE SENSE	UNITS			
ADF FREQUENCY	Α	032	BCD	5	00	190 to 1750	ALWAYS POS	KHZ			



ADF PNL											
DISCRETE OCTAL LABELS/BIT CHART											
SIGNAL OCTAL LABEL BIT ONE-STATE ZERO-STATE											
BFO ON	032	11	BFO ON	BFO OFF							
ANT MODE	032	12	ANT MODE	ADF MODE							
0.5 KHZ TUNING	032	14	.5 KHZ	.O KHZ							

EFFECTIVITY-



FLIGHT MANAGEMENT COMPUTER SYSTEM

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
CIRCUIT BREAKER - DATA LOADER, C627 FMCS CDU LEFT, C597 FMCS CDU RIGHT, C598 FMCS CMPTR LEFT, C609 FMCS CMPTR RIGHT, C610 COMPUTER - (FIM 31-41-00/101) EICAS L, M10181	1	1 1 1 1 1	FLT COMPT, P11 11B1 11E8 11E29 11E9 11E30	* * * *
EICAS R, M10182 COMPUTER - FLIGHT MANAGEMENT L, M134 COMPUTER - FLIGHT MANAGEMENT R, M135 INDICATOR - (FIM 34-22-00/101) CAPT ELECTRONIC ATTITUDE DIRECTOR, N4 CAPT ELECTRONIC HORIZONTAL SITUATION, N5 F/O'S ELECTRONIC ATTITUDE DIRECTOR, N44	2 2	1 1	119AL, MAIN EQUIP CTR, E2-2 119AL, MAIN EQUIP CTR, E2-3	34-61-01 34-61-01
F/O'S ELECTRONIC HORIZONTAL SITUATION, N45 LIGHT - FMC ANNUNCIATOR, L603 LOADER - AIRBORNE DATA, M1736 PANEL - (FIM 22-11-00/101) AFCS MODE CONTROL, M90 PANEL - (FIM 34-22-00/101) EFIS CONTROL D, M94	1 2	1 1	FLT COMPT, P1-3 FLT COMPT, P61	* 34-61-05
EFIS CONTROL R, M93 PANEL - DATA LOADER CONTROL, M1737	2	1	FLT COMPT, P61	34-61-06

^{*} SEE THE WDM EQUIPMENT LIST

Flight Management Computer System - Component Index Figure 101 (Sheet 1)

ALL

34-61-00

612256



FLIGHT MANAGEMENT COMPUTER SYSTEM

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
PRINTER - (REF 31-35-00, FIG. 101) MULTI-INPUT, M1631 RELAY CDU NAV ENABLE L, K2065	2	1	119AL, MAIN EQUIP CTR, E2-2	*
FCC SOURCE SELECT L, K2067 RELAY	2	1	119AL, MAIN EQUIP CTR, E2-3	*
CAPT & F/O SOURCE SELECT R, K2069 CDU NAV ENABLE R, K2066 FCC SOURCE SELECT R, K2068		1 1		*
RELAY - (REF 31-01-36, FIG. 101) FMC TUNING L, K757 RELAY - (REF 31-01-37, FIG. 101) FMC TUNING R, K758				
SWITCH - LEFT FMC, S2	1	1	FLT COMPT, P1 FLT COMPT, P3	*
SWITCH - RIGHT FMC, S10 SYMBOL GENERATOR - (REF 34-22-00, FIG. 101) EFIS L, M148 EFIS C, M149 EFIS R, M150	'	'	FLI COMPI, F3	
UNIT - FLIGHT MANAGEMENT COMPUTER CONTROL/ DISPLAY L, M76	1	1	FLT COMPT, P9	34-61-02
UNIT - FLIGHT MANAGEMENT COMPUTER CONTROL/ DISPLAY R, M77	1	1	FLT COMPT, P9	34-61-02


^{*} SEE THE WDM EQUIPMENT LIST

Flight Management Computer System - Component Index Figure 101 (Sheet 2)

EFFECTIVITY-ALL 34-61-00

727414






 \Box

BRT

EXEC

PROG


w




Flight Management Computer System - Component Location Figure 102 (Sheet 1)

EFFECTIVITY-34-61-00 ALL 23 Page 103 May 10/97 BOEING PROPRIETARY - Copyright (C) - Unpublished Work - See title page for details.








MAIN EQUIPMENT CENTER





LEFT OR RIGHT FLIGHT MANAGEMENT COMPUTER, M134 OR M135



Flight Management Computer System - Component Location Figure 102 (Sheet 2)

ALL

34-61-00

05

Page 104 Aug 10/90



FMC NAV DATA CROSSLOADING **PROBLEMS**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:

11E8,11E9,11E29,11E30 MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:

ELECTRICAL POWER IS ON (AMM 24-22-00/201)

SET THE L FMC NAV SWITCH ON THE P1 PANEL TO THE FMC-L POSITION AND THE R FMC NAV SWITCH ON THE P3 PANEL TO THE FMC-R POSITION. GET THE ANALOG DISCR PAGE ON THE TWO CDUS. PUSH THE

NEXT PAGE KEY ON THE TWO CDUs TO GET THE PAGE WITH "SRCE SEL SW X" ON IT.

DO THE TWO CDUs SHOW "SRCE SEL SW L" AND THE "SRCE SEL SW R" AS "NORM"?

YES

YES

SEE SHEET 2 (BLOCK 6)

20 REMOVE THE LEFT (RIGHT) CONNECTOR D4151 (D4505). DO A CONTINUITY CHECK FROM CON-NECTOR D4151 (D4505), PIN 20 (32), TO GROUND (WDM 34-61-11, -21).

IS THE CONTINUITY CORRECT?

NO

30 REPLACE THE LEFT (RIGHT) FMC SW, S2 (S10)(WDM 34-61-11, -16,-21,-26).

31 REMOVE THE LEFT (RIGHT) CDU, M76 (M77)(AMM 34-61-02/ 201). EXAMINE THE CIRCUIT FROM THE LEFT (RIGHT) CDU, CONNEC-TOR D465 (D467), PIN 29, TO THE LEFT (RIGHT) CONNECTOR D1451 (D4505), PIN 20 (32) (WDM 34-61-11,-21).

REPAIR THE PROBLEMS THAT YOU FIND.

INSTALL THE CDU AND CON-NECT CONNECTOR D4151 (D4505) AGAIN.

YES DOES THE LEFT (RIGHT) FMC 32 DO THIS PROCEDURE: FLIGHT SHOW FAILURE INDICATIONS? MANAGEMENT COMPUTER SYSTEM BITE PROCEDURE (FIM 34-61-00/ 101, FIG. 111).

YES DOES THE LEFT (RIGHT) CDU 33 REPLACE THE LEFT (RIGHT) SHOW FAILURE INDICATIONS? CDU, M76 (M77)(AMM 34-61-02/ 201). NO

NO IS THE NAVIGATION DATA 34 PUT THE NAV DATA BASE INTO BASE IN THE MASTER FMC THE MASTER FMC (AMM 34-61-00/ CORRECT? 201).

NO 5 GET THE SENSOR STATUS PAGE ON THE TWO CDUs. PUSH THE NEXT KEY TO SHOW PAGE 2/2. ON THE LEFT CDU IS THE CONDITION OF"FMC, RIGHT" SHOWN AS "OK"?

35 REMOVE THE LEFT FMC, M134, AND RIGHT FMC, M135 (AMM 34-61-01/401).EXAMINE THE CIRCUIT FROM


THE LEFT FMC, CONNECTOR D323B, PINS G1,H1, TO THE RIGHT FMC, CONNECTOR D353A, PINS A13,B13 (WDM 34-61-11). REPAIR THE PROBLEMS THAT

YOU FIND. INSTALL THE TWO FMCs.


FMC NAV Data Crossloading Problems Figure 103A (Sheet 1)

EFFECTIVITY-ALL 05

34-61-00



FMC NAV Data Crossloading Problems Figure 103A (Sheet 2)






ACTION PERFORMED ON LEFT (RIGHT) CDU KEYBOARD IS NOT EFFECTIVE

PREREQUISITES


MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11E8,11E9,11E29,11E30

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)



Action Performed on Left (Right) CDU Keyboard Is Not Effective Figure 104 (Sheet 1)

34-61-00



Action Performed on Left (Right) CDU Keyboard Is Not Effective Figure 104 (Sheet 2)

ALL

O5
Page 108
Aug 10/98


BOEING PROPRIETARY - Copyright (C) - Unpublished Work - See title page for details.



ELECTRICAL POWER (MM 24-22-00/201)
AIR DATA COMPUTING SYSTEM (MM 34-12-00/501)
VOR SYSTEM (MM 34-51-00/501)
DME SYSTEM (MM 34-55-00/501)
INERTIAL REFERENCE SYSTEM (MM 34-21-00/501)

DATA INCORRECT ON LEFT (RIGHT) CDU DISPLAY

CB'S: 11E8,11E9,11E29,11E30




Data Incorrect on Left (Right) CDU Display Figure 105 (Sheet 1)

ALL

O1 Page 109
Aug 10/90

BOEING PROPRIETARY - Copyright (C) - Unpublished Work - See title page for details.



Data Incorrect on Left (Right) CDU Display Figure 105 (Sheet 2)

ALL

O1 Page 110
Aug 10/90

BOEING PROPRIETARY - Copyright (C) - Unpublished Work - See title page for details.




MAKE SURE THESE SYSTEMS WILL OPERATE:
EICAS (AMM 31-41-00/501)
FUEL QUANTITY INDICATING SYSTEM (AMM 28-41-00/501)
FUEL FLOW INDICATING SYSTEM (AMM 73-31-00/501)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11E8, 11E9, 11E29, 11E30

FUEL ERROR ON CDU DISPLAY


MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)



Fuel Error on CDU Display Figure 106 (Sheet 1)

EFFECTIVITY ALL

34-61-00



Fuel Error on CDU Display Figure 106 (Sheet 2)

MAKE SURE THESE SYSTEMS WILL OPERATE:
FUEL QUANITY INDICATING SYSTEM (AMM 28-41-00/501)
CLOCKS (AMM 31-25-00/501)
INERTIAL REFERENCE SYSTEM (AMM 34-21-00/501)


VOR SYSTEM (AMM 34-21-0 DME SYSTEM (AMM 34-21-0 DME SYSTEM (AMM 34-55-00/501)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11E8,11E9,11E29,11E30

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)

FMC CDU MESSAGES

296993




MAKE SURE BEFORE A MAINTENANCE PROCEDURE IS DONE THAT THE CDU MESSAGE IS CAUSED BY A PROBLEM AND NOT THE RESULT OF SYSTEM OPERATION.

FMC CDU Messages Figure 106A (Sheet 1)

ALL

Of Page 113
Aug 10/93

BOEING PROPRIETARY - Copyright (C) - Unpublished Work - See title page for details.



2 MTH 275-999


FMC CDU Messages Figure 106A (Sheet 2)





FMC NAVIGATION
DATA BASE OR
PROGRAM INCORRECT

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)



1 > MTH 275-999

FMC Navigation Data Base or Program Incorrect Figure 107

ALL

ALL

15 Page 115

Aug 10/95

BOEING PROPRIETARY - Copyright (C) - Unpublished Work - See title page for details.



FMC LIGHT FAILS TO ILLUMINATE WITH CDU ALERT

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11E8,11E9,11E29,11E30

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)

N0 PUSH THE MASTER DIM AND 20 PUT A NEW LAMP IN THE FMC, TEST SWITCH. LIGHT L603. DOES THE FMC LIGHT COME IF THE PROBLEM CONTINUES, REPLACE THE DIODE/FUSE CARD ON? (AMM 33-16-02/201). YES 21 EXAMINE THE CIRCUIT FROM THE FMC, LIGHT L603, PIN 2, TO THE LEFT (RIGHT) FMC, CONNECTOR D323A (D353A), PIN K13 (K13)(WDM 34-61-15, REPAIR THE PROBLEMS THAT YOU FIND. IF THE PROBLEM CONTINUES, REPLACE THE LEFT (RIGHT) FMC, M134 (M135), THAT HAD THE CDU MESSAGE ALERT (AMM 34-61-01/ 401).

FMC Light Fails to Illuminate with CDU Alert Figure 108

34-61-00

02

Page 116 Nov 10/95




MAKE SURE THESE SYSTEMS WILL OPERATE:
AUTOPILOT (AMM 22-10-00/501)
THRUST MANAGEMENT SYSTEM (AMM 22-32-00/501)
INERTIAL REFERENCE SYSTEM (AMM 34-21-00/501) OR
AIR DATA INERTIAL REFERENCE SYSTEM
(AMM 34-26-00/501)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11E8, 11E9, 11E29, 11E30

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)

"L (R) FMC FAIL" ON EICAS



"L (R) FMC FAIL" on EICAS Figure 108A

ALL

O1 Page 117

Dec 22/08

BOEING PROPRIETARY - Copyright (C) - Unpublished Work - See title page for details.



"MAP RANGE DISAGREE"
MESSAGE DISPLAYED
ON LEFT (RIGHT) EHSI

PREREQUISITES

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11E8,11E9,11E29,11E30

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)

1 GET THE SENSOR STATUS PAGE
ON THE LEFT (RIGHT) CDUS.
IS THE EFIS/CP SHOWN AS
"FAIL"?

NO

11 REPLACE THE LEFT (RIGHT)
EFIS CONTROL PANEL, M94 (M93)
(AMM 34-22-02/201).

11 REPLACE APPLICABLE (L,C,R)
EFIS SYMBOL GENERATOR (M148, M149,M150)(AMM 34-22-01/401).

MAP RANGE DISAGREE Message Displayed on Left (Right) EHSI Figure 109

48574




MAKE SURE THESE SYSTEMS WILL OPERATE:
AUTOPILOT (AMM 22-10-00/501)
THRUST MANAGEMENT SYSTEM (AMM 22-32-00/501)
INERTIAL REFERENCE SYSTEM (AMM 34-21-00/501)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11E8,11E9,11E29,11E30

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)

VNAV PATH, ALTITUDE, TRANSITION; LNAV PATH, HEADING, TRANSITION ERROR



VNAV Path, Altitude, Transition, LNAV Path, Heading, Transition Error Figure 109A

34-61-00

01

Page 119 Aug 22/03



MAKE SURE THESE SYSTEMS WILL OPERATE:
AUTOPILOT (AMM 22-10-00/501)
THRUST MANAGEMENT SYSTEM (AMM 22-32-00/501)
INERTIAL REFERENCE SYSTEM (AMM 34-21-00/501)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11E8, 11E9, 11E29, 11E30

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)

ERRONEOUS DISPLAY
OF ".ATC" AND
".FMC" MESSAGES
ON EICAS

NO 1 DO THE ".ATC" AND ".FMC" 20 THE SYSTEM IS OK. MESSAGES SHOW ON THE EICAS WHEN NO ATC AND/OR AOC INFORMATION UPLINK TO THE FMC? YFS NO OPEN THESE CIRCUIT 21 THE SYSTEM IS OK. BREAKERS ON THE P11 PANEL, WAIT FOR AT LEAST 10 SECONDS: 11E9, FMCS CMPTR LEFT 11E30, FMCS CMPTR RIGHT CLOSE THESE CIRCUIT **BREAKERS:** 11E9, FMCS CMPTR LEFT 11E30, FMCS CMPTR RIGHT DO THE ".ATC" AND ".FMC" MESSAGES SHOW ON THE EICAS? YES 22 IF THE PROBLEM CONTINUES, REPLACE THE LEFT (RIGHT) FMC, M134 (M135) (AMM 34-61-01/401).

> Erroneous Display Of ".ATC" And ".FMC" Messages On EICAS Figure 109B




FMC FAILS TO ERASE
ATS DATALINK
MESSAGE FROM
PREVIOUS FLIGHT
AND
INAPPROPRIATELY
DISPLAY THESE
MESSAGES ON THE
NEXT FLIGHT

PREREQUISITES

MAKE SURE THESE SYSTEMS WILL OPERATE: AUTOPILOT (AMM 22-10-00/501) THRUST MANAGEMENT SYSTEM (AMM 22-32-00/501) AIR DATA INERTIAL REFERENCE SYSTEM (AMM 34-26-00/501)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11E8, 11E9, 11E29, 11E30

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)



FMC Fails To Erase Ats Datalink Message From Previous Flight And Inappropriately Display These Messages On The Next Flight Figure 109C

AIRPLANES WITH PEGASUS FMC; OPERATION SOFTWARE PRIOR TO 2003.




MAKE SURE THESE SYSTEMS WILL OPERATE:
AUTOPILOT (AMM 22-10-00/501)
THRUST MANAGEMENT SYSTEM (AMM 22-32-00/501)
AIR DATA INERTIAL REFERENCE SYSTEM
(AMM 34-26-00/501)

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11E8, 11E9, 11E29, 11E30

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)

FMC CDU LOCKUP AND MESSAGE STANDBY ONE IS DISPLAYED




FMC CDU Lockup and Message Standby One is Displayed on Frozen CDU Figure 109D

AIRPLANES WITH PEGASUS FMC



UNABLE TO REMOTELY TUNE VOR FROM LEFT (RIGHT) CDU

PREREQUISITES
BREAKOUT BOX



Unable to Remotely Tune VOR from Left (Right) CDU Figure 110

34-61-00

BOEING PROPRIETARY - Copyright (C) - Unpublished Work - See title page for details.

MAKE SURE THESE SYSTEMS WILL OPERATE:
AUTOPILOT (AMM 22-10-00/501)
THRUST MANAGEMENT SYSTEM (AMM 22-32-00/501)
INERTIAL REFERENCE SYSTEM (AMM 34-21-00/501)


MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED: 11E8, 11E9, 11E29, 11E30

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)

FMC FAILURE CAUSED BY VOR/DME DATA ERROR

YES 1 ON THE P11 PANEL, OPEN 20 DO THIS PROCEDURE: THESE CIRCUIT BREAKERS: BITE PROCEDURE • LEFT AND RIGHT FMC (11E9, (FIM 34-51-00/101). 11E30) • LEFT AND RIGHT VOR (11A2, 11E33) • LEFT AND RIGHT DME (11E11, 11E32) AFTER 15 SECONDS, CLOSE THESE CIRCUIT BREAKERS: • LEFT AND RIGHT FMC (11E9, 11E30) • LEFT AND RIGHT VOR (11A2, 11E33) • LEFT AND RIGHT DME (11E11, 11E32) GET THE SENSOR STATUS PAGE 1/2 ON THE LEFT (RIGHT) DOES THE LEFT (RIGHT) VOR SHOW "FAIL"? NO YES DOES THE LEFT (RIGHT) DME 21 DO THIS PROCEDURE: DME SHOW "FAIL"? BITE PROCEDURE (FIM 34-55-00/101). NO 3 GET THE SENSOR STATUS 22 DO THIS PROCEDURE: FMC PAGE 2/2 ON THE LEFT (RIGHT) BITE PROCEDURE (FIM 34-61-01/101). CDU. DOES THE LEFT (RIGHT) FMC SHOW "OK"? YES 23 THE SYSTEM IS OK.

FMC Failure Caused by VOR/DME Data Error Figure 110A




MAKE SURE THESE SYSTEMS WILL OPERATE: AUTOFLIGHT (MM 22-10-00/501) THRUST MANAGEMENT SYSTEM (MM 22-32-00/501) FUEL QUANITY INDICATING SYSTEM (MM 28-41-00/501) CLOCKS (MM 31-25-00/501) EICAS (MM 31-41-00/501) AIR DATA COMPUTING SYSTEM (MM 34-12-00/501) INERTIAL REFERENCE SYSTEM (MM 34-21-00/501) EFIS (MM 34-22-00/501) INSTRUMENT LANDING SYSTEM (MM 34-31-00/501) VOR SYSTEM (MM 34-51-00/501) DME SYSTEM (MM 34-55-00/501) MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:

11E8,11E9,11E29,11E30

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:

ELECTRICAL POWER IS ON (MM 24-22-00/201)


FLIGHT MANAGEMENT **COMPUTER SYSTEM BITE PROCEDURE**




Flight Management Computer System BITE Procedure Figure 111 (Sheet 1)

EFFECTIVITY-ALL


799429




Flight Management Computer System BITE Procedure
Figure 111 (Sheet 2)









Flight Management Computer System BITE Procedure Figure 111 (Sheet 3)






Flight Management Computer System BITE Procedure Figure 111 (Sheet 4)







Flight Management Computer System BITE Procedure Figure 111 (Sheet 5)

ALL

ALL

22 Page 129
Apr 22/07

BOEING PROPRIETARY - Copyright (C) - Unpublished Work - See title page for details.



1. <u>Data Loader Fault Isolation Procedure</u>

- A. These are indications that can show on the data loader that are not usual installation conditions. The figures contain problems and corrective actions for the data loading procedure.
 - (1) The CONFIG.LDR FILE? shows on the data loader (see Figure 113).
 - (2) The CONFIG.LDR ERROR shows on the data loader (see Figure 113).
 - (3) The WRONG DISK SEQ # shows on the data loader (see Figure 113).
 - (4) The ADL FAIL light comes on after the data loader's power up test (see Figure 113).
 - (5) The TRANSFER FAIL shows on the data loader (see Figure 114).
 - (6) The Vol:<label>, <filename> n% and the INSERT DISK #1 show again and again in sequence while the disk is in the data loader (see Figure 115).
 - (7) The R/W FAIL shows on the data loader (see Figure 113).
 - (8) The Vol:<label> shows for more than 3 minutes after you put the disk into the data loader (see Figure 116).
- B. When it is necessary to replace the LRU, refer to Figure 112 for the applicable Removal/Installation procedures.

ALL ALL



This table gives references to Maintenance Manual Removal/Installation procedures. The Removal/Installation procedures are for the LRUs which can have software installed through the data loader.

LRU [>>	MAINTENANCE MANUAL REFERENCES
FMC-LEFT(RIGHT), M134(M135)	34-61-01/401
ACMS DMU, M1200	31-35-08/401

THE LRU IS THE SAME AS THE NAME ON THE DATA LOADER SWITCH POSITION.

LRU Removal/Installation Maintenance Manual References Figure 112

34-61-00

05

Page 131 Apr 22/07



This table contains problems and corrective actions for the data loading procedure.

PROBLEM	CORRECTIVE ACTION
"CONFIG.LDR FILE?" SHOWS ON THE DATA LOADER.	REPLACE THE DISK.
"CONFIG.LDR ERROR" SHOWS ON THE DATA LOADER.	REPLACE THE DISK.
"WRONG DISK SEQ #" SHOWS ON THE DATA LOADER.	MAKE SURE YOU PUT THE DISK INTO THE DATA LOADER IN THE CORRECT SEQUENCE. IF THE PROBLEM CONTINUES, REPLACE THE DISKS.
THE "ADL FAIL" LIGHT COMES ON AFTER THE DATA LOADER'S POWER UP TEST.	REPLACE THE DATA LOADER (MM 34-61-05/401). NOTE: THE "ADL FAIL" LIGHT WILL FLASH ON AND OFF ONE TIME DURING THE DATA LOADER'S POWER UP TEST.
"TRANSFER FAIL" SHOWS ON THE DATA LOADER.	SEE FIGURE 114.
THE "Vol: <label>", "<filename>n%" AND THE "INSERT DISK #1" SHOW AGAIN AND AGAIN IN SEQUENCE WHILE THE DISK IS IN THE DATA LOADER.</filename></label>	SEE FIGURE 115.
"R/W FAIL" SHOWS ON THE DATA LOADER.	REPLACE THE DISK. IF THE PROBLEM CONTI- NUES, REPLACE THE DATA LOADER (MM 34-61-05/401).
"Vol: <label>" SHOWS FOR MORE THAN 3 MINUTES AFTER YOU PUT THE DISK INTO THE DATA LOADER.</label>	SEE FIGURE 116.

Data Loading Procedure Problems and Corrective Actions Figure 113

EFFECTIVITY-




"TRANSFER FAIL" SHOWS ON THE DATA LOADER

PREREQUISITES

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:

ELECTRICAL POWER IS ON (MM 24-22-00)



TRANSFER FAIL Shows on the Data Loader Figure 114

EFFECTIVITY-ALL


956363

THE "Vol:<label>", "filename>n%" AND THE "INSERT DISK #1 SHOW AGAIN AND AGAIN IN SEQUENCE WHILE THE DISK IS IN THE DATA LOADER

PREREQUISITES

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:

ELECTRICAL POWER IS ON (MM 24-22-00)



The VOL:<LABEL>,<FILENAME>N% and the INSERT DISK #1 Show Again and Again in Sequence While the Disk is in the Data Loader Figure 115

EFFECTIVITY-ALL

34-61-00

21


Page 134 Apr 22/07



"Vol:<label>" SHOWS FOR MORE THAN 3 MINUTES AFTER YOU PUT THE DISK INTO THE DATA LOADER

PREREQUISITES

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION: ELECTRICAL POWER IS ON (AMM 24-22-00/201)




VOL:<LABEL> Shows for More Than 3 Minutes after You Put the Disk into the Data Loader Figure 116 (Sheet 1)

34-61-00

22

Page 135 Apr 22/07



VOL:<LABEL> Shows for More Than 3 Minutes after You Put the Disk into the Data Loader Figure 116 (Sheet 2)

ALL

ALL

18 Page 136
Apr 22/07

BOEING PROPRIETARY - Copyright (C) - Unpublished Work - See title page for details.