


**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

## Scandinavian Airlines System

PAGE	DATE	CODE	PAGE	DATE	CODE	PAGE	DATE	CODE
CHAPTER 52 TAB			52-FAULT CODE INDEX			52-33-00		
DOORS			1	AUG 22/00	10	121	FEB 10/97	03
EFFECTIVE PAGES			2	APR 22/05	03	122	FEB 10/97	03
SEE LAST PAGE OF LIST FOR			3	AUG 22/05	02	123	AUG 22/07	03
NUMBER OF PAGES			4	APR 22/05	02	124	FEB 10/97	03
52-CONTENTS			5	MAY 10/96	08	125	DEC 22/99	03
1	DEC 22/99	SAS	6	MAY 10/96	09	126	DEC 22/99	03
2	APR 22/01	SAS	7	MAY 10/96	08	127	DEC 22/99	03
3	APR 22/01	SAS	8	MAY 10/96	02	128	DEC 22/99	03
4	APR 22/01	SAS	9	APR 22/05	06	129	DEC 22/99	03
5	APR 22/01	SAS	10	APR 22/05	03	130	DEC 22/99	03
6	APR 22/04	SAS	52-BITE INDEX			131	AUG 22/07	03
7	DEC 22/05	SAS	1	AUG 22/99	01	132	DEC 22/99	03
8	DEC 22/05	SAS	2	AUG 22/99	01	133	DEC 22/99	03
9	APR 22/06	SAS	3	AUG 22/99	01	134	DEC 22/99	03
10	BLANK		4	BLANK		135	DEC 22/99	03
52-HOW TO USE THE FIM			52-11-00			136	DEC 22/99	03
1	AUG 22/99	01	101	MAY 10/91	01	137	AUG 22/07	03
2	AUG 22/99	01	102	MAY 10/91	01	138	DEC 22/99	03
3	AUG 22/99	01	103	MAY 10/91	01	139	DEC 22/99	03
4	AUG 22/99	01	104	DEC 22/99	01	140	BLANK	
5	AUG 22/99	01	105	APR 22/08	01	52-35-00		
6	AUG 22/99	01	106	DEC 22/99	01	101	NOV 10/96	02
52-INDEX			107	APR 22/08	01	102	NOV 10/95	01
1	DEC 22/05	11	108	APR 22/08	01	103	NOV 10/90	01
2	APR 22/05	09	109	DEC 22/99	01	104	NOV 10/90	01
3	NOV 10/92	03	110	APR 22/08	01	105	NOV 10/96	02
4	BLANK		111	APR 22/08	01	106	NOV 10/90	01
52-EICAS MESSAGES			112	APR 22/08	01	107	NOV 10/90	02
1	NOV 10/90	01	52-21-00			108	DEC 22/07	02
2	APR 22/99	01	101	NOV 10/92	02	109	APR 22/08	01
3	AUG 22/00	01	102	NOV 10/92	02	110	APR 22/08	01
4	APR 22/04	08	103	NOV 10/92	02	111	NOV 10/96	02
5	APR 22/04	06	104	NOV 10/92	02	112	AUG 10/98	01
6	BLANK		52-33-00			113	APR 22/08	01
52-FAULT CODE DIAGRAM			101	AUG 10/90	06	114	APR 22/08	01
1	NOV 10/95	07	102	NOV 10/95	03	115	DEC 22/07	02
2	NOV 10/95	01	103	AUG 10/90	03	116	APR 22/08	01
3	NOV 10/95	02	104	AUG 10/90	03	117	DEC 22/07	02
4	FEB 10/88	02	105	AUG 10/90	03	118	APR 22/08	01
5	AUG 01/86	05	106	AUG 10/90	03	119	APR 22/08	01
6	AUG 22/00	02	107	AUG 10/90	06	120	APR 22/08	01
7	MAY 10/90	04	108	DEC 22/00	07	121	APR 22/99	02
8	DEC 22/05	09	109	AUG 10/90	06	122	APR 22/08	01
9	DEC 22/05	06	110	AUG 10/90	06	123	DEC 22/07	02
10	BLANK		111	AUG 22/07	04	124	AUG 10/98	01
			112	NOV 10/90	04	125	AUG 22/99	01
			113	NOV 10/90	04	126	APR 22/08	01
			114	NOV 10/90	04	52-36-00		
			115	NOV 10/90	04	101	AUG 10/94	04
			116	NOV 10/90	04	102	AUG 10/94	04
			117	NOV 10/90	04	103	MAY 10/95	01
			118	NOV 10/90	04	104	AUG 10/94	01
			119	AUG 22/07	04			
			120	FEB 10/97	03			

 R = REVISED, A = ADDED OR D = DELETED  
 F = FOLDOUT PAGE  
 33  
 AUG 22/09

# D633T633

 CHAPTER 52  
 EFFECTIVE PAGES  
 PAGE 1  
 CONTINUED



**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

Scandinavian Airlines System

PAGE	DATE	CODE	PAGE	DATE	CODE	PAGE	DATE	CODE
52-51-00	CONFIG 1							
101	DEC 22/05	24F						
102	DEC 22/05	24F						
103	DEC 22/05	24F						
104	DEC 22/05	24F						
105	DEC 22/05	24F						
106	DEC 22/05	24F						
52-51-00	CONFIG 2							
101	DEC 22/05	19F						
102	DEC 22/05	19F						
103	DEC 22/05	19F						
104	DEC 22/05	19F						
105	DEC 22/05	19F						
106	DEC 22/05	19F						
107	DEC 22/05	19F						
108	DEC 22/05	19F						
109	DEC 22/05	19F						
110	DEC 22/05	19F						
111	DEC 22/05	19F						
112	DEC 22/05	19F						
113	DEC 22/05	19F						
114	BLANK							
52-51-00	CONFIG 4							
101	DEC 22/05	27F						
102	DEC 22/05	27F						
103	DEC 22/05	27F						
104	DEC 22/05	27F						
105	DEC 22/05	27F						
106	DEC 22/05	27F						
107	DEC 22/05	27F						
108	DEC 22/05	27F						
109	DEC 22/05	27F						
110	DEC 22/05	27F						
111	DEC 22/05	27F						
112	DEC 22/05	27F						
113	DEC 22/05	27F						
114	BLANK							
52-71-00								
101	MAY 10/96	08						
102	APR 22/01	06						
103	NOV 10/95	02						
104	FEB 10/96	02						
105	AUG 22/01	02						
106	AUG 22/01	02						
107	AUG 22/01	02						
108	AUG 22/01	03						
109	AUG 22/01	03						
110	NOV 10/92	03						
111	NOV 10/92	10						
112	NOV 10/92	02						
113	APR 22/08	02						
114	AUG 10/95	05						
115	APR 22/08	03						
116	APR 22/08	03						
117	DEC 22/07	03						
118	APR 22/99	02						

R = REVISED, A = ADDED OR D = DELETED  
 F = FOLDOUT PAGE  
 33  
 AUG 22/09

**D633T633**

CHAPTER 52  
 EFFECTIVE PAGES  
 PAGE 2  
 LAST PAGE



**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

CHAPTER 52 - DOORS

TABLE OF CONTENTS

<u>Subject</u>	Chapter Section <u>Subject</u>	<u>Page</u>	<u>Effectivity</u>
HOW TO USE THE FIM	52-HOW TO USE THE FIM	1	ALL
INDEX	52-INDEX	1	ALL
EICAS MESSAGES	52-EICAS MESSAGES	1	ALL
FAULT CODE DIAGRAMS	52-FAULT CODE DIAGRAM	1	ALL
FAULT CODE INDEX	52-FAULT CODE INDEX	1	ALL
BITE INDEX	52-BITE INDEX	1	ALL
<u>DOORS</u>	52-00-00		
<u>PASSENGER/CREW</u>	52-10-00		
ENTRY/SERVICE DOORS	52-11-00		
Component Location		101	ALL
Component Index			
Component Location			
Fault Isolation			
Door Difficult to Latch or Unlatch (Fig. 105)		106	
Door Difficult to Open or Close (Fig. 104)		105	
Door Slide Arming Handle Difficult to Arm (Fig. 103)		104	
L Fwd Door Will Not Lower Electrically (Fig. 107)		110	
L Fwd Door Will Not Raise or Lower Electrically (Fig. 108)		112	
L Fwd Door Will Not Raise Electrically (Fig. 106)		108	

52-CONTENTS

SAS

Page 1  
Dec 22/99



767

FAULT ISOLATION/MAINT MANUAL

CHAPTER 52 - DOORS

TABLE OF CONTENTS

<u>Subject</u>	Chapter Section <u>Subject</u>	<u>Page</u>	<u>Effectivity</u>
<u>EMERGENCY EXIT</u>	52-20-00		
OVERWING ESCAPE HATCH	52-21-00		
Component Location		101	ALL
Component Index			
Component Location			



767  
FAULT ISOLATION/MAINT MANUAL

CHAPTER 52 - DOORS

TABLE OF CONTENTS

<u>Subject</u>	<u>Chapter Section Subject</u>	<u>Page</u>	<u>Effectivity</u>
<u>CARGO</u>	52-30-00		
LARGE FORWARD CARGO DOOR	52-33-00		
Component Location		101	ALL
Component Index			
Component Location			
Fault Isolation			
Fwd Cargo Door will not Lift or Lower Electrically or Manually. Other Electrical Modes Normal (Fig. 112)		130	
Fwd Cargo Door Electrical Operation Inop (Fig. 113)		131	
Fwd Cargo Door Fails to Raise Full Up (Fig. 116)		137	
Fwd Cargo Door Will Not Latch Lock (Fig. 114)		135	
Fwd Cargo Door Will Not Latch Unlock (Fig. 115)		136	
Fwd Cargo Door Will Not Latch/Hook Closed or Unlatch/ Unhook Electrically. Other Elec Modes Normal (Fig. 107)		119	
Fwd Cargo Door Will Not Latch/Hook Closed Electrically. Other Elec Modes Normal (Fig. 105)		115	
Fwd Cargo Door Will Not Latch/Hook Closed Electrically or Manually. Other Elec Modes Normal (Fig. 106)		117	
Fwd Cargo Door Will Not Lift or Lower Electrically or Manually. Other Elec Modes Normal (Fig. 109)		125	
Fwd Cargo Door Will Not Lift or Lower Electrically. Other Elec Modes Normal (Fig. 111)		128	
Fwd Cargo Door Will Not Lift Electrically. Other Elec Modes Normal. (Fig. 108)		123	

52-CONTENTS

SAS

Page 3  
Apr 22/01

 **BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

CHAPTER 52 - DOORS

TABLE OF CONTENTS

<u>Subject</u>	Chapter Section <u>Subject</u>	<u>Page</u>	<u>Effectivity</u>
Fwd Cargo Door Will Not Lower Electrically. Other Elec Modes Normal (Fig. 110)		127	
Fwd Cargo Door Will Not Unlatch/Unhook Electrically or Manually (Fig. 104)		113	
Fwd Cargo Door Will Not Unlatch/Unhook Electrically. Other Elec Modes Normal (Fig. 103)		111	
Severe Vibration of Fwd Cargo Door While Moving (Fig. 117)		139	

52-CONTENTS

SAS

Page 4  
Apr 22/01



**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

CHAPTER 52 - DOORS

TABLE OF CONTENTS

<u>Subject</u>	Chapter Section <u>Subject</u>	<u>Page</u>	<u>Effectivity</u>
AFT CARGO DOOR	52-35-00		
Component Location		101	ALL
Component Index			
Component Location			
Fault Isolation			
Aft Cargo door Fails to Latch Completely (Fig. 114)		126	
Aft Cargo Door Will Not Raise or Lower Electrically or Manually. Other Elec Modes Normal (Fig. 109)		119	
Cargo Door has Erratic Movement during Raise Mode (Fig. 112)		124	
Cargo Door has Intermittent Movement during Lower Mode (Fig. 113)		125	
Cargo Door will Not Unlatch Electrically or With Manual Drive. Other Modes Normal (Fig. 104)		110	
Cargo Door Electrical Operation Inop (Fig. 111)		123	
Cargo Door Will Not Latch Closed Electrically or Manually (Fig. 106)		114	
Cargo Door Will Not Latch Closed Electrically. Manual Drive Will Lock Door Closed. Other Elec Modes Normal (Fig. 105)		111	
Cargo Door Will Not Lower Electrically. Manual Drive Will Lower Door. Other Elec Modes Normal (Fig. 110)		121	
Cargo Door Will Not Raise Electrically. Manual Drive Will Raise Door. Other Elec Modes Normal. (Fig. 108)		117	
Cargo Door Will Not Unlatch or Latch Electrically. Other Elec Modes Normal. (Fig. 107)		115	

52-CONTENTS

SAS

Page 5  
Apr 22/01



**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

CHAPTER 52 - DOORS

TABLE OF CONTENTS

<u>Subject</u>	<u>Chapter Section Subject</u>	<u>Page</u>	<u>Effectivity</u>
Cargo Door Will Not Unlatch Electrically. Manual Drive Unlocks Door Normal. Other Elec Modes Normal (Fig. 103)		108	
BULK CARGO DOOR	52-36-00		
Component Location		101	ALL
Component Index			
Component Location			
Fault Isolation			
Bulk Cargo Door will Unlatch, but Not Open (Fig. 103)		103	
Bulk Cargo Door Requires High Handle Forces When Latching Door (Fig. 104)		104	

52-CONTENTS

SAS

Page 6  
Apr 22/04





**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

CHAPTER 52 - DOORS

TABLE OF CONTENTS

<u>Subject</u>	Chapter Section <u>Subject</u>	<u>Page</u>	<u>Effectivity</u>
<u>FIXED INTERIOR</u>	52-50-00		
FLIGHT COMPARTMENT DOOR	52-51-00		
Component Location		101	CONFIG 1 [*]
Component Index			
Component Location			
Fault Isolation			
Flight Deck Door Will Not Release Electrically (Fig. 103)		105	
[*] SAS 050, 051, 156, 162-167 PRE-SB 25-325; 154 PRE-SB 25-332			
Component Location		101	CONFIG 2 [*]
Component Index			
Component Location			
Fault Isolation			
Flight Deck Door "AUTO UNLK" Light Does Not Come On (Fig. 109)		113	
Flight Deck Door "LOCK FAIL" Light Is On (Fig. 108)		112	
Flight Deck Door Chime Does Not Sound After Correct Code (Fig. 107)		111	
Flight Deck Door Does Not Lock In The "Auto" Mode (Fig. 103)		106	
Flight Deck Door Does Not Unlock In "AUTO" Mode (Fig. 105)		109	
Flight Deck Door Does Not Unlock In The "Unlock" Mode (Fig. 104)		108	
Flight Deck Door Unlocks Or Chimes Sound In "DENY" Mode (Fig. 106)		110	
[*] SAS 155-157, 276-278, 280; 050, 051, 156, 162-167 POST-SB 25-325			
Component Location		101	CONFIG 4 [*]
Component Index			
Component Location			
Fault Isolation			

52-CONTENTS

SAS

Page 7

Dec 22/05



**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

CHAPTER 52 - DOORS

TABLE OF CONTENTS

<u>Subject</u>	<u>Chapter Section Subject</u>	<u>Page</u>	<u>Effectivity</u>
Flight Deck Door "AUTO UNLK" Light Does Not Come On (Fig. 109)		113	
Flight Deck Door "LOCK FAIL" Light Is On (Fig. 108)		112	
Flight Deck Door Chime Does Not Sound After Correct Code (Fig. 107)		111	
Flight Deck Door Does Not Lock In The "Auto" Mode (Fig. 103)		106	
Flight Deck Door Does Not Unlock In "AUTO" Mode (Fig. 105)		109	
Flight Deck Door Does Not Unlock In The "Unlock" Mode (Fig. 104)		108	
Flight Deck Door Unlocks Or Chimes Sound In "DENY" Mode (Fig. 106)		110	
[*] SAS 150-153, 275; 154 POST-SB 25-332			




**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

CHAPTER 52 - DOORS

TABLE OF CONTENTS

<u>Subject</u>	Chapter Section <u>Subject</u>	<u>Page</u>	<u>Effectivity</u>
<u>DOOR WARNING</u>	52-70-00		
DOOR WARNING SYSTEM	52-71-00		
Component Location		101	ALL
Component Index			
Component Location			
Fault Isolation			
Cargo Doors Light Illum. EICAS Message AFT CARGO DOOR Displayed (Fig. 104A)		115	
Cargo Doors Light Illum. EICAS Message FWD CARGO DOOR Displayed (Fig. 104)		114	
Emer Doors Light Illum. EICAS Message L WING SLIDE or R WING SLIDE Displayed (Fig. 107)		118	
EICAS Message Displayed for Entry Door, Emer Door, Cargo Door, or Access Door. Corresponding Annunciator Light Not Illuminated. (Fig. 106)		117	
EMER DOORS Light Illum. EICAS Message EMER DOOR Displayed (Fig. 105)		116	
ENTRY DOORS Lgt Illum. EICAS Msg (L FWD ENT DOOR, L AFT ENT DOOR, R FWD ENT DOOR, R AFT ENT DOOR) Displayed. Lock Pin is Engaged (Fig. 103)		113	



Basic Fault Isolation Process  
Figure 1


EFFECTIVITY

ALL

## 52-HOW TO USE THE FIM

01

Page 1  
Aug 22/99



How to Get Fault Information from BITE  
Figure 2

EFFECTIVITY


ALL

## 52-HOW TO USE THE FIM

01

Page 2  
Aug 22/99

K37719



How to Find the Corrective Action or Fault Isolation Procedure in the FIM

Figure 3

EFFECTIVITY

ALL

## 52-HOW TO USE THE FIM

01

Page 3  
Aug 22/99

ASSUMED CONDITIONS AT START OF TASK

- External electrical power is OFF
- Hydraulic power and pneumatic power are OFF
- Engines are shut down
- Circuit breakers for the system are closed
- No equipment in the system is deactivated

PREREQUISITES

- This box gives the steps to get the airplane from the normal shutdown condition to the configuration necessary to do the fault isolation procedure.
- The Prerequisites give procedure references, circuit breakers, and special tools and equipment requirements.

FAULT ISOLATION BLOCKS

- Start the fault isolation procedure at block 1 unless specified differently.
- Do the check to get an answer to the question in the box. Follow the arrow that applies to your answer. This will go to the next check.
- When you get to a box in the column at the right of the page, you have isolated that fault. Do the steps in that box to repair the cause of the fault.
- Make sure that fault is corrected to complete the procedure.

Do the Fault Isolation Procedure  
Figure 4


EFFECTIVITY

ALL

**52-HOW TO USE THE FIM**

01


Page 4  
Aug 22/99



Subjects in Each FIM Chapter  
Figure 5 (Sheet 1)

<p>EFFECTIVITY</p> <hr/> <p align="center">ALL</p>	<p align="center"><b>52-HOW TO USE THE FIM</b></p> <p align="right">01      Page 5 Aug 22/99</p>
--	--






Alphabetical list of the EICAS messages. Gives the procedure to repair the cause of the message or a reference to a fault isolation procedure.

Failure analysis diagrams for the airplane systems to find the correct fault code for the fault.


Numerical list of fault codes. Gives the procedure to repair the cause of the fault or a reference to a fault isolation procedure.



Alphabetical list of all the LRUs/systems that have BITE. Gives the chapter/section for the BITE procedure.

Component index, component location, and fault isolation procedures for the systems in the chapter.


Subjects in Each FIM Chapter  
Figure 5 (Sheet 2)




# 52-HOW TO USE THE FIM

<u>TITLE</u>	<u>CHAP/SEC</u>
AFT AND BULK CARGO	
DOORS .....	5236, 5237
COCKPIT DOOR .....	5251
COLD DOOR AREA .....	CHAPTER 21
DOOR AIR NOISE .....	5212, 5232
DOOR INDICATION .....	5271
FORWARD CARGO DOOR.....	5233
LAVATORY DOORS .....	CHAPTER 25
ENTRY/SERVICE DOORS.....	5212
SLIDE PRESSURE.....	CHAPTER 25
WINDOW (CONDENSATION/ FOG) .....	CHAPTER 25


DOORS - INDEX




**52-INDEX**




OVERHEAD PANEL




ENTRY/SERVICE DOOR




OVERHEAD PANEL




FLT DECK DOOR




ATTENDANT PANEL



OVERWING EMERGENCY EXIT



OVERHEAD PANEL









FLT DK DOOR

- 1 POWERED ENTRY DOORS
- 2 AS INSTALLED

**DOORS - INDEX**

EFFECTIVITY	ALL
-------------	-----

**52-INDEX**



1 ▷ NORMAL SIZE CARGO DOOR

**DOORS - INDEX**

EFFECTIVITY	ALL
-------------	-----

**52-INDEX**

DOORS - EICAS MESSAGE LIST

1. General

- A. This procedure shows the EICAS message locations and gives a list of procedures to find the solution for each message.
- (1) EICAS Message Locations (Fig. 1)
    - (a) Figure 1 shows the location of the EICAS display units and the area where the messages show on the display units.
    - (b) Each message level has a different location. The location and color of each message level is also shown.
  - (2) The EICAS MESSAGE LIST gives the message, level, and procedure for each message.
    - (a) The EICAS MESSAGE column lists the messages alphabetically. Messages which start with L, R, or C are put together and alphabetized at L.
    - (b) The LEVEL column gives all levels for each message as follows:
      - A - Warning messages
      - B - Caution messages
      - C - Advisory messages
      - S - Status messages
      - M - Maintenance messages
    - (c) The PROCEDURE column gives the steps that are necessary to remove the message and includes one or more of the procedures that follow:
      - 1) A Fault Isolation Manual procedure reference
      - 2) A Maintenance Manual procedure and reference
      - 3) Wiring checks and a Wiring Diagram Manual reference
      - 4) A reference to an EICAS message list in a different chapter.
      - 5) A reference to a FAULT CODE INDEX and specified fault codes
      - 6) A step to change the airplane configuration

EFFECTIVITY



ALL

## 52-EICAS MESSAGES


01

Page 1  
Nov 10/90



**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL



ENGINE PRIMARY PAGE OR COMPACTED PAGE  
(TOP DISPLAY UNIT)




ECS/MSG PAGE  
(BOTTOM DISPLAY UNIT)



STATUS PAGE  
(BOTTOM DISPLAY UNIT)

LEVEL	COLOR
A-WARNING	RED
B-CAUTION	YELLOW
C-ADVISORY	YELLOW
S-STATUS	WHITE
M-MAINTENANCE	WHITE

EICAS Message Locations  
Figure 1



# 52-EICAS MESSAGES



**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

EICAS MESSAGE LIST		
EICAS MESSAGE	LEVEL	PROCEDURE
ACCESS DOORS	C	Remove the unwanted material or blockages from the forward access door or the electronics access door latch pins and latch fittings. If the problem continues, adjust the access door proximity sensors S200 and S201 (AMM 52-71-00/501).
AFT CARGO DOOR	C	Remove the unwanted material or blockages from the aft cargo door latches. If the problem continues, adjust the aft cargo door locked proximity sensor, S208 (AMM 52-71-00/501).
BULK CARGO DOOR	C	Remove the unwanted material or blockages from the bulk cargo door latches. If the problem continues, adjust the bulk cargo door latched proximity sensor, S211 (AMM 52-71-00/501).
CARGO DOORS	C	Remove the unwanted material or blockages from all of the cargo door latches. If the problem continues, adjust the cargo door locked proximity sensors, S208, S211, and S214 (AMM 52-71-00/501).
E/E ACCESS DOORS	C	Remove the unwanted material or blockages from all of the electronics access door latch pins and latch fittings. If the problem continues, adjust the proximity sensor S201 (AMM 52-71-00/501).
EMER DOORS	C	Remove the unwanted material or blockages from all of the emergency exit latch rollers and latch cams. If the problem continues, adjust the emergency exit proximity sensors (AMM 52-71-00/501).
FWD ACCESS DOOR	C	Remove the unwanted material or blockages from the forward access door latch pins and latch fittings. If the problem continues, adjust the proximity sensor S200 (AMM 52-71-00/501).

EFFECTIVITY

ALL

## 52-EICAS MESSAGES

01

Page 3  
Aug 22/00


**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

EICAS MESSAGE LIST		
EICAS MESSAGE	LEVEL	PROCEDURE
FWD CARGO DOOR	B	Remove the unwanted material or blockages from the forward cargo door latches. If the problem continues adjust the forward cargo door locked proximity sensor, S214 (AMM 52-71-02/201).
ON AIRPLANES WITH TWO HATCHES OVER EACH WING, (L,R) AFT EMER DOOR	C	Remove the unwanted material or blockages from the aft hatch latch rollers and latch cams. If the problem continues, adjust the hatch proximity sensor S216 or S217 (AMM 52-71-00/501).
(L,R) AFT ENT DOOR	C	Close and latch the aft entry door in the correct sequence and make sure the exterior handle is smooth with the fuselage surface (AMM 52-11-00/501). If the problem continues, adjust the aft entry door closed proximity sensor, S204 or S206 (AMM 52-71-00/501) and the latch pin cable (AMM 52-11-00/501). If the problem continues, do the Entry Door System Handle Mechanism Rigging Quick Check procedure (AMM 52-11-25-2).
ON AIRPLANES WITH ONE HATCH OVER EACH WING, (L,R) FWD EMER DOOR	C	Remove the unwanted material or blockages from the hatch latch rollers and latch cams. If the problem continues, adjust the hatch proximity sensor S192 or S193 (AMM 52-71-00/501).
(L,R) ENTRY DOOR	C	Close and latch the forward and aft entry doors in the correct sequence and make sure the exterior handle is smooth with the fuselage surface (AMM 52-11-00/201). If the problem continues, adjust the forward and aft entry door closed proximity sensors, S194, S196, S204, or S206 (AMM 52-71-00/501) and the latch pin cable (AMM 52-11-00/501). If the problem continues, do the Entry Door System Handle Mechanism Rigging Quick Check procedure (AMM 52-11-25-2).

EFFECTIVITY

ALL

## 52-EICAS MESSAGES

08

Page 4  
Apr 22/04




**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

EICAS MESSAGE LIST		
EICAS MESSAGE	LEVEL	PROCEDURE
ON AIRPLANES WITH TWO HATCHES OVER EACH WING, (L,R) FWD EMER DOOR	C	Remove the unwanted material or blockages from the hatch latch rollers and latch cams. If the problem continues, adjust the hatch proximity sensor S192 or S193 (AMM 52-71-00/501).
(L,R) FWD ENT DOOR	C	Close and latch the forward entry door in the correct sequence and make sure the exterior handle is smooth with the fuselage surface (AMM 52-11-00/201). If the problem continues, adjust the forward entry door closed proximity sensor, S194 or S196 (AMM 52-71-00/501) and the latch pin cable (AMM 52-11-00/501). If the problem continues, do the Entry Door System Handle Mechanism Rigging Quick Check procedure (AMM 52-11-25-2).
(L,R) WING SLIDE	C	Remove the unwanted material or blockages from the offwing slide compartment door latches. If the problem continues, adjust the offwing slide compartment door closed proximity sensor S218 or S219 and the offwing slide compartment door locked sensor S198 or S199 (AMM 52-71-00/501).


EFFECTIVITY

ALL

## 52-EICAS MESSAGES

06

Page 5  
Apr 22/04



### PASSENGER/SERVICE DOORS (SHEET 1) - FAULT CODES

EFFECTIVITY

ALL


## 52-FAULT CODE DIAGRAM

# BOEING


## 767

### FAULT ISOLATION/MAINT MANUAL

SLIDE ARMING HANDLE, COVER, INDICATOR



DOOR BUSTLE, WINDOW



FAULT CODE/  
LOCATION

L FWD 04  
R FWD 05  
L AFT 08  
R AFT 09

WAS SLIDE HANDLE, COVER, INDICATOR NORM?

WAS BUSTLE SECURE, WINDOWS NORMAL?

NOT APPLY 00

FROM SHEET 1

YES

YES

NORMAL

BUSTLE LOOSE, BROKEN, ETC.

52 11 01

CONDENSATION BETWEEN WINDOWS

1

INNER WINDOW LOOSE, CAME OUT OF MOLDING

52 11 26

DIFFICULT TO ARM, DISARM.

52 11 02

COVER NOT FLUSH, BROKEN

52 11 13

ARMED IND FLAG GOES

BEHIND HANDLE, MISSING, ETC

52 11 14

REPORT ANY FAULT SYMPTOM OR PATTERN NOT SHOWN ABOVE

52 11 XB

1 SEE EQUIPMENT & FURNISHINGS, "APPEARANCE ITEMS" FAULT CODES.

APPLICABLE CIRCUIT BREAKERS  
NONE

### PASSENGER/SERVICE DOORS (SHEET 2) - FAULT CODES

EFFECTIVITY

ALL

## 52-FAULT CODE DIAGRAM


01

Page 2  
Nov 10/95

ENTRY/SERVICE DOORS


L/R OVERWING  
EMERGENCY EXIT

FAULT CODE/  
LOCATION<sup>1</sup>



L FWD	04
R FWD	05
L EMER	06
R EMER	07
L AFT	08
R AFT	09
L FWD EMER	12
R FWD EMER	13
L AFT EMER	14
R AFT EMER	15

DOES DOOR HAVE EXCESSIVE  
NOISE LEVEL DUE TO LEAKAGE?



REPORT ANY FAULT SYMPTOM OR PATTERN NOT SHOWN ABOVE

52 11 XC

<sup>1</sup> AS INSTALLED

APPLICABLE CIRCUIT BREAKERS

NONE

**DOOR AIR NOISE – FAULT CODES**

EFFECTIVITY

ALL

**52-FAULT CODE DIAGRAM**

02


Page 3  
Nov 10/95



# BOEING

## 767

### FAULT ISOLATION/MAINT MANUAL



APPLICABLE CIRCUIT BREAKERS

NONE

### AFT AND BULK CARGO DOORS - FAULT CODES


EFFECTIVITY


ALL

## 52-FAULT CODE DIAGRAM

05

Page 5  
Aug 01/86





**FORWARD CARGO DOOR – FAULT CODES**


EFFECTIVITY

ALL

**52-FAULT CODE DIAGRAM**



OVERHEAD PANEL



FAULT CODE/  
LOCATION

UNLK	01
AUTO	02
DENY	03
ALL	04

WAS FLIGHT DECK DOOR CONTROL PANEL OPERATION NORMAL?

NOT APPLY 00

YES	→	NORMAL	↓
DOOR LOCK FAIL LIGHT ABNORMAL	→	52 51 11 00	
DOOR AUTO UNLOCK LIGHT ABNORMAL	→	52 51 12 00	
DOOR LOCK CONTROL SELECTOR ABNORMAL	→	52 51 13 --	

REPORT ANY FAULT SYMPTOM OR PATTERN NOT SHOWN ABOVE → 52 51 XB --

APPLICABLE CIRCUIT BREAKERS

NONE

1 AS INSTALLED


FLIGHT DECK DOOR CONTROL PANEL - FAULT CODES

EFFECTIVITY


ALL

# 52-FAULT CODE DIAGRAM

FAULT CODE/  
LOCATION




WAS FLIGHT DECK ACCESS PANEL OPERATION NORMAL?



REPORT ANY FAULT SYMPTOM OR PATTERN NOT SHOWN ABOVE → 52 51 XC 00

APPLICABLE CIRCUIT BREAKERS

NONE

 AS INSTALLED

FLIGHT DECK ACCESS PANEL – FAULT CODES

EFFECTIVITY

ALL

# 52-FAULT CODE DIAGRAM

06

Page 9  
Dec 22/05


**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
52 11 XA --	1. A (04=L FWD, 08=L AFT, 05=R FWD, 09=R AFT) door operation problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref Fault Code Diagram for flight crew actions). 2. AMM 52-11-00
52 11 XB --	1. A (04=L FWD, 05=R FWD, 08=L AFT, 09=R AFT) door window or slide arming problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref Fault Code Diagram for flight crew actions). 2. AMM 52-11-00
52 11 XC --	1. A (04=L FWD, 05=R FWD, 06=L EMER, 07=R EMER, 08=L AFT, 09=R AFT, 12=L FWD EMER, 13=R FWD EMER, 14=L AFT EMER, 15=R AFT EMER) door air leak problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref Fault Code Diagram for flight crew actions). 2. AMM 52-09-00
52 34 XB 00	1. Large forward cargo door problem was encountered by the ground crew which is not covered in the fault code diagrams. (Ref Fault Code Diagram for ground crew actions.) 2. AMM 52-33-00
52 35 XA 00	1. Aft and bulk cargo door problem was encountered by the ground crew which is not covered in the fault code diagrams. (Ref Fault Code Diagram for ground crew actions.) 2. AMM 52-35-00, AMM 52-36-00
52 51 XA 00	1. A cockpit door problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref Fault Code Diagram for flight crew actions). 2. FIM 52-51-00/101, Fig. 104, Block 1

EFFECTIVITY

ALL

## 52-FAULT CODE INDEX

10

Page 1  
Aug 22/00


**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
52 51 XB --	1. A flight deck door control panel problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref Fault Code Diagram for flight crew actions). 2. FIM 52-51-00
52 51 XC 00	1. A flight deck access panel problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref Fault Code Diagram for flight crew actions). 2. FIM 52-51-00
52 71 XA --	1. A (01= L FWD, 02=L AFT, 03=R FWD, 04=R AFT, 05=L EMER, 06=R EMER, 07=L FWD EMER, 08=L AFT EMER, 09=R FWD EMER, 10=R AFT EMER, 11=FWD CARGO, 12=AFT CARGO, 13=FWD ACCESS, 14=E/E ACCESS, 15=L WING SLIDE, 16=R WING SLIDE, 17=BULK CARGO) door warning indication problem was encountered by the flight crew which is not covered in the fault code diagrams. (Ref Fault Code Diagrams for flight crew actions). 2. AMM 52-71-00
52 11 01 --	1. (04=L FWD, 05=R FWD, 08=L AFT, 09=R AFT) door bustle not secure (Ref Log Book Report for detailed problem description). 2. Replace bustle (AMM 52-11-00)
52 11 02 --	1. (04=L FWD, 05=R FWD, 08=L AFT, 09=R AFT) door slide arming handle difficult to (arm, disarm). 2. FIM 52-11-00/101, Fig. 103, Block 1
52 11 03 04	1. L FWD door will not raise electrically. 2. FIM 52-11-00/101, Fig. 106, Block 1
52 11 04 04	1. L FWD door will not lower electrically. 2. FIM 52-11-00/101, Fig. 107, Block 1
52 11 05 04	1. L FWD door will not raise or lower electrically. 2. FIM 52-11-00/101, Fig. 108, Block 1
52 11 06 --	1. (04=L FWD, 05=R FWD, 08=L AFT, 09=R AFT) door difficult to open. 2. FIM 52-11-00/101, Fig. 104, Block 1
52 11 07 --	1. (04=L FWD, 05=R FWD, 08=L AFT, 09=R AFT) door difficult to close. 2. FIM 52-11-00/101, Fig. 104, Block 1

EFFECTIVITY

ALL

## 52-FAULT CODE INDEX

03

Page 2  
Apr 22/05


**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
52 11 08 --	1. (04=L FWD, 05=R FWD, 08=L AFT, 09=R AFT) door difficult to unlatch. 2. FIM 52-11-00/101, Fig. 105, Block 1
52 11 09 --	1. (04=L FWD, 05=R FWD, 08=L AFT, 09=R AFT) door difficult to latch. 2. FIM 52-11-00/101, Fig. 105, Block 1
52 11 10 --	1. (04= L FWD, 05= R FWD, 08= L AFT, 09= R AFT) door has noise from air leak (Ref Log Book Report for detailed problem description). 2. Repair or replace door seal (AMM 52-09-00 or AMM 52-09-01) as required.
51 11 11 --	Not Used
52 11 12 --	Not Used
52 11 13 --	1. (04=L FWD, 05=R FWD, 08=L AFT, 09=R AFT) Arming lever cover (not flush, broken). (Ref Log Book Report for description of problem). 2. Repair or replace arming lever cover as required (AMM 52-11-00).
52 11 14 --	1. (04=L FWD, 05=R FWD, 08=L AFT, 09=R AFT) Armed indicator flag (goes behind handle, missing, etc). (Ref Log Book Report for description of problem). 2. Repair, replace, or adjust armed indicator flag as required (AMM 52-11-00).
52 11 15 04	1. L fwd door will not raise using EXT DR SW. 2. Replace fwd entry door external control switch, S410 (AMM 52-11-46).
52 11 16 04	1. L fwd door will not lower using EXT DR SW. 2. Replace fwd entry door external control switch, S410 (AMM 52-11-46).
52 11 17 04	1. L fwd door power drive motor runs but door will not move. 2. Replace power drive unit (ELEC MOTOR) (AMM 52-11-45).
52 11 18 --	1. (04=L FWD, 05=R FWD, 08=L AFT, 09=R AFT) Door difficult to close using EXT DR handle. 2. Replace door handle mechanism if damaged (AMM 52-11-25). Adjust door handle mechanism (AMM 52-11-25).

EFFECTIVITY

ALL

## 52-FAULT CODE INDEX

02

Page 3  
Aug 22/05


**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
52 11 19 --	1. (04=L FWD, 05=R FWD, 08=L AFT, 09=R AFT) Door difficult to latch using EXT DR handle. 2. Replace door handle mechanism if damaged (AMM 52-11-25). Adjust door handle mechanism (AMM 52-11-25).
52 11 20 --	1. (04=L FWD, 05=R FWD, 08=L AFT, 09=R AFT) Upper door liner tracks damaged. 2. Replace upper door liner tracks (AMM 25-22-07). Adjust upper door liner tracks (AMM 25-22-07).
52 11 21 --	1. (04=L FWD, 05=R FWD, 08=L AFT, 09=R AFT) Door upper sidewall panel (broken, out of track, etc). 2. Replace door upper sidewall panel (upper door liner) if broken (AMM 52-11-00). Adjust upper door liner tracks (AMM 25-22-07).
52 11 22 --	1. (04=L FWD, 05=R FWD, 08=L AFT, 09=R AFT) Movable ceiling panels (broken, out of track, etc). 2. Replace door ceiling panels if broken (AMM 25-22-03). Adjust upper door liner tracks (AMM 25-22-07).
52 11 23 04	1. L fwd door (up/down) button sticks. 2. Repair or replace applicable switch (S13, S18) (WDM 52-11-11).
52 11 24 --	1. (04=L fwd, 05=R fwd 08=L aft, 09=R aft) door handle has no snubbing action. 2. Replace snubber (AMM 52-11-10).
52 11 25 --	1. (04=L fwd, 05=R fwd, 08=L aft, 09=R aft) door gutter (bent, leaks, damaged, etc). 2. Repair or replace gutter (AMM 52-00-00).
52 11 26 --	1. (04=L fwd, 05=R fwd, 08=L aft, 09=R aft) door inner window is (loose, out of molding). 2. Replace window (AMM 56-31-01).
52 21 01 --	1. (06=L EMER, 07=R EMER, 12=L FWD EMER, 13=R FWD EMER, 14=L AFT EMER, 15=R AFT EMER) exit has noise from air leak (Describe area). 2. Repair or replace door seal as required (AMM 52-09-00/801).
52 34 01 00 thru 52 34 11 00	Not Used
52 34 12 00	1. Fwd cargo door will not unlatch/unhook electrically. Other elec modes normal. 2. FIM 52-33-00/101, Fig. 103, Block 1

EFFECTIVITY

ALL

## 52-FAULT CODE INDEX

02

Page 4  
Apr 22/05



**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
52 34 13 00	1. Fwd cargo door will not unlatch/unhook electrically or manually. 2. FIM 52-33-00/101, Fig. 104, Block 1
52 34 14 00	1. Fwd cargo door will not latch/hook closed electrically. Other elec modes normal. 2. FIM 52-33-00/101, Fig. 105, Block 1
52 34 15 00	1. Fwd cargo door will not latch/hook closed electrically or manually. Other elec modes normal. 2. FIM 52-33-00/101, Fig. 106, Block 1
52 34 16 00	1. Fwd cargo door will not latch/hook closed or unlatch/unhook electrically. Other elec modes normal. 2. FIM 52-33-00/101, Fig. 107, Block 1
52 34 17 00	1. Fwd cargo door will not latch/hook closed or unlatch/unhook electrically or manually. Other elec modes normal. 2. FIM 52-33-00/101, Fig. 104, Block 1 FIM 52-33-00/101, Fig. 106, Block 1
52 34 18 00	1. Fwd cargo door will not lift electrically. Other elec modes normal. 2. FIM 52-33-00/101, Fig. 108, Block 1
52 34 19 00	1. Fwd cargo door will not lift electrically or manually. Other elec modes normal. 2. FIM 52-33-00/101, Fig. 109, Block 1
52 34 20 00	1. Fwd cargo door will not lower electrically. Other elec modes normal. 2. FIM 52-33-00/101, Fig. 110, Block 1
52 34 21 00	1. Fwd cargo door will not lower electrically or manually. Other elec modes normal. 2. FIM 52-33-00/101, Fig. 109, Block 1
52 34 22 00	1. Fwd cargo door will not lift or lower electrically. Other elec modes normal. 2. FIM 52-33-00/101, Fig. 111, Block 1
52 34 23 00	1. Fwd cargo door will not lift or lower electrically or manually. Other elec modes normal. 2. FIM 52-33-00/101, Fig. 112, Block 1

EFFECTIVITY

ALL

## 52-FAULT CODE INDEX

08

Page 5  
May 10/96


**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
52 34 24 00	1. Fwd cargo door electrical operation inop. 2. FIM 52-33-00/101, Fig. 113, Block 1
52 34 25 00	1. Fwd cargo door will not latch lock. 2. FIM 52-33-00/101, Fig. 114, Block 1
52 34 26 00	1. Fwd cargo door will not latch unlock. 2. FIM 52-33-00/101, Fig. 115, Block 1
52 34 27 00	1. Fwd cargo door will not latch lock or latch unlock. 2. FIM 52-33-00/101, Fig. 114, Block 1 FIM 52-33-00/101, Fig. 115, Block 1
52 34 28 -- thru 52 34 29 --	Not Used
52 34 30 00	1. Fwd cargo door will not latch completely. 2. FIM 52-33-00/101, Fig. 114, Block 1
52 34 31 00	1. Fwd cargo door fails to raise full up. 2. FIM 52-33-00/101, Fig. 116, Block 1
52 35 01 00	1. Aft cargo door will not unlatch electrically. Manual drive unlocks door normal. Other elec modes normal. 2. FIM 52-35-00/101, Fig. 103, Block 1
52 35 02 00	1. Aft cargo door will not unlatch electrically, or with manual drive. Other elec modes normal. 2. FIM 52-35-00/101, Fig. 104, Block 1
52 35 03 00	1. Aft cargo door will not latch closed electrically. Manual drive will lock door closed. Other elec modes normal. 2. FIM 52-35-00/101, Fig. 105, Block 1
52 35 04 00	1. Aft cargo door will not latch closed electrically or manually. Other elec modes normal. 2. FIM 52-35-00/101, Fig. 106, Block 1
52 35 05 00	1. Aft cargo door will not unlatch or latch electrically. Other elec modes normal. 2. FIM 52-35-00/101, Fig. 107, Block 1

EFFECTIVITY

ALL

## 52-FAULT CODE INDEX

09

Page 6  
May 10/96




**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
52 35 06 00	1. Aft cargo door will not raise electrically. Manual drive will raise door. Other elec modes normal. 2. FIM 52-35-00/101, Fig. 108, Block 1
52 35 07 00	1. Aft cargo door will not raise electrically or manually. Other elec modes normal. 2. FIM 52-35-00/101, Fig. 109, Block 1
52 35 08 00	1. Aft cargo door will not lower electrically. Manual drive will lower door. Other elec modes normal. 2. FIM 52-35-00/101, Fig. 110, Block 1
52 35 09 00	1. Aft cargo door will not lower electrically or manually. Other elec modes normal. 2. FIM 52-35-00/101, Fig. 109, Block 1
52 35 10 00	1. Aft cargo door will not raise or lower electrically or manually. Other elec modes normal. 2. FIM 52-35-00/101, Fig. 109, Block 1
52 35 11 00	1. Aft cargo door electrical operation inop. 2. FIM 52-35-00/101, Fig. 111, Block 1
52 35 12 00	1. Aft cargo door has erratic movement during raise mode. 2. FIM 52-35-00/101, Fig. 112, Block 1
52 35 13 00	1. Aft cargo door has intermittent movement during lower mode. 2. FIM 52-35-00/101, Fig. 113, Block 1
52 35 14 00	1. Aft cargo door will not latch completely. 2. FIM 52-35-00/101, Fig. 114, Block 1
52 35 15 00	1. Aft cargo door fails to raise full up. 2. FIM 52-35-00/101, Fig. 109, Block 2
52 36 01 00	1. Bulk cargo door will unlatch, but not open. 2. FIM 52-36-00/101, Fig. 103, Block 1
52 36 02 00	1. Bulk cargo door handle requires high forces when latching door. 2. FIM 52-36-00/101, Fig. 104, Block 1

EFFECTIVITY

ALL

## 52-FAULT CODE INDEX

08

Page 7  
May 10/96


**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
52 51 01 00	1. Cockpit door will not release electrically. 2. FIM 52-51-00/101, Fig. 103, Block 1
52 51 02 00	1. Cockpit door difficult to (open/close) (Ref Log Book Report for detailed problem description). 2. Repair or replace door as required (AMM 52-51-01).
52 51 03 00	1. Cockpit door (will not latch, latch broken, latch sticks). 2. Replace door strike (AMM 52-51-03).
52 51 04 00	1. Cockpit door knob (loose, came off) (Ref Log Book Report for description of problem). 2. Repair or replace door knob as required (AMM 52-51-00).
52 51 05 00	1. Cockpit door lock (stiff, inop) (Ref Log Book Report for description of problem). 2. Repair or replace door lock as required (AMM 52-51-01).
52 51 06 00	1. Cockpit door UNLKD lgt failed to extin with door locked. 2. FIM 52-51-00/101, Fig. 104, Block 1
52 51 07 00	Not Used
52 51 08 00	1. Flt dk door switch is defective. Describe problem. 2. Replace switch/light YXS1 on right overhead lighting control module M10057 (AMM 33-13-00) or M10057 (WDM 53-51-11).
52 51 09 00	1. Cockpit door key (missing, doesn't fit, etc.). 2. Obtain new key.
52 51 10 00	1. Cockpit door (seal, moulding, trim) is (loose, damaged, missing). 2. Repair or replace as required

EFFECTIVITY

ALL

## 52-FAULT CODE INDEX

02

Page 8  
May 10/96


**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
52 51 11 00	1. Flight Deck Door LOCK FAIL (inop, door locked, etc.). 2. Repair or replace as required (FIM 52-51-00).
52 51 12 00	1. Flight Deck Door AUTO UNLK light operation abnormal. 2. Repair or replace as required (FIM 52-51-00).
52 51 13 --	1. Flight Deck Door Lock Selector operation abnormal. 2. Repair or replace as required (FIM 52-51-00).
52 51 14 00	1. Flight Deck Access Panel Keypad (access code, specify key) operation abnormal. 2. Repair or replace as required (FIM 52-51-00).
52 51 15 00	1. Flight Deck Access Panel (red, amber, green) LED operation abnormal. 2. Repair or replace as required (FIM 52-51-00).
52 71 01 --	1. ENTRY DOORS light illum (steady, intermittent). EICAS message (01=L FWD ENT DOOR, 02=L AFT ENT DOOR, 03=R FWD ENT DOOR, 04=R AFT ENT DOOR) displayed (steady, intermittent). Lock pin is engaged. 2. FIM 52-71-00/101, Fig. 103, Block 1
52 71 02 --	Not Used
52 71 03 --	1. EMER DOORS light illum (steady, intermittent). EICAS message (05=L EMER DOOR, 06=R EMER DOOR, 07=L FWD EMER, 08=L AFT EMER, 09=R FWD EMER, 10=R AFT EMER, 15=L WING SLIDE, 16=R WING SLIDE) displayed (steady, intermittent). 2. (05=L EMER DOOR, 06=R EMER DOOR, 07=L FWD EMER, 08=L AFT EMER, 09=R FWD EMER, 10=R AFT EMER) FIM 52-71-00/101, Fig. 105, Block 1 (15=L WING SLIDE, 16=R WING SLIDE) FIM 52-71-00/101, Fig. 107, Block 1
52 71 04 --	1. CARGO DOORS light illum (steady, intermittent). EICAS message (11=FWD CARGO DOOR, 12=AFT CARGO DOOR, 17=BULK CARGO DOOR) displayed (steady, intermittent). Cabin press norm. 2. (07=FWD CARGO DOOR, 08=AFT CARGO DOOR) FIM 52-71-00/101, Fig. 104, Block 1 (17=BULK CARGO DOOR) FIM 32-09-03/101, Fig. 103, Block 1

EFFECTIVITY

ALL

## 52-FAULT CODE INDEX

06

Page 9  
Apr 22/05


**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

FAULT CODE	1. LOG BOOK REPORT 2. FAULT ISOLATION REFERENCE
52 71 05 --	1. Corresponding EICAS message displayed for (01=L FWD, 02=L AFT, 03=R FWD, 04=R AFT, 05=L EMER, 06=R EMER, 07=L FWD EMER, 08=L AFT EMER, 09=R FWD EMER, 10=R AFT EMER, 11=FWD CARGO, 12=AFT CARGO, 13=FWD ACCESS, 14=E/E ACCESS, 17=BULK CARGO) DOOR. DOOR OPEN light not illuminated. 2. FIM 52-71-00/101, Fig. 106, Block 1
52 71 06 --	1. ACCESS DOORS light illum (steady, intermittent). EICAS message (13=FWD ACCESS DOOR, 14=E/E ACCESS DOOR) displayed (steady, intermittent). Cabin press norm. 2. FIM 32-09-03/101, Fig. 103, Block 1
52 71 07 00	1. ENTRY DOORS lgt illum without associated door EICAS msg. 2. Check wiring from ENTRY DOORS light (YDLL1) terminal 2 to M162 Proximity Switch Electronics Unit (PSEU) connector D2166D pin K15 for shorts. Repair circuit as necessary (WDM 52-71-11).
52 71 08 --	1. EICAS msg (01=L FWD, 02=L AFT, 03=R FWD, 04=R AFT) ENT DOOR did not display with door open. 2. FIM 32-09-03/101, Fig. 103, Block 1
52 71 09 --	1. EICAS msg (05=L EMER, 06=R EMER, 07=L FWD EMER, 08=L AFT EMER, 09=R FWD EMER, 10=R AFT EMER, 15=L WING SLIDE, 16=R WING SLIDE) DOOR did not display with door open. 2. FIM 32-09-03/101, Fig. 103, Block 1
52 71 10 --	1. EICAS msg (11=FWD CARGO, 12=AFT CARGO, 17=BULK CARGO) DOOR did not display with door open. 2. FIM 32-09-03/101, Fig. 103, Block 1
52 71 11 --	1. EICAS msg (13=FWD ACCESS, 14=E/E ACCESS) DOOR did not display with door open. 2. FIM 32-09-03/101, Fig. 103, Block 1

EFFECTIVITY

ALL

## 52-FAULT CODE INDEX

03

Page 10  
Apr 22/05


**BITE Index**

1. General

- A. Use this index to find the BITE procedure for the applicable LRU/System.
- B. The BITE procedure will provide the fault isolation instructions for the fault indications/LRU maintenance messages.

<u>LRU/System Name</u>	<u>Acronym</u>	<u>FIM Reference</u>
ACARS Management Unit		23-22
Air Data Computer	ADC	34-12
Air Data Inertial Reference Unit	ADIRU	34-26
Air Supply Control and Test Unit	ASCTU	36-20
Air Traffic Control Transponder	ATC	34-53
Airborne Vibration Monitor Signal Conditioner	AVM	77-31
Antiskid/Autobrake Control Unit	AACU	32-42
APU Fire Detection System		26-15
Automatic Direction Finder Receiver	ADF	34-57
APU Control Unit (or Electronic Control Unit)	ECU	49-11
Autopilot/Flight Director	AFDS	22-00
Auxiliary Zone Temperature Controller	AZTC	2160/21-61
Brake Temperature Monitor Unit	BTMU	32-46
Bus Power Control Unit	BPCU	24-20
Cabin Pressure Controller	CPC	21-30/21-31
Cabin Temperature Controller	CTC	21-61
Digital Flight Data Acquisition Unit	DFDAU	31-31
Distance Measuring Equipment Interrogator	DME	34-55
Duct Leak (Wing and Body)		26-18
E/E Cooling Control Card (If cards installed)		21-58
ECS Bleed Configuration Card		36-10
Electronic Control Unit	ECU	49-11
Electronic Engine Control Monitor Unit (Non-FADEC Engines)	EECM	71-EECM Message Index
Electronic Flight Instrument System	EFIS	34-22

Bite Index  
Figure 1 (Sheet 1)




# 52-BITE INDEX


**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

<u>LRU/System Name</u>	<u>Acronym</u>	<u>FIM Reference</u>
Engine Fire/Overheat Detection System		26-11
Engine Indication and Crew Alerting System Computer	EICAS	31-41
Enhanced Ground Proximity Warning Computer	EGPWC	34-46
Equipment Cooling System Controller		21-58
Equipment Cooling Temperature Controller		21-58
Flap/Slat Electronic Unit	FSEU	27-51
Flap/Stabilizer Position Module	FSPM	27-58
Flight Management Computer	FMC	34-61
Fuel Quantity Indicating System Processor	FQIS	28-41
Ground Proximity Warning Computer	GPWC	34-46
HF (High Frequency) Communication		23-11
In-Flight Entertainment Equipment Cooling Card		21-58
Inertial Reference Unit	IRU	34-21
Instrument Comparator Unit	ICU	34-25
Instrument Landing System Receiver	ILS	34-31
Large Format Display System	LFDS	31-63
Lower Cargo Compartment Smoke Detection System		26-16
Maintenance Control Display Panel	MCDP	22-00
Multi-Mode Receiver	MMR	34-31
PA (Passenger Address) Amplifier		23-31
Pack Standby Temperature Controller	PSTC	21-51
Pack Temperature Controller	PTC	21-51
Passenger Entertainment System	PES	23-34
Power Supply Module (Control System Electronics Units)	PSM	27-09
Propulsion Interface and Monitor Unit (FADEC Engines)	PIMU	71-PIMU Message Index
Proximity Switch Electronics Unit	PSEU	32-09

Bite Index  
Figure 1 (Sheet 2)




## 52-BITE INDEX


  
**767**
  
**FAULT ISOLATION/MAINT MANUAL**

<u>LRU/System Name</u>	<u>Acronym</u>	<u>FIM Reference</u>
Radio Altimeter Transmitter/Receiver	RA	34-33
Rudder Ratio Changer Module	RRCM	27-09
Satellite Data Unit	SDU	23-25
Spoiler Control Module	SCM	27-09
Stabilizer Trim/Elevator Asymmetry Limit Module	SAM	27-09
Stall Warning Computer/Module (in Warning Electronic Unit)	SWC	27-32
Strut Overheat Detection System (RR Engines)		26-12
Thrust Management Computer/Autothrottle	TMC	22-00
Traffic Alert and Collision Avoidance Computer	TCAS	34-45
VHF (Very High Frequency) Communication		23-12
VOR/Marker Beacon Receiver	VOR/MKR	34-51
Warning Electronic Unit BITE Module (Stall Warning)	WEU	27-32
Weather Radar Transceiver	WXR	34-43
Wheel Well Fire Detection		26-17
Window Heat Control Unit	WHCU	30-41
Yaw Damper Module	YDM	22-21
Yaw Damper/Stabilizer Trim Module	YSM	27-09
Zone Temperature Controller	ZTC	21-60/21-61

Bite Index  
Figure 1 (Sheet 3)



## 52-BITE INDEX

01

Page 3  
Aug 22/99

 **BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

ENTRY/SERVICE DOORS

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
ACTUATOR - ENTRY DOOR ROTARY, M627	1	1	FORWARD ENTRY DOOR COUNTERBALANCE	52-11-45
BUSTLE		4	ENTRY/SERVICE DOORS	
CABLE - COUNTERBALANCE	1	8	ABOVE DOORWAY LOWERED CEILINGS	52-11-16
CARRIER - GIRT BAR	1	4	BEHIND BUSTLE	
CIRCUIT BREAKERS			FLIGHT COMPARTMENT, P11	
FWD ENTRY DR CONT, C1402		1	11T6	*
CIRCUIT BREAKERS			119AL, MAIN EQUIP CTR, P33	
FWD ENTRY DOOR, C363		1	33F6	*
CIRCUIT BREAKERS			119AL, MAIN EQUIP CTR, P33	
FWD ENTRY DOOR CONT, C1408		1	34J5	*
COUNTERBALANCE	1	4	ABOVE DOORWAY LOWERED CEILINGS	52-11-16
DOORS - ENTRY/SERVICE	1			52-11-01
FORWARD ENTRY		1	831	
FORWARD SERVICE		1	841	
AFT ENTRY		1	833	
AFT SERVICE		1	843	
LATCH CAM	2	4	DOOR UPPER TRACKS	
LINING - DOORWAY		4	ENTRY/SERVICE DOORS	52-11-02
MECHANISM - CEILING PANEL LATCH	1	4	ABOVE MOVABLE CEILING PANELS	52-11-34
MECHANISM - DOOR HANDLE	1	4	BEHIND DOORWAY LINING	52-11-25
MECHANISM - DOOR LATCH OVERCENTER	1	4	BEHIND DOORWAY LINING	52-11-32
MECHANISM - MODE SELECT	1	4	BEHIND DOORWAY LINING	
PULLEY - COUNTERBALANCE CABLE	1	8	ABOVE MOVABLE CEILING PANELS	52-11-16
RELAY - (REF 31-01-19, FIG. 101)				
FWD ENTRY DR DN, K418				
FWD ENTRY DR UP NO. 1, K417				
FWD ENTRY DR UP NO. 2, K380				
UP ENABLE, K767				
RELAY - (REF 31-01-36, FIG. 101)				
FWD ENTRY DR PWR TRANS, K43				
SEAL - DOOR		4	ENTRY/SERVICE DOORS	52-09-01
SENSORS - DOOR CONTROL PROXIMITY				52-11-47
FWD ENTRY DOOR DOWN, S186		1	DOOR UPPER TRACKS	*
FWD ENTRY DOOR HANDLE UP, S184		1	OVERCENTER MECHANISM	*
FWD ENTRY DOOR UP, S185		1	DOOR UPPER TRACKS	*
UPLATCH RELEASE, S187		1	UPLATCH	*
SOLENOID - UPLATCH, M778	2	1	BEHIND FORWARD ENTRY DOORWAY LINING	52-11-12
SWITCH - DOOR CONTROL, S410		1	FORWARD ENTRY DOOR EXTERIOR HANDLE	52-11-46
TIME DELAY - (REF 31-01-19, FIG. 101)				
DR DN, M1152				
TRACKS - DOOR SIDE	1	8	DOORWAYS	
TRACKS - DOOR UPPER	1	4	ABOVE MOVABLE CEILING PANELS	52-11-06
TROLLEY - DOOR	1	4	DOOR UPPER TRACKS	52-11-08
UPLATCH	1	4	BEHIND DOORWAY LINING	52-11-12

\* SEE THE WDM EQUIPMENT LIST

Entry/Service Doors - Component Index  
Figure 101

EFFECTIVITY

ALL


52-11-00

01

Page 101  
May 10/91

29763








Entry/Service Doors - Component Location  
Figure 102 (Sheet 1)

EFFECTIVITY	
	ALL

52-11-00

848035




Entry/Service Doors - Component Location  
Figure 102 (Sheet 2)

EFFECTIVITY	
	ALL

52-11-00

**DOOR SLIDE ARMING  
HANDLE DIFFICULT  
TO ARM**

**PREREQUISITES**  
 MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
 DOOR IS CLOSED AND LATCHED



Door Slide Arming Handle Difficult to Arm  
Figure 103


EFFECTIVITY	ALL
-------------	-----

**52-11-00**

**DOOR DIFFICULT TO OPEN OR CLOSE**

**PREREQUISITES**

NONE



Door Difficult to Open or Close  
Figure 104

EFFECTIVITY

ALL

**52-11-00**


01

Page 105  
Apr 22/08

23276

**DOOR DIFFICULT TO LATCH OR UNLATCH**

**PREREQUISITES**  
NONE




Door Difficult to Latch or Unlatch  
Figure 105 (Sheet 1)

EFFECTIVITY

ALL
-----

52-11-00



Door Difficult to Latch or Unlatch  
Figure 105 (Sheet 2)

EFFECTIVITY

ALL
-----

52-11-00

01


Page 107  
Apr 22/08

**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
11T6,33F6,34J5

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
DOOR IS CLOSED  
INTERIOR HANDLE IS NOT LATCHED

**L FWD DOOR WILL NOT RAISE ELECTRICALLY**




L Fwd Door Will Not Raise Electrically  
Figure 106 (Sheet 1)

EFFECTIVITY

ALL

**52-11-00**



L Fwd Door Will Not Raise Electrically  
Figure 106 (Sheet 2)

EFFECTIVITY

ALL

52-11-00

01

Page 109  
Dec 22/99

678826




**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
 11T6,33F6,34J5

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:  
 ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
 DOOR IS OPEN  
 INTERIOR HANDLE IS NOT LATCHED

**L FWD DOOR WILL NOT LOWER ELECTRICALLY**




L Fwd Door Will Not Lower Electrically  
 Figure 107 (Sheet 1)

EFFECTIVITY	ALL
-------------	-----

**52-11-00**

 **BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL



L Fwd Door Will Not Lower Electrically  
Figure 107 (Sheet 2)

EFFECTIVITY

ALL

52-11-00

01

Page 111  
Apr 22/08


678836

L FWD DOOR WILL NOT RAISE OR LOWER ELECTRICALLY

**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
11T6,34J5

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
DOOR IS NOT FULLY CLOSED









L Fwd Door Will Not Raise or Lower Electrically  
Figure 108



EFFECTIVITY	ALL
-------------	-----

52-11-00


**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

OVERWING ESCAPE HATCH


COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
FITTINGS - PIVOT HANDLES	1	8	LOWER EDGE OF EMER ESCAPE HATCH	52-21-00
EMERGENCY PULL EXTERIOR	1,2	4	INTERIOR OF EMER ESCAPE HATCH	52-21-00
INTERIOR ASSIST	1	4	EXTERIOR OF EMER ESCAPE HATCH	
	2	4	INTERIOR OF EMER ESCAPE HATCH	
HATCH - OVERWING ESCAPE FORWARD/LEFT  	1	1	832	52-21-01
HATCH - OVERWING ESCAPE AFT/LEFT 	1	1	834	52-21-01
HATCH - OVERWING ESCAPE FORWARD/RIGHT  	1	1	842	52-21-01
HATCH - OVERWING ESCAPE AFT/RIGHT 	1	1	844	52-21-01
LINING - OVERWING ESCAPE HATCH	2	4	INTERIOR OF EMER ESCAPE HATCH	52-21-02
PIN - STRIKER	1,2	4	LATCH TORQUE TUBE	52-21-00
PLATE - COVER	2	4	INTERIOR OF EMER ESCAPE HATCH	52-21-00
ROLLER - LATCH	1,2	8	ENDS OF LATCH TORQUE TUBE	52-21-00
SPRING - OVERCENTER	2	8	LATCH TORQUE TUBE	52-21-00
STOP - DOOR	1	24	FORWARD AND AFT EDGES OF EMER ESCAPE HATCH	52-21-00
TORQUE TUBE - LATCH	2	4	UPPER PART OF EMER ESCAPE HATCH	52-21-00

-  AIRPLANES WITH ONE HATCH OVER EACH WING
-  AIRPLANES WITH TWO HATCHES OVER EACH WING

Overwing Escape Hatch - Component Index  
Figure 101




52-21-00




834,844, AFT OVERWING ESCAPE HATCH 2  
(LEFT SHOWN, RIGHT OPPOSITE)  
VIEW FROM OUTSIDE  
SEE (A)  
VIEW FROM INSIDE  
SEE (B)

832,842, FORWARD OVERWING ESCAPE HATCH 1 2  
(LEFT SHOWN, RIGHT OPPOSITE)  
VIEW FROM OUTSIDE  
SEE (A)  
VIEW FROM INSIDE  
SEE (B)



OVERWING ESCAPE HATCH  
(A)



OVERWING ESCAPE HATCH  
(LINING NOT SHOWN)  
(B)


- 1 AIRPLANES WITH ONE HATCH OVER EACH WING
- 2 AIRPLANES WITH TWO HATCHES OVER EACH WING

Overwing Escape Hatch - Component Location  
Figure 102 (Sheet 1)


EFFECTIVITY	ALL
-------------	-----

52-21-00

851175



(C)



VIEW FROM INSIDE  
(LINING INSTALLED)

Overwing Escape Hatch - Component Location  
Figure 102 (Sheet 2)

EFFECTIVITY	
	ALL

52-21-00

**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

LARGE FORWARD CARGO DOOR

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
ACTUATOR - LATCH/HOOK, M630	1	1	821, FWD CARGO DOOR	52-33-08
ACTUATOR - ROTARY	1	1	821, FWD CARGO DOOR	52-33-04
CAMS - MAIN LATCH	2	2	821, FWD CARGO DOOR	52-33-00
CAMS - MIDSPAN LATCH	2	1	821, FWD CARGO DOOR	52-33-00
CENTERING RAMP AND ROLLER	3	12	821, FWD CARGO DOOR	52-33-00
CIRCUIT BREAKERS DOOR INDICATION, C1406		1	FLT COMPT, P11 11T33	*
CIRCUIT BREAKERS CARGO DOOR CONTROL, C1403		1	119AL, MAIN EQUIP CTR, P34 34J4	*
FORWARD CARGO DOOR, C360		1	34J7	
DIODE - (REF 31-01-35, FIG. 101) R35				
DOOR - LARGE FORWARD CARGO	1	1	821, FWD CARGO DOOR	52-33-01
DOOR - VENT	3	2	821, FWD CARGO DOOR	52-33-07
HINGE - DOOR	2	2	821, FWD CARGO DOOR	52-33-00
HOOK - PULL-IN	3	2	821, FWD CARGO DOOR	52-33-00
LEVER - STOP	3	1	821, FWD CARGO DOOR	52-33-00
LIGHT - INDICATOR, FWD CARGO DOOR CLOSED LIGHT, L599	8	1	124AR, EXT FWD CARGO DR CONT PNL, P43	52-33-00
LIGHT - INDICATOR, FWD CARGO DOOR OPEN LIGHT, L597	8	1	124AR, EXT FWD CARGO DR CONT PNL, P43	52-33-00
MECHANISM - LATCH/HOOK	1	1	821, FWD CARGO DOOR	52-33-00
MECHANISM - LATCH LOCK HANDLE	2	1	821, FWD CARGO COMPARTMENT	52-33-06
MECHANISM - LIFT DRIVE	1	1	821, FWD CARGO DOOR	52-33-00
PINS - MAIN LATCH	5	12	821, FWD CARGO COMPARTMENT	52-33-09
PINS - MIDSPAN LATCH	5	2	821, FWD CARGO COMPARTMENT	52-33-09
PINS - PULL-IN	5	2	821, FWD CARGO COMPARTMENT	52-33-10
RELAY - (REF 31-01-35, FIG. 101) FWD CARGO DOOR HINGE DN, K32 FWD CARGO DOOR HINGE UP, K31 FWD CARGO DOOR LATCH, K34 FWD CARGO DOOR UNLATCH, K33				
SENSOR - (REF 52-71-00, FIG. 101) PROXIMITY, DOOR CLOSED INDICATOR, S215 PROXIMITY, LOCK SECTOR LOCKED INDICATOR, S214				
SENSOR - PROXIMITY, DOOR LATCHED CONTROL, S154	7	1	821, FWD CARGO DOOR	52-33-00
SENSOR - PROXIMITY, DOOR OPEN CONTROL, S151	6	1	821, FWD CARGO COMPARTMENT	52-33-00
SENSOR - PROXIMITY, DOOR OPENING LATCH RANGE, S152	7	1	821, FWD CARGO DOOR	52-33-00
SENSOR - PROXIMITY, DOOR UNLATCHED CONTROL, S150	7	1	821, FWD CARGO DOOR	52-33-00
SENSOR - PROXIMITY, HANDLE UNLOCKED POWER CONTROL, S153	7	1	821, FWD CARGO COMPARTMENT	52-33-00
SWITCH - FWD CARGO DOOR CONTROL, S411	9	1	821, FWD COMPT CARGO HDLG ACCESS PNL, P35	52-33-00
SWITCH - FWD CARGO DOOR CONTROL, S511	8	1	821, EXT FWD CARGO DR CONT PNL, P43	52-33-00
TORQUE TUBE - LATCH/LOCK	1,3	1	821, FWD CARGO DOOR	52-33-00
UNIT - HINGE POWER, M629	4	1	821, FWD CARGO DOOR	52-33-02
UNIT - (REF 32-09-03, FIG. 101) PROX SW ELEC, M162				

\* SEE THE WDM EQUIPMENT LIST

Large Forward Cargo Door - Component Index  
Figure 101

EFFECTIVITY

ALL


**52-33-00**

06

Page 101  
Aug 10/90

777398

**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL




Large Forward Cargo Door - Component Location  
Figure 102 (Sheet 1)

EFFECTIVITY	
	ALL

52-33-00






Large Forward Cargo Door - Component Location  
Figure 102 (Sheet 2)

EFFECTIVITY	
	ALL


52-33-00




Large Forward Cargo Door - Component Location  
Figure 102 (Sheet 3)

EFFECTIVITY	
	ALL


52-33-00




**H**




**I**



**J**







**K**



Large Forward Cargo Door - Component Location  
Figure 102 (Sheet 4)

EFFECTIVITY	ALL
-------------	-----

**52-33-00**





Large Forward Cargo Door - Component Location  
Figure 102 (Sheet 5)

EFFECTIVITY	
ALL	

52-33-00

774351


**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL




Large Forward Cargo Door - Component Location  
 Figure 102 (Sheet 6)

EFFECTIVITY	
	ALL

52-33-00

06



Page 107  
Aug 10/90



Large Forward Cargo Door - Component Location  
Figure 102 (Sheet 7)

EFFECTIVITY	ALL
-------------	-----


**52-33-00**



Large Forward Cargo Door - Component Location  
Figure 102 (Sheet 8)

EFFECTIVITY	ALL
-------------	-----

52-33-00



Large Forward Cargo Door - Component Location  
Figure 102 (Sheet 9)

EFFECTIVITY	
	ALL

52-33-00




FWD CARGO DOOR WILL NOT UNLATCH/UNHOOK ELECTRICALLY.  
OTHER ELEC MODES NORMAL

**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
34J4, 34J7

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)



Fwd Cargo Door Will Not Unlatch/Unhook Electrically.  
Other Elec Modes Normal  
Figure 103 (Sheet 1)

EFFECTIVITY

ALL


**52-33-00**

04

Page 111  
Aug 22/07

779868

FROM SHEET 1  
(BLOCK 3)



Fwd Cargo Door Will Not Unlatch/Unhook Electrically.  
Other Elec Modes Normal  
Figure 103 (Sheet 2)

EFFECTIVITY	ALL
-------------	-----


52-33-00

**FWD CARGO DOOR WILL NOT UNLATCH/UNHOOK ELECTRICALLY OR MANUALLY**

**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
34J4, 34J7

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:  
ELECTRICAL POWER IS ON (MM 24-22-00/201)



Fwd Cargo Door Will Not Unlatch/Unhook Electrically or Manually  
Figure 104 (Sheet 1)

EFFECTIVITY

ALL


**52-33-00**

04

Page 113  
Nov 10/90

779870

FROM SHEET 1  
(BLOCK 3)



Fwd Cargo Door Will Not Unlatch/Unhook Electrically or Manually  
Figure 104 (Sheet 2)

EFFECTIVITY

ALL

**52-33-00**

04


Page 114  
Nov 10/90

FWD CARGO DOOR WILL NOT LATCH/HOOK CLOSED ELECTRICALLY. OTHER ELEC MODES NORMAL

**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
34J4, 34J7

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:  
ELECTRICAL POWER IS ON (MM 24-22-00/201)



Fwd Cargo Door Will Not Latch/Hook Closed Electrically.  
Other Elec Modes Normal  
Figure 105 (Sheet 1)


EFFECTIVITY

ALL

**52-33-00**

04

Page 115  
Nov 10/90



Fwd Cargo Door Will Not Latch/Hook Closed Electrically.  
Other Elec Modes Normal  
Figure 105 (Sheet 2)

EFFECTIVITY	ALL
-------------	-----

52-33-00


FWD CARGO DOOR WILL NOT LATCH/HOOK CLOSED ELECTRICALLY OR MANUALLY. OTHER ELEC MODES NORMAL

**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
34J4, 34J7

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:

ELECTRICAL POWER IS ON (MM 24-22-00/201)  
THE DOOR LINING IS REMOVED



Fwd Cargo Door Will Not Latch/Hook Closed Electrically or Manually.  
Other Elec Modes Normal  
Figure 106 (Sheet 1)

EFFECTIVITY


ALL

**52-33-00**


04

Page 117  
Nov 10/90

777790



Fwd Cargo Door Will Not Latch/Hook Closed Electrically or Manually.  
 Other Elec Modes Normal  
 Figure 106 (Sheet 2)



52-33-00




FWD CARGO DOOR WILL NOT LATCH/HOOK CLOSED OR UNLATCH/UNHOOK ELECTRICALLY. OTHER ELEC MODES NORMAL.

**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
34J4, 34J7

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)



Fwd Cargo Door Will Not Latch/Hook Closed or Unlatch/Unhook Electrically.  
Other Elec Modes Normal  
Figure 107 (Sheet 1)

EFFECTIVITY

ALL

**52-33-00**

04

Page 119  
Aug 22/07

777889

FROM SHEET 1  
(BLOCK 3)

NO

4 DO A CHECK FOR THE PROXIMITY SENSORS S150, S151, S152, S153, AND S154 FOR THE TARGET NEAR OR FAR BY USING THE PSEU:

- PUT THE CARGO DOOR IN THE CLOSE POSITION AND PUT THE LATCH HANDLE IN THE LOCKED CLOSED POSITION, THE SENSORS ARE AS FOLLOWS:

<u>SENSOR</u>	<u>TARGET POSITION</u>
S150 (DOOR UNLATCHED)	FAR
S151 (DOOR OPEN)	FAR
S152 (LATCH RANGE)	NEAR
S153 (HANDLE UNLOCKED)	FAR
S154 (DOOR LATCHED)	NEAR

DID THE SENSOR(S) NOT HAVE A CORRECT POSITION?

YES

23 ADJUST THE SENSORS (AMM 52-33-00/501).

NO

5 DO A CHECK FOR THE PROXIMITY SENSORS S150, S151, S152, S153, AND S154 FOR THE TARGET NEAR OR FAR BY USING THE PSEU:

- PUT THE CARGO DOOR IN THE CLOSE POSITION AND THE LATCH HANDLE IN THE OPEN POSITION, THE SENSORS ARE AS FOLLOWS:

<u>SENSOR</u>	<u>TARGET POSITION</u>
S150 (DOOR UNLATCHED)	FAR
S151 (DOOR OPEN)	FAR
S152 (LATCH RANGE)	NEAR
S153 (HANDLE UNLOCKED)	NEAR
S154 (DOOR LATCHED)	NEAR

DID THE SENSOR(S) NOT HAVE A CORRECT POSITION?

YES

24 ADJUST THE SENSORS (AMM 52-33-00/501).

NO

SEE SHEET 3  
(BLOCK 6)  
Fwd Cargo Door Will Not Latch/Hook Closed or Unlatch/Unhook Electrically.  
Other Elec Modes Normal  
Figure 107 (Sheet 2)

EFFECTIVITY

ALL

52-33-00

03

Page 120  
Feb 10/97

G33112

FROM SHEET 2  
(BLOCK 5)

NO

6 DO A CHECK FOR THE PROXIMITY SENSORS S150, S151, S152, S153, AND S154 FOR THE TARGET NEAR OR FAR BY USING THE PSEU:

- PUT THE CARGO DOOR IN THE OPEN POSITION 2.6 INCHES MINIMUM, THE SENSORS ARE AS FOLLOWS:

<u>SENSOR</u>	<u>TARGET POSITION</u>
S150 (DOOR UNLATCHED)	NEAR
S151 (DOOR OPEN)	FAR
S152 (LATCH RANGE)	FAR
S153 (HANDLE UNLOCKED)	NEAR
S154 (DOOR LATCHED)	FAR

DID THE SENSOR(S) NOT HAVE A CORRECT POSITION?

YES

25 ADJUST THE SENSORS  
(AMM 52-33-00/501).

NO

7 DO A CHECK FOR THE PROXIMITY SENSORS S150, S151, S152, S153, AND S154 FOR THE TARGET NEAR OR FAR BY USING THE PSEU:

- PUT THE CARGO DOOR IN FULLY OPEN POSITION, THE SENSORS ARE AS FOLLOWS:

<u>SENSOR</u>	<u>TARGET POSITION</u>
S150 (DOOR UNLATCHED)	NEAR
S151 (DOOR OPEN)	NEAR
S152 (LATCH RANGE)	FAR
S153 (HANDLE UNLOCKED)	NEAR
S154 (DOOR LATCHED)	FAR

DID THE SENSOR(S) NOT HAVE A CORRECT POSITION?

YES

26 ADJUST THE SENSORS  
(AMM 52-33-00/501).

NO

SEE SHEET 4  
(BLOCK 8)

Fwd Cargo Door Will Not Latch/Hook Closed or Unlatch/Unhook Electrically.  
 Other Elec Modes Normal  
 Figure 107 (Sheet 3)

EFFECTIVITY

ALL


52-33-00

03

Page 121  
Feb 10/97

G33125

FROM SHEET 3  
(BLOCK 7)



Fwd Cargo Door Will Not Latch/Hook Closed or Unlatch/Unhook Electrically.  
Other Elec Modes Normal  
Figure 107 (Sheet 4)

EFFECTIVITY	ALL
-------------	-----


52-33-00

**FWD CARGO DOOR WILL NOT LIFT ELECTRICALLY. OTHER ELEC MODES NORMAL.**

**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
34J4, 34J7

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)




Fwd Cargo Door Will Not Lift Electrically. Other Elec Modes Normal.  
Figure 108 (Sheet 1)

EFFECTIVITY	ALL
-------------	-----

52-33-00

**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL



Fwd Cargo Door Will Not Lift Electrically. Other Elec Modes Normal  
Figure 108 (Sheet 2)

EFFECTIVITY

ALL
-----


52-33-00

FWD CARGO DOOR WILL NOT LIFT OR LOWER ELECTRICALLY OR MANUALLY. OTHER ELEC MODES NORMAL

**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
34J4, 34J7

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION;  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)




Fwd Cargo Door Will Not Lift or Lower Electrically or Manually.  
Other Elec Modes Normal  
Figure 109 (Sheet 1)

EFFECTIVITY

ALL
-----

52-33-00

**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL



Fwd Cargo Door Will Not Lift or Lower Electrically or Manually.  
Other Elec Modes Normal  
Figure 109 (Sheet 2)

EFFECTIVITY

ALL
-----

52-33-00

03

Page 126  
Dec 22/99




**FWD CARGO DOOR WILL NOT LOWER ELECTRICALLY. OTHER ELEC MODES NORMAL**

**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
34J4, 34J7

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:  
ELECTRICAL POWER IS ON (MM 24-22-00/201)



Fwd Cargo Door Will Not Lower Electrically. Other Elec Modes Normal  
Figure 110

EFFECTIVITY

ALL

**52-33-00**

03

Page 127  
Dec 22/99


778035

FWD CARGO DOOR WILL NOT LIFT OR LOWER ELECTRICALLY. OTHER ELEC MODES NORMAL

**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
34J4,34J7


MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:  
ELECTRICAL POWER IS ON (MM 24-22-00/201)



Fwd Cargo Door Will Not Lift or Lower Electrically. Other Elec Modes Normal  
Figure 111 (Sheet 1)

EFFECTIVITY	ALL
-------------	-----

**52-33-00**



Fwd Cargo Door Will Not Lift or Lower Electrically. Other Elec Modes Normal  
Figure 111 (Sheet 2)

EFFECTIVITY

ALL

**52-33-00**

03


Page 129  
Dec 22/99

FWD CARGO DOOR WILL NOT LIFT OR LOWER ELECTRICALLY OR MANUALLY. OTHER ELECTRICAL MODES NORMAL

**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
34J4, 34J7

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:  
ELECTRICAL POWER IS ON (MM 24-22-00/201)



Fwd Cargo Door will not Lift or Lower Electrically or Manually.  
Other Electrical Modes Normal  
Figure 112

EFFECTIVITY	ALL
-------------	-----


52-33-00

**FWD CARGO DOOR  
ELECTRICAL  
OPERATION INOP**

**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
34J4, 34J7

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)



Fwd Cargo Door Electrical Operation Inop  
Figure 113 (Sheet 1)

EFFECTIVITY

ALL

**52-33-00**

03

Page 131  
Aug 22/07

778165

FROM SHEET 1  
(BLOCK 3)

NO

4 DO A CHECK FOR THE PROXIMITY SENSORS S150, S151, S152, S153, AND S154 FOR THE TARGET NEAR OR FAR BY USING THE PSEU:

- PUT THE CARGO DOOR IN THE CLOSE POSITION AND PUT THE LATCH HANDLE IN THE LOCKED CLOSED POSITION, THE SENSORS ARE AS FOLLOWS:

<u>SENSOR</u>	<u>TARGET POSITION</u>
S150 (DOOR UNLATCHED)	FAR
S151 (DOOR OPEN)	FAR
S152 (LATCH RANGE)	NEAR
S153 (HANDLE UNLOCKED)	FAR
S154 (DOOR LATCHED)	NEAR

DID THE SENSOR(S) NOT HAVE A CORRECT POSITION?

YES

23 ADJUST THE SENSORS  
(AMM 52-33-00/501).

NO

5 DO A CHECK FOR THE PROXIMITY SENSORS S150, S151, S152, S153, AND S154 FOR THE TARGET NEAR OR FAR BY USING THE PSEU:

- PUT THE CARGO DOOR IN THE CLOSE POSITION AND THE LATCH HANDLE IN THE OPEN POSITION, THE SENSORS ARE AS FOLLOWS:

<u>SENSOR</u>	<u>TARGET POSITION</u>
S150 (DOOR UNLATCHED)	FAR
S151 (DOOR OPEN)	FAR
S152 (LATCH RANGE)	NEAR
S153 (HANDLE UNLOCKED)	NEAR
S154 (DOOR LATCHED)	NEAR

DID THE SENSOR(S) NOT HAVE A CORRECT POSITION?

YES

24 ADJUST THE SENSORS  
(AMM 52-33-00/501).

NO

SEE SHEET 3  
(BLOCK 6)

Fwd Cargo Door Electrical Operation Inop  
Figure 113 (Sheet 2)

EFFECTIVITY

ALL

**52-33-00**

03

Page 132  
Dec 22/99

G33159

FROM SHEET 2  
(BLOCK 5)

NO

6 DO A CHECK FOR THE PROXIMITY SENSORS S150, S151, S152, S153, AND S154 FOR THE TARGET NEAR OR FAR BY USING THE PSEU:

- PUT THE CARGO DOOR IN THE OPEN POSITION 2.6 INCHES MINIMUM, THE SENSORS ARE AS FOLLOWS:

<u>SENSOR</u>	<u>TARGET POSITION</u>
S150 (DOOR UNLATCHED)	NEAR
S151 (DOOR OPEN)	FAR
S152 (LATCH RANGE)	FAR
S153 (HANDLE UNLOCKED)	NEAR
S154 (DOOR LATCHED)	FAR

DID THE SENSOR(S) NOT HAVE A CORRECT POSITION?

YES

25 ADJUST THE SENSORS  
(AMM 52-33-00/501).

NO

7 DO A CHECK FOR THE PROXIMITY SENSORS S150, S151, S152, S153, AND S154 FOR THE TARGET NEAR OR FAR BY USING THE PSEU:

- PUT THE CARGO DOOR IN FULLY OPEN POSITION, THE SENSORS ARE AS FOLLOWS:

<u>SENSOR</u>	<u>TARGET POSITION</u>
S150 (DOOR UNLATCHED)	NEAR
S151 (DOOR OPEN)	NEAR
S152 (LATCH RANGE)	FAR
S153 (HANDLE UNLOCKED)	NEAR
S154 (DOOR LATCHED)	FAR

DID THE SENSOR(S) NOT HAVE A CORRECT POSITION?

YES

26 ADJUST THE SENSORS  
(AMM 52-33-00/501).

NO

SEE SHEET 4  
(BLOCK 8)

Fwd Cargo Door Electrical Operation Inop  
Figure 113 (Sheet 3)

EFFECTIVITY

ALL


52-33-00

03

Page 133  
Dec 22/99

G33162

FROM SHEET 3  
(BLOCK 7)



Fwd Cargo Door Electrical Operation Inop  
Figure 113 (Sheet 4)

EFFECTIVITY	ALL
-------------	-----

**52-33-00**




**FWD CARGO DOOR WILL NOT LATCH LOCK**

**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
34J4, 34J7

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:  
ELECTRICAL POWER IS ON (MM 24-22-00/201)



Fwd Cargo Door Will Not Latch Lock  
Figure 114

EFFECTIVITY

ALL

**52-33-00**

03


Page 135  
Dec 22/99

**FWD CARGO DOOR WILL NOT LATCH UNLOCK**

**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
34J4, 34J7

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:  
ELECTRICAL POWER IS ON (MM 24-22-00/201)



Fwd Cargo Door Will Not Latch Unlock  
Figure 115

EFFECTIVITY

ALL
-----

**52-33-00**


778360

**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
34J4, 34J7

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)

**FWD CARGO DOOR FAILS TO RAISE FULL UP**



Fwd Cargo Door Fails to Raise Full Up  
Figure 116 (Sheet 1)


EFFECTIVITY

ALL

**52-33-00**

03

Page 137  
Aug 22/07



Fwd Cargo Door Fails to Raise Full Up  
Figure 116 (Sheet 2)

EFFECTIVITY

ALL

**52-33-00**

03

Page 138  
Dec 22/99


787501

**SEVERE VIBRATION  
OF FWD CARGO DOOR  
WHILE MOVING**

**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
34J4,34J7

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT  
FOLLOWS:  
ELECTRICAL POWER IS ON (MM 24-22-00/201)




Severe Vibration of Fwd Cargo Door While Moving  
Figure 117

EFFECTIVITY	ALL
-------------	-----

**52-33-00**

 **BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

AFT CARGO DOOR

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
ACTUATOR - ROTARY	2	2	822, AFT CARGO COMPARTMENT	52-35-03
ARM - HINGE	2	2	822, AFT CARGO COMPARTMENT	52-35-04
CIRCUIT BREAKERS	1		119AL, MAIN EQUIP CTR, P34	
CARGO DOOR, C361		1	34J10	*
CARGO DOOR CONTROL, C1403		1	34J4	*
LIGHT - INDICATOR, DOOR CLOSED, L600	1	1	156AR, EXT FUSELAGE CONTROL PANEL, P44	*
LIGHT - INDICATOR, DOOR OPEN, L598	1	1	156AR, EXT FUSELAGE CONTROL PANEL, P44	*
DIODE - (FIM 31-01-39/101) R37				
DOOR - CARGO, 822	1	1	822, AFT CARGO COMPARTMENT	52-35-01
DOOR - VENT	3	2	822, AFT CARGO DOOR	52-35-15
FLEXIBLE SHAFT - MANUAL DRIVE	2	1	822, AFT CARGO COMPARTMENT	52-35-26
MECHANISM - HINGE	2	2	822, AFT CARGO COMPARTMENT	52-35-00
MECHANISM - HINGE DRIVE	2	1	822, AFT CARGO COMPARTMENT	52-35-00
MECHANISM - LIFT/LATCH	2	1	822, AFT CARGO COMPARTMENT	52-35-00
RELAY - (FIM 31-01-39/101) CARGO DOOR CONTROL ARM, K40				
CARGO DOOR HINGE DOWN, K37				
CARGO DOOR HINGE UP, K36				
CARGO DOOR LIFT LATCH DOWN, K39				
CARGO DOOR LIFT LATCH UP, K38				
SENSOR - PROX, AFT CARGO DOOR DOWN NO. 1, S159 	5	1	822, AFT CARGO DOOR	52-35-43
SENSOR - PROX, AFT CARGO DOOR DOWN NO. 2, S160	5	1	822, AFT CARGO DOOR	52-35-43
SENSOR - PROX, AFT CARGO DOOR OPEN, S158	5	1	822, AFT CARGO DOOR	52-35-43
SENSOR - PROX, AFT CARGO DOOR LATCHED, S161	4	1	822, AFT CARGO DOOR	52-35-43
SENSOR - PROX, AFT CARGO DOOR LIFT RANGE, S157	4	1	822, AFT CARGO DOOR	52-35-43
SENSOR - (FIM 52-71-00/101) DOOR WARNING, S208				
DOOR WARNING, S209				
SWITCH - CARGO DOOR CONTROL, S413	1	1	822, AFT CARGO COMP HDLG ACCESS PANEL, P39	*
SWITCH - CARGO DOOR CONTROL ARM, S414	1	1	822, AFT CARGO COMP HDLG ACCESS PANEL, P39	*
SWITCH - CARGO DOOR CONTROL, S512	1	1	156AR, P44 EXT FUSELAGE CONTROL PANEL	*
SWITCH - CARGO DOOR CONTROL ARM, S510	1	1	156AR, P44 EXT FUSELAGE CONTROL PANEL	*
UNIT - HINGE POWER DRIVE, M631	3	1	822, AFT CARGO COMPARTMENT	52-35-02
UNIT - LIFT/LATCH POWER, M632	3	1	822, AFT CARGO DOOR	52-35-10
UNIT - (FIM 32-09-03/101) PROX SW ELECT, M162				

\* SEE THE WDM EQUIPMENT LIST

NOTE: 767-300 AIRPLANES;  
PROXIMITY SENSOR, S159, IS NOT INSTALLED.

 PROXIMITY SENSOR, S159, HAS A STEEL TARGET PERMANENTLY INSTALLED AND DOES NOT OPERATE.

Aft Cargo Door - Component Index  
Figure 101


EFFECTIVITY

ALL

52-35-00

02

Page 101  
Nov 10/96



Aft Cargo Door - Component Location  
Figure 102 (Sheet 1)


EFFECTIVITY

ALL

52-35-00

01

Page 102  
Nov 10/95




Aft Cargo Door - Component Location  
Figure 102 (Sheet 2)

EFFECTIVITY
ALL


52-35-00






HINGE POWER UNIT, M631

(F)



LIFT/LATCH POWER UNIT, M632

(G)



VENT DOOR



(H)

Aft Cargo Door - Component Location (Details from Sht 2)  
Figure 102 (Sheet 3)

EFFECTIVITY	
	ALL

52-35-00

**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL



**NOTE:** ON 767-300 AIRPLANES, PROXIMITY SENSOR S159 IS NOT INSTALLED.


1 PROXIMITY SENSOR S159 HAS A STEEL TARGET PERMANENTLY INSTALLED AND DOES NOT OPERATE.

Aft Cargo Door - Component Location  
Figure 102 (Sheet 4)

EFFECTIVITY	ALL
-------------	-----


**52-35-00**

**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL



S158  
 (CARGO DOOR IN THE OPEN POSITION)

(J) FROM SHT 4



A-A

Aft Cargo Door - Component Location  
 Figure 102 (Sheet 5)



EFFECTIVITY	ALL
-------------	-----

52-35-00

01

Page 106  
 Nov 10/90

94269



Aft Cargo Door - Component Location (Detail from Sht 4)  
Figure 102 (Sheet 6)

EFFECTIVITY	
	ALL


52-35-00

CARGO DOOR WILL NOT UNLATCH ELECTRICALLY. MANUAL DRIVE UNLOCKS DOOR NORMAL. OTHER ELEC MODES NORMAL.

**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
34J4, 34J10

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
THE CARGO DOOR IS CLOSED AND LATCHED



Cargo Door Will Not Unlatch Electrically. Manual Drive Unlocks Door Normal.  
Other Elec Modes Normal  
Figure 103 (Sheet 1)


EFFECTIVITY

ALL

**52-35-00**

02

Page 108  
Dec 22/07



Cargo Door Will Not Unlatch Electrically. Manual Drive Unlocks Door Normal.  
 Other Elec Modes Normal  
 Figure 103 (Sheet 2)

EFFECTIVITY

ALL
-----


52-35-00

**CARGO DOOR WILL NOT  
 NOT UNLATCH  
 ELECTRICALLY OR WITH  
 MANUAL DRIVE.  
 OTHER MODES NORMAL**

**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
 34J4,34J10

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:  
 ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
 THE CARGO DOOR IS CLOSED



Cargo Door Will Not Unlatch Electrically or With Manual Drive.  
 Other Modes Normal  
 Figure 104

EFFECTIVITY	ALL
-------------	-----


**52-35-00**

CARGO DOOR WILL NOT LATCH CLOSED ELECTRICALLY. MANUAL DRIVE WILL LOCK DOOR CLOSED. OTHER ELEC MODES NORMAL

**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
34J4, 34J10

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)



**NOTE:** 767-300 AIRPLANES;  
PROXIMITY SENSOR, S159, IS NOT INSTALLED.

**1** PROXIMITY SENSOR, S159, HAS A STEEL TARGET PERMANENTLY INSTALLED AND ADJUSTMENT IS NOT NECESSARY.

Cargo Door Will Not Latch Closed Electrically. Manual Drive Will Lock Door Closed.  
Other Elec Modes Normal  
Figure 105 (Sheet 1)

EFFECTIVITY

ALL


**52-35-00**

02

Page 111  
Nov 10/96



FROM SHEET 1  
(BLOCK 3)




Cargo Door Will Not Latch Closed Electrically. Manual Drive Will Lock Door Closed. Other Elec Modes Normal  
Figure 105 (Sheet 2)

EFFECTIVITY

ALL
-----

52-35-00



Cargo Door Will Not Latch Closed Electrically. Manual Drive Will Lock  
 Door Closed. Other Elec Modes Normal  
 Figure 105 (Sheet 3)

EFFECTIVITY

ALL
-----

52-35-00

01


Page 113  
Apr 22/08

**CARGO DOOR WILL NOT LATCH CLOSED ELECTRICALLY OR MANUALLY**

**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
34J4,34J10

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)



Cargo Door Will Not Latch Closed Electrically or Manually  
Figure 106

EFFECTIVITY	ALL
-------------	-----

**52-35-00**


48094

**CARGO DOOR WILL NOT UNLATCH OR LATCH ELECTRICALLY. OTHER ELEC MODES NORMAL.**

**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
34J4, 34J10

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:  
ELECTRICAL POWER IS ON (AMM 24-22-00/401)



Cargo Door Will Not Unlatch or Latch Electrically. Other Elec Modes Normal.  
Figure 107 (Sheet 1)

EFFECTIVITY


ALL

**52-35-00**

02

Page 115  
Dec 22/07

FROM SHEET 1  
(BLOCK 3)



Cargo Door Will Not Unlatch or Latch Electrically. Other Elec Modes Normal  
Figure 107 (Sheet 2)

EFFECTIVITY

ALL

**52-35-00**

01

Page 116  
Apr 22/08

243597


CARGO DOOR WILL NOT RAISE ELECTRICALLY. MANUAL DRIVE WILL RAISE DOOR. OTHER ELEC MODES NORMAL.

**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
34J4, 34J10

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:

ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
THE CARGO DOOR IS CLOSED AND LATCHED




Cargo Door Will Not Raise Electrically. Manual Drive Will Raise Door.  
Other Elec Modes Normal.  
Figure 108 (Sheet 1)

EFFECTIVITY	
ALL	

**52-35-00**

FROM SHEET 1  
(BLOCK 3)



Cargo Door Will Not Raise Electrically. Manual Drive Will Raise Door.  
Other Elec Modes Normal.  
Figure 108 (Sheet 2)

EFFECTIVITY

ALL

**52-35-00**

01

Page 118  
Apr 22/08


256972

AFT CARGO DOOR WILL NOT RAISE OR LOWER ELECTRICALLY OR MANUALLY. OTHER ELEC MODES NORMAL

**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
34J4, 34J10

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)



Aft Cargo Door Will Not Raise or Lower Electrically or Manually.  
Other Elec Modes Normal  
Figure 109 (Sheet 1)

EFFECTIVITY

ALL


**52-35-00**

01


Page 119  
Apr 22/08



FROM SHEET 1  
(BLOCK 3)



Aft Cargo Door Will Not Raise or Lower Electrically or Manually.  
 Other Elec Modes Normal  
 Figure 109 (Sheet 2)




**52-35-00**

CARGO DOOR WILL NOT LOWER ELECTRICALLY.  
MANUAL DRIVE WILL LOWER DOOR. OTHER ELEC MODES NORMAL

**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
34J4, 34J10

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)




Cargo Door Will Not Lower Electrically. Manual Drive Will Lower Door.  
Other Elec Modes Normal  
Figure 110 (Sheet 1)

EFFECTIVITY	ALL
-------------	-----

**52-35-00**

FROM SHEET 1  
(BLOCK 3)



Cargo Door Will Not Lower Electrically. Manual Drive Will Lower Door.  
 Other Elec Modes Normal.  
 Figure 110 (Sheet 2)

EFFECTIVITY

ALL
-----


52-35-00

**CARGO DOOR  
ELECTRICAL  
OPERATION INOP**

**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
34J4, 34J10

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)



Cargo Door Electrical Operation Inop  
Figure 111

EFFECTIVITY

ALL

**52-35-00**

02

Page 123  
Dec 22/07


270861

**CARGO DOOR HAS ERRATIC MOVEMENT DURING RAISE MODE**

**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
34J4,34J10

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)



Cargo Door Has Erratic Movement during Raise Mode  
Figure 112

EFFECTIVITY

ALL
-----


**52-35-00**

**CARGO DOOR HAS  
ERRATIC MOVEMENT  
DURING LOWER MODE**


**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
34J4, 34J10

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)



Cargo Door has Erratic Movement during Lower Mode  
Figure 113




**52-35-00**

**AFT CARGO DOOR  
FAILS TO LATCH  
COMPLETELY**

**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
34J4,34J10

MAKE SURE THE AIRPLANE IS IN THE CONFIGURATION THAT FOLLOWS:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)



Aft Cargo Door Fails to Latch Completely  
Figure 114

EFFECTIVITY	ALL
-------------	-----

**52-35-00**


**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

BULK CARGO DOOR

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
ARM - HINGE	--	2	811, AFT CARGO COMPARTMENT	52-36-04
DOOR - BULK CARGO	--	1	811, AFT CARGO COMPARTMENT	52-36-01
MECHANISM - BALANCE	--	1	811, AFT CARGO COMPARTMENT	52-36-02
MECHANISM - DOOR LATCHING	--	1	811, AFT CARGO COMPARTMENT	52-36-00
PROTECTOR - BULK CARGO DOOR <span style="border: 1px solid black; padding: 0 2px;">1</span>	--	1	811, AFT CARGO COMPARTMENT	52-36-10
SENSOR - (AMM 52-71-00/101) PROX, BULK CARGO DOOR LATCHED, S211	--	1	811, AFT CARGO COMPARTMENT	52-36-03
SNUBBER	--	1	811, AFT CARGO COMPARTMENT	52-36-03

1 AIRPLANES WITH BULK CARGO DOOR PROTECTOR

Bulk Cargo Door - Component Index  
Figure 101




52-36-00

04

Page 101  
Aug 10/94

E41410






Bulk Cargo Door - Component Index  
Figure 102

EFFECTIVITY	
	ALL


52-36-00

**BULK CARGO DOOR  
WILL UNLATCH, BUT  
NOT OPEN**

PREREQUISITES  
NONE




Bulk Cargo Door will Unlatch, but Not Open  
Figure 103




52-36-00

BULK CARGO DOOR  
REQUIRES HIGH  
HANDLE FORCES WHEN  
LATCHING DOOR

PREREQUISITES  
 NONE



Bulk Cargo Door Requires High Handle Forces When Latching Door  
Figure 104



52-36-00

EFFECTIVITY  
SAS 050, 051, 156, 162-167  
PRE-SB 25-325; 154 PRE-SB 25-332

**52-51-00**  
CONFIG 1  
Page 101  
Dec 22/05

24F


**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

FLIGHT COMPARTMENT DOOR

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
CIRCUIT BREAKER - FLIGHT DECK DOOR LOCK, C1400	1	1	FLIGHT COMPARTMENT, P11 11T5	*
DOOR - FLIGHT COMPARTMENT	1	1	FLIGHT COMPARTMENT	52-51-01
DOOR LOCK UNIT - FLIGHT COMPARTMENT, M635	1	1	FLIGHT COMPARTMENT DOORJAMB	52-51-01
PANEL - (FIM 33-11-00/101)				
RIGHT OVERHEAD LIGHTING CONTROL, M10057				
RELAY - (FIM 33-22-00/101)				
DIRECT LIGHTS CONTROL, K358				
DOOR LOCK POWER SENSING, K642				
SWITCH - (FIM 33-22-00/101)				
FLIGHT DECK DOOR, S460				
SWITCH - FLIGHT DECK DOOR LOCK/UNLOCK, YCXS1	2	1	FLIGHT COMPARTMENT, P5, RIGHT OVERHEAD LIGHTING CONTROL PANEL, M10057	*


\* SEE THE WDM EQUIPMENT LIST

Flight Compartment Door - Component Index  
Figure 101


EFFECTIVITY  
 SAS 050, 051, 156, 162-167  
 PRE-SB 25-325; 154 PRE-SB 25-332

**52-51-00**  
 CONFIG 1  
 Page 102  
 Dec 22/05

24F



FLIGHT COMPARTMENT  
(VIEW IN THE FORWARD DIRECTION)



FLIGHT COMPARTMENT  
DOOR LOCK UNIT, M635

A

Flight Compartment Door - Component Location  
Figure 102 (Sheet 1)

EFFECTIVITY  
SAS 050, 051, 156, 162-167  
PRE-SB 25-325; 154 PRE-SB 25-332

52-51-00


CONFIG 1

24F


Page 103

Dec 22/05


**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL



**FLIGHT COMPARTMENT**



**RIGHT OVERHEAD LIGHTING CONTROL PANEL, M10057**

(B)

Flight Compartment Door - Component Location  
Figure 102 (Sheet 2)

EFFECTIVITY  
SAS 050, 051, 156, 162-167  
PRE-SB 25-325; 154 PRE-SB 25-332

**52-51-00**  
 CONFIG 1  
 Page 104  
 Dec 22/05


24F

**FLIGHT DECK DOOR  
WILL NOT RELEASE  
ELECTRICALLY**

**PREREQUISITES**

MAKE SURE THIS CIRCUIT BREAKER IS CLOSED:  
11T5

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)



Flight Deck Door Will Not Release Electrically  
Figure 103

EFFECTIVITY

SAS 050, 051, 156, 162-167 PRE-SB 25-325; 154 PRE-SB 25-332
--

**52-51-00**  
 CONFIG 1  
 Page 105  
 Dec 22/05

24F




**COCKPIT DOOR "UNLKD"  
LGT FAILS TO EXTIN  
WITH DOOR LOCKED**

**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
6L3, 11T5, 33L5

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)



Cockpit Door UNLKD Lgt Fails to Extin with Door Locked  
Figure 104

EFFECTIVITY  
SAS 050, 051, 156, 162-167  
PRE-SB 25-325; 154 PRE-SB 25-332

**52-51-00**  
CONFIG 1  
Page 106  
Dec 22/05


**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

FLIGHT COMPARTMENT DOOR


COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
CHIME MODULE, M12093	1	1	FLIGHT COMPARTMENT DOORJAMB	52-51-10
CIRCUIT BREAKER -				
FLT DECK DR LOCK, C01400		1	FLIGHT COMPARTMENT, P11 11T5	*
DIRECT LIGHTS CONTROL RELAY, K359		1	FLIGHT COMPARTMENT, P19	
DOOR - FLIGHT COMPARTMENT	1, 3	1	FLIGHT COMPARTMENT	52-51-05
DOOR LOCK POWER SENSING RELAY, K642		1	FLIGHT COMPARTMENT, P19	
DOOR LOCK UNIT - FLIGHT COMPARTMENT, M10295	2	1	FLIGHT COMPARTMENT DOORJAMB	52-51-07
KEYPAD, M10294	3	1	FLIGHT COMPARTMENT DOORJAMB	52-51-09
PANEL - RIGHT OVERHEAD LIGHTING CONTROL, M10057	4	1	FLIGHT COMPARTMENT	
PRESSURE SENSOR, M12096	1	1	FLIGHT COMPARTMENT DOORJAMB	52-51-11
SWITCH - FLIGHT DECK DOOR, S1	4	1	FLIGHT COMPARTMENT	*

\* SEE THE WDM EQUIPMENT LIST

Flight Compartment Door - Component Index  
Figure 101

EFFECTIVITY  
 SAS 155-157, 276-278, 280; 050, 051,  
 156, 162-167 POST-SB 25-325

**52-51-00**  
 CONFIG 2  
 Page 101  
 Dec 22/05




FLIGHT COMPARTMENT DOOR

Flight Compartment Door - Component Location  
Figure 102 (Sheet 1)

EFFECTIVITY  
 SAS 155-157, 276-278, 280; 050, 051,  
 156, 162-167 POST-SB 25-325

**52-51-00**  
 CONFIG 2  
 Page 102  
 Dec 22/05



FLIGHT COMPARTMENT  
ELECTRIC STRIKE, M10295

(A)


Flight Compartment Door - Component Location  
Figure 102 (Sheet 2)

EFFECTIVITY  
SAS 155-157, 276-278, 280; 050, 051,  
156, 162-167 POST-SB 25-325

**52-51-00**

CONFIG 2  
Page 103  
Dec 22/05

19F



FLIGHT COMPARTMENT DOOR


Flight Compartment Door - Component Location  
Figure 102 (Sheet 3)

EFFECTIVITY  
SAS 155-157, 276-278, 280; 050, 051,  
156, 162-167 POST-SB 25-325


**52-51-00**  
CONFIG 2  
Page 104  
Dec 22/05

19F


**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL



**FLIGHT COMPARTMENT**



**RIGHT OVERHEAD LIGHTING CONTROL PANEL, M10057**  
 (B)

**Flight Compartment Door - Component Location**  
**Figure 102 (Sheet 4)**

EFFECTIVITY  
 SAS 155-157, 276-278, 280; 050, 051,  
 156, 162-167 POST-SB 25-325

**52-51-00**  
 CONFIG 2  
 Page 105  
 Dec 22/05

**DOOR DOES NOT LOCK  
IN THE "AUTO" MODE**



**DESCRIPTION:**

THE DOOR LOCK UNIT, M10295 IS DEFECTIVE OR NOT GETTING VOLTAGE OR GROUND.

**POSSIBLE CAUSES:**

1. MODULE-CHIME, M12093
2. FLIGHT DECK DOOR LOCK UNIT, M10295
3. PRESSURE SENSOR, M12096
4. AIRCRAFT WIRING.

**FAULT ISOLATION:**



**PREREQUISITES**


MAKE SURE THIS CIRCUIT BREAKER IS CLOSED:  
11T5

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
FLIGHT DECK DOOR IS CLOSED  
POWER SWITCH ON THE MODULE-CHIME, M12093 IS IN THE "ON" POSITION  
DEADBOLT ON THE FLIGHT DECK DOOR IS UNLOCKED

Door Does Not Lock in the "AUTO" Mode  
Figure 103 (Sheet 1)

EFFECTIVITY  
SAS 155-157, 276-278, 280; 050, 051,  
156, 162-167 POST-SB 25-325

**52-51-00**  
CONFIG 2  
Page 106  
Dec 22/05



Door Does Not Lock in the "AUTO" Mode  
Figure 103 (Sheet 2)

EFFECTIVITY  
SAS 155-157, 276-278, 280; 050, 051,  
156, 162-167 POST-SB 25-325

**52-51-00**  
 CONFIG 2  
 Page 107  
 Dec 22/05



DOOR DOES NOT  
UNLOCK IN  
"UNLOCK" MODE



**PREREQUISITES**

MAKE SURE THIS CIRCUIT BREAKER IS CLOSED:  
11T5

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
FLIGHT DECK DOOR IS CLOSED  
DEADBOLT ON THE FLIGHT DECK DOOR IS UNLOCKED


**DESCRIPTION:**

THE FLIGHT DECK DOOR LOCK UNIT, M12093, CIRCUIT TO GROUND WILL NOT OPEN.

**POSSIBLE CAUSES:**

1. MODULE-CHIME, M12093
2. RIGHT OVHD PANEL ASSY LIGHTING CONTROL UNIT, M10057
3. WIRING PROBLEM BETWEEN THE MODULE-CHIME, M12093 AND STRUCTURE GROUND (WDM 52-51-11).

**FAULT ISOLATION:**



Door Does Not UnLock in the "UNLOCK" Mode  
Figure 104

EFFECTIVITY  
SAS 155-157, 276-278, 280; 050, 051,  
156, 162-167 POST-SB 25-325

**52-51-00**  
CONFIG 2  
Page 108  
Dec 22/05

DOOR DOES NOT UNLOCK  
IN "AUTO" MODE AFTER  
A CORRECT CODE HAS  
BEEN ENTERED ON THE  
KEYPAD



**PREREQUISITES**

MAKE SURE THIS CIRCUIT BREAKER IS CLOSED:  
11T5

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
FLIGHT DECK DOOR IS CLOSED  
DEADBOLT ON THE FLIGHT DECK DOOR IS UNLOCKED


**DESCRIPTION:**

THE FLIGHT DECK DOOR LOCK UNIT, M12093, CIRCUIT TO GROUND WILL NOT OPEN.

**POSSIBLE CAUSES:**

1. MODULE-CHIME, M12093
2. KEYPAD, M10294
3. WIRING PROBLEM BETWEEN THE MODULE-CHIME, M12093 AND STRUCTURE GROUND (WDM 52-51-11).

**FAULT ISOLATION:**



Door Does Not Unlock in "AUTO" Mode After a Correct Code Has  
Been Entered On the Keypad  
Figure 105

EFFECTIVITY  
SAS 155-157, 276-278, 280; 050, 051,  
156, 162-167 POST-SB 25-325

**52-51-00**  
CONFIG 2  
Page 109  
Dec 22/05

DOOR UNLOCKS OR  
CHIMES SOUND IN THE  
"DENY" MODE



**PREREQUISITES**

MAKE SURE THIS CIRCUIT BREAKER IS CLOSED:  
11T5

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
FLIGHT DECK DOOR IS CLOSED  
POWER SWITCH ON THE MODULE-CHIME, M12093 IS IN  
THE "ON" POSITION


**DESCRIPTION:**

THE MODULE-CHIME, M12093 IS DEFECTIVE OR NOT RECEIVING THE CORRECT GROUND SIGNAL.

**POSSIBLE CAUSES:**

1. RIGHT OVHD PANEL ASSY LIGHTING CONTROL UNIT, M10057
2. MODULE-CHIME, M12093
3. WIRING PROBLEM BETWEEN THE MODULE-CHIME, M12093 AND STRUCTURE GROUND (WDM 52-51-11).

**FAULT ISOLATION:**



Door Unlocks or Chimes Sound in the "DENY" Mode  
Figure 106

EFFECTIVITY  
SAS 155-157, 276-278, 280; 050, 051,  
156, 162-167 POST-SB 25-325

**52-51-00**  
CONFIG 2  
Page 110  
Dec 22/05

CHIME DOES NOT SOUND  
WHEN A CORRECT CODE  
IS ENTERED ON THE  
KEYPAD IN "AUTO"  
MODE




**DESCRIPTION:**

THE MODULE-CHIME, M12093 IS DEFECTIVE OR THE SYSTEM IS IN DENY MODE.

**POSSIBLE CAUSES:**

1. MODULE-CHIME, M12093

**FAULT ISOLATION:**



**PREREQUISITES**

MAKE SURE THIS CIRCUIT BREAKER IS CLOSED:  
11T5

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
FLIGHT DECK DOOR IS CLOSED  
POWER SWITCH ON THE MODULE-CHIME, M12093 IS IN THE "ON" POSITION

**NOTE:** THE CHIME AND KEYPAD CAN BE DISABLED FOR UP TO 30 MINUTES AFTER THE DOOR LOCK SWITCH IS TURNED TO THE "DENY" POSITION. THE DENY MODE CAN BE ENDED BY TURNING THE DOOR LOCK SWITCH TO THE "UNLOCK" POSITION.

Chime Does Not Sound When a Correct Code is Entered on the Keypad in "AUTO" Mode  
Figure 107

EFFECTIVITY  
SAS 155-157, 276-278, 280; 050, 051,  
156, 162-167 POST-SB 25-325

**52-51-00**  
CONFIG 2  
Page 111  
Dec 22/05

**FLIGHT DECK DOOR  
 "LOCK FAIL" LIGHT  
 IS ON**



**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
11T5

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
FLIGHT DECK DOOR IS CLOSED  
DEADBOLT ON THE FLIGHTDECK DOOR IS UNLOCKED


**DESCRIPTION:**

THE DOOR LOCK SOLENOID IS COMMANDED TO THE LOCKED POSITION BUT IS NOT IN THE LOCKED POSITION. THE MODULE-CHIME SENSES A CONDITION WHERE POWER IS APPLIED TO THE FLIGHT DECK DOOR LOCK UNIT, M100295 BUT ELECTRICAL CONTACTS IN THE UNIT ARE NOT CLOSED.

**POSSIBLE CAUSES:**

1. THE FLIGHT DECK DOOR LOCK UNIT, M100295, IS JAMMED OR DEFECTIVE
2. RIGHT OVHD PANEL ASSY LIGHTING CONTROL UNIT, M10057
3. WIRING PROBLEM BETWEEN THE MODULE-CHIME, M12093 AND STRUCTURE GROUND (WDM 52-51-11).

**FAULT ISOLATION:**



Flight Deck Door "LOCK FAIL" Light is on  
Figure 108

EFFECTIVITY  
SAS 155-157, 276-278, 280; 050, 051,  
156, 162-167 POST-SB 25-325

**52-51-00**  
 CONFIG 2  
 Page 112  
 Dec 22/05

FLIGHT DECK DOOR  
"AUTO UNLK" LIGHT  
DOES NOT COME ON  
AFTER A CORRECT  
ACCESS CODE HAS  
BEEN ENTERED




**DESCRIPTION:**

THE "AUTO UNLK" LIGHT IS COMMANDED TO COME ON FROM THE MODULE-CHIME, M12093 WHEN A CORRECT ACCESS CODE IS ENTERED ON THE KEYPAD.

**POSSIBLE CAUSES:**

1. DEFECTIVE LIGHT BULB
2. MODULE-CHIME, M12093
3. WIRING PROBLEM BETWEEN THE MODULE-CHIME, M12093 AND "AUTO UNLK" LIGHT

**FAULT ISOLATION:**



Flight Deck Door "AUTO UNLK" Light Does Not Come On  
After a Correct Pass Code Has Been Entered  
Figure 109

EFFECTIVITY  
SAS 155-157, 276-278, 280; 050, 051,  
156, 162-167 POST-SB 25-325

**52-51-00**  
CONFIG 2  
Page 113  
Dec 22/05

**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

FLIGHT COMPARTMENT DOOR

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
CHIME MODULE, M12093	1	1	FLIGHT COMPARTMENT DOORJAMB	52-51-10
CIRCUIT BREAKER -				
FLT DECK DR LOCK, C01400		1	FLIGHT COMPARTMENT, P11 11T5	*
DIRECT LIGHTS CONTROL RELAY, K359		1	FLIGHT COMPARTMENT, P19	
DOOR - FLIGHT COMPARTMENT	1, 3	1	FLIGHT COMPARTMENT	52-51-05
DOOR LOCK POWER SENSING RELAY, K642		1	FLIGHT COMPARTMENT, P19	
DOOR LOCK UNIT - FLIGHT COMPARTMENT, M10295	2	1	FLIGHT COMPARTMENT DOORJAMB	52-51-07
KEYPAD, M10294	3	1	FLIGHT COMPARTMENT DOORJAMB	52-51-09
PANEL - RIGHT OVERHEAD LIGHTING CONTROL, M10057	4	1	FLIGHT COMPARTMENT	
PRESSURE SENSOR, M12096	1	1	FLIGHT COMPARTMENT DOORJAMB	52-51-11
SWITCH - FLIGHT DECK DOOR, S1	4	1	FLIGHT COMPARTMENT	*


\* SEE THE WDM EQUIPMENT LIST

Flight Compartment Door - Component Index  
Figure 101

EFFECTIVITY  
SAS 150-153, 275; 154 POST-SB 25-332

**52-51-00**  
CONFIG 4  
Page 101  
Dec 22/05

27F



FLIGHT COMPARTMENT DOOR

Flight Compartment Door - Component Location  
Figure 102 (Sheet 1)

EFFECTIVITY  
SAS 150-153, 275; 154 POST-SB 25-332

**52-51-00**


CONFIG 4

Page 102

Dec 22/05

27F





FLIGHT COMPARTMENT  
ELECTRIC STRIKE, M10295

(A)

Flight Compartment Door - Component Location  
Figure 102 (Sheet 2)

EFFECTIVITY  
SAS 150-153, 275; 154 POST-SB 25-332

**52-51-00**


CONFIG 4

27F

Page 103

Dec 22/05

382942



FLIGHT COMPARTMENT DOOR

KEYPAD, M10294


Flight Compartment Door - Component Location  
Figure 102 (Sheet 3)

EFFECTIVITY  
SAS 150-153, 275; 154 POST-SB 25-332


**52-51-00**  
CONFIG 4  
Page 104  
Dec 22/05

27F


**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL



**FLIGHT COMPARTMENT**



**RIGHT OVERHEAD LIGHTING CONTROL PANEL, M10057**

(C)

Flight Compartment Door - Component Location  
Figure 102 (Sheet 4)

EFFECTIVITY  
SAS 150-153, 275; 154 POST-SB 25-332

**52-51-00**

CONFIG 4  
Page 105  
Dec 22/05

27F

**DOOR DOES NOT LOCK  
IN THE "AUTO" MODE**



**DESCRIPTION:**

THE DOOR LOCK UNIT, M10295 IS DEFECTIVE OR NOT GETTING VOLTAGE OR GROUND.

**POSSIBLE CAUSES:**

1. MODULE-CHIME, M12093
2. FLIGHT DECK DOOR LOCK UNIT, M10295
3. PRESSURE SENSOR, M12096
4. AIRCRAFT WIRING.

**FAULT ISOLATION:**



**PREREQUISITES**

MAKE SURE THIS CIRCUIT BREAKER IS CLOSED:  
11T5

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
FLIGHT DECK DOOR IS CLOSED  
POWER SWITCH ON THE MODULE-CHIME, M12093 IS IN THE "ON" POSITION  
DEADBOLT ON THE FLIGHT DECK DOOR IS UNLOCKED


Door Does Not Lock in the "AUTO" Mode  
Figure 103 (Sheet 1)

EFFECTIVITY  
SAS 150-153, 275; 154 POST-SB 25-332

**52-51-00**  
CONFIG 4  
Page 106  
Dec 22/05

27F

 **BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL



Door Does Not Lock in the "AUTO" Mode  
Figure 103 (Sheet 2)

EFFECTIVITY  
SAS 150-153, 275; 154 POST-SB 25-332

**52-51-00**  
CONFIG 4  
Page 107  
Dec 22/05

27F

DOOR DOES NOT  
UNLOCK IN  
"UNLOCK" MODE



**PREREQUISITES**

MAKE SURE THIS CIRCUIT BREAKER IS CLOSED:  
11T5

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
FLIGHT DECK DOOR IS CLOSED  
DEADBOLT ON THE FLIGHT DECK DOOR IS UNLOCKED


**DESCRIPTION:**

THE FLIGHT DECK DOOR LOCK UNIT, M12093, CIRCUIT TO GROUND WILL NOT OPEN.

**POSSIBLE CAUSES:**

1. MODULE-CHIME, M12093
2. RIGHT OVHD PANEL ASSY LIGHTING CONTROL UNIT, M10057
3. WIRING PROBLEM BETWEEN THE MODULE-CHIME, M12093 AND STRUCTURE GROUND (WDM 52-51-11).

**FAULT ISOLATION:**



Door Does Not UnLock in the "UNLOCK" Mode  
Figure 104

EFFECTIVITY  
SAS 150-153, 275; 154 POST-SB 25-332

**52-51-00**  
CONFIG 4  
Page 108  
Dec 22/05

27F

DOOR DOES NOT UNLOCK  
IN "AUTO" MODE AFTER  
A CORRECT CODE HAS  
BEEN ENTERED ON THE  
KEYPAD



**PREREQUISITES**

MAKE SURE THIS CIRCUIT BREAKER IS CLOSED:  
11T5

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
FLIGHT DECK DOOR IS CLOSED  
DEADBOLT ON THE FLIGHT DECK DOOR IS UNLOCKED


**DESCRIPTION:**

THE FLIGHT DECK DOOR LOCK UNIT, M12093, CIRCUIT TO GROUND WILL NOT OPEN.

**POSSIBLE CAUSES:**

1. MODULE-CHIME, M12093
2. KEYPAD, M10294
3. WIRING PROBLEM BETWEEN THE MODULE-CHIME, M12093 AND STRUCTURE GROUND (WDM 52-51-11).

**FAULT ISOLATION:**



Door Does Not Unlock in "AUTO" Mode After a Correct Code Has  
Been Entered On the Keypad  
Figure 105

EFFECTIVITY  
SAS 150-153, 275; 154 POST-SB 25-332

**52-51-00**  
CONFIG 4  
Page 109  
Dec 22/05

27F

DOOR UNLOCKS OR  
CHIMES SOUND IN THE  
"DENY" MODE



**PREREQUISITES**

MAKE SURE THIS CIRCUIT BREAKER IS CLOSED:  
11T5

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
FLIGHT DECK DOOR IS CLOSED  
POWER SWITCH ON THE MODULE-CHIME, M12093 IS IN  
THE "ON" POSITION


**DESCRIPTION:**

THE MODULE-CHIME, M12093 IS DEFECTIVE OR NOT RECEIVING THE CORRECT GROUND SIGNAL.

**POSSIBLE CAUSES:**

1. RIGHT OVHD PANEL ASSY LIGHTING CONTROL UNIT, M10057
2. MODULE-CHIME, M12093
3. WIRING PROBLEM BETWEEN THE MODULE-CHIME, M12093 AND STRUCTURE GROUND (WDM 52-51-11).

**FAULT ISOLATION:**



Door Unlocks or Chimes Sound in the "DENY" Mode  
Figure 106

EFFECTIVITY  
SAS 150-153, 275; 154 POST-SB 25-332

**52-51-00**  
CONFIG 4  
Page 110  
Dec 22/05

27F



CHIME DOES NOT SOUND  
WHEN A CORRECT CODE  
IS ENTERED ON THE  
KEYPAD IN "AUTO"  
MODE




**DESCRIPTION:**

THE MODULE-CHIME, M12093 IS DEFECTIVE OR THE SYSTEM IS IN DENY MODE.

**POSSIBLE CAUSES:**

1. MODULE-CHIME, M12093

**FAULT ISOLATION:**



**PREREQUISITES**

MAKE SURE THIS CIRCUIT BREAKER IS CLOSED:  
11T5

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
FLIGHT DECK DOOR IS CLOSED  
POWER SWITCH ON THE MODULE-CHIME, M12093 IS IN THE "ON" POSITION

**NOTE:** THE CHIME AND KEYPAD CAN BE DISABLED FOR UP TO 30 MINUTES AFTER THE DOOR LOCK SWITCH IS TURNED TO THE "DENY" POSITION. THE DENY MODE CAN BE ENDED BY TURNING THE DOOR LOCK SWITCH TO THE "UNLOCK" POSITION.

Chime Does Not Sound When a Correct Code is Entered on the Keypad in "AUTO" Mode  
Figure 107

EFFECTIVITY  
SAS 150-153, 275; 154 POST-SB 25-332

**52-51-00**  
CONFIG 4  
Page 111  
Dec 22/05

27F

**FLIGHT DECK DOOR  
"LOCK FAIL" LIGHT  
IS ON**



**PREREQUISITES**

MAKE SURE THESE CIRCUIT BREAKERS ARE CLOSED:  
11T5

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)  
FLIGHT DECK DOOR IS CLOSED  
DEADBOLT ON THE FLIGHTDECK DOOR IS UNLOCKED


**DESCRIPTION:**

THE DOOR LOCK SOLENOID IS COMMANDED TO THE LOCKED POSITION BUT IS NOT IN THE LOCKED POSITION. THE MODULE-CHIME SENSES A CONDITION WHERE POWER IS APPLIED TO THE FLIGHT DECK DOOR LOCK UNIT, M100295 BUT ELECTRICAL CONTACTS IN THE UNIT ARE NOT CLOSED.

**POSSIBLE CAUSES:**

1. THE FLIGHT DECK DOOR LOCK UNIT, M100295, IS JAMMED OR DEFECTIVE
2. RIGHT OVHD PANEL ASSY LIGHTING CONTROL UNIT, M10057
3. WIRING PROBLEM BETWEEN THE MODULE-CHIME, M12093 AND STRUCTURE GROUND (WDM 52-51-11).

**FAULT ISOLATION:**



Flight Deck Door "LOCK FAIL" Light is on  
Figure 108

EFFECTIVITY  
SAS 150-153, 275; 154 POST-SB 25-332

**52-51-00**  
CONFIG 4  
Page 112  
Dec 22/05

27F

FLIGHT DECK DOOR  
"AUTO UNLK" LIGHT  
DOES NOT COME ON  
AFTER A CORRECT  
ACCESS CODE HAS  
BEEN ENTERED




**DESCRIPTION:**

THE "AUTO UNLK" LIGHT IS COMMANDED TO COME ON FROM THE MODULE-CHIME, M12093 WHEN A CORRECT ACCESS CODE IS ENTERED ON THE KEYPAD.

**POSSIBLE CAUSES:**

1. DEFECTIVE LIGHT BULB
2. MODULE-CHIME, M12093
3. WIRING PROBLEM BETWEEN THE MODULE-CHIME, M12093 AND "AUTO UNLK" LIGHT

**FAULT ISOLATION:**



Flight Deck Door "AUTO UNLK" Light Does Not Come On  
After a Correct Pass Code Has Been Entered  
Figure 109

EFFECTIVITY  
SAS 150-153, 275; 154 POST-SB 25-332

**52-51-00**  
CONFIG 4  
Page 113  
Dec 22/05

**BOEING**  
767  
FAULT ISOLATION/MAINT MANUAL

DOOR WARNING SYSTEM

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	REFERENCE
CIRCUIT BREAKER - DOOR IND, C1406		1	FLIGHT COMPARTMENT, P11, 11T33	
COMPUTERS - (31-41-00/101)				
LEFT EICAS, M10181				
RIGHT EICAS, M10182				
LIGHT - ACCESS DOORS INDICATOR, YDLL4			FLIGHT COMPARTMENT, P5, M10394	*
LIGHT - CARGO DOORS INDICATOR, YDLL3			FLIGHT COMPARTMENT, P5, M10394	*
LIGHT - EMER DOORS INDICATOR, YDLL2			FLIGHT COMPARTMENT, P5, M10394	*
LIGHT - ENTRY DOORS INDICATOR, YDLL1			FLIGHT COMPARTMENT, P5, M10394	*
PANEL - (30-31-00/101)				
ANNUNCIATOR, M10394				
PROXIMITY SWITCH ELECTRONICS UNIT, M162 (32-09-00/101)				
SENSORS - ACCESS DOORS				
ELECTRONICS ACCESS DOOR CLOSED, S201	4	1	119AL, DOOR FORWARD FRAME	52-71-01
FORWARD ACCESS DOOR CLOSED, S200	3	1	113AL, DOOR FORWARD FRAME	52-71-01
SENSORS - CARGO DOORS				
AFT CARGO DOOR CLOSED, S209	7	1	822, FLOOR BEAM ADJACENT TO HINGE ARM	52-71-01
AFT CARGO DOOR LOCKED, S208	7	1	822, DOOR FORWARD FRAME	52-71-01
BULK CARGO DOOR LATCHED, S211	5	1	811, DOOR AFT FRAME	52-71-01
FORWARD CARGO DOOR CLOSED, S215	6	1	821, DOOR LOWER EDGE	52-71-01
FORWARD CARGO DOOR LOCKED, S214	6	1	821, DOOR LOWER FRAME	52-71-01
SENSORS - ENTRY/SERVICE DOORS				
AFT ENTRY DOOR CLOSED, S204	2	1	833, UPPER DOOR FRAME	52-71-01
AFT ENTRY DOOR LOCKED, S205	2	1	833, UPPER DOOR FRAME	52-71-01
AFT ENTRY GIRT BAR ACTIVATE, S212	2	1	833, DOOR AFT FRAME	52-71-01
AFT SERVICE DOOR CLOSED, S206	2	1	843, UPPER DOOR FRAME	52-71-01
AFT SERVICE DOOR LOCKED, S207	2	1	843, UPPER DOOR FRAME	52-71-01
AFT SERVICE GIRT BAR ACTIVATE, S213	2	1	843, DOOR AFT FRAME	52-71-01
FORWARD ENTRY DOOR CLOSED, S194	2	1	831, UPPER DOOR FRAME	52-71-01
FORWARD ENTRY DOOR LOCKED, S195	2	1	831, UPPER DOOR FRAME	52-71-01
FORWARD ENTRY GIRT BAR ACTIVATE, S202	2	1	831, DOOR AFT FRAME	52-71-01
FORWARD SERVICE DOOR CLOSED, S196	2	1	841, UPPER DOOR FRAME	52-71-01
FORWARD SERVICE DOOR LOCKED, S197	2	1	841, UPPER DOOR FRAME	52-71-01
FORWARD SERVICE GIRT BAR ACTIVATE, S203	2	1	841, DOOR AFT FRAME	52-71-01

\* SEE THE WDM EQUIPMENT LIST

Door Warning System - Component Index  
Figure 101 (Sheet 1)

EFFECTIVITY

ALL







**52-71-00**



08

Page 101  
May 10/96


294915


**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL

COMPONENT	FIG. 102 SHT	QTY	ACCESS/AREA	AMM REFERENCE
<b>SENSOR - OFF-WING ESCAPE SYSTEM</b>				
AFT/LEFT OVERWING EMERGENCY EXIT HATCH CLOSED, S216 	8	1	834, HATCH FORWARD FRAME	52-71-01
AFT/RIGHT OVERWING EMERGENCY EXIT HATCH CLOSED, S217 	8	1	844, HATCH FORWARD FRAME	52-71-01
FORWARD/LEFT OVERWING EMERGENCY EXIT HATCH CLOSED, S192 	8	1	832, HATCH FORWARD FRAME	52-71-01
FORWARD/RIGHT OVERWING EMERGENCY EXIT HATCH CLOSED, S193 	8	1	842, HATCH FORWARD FRAME	52-71-01
LEFT OVERWING EMERGENCY EXIT HATCH CLOSED, S192 	8	1	832, HATCH FORWARD FRAME	52-71-01
LEFT SLIDE COMPARTMENT DOOR CLOSED, S218	9	1	195EL, DOOR UPPER FRAME	52-71-01
LEFT SLIDE COMPARTMENT DOOR LOCKED, S198	10	1	195EL, DOOR UPPER FRAME	52-71-01
RIGHT OVERWING EMERGENCY EXIT HATCH CLOSED, S193 	8	1	842, HATCH FORWARD FRAME	52-71-01
RIGHT SLIDE COMPARTMENT DOOR CLOSED, S219	9	1	195ER, DOOR UPPER FRAME	52-71-01
RIGHT SLIDE COMPARTMENT DOOR LOCKED, S199	10	1	195ER, DOOR UPPER FRAME	52-71-01


-  AIRPLANES WITH TWO HATCHES OVER EACH WING
-  AIRPLANES WITH ONE HATCH OVER EACH WING

Door Warning System - Component Index  
Figure 101 (Sheet 2)




52-71-00


**BOEING**  
 767  
 FAULT ISOLATION/MAINT MANUAL




FLIGHT COMPARTMENT



ANNUNCIATOR PANEL, M10394

(A)

Door Warning System - Component Location  
 Figure 102 (Sheet 1)




94352


52-71-00

02

Page 103  
Nov 10/95




- ENTRY/SERVICE DOOR LOCKED SENSOR:
- FORWARD ENTRY, S195
  - AFT ENTRY, S205
  - FORWARD SERVICE, S197
  - AFT SERVICE, S207



Door Warning System - Component Location  
Figure 102 (Sheet 2)

EFFECTIVITY	ALL
-------------	-----

52-71-00



Door Warning System - Component Location  
Figure 102 (Sheet 3)

EFFECTIVITY	
	ALL


52-71-00

02

Page 105  
Aug 22/01

221586






Door Warning System - Component Location  
Figure 102 (Sheet 4)

EFFECTIVITY	ALL
-------------	-----



52-71-00



Door Warning System - Component Location  
Figure 102 (Sheet 5)

EFFECTIVITY	ALL
-------------	-----

52-71-00




FORWARD CARGO DOOR CLOSED SENSOR, S215  
SEE (H)

FORWARD CARGO DOOR LOCKED SENSOR, S214  
SEE (G)


LARGE FORWARD CARGO DOOR (OPEN POSITION, INTERNAL VIEW)

(F)



FORWARD CARGO DOOR LOCKED SENSOR, S214

(G)



FORWARD CARGO DOOR CLOSED SENSOR, S215

(H)

Door Warning System - Component Location  
Figure 102 (Sheet 6)


EFFECTIVITY

ALL

52-71-00

03

Page 108  
Aug 22/01





Door Warning System - Component Location  
Figure 102 (Sheet 7)

EFFECTIVITY	
	ALL

52-71-00

03

Page 109  
Aug 22/01





- 1 AIRPLANES WITH ONE HATCH OVER EACH WING
- 2 AIRPLANES WITH TWO HATCHES OVER EACH WING

Door Warning System - Component Location  
Figure 102 (Sheet 8)

EFFECTIVITY	ALL
-------------	-----


52-71-00



Door Warning System - Component Location  
Figure 102 (Sheet 9)


EFFECTIVITY	ALL
-------------	-----

52-71-00



SLIDE COMPARTMENT DOOR

(N)



Door Warning System - Component Location  
Figure 102 (Sheet 10)

EFFECTIVITY	ALL
-------------	-----


52-71-00

"ENTRY DOORS" LGT ILLUM. "EICAS" MSG ("L FWD ENT DOOR", "L AFT ENT DOOR", "R FWD ENT DOOR", "R AFT ENT DOOR") DISPLAYED. LOCK PIN IS ENGAGED.

**PREREQUISITES**

MAKE SURE THIS CIRCUIT BREAKER IS CLOSED:  
11T33

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)



ENTRY DOORS Lgt Illum. EICAS Msg (L FWD ENT DOOR, L AFT ENT DOOR, R FWD ENT DOOR, R AFT ENT DOOR) Displayed. Lock Pin is Engaged  
Figure 103


EFFECTIVITY	ALL
-------------	-----

**52-71-00**



CARGO DOORS LIGHT  
ILLUM. EICAS  
MESSAGE "FWD CARGO  
DOOR" DISPLAYED

**PREREQUISITES**  
MAKE SURE THIS CIRCUIT BREAKER IS CLOSED:  
11T33  
MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)



Cargo Doors Light Illum. EICAS Message FWD CARGO DOOR Displayed  
Figure 104

EFFECTIVITY	ALL
-------------	-----


52-71-00

846749

CARGO DOORS LIGHT  
ILLUM. EICAS  
MESSAGE "AFT CARGO  
DOOR" DISPLAYED

**PREREQUISITES**

MAKE SURE THIS CIRCUIT BREAKER IS CLOSED:  
11T33  
MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)



Cargo Doors Light Illum. EICAS Message AFT CARGO DOOR Displayed  
Figure 104A

EFFECTIVITY

ALL

**52-71-00**

03

Page 115  
Apr 22/08

981026

**PREREQUISITES**


MAKE SURE THIS CIRCUIT BREAKER IS CLOSED:  
11T33

MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)

**WARNING:** MAKE SURE YOU DISARM THE OFF-WING ESCAPE SYSTEM. REFER TO AMM 25-65-00/201 FOR THE DISARM PROCEDURE. IF THE SYSTEM IS NOT DISARMED, THE SYSTEM WILL DEPLOY AND CAN CAUSE INJURY OR DAMAGE.

REFER TO AMM 52-21-01/201 TO OPEN AND CLOSE THE OVERWING EMERGENCY EXIT HATCH.

"EMER DOORS" LIGHT ILLUM. EICAS MESSAGE "EMER DOOR" DISPLAYED



EMER DOORS Light Illum. EICAS Message EMER DOOR Displayed  
Figure 105


EFFECTIVITY	ALL
-------------	-----

**52-71-00**

EICAS MESSAGE  
DISPLAYED FOR ENTRY  
DOOR, EMER DOOR,  
CARGO DOOR, OR  
ACCESS DOOR.  
CORRESPONDING  
ANNUNCIATOR LIGHT  
NOT ILLUMINATED.

**PREREQUISITES**

MAKE SURE THIS CIRCUIT BREAKER IS CLOSED:  
11T33  
MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201).



EICAS Message Displayed for Entry Door, Emer Door, Cargo Door, or Access Door.  
Corresponding Annunciator Light Not Illuminated.

Figure 106

EFFECTIVITY

ALL

52-71-00


03

Page 117  
Dec 22/07

981047

EMER DOORS LIGHT  
ILLUM. EICAS  
MESSAGE "L WING  
SLIDE" OR "R WING  
SLIDE" DISPLAYED

**PREREQUISITES**  
MAKE SURE THIS CIRCUIT BREAKER IS CLOSED:  
11T33  
MAKE SURE THE AIRPLANE IS IN THIS CONFIGURATION:  
ELECTRICAL POWER IS ON (AMM 24-22-00/201)



Emer Doors Light Illum. EICAS Message "L WING SLIDE" or "R WING SLIDE" Displayed  
Figure 107

EFFECTIVITY	ALL
-------------	-----

52-71-00