



6+K agents - Path 9381 2705

---

#78777

**2237 Controller**  
**Integrating Sound Level Meter**

From serial no. 1896 028

June 1996

## Trademarks

2237 Controller is a trademark of Brüel & Kjær A/S. Macintosh is a registered trademark of Apple Computer, Inc. Microsoft, Windows, and MS-DOS are trademarks of Microsoft Corporation.

Copyright © 1996, Brüel & Kjær A/S

All rights reserved. No part of this publication may be reproduced or distributed in any form, or by any means, without prior consent in writing from Brüel & Kjær A/S, Nærum, Denmark.

# Contents

---

## Introduction

About this manual and the 2237 Controller. Terminology.

---

1

---

## Getting Started

Basic introduction to the instrument: Fitting batteries, use of pushkeys, the display, choosing the language.

---

2

---

## Taking Measurements

How to use the 2237 Controller: Calibrating, taking a measurement, what can be read from the display, changing the set-up.

---

3

---

## Data Operations

Saving and recalling measurement results. Printing results. Transferring results to a computer. Using the AC output.

---

4

---

## Maintenance & Troubleshooting

Caring for your instrument. Warnings and error messages.

---

5

---

## Specifications

Complete specifications of 2237 Controller.

---

6

---

## Quick Reference

Overviews of parameters, menus and functions.

---

7

---

## Index

---

8



# Chapter 1

---

## Introduction

---

1.1	About this Manual .....	1-2
	Summary of Contents .....	1-2
	Conventions Used in this Manual .....	1-2
1.2	Features .....	1-3
1.3	Parameters .....	1-4
1.4	Settings .....	1-4
1.5	Memory .....	1-5
	Set-up Memory .....	1-5
	Buffer .....	1-5
	Records .....	1-5
1.6	Backlight .....	1-6

## 1.1 About this Manual


### 1.1.1 Summary of Contents

- **Chapter 1 – Introduction:** provides a general overview of the instrument and its functions.
- **Chapter 2 – Getting Started:** provides basic information including: replacing batteries, using the buttons, reading the screen, and setting the language.
- **Chapter 3 – Taking Measurements:** gives instructions for calibrating and measuring with the 2237 Controller.
- **Chapter 4 – Data Functions:** contains information and instructions about using the data functions and AC output, including: saving, viewing, and erasing records; downloading records; printing measurements; recording to DAT; and monitoring with headphones.
- **Chapter 5 – Maintenance and Troubleshooting:** gives care, cleaning and storage instructions, and a table of error messages together with their causes and solutions.
- **Chapter 6 – Specifications:** a comprehensive listing of technical specifications for the 2237 Controller.
- **Chapter 7 – Quick Reference:** contains several flow charts and some brief descriptions to help you find the settings you need when working with the instrument.
- **Chapter 8 – Index**

### 1.1.2 Conventions Used in this Manual

All references to buttons on the 2237 Controller are shown with the button's pictogram as it appears on the instrument. Refer to section 2.2 for a complete list of button pictograms and their functions.

Text which refers directly to text on the instrument's screen or printouts is indicated using a Courier type face.

For example, "Press  until MaxP is visible on the screen."



## 1.2 Features


The 2237 Controller contains several features that enable you to take and save sound level measurements under a variety of conditions. Features include:

- Ease of use
- Three measurement ranges
- Seven measured parameters (see below)
- Fast, Slow, and Impulse time weightings
- Easy to read display with backlight
- Preset measurement time up to eight hours
- Storage of up to 40 records (see below)
- Serial port for printing or downloading records to a computer
- Downloading records in a standard spreadsheet format
- AC output for headphone monitoring or DAT recording
- Five built-in languages

## 1.3 Parameters

The following parameters are monitored during measurement and can be viewed selectively:



- $L_{eq}$  ( $L_{Im}$ )
- MaxP
- Peak
- MaxL
- MinL
- SPL
- Inst

You can change the displayed parameters during measurement by pressing the  key. The  $L_{Im}$  parameter is displayed instead of  $L_{eq}$  when an Impulse time weighting is used. For more information about selecting and reading the parameters, see section 3.3.

## 1.4 Settings

The following settings are available:

- Measurement range
- Time weighting
- Preset time
- Time and date

You can change the measurement range by pressing the  key. You can change the other settings through windows that are displayed when you press the  key. Settings can not be changed while the instrument is measuring. For more information about setting up the sound level meter for measurement, see section 3.4.

## 1.5 Memory

The sound level meter has three kinds of memory

- Set-up
- Buffer
- Records

### 1.5.1 Set-up Memory

The set-up memory is used to store the date and time, last settings used, and the language selection. This memory is maintained by the backup battery, so it is saved when you turn off the instrument. The date and time are stored directly in the real time clock, which is also powered by the backup battery.

### 1.5.2 Buffer

Holds all of the measurement results from the last measurement period. It is cleared each time you start a measurement or turn off the sound level meter. Results in the buffer can be output to a printer or copied into a record.


### 1.5.3 Records

Up to 40 records of measurement results can be stored in memory. Records are copied from the buffer. They can be stored automatically (after a preset-timed measurement) or manually (at any time after a measurement is stopped).

The records are stored in non-volatile memory, which is powered by the backup battery. All records are preserved when you turn off the instrument.

The following parameters are stored in each record:


- Leq ( $L_{Im}$ )
- MaxP
- MaxL
- MinL
- Time and frequency weightings
- Time and date of measurement
- Measurement duration
- Overload status

The following data functions are available via windows that are displayed when you press the  key:

- Save the buffer to a record
- Recall a record to the screen
- Print results of the last measurement
- Download spreadsheet data of records
- Erase last record
- Erase all records

For more information about records, see section 4.1.

## 1.6 Backlight

The 2237 Controller includes a backlight, which makes the display easier to read in low light situations. Press  to turn it on or off. To save batteries, the light will switch off automatically after 30 seconds.

# Chapter 2

---

## Getting Started


---

2.1	Fitting Batteries .....	2-2
	Checking the Battery Level .....	2-2
	Replacing Batteries .....	2-4
	The Back-up Battery .....	2-5
2.2	Pushkey Definitions .....	2-6
2.3	The Measurement Window .....	2-8
2.4	Choosing the Language .....	2-10

## 2.1 Fitting Batteries

### 2.1.1 Checking the Battery Level


The battery symbol in the upper right hand corner of the Measurement Window indicates the current battery level.



*Fig.2.1 Location of the battery level indicator*

When the battery is full, the battery level indicator is fully black. As the batteries are used, the level will fall until the indicator is completely empty. When it is time to replace the batteries, the indicator will be empty and blinking.

The battery level indicator has five lines of pixels in it (including the tip). Each line represents approximately 2.5 hours of remaining battery time (at room temperature). When the indicator is blinking, there is less than one hour left. Under extreme cold or hot environments, the remaining time may be less.



*Fig. 2.2 Interpreting the battery level indicator*

### Caution

It is possible for batteries to explode or leak if they are handled incorrectly, so:

- For long-term storage, remove the batteries and keep the sound level meter in a dry place.
- Never mix different makes or types of battery.
- Never mix charged and discharged batteries.

## 2.1.2 Replacing Batteries

To replace the batteries:

1. Make sure the sound level meter is switched off by pressing ①.
2. The battery compartment is located in the centre of the back of the instrument. Press the two tabs on the upper edge of the battery compartment and remove the lid.



*Fig.2.3 The 2237 Controller with the battery lid removed*



3. Remove all of the old batteries.
4. Insert new batteries (four 1.5V LR6/AA size alkaline batteries) following the +/- orientation shown in the bottom of the battery compartment.
5. Press the compartment lid back into place.

**Note:** If you cannot switch on the sound level meter after replacing the batteries, check that you have inserted them correctly. The sound level meter is designed so that it will not work if the batteries are inserted incorrectly in the battery compartment.

### 2.1.3 The Back-up Battery

The sound level meter has a back-up battery for running the clock and maintaining the records and settings, even when it is switched off or the main batteries are removed.

The back-up battery is recharged automatically when there are standard batteries in the sound level meter. It is fully charged after about 10 hours. Fully charged, the back-up battery runs the clock and retains records and settings for about 6 months.

These charge times are typical for a sound level meter at room temperature.







#### **Important:**





If the back-up battery is flat, then you will see the Set-up Language Window when the instrument starts-up (see section 2.4). The measurement settings, date and time will also be reset to factory-set values.

If this happens, then your instrument's calibration may no longer be valid. Contact your Brüel & Kjær dealer to have your sound level meter recalibrated.

## 2.2 Pushkey Definitions

To control the sound level meter, you must use the pushkeys on the instrument's front panel. Each button is marked with a pictogram. This section gives a brief explanation of each button.

- |              |   |  |
|--------------|---|--|
| Power        |    | Press this key to switch the instrument on or off. The instrument will begin measuring as soon as it starts-up.  |
| Calibrate    |    | Press this key to calibrate your instrument. See section 3.1 for calibration instructions.   |
| Settings     |    | Press this key to step through the measurement settings windows. With these windows you can adjust the measurement time, time weighting, and current date and time.  |
| Up Arrow     |    | Press this key to make changes in the settings, data, or calibration windows. When recalling records, use this key to step through the displayed records. It increments the available numbers and choices. |
| Down Arrow   |  | Press this key to make changes in the settings, data, or calibration windows. When recalling records, use this key to step through the displayed records. It decrements the available numbers and choices. |
| Data Records |  | Press this key to step through the data windows. With these windows you can store, recall, erase, print and/or download records of your measurements.  |

- Range**  Press this key to step through the available measurement ranges.
- Measure / Cancel**  While viewing the Measurement Window or saved records, press this key to step through the available measurement parameters.
- While viewing any of the calibration, data, or settings windows, press this key to exit to the Measurement Window without changing any settings.
- Start / Stop / OK**  While viewing the Measurement Window, press this key to start or stop a measurement.
- While viewing any of the calibration, data, or setting windows, press this key to perform the displayed action (e.g. Erase All Records) or apply all new settings you have made.
- While viewing saved records, press this key to return to the Measurement Window.
- Backlight**  Switches on or off the display's backlight. To save batteries, the backlight switches off automatically after 30 seconds.

## 2.3 The Measurement Window

During normal operation you will use the Measurement Window to view your measured data. It provides several kinds of information about your settings and measurements.











Fig.2.4 The Measurement Window


1. *The bottom end of the measurement range (in dB):* all sound below this level will register as under range. To change the measurement range, press while measurement is stopped.
2. *Quasi-analogue display:* shows a graphical representation of the current sound pressure level. It is updated 15 times a second.
3. *The upper end of the measurement range (in dB) and overload indicator:* Peaks above this level will trigger an overload warning. If an overload has occurred in the last one second, this number will change to read “OVL” for the duration of the next second. If an overload has occurred at any time during a measurement in progress, then this number will blink (this is called a “latched overload”). To change the measurement range, press .

4. *Battery level*: when the batteries are new, this indicator is completely black. As the batteries are used, the level falls. Replace the batteries when this indicator is empty and blinking.
5. *Run/Stop indicator*: displays the current status of measurement. Press  to start or stop a measurement.
6. *Elapsed time*: the amount of time that has passed since measurement began.
7. *Peak parameter*: shows the type of peak reading displayed (MaxP or Peak). Press  to select the displayed parameters.
8. Value of the peak parameter
9. *Weightings used for the RMS parameter*: Can be either AF (“A” frequency weighted and Fast time weighted), AS (“A” frequency weighted and Slow time weighted), or AI (“A” frequency weighted and Impulse time weighted).
10. *RMS parameter*: Shows the type of RMS sound level reading displayed ( $L_{eq}$  ( $L_{Im}$ ), MinL, MaxL, SPL, or Inst). Press  to select the displayed parameters.
11. Value of the RMS parameter





## 2.4 Choosing the Language

The 2237 Controller is fluent in five languages. Use the procedure below to choose the language used in the instrument's display screen.


1. If the sound level meter is on, then press  to switch it off.
2. While the instrument is off, press  and hold it down.
3. While holding , press .
4. Release both buttons. The instrument does a self-test as usual and then displays the Set-up Language window.



*Fig.2.5 The Set-up Language Window*

5. Press the  and/or  keys until your preferred language appears in the window. The choices are (in order):
  - English
  - Francais
  - Deutsch
  - Italiano
  - Espanol
6. Press  or  to choose the language and proceed to the Measurement Window.

### **Important**

If the Set-up Language window appears unexpectedly when you start up your instrument (i.e. when you have not pressed ) and the clock and measurement settings have been reset, then the back-up battery is probably flat. This means that your factory calibration is no longer valid and must be redone at a Brüel & Kjær service centre. Contact your Brüel & Kjær dealer for assistance.





# Chapter 3

---

## Taking Measurements

---

3.1	Calibration.....	3-2
	When to Calibrate .....	3-2
	Principle of Calibration.....	3-2
	Free and Diffuse Field Measurements.....	3-2
	Which Calibrators Can I Use? .....	3-3
	Calibrating the 2237 Controller .....	3-4
3.2	Taking Measurements .....	3-6
	Taking Manually Timed Measurements.....	3-6
	Taking Preset-timed Measurements .....	3-8
	Overload Conditions.....	3-9
3.3	Reading the Parameters .....	3-11
3.4	Making Measurement Settings .....	3-13
	Setting the Measurement Range.....	3-14
	Setting the Time Weighting.....	3-15
	Setting the Measurement Time.....	3-17
	Setting the Time and Date.....	3-19

## **3.1 Calibration**

### **3.1.1 When to Calibrate**

Most national standards recommend that you calibrate your sound level meter before each set of measurements and check the calibration after each set.

### **3.1.2 Principle of Calibration**

The sound level meter uses a calibration factor to correct for drift. It compares a signal of known volume and frequency, which is emitted by a certified calibrator, against the sound level meter's reading of that signal.

When calibrating, you enter the calibration level into the sound level meter and then take a measurement from the calibrator. The sound level meter then computes a calibration factor that will correct its response to match the known value.

### **3.1.3 Free and Diffuse Field Measurements**


The sound level meter is calibrated in the same way for free field measurements (according to IEC) and diffuse field measurements (according to ANSI). However, the calibration levels for some calibrators may be different, depending on which measurements are to be made. See your calibrator's user manual for details.

Always remove the Random Incidence Corrector DZ9566 (if fitted) from the microphone when calibrating or checking the calibration.

### 3.1.4 Which Calibrators Can I Use?

The sound level meter can be calibrated with Brüel & Kjær Sound Level Calibrator Type 4231 or any other certified sound level meter calibrator that emits a 1 kHz signal at 94 dB.


Each individual calibrator is slightly different. The actual calibration level is not necessarily equal to the nominal calibration level. Therefore, it is important to check the level listed in the chart included with your calibrator and set your sound level meter accordingly.



*Fig.3.1 Sound Level Calibrator Type 4231 fitted onto the 2237 Controller*

### 3.1.5 Calibrating the 2237 Controller

1. Stand away from loud noise sources.
2. Fit the calibrator carefully onto the sound level meter and rest the assembly on a table or other flat surface as shown in Fig. 3.1. Ensure that the calibrator fits snugly on the microphone.
3. Press  $\text{⓪}$  to switch on the sound level meter.
4. Press  $\blacktriangleright/\blacksquare$  to stop the sound level meter from measuring.
5. Set the calibrator to emit a 1 kHz signal at 94 dB (see the calibrator's user manual for instructions). The Type 4231 does this automatically.
6. Press  $\blacktriangle$  on the sound level meter to display the Calibration Window, as shown below.



*Fig. 3.2 The Calibration Window*

7. Check your calibrator's documentation for the correct calibration level. Different values are usually listed for free field (IEC standard – usually 94 dB) and diffuse field (ANSI standard – usually 93.85 dB) calibrations. Pressure field calibrations are the same for both standards (usually 94 dB). In some cases, you may need to round to the nearest tenth of a dB. For example, if your calibrator's chart reads "93.85 dB" then set your sound level meter to 93.9 dB. Use the  $\blacktriangle$  and  $\blacktriangledown$  keys on the sound level meter to set the Level to the correct value.
8. Switch on the calibrator. Wait a few seconds for it to warm up.

9. Press  $\blacktriangleright/\blacksquare$  to calibrate your instrument. (Press  $\text{⏏}$  if you want to abort the calibration procedure.)
10. Your instrument is now calibrated.

**Note:**

If an error message appears after you press  $\blacktriangleright/\blacksquare$ , make sure that:

- the calibrator is switched on
- the calibrator is securely attached to the top of your sound level meter
- the calibrator's batteries are fully charged
- the surrounding sounds are not loud enough to interfere with the calibration







Then press  $\blacktriangleright/\blacksquare$  again. If the error message is repeated, then take note of the text and contact your Brüel & Kjær dealer. Also, see section 5.3.


## 3.2 Taking Measurements

There are two ways to take a basic measurement. One is to start and stop the instrument manually, the other is to use a preset measurement period. In both cases, the sound level meter must be correctly configured before you start the measurement. See section 3.4 for more information about configuring the range and measurement settings.

### 3.2.1 Taking Manually Timed Measurements

To take a manually timed measurement, the preset time must be set to “Off”. See section 3.4.3 for more information about making this setting.

1. Press  to switch on the instrument. (If the instrument is already switched on but not measuring, then press  and skip to step 4.)
2. Wait for the sound level meter to start-up (about 8 seconds).
3. Measurement begins automatically.
4. Wait an appropriate amount of time. In some situations, the measurement time will be prescribed by regulations. Otherwise, watch the Measurement Window until the Leq reading has stabilized (if necessary, press  until Leq is visible).
5. Press  to stop measuring.
6. Check the upper limit of the measurement range, if it is blinking (see Fig. 3.3), then an overload has occurred and the measurement may be invalid. If an overload has occurred, then increase the measurement range by pressing  (check the measurement range on the screen as shown in Fig. 3.3). Begin a new measurement by pressing  and repeat from step 4.










*Fig.3.3 The measurement range limits*


7. Step through the displayed measurement parameters by pressing . If some of them show no value (---. - dB), then input levels were too low for the measurement range (under range). Decrease the measurement range by pressing (check the measurement range on the screen as shown in Fig.3.3).
8. If you are keeping manual records, then press to step through the displayed parameters until the ones you need are visible. Take note of your readings.
9. If you want to make a print using a portable printer, then refer to section 4.2 for connecting and printing instructions.
10. If you want to download your results later to a computer, then save your measurements in a record (see section 4.1 for instructions). Take note of the record number. Refer to section 4.3 for instructions for connecting to a computer and downloading records. If there are no records left, then you will see a warning on your screen (see section 4.1.2 for more information).

### 3.2.2 Taking Preset-timed Measurements

To take a preset-timed measurement, the preset time must be set to a specific interval (not "OFF"). See section 3.4.3 for more information about making this setting.

1. Press  to switch on the instrument. (If the instrument is already switched on but not measuring, then press  and skip to step 4.)
2. Wait for the sound level meter to start-up (about 8 seconds). This gives you time to step away from the instrument if required.
3. Measurement begins automatically.
4. Measurement will stop automatically after the preset time interval has expired. All measured parameters will be saved in the next available record (see section 4.1 for more information). If there are no records left, then you will see a warning on your screen (see section 4.1.2).
5. Check the upper limit of the measurement range, if it is blinking, then an overload has occurred and the measurement may be invalid (see Fig. 3.3). If an overload has occurred, then increase the measurement range by pressing . You may want to erase the last record of the overloaded measurement as described in section 4.1.4. Begin a new measurement by pressing  and repeat from step 4.
6. Step through the displayed measurement parameters by pressing . If some of them show no value (---. dB), then input levels were too low for the measurement range (under range). If necessary, decrease the measurement range by pressing  once or twice (check the measurement range on the screen as shown in Fig. 3.3). You may want to erase the last record of the under ranged measurement as described in section 4.1.4. Begin a new measurement by pressing  and repeat from step 4.



7. If you are keeping manual records, then press  to step through the displayed parameters until the ones you need are visible. Take note of your readings.
8. If you want to make a print using a portable printer, then refer to section 4.2 for connecting and printing instructions.
9. If you want to download your results to a computer, then refer to section 4.3.

### 3.2.3 Overload Conditions

If you measure sound with peak values higher than the upper limit of the measurement range, then the sound level meter will register an overload. This may invalidate your measurement because the instrument is not capable of reading how loud the overload was, only that an overload occurred. Overloads are indicated in two ways:

1. *Instantaneous Overload*: If an overload has occurred within the last second, then the upper limit of the measurement range value will change to read “OVL”, as shown in Fig. 3.4, until the overload stops.






Fig. 3.4 Instantaneous overload

2. *Latched Overload*: If the instrument is taking a measurement when the overload occurs, it will show OVL until the overload stops (as described above). Thereafter, the upper limit of the measurement range will blink until a new measurement is started.




*Fig.3.5 Latched overload*


If an overload has occurred, then stop measuring (if necessary), increase the measurement range by pressing  and retake the measurement.

Overloads are also indicated in printouts and in records.

- In recalled records, all parameter values will blink if an overload occurred in that record (see section 4.1.3)
- Printed results indicate an overload by showing “Overload” on the printout (see section 4.2.2)
- Spreadsheet results have a special overload column in which overloads are indicated with “Y”.

### 3.3 Reading the Parameters

Seven parameters are monitored by the sound level meter. Two parameters are displayed at a time; one for each of the bottom two lines of the Measurement Window. To change the set of parameters displayed on the screen, press .



*Fig.3.6 Parameters in the Measurement Window*

The displayed parameters have the following meanings:

$L_{eq}$  ( $L_{Im}$ ) Equivalent continuous sound level over the elapsed measurement time. This is the most useful parameter for giving an impression of the average sound pressure level. Limits to  $L_{eq}$  are normally prominent in sound regulations. Note that when an impulse time weighting is used, then this parameter is called " $L_{Im}$ ".

**MaxP** Maximum peak level. It is equal to the highest value of Peak since the measurement started. This parameter is normally important for occupational health readings.

## Chapter 3 – Taking Measurements

### Reading the Parameters

---

<b>Peak</b>	The maximum peak level within the last one second interval.
<b>MaxL</b>	Maximum sound pressure level (SPL) over the elapsed measurement time.
<b>MinL</b>	Minimum sound pressure level (SPL) over the elapsed measurement time.
<b>SPL</b>	The maximum sound pressure level within the last one second interval. This parameter is the numerical equivalent of the level indicated by the quasi-analogue display. It differs from the peak value because SPL is an RMS (root mean square) measurement.
<b>Inst</b>	A randomly sampled instantaneous sound level within the last one second. Generally, it shows a smaller value than SPL.

The values of the RMS value parameters (SPL, MaxL, MinL,  $L_{eq}$  and Inst) are affected by the time weighting setting (see section 3.4.2). The time weighting is shown on the display next to the relevant parameters. The RMS parameters always have an “A” frequency weighting.

Consult your local authorities for regulations concerning which parameters you need to monitor and which time weighting you should use. In general,  $L_{eq}$  and MaxP measured with a Fast time weighting are required.

The peak value parameters (Peak and MaxP) are not affected by the time weighting.

The following codes are displayed to indicate the applied frequency and time weightings:

- AF “A” frequency weighting and Fast time weighting
- AS “A” frequency weighting and Slow time weighting
- AI “A” frequency weighting and Impulse time weighting

Regardless of the parameters that are displayed, the following parameters are always saved when you store a record:

- $L_{eq}$
- MaxP
- MaxL
- MinL
- Time and frequency weightings
- Time and date or measurement
- Measurement duration
- Overload status

For more information about records, see section 4.1.

For a complete listing of the available parameter combinations, see the section 7.3.

## 3.4 Making Measurement Settings

Before you begin measuring, your sound level meter must be set up correctly. Settings that affect measurements and records are:

- Measurement Range
- Time Weighting
- Preset Time
- Date and Time
- Calibration (see section 3.1)

This section explains how to make each of the above settings (except calibration, which is described in section 3.1) and how they will affect your measurements.


### 3.4.1 Setting the Measurement Range


The sound level meter is capable of measuring in any one of three different ranges:

- 30 to 100 dB
- 50 to 120 dB
- 70 to 140 dB


The range you choose will depend on the environment in which you are measuring. It is important to select the measurement range so that the instrument is sensitive enough to measure all relevant sound, but not so sensitive that it overloads. Your measurement will not be accurate if an overload occurs. See section 3.2.3 for more information about overloads.

**To set the measurement range:**

1. If the instrument is measuring, then press  to stop it. The Measurement Window must read STOP (as shown below), not RUN.



*Fig. 3.7 The display when measurement is stopped*

2. Check the current measurement range. It is shown at the top of the Measurement Window. (In the example above, the range is 30 to 100 dB.)
3. To select a new range, press  repeatedly until the range you need is displayed in the Measurement Window.
4. Use the quasi-analogue display to decide if you have set the range correctly. If the display is blank most of the

time, then sound levels are too soft; select a lower measurement range. If the display ever becomes full and the value for the upper limit of the measurement range changes to read “OVL”, then sound levels are overloading the instrument; select a higher range.

### 3.4.2 Setting the Time Weighting

The time weighting adjusts how quickly the sound level meter reacts to sudden changes in sound pressure level. Three time weightings are available, each of which is defined in the IEC and ANSI standards.


- *F (Fast)*: uses a 125 ms time constant. This setting is used in most situations
- *S (Slow)*: uses a 1 s time constant, which smooths out fluctuating levels
- *I (Impulse)*: uses a 35 ms time constant with a slow decay, which allows readings of short-duration sound events.

The time weighting you choose will usually depend on the regulations for which you are measuring. If no time weighting is specified, then use the Fast weighting.

The current time weighting setting is displayed in the Measurement Window. It appears in the bottom left-hand corner. It will show one of three values:

- AF: “A” frequency weighted and Fast time weighted
- AS: “A” frequency weighted and Slow time weighted
- AI: “A” frequency weighted and Impulse time weighted


In Fig. 3.8, the current setting is shown to be AF, so a fast time weighting has been set.



*Fig.3.8 The Measurement window with a fast time weighting selected and with measurement stopped*

### To Change the Time Weighting:

1. Make sure measurement has stopped (as shown in Fig. 3.8). If the instrument is measuring, then press  $\blacktriangleright/\blacksquare$  to stop it.
2. Press  $\pm/\pm$  until the Time Weighting Set-up Window is visible on the screen, as shown below.



*Fig.3.9 The Time Weighting Set-up Window*

3. Press  $\blacktriangle$  or  $\blacktriangledown$  to step through the time weighting settings (F (Fast), S (Slow), I (Impulse)).
4. To store the new time weighting, press  $\blacktriangleright/\blacksquare$ . (If you prefer to cancel your changes and return to the old time weighting, press  $\text{⏏}$ .) You will then return to the Measurement Window.



### 3.4.3 Setting the Measurement Time

The 2237 Controller can be set to measure for a fixed amount of time. When the set time has elapsed, measurement is stopped automatically and the results are stored in the next available record (except when the off (manual) setting is used).

There are 10 preset time settings available:

- Off (manual)
- 10 s
- 30 s
- 1 min
- 5 min
- 8 min
- 10 min
- 30 min
- 1 h
- 8 h


If the preset time is set to Off (manual), then the instrument will continue measuring until you press  $\blacktriangleright/\blacksquare$ . Also, results will not be saved automatically. For instructions on how to save results from a manually timed measurement, refer to section 4.1.1.

To begin a measurement, regardless of the preset time setting, simply switch on the instrument by pressing  $\textcircled{1}$ . If the instrument is already switched on but not measuring, then press  $\blacktriangleright/\blacksquare$  to begin measuring.

To interrupt a preset-timed measurement in progress, press  $\blacktriangleright/\blacksquare$ . Note that the results will not be saved to a record in this case. For instructions on how to save results from a manually stopped measurement, refer to section 4.1.1.


**To set the Preset Time:**

1. If the instrument is measuring, then press  $\blacktriangleright/\blacksquare$  to stop it. The Measurement Window must read STOP (as shown below), not RUN.



*Fig.3.10 The display when measurement is stopped*

2. Press  $\pm$  until the Preset Time Set-up Window is visible on the screen, as shown below.



*Fig.3.11 The Preset Time Set-up Window*


3. Press  $\blacktriangle$  to increase the preset time; press  $\blacktriangledown$  to decrease it. The setting will wrap around between Off and 8 h. Stop when the desired setting appears on the screen.
4. To store the new preset time, press  $\blacktriangleright/\blacksquare$ . (If you prefer to cancel your changes and return to the old preset time, press  $\text{⏏}$ .) You will then return to the Measurement Window.

### 3.4.4 Setting the Time and Date

Date and time information is stored with each record you save. Therefore, it is important to make sure this information is correct.


#### To set the date and time:

1. If the instrument is measuring, then press  $\blacktriangleright/\blacksquare$  to stop it. The Measurement Window must read STOP (as shown below), not RUN.



*Fig. 3.12 The display when measurement is stopped*

2. Press  $\frac{\pm}{\pm}$  until the Date/Time Set-up Window is visible on the screen, as shown below.



*Fig. 3.13 The Date/Time Set-up Window*

3. A blinking cursor indicates the currently selected parameter. In the figure above, the cursor points to the number "04", which is the day. To increment the day, press  $\blacktriangle$ . To decrement the day, press  $\blacktriangledown$ . Continue to use these cursors until the correct day is shown.

## Chapter 3 – Taking Measurements

### Making Measurement Settings

---

4. Press  $\frac{+}{-}$  to move the next parameter (the month). Use the  $\blacktriangle$  and  $\blacktriangledown$  keys to set the current month.
5. Repeat step 4 until you have set the current year, hour, minute, and second. If you want to adjust a previous parameter (for example, to set the day after you have set the year), then you must press  $\frac{+}{-}$  repeatedly to cycle back through the set-up windows.
6. To store the new date and time, press  $\blacktriangleright/\blacksquare$  or  $\text{⌂}$ . It is not possible to cancel Date/Time changes. You will then return to the Measurement Window.

# Chapter 4

---

## Data Operations

---

4.1	Working with Records.....	4-2
	Saving Records .....	4-2
	When All Records are Full .....	4-4
	Recalling a Stored Record .....	4-5
	Erasing Records.....	4-6
4.2	Using a Portable Printer.....	4-10
	To Make a Print.....	4-10
	Reading the Printout.....	4-12
4.3	Transferring Records to a Computer.....	4-14
	Connecting to a Computer .....	4-14
	Transferring Results with Brüel & Kjær Software .....	4-15
	Transferring Results with Third Party Software .....	4-16
4.4	Using the AC Output.....	4-17
	To Record Measured Sound to a DAT .....	4-17
	To Monitor the Measurement with Headphones.....	4-19

## 4.1 Working with Records

The 2237 Controller is capable of saving up to 40 records of measured results. This enables you to take several readings at different locations or at different times of day and store each one for future reference. All records can be recalled to the screen and/or downloaded to a computer in a standard spreadsheet format.

### 4.1.1 Saving Records


A record is saved automatically after each preset-timed measurement (see section 3.4.3). Results from a manually timed measurement or an interrupted preset-timed measurement must be saved manually. Records are numbered from 1 to 40 and are filled sequentially.


Each record holds the following information:

- $L_{eq}$
- MaxP
- MaxL
- MinL
- Time and frequency weightings
- Time and date of measurement
- Measurement duration
- Overload Status



Once all 40 records have been filled, no further records can be stored until some or all of the stored records are erased. You are able to erase the last record taken or all records at once (see section 4.1.4).

**To save a record manually:**

1. Take a manually timed measurement as described in section 3.2.1.
2. Press  until the Store Results Window appears on the screen, as shown below.



*Fig.4.1 The Store Results Window*

3. Press  to store the results in the displayed record number (in the example shown in the figure above, results will be stored in record number 4). You will then return to the Measurement Window. If you wish to cancel the operation rather than store the record, press  to return to the Measurement Window.

## 4.1.2 When All Records are Full

If you attempt to store a record (either manually, or after a preset-timed measurement) after all 40 records have been filled, you will see the following message:

```
*** WARNING ****  
No Free Record  
to Store Current  
Measurement
```

*Fig. 4.2 The No Free Records warning*

If you see this message, then you must erase some or all of your records (see section 4.1.4) or take written records of your measurements.

### To prevent problems:


- Always check the number of records available before starting a series of measurements.
- Always erase all records after you have downloaded and saved them to your computer's hard disk.
- Erase records of invalid measurements (e.g. overloads) right away by using the *Erase Last Record* command (see section 4.1.4).



### 4.1.3 Recalling a Stored Record

To view the results of any of your stored measurements, follow the procedure below.


1. If the instrument is measuring, then press  $\blacktriangleright/\blacksquare$  to stop it. The Measurement Window must read STOP (as shown below), not RUN.



30 ■■■ 100 ■  
STOP 00:05:41  
MaxP 94.7 dB  
AF Leq 45.8 dB

*Fig. 4.3 The display when measurement is stopped*


2. Press  $\square$  until the Recall Records to Display Window is visible on the screen, as shown below.



RECALL  
Records  
to  
Display

*Fig. 4.4 The Recall Records to Display Window*

3. Press  $\blacktriangleright/\blacksquare$  to display the most recently stored record, which will resemble the example shown in Fig. 4.5. Note that if an overload occurred during the measurement, then the value for each parameter will blink.



*Fig. 4.5 An example of a recalled record*

4. To step through the parameters stored in the record, press  $\updownarrow$ . They are displayed in the following order:
  - $L_{eq}$  (default)
  - MaxP (no displayed weightings)
  - MaxL
  - MinL

For more information about the meanings of the parameters and weightings, see section 3.3.


5. To view earlier records, press  $\blacktriangle$ . To view later records, or to wrap back around to the first record, press  $\blacktriangledown$ .
6. When you have finished viewing your records, press  $\blacktriangleright/\blacksquare$  to return to the Measurement Window.


#### 4.1.4 Erasing Records

In some cases, you may want to erase the last record you saved. For example, if you took a preset-timed measurement that was overloaded and therefore invalid, then you should erase the record and retake the measurement. (Note that this is not necessary with an interrupted or manually timed measurement, since the record is not saved automatically.)

After you have downloaded your records to a computer, then you no longer need to store your record on the instrument. You should erase all records on the sound level meter so that the memory will be free for storing future measurements.


**To erase the last record taken:**


1. If the instrument is measuring, then press  to stop it. The Measurement Window must read STOP (as shown below), not RUN.



30	■■■	_____	100	■
STOP		00:05:41		
	MaxP	94.7	dB	
	AF Leq	45.8	dB	



*Fig. 4.6 The display when measurement is stopped*

2. Press  until the Erase Last Record Window is visible on the screen, as shown in Fig. 4.7. The number of the last recorded record is displayed. In the example shown, record no 6 will be erased.



ERASE
Record No. 6

*Fig. 4.7 The Erase Last Record Window*

3. To erase the record shown, press . To cancel, press . If you select to erase the record, then a warning like the one shown in Fig. 4.8 will appear to make sure you have not made a mistake.

```
*** WARNING ****  
Press Same Key  
Again to Erase  
Record No. 6
```

*Fig. 4.8 The Erase Last Record Warning*

4. If you mean to erase the record, press  $\blacktriangleright/\blacksquare$  again. Otherwise, press  $\blacktriangleright$  to keep the record and return to the Measurement Window.

**To erase all records:**

1. If the instrument is measuring, then press  $\blacktriangleright/\blacksquare$  to stop it. The Measurement Window must read STOP (as shown below), not RUN.

```
30 ■■■ _____ 100 ■  
STOP      00:05:41  
MaxP     94.7 dB  
AF Leq   45.8 dB
```

*Fig. 4.9 The display when measurement is stopped*

2. Press  $\square$  until the Erase All Records Window is visible on the screen, as shown below.

```
ERASE  
All  
Records
```

*Fig. 4.10 The Erase All Records Window*

3. To erase all records, press  $\blacktriangleright/\blacksquare$ . To cancel, press  $\uparrow$ . If you select to erase all records, then a warning like the one shown in Fig. 4.11 will appear to make sure you have not made a mistake.

```
*** WARNING ****  
Press Same Key  
Again to Erase  
All Records
```

*Fig. 4.11 The Erase All Records Warning*

4. If you mean to erase all records, press  $\blacktriangleright/\blacksquare$  again. Otherwise, press  $\uparrow$  to leave all records stored and return to the Measurement Window.

## 4.2 Using a Portable Printer

The 2237 Controller includes a standard serial port interface. It is designed to work with portable serial printers. Contact your Brüel & Kjær dealer for more information about printers recommended for use with the 2237 Controller.


### 4.2.1 To Make a Print

If you are using a portable printer, you will get the best results by printing each set of measurements immediately after you have taken them. If you want to save your measurements as records, then it is best to download the records to a computer and print from a spreadsheet program. This is because records are stored in a spreadsheet format, which will not print correctly.

To connect the sound level meter to a serial printer, you must use Brüel & Kjær adaptor cable AO 1386. Contact your Brüel & Kjær dealer if you do not have one.


#### **To print measurement results:**


1. If you have already taken the measurement you wish to print, do not turn off the sound level meter. If you do, your results will be erased.
2. Connect one end of a Brüel & Kjær adaptor cable AO 1386 to the serial port on the back of the sound level meter.
3. Tighten the cable's connector screws to the screw holes on the sound level meter.
4. Connect the other end of the cable to your printer as described in your printer manual.
5. If necessary, switch on the printer as described in your printer manual.




*Fig.4.12 Location of the serial port*

6. Configure your printer to use the communication setup listed below. Refer to your printer manual for instructions.
  - 9600 Baud
  - 8 data bits
  - 1 stop bit
  - Parity: none
  - Handshake: XON/XOFF
7. If you have not taken a measurement, then take a complete measurement as described in section 3.2. Make sure measurement has stopped before proceeding to the next step.

8. Press  until the Print Measurement Window is visible on the screen, as shown below.



*Fig. 4.13 The Print Measurement Window*

9. Press  to begin printing. Press  to cancel the operation.

## 4.2.2 Reading the Printout

The 2237 Controller generates a printout that supplies the following information:

- Time weighting
- Frequency weighting
- Measurement range
- Date and time
- Elapsed time
- MaxP
- MaxL
- MinL
- $L_{eq}$
- Overload status

Sample printouts are shown in Fig. 4.14.



```
-----  
Bruel & Kjaer  
SLM Type 2237  
-----  
Comments:.....  
.....  
.....  
.....  
-----  
SETTINGS:  
-----  
Time Wt.                F  
Freq. Wt. (RMS)        A  
Range Level  30-100 dB  
-----  
RESULTS:  
-----  
21 May 1996   00:08:09  
Elapsed time  00:00:10  
  
MaxP          85.2 dB  
MaxL          67.7 dB  
MinL          43.3 dB  
Leq           56.4 dB
```

```
-----  
Bruel & Kjaer  
SLM Type 2237  
-----  
Comments:.....  
.....  
.....  
.....  
-----  
SETTINGS:  
-----  
Time Wt.                F  
Freq. Wt. (RMS)        A  
Range Level  30-100 dB  
-----  
RESULTS:  
-----  
21 May 1996   00:08:30  
Elapsed time  00:00:30  
Overload  
  
MaxP          107.2 dB  
MaxL          83.3 dB  
MinL          40.3 dB  
Leq           68.4 dB
```


*Fig. 4.14 Print examples. In the example on the right an overload has occurred, which is indicated by the "Overload" label on the sixth line from the bottom*

## 4.3 Transferring Records to a Computer

The 2237 Controller is capable of saving up to 40 records of measured results. For more information about saving records, refer to section 4.1. All records can be downloaded to a computer in a standard spreadsheet format. This enables you to read, print, and present your test results in any standard spreadsheet program (such as Microsoft™ Excel).

### 4.3.1 Connecting to a Computer

1. Take a set of measurements and save each to a record. See section 3.2 and section 4.1 for instructions.
2. Switch off the sound level meter and bring it to your computer.
3. Switch off your computer.
4. Connect one end of a Brüel & Kjær adaptor cable AO 1386 to the serial port on the back of the sound level meter.



*Fig. 4.15 Location of the serial port*

5. Tighten the cable's connector screws to the screw holes on the sound level meter.

6. Connect the other end of the serial cable to your computer as described in your computer manual.
7. Switch on the sound level meter by pressing ①.
8. Switch on your computer.


### 4.3.2 Transferring Results with Brüel & Kjær Software


Brüel & Kjær communication software is included with your instrument. It makes transferring results from your sound level meter fast and easy, and it can open results right in Microsoft™ Excel (if Excel is installed) or in the standard Windows® NotePad editor. From NotePad, results can be copied and pasted into other Windows programs. Microsoft Windows 3.x or better is required in order to use this software.

1. If Brüel & Kjær communication software is not installed on your computer, then locate the diskette and follow the instructions given on the label.
2. Connect the 2237 Controller to your computer as described above.
3. Start running the Brüel & Kjær communication software. All communication parameters are set automatically, so no further configuration is required.
4. Use the on-line help to learn how to download your results and transfer them to Microsoft Excel or the Windows NotePad editor. All records will be saved in a single spreadsheet format file (tab separated) with the name and location you choose.
5. If you want to open the file using another spreadsheet program (besides Microsoft Excel), then start your application and open the file from there. Refer to your program's user manual for instructions.

### 4.3.3 Transferring Results with Third Party Software

In some situations (e.g. if you are using a Macintosh™ or DOS-only machine), you may want to use communications software other than that included with your instrument. If so, follow the instructions below.

1. Connect the 2237 Controller to your computer as described in section 4.3.1.
2. Start your communications software.
3. Set your software's communication parameters as follows:
  - 9600 Baud
  - 8 data bits
  - 1 stop bit
  - Parity: none
  - Handshake: XON/XOFF
4. Your communications software will probably ask you for a name and location to which to save the data. Make the appropriate selections. All records will be saved in a single spreadsheet format file (tab separated) with the name and location you choose.
5. On the sound level meter, press  until the Output Stored Results Window is visible on the screen, as shown below.



OUTPUT  
Stored Results  
to  
Spreadsheet

*Fig. 4.16 The Output Stored Results Window*

6. Press  $\blacktriangleright$  to begin downloading the results. (Press  $\cancel{\text{F}}$  to cancel the operation.)
7. To view the data, start a spreadsheet program and open the file from there. Refer to your program's user manual for instructions.


## 4.4 Using the AC Output

The 2237 Controller includes an AC output port, which transmits sound straight from the microphone's preamplifier. This is useful, for example, for recording sounds to a DAT so you can bring samples back to a laboratory for further analysis. You may also want to use a set of headphones connected to the AC port to monitor the measurement.

The AC output port is easy to use. All you need is the appropriate cabling to get the signal from the sound level meter into your DAT recorder or headphones. See section 6.2 or contact your Brüel & Kjær dealer for information about ordering the required cables and adaptors.

### 4.4.1 To Record Measured Sound to a DAT

1. Set up measurement range and other settings as described in section 3.4.
2. Check the AC output specifications given in section 6.1. Set your DAT recorder appropriately, as described in your DAT's user manual.
3. Switch off the sound level meter and your DAT recorder.
4. Connect the LEMO end of a Brüel & Kjær A0 403 LEMO to BNC cable to the AC output socket on the back of the sound level meter. Contact your Brüel & Kjær dealer if you do not have this cable.



*Fig. 4.17 Location of the AC output socket*

5. Connect the BNC end of the cable (using an adaptor if required) to your DAT recorder.
6. Switch on the sound level meter, calibrator, and DAT recorder.
7. Set the record levels on your DAT recorder appropriately.
8. If you intend to use a sound analyzer on the recording, then connect a calibrator as described in section 3.1. Switch on the calibrator and record a few seconds of the calibration signal on the DAT. Take note of the calibration level shown on the sound level meter. Remove the calibrator when you are done.
9. Begin recording on the DAT and use your sound level meter as normal.
10. If you intend to use a sound analyzer on the recording, then repeat step 8.

#### 4.4.2 To Monitor the Measurement with Headphones

**Note:** For best results, use headphones with an impedance that is equal to or greater than that of the sound level meter (100  $\Omega$ ).

1. Switch off the sound level meter and your DAT recorder.
2. Connect a headphones adaptor to the AC output socket on the sound level meter (see Fig. 4.17).
3. Plug your headphones cable into the adaptor.
4. Use your sound level meter as normal.





# Chapter 5

---

## Maintenance & Troubleshooting

---

5.1	Service and Repair.....	5-2
5.2	Care, Cleaning and Storage.....	5-2
	Storing the Instrument.....	5-2
	Cleaning the Instrument .....	5-2
	Handling the instrument.....	5-3
5.3	Warnings and Error messages.....	5-4

## **5.1 Service and Repair**

The 2237 Controller is designed and constructed to provide many years of reliable operation. However, if a fault occurs that impairs the sound level meter's correct function, then remove the batteries to prevent risk of further damage.

For more information about preventing or identifying faults or damage to your sound level meter, please read the other sections of this chapter.

For repair, contact your local Brüel & Kjær dealer.

## **5.2 Care, Cleaning and Storage**

The 2237 Controller is a delicate precision instrument. When handling, storing, or cleaning your instrument, please take note of the following precautions:

### **5.2.1 Storing the Instrument**

- Keep the sound level meter in a dry place.
- For long-term storage, remove the batteries
- Do not exceed storage temperature limits of  $-25$  to  $+60^{\circ}\text{C}$  ( $-13$  to  $+140^{\circ}\text{F}$ ).

### **5.2.2 Cleaning the Instrument**






If the instrument casing becomes dirty, then wipe it with a cloth lightly dampened with water. Do not use abrasive cleansers or solvents. Do not allow moisture to enter the microphone, connectors, or casing.

### 5.2.3 Handling the instrument

- Do not try to remove the microphone grid, you can easily damage the microphone in this way.
- Do not attempt to open the instrument. There are no user-serviceable parts inside. If you think your instrument requires service, then please contact your Brüel & Kjær dealer.
- Do not allow the instrument to get wet.
- Never mix different makes or types of battery.
- Never mix charged and discharged batteries.
- Do not allow fully discharged batteries to remain inside the instrument
- Protect the instrument from impact. Do not drop it. Transport it in the supplied shoulder bag.

## 5.3 Warnings and Error messages


If you get an error message while using or calibrating your 2237 Controller, then refer to the chart below.

Message	Occurs	Solution
*** Warning *** Function Not Available While Measuring	If you press  ,  ,  , or  while the instrument is in the middle of a measurement.	Wait for measurement to finish or press  to stop measurement and then make your settings.
***** Error ***** Calibration Stopped due to Input Error	During calibration, if foreign sounds have corrupted the calibration signal or if the calibrator is not switched on.	Make sure you have turned on and connected the calibrator correctly, check the calibrator's batteries, and/or move to a quieter location. If the error persists, then contact your Brüel & Kjær dealer.
***** Error ***** New Initial Calibration Needed	During calibration, if the instrument has discovered that the required calibration factor is more than $\pm 1.5$ dB from the factory calibration.	Check the conditions listed above. Make sure you have selected the correct calibration level on your calibrator and sound level meter <sup>†</sup> . If the error persists, then you may need a new factory calibration. Contact your Brüel & Kjær dealer for assistance.

\*. See section 3.1 for more information.

†. See section 3.1 for more information.

## Chapter 5 – Maintenance & Troubleshooting Warnings and Error messages

Message	Occurs	Solution
<p>*** WARNING **** No Free Records to Store Overall Results</p>	When you try to save a record when all 40 records are full.	Erase records or take manual records. See section 4.1.2 for more suggestions.
<p>2237 SELFTEST Memory:....FAILED Program:...FAILED</p>	On start-up if there is a problem with the memory or program.	Contact your Brüel & Kjær dealer for assistance.
<p>SET-UP Language  &gt;English</p>	<p>Normally, as described in section 2.4 (not an error).</p> <p>However, if it appears unexpectedly on start-up, then your back-up battery is probably flat. In this case, the clock and all settings will also be reset. This means that the instrument requires a new factory calibration.</p>	Contact your Brüel & Kjær dealer to arrange for a new factory calibration.
<p>*** WARNING **** No Data Available</p>	If you press  when there are no records saved and the buffer is empty.	Make and store records before using this function.



# Chapter 6

---

## Specifications

---

6.1	Specifications.....	6-2
6.2	Ordering Information.....	6-8

### 6.1 Specifications

#### Standards:

Conforms with: IEC651 (1979) and 804 (1985) Type 2; ANSI S1.4 – 1983 and Draft S1.43, 6th September, 1992 Type 2; BS 5969 and BS 6698 Type 2

#### Measuring Ranges:

Range (dB)	Max. Peak level	Upper limit (RMS) for signals with crest factor = 5 (14dB)
30 – 100	103	89
50 – 120	123	109
70 – 140	143	129

#### Noise Floor:

Below measurement range; less than 30dB.

#### Frequency Weighting:

##### RMS:

A: According to Type 2 tolerances

##### Peak:

C: According to Type 2 tolerances

Linear: 31.5 Hz – 8 kHz (-3dB)

#### Detectors:

Simultaneous RMS and Peak with independent frequency weightings

Linearity Range: 70dB

Pulse Range: 73dB

Non-linear Distortion: Too small to affect accuracy

Peak Detector Rise Time: Typically 50  $\mu$ s

#### Time Weighting:

S, F, I according to Type 2 tolerances. See Fig.6.2 .

#### Display:

4 line LCD showing:

- Input signal level – indicated with a quasi-analogue bar (updated 15 times per second)
- Selected parameters with level
- Warnings for: battery low and overload
- Measuring range
- Time weighting setting
- Elapsed measurement time
- Menus for displaying and editing settings
- Recalled records

Features a back-light for easy viewing, which can be turned on and off and includes an auto time-out to save batteries.

Displayed parameters updated once per second.

#### Exchange Rate:

3dB

#### Parameters:

##### Types:

$L_{eq}$  ( $L_{im}$ ), MaxP, Peak, MaxL, MinL, SPL, Inst

Resolution: 0.1dB

#### Memory:

40 Records of measurement results

#### Microphone:

Type 4137 Prepolarized Free-field 1/2" Condenser Microphone

Sensitivity: -30dB re 1V/Pa  $\pm$ 2dB

Frequency Range: 8 Hz to 10 kHz  $\pm$ 2dB

Capacitance: 12 pF



**Serial Interface:**

**Compatible with:**  
 EIA-574  
 EIA-232-E with 25-pole adaptor  
**Baud Rate:** 9600  
**Data Bits:** 8  
**Stop Bit:** 1  
**Parity:** None  
**Handshake:** XON/XOFF  
**Result Output Formats:**  
 Buffer (printer format) or all records (spreadsheet format)

**AC Output:**

Short-circuit protected coaxial LEMO series 00 socket  
**Max. Output:** 0.5V RMS corresponding to the top of the selected measurement range  $\pm 3$ dB depending on the microphone's sensitivity  
**Output Resistance:** 100 $\Omega$   
**Output:** Output signal from preamplifier (un-weighted)

**Clock:**

Real-time (calendar) and measurement duration  
 Factory set to Central European Time

**Start-up Time:**

Less than 10s

**Effect of Magnetic Field**

80A/m (1 $\text{\AA}$ rsted) at 50Hz gives <30 dB (A)

**Calibration Conditions:**

**Reference Frequency:** 1000Hz  
**Reference SPL:** 94 dB  
**Reference Temperature:** 20°C (68°F)  
**Reference RH:** 65%  
**Reference Range:** 50–130 dB (set automatically during calibration sequence)  
**Reference Direction of Incidence:** Frontal

**Environmental Effects:**

**Storage Temperature:** -25 to +60°C (-13 to +140°F)  
**Operating Temperature:** -10 to +50°C (14 to 122°F)  
**Effect of Temperature:** <0.5dB (-10 to +50°C)  
**Effect of Humidity:** <0.5dB for 30%<RH<90% (at 40°C, 1kHz)

**Vibration Sensitivity**

<80dB at 1m/s<sup>2</sup> horizontally  
 <85dB at 1m/s<sup>2</sup> vertically

**Batteries:**

Four 1.5V LR6/AA size alkaline cells  
**Lifetime (at room temperature):** Typically >12h  
**Internal back-up battery:**  
 Keeps clock and memories operating for at least 6months (typically) if fully charged.

**Physical Characteristics:**

**Size:** 257x97x41mm  
**Weight:** 460g (incl. batteries)




Fig. 6.1 Response of the sound level meter to tone bursts of varying characteristics

**CE Certification**

<b>CE</b>	CE-mark Indicates compliance with EMC Directive
<b>Safety</b>	EN 61010-1 (1993) and IEC 1010-1 (1990): Safety requirements for electrical equipment for measurement, control and laboratory use
<b>EMC Emission</b>	EN 50081-1 (1992): Generic emission standard. Part 1: Residential, commercial and light industry EN 50081-2 (1993): Generic emission standard. Part 2: Industrial environment CISPR 22 (1993): Radio disturbance characteristics of information technology equipment. Class B Limits FCC Rules, Part 15: Complies with the limits for a Class B digital device
<b>EMC Immunity</b>	EN 50082-1 (1992): Generic immunity standard. Part 1: Residential, commercial and light industry RF immunity implies that sound level indications of 50 dB or greater will be affected by no more than $\pm 1$ dB EN 50082-2 (1995): Generic immunity standard. Part 2: Industrial environment RF immunity implies that sound level indications of 60 dB or greater will be affected by no more than $\pm 1$ dB
<p><b>Note:</b> The EMC specifications are given for use with:</p> <ul style="list-style-type: none"> <li>• one AO 0403 BNC to Lemo cable connected to the AC output</li> <li>• one AO 1386 RS232 cable</li> </ul> <p>EMC standards are not guaranteed to be fulfilled with cables other than those mentioned above</p>	

**Frequency Weighting Characteristics**




Fig. 6.2 Nominal frequency weighting characteristics

## Frequency Response




Fig. 6.3 Typical free-field response of Microphone Type 4137 for 0° incidence without random incidence corrector




Fig. 6.4 Typical diffuse-field response of Microphone Type 4137 with random incidence corrector




Fig. 6.5 Directional characteristics of the complete instrument

## Effect of Accessories




Fig. 6.6 (a) Effect of the sound level meter's casing on its frequency response (for reference) compared to (b) the effect of Tripod UA0801 on the sound level meter's frequency response




Fig. 6.7 Effect of Protective Cover UA1236 on the sound level meter's frequency response

## 6.2 Ordering Information

Type 2237      Integrating Sound Level Meter

### Included Accessories

**4xQB 0013**      Four 1.5V LR6/AA size alkaline cells  
**Type 4137:**      Prepolarized Condenser Microphone Cartridge  
**KE 0323:**      Shoulder Bag  
**UA 1236:**      Protective Cover

### Optional Accessories

**Type 4231:**      Sound Level Calibrator (Type 1)  
**UA 1251:**      Tripod  
**UA 0801:**      Tripod  
**UA 1254:**      Microphone Holder (for tripod)  
**UA 0237:**      Windscreen (90 mm)  
**UA 0459:**      Windscreen (65 mm)  
**AO 0403**      LEMO to BNC Cable  
**AO 0404**      9-pole to LEMO Cable (for 2318)  
**AO 1386**      9-pole Cable with 25-pole Adaptor (for serial printer)

### Carrying Cases:

**KE 0325:**      Carrying Case with insert for sound level meter, Sound Level Calibrator Type 4231 and Tripod UA 1251

Brüel&Kjær reserves the right to change specifications and accessories without notice.

# Chapter 7

---


## Quick Reference

---

7.1	The Measurement Window .....	7-2
7.2	Measurement Range Flow Chart.....	7-3
7.3	Displayed Parameters .....	7-4
	Parameter Definitions.....	7-4
	Possible Weightings .....	7-4
	Displayed Parameter Flowchart.....	7-5
7.4	Set-up Functions Flow Chart.....	7-6
7.5	Data Functions Flow Chart.....	7-8

## 7.1 The Measurement Window

During normal operation, you will use the Measurement Window to view your measured data. It provides several kinds of information about your settings and measurements. See section 2.3 for a more detailed description.





*Fig. 7.1 The Measurement Window*

1. The bottom end of the measurement range (in dB)
2. Quasi-analogue display
3. The upper end of the measurement range (in dB) and overload indicator (when showing “OVL” or blinking, see section 3.2.3 for more information about overloads)
4. Battery level (see section 2.1.1)
5. Run/Stop indicator
6. Elapsed time
7. Peak parameter
8. Value of the peak parameter
9. RMS parameter weightings and type (see section 7.3)
10. Value of the RMS parameter




## 7.2 Measurement Range Flow Chart

Three measurement ranges exist. It is important to select a measurement range that is appropriate to your measuring environment; the instrument must be sensitive enough to measure the quietest relevant sounds, yet should never be overloaded. You are only able to change the measurement range while the instrument is not measuring. To set the measurement range, press  to step through the available options as detailed in the flowchart below (the measurement range is shown at the top of each screen). Refer to section 3.4.1 for more information.



*Fig. 7.2 Displayed parameter flowchart*

## 7.3 Displayed Parameters

The Measurement Window displays two parameters at a time on the bottom two lines of the screen, though seven parameters are monitored by the instrument at all times. Press  to step through the readings. You are able to change the displayed parameters both during and after measurement. The flowchart below details the available paired choices. Note that the weightings shown in the screens below (AF) may differ from your own, depending on your settings. For more information, see section 3.3.


### 7.3.1 Parameter Definitions

$L_{eq}$ ( $L_{Im}$ )	Equivalent continuous sound level since the last reset. $L_{Im}$ is shown instead of $L_{eq}$ when the instrument is set to an Impulse time weighting.
MaxP	Maximum Peak since last reset
Peak	Maximum peak in the last one second interval
MaxL	Maximum SPL since last reset
MinL	Minimum SPL since last reset
SPL	Maximum sound level in the last one second interval.
Inst	A randomly sampled instantaneous sound level from within the last one second.

### 7.3.2 Possible Weightings

AF	“A” frequency weighting and Fast time weighting
AS	“A” frequency weighting and Slow time weighting
AI	“A” frequency weighting and Impulse time weighting

### 7.3.3 Displayed Parameter Flowchart



*Fig. 7.3 Displayed parameter flowchart*

## 7.4 Set-up Functions Flow Chart

The  $\frac{+}{-}$  button gives you access to the measurement settings (time weighting, preset time, current date and time). You are only able to do this while the instrument is not measuring. Press  $\frac{+}{-}$  to step through the available settings, as detailed in the flowchart below. The arrow on the screen (>) indicates the selected parameter. Use  $\blacktriangle$  to increment the selected parameter and  $\blacktriangledown$  to decrement it. See section 3.4 for more information.




Fig. 7.4 Set-up functions flowchart, part 1







Fig. 7.5 Set-up functions flowchart, part 2


## 7.5 Data Functions Flow Chart

The  button gives you access to the sound level meter's data functions. These are used to store, print, download, and/or erase records of sound measurements. You are only able to do this while the instrument is not measuring. Press  to step through the available settings, as detailed in the flow-chart below. See section 3.4.4, section 4.2 and section 4.3 for more information.

**Note:**

The flow chart shown in Fig. 7.7 shows all possible choices. The following exceptions apply:

- If the buffer is empty (elapsed measurement time = 0), then the Store Results window will not appear.
- If there are no stored records, then none of the recall, output, or erase windows will appear.
- If there are no stored records and the buffer is empty, then the following warning message will appear when you press .



*Fig. 7.6 The no data available warning*




Fig. 7.7 Data functions flowchart, part 1

Chapter 7 – Quick Reference  
Data Functions Flow Chart




Fig.7.8 Data functions flowchart, part 2



---

# Index

---

- A**
- AC Output ..... 4-17, 6-3
  - Accessories
    - Effect of ..... 6-7
    - included ..... 6-8
    - optional ..... 6-8
- B**
- Backlight ..... 1-6
  - Back-up Battery ..... 2-5
  - Batteries ..... 2-2, 6-3
    - back-up ..... 2-5
    - cautions ..... 2-3
    - replacing ..... 2-4
    - time remaining ..... 2-2
  - Blinking
    - battery indicator ..... 2-2
    - range values ..... 3-10
    - recalled parameters ..... 3-10
  - Brüel & Kjær Software ..... 4-15
  - Buffer ..... 1-5
- C**
- Calibration ..... 3-2
    - choosing a calibrator ..... 3-3
    - errors ..... 3-5, 5-4
    - how often ..... 3-2
    - procedure ..... 3-4
  - Calibration conditions ..... 6-3
  - Care, Cleaning and Storage ..... 5-2
  - Carrying cases ..... 6-8
- CE certification** ..... 6-4
- Cleaning** ..... 5-2
- Clock** ..... 6-3
- Communication software**
- Brüel & Kjær ..... 4-15
  - third party ..... 4-16
- Connecting to a Computer** ..... 4-14
- D**
- DAT recording ..... 4-17
  - Data functions flow chart ..... 7-8
  - Detectors ..... 6-2
  - Directional characteristics ..... 6-6
  - Display ..... 6-2
  - Downloading records ..... 4-14
- E**
- Effect of accessories ..... 6-7
  - Elapsed time ..... 2-9
  - EMC emission ..... 6-4
  - EMC immunity ..... 6-4
  - Environmental effects ..... 6-3
  - Erase
    - all records ..... 4-8
    - last record ..... 4-7
  - Error messages ..... 5-4
  - Exchange rate ..... 6-2
- F**
- Fast time weighting ..... 3-15

# Index

Features .....	1-3
Flashing	
battery indicator .....	2-2
range values .....	3-10
recalled parameters .....	3-10
Frequency response .....	6-5
Frequency weighting .....	6-2
Frequency weighting characteristics .....	6-4

## H

Handling the instrument .....	5-3
Headphones .....	4-19

## I

Impulse time weighting .....	3-15
Inst (instantaneous) parameter .....	3-12

## L

Language setting .....	2-10, 5-5
Latched overload .....	3-9
Leq parameter .....	3-11
Light .....	1-6
Lim parameter .....	3-11

## M

Magnetic field effect .....	6-3
MaxL parameter .....	3-12
MaxP parameter .....	3-11
Measurement range	
flow chart .....	7-3
reading .....	2-8
setting .....	3-14
Measurement time, setting .....	3-17
Measurement Window .....	2-8, 7-2
Measuring .....	3-6
manually timed .....	3-6
overload .....	3-9
preset-timed .....	3-8
under range .....	3-7, 3-8
Measuring range .....	6-2
Memory	
buffer .....	1-5
failure .....	5-5
records .....	1-5
set-up memory .....	1-5
Microphone .....	6-2
MinL parameter .....	3-12

## N

New initial calibration .....	5-4
No data available .....	5-5
No free records .....	4-4, 5-5
Noise floor .....	6-2

## O

Ordering information .....	6-8
Overload .....	3-9
in printouts .....	3-10, 4-13
in records .....	3-10, 4-6
in spreadsheets .....	3-10
Instantaneous .....	3-9
latched .....	3-9
OVL .....	3-9

## P

Parameters .....	1-4, 6-2, 7-4
definitions .....	7-4
flow chart .....	7-5
saved .....	3-13
Peak parameter .....	2-9, 3-12
Peak value parameters .....	3-12
Preset time .....	3-17
off (manual) .....	3-17
setting .....	3-18
Preset-timed measurements .....	3-8
Printing	
connecting a printer .....	4-10
procedure .....	4-10
Reading the printout .....	4-12
Using a portable printer .....	4-10
Program failure .....	5-5
Pushkey definitions .....	2-6

## Q

Quasi-analogue display .....	2-8
------------------------------	-----

## R

Recalling records .....	4-5
Recording to DAT .....	4-17
Records .....	4-2
downloading to computer .....	4-14
erasing .....	4-6
flow chart .....	7-8
none free .....	4-4
recalling to screen .....	4-5
saving .....	4-2
Repair .....	5-2
RMS value parameters .....	2-9, 3-12
Run/Stop indicator .....	2-9

## S

Saving records .....	4-2
Selftest failure .....	5-5
Serial interface .....	6-3
Service and Repair .....	5-2
Settings .....	1-4, 3-13
flow chart .....	7-6
measurement range .....	3-14
measurement time .....	3-17

preset time .....	3-18
time weighting .....	3-15
Set-up memory .....	1-5
Size .....	6-3
Slow time weighting .....	3-15
Specifications .....	6-2
SPL parameter .....	3-12
Start-up time .....	6-3
Storage .....	5-2

**T**

Third party software .....	4-16
Time weighting	
Fast .....	3-15
Impulse .....	3-15
reading .....	3-15
setting .....	3-15
Slow .....	3-15
specifications .....	6-2
Tone burst response .....	6-3

**U**

Under range .....	3-7, 3-8
-------------------	----------

**V**

Vibration sensitivity .....	6-3
-----------------------------	-----

**W**

Warning messages .....	5-4
Weight .....	6-3
Weightings .....	3-12, 7-4

