



---

**NOS VERSION 2  
NETWORK TERMINAL  
USER'S INSTANT**

---

**CDC® COMPUTER SYSTEMS:  
CYBER 170  
CYBER 70  
MODELS 71, 72, 73, 74  
6000**

REVISION RECORD

Revision

Description

A (08-31-82)	Manual released. Reflects NOS 2.0 at PSR level 562.
-----------------	--

Publication No.  
60459380

Revision letters I, O, Q, S, X, and Z are not used.

Address comments to:

Control Data Corporation  
Publications and Graphics Division  
4201 North Lexington Avenue  
St. Paul, Minnesota 55112

© 1982  
by Control Data Corporation  
All Rights Reserved  
Printed in USA

## LIST OF EFFECTIVE PAGES

New features, as well as changes, deletions, and additions to information in this manual, are indicated by bars in the margins or by a dot near the page number if the entire page is affected. A bar by the page number indicates pagination rather than content has changed.

PAGE	REV
Front Cover	-
Title Page	-
2	A
3	A
4	A
5	A
6	A
7	A
8	A
1-1	A
1-2	A
1-3	A
1-4	A
1-5	A
1-6	A
1-7	A
1-8	A
1-9	A
1-10	A
2-1	A
2-2	A
2-3	A
2-4	A
2-5	A
2-6	A
2-7	A
2-8	A
2-9	A
2-10	A
3-1	A
3-2	A
3-3	A
3-4	A
3-5	A
3-6	A
3-7	A

PAGE	REV
3-8	A
3-9	A
3-10	A
3-11	A
3-12	A
3-13	A
3-14	A
3-15	A
3-16	A
3-17	A
3-18	A
3-19	A
3-20	A
3-21	A
3-22	A
3-23	A
3-24	A
3-25	A
3-26	A
3-27	A
3-28	A
3-29	A
3-30	A
3-31	A
3-32	A
3-33	A
3-34	A
3-35	A
3-36	A
3-37	A
4-1	A
4-2	A
4-3	A
4-4	A
4-5	A
4-6	A



# PREFACE

---

This manual describes the operation of a terminal connected to the Network Operating System (NOS) Version 2 via the Network Access Method (NAM). NOS controls operation of CDC® CYBER 170 Computer Systems; CDC CYBER 70 Computer Systems, Models 71, 72, 73, and 74; and CDC 6000 Computer Systems.

## AUDIENCE

This manual is written for all NOS users who use NOS via a network terminal.

## ORGANIZATION

This manual provides information on entering and leaving the system and communicating with the network via an interactive terminal. The final three sections contain formats and descriptions of the commands that can be entered under the Interactive Facility, Remote Batch Facility, Message Control System, and Terminal Verification Facility applications.

## RELATED PUBLICATIONS

This manual is intended to serve as a quick reference guide. Detailed information about the features described in this manual is contained in other Control Data publications.

The NOS Manual Abstracts is a pocket-sized manual containing brief descriptions of the content of all NOS and NOS product manuals. The abstracts can be useful in determining which manuals are of greatest interest to you.

Control Data also publishes a Software Release History Report of all software manuals and revision packets it has issued. This history lists the revision level of a particular manual that corresponds to each released level of software.

These manuals are available through Control Data sales offices or Control Data Literature Distribution Services, 308 North Dale, St. Paul, Minnesota 55103.

<u>Control Data Publication</u>	<u>Publication Number</u>
Message Control System Version 1 Reference Manual	60480300
Network Access Method Version 1 Reference Manual	60499500
Network Access Method Version 1 Terminal Interface Guide	60480600
NOS Version 2 Manual Abstracts	60485500
NOS Version 2 Reference Set, Volume 1, Introduction to Interactive Usage	60459660
NOS Version 2 Reference Set, Volume 3, System Commands	60459680
Remote Batch Facility Version 1 Reference Manual	60499600
Software Publications Release History	60481000
TAF Version 1 Reference Manual	60459500
XEDIT Version 3 Reference Manual	60455730

# CONTENTS

---

1. ENTERING AND LEAVING THE SYSTEM	1-1
Login Sequence	1-1
Application Selection	1-3
Interactive Facility Selection	1-3
Remote Batch Facility Selection	1-4
Message Control System Selection	1-5
Terminal Verification Facility Selection	1-6
Transaction Facility Selection	1-6
Application Switching	1-6
Switching from IAF	1-7
Switching from RBF	1-7
Switching from MCS	1-8
Logout Sequence	1-8
IAF Logout	1-8
RBF Logout	1-9
MCS Logout	1-9
TVF Logout	1-10
TAF Logout	1-10
Network Logout	1-10
2. COMMUNICATING WITH THE SYSTEM	2-1
Terminal Definition Commands	2-1
Line Feed and Transmission Keys	2-7
Carriage Return	2-7
New Line	2-7
Line Feed	2-7
Network Communication Commands	2-9
Abort Output Line Sequence	2-9
Cancel Input Line Sequence	2-9
Character Code Set Command	2-9
Interruption Sequence for IAF	2-10
Message Command	2-10
Termination Sequence for IAF	2-10
Termination Sequence for RBF	2-10
Termination Sequence for MCS	2-10
3. INTERACTIVE FACILITY	3-1
System Commands	3-1
XEDIT Commands	3-20
XEDIT Command Words	3-20
XEDIT Control Characters	3-27
Summary of XEDIT Commands and Formats	3-28
Control Bytes	3-31

4. REMOTE BATCH FACILITY	4-1
RBF Commands	4-1
5. MESSAGE CONTROL SYSTEM	5-1
MCS Commands	5-1
6. TERMINAL VERIFICATION FACILITY	6-1
TVF Commands	6-1

## APPENDIX

A. CHARACTER SETS	A-1
-------------------	-----

## TABLES

2-1 Default Terminal Definition Values	2-3
2-2 Function Keys by Terminal Class	2-8
3-1 Terminal Characteristics	3-34
A-1 Interactive Character Sets	A-1
A-2 Batch Character Sets	A-5
A-3 ASCII to 6/12 Display Code Conversion	A-11



# ENTERING AND LEAVING THE SYSTEM 1

## LOGIN SEQUENCE

1. Complete dial-in procedure, if necessary, to connect the terminal to the network. Check to ensure that the terminal switches are set to the correct positions.
2. Once the connection is established, it may be necessary to identify the terminal to the network. This is required on autorecognition lines so that the network can determine the line speed and/or character code set of the terminal. Press the carriage return key on your terminal. This key may be labeled RETURN, CR, CARRIAGE RETURN, NEXT, SEND, NEW LINE, or ETX. The carriage return key will be represented in this manual by symbol  $\text{\textcircled{CR}}$ .

Entering a  $\text{\textcircled{CR}}$  at terminals of classes 1 through 8 enables the system to determine the terminal's line speed. When the line speed is recognized, the system issues two line feeds. You then have 60 seconds to enter either of the following sequences for character code set recognition.

)  $\text{\textcircled{CR}}$  The system determines the character code set in use at the terminal.

$\text{\textcircled{CR}}$  The ASCII character code set is assumed.

If you do not respond in 60 seconds, the system disconnects the terminal. If the system prints the message UNSUPPORTED CODE SET, the code set of your terminal is not supported at the site and you may have to restart the login sequence.

3. When communication with the network is established, the network initiates the login sequence by requesting that you enter a family name as follows:

yy/mm/dd. hh.mm.ss.† termname ††

CDC NETWORK OPERATING SYSTEM NOS 2

FAMILY:

Enter your family name on the same line.

4. After your family name is accepted, the network requests that you enter your user name.

USER NAME:

Enter your user name on the same line.

5. The network then requests that you enter your password.

PASSWORD



On terminals where overtyping is possible, the network blacks out the password entry area by overtyping a variety of characters. This is done to preserve password secrecy.

Enter your password or, if no password is assigned, press (CR) only.

6. After the password is accepted, select an application as described under Application Selection.

Steps 3, 4, 5, and 6 can be done in a one-line entry by responding to the FAMILY: prompt as follows:

FAMILY: familyname,username,password,application (CR)

Depending on how your site is configured, steps 3, 4, 5, and/or 6 may be done automatically by the system.

† Date is given in year/month/day and time in a 24-hour format (hours.minutes.seconds.).  
†† termname is the network-supplied terminal name.

## APPLICATION SELECTION

After the network has accepted your family name, user name, and password, it requests you to enter the name of the application to which you want to be connected.

terminalname - APPLICATION:

Enter the application name on the same line.

You can be automatically logged into an application during the initial login sequence. If this is the case, the application selection message does not appear. If you have automatic application selection and make a mistake on the first login attempt, or if you enter a HELLO command, the subsequent login sequence will contain the application selection request. The following paragraphs describe selection of the Interactive Facility, the Remote Batch Facility, the Message Control System, the Terminal Verification Facility, and the Transaction Facility.

## INTERACTIVE FACILITY SELECTION

To use the Interactive Facility (IAF), enter IAF following the application prompt.

IAF then displays the job sequence name (JSN) and terminal type (NAMIAF).

JSN: nnnn,NAMIAF

If your site requires you to enter a charge number and project number during login, IAF issues the following prompt:

CHARGE:

You can enter your charge number and project number in any of three ways.

1. Enter your charge number, a comma, and your project number.
2. Enter your charge number. IAF issues the following prompt:

PROJECT:

Enter your project number.



## MESSAGE CONTROL SYSTEM SELECTION

To use the Message Control System (MCS), enter MCS following the application prompt.

MCS responds with the following message.

```
MCS1.0 yy/mm/dd. hh.mm.ss.
```

If the terminal is dedicated, MCS issues the following message.

```
DEDICATED TERMINAL  
APPLICATION=application  
SYMBOLIC NAME=name  
STATUS=status  
mode MODE  
?
```

This message informs you of the application to which the terminal is dedicated, the symbolic name of the terminal, the terminal's status (ENABLED or DISABLED), and the terminal's mode (DATA or COMMAND).

If the terminal is not dedicated or only dedicated to the application or symbolic name, the system makes the following requests.

1. The system requests entry of an MCS application. Enter the application following the application prompt.

MCS APPLICATION?

If the terminal is dedicated to a particular application, MCS does not issue the prompt.

2. After the system accepts the application, it requests the symbolic name of the terminal.

SYMBOLIC NAME?

Enter either one or two symbolic names. The symbolic name may be a source, destination, or interactive name. If the user enters two symbolic names, the first must be a source name, the second must be a destination name, and they must be separated by a space.

If the terminal is named in an ALIAS clause in the application definition, the prompt is not issued.

3. The system then issues the operating mode of the terminal and a question mark. The mode is either DATA or COMMAND.

```
mode MODE  
?
```

You can change the operating mode. To change from COMMAND mode to DATA mode, enter DATA. To change from DATA mode to COMMAND mode, enter the termination character.

Depending on the mode, enter message data or an MCS command on the same line as the question mark.

## TERMINAL VERIFICATION FACILITY SELECTION

To use the Terminal Verification Facility (TVF), enter TVF following the application prompt.

TVF responds with the following messages.

```
yy/mm/dd.          hh.mm.ss.  
TVF  
TERMINAL NAME=terminalname  
TERMINAL CLASS=tc/MODEL model  
LINE WIDTH=pw.  
PAGE LENGTH=pl.  
NAM VER 1x lev  
..
```

Enter any valid TVF command.

## TRANSACTION FACILITY SELECTION

To use the Transaction Facility (TAF), enter TAF following the application prompt.

TAF responds with the following message.

```
READY.
```

Further input under TAF is task controlled. Refer to the TAF Version 1 Reference Manual listed in the preface.

## APPLICATION SWITCHING

You can switch from one application to another as described in the following paragraphs. All terminal characteristics in effect under the previous application remain in effect under the new application unless specifically altered by you or by the application.

## SWITCHING FROM IAF

To leave IAF control and access another application, enter one of the following commands.

BYE, application  
GOODBYE, application  
HELLO, application  
LOGIN, application  
LOGOUT, application

A logout message is displayed and the terminal is disconnected from IAF. If you are authorized to use the specified application, the terminal is connected to the application.

If you enter one of the preceding commands without specifying an application (for example, BYE, ), or if the application entered is not available or not allowed, a logout message is displayed, the terminal is disconnected from IAF, and the next application is requested.

terminalname - APPLICATION:

Enter the name of an application.

Entering one of the preceding commands with neither a comma nor an application (for example, BYE) is described under Logout Sequence later in this section.

## SWITCHING FROM RBF

To leave RBF control and access IAF, enter the following command.

IAF

If you are authorized to use IAF, a logout message is displayed, and the terminal is disconnected from RBF and connected to IAF.

To leave RBF control and access an application other than IAF, enter the following command.

END

A logout message is displayed, the terminal is disconnected from RBF, and entry of the next application is requested.

terminalname - APPLICATION:

Enter the name of an application.

## SWITCHING FROM MCS

To leave MCS control and access another application, enter one of the following commands.

BYE application	LOGIN application
END application	LOGOFF application
GOODBYE application	LOGON application
HELLO application	LOGOUT application

A logout message is displayed, and the terminal is disconnected from MCS.

If you are authorized to use the specified application, the terminal is connected to the application.

If you enter one of the preceding commands without specifying an application, a logout message is displayed, the terminal is disconnected from MCS, and the system requests the application desired.

terminalname - APPLICATION:

Enter the name of an application.

## LOGOUT SEQUENCE

To terminate the session, you enter certain commands to disconnect the terminal from the current application and, optionally, from the network. When leaving the network, all terminal characteristics are reset. When leaving the application but remaining connected to the network, all terminal characteristics in effect under the previous application remain in effect unless you or subsequent applications specifically alter them. The descriptions of the logout procedures follow.

### IAF LOGOUT

To leave IAF and network control, enter one of the following commands.

BYE  
GOODBYE  
LOGOUT

A logout message is displayed, and the terminal is disconnected from the network.



To leave IAF but remain connected to the network, enter one of the following commands.

HELLO  
LOGIN

A logout message is displayed, and the login sequence is reinitiated.

### **RBF LOGOUT**

To leave RBF and network control, enter one of the following commands.

LOGOFF  
LOGOUT

A logout message is displayed and the terminal is disconnected from the network.

To leave RBF and reinitiate the login sequence, enter one of the following commands.

LOGIN  
LOGON

A logout message is displayed, and the login sequence is reinitiated.

### **MCS LOGOUT**

To leave MCS and network control, enter one of the following commands.

BYE  
GOODBYE  
LOGOFF  
LOGOUT

A logout message is displayed, and the terminal is disconnected from the network.

To leave MCS but remain connected to the network, enter one of the following commands.

HELLO  
LOGIN  
LOGON

A logout message is displayed, and the login sequence is reinitiated.

## TVF LOGOUT

To leave TVF but remain connected to the network, enter the following command.

END

The network issues the message

TVF CONNECT TIME hh.mm.ss.

The terminal is then available for login to any network application.

## TAF LOGOUT

To leave TAF but remain connected to the network, enter the following command.

EX.LOGT

The message END OF TRANSACTION SESSION is displayed, and the terminal is then available for login to any network application.

## NETWORK LOGOUT

To leave network control when the APPLICATION prompt is issued, enter one of the following commands.

BYE  
LOGOUT

To reinitiate the login sequence when the APPLICATION prompt is issued, enter one of the following commands.

HELLO  
LOGIN

## COMMUNICATING WITH THE SYSTEM 2

---

### TERMINAL DEFINITION COMMANDS

The terminal class or terminal definition values can be changed by entering terminal definition commands† in the following format.

c mnemonic=value ††

c            Terminal control character defined for the terminal in use (CT character in table 2-1).

mnemonic    Two-character mnemonic for terminal class or terminal definition parameter.

value       Value for terminal class or terminal definition parameter.

---

† IAF users also can enter the TRMDEF command (refer to section 3).

†† Spaces are included for clarity. They should be omitted when entering the command.

The terminal definition mnemonics have the following meanings and ranges of values.

<u>Mnemonic</u>	<u>Meaning</u>	<u>Range</u>
TC	Terminal class	1-17
CT	Control character	Any †
BS	Backspace character	Any †
CN	Cancel input line character	Any †
AL	Abort output line character	Any †
B1	Interruption character (user break 1)	Any †
B2	Termination character (user break 2)	Any †
CI	Carriage return idle count	0-99, CA
LI	Line feed idle count	0-99, CA
PW	Page width	0-255
PL	Page length	0-255
PG	Page wait	Y, N
PA	Parity	Z, O, E, N ††
SE	Special editing †††	Y, N
DL	Transparent text delimiter	X any C1-C4095 TO
IN	Input device	Refer to table 2-1
OP	Output device	Refer to table 2-1
EP	Echoplex mode	Y, N

---

† Any ASCII character except NUL, STX, EOT, LF, CR, DL, =, and space.

†† O (odd parity) is the only value allowed for terminal classes 10, 11, 12, 13, and 15.

††† Special editing is not supported at some sites.

Table 2-1. Default Terminal Definition Values (Sheet 1 of 4)

Mnemonic†	M33, M35 M37, M38	CDC 713-10	IBM 2741	M40	Hazeltine 2000	CDC 751-1	Tektronix 4000	HASP Protocol
TC	1	2	4	5	6	7	8	9
CT	ESC	ESC	%	ESC	ESC	ESC	ESC	%
BS	CTRL/H	←	BACKSPACE	No default	CTRL/H	←	CTRL/H	N/A
CN	CTRL/X	CTRL/X	ATTN (	CTRL/X	CTRL/X	CTRL/X	CTRL/X	(
AL	CTRL/X	CTRL/X	ATTN (	CTRL/X	CTRL/X	CTRL/X	CTRL/X	N/A
B1	CTRL/P	CTRL/P	ATTN :	CTRL/F	CTRL/P	CTRL/P	CTRL/P	:
B2	CTRL/T	CTRL/T	ATTN )	CTRL/T	CTRL/T	CTRL/T	CTRL/T	)
CI	2	0	CA	1	0	0	0	N/A
LI	1	0	1	3	3	0	0	N/A

† Refer to Terminal Definition Commands earlier in this section for mnemonic definitions.

Table 2-1. Default Terminal Definition Values (Sheet 2 of 4)

Mnemonic†	M33, M35 M37, M38	CDC 713-10	IBM 2741	M40	Hazeltine 2000	CDC 751-1	Tektronix 4000	HASP Protocol
PW	72	80	132	74	74	80	74	80
PL	0	0	0	0	0	0	0	0
PG	N	N	N	N	N	N	N	N/A
PA	E	E	0	E	E	E	E	N/A
SE	N	N	N	N	N	N	N	N/A
DL	X OD C2043	X OD C2043	X 6D	X OD C2043	X OD C2043	X OD C2043	X OD C2043	N/A
IN	KB (KB,PT, XK,XP,X)	KB (KB,PT, XK,XP,X)	KB (KB, XK,X)	KB (KB,PT, XK,XP,X)	KB (KB,PT, XK,XP,X)	KB (KB,PT, XK,XP,X)	KB (KB,PT, XK,XP,X)	KB
OP	PR (PR,PT)	DI (DI,PT)	PR (PR,PT)	DI (DI,PT)	DI (DI,PT)	DI (DI,PT)	DI (DI,PT)	DI
EP	N	N	N/A	N	N	N	N	N/A

† Refer to Terminal Definition Commands earlier in this section for mnemonic definitions.

Table 2-1. Default Terminal Definition Values (Sheet 3 of 4)

Mnemonic†	200 UT	CDC 714-30	CDC 711-10	CDC 714-10/20	CDC 731-12 CDC 732-12	CDC 734	IBM 2780	IBM 3780
TC	10	11	12	13	14	15	16	17
CT	%	%	%	%	%	%	%	%
BS	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
CN	(	(	(	(	(	(	N/A	N/A
AL	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
B1	:	:	:	:	:	:	N/A	N/A
B2	)	)	)	)	)	)	N/A	N/A
CI	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
LI	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A

†Refer to Terminal Definition Commands earlier in this section for mnemonic definitions.

Table 2-1. Default Terminal Definition Values (Sheet 4 of 4)

Mnemonic†	200 UT	CDC 714-30	CDC 711-10	CDC 714-10/20	CDC 731-12 CDC 732-12	CDC 734	IBM 2780	IBM 3780
PW	80	80	80	80	80	80	80	120
PL	13	16	16	16	13	13	0	0
PG	Y	Y	Y	Y	Y	Y	N/A	N/A
PA	0	0	0	0	0	0	N/A	N/A
SE	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
DL	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
IN	KB	KB	KB (KB, XK, X)	KB (KB, XK, X)	KB	KB	N/A	N/A
DP	DI	DI	DI	DI	DI	DI	N/A	N/A
EP	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A

†Refer to Terminal Definition Commands earlier in this section for mnemonic definitions.



## **LINE FEED AND TRANSMISSION KEYS**

The following line feed and transmission functions are performed using special keys on your terminal.

### **CARRIAGE RETURN**

Terminates message, advances cursor or carriage to beginning of next line, and transmits message. Also transmits any other messages that are stored in the terminal's buffer.

### **NEW LINE**

Terminates message, advances cursor or carriage, and stores message in terminal's buffer until carriage return key is pressed. Many terminals do not have a new line key, and on other terminals the new line key does not perform the new line function. Refer to specific terminal documentation for information concerning operation of this key on your terminal.

### **LINE FEED**

Terminates physical line of input and advances cursor or carriage to beginning of next line.

Table 2-2 shows the keys used to perform the carriage return, new line, and line feed functions for each terminal class.

Table 2-2. Function Keys by Terminal Class

Terminal Class	Carriage Return	New Line	Line Feed
1	RETURN	N/A	LINE FEED
2	RETURN	N/A	↓
4	RETURN	N/A	ATTN
5	RETURN	N/A	NEW LINE
6	CR	N/A	LF
7	CARRIAGE RETURN †	N/A	LINE FEED
8	RETURN	N/A	LF
9	Varies ††	Varies	Varies
10	SEND	RETURN	N/A
11	SEND	RETURN	N/A
12	ETX	NEW LINE	N/A
13	ETX	NEW LINE	N/A
14	ETX	NEW LINE	N/A
15	SEND	NEW LINE	N/A
16	EOT	EM	N/A
17	EOT	EM	N/A

† For block mode, refer to terminal documentation for terminal key equivalences. Those keys listed are for character and line modes.

†† Terminals operating under HASP protocol use different keys for this purpose.

# NETWORK COMMUNICATION COMMANDS

## ABORT OUTPUT LINE SEQUENCE

When you enter the abort output line character as the only character on a line, the system discards the current output line. If you can interrupt output at the terminal by pressing the BREAK key, † output will continue, starting with the next line, by entering the abort output line character (refer to table 2-1 for abort line values).

## CANCEL INPUT LINE SEQUENCE

You can enter the cancel input line character as the last character before Ⓢ in order to delete the line that was entered. This character (CN) is specified in table 2-1. The network responds by printing \*DEL\* on the next line and positioning the carriage to the beginning of a new line.

## CHARACTER CODE SET COMMAND

This command allows you to change the terminal's character code set. (This command is used only on terminal classes 1 through 8.) The command can be entered any time after the terminal identification part of login. The format is:

c CD=A ††

- c           The terminal control character (CT) defined for the terminal in use (refer to table 2-1).

After entering the command, you select the character code set by entering one of the following:

- ) Ⓢ   For recognition of the character code set in use.
- Ⓢ   For the ASCII character code set.

When the system recognizes the character code set, it issues two line feeds to indicate that you can continue. If the system prints the message UNSUPPORTED CODE SET, your terminal's code set is not supported at the site. A dial-up line is disconnected, and a leased (hardwired) line waits for you to reenter, ) Ⓢ , or Ⓢ .

---

† The BREAK key is sometimes labeled INT, INTRPT, or ATTN.

†† Spaces are included for clarity. They should be omitted when entering the command.

## INTERRUPTION SEQUENCE FOR IAF

To interrupt an executing program or the listing of a file, enter the interruption character followed by  $\text{\textcircled{CR}}$ . This character (B1) can be found in table 2-1. To continue after an interruption, enter  $\text{\textcircled{CR}}$  or P  $\text{\textcircled{CR}}$ . To terminate, enter the termination sequence.

## MESSAGE COMMAND

This command enables you to send a message to the local operator. The format is:

c MS=message †

control      Terminal control character (CT) defined for the terminal in use (refer to table 2-1).

message      Message of no more than 76 characters (including spaces).

## TERMINATION SEQUENCE FOR IAF

To terminate an executing program or a file listing, enter the termination character followed by  $\text{\textcircled{CR}}$ . This character (B2) can be found in table 2-1.

## TERMINATION SEQUENCE FOR RBF

To terminate refreshing the display, enter any RBF command, the interruption character (B1), or the termination character (B2), followed by  $\text{\textcircled{CR}}$ . These characters can be found in table 2-1. To start display refreshing, enter the DISPLAY,type,RFR command. If refreshing the display is not in effect, the break character is ignored.

## TERMINATION SEQUENCE FOR MCS

To switch a terminal from command mode to data mode, enter the termination character (B1) followed by a  $\text{\textcircled{CR}}$ . To terminate output to the terminal, enter the interruption character (B2) followed by a  $\text{\textcircled{CR}}$ . These characters can be found in table 2-1.

---

† Spaces are included for clarity. They should be omitted when entering the command.

---

## SYSTEM COMMANDS

The following commands can only be entered from an interactive terminal.

ACCESS	LIB
ALTER	LIST
ASCII	LOGIN
AUTO	LOGOUT
BASIC	MOVE
BATCH	NORMAL
BRIEF	NOSORT
BYE	NULL
CSET	READ
DELETE	RECOVER
DIAL	RUN
DUP	TEXT
EXECUTE	TIMEOUT
FORTRAN	TRMDEF
FTNTS	WHATJSN
GOODBYE	WRITE
HELLO	WRITEN
HELP	X

ACCESS.

Selects Access subsystem for validated users.

ALTER, $l_1, l_2, \dots, l_n$ ,/string1/string2/.

Changes character strings within specified lines of primary file.

APPEND,pfn,lf $n_1$ ,lf $n_2$ ,...,lf $n_n$ /PW=password,  
UN=username,PN=packname,R=r,NA,WB.

Copies local files to end of indirect access permanent file.

ASCII.

Changes terminal to ASCII mode.

ASSIGN, nn, lfn, VSN=vs<sub>n1</sub>/vs<sub>n2</sub>=...=vs<sub>n-1</sub>/vs<sub>n</sub>,

$\left\{ \begin{array}{l} D=den \\ den \end{array} \right\}$ ,  $\left\{ \begin{array}{l} FC=fcount \\ C=ccount \end{array} \right\}$ , CV=cv,  $\left\{ \begin{array}{l} MT \\ NT \end{array} \right\}$ , PO=P<sub>1</sub>P<sub>2</sub>...P<sub>n</sub>,

F=format, NS=ns, LB=lb,  $\left\{ \begin{array}{l} CB \\ CK \end{array} \right\}$ .

Assigns local file to device or device type nn.

ATTACH, lfn, =pf<sub>n1</sub>, lfn<sub>2</sub>=pf<sub>n2</sub>, ..., lfn<sub>n</sub>=pf<sub>nn</sub>/UN=username,  
PW=password, M=m, PN=packname, R=r, NA, RT, WB.

Attaches direct access permanent files.

BLANK,  $\left\{ \begin{array}{l} D=den \\ den \end{array} \right\}$ ,  $\left\{ \begin{array}{l} MT \\ NT \end{array} \right\}$ , VSN=vs<sub>n</sub>, FA=fa, VA=va, OFA=ofa,  
CV=cv, OWNER=username/familyname, LSL=lsl, U.

Blank labels a magnetic tape.

AUTO, nnnnn, iiii.

Automatically generates five-digit line numbers.

BASIC, ccc.

Selects BASIC subsystem.

BATCH, fl.

Selects batch subsystem.

BKSP, lfn, n, m.

Backspaces local file n logical records.

BRIEF.

Suppresses some headers and prevents echoing of editing changes.

BYE, application.

Ends IAF session.

CATALOG, lfn, N=n, L=fname, T, U, CS, D, R.

Catalogs local file.

CATLIST,LO=p,FN=pf,UN=username,PN=packname,R=r,  
L=lf,NA,DN=dn.

List information about your permanent files and other users' files that you can access.

CFO,jsn.data.

Sends data to executing job.

CHANGE,nfn<sub>1</sub>=ofn<sub>1</sub>,nfn<sub>2</sub>,...,nfn<sub>n</sub>=ofn<sub>n</sub>/CT=ct,M=m,  
PW=password,PN=packname,R=r,SS=subsystem,NA,CE,  
PR=pr,BR=br,WB.

Changes characteristics of your permanent files.

CHARGE,chargenumber,projectnumber.

Specifies your charge and project numbers for validation.

CHARGE.

Indicates that INPUT file contains chargenumber,projectnumber.

CKP,lf<sub>1</sub>,lf<sub>2</sub>,...,lf<sub>n</sub>.

Directs system to make checkpoint dump.

CLEAR.

Releases all files currently assigned to your job, except those with no-auto-drop status.

CLEAR\*,lf<sub>1</sub>,lf<sub>2</sub>,...,lf<sub>n</sub>.

Releases all but specified list of files and files with no-auto-drop status currently assigned to your job.

COMMENT.comment or  
COMMENT,jsn.comment or  
\*comment

Enters comment in system dayfile and job dayfile

COMMON,lf<sub>1</sub>,lf<sub>2</sub>,...,lf<sub>n</sub>.

Accesses library type files.

CONVERT,P=lf<sub>n1</sub>,N=lf<sub>n2</sub>,RS=n<sub>1</sub>,64,TS=t,R,RC=n<sub>2</sub>,  
NM.

Converts records from one character set to another.

COPY,I=lf<sub>n1</sub>,O=lf<sub>n2</sub>,V=x,M=c,TC=tc,N=copycnt,  
BS=bsize,CC=charcnt,EL=erlimit,  
PO=P<sub>1</sub>P<sub>2</sub>...P<sub>n</sub>,L=lf<sub>n3</sub>.

Copies lf<sub>n1</sub> to lf<sub>n2</sub>.

COPYBF,lf<sub>n1</sub>,lf<sub>n2</sub>,n,c.

Copies n files from lf<sub>n1</sub> in binary mode to lf<sub>n2</sub>.

COPYBR,lf<sub>n1</sub>,lf<sub>n2</sub>,n,c.

Copies n records from lf<sub>n1</sub> in binary mode to lf<sub>n2</sub>.

COPYCF,lf<sub>n1</sub>,lf<sub>n2</sub>,n,fchar,lchar,na.

Copies n files from lf<sub>n1</sub> in coded mode to lf<sub>n2</sub>.

COPYCR,lf<sub>n1</sub>,lf<sub>n2</sub>,fchar,lchar,na.

Copies n records from lf<sub>n1</sub> in coded mode to lf<sub>n2</sub>.

COPYEI,lf<sub>n1</sub>,lf<sub>n2</sub>,x,c.

Copies lf<sub>n1</sub> in binary mode to lf<sub>n2</sub> until EOI is reached.

COPYL,oldlfn,replfn,newlfn,last,flag.

Copies oldlfn to newlfn, substituting records from replfn for matching records on oldlfn and using each record of replfn only once.

COPYLM,oldlfn,replfn,newlfn,last,flag.

Copies oldlfn to newlfn, substituting records from replfn for matching records on oldlfn and using each record of replfn for every matching record on oldlfn.



COPYSBF, lfn<sub>1</sub>, lfn<sub>2</sub>, n, na.

Copies n files from lfn<sub>1</sub> in coded mode to lfn<sub>2</sub>, shifting each line image one character to right and adding leading space.

COPYX, lfn<sub>1</sub>, lfn<sub>2</sub>, x, b, c. or  
COPYX, lfn<sub>1</sub>, lfn<sub>2</sub>, type/name, b, c.

Copies logical records from lfn<sub>1</sub> to lfn<sub>2</sub>.

CSET, c.

Changes terminal's character set.

DAYFILE, lfn, string, op, pd, pl, infile. or  
DAYFILE, L=lfn, FR=string, OP=op, PD=pd, PL=pl, I=infile.

Writes job dayfile.

DEFINE, lfn<sub>1</sub>=pfn<sub>1</sub>, lfn<sub>2</sub>=pfn<sub>2</sub>, ..., lfn<sub>n</sub>=pfn<sub>n</sub>/PW=password,  
CT=ct, M=m, R=r, S=space, PN=packname, NA, PR=pr,  
BR=br, WB.

Creates empty direct access permanent file.

DELETE, c<sub>1</sub>, c<sub>2</sub>, ..., c<sub>n</sub>, /string/.

Deletes specified lines from primary file.

DIAL, jsn, msg.

Sends one-line message to another terminal user (can only be used under the access subsystem).

DISPLAY, expression.

Evaluates expression and sends results to job dayfile.

DMB, ordinal, xmemory.

Generates binary dump of job's exchange package, central memory, and extended memory.

DMD, fwa, lwa.

Dumps central memory with display code equivalents.

DMDECS, fwa, lwa.

Dumps extended memory with display code equivalents.

DMP, fwa, lwa.

Dumps central memory.

DMPECS, fwa, lwa.

Dumps extended memory.

DOCUMENT, I=lf<sub>n1</sub>, S=lf<sub>n2</sub>, L=lf<sub>n3</sub>, N=nn, T=type, C=cc,  
P=pp, NT, NR, TC.

Extracts documentation from source code file.

DROP, JSN=jsn, DC=q, UJN=ujn. or  
DROP, jsn, q, ujn.

Drops executing or queued job.

DUP, lines, number, increment.

Duplicates and inserts lines in specified location in primary file.

ELSE, labelstring.

Terminates skipping when used in conjunction with IFE, provided label strings match; initiates skipping if IFE has not done so.

ENDIF, labelstring.

Terminates skipping when used in conjunction with IFE, ELSE, or SKIP command, provided label strings match; otherwise, it is ignored.

ENDW, labelstring.

Terminates iterative processing of group of commands when used in conjunction with WHILE command, provided label strings match.

ENQUIRE, p<sub>1</sub>p<sub>2</sub>...p<sub>n</sub>. or  
ENQUIRE, OP=p<sub>1</sub>p<sub>2</sub>...p<sub>n</sub>, FN=lf<sub>n1</sub>, O=lf<sub>n2</sub>.

Lists information about your job.

ENQUIRE,JSN=jsn,O=lfn. or  
ENQUIRE,UJN=ujn,O=lfn.

Lists information about specified job.

ENTER./command<sub>1</sub>/command<sub>2</sub>/.../command<sub>n</sub>.

Enters series of commands on one line in batch subsystem.

EVICT,lfn<sub>1</sub>,lfn<sub>2</sub>,...,lfn<sub>n</sub>.

Releases file space for local files but for most files does not release assignment to job.

EXECUTE,ccc.

Selects execute subsystem for use on previously compiled program.

EXIT.

Indicates where in command record to resume command processing if error is encountered, or where to terminate normal command processing.

FCOPY,P=lfn<sub>1</sub>,N=lfn<sub>2</sub>,PC=cs,NC=cs,R.

Converts file from one code format to another.

FORTRAN,ccc.

Selects FORTRAN Version 5 subsystem.

FTNTS,ccc.

Selects FORTRAN Extended Version 4 subsystem.

GET,lfn<sub>1</sub>=pfn<sub>1</sub>,lfn<sub>2</sub>=pfn<sub>2</sub>,...,lfn<sub>n</sub>=pfn<sub>n</sub>/UN=username,  
PW=password,PN=packname,R=r,NA,WB.

Creates copy of indirect access permanent file for use as local file.

GO,jsn.

Clears pause bit of executing job.

GOODBYE,application

Same as BYE command.

GTR, lfn<sub>1</sub>, lfn<sub>2</sub>, d, NR, S, NA.directive<sub>1</sub>,  
directive<sub>2</sub>, ..., directive<sub>n</sub>.

Copies record specified by selection directives  
from lfn<sub>1</sub> to lfn<sub>2</sub>.

HELLO,application.

Logs you out of IAF and switches you to another  
application or reinitiates login sequence.

HELP.

Gives description of system commands.

HTIME.

Issues dayfile message containing model 176  
accumulated clock cycle count for job.

IFE, expression, labelstring.

Causes skipping of commands until ELSE or ENDIF  
command with matching label string is reached,  
provided expression is false.

ITEMIZE, lfn, L=listfln, BL, PW=n, PD, NR, N=n, E.

Lists information about records on binary file.

KRONREF, P=lfn<sub>1</sub>, L=lfn<sub>2</sub>, S=lfn<sub>3</sub>, G=lfn<sub>4</sub>.

Generates cross-reference listing of symbols  
used by decks on MODIFY OPL.

LABEL, lfn, VSN=vs<sub>n1</sub>/vs<sub>n2</sub>=...=VSN<sub>n-1</sub>/vs<sub>n</sub>, { MT  
NT },  
D=den, F=format, LB=lb, { FC=fcount  
c=ccount }, CV=cv,  
NS=ns, PO=p<sub>1</sub>p<sub>2</sub>...p<sub>n</sub>, { CK }, { SI=setid },  
{ CB }, { M=setid },  
{ SN=secno }, { QN=seqno }, { FI=fileid }, FA=fa,  
{ V=secno }, { P=seqno }, { L=fileid },  
G=genno, E=gvn, { CR=cdate }, { RT=yyddd }, { W },  
{ C=cdate }, { T=ddd }, { R }.

Assigns local file to tape unit and accesses new  
or existing tape.

LBC,addr.

Reads one record from INPUT file and loads binary corrections into central memory.

LDI,lfn,id,op,dc,un,cm. or  
LDI,FN=fln,ID=id,OP=op,DC=dc,UN=un,FM=fm.

Copies file of batch jobs on local file to mass storage and enters each job into system input queue.

LENGTH,lfn.

Returns length and status of local file.

LIB,lfn=pfm,PW=password,PN=packname,R=r,NA,ND,WB.

Creates copy of indirect access permanent file and makes it primary.

LIBGEN,F=lfn<sub>1</sub>,P=lfn<sub>2</sub>,N=name,NX=n.

Generates user library file.

LIMITS,L=lfn.

Lists validation information.

LIST,L=lfn. or  
LIST,c<sub>1</sub>,c<sub>2</sub>,...,c<sub>n</sub>,/string/.

Lists contents of local file or specified lines of primary file.

LISTLB,lfn, { SI=setid }, { QN=seqno },LO=ltype,L=out.  
                  M=setid     P=seqno

Reads ANSI labels on local file and writes them to specified file.

LIST80,lfn<sub>1</sub>,lfn<sub>2</sub>,NR.

Reads lfn<sub>1</sub> containing COMPASS assembly listing and writes it, compressed to 80 columns, to lfn<sub>2</sub>.

LOC,fwa,lwa.

Reads octal line images from INPUT file into central memory.

LOCK, lfn<sub>1</sub>, lfn<sub>2</sub>, ..., lfn<sub>n</sub>.

Prevents writing on local file.

LOGIN, application.

Same as HELLO command.

LOGOUT, application.

Same as BYE command.

LO72, I=lfn<sub>1</sub>, S=lfn<sub>2</sub>, L=lfn<sub>3</sub>, H=xxx, LP, NR, Nx=y,  
lx=y, Ox=y, IT.

Reformats files to 72 columns.

MACHINE, EP=state.

Enables or disables extended instruction stack  
purging on models 825, 835, and 855.

MFL, cmfl, emfl. or  
MFL, CM=cmfl, EM=emfl.

Sets maximum central memory and extended memory  
field length.

MODE, m.

Sets CPU program exit mode.

MOVE, l...l, number, increment.

Moves line of primary file.

NEW, lfn/ND.

Creates new primary file.

NOEXIT.

Suppresses transfer to command following next  
EXIT command if an error flag is encountered.

NORERUN.

Clears rerun status of job.

NORMAL.

Converts all lowercase input characters to uppercase, prints all headers and prompts.

NOSORT.

Prevents automatic sorting of primary file.

NOTE, lfn, NR./line<sub>1</sub>/line<sub>2</sub>.../line<sub>n</sub>

Creates file containing specified lines of data.

NULL.

Selects NULL subsystem.

OFFSW, jsn, switch<sub>1</sub>, switch<sub>2</sub>, ..., switch<sub>n</sub>.

Clears sense switches for specified job (or, if jsn is not specified, the job from which the command is issued).

OLD, lfn=pfm/UN=username, PW=password, PN=packname, R=r, NA, ND, WB.

Creates copy of indirect access permanent file and makes it primary file.

ONEXIT.

Reverses effect of NOEXIT command.

ONSW, jsn, switch<sub>1</sub>, switch<sub>2</sub>, ..., switch<sub>n</sub>.

Sets sense switches for specified job (or, if jsn is not specified, the job from which the command is issued).

OUT. or

OUT, \*, lfn<sub>1</sub>, lfn<sub>2</sub>, ..., lfn<sub>n</sub>.

Queues deferred files and OUTPUT, PUNCHB, PUNCH, and P8 files, if on mass storage.

PACK, lfn<sub>1</sub>, lfn<sub>2</sub>, x.

Packs lfn<sub>1</sub> into one record on lfn<sub>2</sub>.

PACKNAM,PN=packname,R=r.

Directs subsequent permanent file requests to specified auxiliary device.

PASSWOR,oldpassword,newpassword.

Changes your password.

PASSWOR.

Indicates that file INPUT contains oldpassword,newpassword.

PAUSE,jsn.

Sets pause bit for specified job.

PBC,fwa,lwa.

Writes one record from central memory to PUNCHB file.

PERMIT,pfn,username<sub>1</sub>=m<sub>1</sub>,username<sub>2</sub>=m<sub>2</sub>,..., username<sub>n</sub>=m<sub>n</sub>/PN=packname,R=r,NA.

Permits other users to access one of your permanent files.

PRIMARY,lfn.

Returns current primary file and makes lfn primary file.

PROTECT,EC=state. or

PROTECT,state.

Activates or deactivates extended memory preservation for your job between job steps.

PURGALL,CT=ct,AD=ad,MD=md,CD=cd,DN=dn,TY=ty,TM=tm,AF, PN=packname,R=r,NA,WB.

Purges all of your permanent files that meet specified selection criteria.

PURGE,pfn<sub>1</sub>,pfn<sub>2</sub>,...,pfn<sub>n</sub>/UN=username, PW=password,PN=packname,R=r,NA,WB.

Removes permanent files from permanent file device.



QGET,JSN=jsn,DC=q,UJN=ujn,FN=lfm. or  
QGET,jsn,q,ujn,lfm.

Removes file from queue and makes it local.

RBR,filename,recordprefix.

Loads one binary record from specified file.

RECOVER.

Displays recoverable jobs at interactive terminal.

RECOVER,JSN=jsn,OP=T. or  
RECOVER,jsn,T.

Recovers detached job or interrupted terminal session.

READ,filename,n,z.

Inserts lines of specified file at specified location in primary file.

RENAME,nfn<sub>1</sub>=ofn<sub>1</sub>,nfn<sub>2</sub>=ofn<sub>2</sub>,...,nfn<sub>n</sub>=ofn<sub>n</sub>.

Changes names of local files.

REPLACE,lfm<sub>1</sub>=pfn<sub>1</sub>,lfm<sub>2</sub>=pfn<sub>2</sub>,...,lfm<sub>n</sub>=pfn<sub>n</sub>/UN=username  
PW=password,PN=packname,R=r,NA,WB.

Replaces indirect access permanent files with copies of local files.

REQUEST,lfm,VSN=vs<sub>n1</sub>/vs<sub>n2</sub>=...vs<sub>n-1</sub>/vs<sub>n</sub>,  
{ D=den }, { FC=fcount }, CV=cv, { MT }, PO=p<sub>1</sub>p<sub>2</sub>...p<sub>n</sub>,  
den }, { C=ccount }, { NT },  
F=format,NS=ns,LB=lb, { CK },  
CB } .comment

Requests operator to assign device to local file.

RERUN.

Sets rerun status for job.

RESEQ, lfn, type, start, step. or  
RESEQ, start, step, type.

Resequences source files that have leading sequence numbers or adds sequence numbers to unsequenced files. Second format is for interactive jobs only.

RESOURC, rt<sub>1</sub>=u<sub>1</sub>, rt<sub>2</sub>=u<sub>2</sub>, ..., rt<sub>n</sub>=u<sub>n</sub>.

Specifies maximum number of tape units and disk packs.

RESTART, lfn, mnnn, x.

Restarts previously terminated job from specified checkpoint.

RETURN, lfn<sub>1</sub>, lfn<sub>2</sub>, ..., lfn<sub>n</sub>.

Releases file space and/or job attachment for specified local files.

RETURN, \*, lfn<sub>1</sub>, lfn<sub>2</sub>, ..., lfn<sub>n</sub>.

Releases file space and/or job attachment for all files except those specified.

REWIND, lfn<sub>1</sub>, lfn<sub>2</sub>, ..., lfn<sub>n</sub>.

Rewinds specified local files and positions them to BOI.

REWIND, \*, lfn<sub>1</sub>, lfn<sub>2</sub>, ..., lfn<sub>n</sub>.

Rewinds all local files, except those specified, and positions them to BOI.

RFL, CM=cm, EC=em. or  
RFL, cm, em.

Sets initial running central memory and extended memory field length.

ROLLOUT, t.

Rolls out your job and releases all memory assigned to job.

ROUTE, lfn, DC=dc, DEF, EC=ec, FC=fc, FID=fid, FM=fm, IC=ic,  
ID=id, PRI=pri, REP=rep, SC=sc, TID=tid, UJN=ujn, UN=un

Prepares local file for entry into queue and optionally places file in queue.

RTIME.

Issues accumulated time in seconds since dead-start to dayfile.

RUN, I=lfn<sub>1</sub>,  $\left\{ \begin{array}{l} B \\ C \end{array} \right\} = \text{lfn}_2$ .

Compiles and initiates execution of local file.

RUN, T, q<sub>1</sub>, q<sub>2</sub>, . . . , q<sub>n</sub>.

Initiates execution of object code FORTRAN program in execute subsystem.

SAVE, lfn<sub>1</sub>=pfn<sub>1</sub>, lfn<sub>2</sub>=pfn<sub>2</sub>, . . . , lfn<sub>n</sub>=pfn<sub>n</sub>/PW=password,  
CT=ct, M=m, SS=subsystem, PN=packname, R=r, NA,  
BR=br, WB.

Retains copies of local files as indirect access files.

SCOPY, lfn<sub>1</sub>, lfn<sub>2</sub>, n, fchar, lchar, NA, R, fcs, fline, lline, ns

Copies specified number of coded files from lfn<sub>1</sub> to lfn<sub>2</sub>, displaying EORs and EOFs.

SET, sym=exp.

Assigns value to flag or control register.

SETASL, s.

Specifies new account block SRU limit for job.

SETCORE, p. or  
SETCORE, -p.

Presets each word within job field length, except first three words.

SETFS, lfn<sub>1</sub>, lfn<sub>2</sub>, ..., lfn<sub>n</sub>/FS=fs.

Sets auto-drop or no-auto-drop status for specified local files.

SETFS, \*, lfn<sub>1</sub>, lfn<sub>2</sub>, ..., lfn<sub>n</sub>/FS=fs.

Sets auto-drop or no-auto-drop status for all local files except those specified.

SETJOB, UJN=ujn, DC=dc, OP=op. or  
SETJOB, ujn, dc, op.

Changes current job's attributes.

SETTL, t.

Specifies maximum time limit for subsequent job steps.

SKIP, labelstring.

Causes unconditional skipping of following commands.

SKIPEI, lfn.

Positions local file to EOI.

SKIPF, lfn, n, m.

Skips files, in forward direction, from current position of local file.

SKIPFB, lfn, n, m.

Skips files, in reverse direction, from current position of local file.

SKIPR, lfn, n, level, m.

Skips records, in forward direction, from current position of local file.

SORT, lfn, NC=n.

Sorts local file to lines, in numerical order, based on leading line numbers consisting of specified number of digits.

STIME.

Issues current value of SRU accumulator to job's dayfile.

SUBMIT, lfn, q, NR. c

Submits batch job on local file to input queue.

SUMMARY, OP=p<sub>1</sub>p<sub>2</sub>...p<sub>n</sub>, FN=lfn<sub>1</sub>, O=lfn<sub>2</sub>. or  
SUMMARY, p<sub>1</sub>p<sub>2</sub>...p<sub>n</sub>.

Lists information about your job.

SWITCH, jsn, s<sub>1</sub>, s<sub>2</sub>, ..., s<sub>n</sub>.

Sets sense switches for specified job (or, if jsn is not specified, for the job from which the command is issued).

TCOPY, I=lfn<sub>1</sub>, O=lfn<sub>2</sub>, F=format, TC=tc, N=copycnt,  
CC=charcnt, E=erlimit, P=p<sub>1</sub>p<sub>2</sub>, L=lfn<sub>3</sub>.

Copies tape to tape or mass storage file, or copies mass storage or tape file to tape.

TDUMP, I=lfn<sub>1</sub>, L=lfn<sub>2</sub>, O, A, R=rcount, F=fcount,  
N=lines, NR.

Dumps local file in octal or alphanumeric format.

TEXT.

Selects text mode; text mode is terminated by entering termination sequence or end-of-text (ETX) as only input on line.

TIMEOUT.

Changes no-timeout status to normal timeout status.

TRMDEF, L=lfn, tc<sub>1</sub>=v<sub>1</sub>, tc<sub>2</sub>=v<sub>2</sub>, ..., tc<sub>n</sub>=v<sub>n</sub>.

Changes characteristics of network terminal. Refer to section 1 for descriptions of parameters.

UNLOAD, lfn<sub>1</sub>, lfn<sub>2</sub>, ..., lfn<sub>n</sub>.

Releases file space and/or job attachment for specified local files without decrementing resource demand count.

UNLOAD, \*, lfn<sub>1</sub>, lfn<sub>2</sub>, ..., lfn<sub>n</sub>.

Releases file space and/or job attachment for all local files, except those specified, without decrementing resource demand count.

UNLOCK, lfn<sub>1</sub>, lfn<sub>2</sub>, ..., lfn<sub>n</sub>.

Reverses effect of LOCK command.

UPROC, FN=pfile.

Specifies file containing procedure to be executed at start of each of your jobs.

USECPU, n.

Specifies CPU to be used for processing.

USER, username, password, familyname.

Identifies you as valid user and enables system to determine your resource limits.

VERIFY, lfn<sub>1</sub>, lfn<sub>2</sub>, P<sub>1</sub>, P<sub>2</sub>, ..., P<sub>n</sub>.

Performs binary comparison of all data from current position of specified files.

VFYLIB, lfn<sub>1</sub>, lfn<sub>2</sub>, lfn<sub>3</sub>, NR.

Performs binary comparison of lfn<sub>1</sub> and lfn<sub>2</sub> and lists replacements, deletions, and insertions on lfn<sub>3</sub>.

VSN, lfn<sub>1</sub>=vs<sub>n1</sub>, lfn<sub>2</sub>=vs<sub>n2</sub>, ..., lfn<sub>n</sub>=vs<sub>n</sub>.

Associates volume serial numbers with local files.

WBR,filename,recordlength.

Writes binary record of specified length from central memory to current position of specified file.

WHATJSN,username.

Determines job sequence name of specified terminal user (can only be used under the ACCESS subsystem).

WHILE,expression,labelstring.

Delimits group of commands and causes them to be processed iteratively as long as specified expression is true (used with ENDW).

WRITE,filename,c<sub>1</sub>,c<sub>2</sub>,...,c<sub>n</sub>,/string/.

Appends lines and line numbers of primary file to specified file.

WRITEF,lfn,x.

Writes empty files on specified local file.

WRITEN,filename,c<sub>1</sub>c<sub>2</sub>,...,c<sub>n</sub>,/string/.

Copies lines from primary file to specified file, removing line numbers.

WRITER,lfn,x.

Writes empty records on specified local file.

X,command.

Enables system to recognize batch command while you are not in batch subsystem.

XEDIT,lfn,p<sub>1</sub>,p<sub>2</sub>,...,p<sub>n</sub>.dcs

Selects XEDIT utility. Refer to XEDIT Commands in this section.

## XEDIT COMMANDS

Refer to System Commands earlier in this section for information on how to call XEDIT.

### XEDIT COMMAND WORDS

ADD or A

Adds a specified string to the end of one or more existing file lines.

ADDLN or ALN

Adds a line number to every line in the file that currently has none.

BOTTOM or B

Moves file pointer to last line of the current record in the file.

BRIEF or BR

Suppresses XEDIT verification mode or turns verification either on (BRIEF-) or off (BRIEF+).

CHANGE(S) or C(S)

Replaces one or more occurrences of a particular string or strings of characters with another string.

COPY

Copies one or more lines from the edit file to a specified file.

COPYD

Same as COPY except that the copied lines are deleted from the edit file.

Ⓞ

Allows you to enter input mode and insert an unspecified number of lines into the file immediately after the line designated by the current pointer position.



DEADL or DBL

Deletes a specified number of bad lines (those not beginning with a line number) beginning at the current pointer position.

DEFTAB or DT

Defines the tab character for subsequent use when entering editing data with the INSERT, INSERTB, or REPLACE commands, or with input mode.

DELETE or D

Deletes one or more lines from a file starting at the current pointer position or deletes a particular number of lines on the basis of specified string criteria.

DELETEDN or DLN

Deletes all line numbers in the file.

DELIMIT or DEL

Establishes a particular character as the delimiter. In subsequent lines the delimiter separates multiple commands and editing data.

DEOF or DF

Deletes a specified number of EOF marks from the file.

DEOR or DR

Deletes a specified number of EOR marks from the file.

DLBLANKS or DLB

Deletes leading blanks from a specified number of lines in the file starting at the current pointer position. Blank lines are entirely deleted.

eEDIT

Same as INPUT.

END or E

Terminates XEDIT execution and allows you to save edited file.

EXPLAIN

Gives you more detailed information about the XEDIT message that was most recently printed.

FBADL or FBL

Searches for a specified number of bad lines (those not beginning with a line number). In verification mode, the bad lines are printed.

FILE or F

Saves the edited file according to parameters specified.

FINDLL or FLL

Searches for long lines (those having more characters than the current RMARGIN setting). In verification mode, the long lines are printed.

HELP or H

Requests information about a specific XEDIT command.

INPUT e or eEDIT

Allows you to insert an unspecified number of lines into the file after the line designated by the current pointer position and to make quick changes to the last line entered by using the escape character e. e may be any character except space or the command delimiter. You leave input mode by entering eEDIT or a  $\text{\textcircled{CR}}$ .

INSERT or I

Inserts a specified number of lines into the file immediately after the line designated by the current pointer position.

INSERTB or IB

Inserts a specified number of lines into the file before the line designated by the current pointer position.

line number

Performs a circular search for the line identified by the specified line number and sets the file pointer at that line.

LISTAB or LT

Lists the current tab character and tab stop column positions.

LOCATE or L

Locates a specified number of lines that contain a particular string or strings of characters, contain one string but not another, or do not contain a certain string. In verification mode, the lines are printed.

MODIFY or M

Allows you to alter line contents on a character-by-character basis.

MODIFY directives:

The following directives can be entered under the character or column to be modified. If no modification directives are entered after the single question mark, no changes are made to the line.

↑ string#      Inserts the alphanumeric string  
          or      contained between the ↑ and # before  
^ string#      the character indicated by ↑.

↑      or    ^      Inserts a blank in front of indicated  
                          character when the directive is not  
                          followed by any other character.

# Deletes indicated character and closes up the space left by the deletion.

blank No change to character above the blank space.

& Replaces the character above & with a blank.

Any alpha- Character in file line is changed to  
numeric character in directive.  
character

NEXT or N

Moves the file pointer from its current position forward or backward a specified number of lines.

NOBELLS or NB

Turns off the bell on your terminal that rings when certain XEDIT messages are printed.

OCTCHANGE or OC

Converts the octal display code of a specified character or string to another octal code character or string.

PRINT or P

Lists a specified number of lines, starting at the current pointer position.

QMOD or QM

Allows you to alter portions of your file lines on the basis of column numbers. XEDIT verifies the modification(s) by printing the affected line(s). QMOD uses MODIFY directives.

QUIT or Q

Same as END command.

READ

Merges one or more local files into the edited file after current pointer position.

READP

Merges one or more permanent files into the edited file after current pointer position.

REPLACE or R

Replaces a specified number of existing file lines (starting at the current pointer position) with the same number of substitute lines.

REPLACELN or RLN

Replaces the existing set of line numbers in a file with a new set of line numbers.

RESTORE or REST

Cancels any changes that have been made since the last time the pointer was positioned to the beginning of the file.

RMARGIN or RM

Sets the column position of the right margin of a file.

STOP

Terminates XEDIT execution without saving the modified edited file.

TABS or TAB

Allows you to define up to eight tab stop column positions.

TEOF

Toggles or turns either on (TEOF+) or off (TEOF-) the printing of --EOF-- messages.

## TEOR

Toggles or turns either on (TEOR+) or off (TEOR-) the printing of --EOR-- messages.

## TOP or T

Moves the file pointer to the first line in your file.

## TOPNULL or TN

Inserts a blank line as the first line in a file and sets the file pointer to that line.

## TRIM

Toggles or turns either on (TRIM+) or off (TRIM-) the trim mode. If trim mode is on, XEDIT ignores trailing blanks on commands that involve string searches.

## TRUNCATE or TRUNC

Truncates a specified number of long lines to RMARGIN length, starting at the current pointer position.

## VERIFY or V

Initiates XEDIT verification mode or turns it on (VERIFY+) or off (VERIFY-).

## WEOF or WF

Writes an EOF mark on the file in front of the current pointer position.

## WEOR or WR

Writes an EOR mark on the file in front of the current pointer position.

## WHERE or W

Prints the current line count (that is, the number of file lines that appear from the beginning of the file to the current pointer position).

## WMARGIN or WM

Sets the left and right window margin column settings to define a window that restricts the scope of string searches to the specified columns.

## Y

Allows you to enter several commands (separated by delimiters) in one line of entry. XEDIT executes the commands without listing them. The Y command delimiter should be different than the delimiter specified by the last DELIMIT command.

## YQMOD or YQM

Same as QMOD except that the set of column numbers is not printed.

## Z

Same as Y command except that XEDIT prints each component command as it is processed.

## .n or -n

Advances the file pointer the specified number of lines and reexecutes the last command (.n) or the last Z or Y command (-n) that you entered.

## XEDIT CONTROL CHARACTERS

### prefix characters

Any number and combination of the following characters that can precede any command.

/ Advances the file pointer ahead one line before processing the command.

X Suppresses editor verification when verification mode is in effect. Verifies the results of the command when brief mode is in effect.

↑ or ^ Moves file pointer to the top of the file before processing the command.

+ Indicates to XEDIT that editing data is on the same line as the command. + can be used with ADD, INSERT(B), MODIFY, QMOD, REPLACE, and YQMOD commands.

In

Optional line number prefix that specifies the line at which the specified command is to be executed.

suffix character

One of the following characters, which can follow any command that does a string search, provided that a window has been defined via the WMARGIN command.

- A Forces only the leftmost character of the first string to reside in the window. All other characters can reside outside the window; otherwise, the string is not found.
- W Forces all characters in the string to reside in the window; otherwise, the string is not found.

## SUMMARY OF XEDIT COMMANDS AND FORMATS

ADD n

ADDLN(S) ln n

BOTTOM

BRIEF

BRIEF+

BRIEF-

CHANGE(S)/string1//n

CHANGE(S)/string1a...string1b//n

CHANGE(S)/string1/string2/n

CHANGE(S)/string1a...string1b/string2/n

CHANGE(S)//string2/n

COPY(D) fname n

COPY(D) fname/string/n

COPY(D) fname/string1...string2/n

COPY(D) fname/string1- - -string2/n

COPY(D) fname/- - -string2/n

Ⓞ

DBADL n

DEFTAB char

DELETE n

DELETE/string/n

DELETE/string1...string2/n

DELETE/string1- - -string2/n



DELETELN  
DELIMIT char  
DEOF m  
DEOR m  
DLBLANKS n  
eEDIT  
END, fname, mode  
EXPLAIN  
FBADL n  
FILE, fname, mode  
FINDLL n  
HELP, cmd  
INPUT e  
INSERT(B) n  
line number  
LISTAB  
LOCATE/string/n  
LOCATE/string1...string2/n  
LOCATE/string1- - -string2/n  
LOCATE/- - -string2/n  
MODIFY  
NEXT n  
NEXT -n  
NOBELLS  
OCTCHANGE oct1 oct2 n  
PRINT n  
QMOD n  
QUIT, fname, mode  
READ(P) fname<sub>1</sub>...fname<sub>n</sub>  
REPLACE n  
REPLACELN ln n

RESTORE

RMARGIN m

STOP

TAB(S)t<sub>1</sub>t<sub>2</sub>...t<sub>n</sub> (n≤8)

TEOF  
TEOF+  
TEOF-

TEOR  
TEOR+  
TEOR-

TOP

TOPNULL

TRIM  
TRIM+  
TRIM-

TRUNCATE n

VERIFY  
VERIFY+  
VERIFY-

WEOF

WEOR

WHERE

WMARGIN lm rm

YQMOD n

Y\$cmd<sub>1</sub>\$cmd<sub>2</sub>\$...\$cmd<sub>n</sub>

Z\$cmd<sub>1</sub>\$cmd<sub>2</sub>\$...\$cmd<sub>n</sub>

.n  
-n

## CONTROL BYTES

A control byte is a 12-bit quantity, right-justified in bit position 0, 12, 24, 36, or 48 of a CM word. Each control byte causes NOS to perform a particular operation when it is written to the terminal output file under IAF. The following control bytes are supported.

### 0000 (End-of-Line)

Generates carriage return and line feed, positioning terminal cursor or printing element at beginning of next line. Consists of from 12 to 66 contiguous zero bits, right-justified, in one or two CM words.

### 0001, 0002 (End-of-Block)

Prevents positioning of terminal cursor or printing element at beginning of next line. Can be used to allow you to enter input on same line as input request. Must be followed by end-of-line. If not followed immediately by a read request, output following this byte may be lost.

### 0003 (Auto Input)

Initiates auto mode input. Preceding characters in word in which this byte occurs are sent to terminal and are also retained as first characters of input line. Must be followed by end-of-line. If not followed immediately by a read request, output following this byte may be lost. Terminal prompt (question mark) is suppressed.

### 0004 (Log Off User)

Disconnects terminal from IAF and network. Must be first byte of a line and must be followed by end-of-line. Any output following this byte may be discarded.

### 0005 (Initiate ASCII Input)

Causes next line of input to be translated into 6/12-bit display code. Terminal prompt (question mark) is suppressed. Must be followed by end-of-line. Any output following this byte may be discarded. Subsequent end-of-line input (normally, carriage return) terminates ASCII input mode.

## 0006 (Initiate Transparent Input Mode)

Changes input mode from normal or ASCII to transparent mode. Terminal prompt (question mark) is suppressed. Must be first byte of a line and word must be terminated by end-of-line. Bytes one and two contain the following information:

Byte one      Maximum number (octal) of characters to be received before input is terminated. If byte one is zero, maximum is one character. If byte one is greater than 160g, maximum is 160g.

Byte two      Termination code. When display code of character received from terminal matches lower 7 bits of this byte, input operation is terminated. If bit 11 of this byte is set, no termination character is assumed. Bit 7 (parity bit) is not checked.

Transparent mode packs each 8 bits of data into lower 8 bits of 12-bit byte and sets bit 11. A 0007 byte is forced as first byte of input so that data is transmitted as transparent output if listed.

## 0007 (Initiate Transparent Output)

Initiates output of data formatted in transparent mode. Must be first byte of a line. This mode continues until end-of-line or nontransparent data byte is detected (each transparent data byte contains 1000<sub>2</sub> in bits 11 through 8 and a display code value in bits 7 through 0). Termination by end-of-line does not cause carriage return and line feed; termination by detection of nontransparent data returns terminal to original (normal or ASCII) output mode. Once transparent output mode is terminated, it remains cleared until resumed by another 0007 control byte.

## 0010 (Reserved)

This byte should not be used.

## 0011 (Initiate ASCII Output)

Initiates ASCII 128-character set output (6/12-bit display code). Must be first byte of a line, and applies only to that line of output.

0012 (Reserved)

This byte should not be used.

0013 (End-of-String)

Terminates line of output data without repositioning terminal carriage. Must be followed by end-of-line, which is ignored; output continues with subsequent data. Should not be used where end-of-line is needed.

0014, 0015 (Reserved)

These bytes should not be used.

0016 (Terminal Redefinition)

Alters terminal characteristics. 0016 byte is followed by a string of two-byte entries terminated by an end-of-line. Each entry has the following format:

40mn 4val

mn      Octal number corresponding to the terminal characteristic mnemonic to be altered.

val     Octal value for the parameter.

Refer to table 3-1 for a list of acceptable mnemonics and corresponding values.

Table 3-1. Terminal Characteristics (Sheet 1 of 4)

Mnemonic	Number (Octal)	Values (Octal) by Terminal Type		
		Asynchronous	Mode 4	HASP
Terminal class (TC) ①	5	1-2, 4, 5-10	12-17	11
Page width (PW)	34	0-377	0-377	0-377
Page length (PL)	35	0-377	0-377	0-377
Cancel input line character (CN)	36	0-177 ②	0-177 ②	0-177 ②
Backspace character (BS)	37	0-177 ②	E	E
0-1 values: 0=no, 1=yes. I This parameter is ignored for this terminal class. E This parameter is invalid for this terminal class. ① Terminal class changes are legal only within the same type. ② Excluding 000 (NUL), 002 (STX), 004 (EOT), 012 (LF), 015 (CR), 040 (space), and 075 (=).				

Table 3-1. Terminal Characteristics (Sheet 2 of 4)

Mnemonic	Number (Octal)	Values (Octal) by Terminal Type		
		Asynchronous	Mode 4	HASP
Control character (CT)	40	0-177 ①	0-177 ①	0-177 ①
Carriage return idle count (CI)	41	0-143	I	I
Line feed idle count (LI)	42	0-143	I	I
Carriage return idle default count (CI=CA)	43	0-1	I	I
Line feed idle default count (LI=CA)	44	0-1	I	I
0-1 values: 0=no, 1=yes. I This parameter is ignored for this terminal class. ① Excluding 000 (NUL), 002 (STX), 004 (EOT), 012 (LF), 015 (CR), 040 (space), and 075 (=).				

Table 3-1. Terminal Characteristics (Sheet 3 of 4)

Mnemonic	Number (Octal)	Values (Octal) by Terminal Type		
		Asynchronous	Mode 4	HASP
Special editing (SE)	45	0-1	I	I
Input device (IN)	53	0-1 ① ②	I	I
Output device (OP)	54	0-1 ② ③	I	I
Echoplex mode (EP)	55	0-1 ②	I	I
Page wait (PG)	56	0-1	0-1	0-1

0-1 values: 0=no, 1=yes.  
 I This parameter is ignored for this terminal class.  
 ① 0=KB, 1=PT.  
 ② Ignored for terminal class 4.  
 ③ 0=DI or PR, 1=PT.



Table 3-1. Terminal Characteristics (Sheet 4 of 4)

Mnemonic	Number (Octal)	Values (Octal) by Terminal Type		
		Asynchronous	Mode 4	HASP
Parity (PA)	57	0-3 ① ②	E	E
Abort output line character (AL)	60	0-177 ③	I	I
Interruption character (B1)	61	0-177 ③	0-177 ③	0-177 ③
Termination character (B2)	62	0-177 ③	0-177 ③	0-177 ③

0-1 values: 0=no, 1=yes.  
 E This parameter is invalid for this terminal class.  
 I This parameter is ignored for this terminal class.  
 ① Illegal for terminal class 4.  
 ② 0=zero parity, 1=odd parity, 2=even parity, 3=no parity.  
 ③ Excluding 000 (NUL), 002 (STX), 004 (EOT), 012 (LF), 015 (CR), 040 (space), and 075 (=).

## RBF COMMANDS

ABORT,dev or  
ABT,dev

Terminates a file being processed by input or output device and purges the file from the system.

dev	Device type:
	CPn            Card punch.
	CRn            Card reader.
	LPn            Line printer.
	PLn            Plotter.
	ALL            All devices.
	omitted       Same as LP1.

n is the device number assigned to the device. If n is omitted, n=1 is assumed. If n=A, all devices of that type are affected.

CANCEL,queue or  
CAN,queue

Cancels extended effects on queue of previous DIVERT command with EXT parameter selected.

queue	One of the following:
	PR            Print queue.
	PT            Plotter queue.
	PU            Punch queue.
	ALL           All queues.
	omitted       Same as ALL.

CHANGE, JOB=jsn, queue, PRI=pppp, REP=rpent or  
CHG, JOB=jsn, queue, PRI=pppp, REP=rpent

Changes priority and/or repeat count of an output file while in output queue.

jsn Four-character job sequence name identifying the output file; can be specified without JOB=.

queue One of the following:

PR Print queue.

PT Plotter queue.

PU Punch queue.

ALL All queues.

omitted Same as PR.

pppp A one- through four-character octal integer specifying the new priority.

rpent A one- or two-digit integer from 0 to 31 specifying the new repeat count. If omitted, rpent=1 is assumed. If REP=rpent is omitted, repeat count is not changed.

DISPLAY, type, RFR or  
DIS, type, RFR

Displays job, file, or device status information.

type Status information for:

PR Print files.

PT Plot files.

PU Punch files.

IN Jobs in input queue.

EX Jobs in execution queue.

DEV Remote batch I/O devices and extended DIVERT commands.

JOB=jsn All system queues  
or pertaining to the  
jsn specified job or file.

omitted Same as DEV.

RFR Optional parameter specifying that the display is to be refreshed and updated at regular intervals; not applicable when DEV is specified.

DIVERT, JOB=jsn, queue, FAM=famname, USR=username, EXT or  
DIV, JOB=jsn, queue, FAM=famname, USR=username, EXT or  
DIVERT, JOB=jsn, queue, HST, EXT or  
DIV, JOB=jsn, queue, HST, EXT

Transfers or reroutes your files and/or jobs to a different destination.

jsn Four-character job sequence name of job or file to be diverted; can be specified without JOB=. If jsn is not specified, all files with same user name, family name, and origin type combination as the terminal from which command is entered are diverted.

queue One of the following:

PR Print queue.

PT Plotter queue.

PU Punch queue.

IN Input queue.

EX Execution queue.

ALL All queues except if HST or EXT is specified; then ALL indicates all output queues.

omitted Same as ALL, if a jobname is specified. Same as output queues if HST or EXT is specified.

famname One- through seven-character family name. If FAM=famname is not specified, the family name of the logged-in user is assumed.

username One- through seven-character name identifying the terminal user to whom jobs and/or files are to be diverted.

EXT Optional parameter specifying that the DIVERT command is extended to jobs and/or files not yet existing; cannot be used with JOB=, ALL, EXT, or IN.

HST           Parameter specifying that jobs and/or files are to be output on the host computer peripherals. If FAM=famname and USR=username are omitted, HST is assumed.

END

Logs you out of RBF and allows selection of another application.

GO,dev or  
G,dev

Enables data transmission to or from device that is stopped.

dev           Device type:

CPn	Card punch.
CRn	Card reader.
LPn	Line printer.
PLn	Plotter.
ALL	All devices.
omitted	Same as LP1.

n specifies the device number assigned to the device. If n is omitted, n=1 is assumed. If n=A, all devices of that type are affected.

IAF

Logs you out of RBF and connects the terminal to the Interactive Facility.

LOGIN

Logs you out of RBF and reinitiates the login sequence.

LOGOFF

Logs you out of RBF and disconnects the terminal.

## LOGON

Logs you out of RBF and reinitiates the login sequence. (Same as LOGIN command.)

## LOGOUT

Logs you out of RBF and disconnects the terminal. (Same as LOGOFF command.)

PURGE,JOB=jsn,queue or  
PUR,JOB=jsn,queue

Drops an executing job or purges a file from the system queues.

jsn Four-character job sequence name of the job to be dropped or the file to be purged; can be specified without JOB=. If JOB=jsn is omitted, queue must be specified.

queue One of the following:

PR Print queue.

PT Plotter queue.

PU Punch queue.

IN Input queue.

EX Execution queue.

ALL All queues. If jobname is omitted, all jobs belonging to the user that reside in the queue specified are purged.

omitted Queue is ALL, and jobname must be specified.

RESTORE,dev,opt or  
RES,dev,opt

Restores acknowledging of input files, printing of the banner, and/or printing under printer format control, all of which were suppressed by a previous SUPPRESS command.

dev Device type:

CRn Card reader.

LPn            Line printer.

n is the device ordinal assigned to the specified device. Defaults depend upon opt parameter.

opt            One or more of the following:

ACK	Displays acknowledgment message (jsn) at the terminal to indicate the end of each input file transmission. If dev is not specified, CR1 is assumed.
BAN	Restores banner page printing at the beginning of the next print file. If dev is not specified, LP1 is assumed.
FMT	Restores print format control immediately. If dev is not specified, then LP1 is assumed.
omitted	Same as ACK, if CRn is specified. Same as FMT, if LPn is specified.

If no parameters are specified, RESTORE,LP1,FMT is assumed.

RESUME or  
R

Causes terminal to resume batch operations if a batch I/O device can transfer data immediately. RESUME or R has no effect on a device stopped because of device failure or on status of STOP or STOP/ABT, and is ignored if entered from a HASP protocol terminal.

RETURN,device,PRI=pppp or  
RET,device,PRI=pppp

Returns an output file active on a device to its queue.

device        One of the following:

CPn	Punch.
LPn	Print.

PLn	Plotter.
ALL	All files.
omitted	Same as LP1.

n is the device number assigned to the device. If n is omitted, n=1 is assumed. If n=A, all devices of that type are affected.

pppp One- through four-digit octal integer that specifies the new scheduler priority. If pppp is omitted, the file is returned to the lowest nonzero priority allowed by the system.

REWIND,dev or  
REW,dev

Rewinds a file currently at an output device.

dev Device type:

CPn	Card punch.
LPn	Line printer.
PLn	Plotter.
ALL	All devices.
omitted	Same as LP1.

n is the device number assigned to the device. n=A implies that files at all devices of the specified type are to be rewound.

SET,dev,REP=rpcent,FMS=fmscode,WID=width,BLK=size

Sets the repeat count of a file at an output device, changes the forms code of an output device, and/or specifies the maximum number of characters that can be printed on one line.

dev Device type:

CPn	Card punch.
LPn	Line printer.
PLn	Plotter.
omitted	Same as LP1.



n is the device number assigned to the device. If n is omitted, n=1 is assumed. If n=A, all devices of that type are affected.

rpcent One- or two-digit decimal integer from 0 through 31 that specifies the number of additional file copies desired. If rpcent is omitted, REP=0 is assumed. If REP=rpcent is omitted, the repeat count is not changed.

fmscode Two alphanumeric character identifiers used to change the forms code of the output device. If fmscode is omitted, existing forms code is removed (default is blanks). If FMS=fmscode is omitted, the forms code is not changed.

width Decimal value from 50 through 150 that specifies the maximum number of characters that can be printed on a line. If width is omitted, the printer width specified when printer was initially connected to RBF is assumed. If WID=width is omitted, print width is not changed.

size Block size specifies the maximum size block that is sent to output device. If size is omitted, default value of 200 decimal is used. Maximum size is 2043 decimal.

SKIP,dev,+val or  
SKP,dev,+val

Repositions the file currently on an output device.

dev Device type:

CPn Card punch.

LPn Line printer.

PLn Plotter.

omitted Same as LP1.

n is the device number assigned to the specified device. If n is omitted, n=1 is assumed. If n=A, all devices of that type are affected.

val One of the following:

Any integer from 1 through 4095 that specifies the number of file sectors in multiples of eight to skip forward (+) or backward (-). A value of 1 means 8 sectors are skipped, 2 means 16 sectors are skipped, and so on. If +val is omitted, +1 is assumed.

DFL Causes skipping to the beginning of dayfile, if one exists; applies only to print files.

END Repositions file to EOI. Repeat counts are honored.

STOP,dev,END or  
S,dev,END

Causes the file transmission to be suspended and the specified device to be stopped.

dev Device type:

CPn Card punch.

CRn Card reader.

LPn Line reader.

PLn Plotter.

ALL All devices.

omitted Same as LP1.

n is the device number assigned to the device. If n is omitted, n=1 is assumed. If n=A, all devices of that type are affected.

END Optional parameter specifying that transmission is to be stopped when end of current file is encountered; selected by default for card readers.

SUPPRESS,dev,opt or  
SUP,dev,opt

Suppresses acknowledgment of input files,  
printing of the banner, and/or format control.

dev Device type:

CRn Card reader.

LPn Line printer.

n is the device number assigned to the  
specified device. Defaults depend  
upon opt parameter.

opt One or more of the following:

ACK Suppresses acknowledgment  
message at the terminal to  
indicate the end of each  
input file transmission.  
If dev is not specified,  
CR1 is assumed.

BAN Suppresses banner page  
printing at the beginning  
of the next print file and  
for subsequent files. If  
dev is not specified, then  
LP1 is assumed.

FMT Causes printing of current  
file, except banner page,  
to be single spaced.  
Carriage control characters  
are printed as leftmost  
characters of each line.  
If dev is not specified,  
then LP1 is assumed.

omitted Same as ACK, if CRn is  
specified. Same as FMT, if  
LPn is specified.

If no parameters are specified, SUPPRESS,LP1,FMT  
is assumed.

---

## MCS COMMANDS

### BYE application

Logs you out of MCS and connects you to specified application. If BYE is specified without an application, the system disconnects you from MCS and network control.

### DATA

Switches terminal from command mode to data mode.

### DISABLE

Disables the terminal. Terminal cannot send and/or receive application messages but can perform all command mode activities.

### DISPLAY name

Displays information about the current status of input and output queues.

<u>name</u>	<u>Description</u>
ALL	Displays status of both input and output queues.
INPUT	Displays status of all input queues.
LAST	Displays serial number of last message received from the terminal.
OUTPUT	Displays status of all output queues
queue	Displays status of specified queue. Queue is the name of an output or input queue defined in the application definition.

### ENABLE

Reestablishes connection between MCS and the terminal. Terminal can send and receive application messages.

#### END application

Logs you out of MCS and connects you to specified application. If END is specified without an application, the system reissues the request for entry of an application.

#### GOODBYE application

Logs you out of MCS and connects you to specified application. If GOODBYE is specified without an application, the system disconnects the terminal from MCS and from the network.

#### HELLO application

Logs you out of MCS and connects you to specified application. If HELLO is specified without an application, the system reissues the request for entry of an application.

#### LOGIN application

Same as HELLO command.

#### LOGOFF application

Same as GOODBYE command.

#### LOGON application

Same as HELLO command.

#### LOGOUT application

Same as GOODBYE command.

#### MESSAGE "string"

Sends the message string to the applications operator. "string" is 80 characters or less.

## TVF COMMANDS

END

Terminates terminal's connection to TVF.

ENDL

Terminates loopback test.

HELP

Displays a list of all legal TVF commands.

TEST

Displays a list of all available terminal verification tests.

1

Initiates loopback test. TVF displays the message

LOOPBACK TEST BEGINS

..

TVF returns to the terminal each line of text entered until the ENDL command is entered.

2

Initiates line test. TVF displays the message

LINE TEST BEGINS

..

TVF returns a string of characters identical to the next character entered from the terminal. The length of the string is the current page width value for the terminal.

Initiates screen test. TVF displays the message

SCREEN TEST BEGINS

..

If a character is entered from the terminal, TVF clears the screen and displays one screen or page of repetitions of the character. If a carriage return is entered from the terminal, TVF clears the screen and displays one screen or page of repeated portions of the ASCII 96-character set.

## **APPENDIX A**

### **CHARACTER SETS**



Table A-1: Interactive Character Sets  
(Sheet 1 of 4)

ASCII Graphic (64 Char)	ASCII Character (128 Char)	Display Code	6/12 Display Code	12-Bit ASCII Code
: colon†	: colon†	00 †		
Display code 00 is undefined at sites using the 63-character set.				
A	A	01	01	0101
B	B	02	02	0102
C	C	03	03	0103
D	D	04	04	0104
E	E	05	05	0105
F	F	06	06	0106
G	G	07	07	0107
H	H	10	10	0110
I	I	11	11	0111
J	J	12	12	0112
K	K	13	13	0113
L	L	14	14	0114
M	M	15	15	0115
N	N	16	16	0116
O	O	17	17	0117
P	P	20	20	0120
Q	Q	21	21	0121
R	R	22	22	0122
S	S	23	23	0123
T	T	24	24	0124
U	U	25	25	0125
V	V	26	26	0126
W	W	27	27	0127
X	X	30	30	0130
Y	Y	31	31	0131
Z	Z	32	32	0132
0	0	33	33	0060
1	1	34	34	0061
2	2	35	35	0062
3	3	36	36	0063
4	4	37	37	0064
5	5	40	40	0065
6	6	41	41	0066
7	7	42	42	0067
8	8	43	43	0070
9	9	44	44	0071
+	+	45	45	0053
-	-	46	46	0055
*	*	47	47	0052

† This value applies to the 64-character set. The line below shows the value for the 63-character set. In ASCII mode for interactive jobs, a colon (: ) is represented as a 7404<sub>8</sub> 6/12 display code.

Table A-1. Interactive Character Sets  
(Sheet 2 of 4)

ASCII Graphic (64 Char)	ASCII Character (128 Char)	Display Code	6/12 Display Code	12-Bit ASCII Code
/	/	50	50	0057
(	(	51	51	0050
)	)	52	52	0051
\$	\$	53	53	0044
=	=	54	54	0075
space	space	55	55	0040
, comma	, comma	56	56	0054
. period	. period	57	57	0056
# num. sign	# num. sign	60	60	0043
[ l. bracket	[ l. bracket	61	61	0133
] r. bracket	] r. bracket	62	62	0135
% †	% †	63 †	63 †	0045
: colon	: colon	63	63	0072
" quote	" quote	64	64	0042
_ underline	_ underline	65	65	0137
! †	! †	66	66	0041
& ampersand	& ampersand	67	67	0046
' apostrophe	' apostrophe	70	70	0047
? †	? †	71	71	0077
<	<	72	72	0074
>	>	73	73	0076
@		74		
\ rev. slant	\ rev. slant	75	75	0134
^ circumflex		76		
; semicolon	; semicolon	77	77	0073
	@		7401	0100
	^ circumflex		7402	0136
	: colon †		7404 †	0072
	* †		7404	0045
	` grave accent		7407	0140
	a		7601	0141
	b		7602	0142
	c		7603	0143
	d		7604	0144
	e		7605	0145
	f		7606	0146
	g		7607	0147

† This value applies to the 64-character set. The line below shows the value for the 63-character set. In ASCII mode for interactive jobs, a colon (: ) is represented as a 7404<sub>8</sub> 6/12 display code.

Table A-1. Interactive Character Sets  
(Sheet 3 of 4)

ASCII Graphic (64 Char)	ASCII Character (128 Char)	Display Code	6/12 Display Code	12-Bit ASCII Code
	h		7610	0150
	i		7611	0151
	j		7612	0152
	k		7613	0153
	l		7614	0154
	m		7615	0155
	n		7616	0156
	o		7617	0157
	p		7620	0160
	q		7621	0161
	r		7622	0162
	s		7623	0163
	t		7624	0164
	u		7625	0165
	v		7626	0166
	w		7627	0167
	x		7630	0170
	y		7631	0171
	z		7632	0172
	{ left brace		7633	0173
	vert. line		7634	0174
	} right brace		7635	0175
	~ tilde		7636	0176
	DEL		7637	0177
	NUL		7640	4000
	SOH		7641	0001
	STX		7642	0002
	ETX		7643	0003
	EOT		7644	0004
	ENQ		7645	0005
	ACK		7646	0006
	BEL		7647	0007
	BS		7650	0010
	HT		7651	0011
	LF		7652	0012
	VT		7653	0013
	FF		7654	0014
	CR		7655	0015
	SO		7656	0016
	SI		7657	0017

Table A-1. Interactive Character Sets  
(Sheet 4 of 4)

ASCII Graphic (64 Char)	ASCII Character (128 Char)	Display Code	6/12 Display Code	12-Bit ASCII Code
	DLE		7660	0020
	DC1		7661	0021
	DC2		7662	0022
	DC3		7663	0023
	DC4		7664	0024
	NAK		7665	0025
	SYN		7666	0026
	ETB		7667	0027
	CAN		7670	0030
	EM		7671	0031
	SUB		7672	0032
	ESC		7673	0033
	FS		7674	0034
	GS		7675	0035
	RS		7676	0036
	US †		7677	0037
† Reserved for network use.				

Table A-2. Batch Character Sets (Sheet 1 of 6)

CDC Graphic (64 Char)	ASCII Graphic (64 Char)	ASCII Graphic (95 Char)	Display Code	6/12 Display Code	12-Bit ASCII Code	Punch Code	
						026	029
: colon†	: colon†		00†			8-2	8-2
Display code 00 is undefined at sites using the 63-character set.							
A	A	A	01	01	0101	12-1	12-1
B	B	B	02	02	0102	12-2	12-2
C	C	C	03	03	0103	12-3	12-3
D	D	D	04	04	0104	12-4	12-4
E	E	E	05	05	0105	12-5	12-5
F	F	F	06	06	0106	12-6	12-6
G	G	G	07	07	0107	12-7	12-7
H	H	H	10	10	0110	12-8	12-8
I	I	I	11	11	0111	12-9	12-9
J	J	J	12	12	0112	11-1	11-1
K	K	K	13	13	0113	11-2	11-2
L	L	L	14	14	0114	11-3	11-3
M	M	M	15	15	0115	11-4	11-4
N	N	N	16	16	0116	11-5	11-5
O	O	O	17	17	0117	11-6	11-6
†This value applies only to the 64-character set. Display code 00 is undefined in the 63-character set.							

Table A-2. Batch Character Sets (Sheet 2 of 6)

CDC Graphic (64 Char)	ASCII Graphic (64 Char)	ASCII Graphic (95 Char)	Display Code	6/12 Display Code	12-Bit ASCII Code	Punch Code	
						026	029
P	P	P	20	20	0120	11-7	11-7
Q	Q	Q	21	21	0121	11-8	11-8
R	R	R	22	22	0122	11-9	11-9
S	S	S	23	23	0123	0-2	0-2
T	T	T	24	24	0124	0-3	0-3
U	U	U	25	25	0125	0-4	0-4
V	V	V	26	26	0126	0-5	0-5
W	W	W	27	27	0127	0-6	0-6
X	X	X	30	30	0130	0-7	0-7
Y	Y	Y	31	31	0131	0-8	0-8
Z	Z	Z	32	32	0132	0-9	0-9
0	0	0	33	33	0060	0	0
1	1	1	34	34	0061	1	1
2	2	2	35	35	0062	2	2
3	3	3	36	36	0063	3	3
4	4	4	37	37	0064	4	4

Table A-2. Batch Character Sets (Sheet 3 of 6)

CDC Graphic (64 Char)	ASCII Graphic (64 Char)	ASCII Graphic (95 Char)	Display Code	6/12 Display Code	12-Bit ASCII Code	Punch Code	
						026	029
5	5	5	40	40	0065	5	5
6	6	6	41	41	0066	6	6
7	7	7	42	42	0067	7	7
8	8	8	43	43	0070	8	8
9	9	9	44	44	0071	9	9
+	+	+	45	45	0053	12	12-8-6
-	-	-	46	46	0055	11	11
*	*	*	47	47	0052	11-8-4	11-8-4
/	/	/	50	50	0057	0-1	0-1
(	(	(	51	51	0050	0-8-4	12-8-5
)	)	)	52	52	0051	12-8-4	11-8-5
\$	\$	\$	53	53	0044	11-8-3	11-8-3
=	=	=	54	54	0075	8-3	8-6
space	space	space	55	55	0040	no punch	no punch
, comma	, comma	, comma	56	56	0054	0-8-3	0-8-3
. period	. period	. period	57	57	0056	12-8-3	12-8-3

Table A-2. Batch Character Sets (Sheet 4 of 6)

CDC Graphic (64 Char)	ASCII Graphic (64 Char)	ASCII Graphic (95 Char)	Display Code	6/12 Display Code	12-Bit ASCII Code	Punch Code	
						026	029
≡ equiv.	# num. sign	# num. sign	60	60	0043	0-8-6	8-3
[ l. bracket	[ l. bracket	[ l. bracket	61	61	0133	8-7	12-8-2
] r. bracket	] r. bracket	] r. bracket	62	62	0135	0-8-2	11-8-2
% †	% †	% †	63 †	63 †	0045	8-6	0-8-4
: colon	: colon	: colon	63	63	0072	8-2	8-2
“ quote	“ quote	“ quote	64	64	0042	8-4	8-7
⎵ underline	⎵ underline	⎵ underline	65	65	0137	0-8-5	0-8-5
∨	! !	! !	66	66	0041	11-0	12-8-7
∧	& ampersand	& ampersand	67	67	0046	0-8-7	12
↑	' apostrophe	' apostrophe	70	70	0047	11-8-5	8-5
↓	? ?	? ?	71	71	0077	11-8-6	0-8-7
<	<	<	72	72	0074	12-0	12-8-4
>	>	>	73	73	0076	11-8-7	0-8-6
@	@	@	74			8-5	8-4
\ rev. slant	\ rev. slant	\ rev. slant	75	75	0134	12-8-5	0-8-2
^ circumflex	^ circumflex	^ circumflex	76			12-8-6	11-8-7
; semicolon	; semicolon	; semicolon	77	77	0073	12-8-7	11-8-6

† This value applies only to the 64-character set. The line below shows the value for the 63-character set.



Table A-2. Batch Character Sets (Sheet 5 of 6)

CDC Graphic (64 Char)	ASCII Graphic (64 Char)	ASCII Graphic (95 Char)	Display Code	6/12 Display Code	12-Bit ASCII Code	Punch Code	
						026	029
		@		7401	0100		
		^ circumflex		7402	0136		
		: colon†		7404	0072		
		~		7404	0045		
		` grave accent		7407	0140		
		a		7601	0141		
		b		7602	0142		
		c		7603	0143		
		d		7604	0144		
		e		7605	0145		
		f		7606	0146		
		g		7607	0147		
		h		7610	0150		
		i		7611	0151		
		j		7612	0152		
		k		7613	0153		

†This value applies only to the 64-character set. The line below shows the value for the 63-character set.

Table A-2. Batch Character Sets (Sheet 6 of 6)

CDC Graphic (64 Char)	ASCII Graphic (64 Char)	ASCII Graphic (95 Char)	Display Code	6/12 Display Code	12-Bit ASCII Code	Punch Code	
						026	029
		l		7614	0154		
		m		7615	0155		
		n		7616	0156		
		o		7617	0157		
		p		7620	0160		
		q		7621	0161		
		r		7622	0162		
		s		7623	0163		
		t		7624	0164		
		u		7625	0165		
		v		7626	0166		
		w		7627	0167		
		x		7630	0170		
		y		7631	0171		
		z		7632	0172		
		{ left brace		7633	0173		
		vert. line		7634	0174		
		} right brace		7635	0175		
		~ tilde		7636	0176		

Table A-3. ASCII to 6/12 Display Code Conversion  
(Sheet 1 of 3)

ASCII Character (128 Char)	12-Bit ASCII Code		6/12 Display Code
	Octal	Hex	
NUL	4000	00	7640
SOH	0001	01	7641
STX	0002	02	7642
ETX	0003	03	7643
EOT	0004	04	7644
ENQ	0005	05	7645
ACK	0006	06	7646
BEL	0007	07	7647
BS	0010	08	7650
HT	0011	09	7651
LF	0012	0A	7652
VT	0013	0B	7653
FF	0014	0C	7654
CR	0015	0D	7655
SO	0016	0E	7656
SI	0017	0F	7657
DLE	0020	10	7660
DC1	0021	11	7661
DC2	0022	12	7662
DC3	0023	13	7663
DC4	0024	14	7664
NAK	0025	15	7665
SYN	0026	16	7666
ETB	0027	17	7667
CAN	0030	18	7670
EM	0031	19	7671
SUB	0032	1A	7672
ESC	0033	1B	7673
FS	0034	1C	7674
GS	0035	1D	7675
RS	0036	1E	7676
US †	0037	1F	7677 †
space	0040	20	55
!	0041	21	66
" quote	0042	22	64
# number sign	0043	23	60
\$	0044	24	53
% ††	0045	25	63 ††
%	0045	25	7404
& ampersand	0046	26	67
' apostrophe	0047	27	70

† The interpretation of this character or code may depend on its context.

†† Reserved for network use.

Table A-3. ASCII to 6/12 Display Code Conversion  
(Sheet 2 of 3)

ASCII Character (128 Char)	12-Bit ASCII Code		6/12 Display Code
	Octal	Hex	
(	0050	28	51
)	0051	29	52
*	0052	2A	47
+	0053	2B	45
, comma	0054	2C	56
-	0055	2D	46
. period	0056	2E	57
/	0057	2F	50
0	0060	30	33
1	0061	31	34
2	0062	32	35
3	0063	33	36
4	0064	34	37
5	0065	35	40
6	0066	36	41
7	0067	37	42
8	0070	38	43
9	0071	39	44
: colon†	0072	3A	7404†
: colon	0072	3A	63
; semicolon	0073	3B	77
<	0074	3C	72
=	0075	3D	54
>	0076	3E	73
?	0077	3F	71
@	0100	40	7401
A	0101	41	01
B	0102	42	02
C	0103	43	03
D	0104	44	04
E	0105	45	05
F	0106	46	06
G	0107	47	07
H	0110	48	10
I	0111	49	11
J	0112	4A	12
K	0113	4B	13
L	0114	4C	14
M	0115	4D	15
N	0116	4E	16
O	0117	4F	17

† Reserved for network use.

Table A-3. ASCII to 6/12 Display Code Conversion  
(Sheet 3 of 3)

ASCII Character (128 Char)	12-Bit ASCII Code		6/12 Display Code
	Octal	Hex	
P	0120	50	20
Q	0121	51	21
R	0122	52	22
S	0123	53	23
T	0124	54	24
U	0125	55	25
V	0126	56	26
W	0127	57	27
X	0130	58	30
Y	0131	59	31
Z	0132	5A	32
[ left bracket	0133	5B	61
\ reverse slant	0134	5C	75
] right bracket	0135	5D	62
^ circumflex	0136	5E	7402
_ underline	0137	5F	65
^ grave accent	0140	60	7407
a	0141	61	7601
b	0142	62	7602
c	0143	63	7603
d	0144	64	7604
e	0145	65	7605
f	0146	66	7606
g	0147	67	7607
h	0150	68	7610
i	0151	69	7611
j	0152	6A	7612
k	0153	6B	7613
l	0154	6C	7614
m	0155	6D	7615
n	0156	6E	7616
o	0157	6F	7617
p	0160	70	7620
q	0161	71	7621
r	0162	72	7622
s	0163	73	7623
t	0164	74	7624
u	0165	75	7625
v	0166	76	7626
w	0167	77	7627
x	0170	78	7630
y	0171	79	7631
z	0172	7A	7632
{ left brace	0173	7B	7633
vertical line	0174	7C	7634
} right brace	0175	7D	7635
~ tilde	0176	7E	7636
DEL	0177	7F	7637

CORPORATE HEADQUARTERS  
P.O. BOX 0  
MINNEAPOLIS, MINNESOTA 55440

SALES OFFICES AND SERVICE CENTERS  
IN MAJOR CITIES  
THROUGHOUT THE WORLD

PRINTED IN U.S.A.

---

---



CONTROL DATA CORPORATION