### **CONTENTS**

1 General Information	4
1.1 \( \frac{\lambda}{\text{ \text{ Safety Instructions}}} \)	4
1.2 Switching the Operating Voltage 230 V~/115 V~	4
1.3 Mains Connection	5
1.4 Installing the AFG 100	5
1.5 Switching on	5
1.6 Inspection and Maintenance	5
1.7 EMC	5
1.8 Warranty	6
1.9 Accessories Supplied	6
2 Application	7
3 Configuration and Functional Description	8
3.1 Block Diagram	8
3.2 Description	9
4 Technical Data	10
4.1 General Data	10
4.2 Specifications	10
4.2.1 Signal Output 1.1.2 Arbitrary Signal	10 11
1.1.3 Sweep Function	11
1.1.4 Amplitude Modulation	11
1.1.5 Square-wave Sync Output	12
1.3 Display	12
1.4 Remote Control	12
5 Control Elements	13
6 Operation of the AFG 100	15
6.1 Introduction	15
6.2 Starting	16
6.3 Operating Parameters	18
6.3.1 Setting the Frequency (FREQ)	18
6.3.2 Setting the Output Level (LEVEL)	18 19
<ul><li>6.3.3 Setting the Dc Voltage Offset (OFFSET)</li><li>6.3.4 Selection of the Wave Form (WAVE)</li></ul>	20
6.3.4.1 Input of the Sample Period at Arbitrary Signals (FREQ)	20
6.4 Operating Modes	21

6.4.1 Activating the Outputs	21
6.4.1.1 Switching on/off the Signal Output (SIGNAL)	21
6.4.1.2 Switching on/off the Sync Output (SYNC)	22
6.4.2 Activating the Sweep Function	22
6.4.2.1 Switching on/off the Sweep Function (MOD)	23
6.4.2.2 Input of the Frequency Limits (FREQ)	23
6.4.2.3 Input of the Period (ST)	24
6.4.3 Activating the Amplitude Modulation (AM)	25 25
6.4.3.1 Switching on/off the AM (MOD) 6.4.3.2 Input of the Modulation Depth at Internal AM (DEPTH)	25 26
6.4.3.3 Input of the Modulation Frequency at Internal AM (F)	27
	28
6.5 User Settings of the AFG 100 6.5.1 Switching on/off the Initialization Test (PS)	28
6.5.2 Self-Diagnosis of the AFG 100 (TEST)	29 29
6.5.3 Display	29
6.5.3.1 Contrast Setting of the Display (CONT)	29
6.5.3.2 Brightness Setting of the Display (BRIGHT)	30
6.5.4 Instrument Settings	31
6.5.4.1 Saving the Current Instrument Settings (STO)	31
6.5.4.2 Loading the Instrument Settings (RCL)	32
6.6 The Special Functions of the AFG 100 (SPC)	33
6.7 Protection of the Signal Output	34
7 Remote Control by Program	35
v e	35
<b>7.1 Preparation of the AFG 100</b> 7.1.1 Selecting the Interface Parameters	35
7.1.1 Selecting the Interface Farameters 7.1.1.1 Setting the Baud Rate (BDR)	36
7.1.1.1 Setting the Batta Rate (BBR) 7.1.1.2 Setting the Transmission Protocol (PROT)	36
7.1.2 Sching the Transmission Protecti (FROT) 7.1.2 Local Control ⇔ Remote Control	37
	38
<b>7.2 Messages of the AFG 100 on Remote Control</b> 7.2.1 Description of the Unit Status	38
7.2.1.1 ESR - EVENT STATUS REGISTER	38 38
7.2.1.2 STB - STATUS BYTE REGISTER	39
7.2.2 Description of Errors	40
7.2.2.1 DER - DEVICE ERROR REGISTER	40
7.2.2.2 Error Messages	41
7.3 List of Commands on Remote Control	42
7.3.1 General Commands	42
7.3.1.1 Interface Commands	42
7.3.1.2 Initializing the Instrument Settings	42
7.3.1.3 Self-Diagnosis of the AFG 100	42
7.3.1.4 Identification of the AFG 100	43
7.3.1.5 Initializing the Status Structure	43
7.3.1.6 Sync Commands	43
7.3.1.7 Query of the Instrument Status	43
7.3.2 Instrument Settings and Messages	44
7.3.2.1 Output Frequency 7.3.2.2 Sample Period at Arbitrary Signals	44 44

7.3.2.3 Output Level	44
7.3.2.4 Dc Voltage Offset of the Output Signal	45
7.3.2.5 Wave Form of the Output Signal	45
7.3.2.6 Switching State of the Signal and Sync Outputs 7.3.2.7 Sweep Function	46 46
7.3.2.8 Amplitude Modulation	40 47
7.3.2.9 Saving the Arbitrary Signals	48
7.3.2.10 Password Input	50
7.4 Programming Notes	51
7.5 Program Example for Square-wave Signal (Q Basic)	52
8 Loading External Arbitrary Signals	53
8.1 File Creation	53
8.1.1 Structure of a TXT File (ASCII)	53
8.1.2 Structure of a BIN File (HEX)	53
8.2 Data Transmission	54
8.2.1 Transmission of a TXT file	54
8.2.1.1 Transmission via MS DOS	54
8.2.1.2 Transmission via Windows with the Help of the TERMINAL Program	54 5.5
8.2.2 Transmission of a BIN File	55
8.2.2.1 Transmission via MS DOS	55 56
8.2.2.2 Transmission via Windows with the Help of the TERMINAL Program 8.2.3 Transmission with Special Program	56
8.3 Activating the Arbitrary Signal	57
8.4 Contents of Enclosed Diskette	57
9 Care and Maintenance	58
10 Appendix	59
10.1 List of Operating Functions	59
10.2 List of Instrument Messages	60

### 1 General Information

### 1.1 / Safety Instructions

<b>F</b>	Note	Wherever	you see	this si	ign <u> y</u> o	u will	find	information	on
		potential h	azards. I	Please ro	ead these s	ections	with 1	particular ca	re!

Warning! Before opening the AFG 100 disconnect the mains plug!

Our instrument fuses are dimensioned in such a way that optimum protection is guaranteed for the AFG 100 and the user.

If the fuse has to be changed, use only G fuse-link  $5 \times 20$  according to IEC 127 (see 4.1)!

Attention! The T250 replacement fuses contained in the accessories are intended for a mains voltage of 115 V and must not be used at a mains voltage of 230 V!

### 1.2 Switching the Operating Voltage 230 V~/115 V~

Your AFG 100 left the factory set to 230 V. Switching to 115 V requires the AFG 100 to be opened, which should only be done by trained personnel.

Setting the operating voltage 115 V~

- **1.** Disconnect the AFG 100 from the mains.
- **2.** Remove upper caps and loosen the screws below.
- **3.** Identify the mains voltage switch by means of the following illustration.
- **4.** Switch the mains voltage switch (slide switch) located under the power switch to the indication "115".
- **5.** Remove safety cover at the mains plug and replace the fuse with the fuse for 115 V supplied with the instrument.
- **6.** Fasten upper caps and put the sticker supplied with the instrument for marking the switch-over to 115 V on to the type label.

#### Mains voltage switch



115 V position



230 V position

#### 1.3 Mains Connection



### /!\ Attention!

The design of the unit meets the requirements of safety class I according to EN 61010-1, i. e. all metal parts accessible from outside and exposed to contact are connected with the protective conductor of the supply network.

Power is supplied via a mains cable with an earthing contact.

### 1.4 Installing the AFG 100



Attention!

The AFG 100 should not be operated close to equipment that develops heat.

### 1.5 Switching on



The AFG 100 is switched on using the power switch at the front. The power switch separates the AFG 100 completely from the primary

side of the transformer.

The LED *I/O* serves as a status indicator.

### 1.6 Inspection and Maintenance



Attention!

If service is needed, due attention should be paid to the regulations according to VDE 0701. The AFG 100 should only be repaired by trained personnel.

#### **1.7 EMC**

Radio interference suppression

The AFG 100 is interference-free according to EN 50081 and EN 50082.

Prerequisite for EMC

In order to fulfil the limit values in line with present standards, it is absolutely essential that only cables which are in perfect condition be connected to the AFG 100. The following information applies here:

- Metallic or metallized socket cases must be used for the serial interface RS-232C. The socket cases and the braided screen of the cables must be connected at the shortest distance possible. The signal earth must not be connected to the braided screen.
- After opening and closing the AFG 100 check that all the fixing elements and contact springs are installed as before and that all the screws have been tightened.

5

### 1.8 Warranty

Conditions for warranty

Digimess guarantees the perfect working order of the AFG 100 for 12

months as from delivery.

There is no warranty for faults arising from improper operation or from changes made to the unit or from inappropriate application.

Returning the instrument

If a fault occurs please contact or send your AFG 100 to:

The AFG 100 should be returned in appropriate packing - if possible in the original packing. Please enclose a detailed fault report (functions working incorrectly, deviating specifications and so on)

including unit type and serial number.

Identification

Kindly verify warranty cases by enclosing your delivery note. Any repairs carried out without reference to a valid warranty will initially

be at the owner's expense.

Should the warranty have expired, we will, of course, be glad to repair your AFG 100 as per our General Terms Of Assembly And

Service.

### 1.9 Accessories Supplied

Contents 1 mains cable 1XK64100

1 coaxial cable 1AK64220

1 fine fuse T125 L/250 V (230 V) 2 fine fuses T250 L/250 V (115 V)

1 operating instructions

1 label for indicating the switch-over to 115 V

1 diskette with arbitrary signals and loading program

### 2 Application

### Performance features

The function generator AFG 100, controlled by a microprocessor, is a compact signal source. The AFG 100 uses the DDS (Direct Digital Synthesis) method and generates the following wave forms:

- Sinusoidal and square-wave signals in the frequency range of 0.01 Hz to 12.5 MHz
- Triangular and sawtooth-shaped signals from 0.01 Hz to 100 kHz
- Arbitrary signals with a sample rate up to 33.33 MSa/s and with a vertical resolution of 10 bits

#### Additional functions

The amplitude and the dc voltage offset of the output signal can be adjusted within a wide range.

The AFG 100 is fitted with a sweep function.

Furthermore, a square-wave signal (sync signal) with a CMOS/TTL level can be picked off.

# Operation via keybord

All functions and measuring ranges can be set via menus by means of four buttons and a rotary switch.

The chosen parameters of the output signal are clearly depicted on a two-line alphanumeric LC matrix display.

## Remote control via RS-232C


The instrument is equipped, as standard, with serial interface RS-232C for communication with a PC.

- All functions and parameters can be set.
- The settings and conditions of the AFG 100 can be transmitted.

7

### 3 Configuration and Functional Description

### 3.1 Block Diagram



- (1) Oscillator
- (2) Predivider
- (3) Phase accumulator
- (4) DDS RAM memory
- (5) D/A converter for DDS
- (6) Lowpass filter
- (7) Lowpass filter
- (8) Multiplexer
- (9) Analog multiplier
- (10) Signal amplifier
- (11) Output attenuator for 20 DB
- (12) Output attenuator for 10 dB
- (13) Output attenuator for 20 dB
- (14) Level control circuit of the output signal
- (15) AM oscillator

- (16) Circuit for the control of the amplitude modulation
- (17) Dc voltage offset generator
- (18) Comparator
- (19) Buffer of the output signal and CMOS/TTL converter
- (20) Microprocessor
- (21) RS-232C interface
- (22) Program memory EPROM
- (23) Data memory RAM
- (24) EEPROM memory for calibrating data
- (25) LC display
- (26) Keyboard with rotary switch
- (27) Power supply

### 3.2 Description

Internal control unit

The internal operational procedures are controlled by the one-chip microprocessor MCS-51 (20) with the help of additional circuits, e. g. program memory EPROM (22), data memory RAM (23) and memory EEPROM for the calibrating data (24).

Operating the AFG 100

The AFG 100 can be operated locally via the keyboard with the rotary switch (26) and via the LC display (25).

Remote control by a PC takes place via the serial interface RS-232C (21) and is controlled by the microprocessor.

Generation of the required wave form

The microprocessor (20) carries out the configuration and sets the hardware of the AFG 100 after the parameters have been selected.

The corresponding value for the phase accumulator (3) is calculated according to the frequency which has been entered. The phase accumulator works with a clock frequency derived from the frequency of the oscillator (1) and from the dividing ratio of the programmable frequency-predivider (2). According to the phase generated by the phase accumulator, the D/A converter (5) derives information about the amplitude of the signal from the DDS RAM memory (4).

Lowpass filters (6), (7) which reconstruct the required signal, are connected at both outputs of the D/A converter. The corresponding signal is forwarded via the switch logic (8).

Generation of the sync signal

A square-wave signal is formed from a sinusoidal signal with the help of the comparator (18). The square-wave signal is fed through the buffer stage (19) with CMOS logic level to the sync output.

Output level setting

The generated output signal is fed to the analog multiplier (9). The output level is set within the range from 0 to 10 dB by means of this circuit. The signal is also led to the amplifier (10) and to the output attenuators (11), (12), (13) in stages of 0, 10, 20, 30, 40 or 50 dB. According to the required value of the output level, the analog multiplier (9) and subsequently the damping of the output attenuators (11), (12), (13) are set via the level control circuit (14). The attenuated signal is led to the output socket of the AFG 100.

Amplitude modulation of the output signal

The output level of the AFG 100 can be influenced by amplitude modulation. This means that the internal AM oscillator (15) and an external AM signal can be used. The AM control circuit (16) feeds the selected AM signal through and with internal amplitude modulation, sets the required modulation depth of the output signal.

Setting the dc voltage offset

The dc voltage offset generator (17), a programmable current source is also connected to the output socket. The current source is controlled by the microprocessor (20) via the control circuit (14). The offset voltage generator permits setting of the dc voltage part of the output signal within a wide voltage range.

9

### 4 Technical Data

#### 4.1 General Data

Operating temperature:  $+ 5 ... + 40 \,^{\circ}\text{C}$ Nominal temperature:  $+ 23 \,^{\circ}\text{C} \pm 2 \,^{\circ}\text{C}$ 

Relative humidity:  $20 \dots 80 \%$ Atmospheric pressure:  $70 \dots 106 \text{ kPa}$ 

Operating position: horizontal or inclined by  $\pm$  15  $^{\circ}$  Operating voltage: sinusoidal alternating voltage

115/230 V (+ 10 %/– 15 %), internally switchable

50 ... 60 Hz (± 5 %)

Distortion factor less than 5 %

Power consumption: max. 27 VA (max. 27 W) Fuses: T125 L/250 V (230 V $\sim$ ) T250 L/250 V (115 V $\sim$ )

Dimensions  $5 \times 20$  mm, according to IEC 127

Safety class: I, according to EN 61010 Part 1

Radio interference suppression: EN 55011 Class B

Dimensions (L  $\times$  H  $\times$  D): 225 mm  $\times$  85 mm  $\times$  200 mm Dimensions of packing: 315 mm  $\times$  115 mm  $\times$  270 mm

Weight of

AFG 100: approx. 2.5 kg incl. packing and accessories: approx. 3.5 kg

### 4.2 Specifications

Frequency range: 0.01 Hz ... 12.5 MHz for sinusoidal and square-

wave signal

0.01 Hz ... 100 kHz for triangular and sawtooth

signal

Frequency setting: 5 places or

4 places + point position

Accuracy of frequency setting

(at nominal temperature):  $\pm 0.01 \% \pm 0.002 \text{ Hz}$ 

Temperature coefficient of frequency:  $\pm 100$  ppm in the range of the operating temperature

Warm-up time: 15 min

#### 4.2.1 Signal Output

Output impedance: 50  $\Omega \pm 1.5$  %, asymmetrical

Output voltage  $V_{PP}$ : 10 mV ... 10 V/50  $\Omega$ 

Maximum output level

incl. offset voltage:  $V_{PP} + |2V_{Offset}| \le 10.00 \text{ V}$ 

Setting the output voltage: 3 places

Accuracy of output voltage

at f = 1 kHz:  $\pm (2 \% + 20 \text{ mV})$ 

Additional frequency error

of output voltage:  $\pm 1 \text{ dB}$  in the range  $10 \text{ Hz} \dots 1 \text{ MHz}$ 

 $\pm$  3 dB in the range 0.01 Hz ... 12.5 MHz

Temperature coefficient

of output voltage:  $< \pm 5 \times 10^{-3}/K$ 

Dc voltage offset

of signal (V<sub>Offset</sub>):  $\pm 2.5 \text{ V/}50 \Omega$ 

Setting

of dc voltage offset: in 10 mV steps

Accuracy of setting

of dc voltage offset:  $\pm (1 \% + 20 \text{ mV})$ Output signal:  $\pm (1 \% + 20 \text{ mV})$ 

square-wave signal triangular signal

sawtooth signal (up, down)

arbitrary signal

Distortion of sinusoidal signal: < 0.5 % in the range  $10 \text{ Hz} \dots 100 \text{ kHz}$ 

Rise time of square-wave signal: < 25 ns

Overshooting of square-wave signal: < 5 % of the output voltage + 30 mV

Nonlinearity

of triangular signal (5 ... 95 %): < 1 %

4.2.2 Arbitrary Signal

Horizontal resolution

(length of the signal): 8,192 samples
Vertical resolution of the level: 1,024 level (10 bit)

Sample period:  $30 \text{ ns} \times 2^{N-1}, N = 1 \dots 32$ 

**4.2.3** Sweep Function

Frequency change

at sweep function: 0.01 Hz ... 12.5 MHz

(100 kHz for triangular and sawtooth signal)

Sweep mode: linear, logarithmic - discreet

Direction of frequency change: rising, falling

Repetition period

at sweep function: 10 ms ... 60 s

4.2.4 Amplitude Modulation

Source of modulation signal: internal, external

Frequency range

of external modulation input: 0 Hz ... 20 kHz

Amplitude of external signal ( $V_{PP}$ ): 2 V for AM modulation depth m = 100 %

Input impedance

of external AM input:  $100 \text{ k}\Omega$ 

Frequency range

of internal modulation oscillator: approx. 100 Hz ... 10 kHz, discreet frequency

results

Depth of amplitude modulation: 0 ... 100 %, in 1 % steps

at internal AM

#### 4.2.5 Square-wave Sync Output

Output impedance: approx.  $50 \Omega$ 

 $5 \text{ V} \pm 10 \%$  in the idling mode Output voltage V<sub>PP</sub>:

Maximum output current: 10 mA

Pulse duty ratio

for periodical signals: approx. 1:1

"start" pulse with a breadth of approx. 5 µs at sweep function:

### 4.3 Display

Set-up and display contents The AFG 100 is equipped with a  $2 \times 16$ -digit alphanumerical LC

matrix display with background lighting.

It indicates the set parameters of the output signal or the menu-

controlled functions and system messages.

#### **4.4 Remote Control**

Performance range The AFG 100 can be fully remote controlled and read via the serial

interface RS-232C. Data transfer is based on the ASCII character set.

Data transmission parameters

Baud rate in Bd (eligible): 1,200, 2,400, 4,800, 9,600, 19,200

1

Length of data character: 8 Bit Number of STOP bits:


Parity: none

Protocol: RTS/CTS, without (NONE)

Length of input buffer: 64 characters Length of output buffer: 256 characters Final character on receiving: LF (10 dec.)


Final characters on transmission: CR + LF (13 dec. + 10 dec.)

Plug connections of cable




### **5 Control Elements**

Front side of AFG 100



#### Rear side of AFG 100



#### [1] Power switch

#### [2] LED I/O

The LED indicates whether the AFG 100 is ready for operation.

#### [3] Display

See 4.3.

### [4] Rotary switch

The rotary switch makes it possible to adjust the measuring parameters and to scroll the current menu forwards and backwards. The sign  $\blacksquare$  in the display signals the parameter setting with the help of the rotary switch.

### [5] Function button F1 (with multiple allocation)

**FREQ** — The button opens the menu to set the frequency of the output signal.

◆ — The button changes between first and second line of the display.

- The button has different meanings in the menu levels.

### [6] Function button F2 (with multiple allocation)

**LEVEL** – The button opens the menu to set the level of the output signal.

The cursor is moved to the left in the menu.

- The button has different meanings in the menu levels.

#### [7] Function button F3 (with multiple allocation)

**WAVE** - The button opens the menu to set the wave form of the output

signal.

► The cursor is moved to the right in the menu.

- The button has different meanings in the menu levels.

### [8] Function button F4 (with multiple allocation)

MENU - The button opens the menu to set further parameters of the

AFG 100.

**ENTER** – With the help of this button the new parameter setting is

confirmed.

**LOC** − On remote control the AFG 100 changes to local control.

- The button has different meanings in the menu levels.

#### [9] **LED** *REM*

The LED lights up if the AFG 100 is being remote controlled via the PC.

### [10] LED OUTPUT

The LED lights up if the signal output is switched on.

#### [11] BNC socket of signal output

- [12] BNC socket of sync output
- [13] Plug of RS-232C interface

#### [14] Fused plug for non-heating appliances

The AFG 100 is protected by a T125 L/250 V fuse for 230 V $\sim$  or T250 L/250 V for 115 V $\sim$  net voltage respectively.

#### [15] Type plate

### [16] Operating voltage indication

The operating voltage indication shows which operating voltage is to be used.

#### [17] BNC input socket for external AM source

### 6 Operation of the AFG 100

#### 6.1 Introduction

Keyboard

The AFG 100 is operated via function buttons F1 to F4 with multiple functions.

In response to the operational status of the AFG 100 and the menudriven settings, the function buttons perform different tasks (see 5).

Menu control via display

After activating the function button F4 [8], menus and also menupoints are opened for settings

After opening a menu, the name of the menu is displayed in the top line of the display [3]. Function buttons F1 to F4 have the function as displayed in the bottom line of the display.

The cursor buttons ◀ [6] and ▶ [7] and the rotary switch [4] are used to set the required parameters. A flashing band under the current entry field of the display [3] requests that you enter these parameters. The symbol ☑ which appears on the right-hand side of the display requests that you activate the rotary switch [4].

Parameter entry and measurement

After opening a menu the operating state of the AFG 100 is interrupted until the menu is exited by pressing the F4 button [8]:

- Pressing the F4 button [8] with the meaning ENTER brings about a completion of the menu-driven settings and the AFG 100 reverts to the operating state. The set parameters are activated.
- Pressing the F4 button [8] with the meaning EXIT will cause the AFG 100 to revert to the operating state without changing the parameters.

**15** 

### 6.2 Starting

### $\bigwedge$

#### Attention!

When the AFG 100 is operated remotely via PC the connecting cable of the system interface RS-232C must be connected before switching on the operating voltage.

### Switching on the AFG 100

- 1. Connect the AFG 100 [14] to the mains with the mains cable.
- **2.** Press the **power switch** [1].
  - The LED *I/O* [2], *REM* [9] and *OUTPUT* [10] light up and the following message appears on the display [3]:

GENERATOR AFG100 PowerUp SelfTest

### Starting the initialization test

An internal initialization test starts up.

The following message appears on the display [3]:

Testing: <UNIT>

The variable **<UNIT>** stands for the unit which has just been tested:

- Processor (CPU)
- Data bus (**BUS**)
- ROM memory (**ROM**)
- RAM memory (**RAM**)
- EEPROM memory (**EEPROM**)
- Battery (BATTERY)
- Display (**DISPLAY**)
- Keyboard (KEYBOARD)
- Complete system (**SYSTEM**)

#### 

The test routine can be switched off (see 6.5.1).

In this case, the initialization test is started only if a button is pushed while switching the AFG 100 on.

#### Fault-free test

On error-free conclusion of the test the current software version and the following confirmation appear, e. g.:

GENERATOR AFG100 Ver: 2.00

and

GENERATOR AFG100 READY

### Operating state

After fault-free testing the LEDs *REM* [9] and *OUTPUT* [10] go out and the parameters of the AFG 100 correspond to the following presettings:

Sync output:switched offSweep function:switched offStart frequency:1.0000 kHzStop frequency:10.000 MHzSweep period:100 msAmplitude modulation:switched off

Modulation depth of internal AM: 100 %

Modulating frequency of internal AM: approx. 1 kHz Baud rate: 9,600 Bd

Data transmission protocol: switched off (NONE)

Initialization test: switched off

The AFG 100 is ready for operation and the following message appears on the display [3]:

FREQ: 1.0000 kHz WAVE: SINE

#### 

If you have saved your own instrument settings, these are loaded after the instrument is switched on (see 6.5.4.2). The AFG 100 starts with the last saved or loaded instrument setting.

#### Faulty test

Should a system error occur during the internal test, the AFG 100 interrupts the test until the error is eliminated. The following message appears on the display [3]:

Testing: <UNIT>

The variable **<UNIT>** stands for the unit which has just been tested (see above).

If errors which have no direct effect on the function of the AFG 100 occur in the component circuits, the test will continue. A warning with corresponding error characterization appears on the display [3], e. g.:

• With incomplete calibrating data:

GENERATOR AFG100 Calibration OFF!

• With faulty data in the EEPROM memory:

GENERATOR AFG100 Bad EEPROM CRC

• With faulty data in the RAM memory (e. g. data of the arbitrary signal):

GENERATOR AFG100 Bad Backup RAM

### **6.3 Operating Parameters**

#### **6.3.1 Setting the Frequency (FREQ)**

Calling up the menu point

- 1. Press the **F1 button FREQ** [5] when the AFG 100 is in operation.
  - The cursor appears on the display [3] on the smallest decimal position of the frequency value, e. g.:

FREQ: 1.000<u>0</u> KHz WAVE: SINE

Changing the parameter

- 2. With the cursor buttons [6] und [7], select the decimal position of the parameter to be changed.
- - **0.01 Hz ... 12.5 MHz** for sinusoidal and square-wave signals
  - **0.01 Hz ... 100 kHz** for triangular and sawtooth signals

■ Note

If the cursor is on the smallest decimal position (on the right) and the cursor button  $\blacktriangleright$  [7] is pressed, the frequency value is reduced by one power place, e. g. **1.0000** kHz  $\rightarrow$  **100.00** Hz.

If the cursor is on the largest decimal position (on the left) and the cursor button  $\blacktriangleleft$  [6] is pressed, the frequency value is extended by one power place, e. g. **1.0000 kHz**  $\rightarrow$  **10.000 kHz**.

If you try to exceed the limit values the following message Limit! is signalled on the display.

Saving the change

- **4.** Save the new setting with the help of the **F4 button ENTER** [8].
  - The cursor disappears and the last position of the cursor is preserved.
  - The AFG 100 returns to the operating state.

### **6.3.2** Setting the Output Level (LEVEL)

Calling up the menu point

- **1.** Press the **F2 button LEVEL** [6] when the AFG 100 is in operation.
  - The last settings of the output voltage and the dc voltage offset appear on the display [3]:

LEVEL: 1.00 V OFFSET: 0.00 V

Changing the parameter

- **2.** With the **cursor buttons** ◀ [6] und ▶ [7], select the decimal position of the parameter to be changed.
- 3. Change the output voltage with the help of the **rotary switch** 
  ☐ [4] in the following range:
  - 10 mV ... 10 V

#### 

If the cursor is on the smallest decimal position (on the right) and the cursor button  $\blacktriangleright$  [7] is pressed, the voltage value is reduced by one power place, e. g.  $1.00 \text{ V} \rightarrow 100 \text{ mV}$ .

If the cursor is on the largest decimal position (on the left) and the cursor button  $\bullet$  [6] is pressed, the voltage value is extended by one power place, e. g. **1.00** V  $\rightarrow$  **10** V.

If you try to exceed the limit values the message **Limit!** is signalled on the display.

It is possible to change between the 1st and 2nd line of the display with the cursor using the **F1 button**  $\updownarrow$  [5].

# Saving the change

- **4.** Save the new setting with the help of the **F4 button ENTER** [8].
  - The cursor disappears and the last position of the cursor is preserved.
  - The AFG 100 returns to the operating state.

#### **6.3.3** Setting the Dc Voltage Offset (OFFSET)

# Calling up the menu point

- **1.** Press the **F2 button LEVEL** [6] when the AFG 100 is in operation.
  - The last settings of the output voltage and the dc voltage offset appear on the display [3]:

LEVEL: 1.00 V OFFSET: 0.00 V

## Changing the parameter

- 2. Shift from the setting for the output voltage to the setting for the dc voltage offset with the **F1 button** ♦ [5].
- **3.** With the **cursor buttons** ◀ [6] und ▶ [7], select the decimal position of the parameter to be changed.
- - ± 2.5 V

#### Note

If you try to exceed the limit values the message **Limit!** is signalled on the display.

It is possible to change between the 1st and 2nd line of the display with the cursor using the **F1 button**  $\Leftrightarrow$  [5].


# Saving the change

- **5.** Save the new setting with the help of the **F4 button ENTER** [8].
  - The cursor disappears and the last position of the cursor is preserved.
  - The AFG 100 returns to the operating state.

#### **6.3.4 Selection of the Wave Form (WAVE)**

Calling up	
the menu po	oint

- 1. Press the **F3 button WAVE** [7] when the AFG 100 is in operation.
  - The current setting of the wave form appears on the display [3], e. g.:



### Changing the parameter

2. Change the form of the generated output signal with the help of the **rotary switch**  $\square$  [4]:

SINE - sinusoidal signal **SQUARE** - square-wave signal **TRIANGLE** - triangular signal - sawtooth signal RAMP UP/RAMP DOWN

**ARBITRARY** - arbitrary, freely programmable

wave form

### Saving the change

- **3.** Save the new setting with the help of the **F4 button ENTER** [8].
  - The AFG 100 returns to the operating state.

#### (F) Note

Simultaneous activation of the arbitrary signal and the sweep function is not permissible.

The data for the arbitrary signal are prepared externally and loaded into the AFG 100 via the serial interface RS-232C (see 7.3.2.9).

#### 6.3.4.1 Input of the Sample Period at Arbitrary Signals (FREQ)

Prerequisite

- 1. Select the wave form **ARBITRARY** (see 6.3.4).
  - A modified main menu appears on the display [3].

Calling up the menu point

- **2.** Press the **F1 button FREQ** [5] when the AFG 100 is in operation.
  - The current setting of the sample period appears on the display [3], e. g.:

RATE: 30.000 ns WAVE: **ARBITRARY** 

### Changing the parameter

- 3. Change the sample period with the help of the rotary switch **4** [4] in the following range:
  - 30 ns  $\times$  2<sup>N-1</sup>, N = 1 ... 32

#### Note

If you try to exceed the limit values the message Limit! is signalled on the display.

### Saving the change

**4.** Save the new setting with the help of the **F4 button ENTER** [8].

### **6.4 Operating Modes**

#### **6.4.1** Activating the Outputs

# Calling up the menu

- 1. Press the **F4 button MENU** [8] when the AFG 100 is in operation.
  - The main menu appears on the display [3]:

- 2. Press the **F1 button OUT** [5].
  - The menu for setting the signal output and the sync output appears on the display [3]:

- **3.** Select the corresponding menu point with the **function buttons F1-F4**:
  - **SYNC** [5] to activate the sync output (see 6.4.1.2)
  - **SIGNAL** [6/7] to activate the signal output (see 6.4.1.1)
  - **EXIT** [8] to leave the menu **without** changing the parameters or adapting the parameters if changes have been made

### 6.4.1.1 Switching on/off the Signal Output (SIGNAL)

# Calling up the menu point

- **1.** Call up the menu for setting the signal output and the sync output with the button sequence: **F4**, **F1** (see 6.4.1).
- 2. Press the F2 or F3 button SIGNAL [6].
  - The current state of the signal output appears on the display [3],
     e. g.:



# Changing the parameter

- **3.** Change the state with the help of the **rotary switch**  $\square$  [4]:
  - **OFF** signal output is switched off
  - **ON** signal output is switched on

# Saving the change

- **4.** Save the new setting with the help of the **F4 button ENTER** [8].
  - The AFG 100 returns to the menu for setting the signal output and the sync output.
  - The activated signal output is displayed with the LED *OUTPUT* [10].

- **5.** Repeated pressing of the **F4-button** [8] allows the user to shift between the different menu levels and/or to the operating state of the AFG 100:
  - Press × 1 main menu
  - Press × 2 2nd stage of the main menu
  - Press × 3 operating state of the AFG 100

### 6.4.1.2 Switching on/off the Sync Output (SYNC)

# Calling up the menu point

- **1.** Call up the menu for setting the signal output and the sync output with the button sequence: **F4**, **F1** (see 6.4.1).
- **2.** Press the **F1 button SYNC** [5].
  - The current state of the sync output appears on the display [3],
     e. g.:



# Changing the parameter

- **3.** Change the state with the help of the **rotary switch □** [4]:
  - **OFF** sync output is switched off
  - **POSITIVE** positive square-wave signal at the sync output
  - **NEGATIVE** negative square-wave signal at the sync output

# Saving the change

- **4.** Save the new setting with the help of the **F4 button ENTER** [8].
  - The AFG 100 returns to the menu for setting the signal output and the sync output.


# Changing to the operating state

- **5.** Repeated pressing of the **F4-button** [8] allows the user to shift between the different menu levels and/or to the operating state of the AFG 100:
  - Press × 1 main menu
  - Press  $\times$  2 2nd stage of the main menu
  - Press × 3 operating state of the AFG 100

### **6.4.2** Activating the Sweep Function

# Calling up the menu

- 1. Press the **F4 button MENU** [8] when the AFG 100 is in operation.
  - The main menu appears on the display [3]:



- 2. Press the **F2 button SWP** [6].
  - The sweep menu appears on the display [3]:



- **3.** Select the corresponding menu point with the **function buttons F1-F4**:
  - MOD [5] to activate the sweep function (see 6.4.2.1)
  - **FREQ** [6] to enter the frequency limits (see 6.4.2.2)
  - **ST** [7] to enter the period (see 6.4.2.3)
  - EXIT [8] to leave the menu without changing the parameters or adapting the parameters if changes have been made

#### 6.4.2.1 Switching on/off the Sweep Function (MOD)

# Calling up the menu point

- **1.** Call up the sweep menu with the butten sequence: **F4**, **F2** (see 6.4.2).
- 2. Press the **F1 button MOD** [5].
  - The current state of the sweep function appears on the display
     [3], e. g.:



# Changing the parameter

- **3.** Change the state with the help of the **rotary switch □** [4]:
  - **OFF** sweep function is switched off
  - LINEAR linear frequency change
  - **LOGARITHMIC** logarithmic frequency change

# Saving the change

- **4.** Save the new setting with the help of the **F4 button ENTER** [8].
  - The AFG 100 returns to the sweep menu.
- **5.** Press the **F4 button EXIT** [8].
  - The AFG 100 is configured anew and the sweep function is either started or stopped.
  - The AFG 100 returns to the main menu.

## Changing to the operating state

- **6.** Repeated pressing of the **F4-button** [8] allows the user to shift between the different menu levels and/or to the operating state of the AFG 100:
  - Press × 1 2nd stage of the main menu
  - Press × 2 operating state of the AFG 100



Simultaneous activation of the arbitrary signal and the sweep function is not permissible.

#### 6.4.2.2 Input of the Frequency Limits (FREQ)

# Calling up the menu point

- **1.** Call up the sweep menu with the butten sequence: **F4**, **F2** (see 6.4.2).
- 2. Press the **F2 button FREQ** [6].
  - The current settings of the frequency limits appear in the display [3], e. g.:

Start: 1.000<u>0</u>kHz Stop: 10.00<u>0</u>MHz

## Changing the parameter

- **3.** Change with the **F1 button ♦** [5] between the upper limit (**Start**) and lower limit (**Stop**) of the frequency change.
- **4.** With the **cursor buttons ◆** [6] und **▶** [7], select the decimal position of the parameter to be changed.

#### Note

If the cursor is on the smallest decimal position (on the right) and the cursor button  $\blacktriangleright$  [7] is pressed, the frequency value is reduced by one power place, e. g. **1.0000 kHz**  $\rightarrow$  **100.00 Hz**.

If the cursor is on the largest decimal position (on the left) and the cursor button  $\P$  [6] is pressed, the frequency value is extended by one power place, e. g. **1.0000 kHz**  $\rightarrow$  **10.000 kHz**.

If you try to exceed the limit values the message **Limit!** is signalled on the display.

# Saving the change

- **6.** Save the new setting with the help of the **F4 button ENTER** [8].
  - The cursor disappears and the last position of the cursor is preserved.
  - The AFG 100 returns to the sweep menu.
- 7. Press the **F4 button EXIT** [8].
  - The AFG 100 is configured anew and the sweep function is either started or stopped.
  - The AFG 100 returns to the main menu.

# Changing to the operating state

- **8.** Repeated pressing of the **F4-button** [8] allows the user to shift between the different menu levels and/or to the operating state of the AFG 100:
  - Press  $\times$  1 2nd stage of the main menu
  - Press × 2 operating state of the AFG 100

#### 6.4.2.3 Input of the Period (ST)

# Calling up the menu point

- **1.** Call up the sweep menu with the butten sequence: **F4**, **F2** (see 6.4.2).
- 2. Press the **F3 button ST** [7].
  - The current setting of the period appears on the display [3], e. g.:



## Changing the parameter

- **3.** With the **cursor buttons** ◀ [6] und ▶ [7], select the decimal position of the parameter to be changed.
- **4.** Change the period within the range of **100 ms** to **60 s** with the help of the **rotary switch !** [4].

#### Note

If you try to exceed the limit values the message **Limit!** is signalled on the display.

# Saving the change

- **5.** Save the new setting with the help of the **F4 button ENTER** [8].
  - The cursor disappears and the last position of the cursor is preserved.
  - The AFG 100 returns to the sweep menu.
- **6.** Press the **F4 button EXIT** [8].
  - The AFG 100 is configured anew and the sweep function is either started or stopped.
  - The AFG 100 returns to the main menu.

# Changing to the operating state

- **7.** Repeated pressing of the **F4-button** [8] allows the user to shift between the different menu levels and/or to the operating state of the AFG 100:
  - Press × 1 2nd stage of the main menu
  - Press × 2 operating state of the AFG 100

#### 6.4.3 Activating the Amplitude Modulation (AM)

### Calling up the menu

- 1. Press the **F4 button MENU** [8] when the AFG 100 is in operation.
  - The main menu appears on the display [3]:



- 2. Press the **F3 button AM** [7].
  - The menu for setting the amplitude modulation appears on the display [3]:

- **3.** Select the corresponding menu point with the **function buttons F1-F4**:
  - **MOD** [5] to activate the AM (see 6.4.3.1)
  - **DEPTH** [6] to enter the modulating depth (see 6.4.3.2)
  - **F** [7] to enter the modulating frequency (see 6.4.3.3)
  - **EXIT** [8] to leave the menu **without** changing the parameters or adapting the parameters if changes have been made

#### 6.4.3.1 Switching on/off the AM (MOD)

# Calling up the menu point

- 1. Call up the menu for setting the amplitude modulation with the butten sequence: **F4**, **F3** (see 6.4.3).
- **2.** Press the **F1 button MOD** [5].
  - The current state of the amplitude modulation appears on the display [3], e. g.:



# Changing the parameter

- **3.** Change the state with the help of the **rotary switch !** [4]:
  - OFF amplitude modulation is switched off
  - **INTERNAL** internal amplitude modulation
  - EXTERNAL external amplitude modulation

# Saving the change

- **4.** Save the new setting with the help of the **F4 button ENTER** [8].
  - The AFG 100 returns to the menu for setting the amplitude modulation.

# Changing to the operating state

- **5.** Repeated pressing of the **F4-button** [8] allows the user to shift between the different menu levels and/or to the operating state of the AFG 100:
  - Press × 1 main menu
  - Press  $\times$  2 2nd stage of the main menu
  - Press × 3 operating state of the AFG 100

### Note

During external amplitude modulation the modulation signal which is supplied via the input **AM INPUT** [17] is used.

### 6.4.3.2 Input of the Modulation Depth at Internal AM (DEPTH)

# Calling up the menu point

- 1. Call up the menu for setting the amplitude modulation with the butten sequence: **F4**, **F3** (see 6.4.3).
- 2. Press the **F2 button DEPTH** [6].
  - The current setting of the modulation depth appears on the display [3], e. g.:

# Changing the parameter

- **3.** With the **cursor buttons** ◀ [6] und ▶ [7], select the decimal position of the parameter to be changed.
- **4.** Change the modulation depth within the range of **0** % to **100** % with the help of the **rotary switch □** [4].

#### 

If you try to exceed the limit values the message **Limit!** is signalled on the display.

## Saving the change

- **5.** Save the new setting with the help of the **F4 button ENTER** [8].
  - The cursor disappears and the last position of the cursor is preserved.
  - The AFG 100 returns to the menu for setting the amplitude modulation.

- **6.** Repeated pressing of the **F4-button** [8] allows the user to shift between the different menu levels and/or to the operating state of the AFG 100:
  - Press  $\times$  1 main menu
  - Press  $\times$  2 2nd stage of the main menu
  - Press  $\times$  3 operating state of the AFG 100

#### 6.4.3.3 Input of the Modulation Frequency at Internal AM (F)

# Calling up the menu point

- **1.** Call up the menu for setting the amplitude modulation with the butten sequence: **F4**, **F3** (see 6.4.3).
- **2.** Press the **F3 button F** [7].
  - The current setting of the modulating frequency appears on the display [3], e. g.:

AM Frequency: 1.00 kHz

# Changing the parameter

3. Change the modulation frequency in discreet frequency values within the range of 100 Hz to 10 kHz with the help of the rotary switch [4].

#### 

If you try to exceed the limit values the message **Limit!** is signalled on the display.

# Saving the change

- **4.** Save the new setting with the help of the **F4 button ENTER** [8].
  - The AFG 100 returns to the menu for setting the amplitude modulation.

- **5.** Repeated pressing of the **F4-button** [8] allows the user to shift between the different menu levels and/or to the operating state of the AFG 100:
  - Press × 1 main menu
  - Press  $\times$  2 2nd stage of the main menu
  - Press × 3 operating state of the AFG 100

### 6.5 User Settings of the AFG 100

Calling up the menu

- 1. Press the **F4 button MENU** [8] when the AFG 100 is in operation.
  - The main menu appears on the display [3]:

-- Main Menu --OUT SWP AM NEXT

- 2. Press the **F4 button NEXT** [8].
  - The 2nd stage of the main menu appears on the display [3]:

-- Main Menu --INT USR SPC EXIT

- 3. Press the **F2 button USR** [6].
  - The menu for the user settings appears on the display [3]:

-- User Menu --PS TEST LCD NEXT

- **4.** Select the corresponding menu point with the **function buttons F1-F4**:
  - **PS** [6] to activate the initialization test (see 6.5.1)
  - **TEST** [7] self-diagnosis of the AFG 100 (see 6.5.2)
  - **LCD** [5] to adjust the display (see 6.5.3)
  - **NEXT** [8] changeover to the 2nd stage of the menu for the user settings (see 6.5.4)

### **6.5.1** Switching on/off the Initialization Test (PS)

Calling up the menu point

- 1. Call up the menu for the user settings with the butten sequence: **F4**, **F4**, **F2** (see 6.5).
- 2. Press the **F1 button PS** [5].
  - The current state for the sequence of operations of the initialization test after switching on the AFG 100 appears on the display [3], e. g.:

PowerUp SelfTST:

Changing the parameter

- **3.** Change the state with the help of the **rotary switch**  $\subseteq$  [4].
  - **ON** Initialization test is switched on
  - **OFF** Initialization test is switched off

Saving the change

- **4.** Save the new setting with the help of the **F4 button ENTER** [8].
  - The AFG 100 returns to the menu for the user settings.

- **5.** Repeated pressing of the **F4-button** [8] allows the user to shift between the different menu levels and/or to the operating state of the AFG 100:
  - Press  $\times$  1 2nd stage of the menu for the user settings
  - Press × 2 2nd stage of the main menu
  - Press × 3 operating state of the AFG 100

#### 

If the initialization test has been deactivated (OFF), it is still possible to activate the test routine when the AFG 100 is switched on. This is done by pressing any button while switching on the instrument. When the AFG 100 is switched off, the current state for the initialization test is preserved.

### 6.5.2 Self-Diagnosis of the AFG 100 (TEST)

#### Note

For successful performance of the test, testing equipment is necessary.

# Calling up the menu point

1. Call up the menu for the user settings with the butten sequence: F4, F4, F2 (see 6.5).

# Starting the self-diagnosis

- **2.** Press the **F2 button TEST** [6].
  - The internal diagnostic test routines are started.
  - After fault-free test the AFG 100 returns to the menu for the user settings.

# Changing to the operating state

- **3.** Repeated pressing of the **F4-button** [8] allows the user to shift between the different menu levels and/or to the operating state of the AFG 100:
  - Press  $\times$  1 2nd stage of the menu for the user settings
  - Press  $\times$  2 2nd stage of the main menu
  - Press × 3 operating state of the AFG 100

#### 6.5.3 Display

#### 6.5.3.1 Contrast Setting of the Display (CONT)

Calling up the menu point

- 1. Call up the menu for the display settings of the with the butten sequence: F4, F4, F2, F3 (see 6.5).
  - The following message appears on the display [3]:

- 2. Press the **F1 button CONT** [5].
  - The current contrast setting appears on the display [3], e. g.:

Contrast	Adjust:
Contrast	75 %

# Changing the parameter

3. Change the contrast within the range of 0 % to 100 % in 5 % steps with the help of the rotary switch ☐ [4].

#### Note

If you try to exceed the limit values the message **Limit!** is signalled on the display.

# Saving the change

- **4.** Save the new setting with the help of the **F4 button ENTER** [8].
  - The AFG 100 returns to the menu for the display settings.

# Changing to the operating state

- **5.** Repeated pressing of the **F4-button** [8] allows the user to shift between the different menu levels and/or to the operating state of the AFG 100:
  - Press  $\times$  1 menu for the user settings
  - Press  $\times$  2 2nd stage of the menu for the user settings
  - Press  $\times$  3 2nd stage of the main menu
  - Press  $\times$  4 operating state of the AFG 100

#### Note

When the AFG 100 is switched off, the last contrast setting is preserved.

#### 6.5.3.2 Brightness Setting of the Display (BRIGHT)

## Calling up the menu point

- 1. Call up the menu for the display settings with the butten sequence: F4, F4, F2, F3 (see 6.5).
  - The following message appears on the display [3]:

- 2. Press the **F2** or **F3 button BRIGHT** [6, 7].
  - The current brightness setting appears on the display [3], e. g.:



# Changing the parameter

3. Change the brightness within the range of 0 % to 100 % in 5 % steps with the help of the rotary switch ☐ [4].

#### Note

If you try to exceed the limit values the message **Limit!** is signalled on the display.

## Saving the change

- **4.** Save the new setting with the help of the **F4 button ENTER** [8].
  - The AFG 100 returns to the menu for the display settings.

# Changing to the operating state

- **5.** Repeated pressing of the **F4-button** [8] allows the user to shift between the different menu levels and/or to the operating state of the AFG 100:
  - Press  $\times$  1 menu for the user settings
  - Press  $\times$  2 2nd stage of the menu for the user settings
  - Press  $\times$  3 2nd stage of the main menu
  - Press  $\times$  4 operating state of the AFG 100

#### Note

When the AFG 100 is switched off, the last contrast setting is preserved.

### **6.5.4 Instrument Settings**

#### Application

If applications with certain instrument settings are repeated, there is the possibility of saving up to 9 user settings in the AFG 100.

Parallel to the freely configurable user settings there is a set instrument setting default of the manufacturer. If required the desired instrument setting can be loaded.

The AFG 100 starts with the last saved or loaded instrument setting.

#### Note

The settings of the interface and the display as well as the activation of the initialization test are **not** saved. After switching on the AFG 100 the parameters which were up-to-date before switching off are set.

#### 6.5.4.1 Saving the Current Instrument Settings (STO)

Calling up the menu point

- 1. Calling up the 2nd stage of the menu for the user settings with the butten sequence: **F4**, **F4**, **F2**, **F4** (see 6.5).
  - The following message appears on the display [3]:

- 2. Press the **F1 button STO** [5].
  - The current storage location appears on the display [3]:

Saving the parameters

- **4.** Press the **F4 button ENTER** [8].
  - If the storage location is free, the actual instrument setting is saved. The following message appears on the display [3]:

The saved instrument setting is loaded in the main memory and continues to be up-to-date. The following message appears on the display [3]:

The AFG 100 returns to the 2nd stage of the menu for the user settings.

 If the storage location is occupied, the question if the memory content should be replaced appears on the display [3]:



### **5.a)** Press the **F4 button YES** [8].

- The current instrument setting is saved. The following message appears on the display [3]:



The saved instrument setting is loaded in the main memory and continues to be up-to-date. The following message appears on the display [3]:

The AFG 100 returns to the 2nd stage of the menu for the user settings.

### **5.b)** Press the **F1 button NO** [5].

 The AFG 100 returns to the 2nd stage of the menu for the user settings without saving.

# Changing to the operating state

- **6.** Repeated pressing of the **F4-button** [8] allows the user to shift between the different menu levels and/or to the operating state of the AFG 100:
  - Press × 1 main menus
  - Press × 2 operating state of the AFG 100

#### 6.5.4.2 Loading the Instrument Settings (RCL)


Calling up the menu point

- 1. Calling up the 2nd stage of the menu for the user settings with the butten sequence: **F4**, **F4**, **F2**, **F4** (see 6.5).
  - The following message appears on the display [3]:

- 2. Press the F2 button RCL [6].
  - The current storage location appears on the display [3], e. g.:

Loading the parameters

- 4. Press the **F4 button ENTER** [8].
  - If the storage location 0 is selected, the instrument setting of the manufacturer is loaded. The following message appears on the display [3]:



- If the storage location 1-9 is occupied, the current instrument setting is loaded. The following message appears on the display [3]:



- If the storage location 1-9 is not occupied, the current instrument setting is preserved. The following message appears on the display [3]:



- The AFG 100 returns to the 2nd stage of the menu for the user settings.

### Changing to the operating state

- **5.** Repeated pressing of the **F4-button** [8] allows the user to shift between the different menu levels and/or to the operating state of the AFG 100:
  - Press × 1 main menu
  - Press × 2 operating state of the AFG 100


#### 6.6 The Special Functions of the AFG 100 (SPC)

Calling up the password input

- 1. Call up the F4 button MENU [8] when the AFG 100 is in operation.
  - The main menu appears on the display [3]:

- 2. Press the **F4 button NEXT** [8].
  - The 2nd stage of the main menu appears on the display [3]:

- 3. Press the **F3 button SPC** [7].
  - The field for the input of the password appears on the display [3]:



Entering the password

- **4.** With the **cursor buttons ◆** [6] und **▶** [7], select the position of the password to be changed.
- **5.** Enter the right password with the help of the **rotary switch** [4].
- **6.** Press the **F4 button ENTER** [8].
  - The special menu is opened to the authorized user (service technicians) for service and calibration work.

Wrong password input

If the wrong password is entered the following message appears on the display [3] and the instrument returns to the main menu:



### 7. Press the **F4 button ENTER** [8].

- The AFG 100 returns to the operating state.

### 6.7 Protection of the Signal Output

Operation The signal output OUTPUT [11] is equipped with a protective circuit

(Reverse Power Protection).

If an external voltage  $V > \pm 15 \text{ V}$  is connected to the active signal output [11] of the AFG 100, the signal output switches itself off

automatically.

Error message The LED *OUTPUT* [10] at the front of the AFG 100 is cleared when

the AFG 100 is switched off and the following error message appears

on the display [3]:

\* \* Error: 31 \* \* RPP Tripped!

Only after the error has been removed is the operating state of the signal output automatically restored and the error message disappears.

### 7 Remote Control by Program

### 7.1 Preparation of the AFG 100

Attention!	For remote control of the AFG 100 the connecting cable of the serial interface RS-232C has to be connected before switching on the operating voltage.
Prerequisite	Remote control of the AFG 100 with a personal computer (PC) is possible via the serial interface RS-232C. The interface of the personal computer must be configured as described in paragraph 4.4. The connecting cable must not be longer than 15 m.
Connecting the connecting cable	1. Connect the connecting cable to the AFG 100 [13] and the PC.
	2. Screw the connections in tight.
Switching on the AFG 100	<ul> <li>3. Switch on the AFG 100.</li> <li>After the initialization test the AFG 100 can receive commands.</li> </ul>
☞ Note	Make sure that the phase of the mains voltage at the AFG 100 and PC is the same, the earth loops has been removed and the ESD regulations are observed.

### 7.1.1 Selecting the Interface Parameters

Calling up the menu

- 1. Press the **F4 button MENU** [8] when the AFG 100 is in operation.
  - The main menu appears on the display [3]:

- 2. Press the **F4 button NEXT** [8].
  - The 2nd stage of the main menu appears on the display [3]:



- **3.** Press the **F1 button INT** [5].
  - The menu for selecting the interface parameters appears on the display [3]:



- **4.** Select the corresponding menu point with the **function buttons F1-F4**:
  - **BDR** [5] to set the baud rate (see 7.1.1.1)
  - **PROT** [6] to set the transmission protocol (see 7.1.1.2)
  - **EXIT** [8] to leave the menu **without** changing the parameters or adapting the parameters if changes have been made

#### 7.1.1.1 Setting the Baud Rate (BDR)

# Calling up the menu point

- **1.** Call up the menu for selecting the interface parameters with the butten sequence: **F4**, **F4**, **F1** (see 7.1.1).
- 2. Press the **F1 button BDR** [5].
  - The current baud rate appears on the display [3], e. g.:



# Changing the parameter

- 3. Change the baud rate with the help of the **rotary switch !** [4].
  - **1200**, **2400**, **4800**, **9600**, **19200** [Bd]
- **4.** Save the new setting with the help of the **F4 button ENTER** [8].
  - The AFG 100 changes to the menu for selecting the interface parameters.

# Changing to the operating state

- **5.** Repeated pressing of the **F4-button** [8] allows the user to shift between the different menu levels and/or to the operating state of the AFG 100:
  - Press × 1 2nd stage of the main menu
  - Press × 2 operating state of the AFG 100



After switching off the AFG 100 the current setting of the baud rate is preserved.

#### 7.1.1.2 Setting the Transmission Protocol (PROT)

# Calling up the menu point

- 1. Call up the menu for selecting the interface parameters with the butten sequence: **F4**, **F4**, **F1** (see 7.1.1).
- 2. Press the **F4 button PROT** [6].
  - The current setting of the transmission protocol appears on the display [3], e. g.:



# Changing the parameter

- - NONE communication without transmission protocol
  - RTS/CTS communication with RTS/CTS protocol
- **4.** Save the new setting with the help of the **F4 button ENTER** [8].
  - The AFG 100 changes to the menu for selecting the interface parameters.

# Changing to the operating state

- **5.** Repeated pressing of the **F4-button** [8] allows the user to shift between the different menu levels and/or to the operating state of the AFG 100:
  - Press × 1 2nd stage of the main menu
  - Press × 2 operating state of the AFG 100

#### Note

After switching off the AFG 100 the current setting of the transmission protocol is preserved.

#### Communication with RTS/CTS protocol

Data received Signal RTS=ON

from PC - AFG 100 can receive data.

Signal RTS=OFF

- AFG 100 cannot receive data.

Data transmitted

Signal CTS=ON

to PC

- AFG 100 transmitting data.

Signal CTS=OFF

- AFG 100 not transmitting data.

#### Communication without RTS/CTS protocol

Data received

Signal RTS=ON

from PC

 AFG 100 can always receive data, when the input buffer is overloaded, the error 131 INP.BUFFER FULL is reported.

Data transmitted

Signal CTS=ON

to PC

- AFG 100 can always transmit data.

#### 7.1.2 Local Control ⇔ Remote Control

Activating the remote control

Transmit the command **REN** via the PC.

The AFG 100 is in the Remote Control status. This is indicated by the LED *REM* [9]. Afterwards control of the AFG 100 by the local control elements is not possible (except with the F4 button **LOC** [8]).

Note

Block the F4 button **LOC** [8] with the help of the command **LLO**. Then all the commands of the PC can be processed completely.

Activating the local control

- There are several ways of switching from remote control to local control:
  - By transmitting the command **GTL** (Go To Local) from the PC
  - By pressing the F4 button LOC [8] at the AFG 100 if the keyboard has not been locked by the command LLO (Local Lock Out)
  - By switching the **power switch** [1] off and on
- The keyboard is ready for use again after the transition to local control. The LED *REM* [9] goes out.

Remote control at local control

- The following commands and instrument messages can also be transmitted by the PC when the AFG 100 is on local control:
  - \*IDN?, \*CLS,\* ESR?,\* ESE, \*ESE?, \*STB?, \*SRE, \*SRE? ,ERR?, DER?

### 7.2 Messages of the AFG 100 on Remote Control

#### 7.2.1 Description of the Unit Status

Introduction

The current status of the operating conditions of the AFG 100 can be interrogated at any time via the EVENT STATUS REGISTER and the STATUS BYTE REGISTER.

#### 7.2.1.1 ESR - EVENT STATUS REGISTER

Reading and deleting the register

The contents of the ESER register **<XXX>** are saved in the output buffer and deleted by transmitting the command **\*ESR?**.

The ESR register is set on **Ø** also after the following operations:

- Switching on the AFG 100 (except bit 7)
- Transmitting the command \*CLS (except bit 4 MAV)
- Changing the interface parameters

Contents of the ESR register

**Bit 7:** (PON) Power On

Operating readiness and interface activities are displayed on 1.

Bit 6: (URQ) User Request

Is not used, is always set on **Ø**.

**Bit 5:** (CME) Command Error

Is set on 1 at instruction errors.

Bit 4: (EXE) Execution Error

Is set on 1 at query errors and execution errors.

Bit 3: (DDE) Device Dependent Error

Device errors are displayed on 1.

Bit 2: (QYE) Query Error

Is set on 1 at query errors.

**Bit 1:** (RQC) Request Control

Is not used, is always set on **Ø**.

**Bit 0:** (OPC) Operation Complete

Is set on 1 by transmitting the command \*OPC.

#### ESE - EVENT STATUS ENABLE REGISTER

Meaning of the register

Various statuses and settings of the AFG 100 can be checked. For this the contents of the ESR register are called with the help of a mask. The single bits are compared and evaluated by the following logical equation:

■ ESB = (ESR7  $\wedge$  ESE7)  $\vee$  (ESR6  $\wedge$  ESE6)  $\vee$  (ESR5  $\wedge$  ESE5)  $\vee$  (ESR4  $\wedge$  ESE4)  $\vee$  (ESR3  $\wedge$  ESE3)  $\vee$  (ESR2  $\wedge$  ESE2)  $\vee$  (ESR1  $\wedge$  ESE1)  $\vee$  (ESR0  $\wedge$  ESE0)

The result ESB (Event Summary Bit) is entered in the STB register.

Describing the register

The command \*ESE <XXX> offers the possibility of initializing the ESE register with any mask. The value <XXX> has to be within the range of 0 to 255. Otherwise the error 134 VAL. OUT OF RANGE is reported.

# Reading and deleting the register

The current contents **<XXX>** are saved in the output buffer by transmitting the command **\*ESE?**.

The ESE register is set on **Ø** after the following operations:

- Switching on the AFG 100
- Transmitting the command \*ESE 0
- Changing the interface parameters

#### 7.2.1.2 STB - STATUS BYTE REGISTER

# Reading and deleting the register

The contents of the STB register **<XXX>** are filed in the output buffer by transmitting the command **\*STB?**.

The STB register is set on **Ø** after the following operations:

- Switching on the AFG 100
- Transmitting the command \*CLS (except bit 4 MAV)
- Changing the interface parameters

# Contents of the STB register

Bit 7: Is not used, is always set on  $\emptyset$ .

**Bit 6:** (MSS) Master Summary Bit Result during checkup of the STB register with a mask (SRE register, see below).

**Bit 5:** (ESB) Event Summary Bit Result during checkup of the ESR register with a mask (ESE register, see above).

**Bit 4:** (MAV) Message Available
Is set on **1** if a current message of the AFG 100 is requested at the output buffer.

Bit 3: Is not used, is always set on  $\emptyset$ .

**Bit 2:** Is not used, is always set on  $\emptyset$ .

**Bit 1:** Is not used, is always set on  $\emptyset$ .

**Bit 0:** Is not used, is always set on  $\emptyset$ .

#### SRE - SERVICE REQUEST ENABLE REGISTER

# Meaning of the register

Various statuses and settings of the AFG 100 can be checked. For this the contents of the STB register are called with the help of a mask. The single bits (except SRE bit 6, which is always set on  $\emptyset$ ) are compared and evaluated by the following logical equation:

■ MSS = (STB7  $\land$  SRE7)  $\lor$  (STB5  $\land$  SRE5)  $\lor$  (STB4  $\land$  SRE4)  $\lor$  (STB3  $\land$  SRE3)  $\lor$  (STB2  $\land$  SRE2)  $\lor$  (STB1  $\land$  SRE1)  $\lor$  (STB0  $\land$  SRE0)

The result MSS (Master Summary Status) is entered in the STB register.

# Describing the register

The command \*SRE <XXX> offers the possibility of initializing the SRE register with any mask. The value <XXX> has to be within the range of 0 to 255. Otherwise the error 134 VAL. OUT OF RANGE is reported.

# Reading and deleting the register

The current contents **<XXX>** are saved in the output buffer by transmitting the command **\*SRE?**.

The SRE register is set on **Ø** after the following operations:

- Switching on the AFG 100
- Transmitting the command \*SRE 0
- Changing the interface parameters

#### 7.2.2 Description of Errors

# Contents of the fault register

When errors occur in the remote-controlled settings and queries, they are saved with a code in the error register.

# Reading and deleting the register

The contents of the error register can be called and deleted at any time by transmitting the command **ERR?**.

If several errors arise only the error codes of the first and last error are saved. By repeatedly transmitting the command **ERR?** the error codes are filed in the output buffer.

The error register is set on **Ø** after the following operations:

- Repeated use of the command ERR? (according to the number of errors)
- Initialization of the status register (\*CLS)

#### 

Before transmission of the command **ERR?** the interface command **DCL** has to be transmitted.

#### 7.2.2.1 DER - DEVICE ERROR REGISTER

# Meaning of the register

The contents of the DER register specify the device error in the error register.

# Reading and deleting the register

The contents of the register **<XXX>** within the range of **0** to **255** are filed in the output buffer by transmitting the command **DER?**.

The DER register is set on **Ø** after the following commands:

- Repeated use of the command ERR? (according to the number of errors)
- Initializing of status structure (\*CLS)

# Contents of the DER register

- **Bit 7**: Is not used, is always set on  $\emptyset$ .
- **Bit 6**: Is set on **1**, if the calibration data have been deleted.
- **Bit 5**: Is set on **1**, if the data in the RAM memory have been deleted.
- **Bit 4**: Is set on **1**, if an external voltage of  $> \pm 15$  V is connected at the output and the output has been switched off.
- Bit 3: Is not used, is always set on  $\emptyset$ .
- **Bit 2**: Is not used, is always set on **Ø**.
- **Bit 1**: Is not used, is always set on **Ø**.
- **Bit 0**: Is not used, is always set on **Ø**.

#### Note

When a device error occurs the bit 3 (DDE) of the ESR register is set on 1.

#### 7.2.2.2 Error Messages

# Dependence of the error message

The error messages are dependent on the **operating status** and the **type of error**.

- On local control interface errors are displayed for only a short time. On remote control of the AFG 100 interface errors are displayed until the contents of the error register have been queried or deleted.
- Device errors are displayed during the error status.

### List of Error Messages

Error code	Error mode Text of messages	Meaning of text
0	-	Faultless operation
	DEVICE ERROR	Device error
31	RPP TRIPPED	Output overload with external voltage
98	INVALID PASSWORD	Wrong password
	QUERY ERROR	Query error
120	BAD USING QUERY	Used query is wrong
	EXECUTION ERROR	Execution error
131	NO EXECUTION	Cannot be executed
132	NOT EX. IN LOCAL	Cannot be executed on local control
134	VAL. OUT OF RANGE	Value is out of range
	COMMAND ERROR	Command error
151	ILLEGAL COMMAND	Unknown command
	RS 232 ERROR	Error of the RS-232C interface
181	INP. BUFFER FULL	Input buffer is full

#### 7.3 List of Commands on Remote Control

#### 7.3.1 General Commands

#### 7.3.1.1 Interface Commands

**REN** – Transition from local control to remote control

(Remote)

ASCII Character (dec.)
HT 9

LLO – Locking of the F4 button LOC [8]

(Local Lock Out)

ASCII Character (dec.)
EM 25

GTL - Transition from remote control to local control

(Go To Local)

ASCII Character (dec.)

SOH 1

**DCL** – Initializing the communications protocol of the interface

(Device Clear) – Initializing the partial circuit and deleting the buffer

ASCII Character (dec.)

DC4 20

**Note** The command **DCL** has no influence on the functions of the device.

These have to be initialized by the general command \*RST.

#### 7.3.1.2 Initializing the Instrument Settings

\*RST — Basic initialization of the AFG 100 as during the starting (see 6.2). (Reset)

Note After switching on the AFG 100 the commands \*RST, DCL and \*CLS are executed automatically and the contents of the ESE and SRE

registers are deleted. Bit 7 (PON) of the ESR register is set on 1.

#### 7.3.1.3 Self-Diagnosis of the AFG 100

\*TST? – Start of internal test and saving of result

(Test) where: **0** - test is successful

1 - test is not successful

#### 7.3.1.4 Identification of the AFG 100

\*IDN? – Identification digimess,AFG 100, <X...X>,<Y...Y>

(Identification) where:  $\langle X...X \rangle$  - production number or 0

<Y...Y> - software version or 0

Note The query \*IDN? should be written at the end of the command line

because subsequent data may be lost before transmission. Otherwise

the error 120 **BAD USING QUERY** is reported.

#### 7.3.1.5 Initializing the Status Structure

\*CLS - Resetting of ESR and STB registers (except bit 4 - MAV)

(Clear Status Byte) ESE and SRE registers are not deleted.

- Initializing of the error structure (see 7.2.2)

#### 7.3.1.6 Sync Commands

(Waiting)

\*WAI \_ The following commands are executed only after completion of

the current operation.

\*OPC \_ After completion of the current operation bit 0 (OPC) in the ESR

(Operation Complete) register is set on 1.

\*OPC? – After completion of the current operation the number 1 is saved in

the output buffer.

**Note** In the AFG 100 all commands are executed sequentially. The

execution of the next command starts only when the current operation is ended.

While the commands \*OPC and \*OPC? are executed immediately,

the command \*WAI does not have any effect.

#### 7.3.1.7 Query of the Instrument Status

**ERR?** – Reading and resetting of the error messages (see 7.2.2)

(Error)

DER? — Contents of the DER register are filed in the output buffer.

\*ESR? - Reading of the ESR register (see 7.2.1.1)

\*ESE <XXX>

\*ESE?

\*STB? – Reading of the STB register (see 7.2.1.2)

\*SRE <XXX>

\*SRE?

#### 7.3.2 Instrument Settings and Messages

#### 7.3.2.1 Output Frequency

#### FREQ <X...X>

Frequency setting [Hz] within the range of **0.010** to **1.2500E7** (in the free format)

The numeric argument is rounded up.

#### Note

If the value is out of range the error 134 **VAL. OUT OF RANGE** is reported.

#### FREQ?

- The set frequency value [Hz] is filed in the output buffer with the following format:
  - **HZ <X.XXXXE+0Y>** or
  - HZ <ZX.XXXE+0Y> or
  - HZ <ZXX.XXE+0Y>

where: **Z** - character from **1** to **9** 

X - character from 0 to 9

**E** - exponent

Y - character 0, 3 or 6

#### 7.3.2.2 Sample Period at Arbitrary Signals

#### RATE <XX>

Setting the sample rate of the arbitrary signal with the help of the coefficient N within the range of 1 to 32 (in the free format)
 The numeric argument is rounded up.
 Sample rate = 30 ns \* 2<sup>N-1</sup>, N = 1 to 32

#### ■ Note

If the value is out of range the error 134 **VAL. OUT OF RANGE** is reported.

#### RATE?

- The set sample rate [s] is filed in the output buffer with the following format:
  - **S** <**Z.XXXXE±0Y>** or
  - **S** <**ZX.XXXE±0Y>** or
  - S <ZXX.XXE±0Y>

where: **Z** - character from **1** to **9** 

X - character from 0 to 9

**E** - exponent

Y - character 0, 3, 6 or 9

#### 7.3.2.3 Output Level

#### LEVEL <X...X>

Level setting [V] within the range of 10.0E-03 to 10.0 (in the free format)

The numeric argument is rounded up.

#### Note

If the value is out of range the error 134 **VAL. OUT OF RANGE** is reported.

#### **LEVEL**

- The set output level [V] is filed in the output buffer with the following format:
  - V <Z.XXE±0Y> or
     V <ZX.XE±0Y> or
     V <ZXXE±0Y>

where: **Z** - character from **1** to **9 X** - character from **0** to **9** 

**E** - exponent

Y - character 0 or 3

## 7.3.2.4 Dc Voltage Offset of the Output Signal

#### OFFSET <X...X>

Setting the dc voltage offset of the output signal [V] within the range of -2.5 to +2.5 (in the free format)
 The numeric argument is rounded up.

#### Note

If the value is out of range the error 134 **VAL. OUT OF RANGE** is reported.

#### **OFFSET**

- The set dc voltage offset [V] is filed in the output buffer with the following format:
  - V <TZ.XXE+00>

where: **T** - character (-/blank)

Z - character from 0 to 2X - character from 0 to 9

E - exponent

## 7.3.2.5 Wave Form of the Output Signal

**W\_SINE** – The sinusoidal output signal is selected.

**W\_SQUARE** – The square-wave output signal is selected.

**W\_TRIANGLE** – The triangular output signal is selected.

**W\_RAMPUP** — The sawtooth output signal (Ramp Up) is selected.

**W\_RAMPDN** – The sawtooth output signal (Ramp Down) is selected.

**W\_ARBIT** — The saved arbitrary output signal is selected.

**WAVE?** - The current selection of the wave form at the output of the

AFG 100 is filed in the output buffer with the following format:

 $\bullet \quad \textbf{W\_SINE}, \textbf{W\_SQUARE}, \textbf{W\_TRIANGLE}, \textbf{W\_RAMPUP},$ 

W RAMPDN or W ARBIT

#### 7.3.2.6 Switching State of the Signal and Sync Outputs

#### Signal output

OUT\_ON - The signal output is switched on.
 OUT\_OFF - The signal output is switched off.

OUT? — The current state of the signal output is filed in the output buffer:

OUT ON or OUT OFF

## Sync output

**SOUT\_OFF** — The square-wave signal at the sync output is switched off.

SOUT\_POS - The positive square-wave signal at the sync output is switched on.
 SOUT\_NEG - The negative square-wave signal at the sync output is switched on.

**SOUT** – The current status is filed in the output buffer:

SOUT\_OFF, SOUT\_POS or SOUT\_NEG

#### 7.3.2.7 Sweep Function

#### Switching on/off

**SWP\_OFF** – The sweep function is switched off.

**SWP\_LIN** – The linear sweep function is switched on.

**SWP\_LOG** – The logarithmic sweep function is switched on.

**SWP** - The current state of the sweep function is filed in the output

buffer:

SWP\_OFF, SWP\_LIN or SWP\_LOG

#### Frequency limits

**SWP\_START <X...X>** – Setting the lower frequency limit [Hz] within the range of **0.010** to

**1.250E7** (in the free format)

The numeric argument is rounded up.

Note If the value is out of range the error 134 VAL. OUT OF RANGE is

reported.

**SWP\_START** – The set lower frequency limit [Hz] is filed in the output buffer

with the following format:

■ **HZ** <**X.XXXXE+0Y>** or

■ HZ <ZX.XXXE+0Y> or

HZ <ZXX.XXE+0Y>

where: **Z** - character from **1** to **9** 

X - character from 0 to 9

**E** - exponent

Y - character 0, 3 or 6

**SWP\_STOP <X...X>** - Setting the upper frequency limit [Hz] within the range of **0.010** to

**1.250E7** (in the free format)

The numeric argument is rounded up.

	If the value is out of range the error 134 <b>VAL. OUT OF RANGE</b> is reported.
SWP_STOP	<ul> <li>The set upper frequency limit [Hz] is filed in the output buffer with the following format:</li> <li>HZ <x.xxxxe+0y> or</x.xxxxe+0y></li> <li>HZ <zx.xxxe+0y> or</zx.xxxe+0y></li> <li>HZ <zxx.xxe+0y> where: Z - character from 1 to 9 <ul> <li>X - character from 0 to 9</li> <li>E - exponent</li> <li>Y - character 0, 3 or 6</li> </ul> </zxx.xxe+0y></li> </ul>
Period	
SWP_TIME <xx></xx>	<ul> <li>Setting the period [s] within the range of 10E-3 to 60 (in the free format)</li> <li>The numeric argument is rounded up.</li> </ul>
	If the value is out of range the error 134 <b>VAL. OUT OF RANGE</b> is reported.
SWP_TIME	<ul> <li>The set period [s] is filed in the output buffer with the following format:</li> <li>S &lt; ZXE±0Y&gt; or</li> <li>S &lt; Z.XXE±0Y&gt; or</li> <li>S &lt; ZX.XE±0Y&gt; or</li> <li>S &lt; ZXXE±0Y&gt; or</li> <li>C + C + C + C + C + C + C + C + C + C +</li></ul>

## 7.3.2.8 Amplitude Modulation

## Switching on/off

Switching on/off			
AM_OFF	<ul> <li>The amplitude modulation is switched off.</li> </ul>		
AM_INT	<ul> <li>The amplitude modulation (internal modulation source) is switched on.</li> </ul>		
AM_EXT	<ul> <li>The amplitude modulation (external modulation source) is switched on.</li> </ul>		
AM	<ul> <li>The current state of the amplitude modulation is filed in the output buffer:</li> <li>AM_OFF, AM_INT or AM_EXT</li> </ul>		

E - exponent Y - character 0 or 3

#### Modulation depth at internal AM

# AM\_DEPTH <X...X> - Setting the modulation depth [%] at internal amplitude modulation within the range of **0** to **100** (in the free format) The numeric argument is rounded up.

# Note If the value is out of range the error 134 VAL. OUT OF RANGE is reported.

#### **AM DEPTH**

- The set modulation depth [%] at internal amplitude modulation is filed in the output buffer with the following format:
  - **PCT** <**X>** or
  - **PCT <ZX>** or
  - PCT 100

where: **Z** - character from **1** to **9 X** - character from **0** to **9** 

#### Modulating frequency at internal AM

## AM\_FREQ <X...X> -

- Setting the discreet frequency values of the oscillator at internal amplitude modulation within the range of **1** to **31** (in the free format)

The numeric argument is rounded up.

#### Note

If the value is out of range the error 134 **VAL. OUT OF RANGE** is reported.

#### AM FREQ

- The set frequency value of the internal oscillator at internal amplitude modulation is filed in the output buffer with the following format:
  - **HZ** <**Z.XXE+0Y>** or
  - **HZ** <**ZX.XE+0Y>** or
  - HZ <ZXXE+0Y>

where: **Z** - character from **1** to **9** 

X - character from 0 to 9

**E** - exponent

Y - character 0 or 3

#### 7.3.2.9 Saving the Arbitrary Signals

#### Memory addressing

#### ARB ADR <X...X>

Input of the start address for saving/loading the arbitrary signal within the range of 0 to 8191 (in the free format)
 The numeric argument is rounded up.

#### Note

If the value is out of range the error 134 **VAL. OUT OF RANGE** is reported.

-		
Saving with ASCII for	<u>t</u>	
ARB_DATA <xx></xx>	<ul> <li>Saving a sample of the arbitrary signal within the range of 0 to 65535 (in the free format)</li> <li>The numeric argument is rounded up.</li> </ul>	
<b>ℰ</b> Note	If the value is out of range the error 134 VAL. OUT OF RANGE is reported.  The start address is set with the command ARB_ADR (see above).  The command ARB_DATA sets the internal address pointer automatically.	
<xx> Structure of the saved data</xx>	Bit 15: If this bit is set on 1, a sync marker is generated. This is carried out when the sample is at the output.  Bit 14: If this bit is set on 1 at all samples, the sync markers are generated according to the setting of bit 15.  Bit 13 10: Is not used, is always set on Ø.  Bit 9: MSB of the sample  Bit 8 1: Sample of the wave form  LSB of the sample	
Note	If bits 14 and 15 are set on <b>Ø</b> , internal sync markers are generated automatically.	
Bit 9 0 Contents of the sample	When setting the output level $V_{pp} = 1$ V and when using the internal sync markers the output level corresponds to the following numeric argument (in the free format):  • - 0.5 V corresponds to 0  • + 0.5 V corresponds to 1023	
ARB_DATA	<ul> <li>A saved sample of the arbitrary signal is filed in the output buffer with the following format:</li> <li>0 65535</li> </ul>	

automatically.

The command ARB\_DATA sets the internal address pointer

Note

#### Saving with binary data blocks

#### ARB <ABPD>

 Fast saving of a whole data block of the arbitrary signal (Arbitrary Block Program Data) in the following format:

#### #<NZD><D><DB>

where: # - Start signal of the data block

<NZD> - ASCII number (no 0) within the range of 49 to 57 (dec.) which defines the number of the following ASCII numbers

- ASCII number within the range of 48 to 57 (dec.) which defines the number of the following binary data blocks

**DB>** - binary data within the range of **0** to **255** (dec.), which are transmitted in the following order:

High byte of the data word
 Low byte of the data word

Example: #500004<DB><DB><DB>

# <DB> Structure of the data word

#### High byte of the data word:

Bit 7: If this bit is set on 1, a sync marker is generated. This is carried out when the sample is at the output.

Bit 6: If this bit is set on 1 at all samples, the sync markers are generated according to the setting of bit 7 (High byte).

Bit 5 ... 2: Is not used, is always set on  $\emptyset$ .

Bit 1: MSB of the sample
Bit 0: Sample of the wave form

#### Low byte of the data word:

Bit 7 ... 1: Sample of the wave form

Bit 0: LSB of the sample

#### Bit 1 ... 0 (H byte), Bit 7 ... 1 (L byte) Contents of the samples

When setting the output level  $V_{pp} = 1$  V and when using the internal sync markers the output level corresponds to the following numeric argument:

- 0.5 V ... corresponds to H byte 0 dec. and L byte 0 dec.
 ... + 0.5 V corresponds to H byte 3 dec. and L byte 255 dec.

#### 7.3.2.10 Password Input

**PASSWORD <X...X>** — Input the 8-digit password **<XXXXXXXX>** for access to the service menu

# Note If the password is wrong, the error 98 INVALID PASSWORD is reported.

## 7.4 Programming Notes

Command line

Single commands can be written consecutively in one command line, the length of which must not exceed 64 characters. In case errors occur, the command sequence is ignored and error 181 INP. BUFFER FULL is indicated.

Separation characters

Commands and device messages have to be separated by a semicolon:

ASCII	Character (dec.)
•	59

Final characters

A final character is at the end of every command line.

• During transmission of commands to the AFG 100:

ASCII	Character (dec.)
LF	10

• During reception of commands from the AFG 100:

ASCII	Character (dec.)
CR + LF	13 + 10

Parameter separators Certain commands or messages can contain parameters or results which are separated from the command by a parameter separator.

• During transmission of commands to the AFG 100:

ASCII	Character (dec.)
SP	32
NUL	0
STX to BS	2 to 8
VT to DC3	11 to 19
NAK to CAN	21 to 24
SUB to US	26 to 31

During reception of commands from the AFG 100:

ASCII	Character (dec.)
SP	32

#### 7.5 Program Example for Square-wave Signal (Q Basic)

```
100 '********************
110 '
                 The Example in Microsoft O Basic
120 '
             of using the AFG 100 with RS-232C interface
130 '
               Serial port is com1 and Bd rate is 9600
140 '
                Settings - output frequency: 1.234 kHz
                        - output level: 2 V
150 '
160 '
                        - wave form: square-wave
180
190 CLS
200
210 '*** Activating interface ****
220
     IDCL\$ = CHR\$(20): IREN\$ = CHR\$(9): ILLO\$ = CHR\$(25):
230
     IGTL$ = CHR$(1)
240
250 '**** Set up device and status reporting ****
260 OPEN "COM1:9600,n,8,1,CS30000,LF" FOR RANDOM AS #1
280 '**** Set up AFG 100 and status reporting ****
290 PRINT #1, IDCL$; IREN$; ILLO$; "*RST;*CLS"
300
310 '**** Frequency setting ****
320 PRINT #1, "FREQ 1.2345E+3"
330
340 '**** Output wave form setting ****
350 PRINT #1, "W_SQUARE"
360
370 '**** Output level setting ****
380 PRINT #1, "LEVEL 2"
390
400 '**** Signal output setting ****
410 PRINT #1, "OUT_ON"
420
430 '**** Set local mode ****
440 PRINT #1, "*OPC?"
450 INPUT #1, A$
460 PRINT #1, IGTL$
470
480 '**** Close statement ****
490 CLOSE #1
500
510 END
```

## **8 Loading External Arbitrary Signals**

Introduction

Each arbitrary signal which is to be used within the AFG 100 must be generated externally. The data which have been generated (samples) must have a defined format and can be loaded into the AFG 100 as a TXT file or a BIN file via interface RS-232C.

Several options are available for data transmission with a PC (e.g. MS-DOS, Special Program).

After activating ARBITRARY mode, the transmitted arbitrary signal is loaded into the main memory (DDS RAM) and is available as a wave form.

#### 8.1 File Creation

#### 8.1.1 Structure of a TXT File (ASCII)

Instructions

The file should have the following structure:

- 1. Command REN
  - Activating the remote control
- 2. Command ARB\_ADR 0
  - Input of the start address when saving the arbitrary signal (see 7.3.2.9)
- 3. 8192 × command ARB\_DATA <X...X>
  - Saving the 8,192 samples of an arbitrary signal (see 7.3.2.9)

Simple ASCII TXT file with arbitrary signal

Ø9H ARB ADR 0

ARB\_DATA <Value\_1> ARB\_DATA <Value\_2> ARB\_DATA <Value\_3>

ARB\_DATA <Value\_8192>

**P** Note Each instruction can be found on one line of the file, i. e. it is concluded with the final characters CR (13 dec.) and LF (10 dec.).

#### 8.1.2 Structure of a BIN File (HEX)

Instructions

The file should have the following structure:

- 1. Command REN
  - Activating the remote control
- 2. Command ARB #516384
  - The instruction leads the block of the binary data which characterizes the arbitrary signal with a length of 16,384 bytes.
- 3.  $8,192 \times \text{byte Arbitrary dat} < XX >$ 
  - Saving the 8,192 samples of an arbitrary signal (see 7.3.2.9)

Simple binary file with arbitrary signal

```
Ø9H
ARB #516384<H byte-Value 1><L byte-
```

Value\_1> ... <H\_byte-Value\_8129><L\_byte-

Value\_8129>

#### 8.2 Data Transmission

#### 8.2.1 Transmission of a TXT file

#### 8.2.1.1 Transmission via MS DOS

Instructions

- **1.** Make the connection between AFG 100 and PC (see 7.1).
- **2.** Set the following interface parameters in the AFG 100:
  - Baud rate: max. 4,800 Bd (see 7.1.1.1)
  - Transmission protocol: switched off (see 7.1.1.2)
- **3.** Configure the PC with the following command:
  - MODE COMz:4800,N,8,1

where: **z** - number of the serial port

- **4.** Transmit the TXT file from the PC to the AFG 100 with the following command:
  - COPY x.y COMz: /B /V

where: x.y - file name of the TXT file

**z** - number of the serial port of the PC

Note

The transmission time is approx. 4 minutes. After fault-free completion of the transmission confirmation appears at the screen.

## 8.2.1.2 Transmission via Windows with the Help of the TERMINAL Program

Instructions

- 1. Make the connection between AFG 100 and PC (see 7.1).
- 2. Set the following interface parameters in the AFG 100:
  - Baud rate: max. 4,800 Bd (see 7.1.1.1)
  - Transmission protocol: switched off (see 7.1.1.2)
- **3.** Configure the serial interface in the program TERMINAL via the menu: Settings\Communication.

■ Baud rate: max. 4,800 Bd

Data bits:Stop bits:

Parity: without
Control of the data flow: none
Parity check: none
Detecting of the disk: none
Serial port: COM 1/2

- **4.** Set the control of the data flow in the program TERMINAL via the menu: Settings\Transmitting Of The Text.
  - Standard control of the data flow
- **5.** Activate the data transmission in the program TERMINAL via the menu: Transmission\Send Text File
  - Select the corresponding file with arbitrary signals
  - Set the option "after the CR sign without changes" (neither add nor leave out the sign LF)
  - Transmit the TXT file from the PC to the AFG 100

#### ■ Note

The transmission time is approx. 4 minutes. After fault-free completion of the transmission confirmation appears at the screen.

#### 8.2.2 Transmission of a BIN File

#### 8.2.2.1 Transmission via MS DOS

Instructions

- 1. Make the connection between AFG 100 and PC (see 7.1).
- 2. Set the following interface parameters in the AFG 100:
  - Baud rate: max. 19,200 Bd (see 7.1.1.1)
  - Transmission protocol: switched off (see 7.1.1.2)
- **3.** Configure the PC with the following command:
  - MODE COMz:19200,N,8,1

where: **z** - number of the serial port

- **4.** Transmit the BIN file from the PC to the AFG 100 with the following command:
  - COPY x.y COMz: /B /V

where: x.y - file name of the BIN file

**z** - number of the serial port of the PC

#### 

The transmission time is approx. 8 seconds. After fault-free completion of the transmission confirmation appears at the screen.

#### 8.2.2.2 Transmission via Windows with the Help of the TERMINAL Program

Instructions

- 1. Make the connection between AFG 100 and PC (see 7.1).
- 2. Set the following interface parameters in the AFG 100:
  - Baud rate: max. 19,200 Bd (see 7.1.1.1)
  - Transmission protocol: switched off (see 7.1.1.2)
- **3.** Configure the serial interface in the program TERMINAL via the menu: Settings\Communication.

■ Baud rate: max. 19,200 Bd

Data bits:Stop bits:

Parity: without
Control of the data flow: none
Parity check: none
Detecting of the disk: none
Serial port: COM 1/2

- **4.** Set the control of the data flow in the program TERMINAL via the menu: Settings\Transmitting Of The Text.
  - Standard control of the data flow
- **5.** Activate the data transmission in the program TERMINAL via the menu: Transmission\Send Text File
  - Select the corresponding file with arbitrary signals
  - Set the option "after the CR sign without changes" (neither add nor leave out the sign LF)
  - Transmit the TXT file from the PC to the AFG 100

 The transmission time is approx. 8 seconds. After fault-free completion of the transmission confirmation appears at the screen.

#### 8.2.3 Transmission with Special Program

Instructions

- 1. Make the connection between AFG 100 and PC (see 7.1).
- **2.** Set the following interface parameters in the AFG 100:
  - Baud rate: max. 19,200 Bd (see 7.1.1.1)
  - Transmission protocol: switched off (see 7.1.1.2)
- **3.** Start the special program **ARB\_AFG.EXE** and set the following parameters:
  - Number of the serial port of the PC: COM 1/2
  - Baud rate: according to AFG 100
  - Name of the TXT file or BIN file
- **4.** Transmit the TXT file or BIN file from the PC to the AFG100.

The program makes possible the conversion of a TXT file to a BIN file simultaneously.

## 8.3 Activating the Arbitrary Signal

Instructions

- **1.** Press the **F4 button LOC** [8] of the AFG 100 after transmission of the TXT file or BIN file.
  - The AFG 100 changes from remote control to local control.
- **2.** Set the wave form **ARBITRARY** at the AFG 100 (see 6.3.4).
  - The transferred arbitrary signal is loaded in the main memory (DDS RAM) and is available as wave form.

#### **8.4** Contents of Enclosed Diskette

Contents of the diskette

There are the following files on the diskette:

- **READ\_ME.DOC** Description "loading of external arbitrary signals" (see 8)
- ARB\_AFG.EXE Special program for data transmission
- ARB\_FCE.TXT TXT file for an arbitrary signal

Text file ARB\_FCE.TXT

The generated arbitrary signal is described with the following equation:

$$f(x) = INT \left( \frac{2^{10}}{2} * sin \left( \frac{16 * x}{8192} * 2\pi \right) * exp^{-\frac{4 * x}{8192}} + \frac{2^{10}}{2} \right)$$

The TXT file can be loaded in the AFG 100 with the above-mentioned possibilities of data transmission.

57

## **9 Care and Maintenance**

<u> </u>	The AFG 100 must be separated from all power sources before maintenance work is carried out and before parts or fuses are repaired or replaced.
Care	Only use a soft wet rag with some soap suds or a soft rinse liquid for cleaning. Avoid acrid cleanser and solvents.
Maintenance	The AFG 100 does not require special maintenance if it is used and handled correctly.  Service work should only be done by trained personnel.  In case of repairs it is vital to ensure that the design features of the AFG 100 are not changed, resulting in a reduction in operational safety, and that replacement parts match the original ones and are installed properly (original state).

## 10 Appendix

## **10.1 List of Operating Functions**

Operating function		Butten sequence in the operating state	
Operating parameters:			
Input of the output frequency	(FREQ)	F1: F2-F3 [ ◆ ▶ ],	
Input of the output level	(LEVEL)	F2: F2-F3 [	
Input of the dc voltage offset	(OFFSET)	F2: F1 [♦], F2-F3 [ ♦ ▶], ☐ [Offset], F4	
Selecting the wave form	(WAVE)	F3: C [Wave form], F4	
Input of the sample period	(FREQ)	F1: C [Sample period], F4	
at arbitrary signals	()	The feature beneal, 14	
Operating modes:			
Activating the outputs:			
Switching on/off	(SIGNAL)	F4, F1, F2/F3: 🗗 [ON/OFF], F4,	
the signal output			
Switching on/off	(SYNC)	<b>F4</b> , <b>F1</b> , <b>F1</b> : ☐ [POS/NEG/OFF], <b>F4</b> ,	
the sync output			
Activating the sweep function:			
Switching on/off	(MOD)	<b>F4, F2, F1:</b> 🗗 [LIN/LOG/OFF], <b>F4</b> ,	
the sweep function			
Input of the frequency limits	(FREQ)	F4, F2, F2: F2-F3 [ ◆ → ], 🕒 [START], F1 [♦],	
		F2-F3 [ ◆ → ], 🗗 [STOP], F4,	
Input of the period	(ST)	<b>F4, F2, F3: F2-F3</b> [ <b>♦ ▶</b> ], <b>☐</b> [Period], <b>F4</b> ,	
Activating the amplitude modulation:			
Switching on/off	(MOD)	F4, F3, F1: 🗗 [INT/EXT/OFF], F4,	
the amplitude modulation			
Input of the modulation depth	(DEPTH)	<b>F4</b> , <b>F3</b> , <b>F2</b> : <b>F2-F3</b> [ ◆ ▶ ], ☐ [AM depth], <b>F4</b> ,	
at internal AM			
Input of the frequency	<b>(F</b> )	<b>F4</b> , <b>F3</b> , <b>F3</b> : 🗗 [AM Freq.], <b>F4</b> ,	
at internal AM			
User settings:			
Switching on/off	( <b>PS</b> )	F4, F4, F2, F1: 🗗 [ON/OFF], F4,	
the initialization test			
Self-diagnosis	(TEST)	<b>F4, F4, F2, F2:</b> [Result], <b>F4,</b>	
Adapting the display:			
Contrast setting	(CONT)	<b>F4</b> , <b>F4</b> , <b>F2</b> , <b>F3</b> , <b>F1</b> : 🗗 [0-100 %], <b>F4</b> ,	
Brightness setting	(BRIGHT)	<b>F4</b> , <b>F4</b> , <b>F2</b> , <b>F3</b> , <b>F2/F3</b> : <b>□</b> [0-100 %], <b>F4</b> ,	
instrument settings:			
Saving the instrument settings	(STO)	<b>F4</b> , <b>F4</b> , <b>F2</b> , <b>F4</b> , <b>F1</b> : 🕒 [Memory 1-9], <b>F4</b> ,	
Loading the instrument settings	(RCL)	<b>F4</b> , <b>F4</b> , <b>F2</b> , <b>F4</b> , <b>F2</b> : 🗗 [Memory 0-9], <b>F4</b> ,	
Configuring the interface:			
Baud rate	(BDR)	F4, F4, F1, F1:  [Bd rate], F4,	
Transmission protocol	(PROT)	F4, F4, F1, F2: C [Protocol], F4,	
<b>Special functions:</b>			
Password input	(SPC)	<b>F4</b> , <b>F4</b> , <b>F3</b> : <b>F2</b> - <b>F3</b> [ ◆ ▶ ], <b>□</b> [Password], <b>F4</b> ,	

#### 10.2 List of Instrument Messages

GENE	RATOR	AFG100
Powe	r Up Se	elfTest

- Internal test starts (see 6.2)

Т	е	s	t	i	n	g	:	< U N I T >
								PASSED

 Faultless test, **<UNIT>** stands for the unit which has just been tested (see 6.2)

Testing: <UNIT>

Error during test, **<UNIT>** stands for the unit which has just been tested (see 6.2)

GENERATOR AFG100 Calibration OFF!

- Warning with error characteristics (see 6.2)

GENERATOR AFG100 Bad Backup RAM - Error description (see 6.2)

GENERATOR AFG100 Bad EEPROM CRC - Error description (see 6.2)

GENERATOR AFG100 Ver: 2,00 - Version of the firmware (see 6.2)

GENERATOR AFG100 READY - Operational readiness of the AFG 100 (see 6.2)

Current Setting:

- Saving the current instrument settings (see 6.5.4.1)

Default Setting
..... LOADING

 Loading the manufacture's instrument settings (see 6.5.4.2)

User Setting

 Loading of the saved user settings (see 6.5.4.2)

User Setting ... Is Not Defined!

- No settings are saved (see 6.5.4.2)

Password: 00000000

- Password input (see 6.6)

Password: INVALID!

- Invalid password (see 6.6)

\*\* Error: 31 \*\* RPP Tripped!  Signal output of external source is overloaded (see 6.7)