

# View Options

## Toolbar

### (View -> Toolbar)

Selecting the **Toolbar** item in the **View** menu, the Toolbar becomes accessible.  
When the **Toolbar** is displayed in the main window the symbol ✓ appears in front of the **Toolbar** item.

*See Also:*

**The Tool Bar**

## Status Bar

### (View -> Status Bar)

Selecting the **Status Bar** item in the **View** menu, the Status Bar becomes accessible.  
When the **Status Bar** is selected the symbol ✓ is displayed.

## Zoom Fault Window

### (View -> Zoom Fault Window)

Selecting the **Zoom Fault Window** in the **View** menu, the Event Monitor Window disappears and the Alarm Monitor Window is magnified.

When the **Zoom Fault Window** is selected the symbol ✓ is displayed.

*See Also:*

**Alarm and Event Monitor Window**

## Refresh

### (View -> Refresh)

Selecting the **Refresh** item in the **View** menu, a refresh operation is performed on the Control Application, in order to remove any eventual condition of misalignment between the physical equipment and its graphical representation (this is done for LEDs status).

PAGE INTENTIONALLY LEFT BLANK