


User's Manual



Digital AC/DC Clamp Meter

Model 38394



INTRODUCTION

Congratulations on your purchase of Extech's 38394 AC/DC Clamp Meter. This clamp meter measures AC/DC Current to 600A, DC/AC Voltage, Resistance, Frequency, and Continuity. Proper use and care of this meter will yield years of reliable service.

SAFETY

Safety Symbols



This symbol, adjacent to another symbol or terminal, indicates the user must refer to the manual for further information.



This symbol, adjacent to a terminal, indicates that, under normal use, hazardous voltages may be present



Double insulation

WARNING: This indicates that a potentially hazardous condition which, if not avoided, could result in death or serious injury.

CAUTION: This indicates that a potentially hazardous condition which, if not avoided, could result in injury or damage to the meter.

Safety Precautions

WARNING: Improper use of this meter can cause damage, shock, injury or death. Read and understand this user's manual before operating the meter.

1. Always remove the test leads before making current measurements.
2. Always remove the test leads before replacing the batteries.
3. Inspect the condition of the jaws, test leads and the meter for any damage before operating the meter. Repair any damage or replace meter before use.
4. Do not exceed the maximum rated input limits.
5. Use great care when making measurements, especially when the voltages are greater than 25VAC rms or 35VDC. These voltages are considered a shock hazard.
6. Always discharge capacitors and remove power from the dut before performing Resistance or Continuity tests.
7. Remove the batteries from the meter if the meter is to be stored for long periods.
8. Ensure that the selected meter function matches the measurement to be taken
9. If the measured current is higher than the range selected for long periods, overheating may occur compromising the safety and the operation of the meter's internal circuits
10. To avoid discharge risks and erroneous readings, do not measure current on high voltage conductors (>600V)

SPECIFICATIONS


Function	Range	Accuracy		
AC/DC Current	240.0A	±(2% rdg + 5d) (AC @ 50/60Hz)		
	600A	±(2% rdg + 8d)		
AC Voltage	2.400V, 24.00V, 240.0V, 600.0V	±(1.2% rdg + 5d) (AC @ 50/60Hz)		
DC Voltage	240.0mV	±(0.5% rdg + 2d)		
	2.400V, 24.00V, 240.0V, 600V	±(1.0% rdg + 2d)		
Resistance	240.0Ω, 2.400kΩ, 24.00kΩ, 240.0kΩ	±(1% rdg + 5d)		
	2.400MΩ	±(2% rdg + 2d)		
	24.00MΩ	±(3.5% rdg + 5d)		
Frequency (≥ 5V)	50.00Hz, 500.0Hz, 5.000kHz, 50.00kHz, 100.0kHz	±(1% rdg + 5d)		
Continuity	Audible tone <40Ω approximately			
Input Limits	Function	Maximum Input	Function	Maximum Input
	V DC/AC	600V DC or AC Peak	Frequency	250V DC or AC peak
	A DC/AC	600A DC/AC, fused	Resistance	400V DC or AC peak (<10 seconds)

Conductor Size:	1.18" (30mm) maximum
Battery type:	2 x 1.5V AA
Range Selection:	Automatic ranging
Display:	5000 Count LCD
Overload Indication:	"OL"
Low Battery Indication:	Battery icon
Environmental conditions	Installation Category II, Pollution degree 2, Altitude: 2000 meters, Indoor use only
Operating Temperature/Humidity	32° to 122°F (0°C to 50°C) / <80% RH
Storage Temperature/Humidity	14° to 140°F (-10°C to 60°C) / <80% RH
Dimensions	7.0x4.2x1.3" (178x64x33mm)
Weight	8.3 oz. (230g)
Zero Adjust	Uses REL (Relative) push button
Diode	Short/Open, Good/Defect Test
Sample Time	0.35 sec approximately.
Input Impedance	10MΩ for ACV & DCV






METER DESCRIPTION

Front panel

1. Current Jaws
2. Jaw opening trigger
3. Rotary function switch
4. REL key
5. DATA HOLD key
6. Function key
7. Range key
8. LCD display
9. COM & V/ Ω input jacks



Symbols and Units of measure


	AC Current or Voltage
	DC Voltage
	Continuity
	Diode test
Hold	Display Data Hold
Auto	Auto Range
	Low Battery icon
V	Volt (voltage)
Ω	Ohm (resistance)
A	Amp (current)
REL	Relative Mode
Hz, KHz	Frequency

OPERATING INSTRUCTIONS

AC/DC Current Measurements

WARNING: Ensure that the test leads are disconnected from the meter before making current clamp measurements.

1. Set the Function switch to the **600A** range.
2. Press the **FUNC** key to select AC or DC (the AC/DC icons will toggle on the LCD with each key press).
3. Press the trigger to open jaw. Fully enclose one conductor to be measured.
4. The clamp meter will display reading and automatically select the proper range



AC/DC Voltage Measurements

1. Set the Function Switch to the **V** position.
2. Press the **FUNC** key to select AC or DC Voltage. The meter will display the selected unit of measure (AC or DC) on the left side of the LCD.
3. Insert the black test lead to the **COM** input jack and the red test lead to the **V** jack.
4. Connect the test leads in **PARALLEL** with the circuit to be measured.
5. Read the measured value from the LCD display.



Manual Range

This meter is automatic ranging. However, the range can be manually held and selected. To manual hold the range, press the **RANGE** key until the desired display range is selected. The units of measure and decimal positioning will change with each press of the **RANGE** key.

Resistance Measurements

CAUTION: Before taking any in-circuit resistance measurements, remove power from the circuit under test and discharge all capacitors.

1. Insert the black test lead to the **COM** input jack and the red test lead to the Ω input jack.
2. Set the Function switch to the **(•)))** Ω position, press the **FUNC** key if necessary to display the Ω icon.
3. Connect the test leads to the device under test and read the measured value on the LCD display.

Continuity Test

CAUTION: Before taking measurements, remove power from circuit under test and discharge all capacitors

1. Insert the black test lead to the **COM** input jack and the red test lead to the Ω input jack.
2. Set the Function switch to the **(•)))** Ω position.
3. Press the **FUNC** key until the **(•)))** icon appears on the upper right-hand portion of the LCD.
4. Connect the test lead tips to the device to be measured.
5. If the resistance is $< 40\Omega$ (approx.) a tone will sound.

Frequency Measurements

CAUTION: Before taking any in-circuit measurements, remove power from the circuit under test and discharge all capacitors.

1. Insert the black test lead to the **COM** input jack and the red test lead to the **V Ω** input jack.
2. Set the Function switch to the **Hz** position.
3. Connect the test lead tips to the device under test.
4. Read the measured value from the LCD display.

Diode Test

CAUTION: Before taking measurements, remove power from circuit under test and discharge all capacitors

1. Insert the black test lead to the **COM** input jack and the red test lead to the **V/ Ω** input jack
2. Set the Function switch to the **•))) Ω** position
3. Press the **FUNC** key until the “**▶**” icon appears on the upper right-hand side of the LCD.
4. Connect the test lead tips to the device to be measured
5. Note the displayed reading
6. Reverse the test lead polarity by swapping the red and black lead connection. Note this reading also.
 - a. If one reading displays a value and the other reading displays “OL”, the diode is good
 - b. If both readings display “OL”, the device is open
 - c. If both readings are very small or 0, the device is shorted

Data Hold

Press the **HOLD** key momentarily to freeze the present reading on the LCD. **Hold** will appear in the display. Press the **H** key again to return to normal operation.

Relative Mode

The Relative mode permits the user to store a reference reading and compare all subsequent readings to the stored reference value. Subsequent readings will display a value that is the difference between the actual reading and the stored value.

1. Press the **REL** key when the desired value is displayed on the meter. This becomes the stored reference.
2. Take measurements and note that the meter displays the actual reading minus the reference reading.
3. Press the **REL** key to return to normal operation.

Using Relative Mode to zero the meter

Press the **REL** key to zero the meter. Ensure that the test leads and clamp jaw are not connected to any circuit while doing so. The display will read zero and all subsequent readings will be displayed relative to zero. Zero as often as necessary.

MAINTENANCE

WARNING: To avoid electrical shock or damage to the meter, keep moisture from entering the meter housing. Also, remove the test leads before opening the meter housing.

Cleaning

Periodically wipe the case with a damp cloth and mild detergent. Do not use abrasives or solvents.

Battery Replacement

When the two AA 1.5V batteries fall to critical voltage levels, the meter will display the low battery symbol. To replace the batteries, remove the rear battery compartment cover.

WARRANTY

EXTECH INSTRUMENTS CORPORATION warrants this instrument to be free of defects in parts and workmanship for one year from date of shipment (a six month limited warranty applies on sensors and cables). If it should become necessary to return the instrument for service during or beyond the warranty period, contact the Customer Service Department at (781) 890-7440 ext. 210 for authorization. A Return Authorization (RA) number must be issued before any product is returned to Extech. The sender is responsible for shipping charges, freight, insurance and proper packaging to prevent damage in transit. This warranty does not apply to defects resulting from action of the user such as misuse, improper wiring, operation outside of specification, improper maintenance or repair, or unauthorized modification. Extech specifically disclaims any implied warranties or merchantability or fitness for a specific purpose and will not be liable for any direct, indirect, incidental or consequential damages. Extech's total liability is limited to repair or replacement of the product. The warranty set forth above is inclusive and no other warranty, whether written or oral, is expressed or implied.

REPAIR AND CALIBRATION SERVICES

Extech offers complete repair and calibration services for all Extech products. For periodic calibration, NIST certification or repair of any Extech product, call customer service for details on services available. Extech recommends that calibration be performed on an annual basis.

**Copyright © 2002 Extech Instruments Corporation. All rights reserved
including the right of reproduction in whole or in part in any form.**



Tech Support Hotlines
781-890-7440 ext. 200
extech@extech.com
www.extech.com