

# Timer/Counter/ Analyzer

PM6690

*Operators Manual*

**FLUKE®**

PN 4822 872 20301  
April 2005 - First Edition

© 2005 Pendulum Instruments AB. All rights reserved.  
Printed in Sweden.

# Table of Contents

GENERAL INFORMATION . . . . .	VI	<b>2 Using the Controls</b>	
About this Manual . . . . .	VI	Basic Controls . . . . .	2-2
Warranty . . . . .	VI	Secondary Controls . . . . .	2-4
Declaration of Conformity . . . . .	VI	Connectors & Indicators . . . . .	2-4
		Rear Panel . . . . .	2-5
<b>1 Preparation for Use</b>		Description of Keys . . . . .	2-6
<b>Preface</b> . . . . .	<b>1-2</b>	Power . . . . .	2-6
Introduction . . . . .	1-2	Select Function . . . . .	2-6
Powerful and Versatile Functions . . . . .	1-2	Autoset/Presets . . . . .	2-6
No Mistakes . . . . .	1-3	Move Cursor . . . . .	2-6
Design Innovations . . . . .	1-3	Display Contrast . . . . .	2-7
State of the Art Technology Gives		Enter . . . . .	2-7
Durable Use . . . . .	1-3	Save & Exit . . . . .	2-7
High Resolution . . . . .	1-3	Don't Save & Exit . . . . .	2-7
Remote Control . . . . .	1-4	Presentation Modes . . . . .	2-7
Fast GPIB Bus . . . . .	1-4	Entering Numeric Values . . . . .	2-8
<b>Safety</b> . . . . .	<b>1-5</b>	Hard Menu Keys . . . . .	2-9
Introduction . . . . .	1-5	Default Settings . . . . .	2-15
Safety Precautions . . . . .	1-5		
Caution and Warning Statements . . . . .	1-6	<b>3 Input Signal Conditioning</b>	
Symbols . . . . .	1-6	Input Amplifier . . . . .	3-2
If in Doubt about Safety . . . . .	1-6	Impedance . . . . .	3-2
<b>Unpacking</b> . . . . .	<b>1-7</b>	Attenuation . . . . .	3-2
Check List . . . . .	1-7	Coupling . . . . .	3-3
Identification . . . . .	1-7	Filter . . . . .	3-3
Installation . . . . .	1-7	Man/Auto . . . . .	3-4
Supply Voltage . . . . .	1-7	Trig . . . . .	3-5
Grounding . . . . .	1-8	How to Reduce or Ignore Noise and	
Orientation and Cooling . . . . .	1-8	Interference . . . . .	3-6
Fold-Down Support . . . . .	1-8	Trigger Hysteresis . . . . .	3-6
Rackmount Adapter . . . . .	1-9	How to use Trigger Level Setting . . . . .	3-7

## 4 Measuring Functions

<b>Introduction to This Chapter</b> . . . . .	<b>4-2</b>
Selecting Function . . . . .	4-2
<b>Frequency Measurements</b> . . . . .	<b>4-3</b>
FREQ A, B . . . . .	4-3
FREQ C . . . . .	4-3
RATIO A/B, B/A, C/A, C/B . . . . .	4-4
BURST A, B, C . . . . .	4-4
Triggering . . . . .	4-4
Burst Measurements using Manual Presetting . . . . .	4-5
Frequency Modulated Signals . . . . .	4-6
Carrier Wave Frequency $f_0$ . . . . .	4-6
$f_{max}$ . . . . .	4-7
$f_{min}$ . . . . .	4-7
$\Delta f_{p-p}$ . . . . .	4-8
Errors in $f_{max}$ , $f_{min}$ , and $\Delta f_{p-p}$ . . . . .	4-8
AM Signals . . . . .	4-8
Carrier Wave Frequency . . . . .	4-8
Modulating Frequency . . . . .	4-9
Theory of Measurement . . . . .	4-9
Reciprocal Counting . . . . .	4-9
Sample-Hold . . . . .	4-10
Time-Out . . . . .	4-10
Measuring Speed . . . . .	4-10
PERIOD . . . . .	4-12
Single A, B . . . . .	4-12
Average A, B, C . . . . .	4-12
<b>Time Measurements</b> . . . . .	<b>4-13</b>
Introduction . . . . .	4-13
Triggering . . . . .	4-13
Time Interval . . . . .	4-14
Time Interval A to B . . . . .	4-14
Time Interval B to A . . . . .	4-14
Time Interval A to A, B to B . . . . .	4-14
Rise/Fall Time A/B . . . . .	4-14
Pulse Width A/B . . . . .	4-15
Duty Factor A/B . . . . .	4-15
Measurement Errors . . . . .	4-15
Hysteresis . . . . .	4-15
Overdrive and Pulse Rounding . . . . .	4-16
Auto Trigger . . . . .	4-16
<b>Phase</b> . . . . .	<b>4-17</b>
What is Phase? . . . . .	4-17
Resolution . . . . .	4-17
Possible Errors . . . . .	4-18

Inaccuracies . . . . .	4-18
<b>Voltage</b> . . . . .	<b>4-22</b>
$V_{MAX}$ , $V_{MIN}$ , $V_{PP}$ . . . . .	4-22
$V_{RMS}$ . . . . .	4-23

## 5 Measurement Control

About This Chapter . . . . .	5-2
Measurement Time . . . . .	5-2
Gate Indicator . . . . .	5-2
Single Measurements . . . . .	5-2
Hold/Run & Restart . . . . .	5-2
Arming . . . . .	5-2
Start Arming . . . . .	5-3
Stop Arming . . . . .	5-3
<b>Controlling Measurement Timing</b> . . . . .	<b>5-4</b>
The Measurement Process . . . . .	5-4
Resolution as Function of Measurement Time . . . . .	5-4
Measurement Time and Rates . . . . .	5-5
What is Arming? . . . . .	5-5
Arming Setup Time . . . . .	5-9
Arming Examples . . . . .	5-9
Introduction to Arming Examples . . . . .	5-9
#1 Measuring the First Burst Pulse . . . . .	5-9
#2 Measuring the Second Burst Pulse . . . . .	5-11
#3 Measuring the Time Between Burst Pulse #1 and #4 . . . . .	5-12
#4 Profiling . . . . .	5-13

## 6 Process

Introduction . . . . .	6-2
Averaging . . . . .	6-2
Mathematics . . . . .	6-2
Example: . . . . .	6-2
Statistics . . . . .	6-3
Allan Deviation vs. Standard Deviation . . . . .	6-3
Selecting Sampling Parameters . . . . .	6-3
Measuring Speed . . . . .	6-4
Determining Long or Short Time Instability . . . . .	6-4
Statistics and Mathematics . . . . .	6-5
Confidence Limits . . . . .	6-5
Jitter Measurements . . . . .	6-5
Limits . . . . .	6-6
Limit Behavior . . . . .	6-6
Limit Mode . . . . .	6-7
Limits and Graphics . . . . .	6-7

## 7 Performance Check

General Information . . . . .	7-2
Preparations . . . . .	7-2
Test Equipment . . . . .	7-2
Front Panel Controls . . . . .	7-3
Internal Self-Tests . . . . .	7-3
Keyboard Test . . . . .	7-3
Short Form Specification Test . . . . .	7-5
Sensitivity and Frequency Range . . . . .	7-5
Voltage . . . . .	7-6
Trigger Indicators and Input Controls . . . . .	7-7
Trigger Level Check . . . . .	7-8
Reference Oscillators . . . . .	7-8
Resolution Test . . . . .	7-9
Rear Inputs/Outputs . . . . .	7-9
10 MHz OUT . . . . .	7-9
EXT REF FREQ INPUT . . . . .	7-9
EXT ARM INPUT . . . . .	7-9
Measuring Functions . . . . .	7-10
Check of HOLD OFF Function . . . . .	7-10
Options . . . . .	7-11
Input C Check . . . . .	7-11

## 8 Specifications

Introduction . . . . .	8-2
Measurement Functions . . . . .	8-2
Frequency A, B, C . . . . .	8-2
Frequency Burst A, B, C . . . . .	8-2
Period A, B, C Average . . . . .	8-2
Period A, B Single . . . . .	8-3
Ratio A/B, B/A, C/A, C/B . . . . .	8-3
Time Interval A to B, B to A, A to A, B to B . . . . .	8-3
Pulse Width A, B . . . . .	8-3
Rise and Fall Time A, B . . . . .	8-3
Phase A Rel. B, B Rel. A . . . . .	8-4
Duty Factor A, B . . . . .	8-4
$V_{max}$ , $V_{min}$ , $V_{p-p}$ A, B . . . . .	8-4
Timestamping A, B . . . . .	8-4
Auto Set / Manual Set . . . . .	8-5
Input and Output Specifications . . . . .	8-5
Inputs A and B . . . . .	8-5
Input C (PM6690/6xx) . . . . .	8-6
Input C (PM6690/7xx) . . . . .	8-6
Rear Panel Inputs & Outputs . . . . .	8-6
Auxiliary Functions . . . . .	8-7
Trigger Hold-Off . . . . .	8-7
External Start/Stop Arming . . . . .	8-7

Statistics . . . . .	8-7
Mathematics . . . . .	8-7
Other Functions . . . . .	8-7
Display . . . . .	8-8
GPIB Interface . . . . .	8-8
USB Interface . . . . .	8-8
TimeView™ . . . . .	8-8
Measurement Uncertainties . . . . .	8-9
Random Uncertainties . . . . .	8-9
Systematic Uncertainties . . . . .	8-9
Time Interval, Pulse Width, Rise/Fall Time . . . . .	8-10
Frequency & Period . . . . .	8-10
Ratio $f_1/f_2$ . . . . .	8-10
Phase . . . . .	8-10
Duty Factor . . . . .	8-10
Calibration . . . . .	8-11
Definition of Terms . . . . .	8-11
General Specifications . . . . .	8-11
Environmental Data . . . . .	8-11
Power Requirements . . . . .	8-11
Explanations . . . . .	8-12
Timebase Options . . . . .	8-12
Dimensions & Weight . . . . .	8-13
Ordering Information . . . . .	8-13

## 9 Index

## 10 Service

Sales and Service office . . . . .	10-2
------------------------------------	------

# GENERAL INFORMATION

## About this Manual

This manual contains directions for use that apply to the Timer/Counter/Analyzer PM6690.

In order to simplify the references, the PM6690 is further referred to throughout this manual as the '90'.

## Warranty

The Warranty Statement is part of the *Getting Started Manual* that is included with the shipment.

## Declaration of Conformity

The complete text with formal statements concerning product identification, manufacturer and standards used for type testing is available on request.

*Chapter 1*

# **Preparation for Use**

# Preface

## Introduction

Congratulations on your choice of instrument. It will serve you well for many years to come.

Your Timer/Counter/Analyzer is designed to bring you a new dimension to bench-top and system counting. It offers significantly increased performance compared to traditional Timer/Counters. The '90' offers the following advantages:

- 12 digits of frequency resolution per second and 100 ps resolution, as a result of high-resolution interpolating reciprocal counting.
- A variety of HF prescaler options with upper frequency limits ranging from 3 GHz to 8 GHz.
- Integrated high performance GPIB interface using SCPI commands.
- A fast USB interface that replaces the traditional but slower RS-232 serial interface.
- Timestamping; the counter records exactly when a measurement is made.
- A high measurement rate of up to 250 k readings/s to internal memory.

## Powerful and Versatile Functions

A unique performance feature in your new instrument is the comprehensive arming possibilities, which allow you to characterize virtually any type of complex signal concerning frequency and time.

For instance, you can insert a delay between the external arming condition and the actual arming of the counter. Read more about Arming in Chapter 5, “Measurement Control”.

In addition to the traditional measurement functions of a timer/counter, these instruments have a multitude of other functions such as phase, duty factor, rise/fall-time and peak voltage. The counter can perform all measurement functions on both main inputs (A & B). Most measurement functions can be armed, either via one of the main inputs or via a separate arming channel (E).

By using the built-in mathematics and statistics functions, the instrument can process the measurement results on your benchtop, without the need for a controller. Math functions include inversion, scaling and offset. Statistics functions include Max, Min and Mean as well



as Standard and Allan Deviation on sample sizes up to  $2 \times 10^9$ .

## No Mistakes

You will soon find that your instrument is more or less self-explanatory with an intuitive user interface. A menu tree with few levels makes the timer/counter easy to operate. The large backlit graphic LCD is the center of information and can show you several signal parameters at the same time as well as setting status and operator messages.

Statistics based on measurement samples can easily be presented as histograms or trend plots in addition to standard numerical measurement results like max, min, mean and standard deviation.

The AUTO function triggers automatically on any input waveform. A bus-learn mode simplifies GPIB programming. With bus-learn mode, manual counter settings can be transferred to the controller for later reprogramming. There is no need to learn code and syntax for each individual counter setting if you are an occasional bus user.

# Design Innovations

## State of the Art Technology Gives Durable Use

These counters are designed for quality and durability. The design is highly integrated. The digital counting circuitry consists of just one custom-developed FPGA and a 32-bit microcontroller. The high integration and low component count reduces power consumption and results in an MTBF of 30,000 hours. Modern surface-mount technology ensures high production quality. A rugged mechanical construction, including a metal cabinet that withstands mechanical shocks and protects against EMI, is also a valuable feature.

## High Resolution

The use of *reciprocal interpolating counting* in this new counter results in excellent relative resolution: 12 digits/s for *all* frequencies.

The measurement is synchronized with the input cycles instead of the timebase. Simultaneously with the normal “digital” counting, the counter makes analog measurements of the time between the start/stop trigger events and the next following clock pulse. This is done in four identical circuits by charging an integrating capacitor with a constant current, starting at the trigger event. Charging is stopped at the leading edge of the first following clock pulse. The stored charge in the integrating capacitor represents the time difference between the start trigger event and the leading edge of the first following clock pulse. A similar charge integration is made for the stop trigger event.

When the “digital” part of the measurement is ready, the stored charges in the capacitors are

measured by means of Analog/Digital Converters.

The counter's microprocessor calculates the result after completing all measurements, i.e. the digital time measurement and the analog interpolation measurements.

The result is that the basic "digital resolution" of  $\pm 1$  clock pulse (10 ns) is reduced to 100 ps for the '90'.

Since the measurement is synchronized with the input signal, the resolution for frequency measurements is very high and independent of frequency.

The counters have 14 display digits to ensure that the display itself does not restrict the resolution.

## Remote Control

This instrument is programmable via two interfaces, GPIB and USB.

The GPIB interface offers full general functionality and compliance with the latest standards in use, the IEEE 488.2 1987 for HW and the SCPI 1999 for SW.

In addition to this 'native' mode of operation there is also a second mode that emulates the Agilent 53131/132 command set for easy exchange of instruments in operational ATE systems.

The USB interface is mainly intended for the lab environment in conjunction with the optional TimeView™ analysis software. The communication protocol is a proprietary version of SCPI.

## Fast GPIB Bus

These counters are not only extremely powerful and versatile bench-top instruments, they also feature extraordinary bus properties.

The bus transfer rate is up to 2000 triggered measurements/s. Array measurements to the internal memory can reach 250 k measurements/s.

This very high measurement rate makes new measurements possible. For example, you can perform *jitter analysis* on several tens of thousands of pulse width measurements and capture them in a second.

An extensive programming manual helps you understand SCPI and counter programming.

The counter is easy to use in GPIB environments. A built-in *bus-learn* mode enables you to make all counter settings manually and transfer them to the controller. The response can later be used to reprogram the counter to the same settings. This eliminates the need for the occasional user to learn all individual programming codes.

Complete (manually set) counter settings can also be stored in 20 internal memory locations and can easily be recalled on a later occasion. Ten of them can be user protected.

# Safety

## Introduction

Even though we know that you are eager to get going, we urge you to take a few minutes to read through this part of the introductory chapter carefully before plugging the line connector into the wall outlet.

This instrument has been designed and tested for Measurement Category I, Pollution Degree 2, in accordance with EN/IEC 61010-1:2001 and CAN/CSA-C22.2 No. 61010-1-04 (including approval). It has been supplied in a safe condition.

Study this manual thoroughly to acquire adequate knowledge of the instrument, especially the section on *Safety Precautions* hereafter and the section on *Installation* on page 1-7.

## Safety Precautions

All equipment that can be connected to line power is a potential danger to life. Handling restrictions imposed on such equipment should be observed.

To ensure the correct and safe operation of the instrument, it is essential that you follow generally accepted safety procedures in addition to the safety precautions specified in this manual.

The instrument is designed to be used by trained personnel only. Removing the cover for repair, maintenance, and adjustment of the instrument must be done by qualified personnel who are aware of the hazards involved.

**The warranty commitments are rendered void if unauthorized access to the interior of the instrument has taken place during the given warranty period.**

## Caution and Warning Statements

**CAUTION:** Shows where incorrect procedures can cause damage to, or destruction of equipment or other property.

**WARNING:** Shows a potential danger that requires correct procedures or practices to prevent personal injury.



**Fig. 1-1** Do not overlook the safety instructions!

- Inform your Fluke representative.
- For example, the instrument is likely to be unsafe if it is visibly damaged.

## Symbols



Shows where the protective ground terminal is connected inside the instrument. **Never** remove or loosen this screw.



This symbol is used for identifying the functional ground of an I/O signal. It is always connected to the instrument chassis.



Indicates that the operator should consult the manual.

One such symbol is printed on the instrument, below the A and B inputs. It points out that the damage level for the input voltage decreases from 350 V<sub>p</sub> to 12V<sub>rms</sub> when you switch the input impedance from 1 MΩ to 50 Ω.

## If in Doubt about Safety

Whenever you suspect that it is unsafe to use the instrument, you must make it inoperative by doing the following:

- Disconnect the line cord
- Clearly mark the instrument to prevent its further operation

# Unpacking

Check that the shipment is complete and that no damage has occurred during transportation. If the contents are incomplete or damaged, file a claim with the carrier immediately. Also notify your local Fluke sales or service organization in case repair or replacement may be required.

## Check List

The shipment should contain the following:

- Counter/Timer/Analyzer, Model 90
- Line cord
- N-to-BNC Adapter (only if one of the prescaler options has been ordered)
- Printed version of the *Getting Started Manual*.
- Brochure with Important Information
- Certificate of Calibration
- Options you ordered should be installed. See *Identification* below.
- CD including the following documentation in PDF:
  - Getting Started Manual
  - Operators Manual
  - Programming Manual

## Identification

The type plate on the rear panel shows type number and serial number. See illustration on page 2-5. Installed options are listed under the menu *User Options - About*, where you can also find information on firmware version and calibration date. See page 2-12.

## Installation

### Supply Voltage

#### ■ Setting

The Counter may be connected to any AC supply with a voltage rating of 90 to 265  $V_{\text{rms}}$ , 45 to 440 Hz. The counter automatically adjusts itself to the input line voltage.

#### ■ Fuse

The secondary supply voltages are electronically protected against overload or short circuit. The primary line voltage side is protected by a fuse located on the power supply unit. The fuse rating covers the full voltage range. Consequently there is no need for the user to replace the fuse under any operating conditions, nor is it accessible from the outside.

**CAUTION: If this fuse is blown, it is likely that the power supply is badly damaged. Do not replace the fuse. Send the counter to the local Service Center.**

Removing the cover for repair, maintenance and adjustment must be done by qualified and trained personnel only, who are fully aware of the hazards involved.

**The warranty commitments are rendered void if unauthorized access to the interior of the instrument has taken place during the given warranty period.**



## Grounding

Grounding faults in the line voltage supply will make any instrument connected to it dangerous. Before connecting any unit to the power line, you must make sure that the protective ground functions correctly. Only then can a unit be connected to the power line and only by using a three-wire line cord. No other method of grounding is permitted. Extension cords must always have a protective ground conductor.


**CAUTION: If a unit is moved from a cold to a warm environment, condensation may cause a shock hazard. Ensure, therefore, that the grounding requirements are strictly met.**

**WARNING: Never interrupt the grounding cord. Any interruption of the protective ground connection inside or outside the instrument or disconnection of the protective ground terminal is likely to make the instrument dangerous.**

## Orientation and Cooling

The counter can be operated in any position desired. Make sure that the air flow through the ventilation slots at the top, and side panels is not obstructed. Leave 5 centimeters (2 inches) of space around the counter.


## Fold-Down Support



**Fig. 1-2** *Fold-down support for comfortable bench-top use.*

For bench-top use, a fold-down support is available for use underneath the counter. This support can also be used as a handle to carry the instrument.


## Rackmount Adapter



**Fig. 1-3** Dimensions for rackmounting hardware.

If you have ordered a 19-inch rack-mount kit for your instrument, it has to be assembled after delivery of the instrument. The rackmount kit consists of the following:

- 2 brackets, (short, left; long, right)
- 4 screws, M5 x 8
- 4 screws, M6 x 8



**Fig. 1-4** Fitting the rack mount brackets on the counter.


**WARNING:** Do not perform any internal service or adjustment of this instrument unless you are qualified to do so.

**Before you remove the cover, disconnect mains cord and wait for one minute.**

**Capacitors inside the instrument can hold their charge even if the instrument has been separated from all voltage sources.**

### ■ Assembling the Rackmount Kit


- Make sure the power cord is disconnected from the instrument.
- Turn the instrument upside down. See Fig. 1-5.
- Undo the two screws (A) and remove them from the cover.
- Remove the rear feet by undoing the two screws (B).
- Remove the four decorative plugs (C) that cover the screw holes on the right and left side of the front panel.
- Grip the front panel and gently push at the rear.
- Pull the instrument out of the cover.



**Fig. 1-5** Remove the screws and push the counter out of the cover.

- Remove the four feet from the cover.

Use a screwdriver as shown in the following illustration or a pair of pliers to remove the springs holding each foot, then push out the feet.



**Fig. 1-6** Removing feet from the cover.

- Push the instrument back into the cover.  
See Fig. 1-5.
- Mount the two rear feet with the screws (B) to the rear panel.
- Put the two screws (A) back.
- Fasten the brackets at the left and right side with the screws included as illustrated in Fig. 1-3.
- Fasten the instrument in the rack via screws in the four rack-mounting holes

The long bracket has an opening so that cables for Input A, B, and C can be routed inside the rack.

### ■ Reversing the Rackmount Kit

The instrument may also be mounted to the right in the rack. To do so, swap the position of the two brackets.



*Chapter 2*

# **Using the Controls**

# Basic Controls

A more elaborate description of the front and rear panels including the user interface with its menu system follows after this introductory

survey, the purpose of which is to make you familiar with the layout of the instrument.

## INPUT A


Opens the menu from which you can adjust all settings for Input A like *Coupling, Impedance and Attenuation*.

## INPUT B

Opens the menu from which you can adjust all settings for Input B like *Coupling, Impedance and Attenuation*.

## SETTINGS

Select measurement parameters such as measurement time, number of measurements, and so on.



## STANDBY LED

The LED lights up when the counter is in STANDBY mode, indicating that power is still applied to an internal optional OCXO, if one has been installed.

## STANDBY/ON

Toggle secondary power switch. Pressing this button in standby mode turns the counter ON and restores the settings as they were at power-down.

## MATH/LIMIT

Menu for selecting one of a set of formulas for modifying the measurement result. Three constants can be entered from the keyboard.

Numerical limits can also be entered for status reporting and recording

## USER OPT.

Controls the following items:

1. Settings memory
2. Interface
3. Calibration
4. Self-test
5. About

**STAT/PLOT**

Enters one of three statistics presentation modes. Switching between the modes is done by toggling the key.

**VALUE**

Enters the normal numerical presentation mode with one main parameter and a number of auxiliary parameters.

**MEAS FUNC**


Menu tree for selecting measurement function. You can use the seven *softkeys* below the display for confirmation.

**AUTO SET**

Adjusts input trigger voltage levels automatically to the optimum levels for the chosen measurement function. Double-click for default settings.

**CURSOR CONTROL**

The cursor position, marked by text inversion on the display, can be moved in four directions.



**HOLD/RUN**

Toggles between HOLD (one-shot) mode and RUN (continuous) mode. Freezes the result after completion of a measurement if HOLD is active.

**RESTART**

Initiates one new measurement if HOLD is active.

**EXIT/OK**

Confirms menu selections and moves up one level in the menu tree.

**CANCEL**

Moves up one menu level without confirming selections made. Exits REMOTE mode if not LOCAL LOCKOUT.

**ENTER**

Confirms menu selections without leaving the menu level.

# Secondary Controls


## Connectors & Indicators

### GRAPHIC DISPLAY

320 x 97 pixels LCD with backlight for showing measurement results in numerical as well as graphical format. The display is also the center of the dynamic user interface, comprising menu trees, indicators and information boxes.

### SOFTKEYS

The function of these seven keys is menu dependent. Actual function is indicated on the LCD. Depressing a softkey is often a faster alternative to moving the cursor to the desired position and then pressing OK.



### TRIGGER INDICATORS

Blinking LED indicates correct triggering.

### GATE INDICATOR

A pending measurement causes the LED to light up.

### MAIN INPUTS

The two identical DC coupled channels A & B are used for all types of measurements, either one at a time or both together.


### RF INPUT

(Optional Input C) A number of RF prescalers are available, covering different frequency ranges. These units are fully automatic and no controls affect the performance. The Type N connector is fitted only if a prescaler is installed.

### NUMERIC INPUT KEYS

Sometimes you may want to enter numeric values like the constants and limits asked for when you are utilizing the postprocessing features in MATH/LIMIT mode. These twelve keys are to be used for this purpose.

## Rear Panel



# Description of Keys

## Power

The **ON/OFF** key is a toggling secondary power switch. Part of the instrument is always ON as long as power is applied, and this standby condition is indicated by a red LED above the key. This indicator is consequently not lit while the instrument is in operation.

## Select Function

This hard key is marked **MEAS FUNC**. When you depress it, the menu below will open.



Fig. 2-1 Select measurement function.

The current selection is indicated by text inversion that is also indicating the cursor position. Select the measurement function you want by depressing the corresponding softkey right below the display.

Alternatively you can move the cursor to the wanted position with the **RIGHT/LEFT** arrow keys. Confirm by pressing **ENTER**.

A new menu will appear where the contents depend on the function. If you for instance have selected **Frequency**, you can then select between **Frequency**, **Frequency Ratio** and **Frequency Burst**. Finally you have to decide which input channel(s) to use.

## Autoset/Preset

By depressing this key once after selecting the wanted measurement function and input chan-

nel, you will most probably get a measurement result. The **AUTOSET** system ensures that the trigger levels are set optimally for each combination of measurement function and input signal amplitude, provided relatively normal signal waveforms are applied. If **Manual Trigger** has been selected before pressing the **AUTOSET** key, the system will make the necessary adjustments once (**Auto Once**) and then return to its inactive condition.

**AUTOSET** performs the following functions:

- Set automatic trigger levels
- Switch attenuators to 1x
- Turn on the display

By depressing this key twice within two seconds, you will enter the **Preset** mode, and a more extensive automatic setting will take place. In addition to the functions above, the following functions will be performed:

- Set **Meas Time** to **200 ms**
- Switch off **Hold-Off**
- Set **HOLD/RUN** to **RUN**
- Switch off **MATH/LIM**
- Switch off **Analog** and **Digital Filters**
- Set **Timebase Ref** to **Internal**
- Switch off **Arming**

## ■ Default Settings

An even more comprehensive preset function can be performed by recalling the factory default settings. See page 2-13.

## Move Cursor

There are four arrow keys for moving the cursor, normally marked by text inversion, around the menu trees in two dimensions.

## Display Contrast

When no cursor is visible (no active menu selected), the **UP/DOWN** arrows are used for adjusting the LCD display contrast ratio.

## Enter

The key marked **ENTER** enables you to confirm a choice without leaving your menu position.

## Save & Exit

This hard key is marked **EXIT/OK**. You will confirm your selection by depressing it, and at the same time you will leave the current menu level for the next higher level.

## Don't Save & Exit

This hard key is marked **CANCEL**. By depressing it you will enter the preceding menu level without confirming any selections made at the current level.

If the instrument is in **REMOTE** mode, this key is used for returning to **LOCAL** mode, unless **LOCAL LOCKOUT** has been programmed.

## Presentation Modes

### ■ VALUE




Fig. 2-2 Main and aux. parameters.

Value mode gives single line numerical presentation of individual results, where the main parameter is displayed in large characters with

full resolution together with a number of auxiliary parameters in small characters with limited resolution.




Fig. 2-3 Limits presentation.

If *Limits Alarm* is enabled you can visualize the deviation of your measurements in relation to the set limits. The numerical readout is now combined with a traditional analog pointer-type instrument, where the current value is represented by a "smiley". The limits are presented as numerical values below the main parameter, and their positions are marked with vertical bars labelled LL (lower limit) and UL (upper limit) on the autoscaled graph.

If one of the limits has been exceeded, the limit indicator at the top of the display will be flashing. In case the current measurement is out of the visible graph area, it is indicated by means of a left or a right arrowhead.

### ■ STAT/PLOT

If you want to treat a number of measurements with statistical methods, this is the key to operate. There are three display modes available by toggling the key:

- Numerical
- Histogram
- Trend Plot

## Numerical




Fig. 2-4 Statistics presented numerically.

In this mode the statistical information is displayed as numerical data containing the following elements:

- Mean: mean value
- Max: maximum value
- Min: minimum value
- P-P: peak-to-peak deviation
- Adev: Allan deviation
- Std: Standard deviation

## Histogram




Fig. 2-5 Statistics presented as a histogram.

The bins in the histogram are always autoscaled based on the measured data. Limits, if enabled, and center of graph are shown as vertical dotted lines. Data outside the limits are not used for autoscaling but are replaced by an arrow indicating the direction where non-displayed values have been recorded.

## Trend Plot




Fig. 2-6 Running trend plot.

This mode is used for observing periodic fluctuations or possible trends. Each plot terminates (if **HOLD** is activated) or restarts (if **RUN** is activated) after the set number of samples. The trend plot is always autoscaled based on the measured data, starting with 0 at restart. Limits are shown as horizontal lines if enabled.

### ■ Remote

When the instrument is controlled from the GPIB bus, and the remote line is asserted, the presentation mode changes to **Remote**, indicated by the label *Remote* on the display. The main measurement result and the input settings are displayed in this mode.

## Entering Numeric Values

Sometimes you may want to enter constants and limits in a value input menu, for instance one of those that you can reach when you press the **MATH/LIMIT** key.

You may also want to select a value that is not in the list of fixed values available by pressing the **UP/DOWN** arrow keys. One example is **Meas Time** under **SETTINGS**.

A similar situation arises when the desired value is too far away to reach conveniently by incrementing or decrementing the original value with the **UP/DOWN** arrow keys. One example is the **Trig Lvl** setting as part of the **INPUT A (B)** settings.



Whenever it is possible to enter numeric values, the keys marked with **0-9**; **.** (decimal point) and **±** (stands for *Change Sign*) take on their alternative numeric meaning.

It is often convenient to enter values using the scientific format. For that purpose, the rightmost softkey is marked **EE** (stands for *Enter Exponent*), making it easy to switch between the mantissa and the exponent.

Press **EXIT/OK** to store the new value or **CANCEL** to keep the old one.

## Hard Menu Keys

These keys are mainly used for opening fixed menus from which further selections can be made by means of the softkeys or the cursor/select keys.

### ■ Input A (B)




Fig. 2-7 Input settings menu.

By depressing this key, the bottom part of the display will show the settings for Input A (B).

The active settings are in bold characters and can be changed by depressing the corresponding softkey below the display. You can also move the cursor, indicated by text inversion, to the desired position with the **RIGHT/LEFT** arrow keys and then change the active setting with the **ENTER** key.

The selections that can be made using this menu are:

- *Trigger Slope*: positive or negative, indicated by corresponding symbols
- *Coupling*: AC or DC

- *Impedance*: 50  $\Omega$  or 1 M $\Omega$
- *Attenuation*: 1x or 10x
- *Trigger*:<sup>1</sup> Manual or Auto
- *Trigger Level*:<sup>2</sup> numerical input via front panel keyboard. If Auto Trigger is active, you can change the default trigger level manually as a percentage of the amplitude.
- *Filter*:<sup>3</sup> On or Off

- Notes:
- 1 Always **Auto** when measuring risetime or falltime
  - 2 The absolute level can either be adjusted using the up/down arrow keys or by pressing **ENTER** to reach the numerical input menu.
  - 3 Pressing the corresponding softkey or **ENTER** opens the Filter Settings menu. See Fig. 2-8. You can select a fixed 100 kHz analog filter or an adjustable digital filter. The equivalent cutoff frequency is set via the value input menu that opens if you select Digital LP Frequency from the menu.



Fig. 2-8 Selecting analog or digital filter.

### ■ Input B

The settings under Input B are equal to those under Input A.

## ■ Settings




Fig. 2-9 The main settings menu.

This key accesses a host of menus that affect the measurement. The figure above is valid after changing the default measuring time to 10 ms.

### Meas Time




Fig. 2-10 Submenu for entering measuring time.

This value input menu is active if you select a frequency function. Longer measuring time means fewer measurements per second and gives higher resolution.

### Burst




Fig. 2-11 Entering burst parameters.

This settings menu is active if the selected measurement function is BURST – a special case of FREQUENCY – and facilitates measurements on pulse-modulated signals. Both the carrier frequency and the modulating frequency – the pulse repetition frequency (PRF) – can be measured, often without the support of an external arming signal.

## Arm



Fig. 2-12 Setting arming conditions.

Arming is the general term used for the means to control the actual start/stop of a measurement. The normal free-running mode is inhibited and triggering takes place when certain pretrigger conditions are fulfilled.

The signal or signals used for initiating the arming can be applied to three channels (A, B, E), and the start channel can be different from the stop channel. All conditions can be set via the menu below.

### Trigger Hold-Off



Fig. 2-13 The trigger hold-off submenu.

A value input menu is opened where you can set the delay during which the stop trigger conditions are ignored after the measurement start. A typical use is to clean up signals generated by bouncing relay contacts.

### Statistics




Fig. 2-14 Entering statistics parameters.

In this menu you can do the following:

- Set the number of samples used for calculation of various statistical measures.
- Set the number of bins in the histogram view.
- Pacing  
The delay between measurements, called pacing, can be set to ON or OFF, and the time can be set within the range 2  $\mu$ s – 1000 s.

### Timebase Reference




Fig. 2-15 Selecting timebase reference source.

Here you can decide if the counter is to use an **Internal** or an **External** timebase. A third alternative is **Auto**. Then the external timebase will be selected if a valid signal is present at the reference input. The *EXT REF* indicator at the upper right corner of the display shows that the instrument is using an external timebase reference.

### Miscellaneous



Fig. 2-16 The 'Misc' submenu.

The options in this menu are:

- *Smart Time Interval* (valid only if the selected measurement function is *Time Interval*)  
The counter decides by means of

timestamping which measurement channel precedes the other.

- *Auto Trig Low Freq*  
In a value input menu you can set the lower frequency limit for automatic triggering and voltage measurements within the range 1 Hz – 100 kHz. A higher limit means faster settling time and consequently faster measurements.
- *Timeout*  
Switch the Timeout function ON or OFF (see below).
- *Timeout Time*  
Set the maximum time the instrument will wait for a pending measurement to finish before outputting a zero result. The range is 10 ms to 1000 s.

### Math/Limit




Fig. 2-17 Selecting 'Math' or 'Limits' parameters.

You enter a menu where you can choose between inputting data for the *Mathematics* or the *Limits* postprocessing unit.




Fig. 2-18 The 'Math' submenu.

The **Math** branch is used for modifying the measurement result mathematically before presentation on the display. Thus you can make the counter show directly what you want without tedious recalculations, e.g. revolutions/min instead of Hz.

The **Limits** branch is used for setting numerical limits and selecting the way the instrument will report the measurement results in relation to them.


Let us explore the **Math** submenu by pressing the corresponding softkey below the display.

The display tells you that the Math function is not active, so press the **Math Off** key once to open the formula selection menu.



**Fig. 2-19** Selecting 'Math' formula for postprocessing.

Select one of the four different formulas, where K, L and M are constants that the user can set to any value. X stands for the current non-modified measurement result.



**Fig. 2-20** Selecting formula constants.

Each of the softkeys below the constant labels opens a value input menu like the one below.




**Fig. 2-21** Entering numeric values for constants.

Use the numeric input keys to enter the mantissa and the exponent, and use the EE key to toggle between the input fields. The key

marked X<sub>0</sub> is used for entering the display reading as the value of the constant.

The **Limit** submenu is treated in a similar way, and its features are explored beginning on page 6-6.

## ■ User Options



**Fig. 2-22** The User Options menu.

From this menu you can reach a number of submenus that do not directly affect the measurement.

You can choose between a number of modes by pressing the corresponding softkey.

## Save/Recall Menu



**Fig. 2-23** The memory management menu.

Twenty complete front panel setups can be stored in non-volatile memory. Access to the first ten memory positions is prohibited when *Setup Protect* is ON. Switching OFF *Setup Protect* releases all ten memory positions simultaneously. The different setups can be individually labeled to make it easier for the operator to remember the application.

The following can be done:

- *Save current setup*



**Fig. 2-24** *Selecting memory position for saving a measurement setup.*

Browse through the available memory positions by using the **RIGHT/LEFT** arrow keys. For faster browsing, press the key **Next** to skip to the next memory bank. Press the softkey below the number (1-20) where you want to save the setting.

- *Recall setup*



**Fig. 2-25** *Selecting memory position for recalling a measurement setup.*

Select the memory position from which you want to retrieve the contents in the same way as under *Save current setup* above. You can also choose *Default* to restore the preprogrammed factory settings. See the table on page 2-15 for a complete list of these settings.

- *Modify labels*

Select a memory position to which you want to assign a label. See the descriptions under *Save/Recall setup* above. Now you can enter alphanumeric characters from the front panel. See the figure below.

The seven softkeys below the display are used for entering letters and digits in the same way as you write SMS messages on a cell phone.

- *Setup protection*

Toggle the softkey to switch between the **ON/OFF** modes. When **ON** is active, the memory positions 1-10 are all protected against accidental overwriting.




**Fig. 2-26** *Entering alphanumeric characters.*

### Calibrate Menu

This menu entry is accessible only for calibration purposes and is password-protected.

### Interface Menu



**Fig. 2-27** *Selecting active bus interface.*

### Bus Type

Select the active bus interface. The alternatives are *GPIB* and *USB*. If you select *GPIB*, you are also supposed to select the *GPIB Mode* and the *GPIB Address*. See the next two paragraphs.

### GPIB Mode

There are two command systems to choose from.

- *Native*  
The SCPI command set used in this mode fully exploits all the features of this instrument series.
- *Compatible*  
The SCPI command set used in this mode is adapted to be compatible with Agilent 53131/132/181.

### GPIB Address

Value input menu for setting the GPIB address.

### Test

A general self-test is always performed every time you power-up the instrument, but you can order a specific test from this menu at any time.




Fig. 2-28 Self-test menu.

Press **Test Mode** to open the menu with available choices.



Fig. 2-29 Selecting a specific test.

Select one of them and press **Start Test** to run it.

### About

Here you can find information on:

- calibration date
- firmware versions for:
  - ◀ basic instrument
  - ◀ interfaces
- optional factory-installed hardware

### ■ Hold/Run

This key serves the purpose of manual arming. A pending measurement will be finished and the result will remain on the display until a new measurement is triggered by pressing the **RESTART** key.

### ■ Restart

Often this key is operated in conjunction with the **HOLD/RUN** key (see above), but it can also be used in free-running mode, especially when long measuring times are being used, e.g. to initiate a new measurement after a change in the input signal. **RESTART** will not affect any front panel settings.

# Default Settings

See page 2-13 to see how the following pre-programmed settings are recalled by a few key-strokes.

PARAMETER	VALUE/SETTING
<b>Input A &amp; B</b>	
Trigger Level	AUTO
Trigger Slope	POS (A), NEG (B)
Impedance	1 M $\Omega$
Attenuator	1x
Coupling	AC
Filter	OFF
<b>Arming</b>	
Start	OFF
Start Slope	POS
Start Arm Delay	200 $\mu$ s
Stop	OFF
Stop Slope	POS
<b>Hold-Off</b>	
Hold-Off State	OFF
Hold-Off Time	200 $\mu$ s
<b>Time-Out</b>	
Time-Out State	OFF
Time-Out Time	100 ms
<b>Statistics</b>	
Statistics	OFF
No. of Samples	100
No. of Bins	20

PARAMETER	VALUE/SETTING
Pacing State	OFF
Pacing Time	20 ms
<b>Mathematics</b>	
Mathematics	OFF
Math Constants	K=1, L=0, M=1
<b>Limits</b>	
Limit State	OFF
Limit Mode	ABOVE
Lower Limit	0
Upper Limit	0
<b>Burst</b>	
Sync Delay	200 $\mu$ s
Start Delay	200 $\mu$ s
Meas. Time	200 $\mu$ s
Freq. Limit	300 MHz
<b>Miscellaneous</b>	
Function	FREQ A
Meas. Time	200 ms
Smart Time Interval	OFF
Auto Trig Low Freq	100 Hz
Timebase Reference	INT

This page is intentionally left blank.



*Chapter 3*

# **Input Signal Conditioning**

# Input Amplifier

The input amplifiers are used for adapting the widely varying signals in the ambient world to the measuring logic of the timer/counter.

These amplifiers have many controls, and it is essential to understand how these controls work together and affect the signal.

The block diagram below shows the order in which the different controls are connected. It is not a complete technical diagram but intended to help understanding the controls.

The menus from which you can adjust the settings for the two main measurement channels are reached by pressing **INPUT A** respectively **INPUT B**. See Figure 3-2. The active choices are shown in boldface on the bottom line.

## Impedance

The input impedance can be set to 1 M $\Omega$  or 50  $\Omega$  by toggling the corresponding softkey.




Fig. 3-2 Input settings menu.

**CAUTION: Switching the impedance to 50  $\Omega$  when the input voltage is above 12 V<sub>RMS</sub> may cause permanent damage to the input circuitry.**

## Attenuation

The input signal's amplitude can be attenuated by 1 or 10 by toggling the softkey marked **1x/10x**.

Use attenuation whenever the input signal exceeds the dynamic input voltage range  $\pm 5$  V or else when attenuation can reduce the influence of noise and interference. See the section dealing with these matters at the end of this chapter.





Fig. 3-1 Block diagram of the signal conditioning.

## Coupling


Switch between AC coupling and DC coupling by toggling the softkey **AC/DC**.



**Fig. 3-3** AC coupling a symmetrical signal.

Use the AC coupling feature to eliminate unwanted DC signal components. Always use AC coupling when the AC signal is superimposed on a DC voltage that is higher than the trigger level setting range. However, we recommend AC coupling in many other measurement situations as well.


When you measure symmetrical signals, such as sine and square/triangle waves, AC coupling filters out all DC components. This means that a 0 V trigger level is always centered around the middle of the signal where triggering is most stable.



**Fig. 3-4** Missing trigger events due to AC coupling of signal with varying duty cycle.

Signals with changing duty cycle or with a very low or high duty cycle do require DC coupling. Fig. 3-4 shows how pulses can be missed, while Fig. 3-5 shows that triggering does not occur at all because the signal amplitude and the hysteresis band are not centered.

*NOTE: For explanation of the hysteresis band, see page 4-3.*



**Fig. 3-5** No triggering due to AC coupling of signal with low duty cycle.

## Filter

If you cannot obtain a stable reading, the signal-to-noise ratio (often designated S/N or SNR) might be too low, probably less than 6 to 10 dB. Then you should use a filter. Certain conditions call for special solutions like highpass, bandpass or notch filters, but usually the unwanted noise signals have higher frequency than the signal you are interested in. In that case you can utilize the built-in lowpass filters. There are both analog and digital filters, and they can also work together.



**Fig. 3-6** The menu choices after selecting FILTER.

### ■ Analog Lowpass Filter

The counter has analog LP filters of RC type, one in each of the channels A and B, with a cutoff frequency of approximately 100 kHz, and a signal rejection of 20 dB at 1 MHz.

Accurate frequency measurements of noisy LF signals (up to 200 kHz) can be made when the noise components have significantly

higher frequencies than the fundamental signal.

### ■ Digital Lowpass Filter

The digital LP filter utilizes the Hold-Off function described below.

With trigger Hold-Off it is possible to insert a deadtime in the input trigger circuit. This means that the input of the counter ignores all hysteresis band crossings by the input signal during a preset time after the first trigger event.

When you set the Hold-Off time to approx. 75% of the cycle time of the signal, erroneous triggering is inhibited around the point where the input signal returns through the hysteresis band. When the signal reaches the trigger point of the next cycle, the set Hold-Off time has elapsed and a new and correct trigger will be initiated.

Instead of letting you calculate a suitable Hold-Off time, the counter will do the job for you by converting the filter cutoff frequency you enter via the value input menu below to an equivalent Hold-Off time.




**Fig. 3-7** Value input menu for setting the cutoff frequency of the digital filter.

You should be aware of a few limitations to be able to use the digital filter feature effectively and unambiguously. First you must have a rough idea of the frequency to be measured. A cutoff frequency that is too low might give a perfectly stable reading that is too low. In such a case, triggering occurs only on every 2nd,

3rd or 4th cycle. A cutoff frequency that is too high (>2 times the input frequency) also leads to a stable reading. Here one noise pulse is counted for each half-cycle.

Use an oscilloscope for verification if you are in doubt about the frequency and waveform of your input signal..

The cutoff frequency setting range is very wide: 1 Hz - 50 MHz



**Fig. 3-8** Digital LP filter operates in the measuring logic, not in the input amplifier.

## Man/Auto

Toggle between manual and automatic triggering with this softkey. When **Auto** is active the counter automatically measures the peak-to-peak levels of the input signal and sets the trigger level to 50% of that value. The attenuation is also set automatically.

At rise/fall time measurements the trigger levels are automatically set to 10% and 90% of the peak values.

When **Manual** is active the trigger level is set in the value input menu designated **Trig**. See below. The current value can be read on the display before entering the menu.

## ■ Speed

The Auto-function measures amplitude and calculates trigger level rapidly, but if you aim at higher measurement speed without having to sacrifice the benefits of automatic triggering, then use the **Auto Trig Low Freq** function to set the lower frequency limit for voltage measurement.

If you know that the signal you are interested in always has a frequency higher than a certain value  $f_{low}$ , then you can enter this value from a value input menu. The range for  $f_{low}$  is 1 Hz to 100 kHz, and the default value is 100 Hz. The higher value, the faster measurement speed due to more rapid trigger level voltage detection.

Even faster measurement speed can be reached by setting the trigger levels manually. See **Trig** below.

Follow the instructions here to change the low-frequency limit:

- Press **SETTINGS** → **Misc** → **Auto Trig Low Freq**.
- Use the **UP/DOWN** arrow keys or the numeric input keys to change the low frequency limit to be used during the trigger level calculation, (default 100 Hz).
- Confirm your choice and leave the **SETTINGS** menu by pressing **EXIT/OK** three times.


## Trig

Value input menu for entering the trigger level manually.

Use the **UP/DOWN** arrow keys or the numeric input keys to set the trigger level.

A blinking underscore indicates the cursor position where the next digit will appear. The **LEFT** arrow key is used for correction, i.e.

deleting the position preceding the current cursor position.



**Fig. 3-9** Value input menu for setting the trigger level.

*NOTE: It is probably easier to make small adjustments around a fixed value by using the arrow keys for incrementation or decrementation. Keep the keys depressed for faster response*

*NOTE: Switching over from AUTO to MAN Trigger Level is automatic if you enter a trigger level manually.*

## ■ Auto Once


### Converting “Auto” to “Fixed”

The trigger levels used by the auto trigger can be frozen and turned into fixed trigger levels simply by toggling the **MAN/AUTO** key. The current calculated trigger level that is visible on the display under **Trig** will be the new fixed manual level. Subsequent measurements will be considerably faster since the signal levels are no longer monitored by the instrument. You should not use this method if the signal levels are unstable.


*NOTE: You can use auto trigger on one input and fixed trigger levels on the other.*

# How to Reduce or Ignore Noise and Interference

Sensitive counter input circuits are of course also sensitive to noise. By matching the signal amplitude to the counter's input sensitivity, you reduce the risk of erroneous counts from noise and interference. These could otherwise ruin a measurement.



**Fig. 3-10** *Narrow hysteresis gives erroneous triggering on noisy signals.*



**Fig. 3-11** *Wide trigger hysteresis gives correct triggering.*

To ensure reliable measuring results, the counter has the following functions to reduce or eliminate the effect of noise:


- 10x input attenuator
- Continuously variable trigger level
- Continuously variable hysteresis for some functions
- Analog low-pass noise suppression filter
- Digital low-pass filter (*Trigger Hold-Off*)

To make reliable measurements possible on very noisy signals, you may use several of the above features simultaneously.

Optimizing the input amplitude and the trigger level, using the attenuator and the trigger control, is independent of input frequency and useful over the entire frequency range. LP filters, on the other hand, function selectively over a limited frequency range.

## Trigger Hysteresis


The signal needs to cross the 20 mV input hysteresis band before triggering occurs. This hysteresis prevents the input from self-oscillating and reduces its sensitivity to noise. Other names for trigger hysteresis are “trigger sensitivity” and “noise immunity”. They explain the various characteristics of the hysteresis.



**Fig. 3-12** *Erroneous counts when noise passes hysteresis window.*


Fig. 3-10 and Fig. 3-12 show how spurious signals can cause the input signal to cross the

trigger or hysteresis window more than once per input cycle and give erroneous counts.



**Fig. 3-13** *Trigger uncertainty due to noise.*

Fig. 3-13 shows that less noise still affects the trigger point by advancing or delaying it, but it does not cause erroneous counts. This trigger uncertainty is of particular importance when measuring low frequency signals, since the signal slew rate (in V/s) is low for LF signals. To reduce the trigger uncertainty, it is desirable to cross the hysteresis band as fast as possible.



**Fig. 3-14** *Low amplitude delays the trigger point*

Fig. 3-14 shows that a high amplitude signal passes the hysteresis faster than a low amplitude signal. For low frequency measurements where the trigger uncertainty is of importance,

do not attenuate the signal too much, and set the sensitivity of the counter high.


In practice however, trigger errors caused by erroneous counts (Fig. 3-10 and Fig. 3-12) are much more important and require just the opposite measures to be taken.

To avoid erroneous counting caused by spurious signals, you need to avoid excessive input signal amplitudes. This is particularly valid when measuring on high impedance circuitry and when using  $1\text{M}\Omega$  input impedance. Under these conditions, the cables easily pick up noise.

External attenuation and the internal 10x attenuator reduce the signal amplitude, including the noise, while the internal sensitivity control in the counter reduces the counter's sensitivity, including sensitivity to noise. Reduce excessive signal amplitudes with the 10x attenuator, or with an external coaxial attenuator, or a 10:1 probe.

## How to use Trigger Level Setting

For most frequency measurements, the optimal triggering is obtained by positioning the mean trigger level at mid amplitude, using either a narrow or a wide hysteresis band, depending on the signal characteristics.



**Fig. 3-15** *Timing error due to slew rate.*

When measuring LF sine wave signals with little noise, you may want to measure with a

high sensitivity (narrow hysteresis band) to reduce the trigger uncertainty. Triggering at or close to the middle of the signal leads to the smallest trigger (timing) error since the signal slope is steepest at the sine wave center, see Fig. 3-15.

When you have to avoid erroneous counts due to noisy signals, see Fig. 3-12, expanding the hysteresis window gives the best result if you still center the window around the middle of the input signal. The input signal excursions beyond the hysteresis band should be equally large.

### ■ Auto Trigger

For normal frequency measurements, i.e. without arming, the Auto Trigger function changes to *Auto (Wide) Hysteresis*, thus widening the hysteresis window to lie between 70 % and 30 % of the peak-to-peak amplitude. This is done with a successive approximation method, by which the signal's MIN. and MAX. levels are identified, i.e., the levels where triggering just stops. After this MIN./MAX. probing, the counter sets the trigger levels to the calculated values. The default relative trigger levels are indicated by 70 % on Input A and 30 % on Input B. These values can be manually adjusted between 50 % and 100 % on Input A and between 0 % and 50 % on Input B. The signal, however, is only applied to one channel.

Before each frequency measurement the counter repeats this signal probing to identify new MIN/MAX values. A prerequisite to enable AUTO triggering is therefore that the input signal is repetitive, i.e.,  $\geq 100$  Hz (default). Another condition is that the signal amplitude does not change significantly after the measurement has started.

*NOTE: AUTO trigger limits the maximum measuring rate when an automatic test sys-*

*tem makes many measurements per second. Here you can increase the measuring rate by switching off this probing if the signal amplitude is constant. One single command and the AUTO trigger function determines the trigger level once and enters it as a fixed trigger level.*

### ■ Manual Trigger

Switching to **Man Trig** also means *Narrow Hysteresis* at the last Auto Level. Pressing **AUTOSET** once starts a single automatic trigger level calculation (*Auto Once*). This calculated value, 50 % of the peak-to-peak amplitude, will be the new fixed trigger level, from which you can make manual adjustments if need be.

### ■ Harmonic Distortion

As rule of thumb, stable readings are free from noise or interference.

However, stable readings are not necessarily correct; harmonic distortion can cause erroneous yet stable readings.

Sine wave signals with much harmonic distortion, see Fig. 3-17, can be measured correctly by shifting the trigger point to a suitable level or by using continuously variable sensitivity, see Fig. 3-16. You can also use Trigger Hold-Off, in case the measurement result is not in line with your expectations.




Fig. 3-16 Variable sensitivity.




Fig. 3-17 Harmonic distortion.



*Chapter 4*

# **Measuring Functions**

# Introduction to This Chapter

This chapter describes the different measuring functions of the counter. They have been grouped as follows:

## *Frequency measurements*

- Frequency
- Period
- Ratio
- Burst frequency and PRF.
- FM
- AM

## *Time measurements*

- Time interval.
- Pulse width.
- Duty factor.
- Rise/Fall time.

## *Phase measurements*


## *Voltage measurements*

- $V_{MAX}$ ,  $V_{MIN}$ .
- $V_{PP}$ .

## Selecting Function

See also the front panel layout on page 2-3 to find the keys mentioned in this section together with short descriptions.

Press **MEAS FUNC** to open the main menu for selecting measuring function. The two basic methods to select a specific function and its subsequent parameters are described on page 2-6.



# Frequency Measurements

## FREQ A, B

The counter measures frequency between 0 Hz and 300 MHz on Input A and Input B.

Frequencies above 100 Hz are best measured using the *Default Setup*. See page 2-13. Then **Freq A** will be selected automatically. Other important automatic settings are **AC Coupling**, **Auto Trig** and **Meas Time 200 ms**. See below for an explanation. You are now ready to start using the most common function with a fair chance to get a result without further adjustments.

### ■ Summary of Settings for Good Frequency Measurements

- *AC Coupling*, because possible DC offset is normally undesirable.
- *Auto Trig* means *Auto Hysteresis* in this case, (comparable to AGC) because superimposed noise exceeding the normal narrow hysteresis window will be suppressed.
- *Meas Time 200 ms* to get a reasonable tradeoff between measurement speed and resolution.

Some of the settings made above by recalling the *Default Setup* can also be made by activating the **AUTOSET** key. Pressing it once means:


- *Auto Trig*. Note that this setting will be made once only if *Man Trig* has been selected earlier.

Pressing **AUTOSET** twice within two seconds also adds the following setting:

- *Meas Time 200 ms*.

## FREQ C

With an optional prescaler the counter can measure up to 3 GHz or 8 GHz on Input C. These RF inputs are fully automatic and no setup is required.



**Fig. 4-1** Frequency is measured as the inverse of the time between one trigger point and the next;

$$f = \frac{1}{t}$$

## RATIO A/B, B/A, C/A, C/B

To find the ratio between two input frequencies, the counter counts the cycles on two channels simultaneously and divides the result on the primary channel by the result on the secondary channel.

Ratio can be measured between Input A and Input B, where either channel can be the primary or the secondary channel. Ratio can also be measured between Input C and Input A or between Input C and Input B. Here Input C is the primary channel.



*Note that the resolution calculations are very different as compared to frequency measurements. See page 8-9 for details.*

## BURST A, B, C

A burst signal as in Fig. 4-2 has a carrier wave (CW) frequency and a modulation frequency, also called the pulse repetition frequency (PRF), that switches the CW signal on and off.

Both the CW frequency, the PRF, and the number of cycles in a burst are measured without external arming signals and with or without selectable start arming delay. See Chapter 5 “Measurement Control” for a fundamental discussion of arming and arming delay.

The general frequency limitations for the respective measuring channel also apply to burst measurements. The minimum number of cycles in a burst on Input A or Input B is 3 below 160 MHz and 6 between 160 MHz and 300 MHz. Burst measurements on Input C involve prescaling, so the minimum number of

cycles will be  $3 \times \text{prescaling factor}$ . The 3 GHz option, for example, has a prescaling factor of 16 and requires at least 48 cycles in each burst.

The minimum burst duration is 40 ns below and 80 ns above 160 MHz.

## Triggering


Bursts with a PRF above 50 Hz can be measured with auto triggering on.

The out-of-sync error described under heading “Possible errors” on page 4-6 may occur more frequently when using *Auto Trigger*.

When PRF is below 50 Hz and when the gap between the bursts is very small, use manual triggering.

Always try using **AUTOSET** first. Then the *Auto Trigger* and the *Auto Sync* functions in combination will give satisfactory results without further tweaking in most cases. Sometimes switching from **AUTO** to **MAN**ual triggering in the **INPUT A/B** menus is enough to get stable readings. The continually calculated trigger levels will then be fixed.

Input C has always automatic triggering and **AUTOSET** only affects the burst synchronization.



**Fig. 4-2** Burst signal.


## Burst Measurements using Manual Presetting

You can measure the frequency on Input A and Input B to 300 MHz and on Input C with limited specifications to the upper frequency limit of the prescaler with the internally synchronized BURST function as follows:

- Select **Freq Burst** under the **Freq** menu
- Select **A, B,** or **C** as measurement input.
- Press **SETTINGS** and **Burst**. Select a **Meas Time** that is shorter than the burst duration minus two CW cycles.

If you do not know the approximate burst parameters of your signal, always start with a short measurement time and increase it gradually until the readout gets unstable.

- Press **Sync Delay** and enter a value longer than the burst duration and shorter than the inverse of the PRF. See Fig. 4-3.




**Fig. 4-3** Set the sync delay so that it expires in the gap between the bursts.

- Press **Start Delay** and enter a value longer than the transient part of the burst pulse.
- Select **Frequency Limit** (160/300 MHz) if Input A or Input B is to be used. Use the low limit if possible to minimize the number of cycles necessary to make a measurement.
- Press **EXIT/OK** to measure.

All relevant burst parameters can be read on the display simultaneously.

## ■ Selecting Measurement Time



**Fig. 4-4** Three time values must be set to measure the correct part of a burst


The measurement time must be shorter than the duration of the burst. If the measurement continues during part of the burst gap, no matter how small a period of time, then the measurement is ruined. Choosing a measurement time that is too short is better since it only reduces the resolution. Making burst frequency measurements on short bursts means using short measurement times, giving a poorer resolution than normally achieved with the counter.

## ■ How Does the Sync Delay Work?

The sync delay works as an internal start arming delay: it prevents the start of a new measurement until the set sync delay has expired. See Fig. 4-5.

After the set measurement time has started, the counter synchronizes the start of the measurement with the second trigger event in the burst. This means that the measurement does

not start erroneously during the Burst Off duration or inside the burst.



**Fig. 4-5** Measuring the frequency of the carrier wave signal in a burst.

### ■ Possible Errors

Before the measurement has been synchronized with the burst signal, the first measurement(s) could start accidentally during the presence of a burst. If this would happen and if the remaining burst duration is shorter than the set measurement time, the readout of the first measurement will be wrong. However, after this first measurement, a properly set start-arming sync delay time will synchronize the next measurements.

In manually operated applications, this is not a problem. In automated test systems where the result of a single measurement sample must be reliable, at least two measurements must be made, the first to synchronize the measurement and the second from which the measurement result can be read out.

## Frequency Modulated Signals

A frequency modulated signal is a carrier wave signal (CW frequency =  $f_0$ ) that changes in frequency to values higher and lower than the frequency  $f_0$ . It is the modulation signal that changes the frequency of the carrier wave.

The counter can measure:

$f_0$  = Carrier frequency.

$f_{\max}$  = Maximum frequency.

$f_{\min}$  = Minimum frequency.

$\Delta f$  = Frequency swing =  $f_{\max} - f_0$ .

### Carrier Wave Frequency $f_0$

To determine the carrier wave frequency, measure  $f_{\text{mean}}$  which is a close approximation of  $f_0$ .

Press **STAT/PLOT** to get an overview of all the statistical parameters.

Select the measurement time so that the counter measures an integral number of modulation periods. This way the positive frequency deviations will compensate the negative deviations during the measurement.

Example: If the modulation frequency is 50 Hz, the measurement time 200 ms will make the counter measure 10 complete modulation cycles.

If the modulation is non-continuous, like a voice signal, it is not possible to fully compensate positive deviations with negative deviations. Here, part of a modulation swing

may remain uncompensated for, and lead to a measuring result that is too high or too low.




Fig. 4-6 Frequency modulation

In the worst case, exactly half a modulation cycle would be uncompensated for, giving a maximum uncertainty of:

$$f_0 - f_{mean} = \pm \frac{\Delta f_{max}}{t_{measuring} \times f_{modulation} \times \pi}$$

For very accurate measurements of the carrier wave frequency  $f_0$ , measure on the unmodulated signal if it is accessible.

### ■ Modulation Frequencies above 1 kHz

- Turn off **SINGLE**.
- Set a long measurement time that is an even multiple of the inverse of the modulation frequency.

You will obtain a good approximation when you select a long measurement time, for instance 10 s, and when the modulation frequency is high, above 1000 Hz.

### ■ Low Modulation Frequencies

Press **SETTINGS** → **STAT** and make the **No. of samples** parameter as large as possible considering the maximum allowed measurement time. Press **STAT/PLOT** and let the

counter calculate the mean value of the samples.

You will usually get good results with 0.1 s measurement time per sample and more than 30 samples ( $n \geq 30$ ). You can try out the optimal combination of sample size and measurement time for specific cases. It depends on the actual  $f_0$  and  $\Delta f_{max}$ .

Here the sampling frequency of the measurement (1/measurement time) is asynchronous with the modulation frequency. This leads to individual measurement results which are randomly higher and lower than  $f_0$ . The statistically averaged value of the frequency  $f_{mean}$  approaches  $f_0$  when the number of averaged samples is sufficiently large.

When the counter measures instantaneous frequency values (when you select a very short measurement time), the RMS measurement uncertainty of the measured value of  $f_0$  is:

$$f_0 - f_{mean} = \pm \frac{1}{\sqrt{2n}} \times \Delta f_{max}$$

where n is the number of averaged samples of f.

### $f_{max}$

- Press **SETTINGS** → **STAT** and set **No. of samples** to 1000 or more.
- Press **Meas Time** and select a low value.
- Press **STAT/PLOT** and watch  $f_{max}$ .

### $f_{min}$

- Press **SETTINGS** → **STAT** and set **No. of samples** to 1000 or more.
- Press **Meas Time** and select a low value.
- Press **STAT/PLOT** and watch  $f_{min}$ .

### $\Delta f_{p-p}$

- Press **SETTINGS** → **STAT** and set **No.of samples** to 1000 or more.
- Press **Meas Time** and select a low value.
- Press **STAT/PLOT** and watch  $\Delta f_{p-p}$ .


$$\Delta f_{p-p} = f_{\max} - f_{\min} = 2 \times \Delta f.$$

### Errors in $f_{\max}$ , $f_{\min}$ , and $\Delta f_{p-p}$

A measurement time corresponding to  $\frac{1}{10}$  cycle, or  $36^\circ$  of the modulation signal, leads to an error of approx 1.5%.

Select the measurement time:

$$t_{\text{measure}} \leq \frac{1}{10 \times f_{\text{modulation}}}$$



**Fig. 4-7** Error when determining  $f_{\max}$

To be confident that the captured maximal frequency really is  $f_{\max}$ , you must select a sufficiently large number of samples, for instance  $n \geq 1000$ .


## AM Signals

The counter can usually measure both the carrier wave frequency and modulation frequency of AM signals. These measurements

are much like the burst measurements described earlier in this manual.

### Carrier Wave Frequency

The carrier wave (CW) is only continuously present in a narrow amplitude band in the middle of the signal if the modulation depth is high. If the sensitivity of the counter is too low, cycles will be lost, and the measurement ruined.



**Fig. 4-8** Effects of different sensitivity when measuring the CW Frequency of an AM signal.


To measure the CW frequency:

- Enter the **INPUT A** menu.
- Select a measurement time that gives you the resolution you want.
- Turn on **Manual** trigger.
- Press **Trig** level and enter 0 V trigger level (press the numeric key **0** and **EXIT/OK**).
- Select **AC** coupling.
- Select **1x** attenuation to get a narrow hysteresis band.
- If the counter triggers on noise, widen the hysteresis band with the ‘variable hysteresis’ function, i.e. enter a trigger level  $>0$  V but  $<V_{p-pmin}$ . See Fig. 4-8.



## Modulating Frequency

The easiest way to measure the modulating frequency is after demodulation, for instance by means of a so-called RF-detector probe (also known as a demodulator probe, e.g. Pomona type 5815) used with AC-coupling of the input channel. If no suitable demodulator is available, use the **Freq Burst** function to measure the modulation frequency in the same way as when measuring Burst PRF.



**Fig. 4-9** Measuring the modulating frequency.

- Press **MEAS FUNC** and select **Freq Burst A**.
- Press **SETTINGS** → **Burst** → **Meas Time** and enter a measurement time that is approximately 25 % of the modulating period.
- Press **Sync Delay** and enter a value that is approximately 75 % of the modulating period. See Fig. 4-3.
- Press **INPUT A** and turn on **Manual** trigger.
- Press **Trig** and enter a trigger level that makes the counter trigger according to Fig. 4-9.


Even though the main frequency reading may now be unstable, the PRF value on the display will represent the modulating frequency.

## Theory of Measurement

### Reciprocal Counting

Simple frequency counters count the number of input cycles during a preset gate time, for instance one second. This leads to a  $\pm 1$  input cycle count error that, at least for low-frequency measurements, is a major contribution to uncertainty.

However, the counters described here use a high-resolution, reciprocal counting technique, synchronizing the measurement start with the input signal. In this way an exact number of integral input cycles will be counted, thereby omitting the  $\pm 1$  input cycle error.



**Fig. 4-10** Synchronization of a measurement.

After the start of the set measurement time, the counter synchronizes the beginning of the actual gate time with the first trigger event ( $t_1$ ) of the input signal. See also Fig. 4-10.

In the same way, the counter synchronizes the stop of the actual gate time with the input signal, after the set measurement time has elapsed. The multi-register counting technique allows you to simultaneously measure the ac-

tual gate time ( $t_g$ ) and the number of cycles ( $n$ ) that occurred during this gate time.

Thereafter, the counter calculates the frequency according to Mr. Hertz's definition:

$$f = \frac{n}{t_g}$$

The '90' measures the gate time,  $t_g$ , with a resolution of 100 ps, independent of the measured frequency. Consequently the use of prescalers does not influence the quantization error. Therefore, the *relative* quantization error is: 100 ps/ $t_g$ .

For a 1-second measurement time, this value is:

$$\frac{100 \text{ ps}}{1 \text{ s}} = 100 \times 10^{-12} = 1 \times 10^{-10}$$

Except for very low frequencies,  $t_g$  and the set measurement time are nearly identical.

## Sample-Hold

If the input signal disappears during the measurement, the counter will behave like a voltmeter with a sample-and-hold feature and will freeze the result of the previous measurement.

## Time-Out

Mainly for GPIB use, you can manually select a fixed time-out in the menu reached by pressing **SETTINGS** → **Misc** → **Timeout Time**. The range of the fixed timeout is 10 ms to 1000 s, and the default setting is **Off**.

Select a time that is longer than the cycle time of the lowest frequency you are going to measure; multiply the time by the prescaling factor of the input channel and enter that time as time-out.

When no triggering has occurred during the time-out, the counter will show **NO SIGNAL**.

## Measuring Speed

The set measurement time determines the measuring speed for those functions that utilize averaging – **Frequency** and **Period**

**Avg**. For continuous signals,

$$\text{Speed} \approx \frac{1}{t_g + 0.2} \text{ readings/s}$$

when **Auto** trigger is on and can be increased to:

$$\text{Speed} \approx \frac{1}{t_g + 0.001} \text{ readings/s}$$

when **Manual** trigger is on, or via GPIB:

$$\text{Speed} \approx \frac{1}{t_g + 0.00012} \text{ readings/s}$$


### ■ Average and Single Cycle Measurements

To reduce the actual gate time or measuring aperture, the counters have very short measurement times and a mode called **Single** for period measurements. The latter means that the counter measures during only *one cycle* of the input signal. In applications where the counter uses an input channel with a prescaler, the **Single** measurement will last as many cycles as the division factor. If you want to measure with a very short aperture, use an input with a low division factor.

Averaging is the normal mode for frequency and period measurements when you want to reach maximum resolution. There is always a tradeoff between time and precision, however, so decide how many digits you need and use as short a measurement time as possible to arrive at your objective.

### ■ Prescaling May Influence Measurement Time

Prescalers do affect the minimum measurement time, inasmuch as short bursts have to contain a minimum number of carrier wave periods. This number depends on the prescaling factor.



**Fig. 4-11** Divide-by-16 Prescaler

Fig. 4-11 shows the effect of the 3 GHz prescaler. For 16 input cycles, the prescaler gives one square wave output cycle. When the counter uses a prescaler, it counts the number of prescaled output cycles, here  $f/16$ . The display shows the correct input frequency since the microcomputer compensates for the effect of the division factor  $d$  as follows:

$$f = \frac{n \times d}{t_g}$$

Prescalers do not reduce resolution in reciprocal counters. The relative quantization error is still:  $\frac{100 \text{ } \mu\text{s}}{t_g}$

See Table 4-1 to find the prescaling factors used in different operating modes.


### ■ LF Signals

Signals below 100 Hz should be measured with manual triggering, unless the default setting (100 Hz) is changed. See page 2-11. The low limit can be set to 1 Hz, but the measurement process will be slowed down considerably if auto triggering is used in conjunction with very low frequencies.

Function	Prescaling Factor
FREQ A/B (300 MHz)	2
BURST A/B (<160 MHz)	1
BURST A/B (>160 MHz)	2
PERIOD A/B AVG (300 MHz)	2
PERIOD A/B SGL (300 MHz)	1
FREQ C (3 GHz)	16
FREQ C (8 GHz)	256
All other functions	1

**Table 4-1** Prescaling factors.

When measuring pulses with a low repetition rate, for example a 0.1 Hz pulse with a non-prescaled function like PERIOD SGL, the measurement will require at least the duration of one cycle, that is 10 seconds, and at worst nearly 20 seconds. The worst case is when a trigger event took place just before the beginning of a measurement time (Fig. 4-12). Measuring the frequency of the same signal will take twice as long, since this function involves prescaling by a factor two.



**Fig. 4-12** Measurement Time


Even if you have chosen a short measurement time, this measurement will require between 20 and 40 seconds (for this example).

## ■ RF Signals

As mentioned before, a prescaler in the C-input divides the input frequency before it is counted by the normal digital counting logic. The division factor is called *prescaler factor* and can have different values depending on the prescaler type. The 3 GHz prescaler is designed for a prescaling factor of 16. This means that an input C frequency of, e.g., 1.024 GHz is transformed to 64 MHz.

Prescalers are designed for optimum performance when measuring stable continuous RF. Most prescalers are inherently unstable and would self-oscillate without an input signal. To prevent a prescaler from oscillating, a “go-detector” is incorporated. See Fig. 4-13.

The go-detector continuously measures the level of the input signal and simply blocks the prescaler output when no signal, or a signal that is too weak, is present.



**Fig. 4-13** Go-detector in the prescaler

The presence of a burst signal to be measured makes certain demands upon the signal itself. Regardless of the basic counter’s ability to measure during very short measurement times, the burst duration must meet the following minimum conditions:

$$Burst_{min} > (presc. factor) \times (inp. cycle time) \times 3$$

or at least 80 ns

Normally the real minimum limit is set by other factors, like the speed of the GO-detector. This speed depends on the specific input option used.

# PERIOD

## Single A, B

### Average A, B, C

From a measuring point of view, the period function is identical to the frequency function. This is because the period of a cyclic signal has the reciprocal value of the frequency ( $1/f$ ).

In practice there are two minor differences.

1. The counter calculates *FREQUENCY* (always AVG) as:

$$f = \frac{\text{number of cycles}}{\text{actual gate time}}$$

while it calculates *PERIOD AVG* as:

$$p = \frac{\text{actual gate time}}{\text{number of cycles}}$$


2. In the *PERIOD SINGLE* mode, the counter uses no prescaler.

All other functions and features as described earlier under “Frequency” apply to Period measurements.

# Time Measurements

## Introduction

Measuring the time between a start and a stop condition on two separate channels is the basis for all time interval measurements. In addition to the fundamental function **Time Interval A to B**, the counters also offer other channel combinations and derived functions like **Pulse Width** and **Rise/Fall Time**.



**Fig. 4-14** Time is measured between the trigger point and the reset point. Accurate measurements are possible only if the hysteresis band is narrow.

## Triggering

The set trigger level and trigger slope define the start and stop triggering.

If **Auto** is on, the counter sets the trigger level to 50% of the signal amplitude, which is ideal for most time measurements.

### ■ Summary of Conditions for Reliable Time Measurements:

- **Auto Once**, that is freezing the levels determined by **Auto Trig**, is normally the best choice when making time measurements. Choose **Man Trig** and press **AUTOSET** once.
- **DC** coupling.
- **1x** Attenuation. Selected automatically if **AUTOSET** was used before to set the trigger levels.
- High signal level.
- Steep signal edges.

Even though the input amplifiers have high sensitivity, the hysteresis band has a finite value that would introduce a small timing error for signals with different rise and fall times, for instance asymmetrical pulse signals like the one in Fig. 4-14. This timing error is taken care of by using hysteresis compensa-

tion that virtually moves the trigger points by half the hysteresis band.

## Time Interval

All time interval functions can be found under the function menu **Time**.

The toggling **SLOPE** keys (marked with a positive  $\lrcorner$  or negative  $\llcorner$  edge symbol) under the menus **INPUT A/B** decide which edge of the signal will start resp. stop the measurement.

### Time Interval A to B

The counter measures the time between a start condition on input A and a stop condition on input B.

### Time Interval B to A

The counter measures the time between a start condition on input B and a stop condition on input A.

### Time Interval A to A, B to B

When the same (common) signal source supplies both start and stop trigger events, connect the signal to either input A or input B.

These functions can be used for measuring rise and fall times between arbitrary trigger levels.

## Rise/Fall Time A/B


These functions can be found under the function menu **Time**.

Rise and fall time can be measured on both input A and input B.

By convention, rise/fall time measurements are made with the trigger levels set to 10 % (start) and 90 % (stop) of the maximum pulse amplitude, see Figure 4-15.

The counter measures the time from when the signal passes 10 % of its amplitude to when it passes 90 % of its amplitude. The trigger levels are calculated and set automatically.

Auxiliary parameters shown simultaneously are Slew Rate (V/s),  $V_{\max}$  and  $V_{\min}$



**Fig. 4-15** Trigger levels for rise/fall measurements.

For ECL circuits, the reference levels are 20 % (start) and 80 % (stop). In this case you can use either of two methods:

1. Select the general *Time Interval* function described above and set the trigger levels manually after calculating them from the absolute peak values. Then you can benefit from the auxiliary parameters  $V_{\max}$  and  $V_{\min}$ . For measurements made on input A, use the following settings:

*Rise Time:*

$$\text{Trig Level A} = V_{\min} + 0.2(V_{\max} - V_{\min})$$

$$\text{Trig Level B} = V_{\min} + 0.8(V_{\max} - V_{\min})$$

*Fall Time:*

$$\text{Trig Level A} = V_{\min} + 0.8(V_{\max} - V_{\min})$$

$$\text{Trig Level B} = V_{\min} + 0.2(V_{\max} - V_{\min})$$

2. Select one of the dedicated *Rise/Fall Time* functions, and exploit the possibility to man-

ually adjust the relative trigger levels (in %) when *Auto Trigger* is active. Both input channel menus are used for entering the levels, but only one channel is the active signal input.

See the paragraph on *Auto Trigger* (page 4-16) to find out how overshoot or ringing may affect your measurement.

$$\text{Duty factor} = \frac{\text{Pulse width}}{\text{Period}}$$



The total measurement time will be doubled compared to a single measurement, because "Duty" requires 2 measurement steps.

## Pulse Width A/B

The function menu designation is **Pulse**. Either input A or input B can be used for measuring, and both positive and negative pulse width can be selected.

- Positive pulse width means the time between a rising edge and the next falling edge.
- Negative pulse width means the time between a falling edge and the next rising edge.

The selected trigger slope is the start trigger slope. The counter automatically selects the inverse polarity as stop slope.

## Duty Factor A/B

The function menu designation is **Duty**. Either input A or input B can be used for measuring, and both positive and negative duty factor can be selected. See the preceding paragraph for a definition of *positive* and *negative* in this context.

Duty factor (or duty cycle) is the ratio between pulse width and period time. The counter determines this ratio by first making a pulse width measurement, then a period measurement, and calculates the duty factor as:

## Measurement Errors

### Hysteresis

The trigger hysteresis, among other things, causes measuring errors, see Figure 4-16. Actual triggering does not occur when the input signal crosses the trigger level at 50 percent of the amplitude, but when the input signal has crossed the entire hysteresis band.





Fig. 4-16 Trigger hysteresis

The hysteresis band is about 20 mV with attenuation **1x**, and 200 mV with attenuation **10x**.

To keep this hysteresis trigger error low, the attenuator setting should be **1x** when possible. Use the **10x** position only when input signals have excessively large amplitudes, or when you need to set trigger levels higher than 5 V.

## Overdrive and Pulse Rounding

Additional timing errors may be caused by triggering with insufficient overdrive, see Figure 4-17. When triggering occurs too close to the maximum voltage of a pulse, two phenomena may influence your measurement uncertainty: overdrive and rounding.



**Fig. 4-17** *Insufficient overdrive causes Trigger Error.*

**Overdrive:** *When the input signal crosses the hysteresis band with only a marginal overdrive, triggering may take some 100 ps longer than usual. The specified worst case 500 ps systematic trigger error includes this error, but you can avoid it by having adequate overdrive.*

**Rounding:** *Very fast pulses may suffer from pulse rounding, overshoot, or other aberrations. Pulse rounding can cause significant trigger errors, particularly when measuring on fast circuitry.*

## Auto Trigger

Auto Trigger is a great help especially when you measure on unknown signals. However, overshoot and ringing may cause **Auto** to choose slightly wrong MIN and MAX signal levels. This does not affect measurements like frequency, but transition time measurements may be affected.

Therefore, when working with known signals such as logic circuitry, set the trigger levels manually.


Always use manual trigger levels if the signal repetition rate drops below 100 Hz (default), or below the low frequency limit set by entering a value between 1 Hz and 50 kHz in the menu **Auto Trig Low Freq**. You can reach it by pressing **SETTINGS** → **Misc**.



# Phase

## What is Phase?

Phase is the time difference between two signals of the same frequency, expressed as an angle.



**Fig. 4-18** Phase delay.

The traditional method to measure phase delay with a timer/counter is a two-step process consisting of two consecutive measurements, first a period measurement and immediately after that a time interval measurement. The phase delay is then mathematically calculated as:


$$\frac{360^\circ \times (\text{Time Interval } A - B)}{\text{Period}}$$

or in other words:

$$\text{Phase } A - B = 360^\circ \times \text{Time Delay} \times \text{FREQ}$$

A somewhat more elaborate method is used in these counters. It allows the necessary measurements to be performed in one pass by using time-stamping. Two consecutive time-stamps from trigger events on channel A and two corresponding time-stamps from channel B are enough to calculate the result, including sign.

## Resolution



**Fig. 4-19** Traditional phase definition.

The frequency range for phase is up to 160 MHz and the resolution depends on the frequency. For frequencies below 100 kHz the resolution is  $0.001^\circ$  and for frequencies above 10 MHz it is  $1^\circ$ . It can be further improved by averaging through the built-in statistics functions.

## Possible Errors

Phase can be measured on input signal frequencies up to 160 MHz. However, at these very high frequencies the phase resolution is reduced to:

$$100ps \times 360^\circ \times FREQ$$

### Inaccuracies

The inaccuracy of Phase A-B measurements depends on several external parameters:

- Input signal frequency
- Peak amplitude and slew rate for input signals A and B
- Input signal S/N-ratio

Some internal parameters are also important:

- Internal time delay between channel A and B signal paths
- Variations in the hysteresis window between channel A and B

Let us look deeper into the restrictions and possibilities of using phase measurements.

Inaccuracy: The measurement errors are of two kinds:

- Random errors
- Systematic errors

The *random errors* consist of resolution (quantization) and noise trigger error.

*Systematic errors* consist of “inter-channel delay difference” and “trigger level timing” errors. Systematic errors are constant for a given set of input signals, and in general, you can compensate for them in the controller (GPIB-systems) or locally via the **MATH/LIM** menu (manual operation) after making calibration measurements. See *Methods of Compensation* on page 4-20.

### ■ Random Errors

The phase quantization error algorithm is:

$$100 ps \times FREQ \times 360^\circ$$

For example, the quantization error for a 1 MHz input signal is thus:

$$100 ps \times 1 \times 10^6 \times 360^\circ \approx 0.04^\circ$$

The trigger noise error consists of *start* and *stop* trigger errors that should be added. For sinusoidal input signals each error is:

$$\frac{360^\circ}{2 \pi \times \frac{S}{N} \text{ ratio}}$$

Let’s use the example above and add some noise so that the S/N ratio will be 40 dB. This corresponds to an amplitude ratio of 100 times (and power ratio of 10000 times). Then the trigger noise will contribute to the random error with:

$$\frac{360^\circ}{2 \pi \times 100} \approx 0.6^\circ$$

The sum of random errors should not be added linearly, but in an “RMS way”, because of their random nature. Let’s do so for our examples above.

Random error =

$$\sqrt{\text{quant. err.}^2 + \text{start trg. err.}^2 + \text{stop trg. err.}^2}$$

The total random errors are thus:

$$\sqrt{0.04^2 + 0.6^2 + 0.6^2} \approx 0.85^\circ \text{ (single-shot)}$$

What about random errors caused by internal amplifier noise? Internal noise contribution is normally negligible. The phase error caused by noise on the signal, whether internal or external, is:

$$\frac{360^\circ}{2\pi \times \%N \text{ ratio}}$$

For an input signal of 250 mV<sub>rms</sub> and the typical internal noise figure of 250 μV<sub>rms</sub> gives us a S/N-ratio of a minimum of 60 dB (1000 times). This gives us a worst case error of 0.06°. Increasing the input signal to 1.5 V<sub>rms</sub> decreases the error to 0.01°.

Another way to decrease random errors is to use the statistics features of the instrument and calculate the mean value from a number of samples.

### ■ Systematic Errors in Phase Measurements

Systematic errors consist of 3 elements:

- Inter-channel propagation delay difference.
- Trigger level timing errors (start and stop), due to trigger level uncertainty.

The inter-channel propagation delay difference is typically 500 ps at identical trigger conditions in both input channels. Therefore, the corresponding Phase difference is:

$$<0.5 \text{ ns} \times 360^\circ \times \text{FREQ}$$

See the following table.

### Trigger level timing error

160 MHz	28.8°
100 MHz	18.0°
10 MHz	1.8°
1 MHz	0.18°
100 kHz	0.018°
10 kHz and below	0.002°

**Table 4-2** Phase difference caused by inter-channel propagation delay difference

The “trigger level timing error” is depending on two factors:

- The actual trigger point is not exactly zero, due to trigger level DAC uncertainty and comparator offset error.
- The two signals have different slew rates at the zero-crossing.

Every counter has input hysteresis. This is necessary to prevent noise to cause erroneous input triggering. The width of the hysteresis band determines the maximum sensitivity of the counter. It is approximately 30 mV, so when you set a trigger level of 0 V, the actual trigger point would normally be +15 mV and the recovery point –15 mV. This kind of timing error is cancelled out by using hysteresis compensation.

Hysteresis compensation means that the microcomputer can offset the trigger level so that actual triggering (after offset) equals the set trigger level (before offset). This general hysteresis compensation is active in phase as well as in time interval and rise/fall time measurements. There is a certain residual uncertainty of a few mV and there is also a certain temperature drift of the trigger point.

## Measuring Functions

The nominal trigger point is 0 V with an uncertainty of  $\pm 10$  mV.

A sine wave expressed as

$V(t) = V_p \times \sin(2\pi ft)$ , has a slew rate  $\frac{\Delta V}{\Delta t}$  of

$V_p \times 2\pi f$  close to the zero-crossing. That gives us the systematic time error when crossing 10 mV, instead of crossing 0 mV.

$$\frac{10mV}{(V_p \times 2\pi \times FREQ)} (s)$$

And the corresponding phase error in degrees is:

$$\frac{10mV \times 360^\circ \times FREQ}{V_p \times 2\pi \times FREQ}$$

which can be reduced to:

$$\frac{0.6}{V_p} (^\circ)$$

This error can occur on both inputs, so the worst case systematic error is thus:

$$\frac{0.6}{V_p(A)} + \frac{0.6}{V_p(B)} (^\circ)$$

Vpeak (A)	Vpeak (B)	Worst case systematic error
150 mV	150 mV	$4^\circ + 4^\circ = 8^\circ$
1.5 V	150 mV	$0.4^\circ + 4^\circ = 4.4^\circ$
1.5 V	1.5 V	$0.4^\circ + 0.4^\circ = 0.8^\circ$

**Table 4-3** Systematic trigger level timing error (examples).

### ■ Methods of Compensation

The calculations above show the typical uncertainties in the constituents that make up the total systematic error. For a given set of input signals you can compensate for this error more or less completely by making calibration

measurements. Depending on the acceptable residual error, you can use one of the methods described below. The first one is very simple but does not take the inter-channel propagation delay difference into account. The second one includes all systematic errors, if it is carried out meticulously, but it is often not practicable.

Common settings for the two inputs are:

<b>Slope:</b>	Pos or Neg
<b>Coupling:</b>	AC
<b>Impedance:</b>	1 M $\Omega$ or 50 $\Omega$ depending on source and frequency
<b>Trigger:</b>	Man
<b>Trigger Level:</b>	0 V
<b>Filter:</b>	Off

#### Method 1:

Connect the test signals to Input A and Input B. Select the function **Phase A rel A** to find the initial error. Use the **MATH/LIM** menu to enter this value as the constant **L** in the formula **K\*X+L** by pressing **X<sub>0</sub>** and change sign.

Now the current measurement result (**X<sub>0</sub>**) will be subtracted from the future phase measurements made by selecting **Phase A rel B**. A considerable part of the systematic phase errors will thus be cancelled out. Note that this calibration has to be repeated if the frequency or the amplitude changes.

#### Method 2:

Connect one of the signals to be measured to both Input A and Input B via a 50  $\Omega$  power splitter or a BNC T-piece, depending on the source impedance. Make sure the cable lengths between power splitter / T-piece and instrument inputs are equal. Select the function **Phase A rel B** and read the result. Enter this value as a correction factor in the same way as described above for Method 1.

In order to minimize the errors you should also maintain the signal amplitudes at the inputs, so that the deviation between calibration and measurement is kept as small as possible.

The same restrictions as for Method 1 regarding frequency and amplitude apply to this method, i.e. you should recalibrate whenever one of these signal parameters changes.

### *Residual Systematic Error:*

By mathematically (on the bench or in the controller) applying corrections according to one of the methods mentioned above, the systematic error will be reduced, but not fully eliminated. The residual time delay error will most probably be negligible, but a trigger level error will always remain to a certain extent, especially if the temperature conditions are not constant.

# Voltage

## $V_{MAX}$ , $V_{MIN}$ , $V_{PP}$

Press **MEAS FUNC** → **Volt**. The counter can measure the input voltage levels  $V_{MAX}$ ,  $V_{MIN}$  and  $V_{PP}$  on DC-input voltages and on repetitive signals between 1 Hz and 300 MHz.


The default low frequency limit is 20 Hz but can be changed via the **SETTINGS** →

**Miscellaneous** menu between 1 Hz and 50 kHz. A higher low-frequency limit means faster measurements.

The voltage capacity is  $-50$  V to  $+50$  V in two automatically selected ranges.

For LF signals the measurement has “voltmeter performance”, i.e. an accuracy of about 1 % of the reading.

You can select any one of the parameters to be the main parameter that is displayed in large digits and with full resolution, while the others are displayed simultaneously at the bottom of the display in smaller characters.



**Fig. 4-20** The voltage is determined by making a series of trigger level settings and sensing when the counter triggers.

# V<sub>RMS</sub>

When the waveform (e.g. sinusoidal, triangular, square) of the input signal is known, its crest factor, defined as the quotient ( $Q_{CF}$ ) of the peak ( $V_p$ ) and RMS ( $V_{rms}$ ) values, can be used to set the constant  $K$  in the mathematical function  $K*X+L$ . The display will then show the actual  $V_{rms}$  value of the input signal, assuming that  $V_{pp}$  is the main parameter.

$$V_{rms} = \frac{1}{2Q_{CF}} V_{pp}$$

*EXAMPLE: A sine wave has a crest factor of 1.414 ( $\sqrt{2}$ ), so the constant in the formula above will be 0.354.*

*Press **MATH/LIM** and after that **Math**→**Math(Off)**→**K\*X+L** Press **K=** and enter **0.354** via the **NUMERIC ENTRY** keys. Check that the **L** constant is set to its default setting 0. Confirm your choices with the softkeys below the display. If the input is AC coupled and **V<sub>pp</sub>** selected, the display will now show the RMS value of any sine wave input.*

If the sine wave is superimposed on a DC voltage, the RMS value is found as:  $0.354*V_{pp} + V_{DC}$ . If  $V_{DC}$  is not known it can be found as:

$$V_{DC} = \frac{V_{MAX} - V_{MIN}}{2}$$

To display the rms value of a sine wave superimposed on a DC voltage, follow the example above, but set  $L = V_{DC}$ .

This page is intentionally left blank.



*Chapter 5*

# **Measurement Control**

# About This Chapter

This chapter explains how you can control the start and stop of measurements and what you can obtain by doing so. The chapter starts by explaining the keys and the functions behind them, then gives some theory, and ends with actual measurement examples.

## Measurement Time

This parameter is only applicable to the functions **Frequency** and **Period Average**. Increasing the measurement time gives more digits, i.e. higher resolution, but fewer measurements per second. The default value is 200 ms but can be changed via **SETTINGS** → **Meas Time** between 20 ns and 1000 s.

The default value gives 11 digits on the display and 4 to 5 measurements each second. Varying the measurement time is a hardware-based averaging method in contrast to the software-based mean value function that can be found in the **STAT/PLOT** menu.

The measurement time changes in 1/2/5 steps if you use the arrow keys for stepping. By using the numeric entry keys you can set any value within the specified range with a resolution of 20 ns.



*To quickly select the lowest measurement time, enter 0. The counter will select 20 ns automatically.*

## Gate Indicator

The GATE LED is on when the counter is busy counting input cycles.

## Single Measurements

**SINGLE** is implicitly the normal measurement mode, which means that the counter

shows the results from a single input cycle. The exceptions are **Frequency** and **Period Average**.

**Single** or **Average** is not relevant for  $V_{\max}$ ,  $V_{\min}$  or  $V_{pp}$  measurements.

## Hold/Run & Restart

Pressing **HOLD** completes the current measurement and freezes the result on the display.

Pressing **RESTART** initiates a new measurement.

If you are performing a statistics measurement and press **HOLD**, the pending sample will be finished. Then the measurement will stop, and you can, for instance, watch the graphic representation of the samples taken so far.

Pressing **RESTART** starts a new measurement from sample 1, and the measurement will stop when the preset number of samples has been taken.

## Arming

Arming gives you the opportunity to start and stop a measurement when an external qualifier event occurs.

Start and stop of the arming function can independently be set to positive slope, negative slope, or it can be turned off. A delay between 10 ns and 2 s can be applied to the start arming channel to facilitate certain measurements. The resolution is 10 ns.

Input E on the rear panel is the normal arming input, but also input A and input B can be used. The frequency range for input E is 80 MHz, whereas it is 160 MHz for the other inputs.

All the versatile arming functions can be reached under **SETTINGS** → **Arm**.

Arming is somewhat complicated yet gives the flexibility to perform a measurement on a specific portion of a complex signal, like a frequency measurement on the colorburst contained in a composite video signal.

Other examples of arming can be found later in this chapter, starting on page 5-9.

## Start Arming

Start arming acts like an ExternalTrigger on an oscilloscope. It allows the start of the actual measurement to be synchronized to an external trigger event.

In a complex signal, you may want to select a certain part to perform measurements on. For this purpose, there is an arming delay function, which delays the actual start of measurement with respect to the arming pulse, similar to a “delayed timebase” in an oscilloscope.

You can choose to delay start arming by a preset time.

Start arming can be used for all functions except **Frequency Burst, Ratio** and **Volt**. If you use start arming to arm an average measurement, it only controls the start of the first sample.

## Stop Arming

Stop arming prevents the stop of a measurement until the counter detects a level shift on the arming input. Combining Start and Stop Arming results in an “external gate” function which determines the duration of the measurement.

Stop arming can be used for all functions except **Frequency Burst, Ratio, Volt** and **Rise/Fall Time**.

# Controlling Measurement Timing

## The Measurement Process

### *Basic Free-running Measurements*

Since these counters use the reciprocal counting technique, they always synchronize the start and stop of the actual measuring period to the input signal trigger events. A new measurement automatically starts when the previous measurement is finished (unless **HOLD** is on). This is ideal for continuous wave signals.

The start of a measurement takes place when the following conditions have been met (in order):

- The counter has fully processed the previous measurement.
- All preparations for a new measurement are made.
- The input signal triggers the counter's measuring input.

The measurement ends when the input signal meets the stop trigger conditions. That happens directly after the following events:

- The set measurement time has expired (applies to **Frequency** and **Period Average** measurements only).
- The input signal fulfils the stop trigger conditions, normally when it passes the trigger window the second time.

### Resolution as Function of Measurement Time

The quantization error and the number of digits on the display mainly define the resolution of the counter, that is the least-significant digit displayed.

As explained on page 4-10 under Reciprocal Counting, the calculated frequency  $f$  is:

$$f = \frac{n}{t_g}$$

while the relative rms quantization error  $E_q = \pm 100\text{ps}/t_g$ .

The counter truncates irrelevant digits so that the rms quantization resolution cannot change the LSD (least-significant digit) more than  $\pm 5$  units. This occurs when the displayed value is

99999999, and the quantization error is worst case. The best case is when the displayed value is 10000000. Then the quantization resolution corresponds to  $\pm 0.5$  LSD units.



$\pm 1$  unit in 99999999 ( $=1E8$ ) means 10 times more relative resolution than  $\pm 1$  unit in 10000000 ( $=1E7$ ), despite the same number of digits.

A gradual increase of the measurement time reduces the instability in the LSD caused by the quantization uncertainty. At a specific measurement time setting, the counter is justified to display one more digit. That one additional digit suddenly gives ten times more display resolution, but not a ten times less quantization uncertainty. Consequently, a measurement time that gives just one more display digit shows more visual uncertainty in the last digit.

For a stable LSD readout, the maximum measurement time selected should be one that still gives the required number of digits. Such optimization of the measurement time enables the total resolution to be equal to the quantization resolution.

## Measurement Time and Rates

The set measurement time decides the length of a measurement if Frequency or Period Average is selected.

This is important to know when you want to make fast measurements, for example when you are using the statistics features, or when you are collecting data over the GPIB bus.

The so-called “dead time”, that is the time between the stop of one measurement and the start of the next one in the course of a block measurement, can be below  $2 \mu\text{s}$ .

A block is a collection of consecutive measurements, the results of which are stored in local memory for statistics or plotting purposes (**STAT/PLOT** menu) or for later transfer to a controller over one of the data communication links (GPIB, USB or ETHERNET).

### Additional controls over start and stop of measurements

Free-running measurements may be easy to understand, but measurements can get more complex.

Besides input signal triggering, the *start* of a measurement is further controlled by the following elements:

- Manual **RESTART**, if **HOLD** is selected.
- GPIB triggering (<GET> or \*TRG), if bus triggering is selected.
- External arming signal, if **Start Arming** is selected.
- Expired start arming delay, if **Arming Delay** is selected.

In addition to expired measurement time and stop signal triggering, the *stop* of measurement is further controlled by:

- External arming signal triggering, if **Stop Arming** is selected.

GPIB triggering is described in the Programming manual.

Now let’s look deeper into the concept of *arming*.

## What is Arming?

*Arming* is a pretrigger condition (“qualifier”) that must be fulfilled before the counter allows a measurement to start.

Arming can also be used to qualify the stop of a measurement. This is called “stop arming”

as opposed to the more common “start arming”.

When you use arming, you disable the normal free-run mode, i.e. individual measurements must be preceded by a valid start arming signal transition.


If you use start arming and stop arming together you get an externally controlled measurement time, a so-called “External Gate”.

### ■ Manual Arming

The counters have a manual start arming function called **HOLD**. Here you manually arm the start of each individual measurement by pressing the **RESTART** key.

Use this manual arming mode to measure single-shot phenomena, which are either triggered manually or occur at long intervals. Another reason for using this manual arming could simply be to allow sufficient time to write down individual results.

### ■ When Do I Use Start Arming?



**Fig. 5-1** A synchronization signal starts the measurement when start arming is used.

Start arming is useful for measurements of frequency in signals, such as the following:


- Single-shot events or non-cyclic signals.
- Pulse signals where pulse width or pulse positions can vary.
- Signals with frequency variations versus time (“profiling”).

- A selected part of a complex waveform signal.

Signal sources that generate complex waveforms like pulsed RF, pulse bursts, TV line signals, or sweep signals, usually also produce a *sync* signal that coincides with the start of a sweep, length of an RF burst, or the start of a TV line. These sync signals can be used to arm the counter. See Fig. 5-1.

### ■ When Do I Use Stop Arming?

You normally use stop arming together with start arming. That means that the external gating signal controls both the start and the stop of the measurement. Such a gating signal can be used to force the counter to measure the frequency of a pulsed RF signal. Here the position of the external gate must be inside a burst. See Fig. 5-2.




**Fig. 5-2** Start and stop arming together is used for burst signal gating.

Note that burst measurements with access to an external sync signal are performed in the normal **Frequency** mode, whereas burst measurements without an external sync signal are performed in the self-synchronizing **Frequency Burst** mode.

In time interval measurements, you can use the stop arming signal as a sort of “external trigger Hold Off signal.” Here you block stop

triggering during the external period. See Fig. 5-3.



**Fig. 5-3** Using arming as an external Hold Off.

### ■ The Arming Input

- **Input E** is the normal arming input. It is suitable for arming (sync) signals that have TTL levels. The trigger level is fixed at 1.4V and cannot be changed. The trigger slope can be set to positive or negative. The Input E connector can be found on the rear panel of the instrument.
- **Input A** or **Input B** can also be used as arming input for all single channel measurements and dual channel measurements where the arming signal is one of the measuring signals. This input is more suitable if your arming signal does not have TTL levels. All input controls such as AC/DC, Trigger Level, 50  $\Omega$  / 1 M $\Omega$  etc. can be used to condition the arming signal.

### Using the measuring signal as arming signal

When performing time or frequency measurements on complex signals having a unique trigger point, input B arming can be used to make the measuring signal itself “auto-arm” the counter, e.g. to measure the frequency of a signal after it has reached a specified voltage limit (= set trigger level), see Fig. 5-4.

- Connect the signal to input A.

- Press **INPUT A** and adjust the settings to suit the interesting part of the signal.
- Press **INPUT B** and adjust the settings so that the unique trigger point can be detected. Normally **DC** coupling and **Manual** trigger level should be preferred.
- Activate start arming with or without delay on input B via the **SETTINGS** menu. The signal on input A will be internally connected to input B, so no external signal tap is necessary.


### ■ When Do I Use Arming With Delay?

You can delay the start arming point with respect to the arming signal. Use this function when the external arming signal does not coincide with the part of the signal that you are interested in.

The time delay range is 20 ns to 2 s with a setting resolution of 10 ns.

### ■ Getting The Whole Picture

The flowchart in Fig. 5-5 illustrates how *arming a trigger hold off* enables precise control of the start and stop of the actual measurement when you operate the counter from the front panel. If you control the counter via the GPIB or USB, read more about bus arming and triggering under the heading “How to use the trigger system” in the Programming Manual.



**Fig. 5-4** Auto-arming using the trigger level on B as qualifier.





Fig. 5-5 Measurement control flow diagram.




# Arming Setup Time

The arming logic needs a setup time of about 5 nanoseconds before the counter is really armed; see Fig. 5-6.



**Fig. 5-6** Time from active external control edge until measurement is armed:

When arming delay is selected, the setup time is different; see Fig. 5-7. It illustrates the effect of the 100 ns delay resolution.



**Fig. 5-7** Time from expired time delay until measurement is armed: . -60 to +40 ns.

Fig. 5-7 shows that a start trigger signal may be detected although it appears 60 nanoseconds before the programmed time delay has expired. The start trigger signal must come 40 nanoseconds after the programmed time delay has expired to guarantee correct start of the measurement.

# Arming Examples

## Introduction to Arming Examples


The following arming examples are available:

- #1 Measuring the first pulse in a burst
- #2 Measuring the second pulse in a burst
- #3 Measuring the time between pulse #1 and #4 in a burst
- #4 Profiling

Examples 1 and 2 measure the pulse width of a selected positive pulse in a burst. You can, however, also measure the period, rise time, or duty factor by changing FUNCTION, and you can measure on a negative pulse by changing trigger slope.

If you do not know the basic parameters of the signal to be measured, we recommend to use an oscilloscope for monitoring. Then you can estimate roughly how to set trigger slope, arming slope and arming delay.

## #1 Measuring the First Burst Pulse



**Fig. 5-8** Synchronizing the measurement so that the pulse width of the first pulse is measured.

In the first example we will measure the width of pulse #1 in a repetitive pulse burst. In this example, a synchronization signal (SYNC) with TTL levels is also available. See Fig. 5-8. However, the quick and simple method de-

scribed first does not employ arming at all but rather draws on the fact that a counter of this type tends to self-synchronize its internal processes to the input signal.

Our task is to synchronize the start of the measurement (start trigger) to the leading edge of the first pulse. Depending on the signal timing, this can be easy, difficult, or very difficult.

### ■ A. Auto Synchronization Without Arming

If we are lucky, we can manage without using the arming function at all. Often, the counter can automatically synchronize the measurement start to the triggering of the first pulse. The conditions for success are that the PRF is not too high, preferably below 50 Hz and certainly not above 150 Hz. The duration of a pulse burst (between first and last pulse) should be substantially less than the distance to the next burst, and the number of pulses in the burst should be more than 100 to avoid occasional miscounts.


Do the following steps to perform auto synchronization without arming:

- Connect the burst signal to input A.
- Adjust the manual sensitivity and trigger level until the burst signal triggers the counter correctly.
- Use the **MEAS/FUNC** key to select **Pulse Width A**.
- Use **Pacing Time** to select a value that approaches the time between the bursts.

Absolute synchronization will not be guaranteed in this way, but there is a high probability that auto-synchronization will work anyway. However, occasional erroneous values will be displayed. To achieve guaranteed synchronization, use the **Start Arming** function.

### ■ B. Synchronization Using Start Arming

The SYNC signal can be directly used to arm the measurement. This requires that the leading edge of the SYNC signal occurs more than 5 nanoseconds before the leading edge of the first pulse in the burst. See Fig. 5-9.



**Fig. 5-9** Synchronization using start arming.

Do the following steps to perform synchronization using start arming:

- Connect SYNC to input E.
- Connect the burst signal to input A.
- Adjust the trigger level to match the burst signal under study.
- Press **SETTINGS** → **Arm**
- Select **Start Arm Delay = 0** and **Start Chan E**.
- Use **MEAS/FUNC** to select **Pulse Width A**.


If there is no (or too little) time difference between the arming signal and the first pulse in the pulse burst, arming must be combined with a delay. See example C.

### ■ C. Synchronization Using Start Arming With Time Delay

If the pulse bursts have a stable repetition frequency, you synchronize the measurement using Start Arming with Time Delay. Here you use the SYNC pulse belonging to a preceding burst to synchronize the start of measurement.

Set the time delay to a time longer than the duration of a pulse burst and shorter than the repetition time of the pulse bursts.

See Fig. 5-10.



**Fig. 5-10** Synchronization using start arming with time delay.

Use the same test setup as in the preceding example but enter a suitable **Start Arm Delay**.


## #2 Measuring the Second Burst Pulse

The next task is to measure the width of the *second* pulse in the pulse train from example 1. How can we now synchronize the measurement start to the start of the second pulse? In this case auto-synchronization, without the use of the arming function, cannot work. Auto-synchronization can be used only to synchronize on the *first* trigger event in a burst.

Depending on the SYNC signal's position relative to the burst, and the duration of the SYNC signal, the measurement can be performed with or without using arming delay.


If the trailing edge of the SYNC signal occurs *after* the leading edge of the first pulse but *before* the second pulse in the pulse burst, then normal start arming without delay can be used. Select triggering on positive slope on input A and negative slope on input E. The slope for the active arming channel is set in the **SETTINGS** → **Arm** → **Start Slope** menu. This example is shown in the following figure:

If the SYNC-pulse timing is not so suitable as in the above measurement example, then arm-



**Fig. 5-11** If the trailing edge of the sync signal appears before the second pulse, use arming without delay.

ing must be used combined with a time delay; see the following figure:




**Fig. 5-12** Use arming with delay if the trailing edge of the sync signal appears too late to be useful.

Use the same test setup as in the preceding example but enter a suitable **Start Arm Delay**.

The set delay time must be set to expire in the gap between pulse #1 and #2.

### #3 Measuring the Time Between Burst Pulse #1 and #4

In the previous examples, the synchronization task has been to identify the *start* of a measurement and to perform a single-shot time interval measurement. Now, we will complicate the picture even more. In our next example we will not only arm the start, but also the stop of a measurement. We will measure the time between the first and the fourth pulse in the pulse burst. We still have the SYNC signal available, see Fig. 5-13.




**Fig. 5-13** Measuring a time interval inside a burst.

The measurement function is not Pulse Width A but **Time Interval A to A** where the settings for input B are used for controlling the stop conditions. The desired start and stop trigger points are marked in the preceding illustration. Our task is now to arm both the start and the stop of this measurement. The start arming is already described in example #1, i.e., synchronize measurement start to the leading edge of the first pulse. The challenge is to synchronize the *stop* of the measurement, i.e., to arm the stop. If we do nothing, the time interval measured will be the time between the first and the second pulse. We must thus delay the stop. This can be done in different ways.

■ **A. Using Trigger Hold Off to Delay the Stop a Certain Time**

Trigger Hold Off is used to inhibit stop triggering during a preset time. The Hold Off pe-

riod starts synchronously with the start trigger event. The Hold Off time should be set to expire somewhere between pulse number 3 and 4, see Fig. 5-14.



**Fig. 5-14** If Hold Off expires between pulses three and four, the correct time interval is measured.


Use the same test setup as in the preceding examples. Then proceed as follows:

- Use the **MEAS/FUNC** key to select **Time Interval A to A**.
- Press **INPUT B** and choose positive slope and a suitable trigger level.
- Press **SETTINGS** → **Trigger Hold Off (On)** and enter a suitable Hold Off time.
- Make sure the start arming conditions from example #1 are maintained, i.e. no arming delay.
- Measure.

■ **B. Using Stop Arming (i.e., External Hold Off) to Delay the Stop**

So far in our examples, the sync signal has been used exclusively as a start arming signal; i.e., we have been concerned only about the leading edge of the sync signal, and not its duration. However, the sync signal can also be used as an *External Trigger Hold Off* when you select stop arming on the trailing edge of the sync signal. If the duration of the sync pulses can be externally varied, we can select

a duration that expires in the gap between pulse #3 and #4.



**Fig. 5-15** Using both start and stop arming to select the part of the burst that is of interest.

Use the same test setup as in the preceding example. Then proceed as follows:

- Press **SETTINGS** → **Arm** and select **Stop Chan E** and negative **Stop Slope**.
- Measure.

## #4 Profiling

*Profiling* means measuring frequency versus time. Examples are measuring warm-up drift in signal sources over hours, measuring the linearity of a frequency sweep during seconds, VCO switching characteristics during milliseconds, or the frequency changes inside a “chirp radar” pulse during microseconds. These counters can handle many profiling measurement situations with some limitations. Profiling can theoretically be done manually, i.e., by reading individual measurement results and plotting in a graph. However, to avoid getting bored long before reaching your 800th or so measurement result, you must use some computing power and a bus interface. In profiling applications, the counter acts as a fast, high-resolution sampling front end, storing results in its internal memory. These results are later transferred to the controller for analysis and graphical presentation. The TimeView™ software package greatly simplifies profiling.

You must distinguish between two different types of measurements called *free-running* and *repetitive sampling*.

### ■ Free-Running Measurements

*Free-running* measurements are performed over a longer period, e.g., to measure the stability over 24 hours of oscillators, to measure initial drift of a generator during a 30-minute warm-up time, or to measure short-term stability during 1 or 10s. In these cases, measurements are performed at user-selected intervals in the range 2  $\mu$ s to 1000 s. There are several different ways of performing the measurements at regular intervals.

#### *Measurements using the statistics features for setting the “pacing time”*

By setting the pacing time to 10 s for example, measurements are automatically made at 10 s intervals until the set number of samples has been taken. The range is 2 - 2\*10<sup>9</sup>. Use **HOLD/RUN** and **RESTART** if you want to stop after one full cycle. You can watch the trend or spread on the graphic display while the measurement is proceeding.

#### *Using a controller as a “pacer”*

As an alternative, the timer in the controller can be used for pacing the individual measurements. This allows for synchronization with external events, for instance a change of DUT when checking a series of components.

#### *Using external arming signals*

External arming signals can also be used for “pacing.” For example with an arming signal consisting of 10 Hz pulses, individual measurements are armed at 100 ms intervals.

#### *Letting the counter run free*

When the counter is free-running, the shortest delay between measurements is approximately 4  $\mu$ s (internal calibration OFF) or 8  $\mu$ s (inter-

nal calibration ON) plus set measurement time. For example, with a measurement time of 0.1 ms, the time between each sample is approximately 104-108  $\mu$ s.

### ■ Repetitive Sampling Profiling

The measurement setup just described will not work when the profiling demands less than 4  $\mu$ s intervals between samples.

*How to do a VCO step response profiling with 100 samples during a time of 10 ms.*

This measurement scenario requires a *repetitive* input step signal, and you have to repeat your measurement 100 times, taking one new sample per cycle. And every new sample should be delayed 100  $\mu$ s with respect to the previous one.

The easiest way to do this is by means of a controller, e.g. a PC, although it is possible but tedious to manually set and perform all 100 measurements.


The following are required to setup a measurement:

- A repetitive input signal (e.g., frequency output of VCO).
- An external SYNC signal (e.g., step voltage input to VCO).
- Use of arming delayed by a preset time (e.g., 100, 200, 300  $\mu$ s).


See Fig. 5-16 and Fig. 5-17.

When all 100 measurements have been made, the results can be used to plot frequency versus time. Note that the absolute accuracy of the time scale is dependent on the input signal itself. Although the measurements are *armed* at 100  $\mu$ s  $\pm$  100 ns intervals, the actual *start of measurement* is always synchronized to the first input signal trigger event after arming.

The TimeView™ software package will do this measurement quickly and easily.



**Fig. 5-16** Setup for transient profiling of a VCO.



**Fig. 5-17** Results from a transient profiling measurement.

*Chapter 6*

# **Process**

## Introduction

Three different ways to process a measuring result are available: Averaging, Mathematics and Statistics. They can be used separately or all together.

In addition to postprocessing you can also monitor the measurement results in real time by setting limits and deciding how to react when they are crossed.

### Averaging

Hardware averaging by means of counting clock pulses during several full input signal cycles is only used for the measurement functions **Frequency** and **Period Average**. The parameter to be set by the operator in this case is **Meas Time** under **SETTINGS**, and the range is 20 ns to 1000 s. Longer measuring times mean higher resolution.

The other functions employ single cycle measuring, and the method to get average results is to utilize the statistics features described later.

## Mathematics

The counter can use four mathematical expressions to process the measurement result before it is displayed:

1.  $K \cdot X + L$
2.  $K / X + L$
3.  $K \cdot X / M + L$
4.  $(K / X + L) / M$

Press **MATH/LIM** → **Math** to enter the first mathematics submenu. See page 2-12 how to enter the constants K, L and M and how to select the formula that best suits your need.

The default values of K, L and M are chosen so that the measurement result is not affected directly after activating **Math**. Recalling the default setting will restore these values as well.

### Example:

If you want to observe the deviation from a certain initial frequency instead of the absolute frequency itself, you can do like this:

- Recall the default settings by pressing **USER OPT** → **Save/Recall** → **Recall Setup** → **Default**.
- Connect the signal to be measured to input A.
- Press **AUTO SET** to let the counter find the optimum trigger conditions on its own.
- Press **MATH/LIM** → **Math** → **L**
- If the current display value is suitable for your purpose, then press **X0**. It will then be transferred to the constant L. You can repeat pressing **X0** until you are satisfied. The constant will be updated with the latest measurement result.
- Instead of using **X0** you can enter any numerical value from the front panel. Let's assume that 10 MHz is your reference frequency. The mantissa is marked by text inversion for immediate editing. Press **1** → **0** → **±** → **EE** → **6**.
- Confirm by pressing **EXIT/OK**. Now the constant L is updated and displayed as **-10E6**.
- Press **Math** and choose the expression **K·X+L** by pressing the softkey below it.
- Now the display will show the deviation from the value you have just entered.

By changing the constant K you can scale the result instead.



# Statistics

Statistics can be applied to all measuring functions and can also be applied to the result from **Mathematics**.

The available statistics functions are as follows:

**X MAX:** Displays the maximum value within a sampled population of  $N$   $x_i$ -values.

**X MIN:** Displays the minimum value within a sampled population of  $N$   $x_i$ -values.

**X P-P:** Displays the peak-to-peak deviation within a sampled population of  $N$   $x_i$ -values.

**MEAN:** Displays the arithmetic mean value ( $\bar{x}$ ) of a sampled population of  $N$   $x_i$ -values and is calculated as:

$$\bar{x} = \frac{1}{N} \sum_{i=1}^N x_i$$

**ST DEV:** Displays the standard deviation ( $s$ ) of a sampled population of  $N$   $x_i$ -values and is calculated as:

$$s = \sqrt{\frac{\sum_{i=1}^N (x_i - \bar{x})^2}{N - 1}}$$

It is defined as the square root of the variance.

**A DEV:** Displays the Allan deviation ( $\sigma$ ) of a sampled population of  $N$   $x_i$ -values and is calculated as:

$$\sigma = \sqrt{\frac{\sum_{i=1}^{N-1} (x_{i+1} - x_i)^2}{2(N - 1)}}$$

It is defined as the square root of the Allan variance.

The number  $N$  in the expressions above can assume any value between 2 and  $2 \cdot 10^9$ .

## Allan Deviation vs. Standard Deviation

The *Allan Deviation* is a statistic used for characterizing short-term instability (e.g. caused by jitter and flutter) by means of samples (measurements) taken at short intervals. The fundamental idea is to eliminate the influence of long-term drift due to aging, temperature or wander. This is done by making consecutive comparisons of adjacent samples.

The *Standard Deviation*, which is probably a more familiar statistic, considers the effects of all types of deviation, as all samples in the population are compared with the total mean value.

As you can see, both the *Allan Deviation* and the *Standard Deviation* are expressed in the same units as the main parameter, e.g. Hz or s.

## Selecting Sampling Parameters

- Press **SETTINGS** → **Stat.**
- Press **No. of samples** and enter a new value by means of the numerical keys or the **UP/DOWN** arrow keys, if you want to change the default value of 100.
- Proceed in the same way for **No. of bins**, if you want to present the measurement results graphically in a histogram.



Note that the six statistic measures are calculated and displayed simultaneously only in the non-graphic presentation mode under **STAT/PLOT**.

Use the same key for toggling between the three modes **Numerical - Histogram - Trend**.

- Press **Pacing time** and enter a new value if you want to change the default value 20 ms. The range is 2  $\mu$ s - 1000 s. The pacing parameter sets the sampling interval.
- Activate the set pacing time by pressing **Pacing Off**. The status is changed to **Pacing On**. Status *Pacing Off* means that the set number of samples will be taken with minimum delay.
- Press **HOLD/RUN** to stop the measuring process.
- Press **RESTART** to initiate one data capture
- Toggle **STAT/PLOT** to view the measurement result as it is displayed in the different presentation modes.



*Note that you can watch the intermediate results update the display continually until the complete data capture is ready.*

*This is particularly valuable if the collection of data is lengthy.*

## Measuring Speed

When using statistics, you must take care that the measurements do not take too long time to perform. Statistics based on 1000 samples does not give a complete measurement result until all 1000 measurements have been made, although it is true that intermediate results are displayed in the course of the data capture. Thus it can take quite some time if the setting of the counter is not optimal.

Here are a few tips to speed up the process:

- Do not use AUTO trigger. It is convenient, but it takes a fraction of a second each time the timer/counter determines new

trigger levels, and 1000 or 10000 times a fraction of a second is a long time.


- Do not use a longer measuring time than necessary for the required resolution.
- Remember to use a short pacing time, if your application does not require data collection over a long period of time.

## Determining Long or Short Time Instability

When making statistical measurements, you must select measuring time in accordance with what you want to obtain:

Jitter or very short time (cycle to cycle) variations require that the samples be taken as Single measurements.

If average is used (Freq or Period Average only), the samples used for the statistical calculations are already averaged, unless the set measuring time is less than the period time of the input signal (up to 160 MHz). Above this frequency prescaling by two is introduced anyhow, and as a consequence a certain amount of averaging. This can be a great advantage when you measure medium or long time instabilities. Here averaging works as a smoothing function, eliminating the effect of jitter.



**Fig. 6-1** Jitter and drift.

The signal in Fig. 6-1 contains a slower variation as well as jitter. When measuring jitter

you should use a limited number of samples so that the slow variation does not become noticeable or alternatively use the dedicated statistical measure for this kind of measurement, the Allan deviation.

To measure the slower variation you calculate Max, Min or Mean on a long series of averaged samples. Here averaging eliminates the jitter in each sample and the long measuring time and large number of samples means that the measurement can record very slow variations. The maximum pacing time equals the maximum measuring time for each sample and is 1000 s, and the maximum number of samples is  $2 \cdot 10^9$ , which in effect means that a single data capture could theoretically span up to  $2 \cdot 10^{12}$  s or more than 60000 years.

## Statistics and Mathematics

The counter allows you to perform mathematical operations on the measured value before it is presented to the display or to the bus. See Page 6-2 to get an overview of the four available equations.

Any systematic measurement uncertainty can be measured for a particular measurement setup, and the needed correction constants can be entered into these equations. Statistics will then be applied to the corrected measured value.

## Confidence Limits

The standard deviation can be used to calculate the confidence limits of a measurement.

Confidence limits =  $\pm k s_x$

Where:

$s_x$  = standard deviation

$k = 1$  for a confidence level of 68.3%  
(1 $\sigma$  - limits)

$k = 2$  for a confidence level of 95.5%  
(2 $\sigma$  - limits)

$k = 3$  for a confidence level of 99.7%  
(3 $\sigma$  - limits)

### ■ Example

A measurement of a time interval of 100  $\mu$ s is used to illustrate how the confidence limits are calculated from the measurement result.

Use the statistics to determine the mean value and standard deviation of the time interval. Take sufficient samples to get a stable reading. Assume further that the start and stop trigger transitions are fast and do not contribute to the measurement uncertainties. The counter displays:

MEAN value = 100.020  $\mu$ s and a STD DEV = 50 ns, then the 95.5% confidence limits =  $\pm 2 s_x = \pm 2 * 50 \text{ ns} = \pm 100 \text{ ns}$ .

The 3 $\sigma$  - limit will then be  $\pm 3 * 50 \text{ ns} = \pm 150 \text{ ns}$

## Jitter Measurements

Statistics provides an easy method of determining the short term timing instability, (jitter) of pulse parameters. The jitter is usually specified with its rms value, which is equal to the standard deviation based on single measurements. The counter can then directly measure and display the rms jitter.

Otherwise, the standard deviation of mean values can be measured. The rms value is a good measure to quantify the jitter, but it gives no information about the distribution of the measurement values.

To improve a design, it might be necessary to analyze the distribution. Such measurements as well as trend analysis can be performed by means of the built in graphic capability - toggle the **STAT/PLOT** key to see the two graphic presentation modes.

Even higher versatility can be exploited with a controller and the optional **TimeView™** Frequency and Time Analyzing Software Package.

## Limits

The Limits Mode makes the counter an efficient alarm condition monitor with high flexibility as to the report possibilities.

Press **MATH/LIM** → **Limits** to enter the first Limits Menu. See below.




Fig. 6-2 The Limit Menu, level 1

You can set two levels by entering the submenus named Lower Limit resp. Upper Limit. Any numerical value can be entered using scientific notation. The active keys are the digits 0-9, the decimal point, the change sign ( $\pm$ ) and the softkey designated EE for toggling between the mantissa and the exponent.

Typos are erased by pressing the left arrow key. Confirm by pressing **ENTER**.

## Limit Behavior

Press **Limit Behavior** to set how the counter will react on limit crossings. The following choices exist:

- **Off**  
No action taken. **LIM** indicator is OFF. In all other behavior modes, the **LIM** indicator is ON and non-flashing, unless the limits set in the **Limit Mode** menu have been crossed.

- **Capture**  
The measurements are compared with the limits set under **Lower Limit** and **Upper Limit**, and the **LIM** symbol will be flashing when the active **Limit Mode** has set the **LIM** flag.

Only samples meeting the test criterion will be part of the population in statistics presentations.

- **Alarm**  
The measurements are compared with the limits set under **Lower Limit** and **Upper Limit**, and the **LIM** symbol will be flashing when the active **Limit Mode** has set the **LIM** flag.

All samples, i.e. also those outside the limits, will be part of the population in statistics presentations.

- **Alarm\_stop**  
The measurements are compared with the limits set under **Lower Limit** and **Upper Limit**, and the **LIM** symbol will be flashing when the active **Limit Mode** has set the **LIM** flag.

The measurement process will stop, and the value that caused the limit detector to trigger can be read on the display.

Only samples taken before the alarm condition will be part of the population in statistics presentations.

The alarm conditions can also be detected via the SRQ function on the GPIB. See the Programming Manual.

## Limit Mode

The **Limit Mode** offers three choices:

- Above**  
 Results above the set lower limit will pass. A flashing **LIM** symbol on the display reports that the measurement result has been below the lower limit at least once since the measurement started. Use **RESTART** to reset the **LIM** symbol to its non-flashing state.
- Below**  
 Results below the set upper limit will pass. A flashing **LIM** symbol on the display reports that the measurement result has been above the upper limit at least once since the measurement started. Use **RESTART** to reset the **LIM** symbol to its non-flashing state.
- Range**  
 Results inside the set limits will pass. A flashing **LIM** symbol on the display reports that the measurement result has been below the lower limit or above the upper limit at least once since the measurement started. Use **RESTART** to reset the **LIM** symbol to its non-flashing state.




Fig. 6-3 The analog limit monitor.

If **Range** is selected and the presentation mode is **VALUES**, a one-dimensional graphic representation of the current measurement value in relation to the limits can be seen at the same time as the numerical value.

The upper limit (UL) and the lower limit (LL) are vertical bars below the main numerical display, and their numerical values are displayed in small digits adjacent to the bars. See Fig. 6-3.

This type of graphic resembles a classic analog pointer instrument, where the pointer is a "happy smiley" as long as it is positioned inside the limits and a "sad smiley" when it gets outside the limits but is still within the display area. Values that fall outside the display area are represented by a "<" at the left edge or a ">" at the right edge.

The location of the bars is fixed, so the "inside" range takes up the mid third of the display area. This means that the resolution and the scale length are set by the limits that have been entered by the operator.

## Limits and Graphics

Limits can also be applied to the two-dimensional graphics, the trend plot and the histogram. By introducing limits you can inhibit the auto-scaling and indirectly set the scale length and the resolution.




Fig. 6-4 Limits in a trend plot.




Fig. 6-5 Limits in a histogram.

This page is intentionally left blank.

*Chapter 7*

# **Performance Check**

# General Information

**WARNING:** Before turning on the instrument, ensure that it has been installed in accordance with the Installation Instructions outlined in Chapter 1 of the User's Manual.

This performance procedure is intended for:

- checking the instrument's specification.
- incoming inspection to determine the acceptability of newly purchased instruments and recently recalibrated instruments.
- checking the necessity of recalibration after the specified recalibration intervals.

*NOTE: The procedure does not check every facet of the instrument's calibration; rather, it is concerned primarily with those parts of the instrument which are essential for determining the function of the instrument.*

It is not necessary to remove the instrument cover to perform this procedure.

## Preparations



Power up your instrument at least 30 minutes before checking to let it reach normal operating temperature. Failure to do so may result in certain test steps not meeting equipment specifications.

## Test Equipment

Type of Equipment	Required Specifications
Reference Oscillator	10 MHz, $1 \times 10^{-8}$ (e.g. 908) for calibrating the standard oscillator
	10 MHz, $1 \times 10^{-9}$ (e.g. 909) for calibrating PM6690/_5_ & PM6690/_6_
Voltage Calibrator	DC -50 V to +50 V (e.g. 5500) for calibrating the built-in voltage reference, alternatively corresponding DC power supply + DVM with uncertainty <0.1 %
LF Synthesizer	Square/ Sine up to 10 MHz, 10 V <sub>RMS</sub>
Pulse Generator	2 ns rise time, 5 V peak, >10 MHz, continuous & one-shot trigger
Oscilloscope	350 MHz, <3% voltage uncertainty
RF Signal Generator	100 MHz to 3 or 8 GHz dep. on prescaler option, 10 MHz ext.ref.
Power Splitter	50 Ω 6 dB BNC
T-piece	BNC
Termination	50 Ω feedthrough BNC
Lowpass Filter	50 kHz (for 1 MΩ)
BNC Cables	5 to 7 pcs of suitable lengths

**Table 7-1** Recommended equipment for calibration and performance check.



# Front Panel Controls

## Internal Self-Tests

The test programs forming the self-diagnosis can be activated from the front panel as follows:

- Press **USER OPT**
- Press **Test**.
- Press **Test Mode**.
- Select one of the six tests available by pressing the softkey below the label with the name of the test function. Five of the tests (RAM, ROM, Logic, Display, and Interface) are individual. They are briefly described below. The sixth, named **All**, performs all five individual tests in sequence.
  - **All** - all tests performed in sequence
  - **RAM** - test of RAM memory
  - **ROM** - test of ROM memory
  - **Logic** - test of counter ASIC and other logic circuits.
  - **Display** - test of graphic display module
  - **Interface** - test of GPIB and USB
- Press **Start Test**.
- If a fault is detected, an error message appears on the display and the program halts. Note any error messages.
- If no faults are detected, the instrument returns to the normal measurement mode.

## Keyboard Test

This test verifies that the timer/counter responds when you press any key. It is not a functional test. Such tests are performed later in this chapter. The important thing here is

that something changes on the display when you press a key. Consequently you can press the keys in almost any order without paying attention to the exact response, but for those who want to be more systematic there is a table overleaf, where all keys are exercised at least once.

Press the keys as described in the first column and look at the display for the text in the second column. Some keys change more text on the display than described here. The display text mentioned here is the one mostly associated with the selected key.

*NOTE: For the instrument to respond correctly, this test must be carried out in sequence, and you must start with the DEFAULT setting. See page 2-13. No signals should be applied to the input connectors*

## Performance Check

Key(s)	Display	Notes	P/F
<b>STANDBY</b>	<b>Off</b>	Red standby LED On (Key common to ON)	
<b>ON</b>	<b>Backlight On</b>	Red standby LED Off (Key common to STANDBY)	
<b>INPUT A</b>	<b>Input A:</b>	Menu for setting Slope, Coupling, Impedance etc.	
<b>Man</b>			
<b>Trig</b>	<b>Trig: xy mV</b>	Menu for entering numeric values in V or mV	
<b>0.123V</b>	<b>Trig: 0.123 V</b>		
◀ (5 times)	<b>Trig: _ V</b>		
<b>4.567</b>	<b>Trig: 4.567 V</b>		
◀ (5 times)	<b>Trig: _ V</b>		
<b>8.9</b>	<b>Trig: 8.9 V</b>		
<b>±</b>	<b>Trig: -8.9 V</b>		
<b>mV</b>	<b>Trig: -8.9 mV</b>		
<b>V</b>	<b>Trig: -8.9 V</b>		
<b>AUTOSET</b>	<b>Menu disappears</b>		
<b>INPUT B</b>	<b>Input B:</b>	Menu for setting Slope, Coupling, Impedance etc.	
<b>SETTINGS</b>	<b>Settings:</b>	Menu for setting Meas Time, Hold-Off, Ref. Source etc.	
<b>ENTER</b>	<b>Meas Time: 200 ms</b>		
<b>▲</b>	<b>Meas Time: 500 ms</b>		
<b>▼</b>	<b>Meas Time: 200 ms</b>		
<b>EXIT/OK</b>	<b>Settings:</b>	Menu for setting Meas Time, Hold-Off, Ref. Source etc.	
<b>EXIT/OK</b>	<b>Menu disappears</b>		
<b>MATH/LIM</b>	<b>Math/Limit:</b>	Menu for selecting post-processing formula and alarm limit	
<b>USER OPT</b>	<b>User options:</b>	Menu for Calibration, Memory Management, Interface etc.	
<b>CANCEL</b>	<b>Menu disappears</b>		
<b>HOLD/RUN</b>	<b>Hold</b>	At upper right corner	
<b>HOLD/RUN</b>	<b>Hold disappears</b>		
<b>MEAS FUNC</b>	<b>Measure function:</b>	Menu for selecting measurement function	

Key(s)	Display	Notes	P/F
▶	Period	Cursor position marked by text inversion	
ENTER	Single A		
EXIT/OK	Menu disappears	Period Single A: at upper left corner	
STAT/PLOT	Period Single A MEAN:	Aux parameters: Max, Min, P-P, Adev, Std	
VALUE	Stat parameters disappear		

**Table 7-2** Keyboard test

## Short Form Specification Test

### Sensitivity and Frequency Range

- Recall the DEFAULT settings.
- Press **INPUT A**.
- Select **50 Ω** input impedance, **1x** attenuation, **MAN**ual trigger and **Trig**ger level **0 V**.
- Connect a signal from a HF generator to a BNC power splitter.
- Connect the power splitter to Input A of your counter and an oscilloscope.
- Set the input impedance to  $50\ \Omega$  on the oscilloscope.
- Adjust the amplitude according to the following table. Read the level on the oscilloscope. The timer/counter should display the correct frequency.
- Connect the signal to Input B.
- Press **INPUT B**.
- Select **50 Ω** input impedance, **1x** attenuation, **MAN**ual trigger and **Trig**ger level **0 V**.
- Press **MEAS FUNC** → **Freq** → **Freq A** → **B**
- Repeat the measurements above for Input B.

Frequency (MHz)	Level		Pass	
	mV <sub>rms</sub>	dBm	Input A	Input B
10	15	-23		
50	15	-23		
100	15	-23		
200	15	-23		
300	25	-19		

**Table 7-3** Sensitivity for inputs A & B at various frequencies

### Voltage

- Recall the DEFAULT settings.
- Press **INPUT A** and select **DC** coupling.  
Do not apply an input signal to Input A yet.
- Press **EXIT/OK**.
- The counter should now indicate:  
 $V_{MAX} = 0 \pm 0.01$  V and  
 $V_{MIN} = 0 \pm 0.01$  V.
- Connect  $4.00 V_{DC}$  to channel A, using an external low pass filter on the input.
- The readings should be:  
 $V_{MAX} = 4.00 \pm 0.05$  V and  
 $V_{MIN} = 4.00 \pm 0.05$  V.
- Repeat the measurement with inverted polarity
- Press **INPUT A** and select **10x**.
- Press **EXIT/OK**.
- Change the DC level to 40 V.
- The counter should indicate:  
 $V_{MAX} = 40.0 \pm 0.5$  V and  
 $V_{MIN} = 40.0 \pm 0.5$  V
- Repeat the measurement with inverted polarity.
- Press **INPUT A** and select **1x**.
- Press **EXIT/OK**.
- Connect a sinusoidal signal to Input A with an amplitude of  $4.00 V_{pp}$  and a frequency of 100 kHz.
- The indication should be  $4.00 \pm 0.27 V_{pp}$ .
- Press **INPUT A** and select **10x**.
- Press **EXIT/OK**.
- Change the amplitude to  $18 V_{pp}$ .
- The display should read  $18.0 \pm 2.1 V_{pp}$ .
- Press **INPUT B** and select **DC** coupling.  
Do not apply an input signal to Input B yet.
- Press **EXIT/OK**.
- Press **MEAS FUNC** → **Freq** → **Freq A** → **B**.
- The counter should now indicate:  
 $V_{MAX} = 0 \pm 0.01$  V and  
 $V_{MIN} = 0 \pm 0.01$  V
- Repeat the measurements for Input B as described above for Input A.

## Trigger Indicators and Input Controls

Trigger Level (manually set)	Trigger Indicator	Pass	
		Input A	Input B
+1 V	off		
-1 V	on		
0.0 V	blinking		

**Table 7-4** Trigger indicator check.

*NOTE: This test must be performed in the sequence given.*

- Recall the **DEFAULT** settings.
- Press **INPUT A** and select **MAN**ual trigger level.
- Connect the LF synthesizer to Input A. Use the following settings (into 50  $\Omega$ ): Sine, 10 kHz, 0.9 V<sub>pp</sub>, and +0.50 V DC offset.
- Verify that the three modes for the trigger indicator are working properly by changing the trigger level:
  - Press the **Trig** key and enter 1 V via the keyboard, then verify by pressing **EXIT/OK**. Check the trigger indicator according to Table 7-4.
  - Press the **Trig** key and enter -1 V via the keyboard by pressing the **±** key, then verify by pressing **EXIT/OK**. Check the trigger indicator according to Table 7-4.
- Press the **Trig** key and enter 0 via the keyboard, then verify by pressing **EXIT/OK**. Check the trigger indicator according to Table 7-4.
- Apply the signal to Input B instead.
- Press **MEAS FUNC** → **Freq** → **Freq A** → **B**
- Press **INPUT B** and select **MAN**ual trigger level.
- Repeat the trigger level settings above to verify the three trigger indicator modes for Input B.

Settings	V <sub>max</sub>	V <sub>min</sub>	Pass/Fail	
			Input A	Input B
<b>INPUT A, DC, 50 <math>\Omega</math></b>	+950 mV	+50 mV		
<b>AC</b>	+450 mV	-450 mV		
<b>10X</b>	+0.45 V	-0.45 V		
<b>1 M<math>\Omega</math></b>	> +0.45 V	< -0.45 V		

**Table 7-5** Input controls check.

## Trigger Level Check

- Recall the DEFAULT settings.
- Connect the LF synthesizer to Input A.  
Use the same settings as in the previous test.
- Press **INPUT A** and select **DC** and **50 Ω**.
- Check the first  $V_{max}$  and  $V_{min}$  voltage levels on the display according to Table 7-5.
- Perform the rest of the settings in sequence, and read the corresponding  $V_{max}$  and  $V_{min}$  values. Remember that these values are approximate and serve only as indicators of state changes.
- Connect the generator to Input B.
- Press **MEAS FUNC** → **Freq** → **Freq A** → **B**
- Press **INPUT B** and select **DC** and **50 Ω**
- Perform the settings and check the  $V_{max}$  and  $V_{min}$  values for Input B according to Table 7-5.

To check the accuracy of the oscillator you must have a calibrated reference signal that is at least five times more stable than the oscillator that you are testing. See Table 7-6 and the list of test equipment on page 7-2. If you use a non-10 MHz reference, you can use the mathematics in the timer/counter to multiply the reading.

- Recall the DEFAULT settings.
- Connect the reference to input A
- Check the readout against the accuracy requirements of your application.

### ■ Acceptance Test

Table 7-6 can serve as an acceptance test and gives a worst case figure after 30 minutes warm-up time. All deviations that can occur in a year are added together.

## Reference Oscillators

X-tal oscillators are affected by a number of external conditions like ambient temperature and supply voltage. Aging is also an important factor. Therefore it is hard to give limits for the allowed frequency deviation. The user himself must decide the limits depending on his application, and recalibrate the oscillator accordingly.

Oscillator	Frequency Readout	Suitable Reference	P/F
PM6690/_1_(Standard)	10.00000000 MHz ± 150 Hz	908	
PM6690/_5_(OCXO)	10.00000000 MHz ± 1 Hz	909	
PM6690/_6_(OCXO)	10.00000000 MHz ± 0.25 Hz	909	

**Table 7-6** Acceptance test for oscillators.

## Resolution Test

- Connect the pulse generator to a power splitter.
- Connect one side of the power splitter to Input A on the counter using a coaxial cable.
- Connect the other side of the power splitter to Input B on the counter.

Settings for the pulse generator:

- Amplitude = 2 V<sub>PP</sub>, (high level +2 V and low level 0 V)
- Period = approx. 1 μs
- Duration = approx. 50 ns
- Rise time = 2 ns

Restore the timer/counter's default settings and make the following changes:

- Function = **Time A-B**
- Press **STAT/PLOT** key to the right of the display.
- Settings for **INPUT A** and **INPUT B**:
  - **50 Ω** input impedance
  - **MAN**ual trigger level
  - **Trig** level = 0.5 V
  - **DC** coupling
  - **POS** slope

The standard deviation (**Std**) should be <100 ps.

## Rear Inputs/Outputs

### 10 MHz OUT

- Connect an oscilloscope to the 10 MHz output on the rear of the counter. Use a coaxial cable and 50 Ω termination.
- The output voltage should be sinusoidal and above 1 V<sub>RMS</sub> (2.8 V<sub>p-p</sub>).

### EXT REF FREQ INPUT

- Recall the **DEFAULT** settings.
- Connect a stable 10 MHz signal (e.g REF OUT from another counter) to input A.
- Connect a 10 MHz, 100 mV<sub>RMS</sub>, (0.28 V<sub>p-p</sub>) signal from the LF synthesizer to EXT REF IN.
- Select Ext Ref. by keying in the following sequence:  
**SETTINGS** → **Meas Ref** → **External**
- The display should show 10 MHz.
- Change the external reference frequency to 5 and 1 MHz.
- The counting should continue, and the display should still show 10 MHz.

### EXT ARM INPUT

- Proceed from the test above.
- Select **MAN**ual trigger.
- Connect the pulse generator to Ext Arm Input.
- Settings for the pulse generator: single shot pulse, manual trigger, amplitude TTL = 0 - 2 V<sub>PP</sub>, and duration = 10 ns.

- Activate start arming by keying in the following sequence:  
**SETTINGS** → **Start Chan** → **E**
- The counter does not measure.
- Apply one single pulse to Ext Arm Input.
- The counter measures once and shows 10 MHz on the display.

## Measuring Functions

- Connect a 10 MHz sine wave signal with approx. 1 V<sub>RMS</sub> amplitude into 50 Ω via a power splitter to Input A and Input B, e.g. from 10 MHz Out on the rear panel. Use equal cable lengths from the power splitter to the inputs.
  - Recall the DEFAULT settings.
- Select the following settings for the timer/counter via **INPUT A** and **INPUT B**:
- **50 Ω** impedance for A and B.
  - **MAN**ual trigger.
  - **POS** slope.
  - Check that the timer/counter performs the correct measurement by displaying the result as shown under the “Display” column in Table 7-7.
  - Select function via **MEAS FUNC.**

## Check of HOLD OFF Function

- Recall the DEFAULT settings.
- Select the following common timer/counter settings for both Input A and Input B via the hard menu keys **INPUT A** and **INPUT B**:
- **50 Ω** impedance.
  - **DC** coupling.
  - **MAN**ual trigger, **x1** attenuation.
  - **Trig**ger level = 0.5 V.
  - Press **SETTINGS** and activate **Hold Off**. Select **Hold Off On** and set the **Trig**ger **Hold Off** time to 1 μs.
  - Connect the pulse generator with the following settings to Input A :
    - Period = 100 μs.
    - Duration 10 ns.
    - Double pulse.
    - Delay = 1 μs.
    - Amplitude = 1.0 V<sub>pp</sub>, (high level +1V and low level 0V).
    - Rise time 2 ns.
  - Check the following results:
    - Freq A with Hold Off **On** = 10 kHz.
    - Freq A with Hold Off **Off** = 20 kHz.
  - Connect the signal to Input B, select **Freq B** and repeat the tests above.



# Options

## Input C Check

To verify the specification of the different RF prescalers (Input C), use the following basic test setup:

- Connect the output of a signal generator covering the specified frequency range to the RF input of the counter.
- Connect the 10 MHz REF OUT from the generator to the EXT REF IN on the rear panel of the counter.

Selected Function	Action	Display	P/F
FREQ A		10 MHz <sup>2)</sup>	
FREQ B		10 MHz <sup>2)</sup>	
FREQ C	500 MHz, -15 dBm to Inp. C	500 MHz <sup>3)</sup>	
FREQ RATIO A/B		1 <sup>2)</sup>	
FREQ RATIO C/B		50 <sup>2) 3)</sup>	
PER SINGLE A		100 ns <sup>2)</sup>	
PER SINGLE B		100 ns <sup>2)</sup>	
PER AVERAGE A		100 ns <sup>2)</sup>	
PER AVERAGE B		100 ns <sup>2)</sup>	
TIME INT A to B	POS SLOPE A, NEG SLOPE B	50 ns <sup>1)</sup>	
	NEG SLOPE A, POS SLOPE B	50 ns <sup>1)</sup>	
PULSE POS A		50 ns <sup>1)</sup>	
PULSE NEG A		50 ns <sup>1)</sup>	
RISE TIME A		30 ns <sup>2)</sup>	
FALL TIME A		30 ns <sup>2)</sup>	
PHASE A rel B	POS SLOPE A, NEG SLOPE B	180° or -180° <sup>1)</sup>	
PHASE B rel A		180° or -180° <sup>1)</sup>	
PHASE A rel A	POS SLOPE A, POS SLOPE B	0° or 360°	
DUTY POS A		0.5 <sup>1)</sup>	
DUTY NEG A		0.5 <sup>1)</sup>	
VOLT MAX A		+0.75 V <sup>2)</sup>	
VOLT MIN A		-0.75 V <sup>2)</sup>	

**Table 7-7** Measuring functions check

1) Value depends on the symmetry of the signal.

2) Exact value depends on input signal.

3) If an RF option is installed.

## Performance Check

---

- Choose **Meas Ref** from the **SETTINGS** menu and select **External**.
- Choose **Freq C** from the **MEAS FUNC** menu.
- Generate a sine wave in accordance with the tables.
- Verify that the counter is counting correctly. (The last digit will be unstable)

Frequency	Amplitude		P/F
	MHz	mV <sub>RMS</sub>	
100-300	20	-21	
300-2500	10	-27	
2500-2700	20	-21	
2700-3000	40	-15	

**Table 7-8** RF input sensitivity,  
3 GHz Option.

Frequency	Amplitude		P/F
	MHz	mV <sub>RMS</sub>	
200-500	20	-21	
500-3000	10	-27	
3000-4500	20	-21	
4500-6000	40	-15	
6000-8000	80	-9	

**Table 7-9** RF input sensitivity,  
8 GHz Option.

*Chapter 8*

# **Specifications**

## Introduction

Only values with tolerances or limits are guaranteed data. Values without tolerances are informative data, without guarantee.

## Measurement Functions

Refer to page 8-9 for uncertainty information.

Inputs A and B can be swapped in all modes except **Rise Time** and **Fall Time**.

**Display:** All measurements are displayed with a large main parameter value and smaller auxiliary parameter values (with less resolution). Some measurements are only available as auxiliary parameters.

### Frequency A, B, C

#### ■ Range:

*Input A:* 0.001 Hz - 300 MHz

*Input B:* 0.001 Hz - 300 MHz

*Input C:* 100 MHz - 3 GHz  
(PM6690/6\_\_)  
200 MHz - 8 GHz  
(PM6690/7\_\_)

*Resolution:* 12 digits/s

#### ■ Display:

*Main Parameter:* Frequency  
*Aux. Parameters:*  $V_{max}$ ,  $V_{min}$ ,  $V_{p-p}$

### Frequency Burst A, B, C

Frequency and PRF of repetitive burst signals can be measured without external control signal and with selectable start arming delay.

*Functions:* Frequency in burst (Hz)  
PRF (Hz)  
Number of cycles in burst

*Range A, B, C:* See Frequency A, B, C

*Min. Burst*

*Duration:* 40 ns (80 ns > 160 MHz)

*Min. No. of Pulses*

*in Burst (Inp A, B):* 3 (6 above 160 MHz)  
*(Inp C):* 3 x prescaler factor

*PRF Range*

*(see also*  
*Inp C spec):* 0.5 Hz - 1 MHz

*Start Delay*

*Range:* 10 ns - 2 s, resolution  
10 ns

#### ■ Display:

*Main Parameter:* Frequency in burst  
*Aux. Parameters:* PRF & number of cycles  
in burst

### Period A, B, C Average

#### ■ Range:

*Input A, B:* 3.3 ns - 1000 s

*Input C (3 GHz):* 370 ps - 10 ns  
*(8 GHz):* 125 ps - 5 ns

*Resolution:* 12 digits/s

#### ■ Display:

*Main Parameter:* Period  
*Aux. Parameters:*  $V_{max}$ ,  $V_{min}$ ,  $V_{p-p}$

## Period A, B Single

*Range A, B:* See Period A, B Average  
*Resolution:* 100 ps

### ■ Display:

*Main Parameter:* Period  
*Aux. Parameters:*  $V_{\max}$ ,  $V_{\min}$ ,  $V_{p-p}$

## Ratio A/B, B/A, C/A, C/B

*Range:*  $10^{-9}$  to  $10^{11}$  (one-pass measurement, values < 1 with reduced resolution)

### ■ Input Frequency

*Input A, B:* 0.1 Hz - 300 MHz  
*Input C:* See *Frequency C* or *Input C*

### ■ Display:

*Main Parameter:* Ratio  
*Aux. Parameters:* Freq 1, Freq 2

## Time Interval A to B, B to A, A to A, B to B

*Range (normal calculation):* 0 ns to  $+10^6$  s  
*Range (smart calculation):*  $-10^6$  to  $+10^6$

*Resolution*  
*Single Shot:* 100 ps

*Input Frequency:* Up to 160 MHz  
*Min. Pulse Width:* 1.6 ns

*Smart Calculation:* Smart Time Int. w. 4 time stamps (2 consecutive Trig A plus 2 consecutive Trig B) to determine sign (A before B or A after B)

### ■ Display:

*Main Parameter:* Time interval  
*Aux. Parameters:* None

## Pulse Width A, B

*Range:* 1.6 ns -  $10^6$  s  
*Input Frequency:* Up to 300 MHz  
*Modes:* Pos. pulse width or neg. pulse width (depending on trigger slope)

### ■ Display:

*Main Parameter:* Pulse width  
*Aux. Parameters:*  $V_{\max}$ ,  $V_{\min}$ ,  $V_{p-p}$

## Rise and Fall Time A, B

*Range:* 700 ps - 1000 s  
*Input Frequency:* Up to 160 MHz  
*Trigger Levels:* Default 10% and 90%  
 Manually adjustable  
*Min. Pulse Width:* 1.6 ns  
*Modes:* Rise or fall time (depending on trigger slope)

### ■ Display:

*Main Parameter:* Rise or fall time  
*Aux. Parameters:* Slew rate,  $V_{\max}$ ,  $V_{\min}$

## Phase A Rel. B, B Rel. A

*Range:* -180° to +360°  
*Resolution:* 0.001° to 10 kHz  
 0.01° to 1 MHz  
 0.1° to 10 MHz  
 1° >10 MHz  
 Resolution can be improved by averaging (Statistics)  
*Input Frequency:* Up to 160 MHz  
*Min. Pulse Width:* 1.6 ns  
*Smart Calculation:* One-pass measurement of time interval + single period between two continuous signals with freq.  $f_1$  resp.  $f_2$ , where  $f_1/f_2=N$  or  $1/N$ . N is an integer. The measurement is made with 4 time stamps (2 consecutive Trig A + 2 consecutive Trig B to determine sign (pos. or neg. phase))

### ■ Display:

*Main Parameter:* Phase  
*Aux. Parameters:* Freq (prim. channel),  $V_A/V_B$  (in dB)

## Duty Factor A, B

*Range:* 0.000001 to 0.999999  
*Input Frequency:* 0.1 Hz - 300 MHz  
*Min. Pulse Width:* 1.6 ns  
*Modes:* Pos. or neg. duty factor (depending on trigger slope)

*Smart Calculation:* One-pass measurement of pulse width + single period. The measurement is made with 3 time stamps (2 consecutive pos. Trig A + 1 neg. Trig A)

### ■ Display:

*Main Parameter:* Duty factor  
*Aux. Parameters:* Period, pulse width

## $V_{max}$ , $V_{min}$ , $V_{p-p}$ A, B

*Range:* -5 V to +5 V  
 -50 V to +50 V  
*Input Frequency:* DC, 1Hz - 300 MHz, default 20 Hz - 300 MHz, higher LF limit means higher meas. speed  
*Mode:*  $V_{max}$ ,  $V_{min}$ ,  $V_{p-p}$   
*Resolution:* 2.5 mV  
*Accuracy:*

DC	1% ± 15 mV
1 Hz - 1 kHz	1% ± 15 mV
1 kHz - 20 MHz	3% ± 15 mV
20 - 100 MHz	10% ± 15 mV
100 - 300 MHz	30% ± 15 mV

### ■ Display:

*Main Parameter:*  $V_{max}$  or  $V_{min}$  or  $V_{p-p}$   
*Aux Parameters:* Freq,  $V_{p-p}$ ,  $V_{min}$  or Freq,  $V_{p-p}$ ,  $V_{max}$  or Freq,  $V_{min}$ ,  $V_{max}$

## Timestamping A, B

The raw timestamp data on Input A or B is only accessible via GPIB or USB. Two different trigger conditions, X and Y, can be timestamped simultaneously. Pulses can be counted on one channel (X). Events will be

counted on either X or Y, with a deadtime depending on sample speed before next event.

Alternatively: Timestamps are taken alternately on channels X and Y, starting with X.

*Register Data:*      Timestamp values of trigger condition X  
                               Timestamp values of trigger condition Y  
                               Number of pulses on X

Selectable Trigger Conditions	Selectable Channel
Set Trigger A	X, Y
Set Trigger B	X, Y
Prescaled Input C	X, Y
Arming Input	X, Y
Opposite Trigger Slope of Set Trigger Condition on A	X
Opposite Trigger Slope of Set Trigger Condition on B	X

### Auto Set / Manual Set

All measuring functions can be auto-set using best settings for the individual functions. This means e.g. an auto hysteresis of 40 % of  $V_{p-p}$  in frequency measurements, an auto trigger at 50 % of  $V_{p-p}$  with minimum hysteresis incl. hysteresis compensation in time measurements, an auto find of burst length and auto sync for frequency burst measurements, etc.

# Input and Output Specifications

## Inputs A and B

*Frequency Range*  
*DC-coupled:*           DC - 300 MHz  
*AC-coupled:*           10 Hz - 300 MHz  
*Coupling:*               AC or DC  
*Rise Time:*             Approx. 700 ps  
*Impedance:*            1 M $\Omega$  / 25 pF or 50  $\Omega$  (VSWR < 2:1)  
  
*Trigger Slope:*        Positive or negative  
*Channels:*              Separate A & B, common via A, common via B  
  
*Max. Channel Timing Difference:* 500 ps  
  
*Hysteresis Window:*   Approx. 30 mV<sub>p-p</sub>  
  
*Residual Hysteresis after Compensation:* 5 mV (DC - 10 kHz)  
  
*Sensitivity*  
*DC - 200 MHz:*        15 mV<sub>rms</sub>  
*200 - 300 MHz:*       25 mV<sub>rms</sub>  
  
*Attenuation:*           x1, x10  
  
*Dynamic Range (x1):*   30 mV<sub>p-p</sub> to 10 V<sub>p-p</sub> within  $\pm 5$  V window  
  
*Trigger Level Resolution:* 2.5 mV  
*Uncertainty (x1):*       $\pm(15 \text{ mV} + 1\% \text{ of trg lvl})$   
*Auto:*                    Automatically set to 50% of input signal (10% and 90% for rise/fall time). Relative level (in %) manually adjustable when necessary.

## Specifications

<i>Auto Hysteresis</i>	
<i>Time Meas. :</i>	Minimum hysteresis window (+compensation)
<i>Freq. Meas. &amp; Per. Avg.:</i>	70% and 30% of input signal. Minimum hysteresis window if arming on A or B is activated.
<i>Freq. Range:</i>	>1 Hz (default 20 Hz)
<i>Analog Noise Reduction Filter:</i>	Nom. 100 kHz, RC type
<i>Digital LP Filter:</i>	1 Hz - 50 MHz using trigger hold-off
<i>Trigger Indicators:</i>	LED
<i>Max. Voltage w/o Damage</i>	
1 M $\Omega$ :	350 V (DC+ AC <sub>pk</sub> ) @ DC to 440 Hz, falling to 12 V <sub>RMS</sub> (x1) and 120 V <sub>RMS</sub> (x10) @ 1 MHz
50 $\Omega$ :	12 V <sub>RMS</sub>

### Input C (PM6690/6xx)

<i>Freq. Range:</i>	100 MHz - 3.0 GHz
<i>Prescaler Factor:</i>	16
<i>Operating Input Voltage Range</i>	
100 - 300 MHz:	20 mV <sub>rms</sub> -12 V <sub>rms</sub>
0.3 - 2.5 GHz:	10 mV <sub>rms</sub> -12 V <sub>rms</sub>
2.5 - 2.7 GHz:	20 mV <sub>rms</sub> -12 V <sub>rms</sub>
2.7 - 3.0 GHz	40 mV <sub>rms</sub> -12 V <sub>rms</sub>
<i>Amplitude Modulation</i>	
DC - 0.1 MHz	
<i>Modulation Frequency:</i>	Up to 94% depth
0.1 - 6 MHz	
<i>Modulation Frequency:</i>	Up to 85% depth Min. signal must exceed min. oper. input voltage
<i>Impedance:</i>	50 $\Omega$ nom. AC-coupled VSWR < 2.5:1

<i>Max. Voltage w/o Damage:</i>	12 V <sub>rms</sub> , PIN diode prot.
<i>Connector:</i>	Type N female

### Input C (PM6690/7xx)

<i>Freq. Range:</i>	200 MHz - 8 GHz
<i>Prescaler Factor:</i>	256
<i>Operating input voltage range:</i>	
0.2 - 0.5 GHz	20 mV <sub>rms</sub> - 7 V <sub>rms</sub>
0.5 - 3.0 GHz	10 mV <sub>rms</sub> - 7 V <sub>rms</sub>
3.0 - 4.5 GHz	20 mV <sub>rms</sub> - 7 V <sub>rms</sub>
4.5 - 6.0 GHz	40 mV <sub>rms</sub> - 7 V <sub>rms</sub>
6.0 - 8.0 GHz	80 mV <sub>rms</sub> - 7 V <sub>rms</sub>
<i>Amplitude Modulation</i>	
DC-0.1 MHz	
<i>Modulation Frequency:</i>	Up to 94% depth
0.1-6 MHz	
<i>Modulation Frequency:</i>	Up to 85% depth Min. signal must exceed min. oper. input voltage
<i>Impedance:</i>	50 $\Omega$ nom. AC-coupled VSWR < 2.5:1

<i>Max. Voltage w/o Damage:</i>	7 V <sub>rms</sub> , PIN diode protected
<i>Connector:</i>	Type N female

### Rear Panel Inputs & Outputs

Ref. Input:	1, 1.544, 2.048, 5, or 10 MHz; 0.1 - 5 V <sub>rms</sub> sinewave; impedance >1 k $\Omega$
Ref. Output:	1x10 MHz, >1 V <sub>rms</sub> into 50 $\Omega$ load



**Arming Input:** Arming of all meas. func.  
**Freq. Range:** DC - 80 MHz  
**Slew Rate:** >2 V/ $\mu$ s  
**Trigger Level:** TTL, 1.4 V nom.  
**Trigger Slope:** Positive or negative  
**Meas. Inputs:** A, B, C (option)  
**Impedance:** 1 M $\Omega$ /50 pF or 50  $\Omega$   
 (VSWR  $\leq$  2:1)  
**Connectors:** BNC (SMA for Input C)

**Sample Size:** 2 to 2 x 10<sup>9</sup>  
**Max. Sample Rate:** 250 kSa/s measured, 2 kSa/s calculated, depending on meas. function and graphics  
**Limit Qualifier:** Off  
 Capture & store values above limit 2  
 Capture & store values below limit 1  
 Capture & store values inside limits 1 and 2  
 Capture & store values outside limits 1 and 2  
**Meas. Pacing Time Range:** 2  $\mu$ s - 500 s  
**Max. Pacing Rate:** 10 k measurements/s  
**Equidistancy:**  $\pm$ (10  $\mu$ s + 5% of pacing time)

## Auxiliary Functions

### Trigger Hold-Off

**Time Delay Range:** 20 ns - 2 s, 10 ns resol.

### External Start/Stop Arming

**Modes:** Start arming, stop arming, start and stop arming  
**Input Channels:** A, B, E  
**Max. Rep. Rate for Arming Signal**  
**Channel A, B:** 160 MHz  
**Channel E:** 80 MHz  
**Start Time Delay Range:** 10 ns - 2 s, 10 ns resol.

NOTE: Stop arming has no delay setting.

### Statistics

**Functions:** Maximum, minimum, mean,  $\Delta_{\text{max-min}}$ , standard deviation, Allan deviation  
**Display:** Numeric or numeric + graphic  
**Graphic:** Histogram & trend plot, auto scaled

## Mathematics

**Functions:**  $K \cdot X + L$ ,  $K/X + L$ ,  $(K \cdot X/M) + L$ , and  $(K/X + L)/M$   
 X is current reading. K, L and M are constants, set via keyboard or as frozen reference value ( $X_0$ ).

## Other Functions

**Measuring Time:** 20 ns - 1000 s for Period AVG, Frequency and PRF, 20 ns - 2 s for Freq. in Burst; Single cycle for other meas. functions. Times >2 s are software controlled w. reduced resolution and accuracy.  
**Timebase Reference:** Internal, external or automatic

## Specifications

---

<i>Display Hold:</i>	Freezes meas. result until a new measurement is initiated via Restart.
<i>Limit Alarm:</i>	Annunciator on display and/or SRQ via GPIB
<i>Limit Values:</i>	Lower limit (limit 1) Upper limit (limit 2)
<i>Settings:</i>	Off Alarm if value > limit 2 Alarm if value < limit 1 Alarm if limit 1 < value < limit 2 Alarm if value > limit 2 or value < limit 1
<i>On Alarm:</i>	Stop or Continue
<i>Display:</i>	Numeric + graphic
<i>Numeric:</i>	Current measurement value + annunciator for limit alarm
<i>Graphic:</i>	Horizontal line w. upper/lower limit markers + current value marker
<i>Stored Instrument Setups:</i>	20 complete setups can be saved and recalled from internal non-volatile memory; 10 can be user protected

## Display

<i>Type &amp; Use:</i>	Graphics screen for menu control, numerical readout (14 digits) and status info
<i>Resolution:</i>	320 x 97 pixels
<i>Technology:</i>	Monochrome LCD with white LED backlight

## GPIB Interface

<i>Programmable Functions:</i>	All front panel accessible functions
<i>Compatibility:</i>	IEEE 488.2-1987, SCPI 1999

<i>Modes:</i>	Native mode Agilent compatible mode
---------------	--

<i>Agilent Compatibility:</i>	HP 53131/132/181 com- mands are emulated. Code and response for- mat is compatible. No tim- ing compatibility. No reso- lution compatibility
-----------------------------------	---

<i>Interface Func- tions:</i>	SH1, AH1, T6, L4, SR1, RL1, DC1, DT1, E2
-----------------------------------	---

<i>Max. Meas. Rate Via GPIB:</i>	2000 readings/s (block) 350 readings/s (individual)
--------------------------------------	--

<i>To Internal Memory:</i>	250 k readings/s
--------------------------------	------------------

<i>Internal Memory Size:</i>	Up to 750 k readings
----------------------------------	----------------------

<i>Data Output:</i>	ASCII, IEEE double preci- sion floating point
---------------------	--

## USB Interface

<i>Version:</i>	2.0, 12 Mb/s
<i>Protocol:</i>	USBTMC-USB488

## TimeView™

This software package is intended for advanced Time & Frequency analysis and runs on any 32-bit Windows® system.

### ■ Data Capture Modes & Measurement Rate

Effective rate depends on measurement function and internal data format.

<i>Free-running Measurement:</i>	250 k readings/s
--------------------------------------	------------------

<i>Repetitive Sampling:</i>	Up to 100 Msa/s equiv. sample rate (10 ns between samples)
<i>Continuous Single Period:</i>	Yes, from LF to 0.5 MHz repetition rate
<i>Waveform Capture:</i>	Yes
<i>Data Analysis Features:</i>	Measurement data vs time FFT graph w. Hamming, Hanning and other relevant filters Root Allan variance Smoothing Zoom Cursor measurements Distribution histogram Setup, measurement data archive and printing

# Measurement Uncertainties

## Random Uncertainties

### ■ Quantization Error ( $E_q$ )

$$E_q = 100 \text{ ps rms}$$

### ■ Start/Stop Trigger Error ( $E_{ss}$ )

$$E_{ss} = \frac{\sqrt{(V_{noise - input})^2 + (V_{noise - signal})^2}}{\text{Signal slew rate } (V/s) \text{ at trigger point}} s_{rms}$$

*V<sub>noise-input</sub>*: 200  $\mu$ V<sub>rms</sub> typical internal noise

*V<sub>noise-signal</sub>*: The rms noise of the applied signal

## Systematic Uncertainties

### ■ Trigger Level Timing Error ( $E_{tl}$ ) Time Interval, Rise/Fall Time, Pulse Width, Duty Factor ( $\times 1$ )

$$E_{tl} = TLU \times (1/S_x + 1/S_y) \pm 0.5 \times Hyst \times (1/S_x + 1/S_y) [s]$$

where:

$S_x$  = Slew rate at start trigger point (V/s)

$S_y$  = Slew rate at stop trigger point (V/s)

TLU = Trigger level uncertainty (V)

Hyst = Hysteresis window (V); Hyst = 5 mV  $\pm 1\%$  of set trigger level (DC to 1 kHz)

### Phase with sinusoidal signals and trigger levels = 0 V ( $\times 1$ )

$$E_{tl} = 0.001/V_{pk(A)} + 0.001/V_{pk(B)} [^\circ]$$

where:

$V_{pk(A)}$  = Input A peak voltage in V

$V_{pk(B)}$  = Input B peak voltage in V

### ■ Display Resolution

#### *LSD Displayed*

Unit value of the least significant digit displayed. All calculated LSDs should be rounded to the nearest decade (e.g. 0.3 Hz is rounded to 0.1 Hz, 5 Hz is rounded to 10 Hz) and cannot exceed the 14th digit.

#### Frequency & Period

$$LSD_{displ} = \frac{(Resolution / 2) \times Measurement Result}{Measuring Time}$$

Resolution in s.

#### Time Interval, Rise/Fall Time, Pulse Width & Ratio

$$LSD_{displ} = Resolution / 2$$

#### Duty Factor

$$LSD_{displ} = 1 \times 10^{-6}$$

## Specifications

---

### Phase

$LSD_{displ} = 0.001^\circ$  to  $1^\circ$ , depending on input frequency (see Phase measurement spec.)

### Ratio $f_1/f_2$

$LSD_{displ} = \text{Prescaler factor} / (f_2 \times \text{meas. time})$

### Volt

$LSD_{displ} = TBD$

### Number of Pulses in Burst

$LSD_{displ} = 1$

## Time Interval, Pulse Width, Rise/Fall Time

### ■ Total Random Uncertainty rms

$$u = \sqrt{E_q^2 + (\text{Start Trigger Error})^2 + (\text{Stop Trigger Error})^2}$$

[s] or minimum 1 ps

### ■ Total Systematic Uncertainty

$u = \pm \text{Trigger Level Timing Error}$

$\pm 500 \text{ ps Systematic Error}$

$\pm \text{Time Base Error} \times \text{Measurement Result}$  [s]

## Frequency & Period

### ■ Total Random Uncertainty rms

For measuring times  $< 200$  ms:

$$u = \frac{\sqrt{E_q^2 + 2 * (\text{Start Trigger Error})^2}}{\text{Measuring Time}} \times$$

$\times \text{Measurement Result}$  [Hz or s]

For measuring times  $\geq 200$  ms:

$$u = \frac{2\sqrt{E_q^2 + 2 * (\text{Start Trigger Error})^2}}{\text{Measuring Time} * \sqrt{N}} \times$$

$\times \text{Measurement Result}$  [Hz or s]

$N = 800 / \text{Measuring Time}$ , however always  $\geq 6$  and  $\leq 1000$

### ■ Total Systematic Uncertainty

$u = \pm \text{Time Base Error} \times \text{Measurement Result} \pm 200 \text{ ps} / \text{Measuring Time}$  [Hz or s]

## Ratio $f_1/f_2$

### ■ Total Random Uncertainty rms

$$u = \frac{\sqrt{(\text{Presc. Fact.})^2 + 2 * (f_1 \times \text{Strt Trg Err of } f_2)^2}}{f_2}$$

[dimensionless, e.g. ppm]

## Phase

### ■ Total Random Uncertainty rms

$$u = \sqrt{E_q^2 + (\text{Strt Trg Err})^2 + (\text{Stop Trg Err})^2} \times \text{Freq.} \times 360 [^\circ]$$

or minimum:  $(1 \text{ ps}) \times \text{Frequency} \times 360 [^\circ]$

### ■ Total Systematic Uncertainty

$u = \pm \text{Trigger Level Timing Error}$

$\pm 500 \text{ ps Systematic Error} \times \text{Freq.} \times 360 [^\circ]$

## Duty Factor

### ■ Total Random Uncertainty rms

$$u = \sqrt{E_q^2 + (\text{Strt Trg Err})^2 + (\text{Stop Trg Err})^2} \times \text{Freq.}$$

or minimum:  $(1 \text{ ps}) \times \text{Frequency}$

[dimensionless, e.g. ppm]

### ■ Total Systematic Uncertainty

$u = \pm \text{Trigger Level Timing Error} \times \text{Frequency}$

$\pm 500 \text{ ps Systematic Error} \times \text{Frequency}$

[dimensionless, e.g. ppm]

# Calibration

*Mode:* Closed case, menu-controlled.

*Calibration Input:* A

*Password*

*Protection:* ON or OFF

*Input Frequencies used for TB*

*Calibration:* 1.0, 1.544, 2.048, 5.0 or 10.0 MHz

## Definition of Terms

*Calibration Adjustment Tolerance:*

The maximum tolerated deviation from the true 10 MHz frequency after calibration. If the timebase frequency does not exceed the tolerance limits at the moment of calibration, an adjustment is not necessary.

*Total Uncertainty:* The total possible deviation from the true 10 MHz frequency under influence of frequency drift due to aging and ambient temperature variations versus the reference temperature. The operating temperature range and the calibration interval are part of this specification.

# General Specifications

## Environmental Data

*Class:* MIL-PRF-28800F, Class 3

*Operat. Temp:* 0 °C to +50 °C

*Storage Temp:* -40 °C to +71 °C

*Humidity:* 5-95 % @ 10-30 °C

5-75 % @ 30-40 °C

5-45 % @ 40-50 °C

*Max. Altitude:* 4600 m

*Vibration:* Random and sinusoidal per MIL-PRF-28800F, Class 3

*Shock:* Half-sine 30G per MIL-PRF-28800F; bench handling

*Transit Drop*

*Test:* Transport box tested according to UN-D 1400 drop test program 1. Heavy-duty transport case and soft carrying case tested according to MIL-PRF-28800F.

*Reliability:* MTBF 30000 h, calculated

*Safety:* Designed and tested for Measurement Category I, Pollution Degree 2, in accordance with EN/IEC 61010-1:2001 and CAN/CSA-C22.2 No. 61010-1-04 (incl. approval)

*EMC:* EN 61326 (1997) A1 (1998), increased test levels per EN 50082-2, Group 1, Class B, CE

## Power Requirements

*Line Voltage:* 90-265 V<sub>RMS</sub>, 45-440 Hz

*Power*

*Consumption:* <40 W

Basic version w/o options.

# Timebase Options

Product Family	'90'		
Option Timebase Type	Standard UCXO	PM6690/_5_ OCXO	PM6690/_6_ OCXO
<b>Uncertainty due to:</b> -Calibration adjustment tolerance @ +23 °C ± 3 °C	<1x10 <sup>-6</sup>	<1x10 <sup>-8</sup>	<3x10 <sup>-9</sup>
-Aging per 24 h per month per year	1) <5x10 <sup>-7</sup> <5x10 <sup>-6</sup>	2)<5x10 <sup>-10</sup> <1x10 <sup>-8</sup> <5x10 <sup>-8</sup>	2)<3x10 <sup>-10</sup> <3x10 <sup>-9</sup> <1.5x10 <sup>-8</sup>
-Temperature variation: 0 °C - 50 °C 20 °C - 26 °C (typ. values)	<1x10 <sup>-5</sup> <3x10 <sup>-6</sup>	<5x10 <sup>-9</sup> <1x10 <sup>-9</sup>	<2.5x10 <sup>-9</sup> <4x10 <sup>-10</sup>
-Power voltage variation: ±10%	<1x10 <sup>-8</sup>	<5x10 <sup>-10</sup>	<5x10 <sup>-10</sup>
<b>Short term stability:</b> (Root Allan Variance)  τ = 1 s Typical values τ = 10 s	not specified	1x10 <sup>-11</sup> 1x10 <sup>-11</sup>	5x10 <sup>-12</sup> 5x10 <sup>-12</sup>
<b>Power-on stability:</b> -Deviation versus final value after 24 h on time, after a warm-up time of:	1) 30 min	<1x10 <sup>-8</sup> 10 min	<5x10 <sup>-9</sup> 10 min
<b>Total uncertainty, for operating temperature 0°C to 50 °C, @ 2σ (95 %) confidence interval:</b> -1 year after calibration -2 years after calibration	<1.2x10 <sup>-5</sup> <1.5x10 <sup>-5</sup>	<6x10 <sup>-8</sup> <1.2x10 <sup>-7</sup>	<1.8x10 <sup>-8</sup> <3.6x10 <sup>-8</sup>
<b>Typical total uncertainty, for op- erating temperature 20°C to 26 °C, @ 2σ (95 %) confidence interval:</b> -1 year after calibration -2 years after calibration	<7x10 <sup>-6</sup> <1.2x10 <sup>-5</sup>	<6x10 <sup>-8</sup> <1.2x10 <sup>-7</sup>	<1.7x10 <sup>-8</sup> <3.5x10 <sup>-8</sup>

## Explanations

1) Negligible in comparison with the deviation caused by 1 °C temperature change.

2) After 1 month of continuous operation.

*NOTE: Electrical adjustment by means of tuning voltage from DAC; no potentiometer trimming.  
Serial interface to all optional oscillators for closed-case calibration and status reporting.*

UCXO: Uncompensated Crystal Oscillator

OCXO: Oven Controlled Crystal Oscillator

## Dimensions & Weight

<i>Width:</i>	½ x 19"
<i>Height:</i>	2E
<i>Depth:</i>	<400 mm
<i>Weight:</i>	Net 4 kg (8.5 lb) Shipping 7 kg (15 lb)

## Ordering Information

### *Basic Model*

<i>PM6690:</i>	300 MHz, 100 ps Timer/Counter including standard timebase and GPIB interface
----------------	---

### *Included with Instrument:*

12 months product warranty, line cord, brochure with important information, 'getting started' manual (printed), operators & programming manuals on CD, Certificate of Calibration.

### *HF Input Options*

<i>PM6690/6__:</i>	3 GHz Input C
<i>PM6690/7__:</i>	8 GHz Input C

### *Timebase Options*

<i>PM6690/_5_:</i>	Very high stability OCXO
<i>PM6690/_6_:</i>	Ultrahigh stability OCXO

### *Optional Accessories*

<i>TimeView-90:</i>	Time & freq. analysis SW
<i>PM9611/90:</i>	Rear panel inputs
<i>PM9622:</i>	Rackmount kit
<i>PM9627:</i>	Carrying case
<i>PM9627H:</i>	Heavy-duty hard transport case

This page is intentionally left blank.



*Chapter 9*

# **Index**

# Index

## !

±1 cycle count error . . . . . 4-9

## A

AC/DC coupling . . . . . 3-3

Allan deviation . . . . . 6-3

AM modulated signals . . . . . 4-8

Aperture

See Measuring time

Arming

description . . . . . 5-5

examples . . . . . 5-9

manually . . . . . 5-6

sync. delay . . . . . 5-7

Attenuator

used to reduce noise . . . . . 3-7

Auto

timeout . . . . . 4-10

Auto once . . . . . 3-5

Auto trigger . . . . . 3-8, 6-4

how to use . . . . . 3-8

Auto Trigger . . . . . 4-16

Average . . . . . 6-2

Averaging . . . . . 4-10, 6-2

## B

Burst

Frequency (CW) . . . . . 4-5

## C

Carrier wave frequency AM . . . . . 4-8

Carrier wave frequency FM . . . . . 4-6

Channel

See Input

Confidence Limits . . . . . 6-5

Count error, ±1 cycle . . . . . 4-9

Counting

reciprocal . . . . . 4-9

CW

AM . . . . . 4-8

## D

DC coupling . . . . . 3-3

Delay

arming sync. . . . . 5-7

Delayed timebase . . . . . 5-3

Display Contrast

adjusting . . . . . 2-7

Distortion . . . . . 3-8

Drift . . . . . 6-4

See Also Long time instability  
 Drift measurements. . . . . 5-13  
 Duty cycle  
   See Duty factor

## E

End of a measurement . . . . . 5-4  
 Erroneous counts . . . . . 3-7  
 Error NO TRIG . . . . . 4-10  
 Examples  
   arming. . . . . 5-9  
 Ext. Arm Input  
   Checking. . . . . 7-9  
 External gate . . . . . 5-6

## F

Filter  
   analog. . . . . 3-3  
 Fixed  
   timeout . . . . . 4-10  
 Fixed triggerlevels. . . . . 3-5  
 FM signals . . . . . 4-6  
 Free-running  
   measurements . . . . . 5-4, 5-13  
 Freezing the display  
   See hold/run  
 Frequency. . . . . 4-3  
   Range test. . . . . 7-5  
   ratio. . . . . 4-4  
 Frequency versus time  
   See Profiling  
 Function  
   period . . . . . 4-12  
   ratio. . . . . 4-4

## G

Gate  
   indicator . . . . . 5-2

## H

Harmonic distortion. . . . . 3-8  
 HF input  
   Checking . . . . . 7-11  
 Hold . . . . . 5-6  
 Hold-Off  
   checking . . . . . 7-10  
   used as filter . . . . . 3-4  
 Hysteresis . . . . . 3-6, 4-15

## I

Instability. . . . . 6-4  
 Internal Reference output  
   Checking. . . . . 7-9

## J

Jitter . . . . . 6-4

## L

LCD Contrast  
   adjusting . . . . . 2-7  
 Limits . . . . . 6-6  
 LOCAL LOCKOUT Mode . . . . . 2-7  
 LOCAL Mode . . . . . 2-7  
 Long time instability. . . . . 6-4  
 Low-pass filter  
   digital . . . . . 3-4

## M

Manual  
 arming . . . . . 5-6

Mathematics  
 and Statistics together . . . . . 6-5  
 constants . . . . . 6-2  
 example . . . . . 6-2  
 function . . . . . 6-2

Mean . . . . . 6-3

Measurement  
 end . . . . . 5-4  
 free-running . . . . . 5-13  
 rate . . . . . 5-5  
 start . . . . . 5-4  
 timing . . . . . 5-4

Measurement rate . . . . . 6-4

Measurement Time  
 setting . . . . . 5-2

Measuring speed . . . . . 4-10, 6-4

Measuring time . . . . . 5-5  
 influence by prescaling . . . . . 4-11

Modulating frequency AM . . . . . 4-9

Monitoring . . . . . 6-2

## N

No trig  
 display message . . . . . 4-10

Noise . . . . . 3-6

## O

Overdrive . . . . . 4-15

## P

Period . . . . . 4-12

Phase  
 inaccuracies . . . . . 4-18

Prescaling

effect of . . . . . 4-11

Processing a measuring result . . . . . 6-2

Profiling . . . . . 5-9, 5-13  
 transient . . . . . 5-14  
 VCO step response . . . . . 5-14

Pulse period . . . . . 4-12

Pulse rounding . . . . . 4-16

Pulse Width  
 description . . . . . 4-15

## R

Rate of measurement . . . . . 5-5

Ratio  
 function . . . . . 4-4

Reciprocal counting . . . . . 4-9

Reference Oscillators  
 Checking . . . . . 7-8

Restart . . . . . 5-2

Rise/Fall time . . . . . 4-14

## S

Sample-Hold . . . . . 4-10

Sensitivity . . . . . 4-15  
 Checking . . . . . 7-5

Setup time  
 for arming . . . . . 5-9

Single . . . . . 4-10, 6-2

Single-shot phenomena . . . . . 5-6

Speed  
 arming . . . . . 5-9  
 of measurement . . . . . 4-10

Standard deviation . . . . . 6-3

Start  
 arming . . . . . 5-2, 5-6  
 of a measurement . . . . . 5-4

Statistics . . . . . 6-3  
 and Mathematics together . . . . . 6-5

- 
- Stop  
  arming . . . . . 5-2, 5-6  
  of measurement . . . . . 5-5
- Synchronization of a measurement . . 4-11
- Synchronization delay  
  arming . . . . . 5-7
- Systematic errors  
  in Phase measurements . . . . . 4-19
- T**
- Time  
  period . . . . . 4-12  
  to set up arming . . . . . 5-9
- Timeout  
  auto . . . . . 4-10  
  fixed . . . . . 4-10  
  manual . . . . . 4-10
- Touch-hold  
  See Sample-hold
- Transient profiling . . . . . 5-14
- Trigger Controls  
  Checking . . . . . 7-7
- Trigger error . . . . . 3-8
- Trigger Hold Off . . . . . 3-4
- Trigger hysteresis . . . . . 3-6
- Trigger Indicators  
  Checking . . . . . 7-7
- Trigger level  
  Auto . . . . . 3-3  
  Converting Auto to Manual . . . . . 3-5  
  how to use . . . . . 3-7  
  setting speed . . . . . 3-5
- V**
- VCO  
  step response profiling . . . . . 5-14
- Voltage  
  check . . . . . 7-6  
  Checking . . . . . 7-6  
  function . . . . . 4-22
- X**
- X max . . . . . 6-3
- X min . . . . . 6-3
- X p-p . . . . . 6-3

This page is intentionally left blank.

*Chapter 10*

# **Service**

# Sales and Service office

For service information, contact your Fluke service center. To locate an authorized service center, visit us on the World Wide Web: [www.fluke.com](http://www.fluke.com), or call Fluke using any of the phone numbers listed below:

888 993 5853 in U.S.A and Canada

+31 (0)40 2675 200 in Europe

+1 425 446 5500 from other countries