

APOLLO[®] 618

with Airspace Alert

HIMORROW INC.
Salem, Oregon U.S.A.
A United Parcel Service Company

Manufacturer of Quality Navigation and Communications Equipment

November 1991

Software Version 4.2

560-4016B

II MORROW INC. Limited Warranty (Avionic Loran Products)

1. Scope of Limited Warranty

II Morrow warrants to the original consumer purchaser that II Morrow products will be free of defects in materials and workmanship, under normal use, for the periods described below. The warranty begins on the original retail delivery date, or on the date of first use, whichever occurs earlier. Avionic Loran receivers are covered for 26 months after delivery or first use, whichever is earlier. Antennas and antenna preamplifiers are covered for a period of 12 months after delivery or first use, whichever is earlier. This warranty shall be effective only if and when (i) II Morrow receives a completed warranty registration card with respect to the specific product unit found to be defective; (ii) the unit was installed by personnel certified by the FAA to install avionic equipment and copy of FAA Form 337 documenting the installation is provided to II Morrow (except for homebuilts); (iii) II Morrow receives notice of such defect during the period of the warranty; and (iv) the consumer purchases the unit in the United States or Canada. (ii) Morrow's sole and exclusive liability for breach of warranty shall be (at II Morrow's option) to repair or replace the defective II Morrow products or return the purchase price for any defective products that are returned during the warranty period. II Morrow products repaired or replaced under this warranty are subsequently warranted only for the remaining, unexpired portion of the warranty period applicable to the original product. If II Morrow elects to repair or replace the product, II Morrow shall have a reasonable time to do so.

2. Limitation of Implied Warranties

TO THE EXTENT ALLOWED BY LAW, ANY IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE APPLICABLE TO II MORROW PRODUCTS ARE LIMITED IN DURATION TO THE DURATION OF THESE WRITTEN WARRANTIES. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

3. Exclusion of Remedies and Liability

IN NO EVENT SHALL II MORROW, ANY DISTRIBUTOR, OR THE SELLING DEALER BE LIABLE FOR ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES (INCLUDING LOSS OF PROFITS, LOSS OF TIME, OR INCONVENIENCE) WHETHER BASED ON CONTRACT, TORT, STRICT LIABILITY OR ANY

OTHER LEGAL THEORY EVEN IF II MORROW, SUCH DISTRIBUTOR, OR THE SELLING DEALER WAS ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Some states do not allow limitations of incidental or consequential damages, so the above limitation may not apply to you.

4. Limitation of Warranty

The foregoing warranty shall not apply to defects resulting from (a) improper or inadequate maintenance; (b) unauthorized modification of the products; (c) operation of the products outside of their environmental specifications; (d) improper installation; (e) neglect, misuse or abuse of the products; (f) integration with other products not covered by a II Morrow warranty; or (g) exposure to corrosive environments. This warranty shall not apply to any products not manufactured by II Morrow. No one is authorized to change or add to this warranty.

5. Technical Assistance

The warranty set forth above shall not be enlarged, diminished or affected by, and no obligation or liability shall arise from II Morrow, any authorized dealer or any other person rendering of technical advice, assistance or service in connection with the selection, purchase or use of any II Morrow products.

6. Installation

II Morrow makes no warranty with respect to any installation of II Morrow products by II Morrow, any authorized dealer or any other person.

7. Other Rights

This warranty gives you specific legal rights. You may also have other rights which vary from state to state.

8. Place of Repair or Replacement

In order to obtain the benefits of this warranty, the defective II Morrow products must be returned to II Morrow at its plant at 2345 Turner Road, S.E., Selem, Oregon 97302, II Morrow Service Center, or to an authorized dealer, with transportation charges prepaid. II Morrow shall pay for the return of the repaired or replaced II Morrow products to you by surface transportation.

Effective September 1988

Summary of Changes

Apollo 618 Pilot's Operating Handbook Revision 7

<u>Action</u>	<u>Section</u>	<u>Pages</u>
Replace	Title Page	Title Page
Replace	History of Revision	iv
Replace	Normal Procedures	Table of Contents
Replace	Normal Procedures	P-9 through P-14
Replace	Normal Procedures	N-31 through N-38
Replace	Index	1 through 4

II Morrow™ and Safe-Glide™ are trademarks of II Morrow Inc.

Apollo® is a registered trademark of II Morrow Inc.

Copyright © 1990 by II Morrow Inc. All rights reserved.

Printed in the U.S.A.

Factory

**II Morrow Inc.
Fleet Management Division
2345 Turner Road S.E.
Salem, Oregon 97302
U.S.A.**

**TWX 5105990110 II MORROW SAM
Phone (503) 581-8101 or 1-800-742-0077
FAX (503) 364-2138
In Canada 1-800-654-3415**

**East Coast Service Center
411 Telegraph Road, Suite 203
Odenton, MD 21113
Phone (301) 674-6050 or 1-800-831-6050**

**Southeast Coast Service Center
102 South 22nd St.
Tampa, FL 33605
Phone (813) 247-4912 or 1-800-622-2723**

USING THE APOLLO® 618 TRAINING MANUAL

The purpose of the Training Manual is to provide you with a comprehensive ground school course in the operation of the Apollo® 618 LORAN-C. This manual is designed to be used on the ground in conjunction with a working receiver.

IMPORTANT

Do NOT use this manual while airborne. Safe flying requires pilots to practice SEE and AVOID procedures mandated by FAA regulations. For this reason, before using the Apollo® 618 in the air, you should be quite familiar with its operation.

II MORROW INC

Apollo® 618

Tab Explanation

Reference Manual	White Tabs
Normal Procedures	
Loran-C Chains	
Troubleshooting	Orange Tab
Training Manual	Blue Tabs
Introduction	
Navigation	
Setup Mode	
Index	

Please begin by reading the Training Manual (blue tabs) so you will be able to take full advantage of the capability of the Apollo® 618. It's recommended you read at least through "Interpreting NAV Pages" in the Navigation section of the Training Manual before using the unit in the air for the first time. The reference manual is for pilots who are already familiar with the Apollo® 618.

We welcome your comments concerning this publication.

Technical Publications
II Morrow Inc.
2345 Turner Rd, SE
Salem, OR 97302

APOLLO® 618

Caution

The Apollo® 618 LORAN-C is a powerful navigation tool, but you should never rely solely on any one piece of navigation equipment. It's important to maintain a constant awareness of the navigation picture by using all appropriate resources.

Optional database updates are available on a 56 day cycle basis. Contact your II Morrow dealer for details.

Your new LORAN should be installed only by an FAA certified facility. Each installation is unique, and there are several variables and cautions that an installer must deal with for you to get the maximum benefit from your Apollo® 618.

Note To Apollo® 618R and 618C Users

The procedures for operating your LORAN are identical to the procedures for operating the Apollo® 618; however the arrangement of the annunciator lights is slightly different on the 618C.

HISTORY OF REVISIONS

Apollo® 618

Manual Revision	Software Version	
0	1.0	June 1988
1	1.0	December 1988
2	2.0	December 1988
3	2.0	July 1989
4	3.0	November 1989
5	3.1	July 1990
6	4.0	March 1991
7	4.2	November 1991

NORMAL PROCEDURES

TABLE OF CONTENTS

PRE-FLIGHT

START-UP	P-1
ENTERING NEW GRI OR MANUALLY SELECTING A TRIAD	P-2

WAYPOINT MANAGEMENT

DISPLAYING WAYPOINTS	P-3
COPYING WAYPOINTS	P-5
CREATING A WAYPOINT	P-5
CREATING A PHANTOM WAYPOINT	P-7
DELETING WAYPOINTS IN PILOT CREATED OR PILOT COPY DATABASE	P-8

FLIGHT PLANNING

NAVIGATING FROM PRESENT POSITION	P-9
USING FLIGHTPLAN PAGE	P-10
CHANGING THE "TO" WAYPOINT	P-11
DISPLAYING INFORMATION ON THE DESTINATION WAYPOINT	P-11
DELETING A SINGLE WAYPOINT	P-12
DELETING FLIGHT PLAN	P-12
INSERTING A WAYPOINT	P-12
REVERSING THE FLIGHTPLAN	P-13
USING NAV PLANNER	P-14
SEARCHING BY CITY NAME	P-15

AIRBORNE FUNCTIONS

EMERGENCY SEARCH WITH SAFE - GLIDE	P-17
RETURNING TO DEPARTURE POINT	P-20
NEAREST WAYPOINT SEARCH	P-21

ALTITUDE SELECT	P-22
ACKNOWLEDGING AN ALERT	P-22
DEFINING A NEW COURSE FROM PRESENT POSITION	P-23
USING VNAV	P-23
DISPLAYING ALTERNATE SOLUTION	P-23
EXTENDED RANGE	P-24
LINING-UP WITH A RUNWAY OR BEARING	P-24

CUSTOM FEATURES

ENTERING NEW AIRSPACE ALERT SETTINGS	P-25
ALTIMETER AND VNAV SETUP WITH THE II MORROW ENCODING ALTIMETER INSTALLED	P-27
VNAV SETUP WITHOUT II MORROW ENCODING ALTIMETER INSTALLED	P-29
EDITING NAV PAGES	P-30
RESTORING DEFAULT NAV PAGES	P-31
USING AUTO NAV SCROLL	P-32
MANUAL CROSS TRACK SENSITIVITY (XTD SENS)	P-34
DEFINING A PARALLEL COURSE (COURSE OFFSET)	P-34
SELECTING THE MAG VAR (MAGNETIC VARIATION) YEAR	P-35
MANUALLY SETTING MAG VAR (MAGNETIC VARIATION)	P-35
POSITION CALIBRATION	P-37

NORMAL PROCEDURES

APOLLO® 618

Note

IF YOU'RE A NEW USER, BEGIN BY READING THE TRAINING MANUAL (BLUE TABS). The Normal Procedures section is intended to serve as a reference for pilots who are already familiar with the Apollo® 618. They are NOT intended to be used on a regular basis in a manner similar to aircraft checklists. Safe flying requires pilots to practice SEE and AVOID procedures mandated by FAA regulations. For this reason, before using the Apollo® 618 in the air, you should be quite familiar with its operation.

PREFLIGHT

START-UP

1. Power - ON
2. GRI - CHECK

Note

To enter a new GRI or manually select a triad, use ENTERING NEW GRI OR MANUALLY SELECTING A TRIAD procedures, page P-2.

3. MODE - SETUP
4. LARGE KNOB - SCROLL to display Setup Pages. Enter new settings as required.

ENTERING NEW GRI OR MANUALLY SELECTING A TRIAD**1. MODE - SETUP**

When entering SETUP MODE, the first display is the GRI/TRIAD page. If the unit is already in the SETUP MODE and not displaying the GRI page, TURN LARGE KNOB to display the GRI page.

2. SEL - PRESS**3. SMALL KNOB - TURN** to choose desired GRI.**4. ENT - PRESS**

Automatic triad selection is active whenever GRI is changed.

If Manual Triad Selection is Desired

To enter Manual Triad Selection, complete steps 5-8.

Note

Anytime the power is turned on Auto Triad Selection is automatically activated.

5. SMALL KNOB - TURN to choose "manual" triad selection**6. ENT - PRESS****7. SMALL KNOB - TURN** to display desired secondaries in large letters.**8. ENT - PRESS***Note*

To reactivate Auto Triad Selection, repeat the above procedure selecting "Auto" in Step 5. Steps 7 & 8 do not apply to Auto Triad Selection.

WAYPOINT MANAGEMENT

DISPLAYING WAYPOINTS

Note

Anytime you are displaying a waypoint in WPT mode, you may return to the beginning of WPT Mode by pressing MODE once.

From NORTH AMERICA DATABASE

1. **MODE - WPT**
2. **SMALL KNOB or LARGE KNOB - TURN** to display NORTH AMERICA DATABASE.
3. **ENT - PRESS**
4. **SMALL KNOB - TURN** to display APT ID, INTERSEC, VOR, or NDB. (To search by city, use **SEARCHING BY CITY NAME** procedures, page P-15).
5. **ENT - PRESS**
6. **SMALL KNOB - SCROLL** to display desired ID character.
7. **ENT - PRESS**
8. **Steps 6 & 7 - REPEAT** to enter remaining ID characters. If ID is shorter than the number of available spaces, enter "_" as the final character. The desired waypoint will be displayed.

From PILOT CREATED, PILOT COPY, and SEABASE/HELIPORT Databases

1. **MODE - WPT**
2. **SMALL KNOB** or **LARGE KNOB - TURN** to display desired database.
3. **ENT - PRESS**
4. **LARGE KNOB - SCROLL** to display desired waypoint.

or

If using LOOK FOR feature:

4. **SEL - PRESS**
5. **SMALL KNOB - SCROLL** to display desired ID character.
6. **ENT - PRESS**
7. **Steps 5 & 6 - REPEAT** to enter remaining ID characters. If ID is shorter than the number of available spaces, enter "_" as the final character. The desired waypoint is displayed.

COPYING WAYPOINTS

Note

It's recommended all waypoints planned for use be copied into the PILOT COPY DATABASE. Entries to the NAV Flightplan page can be made only from the PILOT COPY DATABASE.

1. With desired waypoint displayed, ENT - PRESS

The message SAVED TO COPY DATABASE will appear momentarily. You may copy any displayed waypoint from any database into the PILOT COPY DATABASE by pressing ENT. To enter the beginning of WPT mode, press MODE once.

CREATING A WAYPOINT

Note

To create a PHANTOM WAYPOINT, use the CREATING A PHANTOM WAYPOINT procedure on page P-7.

1. MODE - WPT
2. SMALL KNOB or LARGE KNOB - TURN to display PILOT CREATED DATABASE.
3. ENT - PRESS
4. LARGE KNOB - TURN one click counter-clockwise to display ENT TO CREATE NEW WPT page.
5. ENT - PRESS
6. SEL - PRESS

Your present position is entered and assigned a numerical identifier. The first number in the identifier flashes. Any portion of the waypoint may be edited as desired, page P-6.

To Edit a CREATED Waypoint

1. **Desired waypoint - DISPLAY** (See **DISPLAYING WAYPOINTS**, page P-3)
2. **SEL - PRESS TWICE**
3. **ENT - PRESS**
4. **SMALL KNOB - SCROLL** to display first waypoint ID character.
5. **ENT - PRESS**
6. **Steps 4 & 5 - REPEAT** to edit remaining waypoint ID characters, the latitude, and the longitude.

Note

Once the desired editing is accomplished, it is not necessary to press ENT repeatedly to fix the remaining values. For example, if you wanted to edit only an identifier, but not the associated coordinates, you could press MODE or scroll LARGE KNOB immediately after editing the identifier.

CREATING A PHANTOM WAYPOINT

A phantom waypoint is referenced as a bearing and distance from an existing waypoint.

Note

Any new PILOT CREATED waypoint may be created as a PHANTOM WAYPOINT.

1. **MODE - WPT**
2. **SMALL KNOB or LARGE KNOB - TURN** to display PILOT CREATED DATABASE.
3. **ENT - PRESS**
4. **LARGE KNOB - TURN** one click counter-clockwise to display ENT TO CREATE NEW WPT.
5. **ENT - PRESS** twice.
6. **SMALL KNOB - SCROLL** to display reference waypoint.

Note

The reference waypoint must be copied into the PILOT COPY DATABASE.

7. **ENT - PRESS**
8. **SMALL KNOB - SCROLL** to display first digit in reference radial.
9. **ENT - PRESS**
10. **Steps 8 & 9 - REPEAT** to enter remaining reference radial digits and DST digits.

The ID and LAT/LONG of the PHANTOM WAYPOINT will be displayed, and you may edit the display by following the procedure, beginning with Step 6, in the "CREATING A WAYPOINT--To Edit a CREATED Waypoint" procedure, page P-6.

DELETING WAYPOINTS IN PILOT CREATED OR PILOT COPY DATABASE

1. **Waypoint to be deleted** - DISPLAY in WPT mode (see DISPLAYING WAYPOINTS, page P-3).
2. **SEL - PRESS**
ENT TO DEL WPT will be displayed.
5. **ENT - PRESS**

Note

Deleting a waypoint in the PILOT CREATED DATABASE automatically deletes it from the PILOT COPY DATABASE; however, deleting a CREATED waypoint from the PILOT COPY DATABASE does NOT delete it from the PILOT CREATED DATABASE.

FLIGHT PLANNING

NAVIGATING FROM PRESENT POSITION

1. FRM - PRESS TWICE within one second.

Note

If the WARN light is still on, the unit cannot yet calculate your present position; however, if the unit is in the same location as it was when it was last turned off, the displayed present position will be accurate provided the WARN light was off when the unit was turned off. You do not have to wait for the WARN light to go out if your correct position is displayed.

2. "To" waypoint - DISPLAY in WPT mode (see DISPLAYING WAYPOINTS, page P-3).
3. TO - PRESS
4. WARN light - VERIFY OFF before using LORAN navigation.

USING FLIGHTPLAN PAGE

The flightplan page allows the pilot to enter a flightplan with up to 20 waypoints. For more information see NAVIGATION section: "Using FlightplanPage".

Note

Waypoints to be used must be in the PILOT COPY DATABASE. Present position is always in the PILOT COPY DATABASE and is updated each time the FRM button is pressed twice within one second.

If Navigating From Present Position

1. WARN light - VERIFY OFF
2. FRM - PRESS TWICE within one second.
The unit displays the Flightplan page with new Present Position (PPFR) as the departure waypoint.
3. SEL - PRESS
4. ENT - PRESS
5. SMALL KNOB - SCROLL to choose a new "To" waypoint.
6. ENT - PRESS TWICE

If Navigating From a Database Waypoint

1. MODE - NAV
2. LARGE KNOB - TURN to display the Flightplan page.
3. SMALL KNOB - TURN to display the desired Flightplan waypoint (1-20), with the leg number for the FROM waypoint displayed on the top line.
4. SEL - PRESS
5. SMALL KNOB - SCROLL to display the desired waypoint.

6. ENT - PRESS
7. SMALL KNOB - SCROLL to choose the next waypoint in the flightplan.
8. ENT - PRESS
9. Repeat - steps 5 through 8 to complete the flightplan.
10. WARN light - VERIFY OFF before using LORAN navigation.

Changing the "To" Waypoint (Moving the arrow)

1. Flightplan page - DISPLAY in NAV mode.
2. SMALL KNOB - SCROLL to position the desired "To" waypoint at the top of the display.
3. SEL - PRESS. The waypoint identifier flashes.
4. TO - PRESS to change the selected "To" waypoint.

Displaying Information and Deleting Waypoints from Flightplan Page

Note

A convenient method of displaying information on the "To" waypoint is to press TO while displaying any page in NAV mode.

Displaying Information from Flightplan Page

1. MODE - NAV
2. LARGE KNOB - TURN to display Flightplan page.
3. SMALL KNOB - SCROLL to position the desired waypoint at the top of the display.
4. SEL - PRESS
The waypoint at the top of the display flashes.

5. SEL - PRESS
6. SMALL KNOB - TURN to view information.
7. SEL - PRESS (once or twice as necessary) to return to Flightplan page.
8. LARGE KNOB - TURN to the desired NAV page.

To Delete A Single Flightplan Waypoint

1. Flightplan page - DISPLAY in NAV mode.
2. SMALL KNOB - SCROLL to position the desired waypoint at the top of the display.
3. SEL - PRESS. The waypoint at the top of the display flashes.
4. SMALL KNOB - SCROLL to "- - -", which is located at both ends of the database.
5. ENT - PRESS to delete waypoint.
6. LARGE KNOB - TURN to the desired NAV page.

To Delete the Active Flightplan

1. Flight Plan Page - Display in NAV mode.
2. SMALL KNOB - TURN counter clockwise to "ENT TO DELETE FLT PLAN".
3. ENT - PRESS to delete active flightplan.

Inserting a Waypoint

1. Flightplan Page - DISPLAY in NAV mode.
2. SMALL KNOB - SCROLL so the waypoint that is to follow the new waypoint appears at the top of the display.

3. SEL - PRESS. The waypoint identifier flashes.
4. SMALL KNOB - SCROLL to display "insrt".
5. ENT - PRESS. The display flashes "- - - -".
6. SMALL KNOB - SCROLL to the waypoint to be inserted.
7. ENT - PRESS to insert the new waypoint into the flightplan.
8. LARGE KNOB - TURN to the desired NAV page.

To Reverse the Active Flightplan

1. Flight Plan Page - Display in NAV mode.
2. SMALL KNOB - TURN clockwise to "ENT TO REVERSE FLT PLAN".
3. ENT - PRESS to reverse active flightplan.

USING NAV PLANNER

The purpose of NAV PLANNER is to display bearing and distance from a waypoint other than your present position. Bearing and distance from your present position is shown on the bottom line of the first page of each waypoint display.

Note

To use NAV PLANNER, the waypoints you are interested in MUST be in the PILOT COPY DATABASE.

1. **MODE - WPT**
2. **SMALL KNOB** or **LARGE KNOB - TURN** to display PILOT COPY DATABASE.
3. **ENT - PRESS**
4. **LARGE KNOB - SCROLL** to display ENT FOR NAV PLANNER (located at both ends of the PILOT COPY DATABASE).
5. **ENT - PRESS**
6. **SMALL KNOB - SCROLL** to display "Fr" waypoint.
7. **ENT - PRESS**
8. **SMALL KNOB - SCROLL** to display "To" waypoint.
The bearing and distance is displayed on the bottom line.

Displaying Information When Using NAV PLANNER

1. **Desired waypoint - DISPLAY** flashing identifier using NAV PLANNER feature.
2. **SEL - PRESS**
3. **SMALL KNOB - TURN** to display information.
4. **SEL - PRESS** twice to return to the NAV PLANNER page.
If the first INFO page is displayed, press SEL only once.

SEARCHING BY CITY NAME*Note*

The NORTH AMERICA DATABASE is sorted alphanumerically according to identifier, not city.

1. **MODE - WPT**
2. **SMALL KNOB** or **LARGE KNOB - TURN** to display **NORTH AMERICA DATABASE**.
3. **ENT - PRESS**
4. **SMALL KNOB - TURN** to display **CITY**.
5. **ENT - PRESS**

Note

To restore the name of the last city you searched for, press ENT again. With the name restored, pressing ENT once more initiates the search. To edit the restored name before searching, press SEL as necessary to cause successive characters to flash.

6. **SMALL KNOB - SCROLL** to display the first letter in the city name.
7. **ENT - PRESS**
8. **Steps 6 & 7 - REPEAT** to enter remaining letters. If you enter less than 8 letters, enter " _ " as the final character. If the name is more than eight letters long, enter up to eight letters. If the waypoint found is not the one desired, proceed with step 9.
9. **SEL - PRESS**
CONTINUE LOOKING FORWARD will be displayed.

Note

You will normally search the database FORWARD according to alphanumeric order; however, if you wish to display a waypoint you previously elected to pass-up, you may select BACKWARD with the SMALL KNOB after completing Step 9.

10. ENT - PRESS

11. Steps 9 & 10 - REPEAT until desired waypoint is displayed.

AIRBORNE FUNCTIONS

EMERGENCY SEARCH WITH SAFE - GLIDE™

IMPORTANT

EMERGENCY SEARCH WITH SAFE - GLIDE™ may be a valuable resource in an actual emergency; however, the information it provides should be considered advisory. The course of action a pilot chooses in an emergency should be based on the existing conditions, including such factors as terrain, altitude, fuel supply, the nature of the emergency, and weather. EMERGENCY SEARCH DOES NOT "CONSIDER" TERRAIN. The unit has no way of "knowing" if a mountain or other obstruction lies between you and an airport. Also, the unit does not consider wind.

To activate the SAFE - GLIDE™ feature, you must program the engine-out glide rate for your aircraft in SETUP MODE. See detailed instructions in the setup mode section.

SAFE - GLIDE™ is incorporated in the EMERGENCY SEARCH Feature. When EMERGENCY SEARCH is activated, the airports are ordered according to the altitude required to reach the airport. For example, an airport with an elevation of 2,500 ft MSL may be the closest to your location; however, an airport with an elevation of 500 ft MSL, while being somewhat further, may require less altitude to reach it. In this case, SAFE - GLIDE™ prioritizes the airports so that the airport at 500 ft MSL displays first.

Without the II Morrow Encoding Altimeter Input:

1. **APR/ENR & ENT - PRESS** simultaneously.

After searching for the nearest airports, the altitude required to glide to the first airport is displayed on the top line. The length of the longest runway is displayed on the middle line, and the bearing and distance is displayed on the bottom line. Press SEL to view airport identifier, state, and city name.

To view information on the displayed airport turn the small knob. If the runway length at the first airport is insufficient or the airport is otherwise undesirable, turn the LARGE KNOB cw to display the next airport. If not on the first information page, pressing SEL will display the first information page.

IMPORTANT

Your glidepath is based on the information you defined in SETUP Mode. SAFE - GLIDE™ DOES NOT CONSIDER WIND; however, as you glide toward the airport the ALTITUDE REQUIRED display will be continually updated so you can monitor your progress. You should periodically check the required altitude as you proceed, especially if you have a headwind component. During your approach, if the aircraft's altitude becomes less than the required altitude, the airport is out of range; however, on short final approach the required altitude may be above the aircraft's altitude because SAFE-GLIDE™ brings the aircraft to the Airport Reference Point, not to the runway threshold. See diagram on page N-61.

If you want to exit Emergency Search without defining an emergency airport as your To waypoint, press APR/ENR and ENT simultaneously. (If you do not wish to exit Emergency Search, continue with step 2).

2. TO - PRESS

The unit switches to NAV mode and the emergency airport is the To waypoint. The SAFE - GLIDE™ information periodically displays over the NAV pages.

To Cancel The SAFE - GLIDE™ FEATURE

1. MODE - PRESS

ENT TO DISABLE SAFGLIDE is displayed. This is to allow you to disable SAFE - GLIDE™ if you are not in an engine-out emergency. (If you do not wish to exit SAFE - GLIDE™, Press MODE four times to re-enter NAV Mode).

NOTE

Changing the Flightplan will also disable SAFE - GLIDE™

2. ENT - PRESS

SAFE - GLIDE™ displays are discontinued.

With II Morrow Encoding Altimeter Input

1. APR/ENR & ENT - PRESS simultaneously.

After searching for the nearest airports, the length of the longest runway is displayed on the middle line, and the bearing and distance is displayed on the bottom line. The top line displays how far (preceded by a "+" sign) the aircraft could glide after reaching the airport. This line alternates with the GLIDE OK message. If the airport is out of range, the distance display (preceded by a "-" sign) will alternate with the TOO FAR message.

IMPORTANT

Your glidepath is based on the information you defined in SETUP Mode. SAFE-GLIDE™ DOES NOT CONSIDER WIND; however as you glide toward the airport the GLIDE OK\TOO FAR display will be continuously updated so you can monitor your progress. During your approach, if the aircraft's altitude becomes less than the required altitude, the airport is out of range, and TOO FAR appears; however, on short final approach TOO FAR may appear because the required altitude is above the aircraft's altitude. This is because SAFE-GLIDE™ brings the aircraft to the Airport Reference Point, not to the runway threshold. See diagram on page N-64.

If you want to exit Emergency Search without defining an emergency airport as your To waypoint, press APR/ENR and ENT simultaneously.

2. TO - PRESS

The unit switches to NAV mode and the emergency airport is the To waypoint. The SAFE - GLIDE™ information periodically appears over the NAV pages.

To Cancel The SAFE - GLIDE™ FEATURE

1. MODE - PRESS

ENT TO DISABLE SAFGLIDE appears. (If you do not wish to exit SAFE - GLIDE™, press MODE four times to re-enter NAV Mode).

NOTE

Changing the Flightplan will also disable SAFE - GLIDE™.

2. **ENT - PRESS**
SAFE - GLIDE™ displays are discontinued.

RETURNING TO DEPARTURE POINT

1. **MODE - NAV**
2. **LARGE KNOB - SCROLL** to display RETURN TO page.
The bearing and distance back to the departure waypoint is displayed.

NEAREST WAYPOINT SEARCH*Note*

If you are looking for the nearest airports in the NORTH AMERICA DATABASE, using EMERGENCY SEARCH is easier than using NEAREST WAYPOINT SEARCH; however, EMERGENCY SEARCH only locates airports. NEAREST WAYPOINT SEARCH locates the nearest waypoints, including NAVAIDS, INTERSECTIONS, and PILOT CREATED WAYPOINTS.

1. **MODE - WPT**
2. **SMALL KNOB or LARGE KNOB - TURN** to display **NEAREST WAYPOINT DATABASE.**
3. **ENT - PRESS**
4. **SMALL KNOB - TURN** to display **APT ID, INTERSEC, VOR, NDB, or CREATED.**
5. **ENT - PRESS**

The nearest waypoint is displayed. Turning the **LARGE KNOB** clockwise displays the 25 nearest waypoints in succession, with the nearest first. If you wish to navigate to one of these waypoints, display the waypoint and press **TO**.

Note

If the WARN light is on, the unit cannot accurately determine your position. NEAREST WAYPOINT uses the last known position as your present position until the WARN light goes out.

ALTITUDE SELECT

This feature alerts you as your aircraft enters the selected altitude range or if your aircraft strays above or below the selected altitude by a user-specified value. The unit must be connected to a II Morrow encoding altimeter and the altimeter setting must be set. If your unit is connected to a buzzer, an audible alert may be selected.

After setting-up Altitude Select (see SETUP MODE), as you fly into the selected altitude range while in NAV or AIRSP Mode, ALTITUDE flashes on the bottom line of the display and the buzzer (if connected and selected) sounds four double beeps. When leaving the selected altitude range, the alert continues until you acknowledge it by pressing ENT or return within the altitude range.

NOTE

Single beeps indicate the WARN light is on. Double beeps indicate an Altitude Alert.

ACKNOWLEDGING AN ALERT:

1. **ENT - PRESS**
The alert ceases.

Selecting a New Altitude in NAV Mode:

1. **MODE - NAV**
2. **LARGE KNOB - TURN** to display any page except the Present Position or Flightplan page.
3. **SEL - PRESS**
The ALT - SEL page appears and the current selected altitude flashes.
4. **SMALL KNOB - TURN** to select the new altitude.
5. **ENT - PRESS**
The NAV page reappears. ENT must be pressed, or the selected altitude will not be changed.

DEFINING A NEW COURSE FROM PRESENT POSITION

1. **WARN** light - **VERIFY** off.
2. **FRM** - **PRESS TWICE** within one second.
The unit automatically switches to the NAV mode Flightplan page. Present Position is now the new departure waypoint.

USING VNAV*Note*

If a II Morrow encoding altimeter is installed, the ARIV light flashes for a few seconds when the aircraft is approximately 2 minutes from the Top of Decent point.

1. **Aircraft Altitude** - Adjust to match the VNAV altitude.

DISPLAYING ALTERNATE SOLUTION

The unit will calculate two possible positions for the aircraft, i.e. an alternate solution. This procedure describes how to change between solutions. See "How Loran-C works" on page N-81 for further discussion of Alternate Solutions.

1. **MODE** - **NAV**
2. **LARGE KNOB** - **TURN** to display the Present Position page.
3. **SEL** - **PRESS**
4. **ENT** - **PRESS** twice.

EXTENDED RANGE*Note*

Normally EXTENDED RANGE will be set to "Off". If you plan to use this feature, be sure to turn it on before leaving the prime coverage area. When the power is turned on, or the GRI is changed, EXTENDED RANGE is automatically set to "Off".

1. **MODE - SETUP**
2. **LARGE KNOB - TURN** to display EXTENDED RANGE page.
3. **SEL - PRESS**
4. **SMALL KNOB - TURN** to display "On".
5. **ENT - PRESS**
To turn EXTENDED RANGE off, repeat the above procedure selecting "Off" in step 4.

LINING-UP WITH A RUNWAY OR BEARING

1. **MODE - NAV**
2. **LARGE KNOB - TURN** to display BRG.
3. Turn aircraft to a heading that intercepts the desired course.
4. When the BRG display approaches the desired course, turn the aircraft to the heading that matches the desired course.
5. **FRM - PRESS** twice.
A straight-in approach is defined.

CUSTOM FEATURES

ENTERING NEW AIRSPACE ALERT SETTINGS

1. **MODE - SETUP**
2. **LARGE KNOB - TURN** to display the ENT FOR AIRSPACE SETUP page (3 clicks clockwise from GRI page).
3. **ENT - PRESS**

To Change The AIRSPACE ALERT "On or Off" Setting

4. **SEL - PRESS**
5. **SMALL KNOB - TURN** to display "on or off" setting.
6. **ENT - PRESS**

To Change The DISTANCE BUFFER Value

7. **SMALL KNOB - TURN** to display DISTANCE BUFFER page.
8. **SEL - PRESS**
9. **SMALL KNOB - TURN** to change DISTANCE BUFFER value (nautical miles).
10. **ENT - PRESS**

To Change The AIRSPACE ALTITUDE BUFFER Value

Note

The ALTITUDE BUFFER page is not displayed if the II Morrow encoding altimeter is not installed or not functioning reliably.

1. **SMALL KNOB - TURN** to display **ALTTITUDE BUFFER** page.
2. **SEL - PRESS**
3. **SMALL KNOB - TURN** to change **ALTTITUDE BUFFER** value.
4. **ENT - PRESS**

Note

After changing a value with the SMALL KNOB for AIRSPACE ALERT, DISTANCE BUFFER, or ALTTITUDE BUFFER, pressing SEL instead of ENT causes the unit to ignore an individual new setting.

**ALTIMETER AND VNAV SETUP WITH THE II MORROW
ENCODING ALTIMETER INSTALLED***Note*

VNAV and ALTIMETER Setup is disabled when you are currently editing NAV pages.

1. **MODE - NAV**
2. **LARGE KNOB - TURN** to display a page with **A^L,V^N**, or both.

Note

Your altitude will not display until the altimeter setting is set. Since you may edit (customize) the NAV pages, it is possible to have your Alt (Altimeter) and VNV (Vertical Navigation) read-outs on separate pages, or on the same page in the reverse order from the default (factory) page. The default page shows (from top to bottom) DST/ALT/VNV. THE REMAINDER OF THESE PROCEDURES ARE BASED ON THE DEFAULT PAGE. If you have edited this page so that ALT and VNV are on separate pages, you need to select the appropriate page to set up each function.

3. **SEL - PRESS**
Press SEL twice if the altimeter has already been set. ENT TO SET ALTIMETR is displayed.
4. **ENT - PRESS**
5. **SMALL KNOB - TURN** to change current altimeter setting. (barometric pressure measured in inches of mercury).
6. **ENT - PRESS**
The NAV page is displayed again.
7. **SEL - PRESS 3 Times**
ENT FOR VNAV SETUP is displayed.
8. **ENT - PRESS**
The GSA value (Glide Slope Angle in tenths of a degree) flashes.
9. **SMALL KNOB - TURN** to change desired GSA.

10. ENT - PRESS

The EL (elevation) setting flashes.

- 11. SMALL KNOB - TURN** to change the first three digits of the desired target elevation (EL). These are in 100 foot increments.

Note

The current EL display is automatically set to the airport elevation of the "To" waypoint, provided the "To" waypoint is an airport from the NORTH AMERICA DATABASE.

12. ENT - PRESS

- 13. Steps 11 & 12 - REPEAT** to enter the remaining two EL digits. These are for 1 foot increments.

**VNAV SETUP WITHOUT II MORROW ENCODING ALTIMETER
INSTALLED**

1. **MODE - NAV**
2. **LARGE KNOB - TURN** to display a page with VNV.
3. **SEL - PRESS** twice
4. **ENT - PRESS**
The GSA setting flashes.
5. **SMALL KNOB - TURN** to display desired GSA.
6. **ENT - PRESS**
The EL setting flashes.
7. **SMALL KNOB - TURN** to display the first three digits of the desired target elevation(EL). These are 100 foot adjustments.
8. **ENT - PRESS**
Steps 6 & 7 - **REPEAT** to enter remaining two EL digits. These are 1 foot adjustments.

EDITING NAV PAGES*Note*

The Flightplan page, RETURN TO page, and Present Position page cannot be altered.

1. **MODE - SETUP**
2. **LARGE KNOB - TURN** two clicks clockwise after entering SETUP mode to display ENT FOR NAV MODE SETUP.
3. **ENT - PRESS**
EDIT NAV PAGES Off is displayed.
4. **SEL - PRESS**
5. **SMALL KNOB - TURN** to display "On"
6. **ENT - PRESS**
The unit automatically switches to NAV mode.
7. **LARGE KNOB - TURN** to display NAV page to be edited.
8. **SEL - PRESS** as necessary to choose the line to be edited. The line will flash.
9. **SMALL KNOB - TURN** to display the desired NAV information.
10. **ENT - PRESS**
The next line flashes, unless the bottom line is altered.
11. **Steps 9 & 10 - REPEAT** as necessary to alter the remaining lines on the page. To edit another NAV page, turn the LARGE KNOB to the desired page and repeat steps 8-11.
12. **MODE - PRESS** to turn NAV PAGE editing "off".

Note

Once you exit NAV mode, EDIT NAV PAGES is automatically set to "Off."

RESTORING DEFAULT NAV PAGES

1. **MODE - SETUP**
2. **LARGE KNOB - TURN** two clicks clockwise after entering SETUP mode to display ENT FOR NAV MODE SETUP.
3. **ENT - PRESS**
EDIT NAV PAGES "Off" is displayed.
4. **SEL - PRESS**
5. **SMALL KNOB - TURN** to display "Default".
6. **ENT - PRESS**
The default NAV pages are restored

USING AUTO NAV SCROLL

1. **MODE - SETUP**
2. **LARGE KNOB - TURN** clockwise two clicks to display ENT FOR NAV MODE SETUP.
3. **ENT - PRESS**
4. **SMALL KNOB - TURN ONE** click clockwise to display AUTO NAV SCROLL "Off/On" page.
5. **SEL - PRESS**
6. **SMALL KNOB - TURN** to display "On".
7. **ENT - PRESS**

Note

If you do not wish to make any changes in the AUTO NAV SCROLL setup, press MODE to leave SETUP mode. AUTO NAV SCROLL is activated/deactivated by pressing ENT in NAV mode.

8. **SMALL KNOB - TURN** to change the number of NAV pages to scroll.
9. **ENT - PRESS**
10. **SMALL KNOB - TURN** to choose the first page you wish to include in the scroll sequence.
11. **ENT - PRESS**
12. **Steps 10 & 11 - REPEAT** as necessary to enter the remaining pages you want to include in the AUTO NAV SCROLL sequence.
13. **SMALL KNOB - TURN** to change the number of seconds each page is to be displayed.
14. **ENT - PRESS**

To Pause AUTO NAV SCROLL On The Displayed Page

1. Any button or knob (except MODE) - PRESS or TURN

To Reactivate AUTO NAV SCROLL After Pausing

1. ENT - PRESS

To Turn Off AUTO NAV SCROLL

Repeat the USING AUTO NAV SCROLL procedure (page P-32), selecting "off" with the SMALL KNOB in step 6.

MANUAL CROSS TRACK SENSITIVITY (XTD SENS)**NOTE**

The sensitivity of the external CDI and internal CDI are independent of each other. XTD SENS only affects the internal CDI.

1. **MODE - SETUP**
2. **LARGE KNOB - TURN** to display XTD SENS page.
3. **SEL - PRESS**
4. **SMALL KNOB - TURN** to display "Manual".
5. **ENT - PRESS**
6. **SMALL KNOB - TURN** to select desired sensitivity. (Hundredths of a nautical mile per dot).
7. **ENT - PRESS**

DEFINING A PARALLEL COURSE (COURSE OFFSET)

1. **MODE - SETUP**
2. **LARGE KNOB - TURN** to display COURSE OFFSET page.
3. **SEL - PRESS**
4. **SMALL KNOB - TURN** to change desired OFFSET distance. Turn the **SMALL KNOB** clockwise for a right of course offset, counterclockwise for a left of course offset. Offset distances are in tenth of a nautical mile increments.
5. **ENT - PRESS**
The OFST light is on, indicating a course offset has been entered. To remove the offset, set the offset to zero.

SELECTING THE MAG VAR (MAGNETIC VARIATION) YEAR

1. **MODE - SETUP**
2. **LARGE KNOB - TURN** to display the ENT FOR MAGVAR SETUP page.
3. **ENT - PRESS**
4. **SMALL KNOB - TURN** to display MAG YEAR page.
5. **SEL - PRESS**
6. **SMALL KNOB - TURN** to choose desired year.
7. **ENT - PRESS**

MANUALLY SETTING MAG VAR (MAGNETIC VARIATION)*Note*

MAG VAR should normally be set to "Auto".

1. **MODE - SETUP**
2. **LARGE KNOB - TURN** to display the ENT FOR MAGVAR SETUP page.
3. **ENT - PRESS**
4. **SEL - PRESS**
5. **SMALL KNOB - TURN** to display "Manual".
6. **ENT - PRESS**
7. **SMALL KNOB - TURN** to choose desired variation in whole degrees East or West.
8. **ENT - PRESS**

NOTE

To set MAG VAR back to "Auto", repeat the above procedure, selecting "Auto" in step 5.

POSITION CALIBRATION

Due to local conditions, the NAV Present Position display may be slightly in error. These errors are generally so small they are insignificant for normal operations. However, when highly precise navigation is called for, calibration factors (also called ASFs--Additional Secondary Phase Factors) may be entered.

1. **MODE - NAV**
2. **LARGE KNOB - TURN** to display the Present Position.
3. **SEL - PRESS**
4. **SMALL KNOB - TURN** to display LAT CAL? (Latitude Calibration) or LON CAL? (Longitude Calibration), as required.
5. **ENT - PRESS**
6. **SMALL KNOB - TURN** (clockwise for +, counterclockwise for -) to adjust the known latitude or longitude.
7. **ENT - PRESS**
The ASF light is on to remind the pilot calibration factors are in use. To remove calibration factors, repeat the above procedure, selecting a calibration factor of "0" in step 6.

NOTES:


LORAN-C CHAINS

Apollo 618


Continental United States Composite	L-1
Central Pacific 4990	L-2
Canadian East Coast 5930	L-3
Commando Lion (Korea) 5970	L-4
Canadian West Coast 5990	L-5
Saudi Arabia (South) 7170	L-6
Labrador Sea 7930	L-7
Eastern USSR 7950	L-8
Gulf of Alaska 7960	L-9
Norwegian Sea 7970	L-10
Southeast U.S. 7980	L-11
Mediterranean Sea 7990	L-12
Western USSR 8000	L-13
Western Europe (France) 8940	L-14
Great Lakes 8970	L-15
Saudi Arabia Composite	L-16
Northeast Saudi Arabia 8990	L-17
Northwest Saudi Arabia 8991	L-18
West Coast U.S. 9940	L-19
Northeast U.S. 9960	L-20
Northwest Pacific 9970	L-21
Iceland 9980	L-22
North Pacific 9990	L-23

CONTINENTAL UNITED STATES COMPOSITE


Composite U.S. VFR Coverage




5990




7980




8970




9940



9960




CENTRAL PACIFIC - GRI 4990



CENTRAL PACIFIC LORAN-C CHAIN - GRI 4990 (old rate 53)

STATION	FUNCTION	COORDINATES	CODING DELAY/BASE- LINE LENGTH	RADIATED POWER(KW)	REMARKS
Johnston Is., HI	Master	16 44 44.0 N 169 30 31.0 W		275	
Upolu Pt., HI	Xray	20 34 49.2 N 155 53 09.7 W	11000/ 4972.23	275	Time service monitor.
Kure Is., HI	Yankee	28 23 41.8 N 178 17 30.2 W	20000/ 5253.17	275	
Laysan Is. Johnston Is., HI	Monitor	16 43 19.5 N 169 32 36.8 W			
Laysan Is. Honolulu, HI	Control				Control's X and Y.


CANADIAN EAST COAST - GRI 5930



CANADIAN EAST COAST LORAN-C CHAIN - GRI 5930

STATION	FUNCTION	COORDINATES	COGING DELAY/BASE- LINE LENGTH	RADIATED POWER(KW)	REMARKS
Caribou, NE	Mester	46°40'27.2"W 67°55'37.7"W		350	Dual-Rated to North- east U.S. Chain.
Nantucket, MA	Arky	41°25'11.9"W 69°58'39.1"W	11000/ 2133.08	275	Dual-Rated to North- east U.S. Chain.
Cape Race, NFLD	Yankee	46°46'32.2"W 53°10'28.2"W	25000/ 3755.02	1500	Dual-Rated to Labrador Sea Chain.
Fox Harbour, Labrador	Zulu	52°22'35.2"W 55°42'28.4"W	30000/ 3594.58	800	Dual-Rated to Lab- rador Sea Chain.
Cape Elizabeth, NE	Monitor	43°33'54.0"W 70°11'58.3"W			Unmanned Receiver Site.
Montague, P.E.I.	Monitor	46°11'40.0"W 62°39'37.0"W			Unmanned Receiver Site.
St. Anthony, NFLD	Monitor/ Control	51°21'32.0"W 55°37'28.0"W			Exercises Operational Control of the Chain.


COMMANDO LION - GRI 5970



COMMANDO LION LORAN-C CHAIN - GRI 5970

STATION	FUNCTION	COORDINATES	CODING DELAY/BASE- LINE LENGTH	RADIATED POWER (KW)	REMARKS
Pohang, Korea	Master	36°11'05.8" N 129°20'27.3" E		35	
Hokkaido, Japan	Whisky	42°44'37.1" N 143°43'09.2" E	11000 4783.69	1000	Dual rated to Northwest Pacific Chain
Kwang Ju, Korea	Xray	35°02'23.9" N 126°32'26.7" E	31000 947.02	35	
Otsu, Japan	Zulu	25°36'25.0" N 128°08'56.4" E	42000 3565.56	1000	Dual rated to Northwest Pacific Chain


CANADIAN WEST COAST - GRI 5990



CANADIAN WEST COAST LORAN-C CHAIN - GRI 5990 (old rate SHI)


STATION	FUNCTION	COORDINATES	CODING DELAY/BASE- LINE LENGTH	RADIATED POWER(KW)	REMARKS
Williams Lake, BC, Canada	Master	51 57 58.8 N 122 22 02.2 W		400	Control for X and Y. Two pulse comms installed.
Shoal Cove, AK	Xray	55 26 20.9 N 131 15 19.7 W	11000/ 2343.60	540	Two pulse comms in- stalled. Dual-rated to Gulf of Alaska Chain.
George, WA	Yankee	47 03 48.0 N 119 44 39.5 W	27000/ 1927.36	1600	Two pulse comms in- stalled. Dual-rated to U.S. West Coast Chain.
Point Hardy, BC, Canada	Zulu	50 36 29.7 N 127 21 29.4 W	41000/ 1266.63	400	Scheduled to be operational June 1980
Alert Bay, Canada	Monitor	50 35 01 N 126 54 39 W			Unmanned receiver site.
Whidbey Is., WA	Monitor	48 17 39 N 124 33 55 W			Unmanned receiver site.

SAUDI ARABIA (SOUTH) - GRI 7170



STATION	FUNCTION	COORDINATES	CODING DELAY/BASE- LINE LENGTH	RADIATED POWER (MW)
Al Khamsin	Master	20°28'01.89" N 44°34'52.34" E		800
Salwa	Whisky	24°50'01.50" N 50°34'12.02" E	11000 2612.55	800
Afif	Xray	27°48'16.82" N 42°51'17.63" E	26000 1371.23	800
Al Lith	Yankee	20°13'56.31" N 40°12'31.02" E	39000 1326.50	200
Al Muwasasim	Zulu	16°25'55.89" N 42°48'04.33" E	52000 1617.59	800


LABRADOR SEA - GRI 7930



LABRADOR SEA LORAN-C CHAIN - GRI 7930

STATION	FUNCTION	COORDINATES	CODING DELAY/BASE-LINE LENGTH	RADIATED POWER(KW)	REMARKS
Fox Harbour, Labrador	Hester	52°22'35.2"N 55°42'28.4"W		800	Dual-Rated to Canadian East Coast Chain.
Cape Race, NFLD	Whiskey	46°45'32.2"N 53°10'28.2"W	11000/ 2167.30	1500	Dual-Rated to Canadian East Coast Chain.
Angissoq, Greenland	Xrky	59°59'17.3"N 45°30'27.5"W	26000/ 3565.38	760	Dual-Rated to Icelandic Chain.
Ss. Anthony, NFLD	Monitor	51°21'37.0"N 55°37'28.0"W			


EASTERN USSR - GRI 7950



Eastern U.S.S.R LORAN-C Chain GRI 7950


Station	Function	Coordinates	Coding Delay/- Baseline Length	Radiated Power (kW)
Aleksandrov	Master	51 04 71.3 N 142 42 08.2 E		700
Petropavlo	Whisky	53 07 79.2 N 157 41 71.5 E	11,000 3508.1	700
Ussuriak	Xray	44 31 99.5 N 131 38 39.0 E	30,000 3678.0	700
Kuril'sk	Yankee	45 12 76.2 N 147 51 61.8 E	46,000 2527.4	6
Okhotsk	Zulu	59 25 03.3 N 143 05 38.2 E	61,000 3101.5	6

GULF OF ALASKA - GRI 7960



STATION	FUNCTION	COORDINATES	COMING DELAY/BASE- LINE LENGTH	RADIATED POWER (KW)	REMARKS
Tok, AK	Master	63° 18 42.8 N 142° 48 31.9 W		540	Two pulse combs installed
Narrow Cape, Kodiak Is., AK	X-ray	57° 28 28.2 N 152° 22 11.3 W	11000/ 2804.45	480	NO pulse combs in- stalled. Dual rated to North Pacific chain.
Shoal Cove, AK	Yankee	55° 28 28.3 N 131° 15 19.7 W	24300/ 2651.14	540	Two pulse combs in- stalled. Dual rated to Canadian West Coast chain.
Port Clarence, AK	Zango	65° 14 46.3 N 166° 53 12.6 W	44080/ 3932.52	1000	Dual rated to North Pacific chain.
Kodiak, AK	Monitor/ control	57° 44 00.7 N 152° 30 20.4 W			Excellent operational control of chain, control for X and Y.
JUNEAU, AK	Monitor	58° 17 54.8 N 134° 24 48.4 W			Unmanned receiver site.


NORWEGIAN SEA - GRI 7970



NORWEGIAN SEA LORAN-C CHAIN - GRI 7970 (old rate SL3)


STATION	FUNCTION	COORDINATES	CODING DELAY/BASE-LINE LENGTH	RADIATED POWER(MW)	REMARKS
Ejde, Faeroe Is., Denmark	Master	62 17 59.7 N 07 04 26.7 W		325	Host Nation Planned, Dual-rated to North Atlantic Chain.
BB, Norway	Zey	68 38 06.2 N 14 27 47.0 E	13000/ 4048.10	165	Host Nation Planned.
Sylt, Germany	Whiskey	54 48 29.8 N 08 17 36.3 E	26000/ 4065.64	325	
Sandur, Iceland	Yankee	64 54 26.6 N 23 55 21.8 W	48000/ 2944.53	1500	Host Nation Planned, dual-rated to North Atlantic Chain.
Jan Mayen, Norway	Zulu	70 54 52.6 N 08 43 58.7 W	60000/ 3216.30	165	Host Nation Planned.
Shetland Is., U.K.	Monitor/Control	60 26 25.3 N 01 18 05.7 W			Control For X, W, Y, and Z

SOUTHEAST UNITED STATES - GRI 7980



STATION	FUNCTION	COORDINATES	COSTING DELAY-BASE- LINE LENGTH	RADIATED POWER(W)	REMARKS
Melrose, FL	Wester	30 59 28.7 N 85 10 09.3 W		800	Control for W, X, Y, and Z. Dual-rated to Great Lakes Chain.
Greenville, LA	Mishay	30 43 33.0 N 90 49 43.6 W	11000/ 1809.54	800	
Raymondville, TX	Xray	26 31 55.0 N 97 50 00.1 W	23000/ 4443.38	400	
Jupiter, FL	Yankee	27 01 56.5 N 80 06 53.5 W	43000/ 2201.88	275	
Caroline Beach, NC	Zulu	34 03 46.0 N 77 54 46.8 W	59000/ 2542.72	550	
Hoyport, FL	Monitor	30 22 58.9 N 81 25 13.1 W			Unmanned receiver site.
Eglin, FL	Monitor	30 35 05.3 N 86 26 54.4 W			Unmanned receiver site.
New Orleans, LA	Monitor	29 49 17.5 N 90 01 44.2 W			Unmanned receiver site.


MEDITERRANEAN - GRI 7990



MEDITERRANEAN SEA LORAN-C CHAIN - GRI 7990 (old rate SL1)

STATION	FUNCTION	COORDINATES	CUTTING DELAY/BASE- LINE LENGTH	RADIATED POWER(W)	REMARKS
Sella Marina, Italy	Master	38 52 20.5 N 15 43 06.2 E		165	Exercises operations control of chain.
Lampedusa, Italy	Xray	35 31 20.8 N 12 31 30.2 E	11000/ 1756.96	325	AIs station.
Kargaburum, Turkey	Yankee	40 58 21.0 N 27 52 01.5 E	29000/ 3273.29	165	
Estarit, Spain	Zulu	42 03 36.5 N 03 12 15.9 E	47000/ 3999.71	165	


WESTERN USSR - GRI 8000



Western U.S.S.R LORAN-C Chain GRI 8000

Station	Function	Coordinates	Coding Delay/- Baseline Length	Radiated Power (kW)
Briansk	Master	53 07 84.3 N 34 54 74.7 E		650
Petrozavodsk	Whisky	61 45 54.0 N 33 41 67.3 E	10,000/ 3217.21	700
Slonim	Xray	53 07 92.0 N 25 23 76.7 E	25,000/ 2125.00	450
Simferopol	Yankee	44 53 34.3 N 33 52 53.5 E	50,000/ 3070.25	550
Syzran	Zulu	53 17 29.3 N 48 06 89.0 E	65,000/ 2941.60	700

WESTERN EUROPE (FRANCE) - GRI 8940




WESTERN EUROPEAN (FRENCH) LORAN-C CHAIN - GRI 8940

STATION	FUNCTION	COORDINATES	CODING DELAY/BASE- LINE LENGTH	RADIATED POWER (KW)	REMARKS
Lessey, France	Master	49°08'55.1" N 01°30'17.6" W		NA	
Soustons, France	Whisky	43°44'22.9" N 01°22'50.1" W	14000 2008.27	NA	
Sylt, Germany	Xray	54°48'29.9" N 08°17'36.3" W	33600 3072.46	NA	
Shetlands	Monitor	60°26'25.3" N 01°18'05.2" W			


All numbers are approximate and preliminary.

GREAT LAKES - GRI 8970




STATION	FUNCTION	COORDINATES	CURTAIN DELAY/BASE- LINE (ENH)	RADIATED POWER(W)	REMARKS
Dana, IN	Master	39 51 07.5 N 87 29 12.1 W		400	Dual-rated to North- east U.S. Chain.
Milroy, FL	Whiskey	30 59 38.7 N 85 10 09.3 W	11000/ 3355.11	800	Dual-rated to South east U.S. Chain.
Smeets, NY	Key	42 43 50.6 N 76 49 33.9 W	28200/ 3182.06	800	Dual-rated to North- east U.S. Chain. Exer- cises operational con- trol of chain.
Baudette, MN	Tanker	48 39 49.8 N 94 33 18.5 W	44000/ 3753.74	400	
LORAN Willwood, NJ	Tango	38 56 56.2 N 74 52 01.6 W	72000/ 1617.92	Various	Experimental station, not to be used for navigation.
Claybanks, MI	Monitor	N W			
Plumrose, OH	Monitor	44 22 47.0 N 82 39 26.5 W			Unmanned receiver site.
Eglin, FL	Monitor	30 35 05.8 N 86 36 54.4 W			Unmanned receiver site.
Hayport, FL	Monitor	30 22 58.9 N 81 29 19.1 W			Unmanned receiver site.

SAUDI ARABIAN (COMPOSITE OF SOUTH - GRI 7170 & NORTH
GRI 8990)




NORTHEAST SAUDI ARABIA - GRI 8990



STATION	FUNCTION	COORDINATES	COOING DELAY/BASE- LINE LENGTH	RADIATED POWER (KW)
Afif	Master	23°48'36.83" N 42°51'37.63" E		800
Salwa	Victor	24°50'01.50" N 50°34'19.02" E	11080 2641.09	800
Ar Ruqi	Whisky	29°01'04.61" N 46°37'21.98" E	25000 2298.51	200
Ash Shaykh Humayd	Kray	28°08'15.87" N 34°45'39.99" E	40080 3145.53	400
Al Lith	Yankee	20°13'58.31" N 40°12'31.02" E	56000 1406.26	200
Jubail	Monitor	27°19'36.60" N 49°26'30.07" E		
Yanbu	Monitor	24°04'14.14" N 38°02'35.90" E		
Al Qur'uddab	Monitor	19°08'48.37" N 41°03'40.69" E		

* The Saudi Arabian chains are not operated or controlled by the United States Coast Guard.

NORTHWEST SAUDI ARABIA - GRI 8991




SAUDI ARABIAN (NORTHWEST) LORAN-C CHAIN* - GRI 899

STATION	FUNCTION	COORDINATES	CODING DIALS/BASE- LINE LENGTH	RADIATED POWER (KW)
Afif	Master	25°48'36.82" N 42°51'37.63" E		800
Ar Ruqi	Whisky	28°01'04.81" N 46°37'21.96" E	25000 2299.81	200
Ash Shaykh Humayd	Xray	28°09'15.87" N 34°45'39.93" E	40000 3145.53	400
Al Lith	Yankee	20°23'58.33" N 48°17'31.02" E	56000 1606.26	200
Al Muwassam	Zulu	16°25'55.89" N 42°48'04.33" E	69000 2726.94	800
Jubail	Monitor	27°19'36.40" N 49°28'30.67" E		
Yanbu	Monitor	24°04'14.14" N 38°02'35.90" E		
Al Qunfuddah	Monitor	19°08'48.27" N 41°03'40.69" E		


* The Saudi Arabian chains are not operated or controlled by the United States Coast Guard.

WEST COAST UNITED STATES - GRI 9940




STATION	FUNCTION	COORDINATES	CURTAIN DELAY/BASE-LINE LENGTH	RADIATED POWER(W)	REMARKS
Fallen, NY	Master	39 33 06.6 N 118 49 56.4 W		400	Two pulse combs installed.
George, WA	Whiskey	47 03 48.0 N 119 44 39.5 W	11000/ 2796.90	1600	Two pulse combs installed. Dual-rated to West Coast Canada Chain.
Middletown, CA	Kray	38 46 57.0 N 122 29 44.5 W	27000/ 1094.50	400	Exercises operational control of chain. Control for M, X, and Y. Two pulse combs installed.
Searchlight, NY	Tankas	35 19 18.2 N 114 48 17.4 W	40000/ 1967.30	540	
North Bend, OH	Monsite	43 24 36.2 N 124 14 27.9 W			Unmanned receiver site.
Pt. Pines, CA	Monsite	36 17 50.0 N 121 56 05.6 W			Unmanned receiver site.

NORTHEAST UNITED STATES - GRI 9960



STATION	FUNCTION	COORDINATES	CODING DELAY/BASE- LINE (MINUTE)	RADIATED POWER (KW)	REMARKS
Sewers, NY	Master	42 42 50.6 N 76 49 33.9 W		800	Control for V, I, Y, and Z. Exercises oper- ational control of Chain.
Carlton, ME	Whisper	46 46 27.2 N 67 55 37.7 W	13000/ 2797.20	350	
Westchester, MA	Xray	41 15 11.9 N 69 58 39.1 W	25000/ 1969.93	275	
Carolina Beach, NC	Tango	34 03 46.0 N 77 54 46.8 W	39000/ 3221.65	550	
Dana, IL	Zulu	39 51 07.5 N 87 29 12.3 W	54000/ 3162.06	400	
Essex Villages, NJ	Tango	38 56 58.2 N 74 52 01.6 W	81500.49	Various	Experimental station, not to be used for navigation.
Cape Elizabeth, ME	Master	43 35 54.0 N 70 11 58.5 W			Unmanned receiver site.
Sandy Hook, NJ	Master	40 28 17.0 N 74 01 03.7 W			Unmanned receiver site.
Flumroo, MA	Master	41 22 47.0 N 82 39 38.5 W			Unmanned receiver site.
Claytons, ME	Master	43 33 48.0 N 66 29 07.0 W			Unmanned receiver site.


NORTHWEST PACIFIC - GRI 9970



NORTHWEST PACIFIC LORAN-C - GRI 9970

STATION	FUNCTION	COORDINATES	CODING DELAY/BASE- LINE LENGTH	RADIATED POWER (kW)	REMARKS
Iwo Jima, Japan	Master	24° 48 03.4 N 141° 19 30.3 E		540	Clarinet Pilgrim TTY2
Marcus Is Japan	Whiskey	24° 19 07.8 N 153° 38 53.2 E	11.000/ 4283.94	1800	Clarinet Pilgrim TTY2 installed
Hokkaido, Japan	Kray	43° 44 37.1 N 143° 43 09.2 E	30.000/ 6489.12	1000	Clarinet Pilgrim TTY2 installed
Gesami, Japan	Yankee	24° 31 28.0 N 128° 08 56.4 E	25.000/ 4443.18	1000	Clarinet Pilgrim TTY2 installed
Guam Is., USA	Fulu	13° 27 51.1 N 144° 49 54.1 E	31.000/ 4365.84	750	Replaces Tap Is.
Salpan, U.S.A.	Monitor/ Control	15° 07 48.8 N 145° 41 38.6 E			Controls W and Z
Yokota, Japan	Monitor/ Control	35° 44 34.6 N 139° 21 41.3 E			Controls X and Y
Chinhaen, Korea	Monitor	35° 11 11.0 N 128° 08 48.0 E			


ICELAND - GRI 9980



ICELANDIC LORAN-C CHAIN - GRI 9980

STATION	FUNCTION	COORDINATES	CODING DELAY/BASE- LINE LENGTH	RADIATED POWER(KW)	REMARKS
Sandur, Iceland	Master	64°58'26.6"N 23°55'21.8"W		1500	
Anglissoe, Greenland	Whiskey	59°59'17.3"N 45°10'27.5"W	11000/ 4068.03	760	Dual-Rated to Lab- rador Sea Chain
Ejde, Faeroe Is., Denmark	Tray	62°17'59.6"N 07°04'26.5"W	30000/ 2948.54	325	Dual-Rated to Nor- wegian Sea Chain.
Keflavik, Iceland	Monitor	63°57'23.0"N 22°43'21.0"W			

NORTH PACIFIC - GRI 9990



NORTH PACIFIC LORAN-C CHAIN - GRI 9990 (old rate 551)

STATION	FUNCTION	COORDINATES	CODING DELAY/BASE- LINE LENGTH	RADIATED POWER(KW)	REMARKS
St. Paul, AK	Master	57 09 12.3 N 170 15 06.6 W		275	Controls X and Y, exercises operational control of chain, two pulse comms installed.
Attu, AK	Xray	52 49 44.0 N 173 30 49.0 E	11000/ 3875.25	275	
Port Clarence, AK	Yankee	66 14 40.3 N 166 53 12.6 W	29000/ 3068.95	1000	
Narrow Cape, AK	Zulu	57 26 20.2 N 152 32 11.3 W	43000/ 3590.45	400	Two pulse comms in- stalled. Dual-rated to Gulf of Alaska Chain.
Kodiak, AK	Monitor/ Control	57 44 00.7 N 152 30 20.4 W			Control for Z.

NOTES:

Facts To Remember

If Your LORAN Needs Service

- 1. Before you call your Dealer or II Morrow, Inc., be sure you know the model number and serial number of your unit.**
- 2. Before you send your unit in for service, be sure to keep a record of any PILOT CREATED waypoints you want to keep. These waypoints are frequently lost in the process of performing the necessary maintenance.**
- 3. New database updates are available every 56 days. Contact your dealer or the II Morrow factory for details.**

TROUBLESHOOTING

Apollo 618

To Ensure Trouble Free Operation

Avoid high cockpit temperatures when aircraft is not in use.

DO NOT clean the face plate with chemical cleaning agents, solvents, or harsh detergents.

Periodically check all antenna, power, and ground connections.

DO NOT wax or paint the antenna.

Battery Replacement

The Apollo 618TCA memory is maintained by a lithium battery. The expected service life of this type of battery is approximately 5 years. This is not a user replaceable item. The lithium battery must be replaced by the factory or an authorized dealer.

Indications Of A Low Battery Level

Loss of the PILOT CREATED DATABASE memory.

GRI changes to 4990.

The unit does not search and acquire the signal properly.

If You Have A Problem

Read the instructions again for the desired function.

If You Are Unable To Correct The Problem

Record the SNRs and ECDs for ALL stations in the chain and call your II Morrow dealer or the factory. The technician MUST have this information before he can analyze the problem.

IN-FLIGHT**INDICATION**

WARN light is on.

PROBLEM

If flying through clouds, rain, snow, etc., the likely problem is precipitation static (P-STAT).

ACTION

Check SNRs. If the problem is P-STAT, all SNRs will be less than 25. After landing inspect (or install) static wicks per aircraft manufacturers specifications. Also, check the bonding on all control surfaces. If the problem continues, skin mapping may be necessary.

PROBLEM

If the aircraft is flying out of the coverage area for the selected chain, once the SNR's become sufficiently low, the WARN light will come on.

ACTION

Select a new GRI.

PROBLEM

If the WARN light is on after takeoff, or runup, noise from the aircraft alternator or magneto may be responsible.

ACTION

Contact the dealer or factory after landing.

IN-FLIGHT (CONTINUED)**INDICATION**

WARN light is on
(continued).

PROBLEM

Flying over a LORAN transmitter may cause the WARN light to come on temporarily. This signal is too strong for proper tracking.

ACTION

None.

PROBLEM

A station the unit is tracking has gone off the air temporarily.

ACTION

Check SNRs. Wait a few minutes; the station will normally come back on.

PROBLEM

Blink condition is occurring.

ACTION

Signal information appears normal. The WARN light goes out when the problem clears.

B EXT light is on.

PROBLEM

Aircraft is on a baseline extension.

ACTION

Select a more suitable chain or manually select a more suitable triad.

IN-FLIGHT (CONTINUED)**INDICATION**

Triad does not select automatically.

PROBLEM

Poor LOP crossing angles.

ACTION

Select best triad manually, then reset automatic selection.

PROBLEM

"Contaminated" signal.

ACTION

Cycle power switch.

PROBLEM

SYSTEM FAILURE is displayed and WARN light is on.

Transient fault may have occurred.

ACTION

Cycle power switch.

PROBLEM

Unit is malfunctioning.

ACTION

Unit needs service.

IN-FLIGHT (CONTINUED)**INDICATION**

Bearing and distance displays appear to be wrong.

PROBLEM

A mistake was made in entering the LAT/LONG coordinates of a PILOT CREATED waypoint.

ACTION

Verify that coordinates of the PILOT CREATED waypoint are accurate. Check the hemispheric identifier.

PROBLEM

Distorted signal.

ACTION

If the problem doesn't correct itself in a few minutes, cycle the power switch.

PROBLEM

The Alternate Solution is displayed.

ACTION

Select the other solution.

PROBLEM

Pilot error in determining position.

ACTION

Verify your position by activating EMERGENCY SEARCH. The correct bearings/distances to the airports should be displayed.

ON THE GROUND**INDICATION**

WARN light stays on after power-up.

PROBLEM

Wrong GRI is selected.

ACTION

Change to appropriate GRI.

PROBLEM

Required secondary is shut down.

ACTION

Check SNRs to see if unit is receiving signals from each secondary. Check GRI to see if a triad is being received. Select another GRI. (if available).

PROBLEM

Signal is weak due to distance from transmitters.

ACTION

Check SNRs. If very low, you may not obtain lock-on until after takeoff.

ON THE GROUND (CONTINUED)**INDICATION**

WARN light stays on after power-up (continued).

PROBLEM

Aircraft may be parked near something interfering with the signal (APU, hanger, high-voltage lines).

ACTION

Check SNRs and ECDs. If SNRs are very low, or ECDs high or changing rapidly, move the aircraft. The unit usually does not work inside a hanger.

PROBLEM

Antenna phase jumper is improperly set.

ACTION

Refer to Installation Manual for procedure.

PROBLEM

Noise generated from the aircraft alternator or magneto.

ACTION

Contact II Morrow dealer or factory.

WARN light is on after run-up.

NOTES:

USING THE APOLLO® 618 TRAINING MANUAL

The purpose of the Training Manual is to provide you with a comprehensive ground school course in the operation of the Apollo® 618 LORAN-C. This manual is designed to be used on the ground in conjunction with a working receiver.

IMPORTANT

Do NOT use this manual while airborne. Safe flying requires pilots to practice SEE and AVOID procedures mandated by FAA regulations. For this reason, before using the Apollo® 618 in the air, you should be quite familiar with its operation.

INTRODUCTION

LORAN-C TERMS	I-1
IMPORTANT FACTS	I-5
CONTROL BUTTONS	I-7
STATUS INDICATORS	I-9
MODE INDICATORS	I-11
HOW LORAN-C WORKS	I-13

LORAN-C TERMS

ACCURACY, ABSOLUTE: a measure of the ability to determine true geographic position (Latitude and Longitude).

ACCURACY, REPEATABLE: a measure of the ability to RETURN to a specific position or location.

ACQUISITION: the process of "locating" the LORAN signal among background noise, and then tracking the signal.

ALTERNATE SOLUTION: There are two solutions to the LORAN's calculations. Normally the unit automatically displays the correct solution. The solution the unit does NOT display is the Alternate Solution.

ASF: Additional Secondary Phase Factor. These are calibration factors entered by the pilot into a LORAN-C receiver to compensate for local propagation variations in the LORAN-C signal.

BASELINE: the great circle line connecting the master transmitting station and a secondary transmitting station.

BASELINE EXTENSION: the extension of the baseline beyond either the master or secondary transmitting station.

BLINK: A transmitted signal that indicates signal information from that station may be inaccurate or missing.

CHAIN: a LORAN-C network consisting of a master station and from two to four secondary stations.

CODING DELAY: the time difference between the pulse groups transmitted by a master station and a secondary station.

CONTROL/MONITOR STATION: a station within a LORAN-C chain that insures proper signal transmission. It is normally an unmanned receiver site located within the prime LORAN coverage area, separate from all of the transmitter stations.

CROSSING ANGLE: the angle formed by two intersecting LOPs (Lines of Position).

CROSS-RATE INTERFERENCE: signal interference caused by over-lapping coverage areas from two or more LORAN-C chains.

CROSS TRACK DISTANCE: the distance, left or right, away from the desired course.

CYCLE SLIP: failure of the receiver to maintain synchronization of the Zero Crossing Tracking Points and phase coding of the LORAN-C pulses. This results in time measurement errors in multiples of 10 usec (microseconds). A cycle slip normally results in a displayed position error of more than one mile, the magnitude of the error depending on the receiver's position in the LORAN coverage area.

DEFAULT PAGES/SETTINGS: Settings programmed into the unit as it leaves the factory. These settings can later be changed by the user.

DUAL RATED STATION: a LORAN-C transmitting station that operates in two LORAN-C chains.

ENVELOPE-TO-CYCLE DIFFERENCE (ECD): a measure of signal distortion determined by the phase shift between the pulse envelope and the 100 kHz carrier.

FIX: a position defined by two intersecting LOPs (Lines of Position).

GEOMETRIC DILUTION OF PRECISION (GDOP): a factor used to express all geometric causes of error in a fix.

GREAT CIRCLE ROUTE: the shortest distance between points along the curved surface of the earth.

GROUND WAVE: a radio wave that travels near or along the Earth's surface.

GROUP REPETITION INTERVAL (GRI): the number used to identify a particular LORAN-C chain. The four digit number indicates the time coded delay. For instance, the West Coast chain GRI is 9940, which refers to a time interval of 99,400 usec (microseconds).

LINE OF POSITION (LOP): a line representing the series of locations of constant time difference between the master and a secondary station.

LORAN: Long Range Navigation.

LORAN-C: a long range navigation system using ground-based transmitters operating in the Low Frequency (LF) radio band. The "C" refers to the version of LORAN.

MASTER STATION: the controlling station of a particular LORAN-C chain which transmits the reference timing signals based on the GRI of that chain.

PRECIPITATION STATIC (P-STATIC): electromagnetic noise created by the rapid discharge of static electricity. An aircraft builds up a static electric charge by passing through charged particles (such as rain, ice, snow, or dust).

REPEATABLE ACCURACY: See ACCURACY, REPEATABLE.

SECONDARY STATIONS: the two to five secondary transmitting stations in a LORAN-C chain which transmit in sequence after the master station at fixed, predetermined, intervals.

SIGNAL-TO-NOISE RATIO (SNR): the ratio of the LORAN-C signal level to the level of background noise.

SKYWAVE: an indirect radio wave that reflects off of the ionosphere, rather than following a direct path from the transmitter to the receiver.


TIME DIFFERENCE (TD): the difference in time of arrival of two LORAN-C signals, one from the master station and the other from one of the secondary stations. TDs are measured in microseconds.

TRACKING: the process of maintaining synchronization of the receiver with the selected signals.

TRIAD: the master and two secondary transmitting stations used by a LORAN receiver to determine position.

WAYPOINT: a specific location on the earth.


NOTES:



IMPORTANT FACTS

1. The NORTH AMERICA DATABASE and SEABASE\HELIPORT DATABASE are in permanent memory and cannot be altered.
2. Knobs may be turned in either direction.
3. Distance information is displayed in nautical miles only. One nautical mile = 1.15 statute miles.
4. Smaller size numbers follow a decimal point. For example, 3555 = 355.5
5. The smaller size numbers in latitude and longitude displays represent tenths and hundredths of a minute (not seconds). For example 44° 5474 = 44 degrees, 54.74 minutes. To convert seconds to a decimal equivalent, divide by 60. For example, 30 seconds = .5 minutes (30/60 = .5). Therefore 39° 21' 30" = 39° 21.5'.

NOTES:

**TO**

Sets the displayed waypoint as the destination waypoint. Also, when in NAV mode, displays information on the "To" waypoint.

FRM

Sets the displayed waypoint as the departure waypoint. Pressing this button twice within one second sets your present position as the departure waypoint regardless of the current mode (except when displaying a waypoint in WPT mode).

**APR
ENR**

Select the approach or enroute sensitivity on the external CDI (for aircraft so equipped). The unit will not automatically switch secondary stations while in approach mode.

Full Scale Deflection

Enroute: 5.0 nautical miles
Approach: 1.25 nautical miles

Note

APR/ENR does not affect the internal CDI. When approach sensitivity is selected, the APP annunciator on the left side of the Information Display is lighted.

MODE

Selects the operating modes (NAV, WPT, AIRSP, SETUP). The current mode is displayed on the right side of the Information Display

SEL


Enables the selection of a displayed item to be changed. The selected item flashes. The displayed item is not entered until ENT is pressed.

ENT

Enters selected data.

APR**ENR and ENT**

EMERGENCY SEARCH WITH SAFE - GLIDE™ is activated when these two buttons are pressed simultaneously.



STATUS ANNUNCIATORS

WARN

Is lighted:

When the signal is not adequate for navigation.

When the computer determines the signal quality is below standard.

For one minute when a math error is detected, even though math errors are normally corrected by the unit in a matter of seconds.

When a Blink condition is detected. (See LORAN-C TERMS for a definition of BLINK.)

Is flashing:

Temporarily, when a new GRI is selected.

When the unit is first turned on. It stops flashing and stays on once it has "found" the signals from a Master and two Secondaries, indicating the acquisition process is proceeding normally.

Note

It may take a few minutes for the unit to determine its position, depending on location and possible interference. The WARN annunciator will go out when the unit determines the signal is suitable for navigation.

ARIV

Lighted when the aircraft is within 1 nautical mile of the destination waypoint for each 100 knots of ground speed. The minimum is 1 nautical mile at speeds below 100 knots. If the optional II Morrow encoding altimeter is installed, the ARIV annunciator will flash for a few seconds when the aircraft is approximately 2 minutes from the Top of Descent Point.

APP

Lighted when approach sensitivity is selected. This affects only the remote CDI, if installed.

OFST


Lighted when a course offset is entered.

ASF

Lighted when Latitude/Longitude calibration factors are entered.

B EXT

Lighted when the aircraft is positioned on or near a baseline extension, indicating possible degraded accuracy.



MODE ANNUNCIATORS

The MODE button advances through the modes from top (NAV) to bottom (SETUP), and then back to the top again. The lighted annunciator indicates the selected mode.

NAV

Navigation Mode - Displays the various "pages" for use when navigating.

WPT

Waypoint Mode - Displays waypoints contained in the unit's various databases.

AIRSP

Airspace Mode - Flashes to alert the pilot the aircraft is approaching a TCA, Restricted Area, Prohibited Area, Alert Area, ARSA, TRSA, MOA, Class C, CYA, CYD, and CYR. Airspace information may be displayed when AIRSP mode is selected with the mode button. When AIRSP mode is selected, the annunciator is lighted solid unless a new airspace alert is detected, in which case the annunciator will flash.

SETUP

Setup Mode - The pilot may display and alter the unit's settings for various features such as XTD SENS (Cross Track Sensitivity) and Airspace Alert. Also, signal information and diagnostic information may be displayed.


NOTES:

HOW LORAN-C WORKS

LORAN is an acronym for LOnG RANGE Navigation, and "C" refers to the version of LORAN. A previous version of LORAN was called LORAN-A, and a military version is called LORAN-D.

Since LORAN-C signals are low frequency, they closely follow the contour of the earth, and as a result can be used for navigation on the ground, in the air, or at sea.

Sky waves are signals reflected back to earth from the ionosphere, and because they are subject to a number of variables, they are not suitable for normal navigation. II Morrow LORAN receivers reject sky wave contamination, and use only Ground Waves.




The LORAN receiver is a precise time measuring device. To visualize how this works, imagine you are flying somewhere within a LORAN-C coverage area. This means your unit is receiving signals from three ground stations. One station is the **Master**, and the other two are **Secondaries**. The Master and all of the Secondaries that define a LORAN-C coverage area are called a **Chain**. Each Chain contains one Master and up to 5 Secondaries. At any given time, the unit must be receiving the Master station and two of the Secondary stations. Together, these three stations form a **Triad**.

To distinguish between the various secondaries in a chain, they are named Whiskey, X-ray, Yankee, and Zulu.


You must manually select the desired chain with your Apollo 618, but the unit automatically chooses the best possible triad within that chain.

LORAN-C signals travel at the speed of light (approx. 186,000 miles per second). Suppose your unit is using secondaries Whiskey and X-ray. It measures the Time Difference (TD) between the arrival of the Master pulse and of the Whiskey pulse. From this, the unit can electronically "plot" a Line of Position (LOP) that represents that measured TD. That is to say, your aircraft is somewhere along this line, a line that represents a constant TD between the Master and Whiskey. The shape of this line is always a hyperbola.


The unit also measures the TD between the arrival of the Master pulse and of the X-ray pulse, defining another LOP. Your position is where the two LOPs intersect. The unit automatically converts this fix into latitude and longitude coordinates.



The unit electronically "plots" this LOP by measuring the TD between the arrival of the signal from the Master station and the arrival of the signal from the station Whiskey.



The unit electronically "plots" this LOP by measuring the TD between the arrival of the signal from the Master station and the arrival of the signal from the station X-ray.




A fix is where the two LOPs intersect.

Each chain is assigned a time code called a **Group Repetition Interval (GRI)**. The GRI is the time between the start of the Master station pulses and the beginning of the next series of Master pulses, and is measured in microseconds (usec.). For example, the U.S. West Coast chain is 9940, meaning the Master station pulse group repeats every 99,400 microseconds.

The accuracy of a fix is determined by the combination of receiver limitations, signal condition, and the operator. LORAN-C accuracy is affected somewhat by weather, terrain, power lines, and mineral deposits. The signal travels the greatest distance with a minimum of distortion over seawater or flat terrain and in clear weather.

Two types of accuracy are considered, **Repeatable Accuracy** and **Absolute Accuracy**.




Absolute accuracy simply describes the ability of the system to determine geographic position. *Repeatable accuracy* refers to the ability to return to the same position. For example, imagine you've made a flight to another airport. Upon arrival, the accuracy of your displayed position would be based on *absolute accuracy*. Now suppose you return to your starting airport, that is, you fly to the same latitude/longitude that was "known" to your Loran when you departed. Now, the accuracy of your navigation system is "repeatable." Absolute accuracy, which varies (depending on condition) between 0.1 and 2.5 nautical miles, is less precise than repeatable accuracy, which typically varies less than .01 nautical miles.

One reason for varying accuracy is due to the aircraft's position within the triad. If the two LOPs cross each other so that the angle between them is approximately 90 degrees, the accuracy is optimum. However, if this **Crossing Angle** is less than 20 degrees, the resulting fix is less accurate.


An imaginary line between the Master station and a Secondary is called a **Baseline**. The crossing angles near a baseline will be good, but the crossing angles near a **Baseline Extension**, shown as dashed lines in the drawing below, will be poor. The crossing angles within a Loran C coverage area will vary, but reasonable accuracy is available anywhere within the coverage area.

All LORAN transmitters operate on the same 100KHZ frequency, and the receiver picks up a maze of pulses from the Master and secondaries in many chains. A unit in the U.S. is likely pick-up signals from many of the



LORAN transmitters on the continent. The signals are actually pulses, which are all virtually identical. No pulse has a unique "signature" that identifies it as having come from a specific chain.

The receiver uses a rather complex strategy to "pick out" the desired pulses among the various pulses and background noise it's receiving, and to find the proper tracking point on the pulses. When the unit is in motion the process becomes more complex because the TDs between the Master and the secondaries are constantly changing. Once all the stations have been acquired, the unit must select the best triad. While these initialization processes are taking place in your Apollo LORAN, the WARN indicator will be lighted.



NOTES:

NAVIGATION

BASIC NAVIGATION

FINDING YOUR PRESENT POSITION	N-1
DEFINING A COURSE	N-5
SEARCHING DATABASES	N-9
INTERPRETING NAV PAGES	N-11

ADVANCED PROCEDURES

CREATING A WAYPOINT	N-19
CREATING A WAYPOINT USING PRESENT POSITION	N-23
COPYING WAYPOINTS	N-25
CREATING A PHANTOM WAYPOINT	N-27
USING FLIGHTPLAN PAGE	N-31
DISPLAYING INFORMATION FROM FLIGHTPLAN PAGE	N-33
DISPLAYING INFORMATION ON THE "TO" WAYPOINT	N-35
DELETING FROM FLIGHTPLAN PAGE	N-37
DELETING WAYPOINTS IN THE PILOT CREATED DATABASE	N-39
EDITING A PREVIOUSLY CREATED WAYPOINT	N-41
DELETING IN THE PILOT COPY DATABASE	N-43
DUPLICATE NDB IDENTIFIERS	N-45
DISPLAYING INFORMATION	N-47
INTERPRETING INFORMATION	N-49
INTERPRETING NAVAID INFORMATION	N-53
SEARCHING BY CITY	N-55

SEARCHING FOR A NAVAID OR INTERSECTION . . .	N-57
ABBREVIATED SEARCHES	N-59
EMERGENCY SEARCH WITH SAFE - GLIDE™	N-61
ALTITUDE SELECT	N-67
USING NAV PLANNER	N-69
ALTIMETER AND VNAV SETUP	N-71
CHANGING COURSE WHILE ENROUTE	N-75
LINING-UP WITH A RUNWAY	N-77
POSITION CALIBRATION	N-79
ALTERNATE SOLUTION	N-81
NEAREST WAYPOINT SEARCH	N-83
AIRSPACE ALERT	N-85

NAVIGATION

APOLLO® 618

Note

Characters against a white background in the displays depicted in the Training Manual indicate the characters are flashing.

FINDING YOUR PRESENT POSITION

Your Apollo 618 has the remarkable ability to "know" its precise location, but first it must be receiving a triad within a LORAN-C chain. Triad selection is automatic, but the LORAN chain must be selected by the pilot. Since LORAN chains cover vast areas, many pilots switch chains infrequently. From an operational standpoint, changing chains is similar to changing frequencies on a conventional radio, and it may be useful to think of it in these terms; however, keep in mind all LORAN signals are transmitted over the same 100 kHz frequency. Selecting a chain is actually selecting the Group Repetition Interval (GRI), i.e. the repetition rate of the Master station signal pulses.

Note

If in any of the exercises you get confused and wish to start over, press MODE until you enter the mode you want to work in. If you are working anywhere in the WPT mode, press MODE once and you'll enter the beginning of WPT mode. After that, pressing MODE will change the mode.

START-UP


1. Power - ON

The entire information display is be lighted momentarily. The name of the current GRI will then appear briefly, after which the WARN light will be flashing. The WARN light turns solid once the unit has found the Master and two secondaries, "telling" you the acquisition process is proceeding normally. This process usually takes about 30 seconds, but to insure a high degree of accuracy, the unit spends additional time

"watching" the signal. You may use the unit for navigation once the WARN light goes out, which generally takes from two to four minutes after power-up. You may continue with this example WITHOUT waiting for the WARN light to go out.

2. MODE - SETUP

The page depicting the name and GRI of the currently selected chain appears momentarily, and then the unit will automatically display the page depicting the GRI on the top line.



Note

Each "s" indicates the unit is conducting a search to acquire a signal from the appropriate station in the chain. After each station signal has been acquired, the "s" changes to a small letter (except for the Master, which is always represented by a capital letter). When a triad is selected (either automatically or manually) the small letter representing each selected station will change to a capital letter. The Master (M) will always be in the triad.

3. SEL - PRESS

The display depicting the name of the currently selected chain reappears, and the GRI numbers flashes.

White background indicates characters are flashing



4. **SMALL KNOB** - TURN to display desired GRI.
The GRI for your area may be found in the LORAN CHAINS section.
The North East chain is depicted below.




5. **ENT - PRESS**

The display depicting the GRI on the top line reappears, and "Auto" (Automatic triad selection) flashes. You are leaving the "Auto" setting. Manually selecting a triad is discussed in the SETUP MODE section.



DISPLAYING PRESENT POSITION

1. **MODE - NAV**
2. **LARGE KNOB** - TURN to display Position page.



Note

If the WARN light is still on, the displayed position is the last position "known" to the LORAN when it was turned off. Therefore, if the unit is in the same location as it was when it was turned off (as is normally the case), it will accurately display your position, provided it had accurately determined a position before it was turned off. While this may be useful, because the displayed present position is accurate under these circumstances, keep in mind the unit cannot calculate a position until it has acquired a signal, selected a triad, and the WARN light has gone out. If the unit is in a new location since it was last turned off, be sure the WARN light is out before continuing.

DEFINING A COURSE

Suppose you would like to fly from your present position to Denver, CO (airport identifier--DEN).


1. MODE - WPT

The last database used is the first database displayed when you reach WPT mode. In the example below, assume the last database was PILOT COPY DATABASE.



2. SMALL KNOB or LARGE KNOB - TURN to display the NORTH AMERICA DATABASE.

All the databases (depicted below) may be displayed by turning the SMALL KNOB. Each database name flashes. The DEN listing is contained in the NORTH AMERICA DATABASE.




Note

The final character in the identifier for a PILOT CREATED DATABASE waypoint is always ^CR, for a SEABASE "s", for a HELIPOINT "h", NDB "n", and a VOR "v".


3. ENT - PRESS

The prompt LOOK FOR APT ID appears. APT ID, which stands for "Airport Identifier," flashes. Since the NORTH AMERICA DATABASE is very large, containing over 20,000 waypoints, it saves time when the unit can restrict its search to a specific type of waypoint, either an airport identifier, a city name, a VOR, an NDB, or an intersection. In this example you're looking for an airport identifier, so the displayed search selection, APT ID, is correct.




4. ENT - PRESS

APT ID stops flashing, and a line in the first space in the bottom row begins to flash.



5. SMALL KNOB - SCROLL to display a flashing "D" in the bottom, left space.




6. ENT - PRESS

The "D" stops flashing, and the line to the right of the "D" flashes.

7. STEPS 5 & 6 - REPEAT to enter the "E", "N" and "_".

The "_" you entered "tells" the unit there's no fourth character in the identifier. The unit now locates and displays the listing for DEN.

**8. TO - PRESS**

The unit automatically switches to the NAV mode Flightplan page, displaying DEN as the "To" waypoint. Also, DEN is automatically be copied into the PILOT COPY DATABASE.

9. FRM - PRESS twice within one second. This defines your present position as your departure point. You have now defined a direct course to DEN.*Note*

Normally you will select your present position as your departure waypoint; however, there are times when you may want to use a database waypoint as your departure point. If the WARN light is still on and the LORAN is not in the same location as it was when it was turned off, it may be more expedient to use the appropriate database listing for your departure waypoint rather than wait for the WARN light to go out and use present position. When using a database waypoint it isn't necessary to wait for the WARN light to go out before defining your departure waypoint. You enter a departure waypoint exactly as you do a destination waypoint, except you press FRM instead of TO.

NOTES:

SEARCHING DATABASES

You will normally use the LOOK FOR feature when searching the NORTH AMERICA DATABASE because scrolling such a large database would be too time-consuming; however, once you display a NORTH AMERICA DATABASE entry, you may scroll to "surrounding" identifier (according to alphanumeric order) entries with the LARGE KNOB.

In other databases you may use either LOOK FOR or scroll with the LARGE KNOB. Unless the PILOT COPY and PILOT CREATED Databases have a considerable number of entries, it will probably be easier to scroll with the LARGE KNOB than to use LOOK FOR.

When using LOOK FOR in any database except NORTH AMERICA, the step selecting and entering the type of waypoint (airport identifier, city, VOR, NDB, intersection) is not applicable and will be omitted.

If you wish to restore the last waypoint identifier you displayed using LOOK FOR, press ENT when the LOOK FOR page is displayed.

LOOK FOR always searches for waypoints that begin with the sequence you've entered. You may enter just the first character (or characters) in the sequence, and the unit displays the first listing found that begins with the character you've entered. You may then scroll the LARGE KNOB to the waypoint you're looking for.


If searching for a name that is longer than the eight characters it's possible to enter, only enter the first eight characters. If entering a city name that's more than one word, do not enter a space between the words.

NOTES:

INTERPRETING NAV PAGES

The NAV pages may be edited as explained in SETUP MODE. The default (factory) NAV pages are depicted below. Many pilots find the default pages very useful without editing.

The following list depicts and explains each line that may appear on a display. NAV pages may be customized in SETUP MODE. (See page S - 11). When customizing, any combination of display lines, in any order, may be selected to appear on a NAV display.



Display Line

Interpretation

To DEN

First leg destination identifier.

BRG 086°

Magnetic bearing from present position to destination.

DST 7125

Distance from present position to destination. (In this example the distance is 712.5nm.)

-II 05

CDI display. In this example the course is to the left 0.5 miles. The numerical display is shown on the opposite side from the direction of the bar graph. When automatic XTD SENS (Cross Track Sensitivity, i.e., CDI Sensitivity) is selected, the sensitivity of the CDI automatically increases when you're within one nautical mile of your course. This feature is fully explained in the SETUP MODE section.

TRK 087°

Ground Track.

A $\frac{1}{2}$ 12500

To display your altitude, the unit MUST be connected to a II Morrow encoding altimeter and the altimeter setting checked. Setting the altimeter is discussed later in this section.

V $\frac{N}{V}$ 2500

If your unit is NOT connected to a II Morrow encoding altimeter, begin your decent when this display matches your cruise altitude. To maintain your descent profile, adjust your descent so that your decent so that your altimeter matches the displayed altitude.

V $\frac{N}{V}$ 230 ↓


If your unit IS connected to a II Morrow encoding altimeter, the unit will display the direction and amount of altitude change to maintain your present profile. Adjusting your target altitude and glide slope angle is discussed later in this section.

GS 234	Ground Speed
ETE 3:03	Estimated Time Enroute
R _T BRG 340	Bearing to return to the departure waypoint. (This line is not included in the default pages.)
R _T DST 127	Distance to return to the departure waypoint (This line is not included in the default pages.)
R _T TO SLE	Departure waypoint identifier. (This line is not included in the default pages.)

Note:

A blank line may also be selected.


The pages below may not be customized.




Each of the default pages is designed to give information pertaining to specific phases of flight.

Examples:


This page defines either a one or two-leg flight.




This page is very useful when lining-up with a runway. In the illustration below, continue on 270 degrees until the BRG is 300 degrees, then turn to 300 degrees. Press FROM twice to setup a straight-in course to runway 30.




This page is particularly useful for enroute navigation.




This page is useful for intercepting a course and fine-tuning your heading. In the illustration below, the aircraft is flying a heading of 270 degrees to intercept the 300 degree BRG to the destination. When the BRG approaches 300 degrees, turn 30 degrees right of your present heading to establish a track of 300 degrees.




In the illustration below, the aircraft heading is 290 degrees and maintaining a TRK of 295 degrees. The desired track is 300, so the pilot should alter the heading slightly to the right to fly the desired course.




This page is used in descent planning and progress. The example below depicts VNAV with the optional II Morrow encoding altimeter installed.




This page is useful in keeping track of your progress.



This page is useful when you want to return to your departure point.



RETURN ^{NAV}
TO XYZ
290° 91



CREATING A WAYPOINT

Most commonly used waypoints are contained in the Apollo 618's extensive database; however, there may be times when you wish to create your own waypoint. The **PILOT CREATED DATABASE** is for this purpose, and you may create and store up to 500 waypoints in nonvolatile memory.

Note


*If at anytime you get confused and want to start over, press **MODE** once to enter the beginning of **WPT** mode.*

Suppose you want to create a waypoint over Mary's Peak, a peak in the central Oregon coast range.

1. **MODE - WPT**
2. **SMALL KNOB** or **LARGE KNOB - TURN** to display **PILOT CREATED DATABASE**.



3. **ENT - PRESS**
4. **LARGE KNOB - TURN ONE INCREMENT COUNTERCLOCKWISE** to display **ENT TO CREATE NEW WPT** page. "ENT TO CREATE A NEW WAYPOINT" is at both ends of the **PILOT CREATED DATABASE**.



5. ENT - PRESS

A prompt asking if you want to create a phantom waypoints appear. Creating a phantom waypoint is discussed later in the section.




6. SEL - PRESS


Your present position is entered and assigned a numerical identifier. If this is the first entry you've made in your PILOT CREATED DATABASE, the assigned identification number is 001. The first number in the identifier flashes. You may elect to leave this number as the waypoint identifier, but it is generally easier to remember a waypoint if you assign it a name. In this example, use MRY (Mary's Peak) for your waypoint identifier.

Note

MRY is also the identifier for Monterey, CA (in the NORTH AMERICA DATABASE), but since C_R is always the fifth character (and cannot be changed) in a PILOT CREATED DATABASE entry, the two waypoints can still be distinguished.



7. SMALL KNOB - SCROLL to display a flashing "M".




8. ENT - PRESS

The "M" stops flashing, and the character to the right of the "M" will flash.


9. Steps 7 & 8 - REPEAT to enter the "R", "Y" and "_".

The degrees latitude flashes. The latitude at Mary's Peak is 44 degrees, 30.20 minutes.



MRY CR WPT
45° 21.00
122° 18.20

10. SMALL KNOB - SCROLL to display 44 degrees latitude.



MRY CR WPT
44° 21.00
122° 18.20

11. ENT - PRESS

44 stops flashing, and the latitude minutes display to the right of 44 flashes.

12. SMALL KNOB - SCROLL to display 30 minutes latitude.


13. ENT - PRESS

30 stops flashing, and the hundredths of a minute display to the right of 30 flashes.


14. SMALL KNOB - SCROLL to display 20 hundredths of a minute latitude.

15. ENT - PRESS

16. **Steps 10-15 - REPEAT** to enter the longitude for MRY^{CR}. The longitude at Mary's Peak is 123 degrees, 32.90 minutes. After the longitude is entered, the hemisphere display flashes. The globe is divided into the hemispheres depicted below. All of the US is in the North and West hemispheres (North latitude and West longitude).



17. **SMALL KNOB - TURN** to display the NW (Northwest) hemisphere if the NW hemisphere is not already displayed.



18. ENT - PRESS

The waypoint is sorted alphanumerically, with letters before numbers, in the PILOT CREATED DATABASE. If you wish to create another waypoint, press MODE and the PILOT CREATED DATABASE page is displayed. You may not want to keep MRY^{CR} in your PILOT CREATED DATABASE, and a later example shows how to delete it.

Note,

Once the desired editing is accomplished, it is not necessary to press ENT repeatedly to fix the remaining values. For example, if you wished to edit only an identifier, and not the associated coordinates, you could press MODE or scroll LARGE KNOB immediately after editing the identifier.

CREATING A WAYPOINT USING PRESENT POSITION

The fastest and most accurate way to create a waypoint in your PILOT CREATED DATABASE is to enter the waypoint when you are actually at the waypoint location (either in the air or on the ground). You created a waypoint using your present position when you first created the MRY^C_R waypoint, before you edited the latitude and longitude.

Since the repeatable accuracy of LORAN-C is more precise than its absolute accuracy (see "LORAN-C Terms" and "How LORAN-C Works" in the Introduction section), it's likely your entry is more accurate if you create a waypoint from your present position than if you use latitude/longitude coordinates from a chart.

Shortcut To Creating Waypoints Using Present Position

If you are planning to create waypoints while in flight, be sure the PILOT CREATED DATABASE is the last database used. This will eliminate having to turn to the PILOT CREATED DATABASE after entering WPT Mode.

After entering WPT Mode, press ENT,ENT, SEL. The waypoint will be created using your present position and will be assigned a numerical identifier. If you want to quickly create another waypoint, press MODE, ENT, ENT, SEL. This procedure allows you to quickly create a string of waypoints without taking time to give them names until the procedure is completed.

NOTES:

COPYING WAYPOINTS


The PILOT COPY DATABASE is a place to store any waypoints you intend to use. You may want to copy not only destination waypoints, but intersections and NAVAIDs near your destination as well. You may copy from any of the other databases into the PILOT COPY DATABASE.

Note

It's recommended all waypoints planned for use be copied into the PILOT COPY DATABASE. Reference waypoints for PHANTOM waypoints and entries made directly from the NAVFlightplan page can be made only from the PILOT COPY DATABASE.


Suppose you want to copy the LAX VOR (Los Angeles International VOR) and MRY ^C_R (the waypoint you created in the previous example) into your PILOT COPY DATABASE.

1. MODE - WPT
2. SMALL KNOB or LARGE KNOB - TURN to display the NORTH AMERICA DATABASE.
3. ENT - PRESS
4. SMALL KNOB - TURN to display flashing "VOR".



5. ENT - PRESS
6. SMALL KNOB - TURN to display a flashing "L".
7. ENT - PRESS

8. **Steps 6 & 7 - REPEAT** to enter the "A" and "X".
The LAX VOR listing is displayed.



9. **ENT - PRESS**

Pressing ENT with any waypoint displayed "tells" the unit to copy the waypoint. A message confirming the waypoint is copied appears briefly, and the waypoint is again displayed.

10. **MODE - WPT**

Pressing MODE once causes you to enter the beginning of WPT mode.

11. **SMALL KNOB - TURN** to display the PILOT CREATED DATABASE.

12. **ENT - PRESS**

13. **LARGE KNOB - TURN** to display the MRY C_R entry.

Pressing SEL instead of turning the LARGE KNOB would have allowed you to LOOK FOR the waypoint as you did in the NORTH AMERICA DATABASE; however, until there are a number of entries in your PILOT CREATED DATABASE, it's probably faster to scroll the LARGE KNOB to display the waypoint.

14. **ENT - PRESS**

The waypoint is copied. A later example will show how to delete this entry from your PILOT COPY DATABASE.


CREATING A PHANTOM WAYPOINT

Suppose you would like to create a waypoint 20 miles from the LAX VOR on the 315 radial. You must have copied the LAX VOR in the previous example into the PILOT COPY DASTABASE before proceeding with this example.


Note

Any PILOT CREATED waypoint may be created as a PHANTOM WAYPOINT.

1. **MODE - WPT**
2. **SMALL KNOB or LARGE KNOB - TURN** to display **PILOT CREATED DATABASE.**
3. **ENT - PRESS**
4. **LARGE KNOB - TURN** one increment counter clockwise to display **ENT TO CREATE NEW WPT.**
5. **ENT - PRESS**
The prompt asking if you wish to create a **PHANTOM** waypoint appears.
6. **ENT - PRESS**
The reference waypoint flashes.




7. **SMALL KNOB** - TURN to display LAXv.




8. **ENT** - PRESS

The first radial digit will flash.



9. **SMALL KNOB** - TURN to display "3".



10. **ENT** - PRESS

"3" stops flashing and the digit to the right of the 3 will flash.

11. **SMALL KNOB** - TURN to display "1".

12. **ENT** - PRESS

"1" stops flashing and the digit to the right of the 1 will flash.

13. **SMALL KNOB** - TURN to display "5".

14. **ENT** - PRESS

The first distance digit flashes.

15. **SMALL KNOB** - TURN to display "0", if "0" is not already displayed.

16. ENT - PRESS

17. SMALL KNOB - TURN to display "2".

18. ENT - PRESS

19. SMALL KNOB - TURN to display "0".

20. ENT - PRESS

The tenths of a mile digit will flash.

21. SMALL KNOB - TURN to display "0".

22. ENT - PRESS

The PHANTOM waypoint is created. Edit the identifier, as in the CREATING A WAYPOINT example, to read LV20. Once you have edited the identifier you may press MODE to enter the beginning of WPT mode. Since the latitude and longitude coordinates are correct, it is not necessary to edit them or fix them by pressing ENT repeatedly.

NOTES:

USING FLIGHTPLAN PAGE

Introduction

The 618 software version 4.2 allows for a total of 20 waypoints in the flight plan feature. These 20 waypoints can be used to create a combination of smaller flight plans which can be left in place indefinitely for future use. The current destination waypoint (the current leg) is indicated by an arrow "-->" pointing to it. Each of these smaller flight plans can be easily reversed or deleted.

Additionally, the method which the 618 uses to sequence from one waypoint to the next has been modified. While in the enroute mode, the current destination waypoint must be within 5 nm before the arrow will sequence to the next waypoint in the flight plan. Pushing the "APR/ENR" button will initiate the approach mode and the flight plan will only sequence if the destination waypoint is within 1 nm. (Please note that the 618 is for VFR use only). Also, while in the approach mode, the 618 will not triad change, so it is recommended that the enroute mode be used except in cases where the distance from one waypoint to the next is less than 5 nm.

All waypoints must be saved to the pilot copy database before they can be used in the creation of a flight plan. To save a waypoint to the pilot copy database, retrieve the desired waypoint in the Waypoint mode and press the "ENT" button an additional time to display the message "SAVED TO COPY DATABASE".

Entering Waypoints for a Flightplan

In the NAV mode, turn the large knob to display the flight plan page. Turn the small knob to display the desired position where you want to begin entering the new flight plan. Press "SEL" and turn the small knob to display your first waypoint. Pressing "ENT" will enter that waypoint and begin the next subsequent waypoint to flash. Continue to change the flashing waypoints with the small knob and entering the desired waypoint with the "ENT" button.

It is important to leave a "blank" waypoint in between each group of waypoints which comprise individual flight plans, this is how the 618 knows where one flight plan ends and the next begins.

Changing the Destination Waypoint (moving the arrow)


To manually move the arrow "-->" to a waypoint, turn the small knob so the desired destination waypoint is shown on the top line of the flight plan display. Press the "SEL" button to make it flash, then press the "TO" button to make the arrow move to this waypoint. The 618 will now navigate to this waypoint.

When a waypoint is flashing, pressing the "ENT" button will make the next waypoint flash. Pressing the "SEL" button when the waypoint is flashing will display information about that waypoint.

Creating a Sample Flightplan

Suppose you want to fly from your present position to the LAX VOR to MRY ^CR. Before proceeding, these waypoints must be in the PILOT COPY DATABASE.

1. MODE - NAV
2. LARGE KNOB - SCROLL to display flightplan page.




3. SMALL KNOB - TURN to desired position where you wish to begin entering the new flightplan.

NOTE:


It is important to note the location of the destination arrow. It may be located on a previously planned flightplan segment. In this case the arrow must be moved to the destination position before proceeding. To move the arrow, refer to Changing the Destination explained above.

4. **FRM** - **PRESS TWICE** within one second will select departure waypoint (waypoint preceding arrow) as your present position.




5. **SMALL KNOB** - **SCROLL** to position the "To" waypoint at the top of the display (the arrow points to the "To" waypoint).

6. **SEL** - **PRESS**. The "To" waypoint flashes.




7. **SMALL KNOB** - **TURN** to display LAXv.



8. **ENT** - **PRESS**. The next waypoint flashes.

9. **SMALL KNOB** - **TURN** to display MR Y C_R.



10. ENT - PRESS

11. Repeat steps 7 through 10 and enter each destination waypoint to complete the flightplan (up to 20 waypoints).

The NAV page now shows LAXv as your "To" waypoint. If you fly this route, after arriving at the LAX VOR, the ARIV (arrival) light will come on, and the waypoints will automatically sequence to MRY Cr.

Note


The ARIV light comes on when the aircraft is within 1 nautical mile per 100 knots of ground speed of your destination. One nautical mile is the minimum at which the ARIV light comes on.

DELETING FROM FLIGHTPLAN PAGE


Deleting Individual Waypoints

You are now deleting the waypoints you previously entered on the Flightplan page, MRY ^C_R and LAXv. This does NOT delete them from any databases.

1. **MODE - NAV**
2. **LARGEKNOB - TURN** to display the Flightplan page.
3. **SMALLKNOB - SCROLL** to position the waypoint to be deleted, at the top of the display.
4. **SEL - PRESS**
The selected waypoint flashes, in this case LAXv.
5. **SMALLKNOB - SCROLL** to display " - - - ".
" - - - " is at either end of the database.



6. **ENT - PRESS**
LAXv is deleted from the Flightplan. The flightplan automatically sequences, and MRY ^C_R becomes the "To" waypoint.




9. Repeat steps 4 through 6 to continue removing waypoints from the flightplan, or TURN the LARGE KNOB to stop.

Deleting the Active Flight Plan

While viewing the flight plan, turn the small knob counterclockwise until the 618 displays "ENT TO DELETE FLT PLAN". Note that pressing the "ENT" button will delete the flight plan that the arrow is pointing at. If there are multiple flight plans entered, only the group of waypoints which the arrow is pointing at will be deleted. If the arrow is pointing at a "blank" waypoint, the message "NO WPTS IN FLT PLAN" will be displayed.


1. MODE - NAV
2. LARGE KNOB - TURN to display the Flightplan Page.
3. SMALL KNOB - TURN counter clockwise to "ENT TO DELETE FLT PLAN".
4. ENT - PRESS to delete active flight plan.



Reversing the Active Flightplan

To reverse the active flight plan (the group of waypoints which the arrow is pointing at), turn the small knob clockwise to the display "ENT TO REVERSE FLT PLAN". Pressing the "ENT" button will reverse the order of the active flight plan. Any other inactive flight plans (groups of waypoints which the arrow is not pointing at) will remain unaffected. If the arrow is pointing at a "blank" waypoint, the message "INVALID "TO -->" WAYPOINT" will be displayed.

1. MODE - NAV
2. LARGE KNOB - TURN to display the Flightplan Page.
3. SMALL KNOB - TURN clockwise to "ENT TO REVERSE FLT PLAN".
4. ENT - PRESS to reverse active flight plan.




NOTES:

DELETING WAYPOINTS IN THE PILOT CREATED DATABASE

You now delete the waypoint you created in a previous example, MRY from the PILOT CREATED DATABASE. This automatically deletes the waypoint from the PILOT COPY DATABASE; however, deleting a waypoint from the PILOT COPY DATABASE does NOT delete it from any other database.

1. **MODE - WPT**
2. **SMALL KNOB or LARGE KNOB - TURN** to display PILOT CREATED DATABASE.
3. **ENT - PRESS**
4. **LARGE KNOB - SCROLL** to display the waypoint, MRY ^{C_R}, or press SEL and use LOOK FOR to display the waypoint.
5. **SEL - PRESS** with the MRY ^{C_R} waypoint displayed. The prompt, ENT TO DEL WPT appears.



ENT TO DEL WPT
MRY ^{C_R}

6. **ENT - PRESS**
The waypoint, MRY ^{C_R}, is deleted from both the PILOT CREATED and PILOT COPY databases.

NOTES:

EDITING A PREVIOUSLY CREATED WAYPOINT

If you wish to edit a waypoint you have stored in the PILOT CREATED DATABASE, follow the procedure for deleting a PILOT CREATED waypoint, except in step 5, press SEL a second time to display ENT TO EDIT WPT. You may then edit the waypoint in the same manner as when creating a new waypoint.

NOTES:

DELETING IN THE PILOT COPY DATABASE

You are now deleting a waypoint you copied in a previous example, LAXv, from the PILOT COPY DATABASE.

1. **MODE - WPT**
2. **SMALL KNOB or LARGE KNOB - TURN** to display the PILOT COPY DATABASE.
3. **ENT - PRESS**
4. **LARGE KNOB - SCROLL** to display LAXv, or press SEL and use LOOK FOR to display the waypoint.
5. **SEL - PRESS**
The prompt, ENT TO DEL WPT, appears.
6. **ENT - PRESS**
The waypoint is deleted from the PILOT COPY DATABASE.

Note

A waypoint that is being used in the Flightplan cannot be deleted.

NOTES:

DUPLICATE NDB IDENTIFIERS

There are no duplicate identifiers within any one state in the NORTH AMERICA DATABASE with the exception of a small number of NDBs, all of which have two-letter identifiers. Anytime you access an NDB with a two-letter identifier, check to be sure you've found the one you wanted. If another NDB exists with the same identifier, it exists "next door" in the database. You may access it by turning the LARGE KNOB one increment.

NOTES:

DISPLAYING INFORMATION

The NORTH AMERICA DATABASE contains all U.S. public-use airports, all intersections with five alpha-character designators, all VORs and NDBs, all public-use heliports and seaplane bases, and all major military bases. Also, information such as the longest runway length, all ATIS frequencies, tower frequencies, VOR frequencies, NDB frequencies, and ground frequencies are contained in this database.

CAUTION

All three-character military base identifiers are bracketed by a heavy bar (Example: ■SUU■). Four-character military identifiers are displayed with ■ after the last character in the identifier. Do not land at a military base unless you have an emergency or prior approval.

NOTES:

INTERPRETING INFORMATION

Begin by displaying the NORTH AMERICA DATABASE LISTING FOR LAX (Los Angeles International Airport).

1. **MODE - WPT**
2. **SMALL KNOB - TURN** to display the NORTH AMERICA DATABASE.
3. **ENT - PRESS**
4. **ENT - PRESS** again to select APT ID.
5. **SMALL KNOB - SCROLL** to display a flashing "L".
6. **ENT - PRESS**
7. **Steps 6 & 7 - REPEAT** to enter the "A", "X", and "_".
The LAX listing is displayed.

Note

The entire LAX listing contains a considerable amount of information. When a waypoint is first located in a database, only the first (top) three lines of the listing are displayed. The entire LAX listing is depicted on the following page in the left column. An explanation of each item in the list is shown in the column on the right. Think of the three line display on the unit as a "window" over this list. If you turn the SMALL KNOB one increment clockwise, the window will move down three lines; turn it one increment counterclockwise, and the window will move up three lines. If the window is already at the top of the list, and you turn the SMALL KNOB counterclockwise (up), it will "circle" to the bottom of the list. If the window is already at the bottom of the list, and you turn the SMALL KNOB clockwise (down), it will circle to the top of the list. Pressing "SEL" will cause the first information page to be displayed.

"Window"

LAX CA LOS ANGELES 175 1214
ATIS 13585 13380
U 12295
TWR 13360 11980
TWR 12055
GND 12185 12175
CLR DEL 12140
APP/DEP 12520 12430
APP/DEP 12850 12450
APP/DEP 12450
ILS 11110 11170
ILS 10850 10950
RUNWAYS 7L/25R 7R/25L

Identifier and State
City
Bearing and Distance from your position

ATIS frequencies

Unicom Frequency

Tower frequencies

Ground control frequencies

Clearance Delivery frequency

Approach and Departure frequencies

ILS frequencies

Displayed in descending order, longest first
Runway 7 Left/25 Right
Runway 7 Right/25 Left

RUNWAYS 6R/24L 6L/24R	Runway 6 Right/24 Left Runway 6 Left/24 Right
12000 L PAVED ELV 126	Longest rwy 12,000' (rounded down to nearest 100'); L = lighted. Runway surface paved (NOT PAVD = not paved) Airport Elevation 126'
FUEL YES	Fuel is available
LAX CA 33°5655 118°2443	Identifier and state Latitude Longitude

LAX has a full-time tower, so there is no CTAF page displayed, but a typical example is shown below.

CTAF 12290	Common Traffic Advisory Frequency
----------------------	-----------------------------------

Note

CTAF is for use when Tower or Unicom operations are closed, or do not exist.

Turning the **LARGE KNOB** allows you to display "nearby" (according to alphanumeric order) listings in the **NORTH AMERICA DATABASE**. For example, if you are viewing **LAX** and you turn the **LARGE KNOB** clockwise one increment, you are displaying the listings for **LA01** (Basile, LA). When viewing **LAX**, turn the **LARGE KNOB** one increment counterclockwise, you are displaying the listings for **LAW** (Lawton, OK). Note that all waypoints are sorted in alphanumeric order according to **IDENTIFIER**. Therefore, the listing for Newport, OR is not in the "Ns", but rather in the "Os", because the airport identifier is **ONP**.

NOTES:

INTERPRETING NAVAID INFORMATION

The information available on Nav aids and intersections is depicted below. VORs are all listed together alphanumerically in the database as are NDBs and intersections. For example, if you locate a VOR entry, the entries "surrounding" it will also be VORs. Each NAVAID listing is two pages long. All NDBs have "n" after the final character in the identifier, and all VORs have "v" after the final character in the identifier.

Note

NAVAID displays depict bearing to, not radial from, the NAVAID. The only time the unit recognises a Radial From is when defining a PHANTOM WPT as a Radial From a reference point.

NAVAID	UBGv OR	Identifier and State
	11740	Frequency
	343 92	Bearing and Distance from your position
NAVAID	UBGv OR	Identifier and state
	45° 2120	Latitude
	122° 5862	Longitude
INTERSECTION	ACORN TX	Identifier and State
	093 1512	Bearing and Distance from your position
INTERSECTION	ACORN TX	Identifier and state
	31° 5537	Latitude
	095° 1780	Longitude

NOTES:

SEARCHING BY CITY

Suppose you wanted to find information on Newport, OR, but you did not know the airport identifier was ONP.

Note

The NORTH AMERICA DATABASE is sorted alphanumerically according to identifier, not city.

1. **MODE - WPT**
2. **SMALL KNOB** or **LARGE KNOB - TURN** to display **NORTH AMERICA DATABASE**.
3. **ENT - PRESS**
4. **SMALL KNOB - TURN** to display city.
5. **ENT - PRESS**

Note

If you wanted to restore the name of the last city you searched for, press ENT again. With the name restored, pressing ENT once more will initiate the search. Press "SEL" to go to the desired character to change.

6. **SMALL KNOB - SCROLL** to display "N".
7. **ENT - PRESS**
8. **Steps 6 & 7 - REPEAT** to enter the E, W, P, O, R, T, _.
The first waypoint found is Newport, VT, instruct the unit to continue its search.

9. SEL - PRESS

CONTINUE LOOKING FORWARD is displayed.

*Note*

You normally search the database FORWARD according to alphanumeric order; however, if you wish to display a waypoint you previously elected to pass-up, you may select BACKWARD with the SMALL KNOB after completing Step 9.

10. ENT - PRESS

This time the search locates the listing for Newport, ME, and again you must instruct the unit to continue its search.

11. SEL - PRESS


12. ENT - PRESS

This time the search locates the listing for Newport, AR, continue the search.

13. SEL - PRESS

14. ENT - PRESS

The unit displays the listing for Newport, Oregon.



15. SMALL KNOB - TURN to display additional information on Newport, OR (ONP).

NOTE

Names like "Los Angeles" must be entered without the space between the words

SEARCHING FOR A NAVAID OR INTERSECTION

After selecting the LOOK FOR feature in the NORTH AMERICA DATABASE, turn the SMALL KNOB to display either NDB, INTERSEC, or VOR, as required, and execute the search according to the waypoint identifier.

NOTES:

ABBREVIATED SEARCHES

At times you may not know the entire identifier for a waypoint, or you may not know the spelling of a city name. Also, you may not want to enter all the characters in a long city name, or the city name may contain more than the eight characters it is possible to display. The unit always "searches" for matches that begin the same as the sequence you've entered.

Suppose you're planning a flight to Syracuse, KS, but you're not sure how to spell the city name, and you don't know the airport identifier.

1. **MODE - WPT**
2. **SMALL KNOB - TURN** to display the NORTH AMERICA DATABASE.
3. **ENT - PRESS**
4. **SMALL KNOB - TURN** to display "CITY".
5. **ENT - PRESS**
6. **SMALL KNOB - SCROLL** to display "S".
7. **ENT - PRESS**
8. **Steps 6 & 7 - REPEAT** to enter Y, R, _.
The first city found is Syracuse, NY. Instruct the unit to continue its search.
9. **SEL - PRESS**
CONTINUE LOOKING FORWARD appears.
10. **ENT - PRESS**
The listing for Syracuse, KS is displayed.

NOTES:

EMERGENCY SEARCH WITH SAFE - GLIDE™


IMPORTANT

EMERGENCY SEARCH WITH SAFE - GLIDE™ may be a valuable resource in an actual emergency; however, the information it provides should be considered advisory. The course of action a pilot chooses in an emergency should be based on the existing conditions. EMERGENCY SEARCH DOES NOT "CONSIDER" TERRAIN. The unit has no way of "knowing" if a mountain or other obstruction lies between you and an airport. Also, the unit DOES NOT CONSIDER WIND.

SAFE - GLIDE™ is incorporated in the EMERGENCY SEARCH Feature. When EMERGENCY SEARCH WITH SAFE - GLIDE™ is used, the airports are ordered according to the altitude and distance required to reach them. For example, an airport with an elevation of 2,500 ft MSL may be the closest to your location; however, an airport with an elevation of 500 ft MSL, while being somewhat further, may require less altitude to reach it. In this case, SAFE - GLIDE™ prioritizes the airports so that the airport at 500 ft MSL displays first. Before using EMERGENCY SEARCH WITH SAFE - GLIDE™, the feature must be set in SETUP MODE. (See the SETUP MODE section.)

Using Emergency Search With Safe - Glide™

Without II Morrow encoding altimeter:




1. APR/ENR & ENT - PRESS simultaneously.

After searching for the nearest waypoints, the altitude required to glide to the first airport is displayed on the top line. The length of the longest runway is displayed on the middle line, and the bearing and distance are displayed on the bottom line. Press SEL to view airport identifier, state, and city name. To view information on the displayed airport turn the small knob. If the runway length at the first airport is insufficient or the airport is otherwise undesirable, turn the LARGE KNOB cw to display the next airport. While viewing information, if you want to return to the first information page for the airport, press SEL.

Display alternates between ALT & REQ.

Meaning: altitude required to glide to the airport




IMPORTANT

Your glidepath is based on the information defined in SETUP Mode. SAFE - GLIDE™ DOES NOT CONSIDER WIND; however, as you glide toward the airport the ALTITUDE REQUIRED display will be continuously updated so you can monitor your progress. You should periodically check the required altitude as you proceed, especially if you have a headwind component. During your approach, if the aircraft's altitude becomes less than the required altitude, the airport is out of range; however, during final approach the required altitude is above the aircraft's altitude because SAFE - GLIDE™ brings the aircraft to the Airport Reference Point, not to the runway threshold.

If you want to exit Emergency Search without defining an emergency airport as your To waypoint, press APR/ENR and ENT simultaneously. (If you do not wish to exit Emergency Search, and you want to navigate to the displayed airport, continue with step 2).

2. TO - PRESS

The unit switches to NAV mode and the emergency airport is the To waypoint. The SAFE - GLIDE™ information periodically displays over the NAV pages.



Periodically flashes over NAV page

3. MODE - PRESS

ENT TO DISABLE SAFGLIDE appears. This is to allow you to disable SAFE - GLIDE™ if you are not in an engine-out emergency. (If you do not wish to exit Safeglide, Press MODE four times to re-enter NAV Mode).

NOTE


Changing the Flightplan disables SAFE - GLIDE™.



4. ENT - PRESS

SAFE - GLIDE™ displays are discontinued.

With II Morrow encoding altimeter:





1. **APR/ENR & ENT - PRESS** simultaneously.

After searching for the nearest waypoints, the length of the longest runway is displayed on the middle line, and the bearing and distance is displayed on the bottom line. If the displayed airport is within the gliding range of the aircraft **GLIDE OK** appears on the top line. This display alternates with a display showing how far (preceded by a "+" sign) the aircraft could glide after reaching the airport. If the airport is out of range, **TOO FAR** appears and alternates with the distance (preceded by a "-" sign) the aircraft would land short of the airport. Press **SEL** to view airport identifier, state, and city name. To view information on the displayed airport turn the small knob. If the runway length at the first airport is insufficient or the airport is otherwise undesirable, turn the **LARGE KNOB** cw to display the next airport. While viewing the airport identifier, state, and city name, press **SEL** to again view the **GLIDE OK/TOO FAR** page. If the Identifier/State/City page is displayed, and the airport is out of range, the city name flashes.

Indicates aircraft will glide 3.7 nm beyond airport.

Indicates airport is within gliding range.



Top line of display alternates back and forth.



Indicates airport is 1.7 miles too far.

Indicates airport is too far.

Top line of display alternates back and forth.




IMPORTANT

Your glidepath is based on the information you defined in SETUP Mode. SAFE - GLIDE™ DOES NOT CONSIDER WIND; however, as you glide toward the airport the GLIDE OK/TOO FAR display will be continuously updated so you can monitor your progress. You should periodically check this information as you proceed, especially if you have a headwind component. During your approach, if the aircraft's altitude becomes less than the required altitude, the airport is out of range, and TOO FAR appears. However, on short final approach TOO FAR may appear because the required altitude is above the aircraft's altitude. This is because SAFE - GLIDE™ brings the aircraft to the Airport Reference Point, not to the runway threshold.

If you want to exit Emergency Search without defining an emergency airport as your To waypoint, press APR/ENR and ENT simultaneously.

2. **TO - PRESS**

The unit switches to NAV mode and the emergency airport is the To waypoint. The SAFE - GLIDE™ information periodically appears over the NAV pages.




Periodically flashes with NAV page

3. **MODE - PRESS**

ENT TO DISABLE SAFGLIDE appears. (If you do not wish to exit SAFE - GLIDE™, press MODE as necessary to re-enter NAV Mode).

NOTE

Changing the flight plan disables SAFE - GLIDE™.



4. **ENT - PRESS**

SAFE - GLIDE™ displays are discontinued.

ALTITUDE SELECT

This feature alerts you as your aircraft enters the selected altitude or if your aircraft strays above or below the selected altitude by a user-specified value. The unit must be connected to a II Morrow altitude encoder and the altimeter setting must be input. Also, the feature must be set in SETUP MODE. (See the SETUP MODE section.)


Using Altitude Select

Nav Mode Alert:

After setting-up Altitude Select (if Altitude Select is on), as you fly into the selected altitude range while in NAV or AIRSP Mode, ALTITUDE flashes on the bottom line of the NAV display and the buzzer (if connected and selected) sounds four double beeps. When leaving the selected altitude range, the alert ("Altitude" Flashing and buzzer beeping) continues until you acknowledge it by pressing ENT or return within the altitude range.

NOTE

Single beeps indicate the WARN light has come on. Double beeps indicate Altitude Alert.



Flashes on NAV page until alert is acknowledged by pressing ENT.

Acknowledging An Alert:


This procedure stops the alert.

1. ENT - PRESS
The alert ceases.

Selecting a New Altitude Setting in NAV Mode:


This procedure changes the Altitude Select setting while in NAV mode.

1. **MODE - NAV**
2. **LARGE KNOB - TURN** to display any page except Present Position and Flightplan page.




BRG 312 ° NAV
ALT 4000
DST 45

3. **SEL - PRESS**
The ALT - SEL page appears and the current selected altitude flashes.




ALT - SEL NAV
ALTITUDE
7000 ft

4. **SMALL KNOB - TURN** to select the new altitude.



ALT - SEL NAV
ALTITUDE
7500 ft

5. **ENT - PRESS**
The NAV page reappears, and the new selected altitude entered.



BRG 312 ° NAV
ALT 4000
DST 45

USING NAV PLANNER


Note

The primary purpose of NAV PLANNER is to display bearing and distance to a waypoint from a waypoint other than your present position. You may use NAV PLANNER to view bearing and distance from your present position provided your present position has been determined as the original waypoint; however, this information is on the bottom line of the first page of each waypoint listing. To use NAV PLANNER, the waypoints you are interested in MUST first be copied into the PILOT COPY DATABASE.


1. **MODE - WPT**
2. **SMALL KNOB or LARGE KNOB - TURN** to display PILOT COPY DATABASE.
3. **ENT - PRESS**
4. **LARGE KNOB - SCROLL** to display ENT FOR NAV PLANNER, located at both ends of the PILOT COPY DATABASE.



5. **ENT - PRESS**
The NAV PLANNER page is displayed.




6. **SMALL KNOB - SCROLL** to display desired "Fr" waypoint.



7. **ENT - PRESS**

8. **SMALL KNOB - SCROLL** to display "To" waypoint.

The bearing and distance is displayed on the bottom line. You may scroll the **SMALL KNOB** to display bearing and distance to other waypoints in the **PILOT COPY DATABASE**.



Displaying Information When Using NAV PLANNER

1. **Desired waypoint - DISPLAY** flashing identifier using **NAV PLANNER** feature.
2. **SEL - PRESS**
3. **SMALL KNOB - SCROLL** to display information.
4. **SEL - PRESS** to return to the **NAV PLANNER** page.
If it is not on the first information page, press "SEL" twice to return to the **NAV PLANNER** page.


ALTIMETER AND VNAV SETUP

Note


Your unit **MUST** be connected to a II Morrow encoding altimeter, and the altimeter set before your altitude (ALT) is displayed. Since you may edit (customize) the NAV pages, it is possible to have your ALT and VNV read-outs on separate pages, or on the same page in the reverse order (from top to bottom) from the default (factory) page. If you have reversed the order of the read-outs, VNAV setup is enabled before SET ALTIMETER, the reverse of the order described here. Setting the altimeter is possible without the altitude encoder installed, but in this case no altitude information is available to the LORAN. If you have edited the default page so that VNV and ALT are on different pages, you are only able to adjust VNAV on the VNV page, and SET ALTIMETER on the ALT page. VNAV and ALTIMETER Setup is disabled when you are currently editing NAV pages.

To Set Altimeter


1. MODE - NAV
2. LARGE KNOB - TURN to display page with ALT.




3. SEL - PRESS
Press SEL twice if the altimeter has already been set. ENT TO SET ALTIMETR is displayed.



4. ENT - PRESS



5. **SMALL KNOB - SCROLL** to set current altimeter setting or field elevation.



Note

When you turn the power on, the unit will note any change in the barometric pressure since it was shut off, provided your position has not changed and you do not acknowledge the altimeter setting until the WARN light goes out. The unit will automatically adjust the altimeter setting to maintain the previous elevation.




6. ENT - PRESS

To Adjust VNAV Settings

1. **MODE - NAV**
2. **LARGE KNOB - TURN** to display VNV page.

3. SEL - PRESS three times

If your unit is not connected to a II Morrow encoder, only press SEL twice. ENT FOR VNAV SETUP is displayed.

**4. ENT - PRESS****5. SMALL KNOB - TURN** to adjust the desired GSA (Glide Slope Angle). The possible settings range from 0.0 to 9.9 degrees.**6. ENT - PRESS****7. SMALL KNOB - TURN** to adjust the first three EL digits. This defines the altitude you wish to descend to.

Note

When you are flying to an airport in the NORTH AMERICA DATABASE, the EL altitude is automatically set to the elevation of the destination airport.

8. ENT - PRESS

9. Steps 7 & 8 - REPEAT to enter the remaining two EL digits.

Note

If your unit is connected to a II Morrow encoding altimeter, the ARIV light will flash approximately two minutes before reaching the Top of Descent Point. The ARIV light continues to flash for approximately 20 seconds.

CHANGING COURSE WHILE ENROUTE

Any number of factors, such as weather along your route of flight or ATC instructions, may cause you to deviate from your intended course. Once off course, it's often preferable to define a new course direct to your destination from your present position rather than return to your original course.

1. **FRM - PRESS** twice.


Regardless of the mode you're in, the unit automatically inserts your present position as the departure waypoint, and switches to NAV mode.

NOTES:

LINING-UP WITH A RUNWAY

You may wish to line-up with a runway to execute a straight-in approach before you have the runway in sight. Suppose you are approaching your destination airport from the SE, without the airport in sight, and you would like to line-up with runway 30.

1. **MODE - NAV**
2. **LARGE KNOB - TURN** to display BRG.
3. **Aircraft heading - TURN** to intercept the 300 bearing to your destination. In this example a heading of 270 would provide a 30 degree intercept angle.
4. **BRG display - MONITOR**, and when it approaches 300, complete Step 5.
5. **Aircraft heading - TURN** to 300.
6. **FRM - PRESS** twice within one second.
You have defined a straight-in course to runway 30.




NOTES:


POSITION CALIBRATION

Due to local conditions, the NAV Position Display may be slightly in error. These errors are generally so small they are insignificant for normal operations. However, if highly precise navigation is called for, calibration factors (also called ASFs--Additional Secondary Phase Factors) may be entered.


1. **MODE - NAV**
2. **LARGE KNOB - TURN** to display Position page.
3. **SEL - PRESS**
"ALT POS?" (Alternate Position) flashes on the top line.




4. **SMALL KNOB - TURN** to display LAT CAL? (Latitude Calibration) or LON CAL? (Longitude Calibration), as required.



5. **ENT - PRESS**



6. **SMALL KNOB - TURN** (clockwise for +, counterclockwise for -) to display the known latitude or longitude.




7. **ENT - PRESS**

The ASF light is on as a reminder calibration factors are in use. To remove calibration factors, repeat the above procedure, selecting a calibration factor of "0" in step 6.

ALTERNATE SOLUTION

LOPs intersect in two locations, so there are two possible solutions to the unit's position calculations. Normally the unit is able to "determine" which solution is correct. On rare occasions, however, the unit may display the wrong solution. This error is usually quite easy to recognize because it is a considerable magnitude. The alternate solution is generally at least several hundred miles from your position. If the unit is displaying the wrong solution, you can manually select the correct solution.

1. **MODE - NAV**
2. **LARGE KNOB - TURN** to display Position page.
3. **SEL - PRESS**



4. **ENT - PRESS**
The other solution is displayed.
5. **ENT - PRESS**
If you wish to use the displayed position.

NOTES:

NEAREST WAYPOINT SEARCH

1. **MODE - WPT**
2. **SMALL KNOB - TURN** to display NEAREST WAYPOINT DATABASE.



3. **ENT - PRESS**



4. **SMALL KNOB - TURN** to display APT ID, INTERSEC, VOR, NDB, or CREATED.



5. **ENT - PRESS**


The nearest waypoint will be displayed. Turning the **LARGE KNOB** clockwise will display the 25 nearest waypoints in succession, with the nearest first. If you wish to navigate to one of these waypoints, display the waypoint and press **TO**.

Note

If the WARN light is on, the unit cannot accurately determine your position. NEAREST WAYPOINT uses the last "known" position until the WARN light goes out.

AIRSPACE ALERT

The AIRSP light flashes when you are approaching or entering the following U.S. and Canadian airspace areas: TCAs, TRSAs, ARSAs, MOAs, Alert Areas, Prohibited Areas, Restricted Areas, CYAs, CYDs, CYRs, and Class C Control Zones. The configuration of AIRSP mode is depicted below.



Distance and Altitude Buffers

Note


Adjusting the Distance Buffer and Altitude Buffer is explained in the SETUP MODE section of this manual. The unit comes with factory settings in these buffers, so it is NOT necessary for you to make any adjustments in SETUP mode before proceeding with this example.

The DISTANCE BUFFER defines the distance from airspace areas at which you would like to be alerted. If your unit is connected to a II Morrow encoding altimeter, an ALTITUDE BUFFER is also available. This tells

The **DISTANCE BUFFER** defines the distance from airspace areas at which you would like to be alerted. If your unit is connected to a II Morrow encoding altimeter, an **ALTITUDE BUFFER** is also available. This tells the unit the altitude above or below airspace areas that you would like the AIRSP light to come on. For example, if you were flying 1,200 ft above the ceiling of a TCA, and your **ALTITUDE BUFFER** were set at 1,000 ft, the unit does not bother you with an alert. If your altitude was 800 ft above the TCA, you would be alerted.


Note

*The **ALTITUDE BUFFER** is not available unless your unit is connected to a II Morrow encoding altimeter.*



INTERPRETING AIRSPACE ALERT INFORMATION


Suppose you're making the flight depicted below, from Red Bluff (RBL), California to Cameron Airpark (O61), California. The approximate locations where you would receive airspace alerts have been assigned letters, and following those letters in the text is an explanation of the displays you would encounter. This depiction is based on the setting of 20nm in the DISTANCE BUFFER, and assumes the unit is either NOT connected to a II Morrow encoding altimeter, or that you're flying within the boundaries of the ALTITUDE BUFFER.



A. When your aircraft comes within 20nm of the China MOA, the AIRSP light alerts you by flashing. The AIRSP light will stop flashing only after you have acknowledged the alert by displaying the flashing airspace name and pressing ENT.

1. **MODE - AIRSP**

The name of the airspace (CHINA) is flashing.



2. **ENT - PRESS**

This acknowledges the alert. CHINA and the AIRSP light stop flashing.

3. **SMALL KNOB - TURN** for information.


Note

The unit displays an abbreviated name of the controlling agency for Restricted Areas, Alert Areas, and MOAs. Communication frequencies are displayed for ARSAs, TRSAs, and TCAs.

Resetting the II Morrow Encoding Altimeter


If while displaying information on CHINA MOA you wanted to change your altimeter setting, you could use the following procedure.

- a. **SMALL KNOB - TURN** to display (in AIRSP mode) the page depicting the vertical boundaries of the airspace. This page is one click clockwise from the page displaying the name of the airspace.



- b. **SEL - PRESS**

SET ALT is displayed, and the current altimeter setting flashes.



- c. **SMALL KNOB - SCROLL** to display correct altimeter setting.

- d. **ENT - PRESS**


4. **MODE - NAV**

B. Your proximity to BEALE AFB ARSA has activated the alert.

1. **MODE - AIRSP**

Since you are still closer to the CHINA MOA than to the BEALE AFB ARSA, the first page displayed is the CHINA MOA, but the name (CHINA) is not flashing because you have already acknowledged it.

2. **LARGE KNOB - TURN** one increment clockwise.
The BEALE alert page is displayed.



3. **ENT - PRESS**

Note

Normally, after you acknowledge an alert, the AIRSP light turns solid. However, if a new alert is detected while you're looking at a previous alert, the AIRSP light does NOT turn solid until the new alert is acknowledged as well. The AIRSP light continues to flash until all alerts are acknowledged. The unit can recognize up to a maximum of 9 alerts at one time.

4. **SMALL KNOB - TURN** to display information.

C. Suppose while you're looking at information on BEALE AFB ARSA, your proximity to HUMMER MOA triggers another alert. The AIRSP light, which had turned solid when you acknowledged the BEALE AFB ARSA, begins flashing again.

1. **LARGE KNOB - TURN** one increment clockwise.
You were displaying the number 2 alert; therefore, this takes you to the new alert page, displaying HUMMER MOA as the number 3 alert area. Regardless of whether you're displaying information or viewing the main alert page, turning the LARGE KNOB clockwise displays the next alert, or counter-clockwise the previous alert.

Note


HUMMER MOA is made up of five areas, HUMMER 1, HUMMER 2,...HUMMER 5. The unit does NOT recognize these individual sections, but rather HUMMER 1-5 MOA as a whole. The altitude of the highest section is considered the top of the entire area, and the altitude of the lowest floor, the floor of the entire area.

2. ENT - PRESS

D. A new alert is triggered by the SACRAMENTO METRO ARSA.

1. MODE - AIRSP

2. LARGE KNOB - TURN to display the SACRAMENTO ARSA.


*Note*

Two other ARSAs are adjacent to the SACRAMENTO ARSA, but the unit recognizes all three ARSAs as the SACRAMENTO ARSA.

3. ENT - PRESS


4. SMALL KNOB - TURN to display information.

Suppose while your viewing information on the SACRAMENTO ARSA, the CHINA MOA goes out of the range set in the DISTANCE BUFFER. The unit no longer considers CHINA MOA as one of the five closest areas, and no longer displays it in AIRSP mode. When you return to the alert page, the SACRAMENTO ARSA will be renumbered to indicate the new order.


*Note*

Anytime the order, according to proximity to your position, of the alert areas changes, they are automatically renumbered and rearranged according to the new order. If you are displaying an area that drops out of range, the display, AREA OUT OF RANGE, appears.

The inverted wedding cake detail of a TCA is not included in the Apollo 618 memory. Only the outer boundary and the ceiling of TCA's, ARSA's, and TRSA's are used for alert purposes to simplify the display and minimize the number of alerts the pilot must acknowledge. The surface is used as the floor of the entire area for all airport related special use airspace.




Some Restricted Areas and Military Operation Areas (MOA's) have a published floor above the surface.



GENERAL

The SETUP Mode configuration is depicted below, and each display is paired with a page number so that an explanation of that display can easily be located in this section. The LARGE KNOB is used to scroll through the SETUP Mode pages. Some of the pages are not applicable to normal operations. The SERVICE DISPLAYS are normally meaningful only to service personnel. The SIGNAL INFORMATION displays are likewise not applicable to normal operations; however, if the pilot encounters an



unexpected WARN light, or if the WARN light fails to go out within four minutes after the power is turned on, the pilot may want to view the ADVISORY WARN page to determine the reason for the WARN light. If the aircraft is used by more than one pilot, it's important to scroll through the PILOT SETUP pages before flight to insure the unit is properly set up. Begin by entering SETUP Mode

Note

In graphic displays, such as the ones on page S-4, a white background indicates that the item will be flashing. The exact displays you will see on your unit may differ due to previously entered settings.


PILOT SETUP PAGES

Pilot Setup contains ten main pages, and is used to customize displays and make setting adjustments. For example; XTD SENS is used to adjust the sensitivity of the CDI, and NAV MODE SETUP is used to customize NAV displays and turn on/off AUTO NAV SCROLL.

GRI AND TRIAD SELECTION

Look in the LORAN CHAINS section of the Pilot's Operating Handbook (POH) to find the chains that provide coverage in the area(s) you'll be flying in.

When you first enter SETUP mode, the page depicting the name and the GRI of the currently selected chain will appear momentarily, and then the unit will automatically display the page that depicts the GRI on the top line.



Note

Each "s" indicates the unit is conducting a search to acquire a signal from the appropriate station in the chain. After each station signal has been acquired, the "s" will change to a lower-case letter (except for the Master, which is always represented by an upper-case letter), either M, w, x, y or z. When a triad is selected, either automatically or manually, the lower-case letter representing each selected station will change to upper-case. The Master (M) station will always be in the triad.


1. SEL - PRESS

The display depicting the name of the currently selected chain will reappear, and the GRI numbers will flash.

White background indicates characters are flashing



2. **SMALL KNOB - TURN** to display the desired GRI.
The North East USA chain is depicted below.



3. ENT - PRESS

The page depicting the GRI on the top line will reappear, and "Auto" will be flashing on the bottom line. This refers to automatic triad selection. Normally you will use automatic triad selection. Anytime the power switch is cycled, automatic triad selection is activated.



If Manual Triad Selection is Desired:

- a. **SMALL KNOB - TURN** to display "Manual" after warn lite goes out.




b. ENT - PRESS

The letters representing the secondaries in the chain will flash.



c. SMALL KNOB - TURN to display desired secondaries in upper case letters.

**d. ENT - PRESS**


The station letters will stop flashing. To return to automatic triad selection press SEL twice, select "Auto" with SMALL KNOB, and press ENT.

NOTES:


ALTITUDE SETUP

This procedure is used to select the target and buffer altitudes for the Altitude Select feature, and to set the altimeter. This is only applicable to units connected to a II Morrow Encoding Altimeter.


1. **MODE - SETUP**
2. **LARGE KNOB - TURN** to display ENT FOR ALTITUDE SETUP.




3. **ENT - PRESS**
ALT-SEL ALTITUDE will appear.



4. **SEL - PRESS**
The current Altitude Select setting will flash.




5. **SMALL KNOB - TURN** to select the altitude.




6. ENT - PRESS

A rectangular display box with a dotted background. The text inside reads "ALT-SEL" on the first line, "ALTITUDE" on the second line, "7000 ft" on the third line, and "SETUP" in smaller text on the right side of the third line.


7. **SMALL KNOB** - TURN one click cw.
The ALT-SEL BUFFER page will appear.

A rectangular display box with a dotted background. The text inside reads "ALT-SEL" on the first line, "BUFFER" on the second line, "± 150 ft" on the third line, and "SETUP" in smaller text on the right side of the third line.


8. **SEL** - PRESS
The current buffer altitude will flash.

A rectangular display box with a dotted background. The text inside reads "ALT-SEL" on the first line, "BUFFER" on the second line, "± 150 ft" on the third line, and "SETUP" in smaller text on the right side of the third line. The number "150" is enclosed in a small rectangular box, indicating it is flashing.

9. **SMALL KNOB** - TURN to select the buffer altitude.


A rectangular display box with a dotted background. The text inside reads "ALT-SEL" on the first line, "BUFFER" on the second line, "± 300 ft" on the third line, and "SETUP" in smaller text on the right side of the third line. The number "300" is enclosed in a small rectangular box, indicating it is flashing.

10. ENT - PRESS

A rectangular display box with a dotted background. The text inside reads "ALT-SEL" on the first line, "BUFFER" on the second line, "± 300 ft" on the third line, and "SETUP" in smaller text on the right side of the third line.


11. **SMALL KNOB - TURN** to display the ALTITUDE SELECT ON/OFF page.

ALTITUDE SELECT will not operate unless ON is selected. To change the current setting, complete steps 12 through 14; otherwise, skip to Step 15.




12. **SEL - PRESS**


The current setting (ON or OFF) will flash.




13. **SMALL KNOB - TURN** to select ON or OFF.



14. **ENT - PRESS**




15. **SMALL KNOB - TURN** one click cw to display the SET ALT page.



16. SEL - PRESS

The altimeter setting will flash.




17. SMALL KNOB - TURN to display the correct altimeter or altitude setting.



18. ENT - PRESS

The altimeter will be set.



NAV MODE SETUP

This feature allows you to customize your NAV displays and adjust and activate AUTO NAV SCROLL.

Note

The NAV mode Position page, Flightplan page, and RETURN TO page are fixed and cannot be edited.

Editing (customizing) NAV Pages

1. **MODE - SETUP**
2. **LARGE KNOB - TURN** to display ENT FOR NAV MODE SETUP.



3. **ENT - PRESS**



4. **SEL - PRESS**
"Off" will flash.




5. **SMALL KNOB** - TURN to display "On".




6. **ENT** - PRESS


The unit will automatically switch to NAV mode. The page displayed will be the first page of the six Nav pages that may be customized. If using the default NAV pages, this page will be the BRG/DST/To page.




7. **LARGE KNOB** - TURN to display the NAV page you would like to edit. The DST/CDI/To page is depicted below.



8. **SEL** - PRESS once, twice, or three times to cause the line you wish to edit to flash. The middle line is shown as flashing in the illustration below.



9. **SMALL KNOB - TURN** to display the desired NAV information.
In the illustration below, GS replaces the CDI line.




10. ENT - PRESS

If you edited the top or middle line, the next line down will flash. Press ENT if you do not want to edit the flashing line, or turn the SMALL KNOB if you want to edit the line and then press ENT. If you want to edit another page, turn the LARGE KNOB to display the desired page, and then proceed with steps 6, 7, and 8. Once you leave NAV mode, the editing feature will automatically be set to "Off."

Restoring Default NAV Pages

Before proceeding, display in SETUP mode the ENT FOR NAV MODE SETUP page.

1. **MODE - SETUP**
2. **LARGE KNOB - TURN** to display ENT FOR NAV MODE SETUP.



3. ENT - PRESS



4. SEL - PRESS



5. SMALL KNOB - TURN to display "Default".



6. ENT - PRESS

The Default NAV pages will be restored.

Auto Nav Scroll

This feature will cause selected NAV pages to scroll at a selected rate.


1. MODE - SETUP

2. LARGE KNOB - TURN to display ENT FOR NAV MODE SETUP.



3. ENT - PRESS

The EDIT NAV PAGES page will be displayed.



4. **SMALL KNOB** - TURN to display AUTO NAV SCROLL page.




5. **SEL** - PRESS
"Off" will flash.




6. **SMALL KNOB** - TURN to display "On".




7. **ENT** - PRESS
HOW MANY PAGES TO SCROLL will be displayed.




8. **SMALL KNOB** - TURN to display the number of NAV pages you want to scroll.




9. ENT - PRESS



10. **SMALL KNOB** - TURN to display the first page you want in the scroll.




11. ENT - PRESS



12. **Steps 10 & 11** - REPEAT to enter remaining pages you want include in the scroll.

When this is completed DISPLAY EACH NAV PG will be displayed.



13. **SMALL KNOB** - TURN to display the number of seconds you want each page to be displayed.



14. ENT - PRESS

The unit will automatically switch to NAV mode, and the selected pages will scroll.

To Pause AUTO NAV SCROLL On The Displayed Page

Turning any knob, or pressing any button (except MODE or TO) stops NAV SCROLL.

To Reactivate AUTO NAV SCROLL After Pausing**1. ENT - PRESS****To Turn AUTO NAV SCROLL Off**

Select "off" in Step 6 of the Auto Nav Scroll procedure.

Note

When the power switch is cycled, AUTO NAV SCROLL will default to the last setting used ("on" or "off").

NOTES:

AIRSPACE SETUP

This procedure is used to turn Airspace Alert On/Off, and select the buffer altitude and distance.

Activating/Deactivating AIRSPACE ALERT

Note

Thereafter, when the power is turned on, the unit will default to the last setting used.

1. MODE - SETUP
2. LARGE KNOB - TURN to display ENT FOR AIRSPACE SETUP.



3. ENT - PRESS



4. SEL - PRESS



5. **SMALL KNOB** - TURN to display "Off" or "On", as desired.



6. **ENT** - PRESS



Setting DISTANCE BUFFER

This feature allows you to select the distance from the various airspace areas that you would like to alerted that you are approaching an airspace area. If you have just completed Activating/Deactivating AIRSPACE ALERT, leave the AIRSPACE ALERT page displayed, and skip to Step 4.

1. **MODE** - SETUP
2. **LARGE KNOB** - TURN to display the ENT FOR AIRSPACE SETUP page.



3. **ENT** - PRESS



4. **SMALL KNOB** - **TURN** to display the **DISTANCE BUFFER** page.



5. **SEL** - **PRESS**



6. **SMALL KNOB** - **SCROLL** to display the desired distance.



7. **ENT** - **PRESS**



Setting ALTITUDE BUFFER

The altitude buffer "tells" the unit the altitude above or below airspace areas at which you want the AIRSP light to alert you. For example, if you were flying 1,200 ft above the ceiling of a TCA, and your ALTITUDE BUFFER were set at 1,000 ft, the unit would not bother you with an alert; however, if your altitude were 800 ft above the TCA, you would be alerted. With the same 1000 foot setting, if you were flying 1500 foot below the floor of a Restricted Area, you would not be bothered with an alert. If you have just completed setting the DISTANCE BUFFER, leave the DISTANCE BUFFER page displayed, and skip to Step 4.

Note

If your unit is not connected to a II Morrow encoding altimeter, the ALTITUDE BUFFER will not exist.


1. **MODE - SETUP**
2. **LARGE KNOB - TURN** to display the ENT FOR AIRSPACE SETUP page.




3. **ENT - PRESS**




4. **SMALL KNOB - TURN** to display the ALTITUDE BUFFER page.




5. SEL - PRESS



6. **SMALL KNOB** - TURN to display the desired buffer altitude.
If you select "Unlimited," you will be alerted to all airspace areas, regardless of your altitude.



7. ENT - PRESS.



NOTES:

SAFE - GLIDE™ SETUP


It will be necessary to input the descent rate and best glide speed in the SETUP mode using aircraft flight manual data to take full advantage of this feature. This procedure defines the distance the aircraft glides while descending 1000 feet, and the best glide speed for your aircraft. The unit uses this distance plus the airport elevation to determine the altitude required for your aircraft to glide to the airport. The best glide speed is used only as a reminder. Consult the Pilot's Operating Handbook (POH) for your aircraft to determine best glide speed, and the distance your aircraft will travel while descending 1,000 ft. You may want to verify these figures for your specific aircraft using simulated engine-out power, on an evaluation flight.

1. MODE - SETUP

2. LARGE KNOB - TURN to display ENT FOR SAFGLIDE SETUP.




3. ENT - PRESS




4. SEL - PRESS


The distance value will flash.




5. **SMALL KNOB - TURN** to select the distance your airplane will glide while descending 1000 feet.



6. **ENT - PRESS**



7. **SMALL KNOB - TURN** one click either direction.
The **BEST GLIDE** page will appear.




8. **SEL - PRESS**
The best glide airspeed value will flash.



9. **SMALL KNOB** - TURN to select the best glide speed.



10. **ENT** - PRESS



NOTES:

EXTERNAL INDICATOR SETUP

This feature allows you to control the external warning output from the Loran to meet your specific needs. Three selections are available:

VFR LITE

If the Apollo 618 is being used to replace an IFR certified unit such as the model 612, you may choose to select VFR LITE. This causes the LORAN VFR annunciator, used in IFR installations, to be lighted continuously assuring that the pilot is notified the 618 is not certified for IFR use.

BUZZER

If you choose to install an external warning indicator such as an audio alert or special purpose warning light, you can activate this indicator by selecting BUZZER. This selection will cause the LORAN to activate the warning for the following:

- Approaching the selected altitude (See Altitude Select in Navigation section).
- An Altitude excursion (See Altitude Select in Navigation section).
- If the WARN light goes on while in flight.

NONE


This selection turns both of the above features off.

1. **MODE - SETUP**
2. **LARGE KNOB - TURN** to display ENT FOR EXTERNAL INDICATOR.



3. ENT - PRESS

The current selection appears.

**4. SMALL KNOB - TURN** to display your selection on the bottom line.**5. ENT - PRESS****If Buzzer Is Not Selected:**

- The pilot must always acknowledge an alert by pressing ENT.

IF Buzzer Is Selected:

- A brief altitude arrival reminder will be given.
- An altitude excursion will be canceled automatically upon returning to the altitude range.
- You may also cancel any alert manually by pressing ENT.

MAG VAR (Magnetic Variation)


Your Apollo "knows" the variation for the area you're flying in, and automatically references NAV pages to Magnetic Course. Magnetic variation changes slightly from year-to-year, so you will "tell" the unit what year it is.

Entering the MAG YEAR

1. **MODE - SETUP**
2. **LARGE KNOB - TURN** to display the ENT FOR MAG VAR SETUP page.



3. **ENT - PRESS**
The page depicting the current MAG VAR settings will be displayed.



4. **SMALL KNOB - TURN** to display MAG YEAR page.



5. SEL - PRESS


The current MAG YEAR setting will flash.

**6. SMALL KNOB - Turn to display the desired MAG YEAR.****7. ENT -PRESS****Selecting "Manual" MAG VAR Setting**

If desired, you may manually enter the variation. The Apollo 618TCA comes from the factory with MAG VAR set to automatic. Thereafter, when you turn the power on, the unit will default to the last setting used. If you have just completed setting the MAG YEAR, turn the SMALL KNOB to display the page depicting the current MAG VAR settings, and to Step 4.

1. MODE - SETUP**2. LARGE KNOB - TURN to display the ENT FOR MAG VAR SETUP page.**

3. ENT - PRESS



4. SEL - PRESS



5. SMALL KNOB - TURN to display "Manual".



6. ENT - PRESS

The current variation setting will flash.



7. SMALL KNOB - SCROLL to display desired variation, clockwise for westerly, counterclockwise for easterly (W=West/E=East).




8. ENT - PRESS

MAG VAR
15 ° W SETUP
Manual


XTD SENS (Cross Track or CDI Sensitivity)

You may adjust the sensitivity of the CDI manually, or use Auto (Automatic) sensitivity. When using "Auto", the sensitivity automatically becomes more sensitive when you are within one nautical mile of your desired course. The CDI bar graph, made up of a series of dots, is only one dot wide when you are using automatic sensitivity and are within one nautical mile of your desired course. When using automatic sensitivity and you are more than one nautical mile off-course, the bar graph will be three dots wide. When using manual sensitivity, the bar graph display will be two parallel rows of dots. The Apollo® 618 comes from the factory with XTD SENS set to "Auto". Thereafter, when the power is turned on, the unit will default to the last setting used. In the illustration below, each bar represents five dots; the individual dots are not depicted.




Selecting Auto or Manual Sensitivity


1. **MODE - SETUP**
2. **LARGE KNOB - TURN** to display the XTD SENS page.




3. **SEL - PRESS**



4. **SMALL KNOB - TURN** to display "Auto" or "Manual", as desired.




5. **ENT - PRESS**




Adjusting Manual Sensitivity


After entering MANUAL sensitivity, the sensitivity value will flash.



1. **SMALL KNOB - SCROLL** to display the desired sensitivity. Sensitivity values for each dot of deflection range from .01 to 1.0 nm.



2. **ENT - PRESS.**




NOTES:

COURSE OFFSET


This feature allows you to fly a course parallel to the original course, at a specified distance. The parallel course may be either left or right of the original course, at a distance from 0.1 to 99.9 nautical miles (selected in 0.1 nm increments). Normally you will leave the offset value at 0.

Setting COURSE OFFSET

1. **MODE - SETUP**
2. **LARGE KNOB - TURN** to display the COURSE OFFSET page.



3. **SEL - PRESS**




4. **SMALL KNOB - TURN** to display the desired offset value.
Turning the **SMALL KNOB** left will define a course to the left of the original course, and turning the **SMALL KNOB** right will define a course to the right of the original course.



5. ENT - PRESS

The offset value will stop flashing, and course guidance will be referenced to the offset course. The OFST indicator will be lighted as a reminder the offset feature is in use. Repeat the above steps to reset the offset to 0.




EXTENDED RANGE

This feature allows the pilot to navigate into fringe Loran-C coverage areas. When EXTENDED RANGE is activated, the Apollo 618 will lock onto the current tracking point of the Loran-C pulses. Normally you will leave EXTENDED RANGE "Off".

Activating EXTENDED RANGE

Activate this feature only in an area with adequate coverage, BEFORE flying into fringe areas.

1. MODE - SETUP




2. LARGE KNOB - TURN to display the EXTENDED RANGE page.


Note

EXTENDED RANGE is automatically set to "Off" when the power switch is cycled. When EXTENDED RANGE is activated, LAT/LONG CAL factors may be adjusted within a range of +/- 99.9 minutes, instead of the normal range of +/- 9.99 minutes. If EXTENDED RANGE is turned off while the unit is on, calibration factors exceeding 9.99 will automatically be set to 9.99; however, calibration factors less than +/- 9.99 will be retained until you remove them. Before proceeding, display in SETUP MODE the EXTENDED RANGE page.

3. SEL - PRESS




4. **SMALL KNOB - TURN** to display "On".



5. **ENT - PRESS**

Repeat the above procedure to reenter the "Off" setting.




SERVICE DISPLAYS

There are two service displays. Their purpose is to help technicians diagnose problems. They do not apply to normal operations; however, it's extremely helpful if you have the information on these displays available when you contact your dealer or the factory concerning a problem.

VERSION

This is used to display the software version number for the operating system (OPER SYS), the Database Version, the Datecode for the North America and Seabase/Heliport database (the date the software was last updated), the Front End Processor (FEP) version number, and the Datecode for the Airspace database. If you contact your dealer or the factory, have these numbers handy.

1. **MODE - SETUP**
2. **LARGE KNOB - TURN** to display the **VERSION (OPER SYS)** page.



3. **SMALL KNOB - TURN** one click cw to display the **VERSION (DATABASE)** page.



4. **SMALL KNOB** - TURN one click cw to display the **DATECODE DATABASE** page.
This displays the date of the North America and Seabase/Heliport database.

DATECODE
09/21/89 SETUP
DATABASE

5. **SMALL KNOB** - TURN one click cw to display the **VERSION (FEP)** page.

VERSION
2.1 SETUP
FEP


6. **SMALL KNOB** - TURN one click cw to display the **DATECODE AIRSPACE** page.
This displays the date of the Airspace database.

DATECODE
09/19/89 SETUP
AIRSPACE

OSC OFST/TMP (Oscillator Offset/Temperature)


This is used to display the OSCs for each station in the chain. This information is used by service personal to determine crystal operating parameters. The TMP display (bottom line) indicates the internal temperature of the crystal in degrees Celsius. OSC OFST/TMP values will vary slightly. The following displays are examples only.

1. **MODE - SETUP**
2. **LARGE KNOB - TURN** to display the OSC OFST page.
The OFST for M (Master) will be displayed.



OSC OFST
M - 2029 SETUP
TMP 21°C

3. **SMALL KNOB - TURN** one click cw to display the OSC OFST value for W (Whiskey).



OSC OFST
M - 1942 SETUP
TMP 22°C

4. **STEP 3 - REPEAT** as necessary to display the OFST for the remaining secondaries.

NOTES:

SIGNAL INFORMATION

There are five main pages contained in signal information displays. They are used to evaluate the signals from the stations on the selected chain. They generally do not apply to normal operations; however, if the WARN light comes on or will not go off, view the ADVISORY WARN page to determine the reason for the WARN light. If you encounter a problem, try to record the SNRs, SIGs, and ECDs. This information may be valuable to service personnel.

TD (Time Difference)

This is used to display TDs for the stations in the LORAN CHAIN. TDs reflect the distance a receiver is from a station, and are used by the receiver to define two intersecting LOPs.

1. MODE - SETUP

2. LARGE KNOB - TURN to display the TD page.

The TDs (in microseconds) between the Master and two of the secondaries are displayed on the middle and bottom lines.

```

TD W&X
1266256
2807738 SETUP
  
```

SMALL KNOB - TURN one click cw to display the TDs between the Master and the remaining secondaries in the chain.

```

TD Y
4392130
SETUP
  
```

NOTES:

ECD (ENVELOPE-TO-CYCLE DIFFERENCE)

This is used to display the ECD values for stations in the selected chain. They are used to monitor the distortion of the LORAN-C signal.

1. MODE - SETUP

2. LARGE KNOB - TURN to display the ECD page.

The ECD for the Master is displayed on the top line, and for two of the secondaries on the middle and bottom lines.

E	M	1	3	
C	W	1	4	
D	X	1	0	SETUP

3. SMALL KNOB - TURN one click cw or ccw to display ECDs for the remaining secondaries. Use the chart at the bottom of this page to help evaluate ECDs.

E	M	1	3	
C	Y	1	2	
D				SETUP


- +5 Unreliable
- +4 Poor
- +3 Fair
- +2 Good
- +1 Good
- 0 Good
- 1 Good
- 2 Good
- 3 Fair
- 4 Poor
- 5 Unreliable

NOTES:

SIG (Signal Level)

This is used to display the Signal Levels for the stations in the selected chain. Values range from 0 to 100. Provided the receiver has locked onto the signal, and the SNR values are adequate, the SIG values may drop very low and still provide adequate navigation information.


1. MODE - SETUP



S M 47
I W 68
G X 43 SETUP

2. LARGE KNOB - TURN to display the SIG page.

The signal level for the Master is displayed on the top line, and for two of the secondaries on the middle and bottom lines.



S M 47
I Y 71
G SETUP

3. SMALL KNOB - TURN one click cw or ccw to display the signal levels for the remaining secondaries.

NOTES:


SNR (Signal to Noise Ratio)

This is used to display SNRs for the stations in the selected chain. SNR values range between 0 and 100, with the higher values indicating a stronger signal in relation to the amount of noise being received. If the SNR becomes less than 25, the WARN indicator will come on.

1. MODE - SETUP


2. LARGE KNOB - TURN to display the SNR page.

The SNR for the Master is displayed on the top line, and for two of the secondaries on the middle and bottom lines.



3. SMALL KNOB - TURN one click cw or ccw to display SNRs for the remaining secondaries.

A reference guide at the bottom of this page is given below to help evaluate SNR values.



70 to 100	Excellent
40 to 69	Good
30 to 39	Fair
6 to 29	Poor
0 to 5	No signal

Low SNR values can be caused by one or more of the following factors:

- 1) A position in, or near, a fringe coverage area.
- 2) Improper installation of the antenna, power cables, or grounding.
- 3) Atmospheric interference caused by storms, lightning, sunspots, etc.

- 4) Strong Low Frequency transmissions.
- 5) Noisy local conditions with interference being generated by industrial switching equipment, local telephone transmissions, precipitation static, etc.
- 6) Operating in a shielded area, such as in a hangar, or near power lines.

ADVISORY

When the WARN indicator is lighted, this is used to display the reason for the warning.

1. MODE - SETUP

2. LARGE KNOB - TURN to display the ADVISORY page.

If the WARN indicator is off, the bottom line will display OFF. If the WARN indicator is lighted, one of the following messages will appear on the bottom line of the display: GRI, SNR, BLINK, TRACKING, or MATH ERR.. The meaning of these messages is shown at the bottom of this page.



GRI - Displayed when insufficient transmitters (i.e. fewer than a master and two secondaries) are being tracked, or automatic triad selection has not been completed.

SNR - Displayed when the SNR of a transmitter in the triad is insufficient.

BLINK - Displayed when a secondary blink condition is detected.

TRACKING - Displayed when a secondary has jumped 10 or more microseconds.

MATH ERR - Displayed when the computer has detected an error in its mathematical calculations.

NOTES:

Note

Many of the terms in the index are defined in LORAN-C TERMS at the beginning of the INTRODUCTION section of the Training Manual

A

Abbreviated Searches	
Navigation	59
Accuracy, Absolute	
Introduction	1
Accuracy, Repeatable	
Introduction	15
Advisory Display	
Setup Mode	55
Airspace Alert	
Normal Procedures	25
Navigation	85
Alternate Solution	
Normal Procedures	23
Navigation	81
Altimeter Setup	
Normal Procedures	29
Navigation	71
Altitude Select	
Navigation	67
APP (Approach) Indicator	
Introduction	9
ARIV (Arrival) Indicator	
Introduction	9
ASF (Additional Secondary Phase Factor)	
Introduction	9
Normal Procedures	37
Navigation	79
Auto Nav Scroll	
Normal Procedures	32

Setup Mode	14
------------	----

B

Baseline	
Introduction	16
Baseline Extension	
Introduction	16
Blink	
Setup Mode	55

C

Calibration Status Indicator	
See ASF	
CDI (Course Deviation Indicator)	
Navigation	14
Setup Mode	41
Chains	
Introduction	13
Selecting	
Normal Procedures	1
Navigation	1
Setup	3
Changing The "To" Waypoint	
Normal Procedures	11
Navigation	32
Control	
Buttons	
Introduction	7
Knobs	
Introduction	5
Converting Seconds to Minutes	
Introduction	5
Copying Waypoints	
Normal Procedures	5
Navigation	25
Course Offset	
Introduction	9
Setup Mode	39

- Creating Waypoints
 Normal Procedures 5
 Navigation 19
 Crossing Angle
 Introduction 17
- D**
- Databases
 North America
 Navigation 5
 Pilot Copy
 Navigation 25
 Pilot Created
 Navigation 19
 Seabase/Heliport
 Navigation 5
 Deleting Waypoints
 Normal Procedures- 12
 From Flightplan Page
 Normal Procedures . . . 8
 Navigation 37
 From PILOT COPY and
 CREATED Databases
 Normal Procedures . . . 8
 Navigation 43
 Duplicate NDB Identifiers
 Navigation 45
- E**
- ECD
 (Envelope-To-Cycle-Difference)
 Setup Mode 49
 Editing NAV Pages
 Normal Procedures 30
 Setup Mode 11
- Emergency Search With Safe -
 Glide TM
 Introduction 8
 Normal Procedures 17
 Navigation 61
- Extended Range
 Normal Procedures 24
 Setup Mode 41
 External Indicator
 Setup Mode 29
- F**
- Fix
 Introduction 14
 Flight Planning
 Navigation 31
 Normal Procedures 10
- G**
- GRI (Group Repetition Interval)
 Introduction 13
 Selecting
 Normal Procedures . . . 1
 Navigation 1
 Setup Mode 3
 Ground Waves
 Introduction 13
- H**
- Hemisphere
 Navigation 20
- L**
- LAT CAL (Latitude Calibration)
 Navigation 79
 Lining-up With a Runway
 Normal Procedures 24
 Navigation 77

- LONG CAL (Longitude Calibration)
 Navigation 79
- Look For
 Navigation 9
- LOP (Line of Position)
 Introduction 14
- M**
- MAG VAR (Magnetic Variation)
 Setup Mode 31
 Normal Procedures 35
- Master Station
 Introduction 13
- MATH ERR (Math Error)
 Setup Mode 53
- Mode Indicators
 Introduction 11
- N**
- NDB Duplicate Identifiers
 Navigation 45
- NAV (Navigation)
 Indicator
 Introduction 11
 Mode
 Introduction 11
 Pages
 Navigation 11
- Nav Planner
 Normal Procedures 30
 Navigation 69
- Nearest Waypoint Search
 Normal Procedures 19
 Navigation 83
- North America Database
 See Databases
- O**
- OFST (Offset) Indicator
 Introduction 11
 Normal Procedures 34
 Setup Mode 39
- OSC OFST (Oscillator Offset)
 Setup Mode 45
- P**
- Phantom Waypoint
 Normal Procedures 7
 Navigation 27
- Pilot Copy Database
 See Databases
- Pilot Created Database
 See Databases
- Pilot Setup Pages
 Setup Mode 3
- POS (Position) Indicator
 Introduction 9
- R**
- Repeatable Accuracy
 Introduction 15
- Reversing Active Flight Plan
 Normal Procedures 13
 Navigation 3
- S**
- Safe - Glidem
 Normal Procedures 17
- Seabase/Heliport Database
 See Databases
- Searching For City Name
 Navigation 55
- Secondaries
 Introduction 13
 Normal Procedures 1

Secondary Blink Condition		Deleting	
Setup Mode	55	Normal Procedures . . .	8
Service Displays		Navigation	37
Setup Mode	43		
SIG (Signal Level)		<u>X</u>	
Setup Mode	51	XTD (Cross Track) Sensitivity	
Signal Information		Normal Procedures . . .	34
Setup Mode	47	Setup Mode	35
Skywaves			
Introduction	13		
SNR (Signal-To-Noise-Ratio)			
Setup Mode	53		
Status Indicators			
Introduction	9		
<u>T</u>			
TD (Time Difference)			
Introduction	13		
Setup Mode	47		
Temp (Temperature)			
Setup Mode	45		
Triad			
Introduction	13		
<u>V</u>			
Version (Software Version)			
Setup	43		
VNAV (Vertical Navigation)			
Normal Procedures	23		
Navigation	71		
<u>W</u>			
WARN Indicator			
Introduction	9		
Navigation	1-2		
Setup Mode	1		
Waypoint			
Creating			
Normal Procedures . . .	5		
Navigation	19		