


**1865+**  
**Megaohmmeter/  
IR Tester  
User and Service Manual**



Copyright © 2010 IET Labs, Inc.  
Visit [www.ietlabs.com](http://www.ietlabs.com) for manual revision updates

1865+ im/October 2010

◆ PRECISION INSTRUMENTS FOR TEST AND MEASUREMENT ◆



---

**IET LABS, INC.**

534 Main Street, Westbury, NY 11590

[www.ietlabs.com](http://www.ietlabs.com)

TEL: (516) 334-5959 • (800) 899-8438 • FAX: (516) 334-5988

## WARRANTY

We warrant that this product is free from defects in material and workmanship and, when properly used, will perform in accordance with applicable IET specifications. If within one year after original shipment, it is found not to meet this standard, it will be repaired or, at the option of IET, replaced at no charge when returned to IET. Changes in this product not approved by IET or application of voltages or currents greater than those allowed by the specifications shall void this warranty. IET shall not be liable for any indirect, special, or consequential damages, even if notice has been given to the possibility of such damages.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE.



## WARNING



OBSERVE ALL SAFETY RULES  
WHEN WORKING WITH HIGH VOLTAGES OR LINE VOLTAGES.

**Dangerous voltages may be present inside this instrument. Do not open the case  
Refer servicing to qualified personnel**

### **HIGH VOLTAGES MAY BE PRESENT AT THE TERMINALS OF THIS INSTRUMENT**

WHENEVER HAZARDOUS VOLTAGES (> 45 V) ARE USED, TAKE ALL MEASURES TO  
AVOID ACCIDENTAL CONTACT WITH ANY LIVE COMPONENTS.

USE MAXIMUM INSULATION AND MINIMIZE THE USE OF BARE  
CONDUCTORS WHEN USING THIS INSTRUMENT.

**Use extreme caution when working with bare conductors or bus bars.**

WHEN WORKING WITH HIGH VOLTAGES, POST WARNING SIGNS AND  
KEEP UNREQUIRED PERSONNEL SAFELY AWAY.



## CAUTION



DO NOT APPLY ANY VOLTAGES OR CURRENTS TO THE TERMINALS OF THIS  
INSTRUMENT IN EXCESS OF THE MAXIMUM LIMITS INDICATED ON  
THE FRONT PANEL OR THE OPERATING GUIDE LABEL.

---

# Contents

---

<b>Specifications</b> .....	<b>1</b>
<b>Accessories</b> .....	<b>3</b>
<b>Safety Precautions</b> .....	<b>5</b>
<b>Condensed Operating Instructions</b> .....	<b>10</b>

## **Introduction - Section 1**

1.1	Unpacking and Inspection.....	13
1.2	Product Overview .....	13
1.3	Controls and Indicators .....	14
	1.3.1 Front Panel Controls and Indicators .....	14
	1.3.2 Rear Panel Controls and Connectors .....	16
1.4	Installation.....	17
	1.4.1 Dimensions .....	17
	1.4.2 Instrument Placement.....	17
	1.4.3 Power Requirements .....	17
	1.4.4 Safety Inspection.....	19

## **Operation - Section 2**

2.1	Terms and Conventions .....	21
2.2	Startup.....	21
2.3	Zeroing.....	22
2.4	Connection to Device Under Test.....	22
2.5	Measurement Procedure.....	24
	2.5.1 General.....	24
	2.5.2 Default Measurement Conditions .....	25
	2.5.3 Automatic Measurement Mode.....	26
	2.5.4 Manual Measurement Mode .....	28
2.6	Menu Functions .....	28
	2.6.1 General.....	28
	2.6.2 Setup Menu .....	29
	2.6.2.1 Voltage.....	29
	2.6.2.2 Charge Time.....	30
	2.6.2.3 Dwell Time .....	30
	2.6.2.4 Measure Time .....	30
	2.6.2.5 Discharge Time .....	31
	2.6.2.6 Mode .....	31
	2.6.2.7 Range .....	32
	2.6.2.8 Limit.....	35
	2.6.2.9 Stop on Pass .....	36
	2.6.2.10 # to Average.....	36

---

## Contents (Continued)

---

### Operation - Section 2 (Continued)

2.6.3	I/O Menu .....	37
2.6.3.1	Display Type .....	37
2.6.3.2	Result Format.....	38
2.6.3.3	RS-232 .....	39
2.6.3.4	IEEE-488.2.....	40
2.6.3.5	Handler.....	40
2.6.3.6	<b>Saving Measurement Results via USB</b> .....	40
2.6.4	Utilities Menu .....	42
2.6.4.1	Save Setup.....	43
2.6.4.2	Recall Setup .....	45
2.6.4.3	Zero .....	46
2.6.4.4	Lock Out .....	47
2.6.4.5	Calibration.....	47
2.6.4.6	Set Time/Date .....	48
2.6.4.7	Elapsed Time .....	49
2.6.4.8	Calibration Date .....	49
2.6.4.9	Set Contrast.....	50
2.6.4.10	LCD Backlight .....	50
2.7	Input/Output Interface .....	50
2.7.1	I/O Interface .....	50
2.7.2	IEEE-488.2 Interface.....	52
2.7.3	Sample Program for National Instruments GPIB Card.....	57
2.7.4	Sample Program for IO Tech GPIB Card .....	58
2.7.5	RS232 Interface.....	59
2.7.6	Sample Program for RS232 .....	60
2.7.7	Results to Printer.....	61
2.8	Error Messages.....	62

### Applications - Section 3

3.1	Insulation Resistance Testing.....	65
3.2	Test Sample Resistivity Measurements .....	66
3.3	Capacitor Insulation Resistance .....	67
3.3.1	General .....	67
3.3.2	Charge Time Constant .....	68
3.3.3	Discharge Time .....	68
3.4	Resistance Measurements .....	69
3.5	Measurement of Voltage Coefficient.....	69
3.6	Guarded, 3 Terminal Measurements .....	70

---

## Contents (Continued)

---

### **Theory Section 4**

4.1	General .....	71
4.2	Instrument Description.....	71
4.2.1	Basic Instrument Architecture.....	71
4.2.2	1865 Instrument Modules .....	72
4.2.3	Instrument Options.....	73

### **Maintenance/Calibration - Section 5**

5.1	Routine Maintenance .....	75
5.1.1	Battery Replacement .....	75
5.1.2	Resetting of Time and Date .....	75
5.1.3	Loss of Display Contrast.....	76
5.1.4	Preventive Maintenance/Cleaning .....	77
5.2	Calibration.....	78
5.2.1	General .....	78
5.2.2	Calibration Procedure .....	78





---

## Specifications

---

**Resistance Range:**  $1 \times 10^3$  to  $> 1 \times 10^{14} \Omega$  (dependent on test voltage)  
 $1 \times 10^6 - > 1 \times 10^{14} \Omega$  at 1000Vdc  
 $1 \times 10^5 - 1 \times 10^{13} \Omega$  at 100Vdc  
 $1 \times 10^4 - 1 \times 10^{12} \Omega$  at 10Vdc  
 $1 \times 10^3 - 1 \times 10^{11} \Omega$  at 1Vdc

(7 ranges or auto ranging)

**Resistance Accuracy:\***  $\pm[0.45\% + \{(R_x/V_x)(0.0005 \text{ FS} + 2\text{pA}) + 30\Omega/R_x\}100\%]$

R<sub>x</sub>: Measured resistance in ohms

V<sub>x</sub>: Programmed voltage in volts

FS: Full scale current range in amperes

**Voltage Range:** 1 to 1000 V, programmable in two ranges

**Voltage Accuracy:\*** 1 – 100 V:  $\pm(1\%$  of setting +1 V)  
25mV resolution  
100 – 1000 V:  $\pm(1\%$  of setting +2 V)  
250 mV resolution

**Output Voltage**

**Impedance:**  $1 \text{ k}\Omega \pm 5\%$

**Current Limited:**  $< 2\text{mA}$

**Current Measure:**  $1 \times 10^{-13}$  to  $1 \times 10^{-3}$  amps

**Current Accuracy:\*** 1nA to 1mA:  $\pm[0.5\% + (0.0005 \text{ FS} + 2 \text{ pA})]$   
100pA to 1nA:  $\pm[1\% + (0.0005 \text{ FS} + 2 \text{ pA})]$   
1pA to 100pA:  $\pm[10\% + (0.0005 \text{ FS} + 2 \text{ pA})]$

**Input Impedance:**  $5 \text{ k}\Omega \pm 5\%$

**Measure Limits:** Pass/Fail (1 limit)

**Display:** LCD graphic display  
Voltage warning indicator  
Pass/Fail indicator

\* specified at front panel connectors

---

## Specifications (Continued)

---

<b>Test Cycle:</b>	Manual: Charge, Measure, Discharge Automatic: Charge time: 0 -300 sec Dwell time: 0 - 300 sec Measure time: 0 - 999 sec Discharge time: 0 - 300 sec
<b>I/O Interface:</b>	Standard -RS232 I/O Port (w/safety interlock) Optional -1865-01 - IEEE-488.2, factory installed at unit purchase 1865-02 – USB connection 1865-03 - Rear panel input terminals, factory installed at purchase 1865-70 - IEEE-488.2, field retrofit
<b>Input Terminals:</b>	Four sheathed banana plugs, front or rear mount (optional) + unknown (red)                      - unknown (black) guard (blue)                              ground (green)
<b>Dimensions:</b>	Bench with tilt back bail (133.4mm high x 444.5mm wide x 406.4mm deep)
<b>Weight:</b>	Approximately 8.2 kg - Net Approximately 11.8 kg - Shipping
<b>Environmental:</b>	MIL-T-28800D, Type 3, Class 5, Style E & F Operating: 0°C to 50°C, stated accuracy <45% RH Storage: -40°C to 71°C Altitude: <2000m, Installation Category 1, Pollution Degree 1
<b>Power:</b>	• 90 – 250 V    • 47 – 63 Hz    • 40 W max
<b>General:</b>	• Fully programmable via menu • Zeroing • Stored test conditions and results • Selected measurement units (engineering or scientific)
<b>Accessories Supplied:</b>	• Instruction Manual                      • AC Power Cable • Calibration Certificate                • 1 MΩ and 100 kΩ Capacitor Adapters • Interlock Connector
<b>Accessories Available:</b>	• 1865-50 Rack Mount Kit    • 1865-51 Shielded Lead Set • 1865-52 Component Test Fixture

---

## Accessories

---

### Accessories Included

<b>Item</b>	<b>Quantity</b>	<b>IET P/N</b>
U.S. ac Power Cable (3-prong)	1	4200-0300
T2.5A 250 V 5X20 mm Line Fuse	1	520049
1 M $\Omega$ Capacitor Adaptor	1	800015
100 k $\Omega$ Capacitor Adaptor	1	800014
Interlock Connector	1	630019
Instruction Manual	1	150073
Calibration Certificate	1	N/A

### Accessories/Options Available

<b>Item</b>	<b>Quantity</b>	<b>IET P/N</b>
IEEE-488.2 Interface (factory installed)	1	1865-01
Rear Panel Input Option (factory installed)	1	1865-03
Rack Mount Kit	1	1865-50
Shielded Lead Set	1	1865-51
Component Test Fixture	1	1865-52
IEEE-488.2 Interface (Field Retro-Fit Option)	1	1865-70
Resistivity Test Cell Fixture	1	1865-11



---

## Safety Precautions

---

### WARNING

The 1865 Megohmmeter/IR Tester can supply an output voltage as high as 1000Vdc to the external device under test (DUT).

Although the 1865 unit is designed with full attention to operator safety, serious hazards could occur if the instrument is used improperly and these safety instructions are not followed.

1. The 1865 unit is designed to be operated with its chassis connected to earth ground. The 1865 instrument is shipped with a three-prong power cord to provide this connection to ground. The power cord should only be plugged in to a receptacle that provides earth ground. Serious injury can result if the Sentry unit is not connected to earth ground.
2. Tightly connect cable(s) to the (green) GND terminal. If this is not done, the DUT's casing can be charged to the high voltage test level and serious injury or electrical shock hazards could result if the DUT is touched.
3. Never touch the metal of the High Voltage probe directly. Touch only the insulated parts of the lead(s).
4. Never touch the test leads, test fixture or DUT in any manner (this includes insulation on all wires and clips) when the high voltage is applied and the red **CAUTION HIGH VOLTAGE** LED is lit.
5. Before turning on the 1865 unit, make sure the AC power cord is plugged into the proper voltage source and that there is no device (DUT) or fixture connected to the test leads.
6. After each test, press the **[STOP]** (red) button for safety. This terminates the high voltage being applied to the output terminals.
7. When the **CAUTION HIGH VOLTAGE** LED is lit, NEVER touch the device under test, the lead wires or the output terminals.
8. Before touching the test lead wires or output terminals make sure:
  - a) The red **[STOP]** button has been pressed.
  - b) The **CAUTION HIGH VOLTAGE** LED is OFF.
  - c) The output voltage display is 0 (zero).
9. In the case of an emergency, turn OFF the **[POWER]** switch using a "hot stick" and disconnect the ac power cord from the wall. **DO NOT TOUCH THE 1865 INSTRUMENT.**  
Position the equipment so it is easy to disconnect. Disconnect by means of the power plug or power connector.
10. If the **CAUTION HIGH VOLTAGE** LED does not go **off** when the **[STOP]** button is pressed, immediately stop using the tester. It is possible that the output voltage is still being delivered regardless of the TEST ON/OFF control signal.
11. When the 1865 instrument is used in remote control mode, be extremely careful. The High Voltage Output is being turned on and off with an external signal.

## Safety Symbols

The product is marked with the following safety symbols.




Product will be marked with this symbol (ISO#3864) when it is necessary for the user to refer to the instruction manual in order to prevent injury or equipment damage.



Product marked with this symbol (IEC417) indicates presence of direct current.



Product will be marked with this symbol (ISO#3864) when voltages in excess of 1000V are present.



Indicates the grounding protect terminal, which is used to prevent electric shock from the leakage on chassis. The ground terminal must connect to earth before using the product.

**Warning** Procedure can cause hazard to human if the warning is neglected.

**Caution** Avoid product misuse. It may cause damage to the product itself and the DUT if the caution is neglected.


**Note** Important information or tips for the procedures and applications.

### Warning Signal During Testing

“DANGER – HIGH VOLTAGE TEST IN PROGRESS, UNAUTHORIZED PERSONS KEEP AWAY”

### Disposal

Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities. Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being. When replacing old appliances with new one, the retailer is legally obligated to take back your old appliances for disposal.



---

## Condensed Operating Instructions

---

### WARNING

High voltage is applied to the measurement terminals of the 1865 any time the **CAUTION HIGH VOLTAGE** LED is ON. While the current from the instrument is limited, the energy stored in a capacitive device connected to the terminals may be lethal. Always make sure the high voltage indicator is **OFF** when connecting or disconnecting the unknown. A flashing **CAUTION HIGH VOLTAGE** light and/or **DANGER** on the display indicates a defective unit with dangerously high voltages possible at the input terminals. Power the unit down and do not use.

### General Information

The 1865 Megohmmeter/IR Tester is a computer controlled measuring instrument for direct readout of resistance and current. The voltage applied to the device under test (DUT) is programmable from 1 to 1000 V. A pass/fail indicator provides a visual display of test results based on a preset limit. A set of power-up default test conditions are stored in the unit and are as set by the factory (1V, test times zero) until reprogrammed by the user.

### Start-up

The 1865 can be operated from a power source between 90 V and 250 Vac at a power line frequency of 47 to 63 Hz. The standard 1865 is shipped from the factory with a 2.5 A fuse in place for 115 V or 220 V operation. To change the fuse, refer to paragraph 1.4.3.

Connect the instrument power cord to the source of proper voltage.

### IMPORTANT

The interlock connector (included with the unit) needs to be installed on the rear panel I/O Port connector if the interlock function is not being used.

Press the [POWER] button on the front panel to apply power. To switch power off press the [POWER] button again or if measurements are to be made proceed with Zeroing the instrument, discussed in the next paragraph.

---

## Condensed Operating Instructions

---

### Zeroing

Before measuring, zero out test lead or fixture measurement errors as follows.

1. If test leads are to be used connect them to the 1865 input terminals, red to + unknown, black to - unknown, with probes open and spaced some distance apart (or fixture open).
2. Press [MENU] key to select menu display.
3. Press Right or Left Arrow key to select Utilities menu.
4. Press Up or Down Arrow key to select Zero in the sub menu.
5. Press [ENTER] key to activate the Zero routine and follow instructions on the instrument display.

### Auto Measurement Mode

In automatic mode, once the [START] button is depressed the instrument sequences automatically through the test cycle phases, charge, dwell, measure and discharge and a pre-stored set of test conditions are executed. These test conditions can be DEFAULT (those at power up), set using menus or the operator can recall a previously stored setup.

1. Connect the device under test to the 1865 test leads or other fixture being used.
2. If the desired setup conditions are anything other than DEFAULT, set using menus or proceed to Recalling Setups below before continuing with step 3.
3. Initiate the auto measurement mode by pressing [START]. The High Voltage Indicator will remain on as the unit sequences automatically through all four phases (charge, dwell, measure, discharge) of the test cycle.
4. The measurement can be aborted at any time during the test cycle by pressing [STOP].
5. Once the High Voltage Indicator goes off the measurement is complete, the final result remains displayed and the device can be removed.



---

# Condensed Operating Instructions

---

## Manual Measurement Mode

In manual measurement mode each phase of a test cycle, charge, measure and discharge is initiated manually at the users discretion. These test conditions can be DEFAULT (those at power up), set using menus or the operator can recall a previously stored setup.

1. Connect the device under test to the 1865 test leads or other fixture being used.
2. Press [MENU] key to select menu display.
3. Press Right or Left Arrow key to select Setup menu.
4. Press Up or Down Arrow key to select Mode in the sub menu.
5. Press [ENTER] to activate the selection field.
6. Press Right or Left Arrow key to select Manual and press [ENTER].
7. If the desired setup conditions are anything other than DEFAULT, set using menus or proceed to Recalling Setups below before continuing with step 8. (Setup measurement times are ignored in manual mode).
8. Initiate the charge phase by pressing [START] to apply high voltage to the device. The High Voltage Indicator will remain on as long as a voltage is applied. The measurement can be aborted at any time during the test cycle by pressing [STOP].
9. Initiate a single measurement by pressing [START] again, The measured result will be displayed on the LCD and will be updated each time [START] is pressed.
10. To discharge the device press [STOP].
11. Before removing the device press [STOP] again to end the discharge phase and turn the High Voltage Indicator off.

## Recalling Setups

1. To recall a set of test conditions previously stored:
    - Press [MENU] key to select menu display.
    - Press Right or Left Arrow key to select Utilities menu.
    - Press Up or Down Arrow key to select Recall Setup.
    - Press [ENTER] key to activate the recall entry field.
    - Press Up or Down Arrow key to select the desired setup. choices are:
      - DEFAULT, if conditions are power up which can be changed by the user.
      - USB, if setup is to be recalled from a flash drive.
      - Setup Name stored in the instrument internal memory or USB.
- Once the desired setup is located press [ENTER] key to finalize recall of the setup conditions.

---

## Condensed Operating Instructions

---

### Saving Setups

1. To save the current set of test conditions as entered (conditions include, voltage, test times, measurement range, limit, and display modes):
  - Press [MENU] key to select menu display.
  - Press Right or Left Arrow key to select Utilities menu.
  - Press Up or Down Arrow key to select Save Setup.
  - Press [ENTER] key to activate setup entry field.
  - Press UP or Down Arrow key to select the desired setup, choices are:
    - NEW, if a setup is to be saved in instruments internal memory.
    - DEFAULT, if conditions at power up are to be changed and restored.
    - USB, if a new setup is to be stored or existing one changed on the flash drive.
    - Setup Name if an existing set of conditions are to be changed in the instrument internal memory or a flash drive.
  - Press [ENTER] key to activate the Save entry field selected above.
  - If NEW is selected (internal memory or USB) enter the desired identifying name, up to 8 characters, under which these set of test conditions will be stored.
  - Press [ENTER] key to finalize storage of the setup conditions or if DEFAULT is selected one must answer Y or N to overwrite.

### Changing Test Voltage

1. Set the desired test voltage:
  - Press [MENU] key to select menu display.
  - Press Right or Left Arrow key to select Setup menu.
  - Press Up or Down Arrow key to select Voltage.
  - Press [ENTER] key to activate the voltage entry field.
  - Enter desired test voltage (up to 5 digits with decimal) between 1 and 1000 V.
  - Press [ENTER] key to finalize the voltage entry.

### Changing Measurement Times

1. To set the desired measurement cycle times, charge, dwell, measure and discharge:
  - Press [MENU] key to select menu display.
  - Press Right or Left Arrow key to select Setup Menu.
  - Press Up or Down Arrow key to select desired time: charge, dwell, measure or discharge.
  - Press [ENTER] key to activate the corresponding time entry field.
  - Enter the desired time between 0 and 300 seconds(measure, 0 – 999 on later units)
  - Press [ENTER] key to finalize the time entry.
2. Continue to set the other times as desired by repeating step 1.

---

## Condensed Operating Instructions

---

### Setting Pass/Fail Limit

1. To enter a single measurement limit for resistance or current (depending on results display selected):
  - Press [MENU] key to select menu display.
  - Press Right or Left Arrow to select Setup menu.
  - Press Up or Down Arrow key to select Limit in sub menu.
  - Press [ENTER] key to activate the limit entry field.
  - Enter the numerical value (up to 4 digits plus decimal point) of the limit desired, then enter the exponential value after first pressing the e select key (use minus exponential value for current).
  - Press [ENTER] key to finalize the limit entry.

### Changing Display Type and Units

1. To change displayed measurement results between Resistance, Current or Pass/Fail:
  - Press [MENU] key to select menu display.
  - Press Right or Left Arrow key to select I/O Menu.
  - Press Up or Down Arrow key to select Display.
  - Press [ENTER] key to activate the selection field.
  - Press Up or Down Arrow key to select desired measurement results, Resistance, Current or Pass/Fail if a limit is to be used.
  - Press [ENTER] key to finalize the entry.
2. To change the measurement results format between Scientific or Engineering units:
  - Press [MENU] key to select menu display.
  - Press Right or Left Arrow key to select I/O Menu.
  - Press Up or Down Arrow key to select Result Format.
  - Press [ENTER] key to activate the selection field.
  - Press Right or Left Arrow to select desired results format, Sci for Scientific or Eng for Engineering.
  - Press [ENTER] key to finalize the entry.



---

# Section 1: Introduction

---

## WARNING

High voltage is applied to the measurement terminals of the 1865 anytime the CAUTION HIGH VOLTAGE LED is ON. While the current from the instrument is limited to a value that is not dangerous under most conditions, the energy stored in a capacitor connected to the terminals may be lethal. Always make sure the CAUTION HIGH VOLTAGE LED is OFF when connecting or disconnecting the unknown.

### 1.1 Unpacking and Inspection

Inspect the shipping carton before opening. If the carton is damaged, contact the carrier agent immediately. Inspect the 1865 instrument for any damage. If the instrument appears damaged or fails to meet specifications notify IET (refer to instruction manual front cover). Retain the shipping carton and packing materials for future use such as returning for recalibration or service.

### 1.2 Product Overview

The 1865 Megohmmeter/IR Tester is a general purpose high voltage instrument for resistance measurements on insulating materials and components. It is designed for easy, accurate and direct readings of high resistance typically found in synthetic resins, porcelains, insulating oils, plastics and other similar materials. It is also used for measurements on capacitors, transformers, switches, cables and connectors. The 1865 provides a direct readout of resistance from 1000  $\Omega$  to 1000 T $\Omega$  with fully automatic ranging. The voltage applied to the unknown is programmable from 1 V to 1000 V.

The 1865 includes a high resolution graphics display and keypad for ease of use. The test cycle is fully automatic with programmable charge, dwell, measure and discharge times. These times, along with other test conditions can be stored in instrument memory and recalled for later use. A pass/fail indicator provides the operator with a visual indication based on a preset resistance limit. The unit also contains automatic zeroing at the test leads as well as built-in self-test routines. Safety features include current limiting to less than 2 mA and a front panel indication when voltage is applied to the test terminals, thus permitting connections to be made safely.


The 1865 comes standard with I/O Port (handler) and RS232 interface. An IEEE-488.2 interface is optional for communication with other instrumentation and remote control operation. A USB connection is also available for storing test conditions and results on a flash drive. There is a direct reading current measurement mode from 1 mA to 1 pA.

The unit is available with front or rear panel input connections with guard and ground terminals to permit measurements of grounded or ungrounded devices.

### 1.3 Controls and Indicators

#### 1.3.1 Front Panel Controls and Indicators

Figure 1-1 shows the controls and indicators on the front of the 1865 unit. Table 1-1 identifies them with description and function.



**Figure 1-1: Front Panel Controls & Indicators**

**Table 1-1: Front Panel Controls and Indicators**


Reference Number Figure 1-1	Name	Type	Function
1	Input Panel		Connection for device under test (DUT)
1a	GROUND	Green Sheathed Banana Plug	Ground Terminal for jumper of (+) Input Terminal or Guard Input to Chassis GND
1b	+	Red Sheathed Banana Plug	High Voltage Terminal for connection to DUT
1c	-	Black Sheathed Banana Plug	Low Voltage Terminal for connection to DUT
1d	GUARD	Blue Sheathed Banana Plug	Guard Terminal for 3-Lead Guarded Measurements
2	Display	LCD Graphic	Displays measurement results, instrument status and user interface menus.
3	SELECT	4 Gray Push Buttons	Function as indicated on adjacent display From top to bottom: functions as: Up (↑), Down (↓), Right (→) or Left (←) during Menu Selection. Other functions include: measurement units, exponent, Yes or No and del (delete).
4	Keypad	White Push Buttons	12 keys for making numerical entries: 0-9, decimal point and minus sign.

**Table 1-1: Front Panel Controls and Indicators (Continued)**

Reference Number Figure 1-1	Name	Type	Function
5	MENU	Green Push Button	Press to enter menu display mode or press to exit sub menu & return to main menu.
6	CNCL	Gray Push Button	To exit menu mode with no parameter changes made or to exit current field
7	ENTER	Gray Push Button	To switch user to entry mode or to accept menu entry as entered.
8	START	Green Push Button	To initiate the measurement
9	POWER	Black Toggle Switch	To apply power to the instrument: 1 = ON, 0 = OFF
10	USB	USB connection	To store test setup conditions and measurement results on a flash drive.
11	STOP	Red Push Button	To stop the measurement (terminate high voltage at the output terminals)
12	TEST		Indicate P/F Measurement Result based on preset limit
12a	FAIL	Red LED	When lit in <b>Resistance Mode</b> , the measured value is below the set minimum value (resistance limit). When lit in <b>Current Mode</b> , the measured value is above the set maximum value (current limit).
12b	PASS	Green LED	When lit, in <b>Resistance Mode</b> , the measured value is above the set minimum value (resistance limit). When lit in <b>Current Mode</b> , the measured value is below the set maximum value (current limit).
13	Caution High Voltage	Red LED	When lit, indicates presence of High Voltage at the output terminals.

### 1.3.2 Rear Panel Controls and Connectors

Figure 1-2 illustrates the controls and connectors on the rear panel of the 1865 Megohmmeter/IR Tester. Table 1-2 identifies them with description and function.



**Figure 1-2: Rear Panel Controls and Connectors**

**Table 1-2: Rear Panel Connectors and Controls**

Reference Number Figure 1-2	Name	Type	Function
1	AC Inlet Module	Black 3-Prong Receptacle & Fuse Drawer	3-wire connection for AC power source. 90-250V AC: T2.5A 250V 5x20mm Fuse
2	Vent	Rear Panel Portion	Instrument ventilation
3	I/O Port	36-pin Male Amp 552302-1 compatible	36-Pin Connector for Component Handler. Use with Amp 552302-1 plug & 552073-5 strain relief cover or ribbon cable clamp connector 553600-1 or equivalent(s).
4	Parallel Port	Not Available	Not Available
5	Option	1865-03	Rear Panel Input Terminals: Ground, (+), (-) and Guard for connection to DUT with High Voltage Indicator
6	Battery	3, AA Size Batteries	DC source for System Memory back-up. 3 AA batteries need to be replaced yearly.
7	RS232 Interface	9-pin DB9 Male	9-pin connector for RS232 I/O transfers
8	IEEE-488.2 Interface	24-pin Male	24-pin connector for IEEE-488.2 I/O transfers



## 1.4 Installation

### 1.4.1 Dimensions

The instrument is supplied in a bench configuration, i.e., in a cabinet with resilient feet for placement on a table. A bail is provided under the front edge so that the instrument can be tilted back for convenient operator viewing.





Figure 1-3: 1865 Instrument Dimensions

### 1.4.2 Instrument Placement

The 1865 instrument contains a high resolution back lit LCD for convenient viewing. The optimum angle for viewing is slightly down and about 30° either side of center. This means that for bench operation the front bail should always be used to angle the instrument up, and for rack installation it should be mounted at eye level or higher.


### 1.4.3 Power Requirements

 The 1865 Megohmmeter/IR Tester can be operated from a power source between 90 and 250Vac at a power line frequency of 47 to 63Hz. Power connection to the rear panel is through an AC inlet module comprised of an ac connector and fuse drawer. Before connecting the 3-wire power cord between the unit and ac power, verify that the fuse is 2.5 A, 250 V, slow-blow, 5x20 mm. Always use an outlet which has a properly connected ground. **The standard 1865+ is factory shipped with the 2.5A fuse in place. The instrument can be damaged if the wrong fuse is installed.** To change the fuse proceed as follows:

## PROCEDURE FOR CHANGING A FUSE

### WARNING

Make sure the unit has been disconnected from its ac power source for at least five minutes before proceeding.



**Figure 1-4: 1865 Instrument Fuse Drawer**

1. Open the fuse drawer by inserting a small flat head screwdriver behind the small tab to pull the drawer outward.  
*If you wish to remove the drawer from the ac inlet module (not required in order to change the fuse), press the sides inward at the rear of the drawer and pull the drawer out.*
2. Remove the fuse from the drawer by prying upward using a small flat head screwdriver.
3. Insert the replacement fuse.
4. (Optional) Insert a spare fuse in the front section of the drawer.
5. Slide the tray back into the into the instrument ac inlet module.

#### 1.4.4 Safety Inspection



Before operating the instrument inspect the ac power inlet module on the rear of the 1865 instrument to ensure that the **properly rated fuse is in place**, otherwise damage to unit is possible. Refer to paragraph 1.4.3.

The 1865 instrument is shipped with a standard U.S. power cord (with Belden SPH-386 socket or equivalent, and 3-wire plug conforming to IEC 320) and CE units are supplied with an approved international cord set. Make sure the instrument is only used with these cables (or other approved international cord set) which ensures the instrument is provided with **connection to earth ground**.

When the 1865 instrument is used in a rack installation (using the 1865-50 Rack Mount Kit) make sure the unit is **secured using the cabinet mounting rails** and not secured solely by the front panel angle brackets.

In bench or rack mount applications the instrument should be positioned with consideration for **ample air flow** to the rear panel ventilation holes. An open space of at least 3 inches (75 mm) is recommend behind the rear panel. The surrounding environment should be **free from excessive dust** to prevent contamination of electronic circuits.

#### **WARNING**

If this instrument is used in a manner not specified in this manual, protection to the operator and equipment may be impaired.

Read this instruction manual in full before operating this instrument.



---

## Section 2 : Operation

---

### 2.1 Terms and Conventions

The names of keys in the manual will generally appear in CAPITAL LETTERS.

The MENU key calls up the main menu display and returns to the line previously selected.

The ">>" symbol on a menu indicates a lower level menu exists.

The select keys generally function as UP, DOWN, LEFT and RIGHT arrow and allow you to move through a menu or field of choices to make the desired selection or turn a function ON or OFF.

The ENTER key switches the unit to entry mode and when pressed again initiates the entry or choice selected on the current screen.

The CNCL key will return the system to main menu display with no changes made. (From a numeric data field CNCL must be hit twice).

### 2.2 Startup

Check to make sure the line voltage indicator on the rear panel AC inlet module agrees with the AC power source available, if not refer to paragraph 1.5.3.

Connect the instrument power cord to the source of proper voltage. **The instrument must be used only with three wire grounded outlets.**

#### WARNING

A flashing **CAUTION HIGH VOLTAGE** light and/or **DANGER** on the display indicates a defective unit with dangerously high voltages possible at the input terminals. Power the unit down and do not use.

#### IMPORTANT

The interlock connector (included with the unit) needs to be installed on the rear panel I/O Port connector if the interlock function is **not** being used. Switching [POWER] OFF and ON quickly may result in error messages. Power should be off for at least 10 seconds to assure proper power-up.


Power is applied to the 1865 by pressing the [POWER] button on the front panel. The instrument runs a self test and any error messages are displayed accordingly (refer to paragraph 2.8).

### 2.3 Zeroing

Before making measurements, the 1865 instrument should be zeroed to correct for test lead or fixture errors. During the zeroing process corrections are calculated and stored in instrument memory and applied to ongoing measurements. Generally the unit should be zeroed at least once per day and each time test leads or fixtures are changed. The zeroing routine is accessed through the Utilities Menu by selecting [ZERO], instructions are given on the LCD display. Refer to paragraph 2.6.4.3.

### 2.4 Connection to Device Under Test

Figure 2-1 illustrates the front panel input terminals and a basic block diagram of their function.




**Figure 2-1: Input Panel and Block Diagram**

An optional shielded lead set is available for use with the 1865 unit, Part Number 1865-51. How the connection to the DUT is made depends on the unknown being measured: if it is a grounded, ungrounded or guarded device. The 1865 instrument is supplied with two resistor adapters which are recommended for use only when measuring high value, low leakage capacitors. These are to be added in series with the (-) terminal lead to eliminate fluctuating test results when measuring this type of device. Refer to paragraph 3.3.


**CAUTION**  
 DO NOT GROUND the (-) negative unknown terminal.  
 This will result in invalid measurements.

Figures 2-2 through 2-4 illustrate various methods of connection to the device under test (DUT). Figure 2-2 illustrates the two-wire connection to DUT. The two-wire ungrounded connection is the recommended connection of ungrounded components or components that can be connected very close to the 1865 input terminals rather than through the lead set provided.




**Figure 2-2: Two-Wire Ungrounded Connection**

The two-wire grounded measurement is a common type of connection to be used on the 1865. This is the recommended connection on grounded components or components that are some physical distance from the input terminals of the unit. A grounded component is one in which one of its connections goes to an earth ground, whereas on an ungrounded component neither connection goes to earth ground. A component being measured with a lead set is considered to be a physical distance away from the terminals and thus the two-wire grounded connection is often recommended.



**Figure 2-3: Two-Wire Grounded Connection**

A three-wire guarded connection is necessary to measure resistance between two points in the presence of resistance from each of these points to a third point. Refer to paragraph 3.6 for a discussion of guarded measurements. The guarded measurement may require different grounding techniques depending on the expected impedance of the DUT.



+ Unknown and - Unknown are connected to DUT

GUARD to DUT Guard Point

+ Unknown shorted to GND

OR

GUARD shorted to GND

**Figure 2-4: Three-Wire Guarded Connection (Grounded or Ungrounded)**

## 2.5 Measurement Procedure

### 2.5.1 General

There are two basic measurement modes of operation, auto and manual. In the automatic mode the test cycle is sequenced automatically through four phases: **Charge**, **Dwell**, **Measure**, and **Discharge**, in accordance with user-programmed times. This is the preferred measurement mode, especially when the approximate resistance value is unknown, since the 1865 instrument employs an auto-ranging technique. The automatic mode would generally be used in a production environment where measurements are repetitive and setup conditions have been previously established. To reduce measurement time when making repetitive measurements, a particular range may be locked in, instead of auto-ranging.



In the manual mode, the test cycle timing is totally at the user's discretion where each of the three phases (**Charge, Measure, or Discharge**) is initiated directly by the user. This mode would typically be used in an engineering environment or for component evaluation, where the measurement results can be observed as test cycle and measurement conditions are altered.

Whenever the 1865 unit is powered up, it is ready to begin measuring at default test conditions. Initially, these conditions will be set to a factory default (1 V, 0 times, Resistance Display, Auto ranging and Automatic Mode), but can be changed by the user and stored to overwrite the factory default settings.

### **2.5.2 Default Measurement Conditions**

A set of default measurement conditions are initially established at the factory and stored in instrument memory. Default conditions are those that determine the instruments status on power up, thus the instrument is always set to a known state before any testing begins. These conditions can be changed by the user for tailoring to a specific application. Refer to paragraph 2.6.4.1 under Save Setup on the Utilities menu.

Factory default measurement conditions are:

#### Under Setup Menu

Voltage – 1 V

Charge, Dwell, Measure and Discharge times – 0

Mode - Auto

Range - Auto (Selected on lower level menu)

Limit - None

Stop on Pass - No

# to Average - None

#### Under I/O Menu

Display Type - Resistance (selected on lower level menu)

Result Format - Engineering Units

RS-232 - Enable

Handler - On


#### Under Utilities Menu

Lockout - Off

Backlight - On

### 2.5.3 Automatic Measurement Mode

Measurements in the automatic mode can be initiated after connecting the DUT by simply pressing [START]. Test conditions are determined by either the power-up default conditions, or by recalling a previously stored setup from instrument memory. In either case, a test cycle is sequenced automatically (Figure 2-5) once [START] is pressed and results displayed (Figure 2-6). When a test limit is entered a PASS/FAIL indication can be displayed in place of the actual measured value (Figure 2-7).



**Figure 2-5: Test Cycle Sequence (Automatic)**




Figure 2-6: Measurement Results Display with Value





Figure 2-7: PASS/FAIL Results Display

## 2.5.4 Manual Measurement Mode

The primary difference between automatic and manual modes is that in the manual mode the phases of the test cycle must be initiated manually by the user. Here there are three phases rather than the four in automatic; the **Dwell** function is part of the **Charge** phase. The results are still displayed in the manner indicated above; the mode indicates **Manual** rather than **Automatic**. Default and other stored setups can still be recalled, the only difference being that the test cycle times are not applicable.



**Figure 2-8: Test Cycle Sequence (Manual)**

## 2.6 Menu Functions

### 2.6.1 General

All programmable functions of the 1865 are controlled by easy to use menu displays. The user enters the menu mode by selecting the [MENU] key which calls up three top level menus, Setup, I/O and Utilities. Each one of these is comprised of a sub menu list whose functions are described in detail below. Navigating around the menu listing is accomplished in a fashion similar to an Automatic Teller Machine (ATM) using the up, down, right and left arrow keys as indicated on the adjacent LCD display. A highlighted menu function can be controlled by pressing the [ENTER] key, making the desired entry or selection, and pressing [ENTER] again to implement.

## 2.6.2 Setup Menus




Figure 2-9: Setup Menu

The first of the three main menus is Setup, shown in Figure 2-9. Each function controls a measurement condition and is described in detail below.

### 2.6.2.1 Voltage





Figure 2-10: Test Voltage Entry

Accepts entry of a test voltage (up to 6 digits and decimal) between 1 and 1000 V. This is the voltage applied to the unit under test during the test cycle and present at the DUT connection anytime that the CAUTION HIGH VOLTAGE lamp is ON. As in the case of many of the menu entries on the 1865 instrument, an "error message" will be displayed for an invalid entry.

### 2.6.2.2 Charge Time



**Figure 2-11: Charge Time Entry**

Accepts entry of a charge time between 0 and 300 seconds in 1 second intervals (up to 3 digits). If the selection is out of range an error message will be displayed. This marks the time when the test voltage is first applied and the unit under test is allowed to charge up to this voltage. Even if the charge time is entered as zero there is still a small delay during the charge phase. In this case or even with much longer charge times the possibility exists that full charge voltage may not be reached at the start of the measurement phase if the DUT has a long time constant.

**NOTE**

For low voltage measurements (<5 V), a minimum charge time of 2 seconds is recommended to meet the instruments stated accuracy.

### 2.6.2.3 Dwell Time

Accepts entry of a dwell time (or electrification time) between 0 and 300 seconds in 1 second intervals. This is a time during which the test voltage is applied to the device under test and prior to any measurement.


### 2.6.2.4 Measure Time

Accepts entry of a measure time between 0 and 999 seconds in 1 second intervals. This is the time during which repeated measurements are made and results displayed as resistance, current, Pass/Fail or no display depending on the results format selected. The display is updated each time a measurement is made during this time phase.

### 2.6.2.5 Discharge Time

Accepts entry of a discharge time between 0 and 300 seconds in 1 second intervals. This is the time when the test voltage is removed and the device under test discharged. The CAUTION HIGH VOLTAGE lamp goes OFF at the end of the programmed interval and the last measurement result is retained on the display (unless no display is selected).

### 2.6.2.6 Mode




**Figure 2-12: Measurement Mode Selection**

Allows selection from two different modes of operation, **Auto** or **Manual** measurement.

In Auto the user presses [START] to initiate the entire test cycle automatically. The first phase of the cycle is charge time, during which the device initially charges up to the applied test voltage. The second phase is dwell, or time of electrification, during which the device is fully charged but prior to a measurement. The third phase is measure time during which measured results are displayed. The fourth and last phase is discharge time during which the voltage is removed and the device allowed to discharge.

In Manual, test cycle timing is under complete user control, [START] must be pressed to initiate the charge and measure phase and [STOP] pressed to discharge the device.

### 2.6.2.7 Range



**Figure 2-13: Range Selection**

A lower-level menu (accessed by pressing [ENTER]) allows the selection of **Auto** or one of seven different measurement ranges (**1 mA through 1 nA**), which is the maximum current for the selected range. In auto mode the 1865 instrument will automatically select the optimum range depending on the programmed test voltage and current drawn by the test device. Any choice other than Auto (1 mA through 1 nA range) is at the user's discretion. Determination of the range is governed by the maximum current available to the DUT for that measurement range and is listed in Table 2-1. **To eliminate operator errors in range setting and ensure specified instrument accuracy the 1865 unit should generally be left in AUTO.** There may be an exception to this when repetitive measurements are to be made on a known range and there is a desire to reduce test time by eliminating range switching. When auto ranging is selected the 1865 instrument will always begin the measurement phase on the highest current range, 1 mA and progress down depending on the current to the device under test. If the current reaches 10% or less of the maximum for a given range the next lowest range will be switched in.

If a range has been selected and the current exceeds 115% of the maximum for that range the unit will indicate OVER RANGE on the display. One needs to keep in mind that an over-range indication does not necessarily mean that the incorrect range has been selected; the device under test could also be defective. Over-range should not be confused with an OVERLOAD display. Overload occurs anytime current to a device attempts to exceed 2mA, this would generally mean a shorted or very-low-resistance device.



**Table 2-1: Range Current**

<b>Range</b>	<b>Maximum Current</b>
1	1 mA
2	100 $\mu$ A
3	10 $\mu$ A
4	1 $\mu$ A
5	100 nA
6	10 nA
7	1 nA

**Example:**


When measuring an unknown of 200 M $\Omega$  at 100 V, Ohm's Law tells us that the device under test would draw 0.5  $\mu$ A ( $I = 100 \text{ V}/200 \text{ M}\Omega$ ). Based on the above, one would expect the 1865 instrument to auto-range from the 1 mA to 1  $\mu$ A range (50% of maximum current), or that the user should select the 1 $\mu$ A range based on prior knowledge of the expected results.

**NOTE**

When measuring in the current mode, in order to calculate the unknown resistance, the input resistance of the instrument (5 k $\Omega$ ) must be taken into consideration. For further discussion of this refer to Display Type in Paragraph 2.6.3.1


The measurement range capability is represented graphically in Figure 2-14. By locating the charge voltage on the vertical axis and the measured resistance – or expected measured resistance – on the horizontal axis, one can determine the optimum range. When Auto-Range is selected, the range switching is done automatically and the specified instrument accuracy always applies. If a range other than Auto is selected, and the resistance value for the given voltage falls outside the range band shown, the measurement accuracy specified does not necessarily apply.

### Measurement Ranges at Specified Voltage



**Figure 2-14: Measurement Range Capability**

### 2.6.2.8 Limit



In the case where I (current) is selected rather than R (resistance), the exponent would be entered as a negative number.

**Figure 2-15: Limit Value (Resistance or Current)**

Allows entry of a single measurement limit in scientific units (up to 4 digits with decimal and exponent) for resistance or current, depending on the results parameter selected. The exponent must be 3 through 14 for resistance or -3 through -13 for current. This limit determines the status of the Pass/Fail indicator and Pass/Fail display, when enabled. When the 1865 instrument is in the Resistance mode, the limit is a minimum value, i.e. any value above the limit will result in a Pass, whereas a value below the limit will result in a Fail. The opposite is true when the unit is in the current mode: the limit is a maximum value; any value below the limit will result in a Pass and a value above the limit will result in a Fail.

If the display parameter on the I/O Menu is selected as resistance, the value entered will be an R limit; if the display is selected as current, the value entered will be an I limit. The 1865's software will check for consistency between the parameter display selected and the limit entered.

An example of the sequence for entering 1 M $\Omega$  as a limit would be:

Press [ENTER]	or	Press [ENTER]
Press [1]		Press [1]
Press [e] select key		Press [0] (zero), three times
Press [6](exponent multiplier)		Press [e] select key
Press [ENTER]		Press [3]
		Press [ENTER]

### **2.6.2.9 Stop on Pass**

Accepts entry of a value between 0 and 300 which is the number of consecutive passing measurements that must occur to exit the measure loop before the measure time has passed. This is only active when there is a measure time and limit specified. An entry of 0 disables the stop on pass function.

### **2.6.2.10 # to Average**

Accepts entry of a value between 0 and 400 which is the number of measurements to be averaged and displayed. If the value is 0 or 1 averaging is disabled and the display is updated with each measurement, if the value is n (between 2 and 400) the average is displayed after n measurements. If the measure time has not elapsed after the first averaged display, then a running average of measurements is made until the measure time is up. For example, if n is 5, the first five measurements are made, averaged and then displayed. The sixth measurement is averaged with the last four and the first ignored, this continues until the user specified measurement time is complete.

When Stop on Pass is in effect, n measurements are made and averaged.

If the Stop on Pass requirement is met, the cycle stops with a Pass even though the measure time has not passed.

If the measure time has passed and the Stop on Pass requirement has not been met, the cycle stops with a Fail.

If the Stop on Pass requirement is not met, and the measure time has not passed, additional measurements are made and averaged. The Stop on Pass and measure time requirement are tested after each measurement until one or the other results in an exit from the test cycle.

When the instrument is selected for Manual mode of operation the averaging works similarly. When the [START] button is pressed to exit Charge and start measure, n measurements are averaged. For each consecutive press of the [START] button one more measurement is made, the last five are averaged and result displayed. The [STOP] button exits the Measure mode to discharge the UUT normally.

### 2.6.3 I/O Menus




Figure 2-16: I/O Menu

The second of the three main menus is I/O, shown in Figure 2-16. Each function controls measurement results or instrument I/O interface, and is described in detail in paragraphs 2.6.3.1 through 2.6.3.6.

#### 2.6.3.1 Display Type




Figure 2-17: Measurement Display

Allows selection from four different modes of measurement display, **Resistance**, **Current**, **Pass/Fail** or **No Display**. In Resistance mode, the 1865 instrument will display the measured value of resistance of the device under test. In Current mode, the 1865 displays the current to the device under test. In Pass/Fail mode the actual measured value is displayed in small font along with a Pass or Fail based on the measurement limit entered, which could apply to either resistance or current.

In No Display, only the voltage, mode and range are displayed, with no measured value. This might be used for security reasons or for the purpose of reducing test time during remote operation.

When the display is selected as current, you need to keep in mind that the 5 kΩ input impedance and the 1 kΩ output voltage source impedance of the unit are in series with the unknown. For low values of resistance (<20 MΩ) the measured current would be the Charge Voltage/(Z<sub>in</sub> + Z<sub>out</sub>+ R<sub>unknown</sub>).

### 2.6.3.2 Result Format




Figure 2-18: Measurement Results Format

Allows selection from two different measurement result formats: **Sci** or **Eng**, for scientific or engineering units. Scientific units are expressed as an exponent and engineering units are expressed in ohms for resistance and amps for current. For example e<sup>6</sup> in scientific units can be expressed as MΩ or as μA in engineering units. This is strictly for the user's convenience.


When **Sci** is selected, the results will always be displayed as 5 digits and an exponent. The 5 digits will be configured as 1 to the left and 4 to the right of the decimal point. When **Eng** is selected, the results will be displayed with a minimum of 4 and maximum of 6 digits: there are always 3 digits to the right of the decimal point, but to the left there could be 1, 2, or 3 digits depending on value. For example, when the unit is MΩ, and, depending on the device being measured, the display might show 1.123 MΩ, 10.123 MΩ or even 100.123 MΩ.

A summary of measurement units (scientific and engineering) and their symbols is given in Table 2-2.

**Table 2-2: Measurement Unit Prefixes**

<u>Multiple</u>	<u>Scientific</u>	<u>Engineering</u>	<u>Symbol</u>
1000000000000000	$10^{15}$	Peta	P
1000000000000	$10^{12}$	Tera	T
1000000000	$10^9$	Giga	G
1000000	$10^6$	Mega	M
1000	$10^3$	Kilo	k
.001	$10^{-3}$	milli	m
.000001	$10^{-6}$	micro	$\mu$
.000000001	$10^{-9}$	nano	n
.000000000001	$10^{-12}$	pico	p
.000000000000001	$10^{-15}$	femto	f

### 2.6.3.3 RS-232




**Figure 2-19: RS-232 Interface Setup**

Allows user setup of standard RS-232 interface formats. Selections include:

- Baud Rate: 12, 24, 48 or 96
- Parity: None, Even or Odd
- Data Bits: 7 or 8
- Stop Bits: 1 or 2

When using the RS-232 interface with a printer the IEEE-488.2 Mode must be set to **Talk** and the State to **Disable**.

### 2.6.3.4 IEEE-488.2



**Figure 2-20: IEEE-488.2 Interface Setup**

Allows user setup of IEEE-488.2 interface operation. Selections include:

Address: 1 through 16  
Mode: Talk or Talk/Listen  
State: Disable or Enable

The instrument will function as either a Talk or a Talk/Listen device in a system depending on the choice made by the operator under Mode. Talk is generally suited to a simple system with no controller or other talkers, for example a printer. Talk/Listen denotes full programmability and is suited for use in a system that has a controller or computer to manage data flow. The "handshake" routine assures that the active talker proceeds slowly enough for the slowest listener.

### 2.6.3.5 Handler

Allows user to turn Handler Interface function ON or OFF. When off is selected, input and output lines on the rear panel I/O interface connector are ignored

### 2.6.3.6 Saving Measurement Results via USB

The user can store measurement results on a USB flash drive. When selected, if a results file is not open, the user is prompted for the filename (up to 8 characters) and the file is opened.

To close a results file that is currently open, select **Results to USB** and press [ENTER] to close. Display indicates "Closing the Results File".

If the user leaves the file open, when the setup is recalled the user will be prompted for a file name.



When multiple tests are being conducted, the results are stored to the flash drive periodically (every 10 measurements) from an internal buffer.

**CAUTION**

To store **all** results, close the file before shutting down the power.

To keep measurement results consistent with the setup conditions, close the file before changing or recalling a new set of test conditions.

The measurement results (one for each complete measurement cycle) are stored as a DOS text file under its assigned identifying number (up to 8 characters) with an extension of .65R. The test setup conditions are saved as a header at the beginning of a results file. A sample file format is shown below. Notice that the results can be stored in either engineering or scientific terms, depending on what the user has selected for setup conditions.


```
100.000000      ;voltage
0.000000        ;charge time
0.000000        ;dwell time
0.000000        ;measure time
0.000000        ;discharge time
0.000000        ;mode (0 = auto, 1 = manual)
0.000000        ;range
1000000.000000  ;limit
0.000000        ;stop on pass
1               ;# to average
0.000000        ;display type
.000000         ;result format
3.000000        ;baud rate (0 = 1200, 1 = 2400, 2 = 4800, 3 = 9600)
0.000000        ;parity
1.000000        ;data bits
0.000000        ;stop bits
4.000000        ;IEEE address
1.000000        ;IEEE mode
0.000000        ;IEEE state
1.000000        ;handler
0.000000        ;result to USB
1.000000        ;backlight (0 = off, 1 = on)
ENDHEADER
```

1.020 M ohmPASS  
1.020 M ohmPASS  
1.020 M ohmPASS  
1.020 M ohmPASS  
1.020 M ohmPASS  
1.020 M ohmPASS

or

1.020015E+006 PASS  
1.020015E+006 PASS  
1.020015E+006 PASS  
1.020015E+006 PASS  
1.020015E+006 PASS


## 2.6.4 Utilities Menus



**Figure 2-21: Utilities Menu**

The last of the three main menus is Utilities, shown in Figure 2-21. Each function is described in detail in paragraphs 2.6.4.1 through 2.6.4.10.

### 2.6.4.1 Save Setup



**Figure 2-22: Save Setup Test Conditions**


Allows a set of test conditions to be stored in instrument memory or on the USB flash drive for later recall. Test conditions are those that are user programmable in the Setup and I/O menus (refer to paragraphs 2.6.2 and 2.6.3 above).

**Stored setup conditions should always be backed-up on a flash drive or recorded on paper.**

**NOTE**

To store setups in the 1865's internal memory, a flash drive must be plugged into the USB port.

To store the current set of test conditions as a new set in unit memory, you need to select [NEW] in the Save Setup menu and enter the identifying name up to 8 characters under which these conditions will be stored (allowable characters from the keypad include 0 through 9 and minus, characters can also include A through Z when operating from remote control ). To save the setup under the name selected or to overwrite if the name already exists, answer Yes or No (Figure 2-23).




**Figure 2-23: Save/Overwriting Setup**

To make the current set of test conditions the default (at power up) one needs to select **[DEFAULT]** in the Save Setup menu and overwrite the conditions currently stored. To prevent overwriting the default setup by mistake an additional level of safety exists where the operator is required to respond with **Yes** or **No**, similar to Figure 2-23.

Selecting **[del]** will delete a set of test conditions and requires a **Yes** or **No** confirmation.

When there are more setups than can fit on the display, the page-down key is active. If there is less than a whole page below, the display wraps around to the previous display. Continuing to page down will eventually return to the first display of setups. The page-down key is only shown when there are more setups than what is visible.

There are two ways to make the current set of test conditions overwrite an existing setup. One is to select that setup in the menu and answer **Yes** to overwrite. The other way is to enter the same name under **New** and answer **Yes** to overwrite.



**Figure 2-24: Saving Setups on a flash drive**

It is possible to store about 25 sets of test conditions in the 1865's memory, and more than 1000 setups can be stored on a flash drive via the USB port. Increasing the quantity of setups results in a slower retrieval process.

To save a set of test conditions externally, select [USB] from the menu in Figure 2-24. You can save a new setup or overwrite an existing one on the flash drive. Pressing [CNCL] returns the menu to the setups stored in internal memory, Figure 2-22.

#### 2.6.4.2 Recall Setup





Figure 2-25: Recall Setup Test Conditions

Allows a previously stored set of test conditions to be recalled from instrument memory. Test conditions are those that are user programmable in the Setup and I/O menus and saved as discussed above. To recall a set of test conditions one needs to arrow down or up to the desired set. **DEFAULT** is always one of the set of test conditions that can be recalled as discussed in the previous paragraph. Selecting [**USB**] allows setups to be recalled from a flash drive if one is connected. Selecting [**del**] will delete a set of test conditions and requires a **Yes** or **No** confirmation.

When there are more setups than can fit on the display the page down key is active. If there is less than a whole page below, the display wraps around to the previous display. Continuing to page down will eventually return to the first display of setups.

### 2.6.4.3 Zero

The zeroing process automatically measures stray parameters and retains the data. It is used to correct measurements, so that results represent parameters of the DUT alone without test lead or fixture capacitance. Zeroing is recommended at the start of each work day, or more often if leads, fixture, or test configuration to the DUT is changed. Zeroing should also be performed anytime the test voltage is changed, which also includes recalling a set of test conditions from memory with a different test voltage. It is important to note that anytime the instrument is zeroed, it is done at the test voltage currently specified. When [Zero] is selected in the menu screen and the [Enter] key is pressed, you are prompted by instructions on the display, the first of which is shown in Figure 2-26.



**Figure 2-26: Zeroing Procedure**

Once the zeroing is initiated by pressing [START] the next message displayed is:

**ZERO CAL IN PROGRESS**

Once complete, typically a minute or slightly longer, the next message displayed is:

**COMPLETE  
HIT <MENU> KEY TO CONTINUE**

#### 2.6.4.4 Lock Out

Allows user to turn the keypad-lock feature ON or OFF. There are two choices which can be selected: **lockout only** and **lockout with setup recall**. In both modes only the [START], [STOP] and [MENU] on the instrument front panel are active, all other keys are disabled. The difference is that in **lockout with setup recall**, the menu key also allows setups to be recalled from instrument memory.

When either is selected the operator must enter a password number up to 8 characters.

#### CAUTION

For security reasons the password is not displayed when it is entered, so the password should be keyed in carefully and remembered.

ENTER PASSWORD  
(8 CHARACTERS MAXIMUM)

\* \* \* \* \*

Once the password is entered and entered again for verification, testing can begin by pressing [START] or the password cleared or changed by selecting [MENU].

HIT <MENU> KEY TO ENTER PASSWORD  
AND TO RETURN TO THE MENU

OR

HIT THE <START> KEY TO  
START A MEASUREMENT


Once activated, only the [START], [STOP] and [MENU] on the instrument front panel are active, all other keys are disabled. To turn the lockout feature off and reactivate menus select [MENU] (select Exit Lockout in Lockout with Setup Recall mode) and enter the previous password from the keypad, the instrument will again function as normal. Failure to remember an entered password requires an override password (186501).

If [Recall Setup] is chosen in the Lockout with Setup Recall mode, the instrument functions as described in paragraph 2.6.4.2 under Recall Setup.

#### 2.6.4.5 Calibration

Refer to Calibration in Paragraph 5.4. INSTRUMENT CALIBRATION SHOULD BE PERFORMED ONLY BY QUALIFIED SERVICE PERSONNEL.

#### 2.6.4.6 Set Time/Date



**Figure 2-28: Set Current Date and Time**

Allows resetting of time and date into unit memory. This is used as the basis for the elapsed time counter and stored calibration date.

T (time) is entered in

HOURS	(up to 2 digits, 0 through 23)
MINUTES	(up to 2 digits, 0 through 59)
SECONDS	(up to 2 digits, 0 through 59)

D (date) is entered in

MONTHS	(up to 2 digits, 1 through 12)
DAYS	(up to 2 digits, 1 through 31)
YEARS	(4 digits, 1991 through 2100)



### 2.6.4.7 Elapsed Time

When selected, indicates the total elapsed time in hours that the unit has been powered up. This is from the moment of initial use and will show some time when shipped from the factory.




Figure 2-29: Display of Elapsed Time

### 2.6.4.8 Calibration Date

When selected indicates date the unit was last calibrated. This date is retained in instrument memory until the unit is re calibrated and then it is updated.




Figure 2-30: Display of Calibration Date

### 2.6.4.9 Set Contrast

Allows adjustment of contrast on the LCD display. Use Up arrow to increase contrast or Down arrow to decrease. When the instrument is powered up it returns to the last set contrast, not some nominal level.




Figure 2-31: Display Contrast Adjustment

### 2.6.4.10 LCD Backlight

Allows the backlight on the LCD display to be turned **ON** or **OFF**. Turning the backlight off when it is not needed or if the display is not in use. Keeping the backlight off prolongs the life of the display.


## 2.7 Input/Output Interface

### 2.7.1 I/O Interface

The 1865 instrument comes standard with an I/O interface port available through a connector (36 pin) on the rear panel of the instrument. This is generally used for interfacing to an automatic component handler. Refer to Table 2-3 for signal names, pin numbers and functions as necessary for cable connections.

**Table 2-3: I/O Interface Connections**

Signal Name	Pin Number	Function
<b>Input*</b>		
START	16	Initiates Measurement Cycle
<b>Outputs**</b>		
Bin 0	1	Fail, Measured Value below preset limit
Bin 1	19	Pass, Measured Value above preset limit
GND	11, 15, 33	System Ground
IGND	5, 10, 23, 28	Isolated Ground
EOT	29	End of Test, Bin signal outputs valid
TEST ACTIVE	30	Measurement in process
VCC	12, 32	+5V (Source Z: 100 $\Omega$ pin12, 10 $\Omega$ pin 32)
<b>Isolated Connections***</b>		
START HI (isolated)	34	High Input from external source
START LO (isolated)	35	Low Input from external source
<b>Interlock</b>		
INTERLOCK	31	Operator Safety feature primarily for use with external fixtures (i.e. operation of the 1865 instrument can be disabled until the cover of the fixture is closed). To enable the interlock function, pin 31 must be connected to ground or controlled electrically with a logic low. This can be converted to an isolated active low input by removing jumper JP4 on the I/O PCB. The interlock connector supplied with the unit makes this connection (pin 31 to 28) when plugged into the rear panel I/O connector (Figure 2-32).



**Figure 2-32: Rear Panel I/O Connector**

**WARNING**


Do not apply an external source in excess of 5 V with jumpers JP2, JP3 or JP4 in place, otherwise the instrument may be damaged. These jumpers are discussed below and on some instruments physically located under the stack on the I/O board.

## Table 2-3 NOTES

\* The input signal is active low and requires a positive-voltage external circuit, which must pull the signal line down below 0.4 V, but not less than 0.0 V, i.e. not negative. The logic-low current is 0.4 mA (max). For the inactive state (logic high), the external circuit must pull the signal line above +2.5 V, but not above +5 V. This can be converted to a *isolated active low input* by removing jumper JP3 on the I/O PCB.

\*\* Outputs can be active low optically isolated open - collector drivers that pull each signal line to IGND (isolated common) when asserted. All outputs require a positive +5 V to +24V external source (referenced to IGND) and pull-up resistor to operate as fully isolated signals. IGND can be isolated from system GND by removing jumper JP2 on the I/O PCB. With jumper JP2 in place optical isolation is defeated allowing the outputs to be pulled up to the system +5 V with external resistors. The outputs can sink up to 80 mA of current. Greater currents can damage the instrument.

\*\*\* Pin 34 is connected to the + input of the optical isolator through a 620  $\Omega$  current limiting resistor. Pin 35 is connected to the - side of the optical isolator. Recommended force current through this circuit should be between 1 and 5 mA nominal (10 mA max).



**Figure 2-33: Isolated Connection**

### 2.7.2 IEEE-488.2 Interface

The IEEE-488.2 interface is available as an option to the 1865. When this option is present connection is made through a connector (24 pin) on the rear panel. This interface can be used to connect to a system containing a number of instruments and a controller in which each meets IEEE Standard 488.2-1987 (Standard Digital Interface for Programmable Instrumentation) Refer to Table 2.4 below for a full tabulation of connections and Table 2.5 for the command set.

The following functions have been implemented. Refer to the standard for an explanation of the function subsets, represented by the identifications below.

SH1	Source Handshake	PP1	Parallel Poll	AH1	Acceptor Handshake
DC1	Device Clear	DT1	Device Trigger	SR1	Service Request
RL1	Remote Local	L3	Listener	C0	Controller
E2	Electrical Interface	T5	Talker		

**Table 2-4: IEEE-488.2 Interface Connections**

<b>Signal Name</b>	<b>Pin Number</b>	<b>Function</b>
DAV	6	Low state: "Data is Available" and valid on DI01 through DI08
NRFD	7	Low state: At least one listener on the bus is "Not ready for Data".
NDAC	8	Low state: At least one listener on the bus is "Not Accepting Data".
ATN	11	"Attention" specifies 1 of 2 uses for the DI01 through DI08 lines Low state - Controller command messages High state - Data bytes from the talker device
IFC	9	"Interface Clear" Low state - Returns portions of interface system to a known quiescent state.
SRQ	10	"Service Request" Low state - a talker or listener signals (to the controller) need for attention in the midst of the current sequence of events
REN	17	"Remote Enable" Low state - enables each device to enter remote mode when addressed to listen High state - all devices revert to local control
EOI	5	"End of Identify" if ATN is in high state, then low state of EOI indicates end of a multiple-byte data transfer sequence. If ATN is in low state, then low state of EOI activates a parallel poll.
DI01	1	The 8-line data bus, that conveys interface messages (ATN low state) or device-dependent messages (ATN high state), such as remote-control commands from the controller or from a talker device
DI02	2	
DI03	3	
DI04	4	
DI05	13	
DI06	14	
DI07	15	
DI08	16	

**Table 2-5: IEEE and RS-232 Commands**

<b>Command</b>	<b>Function</b>	<b>Parameter(s)</b>
<b>CONFigure:</b>		
VALid?	Is filename valid to save?	XXXXXXXX
SAVE:		
DUPLICATE	Save setup as duplicate filename in battery backed up RAM	XXXXXXXX
NEW	Save setup as new filename in battery backed up RAM	XXXXXXXX
RECall filename	Recall setup filename from battery backed up RAM	XXXXXXXX
FVALid?	Is filename valid to save?	XXXXXXXX
FSAVE:		
DUPLICATE	Save setup as duplicate filename on USB	XXXXXXXX
NEW	Save setup as new filename on USB	XXXXXXXX
FRECall filename	Recall setup filename from USB flash drive	XXXXXXXX
HANDler (state)	Turn handler port OFF or ON	0 (OFF) 1 (ON)
VOLTage value	Set the voltage to value	0000.000
TCHarge value	Set the charge time to value	000
TDWell value	Set the dwell time to value	000
TMEasure value	Set the measure time to value	000
TDIScharge value	Set the discharge time to value	000
MODE	Set the mode to	A (Auto) M (Manual)

**CAUTION**

When using **Manual MODE** via the RS232 interface, a delay time must be inserted between the issuing of the **Start** command and the sending of the **Fetch?** command. This delay time must be sufficient to ensure that the 1865+ has displayed a measurement. If the **Fetch?** is sent before data is displayed, a timeout can occur which will cause the 1865+ to stop responding to RS232 commands, and the 1865+ would have to be reset manually.

RANGE	Set the range to	Auto 1mA 100uA 10uA 1uA 100nA 10nA 1nA
AVERage	Set # to average	000
LIMit value	Set the limit to value	floating point number
FRESult	Set the result format to	S (Scientific) E (Engineering)
DISPlay type	Set display type to	R (Resistance) I (Current) P (Pass/Fail) N (No Display)
SONPass	Stop on pass	000
RVALid?	Is results filename valid?	XXXXXXXX
RTOUSB:	Results to USB	

**Table 2-5: IEEE and RS-232 Commands (Continued)**

<b>Command</b>	<b>Function</b>	<b>Parameter(s)</b>
DUPLicate	Save results as duplicate filename on USB	XXXXXXXX
NEW	Save results as new filename on USB	XXXXXXXX
APPend	Append results to existing filename	XXXXXXXX
CLOSE	Close results of filename	XXXXXXXX
<b><u>SYSTEM:</u></b>		
TIME	Set the time to hours, minutes	hh:mm
DATE	Set the date to month, day, year	mm/dd/yyyy
LOCKout state	Set the front panel lockout off or on	0 (Off) 1 (On)
ELAPsed?	Query the elapsed time the machine has run	
DCALibration?	Query the calibration date	
<b><u>MEASure:</u></b>		
RESistance	Measure the resistance value	
CURRent	Measure the current value	

**FETCH?**

Fetches the most recent measurement value (with pass/fail if limit selected) for the selected parameter, resistance or current. The character sequence is as follows, terminated with a line feed: N.NNNNE+NNN (2 spaces) PASS. The plus (+) sign will be negative (-) when the parameter is selected as current. Pass can also be Fail or neither if no limit is entered.

**\*IDN?**

Returns instrument identification "IET,1865,0,software version"

**START**

Initiates a measurement in Auto mode, in Manual mode it initiates charge, if sent again it takes one measurement, each time sent thereafter one additional measurement is taken.

**STOP**

Stops a measurement in process in Auto mode, in Manual mode it exits the measurement loop to discharge , if sent again it exits discharge.

**CALibrate:**

DATA?	Returns the calibration data to the user (21 values) <i>see next page</i>
ZERO	Instrument zero

**NOTE:**

When a “Bad Zero Calibration” message is returned, query the IEEE for an error using the ESR for a decimal value of 16 for an execution error. Looking at the execution error prevents an automation program from hanging while waiting for the instrument to make a measurement and return a value.

**Table 2-5: IEEE and RS-232 Commands (Continued)**

Description of the 21 values returned by the remote “CAL: DATA?”

1	The value of the internal voltage standard
2	The 100 volt full scale value
3	The 1000 volt full scale value
4	The gain of the 500:1 voltage attenuator (.002)
5	The gain of the 50:1 voltage attenuator (.02)
6	The gain of the 5:1 voltage attenuator (.2)
7	The input resistance
8	The value of the range 1 standard (2 kΩ)
9	The value of the range 2 standard (20 kΩ)
10	The value of the range 3 standard (200 kΩ)
11	The value of the range 4 standard (2 MΩ)
12	The value of the range 5 standard (20 MΩ)
13	The value of the range 6 standard (200 MΩ)
14	The value of the range 7 standard (2 GΩ)
15	The open circuit correction for range 1
16	The open circuit correction for range 2
17	The open circuit correction for range 3
18	The open circuit correction for range 4
19	The open circuit correction for range 5
20	The open circuit correction for range 6
21	The open circuit correction for range 7

<b>Command</b>	<b>Function</b>	<b>Parameters</b>
<b><u>RST</u></b> (Reset)	This command performs a device reset	
<b><u>CLS</u></b> (Clear Status)	This command clears status data structures	
<b><u>ESR?</u></b> (Event Status Register)	Sends the event status register information. This is a destructive read.	
<b><u>STB?</u></b> (Status Byte Register)	Sends user the status byte register information	
<b><u>ESE?</u></b> (Event Status Enable Register)	Sends the user event status enable register info.	
<b><u>SRE?</u></b> (Service Request Enable Register)	Sends the user service request enable register info.	
<b><u>ESE</u></b> (Event Status Enable Register)	Writes the event status enable register info.	value
<b><u>SRE</u></b> (Service Request Enable Register)	Writes the service request enable register info.	value

Status Byte Register			Event Status Register		
Bit	Decimal Value	Use	Bit	Decimal Value	Use
7	128	None	7	128	Power Up since last Query
6	64	SRQ, SPOL Resets	6	64	None
5	32	Summary Standard Event Status Register	5	32	Command Error (Syntax)
4	16	Message Available	4	16	Execution Error (Over Range, etc.)
3	8	None	3	8	No Contact
2	4	None	2	4	None
1	2	None	1	2	None
0	1	None	0	1	Operation Complete



This page is intentionally left blank.

### 2.7.3 Sample Program for IO Tech GPIB card

```
OPEN "\dev\ieeeeout" FOR OUTPUT AS #1
IOCTL #1, "BREAK"
PRINT #1, "RESET"
OPEN "\dev\ieeeein" FOR INPUT AS #2
PRINT #1, "fill error"
```

```
PRINT #1, "remote 04"
PRINT #1, "local lockout"
```

```
id$ = space$(30) : c$=space$(15)
```

```
PRINT #1, "output 04;idn?"
PRINT #1, "enter 04"
FOR i = 1 TO 3000: NEXT i
INPUT #2, id$
PRINT "Company identification is "; id$
INPUT #2, id$
PRINT "Instrument identification is "; id$
INPUT #2, id$
PRINT "Serial number is "; id$
INPUT #2, id$
PRINT "Software revision is "; id$
```

```
PRINT #1, "output 04;syst:Dcal?"
PRINT #1, "enter 04"
INPUT #2, c$
PRINT "This unit was calibrated on "; c$
```

```
PRINT #1, "output 04;conf:volt 100"
PRINT #1, "output 04;conf:lim 9.97e5"
PRINT #1, "output 04;conf:disp r"
```

```
PRINT #1, "spoll"
INPUT #2, y
IF y THEN
    PRINT #1, "spoll 04"
    INPUT #2, x : PRINT "spoll 04 = "; x
END IF
```

' an error will produce a SRQ

```
PRINT #1, "output 04;MEAS:RES"
y = 0
WHILE y = 0
PRINT #1, "spoll"
```

'SRQ at end of measurement

```

INPUT #2, y
IF y THEN
    PRINT #1, "spoll 04"
    INPUT #2, x
END IF
WEND
PRINT #1, "output 04;fetc?"           'request data
PRINT #1, "enter 04"                 'get data
INPUT #2, c$
PRINT c$

PRINT #1, "output 04;system:lock 0"  'enable front panel
PRINT #1, "local"
END

```

#### 2.7.4 RS232 Interface

The 1865 instrument comes standard with an RS232 serial port interface, available through a connector (9 pin) on the rear panel of the instrument, for connecting to a PC. The RS232 standard defines electrical specifications for the transmission of bit serial information. The use of the RS232 port requires five lines: receive data, transmit data, data terminal ready, data set ready and signal ground. With some controllers additional signals maybe required and are listed in Table 2-6. Refer to Figure 2-34 for null modem cable configuration to the standard db9 or db25 connector. Refer to Table 2.5 for the command set which also applies to the RS232 interface. When using the RS-232 interface with a printer the IEEE-488.2 Mode must be set to **Talk** and the State to **Disable**.

**Table 2-6: RS232 Interface Connections**

Signal Name	Pin Number	Function
<b>Input:</b>		
DCD	1	Data Carrier Detect
DSR	6	Data Set Ready
RXD	2	Receive Data
CTS	8	Clear to Send
RI	9	Ring Indicator
<b>Outputs:</b>		
RTS	7	Request to Send
TXD	3	Transmit Data
DTR	4	Data Terminal Ready
GND	5	Signal Ground

### db9 to db9 Cable Configuration

1865			Controller	
Pin #	Function		Pin #	Function
2	Receive data	Connect to	3	Transmit data
3	Transmit data		2	Receive data
4	Data terminal ready		6	Data set ready
5	Signal ground		5	Signal ground
6	Data set ready		4	Data terminal ready

### db9 to db25 Cable Configuration

1865			Controller	
Pin #	Function		Pin #	Function
2	Receive data	Connect to	2	Transmit data
3	Transmit data		3	Receive data
4	Data terminal ready		6	Data set ready
5	Signal ground		7	Signal ground
6	Data set ready		20	Data terminal ready

**Figure 2-34: RS-232 Cable Configurations**

#### 2.7.5 Sample Program for RS-232

```

OPEN "com1:9600,n,8,1,rs" FOR RANDOM AS #2
'OPEN "com2:9600,n,8,1" FOR RANDOM AS #2
PRINT #2, "system:lock 1"
PRINT #2, "idn?"
GOSUB cget
r$ = INPUT$(x, #2): PRINT "idn = "; r$;
PRINT #2, "syst:dcal?"
GOSUB cget
r$ = INPUT$(x, #2): PRINT "calibration date is "; r$;

PRINT #2, "conf:fres s"
PRINT #2, "conf:tch 0"
PRINT #2, "conf:tme 0"

PRINT #2, "conf:volt 100"
FOR i = 1 TO 30000: NEXT i
gg:
PRINT #2, "meas:res"

```

'some com ports require this ie ,rs  
'others run best without ,rs  
'get unit identification  
'read serial data subroutine  
'get calibration date  
'configure unit  
'delay

```
FOR i = 1 TO 30000: NEXT i
PRINT #2, "fetc?"
GOSUB cget
```

```
s$ = INPUT$(x, #2)
PRINT "res at 100 volts is "; s$;
PRINT #2, "system:lock 0"
END
```

cget:

' subroutine to get serial input loop  
' until first character is received

```
DO WHILE (LOC(2) = 0)
LOOP
y = x + LOC(2)
DO WHILE (x <> y)
y = x
FOR j = 1 TO 300: NEXT j
x = LOC(2)
LOOP
RETURN
```

' then get the rest of the string

### 2.7.6 Results to Printer

The 1865 can be setup to output to an RS-232 or IEEE printer. Results format is the same as results to USB, refer to paragraph 2.6.3.6.

**RS-232** RS-232 must be selected on I/O Menus and format set IEEE must also be selected for Talk mode and Disable state.

**IEEE** IEEE must be selected on I/O Menus and set for Address, Talk mode and Enable state.

## 2.8 Error Messages

"BAD DRIVE-REQUEST STRUCTURE"	Flash drive is either not connected or defective
"BAD VOLTAGE SENT TO FUNCTION"	Improper voltage entered during calibration procedure
"BAD ZERO CALIBRATION"	Zeroing error, repeat and/or remove component from input terminals/fixture (Refer to Note on p.63)
"CALIBRATION STANDARD OUT OF RANGE"	Entered value > than 1% of 1 Megohm
"CORRUPT SETUP DATA"	Stored setups lost or corrupt (battery for non-volatile memory may be defective or has been disconnected)
"CRC ERROR ON USB"	Stored setup lost or corrupt (cyclic-redundancy-check)
"PROTECT ERROR"	Flash drive is write protected
"ELAPSED TIME ERROR, SET TO 0"	Elapsed time is incorrect and has been set to zero (battery for non-volatile memory may be defective or has been disconnected)
"FAILURE # SEE DOCUMENTATION"	Hardware or software failure, 1 - 99 (# list not included in this manual)
"FILE ACCESS VIOLATION"	File selected from flash drive is Read Only
"FILE EXISTS"	File already exists under the chosen name
"USB DRIVE NOT READY"	Flash drive is either not connected or defective
"USB MEDIA DEFECT"	Flash drive defective, format or replace
"USB READ FAULT"	Flash drive is either not connected or defective
"USB SECTOR UNFORMATTED"	Flash drive is not formatted

"USB SEEK ERROR"	Flash drive is either not connected or defective
"USB WRITE FAULT"	Flash drive is either not connected or defective
"GENERAL FAILURE, USB"	Flash drive is either not connected or defective
"HANDLER PORT FAILURE"	I/O port malfunction during power up
"HARDWARE TIMER FAILURE, REBOOT"	Hardware malfunction during power up
"INVALID CALIBRATION CODE"	Entered calibration code is invalid
"INVALID LIMIT"	Entered limit is invalid
"INTERNAL HARDWARE FAILURE, REBOOT"	Hardware malfunction during power up
"LIMIT INVALID, SET TO NONE"	No limit is accepted (out of range or invalid)
"LOW BATTERY VOLTAGE"	Memory backup battery, low voltage (setups and instrument zero could be lost)
"MAXIMUM # OF SETUPS REACHED"	Maximum number of files have been stored
"NO CALIBRATION DATA FOUND"	Calibration required (refer to Paragraph 5.4)
"NO IEEE 488.2 INTERFACE"	Unit does not include IEEE 488.2 Option
"NO INTERLOCK SIGNAL"	Open interlock connection at rear panel I/O Port
"NO PASSWORD ENTERED"	Password entry canceled, re-enter
"NO SETUP DATA FOUND"	Memory backup battery has been disconnected, reset time and date
"NO ZERO DATA FOUND"	Unit requires zeroing (Refer to Utilities Menu, P 2.6.4.3)
"PASSWORD DID NOT MATCH"	Incorrect password entered

"PASSWORD NOT SAVED IN RAM"	Error trying to save password, repeat
"PASSWORD VERIFICATION FAILURE"	Wrong password entry for verification
"RANGE RESISTOR VALUE OUT OF RANGE"	Malfunction of internal calibration resistors
"REMOTE COMMAND INVALID"	IEEE or RS232 command is incorrect (for example: to set voltage use VOLTage)
"REMOTE COMMAND PARAMETER INVALID"	IEEE or RS232 parameter is incorrect (for example: voltage parameter can be XXXX.XXX)
"REMOTE COMMAND PREFIX INVALID"	IEEE or RS232 command prefix is incorrect (for example: to configure unit use CONFigure)
"SHUT THE POWER OFF"	Malfunction of high voltage source
"TIME / DATE ERROR, PLEASE SET"	Reset time and date
"UNABLE TO READ FROM USB"	Flash drive is either not connected or defective
"UNABLE TO READ THAT FILENAME"	Selected file unreadable, improper format
"UNABLE TO SAVE CALIBRATION DATA"	Repeat calibration, data not stored
"UNABLE TO WRITE TO USB"	Flash drive is either not connected or defective
"UNABLE TO WRITE TO REMOTE"	IEEE or RS232 not setup correctly or IEEE option not present
"UNKNOWN UNIT"	USB is not recognized
"VALID RANGE = low value - hi value"	Entry invalid, should be between specified values
"VOLTAGE PROGRAM FAILURE"	Malfunction of instrument power supplies



---

## Section 3 : Applications

---

### 3.1 Insulation Resistance Testing

Insulation resistance of materials is one of several parameters that may indicate the condition of insulation. An insulation test is to measure the resistance offered by the insulating members of a component part to an impressed direct voltage tending to produce a leakage of current through or on the surface of these members. There are times when knowledge of insulation resistance can be very important, for example; when resistance is high it may be the limiting factor in design of a high-impedance circuit, when resistance is low it can disturb the operation of circuits intended to be isolated. Insulation resistance measurements should not be considered the equivalent of a voltage breakdown test. Material with high insulation resistance could possess a mechanical fault that might fail during a voltage test and conversely material with low insulation resistance might not breakdown during a voltage test.

Factors that affect insulation resistance measurements include such things as temperature, humidity, previous conditioning, test voltage, charging current and duration of the test voltage (electrification time). It is characteristic of certain components (for example, capacitors or capacitive components or materials) for the current to fall from an instantaneous high value to a steady lower value, consequently the measured insulation resistance will increase from an appreciable time as test voltage is applied. Because of this it may take minutes to approach maximum insulation resistance readings, thus specifications usually require that readings be taken after a specified time, again electrification time. A routine test that has been widely adopted for insulation testing calls for the measurement of the apparent leakage resistance after a test voltage has been applied for 1 to 2 minutes.

For discussion on insulation resistance measurement methods and procedures refer to MIL-STD-202 and ASTM (American Society for Testing and Materials) Standard D257.

### 3.2 Test Sample Resistivity Measurements

The 1865 can be used for measuring the resistivity of test samples as described by ASTM Standard D 257, which describes in detail the techniques for both surface and volume resistivity measurements. The 1865-11 Test Cell is shown in Figure 3-1




Figure 3-1: 1865-11 Surface Plate Test Sample Cell

The 1865-11 Test Cell measures resistance and with unique formulas, the resistance can be converted to surface and volume resistivity. The formulas required to convert from measured resistance to resistivity are given in the ASTM D257 Standard. For the circular or concentric electrode configuration, the resistivity is calculated by:

$$\text{Surface Resistivity} = \rho_s = \frac{P}{g} R_s$$

P = effective perimeter of measuring electrode  
 g = dimension of space between electrodes 2 and 1  
 R<sub>s</sub> = measured surface resistance in ohms

$$\text{Volume Resistivity} = \rho_v = \frac{A}{t} R_v$$

A = effective area of measuring electrode  
 t = average thickness of the specimen  
 R<sub>v</sub> = measured volume resistance in ohms

Refer to ASTM D257 for formulas based on electrode configuration of the test cell.

### 3.3 Capacitor Insulation Resistance

#### 3.3.1 General

The insulation resistance measurements of capacitors is different from that of resistors by the fact that some consideration must be given to the charge and discharge currents. Consideration should also be given to high value, low leakage capacitive devices relative to dc resistance measurements. Inherent to some degree in all high resistance measurement instrumentation is the inability to provide stable leakage measurements on high value capacitors. This is due to the fact that a capacitive element is very ac sensitive and the dc voltage applied to the device always contains a small percentage of low frequency noise ripple. Measurements on pure resistive elements will tolerate a high degree of ripple due to the voltage ratio measurements whereas a capacitor easily passes the noise ripple. When this is amplified by the current amplifier of the measuring instrument results can fluctuate and vary widely. To eliminate this in the 1865 two resistance adapters are supplied which can be placed in series with the (-) unknown (black) when measurements are made on the low current ranges (the 1MΩ, Hi Range Adapter is recommended for ranges 1nA & 10nA and the 100kΩ, Lo Range Adapter for ranges 100nA, 1nA & 10uA). This added resistance has negligible effect on the dc measurement since its value is very small compared to the leakage resistance of the unknown however it increases the ac input resistance to the current amplifier, reducing the ac gain and thus minimizing the wide fluctuations. This added resistance will have an effect on the charge time constant and is discussed briefly in paragraph 3.3.2 below.

#### WARNING

Capacitors being measured may be charged and contain lethal energy. Always make sure the **CAUTION HIGH VOLTAGE** Indicator is OFF when connecting or disconnecting the capacitor under test.

### 3.3.2 Charge Time Constant

The time constant for charging a capacitor in the charge phase is determined by the value of the capacitor times the effective source impedance of the supply. The supply resistance is approximately,

$$R_O = \frac{E}{I_{\max}} \Omega = \frac{E}{0.002 \text{ A}} \Omega = \frac{E}{2} \text{ k}\Omega$$

where E is the user specified test voltage in volts and I max is the current limit of the 1865 instrument, which is approximately 2mA. Therefore, the time constant is

$$T = R_O C_X = \frac{E C_X}{2000} \text{ seconds}$$

where Cx is in  $\mu\text{F}$ . As an example, for a 500 V test voltage Ro is approximately 250 k $\Omega$  so that the time constant for charging of a 1 $\mu\text{F}$  capacitor is 0.25 seconds. The charge time should be set for a minimum of 10 time constants.

When the resistance adapters (discussed in paragraph 3.3.1 above) are used the time constant will be increased. In the example above if the 100 k $\Omega$  or 1 M $\Omega$  adapter is placed in series with the effective source impedance of 250 k $\Omega$  the charge time will be increased by a factor of 0.4 and 4 respectively.

### 3.3.3 Discharge Time

The time constant for discharging a capacitor in the discharge phase is determined by the value of the capacitor times the resistance of the 1865 discharge circuit. The discharge resistance is approximately 66 k $\Omega$ . The CAUTION HIGH VOLTAGE lamp is turned off after the user specified discharge time. If the discharge time is set to zero or a very short time a capacitor could remain with a charge after the indicator is extinguished. However, the discharge time is so short this is not a practical consideration except for capacitors greater than 10  $\mu\text{F}$  or so.

Capacitors with high dielectric absorption can have a residual charge even after they are shunted and must be repeatedly shunted to completely discharge. Usually a "voltage recovery" of this type would be a very small percentage of the original applied voltage and generally not dangerous to the operator. This risk is further minimized by the fact that the 1865 circuitry remains in a discharge mode until the operator initiates another charge and measure cycle.

### 3.4 Resistance Measurements

The recommended test voltage is typically 100 V for fixed composition resistors, film resistors or wire wound resistors above 100 kΩ. Refer to the component manufacturers' recommended test voltages. These resistors (values greater than 1000 Ω) can easily be measured on the 1865 where the instrument basic accuracy of 0.5% is adequate. For single component resistors a two terminal connection, +UNKNOWN and -UNKNOWN is recommended.

### 3.5 Measurement of Voltage Coefficient

The 1865 instrument may be used to measure voltage coefficient which is defined as :

$$\frac{R_1 - R_2}{R_2 (V_1 - V_2)} \times 100\%$$

where  $V_1 > V_2$

$R_1$  is the resistance at  $V_1$ , the higher voltage

$R_2$  is the resistance at  $V_2$

For example, if  $V_1 = 500$  V and  $V_2 = 100$  V,


$$\text{Voltage Coefficient} = \frac{R_{500V} - R_{100V}}{R_{100V} (400)} \times 100\%$$

$$= \frac{\Delta R}{R_{100V}} \times 100\%$$

This voltage coefficient is usually negative.

### 3.6 Guarded, 3-Terminal Measurements

In many cases it is necessary to measure the resistance between two points in the presence of resistance from each of these points to a third point. This third point can often be guarded to avoid error caused by the extraneous resistance. This can best be illustrated as shown in Figure 3-2 below. Here  $R_X$  is the quantity to be measured in the presence of  $R_A$  and  $R_B$ . If the junction of  $R_A$  and  $R_B$  is tied to guard,  $R_A$  is placed across the voltage source and has no effect if it is greater than  $1.25\text{ M}\Omega$ . As long as  $R_B$  is greater than  $R_S$  (standard range resistor) the error caused by  $R_B$  is minimized, thus if there is a choice its better to have the higher of the two stray resistances connected to  $R_B$ .



**Figure 3-2: Guarded Measurement Configuration**

The guard terminal can be used whether GUARD or the +UNKNOWN terminal is grounded, but it's important to note that if the +UNKNOWN terminal is grounded the GUARD terminal will be at a high negative voltage level. When the GUARD terminal is connected to a true ground of a device, such as chassis, it is the one that **must** be grounded, not the +UNKNOWN.

---

## Section 4: Theory

---

### 4.1 General

The 1865 Megohmmeter/IR Tester consists of a standard mechanical package, LCD display/keypad, microprocessor unit, digital I/O interface and power supply. It incorporates circuitry unique to the 1865, an analog instrument module, and a power supply. In addition, there is an IEEE.488.2 option, discussed briefly below.

### 4.2 Instrument Description

#### 4.2.1 Basic Instrument Architecture

##### Processor Board

The processor board provides the basic control for the 1865. It has a Pentium 4 processor, mimics the IBM-PC architecture, and uses a DOS operating system. Besides the central processing unit and memory modules it includes ports for a keypad, a USB connection, and an RS232 interface. It stores instrument software in an electronic “chip disk.” The RS232 port is connected to its rear panel connector by a cable. The processor board is stacked on the Digital I/O Board which is mounted on the Analog Instrument board. The processor board can have an optional IEEE-488.2 board stacked on it.

##### Digital I/O Board

The digital I/O board provides interfaces to the LCD display, the keypad and provides handler interface functions through a cable to the rear panel connection. It also contains the circuitry for the instrument's many timing functions, as well as a non-volatile memory used for storing test setup conditions and corrections for instrument zeroing. A battery backup for the RAM on this board is provided by 3-AA alkaline batteries which should be changed, once a year. This board is mounted on the analog instrument board in the instruments main compartment. The 3 batteries are installed in the long round tube towards the rear left of the unit.

### LCD Display/Keypad Panel


The front panel user interface consists of a molded silicon rubber keypad that actuates a membrane switch assembly. The keypad is environmentally sealed, designed for long life, and all keys provide tactile feedback to the operator. The 2 1/2" x 4 3/4" LCD is a high-resolution graphic display with on/off backlight for visual clarity. Both keypad and display are connected to the instrument I/O board via ribbon cables.

### **4.2.2 1865 Instrument Modules**

#### Analog Instrument Board

The analog instrument board is the heart of the 1865. It includes the measurement detector, high voltage source, and bus interface to the processor. This board also contains a non-volatile memory in EEPROM (electrically erasable programmable read only memory) for retaining vital calibration information. This is the main board in the instrument compartment, to the left of the power supply modules. All other boards are mounted to it. A brief description of the operation of the measurement detector is as follows.

Figure 4-1 shows the basic block diagram for the measurement module. A programmable high voltage (0 - 1000V) is applied to the unknown component ( $R_x$ ). The current flowing through the unknown is measured by the current to voltage converter whose output ( $E_1$ ) is applied to the A/D for processing by the instruments CPU. The measured results can be expressed as  $E_1 = -(R_s/R_x)E_x$ . This technique is dependent upon the accuracy of the applied voltage source, so to improve measurement accuracy and eliminate applied voltage dependency an extra current measurement based on another set of reference standards ( $R_b/R_a$ ) is made. This measurement results can be expressed as  $E_2 = -(R_b/R_a)E_x$ . The ratio of the  $E_2/E_1$  results in the expression for the unknown  $R_x = (R_a/R_b)(R_s)(E_2/E_1)$ .



**Figure 4-1: Detector Block Diagram**



### Power Supply Assembly

The 1865 Power Supply Assembly consists of two modular, switching power supplies. The first has a +24, +5, and -12 Vdc output. It supplies the Instrument Board. The second has +5 and  $\pm 15$  Vdc outputs, and powers the I/O and Processor boards.

### **4.2.3 Instrument Options**

#### IEEE-488.2 Board & Cable

The IEEE-488.2 board is offered as an option to the 1865 and allows complete control over all aspects of the instrument. Any user control available through the keyboard or any information available for display can be accessed over this interface. This board is mounted towards the right rear of the unit stacked above the processor board. Connection to the IEEE-488.2 connector on the rear panel is made by an interconnecting cable.

#### USB Port

A USB port is included on the 1865 for storing multiple setup conditions beyond what can be retained in the internal RAM of the unit, and for storing test results. It is also used for loading program software.



---

## Section 5: Service & Calibration

---

### 5.1 Routine Maintenance

Routine maintenance of the 1865 instrument includes battery replacement, time & date resetting, display contrast monitoring, preventative cleaning and calibration.

#### 5.1.1 Battery Replacement

**CAUTION**

To avoid damaging the unit, replace the batteries annually.

Backup power for the instrument's non-volatile memory is supplied by 3 standard AA batteries. These should be **replaced annually with alkaline batteries**, otherwise damage to the unit is possible as a result of battery leakage. IET will assume no responsibility for instrument damage resulting from the batteries not being changed as recommended. To replace the batteries, refer to figure 5-1 and proceed as follows:

1. Turn the instrument on and make sure it is **not** in measurement mode.

**CAUTION**


If the batteries are removed with the power off, there would be no power to the non-volatile memory and important data such as stored test conditions would be lost.

2. Place a flat head screwdriver in the groove of the battery compartment end cap and rotate counterclockwise (CCW) about 1/4 turn to remove.
3. Lift the front of the instrument up slightly so that the batteries slide out of the compartment.
4. Install three new batteries, **positive side out**.

**CAUTION**

Do not install the batteries backwards.

5. Reinstall the end cap and rotate clockwise (CW) to secure.



**Figure 5-1: Battery Compartment**

### 5.1.2 Resetting of Time and Date

If for some reason the backup power supplied by the 3 AA batteries should fail during shipment of the instrument (due to shock, vibration or extreme temperature) the unit will lose its zero, time and date, elapsed time and stored setup conditions. An indication of such an occurrence would be the display of the error message "ELAPSED TIME ERROR, SET TO 0" when the unit is first powered up. The most likely cause would be an intermittent connection to the battery due to shock or vibration. **It is very important that the time and date be reset and the instrument zeroed before proceeding with any measurements.** Proceed as follows:

1. Press [MENU] key to select menu display.
2. Press Right or Left Arrow key to select Utilities menu.
3. Press Up or Down Arrow key to select Set Time/Date.
4. Press [ENTER] key to activate the entry field.
5. Set the current time and date as instructed on the display, refer to paragraph 2.6.4.6 if necessary. After the time and date have been reset press [MENU] to return to the menu display.
6. Press Up or Down Arrow key to select Zero.
7. Press [ENTER] key to activate the Zero routine and follow instructions on the instrument display.
8. Once the Time and Date have been reset and the instrument zeroed the 1865 is ready for routine measurements. It's important to note that the elapsed time will have been reset back to zero during this process.

### 5.1.3 Loss of Display Contrast

If for some reason the instrument should lose its display contrast it is possible to reset it easily using the procedure below. **Loss of contrast would exhibit no display at all when the instrument is powered up.**

Procedure for restoring loss of contrast:

1. Consider the SELECT buttons as labeled 1, 2, 3, and 4 from top to bottom.
2. Turn the instrument on and wait 20 seconds (or after High Voltage light flashes)
3. Press [MENU] key twice.
4. Press [SELECT "4"] one time.
5. Press [SELECT "1"] two times.
6. Press [ENTER].
7. Press [SELECT "1"] many times till contrast returns to normal.
8. Press [ENTER].
9. Arrow up to [SAVE SETUP] and save as [DEFAULT].

If the above procedure fails to restore the contrast try repeating again. Failing restoration of the contrast may be indication of another instrument problem.

### 5.1.4 Preventive Maintenance/Cleaning

In addition to the annual battery replacement and calibration discussed below periodic cleaning of dust from the 3 1/3" disk drive (when this option is present) is recommended depending on the environmental conditions. Vacuuming of the drive by qualified service personnel should be done in accordance with common procedures used in computer maintenance.