



Standard Equipment

- 1 Multimeter for isolation measurement
- 1 protective rubber cover
- 1 KS17-2 cable set
- 1 condensed operating instructions, English/German
- 1 operating instructions in English and German (CD ROM or printed)
- 1 DKD calibration certificate with calibration report
- 2 batteries, 1.5 V, type AA, installed

Function	METRAHIT	Iso
V AC+DC TRMS (Ri = 1 MΩ)		•
V AC / Hz TRMS (Ri ≥ 9 MΩ)		• 1kHz Filter
V AC+DC TRMS (Ri ≥ 9 MΩ)		•
V DC (Ri ≥ 9 MΩ)		•
Hz (V AC)		... 300 kHz
Bandwidth V AC		15 Hz ... 10 kHz
A AC / Hz TRMS		300 μA
A AC+DC TRMS		3/30/300 mA
A DC		3 A / 10 A
Fuse		10 A/1000 V
Transformation factor $\succ C$		mV/A, mA/A
Hz (A AC)		... 30 kHz
Insulation Resistance $M_{\Omega ISO}$		adjustable test voltage
Resistance $\Omega$		•
Continuity $\square 1)$		•
Diode ... 5,1 V $\rightarrow \dashv$		•
Temperature TC (K)		•
Temperature RTD		•
Capacitance $\dashv \dashv$		•
MIN/MAX / data hold		•
4 MBit memory <sup>1)</sup>		•
IR Interface		•
Power pack adapter socket		•
Protection		IP54
Measuring category		1000 V CAT II, 600 V CAT III

<sup>1)</sup> For 15,400 measured values, sampling rate adjustable from 0.1 second to 9 hours

### **Accessories (sensors, plug inserts, adapters, consumable materials)**

The accessories available for your instrument are checked for compliance with currently valid safety regulations at regular intervals, and are amended as required for new applications. Currently up-to-date accessories which are suitable for your measuring instrument are listed at the following web address along with photo, order number, description and, depending upon the scope of the respective accessory, data sheet and operating instructions:  
[www.gossenmetrawatt.com](http://www.gossenmetrawatt.com)

See also chapter 10 on page 66.

### **Product Support**

Technical Queries  
(use, operation, software registration)

If required please contact:

GMC-I Messtechnik GmbH

#### **Product Support Hotline**

Phone: +4 9 911 8602-0

Fax: +49 911 8602-709

E-mail support [t@gossenmetrawatt.com](mailto:t@gossenmetrawatt.com)

### **Software Enabling for METRAWin 10**

GMC-I Messtechnik GmbH

#### **Front Office**

Phone: +4 9 911 8602-111

Fax: +4 9 911 8602-777

E-mail: [info@gossenmetrawatt.com](mailto:info@gossenmetrawatt.com)

### **Training**

Training in Nuremberg, on-site training at customer facilities  
(scheduling, prices, registration, travel, accommodation)

If required please contact:

GMC-I Messtechnik GmbH

#### **Training Division**

Phone: +4 9 911 8602-406

Fax: +4 9 911 8602-724

E-mail: [training@gossenmetrawatt.com](mailto:training@gossenmetrawatt.com)

### Recalibration Service

We **calibrate** and **recalibrate** all instruments supplied by GMC-I Messtechnik GmbH, as well as other manufacturers, at our service center, for example after one year within the framework of your test equipment monitoring program, as well as prior to use etc. and offer you test equipment management free of charge.

### Repair and Replacement Parts Service Calibration Center\* and Rental Instrument Service

If required please contact:

GMC-I Service GmbH

#### Service Center

Thomas-Mann-Str. 16-20

90471 Nuremberg, Germany

Phone: +4 9 911 817718-0

Fax: +49 911 817718-253

E-mail [service@gossenmetrawatt.com](mailto:service@gossenmetrawatt.com)

This address is only valid in Germany. Please contact our representatives or subsidiaries for service in other countries.

\* **DKD** Calibration Laboratory for Measured Electrical Quantities  
DKD – K – 19701 accredited per DIN EN ISO/IEC 17025:2005

Accredited quantities: direct voltage, direct current value, direct current resistance, alternating voltage, alternating current value, AC active power, AC apparent power, DC power, capacitance, frequency, temperature

### Competent Partner

GMC-I Messtechnik GmbH is certified in accordance with DIN EN ISO 9001:2000.

Our DKD calibration lab is accredited by the Physikalisch-Technischen Bundesanstalt (German Federal Institute of Physics and Metrology) and the Deutscher Kalibrierdienst (German Calibration Service) in accordance with DIN EN ISO/IEC 17025:2005 under registration number DKD-K-19701.

We offer a complete range of expertise in the field of metrology: from **test reports** and **factory calibration certificates**, right on up to **DKD calibration certificates**.

Our spectrum of offerings is rounded out with free **test equipment management**.

As a full service calibration lab, we can calibrate instruments from other manufacturers as well.

# Table of Contents

Contents	Page	Contents	Page
<b>1 Safety Features and Precautions .....</b>	<b>8</b>	<b>5 Measurements ... ..</b>	<b>26</b>
1.1 Use for Intended Purpose .....	10	5.1 Voltage Measurement .....	26
1.2 Meanings of Danger Symbols .....	10	5.1.1 Direct and Pulsating Voltage Measurement, V DC and V (DC+AC) ....	27
1.3 Meanings of Acoustic Warning Signals .....	10	5.1.2 Alternating Voltage and Frequency Measurement V AC and Hz with Selectable Low-Pass Filter .....	28
<b>2 Operating Overview – Connections, Keys, Rotary Switch, Symbols 12</b>		5.1.3 Transient Overvoltages .....	30
<b>3 Initial Start-Up .....</b>	<b>16</b>	5.1.4 Voltage Measurements at Above 600 V .....	30
3.1 Batteries .....	16	5.2 Resistance Measurement, $\Omega$ .....	31
3.2 Activation .....	16	5.3 Temperature Measurement – Temp RTD .....	32
3.3 Setting the Operating Parameters .....	16	5.3.1 Measurement with Resistance Thermometers .....	32
3.4 Switching the Instrument Off .....	17	5.4 Continuity Test .....	35
<b>4 Control Functions .....</b>	<b>18</b>	5.5 Diode Testing with 2 mA Constant Current .....	36
4.1 Selecting Measuring Functions and Measuring Ranges .....	18	5.6 Capacitance Measurement .....	38
4.1.1 Automatic Range Selection .....	18	5.6.1 Cable Length Measurement m .....	38
4.1.2 Manual Measuring Range Selection .....	18	5.7 Insulation Resistance Measurement: in Telecommunications Networks – M $\Omega$ ISO Function .....	39
4.1.3 Quick Measurements .....	19	5.7.1 Connecting the Measurement Cables .....	40
4.2 Zero Offset / Relative Measurements .....	19	5.7.2 <b>Detection of Interference Voltages .....</b>	<b>40</b>
4.3 Display (LCD) .....	20	5.7.3 Performing Insulation Resistance Measurements .....	40
4.3.1 Digital Display .....	20	5.7.4 Ending the Measurement and Discharging .....	42
4.3.2 Analog Display .....	20	5.8 Current Measurement .....	43
4.4 Measured Value Storage: DATA (auto-hold / compare) .....	21	5.8.1 Direct and Pulsating Current Measurement, Direct Connection, A DC and A (DC+AC) .....	44
4.4.1 Saving Minimum and Maximum Values – MIN/MAX Function .....	22	5.8.2 Alternating Current and Frequency Measurement, Direct Connection, A AC and Hz .....	45
4.5 Measurement Data Recording .....	23	5.8.3 Direct and Pulsating Current Measurement with Clip-On Current Sensor, A DC and A (DC+AC) .....	46
		5.8.4 Alternating Current Measurement with Clip-On Current Sensor, A AC and Hz .....	47

Contents	Page	Contents	Page
<b>6 Device and Measuring Parameters .....</b>	<b>48</b>	<b>11 Index .....</b>	<b>68</b>
6.1 Paths to the Various Parameters .....	49		
6.2 List of All Parameters .....	49		
6.3 Querying Parameters – InFo Menu (as moving letters) .....	50		
6.4 Entering Parameters – SETUP Menu .....	50		
6.5 Default Settings .....	53		
<b>7 Interface Operation .....</b>	<b>54</b>		
7.1 Activating the Interface .....	54		
7.2 Configuring Interface Parameters .....	55		
<b>8 Technical Data .....</b>	<b>56</b>		
<b>9 Maintenance and Calibration .....</b>	<b>62</b>		
9.1 Displays – Error Messages .....	62		
9.2 Batteries .....	62		
9.3 Fuses .....	63		
9.4 Housing Maintenance .....	64		
9.5 Return and Environmentally Sound Disposal .....	64		
9.6 Recalibration Service .....	64		
9.7 Manufacturer’s Guarantee .....	65		
<b>10 Accessories .....</b>	<b>66</b>		
10.1 General .....	66		
10.2 Technical Data for Measurement Cables (scope of delivery: KS21T safety cable set) .....	66		
10.3 Power Pack NA   X-TRA (not included) .....	66		
10.4 Interface Accessories (not included) .....	67		

### 1 Safety Features and Precautions

You have selected an instrument which provides you with a high level of safety.

This instrument fulfills the requirements of applicable European and national EC directives. This is confirmed by means of the CE mark. A corresponding declaration of conformity can be requested from GMC-I Messtechnik GmbH.

The TRMS digital multimeter has been manufactured and tested in accordance with the following safety regulations: IEC 61010–1:2001 / DIN EN 61010–1/VDE 0411–1:2002. When used for its intended purpose (see page 10), safety of the operator, as well as that of the instrument, is assured. Their safety is however not guaranteed, if the instrument is used improperly or handled carelessly.

**In order to maintain flawless technical safety conditions, and to assure safe use, it is imperative that you read the operating instructions thoroughly and carefully before placing your instrument into service, and that you follow all instructions contained therein.**

The multimeter is equipped with an automatic socket blocking mechanism for your safety, and in order to safeguard your instrument. This mechanism is linked to the rotary switch and only allows access to those jacks which are actually required for the selected function. It also prevents the user from turning the rotary switch to impermissible functions after the measurement cables have already been plugged in.

### Measuring Categories and their Significance per IEC 61010-1

CAT	Definition
I	Measurements in electrical circuits which are not directly connected to the mains: <i>e.g. electrical systems in motor vehicles and aircraft, batteries etc.</i>
II	Measurements in electrical circuits which are electrically connected to the low-voltage mains: <i>via plug, e.g. in household, office and laboratory applications</i>
III	Measurements in building installations: stationary consumers, distributor terminals, devices connected permanently to the distributor

The measuring category and the maximum rated voltage which are printed on the device apply to your measuring instrument, e.g. 600 V CAT III or 1000 V CAT II.

#### Observe the following safety precautions:

- The multimeter may not be used in **potentially explosive atmospheres**.
- The multimeter may only be operated by persons who are capable of recognizing **contact hazards** and taking the appropriate safety precautions. Contact hazards according to the standards exist anywhere, where voltages of greater than 33 V RMS or 70 V DC may occur. Avoid working alone when taking measurements which involve contact hazards. Be certain that a second person is present.
- **Maximum allowable voltage** between the voltage measuring sockets or all connector sockets and ground is 1000 V for measuring category II, and 600 V for measuring category III.
- Be prepared for the occurrence of unexpected voltages at devices under test (e.g. defective devices). For example, capacitors may be dangerously charged.



- Make certain that the measurement cables are in flawless condition, e.g. no damage to insulation, no interruptions in cables or plugs etc.
- No measurements may be made with this instrument in electrical circuits with corona discharge (high-voltage).
- Special care is required when measurements are made in HF electrical circuits. Dangerous pulsating voltages may be present.
- Measurements under moist ambient conditions are not permitted.
- Be absolutely certain that the measuring ranges are not overloaded beyond their allowable capacities. Limit values are included in chapter 8; "Technical Data" in the table entitled "Measuring Functions and Measuring Ranges" in the "Overload Capacity" column.
- **The multimeter may only be operated with installed batteries or rechargeable batteries. Dangerous currents and voltages are otherwise not indicated, and the instrument may be damaged.**
- The instrument may not be operated if the fuse cover or the battery compartment lid has been removed, or if its housing is open.
- The input for the current measuring range is equipped with a fuse link.  
Maximum permissible voltage for the measuring circuit (= rated voltage of the fuse) is 1000 V AC/DC.  
Use specified fuses only (see page 61)! The fuse must have a **breaking capacity of at least 30 kA.**

### Repair and Parts Replacement

When the instrument is opened, voltage conducting parts may be exposed. The instrument must be disconnected from the measuring circuit before the performance of repairs or the replacement of parts. If repair of a live open instrument is required, it may only be carried out by trained personnel who are familiar with the dangers involved.

### Defects and Extraordinary Strains

If it may be assumed that the instrument can no longer be operated safely, it must be removed from service and secured against unintentional use.

Safe operation can no longer be relied upon:

- If the device demonstrates visible damage,
- If the instrument no longer functions, or if malfunctioning occurs,
- After long periods of storage under unfavorable conditions, e.g. humidity, dust or extreme temperature (see "Ambient Conditions" on page 59).

### 1.1 Use for Intended Purpose

- The respective multimeter is a portable device which can be held in the hand during the performance of measurements.
- Only those types of measurements described in chapter 5 may be performed with the measuring instrument.
- The measuring instrument, including measurement cables and plug-on test probes, may only be utilized within the specified measuring category (see page 61 and the table on page 8 regarding significance).
- Overload limits may not be exceeded. See technical data on page 56 for overload values and overload limits.
- Measurements may only be performed under the specified ambient conditions. See page 59 regarding operating temperature range and relative humidity.
- The measuring instrument may only be used in accordance with the specified degree of protection (IP code) (see page 61).

### 1.2 Meanings of Danger Symbols




Warning concerning a point of danger  
(attention: observe documentation!)




**Warning concerning dangerous voltage at the measurement input:  $U > 15 \text{ V AC}$  or  $U > 25 \text{ V DC}$**

### 1.3 Meanings of Acoustic Warning Signals



**Voltage warning:  $> 1000 \text{ V}$  (intermittent acoustic signal)**



**Current warning:  $> 11 \text{ A}$  (continuous acoustic signal)**




### 2 Operating Overview – Connections, Keys, Rotary Switch, Symbols




- 1 Display (LCD) (see page 13 for significance of symbols)
- 2 **MAN / AUTO** shift key for manual/automatic measuring range selection
  - △ Increase parameter values
  - “Operating Mode” menu:* Selection of individual menu entries against the direction of flow
- 3 **ON / OFF | LIGHT** key for switching device and display illumination on and off
- 4 **FUNC | ENTER** multifunction key
  - “Operating Mode” menu:* Acknowledge entry (ENTER)
- 5 **ISO ON / OFF** Insulation resistance measurement
  - Key for switching insulation resistance measurement on and off
  - ▷ Increase measuring range or move decimal point to the right (MAN function)
- 6 **Rotary switch** for measuring functions (see page 14 for significance of symbols)
- 7 DKD calibration mark
- 8 Connector socket for ground / connected to ground
- 9 Connector socket for current measurement with automatic blocking
- 10 Connector socket for voltage, resistance, temperature, diode and capacitance measurement with automatic blocking
- 11 **DATA / MIN / MAX**
  - Key for freezing, comparing, deleting the measured value, and for Min/Max function
  - ▽ Decrease values
  - “Operating Mode” menu:* Select individual menu entries in flow direction
- 12 **MEASURE | SETUP** Key for switching between measuring and menu functions
- 13 **ZERO | ESC**
  - Key for zero balancing
  - “Operating Mode” menu:* Exit menu level and return to a higher level, exit parameters entry function without saving
- 14 ◁ Decrease measuring range or move decimal point to the left (MAN function)
- 15 Power pack connector jack
- 16 Infrared interface


## Symbols used in the Digital Display



### Battery level indicator



### Interface indicator



- 1 Battery level indicator
- 2 ON: continuous operation (automatic shutdown deactivated)
- 3 MAN: manual measuring range selection active
- 4 Digital display with decimal point and polarity display
- 5 max/min: Min/Max value storage
- 6 DATA: display memory, "freeze measured value"
- 7 STORE: memory mode active
- 8 ISO: insulation resistance measurement active / selected test voltage
- 9 1: x current clip factor (transformation ratio)
- 10 IR: infrared interface display
- 11 Scale for analog display
- 12 Pointer for analog display (bar graph – pointer)  
*triangle appears:* indicates overranging
- 13 Diode measurement selected
- 14 Selected type of current
- 15 TRMS measurement
- 16 Pt100(0): selected platinum resistance thermometer with automatic recognition of Pt100/Pt1000
- 17 Type K: temperature measurement with type K (NiCr-Ni) thermocouple
- 18 sec (seconds): unit of time
- 19 ΔREL: relative measurement with reference to offset
- 20 Unit of measure
- 21 ZERO: zero balancing active
- 22 Keying Ratio Measurement  
(this function only available with customer-specific variant)
- 23 **Warning regarding dangerous voltage:  $U > 15 \text{ V AC}$  or  $U > 25 \text{ V DC}$**
- 24 Continuity test with acoustic signal active
- 25 h (hours): unit of time

## Operating Overview – Connections, Keys, Rotary Switch, Symbols


### Symbols used for Rotary Switch positions

Switch	FUNC	Display	Measuring Function	Additional Function clip-on (by menu SET ⇒ CLIP 1:1/10/100/1000)
	0/2	V DC AC TRMS	Pulsating voltage, TRMS DC + AC, 15 Hz ... 500 Hz <i>only for detection of interference voltage!</i>	
	1	UI SO Ω/MΩ	Insulation resistance measurement	
	0/5	V~ AC TRMS	Alternating voltage, AC TRMS, full bandwidth	Clip-on AC (V): clip-on current sensor
	1	Hz ~ AC	Voltage frequency, full bandwidth	Clip-on Hz (V): clip-on current sensor
	2	%	Keying Ratio Measurement (customer-specific variant)	
	3	V Fil ~ AC TRMS	Voltage frequency, with low pass filter (1 kHz)	
	4	Hz Fil ~ AC	Voltage frequency, with low pass filter (1 kHz)	
	0/2	V--- DC	Direct voltage	Clip-on DC (V): clip-on current sensor
	1	V with AC and DC lines DC AC TRMS	Pulsating voltage, TRMS ( $V_{ACDC} = \sqrt{V_{AC}^2 + V_{DC}^2}$ )	Clip-on DC + AC (V): clip-on current sensor
	0	Ω	(DC) resistance	
	0/2	Ω	Continuity test with acoustic signal	
	1	V--- DC	Diode voltage where I is constant	
	0	°C Pt 100/1000	Temperature with Pt 100 / Pt 1000 resistance thermometer	
	1	°C Typ-K	Temperature with thermoelement type K	
	0	nF, μF	Capacitance	
	0/2	A--- DC	Direct current value	
	1	A with AC and DC lines DC AC TRMS	Pulsating current amperage, AC DC TRMS	
	0/2	A~ AC TRMS	Alternating current amperage, AC TRMS	Clip-on AC (A): clip-on current transformer
	1	Hz ~ AC	Current frequency	Clip-on Hz (A): clip-on current transformer

## User Interface Symbols in the Following Chapters


- ▷ ... ▷ Scroll through main menu
- ▽ ... ▽ S scroll through submenu
- ◁ ▷ Select decimal point
- △ ▽ Increase/decrease value
- b PE* Submenu/parameter (7-segment font)
- Info** Main menu (7-segment font, boldface)

## Symbols on the Device

 Warning concerning a point of danger (attention: observe documentation!)

 Ground

**CAT II / III** Measuring category II or III device, see also “Measuring Categories and their Significance per IEC 61010-1” on page 8.


 Continuous, doubled or reinforced insulation

**CE** Indicates EC conformity

**▲ IR ▼** Position of the infrared interface, window on the top of the instrument




Position of the power pack adapter socket, see also chapter 3.1.

 Fuse for current measuring ranges (see chapter 9.3)



The device may not be disposed of with the trash. Further information regarding the WEEE mark can be accessed on the Internet at [www.gossenmetrawatt.com](http://www.gossenmetrawatt.com) under the search term WEEE (see also chapter 9.5).

Calibration seal (red seal):



See also “Recalibration Service” on page 64.

### 3 Initial Start-Up

#### 3.1 Batteries

*Be certain to refer to chapter 9.2 regarding correct battery installation!*

Momentary battery voltage can be queried in the “Info” menu (see chapter 6.3).



#### **Attention!**

Disconnect the instrument from the measuring circuit before opening the battery compartment lid in order to replace the batteries.

---

#### **Operation with Power Pack (not included, see chapter 10.3)**

Installed batteries are disconnected electronically if the NA | X-TRA power pack is used, and need not be removed from the instrument. If rechargeable batteries are used, they must be recharged externally.

If the external power supply is switched off, the device is switched to battery operation without interruption.

#### 3.2 Activation

##### **Switching the Instrument On Manually**

- Press the **ON / OFF | LIGHT** key until the display appears. Power-up is acknowledged with a brief acoustic signal. As long as the key is held depressed, all of the segments at the liquid crystal display (LCD) are illuminated. The LCD is depicted on page 13. The instrument is ready for use as soon as the key is released.

##### **Display Illumination**

After the instrument has been switched on, background illumination can be activated by briefly pressing the **ON / OFF | LIGHT** key. Illumination is switched back off by once again pressing the same key, or automatically after approximately 1 minute.

##### **Switching the Instrument On with a PC**

The multimeter is switched on after transmission of a data block from the PC, assuming the “i\_r5tB” parameter has been set to “i\_r on” (see chapter 6.4).

However, we recommend using the power saving mode: “i\_r off”.

---



#### **Note**

Electrical discharge and high frequency interference may cause incorrect displays to appear, and may disable the measuring sequence.

**Disconnect the device from the measuring circuit.** Switch the instrument off and back on again in order to reset. If the problem persists, briefly dislodge the battery from the connector contacts (see also chapter 9.2).

---

#### 3.3 Setting the Operating Parameters

##### **Setting Time and Date**

See “t\_r NE” and “d\_r EE” parameters in chapter 6.4.

##### **Display Modes for the Digital Display**

Selection can be made from two different display modes (see “D\_d r SP” parameter in chapter 6.4).



### 3.4 Switching the Instrument Off

#### Switching the Instrument Off Manually

- ⇨ Press the **ON / OFF | LIGHT** key until **OFF** appears at the display. Shutdown is acknowledged with a brief acoustic signal.

#### Automatic Shutdown

The instrument is switched off automatically if the measured value remains unchanged for a long period of time (maximum measured value fluctuation of approximately 0.8% of the measuring range per minute or 1° C or 1° F per minute), and if none of the keys or the rotary switch have been activated before a selected period of time in minutes has elapsed (see “*RP<sub>OFF</sub>*” parameter on page 49). Shutdown is acknowledged with a brief acoustic signal. Exceptions include:

Transmission and memory mode operation, continuous operation and whenever a dangerous voltage is applied to the input ( $U > 15 \text{ V AC}$  or  $U > 25 \text{ V DC}$ ).

#### Disabling Automatic Shutdown


The instrument can be set to continuous operation.

- ⇨ Simultaneously press the

**ON / OFF | LIGHT** and **FUNC | ENTER** keys to this end.

The “Continuous On” function is indicated at by means of the **ON** display to the right of the battery symbol.

**The “Continuous On” setting can be cancelled by changing the respective parameter or by switching the instrument off manually. In this case the parameter will be reset to 10 min (see “*RP<sub>OFF</sub>*” on page 52).**



## 4 Control Functions

### 4.1 Selecting Measuring Functions and Measuring Ranges

#### 4.1.1 Automatic Range Selection

The multimeter is equipped with auto-ranging for all measuring functions, except for temperature measurement, and diode and continuity testing. Auto-ranging is active as soon as the instrument is switched on. The instrument automatically selects the measuring range which allows for highest possible resolution of the applied quantity. When the instrument is switched to frequency measurement, the previously selected voltage measuring range remains active.

#### AUTO-Range Function

The multimeter is switched automatically to the next higher range at  $\pm(3099 \text{ d} + 1 \text{ d} \rightarrow 03 \text{ 10 d})$ , and to the next lower range at  $\pm(280 \text{ d} - 1 \text{ d} \rightarrow 2799 \text{ d})$ .

With high resolution the multimeter is switched automatically to the next higher range at  $\pm(30999 \text{ d} + 1 \text{ d} \rightarrow 03 \text{ 100 d})$ , and to the next lower range at  $\pm(2800 \text{ d} - 1 \text{ d} \rightarrow 27999 \text{ d})$ .

#### 4.1.2 Manual Measuring Range Selection

Auto-ranging can be deactivated and measuring ranges can be selected manually in accordance with the following table by pressing the **MAN / AUTO** button.

The desired measuring range can then be selected with the  $\triangleleft$  or  $\triangleright$  key.

The instrument is automatically returned to range selection when the **MAN / AUTO** key is pressed, the rotary switch is activated or the instrument is switched off and back on again.

### Overview: Auto-Ranging and Manual Range Selection

	Function	Display
<b>MAN / AUTO</b>	Manual mode active: utilized measuring range is fixed	MAN
$\triangleleft$ or $\triangleright$	Range switching sequence for: <b>V:</b> 300 mV* $\leftrightarrow$ 3 V $\leftrightarrow$ 30 V $\leftrightarrow$ 300 V $\leftrightarrow$ 1000 V <b>Hz:</b> 300 Hz $\leftrightarrow$ 3 kHz $\leftrightarrow$ 30 kHz $\leftrightarrow$ 300 kHz (Hz(U)) <b><math>\Omega</math>:</b> 300 $\Omega$ $\leftrightarrow$ 3 k $\Omega$ $\leftrightarrow$ 30 k $\Omega$ $\leftrightarrow$ 300 k $\Omega$ $\leftrightarrow$ 3 M $\Omega$ $\leftrightarrow$ 30 M $\Omega$ <b>A:</b> 300 $\mu$ A $\leftrightarrow$ 3 mA $\leftrightarrow$ 30 mA $\leftrightarrow$ 300 mA $\leftrightarrow$ 3 A $\leftrightarrow$ 10 A <b>A <math>\chi</math>:</b> See chapter 5.8.3 und chapter 5.8.4 <b>F:</b> 30 nF $\leftrightarrow$ 300 nF $\leftrightarrow$ 3 $\mu$ F $\leftrightarrow$ 30 $\mu$ F $\leftrightarrow$ 300 $\mu$ F <b>M<math>\Omega</math>@ISO:</b> 300 k $\Omega$ $\leftrightarrow$ 3 M $\Omega$ $\leftrightarrow$ 30 M $\Omega$ $\leftrightarrow$ 300 M $\Omega$ $\leftrightarrow$ 3000 M $\Omega$	MAN
<b>MAN / AUTO</b>	Return to automatic measuring range selection	—

\* Via manual measuring range selection only

The multimeter is held in the selected measuring range. If the range limit is exceeded, **OL** appears at the display. You should then switch to the next higher measuring range with the help of the  $\triangleright$  key.

### 4.1.3 Quick Measurements

Measurements performed using a suitable fixed measuring range are executed more quickly than those which utilize automatic range selection. Quick measurement is made possible with the following two functions:

- **Manual measuring range selection**, i.e. selection of the measuring range with the best resolution (see chapter 4.1.2)

or

- With the **DATA function** (see chapter 4.4). In this way, the appropriate measuring range is selected automatically after the first measurement and the second measurement is executed more quickly.

The selected measuring range remains active for the subsequent series of measurements with these two functions.

## 4.2 Zero Offset / Relative Measurements

Zero balancing or a reference value for relative measurements can be stored to memory depending upon deviation from the zero point:

Deviation from zero – with short-circuited measurement cables for V, $\Omega$ , A – with open input for capacitance unit of measure: F	Display
0 to 200 digits	ZERO $\Delta$ REL
> 200 to 1500 digits	$\Delta$ REL

The relevant reference or correction value is deducted individually for the respective measuring function as an offset from all future measurements and remains in memory until deleted, or until the multimeter is switched off.

Zero balancing and reference value adjustment can be used for auto-ranging, as well as for manual measuring range selection.

### Zero Balancing

- ⇨ Plug the measuring cables into the instrument and connect the free ends to each other, except for capacitance measurement in which case the ends of the cables are not connected to each other.
- ⇨ Briefly press the **ZERO | ESC** key.  
The instrument acknowledges zero balancing with an acoustic signal, and the “ZERO  $\Delta$ REL” symbol appears at the LCD. The value measured at the moment the key is pressed serves as a reference value.
- ⇨ Zero balancing can be cleared by once again pressing the **ZERO | ESC** key.

### Note

As a result of TRMS measurement, the multimeter displays a residual value of 1 to 10/35 digits with short-circuited measurement cables as the zero point for V AC / I AC or V(AC+DC) / I (AC+DC) measurements (non-linearity of the TRMS converter). This has no influence on specified accuracy above 1% of the measuring range (or 3% in the mV, V(AC+DC) ranges).

### Setting the Reference Value

- ⇨ Plug the measuring cables into the instrument and measure a reference value (max. 1500 digits).

## Control Functions

---

- ⇨ Briefly press the **ZERO | ESC** key.  
The instrument acknowledges storage of the reference value with an acoustic signal, and the “ZERO  $\Delta$ REL” or the “ $\Delta$ REL” symbol appears at the LCD. The value measured at the moment the key is pressed serves as a reference value.
- ⇨ The reference value can be cleared by once again pressing the **ZERO | ESC** key.

of voltage measurement in the 1000 V range, as of 5.100 V for diode testing, and as of 11.00 A in the 10 A range.

### Notes Regarding Relative Measurement

- Relative measurement effects the digital display only. The analog display continues to read out the original measured value.
- In the case of relative measurement,  $\Omega$  F or AC quantities may also appear as negative values.

## 4.3 Display (LCD)

### 4.3.1 Digital Display

#### Measured Value, Unit of Measure, Type of Current, Polarity

The measured value with decimal and plus or minus sign appears at the digital display. The selected unit of measure and current type are displayed as well. A minus sign appears to the left of the value during the measurement of zero-frequency quantities, if the plus pole of the measured quantity is applied to the “ $\perp$ ” input. The “ $\overline{0}$ ,  $d$ ,  $SP$ ” parameter can be used to determine whether leading zeros will be appear or be suppressed at the measured value display (see chapter 6.4).

#### Overranging

If the upper range limit of 3100 digits is exceeded “ $\overline{0}L$ ” (overload) appears at the display.  
Exceptions: “ $\overline{0}L$ ” appears at the display as of 1000.0 V in the case

---

### 4.3.2 Analog Display

#### Measured Value, Polarity

The analog display demonstrates the dynamic performance of a moving-coil mechanism. This display is especially advantageous for observing measured value fluctuation, and for balancing procedures.

Display mode Pointer: the current measured value is tracked in real-time.

The analog scale displays a negative range of 5 scale divisions for the measurement of zero-frequency quantities, allowing for precise observation of measured value fluctuation around zero. If the measured value exceeds the negative range of 5 scale divisions, polarity is reversed at the analog display.

Scaling of the analog scale is automatic. This is very helpful for manual measuring range selection.

#### Overranging

Overranging in the positive range is displayed by means of the right triangle symbol.

#### Refresh Rate

In the bar graph and pointer modes, the analog display is refreshed 40 times per second.

### 4.4 Measured Value Storage: DATA (auto-hold / compare)

An individual measured value can be automatically “frozen” with the DATA function (auto-hold). This is useful, for example, when contacting the measuring points with the test probes requires your full attention. After the measuring signal has been applied and the measured value has settled in accordance with the “condition” listed in the table below, the measured value is frozen at the digital display and an acoustic signal is generated. The test probes can now be removed from the measuring points, and the measured value can be read from the digital display. If the measuring signal falls below the value specified in the table, the function is reactivated for storage of the next value.


#### Measured Value Comparison (DATA Compare)



If the currently frozen value deviates from the first saved value by less than 100 digits, the acoustic signal is generated twice. If deviation is greater than 100 digits, only one brief acoustic signal is generated.

#### Note

The DATA function has no effect on the analog display, at which the current measured value continues to appear. However, when the digital display is “frozen”, the decimal point is fixed as well (fixed measuring range, symbol: MAN). The selected measuring range should not be manually changed as long as the DATA function is active.

The DATA function is deactivated by pressing and holding the **DATA/MIN/MAX** key (approx. 1 second), when the measuring function is changed or when the instrument is switched off and back on again.



DATA Function	Press DATA / Min/Max	Condition		Response from Instrument		
		Measuring Function	Measuring Signal	MV Digital	DATA	Acoustic
Activate	Brief				Blinks	Once
Save (stabilized measured value)		V, A, F, Hz, %	> 10% of R	Is displayed	Static	Once Twice <sup>2)</sup>
		$\Omega$ 	$\neq OL$			
Reactivate <sup>1)</sup>		V, A, F, Hz, %	< 10% of R	Stored MV	Blinks	
		$\Omega$ 	$= OL$			
Change to Min/Max	brief	See table in chapter 4.4.1				
Exit	long			Is cleared	Is cleared	Twice

<sup>1)</sup> Reactivation results from falling short of specified measured value limits.

<sup>2)</sup> Two acoustic signals are generated the first time a measured value is saved as a reference value. For subsequent data hold, two acoustic signals are only generated if the currently frozen value deviates from the **first** saved value by less than 100 digits.

Key: MV = measured value, R = measuring range

### Example

The voltage measuring range is set manually to 30 V. The first measured value is 5 V and is stored to memory because it is greater than 10% of the measuring range (= 3 V), and is thus reliable above the background noise level. As soon as the measured values drops to less than 10% of the measuring range, i.e. amounts to less than 3 V which corresponds to removal of the test probes from the measuring point, the instrument is ready to store a new value.

#### 4.4.1 Saving Minimum and Maximum Values – MIN/MAX Function

Minimum and maximum measured values applied to the measuring instrument's input after the Min/Max function has been activated can be "frozen" at the display. The most important use of this function is the determination of minimum and maximum values during long-term measured value observation.

The Min/Max function can be activated in all measuring functions. The Min/Max function has no effect on the analog display, at which the current measured value continues to appear.

Apply the measured quantity to the instrument and set the measuring range with the **MAN / AUTO** key before activating the Min/Max function.

The Min/Max function is deactivated by pressing and holding the **DATA/MIN/MAX** key (approx. 1 second), when the measuring function is changed or when the instrument is switched off and back on again.



#### Note

As opposed to the DATA function, the Min/Max function can also be used for temperature measurement.

Function Min/Max	Press DATA / Min/Max	Min. and Max. Measured Values	Response from Instrument		
			Display Measured Value Digital	Max. Min.	Acoustic Signal
1 Activate and save	2 x brief	Are saved	Current measured value	Max and min	Twice
2 Save and display	Brief	Storage continues in background, new min. and max. values are displayed.	Saved min. value	Min.	Once
	Brief		Saved max. value	Max.	Once
3 Return to 1	Brief	Same as 1, stored values are not deleted	Same as 1	Same as 1	Once
Stop	Long	Are deleted	Current measured value	Is deleted	Twice

### 4.5 Measurement Data Recording

The multimeter is capable of recording measurement data using an adjustable sampling rate for long periods of time in the form of measurement series. Data are stored to a battery-backed memory module, and are retained even after the multimeter is switched off. The system acquires measured values relative to real-time.

Stored measured values can subsequently be read out with the help of **METRAWIN 10** software. The only prerequisite is a PC which is connected by means of an interface cable to the USB | **X-TRA** bidirectional interface adapter, which is plugged onto a multimeter. See also chapter 7, "Interface Operation".

#### Memory Parameters Overview

Parameter	Page: Header
<i>CLEAR</i>	25: Clear Memory
<i>EMPTY</i>	25: Clear Memory – appears after <i>CLEAR</i>
<i>OCCUP</i>	25: Querying Memory Occupancy
<i>rATE</i>	51: rATE – set the sampling rate
<i>StARt</i>	24: Starting Recording via Menu Functions
<i>StoP</i>	25: Ending Recording

#### The STORE Menu Function

- First set the **sampling rate** for memory mode operation (see chapter 6.4 the *rATE* parameter), and then start memory mode operation.
- First select the desired measuring function and an appropriate measuring range.
- Check the battery charge level before starting long-term measurement recordings (see chapter 6.3). Connect the NA | **X-TRA** power pack if required.

#### Starting Recording via Menu Functions

- Switch to the "**StoP**" mode by pressing **MEASURE | SETUP**, and select the "**StoP**" menu.



- Memory mode operation is started by activating **FUNC | ENTER**. **STORE** appears underneath the analog display and indicates that the memory mode has been activated. "**StoP**" appears at the digital display.
- Press **MEASURE | SETUP** in order to return to the measuring function.



### During Recording

**STORE** is displayed underneath the analog display during memory mode operation, and **memory occupancy** can be monitored:

StoP ▷ 000.3%

The following message appears as soon as memory is full: "100.0%".

In order to be able to **observe measured values during recording**, switch to the measuring function by pressing **MEASURE | SETUP**. The display is returned to the memory menu after once again pressing **MEASURE | SETUP**.

A new memory block is created when another measuring function is selected with the rotary switch or the **FUNC | ENTER** key. Data storage then continues automatically.

### Ending Recording

▷ "StoP" appears at the display after pressing **MEASURE | SETUP**.

StoP  Start

- ▷ Acknowledge the "StoP" display by pressing **FUNC | ENTER**. **STORE** is cleared from the display indicating that recording has been ended.
- ▷ Press **MEASURE | SETUP** in order to return to the measuring function.
- ▷ Memory mode operation can also be exited by switching the multimeter off.

### Querying Memory Occupancy

Memory occupancy can be queried during recording with the help of the "**Info**" menu (see also chapter 6.3).

Memory occupancy range: 000.1% to 099.9%.

 Info  Batt: ▽ ... ▽ OCCUP %: 0 17.4 %

Memory occupancy can be queried before recording is started via the "**StoE**" menu.

 Info ▷ ... ▷ StoE  0 17.4 % ▷ Start

### Clear Memory

This function deletes all measured values from memory!

This function cannot be executed during memory mode operation.

 Info ▷ ... ▷ StoE  0 17.4 % ▷ Start

▷ CLEAR  EMPTY

## 5 Measurements

### 5.1 Voltage Measurement

#### Notes Regarding Voltage Measurement

- The multimeter may only be operated with installed batteries. Dangerous voltages are otherwise not indicated, and the instrument may be damaged.
- The multimeter may only be operated by persons who are capable of recognizing **contact hazards** and taking the appropriate safety precautions. Contact hazards exist anywhere, where voltages of greater than 33 V RMS may occur. The test probes may only be only gripped up to the finger guard. Do not touch the metallic test probes under any circumstances.
- Avoid working alone when taking measurements which involve **contact hazards**. Be certain that a second person is present.
- **Maximum allowable voltage** between terminals 9 or 10 and ground (8) is 1000 V for measuring category II, and 600 V for measuring category III.
- Be prepared for the occurrence of unexpected voltages at devices under test (e.g. defective devices). For example, capacitors may be dangerously charged.
- No measurements may be made with this instrument in electrical circuits with corona discharge (high-voltage).
- Special care is required when measurements are made in HF electrical circuits. Dangerous pulsating voltages may be present.

- Be aware of the fact that dangerous voltage spikes are not displayed during measurement with the low-pass filter. We recommend measuring voltage without the low-pass filter first, in order to be able to detect any dangerous voltages.
- Be absolutely certain that the measuring ranges are not overloaded beyond their allowable capacities. Limit values are included in chapter 8, "Technical Data", in the table entitled "Measuring Functions and Measuring Ranges" in the "Overload Capacity" column.

---

#### Note

Rotary selector switch position "**V 1M $\Omega$  / M $\Omega_{\text{@UISO}}$** " is available for the detection of interference voltage during insulation resistance measurement. Use switch position  $\text{V}\sim$ ,  $\text{V}\equiv$  or  $\text{V}\approx$  in order to perform precise voltage measurements.

---

### 5.1.1 Direct and Pulsating Voltage Measurement, V DC and V (DC+AC)

- Set the  $\text{CL}, P$  parameter to **OFF** in the current clip setup menu. Otherwise all measured values are displayed in amperes, corrected by the amount resulting from the selected transformation ratio for an interconnected clip-on current sensor.



- In accordance with the voltage to be measured, turn the rotary switch to  $V_{\text{DC}}$  or  $V_{\text{AC}}$ .
- Connect the measurement cables as shown. The “ $\perp$ ” connector jack should be grounded.

#### Note

An intermittent acoustic signal warns the operator if the measured value exceeds the upper range limit in the 1000 V range.

Make sure that a current measuring range (“A”) has **not** been activated when the multimeter is connected for voltage measurement! If the fuse’s blowing limits are exceeded as a result of operator error, both the operator and the instrument are in danger!

With the rotary switch in the V position, the multimeter is always in the 1 V measuring range immediately after it is switched on. As soon as the **MAN / AUTO** key is pressed, and assuming the measured value is less than 280 mV, the multimeter is switched to the mV measuring range.

**MEASURE SETUP** ...  $\triangleright$  **SET**    **FUNC ENTER** ...  $\nabla$   $\text{CL}, P$     **FUNC ENTER**  $\triangle \nabla$  **OFF**

$V_{\text{DC}}$     **20.00**  $V_{\text{DC}}$      $V_{\text{DC}}$

**FUNC ENTER**

$V_{\text{AC}}$     **20.00**  $V_{\text{AC TRMS}}$      $V_{\text{AC}}$

**MEASURE SETUP**     $V_{\Omega}$   $\text{M}\Omega_{\text{UI50}}$      $\perp$  | **COM** **mA/A**    **Temp**  $\rightarrow$   $\rightarrow$

$\downarrow$      $\downarrow$      $\downarrow$

$- (+)$

$+ (-)$

**Measuring Ranges:**  
 $V_{\text{DC}}$ : 100  $\mu\text{V}$ ...1000 V  
 $V_{\text{AC}}$ : 10 mV...1000 V  
 5 ranges: 300 mV, 3 V, 30 V, 300 V and 1000 V

**Max. 1000 V, 3 kHz**  
 Hz: 1 Hz ... 300 kHz  
 $P_{\text{max}} = 3 \times 10^6 \text{ V} \times \text{Hz}$

**Warnings regarding dangerous voltage:**  
 $> 15 \text{ V AC}$  or  $> 25 \text{ V DC}$ : **2300**  
 $> 1000 \text{ V}$ :

### 5.1.2 Alternating Voltage and Frequency Measurement V AC and Hz with Selectable Low-Pass Filter

- Set the  $\text{CLP}$  parameter to **OFF** in the current clip setup menu. Otherwise all measured values are displayed in amperes, corrected by the amount resulting from the selected transformation ratio for an interconnected clip-on current sensor.



- In accordance with the voltage or frequency to be measured, turn the rotary switch to V~ or Hz/%.
- Connect the measurement cables as shown. The “ $\perp$ ” connector jack should be grounded.

#### Voltage Measurement



#### Note

An intermittent acoustic signal warns the operator if the measured value exceeds the upper range limit in the 1000 V range.

- Make sure that a current measuring range (“A”) has not been activated, when the multimeter is connected for voltage measurement! If the fuse’s blowing limits are exceeded as a result of operator error, both the operator and the instrument are in danger!
- You can switch back and forth between voltage measurement with and without low-pass filter.
  - Repeatedly press the **FUNC | ENTER** multifunction key, until the V or V/Fil unit of measure appears at the display.

#### Frequency Measurement

- Connect the measured quantity in the same way as for voltage measurement.
- Manually select the measuring range for the voltage amplitude. When the instrument is switched to frequency measurement, the previously selected voltage measuring range remains active.
- You can switch back and forth between frequency measurement with and without low-pass filter. Repeatedly press the **FUNC | ENTER** multifunction key, until the Hz or Hz/Fil unit of measure appears at the display. Lowest measurable frequencies and maximum allowable voltages are included in chapter 8, “Technical Data”.

#### Measurement with Low-Pass Filter




#### Attention!

Be aware of the fact that dangerous voltage spikes are not displayed during this type of measurement (see also “Voltage Comparator”). We recommend measuring voltage without the low-pass filter first, in order to be able to detect any dangerous voltages.

- A 1 kHz/-3 dB low-pass filter can be activated if required, in order to filter out capacitively induced high frequency pulses of greater than 1 kHz, for example when performing measurements at cables, i.e. undesired voltages of greater than 1 kHz can be suppressed.
- “Fil” appears at the display in order to indicate the respectively activated low-pass filter. The multimeter is automatically switched to manual measuring range selection.



Specified measuring accuracy is not reached with signals of greater than 500 Hz when the filter is active.




**Measuring Ranges:**  
 V~: 10 mV ... 1000 V  
 5 ranges: 300 mV, 3 V, 30 V, 300 V and 1000 V


**Max. 1000 V, 3 kHz**  
 Hz: 1 Hz ... 300 kHz  
 $P_{max} = 3 \times 10^6 \text{ V} \times \text{Hz}$

**Warnings regarding dangerous voltage:**

- > 15 V AC or > 25 V DC: 
- > 1000 V: 

### Voltage Comparator for Displaying Dangerous Voltage

The input signal or measuring signal is checked by a voltage comparator for dangerous spikes, because these do not appear at the display when the low-pass filter is used. At voltages of greater than 15 V AC or 25 V DC, a danger symbol appears at the display: .



**MEASURE SETUP** ...  $\triangleright$  *SET*    **FUNC ENTER** ...  $\nabla$  *CL, P*    **FUNC ENTER**  $\triangle\triangle$  *OFF*

**V~**    **Hz %**

230.6  $\sim$  AC TRMS V

**FUNC ENTER**  $\Downarrow$

The following function is only available with customer-specific variants.


Hz: *UPN = OFF*  
 RPM: *UPN  $\neq$  OFF*

**Hz / %**

050.3  $\sim$  AC Hz

**FUNC ENTER**  $\Downarrow$


**V~ with Filter**



229.9  $\sim$  AC TRMS V Fil  $\frac{1}{1 \text{ kHz}}$

**FUNC ENTER**  $\Downarrow$

**Hz with Filter**



050.0  $\sim$  AC Hz Fil  $\frac{1}{1 \text{ kHz}}$

**FUNC ENTER**  $\Downarrow$


**Keying Ratio Measurement**  
(this function only available with customer-specific variant)


- ⇨ Set the rotary switch to V~.
- ⇨ Repeatedly press the **FUNC | ENTER** multifunction key until % appears at the display.
- ⇨ Connect the measurement cables as shown.

Make sure that a current measuring range (“A”) has not been activated, when the multimeter is connected for frequency or keying ratio measurement!

The ratio of pulse duration to pulse period is measured with periodic square-wave signals and displayed as a percentage.

$$\text{Keying ratio (\%)} = \frac{\text{Pulse duration (}t_E\text{)}}{\text{Pulse period (}t_p\text{)}} \cdot 100$$

 **Note**  
The applied frequency must remain constant during keying ratio measurement.



**Pulse Time Quantities**

- $f_p$  pulse frequency =  $1/t_p$
- $t_E$  pulse duration
- $t_p$  pulse period
- $t_p - t_E$  interpulse period
- $t_E/t_p$  pulse or keying ratio

**Measuring Ranges:**

Hz	$t_E/t_p$
15 Hz ... 1 kHz	5 ... 95%
1 kHz ... 4 kHz	10 ... 90%

### RPM Measurement (function only available with customer-specific variant)

Revolutions per minute (also known as rotational frequency) are measured by acquiring pulses. As a prerequisite for this measurement, the number of measurable pulses per revolution must first be set in the RPM setup menu ( $UPN \neq OFF$ , see below).


- ↪ Set the rotary switch to V~.
- ↪ Repeatedly press the **FUNC | ENTER** multifunction key until RPM is briefly displayed. The measured value then appears in RPM, for example “244.3 r”.

$$RPM = \left( \frac{\text{Revolutions}}{\text{min}} / \frac{\text{Pulses}}{\text{Revolution}} \right) \times \frac{60s}{s}$$

Measured value RPM = revolutions per minute.

Parameter  $UPN$  = pulses per revolution.

### Pulses per Revolution Setup Menu




### 5.1.3 Transient Overvoltages

The multimeters are protected against transient overvoltages of up to 6 kV with wave-front durations of 1.2 ms and halftimes of 50  $\mu$ s in the voltage measuring range. If longer pulse durations are expected, e.g. when conducting measurements at transformers or motors, use of our KS30 measuring adapter is recommended. It provides protection against transient overvoltages of up to 6 kV with wave-front durations of 10, and halftimes of 1000  $\mu$ s. Continuous load capacity is 1200V<sub>RMS</sub>. Additional influence error caused by the KS30 measuring adapter amounts to approximately -2%.

### 5.1.4 Voltage Measurements at Above 1000 V

Voltages of greater than 1000 V can be measured with a high-voltage probe, e.g. the HV3<sup>1</sup> or the HV30<sup>2</sup> from GMC-I Messtechnik GmbH. It is absolutely essential to earth the ground terminal in this case. Observe all applicable safety precautions!



<sup>1</sup> HV3: 3 kV  
<sup>2</sup> HV30: 30 kV, for  $\equiv$  (DC) voltages only

## 5.2 Resistance Measurement, $\Omega$


- ⇨ Disconnect supply power from the electrical circuit of the device to be measured, and discharge all high-voltage capacitors.
- ⇨ Make sure that the device under test is voltage-free. Interference voltages distort measurement results! Refer to section 5.1.1 regarding testing for the absence of voltage with the help of the direct voltage measurement.
- ⇨ Set the rotary switch to “ $\Omega$ ”.
- ⇨ Connect the device under test as shown.

### Note

Use short or shielded measurement cables in the case of high-impedance resistance.

### Improving Accuracy by means of Zero Balancing

Cable resistance and contact resistance can be eliminated in all measuring ranges by means of zero balancing (see section 4.2).






### 5.3 Temperature Measurement: Temp RTD and Temp TC

Temperature measurement is performed with a Pt100 or Pt1000 resistance thermometer, or a type K thermocouple (accessory, not included), which is connected to the voltage input.

#### Selecting the Unit of Measure for Temperature



( $^{\circ}\text{C}$  = default setting)

#### 5.3.1 Measurement with Resistance Thermometers

⇒ Set the rotary switch to “Temp<sub>RTD</sub>”.

Press the **FUNC | ENTER** key in order to change to the other measuring function if required.

The sensor type, i.e. Pt100 or Pt1000, is detected automatically and displayed.

There are two different ways to compensate for cable resistance:

#### Automatic Compensation

⇒ Acknowledge by pressing the **ZERO | ESC** key.  
“Short leads” appears at the display.

If you prefer to enter cable resistance directly, you can skip the following entry prompt.


⇒ Short circuit the measuring instrument’s connector cables.  
“000.0” appears at the display. After pressing the **FUNC | ENTER** key, automatic compensation of cable resistance is activated for all subsequent measurements. The short-circuit can now be eliminated, and the device is ready for use.

#### Enter Cable Resistance

⇒ Press the **ZERO | ESC** key once again in the automatic compensation menu.

⇒ Enter the known resistance of the connector cables with the scroll keys:  
Select the digit to be changed with the  $\blacktriangleleft \blacktriangleright$  keys, and change the respectively selected digit with the  $\nabla \Delta$  keys. The default value is 0.43  $\Omega$ . Values can be selected within a range of 0 to 50  $\Omega$ .

⇒ Upon pressing the **FUNC | ENTER** key, the selected value is activated and the display is returned to the measuring function. Cable resistance remains in memory even after the instrument has been switched off.



### 5.3.2 Measurement with Thermocouples, Temp TC

- Set the rotary switch to "Temp<sub>RTD</sub>".

**Note**


The last selected temperature measurement or the last selected temperature sensor, i.e. type K or Pt100/Pt1000, remains in memory and is accordingly displayed. Press the **FUNC | ENTER** key in order to change to the other measuring function if required.

- The reference temperature is measured at the internal reference junction (see parameter "REFTEMP" in Seite 50 regarding querying).

**Note**

The internal reference temperature (temperature of the internal reference junction) is measured by a temperature sensor inside of the instrument. This may be somewhat above room temperature as a result of internal heat-up, or moving from warmer to colder surroundings or vice versa.


- Connect the sensor to the two accessible jacks. The instrument displays the measured temperature using the selected unit of measure.




### 5.4 Continuity Test $\square$ )

- ⇨ Disconnect supply power from the electrical circuit of the device to be measured, and discharge all high-voltage capacitors.
- ⇨ Make sure that the device under test is voltage-free. Interference voltages distort measurement results!
- ⇨ Set the rotary switch to " $\square$ )".
- ⇨ A loudspeaker symbol appears at the display.
- ⇨ Connect the conductor path under test as shown.

Depending upon the selected limit value, the multimeter generates a continuous acoustic signal in the case of continuity or short-circuiting, i.e. at a value of less than the selected limit value. " $\square$ " appears at the display in the case of an open connection. The limit value can be adjusted in the "**SET**" menu (see also section 6.4):



(10 = default setting)



### 5.5 Diode Testing $\rightarrow$ with Constant Current of 1 mA

- Disconnect supply power from the electrical circuit of the device to be measured, and discharge all high-voltage capacitors.
- Make sure that the device under test is voltage-free. Interference voltages distort measurement results! Refer to section 5.1.1 regarding testing for the absence of voltage with the help of the direct voltage measurement.
- Set the rotary switch to " $\square$ ".
- Press the **FUNC | ENTER** key and the diode symbol appears at the display.
- Connect the device under test as shown.

#### Conducting Direction and Short-Circuit


The instrument displays forward voltage in volts (display: 4 places). As long as voltage drop does not exceed the maximum display value of 5.1 V, several series connected components or reference diodes with small reference voltages, as well as Z-diodes and LEDs, can be tested.

#### Reverse Direction and Interruption

The measuring instrument indicates overload **OL**


#### Note


Resistors and semiconductor paths connected in parallel to the diode distort measurement results!



### 5.6 Capacitance Measurement $\text{--}$

- ⇨ Disconnect supply power from the electrical circuit of the device to be measured, and discharge all high-voltage capacitors.
- ⇨ Make sure that the device under test is voltage-free.  
Capacitors must always be discharged before measurement is performed.  
Interference voltages distort measurement results!  
Refer to section 5.1.1 regarding testing for the absence of voltage with the help of the direct voltage measurement.
- ⇨ Set the rotary switch to to “ $\text{--}$ ”.
- ⇨ Connect the (discharged!) device under test to the sockets with the measurement cables as shown.

 **Note**  
The “ $\text{--}$ ” pole of polarized capacitors must be connected to the “ $\perp$ ” jack.  
Resistors and semiconductor paths connected in parallel to the capacitor distort measurement results!



## 5.7 Insulation Resistance Measurement – $\text{M}\Omega_{\text{@UISO}}$


### 5.7.1 Preparing for Measurement



#### Note

#### Testing the Measurement Cables

The test probes at the ends of the measurement cables should be short circuited before performing insulation resistance measurements with the selector switch in the  $\Omega$  or the  $\square$ ) position, in order to make sure that a value close to 0  $\Omega$  is displayed at the instrument. Incorrect connection or a broken measurement cable can be detected in this way




#### Note

Insulation resistance may only be measured at voltage-free devices. The measurement cables may not come into contact with one another during high-resistance insulation measurements.

- Set the rotary switch to “ $\text{M}\Omega_{\text{@UISO}}$ ”.
- Connect the measurement cables to the two accessible jacks.
- Interference voltage measurement (V AC+DC TRMS) is conducted in this switch position.

The **FUNC | ENTER** key for **Uiso ON / OFF** may only be pressed in order to start the insulation resistance measurement if the device under test is voltage-free.



#### Note

The  $\text{M}\Omega_{\text{@UISO}}$  switch position may only be used for insulation resistance measurement. However, if interference voltage is inadvertently applied with the switch in this position, it appears at the display.

If an interference voltage of > 50 V is present, insulation resistance measurement is disabled. The LCD continues to display the interference voltage value. If a voltage of greater than 1000 V is present, an acoustic signal is generated as well.



**Caution: High-Voltage!**

Do not touch the conductive ends of the test probes when the instrument has been activated for the measurement of insulation resistance.


You may otherwise be exposed to a current of 2.5 mA (limited in the measuring instrument), and although this is not life endangering, the resulting electrical shock is quite discernible.

If, on the other hand, measurement is being performed on a capacitive device under test, for example a cable, it may be charged with up to approximately  $\pm 1200\text{ V}$ .

**Touching the device under test after measurement has been performed is life endangering in this case!**

**Selecting the Test Voltage ( $U_{\text{ISO}} = 50$  to  $1000\text{ V}$ )**

The desired test voltage can be selected in the “**SET**” menu (see also section 6.4):




\* Selectable test voltages and the default value depend upon the respective device variant.

The selected test voltage appears at the display during testing.

**5.7.2 Performing the Insulation Measurement**

➤ **Starting the insulation resistance measurement:**

Press and hold the **UISO ON / OFF** key until the display settles in, in order to measure insulation resistance. Insulation resistance measurement is ended by releasing the key.



Auto-ranging is active during insulation resistance measurement.



### Automatic Recognition of Interference Voltage during Insulation Resistance Measurement

If the instrument detects interference voltage of greater than **15 V AC** or **> 25 V DC** during insulation testing (condition:  $U_{\text{interference}} \neq U_{\text{ISO}}$ , e.g.  $R_{\text{iq}} < 100 \text{ k}\Omega$  at 100 V, see Seite 58, footnote 1), **Error** is briefly displayed at the LCD. The instrument is then automatically switched to voltage measurement, and the currently measured voltage value is displayed.

#### Note

A dead zone results in erroneous measurements for automatic interference voltage detection during insulation resistance measurement. The dead zone lies within a range of 80% to 120% of the selected test voltage (in the case of an interference voltage whose value is equal to that of measuring voltage, the two voltages neutralize each other).

Manual switching to insulation resistance measurement is disabled for as long as voltage is applied to the test terminals.

If interference voltage is no longer present, the  $\text{M}\Omega_{\text{@ISO}}$  measurement can be started by once again pressing the **Uiso ON / OFF** key.

#### Attention!

If **Error** appears at the display, the cable (the device under test) is most likely capacitively charged to a significant extent.  
Remedy:  
Short circuit the cable (the device under test). Repeat the measurement.

### 5.7.3 Ending the Measurement and Discharging



⇒ Briefly press the **Uiso ON / OFF** key.

After measurement has been completed, any remaining residual voltage is displayed which may result from cable capacitance. The instrument's internal  $100 \text{ M}\Omega$  resistor causes rapid discharging. However, contact to the device under test must be maintained. The falling voltage value can be observed directly at the LCD. **Do not disconnect the device under test until the voltage value has dropped to < 25 V!**

#### Note

The instrument's batteries are rapidly depleted during insulation resistance measurement. Deactivate insulation resistance measurement between measurements for this reason. Use only alkaline manganese batteries in accordance with IEC 6 LR61.

#### Note

Rotary selector switch position "**V 1M $\Omega$  / M $\Omega_{\text{@ISO}}$** " is available for the detection of interference voltage during insulation resistance measurement.  
Use switch position  $\text{V} \sim$ ,  $\text{V} \equiv$  or  $\text{V} \approx$  in order to perform precise voltage measurements.

## 5.8 Current Measurement

### Notes Regarding Current Measurement

- The multimeter may only be operated with installed batteries or rechargeable batteries. Dangerous currents are otherwise not indicated, and the instrument may be damaged.
- Set up the measuring circuit in a mechanically secure fashion, and secure it against inadvertent breaks. Select conductor cross-sections and lay out connections such that they do not overheat.
- An continuous acoustic signal warns of current greater than 11 A.
- The input for the current measuring range is equipped with a fuse link. Maximum permissible voltage for the measuring circuit (= rated voltage of the fuse) is 1000 V AC/DC. Use specified fuses only! The fuse must have a **breaking capacity of at least 30 kA**.
- If the fuse for the active current measuring range blows, "FUSE" appears at the digital display, and an acoustic signal is generated at the same time.
- If a fuse should blow, eliminate the cause of overload before placing the instrument back into service!
- Fuse replacement is described in section 9.3.
- Be absolutely certain that the measuring ranges are not overloaded beyond their allowable capacities. Limit values are included in chapter 8, "Technical Data" in the table entitled "Measuring Functions and Measuring Ranges" in the "Overload Capacity" column.

### Direct Current Measurement – CLIP Parameter = OFF


- Set the  $CLIP$  parameter to **OFF** in the current clip setup menu. Otherwise all displayed measured values are corrected by the amount resulting from the selected transformation ratio for an interconnected clip-on current sensor.



Switch	FUNC	Display	Additional clip function (via CLIP 1:1/10/100/1000 in the SET menu)
<b>A<math>\overline{=}</math></b>	0/2	A $\overline{=}$ DC	
<b>A<math>\overline{\approx}</math></b>	1	A $\overline{\approx}$ DC AC TRMS	
<b>A<math>\sim</math></b>	0/2	A $\sim$ AC TRMS	➤ AC (A) clip: clip-on current transformer
<b>Hz (A)</b>	1	Hz C- A	➤ Hz (A) clip: clip-on current transformer

### 5.8.1 Direct and Pulsating Current Measurement, Direct Connection, A DC and A (DC+AC)

- First disconnect supply power from the measuring circuit or the power consumer (1), and discharge any capacitors.
- In accordance with the current to be measured, set the rotary switch to A  $\text{DC}$  or A  $\text{DC}+\text{AC}$ .
- Select the type of current appropriate for the measured quantity by briefly pressing the **FUNC | ENTER** multifunction key. Each time the key is pressed, the instrument is switched back and forth between A DC and A (DC + AC)<sub>TRMS</sub>, which is indicated by means of an acoustic signal. The current type is indicated at the LCD by means of the DC or the (DC+AC)<sub>TRMS</sub> symbol.
- Safely connect the measuring instrument (without contact resistance) in series to the power consumer (2) as shown.
- Switch supply power to the measuring circuit back on (3).
- Read the display. Make a note of the measured value if the instrument is not being operated in the memory mode or the transmission mode.
- Disconnect supply power from the measuring circuit or the power consumer (1) once again, and discharge any capacitors.
- Remove the test probes from the measuring point and return the measuring circuit to its normal condition.



### 5.8.2 Alternating Current and Frequency Measurement, Direct Connection, A AC and Hz

- First disconnect supply power from the measuring circuit or the power consumer (1), and discharge any capacitors.
- In accordance with the current or frequency to be measured, turn the rotary switch to A~ or Hz.
- Select the desired measured quantity by briefly pressing the **FUNC | ENTER** multifunction key. Each time the key is pressed, AC<sub>TRMS</sub> and Hz are alternately selected, and switching is acknowledged with an acoustic signal.
- Safely connect the measuring instrument (without contact resistance) in series to the power consumer as shown.
- Switch supply power to the measuring circuit back on (3).
- Read the display. Make a note of the measured value if the instrument is not being operated in the memory mode or the transmission mode.
- Disconnect supply power from the measuring circuit or the power consumer (1) once again, and discharge any capacitors.
- Remove the test probes from the measuring point and return the measuring circuit to its normal condition.

**MEASURE SETUP** ...  $\triangleright$  *SET*    **FUNC ENTER** ...  $\nabla$  *CL, P*    **FUNC ENTER**  $\triangle\triangle$  *OFF*

**Hz** **A~**

**Current measurement may only be performed with installed batteries!**

**03.50**  $\text{mA}$  **AC TRMS** **A~**

**FUNC ENTER**

**050.1** **Hz** **AC** **Hz**

**Measuring Ranges:**  
**A ~:** 10  $\mu\text{A}$  ... 11 A  
**6 ranges:** 300  $\mu\text{A}$ , 3 mA, 30 mA, 300 mA, 3 A and 10 A

**Hz:** 1 Hz ... 31 kHz  
**3 ranges:** 300 Hz, 3 kHz and 30 kHz

V $\Omega$ |MC<sub>iso</sub>    Temp |  $\rightarrow$     COM mA|A


**I > 11 A**  
**Current**

### 5.8.3 Direct and Pulsating Current Measurement with Clip-On Current Sensor A DC and A (DC+AC)

#### Transformer Output, Voltage/Current

When a clip-on current sensor is connected to the multimeter (V input), all current displays appear with the correct value in accordance with the selected transformation ratio. The only prerequisite is that the current sensor is equipped with at least one of the below listed transformation ratios, and that the ratio has been previously selected in the following menu (**CL, P = OFF**).


#### Current Clip Setup Menu



Transf. Ratio <b>CL, P</b>	Measuring Ranges			Clip Type
	300 mV	3 V	30 V	
<b>1:1</b> 1 mV / 1 mA	300.0 mA	3.000 A	30.00 A	WZ12C
<b>1:10</b> 1m V / 10 mA	3.000 A	30.00 A	300.0 A	WZ12B, Z201A
<b>1:100</b> 1m V / 100 mA	30.00 A	300.0 A	3,000 kA	Z202A
<b>1:1000</b> 1 mV/1 A	300.0 A	3,000 kA	30.00 kA	Z202A, Z203A, WZ12C

Maximum allowable operating voltage is equal to the current transformer's nominal voltage. When reading the measured value, additional error resulting from the clip-on current sensor must also be taken into consideration.

(default value: **CL, P = OFF** = voltage display)




### 5.8.4 Alternating Current Measurement with Clip-On Current Sensor, A AC and Hz

#### Transformer Output, Voltage/Current

When a clip-on current sensor is connected to the multimeter (V input), all current displays appear with the correct value in accordance with the selected transformation ratio. The only prerequisite is that the current sensor is equipped with at least one of the below listed transformation ratios, and that the ratio has been previously selected in the following menu (**CL, P**  $\neq$  **OFF**).


#### Current Clip Setup Menu



Transf. Ratio <b>CL, P</b>	Measuring Ranges			Clip Type
	300 mV	3 V	30 V	
<b>1:1</b> 1 mV / 1 mA	300.0 mA	3.000 A	30.00 A	WZ12C
<b>1:10</b> 1m V / 10 mA	3.000 A	30.00 A	300.0 A	WZ12B, Z201A
<b>1:100</b> 1m V / 100 mA	30.00 A	300.0 A	3,000 kA	Z202A
<b>1:1000</b> 1 mV/1 A	300.0 A	3,000 kA	30.00 kA	Z202A, Z203A, WZ12C

Maximum allowable operating voltage is equal to the current transformer's nominal voltage. When reading the measured value, additional error resulting from the clip-on current sensor must also be taken into consideration.

(default value: **CL, P** = **OFF** = voltage display)




### 5.8.5 Alternating Current Measurement with A AC and Hz Clip-On Current Transformer

#### Current/Current Transformer Output

When a clip-on current transformer is connected to the multimeter (mA/A input), all current displays appear with the correct value in accordance with the selected transformation ratio. The only prerequisite is that the current transformer is equipped with at least one of the below listed transformation ratios, and that the ratio has been previously selected in the following menu ( $CL, P \neq OFF$ ).

#### Current Clip Setup Menu



Transf. Ratios $CL, P$	DMM Measuring Ranges			Clip Types
	30 mA	300 mA	3 A	
<b>1:1</b> 1 mA / 1 mA	30.00 mA	300.0 mA	3.000 A	
<b>1:10</b> 1 mA / 10 mA	300 mA	3.000 A	30.00 A	
<b>1:100</b> 1 mA / 100 mA	3.000 A	30.00 A	300.0 A	
<b>1:1000</b> 1 mA / 1 A	30.00 A	300.0 A	3000.0 A	WZ12A, WZ12D, WZ11A, Z3511, Z3512, Z3514

**Measuring Ranges:**  
 mA / A: see table  
 Hz: 1 Hz . . . 31 kHz  
 3 ranges: 300 Hz, 3 kHz and 30 kHz


### 6 Device and Measuring Parameters

The instrument's "**SELP**" mode (menu mode) makes it possible to set operating and measuring parameters, query information and activate the interface.

- ⇨ The menu mode is accessed by pressing the **MEASURE | SETUP** key, assuming that the instrument is switched on and set to "Measure" (measuring mode operation).  
"Info" appears at the display.
- ⇨ The main menus, i.e. the "**SEL**" and "**LENP**" menus, as well as the "**SEnd**" and "**StorE**" menus, are accessed, and the display is returned to "Info", by repeatedly activating the  $\triangleleft \triangleright \triangle \nabla$  keys (in any direction).
- ⇨ After selecting the desired main menu, sub-menus are accessed by pressing the **FUNC | ENTER** key.
- ⇨ The desired parameter is selected by repeatedly pressing the  $\triangle \nabla$  keys.
- ⇨ In order to check or change a parameter, acknowledge it with the **FUNC | ENTER** key.
- ⇨ The  $\triangleleft \triangleright$  keys can be used to position the cursor at the entry position.  
The desired value is selected with the help of the  $\triangle \nabla$  keys.
- ⇨ Changes can only be accepted with the **FUNC | ENTER** key.
- ⇨ You can return to the sub-menu without making any changes by pressing the **ZERO | ESC** key, and to the main menu by pressing the **ZERO | ESC** key once again etc.
- ⇨ You can switch to the measuring mode from any menu level by pressing the **FUNC | ENTER** key.

After repeatedly pressing the **MEASURE | SETUP** key (without first turning the multimeter off), you can return to the last selected menu or parameter from the measuring mode.

#### Example: Setting Time



#### Setting hours and minutes:

- $\triangleleft \triangleright$  Advance to desired entry position.
- $\triangle \nabla$  Change the setting, the entry position blinks.  
Press and hold the key to change the setting rapidly.
- FUNC | ENTER The new time setting is activated after acknowledgement.





## Device and Measuring Parameters

---

### 6.3 Querying Parameters – InFo Menu (as moving letters)

---

#### bAtt – query battery voltage

 *Info*  bAtt: 2.75 V.

---



#### vErSion – query firmware version

 *Info*  bAtt: vErSion: 1.00

---



#### ItEMP – query reference temperature

The temperature of the internal reference junction is measured with a temperature sensor in close proximity to the input sockets.

 *Info*  bAtt: ItEMP: 24 °C

---

#### dAtE – query date


 *Info*  bAtt: dAtE: 31.12.05 (DD.MM.YY)

D = day, M = month, Y = year

Date and time must be reentered after replacing the batteries.

---

#### tiME – query time



 *Info*  bAtt: tiME: 13:46:56  
(hh:mm:ss)

h = hours, m = minutes, s = seconds

Date and time must be reentered after replacing the batteries.

---

#### OCCUP – query memory occupancy

 *Info*  bAtt: OCCUP: 000.0%

## 6.4 Entering Parameters – SETUP Menu

### rAtE – set the sampling rate

The sampling rate specifies the time interval after which the respective measured value is transmitted to the interface, or to measured value memory.

Any one of the following sampling rates can be selected:  
 [mm:ss.t]: 00:00,1, 00:00,2, **00:00.5**, 00:01,0, 00:02,0, 00:05.0  
 [h:mm:ss.t] (h=hours, m=minutes, s=seconds, z=tenths of a sec.):  
 0:00:10, 0:00:20, 0:00:30, 0:00:40, 0:00:50, 0:01:00, 0:02:00,  
 0:05:00, 0:10:00, 0:20:00, 0:30:00, 0:40:00, 0:50:00, 1:00:00,  
 2:00:00, 3:00:00, 4:00:00, 5:00:00, 6:00:00, 7:00:00, 8:00:00,  
 9:00:00


Setting the Sampling Rate



(00:00.5 = 0.5 s = default value)

### rESoL – high resolution for V DC and $\Omega$ (customer-specific function)


Switching back and forth between 3¾ and 4¾ places is possible for direct voltage and resistance measurement.



(3000 = default setting)

### 0.diSP – show/hide leading zeros

This parameter determines whether or not leading zeros will appear in the measured value display.



0000.0 : with leading zeros (default value)

0.0 : leading zeros suppressed

### CLIP – set current clip factor


See chapter 5.8.3, chapter 5.8.4 and chapter 5.8.5.

## Device and Measuring Parameters

### APoFF – specified time for automatic shutdown and continuous ON

The instrument is switched off automatically if the measured value remains unchanged for a long period of time and if none of the keys or the rotary switch have been activated before the specified time “APoFF” (entered in minutes) has elapsed.


If the *on* setting is selected, the multimeter is set for long-term measurement and *ON* appears in the display to the right of the battery symbol. In this case, the multimeter can only be switched off manually. The “*on*” setting can only be cancelled by changing the respective parameter, and not by switching the instrument off.



(10 minutes = default setting)

### U\_Iso – select test voltage

The desired test voltage for insulation resistance measurement can be selected here:




\* Selectable test voltages and the default setting depend upon the respective customer-specific variant.

### RPM – revolutions per minute (customer-specific function)

See section 5.1.2 regarding settings.

### bBEEP – set limit value for continuity testing



(10 Ω = default setting)

### irStb – status of the infrared receiver in the stand-by mode


See chapter 7.2 on page 55 regarding settings.

### Addr – set device address

See chapter 7.2 on page 55.

**dAtE – enter date**


Entering the current date makes it possible to acquire measured values in real-time.



Date and time must be reentered after replacing the batteries.

**tiME – set time**



Entering the correct time makes it possible to acquire measured values in real-time.



Date and time must be reentered after replacing the batteries.

**6.5 Default Settings**

Previously entered changes can be undone, and the default settings can be reactivated. This may be advisable under the following circumstances:

- after the occurrence of software or hardware errors,
  - if you are under the impression that the multimeter does not work correctly.
- ⇒ **Disconnect the device from the measuring circuit.**
- ⇒ Remove the batteries temporarily (see also chapter 9.2).
- ⇒ Simultaneously press and hold the  and 

keys, and connect the battery at the same time.

A sequence of acoustic signals consisting of two immediately consecutive tones acknowledges successful resetting.

### 7 Interface Operation

The multimeter is equipped with an infrared interface for the transmission of measurement data to a PC. Measured data are optically transferred through the instrument housing by means of infrared light to an interface adapter (accessory), which is attached to the multimeter. The adapter's USB interface allows for the establishment of a connection to the PC via an interface cable. Beyond this, commands and parameters can be transmitted from the PC to the multimeter as well. The following functions can be executed:

- Configuration and read-out of measuring parameters,
- Measuring function and measuring range selection,
- Start measurement,
- Read out stored measured values.

#### 7.1 Activating the Interface

The interface is automatically activated for receiving operation (multimeter receives data from the PC) as soon as the interface is addressed by the PC, assuming that the “*rStb*” parameter has been set to “*1 roni*” (see chapter 7.2), or the instrument is already switched on (the first command wakes up the multimeter, but does not yet execute any further commands).


The “continuous transmission” operating mode is selected manually as described below. In this operating mode, the instrument continuously transmits measurement data to the PC via the interface adapter, which can then be displayed with the help of a terminal program.

#### Starting Continuous Transmission Operation with Menu Functions



The **↓IR↑** symbol blinks at the display in order to indicate interface operation.

#### Stopping Continuous Transmission Operation with Menu Functions



The **↓IR↑** symbol is cleared from the display.

#### Automatic Activation and Deactivation of Transmission Mode Operation

If the sampling rate is 10 seconds or longer, the display is switched off automatically between samples in order to prolong battery service life. The only exception is when the multimeter is set to continuous operation.






As soon as an event occurs, the display is automatically switched back on.

## 7.2 Configuring Interface Parameters

### *rStb* – status of the infrared receiver in the stand-by mode

There are two possible switching statuses for the infrared interface when the multimeter is switched off:






- rOn*: IR appears at the display and the infrared interface is active, i.e. signals such as making commands can be received, and power is consumed even though the multimeter is switched off.
- rOff*: IR does not appear at the display and the infrared interface is switched off, signals cannot be received.

 *Info* ▷ ... ▷   *rALe* ▽ ... ▽ *rStb*  
 *rOn* / *rOff* △ ▽ 

(*rStb* = *rOff* = default setting)





### *Addr* – Address

If several multimeters are connected to the PC via an interface adapter, a separate address can be assigned to each instrument. Address number 1 should be selected for the first instrument, 2 should be assigned to the second and so forth.

 *Info* ▷ ... ▷   *rALe* ▽ ... ▽ *Addr*  
 *00* ... *01* ... *15* △ ▽ 

(15 = default setting)

8 Technical Data

Meas. Function (input)	Measuring Range	Resolution at Upper Range Limit		Input Impedance		Intrinsic Uncertainty under Reference Conditions				Overload Capacity <sup>2)</sup>	
						±(... % rdg. + ... d)					
						30000	3000	30000	3000	3000	3000
<b>V</b>	300.0 mV 10	μV	100 μV	9 MΩ	9 MΩ // < 50 pF	0.15 + 15 <sup>10)</sup>	0.2 + 3 <sup>10)</sup>	1 + 3 (> 100 D)	1.5 + 5 (> 100 D)	1000 V DC AC RMS Sine <sup>6)</sup>	Cont.
	3.000 V 100	μV	1 mV	9 MΩ	9 MΩ // < 50 pF	0.15 + 15	0.15 + 2	1 + 3 (> 30 D)	1.5 + 5 (> 100 D)		
	30.00 V 1 m	V	10 mV	9 MΩ	9 MΩ // < 50 pF	0.15 + 15	0.15 + 2				
	300.0 V 10	mV	100 mV	9 MΩ	9 MΩ // < 50 pF	0.15 + 15	0.15 + 2				
	1000 V 100	mV	1 V	9 MΩ	9 MΩ // < 50 pF	0.15 + 15	0.2 + 2				
<b>Voltage drop at approx. range limit</b>						≡	~ <sup>1) 11)</sup>	≡ <sup>1) 11)</sup>			
<b>A</b>	300.0 μA		100 nA	18 mV	18 mV	0.5 + 5	1.5 + 5 (> 100 D)	1.5 + 5 (> 100 D)	1.5 + 5 (> 100 D)	0.3 A	Cont.
	3.000 mA		1 μA	160 mV	160 mV						
	30.00 mA		10 μA	32 mV	32 mV						
	300.0 mA		100 μA	200 mV	200 mV						
	3.000 A		1 mA	120 mV	120 mV						
	10.00 A		10 mA	400 mV	400 mV						
Factor 1:1/10/100/1000		<b>Input</b>		<b>Input impedance</b>		≡	~ <sup>1) 11)</sup>	≡ <sup>1) 11)</sup>			
<b>A</b>  @ <b>A</b>	0.03/0.3/3/30 A	30 mA		Current measurement input (jack A~)		—	1.5 + 5 (> 100 D)	—	0.3 A	Cont.	
	0.3/3/30/300 A	300 mA									
	3/30/300/3k A	3 A									
Plus clip-on current transformer error									3 A	5 min	
<b>A</b>  @ <b>V</b>	0.3/3/30/300 A	300 mV		Voltage measurement input approx. 9 MΩ (X socket)		0.5 + 3	1.5 + 3 (> 300 D)	1.5 + 5 (> 300 D)	1.5 + 5 (> 100 D)	Meas. input <sup>b)</sup> : 1000 V RMS max. 10 s	
	3/30/300/3k A	3 V									
	30/300/3k/30k A	30 V									
Plus clip-on current sensor error											
				<b>Open-circuit voltage</b>	<b>Meas. current at range limit</b>	±(... % rdg. + ... d)					
						30000	3000				
<b>Ω</b>	300.0 Ω	10 mΩ	100 mΩ	< 1.4 V	Approx. 300 μA	0.5 + 15 with ZERO active	0.5 + 3 with ZERO active			1000 V DC AC RMS Sine	max. 10 s
	3.000 kΩ	100 mΩ	1 Ω	< 1.4 V	Approx. 200 μA	0.5 + 15	0.5 + 2				
	30.00 kΩ	1 Ω	10 Ω	< 1.4 V	Approx. 30 μA	0.5 + 15	0.5 + 2				
	300.0 kΩ	10 Ω	100 Ω	< 1.4 V	Approx. 3 μA	0.5 + 15	0.5 + 2				
	3.000 MΩ	100 Ω	1 kΩ	< 1.4 V	Approx. 0.3 μA	0.5 + 15	0.5 + 2				
	30.00 MΩ	1 kΩ	10 kΩ	< 1.4 V	Approx. 33 nA	2.0 + 20	2.0 + 5				
 	300.0 Ω		100 mΩ	ca. 10 V	Approx. 1 mA const.	3 + 5					
	5.1 V <sup>3)</sup>		1 mV	ca. 0 V		2 + 5					



Meas. Function (input)	Measuring Range		Resolution at Upper Range Limit		Intrinsic Uncertainty under Reference Conditions		Overload Capacity <sup>2)</sup>				
				3000			Value	Time			
				<b>Discharge resist.</b>	<b>U<sub>0 max</sub></b>	±(... % rdg. + ... d)					
<b>F</b>	30.00	nF	10	pF	10	MΩ	0.7	V	±(1 + 6 <sup>4)</sup> with ZERO function active	1000 V DC AC RMS Sine	max. 10 s
	300.0	nF	100	pF	1	MΩ	0.7	V	±(1 + 6 <sup>4)</sup>		
	3.000	μF	1	nF	100	kΩ	0.7	V	±(1 + 6 <sup>4)</sup>		
	30.00	μF	10	nF	12	kΩ	0.7	V	±(1 + 6 <sup>4)</sup>		
	300.0	μF	100	nF	3	kΩ	0.7	V	±(5 + 6 <sup>4)</sup>		
						<b>f<sub>min</sub></b> <sup>5)</sup>	±(... % rdg. + ... d)				
<b>Hz (V)/</b>	300.0	Hz	0.1	Hz							
<b>Hz (A)</b>	3.000	kHz	1	Hz			1	Hz	0.1 + 2 <sup>8)</sup>	Hz (V) <sup>6)</sup> ; Hz(A) > 10 <sup>6)</sup> ; 1000 V Hz (A): <sup>7)</sup>	max. 10 s
<b>Hz (A)</b>	30.00	kHz	10	Hz			10	Hz			
<b>Hz (V)</b>	300.0	kHz	100	Hz			100	Hz			
							±(... % rdg. + ... d) <sup>9)</sup>				
<b>°C</b>	Pt 100	-200.0 ... +850.0 °C	0.1	°C					0.5 % + 15	1000 V DC/AC RMS Sine	max. 10 s
	Pt 1000	-150.0 ... +850.0 °C					0.5 % + 15				
	K (NiCr-Ni)	-250.0 ... +1372.0 °C					1 % + 5 K				

1) 15 ... 45 ... 65 Hz ... 10 (5) kHz sine. See following page for influences.

2) At 0 ° ... + 40 °C

3) Display of up to max. 5.1 V, "OL" in excess of 5.1 V.

4) Applies to measurements at film capacitors and battery operated

5) Lowest measurable freq. for sinusoidal meas. signals symmetrical to zero point

6) Overload capacity of the voltage measurement input: power limiting: frequency x max. voltage 3 x 10<sup>6</sup> V x Hz @ U > 100 V

7) Overload capacity of the current measurement input:

See current measuring ranges for maximum current values.

8) Input sensitivity, sinusoidal signal, 10% to 100% of the voltage or current measuring range; limitation: up to 30% of the range at up to 100 kHz in the mV measuring range, 30% of the range in the 3 A measuring range. The voltage measuring ranges with max. 30 kHz apply in the A measuring range.

9) Plus sensor deviation

10) With ZERO function active

11) Residual value of 1 to 10 d with short circuited terminal tips,

exception: mV / μA range of 1 to 35 d at zero point due to the TRMS converter

12) 10 minute cool-down period

**Key:** R = meas. range, d = digit(s), rdg. = measured value (reading)

## Insulation Resistance Measurement <sup>1)</sup>

Measuring Range	Resolution	Test voltage U <sub>ISO</sub>	Digital Display Intrinsic Uncertainty under Reference Conditions
0,3 V ... 1000 V $\approx$ <sup>2)</sup>		Ri=1M $\Omega$	3 + 30 > 100 Digit
5 ... 310.0 k $\Omega$ 0,1	k $\Omega$	50/100/250/500 V	3 + 5
0.280 ... 3.100 M $\Omega$	1 k $\Omega$	50/100/250/500/1000 V	3 + 5
02.80 ... 31.00 M $\Omega$	10 k $\Omega$	50/100/250/500/1000 V	5 + 5
028.0 ... 310.0 M $\Omega$	100 k $\Omega$	50/100/250/500/1000 V	5 + 5
0280 ... 3100 M $\Omega$	1 M $\Omega$	500/1000 V	5 + 5

<sup>1)</sup> During insulation measurement (M $\Omega$ <sub>@U<sub>ISO</sub></sub>): If „Error“ is displayed >> limits: U<sub>interference</sub> > 10...20 V and U<sub>interference</sub>  $\neq$  U<sub>ISO</sub>, Ri < 50 k $\Omega$  @ U<sub>iso</sub> 50 V, Ri < 100 k $\Omega$  @ U<sub>iso</sub> 100 V, Ri < 250 k $\Omega$  @ U<sub>iso</sub> 250 V, Ri < 500 k $\Omega$  @ U<sub>iso</sub> 500 V, Ri < 1000 k $\Omega$  @ U<sub>iso</sub> 1000 V

<sup>2)</sup> Interference voltage measurement TRMS (V AC + DC) with 1 M $\Omega$  input resistance, Bandwidth 15 Hz ... 500 Hz, measuring error 3% + 30 Digit

Measuring Function	Nom. Voltage U <sub>N</sub>	Open-Circuit Voltage U <sub>o</sub>	Nom. Current I <sub>N</sub>	Short-Circuit Current I <sub>k</sub>	Acoustic Signal for	Overload Capacity	
						Value	Time
U <sub>interference</sub> /M $\Omega$ <sub>@U<sub>ISO</sub></sub>	—	—	—	—	U>1000V	1000 V $\approx$	dauernd
M $\Omega$ <sub>@U<sub>ISO</sub></sub>	50, 100, 250, 500 V	max. 1.1x U <sub>ISO</sub>	1.0 mA	< 1.2 mA	U>1000V	1000 V $\approx$	10 s
M $\Omega$ <sub>@U<sub>ISO</sub></sub>	1000 V	max. 1.1x U <sub>ISO</sub>	0.5 mA	< 1.2 mA	U>1000V	1000 V $\approx$	10 s

## Internal Clock

Time format	TT.MM.JJJJ hh:mm:ss
Resolution	0.1 s
Accuracy	$\pm$ 1 minute per month
Temperature influence	50 ppm/K

## Influencing Quantities and Influence Error

Influencing Quantity	Sphere of Influence	Measured Quantity / Measuring Range <sup>1)</sup>	Influence Error (... % rdg. + ... d) / 10 K
Temperature	0 °C ... +21 °C and +25 °C ... +40 °C	V $\approx$	0.2 + 5
		V $\sim$	0.4 + 5
		300 $\Omega$ ... 3 M $\Omega$	0.5 + 5
		30 M $\Omega$	1 + 5
		mA/A $\approx$	0.5 + 5
		mA/A $\approx$	0.8 + 5
		30 nF ... 300 $\mu$ F	1
		Hz	0.2 + 5
°C/F (Pt100/Pt1000)	0.5 + 5		

+ 5

<sup>1)</sup> With zero balancing

Influencing Quantity	Measured Quantity / Measuring Range	Sphere of Influence	Intrinsic Uncertainty <sup>3)</sup> $\pm$ (... % rdg. + ... d)	
				Frequency
1000 V	> 65 Hz ... 2 kHz	2 + 5 > 300 Digit		
	> 2 kHz ... 10 kHz	3 + 5 > 300 Digit		
A <sub>AC</sub>	300 $\mu$ A ... 10 A	> 15 Hz ... 45 Hz	3 + 5 > 60 Digit	
	300 $\mu$ A ... 10 A	> 65 Hz ... 10 kHz	3 + 10 > 300 Digit	
		300 $\mu$ A ... 10 A	> 15 Hz ... 45 Hz	
	A <sub>AC+DC</sub>		> 65 Hz ... 10 kHz	
A <sub>AC</sub> $\succ$		300 mV / 3 V / 30 V <sup>2)</sup>	> 65 Hz ... 10 kHz	
A <sub>AC</sub> $\succ$	30 mA...3 A	> 65 Hz ... 10 kHz	3 + 30 > 300 Digit	

<sup>2)</sup> Power limiting: frequency x voltage, max. 3 x 10<sup>6</sup> V x Hz

<sup>3)</sup> The accuracy specification is valid as of a display value of 10% and up to 100% of the measuring range for both measuring modes with the TRMS converter in the A AC and A (AC+DC) ranges.

Influencing Quantity	Sphere of Influence	Measured Quantity / Measuring Range	Influence Error <sup>5)</sup>
Crest Factor CF	1 ... 3	V ~, ~A	± 1% rdg.
	> 3 ... 5		± 3% rdg.

<sup>5)</sup> Except for sinusoidal waveshape

Influencing Quantity	Sphere of Influence	Measured Quantity	Influence Error
Relative Humidity	75%, 3 days, instrument off	V, A, Ω, F, Hz, °C	1 x intrinsic uncertainty
Battery voltage	1.8 to 3.6 V	ditto	Included in intrinsic uncertainty

Influencing Quantity	Sphere of Influence	Measured Qty. / Measuring Range	Damping
Common Mode Interference Voltage	Interference quantity max. 1000 V ~ 50 Hz ... 60 Hz, sine	V ≡	> 120 dB
		3 V ~, 30 V ~	> 80 dB
		300 V ~	> 70 dB
		1000 V ~	> 60 dB
Series Mode Interference Voltage	Interference quantity: V ~, respective nominal value of the measuring range, max. 1000 V ~, 50 Hz ... 60 Hz sine	V ≡	> 0 dB
		V ~	> 110 dB

### Response Time (after manual range selection)

Measured Quantity / Measuring Range	Response Time Digital Display	Measured Quantity Jump Function
V ≡, ~V A ≡, ~A	1.5 s	From 0 to 80% of upper range limit value
300 Ω ... 3 MΩ	2 s	From ∞ to 50% of upper range limit value
30 MΩ, MΩ@ <sub>ISO</sub>	Max. 5 s	
Continuity	< 50 ms	
°C (Pt 100)	Max. 3 s	
→	1.5 s	5 From 0 to 50% of upper range limit value
30 nF ... 300 μF >10 Hz	Max. s 1.5 s	

### Reference Conditions

Ambient temperature	+23° C ±2 K
Relative humidity	40% to 75%
Meas. Qty. Freq.	45 Hz ... 65 Hz
Meas. Qty. Waveshape	Sin e
Battery voltage	3 V ±0.1 V

### Ambient Conditions

Accuracy range	0° C ... +40° C
Operating temp. range	-10° C ... +50° C
Storage temp. range	-25° C ... +70° C (without batteries)
Relative humidity	40 to 75%, no condensation allowed
Elevation	to 2000 m
Deployment	Indoors, except within specified ambient conditions

## Technical Data

### Display

LCD panel (65 mm x 36 mm) with analog and digital display including unit of measure, type of current and various special functions

### Background illumination

Background illumination is switched off approximately 1 minute after it has been activated.

### Analog

Display LCD scale with pointer  
 Scaling Linear:  
 $\mp 5 \dots 0 \dots \pm 30$  with 35 scale divisions  
 for  $\equiv$ ,  $0 \dots 30$  with 30 scale divisions in all other ranges

Polarity display With automatic switching  
 Overflow display With the ► symbol  
 Measuring rate 40 measurements per second and display refresh

### Digital

Display/Char. Height 7-segment characters / 15 mm  
 Number of places  $3\frac{3}{4}$  places,  $\cong 3100$  steps  
 $4\frac{3}{4}$  places in measuring function V DC and  $\Omega$

Overflow display "OL" is displayed for  $\geq 3100$  digits  
 Polarity display "-" (minus sign) is displayed if plus pole is connected to "1"


Measuring rate 10 and 40 measurements per second with the Min/Max function except for the capacitance, frequency and keying ratio measuring functions

Refresh Rate 2 times per sec., every 500 ms

### Power Supply

Battery 2 ea. 1.5 V mignon cell (2 ea. size AA), alkaline manganese per IEC LR6

Service life With alkaline manganese batteries: approx. 200 hours (without  $M\Omega_{@UISO}$  measurement)

Battery test Battery capacity display with battery symbol in 4 segments: . Querying of momentary battery voltage via menu function.

Power OFF function The multimeter is switched off automatically:  
 – If battery voltage drops to below approx. 1.8 V  
 – If none of the keys or the rotary switch are activated for an adjustable duration of 10 to 59 minutes, and the multimeter is not in the continuous operation mode

Power pack socket If the power pack has been plugged into the instrument, the installed batteries are disconnected automatically. Rechargeable batteries can only be recharged externally.

Measuring Function	Nominal Voltage $U_N$	Resistance of the DUT	Service life in Hours	Number of Possible Measurements with Nominal Current per VDE 0413
V $\equiv$			200 <sup>1)</sup>	
V $\sim$			150 <sup>1)</sup>	
$M\Omega$	100 V	1 $M\Omega$	50	
	100 V	100 $k\Omega$		3000
	500 V	500 $k\Omega$		600
	1000 V	2 $M\Omega$		200

<sup>1)</sup> Times 0.7 for interface operation

### Electrical Safety

Safety class	II per EN 61010-1:2001/VDE 0411-1:2002	
Measuring category	CAT II	CAT III
Nominal voltage	1000 V	600 V
Fouling factor	2	
Test voltage	5.2 kV~ per EN 61010-1:2001/VDE 0411-1:2002	

### Fuses

Fuse link	FF 10 A/1000 V AC/DC; 10 mm x 38 mm; switching capacity: 30 kA at 1000 V AC/DC; protects the current measurement input in the 300 µA through 10 A ranges
-----------	--

### Electromagnetic Compatibility (EMC)

Interference emission	EN 61326-1:2006, class B
Interference immunity	EN 61326-1:2006 EN 61326-2-1:2006

### Data Interface

Type	Optical via infrared light through the housing
Data transmission	Serial, bidirectional (not IrDa compatible)
Protocol	Device specific
Baud Rate	38,400 baud
Functions	<ul style="list-style-type: none"> <li>– Select/query measuring functions and parameters</li> <li>– Query momentary measurement data</li> </ul>

The USB | **X-TRA** plug-in interface adapter (see accessories) is used for adaptation to the PC's USB port.

### Internal Measured Value Storage

Memory capacity	4 MBit / 540 kB for approx. 15,000 measured values with indication of date and time
-----------------	---

### Mechanical Design

Housing	Impact resistant plastic (ABS)
Dimensions	200 x 87 x 45 mm (without protective rubber cover)
Weight	Approx. 0.35 kg with batteries
Protection	Housing: IP 54 (pressure equalization by means of the housing)

Table Excerpt Regarding Significance of the IP Code

IP XY (1 <sup>st</sup> digit X)	Protection against foreign object entry	IP XY (2 <sup>nd</sup> digit Y)	Protection against the penetration of water
4	≥ 1.0 mm dia.	4	splashing water
5	dust protected	5	water jets

## 9 Maintenance and Calibration



### Attention!

Disconnect the instrument from the measuring circuit before opening the battery compartment lid or fuse cover when replacing batteries or fuses!

### 9.1 Displays – Error Messages

Message	Function	Meaning
<i>FUSE</i>	Current measurement	Blown fuse
	In all operating modes	Battery voltage has fallen below 1.8 V
<i>OL</i>	Measurement	Indicates overflow
<i>ur</i>	$M\Omega_{ISO}$ measurement	Measured value of less than 10% of the measuring range
<i>Error</i>	$M\Omega_{ISO}$ measurement	Interference voltage detected

### 9.2 Batteries



### Note

#### Removing the Batteries During Periods of Non-Use

The integrated quartz movement draws power from the batteries even when the instrument is switched off. It is advisable to remove the batteries during long periods of non-use for this reason (e.g. vacation). This prevents excessive depletion of the battery, which may result in damage under unfavorable conditions.



### Note

#### Battery Replacement

Stored measurement data are lost when the batteries are replaced. In order to prevent data loss, it is advisable to backup your data to a PC with the help of **METRAWIN 10** software before replacing the batteries.

The selected operating parameters remain in memory, although date and time must be reentered.

### Battery

The current battery charge level can be queried in the “*Info*” menu:



Make sure that no battery leakage has occurred before initial start-up, as well as after long periods of storage. Continue to inspect the batteries for leakage at short, regular intervals.

If battery leakage has occurred, carefully and completely clean the electrolyte from the instrument with a damp cloth, and replace the battery before using the instrument.

If the “” symbol appears at the display, the batteries should be replaced as soon as possible. You can continue working with the instrument, but reduced measuring accuracy may result.

The instrument requires two 1.5 V batteries in accordance with IEC LR 6, or two equivalent rechargeable NiCd batteries.

## Replacing the Batteries



### Attention!

Disconnect the instrument from the measuring circuit before opening the battery compartment lid in order to replace the batteries.

- ↗ Set the instrument face down onto the working surface.
- ↗ Turn the slotted screw on the lid with the battery symbols counterclockwise.
- ↗ Lift off the lid and remove the batteries from the battery compartment.
- ↗ Insert two new 1.5 V mignon batteries into the battery compartment, making sure that the plus and minus poles match up with the provided polarity symbols.
- ↗ When replacing the battery compartment lid, insert the side with the guide hooks first. Tighten the screw by turning it clockwise.
- ↗ Please dispose of depleted batteries in accordance with environmental protection regulations!

## 9.3 Fuses

### Testing the Fuse

The fuse is tested automatically:

- When the instrument is switched on with the rotary switch in the A position
- When the instrument is already on and the rotary switch is turned to the A position
- In the active current measuring range when voltage is applied

If the fuse is blown or has not been inserted, “FuSE” appears at the digital display. The fuse interrupts the current measuring ranges. All other measuring ranges remain functional.



### Replacing the Fuse

If a fuse should blow, eliminate the cause of overload before placing the instrument back into service!



### Attention!

Disconnect the instrument from the measuring circuit before opening the fuse cover in order to replace the fuse!

- ↗ Set the instrument face down onto the working surface.
- ↗ Turn the slotted screw on the cover with the fuse symbol counterclockwise.
- ↗ Lift off the cover and pry the fuse out using the flat side of the fuse cover.
- ↗ Insert a new fuse. Make sure that the fuse is centered, i.e. between the tabs at the sides.
- ↗ When replacing the fuse cover, insert the side with the guide hooks first. Tighten the screw by turning it clockwise.
- ↗ Dispose of the blown fuse with the trash.



### Attention!

Use specified fuses only!

If fuses with other blowing characteristics, other current ratings or other breaking capacities are used, the operator is placed in danger, and protective diodes, resistors and other components may be damaged.

The use of repaired fuses or short-circuiting the fuse holder is prohibited.

---



### Note

#### Testing the Fuse with the Instrument Switched On

After inserting the fuse with the instrument switched on, the instrument must be switched off briefly and then switched back on, or briefly switched to a non current measuring range and then back to the A measuring range.

If contact is poor or the fuse is blown, FUSE appears at the display.

---

### 9.4 Housing Maintenance

No special maintenance is required for the housing. Keep outside surfaces clean. Use a slightly dampened cloth for cleaning. Avoid the use of cleansers, abrasives or solvents.

### 9.5 Return and Environmentally Sound Disposal

The instrument is a category 9 product (monitoring and control instrument) in accordance with ElektroG (German electrical and electronic device law). This device is not subject to the RoHS directive.

We identify our electrical and electronic devices (as of August 2005) in accordance with WEEE 2002/96/EC and ElektroG with the symbol shown at the right per DIN EN 50419.



These devices may not be disposed of with the trash.

Please contact our service department regarding the return of old devices (see page 4).

### 9.6 Recalibration Service

We **calibrate** and **recalibrate** all instruments supplied by GMC-I Messtechnik GmbH, as well as other manufacturers, at our service center, for example after one year within the framework of your test equipment monitoring program, as well as prior to use etc. (see address on page 4).



### **9.7 Manufacturer's Guarantee**

The multimeter is guaranteed for a period of 3 years after shipment. The manufacturer's guarantee covers materials and workmanship. Damages resulting from use for any other than the intended purpose, as well as any and all consequential damages, are excluded.

Calibration is guaranteed for a period of 12 months.

### 10 Accessories

#### 10.1 General

The extensive accessories available for our measuring instruments are checked for compliance with currently valid safety regulations at regular intervals, and are expanded as required for new applications. Currently up-to-date accessories which are suitable for your measuring instrument are listed at the following web address along with photo, order number, description and, depending upon the scope of the respective accessory, data sheet and operating instructions: [www.gossenmetrawatt.de](http://www.gossenmetrawatt.de) (→ Products → Measuring Technology – Portable → Digital Multimeters → **METRAHIT** | ... → Accessories).

#### 10.2 Technical Data for Measurement Cables (scope of delivery: KS17-2 safety cable set)

##### Electrical Safety

Maximum rated voltage  
Measuring category 1000 V CAT III, 600 V CAT IV  
Maximum rated  
current 16 A

##### Ambient Conditions (EN 61 010-031)

Temperature –20 °C ... + 50 °C  
Relative humidity 50 to 80%  
Fouling factor 2

#### 10.3 Power Pack NA | X-TRA (not included)

Use only power packs from GMC-I Messtechnik GmbH only in combination with your instrument. This assures operator safety by means of an extremely well insulated cable, and safe electrical isolation (nominal secondary ratings: 5 V / 600 mA). Installed batteries are disconnected electronically if the power pack is used, and need not be removed from the instrument.

## 10.4 Interface Accessories (not included)

### USB | X-TRA Bidirectional Interface Adapter

This adapter makes it possible to connect cable multimeters, as well as **METRAHIT | X-TRA** multimeters which are equipped with a serial IR interface, to the USB port at a PC. The adapter allows for data transmission between the multimeter and the PC.

### METRAwin 10 PC Analysis Software

**METRAwin 10** PC software is a multilingual, measurement data logging program for recording, visualizing, evaluating and documenting measured values from **METRAHIT |** multimeters.

The following conditions must be fulfilled in order to allow for use of **METRAwin 10**:

#### Hardware

- IBM compatible Windows PC, 200 MHz Pentium processor or faster with at least 64 MB RAM
- SVGA monitor with at least 1024 x 768 pixels
- Hard disk with at least 40 MB available memory capacity
- CD-ROM drive
- Microsoft compatible mouse
- Windows supported printer
- 1 USB port for the use of USB | X-TRA

#### Software

- MS Windows 98, ME, NT4.0, 2000, XP or VISTA

11 Index

**Numerics**

0.diSP ..... 51

**A**

Addr ..... 55

APoFF ..... 52

Auflösung, hohe bei V DC und Ohm ..... 51

Automatic Shutdown

    Disable ..... 17

    Specify Time ..... 17

Auto-Range Function ..... 18

**B**

bAtt ..... 50

Batteries

    Charge Level ..... 62

    Level Indicator ..... 13

    Periods of Non-Use ..... 62

    Replacement ..... 63

bEEP ..... 52

**C**

Cable Resistance ..... 33

Capacitance Measurement ..... 38

Clip-On Current Sensor ..... 45, 46

Continuity Test ..... 36

Current Measurement

    Notes ..... 42

**D**

dAtE ..... 50, 53

Default Settings ..... 53

Device Returns ..... 64

Diode Test ..... 37

Discharge ..... 41

Display Illumination ..... 16

**E**

Error ..... 41

Error Messages ..... 62

**F**

Fuse

    Replacement ..... 63

**I**

Interfaces

    Accessories ..... 67

    Statuses ..... 13

irStb ..... 55

itEMP ..... 50

**K**

Keying Ratio Measurement ..... 30

**M**

Maintenance

    Housing ..... 64

Manufacturer's Guarantee ..... 65

Measured Value Storage

    DATA Function ..... 22

    MIN/MAX Values ..... 23

Measurement Cables ..... 66

Measuring Category

    Significance ..... 8

Measuring Range Selection

    Automatic ..... 18

Manual ..... 18

Memory

    Clear ..... 25

    Ending Recording ..... 25

    Querying Occupancy ..... 25

    Start Recording ..... 24

**O**

OCCUP ..... 50

Overview

    Keys and Connections ..... 12

    Parameters ..... 49

**P**

Power Pack

    Accessories ..... 66

    Initial Start-Up ..... 16

Power Pack Adapter Socket

    Position of the Connector Socket ..... 15

Product Support ..... 3

Product Support Hotline ..... 3

**R**

rAtE ..... 51

Recalibration Service ..... 4, 64

Recognition of Interference Voltage ..... 41

Reference Junction ..... 35

Repair and Replacement Parts Service ..... 4

Resistance Measurement ..... 32

Resolution, high for V DC and Ohm ..... 51

RPM Measurement (function only available with customer-specific variant) ..... 31

---

<b>S</b>	
Safety Precautions .....	8
Software Enabling .....	3
Standard Equipment .....	2
Switching the Instrument On	
Manual .....	16
Via PC .....	16
Symbols	
Device .....	15
Digital Display .....	13
Rotary Switch Positions .....	14
<b>T</b>	
Temperature Measurement	
with Resistance Thermometers .....	33
with Thermocouples .....	35
tiME .....	50, 53
Training .....	3
<b>U</b>	
ur (under-range) .....	62
Use for Intended Purpose .....	10
<b>V</b>	
vErSion .....	50
Voltage Comparator .....	29
Voltage Measurement	
Notes .....	26
Voltage Measurements	
Above 1000 V .....	31
<b>W</b>	
WEEE Mark .....	15





---

Edited in Germany • Subject to change without notice • A pdf version is available on the internet

 **GOSSEN METRAWATT**

GMC-I Messtechnik GmbH  
Südwestpark 15  
90449 Nürnberg • Germany

Telefon+49 911 8602-111  
Telefax +49 911 8602-777  
E-Mail [info@gossenmetrawatt.com](mailto:info@gossenmetrawatt.com)  
[www.gossenmetrawatt.com](http://www.gossenmetrawatt.com)