

METRAHit[®] 27


METRAHit[®] 27M: Digital Multimeter and Milliohmmeter

METRAHit[®] 27I: Digital Multimeter, Milliohmmeter and Megohmmeter

3-349-207-02

1/1.03





- 1 Display (LCD)
- 2 **ON/OFF** key
Operating mode menu: open submenus / acknowledge entries METRA-Hit®271: background illumination ON / OFF
- 3 **DATA/CLEAR** key for following functions: save measured value, delete and MIN/MAX
Operating mode menu: Selection of individual menu items against direction of flow, increase values
- 4 **MAN/AUTO** key for manual measuring range selection
Operating mode menu: Selection of individual menu items in direction of flow, decrease values
- 5 **FUNC/ESC** key for selecting functions, start key INS measurement
Operating mode menu: Exit menu level and return to a higher level, exit parameters configuration without saving data
- 6 Rotary selector switch for measuring function
- 7 Connector jacks *
- 8 Connector jacks for mains power battery charger (only with rechargeable batteries inserted)

Symbols used in the Digital Display

- 1 Main display with decimal point and polarity display
- 2 Auxiliary display with decimal point and polarity display
- 3 : Multimeter in continuous operation, ON blinks at transmission frequency in transmission mode
- 4 REM: Memory mode operation, disappears after communication via the interface is ended by means of key or switch operation
- 5 ZERO: Zero balancing
- 6 MAN: Manual measuring range selection
- 7 Unit of measure (if blinking, refer to chapter 11.2 on page 15 and chapter 15 on page 23)
- 8 MIN/MAX: Display of smallest/largest recorded values with time specification
- 9 : Acoustic signal enabled, beeper is activated for corresponding function
- 10 : Low battery voltage (< 3.3 V), replace batteries

* 1 Earthing input
S- Sense -, for 4-wire connection only with $\Omega/m\Omega/m\Omega@1A$
S+ Sense +, for 4-wire connection only with $\Omega/m\Omega/m\Omega@1A$
V: Ω ; $^{\circ}C$, $M\Omega$ measurement input

Table of Contents

	Page	Page
1 Safety Features and Precautions	4	
2 Initial Start-Up	5	
3 Selecting Measuring Functions and Measuring Ranges	6	
3.1 Automatic Measuring Range Selection	6	
3.2 Manual Measuring Range Selection	6	
3.3 Quick Measurements	6	
4 Triple Digital Display	7	
5 Measured Value Storage, "DATA" Hold and Compare 7		
6 Saving Minimum and Maximum Values "MIN/MAX" with Time Stamp	8	
7 Voltage and Frequency Measurement	9	
7.1 Voltage Measurement [V]	9	
7.1.1 Zero Balancing in the 3 V DC Measuring Range	9	
7.1.2 Transient Overvoltages	9	
7.1.3 Voltage Measurements at Above 600 V	9	
7.2 Frequency Measurement [Hz]	10	
8 Resistance and Diode Measurements	10	
8.1 Resistance Measurement (2-wire connection) [Ω]	10	
8.1.1 Zero Balancing in the 300 Ω and 3 k Ω Measuring Ranges	10	
8.2 Continuity Test during Resistance Measurement	11	
8.3 Diode Measurements	11	
9 Milliohm Measurement (4-Pole-Measurement)	12	
9.1 Compensation of Cable Resistance	12	
9.1.1 Measurement with Kelvin Probe KC27	12	
9.2 Thermovoltage Compensation	12	
9.3 Milliohm Measurement with 200 mA or 20 mA DC [$m\Omega$]	13	
9.4 Milliohm Measurement with 1 A Pulsating Measuring Current [$m\Omega@1\text{ A}$] (automatic thermovoltage correction in 3 ... 300 $m\Omega$ range)	13	
10 Temperature Measurement [$^{\circ}\text{C}$]	13	
11 Insulation Resistance Measurement [$M\Omega@...V$] (METRAHit[®]271 only)	14	
11.1 Preparing for Measurement	14	
11.2 Insulation Resistance Measurement	15	
11.3 Ending the Measurement and Discharging	15	
12 Using the Menus – from the Initial InFO Menu to Operating and Measuring Parameters	16	
12.1 Sampling <i>rAtE</i>	18	
12.2 Saving Measured Values to Memory with DATA key	18	
12.2.1 InFO → MEMO/OCCUP – Querying Memory Occupancy	18	
12.2.2 MEMO → CLEAR – Clearing the Memory	18	
12.3 Activating the Default Values	18	
12.4 Transmission Mode Operation with RS 232 Interface	18	
13 Characteristic Values	19	
14 Maintenance	22	
14.1 Rechargeable Batteries and Batteries	22	
14.2 Fuses	23	
14.3 Housing	23	
15 Multimeter Messages	23	
16 Accessories	23	
17 Repair and Replacement Parts Service, DKD Calibration Lab and Rental Instrument Service 24		
18 Guarantee	24	
19 Product Support	24	

1 Safety Features and Precautions

You have selected an instrument which provides you with high levels of safety.

The METRAHit®27 is manufactured and tested in accordance with safety regulations IEC 61010-1 / DIN EN 61010-1 / VDE 0411-1. When used for its intended purpose, safety of the operator, as well as that of the instrument, is assured. Their safety is however not guaranteed, if the instrument is used improperly or handled carelessly.

In order to maintain flawless technical safety conditions, and to assure safe use, it is imperative that you read the operating instructions thoroughly and carefully before placing your instrument into service, and that you follow all instructions contained therein.

Observe the following safety precautions:

- The instrument may only be operated by persons who are capable of recognizing contact hazards and taking the appropriate safety precautions. Contact hazards exist anywhere, where voltages of greater than 33 V (RMS) may occur.
- Avoid working alone when taking measurements which involve contact hazards. Be certain that a second person is present.



Attention!

Maximum allowable voltage between any given connector jack and earth is 600 V, category II.



Attention!

Nominal system voltage may not exceed 600 V. Voltage measurements may only be performed with the selector switch set to the V \equiv or the V \sim position. If the multimeter sockets are confused with the sense sockets, the instrument may be damaged and the operator may be subjected to danger!



Attention!

Contact hazard!

Dangerous voltages at the external jacks may be looped through to the sense sockets during voltage measurement. Therefore do not touch the sense sockets.

- Be prepared for the occurrence of unexpected voltages at devices under test (e.g. defective devices). For example, capacitors may be dangerously charged.
- Make certain that the measurement cables are in flawless condition, e.g. no damage to insulation, no interruptions in cables or plugs etc.
- No measurements may be made with this instrument in electrical circuits with corona discharge (high-voltage).
- Special care is required when measurements are made in HF electrical circuits. Dangerous pulsating voltages may be present.

- Measurements under moist ambient conditions, or with an instrument with condensation moisture are not permitted.
 - Be absolutely certain that the *measuring ranges are not overloaded beyond their allowable capacities*. Limit values are listed in chapter 13 on page 19.
 - **The instrument may only be used in power installations if the electrical circuit is protected with a fuse or circuit breaker with a maximum rating of 20 A, and the nominal voltage of the installation does not exceed 600 V.**
 - Maximum allowable interference voltage between the jacks (7) and earth briefly amounts to 600 V_{RMS} in all selector switch positions in the event of an error. The fuse blows at an interference voltage value of > 3 V in the m Ω range.
 - Be prepared for the occurrence of unexpected voltages at devices under test (e.g. defective devices, after testing coil resistance at contactors etc.), for example, capacitors may be dangerously charged. In the interest of safety, always test for the absence of voltage first with the selector switch in the V \equiv and V \sim positions.
 - In order to avoid damage to the instrument when interference voltages are applied (within allowable limit values), the m Ω measuring circuit is equipped with an F1.6/1000 V fuse, which makes this measuring circuit highly resistive if excessive current should occur in the event of a fault for the duration of overloading.
 - Do not plug the mains power battery charger into the instrument if normal batteries have been installed instead of rechargeable batteries.
-



Warning!

The instrument may not be operated in explosive atmospheres, or connected to intrinsically safe electrical circuits.

Meanings of symbols on the instrument:



Warning concerning a source of danger (attention: observe documentation!)



Ground



Mains power battery charger connection for recharging storage batteries (rechargeable batteries)



Continuous, doubled or reinforced insulation

CAT II

Overvoltage category II device



CSA approval mark
in process



Indicates EC conformity

DKD calibration certificate (red label):



- Consecutive number
- German calibration service calibration laboratory
- Registration number
- Date of calibration (year - month)

Repair, Parts Replacement and Balancing

When the instrument is opened, voltage conducting parts may be exposed. The instrument must be disconnected from the measuring circuit before the performance of repairs, the replacement of parts, or balancing. If balancing, maintenance or repair of a live open instrument is required, this may only be carried out by trained personnel who are familiar with the dangers involved.

Defects and Extraordinary Strains

If it may be assumed that the instrument can no longer be operated safely, it must be removed from service and secured against unintentional use.

Safe operation can no longer be relied upon,

- If the instrument or the test probes are damaged
- If the instrument no longer functions
- After long periods of storage under unfavorable conditions (e.g. humidity, dust, or excessive temperature), see „Ambient Conditions“, page 21.

2 Initial Start-Up

Rechargeable Batteries or Batteries

Refer to chapter 14.1 regarding correct battery installation.



Warning!

The mains power battery charger may not be connected if normal batteries have been installed instead of rechargeable batteries: Danger of explosion!



Attention!

As a result of internal voltage monitoring, the instrument may respond as follows if the battery charge level is low:

- Cannot be switched on
- Shuts back down immediately
- Shuts back down immediately when a load is applied in the m Ω range

If this is the case, replace or recharge the batteries.



Attention!

The mains power battery charger may only be used to recharge the batteries!

Mains power battery chargers with an output voltage of greater than 4.2 V may not be used. The milliohmmeter's internal voltage regulator might otherwise be destroyed. No guarantee claims can be accepted if any mains power battery charger other than the NA4/500 is used (available as an accessory).

Switching the Instrument On Manually

- Press the ON/OFF key.
As long as the key is held depressed, all of the segments at the LCD are illuminated. The LCD is shown on page 2. Power-up is acknowledged with a brief acoustic signal. The instrument is ready for use as soon as the key is released.

Switching the Instrument On with a PC

After transmission of a data frame from the PC, the multimeter is switched on. See also chapter 12.4.

Switching the Instrument On Automatically

The multimeter is switched on automatically in the transmission and memory modes.



Note!

Electrical discharge and high frequency interference may cause incorrect displays to appear, and may disable the measuring sequence. In such cases, switch the instrument off and back on again in order to reset. If the problem persists, briefly dislodge the batteries from the connector contacts.

Setting Time and Date

See chapter 12 on page 16.

Switching the Instrument Off Manually

- Press and hold the ON/OFF key until OFF appears at the display.

Shutdown is acknowledged with two, brief acoustic signals.

Switching the Instrument Off Automatically – SLEEP MODE

The instrument is switched off automatically if none of the keys or the rotary switch are activated for approximately 10 minutes. Shutdown is acknowledged with a brief acoustic signal.

Transmission mode: In this case, checking is first performed to determine whether or not the sampling rate has been set to a value of greater than 10 s. The instrument is switched off after 10 minutes, but the instrument is reactivated 10 s before data is to be saved to memory. The instrument is then switched back off again.

In the transmission mode, the instrument can be manually activated with the ON/OFF key. After activation of this type, the instrument returns to the “SLEEP MODE”.

If the instrument is to be fully shut down, it must first be activated and then switched off with the ON/OFF key. This ends both memory mode and transmission mode operation.

We recommend setting the instrument to continuous operation for **transmission mode** operation.

The continuous operation mode is not effected by automatic shutdown.

Disabling Automatic Shutdown

The instrument can be set to continuous operation.

- Press and hold the FUNC key and then switch the instrument on by pressing the ON/OFF key. Continuous operation is indicated at the display with the Δ symbol.

Switching LCD Illumination On and Off (METRAHit[®]271 only)

- Briefly press the ON/OFF key (2) after the instrument has already been switched on.

Illumination is switched off automatically after approximately 2 minutes.

Note: Electrical discharge and high frequency interference may cause incorrect displays to appear, and may disable the measuring sequence. In such cases, switch the instrument off and back on again in order to reset. If the problem persists, briefly dislodge the battery from the connector contacts.

Disconnect the instrument from the measuring circuit before opening and refer to chapter 14.1, “Rechargeable Batteries and Batteries”!

3 Selecting Measuring Functions and Measuring Ranges

3.1 Automatic Measuring Range Selection

The multimeter is equipped with auto-ranging for all measuring ranges, except for temperature measurement,

and diode and continuity testing. Auto-ranging is active as soon as the multimeter is switched on. The instrument automatically selects the measuring range which allows for highest possible resolution for the applied quantity. When the instrument is switched to frequency measurement, the previously selected voltage measuring range remains active. The instrument automatically switches to the next highest or next lowest measuring range for the following measured quantities:

Measuring Ranges	Resolution	Switching to next highest range at $\pm(\dots d + 1 d)$	Switching to next lowest range at $\pm(\dots d - 1 d)$
V \sim , V $\overline{\sim}$, Hz, Ω , m Ω , 30 / 300 m Ω at 1 A	4%	31,000	2800
3 m Ω @1A, M Ω @...V	3%	3100	280

3.2 Manual Measuring Range Selection

Auto-ranging can be deactivated and measuring ranges can be selected manually in accordance with the following table.

The manual mode is deactivated by pressing and holding the MAN/AUTO key (approx. 1 s), by activating the rotary switch, or by switching the instrument off and then back on again.

\downarrow MAN/ AUTO	Function	Acknowledgement	
		Dis-play	Acoust. Signal
short	Manual mode active: utilized measuring range is fixed	MAN	1 x
short	Range switching sequence for: V: 3 V \rightarrow 30 V \rightarrow 300 V \rightarrow 600 V \rightarrow 3 V \rightarrow ... Hz: 300 Hz \rightarrow 3 kHz \rightarrow 300 Hz \rightarrow ... Ω : 30 M Ω \rightarrow 300 Ω \rightarrow 3 k Ω \rightarrow 30 k Ω \rightarrow 300k Ω \rightarrow 3 M Ω \rightarrow ... m Ω : 30 m Ω \rightarrow 300 m Ω \rightarrow 3 Ω \rightarrow 30 Ω \rightarrow 30 m Ω \rightarrow ... m Ω @1A: 3 m Ω \rightarrow 30 m Ω \rightarrow 300 m Ω \rightarrow 3 m Ω \rightarrow ...	MAN	1 x
long	Return to automatic range selection	—	2 x

Automatic range selection is disabled as long as the MIN/MAX function is active.

3.3 Quick Measurements

If you wish to perform quicker measurements than those possible with the automatic measuring range selection function, make sure to establish the appropriate measuring range:

- by **manual measuring range selection**, i. e. by selecting the measuring range with the best resolution, see chapter 3.2.

or

- via **DATA function**, see chapter 5. After the first measurement, the proper measuring range will be automatically determined so that measurements are performed more rapidly from the second measured value onwards.


With both functions, the established measuring range is maintained for the subsequent series mode measurements.

4 Triple Digital Display

The three digital displays (1 main display and 2 auxiliary displays) show the measured value with decimal and plus or minus sign. The selected unit of measure is displayed as well. A minus sign appears to the left of the value during the measurement of zero-frequency quantities, if the plus pole of the measured quantity is applied to the “+” input.

“OL” (overload) appears if the measuring range upper limit is exceeded for the following measured quantities:
 V AC, V DC, Hz, Ω , \rightarrow , m Ω , 30 / 300 m Ω at 1 A: 30999
 3 m Ω at 1 A, \rightarrow , M Ω @...V: 3099

The digital display is refreshed at different frequencies for the various measured quantities.



The main display appears immediately after the multimeter is switched on, but the auxiliary displays have to be activated by pressing the DATA/CLEAR key (except for position M Ω @...V, where the auxiliary displays appear immediately upon selecting the function).

This assures that any undefined existing condition which prevailed when measurement was started is not continuously displayed as a maximum value, e.g. no-load operation.


In the following flowcharts, the initial displays are highlighted through the use of a bold border line.

5 Measured Value Storage, “DATA” Hold and Compare

Measured values can be automatically “frozen” with the DATA hold function. This is useful when, for example, contacting the measuring points with the test probes requires your full attention.

After the measured value has been applied and the corresponding “condition” from the table below has been fulfilled, the measured value appears at the left-hand auxiliary display and 2 acoustic signals are generated. At the same time, “MAN” appears, indicating that the measuring range can now be manually adjusted. The test probes can now be removed from the measuring points, and the measured value can be read from the auxiliary display. If the measured value is less than the value specified in the table, the instrument is reactivated for storage of the next value and “dAtA” blinks at

the display. The measured value is saved to non-volatile memory.



If the next measured value stored to memory deviates from the first by less than 0.33% of the measuring range, two acoustic signals are generated (DATA Compare).

Function DATA	↓ DATA	Condition		Response from Instrument		
		Measuring Ranges	Measured Value Limits (digits)	Auxiliary Display MV	dAtA	Acoustic Signal
Activation	short				is displayed	short
Save		V Ω \rightarrow Hz	> 10% of R OL ³⁾ > 10% ³⁾ of R	is displayed	is displayed	short 2x ²⁾
Reactivate ¹⁾		V Ω \rightarrow M Ω , Hz	< 10% of R OL ³⁾ < 10% ³⁾ of R	stored MV	blinks	
Stop	short			is deleted		short
Turn back on	long short					

- 1) Reactivation results from falling short of specified measured value limits.
- 2) Two acoustic signals are generated the first time a measured value is saved. For subsequent data hold, two acoustic signals are only generated if the currently frozen value deviates from the first saved value by less than 0.33% of the measuring range, depending upon resolution.

Key

R = measuring range, MV = measured value

The DATA function is deactivated by pressing and holding the DATA key once again, by turning the rotary switch, or by switching the instrument off and back on again.

6 Saving Minimum and Maximum Values “MIN/MAX” with Time Stamp

Minimum and maximum values can be displayed at the auxiliary displays for long-term observation of measured quantities.

- Press the DATA key twice: Current MIN and MAX values appear at the auxiliary displays.

Automatic range selection is disabled as long as the MIN/MAX function is active.

- Press the DATA key once again for a display of the minimum value and the time of its occurrence.
- Press the DATA key once again for a display of the maximum value and the time of its occurrence.


The MIN and MAX values are deleted by pressing and holding the CLEAR key (approx. 1 s), by turning the rotary switch, or by switching the instrument off and back on again.

Function MIN/MAX	↓ DATA	MIN and MAX Measured Values / Time of Measurement	Response from Instrument		
			Main Display	Aux. Display	Acoustic Signal
1. Save	2 x short ↓ ↓	are saved	Current measured value	MIN and MAX	1 x
2. Save and Display	short ↓	are saved		t and MIN	1 x
	short ↓		t and MAX	1 x	
3. Return to 1	short ↓	are saved	same as 1	same as 1	1 x
Stop	long ↓	are deleted	is deleted	is deleted	2 x




Note!

No new MIN/MAX values are calculated for a period of 2 to 4 seconds after the measuring range has been changed (depending upon measuring function), in order to allow measured values to settle in.



7 Voltage and Frequency Measurement



7.1 Voltage Measurement [V]

- Select voltage type $V \equiv$ or $V \sim / \text{Hz}$ with the rotary selector switch as appropriate for the measured quantity.
- Connect the measurement cables as shown. The “⊥” connector jack should be grounded.
- **The $V \sim / \text{Hz}$ selector switch position:** Each time the FUNC key is pressed, voltage and frequency measurement are alternately selected, and switching is acknowledged with an acoustic signal. The respective measured quantity is displayed at the LCD.


Note!

An intermittent acoustic signal warns the operator if the measured value exceeds the upper range limit in the 600 V range.

Attention!

Make sure that a current measuring function (Ω , $m\Omega$, $M\Omega$) or a C measuring function ($^\circ$) has not been selected when the multimeter is connected for voltage measurement!

If fuse blowing limits are exceeded as a result of operator error, both the operator and the instrument are in danger!



7.1.1 Zero Balancing in the 3 V DC Measuring Range

- Select the 3 V \equiv measuring range.
- Plug the measuring cables into the instrument and connect the free ends to each other.
- Press the FUNC key.

The instrument acknowledges zero balancing with an acoustic signal, and „0.0000 V“ and the “ZERO” symbol appear at the display. The voltage value measured at the moment the key is pressed serves as a reference value (2000 digits). It is automatically subtracted from all subsequent measured values. If the measuring range is changed (MAN key), the ZERO function only remains active (at the display and in memory) for the selected measuring range.


- Zero balancing can be deleted:
 - By once again pressing and holding the FUNC key, which is acknowledged with two acoustic signals
 - By switching the instrument off

7.1.2 Transient Overvoltages

The multimeter is protected against transient overvoltages of up to 4 kV with rise times of 1.2, and halftimes of 50 μs . For measurements at transformers or motors with long pulse durations etc., we recommend the use of our KS30 measuring adapter. It provides protection against transient overvoltages of up to 6 kV with rise times of 10, and halftimes of 1000 μs . It has a continuous load capacity of 1200 V_{RMS} . Additional influence error caused by the KS30 measuring adapter amounts to approximately -2%.

7.1.3 Voltage Measurements at Above 600 V

Voltages of greater than 600 V can be measured with a high-voltage probe, e.g. the HV3¹⁾ or the HV30²⁾ from GOSSEN METRAWATT GMBH. It is absolutely essential to ground the bonding terminal. Observe all applicable safety precautions!



¹⁾ HV3: 3 kV

²⁾ HV30: 30 kV, for direct voltage only


7.2 Frequency Measurement [Hz]

- ⇨ Select the V~/Hz measuring function with the rotary selector switch.
- ⇨ Apply the measured quantity as described under voltage measurement.
- ⇨ Briefly press the FUNC key in order to measure frequency. The frequency values appears at the main display. The frequency measuring range can be selected subsequently by pressing MAN/AUTO. The previously selected voltage measuring range remains active.
- ⇨ The instrument can be switched from frequency measurement back to alternating voltage measurement by pressing the FUNC key once again. This selection is acknowledged with an acoustic signal.

Note!

Frequency measurement is only possible if the measuring signal passes through zero (AC coupling).

8 Resistance and Diode Measurements



8.1 Resistance Measurement (2-wire connection) [Ω]


- ⇨ Make sure that the device under test is voltage-free (see chapter 7.1). Interference voltages distort measurement results and damage the instrument!
- ⇨ Set the rotary selector switch to “Ω”.
- ⇨ Connect the device under test as shown.



Note!

High Impedance Measurements in the 3 MΩ/30 MΩ Range

In the event of extremely high resistances the capacitive influence of the person performing the measurement and/or the measuring cable may distort the measured value. Use therefore short or shielded measurement cables.



8.1.1 Zero Balancing in the 300 Ω and 3 kΩ Measuring Ranges

Cable and contact resistances can be eliminated for the measurement of small resistance values in the 300 Ω and 3 kΩ ranges by means of zero balancing:

- ⇨ Plug the measuring cables into the instrument and connect the free ends to each other.
- ⇨ Press the FUNC key.

The instrument acknowledges zero balancing with an acoustic signal, and „000.00 Ω“ or „0.0000 kΩ“ and the “ZERO” symbol appear at the display. The resistance value measured at the moment the key is pressed serves as a reference value (max. 20 Ω, or 200 Ω, or 2000 digits). It is automatically subtracted from all subsequent measured values. If the measuring range is changed (MAN key), the ZERO function remains active (at the display and in memory).

- ⇨ Zero balancing can be deleted:
 - By once again pressing and holding the FUNC key, which is acknowledged with two acoustic signals,
 - By switching the instrument off.

8.2 Continuity Test during Resistance Measurement $\text{m}\Omega$

If the "acoustic signal $\text{m}\Omega$ " function is activated and the 0 ... 310 Ω measuring range is selected, a continuous acoustic signal is generated by the instrument within a range of 0 to approx. 10 Ω .


Overflow ".OL" is displayed where $R_d > 310 \Omega$.

Activating and Deactivating Continuity Testing (acoustic signal)

- Set the rotary selector switch to „ $\Omega/\rightarrow/\text{m}\Omega$ “.
- Repeatedly press the FUNC key until $\text{m}\Omega$ and "Short" appear at the display, provided the connector jacks are open (Display OL).
- Connect the measurement cables to the device under test.
- The instrument is switched to resistance measurement by pressing the FUNC key once again.

8.3 Diode Measurements \rightarrow

- Make sure that the device under test is voltage-free (see chapter 7.1). Interference voltages distort measurement results!
- Set the rotary selector switch to „ $\Omega/\rightarrow/\text{m}\Omega$ “.
- Briefly press the FUNC key for diode measurement. Unit of measure "V" and "d, $\text{m}\Omega$ " are then displayed if the connector jacks are open (Display OL).
- Connect the device under test as shown.



Conducting Direction and Short-Circuit

The instrument displays conducting-state voltage in volts. As long as voltage drop does not exceed the maximum display value of 3 V, several series connected components or reference diodes can be tested.

Reverse Direction or Interruption

Overload (.OL) is displayed at the instrument for diode measurements where $U_d > 3.1 \text{ V}$. Measuring current is always a constant current of approximately 1 mA.



Note!

Resistors and semiconductors which are connected in parallel to the diode distort measurement results!

9 Milliohm Measurement (4-Pole-Measurement)


9.1 Compensation of Cable Resistance

Electrical resistance is a dipole quantity which can generally only be measured using two poles. This is accomplished by directing a measuring current of predetermined magnitude through the device under test, and measuring the resultant voltage drop. The respective resistance value is derived from the quotient of these two values.

The two points between which voltage is measured are decisive as regards the results of the measurement. All resistances between these two points add to the measured resistance value. These include contact resistance, as well as cable resistance. If a very low resistance value needs to be measured, for example contact resistance at a contactor with a value of only a few milliohms, the points between which voltage is measured must be moved out of the measuring instrument and positioned as closely as possible to the device under test. For this reason, the measuring instrument is equipped with separate jacks for current feed and voltage measurement. This type of 4-pole connection is known as connection according to Kelvin.



KC4 Kelvin clips and KC27 Kelvin probes (available as accessories) allow for easy, correct connection.

9.1.1 Measurement with Kelvin Probe KC27



9.2 Thermovoltage Compensation

Thermovoltages which occur as a result of material and temperature differences may distort measurement results. For this reason, the instrument is equipped with automatic thermovoltage compensation in the relevant measuring ranges.



9.3 Milliohm Measurement with 200 mA or 20 mA DC [mΩ]

- Make sure that the device under test is voltage-free (see chapter 7.1). Interference voltages distort measurement results!
- Set the rotary selector switch to “mΩ”.
- Connect the device under test as shown. KC4 Kelvin clips and KC27 Kelvin probes (available as accessories) allow for easy, correct connection. Resistance at the current jacks should amount to < 1 Ω.
- If applicable, select the desired measuring range using the MAN key: **30 mΩ, 300 mΩ, 3 Ω or 30 Ω**.

This measuring method is suitable for resistances with inductances of up to 1 H.

Thermovoltage Correction in the 30/300 mΩ Range

- Press the FUNC key in order to measure thermovoltage. Wait until the measured value has settled in. This may take several seconds, depending upon inductivity. Then press the FUNC key once again in order to return to the milliohm measuring function. All future measurement result will be corrected based upon the previously measured thermovoltage value. ZERO appears at the display in order to indicate active compensation.

Measurements at Inductive Devices

Coils in motors, choke ballasts and contactors are highly inductive. Changes in current at inductive devices, including switching the milliohmmeter on and off or changing the measuring range, result in a corresponding voltage change. These changes may be of significant magnitude, and may result in arcing under unfavorable conditions. The milliohmmeter is protected against arcing by means of suitable voltage arrestors.

9.4 Milliohm Measurement with 1 A Pulsating Measuring Current [mΩ@1 A] (automatic thermovoltage correction in 3 ... 300 mΩ range)

- Make sure that the device under test is voltage-free (see chapter 7.1). Interference voltages distort measurement results!
- Set the rotary selector switch to “mΩ@1A”.
- Connect the device under test as shown. KC4 Kelvin clips and KC27 Kelvin probes (available as accessories) allow for easy, correct connection. Resistance at the current jacks should amount to < 0.2 Ω.
- If applicable, select the desired measuring range using the MAN key: **3 mΩ, (30 mΩ or 300 mΩ)**


Thermovoltage is compensated automatically.

Note!

Due to high current consumption during this measurement, rechargeable NiMH batteries should be installed **and** the NA4/500 mains power battery charger should be used.

10 Temperature Measurement [°C]

Resistance thermometers (available as accessories) are used for temperature measurement. A 2-pole measurement is utilized. Cable resistance is set to 0.1 Ω as a default value.




Selecting Temperature Unit of Measure and Sensor Type

- Set the rotary selector switch to “°C”. Press Esc to access the selection menu for temperature unit of measure and sensor type. *SEnSr* and *SELct* are displayed.
- Press the FUNC key to select the desired temperature unit of measure: °C or °F.
- Select the sensor type (RTD) with the ↓↑ keys.
- Connect the sensor to the two jacks (see diagram).

Note!

The selected temperature unit of measure and sensor type remain unchanged after exiting the function, and when the instrument is switched off.



Adjusting Cable Resistance


- ⇨ After selecting a resistance thermometer, the measurement display is accessed by pressing the → key.
- ⇨ The menu for cable resistance adjustment is opened by simultaneously pressing the ← and ↓ keys. *PLEAD* and *LEFP* are displayed.
- ⇨ The decade (i.e. the position of the digit to be changed) is selected with the ← → keys, and the respective digit is set with the ↓ ↑ keys.
- ⇨ The menu is exited upon acknowledging the last digit by pressing the → key, whereupon the measuring display returns. The cable resistance value remains in memory. The default value is 0.1 Ω. Entry is limited to a range of 0 to 50 Ω.



Note!

The selected cable resistance value remains unchanged after exiting the function, and when the instrument is switched off.

11 Insulation Resistance Measurement [MΩ@...V] (METRAHit® 271 only)



11.1 Preparing for Measurement



Note!

High-resistance measurements

In the event of extremely high resistances the capacitive influence of the person performing the measurement and/or the measuring cable may distort the measured value. Use therefore short or shielded measurement cables.

The measurement cables may not come into contact with one another during high-resistance insulation measurements.

- ⇨ Set the rotary selector switch to “MΩ@50V”, “100V”, “250V” or “500V”, depending upon the desired test voltage.
- ⇨ Connect the DUT as shown on the next page.



Note!

Interference voltage

The rotary selector switch may only be set to MΩ@...V for insulation resistance measurement (not for voltage measurement).

However, if interference voltage is inadvertently applied with the switch in this position, it is displayed at the bottom left. Insulation resistances may only be measured on voltage-free objects.


If an interference voltage of > 50 V is present, insulation resistance measurement is disabled. The LCD continues to display the interference voltage value. If a voltage of greater than 610 V is present, an acoustic signal is generated as well.



Note!

Testing the Measurement Cables

Initial testing should be performed by short-circuiting the measurement cables using their test probes. The instrument must display nearly 0 Ω . A broken measurement cable can be detected in this way.



Attention!

Do **not** touch the conductive ends of the test probes when the instrument has been activated for the measurement of insulation resistance.

You may otherwise be exposed to a current of 1.5 mA (limited in the measuring instrument), and although this is not life endangering, the resulting electrical shock is quite discernible.

If, on the other hand, measurement is being performed on a capacitive device under test, for example a cable, it may be charged to approximately ± 600 V, depending upon the selected nominal voltage.

Touching the device under test after measurement has been performed may be life endangering in this case!

11.2 Insulation Resistance Measurement

- Press and hold the FUNC key until the display settles in, in order to measure insulation resistance.



Attention!

The selected and displayed test voltage blinks during measurement.

Attention: Contact hazard!

Current voltage at the device under test appears at the interference or residual voltage display during measurement. This value is slightly less than nominal voltage.

Insulation resistance measurement is ended by releasing the FUNC key. The last measured insulation resistance value R_{ISO} is retained at the display.

Auto-ranging is active during insulation resistance measurement. Manual measuring range selection is not possible.



Note!

The instrument's batteries are rapidly depleted during insulation resistance measurement. Only hold the multifunction key depressed as long as is actually necessary. The continuous measurement described below should only be performed if absolutely necessary.

Use NiMH batteries only.

Continuous Measurement

- Activation: Briefly press the yellow multifunction key and the AUTO/MAN key simultaneously. This is acknowledged with an acoustic signal.
- Deactivation: Briefly press the yellow multifunction key.

11.3 Ending the Measurement and Discharging

After measurement has been completed, any remaining residual voltage is displayed which may result from cable capacitance. These charges are quickly dispersed by means of two internal resistors with a value of 2 M Ω . However, contact to the device under test must be maintained. The falling voltage value can be observed at the interference or residual voltage display.

Do not disconnect the device under test until the voltage value has dropped to below 25 V!

12 Using the Menus – from the Initial InFO Menu to Operating and Measuring Parameters


Menu-driven operation via the initial „InFO“ menu allows the user to query online help, activate the memory and query memory occupancy, activate the interface and configure device parameters.

- The initial „InFO“ menu is accessed by simultaneously pressing and holding the FUNC and ON keys with the instrument switched on, until „InFO“ appears at the display.
- The display can be switched from the main „InFO“ menu to the other main menus including „nENd“, „SEnd“ and „SEt“, and then back to the „InFO“ menu, by repeatedly pressing the ↓↑ keys.
- After accessing the desired main menu, the associated submenus are opened by activating the → key.

- The desired parameter is selected by repeatedly pressing the ↓↑ keys.
- Acknowledge with the → key in order to change the corresponding parameter or parameters.
- After the desired digit has been selected with the ←→ keys and the value has been adjusted with the ↓↑ keys, the next digit is accessed with the → key, or the display is returned to the start menu or switched to the next submenu.
- The measuring mode is started by repeatedly pressing the ESC key until the measuring display appears.
- The multimeter is switched off by pressing and holding the ON/OFF key until the display goes blank.


The following pages include an overview of the menu structure.

Main Menus and Submenus




Continued from previous page

Set Sampling Rate (see also chapter 12.1)



Possible Settings
 (hh:mm:ss, h = hours, m = minutes, s = seconds)
 00:00:01, 00:00:02, 00:00:05, 00:00:10, 00:00:20, 00:01:00
 00:02:00, 00:05:00, 00:10:00, 00:20:00, 01:00:00; 0.50 = 500 ms

Set Time




Possible Settings (hh:mm:ss, hh=hours, mm=minutes, ss=seconds)

Set Date



Possible Settings (DD:MM:YY, DD=day, MM=month, YY=year)

Set Device Address



Possible Settings (see also chapter 12.4): 0 ... 15

12.1 Sampling rate

The sampling rate specifies the time interval after which the respective measured value is transmitted to the interface or to measured value memory.

Certain sampling rate limit values apply to various measured quantities, and these may not be exceeded (see table below).

Measured Quantity	Sampling Rate
V	0.5 s
V	0.5 s
m Ω , Ω , °C (Pt100, Pt1000)	0.5 s
Hz	1 s
m Ω @1A	1.5 s

12.2 Saving Measured Values to Memory with DATA key

The instrument is equipped with a measured value memory (32 kB) which is synchronized with a quartz movement, and has an average capacity of 1000 measured values. Minimum capacity is 800 measured values and maximum capacity is 1200 measured values.

Data are stored and can be transmitted directly to a PC with the METRAWin[®]10 software. Date and time must be reset if the batteries are depleted and/or replaced.

Measured values are stored in so-called blocks. Measured values resulting from the same measuring function are saved to the same block.

Only absolute values and absolute time stamps can be saved, i.e. no relative or Δ values, and no relative time stamps.

Memory content can only be read out with the help of a PC, an IR adapter (BD232), and METRAWin[®]10 analysis software. Stored measurement data blocks are retained even if the instrument is without voltage supply.

Preparing for Memory Mode Operation

- ↻ First select the desired measuring function and an appropriate measuring range.
- ↻ Check the battery charge level before starting long-term measurement recordings (see chapter 14.1 on page 22). Connect the mains power battery charger if applicable.

12.2.1 INFO → MEMO/OCCUP – Querying Memory Occupancy

Memory occupancy can be queried from the „*Info*“ menu. The main display shows current occupancy as a percentage between 001 and 100%

12.2.2 MEMO → CLEAR – Clearing the Memory



Attention!

This function deletes all measured values from memory.

12.3 Activating the Default Values

Previously entered changes can be undone, and the default settings can be reactivated. This may be advisable after the occurrence of software or hardware errors.

- ↻ Simultaneously press and hold the FUNC, MAN and DATA keys, and switch the instrument on with the ON key.

12.4 Transmission Mode Operation with RS 232 Interface

The METRAWin[®]27 is equipped with a bidirectional infrared interface for the transmission of measurement data to a PC. Data are transferred optically through the instrument housing by means of infrared light to an interface adapter (accessory BD232), which is attached to the instrument. The adapter's RS 232 interface allows for the establishment of a connection to the PC via an interface cable. Beyond this, commands and parameters can be transmitted from the PC to the instrument as well. The following functions can be executed:

- Configuration and read-out of measuring parameters
- Measuring function and measuring range selection
- Start measurements
- Read out measured values

Activating the Interface

The interface is switched on manually as described below for transmission mode operation. The instrument continuously transmits measurement data to the PC via the interface adapter in this operating mode. The interface is activated automatically by the PC for receiving operation (i.e. the instrument receives data from the PC).

Starting Transmission with Menu Functions

Info ↓ SEnd → StArt →

The symbol blinks at the display in order to indicate interface operation.

Automatic Activation and Deactivation of the Transmission Mode

If the sampling rate is 20 s or longer, the display is switched off automatically between samples in order to prolong battery service life.

Exception: continuous operation

As soon as an event occurs, the display is automatically switched back on.

Configuring Interface Parameters

Addr – Address

If several instruments are connected to the PC via interface adapters, a unique address must be assigned to each device. Address 1 should be used for the first device, address 2 for the second etc. If only one multimeter is utilized, an address between 1 and 14 should be used. Address 15 is not used for addressing, i.e. the device with address 15 always responds, regardless of the actual address.

13 Characteristic Values

Measuring Function	Measuring Range	Resolution at Upper Range Limit 4¾ 30000 / 3¾ 3000 ¹⁾	Input Impedance		Intrinsic Error at Max. Resolution under Reference Conditions ±(...% rdg. + ... d)		Overload Capacity ³⁾	
			DC	AC ⁶⁾	DC	AC ⁶⁾	Value	Time
V	3 V	100 µV	2.1 MΩ	2.1 MΩ // < 50 pF	0.1 + 10 ⁴⁾	0.2 + 10 (>500d)	600 V DC AC RMS sine	Cont.
	30 V	1 mV	2.1 MΩ	2.1 MΩ // < 50 pF	0.1 + 5	0.2 + 10 (>500d)		
	300 V	10 mV	2.1 MΩ	2.1 MΩ // < 50 pF	0.1 + 5	0.2 + 10 (>500d)		
	600 V	100 mV	2.1 MΩ	2.1 MΩ // < 50 pF	0.1 + 5	0.2 + 10 (>500d)		
			Open-circuit voltage	Meas. current approx.	±(...% rdg. + ... d)			
mΩ@1A (4 L)	3 mΩ	0.001 mΩ	3.5 ... 4 V	1 A ⁷⁾	1 + 10		±0.6 V	Cont.
	30 mΩ	0.001 mΩ	3.5 ... 4 V	1 A ⁷⁾	0.5 + 10			
	300 mΩ	0.01 mΩ	3.5 ... 4 V	1 A ⁷⁾	0.5 + 10			
mΩ (4 L)	30 mΩ	0.01 mΩ	3.5 ... 4 V	200 mA	0.25 + 10		±0.6 V	Cont.
	300 mΩ	0.01 mΩ	3.5 ... 4 V	200 mA				
	3 Ω	0.1 mΩ	3.5 ... 4 V	20 mA				
	30 Ω	1 mΩ	3.5 ... 4 V	20 mA				
Ω (2 L)	300 Ω	10 mΩ	3.5 ... 4 V	1 mA	0.1 + 10 ⁴⁾		600 V DC AC RMS sine	max. 10 s
	3 kΩ	100 mΩ	3.5 ... 4 V	100 µA	0.1 + 5 ⁴⁾			
	30 kΩ	1 Ω	3.5 ... 4 V	20 µA	0.1 + 5			
	300 kΩ	10 Ω	3.5 ... 4 V	20 µA	0.1 + 5			
	3 MΩ	100 Ω	3.5 ... 4 V	10 µA	0.1 + 5			
	30 MΩ	1 kΩ	3.5 ... 4 V	10 µA	1.5 + 10			
⚡)	300 Ω	0.1 Ω	3 V	1 mA	1 + 5			
→	3 V	0.1 mV	3 V	1 mA	1 + 5			
			Test Voltage	Measuring Current				
MΩ@ ...V	30 MΩ	0.01 MΩ	50/100/250/500 V	< 1.5 mA	2 + 10		600 V DC/AC	max. 10 s
	300 MΩ	0.1 MΩ	50/100/250/500 V		2 + 10			
	3000MΩ ¹⁰⁾	1 MΩ	50/100/250/500 V		3 + 10			
			f_{min} ²⁾	±(...% rdg. + ... d)				
Hz	300 Hz	0.01 Hz	1 Hz	0.05 + 5 ⁵⁾		600 V AC	Cont.	
	3 kHz	0.1 Hz						
	Temperature Sensor	Measuring Range	Resolution	Intrinsic Error at Max. Resolution under Reference Conditions ±(...% rdg. + ... d)⁸⁾				
°C/°F	Pt 100 ⁹⁾	-200.0 ... +100.0 °C	0.1 °K	1 K + 5		600 V DC AC RMS sine	max. 10 s	
		+100.0 ... +600.0 °C		0.5 + 5				
	Pt 1000	-200.0 ... +100.0 °C		1 K + 5				
		+100.0 ... +600.0 °C		0.5 + 5				
	Ni 100	-60.0 ... +180.0 °C		0.5 + 5				
Ni 1000	-60.0 ... +180.0 °C	0.5 + 5						

1) Display: 3¾ places in the range of 3 mΩ@1A, 30 mΩ, ⚡), MΩ@...V;
A different sampling rate can be selected in the rAtE menu for saving and transmitting measured values.

2) Lowest measurable frequency for sinusoidal measuring signals symmetrical to the zero point

3) At 0° ... + 40° C

4) ZERO is displayed for "zero balancing" function.

5) Range 3V-: U_E = 0.15V_{eff/rms} ... 3V_{eff/rms}
30V-: U_E = 1.5V_{eff/rms} ... 30V_{eff/rms}
300V-: U_E = 15V_{eff/rms} ... 300V_{eff/rms}
600V-: U_E = 30V_{eff/rms} ... 600V_{eff/rms}

For voltages > 100 V: power limiting of 1.8 · 10⁶ V · Hz

6) 20 ... 45 ... 65 Hz ... 1 kHz sine, see influences on page 20.

7) Pulsating measuring current with interval of T = 1 s

8) Plus sensor deviation

9) Temperature value is calculated from the characteristic curve per EN 60751
10) In the event of extremely high resistances the capacitive influence of the person performing the measurement and/or the measuring cable may distort the measured value.

Use therefore short or shielded measurement cables.

Key

rdg. = reading (measured value), R = measuring range, d = digit(s), 2/4 L = 2/4-wire connection

Influencing Quantities and Influence Error

Influencing Quantity	Sphere of Influence	Measured Quantity / Measuring Range ¹⁾	Influence Error $\pm (... \% \text{ rdg.} + d)/10 \text{ K}$
Temperature	0 ... +21 °C and +25... +40 °C	V DC	0.1 + 5
		V AC	0.5 + 5
		mΩ@ 1 A 4L	1 + 5
		mΩ@ 200 mA 4L	1 + 5
		300 Ω ... 300 kΩ 2L	0.2 + 5
		3 MΩ 2L	0.5 + 5
		30 MΩ 2L	1 + 5
		Insulation, 30 MΩ ... 3 GΩ	2 + 5
	Hz	0.1 + 5	
°C (RTD)	0.5 + 10		

¹⁾ With zero balancing

Influencing Quantity	Frequency	Measured Quantity / Measuring Range	Influence Error ²⁾ $\pm (... \% \text{ rdg.} + d)$
Frequency V_{AC}	> 20 Hz ... 45 Hz	3 V up to 600.0 V	2 + 10
	> 65 Hz ... 1 kHz		

²⁾ Specified error valid as of display values of 10% of the measuring range

Influencing Quantity	Sphere of Influence	Measured Quantity / Measuring Range ¹⁾	Influence Error
Relative humidity	75% 3 days instrument off	All measured quantities	1 x intrinsic error

¹⁾ With zero balancing

Influencing Quantity	Sphere of Influence	Measuring Range	Damping $\pm \text{dB}$
Common Mode Interference Voltage	Interference quantity max. 600 V ~ 50 Hz, 60 Hz sine	V DC	> 90 dB
		30 V ~	> 80 dB
		300 V ~ 600 V ~	> 70 dB > 60 dB
Series Mode Interference Voltage	Interference quantity: V~, respective nominal value of the measuring range, max. 600 V ~, 50 Hz, 60 Hz sine	V =	> 60 dB
		V ~	> 60 dB

Real-Time Clock

Accuracy	± 1 minute per month
Temperature Influence	50 ppm/K

Reference Conditions

Ambient temperature	+23° C \pm 2 K
Relative humidity,	40 ... 60%
Measured quantity frequency	45 ... 65 Hz
Measured quantity waveshape	Sinusoidal, deviation between RMS and rectified value < 0.1%
Battery voltage	3.6 V \pm 0.2 V

Response Time

Response Time (after manual range selection)

Measured Quantity / Measuring Range	Response Time for Digital Display	Measured Quantity Step Function
V DC, V AC	1.5 s	from 0 to 80% of upper range limit value
mΩ@ 1 A 4L	2 s	from ∞ to 50% of upper range limit value
mΩ	1.5 s	
300 Ω ... 3 MΩ	2 s	
3 GΩ *	5 s	
↔) Continuity	< 50 ms	
→←	1.5 s	
°C Pt100	max. 3 s	
> 10 Hz	1.5 s	from 0 to 50% of upper range limit value

* without parallel capacity

Display

LCD panel (65 mm x 30 mm) with display of up to 3 measured values, unit of measure, type of current and various special functions.

Display / Char. Height	7-segment characters Main display: 12 mm Auxiliary displays: 7 mm
Number of places	4¾ places \cong 30999 steps
Overflow display	„0.L“ appears
Polarity display	“-” sign is displayed if plus pole is connected to “1”

LCD test
All display segments available during operation of the METRAHit[®]27 are activated after the instrument is switched on.

Background illumination METRAHit[®]271 only

Power Supply

Rechargeable batteries	METRAHit®271 (standard): 3 ea. 1.2 V/1600 mAh NiMH batteries (AA size)
Batteries	METRAHit®27M: 3 ea. 1.5 V mignon, IEC LR6 (AA)
Service life with set of 1600 mAh NiMH batteries	

Measuring Function	Current [mA] / 3.6 V	Service Life [h]
V, Hz, Ω , \rightarrow , °C	70	20
m Ω @1A	700	2
m Ω @200mA	260	5.4
m Ω @20mA	85	16.5
M Ω @ ... V / 1 M Ω	100	15
Standby (MEM + clock)	0.15	6 months

Additional consumption for:

Interface operation	0.5 mA
LCD illumination	25 mA at 3.6 V If voltage drops below 2.7 V, the instrument is switched off automatically.
Battery test	" \rightarrow " is displayed automatically if battery voltage drops to below approx. 3.3 V (at m Ω @1A < 3.1 V).
Battery charging	With NA4/500 mains power battery charger (Set of batteries 1600 mAh: recharging time 14 h)

Fuses

Fusible links for all m Ω measuring ranges	FF (UR) 1.6 A/1000 V AC/DC, 6.3 mm x 32 mm; 10 kA switching capacity at 1000 V AC/DC and ohmic load
Acoustic signal	For display > 610 V in 600 V range (intermittent tone, 250 ms on/off)

Electrical Safety

Safety class	II per IEC 61010-1/EN 61010-1 /VDE 0411-1
Overvoltage category	II
Operating voltage	600 V
Fouling factor	2
Test voltage	3.5 kV~ per IEC 61010-1/EN 61010-1/VDE 0411-1

Electromagnetic Compatibility (EMC)

Interference emission	EN 61326: 2002 class B
Interference immunity	EN 61326: 2002 IEC 61000-4-2: 1995/A1: 1998 Feature A: 8 kV atmospheric discharge 4 kV contact discharge IEC 61000-4-3: 1995/A1: 1998 Feature B: 3 V/m

Data Interface

With BD232 interface adapter as accessory

Data transmission	Optical via infrared light through the housing
Type	RS 232C, serial, per DIN 19241
Bidirectional baud rate (read and write)	SI232-II: all baud rates BD232: 9600 baud

Ambient Conditions

Accuracy range	0° C ... +40° C
Operating temperature	-10° C ... +50° C
Storage temperature	-25° C ... +70° C (w/o batteries)
Relative humidity	45% ... 75%, no condensation allowed
Elevation	to 2000 m
Deployment	Indoors only, except within specified ambient conditions

Mechanical Design

Protection	Housing: IP 54, Connector jacks: IP 20
Dimensions	84 mm x 195 mm x 35 mm
Weight	Approx. 420 gr. with batteries (without GH18 protective rubber cover)

14 Maintenance



Attention!

Disconnect the instrument from the measuring circuit before opening to replace batteries or fuses!

14.1 Rechargeable Batteries and Batteries



Warning!

The mains power battery charger may not be connected if normal batteries have been installed instead of rechargeable batteries: Danger of explosion!

Removing the Batteries During Periods of Non-Use

The integrated quartz clock draws power from the batteries, even when the instrument is switched off. It is advisable to remove the batteries during long periods of non-use for this reason (e.g. vacation). This prevents excessive depletion of the batteries, which may result in damage under unfavorable conditions.

Checking Battery Charge-Level and Condition

The current battery charge level can be queried in the "Info" menu (see chapter 12 on page 16):
Func + 0n ↓ ↑ InF0 → X.X V (bAtt).

Make sure that no battery leakage has occurred before initial start-up, and after long periods of storage. Continue to inspect the batteries for leakage at short, regular intervals.

- If **battery leakage has occurred**, carefully and completely clean electrolyte from the instrument with a damp cloth, and replace the batteries before using the instrument.
- If the **"-L-" symbol appears at the display**, the batteries should be replaced as soon as possible. You can continue working with the instrument, but reduced measuring accuracy may result. Depleted rechargeable batteries require approximately 14 hours recharging time. Recharging starts as soon as the instrument is connected to the mains power battery charger. If the batteries have been excessively depleted, the instrument cannot be switched on. If this is the case, leave the (switched on) instrument connected to the charger for approximately 30 minutes, and then proceed as described above.



Attention!

Battery leakage must be avoided. Resulting damage is not covered by the guarantee.

Recharging the Batteries

Use only the NA4/500 mains power battery charger from GOSSEN METRAWATT GMBH. This assures operator safety by means of an extremely well insulated cable, and safe electrical isolation (nominal secondary ratings: 4.5 V /

500 mA). The recharging time of the batteries (1,600 mAh) in the instrument is approx. 14 h.

Country	Type / Article Number
Germany	Z218A
North America	Z218C
Great Britain	Z218D

Before connecting the mains power battery charger to the recharging jack, make sure that:

- **Rechargeable batteries have been installed (not normal batteries)**
- The instrument has been disconnected from the measuring circuit at all poles.

If possible, use the mains power battery charger only for recharging storage batteries, not for measurements, in order to avoid influence errors.

Replacing the Batteries

- ⇨ Set the instrument face down onto a flat working surface, loosen the two screws at the back and lift off the housing base, starting at the bottom. The housing top and housing base are held together with the help of snap hooks at the top front.
- ⇨ Remove the batteries from the battery compartment.
- ⇨ Insert three 1.2 V rechargeable NiMH batteries into the battery compartment, making sure that the plus and minus poles match up with the provided polarity symbols.
- ⇨ Important for reassembly: First set the housing base onto the housing top and align accurately (see photo below). Then press the two housing halves together, first at the bottom front (a), and then at the top front (b).



- ⇨ Secure the housing base with the two screws.



Attention!

The instrument may not be operated if the housing base has not been properly installed and secured!

Disposing of Batteries

Dispose of old batteries properly, i.e. at a designated collection point.

14.2 Fuses

The fuse is located at the measuring input. When the fuse is defective, the measurements in the $m\Omega/\Omega/\rightarrow/+/0$ ranges are faulty. The error in the V range amounts to only 10%. If a fuse should blow, eliminate the cause of overload before placing the instrument back into service!

Inspecting the Integrated Fuse

- ◇ Set the rotary switch to the Ω measuring function.
- ◇ Short circuit the \perp and Ω jacks.
Display $< 0.2 \Omega$: fuse OK
Display approx. 200 k Ω : fuse blown or poor contact at the fuse holder

Replacing the Fuse

- ◇ Open the instrument as described under "Replacing the Batteries".
- ◇ Remove the blown fuse with the help of an object such as a test probe, and replace it with a new fuse.

Table of Allowable Fuses

Type	Dimensions	Article Number
FF (UR) 1.6 A/1000 V AC/DC (10 kA)	6.3 mm x 32 mm	Z109C *

* These fuses are available in packages of ten from our sales offices and distributors.



Attention!

Use specified fuses only!
If fuses with other blowing characteristics, other current ratings or other breaking capacities are used, the operator is placed in danger, and protective diodes, resistors and other components may be damaged.
The use of repaired fuses and short-circuiting the fuse holder are prohibited.

14.3 Housing

No special maintenance is required for the housing. Keep outside surfaces clean. Use a slightly dampened cloth for cleaning. Avoid the use of cleansers, abrasives and solvents.

15 Multimeter Messages

The following messages appear at the main display, or the auxiliary displays as required. See "Symbols used in the Digital Display" on page 2 for messages displayed at visible segments.

Message	Function	Meaning
$\square L$	Measuring	Indicates overflow

Blinking Unit of Measure

All measuring functions are balanced for each METRAHit[®]27 at the factory in accordance with the respective technical specification. If a unit of measure blinks, this indicates that balancing constants which have been established and saved to the multimeter are no longer available for the respective function. If this is the case, measurement results may deviate from the specification. We recommend sending the instrument to our Repair and Replacement Parts department for rebalancing (see chapter 17).

16 Accessories

The **BD232 interface adapter** (without memory) allows for remote control of the instrument, as well as transmission of measurement data from up to six multimeters to a PC (in the online operating mode with METRAwin[®]10).

METRAwin[®]10 Software

METRAwin[®]10 software is used to process and display measurement data at a PC. Sampling can be triggered manually with an adjustable sampling interval, or in a signal dependent fashion. Storage of data in ASCII format can be controlled with two trigger thresholds per measuring channel, as well as by means of system time.

Hardware Requirements

- IBM compatible Windows PC, Pentium CPU or better with at least 64 MB RAM
- VGA monitor
- Hard disk with at least 40 MB available memory
- 3½" floppy disk drive for 1.4 MB floppies and a CD drive
- Microsoft compatible mouse
- If print-outs are required: a Windows supported printer
- 1 serial interface: COM1 or COM2

Software Requirements

- MS Windows 95, 98, ME, NT, 2000 or XP

17 Repair and Replacement Parts Service, DKD Calibration Lab* and Rental Instrument Service

If required please contact:

GOSEN METRAWATT GMBH
Service Center
Thomas-Mann-Str. 20
90471 Nuremberg, Germany
Phone +49-(0)-911-8602-0
Fax +49-(0)-911-8602-253
e-mail service@gmc-instruments.com

This address is only valid in Germany.
Please contact our representatives or subsidiaries for service
in other countries.

* **DKD** Calibration Laboratory for Electrical Quantities DKD – K – 19701 accredited as per DIN EN ISO/IEC 17025

Accredited quantities: direct voltage, DC value, DC resistance,
alternating voltage, AC value, AC active power, AC apparent power,
DC power, capacitance, frequency

Competent Partner

GOSEN METRAWATT GMBH is certified per
DIN EN ISO 9001:2000.

Our DKD Calibration Laboratory has been accredited in
accordance with DIN EN ISO/IEC 17025 by the Physikalisch
Technische Bundesanstalt (*Federal Institute for Physics and
Technology*) and the Deutsche Kalibrierdienst (*German Cali-
bration Service*) under registration number DKD-K-19701.

Our competence in the field of metrology covers **test reports,
Proprietary Calibration Certificates** as well as **DKD Calibration Cer-
tificates**.

Our range of services is complemented by our **Test Equipment
Management** service which is provided free of charge.

The **DKD Calibration Laboratory** is an integral part of our service
department. If any faults are detected during calibration, our
specialists are able to carry out the necessary repairs with
original replacement parts.

Needless to say, in our function as calibration laboratory, we
calibrate all instruments, irrespective of the manufacturer.

DKD Calibration Certificate Reprints

If you order a DKD calibration certificate reprint for your
instrument, please provide us with the reference numbers
indicated in the upper and lower most fields of the calibration
seal. We do not need the instrument's serial number.

18 Guarantee

The guarantee period for all METRAHit® measuring and
calibration instruments is 3 years after date of shipment.
Calibration is guaranteed for a period of 12 months. The
guarantee covers materials and workmanship. Damages
resulting from use for any other than the intended purpose or
operating errors, as well as any and all consequential
damages, are excluded.

19 Product Support

If required please contact:

GOSEN METRAWATT GMBH
Product Support Hotline
Phone +49-(0)-911-8602-112
Fax +49-(0)-911-8602-709
e-mail support@gmc-instruments.com

Printed in Germany • Subject to change without notice

GOSEN METRAWATT GMBH
Thomas-Mann-Str. 16-20
90471 Nuremberg, Germany

 Member of
GMC Instruments Group

Phone +49-(0)-911-8602-0
Fax +49-(0)-911-8602-669
e-mail info@gmc-instruments.com
www.gmc-instruments.com

 GOSEN METRAWATT