

METRAMax 6

Analog multimeter

3-348-602-02

2/3.97





Caution!

The analog multimeter METRMax 6 is constructed in compliance with the safety rules of IEC 1010-1/ EN 61010-1/VDE 0411-1. When properly used, the safety of both the user and the meter is assured. Their safety is not assured, however, if the meter is misused or carelessly handled. That is why it is absolutely necessary to carefully and completely read these operating instructions before using the METRMax 4 and to follow them in all respects.

Contents

	Page
1 Applications	4
2 Description	5
3 Operation	6
3.1 Operating controls	6
3.2 Inserting the battery	7
3.3 Checking the mechanical zero	7
3.4 Battery test	7
4 Measurement	8
4.1 Resistance measurement	8
4.1.1 Measuring on the range up to 50 Ω (Ω x 1, red)	8
4.1.2 Measuring on the ranges up to 1 M Ω (Ω x 1/10/100/1000, black)	9
4.2 Rough capacitance measurement	9
4.3 Diode and transistor test	10
4.4 Continuity test with sound signal	10
5 End of measurement	11
6 Specifications	12
7 Maintenance	14
7.1 Battery	14
7.2 Fuse link	14
7.2.1 Fuse replacement	14
7.3 Case	14
8 Repair and replacement parts service	15

1 Applications

The METRMax 6 is a battery-powered ohmmeter. It excels by its handy size, ease of use, and a large measuring span. It is meant for measurement of resistances between 0.05Ω and $1 \text{ M}\Omega$, for rough capacitance measurements between $1 \mu\text{F}$ and $30,000 \mu\text{F}$, and for continuity tests with beeper

2 Description

The METRAMax 6 offers 9 measuring ranges for resistance and capacitance measurements. The measuring ranges are selected with a range switch.

The meter has a rugged movement with spring-loaded jewels. It is widely insensitive to vibrations and shocks.

The scale is mirror-backed for exact reading of the measured values.

The measuring range $\Omega \times 1$, marked in red, and the scale marked in red are provided for measurements of small resistance values (0.05 Ω bis 50 Ω). To measure higher resistance values, there are 4 measuring ranges which have a common black scale.

A part of the two scale arcs is boldly marked. The measuring error, referred to the actual resistance value, is smallest on these marked indicating ranges.

For rough capacitance measurements, there are 4 measuring ranges with a common scale.

A beeper is incorporated for audible continuity tests.

The connectors are protected against accidental contact. It is recommended to use measuring leads with shockproof connection plugs (4 mm diameter).

3 Operation




Caution!

Only electrically dead devices under test must be measured!

Prior to each measurement, check mechanical zero and full-scale deflection.

3.1 Operating controls



- 1 Range selector switch
- 2 Rotary knob to adjust the full-scale deflection
- 3 Connection sockets
- 4 Battery compartment
- 5 Nose to open the meter
- 6 Adjustment screw for the mechanical zero
(∞ on black scale)

3.2 Inserting the battery

Prior to starting the METRAMax 6, insert a 1.5 V mignon cell into the battery compartment. This requires removal of the lower part of the case



Caution!

Disconnect the test leads from the measuring circuit before opening the meter!

- Press the nose (5) on the rear of the meter inwards, using an adequate tool, and remove the lower part.
- Insert a leakproof 1.5 V mignon cell according to IEC R6 into the battery compartment (4), paying attention to the polarity markings. Verify that reliable contact is made.
- Replace the lower part of the case and press the two parts together until they engage.

3.3 Checking the mechanical zero

- Place the METRAMax 6 into a horizontal position.
- Set the range selector switch (1) to the "O" position (OFF).
- The pointer has to be exactly over the bar code of the full-scale deflection (∞ on the black scale).
- Correct deviations with the adjusting screw (6) on the rear of the meter with a screwdriver, if required.

3.4 Battery test

- Set the range selector switch (1) to the " $\Omega \times 1$ " position (red marking).
- With the rotary knob (2), adjust the movement pointer on the red scale to full-scale deflection (∞).

If the pointer can no longer be adjusted to full-scale deflection, or if the indication is instable after the adjustment, the battery is exhausted and has to be replaced with a new one, see Section 3.2.

4 Measurement

4.1 Resistance measurement


Resistance is measured with DC voltage from the inserted 1.5 V mignon cell. The maximum measuring currents at full-scale deflection, with a battery voltage of 1.5 V, are listed in the range table (see Section 6. Specifications).

If possible, select the measuring range in such a way that indication is in the range of the boldly drawn scale arc. The measuring error, referred to the actual resistance value, is smallest in this range.

During prolonged resistance measurements, occasionally check for full-scale deflection (0Ω or ∞).

When switching the range selector switch (1) to another resistance range, always check for full-scale deflection and adjust with the rotary knob (2), if required.

4.1.1 Measuring on the range up to 50Ω ($\Omega \times 1$, red)




- Set the range selector switch (1) to $\Omega \times 1$ (red marking).
- With the rotary knob (2), adjust the pointer to full-scale deflection (∞) on the **red** scale.
- Connect the unknown resistance R_x to be measured and read the resistance value on the **red** scale.

4.1.2 Measuring on the ranges up to $1\text{ M}\Omega$

($\Omega \times 1/10/100/1000$, black)

- Set the range selector switch (1) to one of the measuring ranges $\Omega \times 1 \dots \Omega \times 1000$, depending upon the resistance value to be measured.
- Short the measuring leads.
- With the rotary knob (2), set the pointer to full-scale deflection ($0\ \Omega$) on the **black** scale.
- Connect the resistance R_x to be measured to the measuring leads and read the resistance value on the black scale. The indicated value must be multiplied by the specified factor in line with the selected measuring range

4.2 Rough capacitance measurement



- Set the range selector switch (1) to one of the measuring ranges $\mu\text{F} \times 1 \dots \mu\text{F} \times 1000$, depending upon the capacitance value to be measured.
- Capacitance is measured according to the ballistic method. Connect the capacitor a few times to the measuring leads with changing polarity and read the largest pointer deflection on the μF scale.


With this method, the capacitance of the capacitor to be measured can only roughly be determined. The measured value can deviate from the actual value by up to $\pm 25\%$.

4.3 Diode and transistor test

The resistance range $\Omega \times 1000$ is suited for a rough functional check on semiconductor elements. A resistance measurement is an easy way to find a short circuit or an interruption on a diode and/or a diode junction between base, collector and emitter. The polarity of a diode and the base connection of a transistor can also be determined by this test.

This measurement does not destroy semiconductor elements to be tested as the 1.75 V voltage and the 100 μA current are not exceeded.

4.4 Continuity test with sound signal



The continuity test (range selector switch (1) set to position ♩) is suitable for testing low-ohmic connections with a resistance value of $\leq 1.5 \Omega$.

No external voltage must be applied during the measurement! The forward direction of semiconductor elements should not be tested by the audible continuity test but only according to the deflection method (see Section 4.3). When using the audible continuity test, inductive voltage spikes appear at the meter connectors which could damage the semiconductors.

5 End of measurement

After the measurement, the range selector switch (1) should be set to "O" to conserve the battery life.

6 Specifications

Measuring ranges

Resistance	Measuring span	Mid-scale value (R_i)	Max. measuring current I_{\max} ¹⁾
$\Omega \times 1$ (red scale)	0.05 Ω ... 50 Ω	1 Ω	75 mA
$\Omega \times 1$	1 Ω ... 1 k Ω	20 Ω	75 mA
$\Omega \times 10$	10 Ω ... 10 k Ω	200 Ω	7.5 mA
$\Omega \times 100$	100 Ω ... 100 k Ω	2 k Ω	0.75 mA
$\Omega \times 1000$	1 k Ω ... 1M Ω	20 k Ω	0.075 mA

Capacitance measuring range	Measuring span	Max. measuring current I_{\max} ¹⁾
$\mu\text{F} \times 1$	0 ... 30 μF	0.075 mA
$\mu\text{F} \times 10$	0 ... 300 μF	0.75 mA
$\mu\text{F} \times 100$	0 ... 3 000 μF	7.5 mA
$\mu\text{F} \times 1000$	0 ... 30 000 μF	75 mA

¹⁾ With a battery voltage of 1.5 V

Continuity test with beeper

Response range	0 ... 1.5 Ω (beeper built-in)
Response current	365 mA
Operating current	170 mA

Accuracy

Error limit	$\pm 1.5\%$	of scale length
	$\pm 8.2\%$	referred to the actual resistance value on the indicating range with boldly marked scale arc.

Display

Scale	Mirror-backed
Scale length	approx. 90 mm
Pointer deflection	$\angle 0^\circ \dots 100^\circ$

Reference conditions

Ambient temperature	+20 °C
Position of use	Horizontal

Power supply

Fuse	1 mignon cell 1.5 V acc. to IEC R6, leakproof
------	---

Overload protection

Fuse link	F 6.3 H/250 V acc. to DIN VDE 0820 part 22/EN 60127-2, fixedly installed
-----------	--

Electrical safety

Protection class	II acc. to IEC 1010-1/EN 61010-1/ VDE 0411-1
Overvoltage category	CAT III
Nominal voltage	300 V
Pollution degree	2
Test voltage	3.7 kV~

EMC

Emission	Electromagnetic compatibility EN 50081-1: 1992
Immunity	EN 50082-1: 1992

Mechanical configuration

Dimensions	100 mm x 140 mm x 35 mm
Weight	approx. 0.3 kg (without battery)

7 Maintenance

7.1 Battery

The state of the battery should be checked from time to time. An exhausted or deteriorating battery must not remain in the battery compartment. Check and replace the battery as described in Section 3.2.

7.2 Fuse link

The holder for the fuse link is soldered to the circuit board. See section 6, overload protection, for the specified fuse.

7.2.1 Fuse replacement

- Disconnect the meter from the measuring circuit!
- Remove the lower part of the case, see section 3.2 on page 7.
- Changing the fuse it is possible to put the holder carefully to side or to desolder it.

Caution!



Absolutely verify that only the specified fuse is inserted! The use of a fuse with other cut-out characteristics, other nominal user and also there is danger of damaging protective diodes and other components.

The use of mended fuses or shorting of the fuse holder is not permitted.

7.3 Case

The meter must only be cleaned with a soft cloth or brush. Eventual static charges of the glass pane can be removed with an antistatic agent or a moist cloth.

8 Repair and replacement parts service

When you need service, please contact:

GOSSEN-METRAWATT GMBH
Service
Thomas-Mann-Straße 16 - 20
D - 90471 Nürnberg
Telefon (09 11) 86 02 - 4 10 / 4 11
Telefax (09 11) 86 02 - 2 53

This address is for Germany only. Abroad, our representatives or establishments are at your disposal.

Printed in Slovenia · Subject to change without notice

GOSSEN-METRAWATT GMBH
D – 90327 Nürnberg

Company address:
Thomas-Mann-Straße 16 – 20
D – 90471 Nürnberg
Telefon (09 11) 86 02 – 0
Telefax (09 11) 86 02 – 6 69

GOSSEN
METRAWATT
CAMILLE BAUER

