

SLP KONSTANTER series SLP 120 / SLP 240

Laboratory power supply

13025
3/6.97



First inspection

Please unpack the **KONSTANTER** and its accessory immediately on receipt and check the package for its completeness and any signs of damage incurred in transit.

Unpacking

- ☞ Unpack the Konstanter with the care obligatory for handling electronic equipment.
- ☞ The **KONSTANTER** is delivered in a packaging suitable for recycling, which is tried and tested to reliably protect the device in transit. Please take this or an equivalent packaging if repackaging the instrument.

Visual inspection

- ☞ Please compare P/O number / type description on the carton and/or label on the device with the indications on the shipping documents.
- ☞ Make sure that all accessory items have been included (→ 1.3 Options and Accessory).
- ☞ Check the packaging and exterior of the instrument and accessory for any signs of damage incurred in transit.

Complaints

If you find any damages, please do not hesitate to complain to the forwarder (keep carton!). Any other deficiencies or the requirement for repair have to be reported to our corresponding representation or directly to the address listed on the back cover.

Warnings and safety instructions

The **KONSTANTER** has been built and tested in accordance with the electrical safety regulations as listed in the specification and left the factory in perfect condition, in particular with regard to protection class I-requirements. To maintain this condition and to ensure safe operation, the user must follow the instructions and warnings in this Operating Manual. They are emphasized by either of the following titles:

CAUTION!

An operating instruction, the practical application, aso. which must be strictly followed to avoid a possible damage of the **KONSTANTER**, and to guarantee the correct operation.

WARNING!

An operating instruction, a practical application, aso. which must be strictly followed to maintain the safety protection of the **KONSTANTER** and to avoid personal injury.

The indispensable warnings are listed below. Each corresponding passage will be referred to throughout the operating instructions.

Indispensable warnings

WARNING I – Non-fused earthing

The **KONSTANTER** may only be operated with a connected non-fused earthed conductor. Each interruption of this non-fused earthed conductor if inside or outside the **KONSTANTER** may lead to the **KONSTANTER** becoming a danger. Any intentional interruptions are prohibited.

The line connection is made by a 3-wired cable with line connector plug which may only be plugged into a corresponding socket with an earthing contact. This protection effect must not be eliminated by an extension cable without a non-fused earthed conductor.

WARNING II – impacted safety protection

If there are any signs that a safe operating might no longer be possible, switch off the **KONSTANTER** immediately and save the instrument against unintentional operation. Signs that a safe operating might no longer be possible may be as follows:

- if the **KONSTANTER** shows visible damages,
- if the **KONSTANTER** stops working,
- after a long-term storage disregarding the specific storage conditions,
- after heavy demands in transit.

WARNING III – opening of case covers

When opening case covers, voltage leading parts might be laid bare as long as the **KONSTANTER** is connected.

Do not touch these voltage leading parts laid bare since this is highly dangerous.

Thus, case covers may only be opened or removed by an expert being familiar with these dangers.

WARNING IV – repairs only by an expert

When opening case covers, voltage leading parts might be laid bare as long as the **KONSTANTER** is connected.

Maintenance and repair works as well as instrument internal alignments may only be made by an expert being familiar with these dangers.

If any possible the **KONSTANTER** has to be separated from all external voltage sources before these works begin. Then please wait 5 minutes so that the internal condensators can be discharged to harmless voltage values.

WARNING V – replacement of fuses

When replacing faulty fuses please do not use other fuses than those being of the indicated type and the given nominal current strength (see specification resp. label indication).

Any manipulation at the fuses or fuse holders ("mending" fuses, short-circuiting of the fuse holder, etc.) is inadmissible.

Contents

	Page
1 Specifications	5
1.1 Facilities and applications	5
1.2 Functional features	5
1.3 Options and accessory	5
1.4 Technical data	6
1.4.1 General data	6
1.4.2 Mechanical data	6
1.4.3 Technical data series 120 W	7
2 Preparation and operation	8
2.1 Line connection	8
2.2 Load connection	8
2.3 Remote sensing	8
2.4 Rack mounting	9
2.5 Combination to a multi-channel desktop instrument	9
3 Control, indicators and connectors	10
4 Adjusting the output values	12
4.1 Output voltage	12
4.1.1 U_{out} – Actual voltage measuring value	12
4.1.2 U_{lim} – Limit value for U_{set}	12
4.1.3 U_{set} – Voltage setting value	12
4.2 Output current	13
4.2.1 I_{out} – Actual current measuring value	13
4.2.2 I_{lim} – Limit value for I_{set}	13
4.2.3 I_{set} – Current setting value	13
4.3 OUTPUT – Switching on/off of the power output	13
5 Control via analog interface	14
5.1 Pin assignment	14
5.2 Status signal outputs	15
5.3 TRIGGER input	15
5.4 Remote control of the output voltage	16
5.5 Remote control of the output current	16
5.6 Voltage monitor output	17
5.7 Current monitor output	17
5.8 Parallel operation	18
5.8.1 Direct parallel operation	18
5.8.2 Master-slave parallel operation	19
5.9 Series operation	20
5.9.1 Direct series operation	20
5.9.2 Master slave series operation	21
5.10 Variation of the output resistance	22

1 Specifications

1.1 Facilities and applications

The SLP KONSTANTERS (Single-Output Laboratory Power Supplies) are one-channel laboratory power supplies to be used in Research, Development, Production, Education and Service.

The KONSTANTERS maintain either **voltage or current constantly** and thus they can cover a wide range with their nominal power of 120 W respectively 240 W by their „auto-ranging“ output.

The manual adjustment of voltage and current effects precisely by 10-turn-potentiometers the adjustment range of which can be reduced by aligning tools to avoid an erroneous adjustment of unrequiredly high values.

Two big 3.5-digit LED digital displays show the output voltage respectively the output current and may be switched to **setting value indication** which is advantageous in particular for current adjustment. **Control status indications** are signaling each corresponding operating status.

The **earth-free, front and back output** can be switched on or off at the standardly provided analog interface either by pressing the key or by signal. When the sensors are connected, the instrument **automatically** switches to **remote-sensing**.

The solid metal case has a firm frame as well on its top as also on its base. Moreover, it contains stand-position legs and a stand-position protection at its rear.

In next to no time several cases can be linked firmly and thus construct a **multi-channel unit**. Furthermore the case is provided with a **line output socket** so that the unit needs only one feeding line which will be passed on by the Jumper power cable (accessory). Even the mounting into 19" racks is possible with the corresponding adapters.

1.2 Functional features

Adjustable functions

- Voltage and current setting value
- Limit value for voltage and current adjustment range
- Switching the output On/Off

Indicative functions

- Voltage / current measuring value
- Voltage / current setting value
- Present regulation mode (CC / CV)

Protective and additional functions

- Pole-confusion protected sensor connectors with automatical activation (auto-sensing)
- Overtemperature protection
- Reverse-voltage protection of the output
- Inrush current limiting
- Temperature-controlled fan
- Master-slave coupling

1.3 Options and accessory

Options

The KONSTANTER is well equipped and therefore offers no further options.

Standard accessory:

The consignment of the KONSTANTER contains the following accessories:

- this operating manual
- 1 line connection cable (approx. 1.5 m) with an earthing contact plug

Additionally available accessory:

(please see list on last page)

- 19" adapter 1x32N for the mounting of a single KONSTANTER of series SLP into a 19" rack
- 19" adapter 2x32N for the mounting of two KONSTANTERS of series SLP into a 19" rack
- Jumper power cable, 0.4 m "bridging" the line supply with one 10 A appliance plug and one 10 A appliance coupling each.

1.4 Technical data

1.4.1 General data


Supply

Connection	Input: 10 A IEC appliance plug Output: 10 A IEC appliance coupling, unswitched, non-fused
Line voltage	230 V AC; +10/-15%; 47...63 Hz;
Power consumption	See section 1.4.3
Inrush current	max. 50 A _{peak}
Line fusing	1x T4A/250V (6.3 x 32 mm, UL) Internal: 1 x T5 A/250 V (5 x 20 mm)

Output

Connection	At the front, 2 x 4 mm safety sockets At the rear, 6-pins terminal block (pluggable)
Output	At the rear, in the output connector plug
Sensor	At the rear, in the output connector plug
Regulator principle	Primary switch-mode regulator with BET technology
Operating modes	Adjustable constant voltage/current source with auto-crossover
Output isolation	Floating output with "safe electrical isolation" to the line input; max. admissible potential output to earth: 120 V; capacity output to earth (case): 60 nF

Output operating range



Short-time operating range:

if operating for a longer time within the short time operating range, the overtemperature protection might react by switching off the output (compare with section 1.4.3: short-term power)

Analog interface

Connection	11-pins terminal block (pluggable)
Ref. potential	Output negative terminal TRG input floating

Connection setting:

Pin	Description	Function
1	SIG1 OUT	Status signal output for output on/off
2	SIG2 OUT	Status signal output for regulation mode CV/CC (open collector, max. 30 V-/20 mA)
3	TRG IN +	Digital control input for output on/off
4	TRG IN -	(low: <1 V; high: 4 ... 26 V); floating
5	+15 V	Auxiliary voltage +15 V/max. 50 mA
6	AGND	Point of reference, connected to -output by reversible fuse
7	U _{set} -	Analog, inverting voltage control input (0 ... -5 V corresp. 0 ... U _{nom} ; R _i = 10 kΩ)
8	U _{set} +	Analog voltage control input (0 ... +5 V corresp. 0 ... U _{nom} ; R _i = 10 kΩ)
9	I _{set} +	Analog current control input (0 ... +5 V corresp. 0 ... I _{nom} ; R _i = 10 kΩ)
10	U-MON	Monitoring output of the output voltage (0 ... 10 V corresp. 0 ... U _{nom} ; R _i = 9.8 kΩ)
11	I-MON	Monitoring output of the output current (0 ... 10 V corresp. 0 ... I _{nom} ; R _i = 9.4 kΩ)

Electrical safety

IEC 1010-1 +A1 ('92)	Safety regulations for electrical measuring, control, regulating and lab instruments;
EN 61010-1 ('93)	(protection class I; overvoltage category: II for line input, I for output and interfaces;
VDE 0411-1 ('94)	pollution degree 2; earth leakage current typ. 2.5 mA);
IEC 950+A1+A2 ('93)	Safety of information technology
EN 60950+A1+A2 ('93)	equipment including electrical
VDE 0805+A2 ('94)	business equipment
IEC 529 ('89)	Framing protective systems;
EN 60529 ('91)	IP 20 for cases and connectors for line,
VDE 0470-1 ('92)	output, analog interface;
Potential isolation	Test voltage
Line/output - PE	1.35 kV AC
Line - output	2.7 kV AC (type test 3.7 kV AC)

Electromagnetic compatibility

Interference emission

EN 50081-2 ('94)	Generic emission standard
VDE 0839-81-2 ('94)	industrial environment
CISPR 11 ('90)	Limit values and measuring procedures
EN 55011 ('91)	for radio interferences of ISM equipment
VDE 0875-11 ('92)	

Interference immunity

EN 50082-2 ('96)	Generic emission standard
VDE 0839-82-2 ('96)	industrial environment
IEC 1000-4-2 ('95)	Electrostatic discharge
EN 61000-4-2 ('95)	(severity level 2 for contact discharge,
VDE 0847-4-2 ('96)	severity level 3 for atmospheric discharge)
IEC 1000-4-3 ('95)	Electromagnetic HF field
ENV 50140 ('95)	(10 V/m, no influence)
VDE 0847-3 ('95)	
IEC 1000-4-4 ('95)	Transient interference quantities - Burst
EN 61000-4-4 ('95)	(severity level 3)
VDE 0847-4-4 ('96)	

Ambient conditions

IEC 68-2-6 ('90)	Vibration resisting strength
	(10-55 Hz; 0.3 mm; 1 oct/min; 3x30 min)
IEC 68-2-27 ('89)	Impact strength
	(15g; 11ms; semi-sine, 3x6 shocks)
Temperature range	Operation: 0 to 50 °C
	at > 40 °C current derating
	(see 1.4.3.)
	Storage: -25 to +75 °C
Humidity	Operation: ≤ 75% RH;
	no dewing
Cooling	By integrated fan
	Air intake: side panels
	Air outlet: rear panels

1.4.2 Mechanical data



Construction type	Desktop instrument, suitable for rack mounting
Dimensions (B x H x T) for 19" rack	See also dimensional drawing 22.15 x 10.2 x 39.75 cm 1/2 19" x 2 HE x 40 cm
Weight	approx. 2.8 kg
Dimensional drawing	See page 6

1.4.3 Technical data series 120 W

- Unless otherwise stated, all data are maximum values and are valid on the operating temperature range from 0 ... 50 °C, nominal power range and line voltage range 230 V ±10 % after a warmup time of 30 minutes.
- The indications in % refer to the respective adjustment or measured values

Short designation Type designation		SLP 120-20 32 N 20 R 10	SLP 120-40 32 N 40 R 6	SLP 120-80 32 N 80 R 3
Nominal output data	Voltage setting range Current setting range Continuous power at $T_u \leq 40$ °C Short-term power for $t < 90$ s / $T_u \leq 25$ °C Current derating at $T_u > 40$ °C	0 ... 20 V 0 ... 10 A max. 120 W max. 200 W -0.25 A/K	0 ... 40 V 0 ... 6 A max. 120 W max. 240 W -0.15 A/K	0 ... 80 V 0 ... 3 A max. 120 W max. 240 W -0.07 A/K
Output performance	Total setting accuracy (at 23 ± 5 °C) referred to 3½-digit set point display Incl. deviation load/line	Voltage 0.2 % + 50 mV Current 0.5 % + 45 mA	Voltage 0.2 % + 150 mV Current 0.5 % + 35 mA	Voltage 0.2 % + 250 mV Current 0.5 % + 20 mA
Load effect ¹⁾ at 100 % load change ¹⁾	Voltage Current	15 mV 20 mA	10 mV 10 mA	10 mV 10 mA
Line effect ¹⁾ at 10 % line voltage variation ¹⁾	Voltage Current	5 mV 8 mA	5 mV 5 mA	5 mV 5 mA
Residual ripple ¹⁾	Voltage (10 Hz ... 10 MHz) Current (10 Hz ... 1 MHz)	10 mV _{rms} 25 mA _{rms}	10 mV _{rms} 20 mA _{rms}	10 mV _{rms} 10 mA _{rms}
Common-mode noise (10 Hz ... 1 MHz)		0.5 mA _{rms}	0.5 mA _{rms}	0.5 mA _{rms}
Settling time (voltage) at a load change 10 ... 90% Inom	Tolerance $\Delta I = 80$ %	40 mV 200 μs	80 mV 200 μs	80 mV 200 μs
Undershoot / overshoot voltage at load step 50 A/ms	$\Delta I = 80$ %	400 mV	400 mV	800 mV
Response time (voltage) at step change in set point 0 → 100 % at step change in set point 100 % → 0	Tolerance No load/nominal load No load/nominal load	40 mV 1 ms / 1 ms 1 ms / 1 ms	80 mV 1 ms / 1 ms 1 ms / 1 ms	160 mV 4 ms / 4 ms 4 ms / 4 ms
Response time (current) at step change in set point 0 → 100 % at step change in set point 100 % → 0	Tolerance Short circuit/nominal load Short circuit/nominal load	100 mA < 5 ms / < 5 ms < 5 ms / < 5 ms	60 mA < 5 ms / < 5 ms < 5 ms / < 5 ms	30 mA < 10 ms / < 10 ms < 10 ms / < 10 ms
Meter performance (3½-digit)				
Resolution	Voltage Current	10 mV 10 mA	100 mV 10 mA	100 mV 10 mA
Accuracy (at 23 ± 5 °C) Referred to the measured value at a time	Voltage Current	0.15 % + 25 mV 0.5 % + 30 mA	0.2 % + 120 mV 0.5 % + 25 mA	0.2 % + 150 mV 0.5 % + 20 mA
Protection features				
Output overvoltage protection	Response value	25 ± 1 V	50 ± 2 V	100 ± 4 V
Loading of pole confusion protection	Continuously	10 A	6 A	3 A
Feedback withstand voltage	Continuously	40 V	80 V	100 V
General				
Power supply ¹⁾	Line voltage	230 V~ +10/-15 % 47 ... 63 Hz	230 V~ +10/-15 % 47 ... 63 Hz	230 V~ +10/-15 % 47 ... 63 Hz
Power consumption	At nominal load In standby mode At maximum short-term power	280 VA; 180 W 45 VA; 15 W 550 VA	280 VA; 170 W 45 VA; 15 W 550 VA	280 VA; 170 W 45 VA; 15 W 550 VA
Efficiency	At nominal load	> 67 %	> 70 %	> 70 %
Switching frequency	Typically	200 kHz	200 kHz	200 kHz
Ordering No.		K220A	K221A	K222A

1) The regulation data increases by the factor of 1.2 on the function range of the line input voltage from -10 % to -15 %.



Technical data series 240 W

- Unless otherwise stated, all data are maximum values and are valid on the operating temperature range from 0 ... 50 °C, nominal power range and line voltage 230 V ±10 % after a warmup time of 30 minutes.
- The indications in % refer to the respective adjustment or measured values

SLP 240-20 32 N 20 R 20	SLP 240-40 32 N 40 R 12	SLP 240-80 32 N 80 R 6	SLP 320-32 32 N 32 RU 18
0 ... 20 V 0 ... 20 A max. 240 W max. 400 W -0.5 A/K	0 ... 40 V 0 ... 12 A max. 240 W max. 480 W -0.3 A/K	0 ... 80 V 0 ... 6 A max. 240 W max. 480 W -0.15 A/K	0 ... 32 V 0 ... 18 A max. 320 W max. 480 W -0.5 A/K
0.2 % + 100 mV 0.5 % + 55 mA	0.2 % + 150 mV 0.5 % + 45 mA	0.2 % + 250 mV 0.5 % + 35 mA	0.2 % + 150 mV 0.5 % + 50 mA
25 mV 30 mA	18 mV 30 mA	18 mV 15 mA	30 mV 40 mA
5 mV 8 mA	5 mV 8 mA	5 mV 5 mA	10 mV 20 mA
15 mV _{rms} 60 mA _{rms}	15 mV _{rms} 25 mA _{rms}	15 mV _{rms} 20 mA _{rms}	30 mV _{rms} 50 mA _{rms}
0.5 mA _{rms}	0.5 mA _{rms}	0.5 mA _{rms}	0.5 mA _{rms}
40 mV 400 μs	80 mV 200 μs	160 mV 200 μs	64 mV 200 μs
400 mV	400 mV	800 mV	400 mV
40 mV 1 ms / 1 ms 1 ms / 1 ms	80 mV 1 ms / 1 ms 1 ms / 1 ms	160 mV 4 ms / 4 ms 4 ms / 4 ms	64 mV 1 ms / 1 ms 1 ms / 1 ms
200 mA < 5 ms / < 5 ms < 5 ms / < 5 ms	120 mA < 5 ms / < 5 ms < 5 ms / < 5 ms	60 mA < 10 ms / < 10 ms < 10 ms / < 10 ms	180 mA < 5 ms / < 5 ms < 5 ms / < 5 ms
10 mV 10 mA	100 mV 10 mA	100 mV 10 mA	100 mV 10 mA
0.2 % + 50 mV 0.5 % + 25 mA	0.2 % + 120 mV 0.5 % + 30 mA	0.2 % + 120 mV 0.5 % + 25 mA	0.2 % + 120 mV 0.5 % + 40 mA
25 ± 1 V	50 ± 2 V	100 ± 4 V	40 ± 1 V
20 A	12 A	6 A	20 A
40 V	80 V	100 V	64 V
230 V~ +10/-15 % 47 ... 63 Hz	230 V~ +10/-15 % 47 ... 63 Hz	230 V~ +10/-15 % 47 ... 63 Hz	230 V~ +10/-15 % 47 ... 63 Hz
550 VA; 360 W 45 VA; 15 W 1050 VA	550 VA; 340 W 45 VA; 15 W 1050 VA	550 VA; 340 W 45 VA; 15 W 1050 VA	660 VA; 460 W 50 VA; 15 W 1050 VA
> 67 %	> 70 %	> 70 %	> 70 %
200 kHz	200 kHz	200 kHz	200 kHz
K230A	K231A	K232A	K234A

1) The regulation data increases by the factor of 1.2 on the function range of the line input voltage from -10 % to -15 %

2 Preparation and operation

2.1 Line connection

WARNING I to be considered!

CAUTION!

Before switching the KONSTANTER on, please make sure that the line voltage is in accordance with the operation voltage indicated at the rear's line connector.

The KONSTANTER needs 230 V AC supply voltage. Please connect the line connector at the rear to a line plug socket with a non-fused earthed conductor by the supplied cable.

The ratings regarding power consumption of the KONSTANTER are stated on the label at the bottom side of the instrument.

Above the line input plug, the KONSTANTER is provided with a line output socket to "bridge" the line voltage to further instruments. This line output socket is neither switched nor fused.

WARNING!

When bridging the line voltage, please consider that the total current consumption at the line feeding point is not exceeding 10 A!

Suitable "Jumper Power Cables" are available as accessory (see list at the last page).

2.2 Load connection

The load lines are connected either by 4 mm safety laboratory plugs to the safety sockets „+“ and „-“ at the front side or to the 6-pins terminal block, outputs „+“ and „-“ at the rear.

The rear load connection is equipped with two pins each for „+“ and „-“.

If the load current is higher than 10 A, both pins must be connected due to the contact load capacity.

Care for a sufficient line cross section and for the polarity. It is recommended to twist the load lines and to mark them at both ends with their polarity.

When loads are connected as well at the front as also at the rear, the constant voltage regulation refers to the connection pins at the rear. This kind of connection is prohibited for parallel outputs since otherwise there would be danger of overload for the internal link.

The yellow-green safety socket at the front side is connected to PE (earth/case) and serves the possible connection of earthing lines, cable shields or as earthing point of one of the output terminals.

2.3 Remote sensing

Take advantage of the high voltage constance of the output even for longer load lines. Compensate the voltage drop of the load lines by additional sensor lines.

Function

- Sensor terminals +SENSE / -SENSE detect the output voltage decisive for the voltage measuring and regulating circuits directly at the load (instead of the output pins).
- This sensor operation (remote sensing) offers the following advantages:
 - + At constant voltage operation the voltage at the load remains largely uninfluenced of the current-dependent voltage drops on the load lines. These voltage drops are compensated by the automatical corresponding increase in voltage at the output sockets.

- + At constant current operation the voltage limit at the load is also independent from the output current.
 - + The voltage value delivered from the measuring function refers to the voltage detected by the sensor lines. Thus, load parameters as well as power input or load resistance can be calculated more precisely.
- For remote sensing, the parameters and limit values shown in figure 2.3 are applicable.




Figure 2.3 Load connection with remote sensing

- C_{S+}, C_{S-} typical ... 220 μ F
- $U_{S+}, U_{S-} \leq 1$ V
- $I_{S+} \approx U_{out_s} / 150 \text{ k}\Omega - U_{S+} / 81 \Omega$
- $I_{S-} \approx 70 \mu\text{A} \cdot U_{out_s} / U_{out \text{ nom}} - U_{S-} / 81 \Omega$

Connection

- Connect the two sensor lines +SENSE and -SENSE at the rear's output plug conductor as near as possible to the load with the corresponding output terminal.
- Interference couplings can be held lower by:
 - ☞ Twisting the sensor lines and / or
 - ☞ Shielding the sensor lines (shield to earth/case or output negative terminal)
- The impedance of long load and sensor lines may lead to oscillations of the output voltage. Load capacities are supporting this.
- By one capacitor each (C_{S+}, C_{S-}) between SENSE and output pin (see figure 2.3), you can counteract to the regulator oscillation.
- Moreover, twisting the load lines reduces their impedance.
- An erroneous connection of the sensors has no damaging effects on the KONSTANTER, but leads to the following reversible events:
 - + Confusing the poles of the sensor or interruption of a load line: If the output voltage at the KONSTANTER is not limited by the current regulation, it will exceed the set value. Then the over-voltage protection reacts at once and deactivates the output.
 - + Interruption of a SENSE line: Automatical switching back to local sensing for the corresponding output terminal.
- If the sensors are connected erroneously, the voltmeter display will not show the voltage at the output pins / load.

Switching on

- The switching to remote sensing effects automatically by linking the SENSE terminal connection to its output terminal.
- Switching it off is made by opening this link.

2.4 Rack mounting

The case of the **KONSTANTERs** is designed to permit use both as a desktop instrument and also for mounting into a 19" rack. You can mount either two **KONSTANTERs** in side-by-side or a single **KONSTANTER** with an additional cover plate into the rack. In next to no time you can change the desktop instrument into a rack mounting device.

Preparing a single **KONSTANTER** for rack mounting

Please use our accessory 19" adapter 1x32N which includes a 19" stop and a 1/2 19" cover plate.

- ① Remove the 4 screws at the front of the **KONSTANTER**.
- ② Remove the two filler strips at the front, left and right side.




Figure 2.4 a Preparing a single instrument for rack mounting

- ③ Replace them by the 19" stop on one side and the 1/2 19" cover plate on the other side and fasten them again with the 4 screws.
- ④ Unscrew the stand-position legs by removing the rubber inlet under which you will find the screws.
- ⑤ Now mount the **KONSTANTER** into the rack. Please keep all dismounted parts just in case you want to refix them in the rack.
- ⑥ The **KONSTANTER** must be laid on **one side on rails** which are, together with the front plate fastening screws required for the fixing of the **KONSTANTER**, rack-specific and to be supplied from your 19" rack supplier.

Preparing two **KONSTANTERs** for rack mounting

Please use our accessory 19" adapter 2x32N which includes two 19" stops and one 19" link.

- ① Remove the 8 screws at the front of the **KONSTANTERs**.
- ② Remove the two filler strips at each front, left and right side.




Figure 2.4 b Preparing two instruments for rack mounting

- ③ Replace them by the 19" stops on the left and right side, mount the 19" link into the middle and fasten them again with the 8 screws.
Now bolt the two cases at bore-hole and thread in the stand-position protection at the rear.
- ④ Unscrew the stand-position legs by removing the rubber inlet under which you will find the screws.
- ⑤ If you wish to connect both **KONSTANTERs** electrically, please use our accessory "Jumper Power Cable".
- ⑥ Now mount the **KONSTANTERs** into the rack. Please keep all dismounted parts just in case you want to refix them in the rack.
- ⑦ The **KONSTANTERs** must be laid on two sides on rails which are, together with the front plate fastening screws required for the fixing of the **KONSTANTER**, rack-specific and to be supplied from your 19" rack supplier.

2.5 Combination to a multi-channel desktop instrument

You may combine up to 3 **KONSTANTERs** to a multi-channel desktop instrument (see also section 5 for the electrical coupling possibilities via analog interface).

- ① Unscrew the stand-position legs by removing the rubber inlet under which you will find the collar screws.
At the bottom side you will now see four enlarged oblong holes.
- ② Screw these 4 collar screws into the 4 threads on the top of the other instrument case. Please keep the 4 washers and the stand-position legs.
- ③ Set the **KONSTANTER** without stand-position legs on top of the other **KONSTANTER**. The screws of the underneath device must be introduced into the enlarged oblong holes of the upper instrument. Now please push the upper instrument slightly until the screws are locked in position.
- ④ Bolt the two instruments together by the bore-holes and threads at the rear stand-position protection. Thus a possible sliding of the corresponding upper instrument can be avoided.
- ⑤ If you wish to connect both **KONSTANTER** electrically, please use our accessory „Jumper Power Cable“.

3 Control, indicators and connectors




Figure 3.1 Control, indicators and connectors at the front

[1] Line switch <POWER>

Switching the **KONSTANTER** on/off.

After having been switched on, the **KONSTANTER** adjusts to all values given by the setting of the control elements or by the control signals at the analog interface. Then the instrument is ready for further operation.

When switching off, the **KONSTANTER** is disconnected from the line and the output will be deactivated.

CAUTION!

Please do not switch on/off too often within short periods. Otherwise, the efficiency of the inrush current limitation might be reduced and as a consequence, the line fuse might react!

[2] <OUTPUT> key

Pressing the button <OUTPUT> activates respectively deactivates the power output.

If the output is activated, one of the regulation mode indicators illuminates **CV** or **CC** [3].

Switching the output on/off produces no considerable over-/undershoot of the output voltage.

When switching the output off, an electronic "sink" will be activated for approx. 300 ms. This circuit discharges the output capacitors rapidly and afterwards the output will be "high-resistive" ($R_i > 50 \text{ k}\Omega \parallel 250 \mu\text{F}$).

☞ Further description in section 4.3

CAUTION!

The output connections are not galvanically insulated by switching the output off.


[3] Regulation mode indicators

The three LED indicators signalize the present operation status (regulation mode) of the output.

"CV" illuminates constant voltage mode
($U_{out} = U_{set}$)

"CC" illuminates constant current mode ($I_{out} = I_{set}$)

"Pmax" illuminates overtemperature protection has reacted;
output is not activated;



[4] Left display

The left digital display shows the **measured value** of the output voltage **Uout** in Volts as **standard indication**. As long as the key [9] <DISPLAY Uset/Iset> is pressed, the display shows the manually set **voltage setpoint value Uset**.

Type/nominal voltage	Measuring resolution / range
20 V	0.01 (max. 19.99)
32/40/80 V	0.1 (xx.x)

[5] Right display

The right digital display shows the measured value of the output current **Iout** in Amperes as **standard indication**. As long as the key [9] <DISPLAY Uset/Iset> is pressed down, the display shows the manually set **current setpoint value Iset**.
Measuring resolution / range 0.01 (max. 19.99)

➤ Further description in section 4.3

[6] Output at the front

The set constant voltage resp. the constant current can be taken from the safety sockets at the front or from the connector at the rear [13].

- (blue) Negative output terminal
- + (red) Positive output terminal
- ⏏ (yellow-green) Earthing feature for the output or shield connections provided that shielded load lines are used. The earthing terminal is linked with the case and the PE contact of the line connector.

➤ Further description in section 2.2

Figure 3.2 Operation and connection elements at the rear

[7] Voltage setting limit adjustment <Ulim>

The upper limit value Ulim for the voltage setting value Uset is adjusted on this trimmer potentiometer. Please use exclusively a screw driver of size 3.

➤ Further description in section 4.1.2

[8] Knob for voltage setting <Uset>

This knob adjusts the output voltage. This adjuster is made as a 10-turn-potentiometer and enables you to adjust the voltage setting value Uset very precisely in the range defined by Ulim [7].

Press key [9] to monitor the setting value Uset.

➤ Further description in section 4.1.3

[9] Display switch key <Uset/Iset>

Pressing key [9] switches both displays [4/5] from Uout/Iout to Uset/Iset.

Keep this key pressed down if you want to control every change of Uset/Iset or Ulim/Ilim during this processing.

[10] Knob for current setting <Iset>

With regard to the current setting, this knob has the same principle as the voltage setting knob [8].

Press key [9] <DISPLAY Uset/Iset> to monitor the **present current setting value**.

➤ Further description in section 4.2.3

[11] Current setting limit adjustment <Ilim>

The upper limit value Ilim for the current setting value Iset is adjusted on this trimmer potentiometer. Please use exclusively a screw driver of size 3.

➤ Further description in section 4.2.2

[12] Analog interface

CAUTION!

The contacts of the analog interface are connected to electronic

components which might be damaged by electrostatic discharges. **Before touching the contacts, please balance the potential difference between you and the KONSTANTER by touching the case!**

The analog interface offers possibilities to

- remotely set the output voltage und current by analog control voltages 0 ... 5 V or 0 ... -5 V
➤ Further description in section 5.4 / 5.5
- externally measure or record output voltage and current via monitor signals 0 – 10 V
➤ Further description in section 5.6 / 5.7

- supply the TRIGGER input or external regulation devices with an auxiliary voltage of approx. +15 V
- couple several **KONSTANTERs** in master/slave operation
 - ☞ Further description in section 5.8.2 / 5.9.2
- vary the output's inner resistance
 - ☞ Further description in section 5.10
- activate/deactivate the output via the potential-free TRIGGER input
 - ☞ Further description in section 5.3

[13] Rear output

The OUTPUT interface offers two possibilities

- Tapping the constant voltage resp. current at the rear of the **KONSTANTER** by connection block
- Connecting the sensor lines (SENSE) to compensate voltage drops on the load feeding lines
 - ☞ Further description in section 2.2 and 2.3

[14] Air outlet

The air outlet at the rear and at the side serve to regulate the temperature in the **KONSTANTER**. Through this ventile supported by a temperature controlled fan, the heat generated in the **KONSTANTER** is blown away.

CAUTION!

The air ventile must not be closed, e.g. the outgoing warm air must not be stopped through blocking the outlet holes. If this instruction has not been followed, the overtemperature protection will react and deactivate the output (see section 4.3).

[15] Line input

Line input with bridged line socket for appliance plugs. These bridged line sockets enable you to connect up to 3 **KONSTANTERs** directly via two short line cables with appliance plugs. Thus, no more than one feeding line is necessary.

- ☞ Further description in section 2.1

[16] Line fusing

Fusing the line voltage input

All device types: T 4.0 A / 250 V (6.3 x 32 mm)

The second line input terminal is fused internally by
T 5.0 A / 250 V (5 x 20 mm)

WARNING!

When replacing faulty fuses please do not use other fuses than those being of the indicated type and the given nominal current strength (see specification resp. label indication. Any manipulation at the fuses or fuse holders („mending“ fuses, short-circuiting of the fuse holder, etc.) is inadmissible.

4 Adjusting the output values

4.1 Output voltage

4.1.1 Uout – Actual voltage measuring value

- The left digital instrument [4] <Volt> shows the actual measured value **Uout** which is the value of the voltage being at the output terminals.
 - With remote sensing, the shown measured value refers to the voltage, which is taken by the sensors at the load.
 - The 3½ digit display is updated approximately three times per second; overflow indication if values exceed 19.99 V on 20 V devices.
 - When the output voltage is superposed with AC signals, the display shows the arithmetic average value.
- ☞ Regarding measuring range, measuring resolution and measuring accuracy see section 1.4.3 Electrical data

4.1.2 Ulim – Limit value for Uset

Function

- Upper limit value for voltage setting range of <Uset> [8]
- Protection against **unintentional** too high adjustment of the voltage setting value Uset
- When inserting **Ulim = 0 V** (left strike), the voltage control <Uset> is **inefficient** (e.g. when setting the output voltage via the analog interface).

Adjustment of Ulim

- Adjust **Ulim** at the **left trimmer potentiometer [7] <Ulim>**
- Use exclusively a **screwdriver of size 3** to avoid any damages at the potentiometer
- Deactivate the output: <OUTPUT> "OFF"
- At first, set **Uset** on **maximum value** (turn potentiometer [8] <Uset> clockwise to the strike)
- Press key [9] <DISPLAY Uset/Iset>
- The left display [4] <Volt> switches from the **actual voltage measuring value Uout** to the manually adjusted voltage setting value **Uset**
- Keep **pressing this key down**
- **Screw simultaneously <Ulim> [7]** with the screwdriver until the left display [4] <Volt> shows the voltage to be set for **Ulim**.
- **Increase in voltage:** screw **clockwise** (increment)
- **Decrease in voltage:** screw **counter-clockwise** (decrement)
- This voltage now is the **maximum value** to which **Uset** can be adjusted manually.

Adjustment range

- The **270°** rotation angle of <Ulim> corresponds to an adjustment range $0\text{ V} \leq U_{\text{lim}} \leq U_{\text{nom}}$.
- The **10 possible turns** at the <Uset> knob [8] **always** correspond to the range **0 V to Ulim**.

4.1.3 Uset – Voltage setting value

Function

- Setting value of the output voltage.

Adjustment of Uset

- Adjust **Uset** at the **left knob [8] <Uset>**
- At first, press key [9] <DISPLAY Uset/Iset>
- The left display [4] <Volt> switches from the **actual voltage measuring value Uout** to the manually **adjusted voltage setting value Uset**
- Keep **pressing this key down**
- **Turn at the same time knob [8] <Uset>**
- **Increase in voltage:** screw **clockwise** (increment)
- **Decrease in voltage:** screw **counter-clockwise** (decrement)
- Provided that output is activated <OUTPUT> "ON", the output voltage changes directly with the setting of the knob.
- If **deactivated output <OUTPUT> "OFF"**, no voltage is at the output, not even during the adjustment. The voltage is only brought to the output after activating <OUTPUT> "ON".
- After releasing key [9] <DISPLAY Uset/Iset> the display [4] switches back to the indication of the **measuring value of the output voltage Uout**.

CAUTION!

The value for Uset can also be changed if the KONSTANTER is not activated.

Adjustment range

- This knob permits **10 rotations**.
- The **10 possible turns** at the multi-turn-potentiometer [8] <Uset> always correspond to the range 0 V to Ulim
- The **lower Ulim** is set, the "finer" can low values be adjusted for Uset.
The setting accuracy specified in section 1.4.3 refers to each setting value shown.
- The indication of the voltages Uout and Uset ends at 19.99 for 20 V devices.
For **exceedingly** adjusted values, the AD converter produces an **overflow indication**:



4.2 Output current

4.2.1 Iout – Actual current measuring value

- The right digital instrument [5] <Amp> shows the actual measured value **Iout** which is the value of the flowing output current.
- When the output current is superposed with AC signals, the display shows the arithmetic average value.
- The 3½ digit display is updated approximately three times per second; overflow indication if values exceed 19.99 A on 20 A devices.

☞ Regarding measuring range, measuring resolution and measuring accuracy see section 1.4.3 Electrical Data.

4.2.2 Ilim – Limit value for Iset

Function

- Upper limit value for current setting range of <Iset> [10].
- Protection against **unintentional** too high adjustment of the current setting value Iset.
- When inserting **Ilim = 0 A** (left strike), the current control <Iset> is **inefficient** (e.g. when setting the output current via the analog interface).

Adjustment of Ilim

- Setting the limit value for Iset is the same procedure as for setting the limit value for Uset (4.1.2)
- **Only the following adjustment and indication elements are changing:**
Left trimmer [7] <Ulim> → Right trimmer <Ilim> [11]
Left knob [8] <Uset> → Right knob <Iset> [10]
Left display [4] <Volt> → Right display <Amp> [5]

Adjustment range

- The 270° rotation angle of <Ilim> corresponds to an adjustment range $0 \text{ A} \leq I_{lim} \leq I_{nom}$.
- The **10 possible turns** at the <Iset> knob [10] always correspond to the range **0 A to Ilim**.

4.2.3 Iset – Current setting value

Function

- Setting value of the output current (limiting).

Adjustment of Iset

- Setting the setting value for Iset is the same procedure as for setting the setting value for Uset (4.1.3)
- **Only the following adjustment and indication elements are changing:**
Left knob [8] <Uset> → Right knob <Iset> [10]
Left display [4] <Volt> → Right display <Amp> [5]

CAUTION!

The value for Iset can also be changed if the KONSTANTER is not activated.

Adjustment range

- The **10 possible turns** at the <Iset> knob [10] always correspond to the range **0 A to Ilim**.
- The **lower Ilim** is set, the "finer" can low values be adjusted for Iset.
The setting accuracy specified in section 1.4.3 refers to each setting value shown.
- The indication of the voltages Iout and Iset ends at 19.99 for **20 V devices**.
For **exceedingly** adjusted values, the AD converter produces an **overflow indication**:



4.3 OUTPUT – Switching on/off of the power output

- The power output is switched on/off by the red <OUTPUT> key [9].
- Pressing this key activates resp. deactivates the power output.
OUTPUT OFF → OUTPUT ON
OUTPUT ON → OUTPUT OFF
- During adjustment of Uset/Ulim/Iset/Ilim, you can switch the power output off to avoid damages at the connected load by unintentionally setting the values exceedingly high.
- If the power output is deactivated "OUTPUT OFF", the regulation mode indicators are switched off.
- If the output was deactivated by the **overtemperature protection**, the **yellow LED "Pmax" [3]** illuminates. The output cannot be reactivated before the KONSTANTER has reached its normal operation temperature.
- **Further functions which may deactivate the power output:**

✗ External control signal to TRG IN at the analog interface (see Section 5.1 and 5.3)

✗ **Overvoltage protection** will react as soon as the voltage at the output terminals exceeds 125 % of Unom
Cause:

- **Output voltage** is set **too high** by the Uset control signal at the analog interface
- **Voltage transients** when switching inductive consumers
- **Homopolar voltage feedback** of connected consumers (for instance DC motors) or of parallel-connected voltage sources
- **Remote sensing**: sensor lines are **reverse** connected or a **load line** is/has been **interrupted**.

In this case the indication "CV" for constant voltage operation **continues to illuminate** whereas the displayed measured output voltage drops to zero. The **analog interface SIG1OUT** signalizes „OUTPUT OFF“.

The output can be reactivated after the cause for overvoltage has been eliminated.

✗ **Overtemperature protection** reacts

Cause:

- **Obstructed cooling**, for instance by covering the air intake or outlet holes.
- **Ambient temperature** or **load** is too high; the instrument is able to give its nominal power in a permanent operation up to 40 °C (measured at the air inlet).
- The integrated fan is defective.

After having cooled down sufficiently, the output is re-activated automatically.

CAUTION!

The output terminals are not galvanically insulated by switching the output off.

5 Control via analog interface

5.1 Pin assignment

SIG1 OUT, SIG2 OUT (output)

- Digital status signal outputs referred to AGND
- **SIG1 OUT** signalizes the status of the power output
- **SIG2 OUT** signalizes the actual regulation mode
- Kind of signal Open Collector
- Max. OFF voltage 30 V DC
- Max ON current 20 mA

☞ Detailed description in section 5.2

TRG IN+, TRG IN- (input)

- Floating digital control input to switch the power output ON/OFF
- Low signal: $-26 \text{ V} \leq U_s \leq +1 \text{ V}$
- High signal: $+4 \text{ V} \leq U_s \leq +26 \text{ V}$
 $I_s = (U_s - 2 \text{ V}) / 1.5 \text{ k}\Omega$

☞ Detailed description in section 5.3

+15 V (output)

- This auxiliary voltage output (14 ... 17.5 V DC referred to AGND) can be used for either to feed the TRIGGER input or also for the supply of external components (for instance reference element to produce control voltages).
- This output is electronically current-limited to approx. 60 mA and short-circuit protected against AGND.

AGND (Analog Ground = Reference point)

- Point of reference for all analog control inputs and outputs.
- By an auto-reversible fuse (rating 110 mA) this connection is internally linked with the negative terminal of the power output.

Uset-, Uset+ (input)

- Analog (differential) **voltage input** referred to **AGND** to control the output voltage. For activated output the following issues apply:
- $U_{out} = U_{SET} + U_{SU} \cdot k_{SU}$
 U_{out} : **output voltage** at constant voltage mode
 U_{SET} : **voltage setting value**, manually adjusted
 U_{SU} : **external control voltage** (0 ... 5 V \cong 0 ... $U_{out_{nom}}$)
 k_{SU} : **voltage control coefficient** = $U_{out_{nom}} / 5 \text{ V}$
 R_{SU} : **input resistance** Uset+: 10 k Ω
 Uset-: 15 k Ω

☞ Detailed description in section 5.4

Iset+ (input)

- Analog **voltage input** referred to **AGND** to control the output current. For activated output the following issues apply:
- $I_{out} = I_{SET} + U_{SI} \cdot k_{SI}$
 I_{out} : **output current** at constant voltage operation
 I_{SET} : **current setting value**, manually adjusted with <Iset> knob
 U_{SI} : **external control voltage** (0 ... 5 V \cong 0 ... $I_{out_{nom}}$)
 k_{SI} : **current control coefficient** = $I_{out_{nom}} / 5 \text{ V}$
 R_{SI} : **input resistance**: 10 k Ω

☞ Detailed description in section 5.5

U-MON (output)

- Analog voltage output, proportional to the output voltage U_{out} measured by the sensor lines (0 ... 10 V \cong 0 ... $U_{out_{nom}}$).
- The output referred to **AGND** has an output resistance of 9.8 k Ω and is **protected against short-circuiting**.

☞ Detailed description in section 5.6

I-MON (output)

- Analog voltage output, proportional to the flowing output current I_{out} (0 ... 10 V \cong 0 ... $I_{out_{nom}}$).
 - The output referred to **AGND** has an output resistance of 9.4 k Ω and is **protected against short-circuiting**.
- ☞ Detailed description in section 5.7.




Figure 5.1 Internal circuitry of analog interface and output (simplified schematic)

5.2 Status signal outputs

Function

- The KONSTANTER is equipped with two digital open collector outputs which are referred to AGND and are designed for the status signalization.
- SIG1 OUT** – signals **activation status of the power output**:
 - OUTPUT ON** = passive high (=OFF)
 - OUTPUT OFF** = active low (=ON)
 - Coupling this output with the TRIGGER input of another KONSTANTER offers the possibility to simultaneously activate resp. deactivate both KONSTANTER outputs (see section 5.8.2 and 5.9.2).
 - Being a **report signal** to surveillance equipment.
 - Controlling an external output relay**.
Since the output voltage drops very rapidly (< 1 ms) if **OUTPUT ON** → **OFF**, the relay can switch off-load with passive consumers.
- SIG2 OUT** – signals the **actual regulation mode of the power output**
 - Const. current (CC) or overload (Pmax) = active low (=ON)
 - Const. voltage (CV) or **OUTPUT OFF** = passive high (=OFF)
 - Being a **report signal** to surveillance equipment.

Connection

- Operating values
 - Max. OFF voltage 30 V DC
 - Max. ON current 20 mA
 - Low level < 1 V at $I_s \leq 20$ mA
- To produce an "active high" signal of +15 V, the status signal outputs can be linked to the +15 V terminal via the pull-up resistor R_{PU} (minimum 1 k Ω).




Figure 5.2 Example for connecting the status signal outputs

5.3 TRIGGER input

Function

- The **floating optocoupler input TRG IN** permits the **remote control** of the **OUTPUT** function by a binary control signal.
- The TRIGGER input cannot be efficient unless **OUTPUT** key has been pressed down (**ON**).
- Coupling this input with the signal output **SIG1OUT** of another **KONSTANTER** offers the possibility to simultaneously activate resp. deactivate both **KONSTANTER** outputs (see section 5.8.2 and 5.9.2)
- In **automatic test systems**, the **OUTPUT** status can be controlled by application-specific signals at the TRIGGER input.

Connection

- Connect the control signal between **TRG IN +** and **TRG IN -**. For signal levels see table.

Signal	U_s	I_s	Output
High	4 ... 26 V DC	$(U_s - 2 \text{ V}) / 1.5 \text{ k}\Omega$	OFF
Low	0 ... 1 V DC	0 mA	ON

- The +15 V output of the analog interface can be used to feed the TRIGGER input (see figure 5.3 a).

WARNING!

The TRIGGER input TRG IN is floating and functionally isolated against the output circuit.

This functional isolation is no "safe electric separation" according to the electrical safety regulations.




Figure 5.3 a Control of the TRIGGER input by a switching element




Figure 5.3 b Control of the TRIGGER input by an external signal

5.4 Remote control of the output voltage

Function

- You can set the output voltage U_{out} by an external control voltage U_{su} via the control inputs U_{set+} (non-inverting) and U_{set-} (inverting).
- The following formula is applicable for constant voltage operation:

$$U_{out} = U_{SET} + U_{su} \cdot k_{su}$$

U_{SET} : manually adjusted voltage setting value

k_{su} : voltage control coefficient = $U_{out_{nom}} / 5 \text{ V}$

Max. setting error: $\pm 0.05 \%$ of U_{nom} $\pm 2 \%$ of the setting value

- The voltage control input is constructed as differential voltage input:

U_{set+} : Non-inverting input:

$U_{su} = 0 \dots +5 \text{ V}$ for $U_{out} = 0 \text{ V} \dots U_{out_{nom}}$;
input resistance $10 \text{ k}\Omega$

U_{set-} : Inverting input:

$U_{su} = 0 \dots -5 \text{ V}$ for $U_{out} = 0 \text{ V} \dots U_{out_{nom}}$;
input resistance $15 \text{ k}\Omega$

Notes

- The **control inputs** are **not isolated**; their point of reference **AGND** is linked with the **negative terminal** of the power output.
- Connecting **earthed circuits** to the control input can lead to setting errors by leakage currents or current loops.
- If the control voltage U_{su} is referred to the **output negative terminal at load side**, the inverting input will have to be linked with this point (**link b** in figure 5.4 a). This reduces the influence produced by the voltage drop on the negative load line.
- If the **control voltage** is **isolated** against the **output**, please connect U_{set-} with **AGND** (**link a** in figure 5.4 a).
- If the **output voltage** is controlled by a **remote potentiometer**, please apply the wiring according to figure 5.4 b.
- U_{su} can also be applied as an **alternating voltage**, for instance to superpose **interference signals** upon the set continuous voltage **USET**.

The **limit frequency** of the modulated output voltage **depends** on the **voltage amplitude**.

A special regulator principle enables the limit frequency to be largely independent from the load altitude and the set current limitation.




Figure 5.4 a Wiring for control of the output voltage by external voltage

Figure 5.4 b Wiring for control of the output voltage by external potentiometer

5.5 Remote control of the output current

Function

- You can set the output current I_{out} by an external control current I_{si} via the control inputs I_{set+} and I_{set-} .
- The following formula is applicable for constant current operation:

$$I_{out} = ISET + U_{si} \cdot k_{si}$$

$ISET$: manually adjusted current setting value

k_{si} : current control coefficient = $I_{out_{nom}} / 5 \text{ V}$

Max. setting error: $\pm 0.1 \%$ of I_{nom} + 2% of the setting value

- Current control input
- I_{set+} : Non-inverting input:
 $U_{si} = 0 \dots +5 \text{ V}$ for $I_{out} = 0 \text{ A} \dots I_{out_{nom}}$;
- The input resistance is $10 \text{ k}\Omega$.

Notes

- The **control input** is **not isolated**; its point of reference **AGND** is linked with the **negative terminal** of the power output.
- Connecting **earthed circuits** to the control input can lead to setting errors by leakage currents or current loops.
- The control voltage U_{si} must not be linked **at load side** with the **output negative terminal** (figure 5.5 a).
- If the **output current** is controlled by a **potentiometer**, please apply the wiring according to figure 5.5 b.
- U_{si} can also be applied as an **alternating voltage**, for instance to superpose **interference signals** upon the set continuous current **ISET**.
The **limit frequency** of the modulated output current **depends** on the **voltage amplitude** due to the load resistance.

CAUTION!

The control inputs U_{set+} , U_{set-} and I_{set+} should always be wired with a shielded cable.

Connect this shield to the point of reference AGND.





Figure 5.5 a Wiring for control of the output current by external current

Figure 5.5 b Wiring for control of the output current by external potentiometer

5.6 Voltage monitor output

Function

- Referring to AGND, the U-MON terminal delivers a voltage U_{MU} proportional to the output voltage U_{out} .
- U-MON is the slave control voltage for the master-slave series operation (see 5.9.2).
- U-MON may also be used for measuring, surveillance or recording purposes.
- The following formula applies
 $U_{MU} = U_{out} \cdot k_{MU} \cdot k_{load} = 0 \dots 10 \text{ V}$
 $k_{MU} = 10 \text{ V} / U_{out_{nom}}$; U monitor coefficient
 $R_i(\text{U monitor}) = 9.8 \text{ k}\Omega$; U monitor output resistance

Load coefficient

$$k_{load} = \frac{R_{load}}{R_{load} + 9.8 \text{ k}\Omega}$$

R_{load} = Load resistance

Max. error of U_{MU} : $\pm 5 \text{ mV} \pm 2 \%$ of reading (for $R_{load} > 10 \text{ M}\Omega$)

Notes

- U-MON is **not isolated**; its point of reference AGND is linked with the negative terminal of the power output.
- Connecting the **earthed circuits** to the monitor outputs can lead to reading errors due to leakage currents or current loops.
- With remote sensing the voltage monitor output refers to the output voltage measured by the sensor lines (see. 2.3).
- The monitor output is **protected against short-circuit**.
 – The **output resistance** is $9.8 \text{ k}\Omega$.




Figure 5.6 Wiring voltage monitor

5.7 Current monitor output

Function

- Referring to AGND, the I-MON terminal delivers a voltage U_{MI} proportional to the output current I_{out} .
- I-MON is the slave control voltage for the master-slave parallel operation (see 5.8.2).
- I-MON may also be used for measuring, surveillance or recording purposes.
- The following formula applies
 $U_{MI} = I_{out} \cdot k_{MI} \cdot k_{load} = 0 \dots 10 \text{ V}$
 $k_{MI} = 10 \text{ V} / I_{out_{nom}}$; I monitor coefficient
 $R_i(\text{I monitor}) = 9.4 \text{ k}\Omega$; I monitor output resistance

Load coefficient

$$k_{load} = \frac{R_{load}}{R_{load} + 9.4 \text{ k}\Omega}$$

R_{load} = Load resistance

Max. error of U_{MI} : $\pm 5 \text{ mV} \pm 2 \%$ of reading (for $R_{load} > 10 \text{ M}\Omega$)

Notes

- I-MON is **not isolated**; its point of reference AGND is linked with the negative terminal of the power output.
- Connecting the **earthed circuits** to the monitor outputs can lead to reading errors due to leakage currents or current loops.
- The monitor output is **protected against short-circuit**.
 – The **output resistance** is $9.4 \text{ k}\Omega$.




Figure 5.7 Wiring current monitor

5.8 Parallel operation

If the output current of a single KONSTANTER is not sufficient for your application requirements, you may connect as many KONSTANTERs parallel as required.

CAUTION


When switching parallelly any outputs with different nominal voltages, all outputs must be limited to the lowest nominal voltage value involved. This adjustment is made by Ulim.

5.8.1 Direct parallel operation

Function

- This is the easiest possibility to supply a higher current for the load than one single KONSTANTER can deliver.
- You may use KONSTANTERs with different output ratings. However, all voltage setting values must be adjusted resp. limited to the same value.
- Not suitable for the constant voltage operation.

Wiring



----- = only for remote sensing

Figure 5.8.1 a Wiring for parallel operation

Adjustment

- Deactivate each output.
- Set the voltage setting values Uset of all KONSTANTERs involved in this parallel operation at approximately the same value.
 $U_{set} = U_{SET1} = U_{SET2} = U_{SET3} = U_{SETn}$
- Set the current setting values Iset in a way that all KONSTANTERs involved in this parallel operation have approximately the same value.
 $I_{setl} = I_{SET1} + I_{SET2} + I_{SET3} + \dots + I_{SETn}$
- Activate the outputs.

Operating principle

- Having been switched on, the KONSTANTER with the highest voltage setting supplies at first the load current.
- The more the load resistance is continuously decreased, the more the load current is steadily increased.
- As soon as the load current reaches the set value Iset for the presently loaded output, the current regulation is activated for this output.
- Reducing the load resistance further decreases the output voltage down to the point where the voltage value coincide with the next output which is set lower.
- Starting from this point, the KONSTANTER supplies a part of the load current.

- This procedure continues as long as the output with the lowest voltage setting will be reached.
- Then, this output keeps the voltage at the load constant. Should even this output lead into current regulation, the load current will be the sum current of all parallel devices and remains constant until short-circuit.




Figure 5.8.1 b Operating principle of direct parallel operation in ideal operating range for voltage regulation at the load




Figure 5.8.1 c U/I diagram at direct parallel operation

Notes

- Each output has a slightly different voltage due to the corresponding setting tolerances. In case of larger voltage differences, an electronic sink will be activated for outputs with lower voltage settings. This sink tries to reach – possibly pulsating – the lower voltage value which does neither damage the KONSTANTER nor the load. However, if problems with the load current measuring might arise, please couple the instruments in master-slave parallel operation (see section 5.8.2).
- Coupling the SIG1 outputs to the TRG inputs enables you to switch the outputs altogether on/off (see section 5.8.2)

5.9 Series operation

If the output voltage of a **single device** is not sufficient for your application requirements or if you wish to produce a \pm voltage, you may switch several **instruments in series**.

WARNING!

The maximum admissible total output voltage of the series connection is 120 V (resp. 240 V with earthed centre).

5.9.1 Direct series operation

CAUTION!

When connecting any outputs with different ratings in series, the highest current adjusted will flow through all outputs in case of a short-circuit. The internal reverse voltage protection diode, however, is only dimensioned for its own nominal current (see reverse voltage protection data section Electrical data). Therefore all current setting values must be limited to the lowest nominal current value involved. This adjustment is made by Ilim. If there are outputs with a lower nominal value, you may also connect a diode reverse-biased (D_e figure 5.9.1a) between the output terminals. This diode must be able to lead the current with the strongest output.

Function

- This is the **easiest possibility** to supply a **higher voltage** for the load than one device can deliver.
- Low time waste for the wiring.
- Not suitable for constant current operation.

Wiring




Figure 5.9.1 a Wiring for the direct series operation

Adjustment

- **Deactivate** each output.
- Set the **current setting values ISET** of all devices involved at **approximately the same value**:
 $Iset = ISET1 = ISET2 = ISET3 = ISETn$
- Set the **voltage setting values USET** of all devices involved in parallel switching at **approximately the same value**:
 $Uset = USET1 + USET2 + USET3 + \dots + USETn$
- **Activate** the outputs.

Operating principle

- The **sum of all output voltages** is offered to the consumer.
- If the connected load resistance is steadily reduced, all outputs deliver **at first the same load current**.
- As soon as the load current reaches the **lowest set current value**, the corresponding output begins to **regulate the current**.
- With further reduced load resistance this output keeps the **load current** as long **constantly** as its **output voltage** has dropped to 0 V.
- **Further reducing** the load resistance forces this output to take a **negative voltage** by the other outputs.
- Its internal **reverse voltage protection diode** will start to lead at approx. **-0.5 V**.
- Now the **load current** can rise again until the output with the **next higher current setting** switches to **current regulation**.
- This procedure will continue as long as the load current finally forces the **output with the highest current setting** into the **current regulation**.
- From this last output the current will be **kept constantly** until **short-circuit**.




Figure 5.9.1 b U/I diagram at direct series operation

Note

- Coupling the **SIG1** outputs to the **TRG** inputs enables you to switch the outputs altogether on/off (see section 5.9.2)

5.9.2 Master slave series operation

Function

The master-slave series operation offers essential **advantages** compared with the direct series operation:

- Suitable as well for constant **voltage** as also for constant **current regulation**.
- The **output parameters** (total output voltage, current limitation, output on/off) are **completely adjusted at the leading instrument** (master).
- All **KONSTANTERs** involved are **loaded equally**.

Wiring

- Define one of the devices as master instrument.
- Couple master and slave instrument(s) as shown in figure 5.9.2.
- Connect the **load lines** at the **outer points** of the **series connection**.
- **Symmetrize** each one of the **output voltages** with R_{Sym} .




Figure 5.9.2 Wiring for the master-slave series operation

- You can **simplify** and **optimize** the **symmetrization** by a combination of trimmer potentiometer and fixed resistor (metal film, $T_k \leq 50$ ppm/K) for R_{Sym} .

Slave nominal voltage	R_{Sym} nominal value	R_{Sym} combination
20 V	40 k Ω / 0.2 W	36 k Ω + 10 k Ω – trimpot
32 V	64 k Ω / 0.2 W	60 k Ω + 10 k Ω – trimpot
40 V	80 k Ω / 0.2 W	75 k Ω + 10 k Ω – trimpot
80 V	160 k Ω / 0.2 W	150 k Ω + 20 k Ω – trimpot

Adjustment

Switching on for the very first-time:

- Do not load output (idling)
- Switch on **master instrument** (line) and set:
OUTPUT off
 $USET = Uset/n$ Uset: required total output voltage
n: number of **KONSTANTERs**;
only applicable if all n instruments have the the same **nominal ratings**; see Notes
 $ISET = Iset$ required output current

- Switch on **slave 1 instrument** (line) and set:
OUTPUT on despite pressed OUTPUT key, the output at first remains inactive since it is still disabled by the master instrument via its TRG input
 $USET = 0$ V You can deactivate Uset knob by adjusting $ULIM = 0$ V
 $ISET > ISET_{master}$ The current setting value of the slave instruments must be set at least 2 % higher than that of the master instrument, for instance on maximum.

- Same procedure for all further slave instruments.
- Pressing **OUTPUT ON** on the master instrument automatically **switches on** and **controls all slave outputs**.
- Check the output voltages on the displays of the **KONSTANTERs**.
- Adjusting R_{Sym} you can **balance** the **output voltage** of each slave accurately to the output voltage of the master device. The change can immediately been seen at each corresponding display.
- Connect load.
- From now on **adjustment** and **regulation** of the (total) output parameters effect **completely** by the **master instrument**.

Switching on repeatedly

- **Any order of sequence** may be selected for off-switching the line and restart later on.

Operating principle

- The leading instrument (master) controls, with its **voltage monitor signal**, the output voltage of the next device (slave 1) via the devices **voltage control input**.
- **Slave 1** uses the same procedure as its **master device** for the following Slave 2, etc.
The sum output voltage thus is always proportional to the master's output voltage.
The leading instrument controls the **OUTPUT on/off status** of the slave devices by **coupling** the **MASTER SIG1** output with the **Slave TRG** input.

Notes

KONSTANTER with different output ratings

- Use the **KONSTANTER** with the **lowest nominal current** as master device.
- The **current setting range** of the other **KONSTANTERs** must be **limited** to this lowest nominal value by **ILIM**.
- $Uout_{Slave}$ corresponds only percentally to $Uout_{Master}$ referred to U_{nom}

Example:

Master:	SLP 120-40	U_{nom} : 40 V	I_{nom} : 6 A
	Setting:	USET : 12 V (30%)	ISET : 3 A
Slave 1:	SLP 120-20	U_{nom} : 20 V	I_{nom} : 10 A
	result:	Uout : 6 V (30%)	Iout : 3 A
Slave 2:	SLP 120-20	U_{nom} : 20 V	I_{nom} : 10 A
	result:	Uout : 6 V (30%)	Iout : 3 A

General

- If the **connections** of the analog interface and the sensor lines are **longer than 1 m**, please use **shielded cables**.
Link the **shield** with **earth/case** or **AGND**.
- The same current is flowing through all **KONSTANTER**.
Therefore the **current measuring value** of the **master instrument** suffices for the measuring of the **load current**.
In order to get the **sum output voltage**, add the **voltage measuring values** of all **KONSTANTERs** involved.

5.10 Variation of the output resistance

Function

- The output resistance of the output is nearly 0Ω in constant voltage mode.
- For some applications, for instance the **simulation of long load lines** or **weak car batteries**, you may increase the output resistance of the output.
The set (no load) output voltage is then decreasing proportionally to the increasing load current (figure 5.10 a).




Figure 5.10 a Dependence of the output voltage on the load

Standardization

- The standard-scaled curve, figure 5.10 b, is applicable for all types of this series.
- From this diagram you can see very quickly and easily which output resistance R_i will be set by which control resistance R_{ext} .
 $R_i = R_{imax} \cdot \text{indicated value}$




Figure 5.10 b Standardized diagram to fix the output resistance if provided control resistance

Wiring

- Wire the analog interface according to figure 5.10 c.
- Thus, the output resistance R_i depends on the external control resistance R_{ext} as follows:

$$R_{ext} = \frac{30 \text{ k}\Omega \times U_{nom}}{R_i \times I_{nom}} - 24,4 \text{ k}\Omega$$

Example: $U_{nom} = 40 \text{ V}$, $I_{nom} = 6 \text{ A}$, $R_i = 0.5 \Omega$
 $\implies R_{ext} = 376 \text{ k}\Omega$




Figure 5.10 c Wiring to vary the output resistance

- Table of the R_{imax} values for each device type

Device type	120-20	120-40	120-80	
R_{imax}/Ω	2.46	8.2	32.8	
Device type	240-20	240-40	240-80	320-32
R_{imax}/Ω	1.23	4.1	16.4	2.19

Ordering informations

Designation	Nom. data	Ordering no.
SLP KONSTANTER 32 N 20 R 10	20 V / 10 A / 120 W	K220A
SLP KONSTANTER 32 N 40 R 6	40 V / 6 A / 120 W	K221A
SLP KONSTANTER 32 N 80 R 3	80 V / 3 A / 120 W	K222A
SLP KONSTANTER 32 N 80 R 3	20 V / 20 A / 240 W	K222A
SLP KONSTANTER 32 N 40 R 12	40 V / 12 A / 240 W	K231A
SLP KONSTANTER 32 N 80 R 6	80 V / 6 A / 240 W	K232A
SLP KONSTANTER 32 N 32 R 18	80 V / 6 A / 240 W	K234A
SLP KONSTANTER 32 N 32 R 18	80 V / 6 A / 320 W	K234A

Accessories

Designation	Ordering no.
19" adapter 1x32N required to mount a single unit of the SSP 32 N / SLP 32 N series into a 19" rack	K990A
19" adapter 2x32N required to mount two units of the SSP 32 N / SLP 32 N series into a 19" rack	K990B
Jumper power cable, 0.4 m The cable is fitted with one 10 A appliance plug and one 10 A appliance coupling each.	K991A
This cable might be used as a "jumper" of the power supply between various devices if the latter are con- nected mechanically to a multi-channel-unit. Thus, the combined unit requires only one power cable.	

Printed in Germany · Subject to change without notice

GOSSEN-METRAWATT GMBH
D-90327 Nürnberg

Company address:
Thomas-Mann-Straße 16-20
D-90471 Nürnberg
Telefon (0911) 8602-0
Telefax (0911) 8602-669

GOSSEN
METRAWATT
CAMILLE BAUER