

## Energy Meters

U1681 ... U1689

U3681 ... U3689

3-348-832-21

8/8.00





## Safety Precautions


- Check mains voltage before placing your meter into operation, see serial plate.
- Make certain that connection cables are not damaged, and that they are free of voltage during hook-up of the meter.
- If it may be assumed that the instrument can no longer be operated safely, it must be removed from service (disconnect input voltage!). Safe operation can no longer be relied upon if the meter displays visible damage.  
Placing the meter back into operation is only permitted after the error has been detected, the meter has been repaired and subsequent testing of calibration and dielectric strength has been carried out at our plant or at an authorized service center.
- When the cover is opened voltage conducting parts may be exposed. If balancing, maintenance or repair of a live, open instrument is required, this may only be carried out by trained personnel who are familiar with the dangers involved.  
Capacitors within the meter may still be charged, even after it has been disconnected from all voltage sources.
- Insulation must be high-voltage tested with the values indicated under technical data after the meter has been repaired or serviced, and after the cover has been closed.





**Note:** Observe the connection schematic in the terminal cover.


**Attention:** Tighten screws by hand only! Tightening torque  
for current terminals (no. 1, 3, 4, 6, 7 and 9) = 2 Nm  
and for all other terminals (no. 2, 5, 8, 11, 20 ... 24) = 0.4 Nm



|   |         |         |           |         |         |           |         |         |          |                        |    |    |            |    |
|---|---------|---------|-----------|---------|---------|-----------|---------|---------|----------|------------------------|----|----|------------|----|
| 1   | 2       | 3       | 4         | 5       | 6       | 7         | 8       | 9       | 11       | 22                     | 21 | 20 | 23         | 24 |
| Current   | Current | Current | Current   | Current | Current | Current   | Current | Current |          |                        |    |    |            |    |
| Voltage   |         | Voltage |           | Voltage |         | Voltage   |         |         |          |                        |    |    |            |    |
| <b>L1</b>   |         |         | <b>L2</b> |         |         | <b>L3</b> |         |         | <b>N</b> | <b>S0-Pulse Output</b> |    |    | <b>LON</b> |    |
| <b>Inputs</b>   |         |         |           |         |         |           |         |         |          |                        |    |    |            |    |
| Current: $\leq 16 \text{ mm}^2$ without connector sleeve  |         |         |           |         |         |           |         |         |          |                        |    |    |            |    |
| Voltage: $\leq 2,5 \text{ mm}^2$ with connector sleeve or<br>$\leq 2 \times 1,5 \text{ mm}^2$ without connector sleeve  |         |         |           |         |         |           |         |         |          |                        |    |    |            |    |
| <div style="display: flex; justify-content: space-between;"> <span><math>\leq 2,5 \text{ mm}^2</math> mit with connect. sleeve or<br/><math>\leq 2 \times 1,5 \text{ mm}^2</math> without connect. sleeve</span> <span><math>\leq 2,5 \text{ mm}^2</math> mit with connect. sleeve or<br/><math>\leq 2 \times 1,5 \text{ mm}^2</math> without connect. sleeve</span> </div> |         |         |           |         |         |           |         |         |          |                        |    |    |            |    |

### 3 Pulse Output

| Electrical Values |              |
|-------------------|--------------|
| Pulse Duration    | 100 ms + 50% |
| Interpulse Period | > 50 ms      |
| $U_{\text{ext}}$  | max. 40 V    |
| Switching Current | max. 27 mA   |



### 4 LED

The **Status LED** lights up briefly each time the counter is activated. The LED blinks with approx. 1 Hz to indicate incorrect phase sequencing (4-wire three-phase current only), and lights up or "flickers periodically" to indicate phase failure (3- or 4-wire).

The **Bez LED** blinks to indicate energy import.

The **Abg LED** blinks to indicate energy export.

The **LON LED** shows the function of the LON bus.

The **start-up LED** left from the counter (meters without LON bus only) allows for a accelerated start-up and open-circuit test.

## 5 LON

### 5.1 Cable Lengths for LON Bus Connections

| Double End Bus Termination and Bus Network Wiring |  |   |
|---|--|---|
| Cable Type  | Max. Bus Length for use with FTT-10 or FTT-10A transceiver | Max. Bus Length for use with FTT-10, FTT-10A and LPT-10 transceiver |
| Belden 85102                                      | 2700 m   | 2200 m  |
| Belden 8471                                       | 2700 m   | 2200 m  |
| Level IV, 22 AWG                                  | 1400 m   | 1150 m  |
| JY (St) Y 2 x 2 x 0.8                             | 900 m  | 750 m   |

| Single End Bus Termination and Point-to-Point Wiring |                                   |                         |
|--|-----------------------------------|-------------------------|
| Cable Type   | Max. Bus Length from node to node | Max. Overall Bus Length |
| Belden 85102   | 500 m                             | 500 m                   |
| Belden 8471  | 400 m                             | 500 m                   |
| Level IV, 22 AWG                                     | 400 m                             | 500 m                   |
| JY (St) Y 2 x 2 x 0.8                                | 320 m                             | 500 m                   |

### 5.2 System State Variables

#### Status

A node responds to the query `nviRequest` by sending its status (status and error bits) to the network as system state variable `nvoStatus`.

The following bits are used:

- unsigned out\_of\_limits becomes 1 where  $P > P_{max}$
- unsigned open\_circuit becomes 1 for phase failure
- unsigned electrical\_fault becomes 1 for incorrect phase sequence
- unsigned fail\_self\_test becomes 1 for internal error

### Transmission Conditions for System State Variables

The transmission status for a new value is determined via MaxSendTime, MinSendTime and MinDelta. A new value is only transmitted if its deviation from the last value is equal to at least MinDelta, and if MinSendTime has elapsed. If a value is not changed, or if its change does not exceed the MinDelta threshold, it is transmitted after MaxSendTime.

### Measurement Value Storage

If system status variable nvi01SetTime is transmitted to the meter, the meter stores its current readings together with a time stamp to permanent internal memory.

### Nodes

| nv# | System State Variable | Data Type        | Comment                        |
|-----|-----------------------|------------------|--------------------------------|
| 0   | nviRequest            | SNVT_obj_request | status query                   |
| 1   | nvoStatus             | SNVT_obj_status  | status message                 |
| 2   | nvo00NodeType         | SNVT_str_asc     | device type                    |
| 3   | nvo00Version          | SNVT_count       | software version               |
| 4   | nvo00Date             | SNVT_time_stamp  | date of manufacture            |
| 5   | nvo00Voltage          | SNVT_volt        | Ur                             |
| 6   | nvo00Current          | SNVT_amp         | Ib                             |
| 7   | nci00StsMaxSendT      | SNVT_elapsed_tm  | adjustable from 1 s ... 18 hr. |

## Energy Meter with Pulse Output

| nv# | System State Variable | Data Type       | Comment  |
|-----|-----------------------|-----------------|--|
| 8   | nvo01EnergyInL        | signed long whr | energy import in Wh  |
| 9   | nvo01EnergyInF        | SNVT_elec_whr_f | energy import in Wh  |
| 10  | nvo01EnergyOutL       | signed long whr | energy export in Wh  |
| 11  | nvo01EnergyOutF       | SNVT_elec_whr_f | energy export in Wh  |
| 12  | nvo01PulseRate        | SNVT_count      | 1 ... 10000 pulses / kWh for pulse outputs                 |
| 13  | nvi01SetTime          | SNVT_time_stamp | time stamp triggers storage of meter readings              |
| 14  | nvo01TimeStamp        | SNVT_time_stamp | time stamp   |
| 15  | nvo01EnergyInLp       | signed long whr | energy import in Wh at time of nvo01TimeStamp              |
| 16  | nvo01EnergyInFp       | SNVT_elec_whr_f | energy import in Wh at time of nvo01TimeStamp              |
| 17  | nvo01EnergyOutLp      | signed long whr | energy export in Wh at time of nvo01TimeStamp              |
| 18  | nvo01EnergyOutFp      | SNVT_elec_whr_f | energy export in Wh at time of nvo01TimeStamp              |
| 19  | nci01MaxSendT         | SNVT_elapsed_tm | adjustable from 1 s ... 18 hr.                             |
| 20  | nci01MinSendT         | SNVT_elapsed_tm | adjustable from 1 s ... 18 hr.                             |
| 21  | nci01MinDeltaF        | SNVT_elec_whr_f | measurement value deviation adjustable from 1 Wh ... 1 MWh |



## Power Meter

| nv# | System State Variable | Data Type       | Comment  |
|-----|-----------------------|-----------------|--|
| 22  | nvo02Power            | SNVT_power_f    | instantaneous power  |
| 23  | nci02MaxSendT         | SNVT_elapsed_tm | adjustable from 1 s ... 18 hr.                             |
| 24  | nci02MinSendT         | SNVT_power_f    | adjustable from 1 s ... 18 hr.                             |
| 25  | nci02MinDelta         | SNVT_power_f    | measurement value deviation adjustable from 1 W ... 100 kW |

## Status Query Object

| Definition          | Node | Energymeter | Powermeter |
|---------------------|------|-------------|------------|
| object_id           | 0000 | 0001        | 0002       |
| object_request Code | 00   | 00          | 00         |
|                     | 02   | 02          | 02         |
|                     | 05   | 05          | 05         |

object\_request Code:

- 00 RQ\_NORMAL supplies status message for the chosen object (see following page)
- 02 RQ\_UPDATE\_STATUS supplies status message for the chosen object (see following page)
- 05 RQ\_REPORT\_MASK supplies bit mask of the bits used for the chosen object

## Status Message

| Bit Number. | Definition       | Description                   |
|-------------|------------------|-------------------------------|
| 31          | invalid_id       | invalid object_id             |
| 30          | invalid_rq       | invalid object_request Code   |
| 28          | out_of_limits    | $P > P_{max}$                 |
| 27          | open_circuit     | phase failure                 |
| 21          | electrical_fault | rotating field error          |
| 18          | fail_self_test   | Internal error                |
| 12          | report_mask      | mask of supported status bits |

## 6 Power Consumption

| Voltage Circuit     |                  |
|---------------------|------------------|
| 2-Wire Meter        | < 5 VA           |
| 3 and 4-Wire Meters | < 3 VA per phase |
| Current Circuit     |                  |
| at $I_{max}$        | < 1 VA           |
| at $I_B = 1 A$      | < 0.05 VA        |
| at $I_B = 5 A$      | < 0.5 VA         |
| at $I_B = 10 A$     | < 0.02 VA        |

## 7 Mounting the Terminal Cover

If the terminal cover is open, it can be easily removed or installed. The terminal cover must be swung out 90° from its closed position. The side panels can then be lifted, one after the other, with the guide slots over the fixed axle studs.

## 8 Inscription Label

The CT and VT factors, as well as their product types, can be entered onto the inscription label beneath the serial plate (see serial plate key on page 3). To this end, the inscription label can be withdrawn from the corresponding slot, provided the terminal cover is open.

## 9 Sealing

### 9.1 Housing Seal

The housing seal is attached to the back panel of the housing. Two drill holes are provided for this purpose, which are located above the hole pattern.

Repairs within the housing may only be undertaken by **GOSSEN-METRAWATT service** or authorized service centers.

### 9.2 Terminal Cover Seal

The terminal cover seal is attached at the left or the right hand side of the terminal cover.

---

Printed in Germany • Subject to change without notice

GOSSEN-METRAWATT GMBH  
Thomas-Mann-Str. 16-20  
90471 Nürnberg, Germany  
Phone +49 911 8602-0  
Fax +49 911 8602-669  
e-mail: [info@gmc-instruments.com](mailto:info@gmc-instruments.com)  
<http://www.gmc-instruments.com>

