

---

# Contents

|                         |    |
|-------------------------|----|
| Using this Manual ..... | ii |
| Safety Symbols .....    | x  |

## 1 Troubleshooting

|   |      |
|---|------|
| Which Firmware relates to which Ink system? .....   | 1-2  |
| How do I Check the Hard Disk Drive Version?<br>(Only applicable to HP DesignJet 2500CP/3500CP) .....                                    | 1-2  |
| Is the Printer Using the Latest Firmware Revision? .....  | 1-2  |
| How do I upgrade the Firmware Revision on the Flash SIMM? .....   | 1-3  |
| How do I upgrade the PostScript Revision on the Flash SIMM? .....   | 1-4  |
| How can I Copy Firmware Data from One Flash SIMM<br>to a Second Flash SIMM? .....   | 1-6  |
| What Can I do when a System Error Code Appears<br>on the Front-Panel Display? .....   | 1-7  |
| Have you performed a Service Test on the Failed Component/Assembly? .....   | 1-7  |
| Have you Performed the Necessary Service Calibrations? .....  | 1-8  |
| What can I do to Solve Image Quality Problems? .....  | 1-8  |
| What can I do if the Carriage is Noisy? .....   | 1-9  |
| What can I do if the Service Station is Noisy? .....  | 1-9  |
| What can I do if the Printer continuously rejects Printheads? .....   | 1-9  |
| What can I do if the Printer has problems with Media Loading? .....   | 1-9  |
| What can I do if the Cover Sensors aren't Working? .....  | 1-10 |
| What can I do if the "Switch Power Off / Check Printhead Path"<br>message appears when the Printer is about to cut or is cutting? ..... | 1-10 |
| What can I do if the Bail Assembly does not lower all the way? .....  | 1-10 |
| What can I do if the "Lens Maintenance" message<br>appears on the Front-Panel? .....  | 1-10 |
| Troubleshooting Media Jams/Printhead Crashes .....  | 1-10 |
| What can I do if the Printer does not Power ON? .....   | 1-12 |
| What can I do if the Line Sensor has Problems Detecting Media? .....  | 1-12 |
| What is the Ink System? .....   | 1-13 |
| How Do I Troubleshoot the Ink System? .....   | 1-13 |
| Does the Customer have Mid-Print Refill Problems in<br>HP DesignJets 3500CP/3000CP? .....   | 1-15 |
| How Do I Clean the Electrical Contacts? .....   | 1-17 |
| How Do I Print some of the Internal Prints? .....   | 1-18 |
| The Service Print .....   | 1-18 |
| The Usage report .....  | 1-19 |
| The PostScript Config .....   | 1-20 |
| How to Navigate through the Front-Panel Menu on<br>HP DesignJets 2500CP and 2000CP .....  | 1-21 |

## 2 System Error Codes

|                      |           |      |
|----------------------|-----------|------|
| System Error: 0000D8 | XXXXXXXXX | 2-3  |
| System Error: 010020 |           | 2-3  |
| System Error: 010021 | XXXXXXXXX | 2-4  |
| System Error: 010022 |           | 2-4  |
| System Error: 010023 |           | 2-5  |
| System Error: 010024 |           | 2-5  |
| System Error: 010030 |           | 2-5  |
| System Error: 010031 |           | 2-6  |
| System Error: 010032 | 000000XX  | 2-7  |
| System Error: 010033 |           | 2-8  |
| System Error: 010034 | 000X0000  | 2-8  |
| System Error: 010035 | 0XABCDEF  | 2-9  |
| System Error: 010036 |           | 2-10 |
| System Error: 010036 | 0000XX00  | 2-11 |
| System Error: 010037 |           | 2-12 |
| System Error: 010038 |           | 2-12 |
| System Error: 010039 |           | 2-13 |
| System Error: 010040 |           | 2-13 |
| System Error: 010041 |           | 2-13 |
| System Error: 010042 | 0000000X  | 2-14 |
| System Error: 010043 |           | 2-15 |
| System Error: 010100 |           | 2-16 |
| System Error: 010101 |           | 2-16 |
| System Error: 010102 |           | 2-16 |
| System Error: 010110 |           | 2-17 |
| System Error: 010111 |           | 2-17 |
| System Error: 010120 |           | 2-18 |
| System Error: 010121 |           | 2-18 |
| System Error: 020000 |           | 2-19 |
| System Error: 020001 |           | 2-20 |
| System Error: 020002 |           | 2-21 |
| System Error: 020003 |           | 2-22 |
| System Error: 020004 |           | 2-23 |
| System Error: 020005 |           | 2-24 |
| System Error: 020006 |           | 2-25 |
| System Error: 020010 |           | 2-25 |
| System Error: 020011 |           | 2-26 |
| System Error: 040xxx |           | 2-26 |
| System Error: 040601 |           | 2-27 |
| System Error: 050000 |           | 2-27 |
| System Error: 060000 |           | 2-28 |
| System Error: 060100 |           | 2-28 |
| System Error: 060200 |           | 2-28 |
| System Error: 060300 |           | 2-29 |
| System Error: 060400 |           | 2-29 |
| System Error: 060500 |           | 2-29 |
| System Error: 07xxxx | XXXXXXXXX | 2-29 |
| System Error: 08xxxx |           | 2-30 |
| System Error: 080001 |           | 2-30 |
| System Error: 09xxxx |           | 2-31 |

|   |      |
|---|------|
| System Error: 090004 .....                    | 2-31 |
| Error Message: Ink System Error XX-YYYY ..... | 2-31 |

### 3 User Messages

|  |     |
|--|-----|
| User Messages for HP DesignJets 2500CP and 2000CP with Firmware<br>Version A.02.14 or Higher and HP DesignJets 3500CP and 3000CP ..... | 3-2 |
|--|-----|

### 4 Service Tests

|  |      |
|--|------|
| Introduction .....   | 4-2  |
| Diagnostics - Self Test .....                              | 4-2  |
| Initialization Sequences .....                             | 4-2  |
| Service Tests (Diagnostics) .....                          | 4-3  |
| Entering the Service Tests (Diagnostics) Menu System ..... | 4-5  |
| D01. Electronics .....                                     | 4-6  |
| D02. Line Sensor .....                                     | 4-9  |
| D03. Carriage Axis (Y-axis) .....                          | 4-11 |
| D04. Media Axis (X-axis) .....                             | 4-13 |
| D05. Service Station .....                                 | 4-15 |
| D06. Refill .....  | 4-16 |
| D07. Front Panel .....                                     | 4-17 |
| D08. Sensors .....   | 4-18 |
| D09. MIO Presence .....                                    | 4-21 |
| D10. Cutter .....  | 4-22 |
| D11. Bail .....  | 4-23 |
| D12. Image Quality .....                                   | 4-24 |
| D13. Printhead ID .....                                    | 4-26 |
| D14. Printhead Continuity .....                            | 4-27 |
| D15. Clean Roller .....                                    | 4-28 |
| D16. Erase EEROM .....                                     | 4-29 |
| D17. Reset Counters .....                                  | 4-30 |
| D19. Hard Disk Drive Revision (Only 2500CP/3500CP) .....   | 4-31 |

### 5 Service Calibrations

|  |      |
|--|------|
| Service Calibrations .....   | 5-3  |
| Entering the Service Calibrations Menu System .....                      | 5-5  |
| C01. Carriage .....  | 5-6  |
| C02. Refill .....  | 5-8  |
| C03. Line Sensor .....   | 5-9  |
| C04. Service Station .....   | 5-11 |
| C05. Printheads Alignment .....  | 5-12 |
| C06. Printheads Check .....  | 5-13 |
| C07. Color Calib. (Only available in DesignJet 2500CP/3500CP printer) .. | 5-15 |
| C08. Service Accuracy .....  | 5-16 |
| C09. Maintenance .....   | 5-18 |
| C10. Font Type Set (Only available in DesignJet 2500CP/3500CP printer)   | 5-19 |

## 6 Image Quality

|  |      |
|--|------|
| Image Quality Troubleshooting Checklist .....              | 6-2  |
| Print Modes .....  | 6-4  |
| Image Quality Print .....                                  | 6-5  |
| Introduction .....   | 6-5  |
| Using the Image Quality Print .....                        | 6-5  |
| Producing the Image Quality Print .....                    | 6-5  |
| Analyzing the Image Quality Print .....                    | 6-7  |
| No Printing Defects Found in the Image Quality Print ..... | 6-17 |
| Media .....  | 6-17 |
| Print Quality Problems .....                               | 6-18 |

## 7 Parts List

|   |      |
|---|------|
| Printer Support (HP DesignJets 2500CP and 2000CP Only) .....      | 7-4  |
| Printer Support (HP DesignJets 3500CP and 3000CP Only) .....      | 7-6  |
| Right Hand Cover Area .....                                       | 7-8  |
| Left Hand Cover Area .....  | 7-10 |
| Printer Rear (HP DesignJets 2500CP and 2000CP Only) .....         | 7-12 |
| Printer Rear (HP DesignJets 3500CP and 3000CP Only) .....         | 7-14 |
| Electronics Module (Internal) .....                               | 7-16 |
| Y-axis Assembly .....   | 7-18 |
| Elevator Assembly .....   | 7-24 |
| Refill Assembly .....   | 7-26 |
| Carriage Assembly .....   | 7-28 |
| Roll Cover Area .....   | 7-30 |
| Service Station Assembly Area .....                               | 7-32 |
| X-axis Motor Assembly .....                                       | 7-34 |
| Drive Roller Area (HP DesignJets 2500CP and 2000CP Only) .....    | 7-36 |
| Drive Roller Area (HP DesignJets 3500CP and 3000CP Only) .....    | 7-38 |
| Entry Platen Area .....   | 7-40 |
| Pincharm Assembly .....   | 7-42 |
| Refill Interconnect PCA and Cutter Assembly .....                 | 7-44 |
| Media Button (HP DesignJets 3500CP and 3000CP Only) .....         | 7-46 |
| Compatible Documentation .....                                    | 7-48 |
| Front Panel Overlays (HP DesignJets 2500CP and 2000CP Only) ..... | 7-51 |
| Front Panel Overlays (HP DesignJets 3500CP and 3000CP Only) ..... | 7-51 |
| Interface Cables .....  | 7-52 |
| Plug-in memory (DRAMM SIMM) .....                                 | 7-52 |
| Ink Delivery Systems .....  | 7-52 |

## 8 Removal and Installation

|   |     |
|---|-----|
| Introduction .....                              | 8-3 |
| Safety Precautions .....                        | 8-4 |
| Electrostatic Discharge (ESD) Precautions ..... | 8-4 |
| Required Tools .....                            | 8-5 |
| Electronics Module .....                        | 8-6 |
| Removal .....                                   | 8-6 |
| Installation .....                              | 8-7 |

|   |      |
|---|------|
| Additional Rear Cover<br>(Only applicable to HP DesignJets 3500CP and 3000CP) ..... | 8-10 |
| Removal .....   | 8-10 |
| Installation .....  | 8-10 |
| Hard Disk Drive, Power Switch Cable .....   | 8-12 |
| Removal .....   | 8-12 |
| Installation .....  | 8-13 |
| Window and Top Cover .....  | 8-15 |
| Removal .....   | 8-15 |
| Installation .....  | 8-15 |
| Left Hand Cover and Left Hand Trim Assembly .....                                   | 8-18 |
| Removal .....   | 8-18 |
| Installation .....  | 8-19 |
| Right Hand Cover and Right Hand Trim Assembly .....                                 | 8-21 |
| Removal .....   | 8-21 |
| Installation .....  | 8-22 |
| Front Panel and Stand-by Button .....   | 8-24 |
| Removal .....   | 8-24 |
| Installation .....  | 8-24 |
| Service Station Assembly and Service Station Flag .....                             | 8-26 |
| Removal of the Service Station Assembly .....                                       | 8-26 |
| Removal of the Service Station Flag .....   | 8-26 |
| Installation of the Service Station Assembly .....                                  | 8-27 |
| Installation of the Service Station Flag .....                                      | 8-27 |
| Primer Assembly (Only Applicable to HP DesignJets 2500CP/2000CP) .....              | 8-29 |
| Removal .....   | 8-29 |
| Installation .....  | 8-30 |
| Encoder Strip .....   | 8-32 |
| Removal .....   | 8-32 |
| Installation .....  | 8-33 |
| Trailing Cable .....  | 8-36 |
| Removal .....   | 8-36 |
| Installation .....  | 8-37 |
| Y-Axis Belt .....   | 8-39 |
| Removal .....   | 8-39 |
| Installation .....  | 8-40 |
| Carriage Assembly .....   | 8-42 |
| Removal .....   | 8-42 |
| Installation .....  | 8-43 |
| Y-Axis Motor Assembly .....   | 8-45 |
| Removal .....   | 8-45 |
| Installation .....  | 8-46 |
| Cutter Assembly (Only Applicable to HP DesignJets 2500CP and 2000CP) .....          | 8-48 |
| Removal .....   | 8-48 |
| Installation .....  | 8-48 |
| Cutter Assembly (Only Applicable to HP DesignJets 3500CP and 3000CP) .....          | 8-50 |
| Removal .....   | 8-50 |
| Installation .....  | 8-50 |
| Elevator Assembly .....   | 8-52 |
| Removal .....   | 8-52 |
| Installation .....  | 8-53 |

|   |      |
|---|------|
| Refill Assembly .....   | 8-55 |
| Removal .....   | 8-55 |
| Installation .....  | 8-56 |
| Bail Assembly and Star Wheel Assemblies .....   | 8-58 |
| Removal .....   | 8-58 |
| Installation .....  | 8-58 |
| Starguard Assembly .....  | 8-60 |
| Removal .....   | 8-60 |
| Installation .....  | 8-60 |
| Bail Stepper Motor .....  | 8-62 |
| Removal .....   | 8-62 |
| Installation .....  | 8-62 |
| Refill Interconnect PCA .....   | 8-64 |
| Removal .....   | 8-64 |
| Installation .....  | 8-64 |
| X-Axis Assembly .....   | 8-66 |
| Removal .....   | 8-66 |
| Installation .....  | 8-67 |
| Overdrive Assembly and Drive Roller<br>(Only Applicable to HP DesignJets 2500CP and 2000CP) ..... | 8-69 |
| To remove the Drive Roller only .....   | 8-69 |
| Installation of the drive roller .....  | 8-70 |
| Installation of the overdrive assembly .....  | 8-70 |
| Overdrive Assembly and Drive Roller<br>(Only Applicable to HP DesignJets 3500CP and 3000CP) ..... | 8-72 |
| To remove the Drive Roller only .....   | 8-72 |
| Installation of the drive roller .....  | 8-73 |
| Installation of the overdrive assembly .....  | 8-73 |
| Entry Platen .....  | 8-78 |
| Removal .....   | 8-78 |
| Installation .....  | 8-79 |
| Roll Cover and Roll Feed Assemblies .....   | 8-81 |
| Removal .....   | 8-81 |
| Installation .....  | 8-82 |
| Pincharm Assemblies, Pincharm Shaft and Pincharm Sensor .....                                     | 8-84 |
| Removal of the pincharm sensor .....  | 8-84 |
| Removal of the pincharm assemblies and the pincharm shaft. ....                                   | 8-84 |
| Installation of the pincharm sensor. ....   | 8-85 |
| Installation of the pincharm assemblies and the pincharm shaft. ....                              | 8-85 |
| Interconnect Cables .....   | 8-87 |
| Removal of the refill interconnect cable. ....  | 8-87 |
| Removal of the service station interconnect cable. ....   | 8-87 |
| Installation of the service station interconnect cable .....                                      | 8-88 |
| Installation of the refill interconnect cable .....   | 8-88 |
| Media Button (Only Applicable to HP DesignJets 3500CP and 3000CP) .....                           | 8-90 |
| Removal .....   | 8-90 |
| Installation .....  | 8-90 |

## 9 Preventive Maintenance

|                               |     |
|-------------------------------|-----|
| Moisture on the Printer ..... | 9-2 |
|-------------------------------|-----|

|  |     |
|--|-----|
| Noisy Carriage Bushing .....                               | 9-2 |
| Belt Swelling .....  | 9-2 |
| Cleaning the Printer .....                                 | 9-2 |
| General Cleaning .....                                     | 9-2 |
| Cleaning the Drive Roller .....                            | 9-3 |
| Cleaning the Electrical Contacts? .....                    | 9-4 |
| Scheduled Maintenance .....                                | 9-4 |
| Level of Printer Usage .....                               | 9-4 |
| Preventive Maintenance Kit - Part Number C4704-60198 ..... | 9-5 |
| Y-axis Maintenance Parts .....                             | 9-5 |

## 10 Functional Overview

|   |      |
|---|------|
| DesignJet 2500CP-PostScript SKU .....       | 10-3 |
| DesignJet 2000CP-RTL SKU .....              | 10-3 |
| Printed Circuit Assemblies (PCA) .....      | 10-3 |
| Y-Axis Assembly .....                       | 10-4 |
| Carriage .....                              | 10-4 |
| Y-axis belt and Y-axis belt tensioner ..... | 10-4 |
| Y-axis motor assembly .....                 | 10-4 |
| Encoder Strip .....                         | 10-4 |
| Trailing cable .....                        | 10-5 |
| Service Station Assembly .....              | 10-5 |
| Primer Assembly .....                       | 10-5 |
| Refill Assembly .....                       | 10-5 |
| Elevator Assembly .....                     | 10-6 |
| X-Axis Assembly .....                       | 10-6 |
| Electronics Module .....                    | 10-6 |
| Stepper Motors .....                        | 10-7 |
| Sensors .....                               | 10-7 |
| Line Sensor .....                           | 10-7 |
| Cover Sensors .....                         | 10-7 |
| Mechanical Interface Sensors .....          | 10-8 |

---


## General Definition of Safety Symbols



International caution symbol (refer to manual): the product is marked with this symbol when it is necessary for the user to refer to the instruction manual in order to protect against damage to the instrument.




Indicates dangerous voltage (terminals fed from the interior by voltage exceeding 1000 volts must also be marked).



Protective conductor terminal. For protection against electrical shock in case of a fault. Used with field wiring terminals to indicate the terminal that must be connected to ground before operating equipment.



Low-noise or noiseless, clean ground (earth) terminal. Used for a signal common, as well as providing protection against electrical shock in case of a fault. A terminal marked with this symbol must be connected to ground in the manner described in the installation (operating) manual, and before operating the equipment.



Frame or chassis terminal. A connection to the frame (chassis) of the equipment, which normally includes all exposed metal.



Alternating current



Direct current



Alternating or direct current

---

**WARNING**

---

The WARNING sign denotes a hazard. It calls attention to a procedure, practice, or the like, which, if not correctly performed or adhered to, could result in personal injury.



Take care not to cut yourself on the encoder strip inside the plotter.

---

**CAUTION**

---

The CAUTION sign denotes a hazard. It calls attention to an operating procedure, practice, or the like, which, if not correctly performed or adhered to, could result in damage to or destruction of part or all of the product.