

# Keysight Technologies

## N5261AH60

### Millimeter Head Controller

Notice: This document contains references to Agilent. Please note that Agilent's Test and Measurement business has become Keysight Technologies. For more information, go to [www.keysight.com](http://www.keysight.com).

# Notices

© Keysight Technologies, Inc.  
2011, 2014-2016

No part of this manual may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Keysight Technologies, Inc. as governed by United States and international copyright laws.

## Trademark Acknowledgments

## Manual Part Number

N5261-90001

## Edition

Edition 1, July 2016

Supersedes: May 2016

Printed in USA

Published by:  
Keysight Technologies  
1400 Fountaingrove Parkway  
Santa Rosa, CA 95403

## Warranty

THE MATERIAL CONTAINED IN THIS DOCUMENT IS PROVIDED "AS IS," AND IS SUBJECT TO BEING CHANGED, WITHOUT NOTICE, IN FUTURE EDITIONS. FURTHER, TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, KEYSIGHT DISCLAIMS ALL WARRANTIES, EITHER EXPRESS OR IMPLIED WITH REGARD TO THIS MANUAL AND ANY INFORMATION CONTAINED HEREIN, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. KEYSIGHT SHALL NOT BE LIABLE FOR ERRORS OR FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH THE FURNISHING, USE, OR PERFORMANCE OF THIS DOCUMENT OR ANY INFORMATION CONTAINED HEREIN. SHOULD KEYSIGHT AND THE USER HAVE A SEPARATE WRITTEN AGREEMENT WITH WARRANTY TERMS

COVERING THE MATERIAL IN THIS DOCUMENT THAT CONFLICT WITH THESE TERMS, THE WARRANTY TERMS IN THE SEPARATE AGREEMENT WILL CONTROL.

## Technology Licenses

The hardware and/or software described in this document are furnished under a license and may be used or copied only in accordance with the terms of such license.

## U.S. Government Rights

The Software is "commercial computer software," as defined by Federal Acquisition Regulation ("FAR") 2.101. Pursuant to FAR 12.212 and 27.405-3 and Department of Defense FAR Supplement ("DFARS") 227.7202, the U.S. government acquires commercial computer software under the same terms by which the software is customarily provided to the public.

Accordingly, Keysight provides the Software to U.S. government customers under its standard commercial license, which is embodied in its End User License Agreement (EULA), a copy of which can be found at

<http://www.keysight.com/find/sweula>

The license set forth in the EULA represents the exclusive authority by which the U.S. government may use, modify, distribute, or disclose the Software. The EULA and the license set forth therein, does not require or permit, among other things, that Keysight: (1) Furnish technical information related to commercial computer software or commercial computer software documentation that is not customarily provided to the public; or (2) Relinquish to, or otherwise provide, the government rights in excess of these rights customarily provided to the public to use, modify, reproduce, release, perform, display, or disclose commercial computer software or commercial computer software

documentation. No additional government requirements beyond those set forth in the EULA shall apply, except to the extent that those terms, rights, or licenses are explicitly required from all providers of commercial computer software pursuant to the FAR and the DFARS and are set forth specifically in writing elsewhere in the EULA. Keysight shall be under no obligation to update, revise or otherwise modify the Software. With respect to any technical data as defined by FAR 2.101, pursuant to FAR 12.211 and 27.404.2 and DFARS 227.7102, the U.S. government acquires no greater than Limited Rights as defined in FAR 27.401 or DFAR 227.7103-5 (c), as applicable in any technical data.

## Safety Notices

### CAUTION

A CAUTION notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in damage to the product or loss of important data. Do not proceed beyond a CAUTION notice until the indicated conditions are fully understood and met.

### WARNING

A WARNING notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in personal injury or death. Do not proceed beyond a WARNING notice until the indicated conditions are fully understood and met.

## Installation & System Operation

Introduction	1
Description	2
Verifying Your Shipment	3
Test Set Accessories	3
Network Analyzer Requirements	4
System Configurations	4
General Specifications	4
Required Conditions for Accuracy Enhanced Measurement	5
Front Panel Features	6
Rear Panel Features	8
Available Fuses	10
System Accessory Information	11
Compatible Millimeter-wave Modules	13
Cable Loss Between the Test Set and the Module	16
System Configuration and Operation	18
Site Preparation	18
Protect Against Electrostatic Discharge (ESD)	18
Hardware Lock-link Installation (U3021-60001)	19
Locking and Test Set to the PNA	19
Millimeter-wave Module Cable Connections	23
Configuring the Network Analyzer Firmware	27
Typeface Key Conventions	27
Before Beginning this Section	27
Millimeter Mode	28
System Operation Verification	32
Banded System Check	32
Required Equipment	32
Preparing the Network Analyzer	33
Procedure Failures	36

## Service Information

Replaceable Parts	37
Test Set Diagrams and Graphics	38
Theory of Operation	44
Test Set Control Board (N5261-60006)	44
Interface Board (N5261-60101)	44
LED Board (N5261-60005)	44
DC Power Board (N5261-60102)	44
Power Supply (0950-4729)	45
Isolators (0955-1595)	45
LO and RF Preamplifier (5087-7750)	45
RF and LO ALC Amplifier (5087-7771)	45
Attenuator, 7 dB (0955-0242)	45
Attenuator, 6 dB (0955-0243)	45
Attenuator, 3 dB (0955-0246)	45
Coupler (0955-0148)	45
Slope Attenuator Cable Assy (N5262-20033)	46
Power Divider (N5262-80003)	46
RF Switch (5087-7733)	46
Troubleshooting the Test Set	47
Test Set Operation Check	47
Troubleshooting, DC Level	47
Power Supply and Fans	47
Over Current LEDs are On (amber)	49
Front Panel Active and Port Status LED	49
Troubleshooting, RF Level	50
LO Out Failure	51
REF IF or Test Failure	51
Test Set Operation Check	52
Required Equipment Preparation	52
Power Sensor and Power Meter Preparation	52
PNA and Test Set Preparation	52
PNA Normalization Calibration	53


Test Set I/O Commands	53
Controlling the Test Set using Test Set I/O Commands	53
Using the GPIB command processor	53
Test Set I/O Command List	54
Measure LO OUT (Gain and Power)	55
Measure RF OUT (Gain and Power)	56
Measuring Test IF and REF IF Path Loss on the N5261AH60	58
Test and Adjustment Procedures	59
Adjust RF and LO ALC Levels	60
PNA and Power Sensor Preparation	60
ALC level for RF Port 1 (Procedure A)	60
ALC level for LO (Procedure B)	61
Safety and Information	62
Introduction	62
Safety Earth Ground	62
Declaration of Conformity	62
Statement of Compliance	62
Before Applying Power	63
Connector Care and Cleaning Precautions	64
Regulatory Information	66
Instrument Markings	66
Battery Collection	68
Electrical Safety Compliance	68
EMI and EMC Compliance	68
Electrostatic Discharge Protection	69
Keysight Support, Services, and Assistance	70
Service and Support Options	70
Contacting Keysight	70
Shipping Your Product to Keysight for Service or Repair	70



# Introduction

This document describes system installation and operation of the N5261AH60 Millimeter Head Controller.

**Figure 1** 2-Port Banded Millimeter-Wave Configuration (N5261AH60)



## Description

The N5261AH60 Millimeter Head Controller was designed for use with the E836xA/B/C PNA network analyzer family and banded millimeter-wave system solutions. Banded millimeter-wave systems are made up of three types of major components: a PNA, a controller test set, and two millimeter-wave heads. These components are generally purchased separately and assembled into a system at the customer's site.

Key features of the N5261AH60:

- Primarily designed for use with E836xA/B/C PNA products with Option H11
- Designed to electrically emulate the legacy N5260A Millimeter-wave Test Set Controller
- Pulsed measurement capability not provided
- The N5250x Broadband systems (10 MHz to 110 GHz) are not supported

**Table 2 on page 4** lists compatible PNA models with required options. **Table 6 on page 15** and **Table 7 on page 15** list available millimeter-wave modules. A typical system configuration is pictured in **Figure 1 on page 1**.

In this document the N5261AH60 will be referred to as the Test Set.

This manual should be used in conjunction with the following documents:

- PNA Series Network Analyzer On-line Help System
- Millimeter-wave Technical Overview 5989-7620EN
- OML Millimeter-wave modules (N5256-90001)
- VDI Millimeter-wave modules (N5256-90002)



## Verifying Your Shipment

To verify the contents shipped with your product, refer to the “Box Content List” included with the shipment.

Inspect the shipping container. If the container or packing material is damaged, it should be kept until the contents of the shipment have been checked mechanically and electrically. If there is any physical damage, refer to **“Contacting Keysight” on page 70**. Keep the damaged shipping materials (if any) for inspection by the carrier and a Keysight Technologies representative.

### WARNING

The N5261AH60 Millimeter Head Controller and the millimeter-wave modules are sensitive to electrostatic discharge (ESD). Ground your work station before unpacking and installing the millimeter-wave modules. See **“Electrostatic Discharge Protection” on page 69**.

## Test Set Accessories

Use the tables below to verify that your shipment is complete.

**Table 1 N5261AH60 Standard Content**

√	Keysight Part Number	Description	Qty
	1250-3975	Connector Adapter, BNC f/SMA m	4
	1810-0118	Coax Termination, 50 Ohm, male (load)	1
	5061-9038	RF Cable Assy, SMA m/m	2
	8120-1839	IF Cable Assy, BNC m/m	4
	9230-0333	Envelope (Calibration Certificate)	1
	9320-6636	Functional Certificate	1
	N4011-21002	Test Set to PNA I/O Interface Cable - DSub25 m/m, 520mm (20in)	1
	N5261-90001	User's and Service Guide	1
	N5261AH60	Millimeter Head Controller Test Set	1

## Network Analyzer Requirements

The PNA Network Analyzer should be updated to the latest firmware. For firmware updates, go to:

<http://na.support.keysight.com/pna/firmware/firmware.html>

## System Configurations

**Table 1** documents all supported Network Analyzer configuration options for banded mm-wave systems using the N5261AH60 test set.

**Table 2 PNA Based Configurations**

PNA Models	PNA Options	Test Set	SRC Connects	Cable Configuration Diagrams
E8361A E8362/3/4B E8361/2/3/4C	H11, 080	N5261AH60	Rear	<a href="#">Fig. 12, Page 22</a>

The Test Set will require a Hardware Lock-Link Kit and a Millimeter Module Cable Interface Kit (U30215 opt 030). Refer to “[Hardware Lock-Link Installation \(U3021-60001\)](#)” on page 19.

### General Specifications

#### Environmental:

Temperature 20 to 30 °C

Altitude 9,842 ft

#### Power Requirements: Nominal

Frequency Range 50/60 Hz

Nominal Voltage Range 100/120/220/240 Vac

AC Power Max. 350 Watts

#### Weight and Dimensions:

Net Weight 10 kg (22 lb)

Dimensions  
Height: 18 cm (7.1 in)  
Width: 42.5 cm (16.75 in)  
Depth: 42.5 cm (16.75 in)

**CAUTION**

This product is designed for use in Installation Category II and Pollution Degree 2.

**Required Conditions for Accuracy Enhanced Measurement**

Accuracy-enhanced (error-corrected) measurements require the ambient temperature of the Millimeter Wave measurement system to be maintained within  $\pm 1$  °C of the ambient temperature at calibration.

The instrument can safely operate in a relative humidity of 80% for temperatures to 31 degrees C, decreasing linearly to 50% relative humidity at 40 degrees C.

**CAUTION**

**Ventilation Requirements:** When installing the instrument in a cabinet, the convection into and out of the instrument must not be restricted. The ambient temperature (outside the cabinet) must be less than the maximum operating temperature of the instrument by 4 °C for every 100 watts dissipated in the cabinet. If the total power dissipated in the cabinet is greater than 800 watts, forced convection must be used.


**Table 3** Characteristics and Specifications

Front/Rear Panel Connector <sup>1</sup>	Power Levels (dBm)			Gain	Frequency
	Min	Typ	Max <sup>2</sup>		
N5261AH60					
TEST or REF IF (Input) (characteristic)	–	–27	–10	–	8.33 MHz
TEST IF to A/B/C/D IF OUTPUT (specification) See <a href="#">Figure 35 on page 57</a> .	–	–	–	–1.5 dB ( $\pm 1$ )	8.33 MHz
REF IF to A/B/C/D IF OUTPUTS (specification) See <a href="#">Figure 36 on page 57</a> .	–	–	–	–1.5 dB ( $\pm 1$ )	8.33 MHz
REF IF to R IF OUTPUTS (specification) See <a href="#">Figure 35 on page 57</a> .	–	–	–	–1.5 dB ( $\pm 1$ )	8.33 MHz
LO IN (characteristic)	–10	–	2	–	1.7 to 20 GHz
LO OUT (specification) <sup>3</sup> See <a href="#">Figure 34 on page 55</a> .	7	10	12	>14.5 dB	1.7 to 20 GHz
SRC1 RF IN (characteristic)	–16	–	5	–	1.7 to 20 GHz
RF OUT (specification) <sup>4</sup> See <a href="#">Figure 35 on page 57</a> .	7	10	12	>14.5 dB	1.7 to 20 GHz

1. All connectors are SMA female.
2. Do not exceed the maximum level or damage may occur.
3. With a –3 dBm Input, measure on the test set connector. See [Figure 34 on page 55](#).
4. ALC on and with 0 dBm Input, measure on the test set connector. See [Figure 35 on page 57](#).

# Front Panel Features

Figure 2 N5261AH60 (2-Port) Front Panel Features



### **TEST IF**

IF signal input connection from the millimeter module's Test or Measure IF Output.

### **REF IF**

Reference IF signal input connection from the millimeter module's Reference IF Output.

### **RF OUT**

Provides an amplified RF source signal to the millimeter-wave module's RF Input.

### **LO OUT**

Provides amplified LO signal to the millimeter-wave module's LO Input.

### **Port Status LEDs**

The amber LEDs indicate which source port is active. The green LEDs indicate which receiver port is active. In normal operation both receiver LEDs are always ON.

### **DC Power (Bias)**

This bias supplies the +12 Vdc and ground lines for OML millimeter-wave modules. Pins 1 and 3 are both +12 Vdc supplies. Pins 4 and 6 are the dc supply ground lines. Pins 2, 5, and 7 are unused. The DC power connections are intended for use with OML modules.

### **DC Power/Over Current LEDs**

The green LEDs indicate that the DC power bias is on. The amber LEDs indicate an over current condition.

### **Standby Switch**


The switch is only a Standby switch, not a AC line power switch.

### **Active LED**

When the test set is connected and addressed by a analyzer, the LED is On (illuminated). The LED is Off (not illuminated) when the test set is in Standby, or not addressed by the analyzer.

## Rear Panel Features

Figure 3 N5261A Rear Panel Features



### **IF OUTPUTs – SMA (female)**

- D (from the test set to the analyzer's IF R2 Input)
- C (from the test set to the analyzer's IF R1 Input)
- A (from the test set to the analyzer's IF A Input)
- B (from the test set to the analyzer's IF B Input)

### **LO IN**

This input is from the LO drive of the analyzer. The signal is split and amplified and then output to the front panel of the N5261AH60.

### **SRC 1 RF IN**

Test set rear panel RF Input access for use with the analyzer's SRC 1 provides the power input for RF OUT Ports 1 & 2.

### **Chassis Ground**

A threaded terminal post for connecting the test set to a conductive object, cabinet or structure to ensure a common potential and reduce leakage current in a system. Requires an English 1/4-20 thread nut (0140-0084) and lock washer (2190-0067).

### **Pass Through Interface**

Connection to another test set.

### **Test Set I/O**

The test set interface connector is used to send address and data to the test set from the analyzer.

### **Line Module**

This assembly houses the line cord connection, line fuse, and line voltage selector. Remove the line module cover to replace or change the fuse. Line voltage selection is automatic and no setting is required. Recommended fuse values are printed on the rear panel of the N5261H60.

### **Power Cords**

A line power cord is supplied in one of several configurations, depending on the destination of the original shipment. Keysight can supply additional certified power cords to meet region electrical supply and receptacle configurations. Please refer to our website at: <http://www.keysight.com> for assistance in power cord selection.

## Available Fuses

- Fuse (F 5 A/250V, 2110-0709) UL listed and CSA certified.

### WARNING

For continued protection against fire hazard replace line fuse only with same type and rating. The use of other fuses or material is prohibited.

---

Figure 4

Line Fuse



### CAUTION

Verify that the premise electrical voltage supply is within the range specified on the instrument.

---



## System Accessory Information

The following tables provide information on available measurement system interface options.

**Table 4 Test Set to the Module Cable Set Options (Sold Separately)**

√	Keysight Part Number	Description	Qty
	N5261A Option 501 (1-Port Trans/Refl Cable Set (48 inches = 1.2 meter))		
	1250-2604	Coax Connector Adapter, right angle- SMA m/f	2
	8121-1221	Coax flex CA-Assy, 3.5 mm male to male, 1.2 m (48 in) - RF & LO	2
	85105-60030	Multi-Cond Flex CA-Assy, Cir 7C, 1.2 m (48 in) - DC Power Bias	1
	85105-60048	Coax flex CA-Assy, right angle- SMA m/m 1.2 m (48 in) - Ref & Test IF	2
	N5261-60019	Cable Sleeve and Marker Kit, 1.2 m (48 in)	1
	N5261A Option 502 (1-Port Trans/Refl Cable Set (79 inches = 2 meter))		
	1250-2604	Coax Connector Adapter, right angle- SMA m/f	2
	N5260-60023	Coax flex CA-Assy, 3.5 mm male to male, 2 m (79 in) - RF & LO	2
	N5260-60070	Coax flex CA-Assy, right angle SMA m/m, 2 m (79 in) - Ref & Test IF	2
	N5260-60025	Multi-Cond Flex CA-Assy, Cir 7C, 2 m (79 in) - DC Power Bias	1
	N5261-60020	Cable Sleeve and Marker Kit, 5 m (197 in)	1
	N5261A Option 503 (1-Port Trans/Refl Cable Set (118 inches = 3 meter))		
	1250-2604	Coax Connector Adapter, right angle- SMA m/f	2
	N5260-60026	Coax flex CA-Assy, 3.5 mm male to male, 3 m (118 in) - RF & LO	2
	N5260-60027	Coax flex CA-Assy, right angle SMA m/m, 3 m (118 in) - Ref & Test IF	2
	N5260-60028	Multi-Cond Flex CA-Assy, Cir 7C, 3 m (118 in) - DC Power Bias	1
	N5261-60020	Cable Sleeve and Marker Kit, 5 m (197 in)	1
	N5261A Option 505 (1-Port Trans/Refl Cable Set (197 inches = 5 meter))		
	1250-2604	Coax Connector Adapter, right angle- SMA m/f	2
	N5260-60029	Coax flex CA-Assy, 3.5 mm male to male, 5 m (179 in) - RF & LO	2
	N5260-60071	Coax flex CA-Assy, right angle SMA m/m, 5 m (179 in) - Ref & Test IF	2
	N5260-60072	Multi-Cond Flex CA-Assy, Cir 7C, 5 m (197 in) - DC Power Bias	1
	N5261-60020	Cable Sleeve and Marker Kit, 5 m (197 in)	1

**Table 5 Test Set Rackmount Front Handle Kit Options (Sold Separately)**

√	Keysight Part Number	Description	Qty
	N5262A Option 1CM (Rackmount Kit without Front Handles)		
	5063-9215	Rackmount Kit - 177.OH-without Handle	1
	N5262A Option 1CN (Front Handle Kit)		
	5063-9228	Front Handle Kit - 177.OH	1
	N5262A Option 1CP (Rackmount Kit with Front Handle Kit)		
	5063-9222	Rackmount Kit with handle- 177.OH	1

## Compatible Millimeter-wave Modules

Keysight offers millimeter modules manufactured by Olsen Microwave Labs (OML) and Virginia Diodes Inc (VDI) for use with the N5261AH60 for banded mm-wave network analyzer systems. Refer to **Table 6, “Available OML Modules,” on page 15** and **Table 7, “Available VDI Modules,” on page 15**.


Transmission/Reflection millimeter-wave modules contain an RF source multiplier, dual directional coupler, reference downconverter and a test downconverter. The Transmission/Reflection millimeter-wave module is usually the primary module of a millimeter-wave VNA system. A single Transmission/Reflection module allows the measurement of S11 reflection coefficient only. Refer to **Figure 5**.

“Receive only” millimeter-wave modules contain a test downconverter to receive the test signal from a Transmission/Reflection millimeter-wave module. The use of a Receiver module, as the second module, allows the system capability to measure S11 and S21 only.

The use of two Transmission/Reflection modules in the millimeter-wave VNA system allows for all four S-parameters to be measured. The test down converters of Transmission/Reflection modules are the receivers for the signal from the modules sources. When the two modules waveguide are connected, S11 and S21 are measured in the forward direction, S22 and S12 are measured when the signal path is reversed. If a 4-Port system is configured with Transmission/Reflection modules, all 16 S-parameter measurements can be made on a 4-Port device.

Figure 5

Module Configurations



**Table 6 Available OML Modules<sup>1 2</sup>**

Banded Freq Ranges (GHz)	Port Type	Source	Receiver	Model #	Notes
33 to 500	Waveguide	√	√	N5256AWxx	T/R Module
33 to 500	Waveguide		√	N5257ARxx	Receiver
33 to 500	Waveguide		Dual	N5258ADxx	Receiver-Dual

1. The Interface cable set is not supplied.
2. Adjustable RF Attenuator, RF & LO internal amplifiers options are available. Refer to OML millimeter-wave modules documentation (N5256-90001).

**Table 7 Available VDI Modules<sup>1 2</sup>**

Banded Freq Ranges (GHz)	Port Type	Source	Receiver	Model #	Notes
750 to 1100	Waveguide	√	√	N5262AW01-TST	T/R Module
500 to 750	Waveguide	√	√	N5256AW01-TST	T/R Module
50 to 500	Waveguide	√	√	N5262AWxx-TST	T/R Module
750 to 1100	Waveguide		√	N5262AR01-TST	Receiver
500 to 750	Waveguide		√	N5256AR01-TST	Receiver
50 to 500	Waveguide		√	N5262ARxx-TST	Receiver

1. The Interface cable set is supplied with each VDI module. Do not order cable Options 501, 502, 503 and 505.
2. These modules are compatible with the test set only. They are provided with their own power supply, do not connect to the test set DC power port. Refer to VDI millimeter-wave modules documentation (N5256-90002).

## Cable Loss Between the Test Set and the Module

If the cables between the test set and the millimeter-wave modules are longer than four feet, cable loss for the RF and LO paths may be excessive. Perform the analysis recommended below.

Determine the input power level requirements for the millimeter-wave module selected for use. Refer to the documentation included with your module. To determine the power available at the module, calculate the cable loss using **Figure 6** or **Table 8**, then subtract the cable loss from the RF and LO Out characteristic power of 10 dBm. You may also use a power meter.


A separate DC supply is recommended for OML modules if they are greater than 5 meters from the controller. A DC bias power cable, with banana plug connectors, is available for use with a separate power supply such as E3615A for OML modules. VDI modules have a DC power supply included with the module.

If you are installing an external amplifier in the LO or RF path, ensure the amplifier's input is connected to the test set, and the output is connected to the mm-wave module's LO or RF Input. Modules with internal amplifiers are available.

**Table 8** Typical Cable Insertion Loss (N5261A Options)

Cable Option	Cable Length	7 GHz	10 GHz	18 GHz
501	4 ft. (1.22 m)	1 dB	1.2 dB	1.6 dB
502	6.58 ft. (2 m)	1.65 dB	2 dB	2.65 dB
503	9.83 ft. (3 m)	2.5 dB	3 dB	4 dB
505	16.4 ft. (5 m)	4.1 dB	5 dB	6.6 dB

Figure 6 Typical RF Cable Loss (dB loss per foot)



## System Configuration and Operation

### Site Preparation

Install the instrument so that the detachable power cord is readily identifiable and is easily reached by the operator. An externally installed switch or circuit breaker (which is readily identifiable and is easily reached by the operator) should be used as the disconnecting device. The detachable power cord can also be used to disconnect the mains circuits from the mains supply before other parts of the instrument. The front panel switch is only a standby switch and is not a LINE switch.

### Protect Against Electrostatic Discharge (ESD)

This is important. If not properly protected electrostatic discharge can seriously damage your analyzer, resulting in costly repair.

#### CAUTION

To reduce the chance of electrostatic discharge, follow all of the recommendations outlined in **“Electrostatic Discharge Protection”** on page 69.

**Table 9** Power Requirements of a Standard Configuration

Standard Equipment	
Instrument	Maximum Watt
N5261AH60 Millimeter Head Controller	350
Millimeter-wave Module (OML)	(powered from controller)
Millimeter-wave Module (VDI)	175



## Hardware Lock-link Installation (U3021-60001)

If your system is to be rack mounted, this installation procedure does not have to be performed.

### **WARNING**


**The opening of covers or removal of parts is likely to expose dangerous voltages. Disconnect the instrument from all voltage sources while it is being opened.**

---

### Locking and Test Set to the PNA


1. The lock-link kit (U3021-60002) includes:
  - 5023-9253 - Lock-link kit (left, 5022-2816 & right 5022-2817), Test Set
  - 5023-0132 - Lock-link kit (left, right and screws), Analyzer
2. Remove the feet from the bottom of the analyzer.
3. Remove the 2 lower standoffs on the rear panel of the analyzer using a T20 Torx driver.

Figure 7 Rear Bottom Feet




4. Install the lower lock-links (left not shown) onto the analyzer.

Figure 8 Install Lock-links to the Analyzer




5. Remove the two upper standoffs on the rear panel of the test set using a T20 Torx driver.
6. Install the left and right lock-links onto the test set.

Figure 9 Rear Lock-links to the Test Set



7. Place the analyzer on top of the test set and ensure that the front frame of the analyzer is positioned slightly forward of the locks that are attached to the test set. Slide the analyzer back so the locks engage the front frame of the analyzer.

Figure 10 Locking the Analyzer




8. Secure the analyzer's lower lock-links to the test set's upper lock-link using the spring-loaded screws. If the analyzer's lock-links are not aligned with the screw holes, loosen the screws securing the feet to the instrument to align and tighten.

Figure 11 Lock-Link Secured



Figure 12 PNA to Test Set Connections



## Millimeter-wave Module Cable Connections

Before connecting the millimeter-wave modules, verify that the test set and the power supplies (if used) are powered down.

There are four RF cables for each T/R module. Cables provided with the VDI modules are pre-labeled. The cables for use with the OML modules come in two types, two lighter and two heavier. Use the lighter cables for the IF signals and the heavier cables for the RF and LO signals.

Figure 13 Example of OML Module Connections





Figure 14 Example of VDI Module Connections



The following detailed instructions are for connecting an OML T/R module. These instructions assume a cable dress kit (black sleeving) is available. Modify the instructions appropriately for other types of modules.

1. Prepare the cable bundle comprised of five cables listed in **Table 10**.
  - a. Complete Steps 1 through 5 of the Installation Guide from the Millimeter-wave Cable Dress Kit (document number N5260-90070 contained in kit part number N5261-60019). **DO NOT APPLY THE VELCRO ASSEMBLIES AT THIS TIME.**
2. Connect the five cables to the front panel of the controller in the following order. Use two right angle adapters (1260-2604).

**Table 10** Controller Connections

Order	Test Set	Module (OML)
1	DC POWER	+12 V
2	TEST IF	Test I.F.
3	REF IF	Ref I.F.
4	RF OUT	R.F. In
5	LO OUT	L.O. In

**Figure 15** Controller Front Panel Connections




3. Repeat step 1 and step 2 for each module in the system.

4. Select a Millimeter-wave module and place it on the work surface in front of the test set.
5. Connect the bundle of cables to the module in the following order.

Table 11 Millimeter Head Connections

Order	Module (OML)
1	+12 V
2	R.F In
3	L.O. In
4	Ref I.F.
5	Test I.F.

Figure 16 Test Head Module Connections



6. Repeat step 4 and step 5 for the remaining modules.
7. Apply Velcro assemblies to the ends of the cable sleeves.
  - a. Complete steps 6, 7 and 8 of the Installation Guide from the Millimeter-wave Cable Dress Kit (document number N5260-90070 contained in kit part number N5261-60019 and N5261-90020).
8. Position each test head in the approximate location where it will be used for measurement operations.
9. Torque all RF connections to 8 in-lb.



## Configuring the Network Analyzer Firmware

This section will describe how to set up and operate the Test Set Millimeter Head Controller with your network analyzer.

The Test Set Millimeter Head Controller is considered a “slave” instrument. A network analyzer must be used to control the test set.

### CAUTION

**Before turning on this instrument, verify that the AC supply voltage is in the specified range.**

---

### Typeface Key Conventions

The following key conventions are used throughout this document.

- [HARDKEYS] are labeled front panel keys.
- SOFTKEYS are indicated on the instrument display.

### Before Beginning this Section

Determine the multiplier factors to use for RF IN and LO IN. The factors for each head are indicated on the labels located on the top of each head (near the RF and LO connectors).

### NOTE

The maximum frequency of RF signals from the PNA rear panel is 19 GHz.

---


### Millimeter Mode

The Millimeter mode allows you to configure the system for the millimeter-wave module you are using. Refer to the analyzer’s Help menu for more information.


The following instructions assume the system has not been configured for the desired heads.

1. Connect your system and turn on all of the equipment.
2. To access the millimeter application select [System] > Configure > Millimeter Module Config...


**Figure 17** Millimeter Modular Configuration Selection



**Figure 18** Millimeter Modular Setup




**Figure 19** Millimeter Modular Setup




3. Enter the RF Multiplier number and LO Multiplier number.
4. Enter the Module Start and Stop Frequency.

**Figure 20** Millimeter Modular Setup




5. Click the New command button. In the Config Name entry dialog box, enter a title for the module then select [OK].

**Figure 21** Millimeter Modular Setup




6. When the newly entered Module is highlighted in the configuration list, select [Activate Selected Config].

**Figure 22** Millimeter Modular Setup



7. Select [OK] when the PNA application restart prompt appears.

**Figure 23** System Operation Verification



## System Operation Verification

- The Banded System Check verifies the configured system is operating correctly. It requires all system components.
- If a problem is suspected with the test set, refer to **“Service Information” on page 37** and **“Troubleshooting the Test Set” on page 47**.

### Banded System Check

The Banded System operational verification procedure confirms that the system is operating correctly. There are no hard specifications for the system measurement performance, but guidelines are provided for evaluating the system operation results.

The purpose of the Operation Check is to detect significant degradations in the system that make the performance unacceptable. The calibration kit and test environment can affect the System Operation Check results. Refer to **“Site Preparation” on page 18**.

When any part of the operator’s check provides unsatisfactory results, refer to **“Troubleshooting, RF Level” on page 50** to determine the cause of the problem.

### Required Equipment

- Waveguide Short
- Data for your mm-wave modules receivers
- 3/32 Ball Driver (OML), or 5/64 Ball Driver (VDI)
- 5/16 Open end Torque Wrench, 8 in-lb.

### PNA Settings

- 401 Points: [Sweep] > Number of Points > 401
- 1 KHz IFBW: [Sweep] > IF Bandwidth > Use down/up arrow buttons to set 1.00 KHz. [OK]

## Preparing the Network Analyzer


1. Connect the analyzer, test set and the millimeter-wave band modules as described in **“System Configuration and Operation” on page 18**.
2. Turn on the test set and the analyzer.
3. Configure the analyzer for operation with the millimeter-wave modules. Refer to **“Configuring the Network Analyzer Firmware” on page 27**. Refer to the Help menu for further information.

## Procedure

This procedure assumes that you have a Transmission/Reflection module on each port. If not, the procedure will have to be modified appropriately.

The Operational Check procedure verifies that the banded system is connected correctly and the modules, test set and analyzer are operating properly.


1. Allow the system to warm up for at least 30 minutes.
2. Attach a waveguide extension section to each module's waveguide flange port to protect the modules waveguide connector.
3. Verify that the analyzer is in Millimeter mode and that the frequency range is correct for the configured millimeter system.
4. To verify the port as a receiver, perform the following steps:
  - a. Connect a short to Port 1.
  - b. Display all receivers on the analyzer's screen using the following menu selections: [System] > Service > Utilities > Receiver Display.

**Figure 24** Millimeter Modular Setup

- c. Compare the A,1 and R1,1 traces to the data for your modules Test and Reference receivers. The general shape should be similar, but not necessarily identical to the graphics in the module documentation. Depending on the PNA model used, there may be a level shift of up to 10 dB. If a waveguide short is not connected the Test Receiver level will appear to have low amplitude.
- d. If you are using more than one Transmission/Reflection module move the short to Port 2. If you are only testing one port proceed to step 6.
- e. Compare the B,2 and R2, 2 traces to the data for your modules Test and Reference receivers for the millimeter-wave module on Port 2. The general level and shape should be similar.
- f. Select each displayed trace window and delete that trace by Trace > Delete Trace.




**Figure 25** Example: Banded Receiver Display



6. Select Trace > New Trace... and select the Receivers Tab. Check the Numerator A and R1 > [OK].

**Figure 26** Example: Two Stack Window Display



7. Next, setup a two stack window display by: Window > Arrange > Stack 2

## Procedure Failures

If the **System Operation Verification** procedure fails, perform the following procedure to isolate the problem.

Refer to the Keysight PNS Series: Firmware, Upgrades, and Support at: <http://na.support.keysight.com/pna> for further information.

To request service, please contact your local service center. In the US, call 800-829-4444. For a listing of service centers worldwide, please visit us at <http://www.keysight.com/find/service>.

1. Confirm that each piece of equipment is turned on, and all analyzer, and Module connections are correct.
2. Verify that the analyzer has the correct options for Millimeter mode operation. Refer to **“Network Analyzer Requirements” on page 4**.
3. Verify that the analyzer is in Millimeter mode for the waveguide band of the modules used.
4. If the receiver levels (A,B, C, D or R 1) fail the Banded System check refer to the Measure, Test and Reference graphs in the documentation included with the module. If the REF IF and Test IF levels are low connect the REF IF and TEST IF cables directly from the mm-wave module to the analyzer’s rear panel IF Inputs. If the levels are correct proceed to step 7. If the levels are low continue with step 5.
5. If one of the ports are working, substitute the mm-module with a known working module. If the port is still not working, measure the RF Out and LO Out power from the test set’s RF Out and LO Out connectors at the end of the cables. Replace or substitute the cables if the loss is greater than the cable specification. If the cables are not the cause, proceed to step 7.

### CAUTION

Turn off the test set before disconnecting or reconnecting the modules.

6. Confirm that the analyzer is working properly by disconnecting it from the test set and performing an Operation Verification (OP VER) in the Help menu.
7. If the analyzer is operating properly, verify the test set by performing the **“Service Information” on page 37**. If the test fails, continue to **“Troubleshooting the Test Set” on page 47**.
8. If the analyzer, test set, and modules are functioning, but the system is not operating properly, contact **“Keysight Support, Services, and Assistance” on page 70**.

# Service Information

## Part Replacement and Location Information

There are many other repair and calibration options available from the Keysight Technologies support organization. These options cover a range of service agreements with varying response times. Contact Keysight for additional information on available service agreements for this product.

## Replaceable Parts

Special options are built to order, so long lead times may be encountered when ordering replacement parts. For parts that are not listed in the following table, refer to **“Keysight Support, Services, and Assistance” on page 70.**

Description	Keysight Part Number
Millimeter Head Interface Bd	N5261-60101
DC Power Bd	N5261-60102
RF/LO Bias/ALC Bd	N5261-60103
Preamplifier Bias Bd	N5261-60104
LED Bd, Front Panel	N5261-60005
Test Set Controller Bd	N5261-60006
RF 4-way Divider	N5262-80003
RF Detector	33330-80021
Coax Cable, Sloped Attenuator	N5262-20033
DC Power Supply	0950-4729
RF Isolator, 20 GHz	0955-1595
Preamplifier	5087-7750
RF/LO Amplifier	5087-7771
Coax Attenuator (3 dB)	0955-0246
Coax Attenuator (6 dB)	0955-0243
Coax Attenuator (7 dB)	0955-0242
RF Directional Coupler (2-20 GHz)	0955-0148
RF Switch, SPDT Solid State	5087-7733
Hex Nut	0140-0084
Lock Washer	2190-0067
Fuse 5 A/250V	2110-0709
Cable, IF MUX, front panel	8121-0150
Cable, IF MUX, rear panel	8120-8483

Test Set Diagrams and Graphics

Figure 27 Test Set Diagram





Figure 28

RF and LO Block Diagram<sup>1</sup>



1. Refer to Figure 27 on page 38 for IF paths.

Figure 29 Signal Routing 2-Port




Figure 30 Top View






Figure 31 Sloped Attn. Cable Assembly




Figure 32 Top Front View







Figure 33

Bottom View



## Theory of Operation

### Functional Block and Assembly Information

The N5261AH60 routes PNA-X LO and RF signals to a millimeter-wave module. This allows the PNA to up-convert for a millimeter-wave source and down-convert a received millimeter-wave frequency to an IF frequency of 8.3 MHz. It also provides the DC power for the millimeter-wave module. The following components are used in the N5261. Refer to the block diagrams, **Figure 27** through **Figure 29** beginning on **page 38**.

#### **Test Set Control Board (N5261-60006)**

The Test Set Control board (N5261-60006) is a surface mount, printed circuit assembly (PCA) that provides a connection to the power supply and the PNA Test Set I/O. The PNA sends address and data commands which are read by the test set controller for selecting the switch paths of the RF and IF switch paths. The front panel "Active" and port LEDs are only on when the PNA has addressed the N5261H60 Millimeter Head Controller. The rear panel fan is on when the Controller board supplies are operational.

#### **Interface Board (N5261-60101)**

The Interface board is installed on top of the test set controller board. It provides switch drive signals and voltage for the solid-state switch that select RF Output to one of the front panel mm-module RF Outputs ports. The board also provides DC voltage and a CPLD programmed device that enables N5261AH60 Millimeter Head Controller operation.

#### **LED Board (N5261-60005)**

Two LED board assemblies are mounted to the front panel. The top LED board indicates the Source Path (amber/yellow color), or Receiver Path (green colored) shown as "S" and "R" for each port. The bottom LED board indicates the DC power is on (green). If an over-current condition occurs on the millimeter-wave module the LED will be amber/yellow, which could be a result of a shorted interface cable or damaged millimeter-wave module. The LED board assemblies are connected to the test set controller board by ribbon cables.

#### **DC Power Board (N5261-60102)**

The DC Power board provides connection to the power supply and self recovering fuses for each millimeter-wave module supply (+12 volt) on the front panel. The fuses are reset when the N5261AH60 is turned off.

### **Power Supply (0950-4729)**

The power supply (0950-4729) converts the AC line voltages to DC. This is an automatic line voltage selecting power supply. The AC line voltage (100 to 240 V @ 50/60 Hz) is provided from the line module located on the rear panel.

### **Isolators (0955-1595)**

Isolators are installed in the LO Output RF path for each port. These 10 watt isolators maximizes the LO power input to the millimeter-wave modules over a frequency range of 8 to 19 GHz.

### **LO and RF Preamplifier (5087-7750)**

A preamplifier installed in the LO and RF Input path provides a higher RF power level required for the LO and RF Amp.

### **RF and LO ALC Amplifier (5087-7771)**

The Mod/Amp has adjustable gain that provides ALC leveling for the front panel RF and LO Output signals. Adjustments are made on each Mod/Amp to set the output power (R3). The output of each amplifier is connected to a coupler, and with a detector for ALC, the mod/amps provide RF and LO leveling. Each Mod Amp has a Bias board (N5261-60103) installed on top that provides the power supply connection and circuitry for setting the gain of the amplifier (R3) and an SMB Input to the modulator.

### **Attenuator, 7 dB (0955-0242)**

This attenuator is used at the LO Input port to provide a good match and set the LO Input level for the preamplifier.

### **Attenuator, 6 dB (0955-0243)**

The 6 dB attenuators are used to attenuate the RF and LO power to the ALC detector to set the RF level for linear operation.

### **Attenuator, 3 dB (0955-0246)**

The 3 dB attenuators are used in the SRC 1 Input Mod/Amp Inputs to provide a good match and ensure it does not exceed +15 dBm.

### **Coupler (0955-0148)**

Directional couplers with 10 dB coupling factor are used for ALC feedback for RF and LO Output leveling.

### **Slope Attenuator Cable Assy (N5262-20033)**

A slope pad is installed on the leveling coupler of the RF Out path to compensate for the RF switch loss at higher frequencies.

### **Power Divider (N5262-80003)**

A four-way power divider provides each Port LO Output from the LO amplifier with approximately 7.2 dB attenuation for each LO Out. Two 50 ohm terminators are installed on the unused N5261A divider paths. If a system is configured with a unused port (a 1-Port reflection system for example) the front panel LO Output ports are to be terminated with a 50 ohm load (1810-0118). This keeps the power divider balanced and prevents an “open” reflective signal from entering the power divider and mixing with the RF signal.

### **RF Switch (5087-7733)**

A solid-state switch with internal 50 ohm termination is used for switching the RF Output path for Ports 1 and 2. This switch is controlled by the test set interface boards.

## Troubleshooting the Test Set

### Test Set Operation Check

This chapter, “Troubleshooting the Test Set,” contains service information for a standalone N5261AH60 controller test set.

The following procedure verifies the test set without system components.

### Troubleshooting, DC Level

For assistance refer to **“Keysight Support, Services, and Assistance” on page 70.**

If the test set is not operating properly, use the following procedures to aid in isolating the problem. Refer to the **“Test Set Diagrams and Graphics”** starting on **page 38.**

### Power Supply and Fans


1. Verify the front panel Standby switch is operational.
  - a. The rear panel fan and front panel DC Power LEDs should be on when the Standby switch is in the on position.
2. AC Line voltage checks.
  - a. Ensure the proper AC line voltage is present at the instrument line cord.
  - b. Remove the AC power cord from the instrument. Check the instrument AC line module 5 amp fuse, as shown in **Figure 4 on page 10.**
  - c. Remove the instrument bottom cover. Near the rear panel are two fuse holders, remove the 8 amp fuses and verify that they are operational. See **Figure 33 on page 43.**

### 3. External DC Power checks.

- a. Verify DC voltage levels on each of the front panel DC power connectors. Pins 1 & 3 = +12 V ( $\pm 0.8$  V), Pins 4 & 6 = ground

Figure 37

Front Panel MM Module DC Power Connector



- b. If no DC voltages are present at the front panel, remove the top and bottom covers.
  - c. Inspect the DC Power board (N5261-60002) connections.
  - d. Measure the +12 Vdc (red wires) on the DC Power board. If the +12 Vdc is present, replace the DC power cable from the front panel (N5652-60001). If the +12 Vdc is not present go to step e.
  - e. Verify that the supply LED indicators on the Test Set Control Board (N5261-60006) are on. If they are, replace the DC Power Board (N5261-60002). Refer to [Figure 30 on page 41](#). If the LEDs not off, refer to [“Troubleshooting the Test Set” on page 47](#).
- ### 4. Internal DC Power checks.
- a. Set the Standby switch to the Standby position.
  - b. Remove the top cover and connect the AC power cord. No fans or DC power LEDs should be on.
  - c. Set the Power Switch to the on position. Both rear panel and internal power supply fans should be operational; the front panel DC Power LEDs should be on. If the DC Power LEDs are off, measure the +12 Vdc pins on the front panel connectors. Refer to [“Test Set I/O Commands” on page 53](#).
  - d. Ensure the Controller board DC Supply indicator LEDs are on. If not, suspect power supply (0950-4727) or front panel Standby switch. Using a DVM measure the power supply terminal connections. Refer to the label on the power supply for voltages on the terminal screws.

- e. If the voltages on the power supply are correct, lift the Interface board. If the Controller board DC Supply LEDs are on, disconnect switches (J60 & J61) and amp cables (J10, 11, 12 and 14) to the Interface board and re-install the board. If the indicator LEDs are on, suspect the switch or amplifier.
- f. If the fan is not working and all Controller board DC Supply LEDs are on, replace fan.

### Over Current LEDs are On (amber)

1. Remove all millimeter module connections from the front panel. If the over current LEDs are off, suspect the millimeter module or the DC Power Bias cable. If the LEDs are on continue with step 2.
2. Verify that the +12 Vdc on the front panel DC Power connectors is not shorted to ground. Refer to **“Service Information” on page 37**. If it is shorted to ground, replace the front panel DC Power cable (N5652-60001) or the DC Power Board (N5261-60002). If it is not shorted to ground continue to step 3.
3. Move the DC Power board ribbon cable to the Source/Receiver Status LED board, if the over current LEDs are still on replace the DC Power Board (N5261-60002). If the LEDs are off replace the DC Power LED Board (N5261-60005).

### Front Panel Active and Port Status LED

Front Panel Receiver and Source Indicator LED check. If the LED indicators are not operating, verify the ribbon cable connection and ensure the rear panel test set interface cable is connected securely. Proceed to the next section for further troubleshooting before replacing the front panel board.

1. Connect the Test Set I/O cable (N4011-21002) from the analyzer to the test set.
2. Using the I/O command values, confirm the correct address and data values are used, refer to **Table 13 on page 58**.
3. Front Panel R and S indicator LED Check.
  - a. Verify that at least two of the Controller Status LEDs are on.
  - b. If none are on, remove the Switch Driver board and recheck. If still no indication, replace the Controller board.
  - c. If the Controller Status LEDs and the front panel Active LED is on, suspect the front panel LED board or the ribbon cable. Replace as needed. You can move the ribbon cable connection to the DC power board and verify if the problem is the Port Status LED board, or use the ribbon cable from the DC power board to verify if the problem is the ribbon cable.

## Troubleshooting, RF Level

If the test ports are not switching, or fail the **“Test Set Operation Check” on page 47**, the following procedures can be used to verify the failure. The procedures assume power supplies, controller board and front panel LEDs are working. Suspect the switch Interface board, ribbon cable connection or RF switch.

1. Inspect the ribbon cable connections from the RF switches to the Switch Interface board (N5261-60001).
2. Start by measuring the power at SRC1 continuing through the RF Amp, Directional Coupler, and Solid State Switch. If you find incorrect power levels and suspect a component has failed, verify the DC voltages. If you suspect the RF Amp (5086-7771), substitute the LO Amp (5086-7771) to verify the failure. The RF Amp uses a leveling circuit with directional coupler and detector that also can be checked before replacing the RF Amp. You may also substitute the Directional Coupler and Detector from the LO Amp section. If the RF Amp is replaced a gain calibration must be preformed.
3. If you suspect the Solid State Switch (SW1) confirm that one of its two LEDs toggle on/off when you send a Test Set I/O command. Refer to **“Measure RF OUT (Gain and Power)” on page 56** and **Table 13 on page 58**.
4. Substitute a known good switch, or connect a known good wire-harness cable, and retest. Replace if necessary.



## LO Out Failure

1. If one of the LO ports are working, suspect the Power Divider.
2. If none of the port are working, start by measuring the power at LO IN, continuing through the pre-amplifier, LO Amp, Directional Coupler and Power Divider. If you find incorrect power levels and suspect a component has failed verify the DC voltages. Replace the failed component.

If you suspect the LO Amp (5086-7771) substitute the RF Amp (5086-7771) to verify the failure. The LO Amp uses a leveling circuit with directional coupler and detector that also can be checked before replacing the LO Amp. You may also substitute the Directional Coupler and Detector from the RF Amp section.

## REF IF or Test IF Failure

Verify that the front panel Port 1 & 2 REF and IF coax cables are properly connected to the rear panel (A, B, C, and D) and insertion loss is  $\leq .25$  dB. Replace the coax cable if defective. Refer to **Figure 27 on page 38**.

## Test Set Operation Check

This chapter contains service information for a standalone N5261AH60 controller test set. The following procedure verifies the test set without mm-module components.

### Required Equipment Preparation

- PNA, PNA-L, PNA-X capable of 20 GHz. (The required Test Set I/O interface is included with all models). The PNA, PNA-L or PNA-X will be referred to as the PNA throughout this procedure.
- Two RF flexible cables with 3.5 mm male connectors (5062-6696 or equivalent). One cable must be long enough to comfortably connect between the PNA and the rear panel of the test set.
- Three SMA or 3.5 mm adapters (female to female)
- Voltmeter
- Power sensor and compatible power meter. The power sensor must be capable of measuring from  $-10$  dBm to  $+15$  dBm at a frequency of 8 GHz. A E4413A power sensor may be used.

### Power Sensor and Power Meter Preparation

The power sensor and power meter must be prepared to make measurements at 8 GHz. This may include calibrating the power sensor with the meter and entering a calibration factor for 8 GHz.

### PNA and Test Set Preparation

1. Connect the Test Set I/O cable from the PNA to the test set.
2. Turn on the PNA and the test set.
3. The PNA must be in “Standard PNA” mode. To check the mode, select Utility > System > Configure > Millimeter Module Configuration. The Millimeter Module Configuration window will be displayed. Next, select [Module Config]. Click on “Standard PNA” in the list of Available Configuration(s) then click OK.

## PNA Normalization Calibration

This procedure prepares the PNA to for path loss measurements.

1. Select [Preset] on PNA.
2. Set the Start and Stop frequencies (8 - 20 GHz).
3. Set the power output level to -10 dBm.
4. Set to measure S12.
5. Connect an RF cable to PNA Port 1. Connect a second RF cable to PNA Port 2.
6. Connect the two RF cables together with an adapter.
7. Normalize the trace, Select [Memory] > Normalize or select [Data] > Normalize. You will see a flat line at 0 dB.
8. Remove the adapter between the RF cables.

## Test Set I/O Commands

The [Service Information](#) requires the use of Test Set I/O commands. These commands are issued by the PNA.

### Controlling the Test Set using Test Set I/O Commands

A Test Set I/O command may be used when the PNA is connected to the Test Set via the Test Set I/O cable. Commands may control the test set or read data from the test set. The GPIB command processor utility, in the network analyzer software, is used to communicate over the Test Set I/O connector.

It is recommended to use a USB keyboard with a PNA when using the command processor.

### Using the GPIB command processor

- Select Utility > System > Configure > SICL/GPIB/SCPI, then select SCPI Command Processor Console. In the dialog box type the command text and then Enter on the keyboard to execute the command.
- A write command is of the form: cont:ext:test:data n,m "n" is the address and "m" is the data to be written. Typically these values may be any number up to three digits in length.
- A read command is of the form: cont:ext:test:data? n "n" is the address. A read command returns a single numeric value.
- Pressing F3 on the keyboard will recall a previously sent command line for editing.
- As a check, send the command: cont:ext:test:data? 0 <enter>. A 61 should be returned, depending on the model number of the test set.
- An active command processor window may be minimized via the "\_" in the upper right hand corner of the window. To access a minimized command processor window, minimize the PNA window. Select File > Minimize Application.

## Test Set I/O Command List

The following commands are available for controlling/reading the test set. The step-by-step commands in the [Service Information](#) procedure require the use of these commands. The user is required to select the appropriate command, depending on the port or function under test.

Read commands involve a single number, an address. Write commands involve two numbers, address and data.

Table 12 I/O Commands

0	address for reading two digits from model number of the test set (+61)
32,0	turns on ALC for both SRC1 (Port 1 and 2)
32,1	turns off ALC for SRC1 (Port 1 and 2)
0,1	SRC1 IN to Port 1 RF OUT
0,2	SRC1 IN to Port 2 RF OUT
64,17	turns on Receiver and Source LED's for Port 1 (Port 2 LEDs off)
64,34	turns on Receiver and Source LED's for Port 2 (Port 1 LEDs off)

### NOTE

The amber Source LEDs are controlled separately from the switch for the RF OUT paths. Receiver LEDs are always ON since they are not switched.

## Measure LO OUT (Gain and Power)


Prepare the PNA to measure S12 with a normalization calibration. Refer to **“PNA Normalization Calibration” on page 53**. Use a frequency range of 8 to 20 GHz and a power level of  $-10$  dBm. The cable on PNA Port 2 must be long enough to reach the rear panel of the test set.

1. Connect the PNA Port 2 cable to the rear panel LO IN.
2. Connect PNA Port 1 to Port 1 LO OUT on the test set. Verify the LO Output gain is approximately 20 dB. The trace should be within 10 dB of “flat” and have no significant holes or discontinuities. Refer to **Figure 34 below**.
3. Move PNA Port 2 cable to Port 2 LO OUT and confirm a similar result.
4. Select [Sweep] > Sweep Type > CW Time. Set the sweep time to 10 seconds.
5. Disconnect the cable from LO IN and measure the power at the end of the cable using a power sensor. The power should be in the  $-8$  to  $-12$  dBm range. Adjust the PNA power output level if needed.

Reconnect the cable to LO IN.

6. Measure the Port 1 LO OUT power using a power meter. The power should be  $+12$  dBm ( $\pm 2$  dB). Measure LO OUT for the other ports on the test set.

**Figure 34** LO Output Gain with  $-10$  dB Input



## Measure RF OUT (Gain and Power)

The following procedure measures gain.


Prepare the PNA to measure S12 with a normalization calibration. Refer to **“PNA Normalization Calibration” on page 53** with a frequency range of 8 to 20 GHz and a power level of 2 dBm.

1. Connect the PNA Port 2 cable to rear panel SCR 1 IN.
2. Connect the Panel PNA Port 1 cable to front panel Port 1 RF OUT.
3. Issue the Test Set I/O commands 0,1 (enable ALC and output to Port 1). Verify that the gain is greater than 10 dB at all frequencies and there are no holes or significant discontinuities in the trace. Refer to **Figure 35 on page 57**.
4. Issue the Test Set I/O command 32,1 (disable ALC on Port 1). Verify that the gain increases at all frequencies and that there are no holes in the trace. Refer to **Figure 36 on page 57**.
5. Move front panel cable connection to Port 2 RF Out.
6. Repeat Step 3 and 4, but change issue commands to 32,0 and 0.2 for Step 3.
7. Issue command 32.0 in preparation for the power check.


The following procedure measures the power output level.

1. Select [Sweep] > Sweep Type > CW Time. Set the sweep time to 10 seconds.
2. Connect PNA Port 2 cable to a Power Sensor.
3. Set the PNA power output level to get a reading at -6 ( $\pm 1$  dBm).
4. Connect the PNA Port 2 cable to SRC1 RF IN on the rear panel.
5. Issue the Test Set I/O commands 32,0 and 0,1 (enable ALC and output to Port 1).
6. Measure the Port 1 RF OUT power using the power sensor. Confirm that RF OUT is +12.5 dBm ( $\pm 1.5$  dB).
7. Move the Power Sensor to Port 2 RF OUT.
8. Issue the Test Set I/O command 0,2. Confirm the RF OUT is +12.5 dBm ( $\pm 1.5$  dB).

**Figure 35** RF Output Gain with +2 dBm ALC On



**Figure 36** RF Output Gain with +2 dBm ALC Off



## Measuring Test IF and REF IF Path Loss on the N5261AH60

**NOTE**

The IF paths for the test set are not switched. See [Figure 27 on page 38](#).

The cable connected to PNA Port 1 must be long enough to reach the rear panel of the test set.

1. Prepare the PNA to measure S12 with a normalization calibration. Select a frequency range of 8 to 9 MHz and a power level of  $-20$  dBm. See [“PNA Normalization Calibration” on page 53](#).
2. Measure the IF signal paths listed below. Connect PNA Port 2 cable to the test set front panel and the PNA Port 1 cable to the rear panel IF OUT. Maximum loss should be  $< 3$  dB.
  - Port 1 TEST IF to A (rear panel)
  - Port 1 REF IF to C (rear panel)
  - Port 2 TEST IF to B (rear panel)
  - Port 2 REF IF to D (rear panel)

**Table 13** IF Path Measurement

From: TEST IF Front Panel	To: N5261A Rear Panel IF OUT	Max Path Loss (dB)
Port 1 TEST IF	A	0.25
Port 2 TEST IF	B	0.25
Port 1 REF IF	C (R1)	0.25
Port 2 REF IF	D (R2)	0.25



## Test and Adjustment Procedures

The “**Test Set Operation Check**” on [page 47](#) should be performed whenever any active electronic part is replaced in the test set.

Additional procedures are required when certain components are replaced. **Table 14** indicates when additional procedures are required. The additional procedures depend on the location of the replaced component.

The additional procedures are indicated as A and B in **Table 14**.

**Table 14 Additional Required Procedures for Assemblies Replaced**

Description of the Replaced Component	Keysight Part Number	Location: Ports 1 & 2 RF Section <sup>1</sup>	Location: LO Section	General Location
Millimeter Head Interface Bd	N5261-60101			
Test Set Controller Bd	N5261-60006			
RF/LO Bias/ALC Bd	N5261-60103	A	B	
Preamplifier Bias Bd	N5261-60104		B	
RF 4-way Divider	N5262-80003		B	
RF Detector	3333-80021	A	B	
Coax Cable, Sloped Attenuator	N5262-20033	A		
Preamplifier	5087-7750		B	
RF/LO Amplifier	5087-7771	A	B	
RF Directional Coupler	0955-0148	A	B	
RF Switch, SPDT Solid State	5087-7733	A		

1. Refer to [Figure 27](#) thru [Figure 29](#) and [Figure 31](#) thru [Figure 33](#) to determine part location.

The procedures referenced above may be found on the following pages. Many of the steps require familiarity with the “**Test Set Operation Check**” section beginning on [page 52](#).

## Adjust RF and LO ALC Levels

### Background

When a component is changed in an RF or LO signal path, it is often necessary to adjust the ALC level for the path. See [Table 14 on page 59](#) for required adjustments when a part is replaced.

### PNA and Power Sensor Preparation

A power sensor and power meter must be prepared to make measurements at 8 GHz. This may include calibrating the power sensor with the meter.

1. Set the PNA to measure S12.
2. Set for CW sweep at 8 GHz.
3. Set the sweep time to 5 seconds.
4. Set the power to -8 dBm.

### ALC level for RF Port 1 (Procedure A)


1. Prepare the PNA and Power Sensor as described above.
2. Connect PNA Rear Panel RF Port to Test Set SRC 1 IN.
3. Connect the power sensor to Test Set front panel Port 1 RF OUT.
4. Issue the Test Set I/O commands: 32,0 and 0,1 (ALC on and Port 1 RF OUT).
5. Identify the “Port 1 & 2 ALC RF Amp”, see [Figure 30 on page 41](#). Identify R7 and R3, see [Figure 38 on page 61](#).
6. Adjust R7: turn full CW (may require up to 30 turns) then 5 turns CCW.
7. Adjust R3: adjust for a reading on the power meter of 12.5 dB ( $\pm 0.1$  dBm).
8. Perform “[Measure RF OUT \(Gain and Power\)](#)” check found on [page 56](#).

### ALC level for LO (Procedure B)

1. Prepare the PNA and Power Sensor as described on [page 60](#).
2. Connect PNA Port 2 to LO IN on the rear panel of the test set.
3. Connect the power sensor to Port 1 LO OUT.
4. Identify the “LO ALC Amp,” R7 and R3, see [Figure 30](#) and [Figure 38](#).
5. Adjust R7: turn full CW (may require up to 30 turns) then 5 turns CCW.
6. Adjust R3: adjust for a reading on the power meter of 12 dB ( $\pm 0.1$  dBm).
7. Perform “[Measure LO Out \(Gain and Power\)](#)” check found on [page 55](#).

Figure 38

### Mod Amp Adjustments



## Safety and Information

### Introduction

Review this product and related documentation to familiarize yourself with safety markings and instructions before you operate the instrument.

This product has been designed and tested in accordance with accepted industry standards, and has been supplied in a safe condition. The documentation contains information and warnings that must be followed by the user to ensure safe operation and to maintain the product in a safe condition.

### Safety Earth Ground

#### **WARNING**

This is a Safety Class I Product (provided with a protective earthing ground incorporated in the power cord). The mains plug shall only be inserted in a socket outlet provided with a protective earth contact. Any interruption of the protective conductor inside or outside of the product is likely to make the product dangerous. Intentional interruption is prohibited.

---

#### **CAUTION**

Always use the three prong AC power cord supplied with this product. Failure to ensure adequate earth grounding by not using this cord may cause product damage and the risk of electrical shock.

---

### Declaration of Conformity

Declarations of Conformity for this product and for other Keysight products may be downloaded from the Keysight Regulatory Website. Click on "Declarations of Conformity" and enter your product number to find the latest Declaration of Conformity statement. <http://regulations.about.keysight.com>

### Statement of Compliance

This instrument has been designed and tested in accordance with CAN/CSA 22.2 No. 61010-1-04, UL Std No. 61010-1 (2nd Edition).

## Before Applying Power

Verify that the premises electrical supply is within the range of the instrument. The instrument has an autoranging power supply.

### WARNING

If this product is not used as specified, the protection provided by the equipment could be impaired. This product must be used in a normal condition (in which all means for protection are intact) only.

---

### CAUTION

The Mains wiring and connectors shall be compatible with the connector used in the premise electrical system. Failure, to ensure adequate earth grounding by not using the correct components may cause product damage, and serious injury.

---

### CAUTION

Always use the three prong AC power cord supplied with this product. Failure to ensure adequate earth grounding by not using this cord may cause product damage and the risk of electrical shock.

---

### CAUTION

This product is designed for use in Installation Category II and Pollution Degree.

---

### CAUTION

Before switching on this instrument, make sure the supply voltage is in the specified range.

---

### CAUTION

Verify that the premise electrical voltage supply is within the range specified on the instrument.

---

### CAUTION

Ventilation Requirements: When installing the instrument in a cabinet, the convection into and out of the instrument must not be restricted. The ambient temperature (outside the cabinet) must be less than the maximum operating temperature of the instrument by 4 °C for every 100 watts dissipated in the cabinet. If the total power dissipated in the cabinet is greater than 800 watts, forced convection must be used.

---

**WARNING**

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended. Discard used batteries according to manufacturer's instructions.

---

**WARNING**

For continued protection against fire hazard replace line fuse only with same type and rating. The use of other fuses or material is prohibited.

---

**WARNING**

These servicing instructions are for use by qualified personnel only. To avoid electrical shock, do not perform any servicing unless you are qualified to do so.

---

**WARNING**

The opening of covers or removal of parts is likely to expose the user to dangerous voltages. Disconnect the instrument from all voltage sources before opening.

---

**WARNING**

No operator serviceable parts inside. Refer servicing to qualified personnel. To prevent electrical shock, do not remove covers.

---

**WARNING**

The detachable power cord is the instrument disconnecting device. It disconnects the mains circuits from the mains supply before other parts of the instrument. The front panel switch is only a standby switch and is not a LINE switch (disconnecting device).

---

## Connector Care and Cleaning Precautions

Remove the power cord to the instrument. To clean the connectors use alcohol in a well ventilated area. Allow all residual alcohol moisture to evaporate, and fumes to dissipate prior to energizing the instrument.

**WARNING**

To prevent electrical shock, disconnect the Keysight N5261A or N5262A from mains electrical supply before cleaning. Use a dry cloth or one slightly dampened with water to clean the external case parts. Do not attempt to clean internally.

---

**WARNING**
















If flammable cleaning materials are used, the material shall not be stored, or left open in the area of the equipment. Adequate ventilation shall be assured to prevent the combustion of fumes, or vapors.

---

## Regulatory Information



This section contains information that is required by various government regulatory agencies.

## Instrument Markings

	The instruction documentation symbol. The product is marked with this symbol when it is necessary for the user to refer to the instructions in the documentation.
	The AC symbol indicates the required nature of the line module input power.
	This symbol indicates separate collection for electrical and electronic equipment, mandated under EU law as of August 13, 2005. All electric and electronic equipment are required to be separated from normal waste for disposal (Reference WEEE Directive, 2002/96/EC).
	This symbol indicates that the power line switch is ON.
	This symbol indicates that the power line switch is in the STANDBY position.
	This symbol indicates that the power line switch is in the OFF position.
	This symbol is used to identify a terminal which is internally connected to the product frame or chassis.
	The CE mark is a registered trademark of the European Community. (If accompanied by a year, it is when the design was proven.)
	The CSA mark is a registered trademark of the CSA International.
	This mark designates the product is an Industrial Scientific and Medical Group 1 Class A product (reference CISPR 11, Clause 5)
	This is a marking to indicate product compliance with the Canadian Interference-Causing Equipment Standard (ICES-001).
	Direct Current.
	The instrument has been designed to meet the requirements of IP 2 0 for ingress and operational environment.
	The RCM mark is a registered trademark of the Australian Communications and Media Authority
	Indicates the time period during which no hazardous or toxic substance elements are expected to leak or deteriorate during normal use. Forty years is the expected useful life of the product.



## Regulatory Information

	This symbol on all primary and secondary packaging indicates compliance to China standard GB 18455-2001.
	South Korean Certification (KC) mark; includes the marking's identifier code which follows the format: MSIP-REM-YYY- <u>ZZZZZZZZZZZZZZ</u> .

## Battery Collection

Do not throw batteries away but collect as small chemical waste, or in accordance with your country's requirements. You may return the battery to Keysight Technologies for disposal. Refer to **“Contacting Keysight” on page 70** for assistance.

## Electrical Safety Compliance

### SAFETY

Complies with European Low Voltage Directive 2014/35/EU

- IEC/EN 61010-1:2010, 3<sup>rd</sup> Edition
- Canada: CSA C22.2 No. 61010-1-12
- USA: UL std no. 61010-1, 3<sup>rd</sup> Edition
- Acoustic statement (European Machinery Directive 2022/42/EC, 1.7.4.2U)  
Accoustical noise emission  
LpA < 70 dB  
Operator position  
Normal operation mode  
Per ISO 7779

## EMI and EMC Compliance

### EMC

Complies with European EMC Directive 2014/30/EU

- IIEC 61326-1:2012/EN 61326-1:2013
- CISPR Pub 11 Group 1, class A
- AS/NZS CISPR 11:2011
- ICES/NMB-001  
This ISM device complies with Canadian ICES-001.  
Cet appareil ISM est conforme a la norme NMB du Canada.
- South Korean Class A EMC declaration: This equipment is Class A suitable for professional use and is for use in electromagnetic environments outside of the home.

A 급 기기 ( 업무용 방송통신기자재 ) 이 기기는 업무용 ( A 급 ) 전자파적합기  
기로서 관 매자 또는 사용자는 이 점을 주 의하시기 바라 며 , 가정외의 지역  
에서 사용하는 것을 목적으 로 합니다 .

## Electrostatic Discharge Protection

Electrostatic discharge (ESD) can damage or destroy electronic components. The product is shipped in materials that prevent damage from static, and should only be removed from the packaging in an anti-static area ensuring that the correct anti-static precautions are taken.

Two types of ESD protection are listed below. Purchase acceptable ESD accessories from your local supplier.

- Conductive table-mat and wrist-strap combination
- Conductive floor-mat and heel-strap combination

Both types, when used together, provide a significant level of ESD protection. To ensure user safety, static-safe accessories must provide at least 1 M $\Omega$  of isolation from ground.

### **WARNING**

**These techniques for a static-safe work station should not be used when working on circuitry with a voltage potential greater than 500 volts.**

---

## Keysight Support, Services, and Assistance

### Service and Support Options

There are many other repair and calibration options available from the Keysight Technologies support organization. These options cover a range of service agreements with varying response times. Contact Keysight for additional information on available service agreements for this product.

### Contacting Keysight

Assistance with test and measurement needs, and information on finding a local Keysight office are available on the Internet at:

**<http://www.keysight.com/find/assist>**

You can also purchase accessories or documentation items on the Internet at:

**<http://www.keysight.com/find>**

If you do not have access to the Internet, contact your field engineer.

#### NOTE

In any correspondence or telephone conversation, refer to the Keysight product by its model number and full serial number. With this information, the Keysight representative can determine the warranty status of your unit.

---

### Shipping Your Product to Keysight for Service or Repair

#### IMPORTANT

Keysight Technologies reserves the right to reformat or replace the internal hard disk drive in your analyzer as part of its repair. This will erase all user information stored on the hard disk. It is imperative, therefore, that you make a backup copy of your critical test data located on the analyzer's hard disk before shipping it to Keysight for repair.

---

If you wish to send your instrument to Keysight Technologies for service or repair:

- Include a complete description of the service requested or of the failure and a description of any failed test and any error message.
- Remove and retain the front handles and all rack mount hardware. The analyzer should be sent to Keysight in the same configuration as it was originally shipped.
- Remove and retain the front handles and all rack mount hardware. The analyzer should be sent to Keysight in the same configuration as it was originally shipped.
- Contact Keysight for instructions on where to ship your analyzer.



This information is subject to change without notice.  
© Keysight Technologies 2011, 2014-2016  
Edition 1 July 2016  
Supersedes: May 2016



N5261-90001



[www.keysight.com](http://www.keysight.com)