

Tips on Input Configuration

Suggestions on how to configure the inputs are specified by measurement function, Frequency or Time Interval A→B.

Frequency

1. On the Function menu, select the channel you will be using.
2. Press the CONFIGURE INPUT softkey.

Preset configures the Input menu parameters to default values. Review these settings for your application as described below.

3. Select the channel you want to configure.

The voltage threshold will be automatically set by the Autoscale routine to 50% of peak-to-peak value.

4. Review the settings for coupling, impedance, and hysteresis.

Hysteresis can be left at Min for most applications. Adjust if your signal is noisy.