

Frequency Modulation Start-up

1. Set the Signal Source to **On** and select **Frequency Modulation**.
2. Press the **Preset** key.
3. Press the **Autoscale** key.

Your display should look similar to the one shown below. Now start exploring the Analyzer. If you would like to follow some steps to analyze this signal, go to page 2-5.

The FM example in chapter 2 shows how to automatically measure the following parameters of the signal: carrier frequency, modulation rate, and peak-to-peak deviation.

