

VCO Step Response Start-up

1. Set the Signal Source to **On** and select **VCO Step Response**.
2. Press the **Preset** key.
3. Press the **Autoscale** key.

Your display should look similar to the one shown below. Now start exploring the Analyzer. If you would like to follow some steps to analyze this signal, go to page 2-9.

The VCO Step example in chapter 2 shows how to adjust the Analyzer to see more detail on the VCO step, use markers to measure the frequency before and after the step, and to measure overshoot and transition time.

